Shaw Environmental & Infrastructure, Inc.

13 British American Boulevard Latham, NY 12110-1405 518.783.1996 Fax 518.783.8397



SOIL VAPOR EXTRACTION OPERATION & MAINTENANCE MANUAL

NATIONAL HEATSET PRINTING FARMINGDALE, NY

SITE NUMBER 1-52-140

PREPARED FOR:

NEW YORK STATE DEPARTMENT OF ENVIRONMENTAL CONSERVATION BUREAU OF EASTERN REMEDIAL ACTION 625 BROADWAY ALBANY, NY 12233-7015

PREPARED BY:

SHAW ENVIRONMENTAL, INC. 13 BRITISH AMERICAN BOULEVARD LATHAM, NY 12110-1405

OCTOBER 2003

Prepared By:

Kina Skaarup

Project Engineer

Reviewed By:

Edward A. Weinberg, P.E. Senior Project Engineer

EXECUTIVE SUMMARY

The following is a description of the soil vapor extraction (SVE) pilot test system that has been installed at the former National Heatset Printing site on Adams Boulevard in Farmingdale, New York.

Shaw Environmental, Inc. (Shaw) has been retained to design, install and operate an SVE system to remove adsorbed-phase volatile organic compounds (VOCs) from the subsurface at the site. The adsorbed phase VOCs are assumed to be from residual contamination from the improper disposal of solvents used by National Heatset Printing.

SVE is a process for removing VOCs from the unsaturated soils by induced air flow. Removal is accomplished by direct volatilization. Additionally, induced air flow to the subsurface provides oxygen to microorganisms, which may promote biodegradation of VOCs. Generally, air flow is induced in the subsurface by applying vacuum to vertical wells or horizontal trenches.

One vertical well has been utilized on the subject property. A maximum flow rate of approximately 400 cfm of VOC vapors will be removed from the subsurface and will be treated using vapor phase activated carbon (VGAC) prior to discharge into the atmosphere.

TABLE OF CONTENTS:

1.0 INTRODUCTION / CERTIFICATION	1
 1.1 INTRODUCTION 1.2 PROFESSIONAL ENGINEER CERTIFICATION	1 2 3 3
2.0 SYSTEM DESCRIPTION	4
 2.1 GENERAL PROCESS EQUIPMENT OVERVIEW	4 7 10 11
3.0 SYSTEM STARTUP AND MONITORING PROCEDURE	
 3.1 PREREQUISITES TO STARTUP	12 13 13
4.0 EQUIPMENT MAINTENANCE AND TESTING	14
 4.1 PREVENTATIVE MAINTENANCE (PM) PROGRAM	14 14 15 15 15 16 16
	17
 5.1 BASELINE STARTUP MONITORING	17 18 18 18 19 19

Soil Vapor Extraction Operation and Maintenance Manual National Heatset Printing, Babylon, New York	iv October 1, 2003
5.4.5 Air Monitoring Results	21
6.0 REPORTING	22
7.0 HEALTH AND SAFETY	23
8.0 DISPOSAL/RESIDUALS MANAGEMENT	24
9.0 PROJECT CLOSURE	25

FIGURES:

- 1. Soil Vapor Extraction Pilot Test Location Map
- 2. Piping and Instrument Diagram
- 3. As-Built Soil Vapor Extraction System General Arrangement
- 4. Electrical One-Line Diagram and Control Schematic
- 5. Wellhead Construction Details

APPENDICES:

- A. Manufacturer's O&M Manuals
- B. Revenue Meter Installation and Instruction Manual
- C. Example Site Visit Form and Process Monitoring Form
- D. VelociCalc Plus Air Velocity Meter Model 8360 Operation and Service Manual
- E. Completed NYSDEC Air Permit Application
- F. PID Information Sheet
- G. Soil Sample Collection Procedure

1.0 INTRODUCTION / CERTIFICATION

1.1 Introduction

This manual discusses the installation, operation and maintenance of the soil vapor extraction (SVE) system at the National Heatset Printing Site in Farmingdale, New York. Shaw installed this system at the request and under the oversite of the New York State Department of Environmental Conservation (NYSDEC). The objective of this Operations and Maintenance Manual is to provide the operations personnel technical information on the equipment comprising the soil vapor extraction system with guidelines on how to operate and maintain it in safe, reliable conditions.

1.2 Professional Engineer Certification

I certify under the penalty of law that this Operation and Maintenance Manual was prepared in accordance with a system designed to assure that the information in this document was properly gathered and evaluated. The information and figures submitted in this manual are, to the best of my knowledge and belief, true, accurate, and complete.

SEAL OF NEW	Printed Name: Edward A. Weinberg
AT A WEINE OF	Signature: Edward A Wei
	Registration No. 075440 Lic. State <u>NY</u>
Courses and senter and	Signature Date: October 2, 2003

1.3 Site Background

The National Heatset Printing site is located at One Adams Boulevard in the Hamlet of East Farmingdale, Town of Babylon, Suffolk County (**Figure 1**). The site contains one multi-tenant

Soil Vapor Extraction Operation and Maintenance Manual National Heatset Printing, Babylon, New York

industrial building and is approximately 4.5 acres in size. The National Heatset Printing Company occupied a portion of the on-site building from July 1983 to April 1989. Their operations consisted of lithographic tri-color printing of newspaper and periodical advertisements and the manufacture of lithographic printing plates. National Heatset had been using organic solvents at the site since 1983. Inspections by the Suffolk County Department of Health Services (SCDHS) in 1983 and 1986 revealed the improper storage and discharge of waste materials.

The National Heatset Printing Company filed for bankruptcy in 1987. The SCDHS discovered that after filing for bankruptcy, National Heatset disposed of its chemical inventory by dumping the materials onto the soils and into a leaching pool located at the rear of the building on the northeast side of the property.

Investigations conducted by the SCDHS and the property owner's consultant revealed the presence of soil and groundwater quality impacts at and downgradient from the site. The contaminants identified consisted of volatile organic compounds, principally Tetrachloroethylene (PCE). The property was listed in the Registry as a Class 2 site in 1993.

1.4 Plant Design and Overall Operation

A Soil Vapor Extraction (SVE) system has been designed to remediate soil contamination existing at the site. The system was designed using the following criteria:

- Extraction of soil vapors using an SVE blower
- Operation of one vapor extraction well (2" riser/screen and 2" extraction line)
- Off-gas Treatment for vapors consisting of two 1,000-lbs granular activated carbon (GAC) units and an engineered 30-feet discharge stack
- All equipment, interconnecting piping and equipment controls mounted or installed within a vented explosion-proof container

Based on the well design flow rates and process losses (such as piping and valve restriction), the total capacity of the SVE blower is 200 Standard Cubic Feet per Minute (SCFM) @ 80 inches of Water Column (W.C.).

1.4.1 Soil Vapor Extraction

The soil vapor extraction system includes one vapor extraction well, monitoring Well F, which was an existing monitoring well, constructed of 2-inch schedule-40 PVC with 0.02 slotted screens and screened from approximately 10 to 30 feet below ground surface (bgs). The well was modified on April 20, 2002 to facilitate vapor extraction and groundwater monitoring. A 2-foot by 2-foot DOT rated roadbox was installed at grade to protect the well. Well modifications included being teed into 2-inch diameter PVC schedule 80 piping that conveys extracted vapor into the treatment equipment enclosure.

Inside the pilot test equipment enclosure, the 2-inch diameter SVE piping contains a ball valve to control the air flow and vacuum, as well as a sampling port for drawing air samples and conducting flow measurements. The 2-inch piping is connected to a vacuum blower designed to extract a maximum of 400 cfm of air flow from the soil vapor well. Vapors from the source area are extracted by applying vacuum via a blower system. A 10 Horsepower (Hp) regenerative blower develops a maximum vacuum of approximately 98" W.C. The system includes blower inlet and discharge silencers to reduce the noise level generated by system operation. The SVE equipment includes vacuum, temperature and pressure gauges. The blower, motor and other ancillary equipment and appurtenances are mounted inside the enclosure and all controls are integrated into a single control panel by the SVE equipment manufacturer. The control panel is mounted on the exterior of the enclosure. Please refer to Figure 2 for the piping and instrumentation details and Figure 3 for a plan view of the treatment enclosure.

Soil gas vapors from the vapor well are drawn through a moisture separator prior to the vacuum blower. Upon high level in the moisture separator, a float is activated, and the SVE system will automatically shut down. The moisture collected from the separator will be containerized and stored on-site prior to sampling and appropriate disposal as necessary.

1.4.2 Off-Discharge Air Treatment

Off-gas treatment system is comprised of two 1,000-lbs vapor-phase granular activated carbon (VGAC) units. The two filters are arranged in this series (lead/lag arrangement) to provide assurance that the discharge air will comply with the air permit discharge criteria.

The discharge stack, constructed of 4-inch Schedule-40 PVC pipe, is mounted along the exterior of the site building and is elevated to a height of approximately 30-feet above the ground surface.

As-built drawings showing the electrical details and well construction details are included as **Figures 4 and 5**.

2.0 SYSTEM DESCRIPTION

Please refer to the as-built drawings as a guide for the following SVE equipment component descriptions. Each major equipment is described by system specification, startup procedures, normal operation, shutdown procedures, preventative maintenance, repair procedures, spare parts and warrantees / guarantees.

2.1 General Process Equipment Overview

- One SVE well,
- Soil Vapor Extraction (SVE) Blower with instrumentation for extracting vapor from the extraction well,
- Two Vapor-Phase Carbon Vessels arranged in series (lead/lag) to treat the VOCs in the off-gas from the SVE blower,
- 30-foot high discharge stack,
- Instrumentation and controls,
- 20' x 8' x 8' enclosure to house the equipment.

2.2 Standard Operating Procedures (SOPs) By Major Equipment

2.2.1 SVE Equipment

The SVE system consists of one SVE well, one moisture separator and a blower with inlet and discharge silencers.

SVE system specifications are as follows:

<u>Blower</u>

AMETEK Rotron Model EN858
200 SCFM @ 80" W.C. – Vacuum
400 cfm
98" W.C.
120" W.C.

5

Motor	AMETEK Rotron, 10.0 HP, Explosion Proof
Electrical Service	230 VAC/3 phase/60 Hz
Temperature rating	120 °C or 248 °F
Materials of construction	Cast aluminum blower housing, cover, impeller and manifold; cast iron threaded flanges; Teflon lip seal

Moisture Separator

Manufacturer/Model	EnviroSupply & Service
Moisture separator size/holding capacity	240 gallons/approximately 120 gallons
Dimensions	38" dia. x 72" high
Materials of Construction	Carbon Steel

<u>Startup</u>

Prior to operating the blower for the first time, or after long-term shutdown, check the unit and the installation for the following prerequisites that should include:

- Verify that the inlet piping is free of debris.
- Recheck blower leveling, drive alignment and tightness of all mounting bolts.
- Verify that the power to the motor is available and that electrical overload devices are installed and workable and that the safety disconnect switch in the container is "ON".
- Open the dilution bleed valve in the in the inlet piping. "Bump" blower a few revolutions with driver to check that direction of rotation is correct, by turning the HOA switch to MANUAL at the control panel outside.

After verifying that the blower is ready for operation, follow the steps below to conduct trial run of the blower:

- Start the blower in MANUAL, let it accelerate to full speed, then shut off. Listen for knocking sounds, both with power on and as speed slows down.
- Operate blower for about 10 minutes unloaded (utilizing 100% dilution air, 50% extraction well air). Feel cylinder and head plate surfaces for development of spots too hot to touch that may be indicative of impeller "rubs". Be aware of any noticeable increase in vibration or noise.
- If all the conditions are met, the blower should be run under normal operating conditions for at least one hour as a final check.
- Gradually adjust the dilution air and extraction well valves to apply working pressure (vacuum).

- Check the vacuum on the inlet line with a good vacuum gauge or manometer to verify that vacuum ratings (98" W.C. (water column)) of the blower are not exceeded.
- Check temperature in inlet and discharge lines of the blower to verify that temperature ratings (120° C) of the blower are not exceeded.

Note: Use the Manual Switch for testing and maintenance checks on the blower. There are no process alarms or blower safeguards when the switch is in manual mode. See "normal operations". When operating in Manual mode the blower will operate until the Manual switch is turned to OFF.

Normal Operation and Controls Description

The SVE blower is designed to extract 200 scfm of air @ 80" W.C. The blower can be started either manually by turning the HOA switch to "Manual" position or automatically. When in "AUTO" position, operation of the blower is controlled by the high level switch installed in the moisture separator.

<u>Shutdown</u>

When in "AUTO" position, the SVE Blower system can be shut down by the following condition:

• Moisture separator liquid is at high-high level – high-high level switch is activated and automatically shuts down the SVE system.

The blower can be shut down manually by turning the HOA switch to "OFF" position.

Preventive Maintenance

- Periodically check operating conditions and verify that there are no drastic changes.
- If the blower capacity is too great for the vapor extraction air requirements, a small amount of ambient air may be sucked in as make-up air by using the dilution bleed air valve.
- Occasionally stop the blower and clean the temporary inlet protective screen.
- In accordance with the AMETEK Rotron service and parts manual, the SVE blower bearings will require replacement after 15,000 to 20,000 hours of run time (approximately two years of continuous use).

Repair Procedures and Spare Parts

Repair procedures and spare parts list for AMETEK Rotron Regenerative Blower are located in the AMETEK Instructions in **Appendix A-Section 1**.

Warranties/Guaranties

All AMETEK Rotron blowers are covered by a manufacturers' warranty for 18 months from date of shipment.

Contact Phone Number: (845) 246-3401

2.2.2 Off-Gas Equipment

SVE blower discharge is treated through two carbon filters prior to being discharged into the atmosphere. The two filters are arranged in lead-lag series to provide assurance that the off-gas will comply with the air permit discharge criteria. A completed NYSDEC Air Permit Application is attached in **Appendix E**.

Carbon Filter specifications are as follows:

Manufacturer/Model	EnviroSupply & Service, Model ESV1000
Air flow rate	400 scfm
Amount of carbon	1,000 lbs per vessel, 40 x 10 mesh GAC, virgin
Materials of Construction	Carbon steel with Polyamide Epoxy Resin internal coating
	and Epoxy Mastic external coating
Pressure Rating	15 psi (max)
Dimensions	48" dia. x 71" high

<u>Startup</u>

- Start introducing process air into carbon vessels.
- Check the following parameters during the startup to achieve the optimum performance:

- Air flow rate
- Air leaks
- Air temperature

Normal Operation – Controls Description

During normal operation the off-gas laden with organic compounds is treated in the vapor phase carbon vessels prior to discharge into the atmosphere. Monitoring of the carbon influent, mid and effluent air is performed during each monthly site visit. VOC concentrations observed at these locations assist in determining the carbon loading rate and in the scheduling of carbon change outs.

Shutdown

The carbon filters have no moving parts. The carbon system is shut down when the SVE system or blower shuts down. During shutdown periods, it may be necessary to drain condensate that may accumulate in the carbon vessels. Draining of the carbon vessels is performed by using the drain port located on each of the vessels. Accumulation of significant quantities of condensate in the carbon vessels is not anticipated because of the moisture separator that is located on the vacuum side of the SVE blower and the heat of compression of the blower operating at 80" W.C. Any condensate collected from the carbon vessels must be containerized on-site pending sampling and appropriate disposal as necessary.

Normal Operation – Carbon Change Out

Periodically the vapor-phase carbon needs to be changed. The frequency of the carbon changeout is determined by the influent VOC concentrations. The two carbon vessels are arranged in series (lead/lag arrangement). When the VOC concentrations in the off-gas from the lag carbon vessel indicate VOC breakthrough, (PID / drager tube field air monitoring concentrations greater than 10 ppm) the carbon in each vessel is to be replaced with fresh carbon.

Procedure and Safety Precautions for Carbon Change Out

The following steps may serve as a guideline for removing and replacing spent carbon from the VGAC units.

- Shut down SVE system. Lockout/Tagout the SVE system to prevent accidental restart.
- Don appropriate Personal Protective Equipment (PPE), including but not limited to Level C with air purifying respirator and organic vapor cartridges.
- Open drain ports on the bottom of each VGAC unit to remove any accumulated liquid. Place any collected liquid into a 55-gallon drum for storage pending disposal in accordance with State, Local and Federal regulations. Close drain ports before proceeding with carbon removal.
- Utilize a drum vacuum or other vacuum equipment to remove the spent carbon from each of the two 1,000-pound VGAC units and place into DOT approved containers for transport to a predetermined reactivation/disposal facility.
- Seal the shipping containers and label each container with appropriate hazardous waste and DOT shipping labels.
- Place 1,000 pounds of fresh granular activated carbon in each VGAC unit, close and seal each unit.
- Load shipping containers onto transport vehicle with appropriate licenses and permits for shipment to the regeneration/disposal facility.
- Remove lockout/tagout device from SVE system. Restart SVE system utilizing procedures listed in Section 2.2.1 and Section 3.2
- Remove PPE and store in a labeled accumulation drum on-site pending disposal in accordance with State, Local and Federal Regulations.

Preventive Maintenance

- Periodically inspect the inside of the vessel before filling with carbon to verify the integrity of the internal components.
- Depending on the inlet gas stream moisture content, periodical drainage of the condensate from the bottom of the carbon vessel is recommended. During this procedure, shut down the SVE blower before opening the drain valve to prevent any water splattering. After all the condensate is drained, close the drain valve and follow a normal restart of the SVE blower.

Troubleshooting

No troubleshooting other than the preventive maintenance items listed above is required for the carbon vessels.

Repair Information and Spare Parts

Refer to the EnviroSupply & Service O&M Manual for repair information and spare parts list.

Warranties/Guarantees

Standard one-year manufacturer's warranty from the date of certification or installation (9/18/02) applies.

Contact: John Slesinski (508) 553-2855.

2.2.3 Treatment Enclosure

The equipment associated with soil vapor extraction is housed in an enclosure (approx. dimensions: 20' long x 8' wide x 8' high) located adjacent to the north wall of the site building in accordance with local building and planning codes. The enclosure is equipped with explosion proof features such as lights, heater with thermostat, ventilation fan, blower and motors

The enclosure has one set of double doors and one personnel door. Appropriate safety signs, *Health and Safety Plan* (HASP), first aid kit, and fire extinguisher are maintained in prominent locations within the enclosure. Treated air is discharged from the carbon filter through a stack, which extends approximately 30' above grade elevation.

The control panel, panel board, the main disconnect switch, and a revenue meter have been installed outside the enclosure. The panel board, the main disconnect switch, and the Revenue Meter are located inside the former treatment room in the site building, while the control panel has been installed on the exterior of the enclosure.

Ventilation Fan specifications are as follows:

Manufacturer/Model	Cook model 201A17DB
Design Air Flow	160 cfm
Electrical Service	1/2 HP, 230 V/3 phase/60 Hz, explosion proof

The ventilation fan is rated for 1 cubic feet per minute for each square foot of solid floor area (160 cfm for 160 square feet).

<u>Heater Fan</u>

A thermostat controlled, explosion proof heater is located within the treatment enclosure.

Repair Procedures and Spare Parts

The manufacturer's cost sheet is located in **Appendix A- Section 6.0**.

Warranties/Guaranties

Standard one-year manufacturer's warranty from the date of certification or installation applies.

2.2.4 Electrical System

All instrumentation, motor controls, and lighting inside the treatment container are explosion proof. The control panel has been installed outside of the container inside a NEMA 4 enclosure. The main disconnect switch and revenue meter have been installed in the former treatment room. The revenue meter installation and instruction manual is presented as **Appendix B**. The power feed to the SVE enclosure is from a new 200A, 3 phase, 230 volt disconnect switch connected from the existing control panel for the former treatment system. See **Figure 4**.

3.1 Prerequisites to Startup

The following steps must be followed prior to startup:

- All the equipment must be tested prior to startup according to the manufacturer's instructions.
- The SVE well, if not preset, must be partially opened.
- All control panels and motors must be connected to power.
- All HOA switches in AUTO position.

3.2 Normal Startup

- Initially, the air filter dilution valve for the extraction blower will be opened.
- The vacuum blower will be started. The only air entering the system will be through the dilution valve. Differential vacuum across the SVE blower, moisture separator, and temperature after the blower will be monitored and recorded on a Process Monitoring Form.
- With the dilution valve open, the extraction well flow control valve will be slowly opened until the extraction wellhead vacuum reads a maximum of 15 in. H₂O. The vacuum at the wellhead will be monitored and recorded on a Process Monitoring Form by a technician in the field. The flowrate, VOC concentration at the corresponding sample port, and the VOC concentration at the system extraction manifold and outlet will be recorded by the start-up engineer.
- The system dilution valve will be adjusted as necessary as vacuum is established. Typically, the dilution bleed valve may be cracked open for normal operation.
- Monitoring will continue during the initial vacuum operations. The following data will be recorded on a Process Monitoring Form until wellhead vacuum readings stabilize. Stabilized conditions will be considered achieved when extraction wellhead vacuum varies less than 10% between subsequent readings. An example process monitoring form is included in Appendix C.

- SVE wellhead vacuum inches H2O
- SVE system flowrate in scfm
- Total VOC's at discharge stack using PID
- Differential vacuum across SVE blower and separator
- Temperature after SVE blower
- Once the operating parameters of the entire SVE system have stabilized, the vacuum and flowrate will be incrementally increased to the design rates. Three incremental steps (e.g., 8 in., 14 in. and 20 in.) are typically required to achieve full system capability. If groundwater is entrained in the extraction flow stream, the vacuum and flowrate will be decreased to the point at which significant water is not entrained.

3.3 System Shutdown

The system will shutdown automatically upon activation of the moisture separator high-high level switch when all of the HOA switches are in the AUTO position.

3.4 Emergency Shutdown

In the event of an emergency, shut down the system by utilizing the main disconnect switch located on the control panel. Meet at the designated safety area in the event of shutdown due to power failure, flood, tornado, or other emergency, contingency episodes.

3.5 Routine Operations / Monitoring

Follow the guidelines in **Sections 4 and 5** for routine system operations and monitoring. The system can run unattended for extended periods of time.

4.0 EQUIPMENT MAINTENANCE AND TESTING

4.1 Preventative Maintenance (PM) Program

The SVE equipment, piping and all instrumentation and controls should be monitored on a monthly basis to prevent the system from shutting down due to leakage, worn out parts or malfunctioning equipment. The program will follow manufacturer's recommended procedures, which are addressed in more detail in Section 2.0, System Startup and Shutdown (Section 3.0), and individual Manufacturer's O&M Manuals included in Appendix A. Sections 4.3.1 and 4.3.2 address scheduled maintenance for SVE components. Section 4.3.3 addresses routine maintenance for the Vapor Phase Carbon system including carbon changeouts, the frequency of which will be determined by influent and effluent concentrations.

4.2 Device Testing / Preventive Monitoring (PM)

4.2.1 Well Tests

If it becomes apparent during the scheduled operation and maintenance visits that the correct vacuum or pressures cannot be achieved at the SVE well, the system will be inspected and taken off-line if necessary.

If the vacuum gauge reading demonstrates low values, the SVE piping, well, and manifold should be checked for leaks or signs of short circuiting, correct valving positions, and proper operation of the blower. Once the cause of the problem is identified, it will be repaired and the system returned to normal operation. If the vacuum gauge demonstrates high readings it may indicate that the well screen needs to be cleaned by injecting air, or that something is lodged in the line, or a valve is in the wrong position.

4.2.2 Fans / Blowers / Filters

Prior to system startup, the SVE blower must be tested for rotation and capacity. Detailed instructions for testing are included in Ametek Rotron O&M Instructions included in Appendix A.

4.2.3 Carbon Changeout Procedures

Carbon changeout procedures and frequency are addressed in Section 2.2.2, Off-Gas Equipment.

4.3 Maintenance Summary Schedule

The following maintenance is recommended for the major SVE equipment by the equipment manufacturer. See **Appendix A** for more details.

4.3.1 SVE Blowers

- Check all gauges (monthly)
- Check for unusual noise or vibration (monthly)
- Check for any air leaks (monthly)

4.3.2 Other SVE Components

<u>Rotometers</u>

The flow of air in the SVE system is being measured with portable anemometers (TSI Velocicalc Plus Model 8360). The flowmeters are calibrated in the factory and normally do not require any extensive maintenance. The only maintenance required to assure proper operation is occasional cleaning. An Operation and Service Manual is presented as **Appendix D**.

SVE Moisture Separator

SVE moisture separator is a 240-gallon vertical pressure vessel manufactured by EnviroSupply & Service. The vessel is equipped with a high-high level switch to monitor liquid level in the tank. Monitoring of the vessel includes occasional visual checks of the level switch to assure proper operation of the moisture separator.

4.3.3 Vapor Phase Activated Carbon

- Replace carbon in the vessels when the VOC concentrations approach the discharge levels (see **Discharge Requirements listed in Appendix E**)
- Monitor inlet temperature on regular basis.
- Inspect discharge Piping/Fittings for cracks/leaks

4.3.4 Ventilation Fan

- Periodically clean guards, dampers, motors, and propeller to prevent decrease in airflow or motor overheating.
- Periodically check for loose bolts and tighten them to prevent excessive vibration.

5.0 SYSTEM MONITORING

The SVE system was designed to operate continuously. Performance monitoring data showing mass removal rates versus time will be used to evaluate trends for the subject area. The duration of SVE operation will be based on acquired operational data.

5.1 Baseline Startup Monitoring

On September 18, 2002 a baseline startup system monitoring event was conducted at the National Heatset Site. During that event the SVE system was activated, routine maintenance tasks were completed, the controls system was checked for proper settings and operation, and startup system readings were taken and recorded.

This data serves as a baseline for which future system operation and remedial effectiveness can be compared. **Appendix C** includes a blank site visit form that can be copied and utilized for future monitoring events.

5.2 Compliance Monitoring and Samples

The SVE system will be monitored on a monthly basis to evaluate system performance, to assure that all components are in working order, and to maintain compliance with the substantive requirements of a New York State Department of Environmental Conservation Air Discharge Permit (See **Appendix E**). The general tasks to be performed during each visit are listed in the following paragraph. Notes from the monthly visits should be recorded and kept in the contractor's operating files.

SVE equipment will be inspected and operating parameters (temperature, vacuum readings, air concentration readings, and air flow rates) of the equipment and at individual points will be monitored and adjusted as required. The SVE point will be monitored and adjusted at the manifold in the equipment shed. Routine maintenance of the equipment will include the following tasks:

- Draining the moisture knock-out tank by utilizing the one-inch drain located approximately 6 inches from the base of the knock-out tank,
- Draining any moisture that may have accumulated in the carbon vessels.

The hour meter readings will be recorded to verify duration of the system operation between site visits.

Air effluent volatile organic compound concentrations will be monitored with a PID and drager tube during each site visit. Air flow rates will be measured and documented. A confirmatory effluent air sample will be collected each month and analyzed by Method TO-14 modified (site specific compounds) to verify field measurements.

5.3 System Operating Parameters and Process Monitoring

During continuous operation, the expected operating parameters for the SVE system are based on the design calculations, pilot test results, and baseline startup as previously summarized.

5.4 Air Monitoring For Working Safety

Air monitoring must be conducted to determine the potential for personnel exposures and fugitive emissions from site contaminants. Results of air monitoring will be used to ensure the proper selection of protective clothing and equipment, including respiratory protection for protection of on-site personnel and off-site receptors from exposure to unacceptable levels of site contaminants. Air monitoring results will also be used to adjust the SVE system such that fugitive emissions are not released into the environment beyond the vacuum influence of the SVE well. Descriptions of air monitoring strategies, procedures and equipment are provided below.

5.4.1. Direct Reading Air Monitoring

During the operation and maintenance of the SVE system, direct reading air monitoring will be performed. Results of the air monitoring will determine exposure to workers. A Photovac PID, equipped with an 11.7 eV lamp will be used to monitor for total VOCs during these activities. The Photovac is equipped with a pre-programmed library selection which provides response

factors for 70 compounds, enabling direct reading of a targeted contaminant in parts per million (ppm). A manufacturer's information sheet is included in **Appendix F**. If a sustained PID reading above background levels are observed, contaminant-specific monitoring methods, such as Draeger colorimetric detector tubes, should be used. The following air monitoring plan and contaminant concentration action levels will apply for all air monitoring points located beyond the range of vacuum influence.

5.4.2 Instrumentation

The following is a description of the air monitoring equipment and procedures to be used at this site.

5.4.3 Photoionization Detector (PID)

Monitoring Procedure

- Breathing Zone: To monitor the breathing zone, the inlet of the PID must be held in the breathing zone for a minimum of 15 seconds. The highest sustained reading observed will be recorded for that air monitoring location.
- SVE Air Sample Ports: Tygon tubing will be attached to the sample ports on the SVE lines and the ports between and after the VGAC units. The sampling pump will be used to fill a vapor sampling bag. A PID will then be used to measure the VOC concentration in the vapor from the sampling bag.
- Vapor Probes and Monitoring Wells: An air tight well cap will be placed on the monitoring well with a tygon tubing attached. A personal air sampling pump will be used to purge the well/probe for three minutes, so that representative soil vapors enter the well from the soil formation. The sampling pump will be used to fill a vapor sampling bag. A PID will then be used to measure the VOC concentration in the vapor from the sampling bag.

Type and Operational Aspects

Described below are the features and operational aspects of the PID.

- Photovac PID Appendix F contains an information sheet for the Photovac 2020.
- Ionization potential (IP) The energy required to remove the outermost electron from a molecule; measured in electron volts (eV); characteristic property of a specific chemical.

- Photoionization Using ultraviolet (UV) light to remove the outermost electron from a molecule.
- Energy of UV light (10.2, 9.5, 11.7 eV) must be equal to or greater than the IP to photoionize the molecule. The 11.7 eV bulb equipped in the Photovac 2020 is adequate for the compounds of concern at the site.
- Fan or pump is used to draw air into the detector where the contaminants are exposed to a UV light source (lamp).
- lons are collected on a charged plate and produce a current directly proportional to the number of ionized molecules; current is amplified and displayed on the meter.

Calibration Method/Frequencies

The PID Photovac is designed for trace gas analysis in ambient air and is calibrated at the manufacturer with certified standards of BTEX as benzene.

The approximate span settings for the probe that would give different readings of the amounts of trace gas of a particular species in a sample are based upon the relative photoionization sensitivities of various gases twice daily (beginning and end of shift).

It is recommended that calibration be checked once each day. The field personnel will record and log such calibration information into an air monitoring notebook.

Preventive Maintenance

Maintenance of the PID Model 2020 consists of cleaning the lamp and ion chamber, and replacement of the lamp or other component parts or sub-assemblies.

5.4.4 Colorimetric Detector Tubes

Type and Operational Aspects

The operator will select a specific colorimetric detector tube for tetrachloroethene. For general air monitoring the tubes should be held in the breathing zone. For monitoring of the SVE influent, mid or effluent air, the colorimetric tube should be placed into the appropriate air sample port.

Draeger Multi Glass Detector Model 21/31

Principle of Operation:

- Colorimetric indicator tubes (detector tubes) consist of a glass tube impregnated with an indicating chemical.
- Tube is connected to a piston or bellow pump to draw a known volume of air through the tube. (Do not overdraw the pump; follow manufacturers instructions)
- Contaminant reacts with the indicator chemical in the tube, producing a change in color whose length is proportional to the contaminant concentration; glass tube has gradations in ppm to match the length of stain.
- Preconditioning filter may precede the detector tube to remove interfering contaminants (vinyl chloride).

Calibration Methods/Frequencies

There is no method or procedure for calibrating any colorimetric detector tube. However, it is important to read the instructions provided with a specific detector tube to determine number of pump strokes, interfering chemicals, proper color change, and shelf life. It is important that the number of strokes is not exceeded on the first measurement, as this may overload the tube and overshoot the standard range of measurement.

The sampling pump can be checked but not calibrated using a bubble tube and bellows pump. All bellows pumps draw in a specific amount of air during each stroke. This amount should correspond to a specific amount on the bubble tube (i.e., if one stroke equals 100 cc, then the bubble should move 100 cc in the bubble tube). Also, a leak check can be conducted by activating the pump stroke, then inserting an unopened colorimetric tube in the pump inlet. The pump should not move, if it does, this indicates a leak. If the pump fails either the leak test or the volume test, return it to the manufacturer for repair.

Preventative Maintenance

Generally speaking, the reagent of the colorimetric tubes cannot be stored for unlimited periods. The shelf life of the Drager tubes are, therefore, limited to two years (for storage at room temperature).

5.4.5 Air Monitoring Results

Air monitoring results will be reported as described in Section 6.0.

Soil Vapor Extraction Operation and Maintenance Manual National Heatset Printing, Babylon, New York

6.0 **REPORTING**

System performance and discharge compliance results will be documented in monthly reports to the NYSDEC Bureau of Eastern Remedial Action.

Soil Vapor Extraction Operation and Maintenance Manual National Heatset Printing, Babylon, New York

7.0 HEALTH AND SAFETY

A site specific Health and Safety Plan has been developed for the National Heatset Site by Shaw. A copy of this plan will kept inside the treatment enclosure for reference at all times.

8.0 DISPOSAL/RESIDUALS MANAGEMENT

Waters collected from the SVE systems 240-gallon moisture separator will be contained in 55gallon drums. Once a drum is full, the fluid will be sampled and analyzed to determine proper off-site disposal options. The collected fluid will be disposed of in accordance with all State, Local, and Federal regulations.

ĥ


Spent carbon from the VGAC units will be shipped for off-site regeneration or disposed of at a permitted off-site facility. The spent carbon will be regenerated or disposed of in accordance with State, Local, and Federal regulations.

Soil Vapor Extraction Operation and Maintenance Manual National Heatset Printing, Babylon, New York


9.0 PROJECT CLOSURE


Shaw was retained by the NYSDEC to operate the system for 12 months following the startup date (September 18, 2002). The final Shaw inspection will be completed in conjunction with personnel from the NYSDEC so that continued O&M may be completed by the department. The SVE system will operate continuously until the VOC removal reaches asymptotic conditions. When asymptotic conditions are reached, the SVE system will be pulsed (manually shut down every other month) until the VOC removal again reaches asymptotic conditions. The SVE system will be shut down at that time and soil samples will be collected from unsaturated soils within the footprint of the site building. To ensure that appropriate locations are reached after pulsed operation of the SVE system. The soil analytical data will be compared to maximum concentration levels specified in the New York State Soil Standards. If the soil analytical data does not meet the New York State guidelines, operation of the SVE system will be resumed after consultation with the NYSDEC.


If the soil analytical data meets the guidelines, operation of the SVE system will not resume. Demobilization and restoration activities will be performed and a project closure report will be submitted to the NYSDEC. FIGURES




PLAN VIEW












	FIGURE 1							
	2		NATIONAL HEATSET PRINTING FARMINGDALE, NEW YORK					
AWING	Shaw & Shaw & Soil VAPOR EXTRACTION Engineering of New York, P.C. PILOT TEST LOCATION MAP							
AWING	DESIGNED BY	J. SKA	AARUP 10/23/02		CHECK	CED BY	401	10/7/03
TO DRAWING	DRAWN BY	CA/HMI	0/SSH 10/23/02 APP		APPRO	MED BY	0	1911 2
AWING	SCALE:		DRAWING ND.			SHEET	NO.	REVISION NO.
/ISSUE	AS SHO	WN	802901B35					4

APPENDIX A

MANUFACTURER'S O&M MANUALS

PRODUCT MANUAL

FOR

THE SHAW GROUP SOIL VAPOR EXTRACTION CONTAINER

S/N 204

Ì

MANUFACTURED BY

ENVIROSUPPLY & SERVICE INC. 1751 KAISER AVE. IRVINE, CA 92614


800-201-8150

EnviroSupply Service

SERVICE AND PARTS MANUAL FOR BLOWER MODEL

EN8, EN12, EN14

DIRECT DRIVE REGENERATIVE BLOWER



.

ROTRON[®] Industrial Products 75 North Street, Saugerties, NY 12477 U.S.A. Telephone: 845-246-3401 Fax: 845-246-3802 e-mail: rotronindustrial@ametek.com Internet: www.rotronindustrial.com

Your Choice. Our Commitment.™

AMETEK

WARRANTY, INSTALLATION, MAINTENANCE AND TROUBLESHOOTING INSTRUCTIONS



ì

AMETEK

ROTRON INDUSTRIAL PRODUCTS 75 North Street, Saugerties, NY 12477 U.S.A. Telephone: 845 -246-3401 Fax: 845-246-3802 e-mail: rotronindustrial@amelek.com web site: www.rotronindustrial.com

- 1. No Fault Policy AMETEK Rotron DR, EN and HiE regenerative direct drive blowers are guaranteed for one full year from the date of installation (limited to 18 months from the date of shipment.) to the original purchaser only. Should the blower fail, regardless of the cause of failure, we will at our option repair or replace the blower.
- 2. **Standard Policy** AMETEK Rotron Minispiral, Revaflow, Multiflow, Nautilair, remote drive blowers, moisture separators, packaged units, CP blowers, Nasty Gas[™] models and special built (EO) products are guaranteed for one full year from date of shipment for workmanship and material defect to the original purchaser only. Should the blower fail, we will evaluate the failure. If failure is determined to be workmanship or material defect related, we will at our option repair or replace the blower.
- 3. **Parts Policy** AMETEK Rotron spare parts and accessories are guaranteed for three months from date of shipment for workmanship and material defect to the original purchaser only. If failure is determined to be workmanship or material defect related we will at our option repair or replace the part.

Corrective Action - A written report will be provided indicating reason(s) for failure, with suggestions for corrective action. Subsequent customer failures due to abuse, misuse, misapplication or repeat offense will not be covered. AMETEK Rotron will then notify you of your options. Any failed unit that is tampered with by attempting repair or diagnosis will void the warranty, unless authorized by the factory.

Terms and Conditions - Our warranty covers repairs or replacement of regenerative blowers only, and will not cover labor for installation, outbound and inbound shipping costs, accessories or other items not considered integral blower parts. Charges may be incurred on products returned for reasons other than failures covered by their appropriate warranty. Out-of -warranty product and in warranty product returned for failures determined to be caused by abuse, misuse, or repeat offense will be subject to an evaluation charge. Maximum liability will in no case exceed the value of the product purchased. Damage resulting from mishandling during shipment is not covered by this warranty. It is the responsibility of the purchaser to file claims with the carrier. Other terms and conditions of sale are stated on the back of the order acknowledgement.

Installation Instructions for SL, DR, EN, CP, and HiE Series Blowers

- 1. Bolt It Down Any blower must be secured against movement prior to starting or testing to prevent injury or damage. The blower does not vibrate much more than a standard electric motor.
- 2. **Filtration** All blowers should be filtered prior to starting. Care must be taken so that no foreign material enters the blower. If foreign material does enter the blower, it could cause internal damage or may exit at extremely high velocity.

Should excessive amounts of material pass through the blower, it is suggested that the cover(s) and impeller(s) be removed periodically and cleaned to avoid impeller imbalance. Impeller

1

imbalance greatly speeds bearing wear, thus reducing blower life. Disassembling the blower will void warranty, so contact the factory for cleaning authorization.

- 3. **Support the Piping -** The blower flanges and nozzles are designed as connection points only and are not designed to be support members.
 - Caution: Plastic piping should not be used on blowers larger than 1 HP that are operating near their maximum pressure or suction point. Blower housing and nearby piping temperatures can exceed 200°F. Access by personnel to the blower or nearby piping should be limited, guarded, or marked, to prevent danger of burns.
- 4. **Wiring** Blowers must be wired and protected/fused in accordance with local and national electrical codes. All blowers must be grounded to prevent electrical shock. Slo-Blo or time delay fuses should be used to bypass the first second of start-up amperage.
- 5. **Pressure/Suction Maximums** The maximum pressure and/or suction listed on the model label should <u>not be exceeded</u>. This can be monitored by means of a pressure or suction gage (available from Rotron), installed in the piping at the blower outlet or inlet. Also, if problems do arise, the Rotron Field representative will need to know the operating pressure/suction to properly diagnose the problem.
- 6. **Excess Air** Bleed excess air off. DO NOT throttle to reduce flow. When bleeding off excess air, the blower draws <u>less</u> power and runs cooler.

Note: Remote Drive (Motorless) Blowers - Properly designed and installed guards should be used on all belts, pulleys, couplings, etc. Observe maximum remote drive speed allowable. Due to the range of uses, drive guards are the responsibility of the customer or user. Belts should be tensioned using belt gauge.

Maintenance Procedure

When properly plped, filtered, and applied, little or no routine maintenance is required. Keep the filter clean. Also, all standard models in the DR, EN, CP, and HiE series have sealed bearings that require no maintenance. Bearing should be changed after 15,000 to 20,000 hours, on average. Replacement bearing information is specified on the chart below.

Bearing Part Number	Size	Seal Material	Grease	Heat Stabilized
510217 510218 510219	205 206 207	Polyacrylic	Nye Rheotemp 500 30% +/- 5% Fill	Yes – 325 F
510449 516440 516648	203 202 307	Buna N	Exxon Polyrex Grease	NO
516840 516841 516842 516843 516844 516845 516845 516846	206 207 208 210 309 310 311	Buna N	Exxon Polyrex Grease	NO
516847	313			

2

Troubleshooting

		POSSIBLE CAUSE	OUT OF WARRANTY REMEDY ***
	Ţ	1. • One phase of power line not connected	1. Connect
LER DOES NOT TURN Humming Sound		2. • One phase of stator winding open	2. Rewind or buy new motor
	S B	3. Bearings defective	3. Change bearings
DOES RN	Ē	4. Impeller jammed by foreign material	4. Clean and add filter
		5. Impeller Jammed against housing or cover	5. Adjust
IMPELLER TU	로	6. ** Capacitor open	6. Change capacitor
2	05_	1. • Two phases of power line not connected	1. Connect
ş	oN Soun	2. • Two phases of stator winding open	2. Rewind or buy new motor
	Blown Fuse	 Insufficient fuse capacity Short circuit 	1. Use time delay fuse of proper rating
	ᅋᅭ		2. Repair
	<u> </u>	1. High or low voltage	1. Check Input voltage
	Motor Overheated Or Protector Trips	2. • Operating in single phase condition	2. Check connections
	tor Overheated Protector Trips	3. Bearings defective	3. Check bearings
	Ê.	4. Impeller rubbing agaInst housing or cover	4. Adjust
SZ		5. Impeller or air passage clogged by foreign materia	I 5. Clean and add filter
NRI N	10	6. Unit operating beyond performance range	6. Reduce system pressure/vacuur
2	a a a a a a a a a a a a a a a a a a a	7. Capacitor shorted	7. Change capacitor
IMPELLER TURNS	~	8. • One phase of stator winding short circuited	8. Rewind or buy new motor
ŭ		1. Impeller rubbing against housing or cover	1. Adjust
Ĩ <u>v</u>	Abnormal Sound	2. Impeller or air passages clogged by foreign	2. Clean and add filter
	Ĕ	material	3. Change bearings
		3. Bearings defective	
	ard	1. Leak in piping	1. Tighten
	l a pa	2. Piping and air passages clogged	2. Clean
	Performance Below Standard	3. Impeller rotation reversed	3. Check wiring
	Ĩ Ĩ Ĩ	4. Leak in blower	4. Tighten cover, flange
		5. Low voltage	5. Check input voitage

- 5 phase units

** 1 phase units

ì

*** Disassembly and repair of new blowers or motors will vold the Rotron warranty. Factory should be contacted prior to any attempt to field repair an in-warranty unit.

Blower Disassembly:

WARNING: Attempting to repair or diagnose a blower may vold Rotron's warranty. It may also be difficult to successfully disassemble and reassemble the unit.

- 1) Disconnect the power leads. **CAUTION:** Be sure the power is disconnected before doing any work whatsoever on the unit.
- 2) Remove or separate piping and/or mufflers and filters from the unit.
- 3) Remove the cover bolts and then the cover. **NOTE:** Some units are equipped with seals. It is mandatory that these seals be replaced once the unit has been opened.
- 4) Remove the impeller bolt and washers and then remove the impeller. **NOTE:** Never pry on the edges of the impeller. Use a puller as necessary.
- 5) Carefully note the number and location of the shims. Remove and set them aside. NOTE: If the disassembly was for inspection and cleaning the unit may now be reassembled by reversing the above steps. If motor servicing or replacement and/or impeller replacement is required the same shims may not be used. It will be necessary to re-shim the impeller according to the procedure explained under assembly.

- 6) Remove the housing bolts and remove the motor assembly (arbor/.housing on remote drive models).
- 7) Arbor disassembly (Applicable on remote drive models only):
 - a) Slide the bearing retraining sleeve off the shaft at the blower end.
 - b) Remove the four (4) screws and the bearing retaining plate from the blower end.
 - c) Lift the shaft assembly far enough out of the arbor to allow removal of the blower end snap ring.
 - d) Remove the shaft assembly from the arbor.
 - e) If necessary, remove the shaft dust seal from the pulley end of the arbor.

Muffler Material Replacement:

- 1) Remove the manifold cover bolts and them manifold cover.
- 2) The muffler material can now be removed and replaced if necessary. On blowers with fiberglass acoustical wrap the tubular retaining screens with the fiberglass matting before sliding the muffler pads over the screens.
- 3) Reassemble by reversing the procedure.

NOTE: On DR068 models with tubular mufflers it is necessary to remove the cover and impeller accessing the muffler material from the housing cavity.

Blower Reassembly:

- 1) Place the assembled motor (assembled arbor assembly for remote drive models) against the rear of the housing and fasten with the bolts and washer.
- 2) To ensure the impeller is centered within the housing cavity re-shim the impeller according to the procedure outlined below.
- 3) If blower had a seal replace the seal with a new one.
- 4) Place the impeller onto the shaft making sure the shaft key is in place and fasten with the bolt, washer and spacer as applicable. Torque the impeller bolt per the table below. Once fastened carefully rotate the impeller to be sure it turns freely.
- 5) Replace the cover and fasten with bolts.
- 6) Reconnect the power leads to the motor per the motor nameplate.

Boit Size	Torque
1/4-20	6.25 +/- 0.25
5/16-18	11.5 +/- 0.25
3/8-16	20.0 +/- 0.5
1⁄2-13	49.0 +/- 1
5/8 –11	90.0 +/- 2

Impeller Shimming Procedure:

WARNING: This unit may be difficult to shim. Extreme care may be exercised.

Tools Needed: Machinist's Parallel Bar

Vernier Caliper with depth measuring capability Feeler gauges or depth gauge


Measure the Following:


Distance from the flange face to the housing (A) Distance from the flange face to the motor shaft shoulder (B) Impeller Thickness (C)

Measurements (A) and (B) are made by laying the parallel bar across the housing flange face and measuring to the proper points. Each measurement should be made at three points, and the average of the readings should be used.

Shim Thickness = B - (A+C)/2

After the impeller installation (step #4 above) the impeller/cover clearance can be checked with feeler gauges, laying the parallel bar across the housing flange face. This clearance should nominally be (A+C)/2.





ASSEMBLY DIAGRAM EN8 EN12 EN14

-

)

)

220033	220039	260913	260913	286913	212606	Muffler Housing	L	B20
Not Used	besU joN	Bolt, Muffler/Housing		A618				
(6 pcs) 155067	(6 pcs) 155067	290991	190991	122032	(e bcs) 122032	Bolt, Muffler Hsg/Hsg	8	B100
220040	220040	110913	110913	212320	212604	Screen, Muffler Retaining, Left (**)	i	078
250042	250042	216010	216010	212321	212603	Screen, Muffler Retaining, Right (**)	F	818
Not Used	Not Used	Lockwasher, Housing	F	B15				
Not Used	Not Used	Not Used	besU toN	Not Used	Not Used	Shaft Sleeve		210
066919	066919	212669	212360	211250	212222	Spacer, Impeller Bolt	<u> </u>	918
140019	140019	140016	610071	610071	610071	Eye Bolt	<u> </u>	816 816
122069	122069	690991	690991	140016	140016	Screw, Cover	8	<u>814</u>
016919	212010	016919	016919	212323	242919	Cover	<u> </u>	B13
Not Used	211250	Washer, Impeller						
387132	361788	561788	882192	521788	521288	Lockwasher, Impeller		815
122068	120261	120261	122028	910041	120210	Bolt, Impeller	F	811
609919	216683	212683	212200	212212	212540		<u>+</u>	<u>B10</u>
Not Used	besU joN	Not Used	Not Use	Not Used	Not Used	"050. mid2	- F	68
766919	211220	211220	766919	211220	211550	"020. mid2	*	
212003	679119	211240	212003	679119	679119	"0r0. mid2	¥ .	
266919	844119	211248	266919	211248	879119	"200. mid2	*	
166919	249119	279119	166919	279119	279119	"200. mid2	*	
Not Used	Not Used	253438	253438	23432	253435	Manifold Plate	<u> </u>	88
911099	220110	216664	216664	216663	299919	Matting, Fiberglass		
(24 bcs) 220013	(24 bcs) 220073		216108	(25 pcs) 515348	212402	Muffler Material	38	98
120205	120206	120205	120205	140014	122034	Screw, Hsg /Motor	<u> </u>	98 98
664919	262919	262919	662919	212326	792919	BuisuoH		<u>84</u>
Not Used	Not Used	besU joN	Not Used	Not Used	Not Used	Elbow 90°	•	
(5 bcs) 155377	(2 pcs) 155377	Not Used	Not Used	besU toN	Not Used	Screen, Flange Guard/O-ring		
216629	216623	286919	986919	913113	211614	Flange	5	
besU toN	Not Used	(18 pcs) 120214	(18 bcs) 120214	120214	120214	Screw, Manifold	<u> </u>	83 85
(e bcs) 140016	(6 pcs) 140016	122032	122032	122031	120011	Screw, Flange	<u></u>	
122066	211235	211235	122092	211235	2211235	Key Motor Shaft		81
					E44600	Description	n hev	<u>W3</u>
						anitringag(P'DOG	UN

· • • ·

1

Item Qty. No. Req'd Description

		OBSOLETE	OBSOLETE	JT3JOSBO	OBSOLETE]
038762			038444	038445	038441	
192820	092860	281850	038488	981860	038182]::0N µe
41N3	41N3	FN14	FINE	ENIS	8NB	
-		uwoba	Parts Bre			

Service and Parts Manual EN 8/12/14

. بعمر

1

1

1


1

. ...

69915	216693	216693	169919	216693	216693	Lip Seal	L
216242	216242	216242	216242	212586	202304	Rail Mounting	B26 2
020991	122050	122050	020991	561789	521286	Nut, Rail	825 4
Not Used	Not Used	Not Used	Not Used	160991	besU toN	Washer/Rail/Motor	B24¥ 4
521288	261788	251788	551788	281182	281182	Lockwasher Rail	854 4
1200256	122022	122022	150526	16099	1200021	Bolt, Rail	853 4
Not Used	Guard Heat slinger	852					
Not Used	Not Used	279119	266919	Not Used	Not Used	Heat Slinger	821
Not Used	Not Used	besU toN	Not Used	Not Used	Not Used	Spacer, Motor/Muffler	
Not Used	Not Used	besU toN	Not Used	Not Used	Not Used	Washer, Motor/Muffler	
Not Used	Lockwasher, Motor/Muffler						
Not Used	Bolt, Motor/Muffler	······					
Not Used	Muffler Discrete						
						· · ·	
, Sate							. n .
			1 1		1 1		1 1
		• •	• •	4 4			

Bearing, Impeller End (M2)	Bearing, Rear (M1)	-	സലുള്ളവ് ഉപന്ദ്യW	Notor	Part No.	leboM
216844	516840		<u></u>	912226	038182	EN8BD72WL
			7 + N	229625	038441	EN8BD86WL
919	216842		K+L	211212	038186	EN12BG72WL
			7+N	129629	038445	EN12BG86WL
			7+N	259632	038444	EN14DX86WL
				210092	038188	EN14DX72WL
2168 4 6	516844		K+L	611613	281880	EN14BK72WL
			K+L	211213	092860	EN14BK72MWL
			K+L	216095	192860	EN14DX72MWL
			K+L	229632	292850	EN14DX86MWL

•



-

GENERAL INSTALLATION INSTRUCTIONS

ROTRON INDUSTRIAL PRODUCTS 75 North Street, Saugerlies, NY 12477 U.S.A. Telephone: 845-246-3802 emil: pitchnightis/damatel.com weble: www.streindestel.ac

Rotron Regenerative Blowers

Installation Instructions for SL, DR, EN, CP, and HIE Series Blowers

- 1. Bolt It Down Any blower must be secured against movement prior to starting or testing to prevent injury or damage. The blower does not vibrate much more than a standard electric motor.
- 2. Filtration All blowers should be filtered prior to starting. Care must be taken so that no foreign material enters the blower. If foreign material does enter the blower, it could cause internal damage or may exit at extremely high velocity.

Should excessive amounts of material pass through the blower, it is suggested that the cover(s) and impeller(s) be removed penodically and cleaned to avoid impeller imbalance. Impeller imbalance greatly speeds bearing wear, thus reducing blower life. Disassembling the blower will void warranty, so contact the factory for cleaning authorization.

- Support the Piping- The biower flanges and nozzles are designed as connection points only and are not designed to be support members.
 - Caution: Plastic piping should not be used on blowers larger than 1 HP that are operating near their maximum pressure or suction point. Blower housing and nearby piping temperatures can exceed 200°F. Access by personnel to the blower or nearby piping should be limited, guarded, or marked, to prevent danger of burns.
- 4. Wiring Blowers must be wired and protected/fused in accordance with local and national electrical codes. All blowers must be grounded to prevent electrical shock. Slo-Blo or time delay fuses should be used to bypass the first second of start-up amperage.
- 5. Pressure/Suction Maximums- The maximum pressure and/or suction listed on the model label should <u>not be exceeded</u>. This can be monitored by means of a pressure or suction gage (available from Rotron), installed in the piping at the blower outlet or inlet. Also, if problems do arise, the Rotron Field representative will need to know the operating pressure/suction to properly diagnose the problem.
- 6. Excess Air Bleed excess air off. DO NOT throttle to reduce flow. When bleeding off excess air, the blower draws<u>less</u> power and runs cooler.

Note: Remote Drive (Motorless) Blowers - Property designed and installed guards should be used on all belts, pulleys, couplings, etc. Observe maximum remote drive speed allowable. Due to the range of uses, drive guards are the responsibility of the customer or user. Belts should be tensioned using belt gauge.

For further information regarding Rotron regenerative blowers (including service & parts manuals), please contact your local field sales engineer.

Maintenance Procedure

When properly piped, filtered, and applied, little or no routine maintenance is required. Keep the filter clean. Also, all standard models in the DR, EN, CP, and lie series have sealed bearings that require no maintenance. Bearing should be changed after 15,000 to 20,000 hours, on average. Replacement bearing information is specified on the chart below.

Bearing Part Number	Size	Seal Material	Grease	Heat Stabilized
510217 510218 510219	205 206 207	Polyacrylic	Nye Rheotemp 500 30% +/- 5% Fill	Yes – 325 F
510449 516440 516648	203 202 307	Buna N	Shell Dolium "R" 25-40% Fill	NO
516840 516841 516842 516843	206 207 208 210	Buna N	Shell Dolium "R" 30%+/- 5% Fill	NO
516844 516845 516846 516847	309 310 311 313			

Troubleshooting

rioubi	53/1001		
		POSSIBLE CAUSE	OUT OF WARRANTY REMEDY ***
	LER DOE NOT TURN Humming Sound	 One phase of power line not connected 	1. Connect
ē	. 5	One phase of stator winding open	2. Rewind or buy new motor
Ū.	s	3. Bearings defective	3. Change bearings
Δž	뒅	Impeller jammed by foreign material	4. Clean and add filter
£2	Ę	5. Impeller jammed against housing or cover	5. Adjust
		6. ** Cepacitor open	6. Change capacitor
IMPELLER DOE NOT TURN	Sound	1. * Two phases of power line not connected	1. Connect
_	Z ð	2. * Two phases of stator winding open	2. Rewind or buy new motor
	Blown Fuse	1. Insufficient fuse capacity	1. Use time delay fuse of proper rating
	응고	2. Short circuit	2. Repair
		1. High or low voltage	1. Check input voltage
	ŏ	Operating In single phase condition	2. Check connections
		3. Bearings defective	3. Check bearings
	Ê F	Impeller rubbing against housing or cover	4. Adjust
Ŷ	Motor Overheated Protector Trips	5. Impeller or air passage clogged by foreign material	5. Clean and add filter
ŝ	1 a a	Unit operating beyond performance range	6. Reduce system pressure/vacuum
ВТ	3	7. Capacitor shorted	7. Change capacitor
IMPELLER TURNS		8. • One phase of stator winding short circuited	8. Rewind or buy new motor
μ	Abnormal Sound	1. Impeller rubbing against housing or cover	1. Adjust
Σ	Sound	Impeller or air passages clogged by foreign material	2. Clean and add filter
		3. Bearings defective	3. Change bearings
	Performance Below Standard	1. Leak in piping	1. Tighten
	S S	Piping and eir passages clogged	2. Clean
	E S	3. Impeller rotation reversed	3. Check wiring
	5	4. Leak in blower	4. Tighten cover, flange
	<u> </u>	5. Low voltage	5. Check input voltage
* 3 phas	se units		

** 1 phase units

*** Disassembly and repair of new blowers or motors will vold the Rotron warranty. Factory should be contacted prior to any attempt to field repair an in-warranty unit.



EXPLOSION-PROOF BLOWERS

ROTRON TECHNICAL MOTOR DIVISION REGENERATIVE BLOWER GROUP

75 North Street Saugerties, New York 12477 Phone: (845) 246-3401 Fax: (845) 246-3802




IMPORTANT: Read before wiring this Explosion-proof Blower

This AMETEK Rotron Explosion-proof Regenerative Blower may be equipped with Pilot Duty Thermal Overload (PDTO) or Automatic Thermal Overload (ATO) protection. When properly wired to a motor starter, this protection limits the motor winding temperature rise per the National Electric Code (NEC) article 500. Failure to property wire this blower is an NEC violation and could cause an explosion. AMETEK Rotron assumes no responsibilities for damages incurred by negligent use of this product, and will not warranty a blower on which the PDTO is not property connected. Some blowers 1 HP and under do not require PDTO and have built in ATO. Consult the factory if verification of wiring connections is regulred.

In all cases, follow the motor controller manufacturer's instructions. The following schematic is for conceptual understanding only, and may not apply to all motor/controller combinations.

The manufacturer's wiring diagram found on the motor takes precedent over reference diagrams supplied by AMETEK Rotron Technical Motor Division.

Schematic



The schematic is shown for a three phase motor. For a single phase motor disregard L3 and M3. Pushing the START button completes the auxiliary control circuit, allowing current to flow through the magnetic coil. The contacts are magnetically closed, starting the motor and latching the auxiliary circuit. The motor will continue to run until the STOP nush button is depressed, the motor reaches the overload temperature, or the current sensing overloads trip out.

If you have any questions, contact AMETEK Rotron at 914-246-3401 for the location of your area representative.

POLICY REGARDING INSTALLATION OF AMETEK ROTRON **REGENERATIVE BLOWERS IN HAZARDOUS LOCATIONS**

AMETEK Rotron will not knowingly specify, design or build any regenerative blower for installation in a hazardous, explosive location without the proper NEMA motor enclosure. AMETEK Rotron does not recognize sealed blowers as a substitute for explosion-proof motors. Sealed units with standard TEFC motors should never be utilized where local, state, and/or federal codes specify the use of explosion-proof equipment.

AMETEK Rotron has a complete line of regenerative blowers with explosion-proof motors. Division 1 & 2, Class I, Group D; Class II, Groups F & G requirements are met with these standard explosion-proof blowers.

AMETEK Rotron will not knowingly specify, design or build any regenerative blower for installation in a hazardous, conosive environment without the proper surface treatment and sealing options.

AMETEK Rotron has a complete line of Chemical Processing and Nasty Gas™ regenerative blowers with Chem-Tough™, stainless steel parts, and seals.


AMETEK Rotron offers general application guidance; however, suitability of the particular blower selection is ultimately the responsibility of the purchaser, not the manufacturer of the blower.

ES2 Rev B 3/10/98

BULLETIN E-20

FLOTECT. MODEL L-6 FLOAT SWITCH

Installation and Operating Instructions



WETTED MATERIALS CHART

Model	frans.	Broaze	Ceremic	Polypropylane	30155	38355	39455
8-8-8-A	X		X		X		X
B-S-3-B	x	X.	X	X	X		
8-8-3-C	X		X		X		x
B-S-3-H	X	X	X		X		x
8-8-9-0	X		X	· X	X		
5-8-8-A			X	x	X		x
8-8-8-C			x		X	х	x
8-S-3-L		[X		X	х	X
5-5-3-0				x	X	x	
5-5-3-8		1	X	x	X	X	

INSTALLATION:

WE/L

nderson

Unpack switch and remove any packing material found inside lower housing or float chamber.

Switch must be installed with body in a horizontal plane and arrow on side pointing down.

If switch tree an external float chamber (tee), connect it to vertical sec-tions of 1" NPT pipe installed outside vessel walls at appropriate levels. If unit has no external float chamber, it must be mounted in a 1" NPT half coupling welded to the vessel wall. The coupling must extend through the well.

inspect and clean wetted parts at regular intervals.

ELECTRICAL CONNECTIONS:

Connect wire leads in accordance with local electrical codes and switch action required. N.O. contacts will close and N.C. contacts will open when liquid level causes float to rise. They will return to "normal" condition. on decreasing liquid level. Black = common, Blue = N.O. and Red . - NC

For units supplied with both internal and external grounds, the ground screw inside the housing must be used to ground the control. The Explosion-Proof; U.L. and C.S.A. Listed -Class I, Groups *A, B, C & D Class II, Groups E, F & G CENELEC: EExd IIC T6 (T amb=75°C) *(Group A. stainless steel body only)

PHYSICAL DATA

PHYSICAL DATA Temperature Limit: 220°F (105°C) maximum Maximum Pressure: See chart below Switches: One or two SPDT snap switches Electrical Rating: U.L.: 5A @ 125/250 VAC. C.S.A. and CENELEC: 5A @ 125/250 VAC, 5A resistive, 3A inductive @ 30 VDC. Optional ratings: MV option--Gold contacts for dry circuits. Rated 0.1A @ 125/250 VAC (not listed). Window Commentions 3.18° (400°F) (205-C) of gr 22220 w/C (not initial). Wiring Connections: 3-18" (460mm) wire leads, 18 ga. CENELEC models only: push-in type terminal blocks Black = common, blue = N.C. red = N.C. Minimum Specific Gravity: Folypropylene float - 0.9 Round SS float - 0.7 Collection SS float - 0.5 Votind 35 note + 0.7 Cylindrical SS float - 0.5 Switch Body: Brass 344" NPT conduit connection. For SS switch body, change model no. to L6EPS. Piping/Mounting Consection: 1" NPT Installation: Horizontal, index arrow pointing down. Weight: 1 fb. (5 KG); w/external chamber 1-34 fb. (8 KG)

MAXIMUM PRESSURE CHART

Nation Number	Fleet	Passare Baling PSIG (KB/CMP)		
L6EPB-B-S-S-A	Cylindrical SS	200 (14)		
L6EP8-8-S-3-8	Polypropylene	250 (18)		
L6EP8-8-3-C	Round SS	350 (25)		
L6EPB-B-S-S-H	Round \$8	250 (18)		
L8EP8-8-6-5-0	Polypropylene	1000 (70)		
L6EPB-S-S-S-A	Cylindrical SS	200 (14)		
LCEPB-S-S-S-C	Round 58	350 (25)		
L6EPB-8-6-3-L	Round SS	850 (25)		
L6EPB-S-S-3-O	Potypropylene	2000 (140)		
L6EPB-S-S-3-S	Polypropylene	2000 (140)		


external ground acraw is for supplementary bonding when allowed or required by local code. Some CSA listed models are turnished with a separate green ground wire. Such units must be equipped with a junction box, not supplied but available on special order


CENELEC certified models include a junction box. Cable should enter enclosure through an approved EX cable gland, not supplied. Push strip-ped and tinned leads into appropriate openings in terminal block(s). To connect fine stranded leads or to remove any wire, depress spring release with small acrewdriver first.

All wiring, conduit and enclosures must meet applicable codes for hazardous areas. Conduits and enclosures must be properly sealed. For outdoor or other locations where temperatures vary widely, precu-tions should be taken to prevent condensation inside switch or enclosure. Electrical components must be kept dry at all times. CAUTION: To prevent ignition of hazardous atmospheres, disconnect the device from the supply circuit before opening. Keep assembly tightly closed when in use.

Dimensions on reverse

-








CSA, CENELEC Condult Enclosure


AND INFLIED. THERE ARE NO INFLIED WARANTED OF NERCHARMENTY OR OF FITNESS FOR A PARTICULAR PLAROGE FOR BOODS COVERED HEREUNDET. THIS EURIEDE LINETE WARANTY IS IN LIEU OF AND EXCLUDES ALL OTHER REPRESENTATIONS MADE BY ADVERTISEMBATE AND ALL

Brywe heredowige the Buyer's for some and sole remedy on account of or in heregy to the futurgame of monconforming or defective. Replacement thereof as provedent, indicate any location of the factle for the cost of may enclanded on any such meterla, or for any applicate, Defect, indirect, indirect or consecutive and sole by meaning of a heread for that if each low conforming or defective.










ES Series Adsorbers

EnviroSupply & Service's liquid and vapor phase activated carbon adsorbers are designed to provide an efficient an economical solution to your filtration needs. The ES V & L series are designed as a low cost, vapor adsorber that can easily be put into service. The ES series adsorbers are designed for a maximum pressure of 15 psi, a vacuum of up to 15" mercury, and are designed to hold from 500 to 2000 lbs of activated carbon.



- Shipped with carbon and ready for immediate service.
- Available for sale or rent.

a wide variety of standard designs and the ability to "build to your specs", EnviroSupply & Service can provide you with simple and cost effective solutions to your treatment needs. Let us help you on your next project. Our 10 stores spanning the nation provide you with local service and support. Call us today!

Sacramento, CA

Fountain Valley, CA



Call 1-800-201-8150 or contact your local office. Visit us at www.envirostore.com !

Convertine : Fire Forest Stanting Hester's

VAC 208.

240

480

480

* Div

For information about choosing a heater, see page 522.

Hazardous-Location Convection Heaters

Approved for Divisions 1 and 2, Class 1, Groups B, C, and D. Heating element has a copper sheath and aluminum fins for Safe and efficient operation. Cabinet is 16-ga. steel. Fur-nished with wall mounting bracket. Have 6" wire leads and operate on 60 Hz, 1 phase. UL listed and CSA certified.



DPST hazardous location thermostat is adjustable for local control within the hazardous location. Mounts to the wall.

Watts	BTU/Hr.	Amps	Ht.	Wd.	Dp.	Each
120 VAC	C Heaters					
						1752K43\$701.75
1,800	6,141	15	18″	34"	8″	1752K21 719.30
208 VA	C Heaters					
<u> </u>	2,729	3.8	18″		8″	1752K45 719.30
						1752K47 956.14
7,600	25,932	36.5	18″	58"	8″	1752K4814 56.14
240 VAC	C Heaters					
						1752K49 719.30
						1752K22 719.30
3,600	12,283	15	18″	34″	8″	1752K24 956.14
7,600	25,932	31.7	18"	58″	8″	1752K26 1493.88
480 VAC	C Heaters					
3,600	12,283	7.5	18″	34"	8″	1752K25 956.14
7,600	25,932	15,8	18″	58″	8″	1752K27 1493.88
DPST H	lazardous	Location	Therm	iostat		1752K34 202.38

Wall-Mount Fan-Forced Heaters

We offer these heaters in two different sizes to fit almost any wall opening. They can also be surface mounted using mounting frames (sold separately below). They feature built-in thermostats and overheat safety shutoff. They



When operating on 208 VAC, the heat out-put (BTUS) and the wattage will decrease by 25%.

					IVNU 3120	
Watts*	BTU/Hr.	cfm	Ht.	Wd.	Dp.	Each
120 VA	C PRETAR	1.62.62		12.8	and the second	
Mid SI: 1,500		N/A	16"	13″	3¥4"1726K7	11\$120.77
208/24	O VAC	199	na politika na Liziona da	enerator est. Si estaria		
Mid Si						
2,000	6,826	N/A	16″	13"	3¾"1726K7	21 119.61
Full Sta						
3,000	10,239	N/A	19¥ıe	"16"	3¾"1726K8	32 • 186.27
4,000	13,652	N/A	19∛ıa	"16"	3¾4″ 1726K8	53 198.08
Surface	Mountin	g Fran	les	- 100-000-0-1-5 1-5-1-5-1-5-5-5-5-5-5-5-5-5-5-5-5-5	See. F. States	net de la Martin de La Com
For M	id-Size He	aters			1726K6	11 22.84
For Fi	ull-Size He	aters			1726K6	19 39.22
+ Divide	by voltage	e to col	nvert to	amos	 4 000 watts @ 	277 volts

Divide by voltage to convert to amps. • 4,000 watts @ 277 volts

Ceiling-Mount Fan-Forced Heaters

These heaters slip onto standard 2 ft.×2 ft. grids of suspended cellings to send heat di-rectly below. Use the recess mounting kit (sold separately below) to mount heaters in plaster/drywall cellings. Heaters require a mounting depth of 91%¹. Adjustable louvers di-rect air flow. Heaters have overheat safety shutoff and 6" wire leads. Run on 60 Hz, 1 phase. UL listed and CSA certified.



•	208 VAC	240 VAC
Watts* BTU/Hr. cfm	Each	Each
3,000 10,236 425	1998K13\$647.93	1998K14 \$647.93
5,000 17,060 425	1998K15 732.63	1998K16 732.63
		Each
Recess Mounting Kit		1998K22 \$80.00
Wall-Mount Thermostat		1998K19 34.83
* Divide by voltage to	convert to amos.	

McMASTER-CARR

High-Output Mobile Fan-Forced Heaters

A high-output heating element combined with a powerful fan results in superior heat coverage. Heaters pivot to direct heat where it's needed. A steel stand with 10' dia. wheels provides mobility. Include adjustable thermostat and overheat safety shutoff. Op-erate on 60 Hz, 3 phase. UL listed and CSA certified excent where netd certified, except where noted. 15,000-watt heaters are 39" Ht. × 27¹/4"

Wd. x 201/4" Dp. **30,000-watt** heater is 39" Ht. x 271/4" Wd. x 22" Dp. Power cords are 25-ft. long and are fur-nished with ring terminals (plugs sold sepa-

ratel

ly on pages 678-683). ∶Watts×BTU/Hr.cfm	Heaters Each	Power Cords (Without Piug) Each
15.000. 51.182800		1714K93 + \$149.12
15,000 51,182800		1714K93 ♦ 149.12
15,000 51,182800		1 714K92 66.67
30,000102,364800. vide by voltage to conv		1714K93 ♦ 149.12

Divide by voltage to convert to amps.
 Power cord not CSA certified.

Portable/Multi-Mount Fan-Forced Heater

Multi-mount bracket acts as a floor Multi-mount bracket acts as a floor stand, or use for mounting heater to the wall or ceiling. Heater features a built-in adjust-able thermostat and overheat safety shut-off. Includes a 6-ft. long, 30-amp, 3-wire cord with NEMA 6-30 plug. Operates on 240 VAC, 60 Hz, 1 phase; also operates on 208 VAC (heat output is reduced 25%). UL and C-ILI listed and C-UL listed.



Watts * BTU/Hr. cfm Ht. Wd. Dp. 5,600 19,107 262 151/2" 101/2" 13" Divide by voltage to convert to amps.

240V Rugged-Duty Fan-Forced Heater

This 2 heater 2½ time 1500-wa on 208 reduced heavy-g baked-e	240 volt (60 safely ger es the heat att heater. volts, but h i by 25% auge stee enamel finis th NEMA 6	Hz, 1 pl nerates of a 120 It also eat outp , Heat with a sh. A 6-1	over volt, runs out is er is a red it. long,	20-amp, uded, UL	NEMA 6-20 Plug 3-wire listed.		
Watts	BTU/Hr.	cfm	Ht.	Wd.	Dp.		Each
4,000	13,648		123/4"	105/8*	.10" 1	704K32	\$117.65
Wall/Ce	iling Moun	ting Bra	cket		1	704K89	42.33

Low-Profile Fan-Forced Heaters

These slim-line heaters are designed for horizontal use and fit under counters, in soffits, and in other recessed locations. Size is 31/2 Ht. $\times 141/4$ Wd. $\times 8^{\circ}$ Dp. (required open-ing size is 33/2 Ht. $\times 141/2$ Wd. $\times 9^{\circ}$ Dp.). They come wired for 1500 watts (can be wired for



750 watts). Run on 60 Hz, 1 phase. Come with a thermostat (SPST for 120 VAC; DPST for 240 VAC). UL listed. Offered in 120 and 208/240 VAC. When running on 208 VAC, heat output is reduced by 25%.

208/240 VAC Each

Watts* BTU/Hr. cfm Each 1500/750..5118/2559..85....17045K72..\$136.82 17045K82..\$143.85 Divide by voltage to convert to amps.

120 VAC

Low-Voltage DC Mini Fan-Forced Heaters


Perfect for vehicles that are slow to warm or for extra heat on the coldest days. Have connections for hardwir-ing to the vehicle's battery and come with a multi-mount bracket for easy installation. They have a built-in ad-justable thermostat, remote on/off switch, overheat safety shutoff, 30-amp wiring harness, and fuse.



u	and on	, oo amp		1.001110	50, a.,	a 1650.	
VDC	Watts	BTU/Hr.	cfm	Ht.	Wd.	Dp.	Each
12	.300	.1100	.102				.17075K71\$99.15
24	.600	.2200	.102		51/4"	*	17075K81 149.85



Each



WARNINGS

- Improperty installed luminaires can cause shock, electrocution and fire hazards.
- Install, operate, and maintain to meet all applicable Codes and Ordinances.
- Disconnect power before installation or servicing.
- Selected ballast voltage must match supply voltage.
- Protect all unused lead ends with approved insulators.
- Handle and secure so luminaire cannot fall.
- · All servicing should be done by qualified personnel.
- Check the operating temperature limits marked on luminaire prior to installation to be sure it conforms to environmental restrictions identified by local inspection authorities and NEC classifications.
 - Ground luminaire to supply ground.
- Read and follow the lamp manufacturer's warning and use this information before installing or relamping this luminaire.
- All installations and wiring should be per National Electrical Code (NEC) and local rules and regulations.
- Installing electricians are responsible for evaluating local conditions and ensuring safe operation.

RIGID PENDANT MOUNTING - LW2C FIXTURE SERIES

- 1. Open splice compartment on top of fixture (remove two screws).
- Attach focure to 3/4" threaded conduit (supplied by customer) with supply wire hanging out. Use a suitable thread lubricant to seal all threaded joints against water leakage (for wet locations).
- 8. Tighten setscrew located inside splice compartment to secure fixture.
- Connect supply wires to correctly marked fixture wires corresponding to the supply voltage. Connect fixture ground wire to supply ground. Tuck all connected wires and extra wires back into splice compartment.
- 5. Close splice compartment (with two screws).

SURFACE THRU-WIRE MOUNTING - LW2C FIXTURE SERIES

- 1. Remove closure plug(s) from side conduit opening(s) in top casting.
- 2. Close top conduit opening with a removed closure plug.
- 3. Open splice compartment (remove two screws).
- 4. Attach fixture to 3/4" threaded conduit. Use a suitable thread sealant to seal all threaded joints against water leakage (for wet locations), including top conduit opening.
- Pull supply wires and attach them to the correctly marked fixture wires corresponding to the supply voltage. Connect fixture ground wire to supply ground. Tuck all connected wires and extra wires back into splice compartment.
- 6. Close splice compartment (with two screws).
- Support fixture by conduit damps placed within 18" of top splice casting, (NECPAR370-13).

CAVE THIS INSTRUCTION SHEET FOR FUTURE USE AND REFERENCE.




Hubbell Lighting, Inc. A Subsidiary of Hubbell Incorporated 2000 Electric Way Christiansburg, VA 24073-2500 (540) 382-6111 FAX (540) 382-1526

GENERAL INFORMATION

- it is not necessary to remove the refractor bottom to install and wire the luminaire. Lamp is usually supplied installed in the luminaire.
- This luminaire is suitable for wet location applications in ambients of 40°C.
- Read the hazardous location label on the luminalre housing to find the temperature code information. Make sure this temperature code is less than the NEC classification rating for the particular installation location.
- Luminalizes are not intended for use in orientations beyond that normally provided by the mounting type assembly. Operation beyond these orientations will void the temperature codes listed on the label.

GENERAL INSTALLATION INFORMATION

- Use a waterproof pipe joint compound, not included, for all wire entries and plugged entries into any mounting type assembly.
- Luminaire shipped assembled with ceiling and pendant mounting types and shipped partially assembled with wall and stanchion mountings. Assemble these before installation.
- Allow a minimum of 6" supply wire to extend outside splice cover for proper hookup.



WALL BRACKET MOUNTING - LW2B FIXTURE SERIES

- Fasten wall mounting box to mounting surface with four 1/4" diameter fasteners (supplied by customer). Wall mount box can be oriented as shown or any other orientation as convenient.
- 2. Remove closure plug(s) from conduit opening(s) as required, to install 3/4" threaded conduit (supplied by customer).
- 3. Open splice compartment cover (remove two screws).
- 4. Thread fixture and its 1-1/4" pipe extension to wall mount box as shown. Use a suitable thread sealant to seal all threaded joints against water leakage (for wet locations). Make sure the fixture wires extend into the wall mount box.
- 5. Tighten the setscrews to secure the fixture in vertical position (two screws).
- Pull supply wires and attach them to the fixture wires. Make sure the voltage for the fixture wires agrees with the supply voltage. Connect fixture ground wire to supply ground. Tuck connected wires back into splice compartment.
- 7. Close splice compartment (with two screws).

STANCHION MOUNTING - LW2S FIXTURE SERIES

- Thread stanchion mount casting and 1-1/4" pipe extension to fixture as shown. Use a suitable thread sealant to seal all threaded joints against water leakage (for wet locations). Make sure the fixture wires extend into the stanchion mount casting.
- 2. Open splice compartment (remove two screws).
- 3. Thread fixture and mounting assembly to an upright 1-1/4" threaded pipe (supplied by customer).
- 4. Orient fixture assembly and tighten all setscrews (three screws).
- 5. Pull supply wires and attach them to the fixture wires. Make sure the voltage for the fixture wires agrees with the supply voltage. Connect fixture ground wire to supply ground. Tuck all connected wires back into splice compartment.
- 6. Close splice compartment (with two screws).


RELAMPING FIXTURE


- Check to make sure the HiD lamp to be installed is the correct type and wattage for the fixture. Important information regarding lamp type and wattage is given on the fixture label.
- 2. Insert lamp into socket and hold socket while threading lamp until tight.
- 3. Wipe fingerprints and grime off the lamp.

MAINTENANCE AND CLEANING

- 1. Periodically brush the dust off of the horizontal surfaces of the ballast housing and clean the refractor and reflector with a mild, non-abrasive scap, water or glass cleaner using a clean soft cloth.
- Maintain a group or section cleaning and relamping program to maximize the lumen output of the fixtures and optimize the cost per lumen generated.
- CAUTION: Do not perform routine maintenance or cleaning while the fixture is energized.

SAVE THIS INSTRUCTION SHEET FOR FUTURE USE AND REFERENCE.





TROUBLESHOOTING A NON-OPERATING FIXTURE

- 1. Make sure that a proper lamp is installed and that it is not old and wom out.
- 2. Check the line voltage at the fixture to see if it is correct and within line voltage tolerance.
- 3. Check to see if fixture is wired property to the incoming power leads.
- 4. Check to see if the fixture is grounded property.
- If all the above have been checked, and the fixture does not operate property, contact your local Hubbell representative, distributor or agent for further troubleshooting.


TOP LUMINAIRE RETAINER

- Angled bracket on top of fixture housing can be used to attach a top luminaire retaining chain.
- Attach chain with S-hook to bracket. Loop chain around suitable structural member for support.
- Reduce stack in chain by looping chain several times around structural member or by positioning the retaining S-hook in a proper place on the supporting chain.
- Close off both S-hooks with large pliers to secure safety chain attachment in place.



Hubbell Lighting, Inc. A Subsidiary of Hubbell Incorporated 2000 Electric Way Christiansburg, VA 24073-2500 (540) 382-6111 FAX (540) 382-1526

268-1152-9901



- Les luminaires montés de façon incorrecte peuvent causer des risques de choc, d'électrocution et d'incendie.
- Installer, utiliser et entretenir en conformité avec les prescriptions des codes en viqueur.
- Mettre hors tension avent de faire le montage ou la maintenance.
- La tension de ballast choisie doit être la même que la tension d'alimentation. Recouvrir les extrémités de tous les conducteurs non utilisés avec des Isolateurs hornologués.
- Manipuler et assujettir le luminaire de façon à ce qu'il ne puisse pas tomber.
- La maintenance doit être effectuée par du personnel qualifié.
- Vérifier les limites de température indiquées sur le luminaire avant le montage pour s'assurer qu'elles sont conformes aux restrictions environnementales imposées par les autorités locales et les classifications du Code canadien de l'électricité.
- Établir la mise à la terre du luminaire à la mise à la terre du système.
- Lire et respecter les avertissements du fabricant de l'ampoule avant d'installer ce luminaire ou avant d'en changer l'ampoule.
- Le montage et le câblage doivent être conformes aux prescriptions du Code canadien de l'électricité et aux codes locaux en vigueur.
- L'électricien installateur est responsable de l'évaluation des conditions loales et d'assurer un fonctionnement sûr.

MONTAGE EN PENDENTIF RIGIDE - LUMINAIRES DE LA SÉRIE LW2C

- 1. Ouvrir le compartiment de connexion sur le dessus du luminaire (enlever 2 vis).
- Fixer le luminaire sur le conduit fileté de 19 mm (fourni par le client) en laissant les câbles d'alimentation pendant. Utiliser un lubrifiant approprié pour sceller tous les joints filetés contre les inflitrations d'eau (dans les endroits mouillés).
- 3. Serrer les vis de blocage à l'intérieur du compartiment de connexion pour assujettir le luminaire.
- 4. Raccorder les câbles d'alimentation aux fils marqués du luminaire correspondant à la tension d'alimentation. Raccorder le fil de MALT du luminaire à la mise à la terre du système. Insérer tous les fils connectés et non utilisés dans le compartiment de connexion.
- 5. Refermer le compartiment de connexion (avec deux vis).

MONTAGE EN SURFACE, CÁBLAGE EN TRAVERSÉE - LUMINAIRES DE LA SÉRIE LW2C

- Enlever l'obturateur de l'ouverture de conduit sur le côté de la pièce supérieure,
- 2. Fermer l'ouverture de conduit du dessus avec l'obturateur enlevé précédemment.
- Ouvrir le compartiment de connexion (enlever deux vis).
- Fixer le luminaire sur le conduit fileté de 19 mm. Utiliser un scellant approprié pour sceller tous les joints filetés, y compris l'ouverture de conduit sur le dessus, contre les infiltrations d'eau (dans les endroits moulilés).
- 5. Tirer les câbles d'alimentation et les raccorder aux fils du luminaire qui correspondent à la tension d'alimentation. Connecter le fil de MALT du luminaire à la mise à la terre de l'alimentation. Insérer tous les fils connectés et non utilisés dans le compartiment de connexion.
 - Fermer le compartiment de connexion (avec deux vis). 6.
 - Supporter le luminaire au moyen de brides de conduit placées à moins de 15 cm de la bolte de connexion.


Hubbell Lighting, Inc. A Subsidiary of Hubbell Incorporated 2000 Electric Way Christiansburg, VA 24073-2500 (540) 382-6111 FAX (540) 382-1526

RENSEIGNEMENTS GÉNÉRAUX

- Il n'est pas nécessaire d'enlever le fond du réfracteur pour installer et câbler le luminaire. Le luminaire est normalement fourni avec l'ampoule installée.
- Ce luminaire convient aux endroits mouillés avec une température ambiante de 40ºC.
- Lire l'étiquette placée sur le bottier du luminaire concernant les endroits dangereux pour trouver le code de température. S'assurer que ce code de température est inférieur à la classification du Code canadien de l'électricité pour l'endroit du montage.
- L'orientation du luminaire n'est pas prévue au-delà des limites normalement permises par le dispositif de fixation. Une orientation au-delà de ces limites annulera le code de température indiqué sur l'étiquette.

DIRECTIVES GÉNÉRALES DE MONTAGE

- Utiliser une pâte de scellement imperméable pour tuyau, non fournie, pour toutes les entrées de câble et les prises d'entrée dans tout type de système de fixation.
- Le luminaire est livré avec les accessoires de suspension au plafond et en pendentif tout assemblés. Il est livré avec les accessoires de fixation au mur et sur poteau partiellement assemblés. Compléter l'assemblage avant le montage.
- Allouer un minimum de 15 cm de câble d'alimentation à l'extérieur de la boîte de connexion pour permettre le raccordement approprié.



CONSERVER CETTE NOTICE POUR RÉFÉRENCE ET USAGE FUTUR

MONTAGE SUR BOITE MURALE - LUMINAIRE SÉRIE LW2B

- Fixer la botté murale sur la surface avec quatre attaches de 6 mm de diamètre (fournies par le client). La botte murale peut être orientée tel quilitustré ou autrement selon les besoins.
- 2. Enlever les obtunateurs de l'ouverture de conduit selon les besoins et installer une conduit de 19 mm (fourni par le client).
- 3. Ouvrir le compartiment de connexion (enlever deux vis).
- 4. Visser le luminaire et son tuyau de 32 mm à la boîte murale. Utiliser un scellant approprié pour sceller tous les joints filetés, y compris l'ouverture de conduit sur le dessus, contre les infiltrations d'eau (dans les endroits mouillés). S'assurer que les câbles du luminaire solent tirés dans la boîte.
- 5. Serrer les vis de blocage pour fixer le luminaire dans la position verticale.
- 6. Tirer les cables d'alimentation et les connecter aux cables du luminaire. S'assurér que la tension du luminaire correspond à la tension d'alimentation. Connecter le fil de MALT du luminaire à la mise à la terre de l'alimentation. Insérer tous les fils connectés dans le compartiment de connexion.
- 7. Refermer le compartiment de connexion (avec deux vis).

MONTAGE SUR POTENCE - LUMINAIRE SÉRIE LW2S

- Visser la potence et le tuyau prolongateur de 32 mm dans le luminaire tel qu'illustré. Utiliser un scellant approprié pour sceller tous les joints filetés contre les infiltrations d'eau (dans les endroits moutilés). S'assurer que les fils du luminaire sont tirés jusqu'au compartiment de connexion.
- 2. Ouvrir le compartiment de connexion (enlever deux vis).
- Visser le luminaire et l'ensemble de fixation sur un tuyau vertical fileté de 32 mm (fourni par le client).
- 4. Orienter le luminaire et serrer toutes les vis de biocage (trois vis).
- Tirer les câbles d'alimentation et les connecter aux câbles du luminaire. S'assurer que la tension du luminaire correspond à la tension d'alimentation. Connecter le fil de MALT du luminaire à la mise à la terre de l'alimentation.
- Insérer tous les fils connectés dans le compartiment de connexion. 6. Refermer le compartiment de connexion (avec deux vis).
- o. Melennoi le compannient de comiexion (avec deux vis).


REMPLACEMENT DE L'AMPOULE


- S'assurer que la tension et la puissance de l'ampoule DHI de remplacement conviennent au luminaire. Des renseignements importants concernant le type et la puissance de l'ampoule sont donnés sur l'étiquette.
- insérer l'ampoule dans la douille. Tenir la douille en vissant l'ampoule solidement.
- 3. Enlever les empreintes de doigts et la saleté de l'ampoule.

MAINTENANCE ET NETTOYAGE

- Brosser et épousseter régulièrement les surfaces horizontales du compartiment du ballast et nettoyer le réflecteur et le réfracteur avec un savon doux non abrasif, de l'eau ou un nettoyant pour verre, avec un chiffon doux.
- Établir un programme de maintenance et de remplacement d'ampoule par groupe ou par section afin de maximiser la luminosité des luminaires et optimiser le coût par lumen produit.
- ATTENTION Ne pas effectuer de maintenance de routine ou de nettoyage alors que le luminaire est sous tension.

CONSERVER CETTE NOTICE POUR RÉFÉRENCE ET USAGE FUTUR





RECHERCHE DE PANNE SUR UN LUMINAIRE QUI NE FONCTIONNE PAS


- 1. S'assurer que l'ampoule installée est celle qui convient et qu'elle n'est pas vieille ni usée.
- Vérifier la tension d'alimentation au luminaire pour s'assurer qu'elle est la bonne et en decà des tolérances.
- 3. Vértfier que les raccordements aux câples d'alimentation sont corrects.
- 4. S'assurer que le luminaire est blen mis à la terre.
- 5. Si tout ce qui précède a été vérifié et que le luminaire ne fonctionne pas correctement, communiquer avec le représentant local, le distributeur ou l'agent de Hubbell pour une intervention plus élaborée.

RETENUE DU LUMINAIRE

- La bride coudée sur le dessus du boîtier du luminaire peut être utilisée pour y fixer une chaîne de retenue.
- Attacher la chaîne à la bride au moyen d'un crochet en «S». Enrouler la chaîne autour d'une poutre de la structure pour établir le support.
- Tendre la chaîne en l'enroulant plusleurs lois autour de la poutre ou en plaçant le crochet en «S» dans un maillon qui convient.
- Refermer le crochet en «S» avec des pinces pour retenir la chaîne en place.



Hubbell Lighting, inc. A Subsidiary of Hubbell Incorporated 2000 Electric Way Christiansburg, VA 24073-2500 (540) 382-6111 FAX (540) 382-1526



Código(s) de lámparas:

_____ Instalado por: _____

__ Fecha : _

ADVERTENCIA

- Las luminarias que no estén instaladas correctamente pueden provocar choques, electrocución y riesgos de incendio.
- Instalar, hacer funcionar y mantener de conformidad con todos los códigos y reglamentos aplicables.
- Desconectar la energía antes de instalar o reparar.
- La tensión de reactancia elegida debe corresponder a la tensión de alimentación.
- Proteger todos los extremos de cable no utilizados con alslantes aprobados.
- Manipular y fijar de modo que la luminaria no pueda caerse.
- Todo servicio de mantenimiento debería estar a cargo de personal competente.
 Verificar los límites de temperatura de funcionamiento marcados en la luminaria.
- antes de Instalarla, para asegurarse de que se ajusta a las límitaciones ambientales determinadas por las autoridades locales de inspección y las clasificaciones de la Norma oficial mexicana.
- Conectar a tierra la luminaria mediante el cable de tierra de la alimentación.
- Leer y respetar los avisos del fabricante de las lámparas y utilizar esa información antes de instalar o cambiar las lámparas de esta luminaria.
- Todas las instalaciones y cableados deberían ajustarse a la Norma oficial mexicana y a los reglamentos locales.
- Los electricistas instaladores son responsables de evaluar las condiciones locales y garantizar un funcionamiento seguro.

ELIACIÓN COLGANTE RÍGIDA - SERIE DE ARTEFACTOS LW2C

Abrir el compartimiento de empaime en la parte superior del artefacto (quitar dos tornillos).

- 2. Unir el artefacto al conducto roscado de 19 mm (provisto por el cliente), de modo que los cables de alimentación queden colgando afuera. Usar un lubricante de rosca aproplado para sellar todas las juntas roscadas contra las filtraciones de agua (en sitios mojados).
- Ajustar el tornillo de apriete situado dentro del compartimiento de empaime para fijar el antefacto.
- 4. Conectar los cables de alimentación con los cables del artefacto correctamente marcados correspondientes a la tensión de alimentación. Conectar el cable de tierra del artefacto al cable de tierra de la alimentación. Volver a pasar todos los cables conectados y excedentes dentro del compartimiento de empaime.
- 5. Cerrar el compartimiento de empaime (con dos tomilios).

FUACIÓN EN CABLE PASANTE DE SUPERFICIE - SERIE DE ARTEFACTOS LW2C

- Quitar el (los) tapón(es) de la(s) abertura(s) lateral(es) para conducto en la pieza fundida superior.
- 2. Cerrar la abertura superior para conducto con uno de los tapones retirados.
- 3. Abrir el compartimiento de empalme (quitar dos tomillos).
- 4. Unir el antefacto a un conducto roscado de 19 mm. Usar un sellador de rosca apropiado para sellar todas las juntas roscadas contra las filtraciones de agua (en sitilos mojados), incluso la abertura superior del conducto.
- 5. Jalar todos los cables de alimentación y uniños a los cables del artefacto correctamente marcados correspondientes a la tensión de alimentación. Conectar el cable de tierra del artefacto al cable de tierra de la alimentación. Volver a pasar todos los cables conectados y excedentes dentro del compartimiento de empalme.
- B. Cerrar el compartimiento de empalme (con dos tomilios).
- Sostener el artefacto mediante grapas de conducto colocadas a menos de 45 cm de la pleza fundida de empalme superior (Norma oficial mexicana, 370-13).

CONSERVAR ESTA PÁGINA DE INSTRUCCIONES PARA USO Y REFOREN CIA FUTUROS




Hubbell Lighting, Inc. A Subsidiary of Hubbell Incorporated 2000 Electric Way Christiansburg, VA 24073-2500 (540) 382-6111 FAX (540) 382-1526

INFORMACIÓN GENERAL:

- No es necesarlo retirar la base del refractor para instalar y cablear la luminaria. Generalmente la lámpara se provee instalada en la luminaria.
- Esta luminaria es apropiada para aplicaciones en lugares mojados, en ambientes de 40°C.
- Leer la etiqueta sobre lugares peligrosos en la caja de la luminaria, donde se encontrará información acerca de la clave de temperaturas. Asegurarse de que esa clave de temperaturas sea inferior a la clasificación nominal de la Norma oficial mexicana para ese sitio de instalación en particular.
- Las luminarias no están destinadas a usarse en orientaciones que excedan la provista normalmente por el tipo de montaje. El funcionamiento al margen de esas orientaciones anulará las ciaves de temperaturas enumeradas en la etiqueta.

INFORMACIÓN GENERAL SOBRE LA INSTALACIÓN:

- Aplicar un compuesto sellador impermeable para cañerías (no incluido) en todas las entradas de cables y enchufes, para cualquier tipo de fijación.
- Las luminarias se entregan montadas para los tipos de fijación al techo y colgante, y parcialmente montadas para la fijación a la pared y en poste. Montar estas últimas antes de la instalación.
- Dejar que el cable de alimentación sobresalga 15 cm, como mínimo, fuera de la tapa de empalme, para acoplarlo debidamente.





FAX (540) 382-1526 1113-282 (013) Christiansburg, VA 24073-2500 2000 Electric Way A Subsidiary of Hubbell Incorporated Hubbell Lighting, Inc.

1066-2011-892

SORUTUR CONSERVAR ESTA PAGINA DE INSTRUCCIONES PARA USO Y REFERENCIA

·ດຽຍຊາຍິງອົກອຸດອອອອອ CURADO: No proceder al mantenimiento o timpleza de rutina mientras el arretacio

- 31 consierieg nemu
- bena meximizar el rendimiento lumínico de los artefactos y optimizar el costo por Neuseuer un programa de limpieza y cambio de lamperas por grupo o sección, 72 presivo, agua o itmpiavidrios, empleando un paño limplo.

cels de reactancia y limplar el retractor y el reflector con un detergente suave no Quitar periódicamente el polvo acumulado en las superiicles horizontales de la AZEIGHELI YOTNETIMINETIMAM

- Limpier las huellas digitales y la suciedad de la lámpara. 'n
 - emni ebeup eup avan
- meentar la lámpara en el portalámparas y sujetario mientras se enrosca la lámpara 3 importante sobre el tipo y potencia de la lámpara.
- apropiados para el artefacto. En la etiqueta del artefacto se ofrece información Asegurarse de que la lámpara HID que se va a instalar es del tipo y potencia
- - PARA CAMBIAR LA LÁMPARA DEL ARTEFACTO
 - Cerrar el compartimiento de empaime (con dos tornillos).
 - .emisqme eb

1

- alimentación. Volver a peser todos los cables conectados dentro del compartimiento alimentación. Conectar el cable de tiena del artefacto al cable de tiena de la de que la tensión de los cables del artefacto corresponda a la tensión de
- Jelar los cables de alimentación y conectarlos a los cables del artefacto. Asegurarse '9 Orientar el conjunto del artefacto y ajustar todos los tornilios de apriete (tres tornilios).
- mm (provisto por el cliente).
- Enroscar el artefacto y el conjunto de fijación a un caño vertical con rosca de 32 .Ε Abrir la tapa del compartimiento de empalme (quitar dos tornitios).
 - 5 ..eteoq ne nökselit anaq
- sitios mojados). Asegurarse de que los cables del artefacto entren a la pleza fundida ne) auga eb serior para seriar todas las juntas roscadas contra las filtraciones de agua (en mm al arhefacto, como se muestra en el diagrama. Usar un sellador de rosca Enroscer la pleza fundida para fijación en poste y la protongeción de ceño de 32
- FUNCTION SOBRE POSTE SERIE DE ARTEFACTOS LW2S
 - - .7


 - Cerrar el compartimiento de empalme (con dos tormillos).
 - .embelme.
- alimentación. Volver a pasar todos los cables conectados dentro del compartimiento
- '9
- alimentación. Conectar el cable de tierra del artefacto al cable de tierra de la
- Vertical (dos tornillos).
- de que la tensión para los cables del artefacto corresponda a la tensión de Jalar los cables de alimentación y conectarios a los cables del artetacio. Asegurarse
- Ajustar los tornillos de apriete para colocar firmemente el artefacto en posición
- '9 Asegurarse de que los cables del artefacto entren en la cala de fijación mural.
- sellar todas las juntas roscadas contra las filtraciones de agua (en sitios mojedos). mural, como se muestra en el disgrama. Usar un sellador de rosca apropiado para

- Enroscer el artefacto y su prolongación de caño de 32 mm en la caja de fijación Abrir la tapa del compartimiento de empalme (quitar dos tornitios).
- Quitar el (los) tapón(es) de la(s) abertura(s) para conducto según sea necesario,
 - para instalar un conducto roscedo de 19 mm (provisto por el cliente). 5

HINGION CON BRAZO MURAL - SERIE DE ARTEFACTOS LW28

de reten de 6 mm de diametro (provistos por el cliente). La caja de fijación mural Moritar la caja de fijación mural sobre la superficie de fijación con cuatro tomitios

- etneinevnoo emitse es eup
- puede orientarse como se muestra en el diagrama o en cualquier otra orientación
- CAJA DE FUACION MURAL



TAPÓN DE CIERRE

EMPALME

BO ARA

6

- la sugara de que la lámpara instalada se abrigada y de que no es antigua la construction de la la construction de la constructi PARA REPARA DESPERFECTOS EN UN ARTEFACTO QUE NO FUNCIONE
- Verificar la tensión de línea en el artefacto, para comprobar si es correcta y está 2 .soalseg alse

Cerrar los extremos del gancho en S con tenazas grandes para que la cadena de

estructural o colocando el gancho en 5 que la sujeta en una posición apropiada El la cadena queda floja, ajustaria enrofiándola varias veces en torno al elemento

Enganchar la cadena en el estabón con un gancho en S. Enlazar la cadena

El estabón filo sobre la caja del artefacto permite enganchar una cadena para

representante, distribuidor o agente de Hubbell para obtener solución al problema. todo to antertor, si el artetacto no funciona correctamente, comunicarse con el Verificar al el artefacio está debidemente conectado a tierra. Una vez comprobado

Verificar si el artefacto está correctamente cableado a los conductores de entrada

alrededor de un elemento estructural, para asegurar el sostén.

ROIFIERD AT NA ALINA ALINA AL PO NOCIEURS

dentro de la toleranda de la tensión de línea.

seguridad quede firme en su sitio.

BODIE IS COORDS.

enjetar la luminaria.

.ເຮຍຫຼາຍກອ ອບ

۰,

'E

5

11

۰,

.Е

Propeller Wall

Propeller Wall Fans

INSTALLATION, OPERATION, AND MAINTENANCE MANUAL

This publication contains the installation, operation and maintenance procedures for standard units of the *Propeller Wall and X.Stream- Propeller Wall Fans.*

COOK

·APD	·APB
·SPB	•AWBS/AWBE
·EWBSM	-SPD
·SWDS	·EWB
•XLW/XMW/XLWS/XMWS	·EWD
·XLP/XMP/XLPS/XMPS	•EPB
·XLWHS/XMWHS	∙EPD
•XLWH/XMWH	•SWD
•XLPH/XMPH	·XLPHS/XMPHS

Carefully read this publication prior to any installation or maintenance procedure.

Loren Cook catalog, *Propeller Wall* and *X.Stream*, provides additional information describing the equipment, fan performance, available accessories and specification data.

For additional safety information, refer to AMCA publication 410-96, Safety Practices for Users and Installers of Industrial and Commercial Fans.

All of the publications listed above can be obtained from Loren Cook Company by phoning 417/869-6474, extension **166**; by FAX at 417/832-9431; or by e-mail at info@lorencook.com.

For information and instructions on special equipment, contact Loren Cook Company at 417/869-6474.

Receiving and inspection

Carefully inspect the fan and accessories for any damage and shortage immediately upon receipt of the fan.

- Turn the propeller by hand to ensure it turns freely and does not bind.
- Record on the *Delivery Receipt* any visible sign of damage.

Handling

Lift propeller wall fans by attachment to the power assembly or by the shipping carton. Never lift by the shaft, motor or housing.

Storage

If the fan is stored for any length of time prior to installation, coat the shaft with grease or a rust preventative compound. Store it in its original shipping crate and protect it from dust, debris and the weather.

Rotate the wheel several revolutions every three to five days to keep a coating of grease on all internal bearing parts.

The entropy of the pairs of each of the pairs. Secure of entropies, and analy of the pair of the second sec

一、行业不可能的 电电压转移机 电子分析仪 的复数可能性的 网络

Installation

Fans mounted to a wall require a different wall opening size than fans mounted in wall collars or wall housings. For specific dimensions, refer to the submittal drawing for the specific fan type.


Motor Installation

To prevent damage to the fan during shipping, motors 5 HP and larger, and extremely heavy motors (cast iron or severe duty) are shipped loose and must be field mounted by bolting the motor on the motor mounting plate in the existing slots.


The motor should be mounted in order that the motor plate is between the fan shaft and the motor shaft.

- a. Remove the motor plate mounting bolts and motor plate.
- b. Remove the motor mounting bolts from the motor plate.
- c. Mount the motor to the motor plate aligning the appropriate holes.
- d. Place the motor plate on the power assembly and reinstall the mounting bolts.

All Statistical and a second secon







Belt and Pulley Installation

Belt tension is determined by the sound of the belts when the fan is first started. The belts will produce a loud squeal, which dissipates after the fan is operating at full capacity. If belt tension is too tight or too loose, lost efficiency and damage can occur.

Do not change the pulley pitch diameter to change tension. The change will result in a different fan speed.

- a. Loosen the motor plate adjustment nuts on motor base and move motor plate in order that the belts can easily slip into the grooves on the pulleys. Never pry, roll, or force the belts over the rim of the pulley.
- b. Adjust the motor plate until proper tension is reached.
 For proper tension, a deflection of approximately 1/4" per foot of center distance should be obtained by firmly pressing the belt. Refer to *Figure 1*.
- c. Lock the motor plate adjustment nuts in place.
- d. Ensure pulleys are properly aligned. Refer to *Figure 2*.




Figure 2

Pulley Alignment

Pulley alignment is adjusted by loosening the motor pulley setscrew and by moving the motor pulley on the motor shaft or by moving the entire motor along the motor mounting bracket




Figure 2 Illustrates correct and incorrect pulley alignment. A recommended method of inspecting the pul-Figure 3

ley alignment is shown in Figure 3. With the shorter leg of a carpenter's square or other straight edge lying along the case of the motor, adjust the position of the motor pulley (or the motor) until the longer leg of the square is parallel to the belt.

Fan Installation

Insert the fan into the wall opening and secure with lag screws, anchor bolts, or other suitable fasteners.

Always mount belt drive wall fans in order that the motor base is below the fan shaft.

Wiring Installation

All wiring should be in accordance with local ordinances and the National Electrical Code, NFPA 70. Ensure the power supply (voltage, frequency, and current carrying capacity of wires) is in accordance with the motor nameplate. Refer to the *Wiring Diagrams*, next page.

Lock off all power sources before unit is wired to power source.

Leave enough slack in the wiring to allow for motor movement when adjusting belt tension. Some fractional motors have to be removed in order to make the connection with the terminal box at the end of the motor.

(a) and (b) and (c) we can be been up and a second of the constant of the constant of the constant of the analysis is the constant of the constant of the state of the second second of the constant of the constant of the second second of the constant of the constant of the second second of the constant of the constant of the second second of the constant of the constant of the second second of the constant of the constant of the second second second second second constant of the constant of the second seco

Follow the wiring diagram in the disconnect switch and the wiring diagram provided with the motor. Correctly label the circuit on the main power box and always identify a closed switch to promote safety (i.e., red tape over a closed switch).

Wall Fans

- a. Extend wires to the fan.
- b. Prevent excess wire from entering the shaft and propeller area by restraining the excess wire to a point outside the base.

Wall Fans with Wire Guard

- a. Remove end panel from the wire guard to gain access to the motor.
- b. Extend wires through a side panel of the wire guard to gain access to the motor.
- c. Prevent excess wire from entering the shaft and propeller area by restraining the excess wire to a point outside the base.

Wall Fans with Wall Housing

- a. Remove end guard from the wall housing.
- b. Drill a hole through either side panel at a convenient location and pull the wires through. Do not pull wires through wire guard at the back panel.
- c. Restrain the incoming wire at the side panel to prevent excess wire from entering the shaft and propeller area.


Shutter Installation

If your fan is supplied with a shutter, follow the direction below. If your fan is not supplied with a shutter, proceed to *Final Installation Steps*.

To ensure long-life, make a weather-proof seal by using a good quality silicon caulking under the shutter flange. a. Place the shutter into the wall opening.


2

Wiring Diagrams Single Speed, Single Phase Motor




When ground is required, attach to ground A or B with no. 6 thread forming screw. To reverse, interchange T-1 and T-4.

2 Speed, 2 Winding, Single Phase Motor




When ground required, attach to ground A or B with No. 6 thread forming screw. To reverse, interchange T-1 and T-4 leads.





When ground required, attach to ground A or B with No. 6 thread forming acrew. To reverse, interchange T-5 and J-10 leads.

Typical Damper Motor Schematic



- b. Mount the shutter to the supporting surface using Number 12 sheet metal screws on six inch centers around the perimeter.
- c. Manually operate the shutter to ensure the blades move freely.
- Typical Installation Refer to page 5.

Finai Installation Steps

- a. Inspect fasteners and setscrews, particularly fan mounting and bearing fasteners, and tighten according to the recommended torque shown in the table on page 4, *Recommended Torque for Setscrews/Bolts*.
- b. Inspect for correct voltage with voltmeter.
- c. Ensure all accessories are installed.
- d. Test the fan to be sure the rotation is the same as indicated by the arrow marked Rotation.

Wiring Diagrams


3 Phase, 9 Lead Motor

3 Phase, 9 Lead Motor **3 Phase, 9 Lead Motor Y-Connection Delta-Connection** High Voltage Low Voltage High Voltage Low Voltage 208/230 Volts 460 Volts 208/230 Volts 460 Volts 4 5 6 0-0-0 00 7 0 0

456	8 8 8 7 8 9	06 04 05 01 02 03	456
1 о 2 о 3 о 7 1 8 1 9 1 L1 L2 L3	1ρ2ρ3ρ L1 L2 L3	$L_1 L_2 L_3$	1ϙ2ϙ 3ϙ _{L1} L ₂ L ₃


To reverse, interchange any 2 line leads.

2 Speed, 1 Winding, 3 Phase Motor



To reverse, interchange any 2 line leads. Motors require magnetic con-

2 Speed, 2 Winding, 3 Phase



To reverse: High Speed-Interchange leads T_{11} and T_{12} . Low Speed-Interchange leads T_1 and T_2 . Both Speeds-Interchange any 2 line leads.

For 3 phase, damper motor voltage should be the same between L_1 and L_2 . For single phase application, disregard L_3 . *Damper motors may be available in 115, 230 and 460 volt models. The damper motor nameplate voltage should be verified prior to connection. **A transformer may be provided in some installations to correct the damper motor voltage to the specified voltage.

Do not allow the fan to run in the wrong direction. This will overheat the motor and cause serious damage. For 3-phase motors, if the fan is running in the wrong direction, check the control switch. It is possible to interchange two leads at this location so that the fan is operating in the correct direction.

Operation

Pre-Start Checks

- a. Lock out all the primary and secondary power sources.
- b. Inspect fasteners and setscrews, particularly those used for mounting the unit, and tighten if necessary.
- c. Inspect belt tension and pulley alignment. (Remember, if belt tension is correct, a loud squeal occurs as
- the fan increases to full power.) d. Inspect motor wiring.
- e. Ensure the belt touches only the pulleys.
- f. Rotate the prop to ensure it does not rub against the venturi.

- g. Ensure fan and ductwork are clean and free of debris.
- h. Test the fan to ensure the rotation of the propeller is the same as indicated by the rotation label.
- i. Close and secure all access doors.
- j. Restore power to unit.

Start Up

Turn the fan on. In variable speed units, set the fan to its lowest speed. Inspect for the following:

- Direction of rotation.
- Excessive vibration.
- Unusual noise.
- Bearing noise.
- Improper belt alignment or tension (listen for a continuous squealing noise).
- Improper motor amperage or voltage.
- If a problem is discovered, immediately shut off the fan. Lock out all electrical power and check for the cause of the trouble. Refer to *Troubleshooting*, page 7.

	S	etscrews				
Key Hex Size Across		Recommer Incl	nded Torque n-Ibs.	Hold Down Bolts		
	Across Flats	Min.	Max.	Size	Wrench Torque (inch-lbs)	
No.10	3/32"	28	33	3/8*-16	240	
1/4"	1/8."	66	80	1/2"-13	600	
5/16"	5/32"	126	156	5/8"-11	1200	
3/8"	3/16"	228	275	3/4"-10	2100	
7/16"	7/32*	348	384	7/8"-9	2040	
1/2"	.1/4"	504	600	1"-8	3000	
5/8"	5/16"	1104	1200	1-1/8"-7	4200	
3/4"	3/8"	1440	1800	1-1/4"-7	6000	

Recommended Torque for Setscrews/Bolts (IN/LB.)

Inspection

Inspection of the fan should be conducted at the first 30 minute, 8 hour and 24 hour intervals of satisfactory operation. During the inspections, stop the fan and inspect as per directions below.

30 Minute Interval

Inspect bolts, setscrews, and motor mounting bolts. Adjust and tighten as necessary.

8 Hour Interval

Inspect belt alignment and tension. Adjust and tighten as necessary.

24 Hour Interval

Inspect belt tension. Adjust and tighten as necessary.

Maintenance

Establish a schedule for inspecting all parts of the fan. The frequency of inspection depends on the operating conditions and location of the fan.

Inspect fans exhausting corrosive or contaminated air within the first month of operation. Fans exhausting contaminated air (airborne abrasives) should be inspected every three months. Clean the propeller and air inlets if material build-up is excessive. Excessive build-up can cause imbalance and failure of the propeller.

Regular inspections are recommended for fans exhausting non-contaminated air.

It is recommended the following inspections be conducted twice per year.

- Inspect bolts and setscrews for tightness. Tighten as necessary.
- Inspect belt wear and alignment. Replace worn belts with new belts and adjust alignment as needed. See *Belt and Pulley Installation*, on page 2.
- Bearings should be inspected as recommended in the *Conditions Chart*, below.
- Inspect for cleanliness. Clean exterior surfaces only. Removing dust and grease on motor housing assures proper motor cooling.

Lubricants

Loren Cook Company uses petroleum lubricant in a lithium base conforming to NLGI grade 2 consistency. Other grades of grease should not be used unless the bearings and lines have been flushed clean. If another grade of grease is used, it should be lithium-based.

A NLGI grade 2 grease is a light viscosity, low-torque, rust-inhibiting lubricant that is water resistant. Its temperature range is from -30°F to +200°F and capable of intermittent highs of +250°F.

Motor Bearings

Motor bearings are pre-lubricated and sealed. Under normal conditions they will not require further maintenance for a period of ten years. However, it is advisable to have your maintenance department remove and disassemble the motor, and lubricate the bearings after three years of operation in excessive heat and or in a contaminated airstream consisting of airborne abrasives.

Conditions Chart									
RPM	Temperature	Fan Status	Greasing Interval						
Up to 100	Up to 120'F	Clean	6 to 12 months						
Up to 500	Up to 150'F	Clean	2 to 6 months						
Up t0 1000	Up to 210'F	Clean	2 weeks to 2 months						
Up to 1500	Over 210°F	Clean	Weekty						
Any Speed	Up to 150'F	Dirty	1 week to 1 month						
Any Speed	Over 150°F	Dirty	Daily to 2 weeks						
Any Speed	Any Temperature	Very Dirty	Daily to 2 weeks						
Any Speed	Any Temperature	Extreme Conditions	Daily to 2 weeks						

Fan Bearings

Greasable fan bearings are lubricated through a grease connector and should be lubricated by the schedule, *Conditions Chart*, on page 4.

For best results, lubricate the bearing while the fan Is rotating. Slowly pump grease into the bearing until a slight bead forms around the bearing seals. Excessive grease can burst seals thus reduce bearing life.

In the event the bearing cannot be seen, use no more than three injections with a hand-operated grease gun.

Motor Services

Should the motor prove defective within a one-year period, contact your local Loren Cook representative or your nearest authorized electric motor service representative.


Changing Shaft Speed

All belt driven Propeller Wall fans with motors up to and including 5HP are equipped with variable pitch pulleys. To change the fan speed, perform the following:


a. Loosen setscrew on driver (motor) pulley and remove key, if equipped.




Typical Installations











Exhaust wall fan with OSHA wire guard and shutter

Illustrated is the typical installation of an exhaust wall fan with an OSHA wire guard and shutter in a steel structure with corrugated siding. The installer will provide a sleeve of suitable material to support the fan at a correct distance from the shutter (minimum distance is the "A" dimension).

AWR. AWD	XLW, XLWH	EWB		-			-	W	0
SWD	XMW, XMWH	EWD	Α	B	С	D	E	Std. Fan	Wire Gd.
. 8	-	-	11	13	12-3/4	10	1	12-1/2	13-1/4
10-12	-	-	12	13	16-3/4	14	1	16-7/16	17-1/4
14-16	· _	-	12	13	20-3/4	18	1	20-7/16	21-1/4
18-20			13	12	24-3/4	22	1	24-7/16	25-1/4
-	20	-	13	21	24-3/4	22	1	24-7/16	25-1/4
24	•	-	15	21	30-3/4	27	1-1/2	30-7/16	31-1/4
•	24	-	15	13	30-3/4	27	1-1/2	30-7/16	31-1/4
30	30	24	16	21	36-3/4	33	1-1/2	36-7/16	37-1/4
36	36	30	16	21	42-3/4	39	1-1/2	42-7/16	43-1/4
42	42	36	17	26	48-7/8	45	1-1/2	48-7/16	49-1/4
48	48	42	17	26	54-7/8	51	1-1/2	54-7/16	55-5/16
	54	48	17	28	60-7/8	57	1-1/2_	60-7/16	61-5/16
	60	54	17	- 28	66-7/8	63	1-1/2	66-7/16	67-1/2
-	• -	60	17	28	72-7/8	69	1-1/2	72-7/16	73-1/2
-	-	72	17	31	84-7/8	81	1-1/2	84-7/16	85-1/2

Exhaust Pac-Fan with shutter guard

Illustrated is the typical installation of an exhaust PAC-Fan in a masonry wall with a shutter guard. The installer provides suitable fasteners (Hex bolts or Lag screws) to support the fan. It is recommended that 5/16" minimum bolts on 6" to 10" centers be used on the perimeter of the housing. Mounting flange should be caulked to exterior of the wall. Fans with motors in excess of 80 lbs. should be additionally supported by hanging rods or supports placed underneath the fan.

APB. APD. SPD	XLP, XLPH, XMP, XMPH	EPB, EPD	A	B-Direct	B-Belt	WO
8	-	-	10-5/8	13-5/8	-	13-1/4
10-12	•	-	14-5/8	17-5/8	· •	17-1/4
14-16	-	-	18-5/8	20	-	21-1/4
18-20	20	•	22-5/8	22	34-1/4	25-1/4
24	24	-	27-7/8	23	34-1/4	31-1/4
30	30	24	33-7/8	24-3/8	37-7/8	37-1/4
36	36	30	39-7/8	28-3/8	39-3/8	43-1/4
42	42	36	45-7/8	33-5/8	40-5/8	49-1/4
48	48	42	51-7/8	39-5/8	50-5/8	55-5/16
•	54	48	57-7/8	40-1/8	47-3/4	61-5/16
	60	54	63-7/8	44-3/4	47-3/4	67-1/2
	-	60	69-7/8	-	47-3/4	73-1/2
	-	72	81-7/8	-	50-3/4	85-1/2

Supply wall fan with wall collar, OSHA wire guard, motorized supply shutter and weather hood

Illustrated is the typical installation of a supply wall fan in a masonry wall with a wall collar, OSHA wire guard, motorized supply shutter and weather hood. The installer provides suitable fasteners to support the fan. Fasteners should be placed on 6" to 10 centers on the perimeter of the wall collar. Wall collar should be caulked to the exterior of the wall. The weather hood should be securely fastened and sealed to the wall. Fans with motors in excess of 80 lbs, should be additionally supported by hanging rods or supports placed underneath the fan.

AWB, AWD, SWD	XLW, XLWH XMW, XMWH	EWB, EWD	A	B	C	D.,	E	WO
8	•	-	18	16	12	13	1	13-1/4
10-12	•	-	22	18-3/4	14-3/8	13	1	17-1/4
14-16		-	26	21-3/4	15-3/8	13	1	21-1/4
18-20	-	-	30	24-1/2	17-5/8	13	1	25-1/4
•	20		30	24-1/2	17-5/8	21	1	25-1/4
24	-	-	30	24-1/2	17-5/8	13	1-1/2	31-1/4
•	24	-	34	27-1/4	18-3/4	21	1-1/2	31-1/4
30	30	24	40	31-1/2	18-3/4	21	1-1/2	37-1/4
36	36	30	46	35-3/4	19-1/2	21	1-1/2	43-1/4
42	42	36	52	. 40	19-1/2	26	1-1/2	49-1/4
48	48	42	58	44-1/4	19-3/4	26	1-1/2	55-5/16
	54	48	64	48-1/2	19-3/4	28	1-1/2	61-5/16
	60	54	70	52-3/4	19-3/4	28	1-1/2	67-1/2
	• • •	60	76	57	19-3/4	28	1-1/2	73-1/2
		72	88	67-1/2	19-3/4	31	1-1/2	85-1/2

5

Changing Shaft Speed continued

- b. Turn the pulley rim to open or close the groove facing. If the pulley has multiple grooves, all must be adjusted to the same width.
- c. After adjustment, inspect for proper belt tension. Speed Reduction

Open the pulley in order that the belt rides deeper in

the groove (smaller pitch diameter).

Speed Increase

Close the pulley in order that the belt rides higher in the groove (larger pitch diameter). Ensure that the RPM limits of the fan and the horsepower limits of the motor are maintained.

Pulley and Belt Replacement Maximum RPM

	SWD Size	Maximum RPM	EWB Size	Maximum RPM	AWB Size	Maximum RPM
•	-8	1690	24	1675	24	1510
	10	1550	30	1370	30	1145
	12	1615	36	1310	36	990
	14	1130	42	1175	42	905
	16	1115	48	1215	48.	900
	18	1095	54	960	-	-
	20	1075	60	890	-	
	24	1050	72	700	-	· -

Maximum RPM

APB Size	Maximum RPM	XLP/XLPS Size	Maximum RPM	XLPH/XLPHS Size	Maximum RPM
24	1005	20	1280	-	· · · · ·
30	800	24	1012	24	1110
36	645	30	666	30	930
42	660	36	566	36	714
48	605	42	424	42	610
•	-	48	356	48	512
•	-	54	316	54	472
	-	60	260	60	446

Maximum RPM

XMP/XMPS Size	Maximum RPM	XMPH/ XMPHS Size	Maximum RPM	XLW/ XLWS Size	Maximum RPM
20	1280	-	1	20	1276
24	1276	24	1410	24	1018
30	830	30	1172	30	674
36	680	-36	838	36	570
42	498	42	716	42	422
48	414	48	596	48	356
54	346	54	516	54	320
60	318	60	474	60	256

Maximum RPM

XLWH/ XLWHS Size	Maximum RPM	XMW/ XMWHS Size	Maximum RPM	XMWH/ XMWHS Size	Maximum RPM
,	1.1.4	:20	1462		
24	1126	24 .	1272	24	1400
30	932	30	860	30	1184
36	720	36	672	36	864
42	610	. 42	498	42	718
48	516	48	416	48	600
54	478	.54	350	54	522
.60	438	60	320	60	476

a. Clean the motor and fan shafts.

- b. Loosen the motor plate mounting bolts to relieve the belt tension. Remove the belt.
- c. Loosen the pulley setscrews and remove the pulleys from the shaft.
- If excessive force is required to remove the pulleys, a three-jaw puller can be used. This tool, however,
- can easily warp a pulley. If the puller is used, inspect the trueness of the pulley after it is removed from the shaft. The pulley will need replacement if it is more

than 0.020 inch out of true.

- d. Clean the bores of the pulleys and place a light coat of oil on the bores.
- e. Remove grease, rust and burrs from the shaft.
- f. Place fan pulley on the fan shaft and the motor pulley on the motor shaft. Damage to the pulleys can occur when excessive force is used in placing the pulleys on their respective shafts.
- g. After the pulleys have been correctly placed back onto their shafts, tighten the pulley setscrews.
- h. Install the belts on the pulleys. Align and adjust the belts to the proper tension as described in *Belt and Pulley Installation*, page 2.

Bearing Replacement

The fan bearings are pillow block ball bearings.

- a. Mark the position of the shaft in reference to both the bearing races and the propeller and pulley. Make a note of the clearance between the propeller and the frame.
- b. Remove the pulley.
- c. Remove the propeller from the shaft. A two-jaw puller may be needed to remove the propeller from the shaft.
- d. Remove the bearing hold-down bolts. Remove the shaft and the bearings as one unit.
- e. Remove the anti-corrosion coating from the shaft with a suitable degreaser.
- f. Remove the bearing from the shaft using a bearing puller. If a bearing puller is not available, remove the bearing by using a wood block and hammer. An emery cloth or file may be needed to remove imperfections in the shaft left by the setscrews.
- g. Clean the shaft and bearing bore thoroughly.
- h. Place the bearings into position ensuring they are not on a worn section of the shaft. Tapping the inner ring face with a soft driver may be required. Do not hammer on the housing.
- i. The outer ring of the bearing is spherical and swivels in the housing to compensate for misalignment. Slightly tighten the hold down bolts.
- j. Align the setscrews on the bearings and tighten one setscrew on each bearing.
- k. Rotate the shaft to allow the bearing outer rings to find the center of free movement.
- I. Install the propeller on the shaft and adjust the bearlng position to center the propeller in the opening.
- m. Tighten the hold-down bolts to the proper torque. Refer to the *Torque Chart*, page 4.
- n. Turn the shaft by hand. Resistance should be the same as it was before the hold-down bolts were fully tightened.
- o. Tighten the bearing setscrews to the specified torque.
- p. Install the pulley and adjust the belt tension.

After 24 hours of continuous operation, tighten the setscrews to the appropriate torque. This assures the full locking of the inner race to the shaft. Ensure the socket key or driver is in good condition with no rounded corners. The key should be fully engaged in the setscrew and held squarely to prevent the rounding out of the setscrew socket when applying maximum torque.




Troubleshooting

Problem and Potential Cause

Low Capacity or Pressure	Overheated Motor
•Incorrect direction of rotation. Make sure the fan rotates in same direction	•Motor improperty wired.
as the arrows on the motor or belt drive assembly.	•Incorrect direction of rotation. Make sure the fan rotates in same
•Poor fan inlet conditions. There should be a straight clear duct at the inlet.	direction as the arrows on the motor or belt drive assembly.
•Improper propeller alignment.	•Cooling air diverted or blocked.
Excessive Vibration and Noise •Damaged or unbalanced propeller. •Belts too loose; worn or oily belts. •Speed too high. •Incorrect direction of rotation. Make sure the fan rotates in same direction as the arrows on the motor or belt drive assembly. •Bearings need lubrication or replacement.	Overheated Bearings •Improper bearing lubrication •Excessive belt tension.

APD Parts List



(2)

(з

6

(7)

(4)

(5)

1

۲

Ð


(12)

Parts	Description	Parts	Description
No.	APD Sizes 16-36	No.	APD Sizes 16-36
1	Power Assembly	6	Anchor Angles (2)
2	Propeller	7	Fan Box Panel (4)
3	Shutter Assembly	8	End Wire Guard
4	Mounting Collar Angles (4)	9	Motor Plate
5	Wall Base	10	Motor

Parts	Description	Parts	Description
No.	APB Sizes 24-48	No.	APB Sizes 24-48
1	Bearings (2)	9	Motor Plate
2	Power Assembly	10	Motor
3	Propeller	11	Fan Box Panel (4)
4	Shutter Assembly	12	End Wire Guard
5	Mounting Collar Angles (4)	13	Driver Sheave
6	Wall Base	14	Belt Set
7	Anchor Angles (2)	15	Driven Sheave
8	Shaft		· · ·


AWDS and AWDE Parts List

⑧



Parts	Description				
No.	AWDS	AWDE			
1	Supply Venturi				
2	Motor	Motor			
3	Motor Plate	Motor Plate			
4	Optional Wire Guard	Birdscreen			
5	Wall Base	Wall Base			
6	Cast Aluminum Propeller	Cast Aluminum Propeller			
7	Power Assembly	Power Assembly			

3)



Part	Description			
No.	AWBS	AWBE		
1	Driven Sheave	Driven Sheave		
2	Bearings (2)	Bearings (2)		
3	Power Assembly	Power Assembly		
4	Supply Venturi	-		
<u>5</u> .	Propeller	Propeller		
6	Shaft	Shaft		
7	Motor Plate	Motor Plate		
8	Motor	Motor		
9	Belt Set	Belt Set		
10	Optional Wire Guard	Birdscreen		
11	Driver Sheave	Driver Sheave		
12	Wall Base	Wall Base		
Part	Descr	1ption		
No.		PD		
1	Power A	ssembly		
2		ntal Venturi		
3		Assembly		
4		lar Angles (4)		
5		ngles (2)		
6	Wall	Base		
7	Fan Box	Panel (4)		
8	End Wir	e Guard		
9	Motor	Plate		
10	Mo	otor		
11		Base		
	Propeller (f	Not Shown)		
Part	Descr	iption		
No.	· · · · · · · · · · · · · · · · · · ·	PB		
1	Bearir	ngs (2)		
2	Power A	ssembly		
3	Wall	Base		
4	·	beller		
5		Assembly		
6		lar Angles (4)		
7	Suppleme	ntal Venturi		
8	Anchor Angles (2)			

Shaft

Motor Plate

Motor

Fan Box Panel (4)

End Wire Guard

Driver Sheave

Belt Set

Driven Sheave Description

> EWD Propeller

> > Motor

Power Assembly

Supplemental Venturi

Motor Plate

Optional Wire Guard

Wall Base

0

8

(3)

(4)

9

10

11

12

13

14

15

16

Part No.

1

3

4


5

6

7


(5)

EWB Parts List




Part	Description	
No.	EWB	
1	Bearings (2)	
2	Wall Base	
3	Supply Venturi	
4 .	Steel Propeller	
5	Shaft	
6	Motor Plate	
7	Power Assembly	
8	Motor	
9	Optional Wire Guard	
10	Driver Sheave	
11	Belt Set	
12	Driven Sheave	

8-48 EWB/EWD Weather Hood Parts List




Part	Description
No.	8-48 EWB/EWD
1	Top Panel
2	Right Side Panel
3	Left Side Panel
4	Bottom Panel
5	1/2" Mesh Galvanized Bird Screen
6	1/4" X 1/2" Speed Screw
7	5/16 SAE Steel Washer




Part	Description
No.	EWBSM
1	Driven Sheave
2	Bearings (2)
3	Power Assembly
4	Wall Base
5	Fan Box Panel (4)
6	Shutter Assembly
7	Mounting Collar Angles (4)
8	Supply Venturi
9	Steel Propeller
10	Shaft
11	Motor Plate
12	Motor
13	Driver Sheave
14	Optional Wire Guard
15	Belt Set

54-60 EWB/EWD Weather Hood Parts List




Part	Description
No.	54-60 EWB/EWD
1	Top Panel, Piece 1
2	Top Panel, Piece 2
3	Right Side Panel
4	Left Side Panel
5	Bottom Panel
6	Bird Screen Support
7	1/2" Mesh Galvanized Bird Screen
8	1/4" X 1/2" Speed Screw
8	5/16 SAE Steel Washer


72 EWB/EWD Weather Hood Parts List




SPD Parts List





SWD Parts List





SWDS Parts List





Part	Description
No.	72 EWB/EWD
1	Top Panel, Piece 1
2	Top Panel, Piece 2
3	Right Side Panel Tip
4	Right Side Panel
5	Left Side Panel Tip
6	Left Side Panel
7	Bottom Panel
8	Bird Screen Support
9	1/2" Mesh Galvanized Bird Screen
10	1/4" X 1/2" Speed Screw
11	5/16 SAE Steel Washer

Part	Description
No.	SPD
1	Fan Box Panel (4)
2	Stamped Aluminum Propeller
3	Anchor Angle (4)
4	Mounting Collar Angle (2)
5	Automatic Louver
6	Wall Base
7	Mounting Grille
8	Motor
9	Mesh Guard

Part	Description	
No.	SWD	
1	Wire Guard	
2	Wall Base	
· 3	Stamped Aluminum Propeiler	
4	Motor	-


Part	Description
No.	SWDS
1	Stamped Aluminum Propeller
2	Wall Base
3	Wire Guard
4	Motor
5	End Wire Guard
6	Wall Collar


10

XLW, XMW, XLWS, XMWS 20 - 36 Parts List

Part No.	Description	Part No.	Description
1	Wall Venturi Base	8	Motor
2	Prop Assembly	9	Optional Wire Guard
3	Power Assembly Foot (3)	10	Drive Sheave
4	Bearings (2)	11	Belt Set
5	Inlet Venturi (Supply only)	12	Driven Sheave
6	Fan Shaft	13	Power Assembly Rail
7	Motor/Bearing Plate		

XLP, XMP, XLPS, XMPS 20 -36 Parts List






(5)


Part No.	Description	Part No.	Description
1	Wall Venturi Base	9	Motor/Bearing Plate
2	Prop Assembly	10	Housing Wrapper Panei (4)
3	Bearings (2)	11	End Safety Guard
4	Fan Shaft	12	Motor
	Exhaust Shutter (Exhaust Only)	13	Drive Sheave
5	Supply Shutter (Supply Only)	14	Belt Set
6	Mounting Collar Angle (4)	15	Driven Sheave
7	Inlet Venturi (Supply Only)	16	Power Assembly Rall
8	Wall Mounting Angle (2)	17	Power Assembly Foot (3)

XLW, XMW, XLWS, XMWS 42 - 60 Parts List



Part No.	Description	Part No.	Description
1	Wall Venturi Base	8	Motor/Bearing Plate
2	Prop Assembly	9	Optional Wire Guard
3	Power Assembly Foot (2)	10	Motor
4	Power Assembly Rail (2)	11	Motor Plate Brace
5	Fan Shaft	12	Drive Sheave
6	Bearings (2)	13	Beit Set
7	Inlet Venturi (Supply Only)	14	Driven Sheave


XLP, XMP, XLPS, XMPS 42 - 60 Parts List



Part No.	Description	Part No.	Description
1	Wall Venturi Base	10.	Wall Mounting Angle (2)
2	Prop Assembly	11	Motor/Bearing Plate
3	Power Assembly Foot (2)	12	Housing Wrapper Partel (4)
4	Power Assembly Rall (2)	13	End Safety Guard
5	Bearings (2)	14	Motor
6	Fan Shaft	- 15	Motor Plate Brace
7	Inlet Venturi (Supply Only)	16	Drive Sheave
8	Exhaust Shutter (Exhaust Only)	17	Belt Set
្ទុំរ	Supply Shutter (Supply Only)	18	Driven Sheave
9	Mounting Collar Angle (4)		· · · · · · · · · · · · · · · · · · ·


11

XLWHS, XMWHS, XLWH, XMWH 24 - 60 Parts List



Part No.	Description	Part No.	Description
1	Wall Venturi Base	7	Motor
2	Power Assembly	8	Optional Wire Guard
3	Prop Assembly	9	Motor Plate
4	Bearings (2)	10	Drive Sheave
5	Fan Shaft	11	Belt Set
6	Inlet Venturi (Supply Only)	12	Driven Sheave





Part No.	Description	Part No.	Description
1	Wall Venturi Base	9	Wall Mounting Angle (2)
2	Power Assembly	10	Motor
3	Prop Assembly	11	Housing Wrapper Panel
4	Bearings	12	End Safety Guard
5	Fan Shaft	13	Motor Plate
•	Exhaust Shutter (Exhaust	14	Drive Sheave
6	Only) Supply Shutter (Supply Only)	15	Belt Set
7	Mounting Collar Angle (4)	16	Driven Sheave
8	Inlet Venturi (Supply Only)		· · ·

Limited Warranty

Limited Warranty Loren Cook Company warrants that your Loren Cook fan was manufactured free of defects in materials and workmanship, to the extent stated herein. For a period of one (1) year after date of shipment, we will replace any parts found to be defective without charge, except for shipping costs which will be pald by you. This warranty is granted only to the original purchaser placing the fan in service. This warranty is vold if the fan or any part thereof has been altered or modified from its original design or has been abused, misused, damaged or is in worn condition or if the fan has been used other than for the uses described in the company manual. This warranty does not cover defects resulting from normal wear and tear. To make a warranty claim, notify Loren Cook Company, General Offices, 2015 East Dale Street, Spring-field, Missouri 65803-4637, explaining in writing, in detail, your complaint and referring to the specific model and serial numbers of your fan. Upon receipt by Loren Cook Company of your written complaint, you will be notified, within thirty (30) days of our receipt of your complaint, in writing, as to the manner in which your claim will be handled. If you are artitized to warranty relief, a warranty edjustment will be completed within sbty (60) business days of the receipt of your written complaint by Loren Cook Company. This warranty gives only the original purchaser placing the fan in service specifically the right. You may have other legal rights which vary from state to state. state to state.


LOREN COOK COMPANY

Corporate Offices: 2015 E: Dale Street Springfield, MO 65803 417.869.6474

www.lorencook.com

APPENDIX B

REVENUE METER INSTALLATION AND INSTRUCTION MANUAL



Energy Monitoring Products

Corporation

Dear Valued Customer:

We are pleased that you chose to buy one of our products and want you to be just as pleased with it. To be sure that you are 100% satisfied with our products, we provide toll-free technical and sales information Monday through Friday 8:00 am to 7:30 pm, eastern time. The toll-free numbers are: Eastern Region: (800) 334-3666 and Western Region: (800) 810-3666. You may also reach us via E-Mail at: info@emon.com.

Before installing your new E-MON product, please read the information on the following pages carefully.

We believe that you will find the E-MON D-MON Kilowatt hour/demand meters easy to install and use for monitoring and evaluating your electrical usage.

Be sure to forward this manual to the owner after installation is complete, so that they may use it as a reference guide when reading the E-MON meters.

Thank you.

E-MON Corporation Manufacturer of Energy Monitoring Products

114	<u>v</u> л		
	Chapter 1	Pre-Installation Information	
;			
	Chapter 2	Current Sensor Assembly	
	Chapter 3	Meter Terminal Block Connections Current Sensor Lead Connection Line Voltage Connection	
	Chapter 4	Various Installation Diagrams	
	Chapter 5	Monitoring Multiplie Loads with One E-MON Meter Parallel Current Sensor Rules Various Parallel Current Sensor Connection Diagrams	
	Chapter 6	Troubleshooting your E-MON Meter Toubleshooting Guide	
	Chapter 7	Operating Guide E-MON KWH Meters only	
	Chapter 8	How to Read the E-MON D-MON KWH Meter	
	Chapter 9	Frequently Asked Questions	

Index

Chapter 1 Pre-Installation Information

The E-MON D-MON KWH meter is a three element meter that is used to monitor electric power to individual loads after the utility meter. Installation should be performed by qualified personnel and **only** according to these instructions and local electrical codes. E-MON Corporation or its representatives assume no responsibility for damage or injury resulting from the improper installation of this meter.

Check the rating and configuration on the meter label to ensure it is suitable for the intended service. Meters listed for use on 115/208 volt **cannot** be used on 277/480 volt services and vice versa.

Verify that the meter rating (amperage) is suitable for the intended load. Compare the color of the arrows on the red coils to the chart below to find the amperage of the current sensors.

SENSOR ARROW		SENSOR
COLOR CODE		RATING
Purple	-	25 Amp
White	-	50 Amp
	-	•
Brown	-	100 Amp
Red	-	200 Amp
Yellow	-	400 Amp
Black	_'	800 Amp
Blue	-	1600 Amp
(2) Blue	-	3200 Amp

Mount the meter in desired location using the mounting flanges located on the top and bottom of the meter enclosure. E-MON meters must be installed indoors where they will not be affected by the elements.


Assemble and install current sensors around conductors to be monitored (Chapter 2).

NOTE: The modular jacks located on the meter board are to be used only in conjunction with E-MON supplied peripherals. *The jacks contain neutral accessible circuits.*

Chapter 2 Current Sensor Assembly

STEP 2:


STEP 1: For each phase being monitored you will need one two-piece current sensor assembly (A three phase meter will require three (3) current sensor assemblies.) Open the two-piece current sensor assembly by releasing the nylon clamp using a flathead screwdriver.



Using a flathead screwdriver, press the tab on the nylon clamp to open the current sensor assembly.

800-3200 Amp

Reassemble current sensor assembly around the conductor(s) to be monitored. Be sure that the current sensor halves marked "Load" are both facing the load side of the conductor. The colored arrow will be on the source side of the conductor being monitored and **MUST** be pointed in a clockwise direction around the conductor being monitored. Tighten nylon clamp to complete assembly.



** IMPORTANT**

When looking from the source side of the conductor(s) being monitored, you should see the arrow on the current sensor assembly, and the arrow should be pointing clockwise around the conductor(s) being monitored.

If the arrow is not on the source side inaccurate readings may result.

Chapter 3 Meter Terminal Block Connections

Current Sensor Connections

STEP 1: Connect the black and white leads from the current sensor assembly to the meter terminal block. The current sensor leads can be extended up to 2,000 feet using 14-22 AWG wire and do not have to be twisted (consult your local electrical codes for proper sizing). When extending the sensor leads, be sure to note what color lead on the extension is connected to the black lead from the sensor, and what color lead on the extension is connected to the white lead from the sensor. There is no hazardous voltage across the current sensor wires and there will be no damage if the sensor wires are shorted together.

When connecting current sensor leads to the meter terminal block be sure to note which phase you bring into the "A" phase terminals, and the same for the "B" and "C" phase terminals. Also be sure that the white wire is connected to the "W" terminal, and the black wire is connected to the "B" terminal for that phase.

STEP 2: Proceed to Chapter 4, Various Installation Diagrams, for further information on current sensor connections.

Voltage Connections

STEP 1: Connect the line voltage input wires to the meter terminal block. Do not connect the voltage wires to the unit while they are live. These wires are normally #14 AWG (consult your local codes for proper sizing). Voltage input conductors require protection, it is recommended that in-line fuses with a five amp rating be installed to protect all phases. Line voltage inputs must correspond to the same phase being monitored by the current sensor inputs.

IMPORTANT

Phasing correspondence between the line voltage and the current sensors must correspond. ("A" phase on the voltage side must be "A" phase on the current sensor side.) If the phasing between the voltage and the current sensors does not correspond, inaccurate readings may result.

Chapter 3

Meter Terminal Block Connections

Voltage Connections

STEP 1: The line voltage input may be taken from wherever it is most convenient (lugs, another breaker, another subpanel, etc.) as long as it is the same power source as the items being monitored. Line voltage **cannot** be pulled from a subpanel powered from a different transformer than the item(s) being monitored.


STEP 2: Push insulating cover down over the terminal block inside meter. Apply voltage to meter only after installation is complete.

Refer to Chapter4, Various Wiring Diagrams for further details.

Various Wiring Diagrams-Standard Wiring Diagrams

This chapter provides you with various installation diagrams depending on your monitoring needs. The diagrams below are standard installation Diagrams using (1) set of current sensors. For special monitoring needs see Chapter 5.


3 Phase, 3 Wire Connection [Delta System (on 4 wire Delta, Neutral is not used)]



Line Voltage Connections: #14 AWG B=Black Lead W=White Lead

* Five-amp Inline fuses recommended

3 Phase, 4 Wire Connection [Wye System]




Line Voltage Connections: #14 AWG Sensor Connections: B=Black Lead

W=White Lead

* Five-amp Inline fuses recommended

Chapter 4 Various Wiring Diagrams-Standard Wiring Diagrams

1 Phase, 3 Wire Connection (Monitoring conductors A-B, B-C, A-C)




Line Voltage Connections: #14 AWG

B=Black Lead Sensor Connections: W=White Lead


* Five-amp Inline fuses recommended

IMPORTANT: Line voltage MUST be present at the A & B phase voltage terminais (e.g. you cannot bring power to A & C phase terminals only, or B & C phase terminals only.

Shorting link MUST be installed on C phase current sensor terminals.



Conductors A-C




For other applications (120 V, 1-Phase, 2 Wire, High Voltage Metering, etc.), contact E-MON Corporation at: Eastern Region: (800) 334-3666 or Western Region: (800) 810-3666

sors in parallel (See Chapter the number of sets of sen-When reading the E-MON meter, be sure to multiply provided to the A & B Line When reading the E-MON can not bring power to only the B & C phase, or installed on the C phase meter, be sure to multiply current sensor terminals the meter multiplier by voltage terminals in the E-MON Meter (e.g. you sensors in parallel (See the meter multiplier by Shorting Link must be Line voltage must be the number of sets of Chapter 8 for details) the A & C phase) **MPORTANT!** 8 for details) Monitor Multiple Loads with One E-MON Meter] ₽ CURRENT SENSORS ZA ØB ØC W B W B W B CURRENT SENSORS 3 Monitoring (2) Three Phase loads Parallel Current Sensor Installation Diagrams **Monitor (2) Single Phase loads** UNE VOLTAGE Current Sensor Leads LINE VOLTAGE 24 28 DC N OA DB DC N Current Sensor Lead a ha ha a ha i Th A COMPA Chapter 5 The E-MON D-MON® KWH meter provides extreme flexibility by allowing additional sets 100 amp, or all 400 amp, etc.). The rating will be determined by the current phase. The multiplier change only applies when extra sets of sensors of current sensors to be used in parallel so multiple locations can be monitored by one monitor 3 phase and single phase loads for a totalized reading, provided they are from breakers from more than one panel, two or more complete panels, etc. You may also All sensors used in parallel must be of the same amperage rating (i.e. all rating (amperage) of the meter. A 200 amp meter, for example must use You may use parallel sensors to monitor specific breakers from one panel, specific When paralleling current sensors, the following rules must be followed for accurate meter monitor two 480 volt loads if they are from a different onginating 480 volt meter, for example, cannot monitor a 208 volt load, nor can a NOTE: Sets of current sensors consist of three sensors, one per are installed on one meter. If you are only using one set of three necessary even when paralleling poly phase with single phase loads. Example: meter multiplier of 8 with 3 sets (of three) current sensors. meter and puiser (if used) multiplier must be factored by the number Example: meter multiplier of 32 with 2 sets (of 3) current sensors ... of current sensors. When using parallel sets of current sensors, the All locations being monitored must have the same power source. A Current sensors must be installed in complete sets of three. This is of sets of current sensors in parallel to provide the correct reading. The multiplier on the meter display is affected by the paralleling meter. This feature allows a totalized display from two or more loads. Monitor Multiple Loads with One E-MON Meter <u>sensors. this multiplier change does not apply</u> power source (or from different transformers). 32 x 2 = 64 (new multiplier) 8 x 3 = 24 (new multiplier extra sets of 200 amp current sensors. the same power source. Chapter 5 RULE 1: readings. RULE 4: RULE 2: RULE 3:

Monitor Multiple Loads with One E-MON Meter

Monitor (1) three phase load and (1) single phase load



NOTE: Three Phase line voltage **MUST** be provided to the E-MON meter. When reading the E-MON meter, be sure to multiply the meter multiplier by the number of sets of sensors in parallel (See Chapter 8 for details)

IMPORTANTI

<u>Current sensors MUST be installed in complete sets of (3)</u>, bring the third sensor into the terminal block at the meter, but <u>do not</u> clamp the actual sensor assembly around any conductors or the neutral

For other applications contact E-MON Corporation Engineering Department at: Eastern Region: (800) 334-3666 or Western Region: (800) 810-3666.

Chapter 6 Troubleshooting Guide


The E-MON D-MON electronic KWH/Demand meter is calibrated and tested at the factory before being packaged and shipped. If installed properly and in accordance with these installation instructions, the E-MON meter should provide years of trouble-free ser. De. If the meter should not function, the following guide will assist in troubleshooting the installation.

PROCEDURE TO FOLLOW

PROBLEM

	1. Display window is blank.	A. check wiring to voltage terminals
		B. check circuit breaker or fuses
	x x	C. verify that power is turned on
		D. test source for correct voltage
		E. press RESET button located
		on the door inside the meter (5 sec.)
	2. Display shows incomplete figures or	A. press RESET button located on the
	numbers other than zeros when	door inside the meter (5 sec.)
	power is turned on.	
-	3. Display reading all zeros (0000)	A. determine if load is sufficient to update
		the display (a load of at least 1% of
	. تعنی	the meter rating for a period of 24 hrs.)
	2 	B. check RESET button to be sure there
		are no wires or other objects pressing
	•	against it when the door is closed.
		C. check the current sensors for
		installation and polarity (see chapters
		2 for instructions)
		D. be sure the current and voltage inputs
e F		have the proper phase relationship
		(see chapter 4 for instructions)
		E. check withing to voltage terminals
		F. check circuit breaker or fuses
		<u>G. test source for correct voltage</u>
	4. Display reads only a fraction of	A. check the supply voltage to be sure
	the power consumption	that it is on continuously 24 hrs./day
		B. check current sensor installation
		and polarity (see chapters 2 for
		instructions)
	•	C. check sensor wiring to the terminal
		strip in meter (color coding W & B)
	If you have any questions contact E-MON at (800) 334-36	666 or (800) 810-3666 <u>BEFORE</u> removing the E-MON meter.


Chapter 7 Operating Guide-E-MON KWH Meters (One 4-Digit Display)



THIS PAGE APPLIES ONLY TO THE E-MON KWH METER.

Chapter 8 Reading the E-MON Meter-(4 Digit) KWH Reading

This page refers to reading your 4-digit KWH display.



The KWH display is the 4-digit display on the front of your E-MON meter. The number on the 4-digit kilowatt hour (KWH) window is in full units, **the decimals (dots) are used as a load indicator only and do not affect the reading**. The reading in the display must be multiplied by the number that is printed on the bottom of the clear window. (This number is preceded by the statement 'MULTIPLY BY"). The resultant figure is in KILOWATT HOURS.

EXAMPLE: The KWH multiplier on a 200 amp meter is 16. If the 4-digit display reading is 25, multiply 25 by 16 for a total of 400 KWH.

To find the dollar cost for the power used by the loads being monitored, you must first find out what the cost per KWH is in your area (this cost can be found on your utility electric bill, or call your local utility and ask for their cost per kilowatt hour). Simply multiply this cost per KWH by the KWH reading from the E-MON meter. The resultant figure is the dollar cost for power used by the load(s) being monitored by this meter.

EXAMPLE:	4-DIGIT DISPLAY READING	25
	4-DIGIT DISPLAY MULTIPLIER	16
	COST PER KWH FROM UTILITY	.02169762
	25 X 16 X .02169762 = \$8.68 (cost for	power used by loads on meter)

NOTE: THE FOLLOWING ONLY APPLIES TO METERS USING MORE THAN ONE SET (OF 3) CURRENT SENSORS. For meters using parallel current sensors the multiplier of the KWH display must be multiplied again by the number of sets of sensors in parallel.

EG. Meter multiplier of 8, two sets of sensors installed, 8 X 2 = 16 (new KWH display multiplier)

sading the l	E-MON M	Reading the E-MON Meter-Meter Multiplier Chart -4-Digit	ultiplier Char		Display	Frequently Asked Questions
e chart below	applies to t	<u>The chart below applies to the 4-digit display on E-MON KWH Meters</u>	<u>v on E-MON KWI</u>	<u>H Meters</u>		Q. When providing line voltage to the E-MON meter, can I tap off of the same breaker I am monitoring?
NOTE NOTE	WH MULTIPL :: When parall	KWH MULTIPLIERS FOR ALL E-MON D-MON KWH METERS NOTE: When paralleling current sensors, sensors must be installed	ON D-MON KWH MI Drs, sensors must b	ETERS He installed		-
How to find your KWH Muttipiler. 1. Find the model number listed 2. Find the number of each of the	ittplier: r listed on the from s of the current of	In complete sets of three. How to find your KWH Muthplier: 1. Find the model number listed on the front of your E-MON Meter in the chart below. 2. If the the number of each and an uncompleted on the set and an our set to be device.	of three. In the chart below	In complete sets of three. Find the model number if the front of your E-MON Meter in the chart below. Find the number of each of the current or noted in the chart below.		Q. Can the meter line voltage wires be run in the same conduit as the current sensor leads? A. Yas, there will be no effect on the meter if the sensor leads and the meter line voltage wires are run in the same conduit.
ne set of sensors su maining columns of the meter. (NOTE ross reference the mc	a of up currents upplied with you niy apply if extra Cone set of curr odel number to th	The mainteen of sets of the current sensors installed on your meter in the creat below. If you are only under a find the set of sensors supplied with your E-MON meter, use the multipliend/block in the gray column. The maining columns only apply if extra sets of currents, uses the multipliend/block in the gray column. The maining columns only apply if extra sets of currents, uses the multipliend/block in the gray column. The maining columns only apply if extra sets of currents, uses the multipliend/block in the gray column. The meter, (NOTE: One set of current sensors consists of 3 individual sensors, one on sech phase) Cross reference the model number to the entitient correct sensors construct as sensors to see your KWH Multiplier.	merer in the chart below. • multiplier/divisor in the rs are being installed in 3 individual sensors, one art sensors to see your K	menter reuner of sensor of use ou une current sensore installed un pour meter in une chat befow. If you are only using the set of sensors supplied with your E-MON meter, use the multiplier/livisor in the gray column. The rematring columns only apply if extra sets of current sensors are being installed in addition to the set supplied with the meter. (NOTE: One set of current sensors consists of 3 individual sensors, one on each phase) Cross reference the model number to the number of sets of current sensors to see your KWH Multiblief.	plied	Q. What size wire defines for the line voltage leads. A. These wires are normally # 14 AWG, but be sure to check your local electrical codes for proper sizing.
					-	Q. What size wire do I use to extend the current sensor leads. Do they have to be twisted?
Model No		Sets (3 sensors per set) of Current Sensors Installed	f Current Sensors Installs	3		A. These wires are normally 14-22 AWG wire (consult your local electrical codes for proper sizing. The wires do not have to be Weisted, and can be extended up to 2,000 feet.
		2	3	4		Q. The load I need to monitor has parallel feeds. How do I install the sensors for this application?
20825 48025 60025		× +	9 X	8 X		A. There are two ways you can monitor parallel feeds. The easiest (and preferred) way to monitor parallel feeds is to clamp the sensors around all feed wires for that phase, if the core supplied with your meter is not large enough, contact your local distributor and ask them to order a larger core size for your meter. The second way to monitor parallel feeds
20850 48050 60050		8 X	X 12	X 16		is to clamp the sensor around one of the feed wires. When you read the meler, the final reading must be multiplied by the number of feed wires for each phase. (e.g. 6 conductors in parallel per phase. Clamp current sensors around one of the conductors of each phase. When you read the meter take the reading from the display, times the multiplier one of the conductors of each phase. When you read the meter take the reading from the display, times the multiplier printed on the window, times six (6) for the parallel conductors, to get your consumption.)
208100 480100 600100		X 16	X 24	X 32		Q. I have two subpanels that i would like to monitor with one meter. These subpanels are fed by different transformers in the building. Can I parallel sensors & monitor both panels with one meter?
208200 480200 600200		X 32	X 48	X 64		A. No. These panels cannot be monitored by one meter because the are from different power sources. When you parallel current sensors, all loads being monitored must be from the same voltage source. Q. I have 5 breakers in one subbanel I would like to monitor with one meter. Can this be done without
208400 480400 600400		X 64	96 X	X 128		
208800 480800 600800		X 128	X 192	X 256		ure A prizes sersor, and the same for B priese and C prizes. The meter should be sized by the highest amount bein monitored by one sensor. Q. I've gone through the troubleshooting guides, and I still can't get my meter to work. What should I do?
2081600 4801600 6001600		X 256	Not Recommended	Not Recommended		 Contact E-MON's Engineering Department at: Eastern Region: (800) 334-3666 or Western Region: (800) 810-3666 Contact E-MON's Engineering Department will help you do detailed troubleshooting of the meter
2083200 4803200 6003200		Not recommended	Not Recommended	Not Recommended		installation in the field and assist you in getting the meter up and running without you having to remove the meter return It.

Chapter 9 Frequently Asked Questions

Q. How accurate are the E-MON Meters?

- A. E-MON meters are Certified to ANSI C12.1 metering standards. (+/- 1% from 1-100% of the rated load)
- Q. What are the plugs inside the meter used for?
- A. The plugs inside the E-MON meter are used to interface E-MON meters with several options that are available including Pulse output, D/A output, high resolution displays, and Automatic Meter Reading systems.
- Q. I have an E-MON KWH Meter. There are 3 decimal points between the digits that blink. When I read the meter, which dot is the decimal point?
- A. The dots between the digits on the KWH meter are NOT decimals. These dots provide a visual pulse showing the load being monitored by the meter. When a higher load is monitored, the dots will blink faster. The display should be read as whole numbers.
- Q. Can I get demand readings without having the demand meter?
- A. The only way to get demand readings without having a demand meter is to interface the KWH meter with an energy management system that can Interpret the KWH readings to KW. E-MON's CE-MON Automatic Meter Reading System, for example, has this capability.
- Q. I have 3 current sensors installed on my meter, one sensor on each phase of a three phase load, when I read the meter, do I have to multiply again by 3?
- A. No. There are 3 sensors in a set of current sensors. One sensor on each phase equates to one set of current sensors, so to read the meter simply take the display reading and multiply by the number printed on the display window. You would only multiply again by 3 if you have three sets of sensors (9 sensors, three on each phase) installed on the meter.
- Q. How do I find the cost for KWH to bill my tenants.
- A. Your local utility bill should list the cost per KWH, if it does not, simply give your utility a call and ask them the cost per KWH.
- Q. I have a 48025 meter that is monitoring a 25 amp load. I want to move the meter and now monitor a 480 volt 100 amp load. Can I use the 48025 to do this, or do I need to order a new meter?
- A. To use the 48025 meter on a 100 amp load, you must change the current sensors used with the meter. Simply contact your local distributor and order one set of 100 amp current sensors. Be sure that when you read the meter with 100 amp current sensors you use the multiplier for the 100 amp meter (X 8).
- Q. I have an existing meter that I would like to Interface with my Energy Management System. Can I field install the pulse output into the E-MON meter?

A. Yes, simply contact your local distributor and order the Pulser option.

Important Information About your New E-MON Product

E-MON Corporation is committed to producing and delivering quality products in appearance and performance. That is why our meters are covered with a *Five Year Limited Warranty* against defects in workmanship and material (see below for details).

If you have questions, we can handle them quickly and effectively with a telephone call. Please let us try to help you by phone, **before** you remove and return your E-MON product. Call our technical department at: Eastern Region: (800) 334-3666 or Western Region: (800) 810-3666 between the hours of 8:00 am and 7:30 pm, eastern time. To help us help you, please have all relevant information on hand when you call (model or part numbers, nature of difficulty, etc.)

E-MON[®] CORPORATION FIVE-YEAR LIMITED WARRANTY

Subject to the exclusions listed below, E-MON Corporation will either repair or replace (at it's option) any product that it manufactures and which contains a defect in material or workmanship. The following exclusions apply:

- This Limited Warranty is effective for a period of five (5) years following the date of manufacture (as indicated on the Limited Warranty).
- E-MON Corporation must be notified of the defect within ninety (90) days after the defect becomes apparent.
- All freight costs are the responsibility of the product owner.
- This Limited Warranty does not cover installation, removal, reinstallation, or labor costs, and excludes the battery and normal wear and tear.
- This Limited Warranty does not cover any product which has been altered from its original manufactured condition, improperly installed, abused or misused, or used in connection with equipment or materials not supplied or recommended by E-MON Corporation.
- 6. This Warranty is limited to the obligation to repair and/or replace the manufactured product. This is the exclusive remedy afforded by this Limited Warranty. IN NO EVENT SHALL E-MON CORPORATION BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, such as property damage or economic losses caused by a product.
- 7. THERE ARE NO OTHER WARRANTIES, EXPRESSED OR IMPLIED, AS TO QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

120/240 volts; 25, 50, 100, 200, 400, 800, 1600, or 3200 amps 115/208 volts; 25, 50, 100, 200, 400, 800, 1600, or 3200 amps 277/480 volts; 25, 50, 100, 200, 400, 800, 1600, or 3200 amps Call E-MON Engineering Department for 2300 V, 4160 V and higher voltage applications. Eastern Region: (800) 334-3666 or Western Region: (800) 810-3666 2-wire, 3-wire and 4-wire This covers all secondary voltage supplies: single-phase, split secondary and three-phase, both grounded and 208 200 D P = E-MON Model Fully electronic, 4-digit display and 2-digit display on KWH/Demand meters, visible and retained during loss of power. Manual reset to zero. Can be overloaded 100% without damaging meter. **TECHNICAL SPECIFICATIONS** Simply state voltage, current rating and any options required: +25% continuously; +100% for 20 cycles. Up to 3200 amps ms A.C. available Other voltages available as options. Up to 600 volts rms A.C. available -20 degrees C to +50 degrees C. PULSE OUTPUT OPTION-Certified to ANSI C12.16 +/-25% of rated voltage. 0.5 leading or lagging 50 Hz to 400 Hz ungrounded. EXAMPLE: VOLTAGE-Voltage Operating Range: High Voltage Metering: Ordering Information: **Femperature Range:** Standard Ranges: Current Overload: Voltage Overload: Voltage Input Configuration: Voltage Input: Current Input: Power Factor: Frequency: Accuracy: Display:

2/01-KWHINST

APPENDIX C

EXAMPLE SITE VISIT FORM AND PROCESS MONITORING FORM

Personnel:				-	Time:				
				-	Date:		<u> </u>		
System Statu Arrival:	19:								
Departure:			. <u>.</u>			-			
Run Timer Re	eading:					-			
Electric Meter				······	· · · · · ·				
System Data	:								
Extraction We	ell F Gate ∨	/alve:		% Open					
Dilution Valve				% Open					
Pre-Bleed Ai	r (Extractio	on Weli):			Post-F	Sleed Air	(SVE Inf	luent):	
Flow:			CFM		Flow:		(01 - 111	CFM	
Vacuum:		·	"H2O		Vacuu	m:		"H2O	
PID Reading:			PPM			eading:		PPM	
Draeger Tube);		- PPM			er Tube:	4	РРМ	
Temperature:			_°F			erature:		_°F	
Carbon Moni	toring:								
Mid:		PPM	. <u></u>	CFM	<u></u>	Temp. (_PPM (
Effluent:		PPM		CFM		Temp. (°F)		_PPM (
Carbon efflue	nt sample o	collected &	shipped to	ab?			-		
Knockout Tan	k Drained?	,					_		
# Gallons:							-		
Purge water d	lrums on-si	ite:			- <u></u>		-		
Monitoring W	/ell Gaugi	ng / Vapor l	Point Moi	nitoring:					
•	MW-C	MW-E	MW-F	MW-G	VP-1	VP-2	VP-3	VP-4	VP-5
Well/V.P. ID:							ļ		<u> </u>
Well/V.P. ID: DTW (ft):							L		
Well/V.P. ID: DTW (ft): Vac. (" H2O):									
Well/V.P. ID: DTW (ft):									
Well/V.P. ID: DTW (ft): Vac. (" H2O):				±					
Well/V.P. ID: DTW (ft): Vac. (" H2O):				<u></u>					

ect Name: ect Number: t Well:	ion Pilot Tes				Date: On-site Pe	:lennos				
	Blower Ope	etell gnitere	fnio9							
	SVE Flow	BVE	Distance from test Well (feet)							
9	ctm) (thm or	HSO) (jucµez	Monitoring Parameters							
			DTW (feet)					 		
etea bruarg			VOCs (ppm)	 			<u> </u>	 	 	
	┝───┤		(OSH ni) muu∋sV							
	-		DTW (feet)	 				 		
(nim 0E + 9mit)				 				 	 	
			Vacuum (in H2O)							
			DTW (feet)	 						
(nim 24 + 9mi)				 						
			(OSH ni) muuseV	 				 		
(oim 09 + emit)			VOCs (ppm) VOCs (ppm)	 				 		
(nim 03 + 9mi)			Vacuum (in H2O)	 				 	 	
			DTW (feet)	 				 	 	
(nim 0e + ạmi)		1	VOCs (ppm)							
			(OSH ni) muuosV	 						=
			DTM (feet)	 						
(nim 021 + 9mi)			(mqq) sOOV						 	
			Vacuum (in H2O)					 	 	
·····			DTW (feet)							
(nim 021 + 9mi)			(mqq) sOOV							
		i	Vacuum (in H2O)	 			····	 	 	

APPENDIX D

VELOCICALC PLUS AIR VELOCITY METER MODEL 8360 OPERATION AND SERVICE MANUAL

Model 8360/8382/8383/8388

VELOCICALC® Plus

Air Velocity Meters

Operation and Service Manual

September 1998 P/N 1980253 Rev C

MAIL TO:

TSI Incorporated P.O. Box 64394 St. Paul, MN 55164-0394 USA

INTERNATIONAL Sales and Customer Service: (1) 651 490-2711 Fax: (1) 651 490-2874

SHIP TO:

TSI Incorporated 500 Cardigan Road Shoreview, MN 55126-3996 USA

U.S.

<u>Sales and Customer Service:</u> (800) 777-8356 / (651) 490-2711 <u>Fax:</u> (651) 490-2874 Copyright© TSI Incorporated/September 1996/All rights reserved. Address TSI Incorporated/P.O. Box 64394/St. Paul, MN 55164/USA Fax No. (651) 490-2874

LIMITATION OF WARRANTY AND LIABILITY. Seller warrants that this product, under normal use and service as described in the operator's manual, shall be free from defects in workmanship and material for a period of twenty-four (24) months, or the length of time specified in operator's manual, from the date of shipment to the customer. This limited warranty is subject to the following exclusions:

- a. Batteries and certain other components when indicated in specifications are warranted for a period of 90 days from the date of shipment to the customer.
- b. With respect to any repair services rendered, Seller warrants that the parts repaired or replaced will be free from defects in workmanship and material, under normal use, for a period of 90 days from the date of shipment to the customer.
- c. Seller does not provide any warranty on finished goods manufactured by others. Only the original manufacturer's warranty applies.
- d. Unless specifically authorized in a separate writing by Seller, Seller makes no warranty with respect to, and shall have no liability in connection with, any goods which are incorporated into other products or equipment by the Buyer. All goods returned under warranty shall be at the Buyer's risk of loss, Seller's factory prepaid, and will be returned at Seller's risk of loss, Buyer's factory prepaid.

The foregoing is IN LIEU OF all other warranties and is subject to the conditions and LIMITATIONS stated herein. NO OTHER EXPRESS OR IMPLIED WARRANTY OF FITNESS FOR PARTICULAR PURPOSE OR MERCHANTABILITY IS MADE.

THE EXCLUSIVE REMEDY OF THE USER OR PURCHASER, AND THE LIMIT OF THE LIABILITY OF SELLER FOR ANY AND ALL LOSSES, INJURIES, OR DAMAGES IN CONNECTION WITH THIS PRODUCT (INCLUDING CLAIMS BASED ON CONTRACT, NEGLIGENCE, STRICT LIABILITY, OTHER TORT, OR OTHERWISE) SHALL BE THE RETURN OF THE PRODUCT TO THE FACTORY OR DESIGNATED LOCATION AND THE REFUND OF THE PURCHASE PRICE, OR, AT THE OPTION OF SELLER, THE REPAIR OR REPLACEMENT OF THE PRODUCT. IN NO EVENT SHALL SELLER BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES. SELLER SHALL NOT BE RESPONSIBLE FOR INSTALLATION, DISMANTLING, REASSEMBLY OR REINSTALLATION COSTS OR CHARGES. NO ACTION, REGARDLESS OF FORM, MAY BE BROUGHT AGAINST THE SELLER MORE THAN ONE YEAR AFTER THE CAUSE OF ACTION HAS ACCRUED.

The purchaser and all users are deemed to have accepted the terms of this LIMITATION OF WARRANTY AND LIABILITY, which contains the complete and exclusive limited warranty of Seller. This LIMITATION OF WARRANTY AND LIABILITY may not be amended or modified nor may any of its terms be waived except by a writing signed by an authorized representative of Seller.

Service Policy

Knowing that inoperative or defective instruments are as detrimental to TSI as they are to our customers, our service policy is designed to give prompt attention to any problems. If any malfunction is discovered, please contact your nearest sales office or representative, or call TSI's Customer Service department at (800) 777-8356 (USA) and (1) 651 490-2711 :(International).

CONTENTS

Chapte	Chapters				
1	Unpacking and Parts Identification1				
	List of Components1				
2	Setting-Up3				
	Supplying Power to the VELOCICALC				
3	Operation5				
	Overview 5 Keypad Functions 5 ON/OFF Switch 5 Measuring Velocity 5 Measuring Temperature 5 Measuring Pressure 6 Zeroing Pressure 6 Measuring Humidity (Model 8360 and 8388 Only) 6 Dew Point Function (Model 8360 and 8388 Only) 6 Flow Rate Function 7 Flow Rate (Calculated Using Velocity and Duct Area) 7 Flow Rate (Calculated Using Pressure and Flow Factor, 7 Models 8382, 8383, and 8388 Only) 8				
	Entering Flow Factor8 Time Constant Function9				
	Using the Clear, Store and Average Functions				

i

4	Maintenance	11
	Probe Tip	
	Recalibration	11
	Cases	11
	Storage	11
5	Troubleshooting	13

Appendices

Α	Specifications	15
В	DIP Switch Settings	17
С	Standard Velocity vs. Actual Velocity	19

Available Application Notes

•	Constant Temperature Thermal Anemometry Theory	#TI-10 5
•	Traversing a Duct to Determine Average	
	Air Velocity or Volume	#TI-106
•	Applications Using the VELOCICALC Plus to	
	Measure Pressure	#TI-107
•	VELOCICALC Serial Interface Connections	#TI-1 08

To obtain any of the listed Application Notes contact TSI at U.S. (800) 777-8356/(651) 490-2711 Fax: (651) 490-2874 International (1) 651-490-2711 Fax: (1) 651-490-2874


Unpacking and Parts Identification

Carefully unpack the instrument and accessories from the shipping container. Check the individual parts against the list of components in Table 1. If any are missing or damaged, notify TSI or your local distributor immediately.

Table	1. List	of components

Qty	Item Description	Part/model
1	Model 8360 VELOCICALC Plus or	8360
	Model 8382 VELOCICALC Plus or	8382
	Model 8383 VELOCICALC Plus (Articulating Probe) or	8383
	Model 8388 VELOCICALC Plus	8388
1	Carrying Case	800277
4	AA Alkaline batteries	1208013
1	AC Adapter (Optional)	
	115 V, NEMA-5	2613033
	230 V, European, CEE 7/16	2613078
	230 V, Great Britain	800169
	240 V, Australian	2613105
1	Operation and Service Manual	1980253
1	Static pressure tip	3002017
8 ft.	Rubber tubing	801039

Parts Identification



6. Battery Access Cover

2

Setting-Up

Supplying Power to the VELOCICALC

The VELOCICALC can be powered in one of two ways: four size AA batteries or the optional AC Adapter.

Installing the Batteries

Insert four AA batteries as indicated by the diagram located on the inside of the battery compartment. TSI ships the unit with alkaline batteries. The VELOCICALC is designed to operate with either alkaline or NiCd rechargeable batteries. Carbon-zinc batteries are not recommended because of the danger of battery acid leakage.

Table 2-1 Typical Battery Life at 20°C

Air Ve	locity	Alkaline	NiCd
(ft/min)	(m/s)	(hrs)	(hrs)
100	0.5	7.0	5.0
1000	5.0	4.4	3.5
9000	45.0	2.4	2.4

Using the AC Adapter

When using the AC adapter, the batteries (if installed) will be bypassed. The AC adapter is not a battery charger.

Selecting the Display Units

The VELOCICALC is capable of displaying the measured values in several different measurement units. The choices of measurement units are shown in Table 2-2.

Table 2-2. Choices of Measurement Units

	Velocity	Temperature/ Dew Point	Flow Rate	Pressure
	ft/min	°F	ft³/min	in. H ₂ O
	m/s	°C	m³/hr	mm Hg
ł			1/s	kPa

To change the display units on your VELOCICALC, refer to Appendix B, DIP Switch Settings.

Using The Telescoping Probe

The telescoping probe, mounted on the side of the VELOCICALC, contains the velocity, temperature, and humidity sensors (humidity sensor, Model 8360 and 8388 only). The probe is shipped pointing downward in the stowed position. The probe can be used either mounted on the VELOCICALC or held in your hand. If the probe is to be used mounted to the VELOCICALC, remove the probe from its stowed position, turn it 180°, and reinstall (pointing upward) in the probe mounting brackets.

Extending The Probe

To extend the probe, hold the handle in one hand while pulling on the probe tip with the other hand. Do not hold the cable while extending the probe as this prevents the probe from moving.

Retracting The Probe

To retract the probe, hold the handle in one hand while pushing on the probe tip with the other hand. If you feel the probe antenna binding, pull gently on the probe cable until the smallest antenna section is retracted. Collapse the rest of the antenna by pressing the probe tip.

When using the probe, make sure the sensor window is fully exposed and the red orientation dot is facing upstream.

Operation

Overview

The Model 8360/8382/8383/8388 VELOCICALC PLUS measures air velocity, temperature, differential pressure, and calculates volumetric flow rates. In addition the 8360/8388 VELOCICALC PLUS measures relative humidity and calculates dew point from the temperature and relative humidity readings. The Model 8383 VELOCICALC PLUS has an articulating probe. The VELOCICALC PLUS can store individual readings and compute the average of these readings.

Keypad Functions

When pressing the keys on the front panel, the VELOCICALC will beep to confirm the function. If you press a key and the VELOCICALC does not beep, then the VELOCICALC does not allow that function during the selected mode. The beep function can be disabled by changing the internal DIP switch (refer to Appendix B).

ON/OFF Switch

Slide the switch upward to the ON position. The power switch is marked in the international symbols "I' for on and 'O' for off. When the instrument is first turned on it goes through a preprogrammed power-up sequence that includes an internal self-check. First, all displayable items will appear for a few seconds. If a problem is detected, the display will light 'CAL' to indicate that it should be returned for servicing and calibration. When the VELOCICALC completes the internal self-check, it will display the approximate percentage of battery life remaining. This feature is accurate for alkaline batteries only.

Measuring Velocity

Press the VELOCITY key to display velocity measurements (the VELOCICALC will automatically start in velocity mode). The velocity will be displayed in ft/min or m/s depending on the DIP switch settings (refer to Appendix B). Place the end of the probe in the location where you want to make the measurement. Make sure the sensor window is fully opened and the red orientation dot is facing upstream.

Measuring Temperature

Press the TEMP key to display air temperature readings. The VELOCICALC will display temperature readings in either degrees Celsius (°C) or degrees Fahrenheit (°F), depending on the DIP switch settings (refer to Appendix B). Allow about 30 seconds for the temperature reading to stabilize after

switching to temperature mode. This is necessary because the velocity sensor is heated during velocity mode, and some heat is conducted down to the temperature sensor.

Measuring Pressure

Press the PRESSURE key to measure differential pressure. To measure pressure, tubing must be connected to the pressure ports on the top back of the unit. When the pressure source is connected the same way the pressure ports are marked, the meter will display a positive number.

Zeroing Pressure

If the zero reading of pressure has drifted, the pressure function can be easily re-zeroed. To reset the zero, make sure that the pressure ports are exposed to the exact same pressure. The easiest way to do this is to remove the pressure hoses and leave both ports exposed to ambient pressure.

Press and hold the PRESSURE key down for at least three seconds. The VELOCICALC will give a double beep and the display will show "0 in. H_2O " (or whatever units have been selected). When the key is released the display will be re-zeroed.

Measuring Humidity (Model 8360 and 8388 Only)

Press the HUMIDITY key to display humidity readings. The readings will be in units of percent relative humidity (%RH). The reading may need time to stabilize if the ambient conditions have recently changed.

In order to see if the humidity reading has stabilized, extend the probe and gently wave it back and forth (or place it in a location where there is a sufficient quantity of moving air), while checking the display for an upward or downward trend in the readings. When no particular trend is apparent, the reading has stabilized.

Situations that may require time to stabilize the sensor would be when moving the instrument from a cold vehicle or storage place into a heated building. Also, if the end of the probe has been warmed by being handled, it will need to cool to ambient temperature. Another example would be when moving from a location with low humidity to high humidity, or vice versa.

Dew Point Function (Model 8360 and 8388 Only)

Press the DEW POINT key to display the dew point temperature. The dew point is calculated using the temperature and relative humidity measurements. Because dew point is not measured directly, accuracy of this calculation depends on both ambient temperature and relative humidity. The dew point reading will be most accurate when the relative humidity is 50% and above (and dew point temperature is closer to the actual temperature). It

Chapter 3

will be less accurate when the relative humidity is less than 50% (and dew point temperature is farther away from the actual temperature).

Flow Rate Function

The VELOCICALC's flow rate function can calculate flow rate using a known area. The Model 8382/8383/8388 VELOCICALC can also calculate flow rate through diffusers by multiplying the square root of the pressure reading by a manufacturer-supplied flow factor. The VELOCICALC displays the volumetric flow rate in ft³/min, m³/hr, or l/s, depending on the DIP switch setting (refer to Appendix B).

Flow Rate (Calculated Using Velocity and Duct Area)

The flow rate can be calculated for a round, square or rectangular duct. The shape and size of the duct or other area through which the flow will be measured must be entered.

Entering Shape and Size

Press the FLOWRATE key to put the VELOCICALC in flow rate mode. The VELOCICALC will prompt the user to enter the shape and size, if this has not been done since the instrument was turned on. The VELOCICALC will request entry of the shape by alternately flashing the circle and rectangle (and pressure units, if DIP switch #6 is ON) on the display. If shape and size <u>have</u> been entered, the VELOCICALC will go directly to displaying flow rate.

Press the SHAPE key to select the shape of the area, rectangular (square) or circular, to measure. Each time the SHAPE key is pressed the shape will change back and forth between the circle and rectangle. When the desired shape appears on the display press the ENTER key. This will enter the shape and the VELOCICALC will then ask for the size.

Use the LARGER and SMALLER keys to select the size of the flow rate area. For a circular flow shape the VELOCICALC will ask for one size, the <u>diameter</u> of the circular area. Select the size and press ENTER to accept it. For a rectangular area the VELOCICALC will ask for two dimensions. First select the horizontal dimension and press the ENTER key, then select the vertical dimension and press ENTER.

To change the shape, press the SHAPE key to select the desired shape. Proceed as above to enter the shape and dimensions. To change the size, hold the LARGER or SMALLER key to enter the new dimensions, then press the ENTER key to accept them.

Flow Rate (Calculated Using Pressure and Flow Factor, Model 8382, 8383, and 8388 Only)

This option is available with Model 8382/8383/8388 only when DIP switch #6 is ON (refer to Appendix B). The flow rate through a diffuser is calculated by multiplying a pressure reading by a manufacturer-supplied flow factor. This flow rate measurement method is applicable for diffusers that contain pressure taps designed for this purpose.

NOTE: When using this option, make sure that the VELOCICALC pressure measurement units and flow rate measurement units are set using the DIP switches to correspond to those provided by the diffuser manufacturer (refer to Appendix B). If using kPa to do this measurement, flow factors should be entered using Pa, not kPa. If they are set incorrectly, the calculated flow rate will be incorrect.

The VELOCICALC will display flow rate and pressure units simultaneously to indicate that the flowrate is being measured from pressure and not from velocity and area. To zero the pressure transducer while in this measurement mode, press and hold the PRESSURE key. The pressure will zero and the VelociCalc will return to flow rate from pressure measurement mode.

Entering Flow Factor

Press the FLOWRATE key to put the VELOCICALC in flow rate mode. The VELOCICALC will prompt you to enter the shape, size, or flow factor if this has not been done since the instrument was turned on. The VELOCICALC will alternately flash the circle, rectangle, and pressure units on the display. If shape, size, or flow factor <u>have</u> been entered, the VELOCICALC will go directly to displaying flow rate.

Press the SHAPE key to select the pressure-flow rate measurement method. Each time the SHAPE key is pressed the shape will change between the circle, rectangle, and pressure units. When the pressure units appear on the display, press the ENTER key. The VELOCICALC will then ask for the flow factor.

The VELOCICALC will display 'FAct = ' and the current flow factor. Use the LARGER and SMALLER keys to select the value of the flow factor and press ENTER to accept it.

To change the flow factor, press the SHAPE key to select the pressure units. Proceed as above to enter the value.

Time Constant Function

Momentarily press and release the TIME CONSTANT key to view the current time-constant. To change the time-constant, press and hold the key. The available time-constant choices (1, 5, 10, 15 and 20 seconds) will sequence on the display. When the desired value is displayed immediately release the key. The VELOCICALC will always reset the time constant to 1 second when turned off.

The time-constant is actually an averaging period. The VELOCICALC display is always updated every second, however, the reading displayed is the average reading over the last time-constant period. For example, if the current time-constant is set to 10 seconds, the display will show readings averaged over the previous 10 seconds, updated every second. This is also called a 10 second "moving average."

Using the Clear, Store and Average Functions

The VELOCICALC has the ability to compute the average of a number of individual stored readings. Every time the STORE key is pressed, the currently displayed reading is added to a store buffer. When the AVERAGE key is pressed, the readings in the store buffer are divided by the number of stored readings to get the average. The CLEAR key is used to clear out the store buffer in order to start taking a new average.

Store Function

Press and hold the STORE key to store the currently displayed measurement. The display will show "STORE" and the number of stored data points that are in memory for about two seconds, and then the recorded value will be displayed until the STORE key is released.

The individual stored values can not be recalled. Only the average of the stored values can be recalled. There are five different store buffers: one for both velocity and flow rate from area, one for temperature, one for humidity, one for pressure, and one for dew point. Models 8382, 8383, and 8388 have a sixth storage buffer for flow rate from pressure. You can switch between measuring modes and store data without affecting data stored in the buffer for another measuring mode. You can later return to any mode and add additional values to the already stored values.

The flow rate from area function (measures and stores velocity readings, calculates flow rate) and velocity function use the same storage buffer. Measurements made in one mode are added to those made in the other mode. When using the flow rate from pressure measurement mode, changing the flow factor value will automatically clear the flow rate storage buffer.

Average Function

Press the AVERAGE key to display the average of the stored values of the current operating mode. The message "AVG" will appear along with a number (between 1 and 255) indicating how many stored values are in the memory buffer. The average value is then displayed for one second. To keep displaying the average value, press and hold the AVERAGE key. Additional values can be stored after the AVERAGE key has been pressed. The next time the AVERAGE key is pressed, the additional values are averaged with those already accumulated.

Clear Function

Press the CLEAR key to erase the stored value in the buffer of the currently active function. Pushing the CLEAR key in one function will not affect the values stored in other buffers. However, velocity and flow rate from area use the same buffer, so clearing velocity will also clear the flow rate. Flow rate from pressure is not affected by clearing velocity. For example, pushing CLEAR while measuring velocity will not affect the values stored for temperature.

Printer Port

While pushing the STORE, AVERAGE or CLEAR key the data is automatically transmitted to the printer port. If the optional Model 8925 Portable Printer is connected the readings will be printed.

Maintenance

Probe Tip

Periodically inspect the probe tip to ensure that it is clean. Dust and oil deposits on the velocity sensor decrease the accuracy of the VELOCICALC.

Caution:	The VELOCICALC must be switched off for cleaning. Do not
	use high-pressure air, strong solvents, or brushes to clean the
	sensor tip; damage to the sensors could result.

To remove dust, blow it off with a gentle stream of air or rinse it off with a gentle stream of water. To remove a combination of dust and oil, rinse the probe tip in isopropyl alcohol and then blow it off with a gentle stream of air. *Be careful not to get the humidity sensor wet!* (The humidity sensor on Models 8360 and 8388 is located at the base of the probe window, just inside the antenna tube.) Also, for the 8383, be careful not to allow water to enter the articulating probe joint.

Caution: Never use heat to dry the probe. Permanent damage to the sensor could result.

Recalibration

To maintain a high degree of accuracy in your measurements, TSI recommends that you return your instrument for annual recalibration. For a nominal fee, we will recalibrate the unit and return it to you with a certificate of calibration and US National Institute of Standards Technology (NIST) traceability. This 'annual checkup' assures you of consistently accurate readings; it is especially important in applications where strict calibration records must be maintained.

Cases

If the instrument case or storage case needs cleaning, wipe it off with a soft cloth and isopropyl alcohol or a mild detergent. Never submerge the VELOCICALC.

Storage

When storing the VELOCICALC for more than a month, it is recommended to remove the batteries. This prevents damage due to battery leakage.

Troubleshooting

Table 5 lists the symptoms, possible causes, and recommended solutions for common problems encountered with the VELOCICALC. If your symptom is not listed, or if none of the solutions solves your problem, please contact TSI.

Symptom	Possible Causes	Corrective Action
No display	Unit not switched on	Switch on the unit.
	Low or dead batteries	Replace the batteries or
		plug in the AC adapter.
	Dirty battery contacts	Clean the battery
		contacts.
BAT is blinking	Batteries are low	Replace or recharge
		batteries.
Display reads	Low battery charge	Replace or recharge
"LO BAT"		batteries.
	Wrong AC adapter	Replace with the correct
		AC adapter.
	Low AC line voltage	Correct the AC line
		voltage or use batteries.
	Dirty battery contacts	Clean the battery
		contacts.
Temperature	Temperature sensor is	Allow about 30 seconds
initially reads	still warm from velocity	before reading
high	mode	temperature.
Display reads	You are trying to enter	Read or record the
"ERR"	more than 255 readings	average; clear the
		storage register and proceed.
Display reads	The VELOCICALC has	Return to factory for
"CAL"	detected an internal fault	service.
Velocity reading	The flow is fluctuating	Reposition the probe in a
fluctuates badly	The new is muchaling	less turbulent section of
nuclaulos sualy		the flow or use a longer
		time constant.
Display says	The velocity,	Use an alternate
"OVER"	temperature or pressure	measurement method.
	is too high	

Table 5. Troubleshooting the VELOCICALC

Warning!	Remove the probe from excess temperature immediately:
	excessive heat can damage the sensor. The pressure sensor is protected from damage up to 10 psi. (75 kPa or 560 mm Hg)
	At higher pressures it can burst!

Notice:	There is sometimes confusion between dew point temperature and wet-bulb temperature when comparing VELOCICALC humidity readings to sling psychrometer readings. (Dew point temperature and wet bulb temperature are not the same thing.) On the psychometric chart used with a sling psychrometer, dew point temperature is a flat horizontal line, wet bulb temperature is a straight line angling downwards from the left, dry bulb temperature is a straight vertical line and relative humidity is a curved line angling upwards from the left.
---------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Appendix A

Specifications

	Model 8360/8388	Models 8382/8383
		VELOCICALC Plus
Velocity		
Measurement Range	30 to 9,999 ft/min	Same
measurement hange	(0.15 to 50 m/s)	Cume
Accuracy, ¹	3% of reading or 3 ft/min (0.02	Same
Accuracy	m/s), whichever is greater	Game
Temperature	(11/3), Whichever 13 greater	
Measurement Range	14 to 140°F (-10 to 60°C)	0 to 200°F (-17.8 to 93.3°C)
Resolution	0.1°F (0.1°C)	Same
	±0.5°F (0.3°C) ²	Same
Accuracy	<u>1 ±0.5 F (0.5 C)</u>	Same
Instrument Temp. Range Electronics		
	40 to 11285 (5 to 1580)	Como
Operation	40 to 113°F (5 to 45°C)	Same
Storage	-4 to 140°F (-20 to 60°C)	-22 to 194°F (-30 to 90°C)
Probe	14 to 140% (10 to 60%)	
Operation	14 to 140°F (-10 to 60°C)	0 to 200°F (17.8 to 93.3°C)
Storage	-4 to 140°F (-20 to 60°C)	-22 to 194°F (-30 to 90°C)
Relative Humidity Range	0 to 95%	N/A
Accuracy	±3% m ³	N/A
Dew point Range	5 to 120°F (-15 to 49°C)	N/A
Static/Differential		
Pressure	-10.00 to +10.00 inches H ₂ O	Same
Range ⁴	(-2.500 to +2.500 kPa or -20.00 to	
	+20.00 mm Hg)	
-	±0.5% of rdg ±0.01 in H ₂ O	Same
Accuracy ⁵	(±0.002 kPa or ±0.02 mm Hg)	
Volumetric Flow Rate	0.2 to 4,50,000 ft ³ /min (0.0424 to	Same
	1,170,000 m ³ /hr or 0.1 to 325,000	
	l/s)	
Duct Sizes	1 to 100 inches in increments of	Same
	0.5 inch, 100 to 255 inches in	
	increments of 1 inch	
	(1 to 100 cm in increments of 0.5	
	cm, 100 to 255 cm in increments	
	of 1 cm)	
Averaging Capability	Up to 255 values each of velocity,	Up to 255 values each of
	temperature, pressure, humidity,	velocity, temperature,
	or pressure flow	pressure, or pressure flow

	Model 8360/8388 VELOCICALC Plus (Cont.)	Models 8382/8383 VELOCICALC Plus (Cont.)		
Response Time				
(63% of final value)				
To Velocity	200 milliseconds	Same		
To Temperature	8 seconds	Same		
Time Constant	Adjustable from 1 to 20 sec.	Same		
Physical Dimensions				
External Dimensions	4.2 in x 7.2 in x 1.5 in	Same		
	(107 mm x 183 mm x 38 mm)			
Probe Length	29 in (735 mm)	37 in (940 mm)		
Weight (with batteries)	1.2 lbs (0.54kg)	1.1 lbs (0.5 kg)		
Display	4-digit LCD, 0.6 in (15 mm) digit height	Same		
Printer Interface	Type: Serial	Same		
	BAUD Rate: 1200			
Power	Four AA-size NiCd rechargeable	Same		
	or Alkaline Batteries (included) or			
	AC adapter			

1 Temperature compensated over an air temperature range of 40 to 150°F (5 to 65°C)

Accuracy with instrument case at 77°F (25°C).
 Add uncertainty of 0.05°F/°F (0.03°C/°C) for change in instrument temperature.
 3 Accuracy with probe at 77°F (25°C).
 Add uncertainty of 0.1%rh/°F (0.2%rh/°C) for change in probe temperature. Includes

1% hysteresis.

4 Overpressure range = 300 inches H₂O (75 kPa, 560 mm Hg)

Specifications within parentheses indicate metric equivalents. 5 Add uncertainy of ±0.02%/°F (±0.03%/°C) for change in instrument temperature.

Appendix B


DIP Switch Settings


To access the DIP switches, remove the batteries from the battery compartment. On the inside of the battery compartment, there is a window with eight DIP switches. The table below shows the functions for each switch.

Caution:		tain that power is turned of DIP switch settings.	ff before
Switch	Function	OFF	ON
	** 1 *.		

Switch	Function	UFF	
1	Velocity	ft/min & ft ³ /min	m/s
2	Flow Rate*	1/s	m ³ /hr
3	Pressure	in. H ₂ O	kPa and mm Hg
4	Pressure**	kPa	mm Hg
5	Temperature	Degrees Fahrenheit (°F)	Degrees Celsius (°C)
6	Flow Rate (8382, 8383, 8388 only)	Flow rate from velocity and area	Flow rate from pressure and flow factor or from veloctiy and area
7		Reserved	Reserved
8	Beep	Beep Disabled	Beep Enabled

- The ON position is away from the batteries and OFF is towards the batteries.
- Always leave DIP switch #7 in the OFF position.
- To select flow rate to display l/s or m³/hr, DIP switch #1 must be in the ON position.
- ** To select Pressure to display kPa or mm Hg, DIP switch #3 must be in the ON position.





Appendix C

Standard Velocity vs. Actual Velocity

Since thermal air velocity sensors are sensitive to changes in air density and air velocity, all thermal anemometers indicate velocities with reference to a set of standard conditions. For TSI instruments, standard conditions are defined as 70° F (21.1° C) and 14.7 psia (101.4 kPa). Other manufacturers may use different values.

Standard velocity is the velocity the air would be moving if the temperature and pressure were at standard conditions. It is usually the most useful measure of airflow because it defines the heat-carrying capacity of the air.

Actual velocity is the velocity at which a microscopic particle of dust would be traveling if it were in the air stream.

In some instances, actual air velocity rather than standard velocity may be of interest. To obtain the value for actual velocity, multiply your standard velocity by the following density correction factor:

Actual Velocity =
$$(Standard Velocity) \left[\frac{460 + T}{460 + 70} \right] \left[\frac{14.7}{P} \right]$$

Where

T = Ambient temperature in degrees Fahrenheit

P = Ambient pressure in psia

If you use metric units, the equation becomes:

Actual Velocity = (Standard Velocity)
$$\left[\frac{273 + T_m}{273 + 21.1}\right] \frac{101.4}{P_m}$$

Where

 T_m = Ambient temperature in degrees Celsius

 P_m = Ambient pressure in kPa

Example No. 1:

You want to measure the actual velocity in a duct. The air temperature in the duct is 55° F and the pressure is 14.24 psia. You take a measurement and the display reads 1200 feet per minute (ft/min).

ActualVelocity =
$$1200 \left[\frac{460 + 55}{460 + 70} \right] \frac{14.7}{14.24} = 1203.7 \, \text{ft} / \text{min}$$

Example No. 2:

You need to measure the actual velocity in a plenum. The air pressure is 99.4 kPa and the temperature is 27° C. The display reading is 2.3 meters per second (m/s).

ActualVelocity =
$$2.3 \left[\frac{273 + 27}{273 + 21.1} \right] \frac{101.4}{99.4} = 2.39 \ m \ / \ s$$

APPENDIX E

COMPLETED NYSDEC AIR PERMIT APPLICATION

DEC ID		APPLICATION ID			OPRIGRAMS FORE
	Section	I - Certificat	ion		nar Hoddor Haadal Gandal Gandal Gandal Gandal Gangad
(Title	V Certification			
I certify under penalty of law that this document and that qualified personnel properly gather and evaluate	e the information submi	tted. Based on my ini	quiry of the person of	or persons directly	y responsible for gathering
information (required pursuant to 6 NYCRR 201-6.3 submitting false information, including the possibility			ns.		re are significant penalti
Responsible Official Signature			Title Date		1 1
	State Fa	acility Certificati	on		
I certify that this facility will be operated in con	*				<u> </u>
Responsible Official		·····	Title	}	
Signature	·····		Date) <u> </u>	1 1
<u> </u>	Section II - Ide	ntification In	formation		
Title V Facility Permit				Facility Permit	
New Significant Modification Renewal Minor Modification	 Administrative General Permit Ti 		• Ne	eral Permit Title:	 Modification
 Application involves construction of new factories 			n involves constru		
		wner/Firm			
Name Adams boulevard	Granoration				
Street Address 195 Mariae	freet				
City Farmino ble		State NY	Cou	ntry US	Zip /1735-05
Owner Classification • Eederal • Corporation/Par	thership	 State Individual 	 Municipal 		Taxpayer ID
Corporational at					
		Facility		·····	Confide
				,·.,	······································
Location Address Adams Bould					7: 1/->>
· City / · Town · Village Babyle	<u>n NT</u>	of Deperintion			Zip 1/735
		ect Description			Continuation She
Installation and operation of a					<u> </u>
imported soil. The purpose		cation is to		record or	the technic
specifications and areaosed		the syste			
		ontact Mailing	Address		
		Vichael	<u></u>		631 293-7393
	watton	Title		Fax No. ()
	reet	State Ary	Country C	15	7 1/7 2 - A
City Forming dale	Essility Cor			<i></i>	Zip 11735-03
Name (Last, First, Middle Initial)		ntact Mailing Ac	01692	Phone No.	100 787-1001
	Colo Lan +	Title Project	Alexant	Fax No.	<u>(518) 783-/996</u> 1) 783-8397
	Tosta cture In		IN amagel		1 105-027/
Street Address 13 Britis Ame	rican Bouler	State NY	Country US	~	Zip 121/0- 14
LOINIM		1 N/	1 county of		<u></u>



	-	DE	C ID	
•			-	

				Section I	II - Facility I				
					Classificatio				
 Hospi 		Residential	• Ed	ucational/lr		• Comme		dustrial	Utility
				Affooto	ed States (Titl				
 Vermo 	ont	Massac	husetts			Pennsylvani	a Tribal La	nd:	
• New H	Hampshire	 Connect 	ticut	• New		Ohio	Tribal La		
					SIC Codes				
2752									
	· · · · · · · · · · · · · · · · · · ·								
				Fa	acility Descrip	otion		Conti	nuation Shee
The				as lig	ht must	ry, and is	currently	listela	s a
<u></u>		ife in t			te Repist	ry of Ind	ctive Haza	rdous l	Jaste
	losal Si	he due	to P(E	- infac	ted soil de	12 groun	water.		
					e Statements	<u> </u>	<u> </u>		
		a data of this a		facility is in a	omplignog with g				
							uirements: • YES		lication (the 'NC
If one of box mu	or more emissi Jst be checked	ion units at the d), the noncom	e facility are no plying units m	ot in compliar ust be identif	nce with all applicated in the "Complia	able requiremen ance Plan" block	ts at the time of sigr on page 8 of this fo	ning this app rm along wit	h the complianc
lf one o box mu plan inf	or more emissi ust be checked formation requ	ion units at the d), the noncom	e facility are no plying units m	ot in compliar ust be identif	nce with all applicated in the "Complia	able requiremen ance Plan" block	is at the time of sigr	ning this app rm along wit	h the complianc
If one of box mu	or more emissi ust be checked formation requ ng:	ion units at the d), the noncom uired. For all e	e facility are no plying units m mission units	ot in compliar ust be identif at this facility	nce with all application in the "Complia y that are operation	able requiremen ance Plan" block ng <u>in complianc</u>	ts at the time of sigr on page 8 of this fo	ning this app rm along witi e requiremer	h the compliance nts complete th
lf one o box mu plan inf	or more emissi ust be checked formation requ ng: This facility those units	ion units at the d), the noncom lired. For all e will continue to referenced ir	e facility are no plying units m mission units to be operated the complian	ot in complian ust be identif at this facility and maintain ce plan porti	nce with all applica ied in the "Compli- y that are operation ned in such a man on of Section IV c	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application	as at the time of sign on page 8 of this fo g with all applicable compliance for the n.	ning this app rm along wit e requiremen duration of th	h the complianc nts complete th ne permit, excep
lf one o box mu plan inf	or more emissi ust be checked formation requing: This facility those units For all emis meet all su	ion units at the d), the noncom uired. For all e will continue f referenced ir ssion units, su uch requiremen	e facility are no plying units m mission units to be operated the complian bject to any a nts on a timely	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec v basis.	nce with all applica ied in the "Compli- y that are operation ned in such a man on of Section IV o uirements that with	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect	is at the time of sign on page 8 of this fo g with all applicable compliance for the h. ive during the term	ning this app rm along wit e requiremen duration of th of the permi	h the compliance hts complete the ne permit, except it, this facility with
lf one o box mu plan inf	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc	ion units at the d), the noncom uired. For all e will continue t s referenced ir ssion units, su ach requirement se certification	e facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. submitted a	nce with all applica ied in the "Complia y that are operation ned in such a man on of Section IV of guirements that with at least once a yea	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect	as at the time of sign on page 8 of this fo g with all applicable compliance for the n.	ning this app rm along wit e requiremen duration of th of the permi	h the compliance hts complete th he permit, excep it, this facility wi
lf one o box mu plan inf	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc	ion units at the d), the noncom uired. For all e will continue f referenced ir ssion units, su uch requiremen	e facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. submitted a	nce with all applica ied in the "Complia y that are operation ned in such a man on of Section IV of guirements that with at least once a yea	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect	is at the time of sign on page 8 of this fo g with all applicable compliance for the h. ive during the term	ning this app rm along wit e requiremen duration of th of the permi	h the complianc hts complete the ne permit, excep it, this facility wi
lf one o box mu plan inf	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc	ion units at the d), the noncom uired. For all e will continue t s referenced ir ssion units, su ach requirement se certification	e facility are no plying units m mission units a to be operated a the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. e submitted a determine the	nce with all applica ied in the "Complia y that are operation on of Section IV of uirements that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w	as at the time of sign on page 8 of this fo g with all applicable compliance for the ive during the term ill certify complianc	ning this app rm along wit e requiremend duration of the of the permine se status with	h the complianc nts complete the ne permit, excep it, this facility wi n respect to eac
If one of box mu plan inf followir • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me	a facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. submitted a determine the cility Appli	nce with all applica ied in the "Complia y that are operation ned in such a man on of Section IV of guirements that with at least once a yea	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w	as at the time of sign on page 8 of this fo g with all applicable compliance for the ive during the term ill certify complianc	ning this app rm along wit e requiremend duration of the of the permine se status with	h the complianc nts complete the ne permit, excep it, this facility wi n respect to eac nuation Sheet
lf one o box mu plan inf	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc	ion units at the d), the noncom uired. For all e will continue t s referenced ir ssion units, su ach requirement se certification	e facility are no plying units m mission units a to be operated a the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. e submitted a determine the	nce with all application the "Complia ied in the "Complia y that are operation on of Section IV of universents that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w	is at the time of sign on page 8 of this fo g with all applicable compliance for the n. ive during the term ill certify compliance nts	ning this app rm along wit e requiremend duration of the of the permine ce status with • Conti	h the complianc nts complete the ne permit, excep it, this facility wi n respect to eac
If one of box mu plan inf followir • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me	a facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. submitted a determine the cility Appli	nce with all application the "Complia ied in the "Complia y that are operation on of Section IV of universents that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w	is at the time of sign on page 8 of this fo g with all applicable compliance for the n. ive during the term ill certify compliance nts	ning this app rm along wit e requiremend duration of the of the permine ce status with • Conti	h the complianc nts complete the ne permit, excep it, this facility wi n respect to eac nuation Shee
If one of box mu plan inf followir • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me	a facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. submitted a determine the cility Appli	nce with all application the "Complia ied in the "Complia y that are operation on of Section IV of universents that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w	is at the time of sign on page 8 of this fo g with all applicable compliance for the n. ive during the term ill certify compliance nts	ning this app rm along wit e requiremend duration of the of the permine ce status with • Conti	h the compliance nts complete the ne permit, except it, this facility with n respect to eacce nuation Shee
If one of box mu plan inf followir • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me	a facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. submitted a determine the cility Appli	nce with all application the "Complia ied in the "Complia y that are operation on of Section IV of universents that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w	is at the time of sign on page 8 of this fo g with all applicable compliance for the n. ive during the term ill certify compliance nts	ning this app rm along wit e requiremend duration of the of the permine ce status with • Conti	h the compliance nts complete the ne permit, except it, this facility with n respect to eace nuation Shee
If one of box mu plan inf followir • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me	a facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. submitted a determine the cility Appli	nce with all application the "Complia ied in the "Complia y that are operation on of Section IV of universents that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w	is at the time of sign on page 8 of this fo g with all applicable compliance for the n. ive during the term ill certify compliance nts	ning this app rm along wit e requiremend duration of the of the permine ce status with • Conti	h the compliance nts complete the ne permit, except it, this facility with n respect to eace nuation Shee
If one of box mu plan inf followir • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me	a facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. e submitted a determine the cility Appli	nce with all application the "Complia ied in the "Complia y that are operation on of Section IV of universents that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w I Requireme Paragraph	is at the time of sign on page 8 of this fo g with all applicable compliance for the n. ive during the term ill certify compliance nts	ning this app rm along wit e requirement duration of the of the permine ce status with • Contine Clause	h the compliance ints complete the ne permit, except it, this facility with n respect to each nuation Shee Sub Claus
If one of box mu plan inf followir • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer Type	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me	a facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. e submitted a determine the cility Appli	nce with all application of the "Complia ied in the "Complia y that are operation on of Section IV of uirements that with at least once a year e status.	able requiremen ance Plan" block ng <u>in complianc</u> ner as to assure of this application ill become effect ar. Each report w I Requireme Paragraph	is at the time of sign on page 8 of this fo g with all applicable compliance for the n. ive during the term ill certify compliance nts	ning this app rm along wit e requirement duration of the of the permine ce status with • Contine Clause	h the complianc ints complete the ne permit, except it, this facility with respect to eac nuation Sheet Sub Claus
If one c box mu plan inf followin • • • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer Type	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me Part	a facility are no plying units m mission units a to be operated to the complian bject to any a nts on a timely reports will be thod used to c Fac Sub Part	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. e submitted a determine the cility Appli Section Facility S Section	ied in the "Complic ied in the "Complia y that are operation on of Section IV of uirements that with at least once a year e status. Cable Federa Sub Division	able requiremen ance Plan" block ng <u>in complianc</u> of this application il become effect ar. Each report w Paragraph	is at the time of sign on page 8 of this fo g with all applicable compliance for the ive during the term ill certify compliance nts Sub Paragraph	ning this app rm along wit e requirement duration of the of the permit ce status with Clause	h the complianc nts complete the ne permit, except it, this facility with n respect to eac nuation Sheet Sub Claus
If one c box mu plan inf followin • • • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer Type	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su the requirement e certification nt, and the me Part	e facility are no plying units m mission units a to be operated the complian bject to any a nts on a timely reports will be thod used to c Fac Sub Part	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. e submitted a determine the cility Appli Section	nce with all application of the "Complia y that are operating on of Section IV of uirements that with the least once a year e status. Cable Federa Sub Division	able requiremen ance Plan" block ng <u>in complianc</u> of this application il become effect ar. Each report w Paragraph	s at the time of sign on page 8 of this fo g with all applicable compliance for the ive during the term ill certify compliance nts Sub Paragraph	hing this app rm along with requirement duration of the of the permine e status with Clause Clause	h the complianc hts complete the he permit, except it, this facility with respect to eac nuation Sheet Sub Claus nuation Sheet Sub Claus
If one c box mu plan inf followin • • • •	or more emissi ust be checked formation requing: This facility those units For all emis meet all su Complianc requiremer Type	ion units at the d), the noncom uired. For all e will continue to referenced in ssion units, su uch requirement e certification nt, and the me Part	a facility are no plying units m mission units a to be operated to the complian bject to any a nts on a timely reports will be thod used to c Fac Sub Part	ot in compliar ust be identif at this facility and maintain ce plan porti pplicable rec basis. e submitted a determine the cility Appli Section Facility S Section	ied in the "Complic ied in the "Complia y that are operation on of Section IV of uirements that with at least once a year e status. Cable Federa Sub Division	able requiremen ance Plan" block ng <u>in complianc</u> of this application il become effect ar. Each report w Paragraph	s at the time of sign on page 8 of this fo g with all applicable compliance for the ive during the term ill certify compliance nts Sub Paragraph	hing this app rm along with requirement duration of the of the permine e status with Clause Clause	h the complianc hts complete the he permit, except it, this facility with respect to eac nuation Sheet Sub Claus nuation Sheet Sub Claus



1			D	Ē) IC)		
-	-				-			

-

					nformation ance Certific						
	· · · ·		Fau			allon			Continu	ation She	
Title	Туре	Part	Sub Part	Section	Citation Sub Division	Daragrap		Paragraph	Claur	o Sub C	
Title	Туре	rait	Sub Fait	Section	Bub Division	l raiagiap	1 0001	alagraph	Claus		
Applicable F	ederal Requirement	- Canaling	CA	S No.		I(ontamir	ant Name		<u> </u>	
 State Only I 	Requirement	 Capping 									
	·				Information						
Ambient /	Air Monitoring	Work F	Practice Invo	olving Specifi	c Operations	• Re	cord Kee	eping/Mair	itenance	e Procedu	
	, <u>,</u>				ription	Ĵ.			- ,		
					veeks at					Hoerca	
Tosks in	clude off.	of equit	ment an				air sa	maling	. M	nthe	
- / /		submitted	to the	. NIVISIA.	r of Envir	on men to	len	redia tis	<u>y ~</u>		
									-		
	k Practice Process Material						Deference Test Method				
туре				Description							
	Tasks include OHM of equipment and influent reforts will be submitted to the Mussion of the										
							Manu	ufacturer N	ame/Mo	odel No.	
						Li	mit Units				
L L	upper		ower	Code			Desc	ription		· ·	
	Averaging Metho	 od		Monitoring	Frequency		R	eporting R	auirem	ents	
			Code		Description		Reporting Requirements Code Description				
			Fa	cility Emiss	ions Summa	ary			Continua	ation She	
CAS	No.		Cont	aminant Name		ŀ	(ibo/s		ange	Actua (Ibs/yr	
NV075	00 - 5			PM-10	······		(lbs/y	"/ C	ode	(iD9/yi	
	00 - 5		DAL	RTICULATES						· · · · · · · · · · · · · · · · · · ·	
	09 - 5			FUR DIOXIDE			<u>_</u>	<u> </u>			
	00 - 0			S OF NITROGE	<u></u>						
	08 - 0			ON MONOXIDE							
	92 - 1			LEAD							
	998 - 00 - 0 VOC						B		+		
NY100 -	00 - 0			HAP [7	ota/]		A				
00127 -	18 - 4	-	Tetrach	loro ether			A				
	59-2			Dichbro e	1.		- Á				
	27-21		<u>u 77</u>								
00/56 -			Trichlan	a p Hiono		1	/ /	1	I		
00156 - 00079 -	01 - 6 60 - 5			<u>e thene</u> 2-Dichbo			^/ 				

12/21/01



			DE)		
-	Т	ΪT		-			Τ

Section III - Facility Information (continued)

				Fac	lity Complia	ance Certific	ation		•	Continu	ation Sh
					Rule	Citation					
Title	T	уре	Part	Sub Part	Section	Sub Division	Paragra	oh Sub	Paragrap	h Clau	se Sub C
							L				
Applicable			 Capping 	CA	S No.			Contami	nant Nam	ie –	
 State Only 	Requireme				 Monitoring	Information					
 Ambient 	AirMoni	itoring	A Mark D	rootioo Inv	olving Specifi			ocord Ko	eping/Ma	intonene	- Droood
Ambient						. <u></u>	• 1		ершулиа	Internatio	
			<u></u>		Desc	ription					
		<u></u>	·								
						· · · · · · · · · · · · · · · · · · ·					
	Type Code Paramet				Material Description			F	Reference	e Test Me	ethod
Туре		Code			Description						
			Para	meter							
	Code				Description			Man	ufacturer	Name/M	odel No.
		Limit					L	imit Units			
	Upper		Lo	wer	Code	<u> </u>		Desc	ription		
	A			r		l			an autica r		
Code	Averagi		on	Code	Monitoring F	Description		Code	eporting F	Requiren Descri	
					-				1		
				Fa	cility Emiss	ions Summa	агу		$\overline{(}$	Continu	ation She
CAS	' No			Cont	aminant Name	· · · · ·			PTE		Actu
								(lbs/	yr)	Range Code	(lbs/y
	- 00 -				PM-10						
	- 00 -			PAF	RTICULATES						
	- 09 -		<u></u>	SUL	FUR DIOXIDE						
	- 00 -				S OF NITROGE						
	- 08 -			CARBO	ON MONOXIDE						_
	- 92 -				LEAD						
	- 00 -				VOC						
					HAP						
	- 00 -	0						-			
			[.].	.l- Tric	hloro ett	ine				A	
NY100 ·			<u>,,</u>	.l- Tric	hloro eth	ine				A	
NY100 ·			<u>(</u> ,	, - <i>Tric</i>	hloro ett	ine				<u>A</u>	
NY100 ·			<u> </u>	, - Tric	hloro eth					<u>A</u>	



	DEC ID
)	

				Unit Desc	it Information			inuation Sh
EMISSION UNIT	0-1-10	møl	1331011	Unit Dest		<u></u>	· Con	inuation 5n
The emissi	Son wast ?		1.0	emelal	Activities as	+ the c	to	On /scher
		discharged t						
					7	/		
		· · · · · · · · · · · · · · · · · · ·						
			E	Building			• Cont	inuation Sh
Building		Building Na			Length (ft)		· · · · ·	Orienta
/	A	laurs Boulevas	d		340	30	Ð	Jerey J Worst C
•								
					- 1			_
			Emi	ssion Poir			Cont	inuation Sh
EMISSION PT.							Cross S	Section
Ground Elev. (ft)	Height (ft)	Height Above Structure (ft)	Inside	Diameter (in)	Exit Temp. (• F)	Length		Width (
8	30	10		X4	27	-		
Exit Velocity	Exit Flow	NYTM (E)		(TM (N)	Building	Distance	Distance to	
(FPS)	(ACFM)	(KM)		(KM)		Property Line (ft)		Remov
37,89	200	X		X	ves	50		
EMISSION PT. Ground Elev.	Li ciabt	Height Above	Incide	Diameter	Exit Temp.		Cross S	Section
(ft)	Height (ft)	Structure (ft)	inside	(in)	(•F)	Length		Width (
Exit Velocity	Exit Flow	NYTM (E)		(TM (N)	Building	Distance		Date
(FPS)	(ACFM)	(KM)		(KM)	,	Property Li	ne (it)	Remov
						1		
		Frr	nission	Source/C	Control		Cont	inuation Sh
Emission Source	Date of	Date of D	Date of	C	Control Type	Manu	facturer	's Name/M
ID Type	Construction		emoval	Code	Description			No.
Carbon K Design		9/07 Capacity Units		048 A	Ctive feed Carbon	No. Ensin	Mad	e Type
Capacity Code	Design	Description		Code	Description	Code		Description
400 118	Maxin	rum Capacify	/					-
Emission Source	Date of Construction		Date of emoval	C Code	Control Type Description	Manu		's Name/M lo.
					Description			
Design	Design	Capacity Units			Vaste Feed			е Туре
Capacity Code	I	Description		Code	Description	Code		Description



DEC ID

	Section IV - E			on (continue	d)
		Process I	nformation		Continuation S
EMISSION UNIT	RMØ1	·	· · · · · · · · · · · · · · · · · · ·	· · · · · · · · · · · · · · · · · · ·	PROCESS 5
			ription		
The SVE sus	ten will Au	1 aga on ing	fel, 200	cfm sort va	Nor from the
subsurface an	6 20 cfm	make-up a	ric through	4 the arts	m units.
		/			· · · · ·
······					
					· · · ·
			-		
Source Classification		Chruput		Thruput Qu	· · · · · · · · · · · · · · · · · · ·
Code (SCC)	Quantity/Hr	Quantity/Yr	Code		Description
	13,200	Operation	0/56	Average :	220 cfm Entet
 Confidential Operating at Maximum (Capacity	Uperating Hrs/Day	Schedule Days/Yr	Building	Floor/Location
 Activity with Insignificant 		24 24	365	1	
	E	mission Source/		er(s)	9
				I	
				1	
EMISSION UNIT -					PROCESS
		Desc	ription		
	· · · · · · · · ·	<u> </u>		· · · · · · · · · · · · · · · · · · ·	<u> </u>
				· · · · · · · · · · · · · · · · · · ·	
	···· ··· ····				
		<u> </u>			
Source Classification	Total 1	Fhruput		Thruput Qu	antity Units
Code (SCC)	Quantity/Hr	Quantity/Yr	Code		Description
 Confidential Operating at Maximum (Capacity		Schedule	Building	Floor/Location
 Operating at Maximum C Activity with Insignificant 		Hrs/Day	Days/Yr		
		1	.		
	E	mission Source/0	Control Identifie	r(S)	
····	E	mission Source/0			



		C)EC)		
-				•			


Emissio	n Emissio	on Process	Emissio		Em	issior	n Unit App	licable F	ederal Requ	uiremen	ts • C	ontinua	tion St
Unit	Point	100033	Source	Title	Туре	Part	Sub Part	Section	Sub Division	Parag.	Sub Parag	Clause	Sub (
-				1					T T	1			
-			<u> </u>								<u> </u>		
_		-											
			<u></u>								1		
-				<u> </u>					<u>i</u>				
				_	_		11 11 01 1						
Emission	n Emissio	on Process	Emissior					· · · · ·	equirements	*	T	ontinual	
Unit				Title				Section	Sub Division	Parag.	Sub Parag	. Clause	Sub (
<u>0-IRM</u>	Ø Stack	SVE	VGAC	6	NYCR	21	3,3	L	79				
-													
-													
-													
			F	miee	sion	Init (Complie	ance C	ertificatio	n		ontinuat	on Sh
		<u></u>										onunudl	011011
			_				ule Cita						
Title	Туре	F	Part S	Sub Pa	rt S	ection	Sub	Division	Paragraph	Sub	Paragraph	Clause	Sub C
	<u> </u>		<u> </u>						<u> </u>				
	licable Fed	colon I		missio		te On	ly Require	ement	 Cappir 				
Emission		pint Pro		Source			CAS No.			C	ontaminant Na	ame	
-							-	-					
<u></u>					Mc	onito	ring Inf	ormatic	on				·······
• Con	ntinuous Er	nission Ma	nitoring						s or Control	Device	Parametere	as Surr	nate
Chinte	rmittent En	nission Te	sting			• Wo	ork Practic	e Involvi:	ng Specific (Dperatio	ns		-9uto
• Aml	bient Air Mo	onitoring				• Re	cord Kee	oing/Mair	ntenance Pr	ocedure	S		
						C)escript	ion					
Masta	via Ja.	14,000	ke I I	a share	, chan		•		reafter.	Mr +1	I. An	trai	11 4
		I A A	<u>U To//(</u> 	WING W/C	1 1 a	d'	Lineniu	1 P	Environme	L/	ly report		
submi	41		W 107	K JY	470	re fi	1-1 14 @a7	OTY	MUITOMM		onserve	1704-	-
	ern bu	rpau.		D									
Nork Prac Type		ode		Proce	ess Mat	terial script				R	eference Te	st Metho	bd
, ype	<u> </u>	,				sonp							
			Der										
	Code		Para	meter	De	script	lion			Manu	ifacturer Nai	me/Mod	el No.
					00				<u> </u>				
		1 imalé			T		· ·			nit Units			
	Upper	Limit		wer	ł	Со	de				iption		
	- 44.01						<u> </u>		·····	2000	<u></u>		
						_		-					
	A								1	_	and a set in the set of the		4
Code	Averaging	Method Description			Mode M	onito	ring Frequ Descr			Re ode	porting Rea	luiremer Descripti	



		 D	EC II)		٦
-	<u> </u>		-			

					ation of Non- Rule	Citatio			- • • • • • • • • • • • • • • • • • • •		Continu	
Title	Тур	е	Part	Sub Par		Sub Divi		Para	agraph S	Sub Paragra	ph Clause	Sub C
Emissio	on Unit	Emiss	ion Point	Process	Ernissio	n Source		• Ap	plicable Feo ate Only Red	leral Requir	ement	
-								• 312				
					Des	cription						
	<u>····</u> ·.						.		•		ć	· •
						<u></u>				····-		
Title	Туре	0	Part	Sub Par		Citatio Sub Divi		Dara	agraph S	Sub Paragra	ph Clause	Sub C
1100	<u> </u>	- -	rait	Subran	Section		51011	Faic		Sub Falagra		3000
Emissic	n Unit	Emiss	on Point	Process	Emissio	n Source				leral Require	ement	_
•								 Sta 	ate Only Red	quirement		
					Desc	ription	1		·			
										· · ·		
												<u> </u>
				<u></u>								
	. *											
					Process Emis	sions	Summa	ary			Continua	
EMISS	ION UNIT	Ø	- IRV	$h \emptyset I$						·····	PROCESS	
CA	S No.			Contamina	nt Name		% Thrup	out	% Capture	% Control	ERP (lbs/hr)	ERP H Determ
00/17	- 18 -	4	tetrac	hlan	Hone					99,7	20,7	04
~/~ [/×		PTE	10102		St	andard		PTF	How		tual
(lb	s/hr)		(lbs/yr)	(s	tandard units)		Units		Deteri		(lbs/hr)	(lbs/
6.2 E		- 3	5,43 E+		······································	1			04	/	· · ·	
	ION UNIT	Ø	- IK	m Ø 1							PROCESS	5
CA	S No.			Contaminar	nt Name		%		%	%	ERP	ERP H
							Thrup	out	Capture	Control	(lbs/hr)	Determ
00079	-01-1	Ь	Hrichto PTE	ro eth	ene		L		<u> </u>	98.3	1.65	04
/16	s/hr)		(lbs/yr)		tandard units)		andard Units		PTE Deteri		(lbs/hr)	tual (lbc/
	E-2		(105/yr) 945 Et	·····					0		(105/117)	(lbs/
	E-X ION UNIT	वि	IR	n Ø I		1					PROCESS	51
					L		%	1	%	%	ERP	ERP H
CA	S No.			Contaminar	nt Name		Thrup	out	Capture	Control	(lbs/hr)	Determ
00/56	- 59 - 2	? (15-1,2-	Dichlor	sethene					90	63	04
			PTÉ				andard			How		ctual
(Ib	s/hr)		(lbs/yr)	(s	tandard units)		Units		Deter		(tbs/hr)	(lbs/
<pre>/ -</pre>	E-1		51 E+	2						94		





				Determi	nation of I				(Title	e V Only))	Continu	uation She
							Citatio				<u></u>		
Title	Тур)e	Part	Sub Pa	art Sectio		Sub Divi	sion	Para	agraph	Sub Paragra	aph Claus	e Sub Cla
Emission	Unit T	Emiss	on Point	Proces	is Er	nission	Source		• Ar	plicable Fer	deral Requir	oment	
-					-					ate Only Re		Cillent	
		-			Desc	ription							
												······	
					·· _					·····			
					F	Rule (Citatio	n					
Title	Тур	e	Part	Sub Pa	rt Sectio	י נ	Sub Divi	sion	Para	agraph	Sub Paragra	aph Claus	e Sub Cla
			Ri Part Sub Part Section sion Point Process Emi										
Emission		Emissi	D D Process E				Source		 Ap State 	plicable Fea ate Only Re	deral Requir quirement	ement	
	-			L		Desc	ription	L					
		<u> </u>									<u></u>		
			± =										
					Process	Emis	sions S	Summ	nary			• Continu	ation Shee
EMISSI	ON UNIT	Ø	- IRI	nØI								PROCES	SJV
CAS	S No.			Contamin	ant Name			~ %		%	%	ERP	ERP Ho
		6						Thru	put	Capture	Control 90	(lbs/hr)	Determir
ωυη	- 55-	~	/	74/011	<u>oethin</u> t			Standard				0.34	Ctual
	s/hr)			T	standard u	nite)		andaro Units			How mined	(lbs/hr)	(lbs/y
	F-2					11.57				Ô			
		ส					<u> </u>				<u> </u>	PROCES	s lí V
				Contant	ant Nor			%		%	%	ERP	ERPHo
	S No.					**		Thru	put	Capture	Control	(lbs/hr)	Determin
00/56	- 60 -	5 7		- Dich	bro e the	N					90	9,2E-2	04
			PTE					andaro	1		How		
	s/hr)		(lbs/yr)		standard u	nits)	<u> </u>	Units		Deter	mined	(lbs/hr)	(lbs/y
9,2E			8.06 E+1 B- IRMBI		<u> </u>			L					
EMISSI	ON UNIT	Ø	·IRI							~		PROCES	ومراجع المحرج
CAS	S No.			Contamin	ant Name			% Thru		% Capture	% Control	ERP (lbs/hr)	ERP Ho Determin
00067	- 66 -	3 Chloro form							63	7.6 E-3	04		
		<u>S</u> <u>Chloro torm</u> PTE					St	andard	1	PTE	How		Actual
(lbs	s/hr)		(Ibs/yr)	(standard u	nits)		Units		Deter	mined	(lbs/hr)	(lbs/y
28F-	-3		2.45 EH	,						0	4		



]	DEC) (()		
-	-							

			ation of Non-A Rule (tion Sh
Title Type	Part	Sub Part		Sub Divi		Paragraph	5	Sub Paragra	h (Clause	Sub C
Emission Unit	Emission Point	Process	Emission	Source		Applicable	- Fed	eral Require	ment		
-						State Onl			mora		
I	·····		Desc	ription	R						
		······		ipuoi			<u> </u>				
										2	
				· · · ·			·				
	<u> </u>							• <u> </u>	···		
		A	Rule C	`itatio	n						
Title Type	Part	Sub Part		Sub Divi		Paragraph		ub Paragrar	b C	Clause	Sub C
1100				00 0111		- aragraph	\uparrow	ab i aragia,	<u> </u>	010000	
Emission Unit	Emission Point	Process	Emission	Source		Applicable	Fed	eral Require	ment		
-						State Only	/ Req	uirement			
_			Desci	rintion			_				
			0000	puon							<u> </u>
									_		
		F	Process Emiss	sions \$	Summa	ary		<	· Co	ntinua	tion She
EMISSION UNIT	Ø.ER		Process Emiss	sions	Summa	ary		<		ontinual	tion She
	ØFER	MØ /		sions (PRO	CESS	5
EMISSION UNIT CAS No.	Ø·ER			sions (Summa % Thrupi	%		% Control		CESS	
CAS No.		MØ /		sions (%	- %		Control	PRO ER (Ibs/)CESS P /hr)	ERP H Determ
	VOC	MØ /			% Thrupi	ut Capt	ure	Control 90	PRO	PCESS P (hr) 7	S ERP H Determ
CAS No. NY998 - 00 - 0	VOC PTE	Contaminan	nt Name	St	% Thrupi andard	ut Capt	ure PTE I	Control 90 How	PRO ER (Ibs/ 7;	PCESS P (hr) 7 Ac	ERP H Determ 04
CAS No. NY993 - 00 - 0 (Ibs/hr)	<u>VOC</u> PTE (lbs/yr)	Contaminan		St	% Thrupi	ut Capt	PTE eterr	Control 90 How nined	PRO ER (Ibs/	PCESS P (hr) 7 Ac	S ERP H Determ
CAS No. NY998 - 00 - 0 (Ibs/hr) 7:7 E-1	VOC PTE	Contaminan	nt Name	St	% Thrupi andard	ut Capt	ure PTE I	Control 90 How nined	PRO BR (Ibs/ 7;	PCESS P (hr) 7 Ac (hr)	ERP H Determ 04
CAS No. NY993 - 00 - 0 (Ibs/hr)	<u>VOC</u> PTE (lbs/yr)	Contaminan	nt Name	St	% Thrupi andard	ut Capt	PTE eterr	Control 90 How nined	PRO BR (Ibs/ 7;	PCESS P (hr) 7 Ac	ERP H Determ 04/ tual (lbs/
CAS No. NY998 - 00 - 0 (Ibs/hr) 7:7 E-1	<u>VOC</u> PTE (lbs/yr)	Contaminan	tandard units)	St	% Thrupi andard Units %	ut Capt	PTE eterr	Control 90 How nined	PRO BR (Ibs/ (Ibs/ PRO BR	PCESS P /hr) Ac /hr) PCESS P	ERP H Determ 04 tual (lbs/ ERP H
CAS No. <u>NY998 - 00 - 0</u> (Ibs/hr) 7.7 E-/ EMISSION UNIT	<u>VOC</u> PTE (lbs/yr)	Contaminan	tandard units)	St	% Thrupi andard Units	ut Capt	PTE eterr	Control 90 How nined	PRO ER (Ibs/ 7,7,7) (Ibs/ PRO	PCESS P /hr) Ac /hr) PCESS P	ERP H Determ 04/ tual (lbs/
CAS No. <u>NY998 - 00 - 0</u> (Ibs/hr) 7.7 E-/ EMISSION UNIT	<u>VOC</u> PTE (lbs/yr)	Contaminan	tandard units)	St	% Thrupi andard Units %	ut Capt	PTE eterr	Control 90 How nined	PRO BR (Ibs/ (Ibs/ PRO BR	PCESS P /hr) Ac /hr) PCESS P	ERP H Determ 04 tual (lbs/ ERP H
CAS No. <u>NY998 - 00 - 0</u> (Ibs/hr) 7.7 E-/ EMISSION UNIT	<u>VOC</u> PTE (lbs/yr)	Contaminan	tandard units)	St	% Thrupi andard Units %	ut Capt	ure PTE eterr 04	Control 90 How nined	PRO BR (Ibs/ (Ibs/ PRO BR	PCESS P /hr) /hr) Ac /hr) PCESS P /hr)	ERP H Determ 04 tual (lbs/ ERP H
CAS No. NY998 - 00 - 0 (Ibs/hr) 7-7 E-1 EMISSION UNIT CAS No. 	V/0C PTE (lbs/yr) 6.75 ₽ 1- PTE	Contaminan	nt Name tandard units) nt Name	St	% Thrupi andard Units % Thrupi	ut Capt		Control 90 How nined 7 Control	PRO BR (lbs/ 7,7) (lbs/ PRO BR (lbs/	PCESS P /hr) Ac /hr) PCESS P hr) Ac	ERP H Determ 04 tual (lbs/) ERP H Determ
CAS No. <u>NY998 - 00 - 0</u> (Ibs/hr) 7.7 E-/ EMISSION UNIT	\/0C PTE (lbs/yr) 6.75 € -	Contaminan	tandard units)	St	% Thrupi andard Units % Thrupi andard	ut Capt		Control 90 How nined 7 Control How	PRO BR (Ibs/ (Ibs/ PRO BR	PCESS P /hr) Ac /hr) PCESS P hr) Ac	ERP H Determ 04 tual (lbs/ ERP H Determ
CAS No. NY998 - 00 - 0 (Ibs/hr) 7-7 E -/ EMISSION UNIT CAS No. (Ibs/hr)	<u>)/0</u> PTE (ibs/yr) 6.75 ₽ -	Contaminan	nt Name tandard units) nt Name	St	% Thrupi andard Units % Thrupi andard	ut Capt		Control 90 How nined 7 Control How	PRO BR (Ibs/ 7,7) (Ibs/ PRO BR (Ibs/	PCESS P /hr) Ac /hr) PCESS P /hr) Ac /hr)	ERP H Determ 04 tual (lbs/) ERP H Determ
CAS No. NY998 - 00 - 0 (Ibs/hr) 7-7 E-1 EMISSION UNIT CAS No. 	V/0C PTE (lbs/yr) 6.75 ₽ 1- PTE	Contaminan	nt Name tandard units) nt Name	St	% Thrupu andard Units % Thrupu andard Units	ut % Capt D ut % Capt	PTE eterr 04	Control 90 How nined % Control How nined	PRO BR (lbs/ 7,7,7) (lbs/ PRO BR (lbs/ (lbs/ PRO	PCESS P /hr) /hr) PCESS P /hr) Ac /hr) Ac /hr) DCESS	ERP H Determ 04 tual (lbs/ ERP H Determ tual (lbs/
CAS No. NY998 - 00 - 0 (Ibs/hr) 7-7 E -/ EMISSION UNIT CAS No. (Ibs/hr)	<u>)/0</u> PTE (ibs/yr) 6.75 ₽ -	Contaminan	tandard units)	St	% Thrupu andard Units andard Units	ut % Capt D ut % Capt D U D	PTE eterr 04	Control 90 How nined 6 Control How nined %	PRO BR (lbs/ 7,7, (lbs/ PRO BR (lbs/ PRO BR	PCESS P /hr) /hr) PCESS P /hr) Ac /hr) CESS P /hr) DCESS	ERP H Determ 04 tual (lbs/ ERP H Determ tual (lbs/
CAS No. NY998 - 00 - 0 (Ibs/hr) 7.7 E -/ EMISSION UNIT CAS No. (Ibs/hr) EMISSION UNIT	<u>)/0</u> PTE (ibs/yr) 6.75 ₽ -	Contaminan	tandard units)	St	% Thrupu andard Units % Thrupu andard Units	ut % Capt D ut % Capt D U D	PTE eterr 04	Control 90 How nined % Control How nined	PRO BR (lbs/ 7,7,7) (lbs/ PRO BR (lbs/ (lbs/ PRO	PCESS P /hr) /hr) PCESS P /hr) Ac /hr) CESS P /hr) DCESS	ERP H Determ 04 tual (lbs/ ERP H Determ tual (lbs/
CAS No. NY998 - 00 - 0 (Ibs/hr) 7.7 E -/ EMISSION UNIT CAS No. (Ibs/hr) EMISSION UNIT	1000 PTE (ibs/yr) 6.75 € 1 - PTE (ibs/yr) -	Contaminan	tandard units)	St	% Thrupu andard Units andard Units	ut % Capt D ut % Capt D U D	PTE eterr 04	Control 90 How nined 6 Control How nined %	PRO BR (lbs/ 7,7, (lbs/ PRO BR (lbs/ PRO BR	PCESS P /hr) Ac /hr) PCESS P /hr) DCESS P /hr) DCESS P /hr)	ERP H Determ 04 tual (lbs/ ERP H Determ tual (lbs/
CAS No. NY998 - 00 - 0 (Ibs/hr) 7-7 E -/ EMISSION UNIT CAS No. (Ibs/hr) EMISSION UNIT CAS No.	<u>)/0</u> PTE (ibs/yr) 6.75 ₽ -	Contaminan	tandard units)	St	% Thrupu andard Units andard Units	ut % Capt I D ut % Capt I D U U U U U U U U U U U U U U U U U U		Control 90 How nined 6 Control How nined %	PRO BR (lbs/ 7,7, (lbs/ PRO BR (lbs/ PRO BR	PCESS P /hr) Ac /hr) PCESS P /hr) DCESS P /hr) DCESS P /hr)	ERP H Determ 04 tual (lbs/ ERP H Determ tual (lbs/
CAS No. NY998 - 00 - 0 (Ibs/hr) 7-7 E -/ EMISSION UNIT CAS No. (Ibs/hr) EMISSION UNIT CAS No.	1000 PTE (ibs/yr) 6.75 € 1 - PTE (ibs/yr) - -	Contaminan	tandard units)	St	% Thrupu andard Units andard Units % Thrupu	ut Capt		Control 90 How nined % Control How nined % Control	PRO BR (lbs/ 7,7, (lbs/ PRO BR (lbs/ PRO BR	PCESS P /hr) Ac /hr) PCESS P /hr) Ac /hr) CESS P /hr) Ac Ac Ac Ac	ERP H Determ 04 tual (lbs/ ERP H Determ tual (lbs/



	[DEC	DI		
-			-		

-

EMISSION	UNIT			Emiss	sion L	- Init Emi	ssions	Summary			۰Co	ontinuati	on Sheet
CASN	•						Contami	nant Name					
00127 -1			tet	rachle		>							
				PTE En				1		Acti	ual		
ERP (lbs	/yr)		(lbs/hr)	·		(lbs/yr)		(11	os/hr)			(lbs	/yr)
18 E+	5		2 E-)	2	5.43 E		-					-
CAS N								nant Name					
00079 -	01 - 6		trick	broet	hene	,				· · · · ·			,
				PTE En						Actu	Jal		
ERP (lbs	/yr)		(lbs/hr)			(lbs/yr)		(It	os/hr)			(lbs/	/yr)
1,4 E+4		2,8	E-2			2.45 E	+2	-	—				
CAS N	о.							nant Name					
00156 -5	59 - 2	Cî	5-1,2-	Dich6	neth	iene							
ERP (lbs				PTE Em						Actu	Jal		
ERF (105	/yi)		(lbs/hr)			(lbs/yr)		(It	os/hr)			(lbs,	'yr)
		6.3	E-1		5	,5 E+3			-	1			
CAS N	0.						Contami	nant Name					
0007/ -3	5-6		111-	trich	lon e	those							
ERP (lbs	/vr)			PTE En	nission	S				Actu	Jal		
	· · · ·		(lbs/hr)			(lbs/yr)		(11	os/hr)			(lbs	'yr)
									~ ~~~				-
					Co	mplian	ce Plar)			• Co	ntinuati	on Sheel
For any emis	sion units	which ar	e <u>not in c</u>	omplian	<u>ce</u> at th	e time of p	permit ap	plication, the	applica	nt shall o	comp	lete the	following
Consent Ord								nitted every 6				1	1
Emission		Emission						e Federal Requ					
Unit	Process	Source	Title	Туре	Part	Sub Part	1	Sub Division		Sub Pa	arag.	Clause	Sub Cla
-					t —				Ť	1			
	1	Bamad'			I	L te Milestor	L	l	I				Date
		Remedi	ai Measi	are / Intel	media					R/I		Sc	heduled
							···· · _· · ·						
			_				<u> </u>			<u> </u>			
								<u> </u>					
							<u></u>					İ	
								······································					



	D	EC ID	
1-1	TTT	-	

-

1

EMISSION				Fmiss	ion U	Init Emi	ssions	Summary			- C	ontinuat	ion Shee
$0 \cdot \square R $													
CAS No								nant Name					·
00156-6	5-5		trans			oro ethe	ne			······			
ERP (lbs/	vr)			PTE Em	ission	s	<u> </u>			Actu	al		<u>.</u>
	<i>.</i> ,		(lbs/hr)			(lbs/yr)		(1	bs/hr)			(Ibs	/yr)
		9,7	E-3			8,06 E+	7						
CAS No				â			Contami	nant Name					
00067 - 6	6 - 3		chloro t					-					
ERP (lbs/	vr)			PTE Em	ission	S	· · · · · · · · · · · · · · · · · · ·			Actu	al		
			(lbs/hr)			(lbs/yr)	_	()	os/hr)			(lbs	/yr)
6,6 E+1			8 <i>E-</i> 3			245							
CAS No			·····				Contami	nant Name			·		
NY 998 - a	0-0	ļ	<u> VOC</u>										
ERP (lbs/	yr)		/m	PTE Em	ission			<u> </u>		Actu	al		
			(lbs/hr)			(lbs/yr)		("	os/hr)			(lbs	/yr)
6,7 E+		/,	7E-1		6,	75 E.							
CAS No).	Contami						nant Name					
<u> </u>	-				11_					A =1		_	-
ERP (lbs/	yr)			PTE Em	issions					Actu		/1L -	h m)
			(lbs/hr)			(lbs/yr)		()"	os/hr)	<u>-</u>		(lbs	/yt)
								<u> </u>					
	······				Co	ompliance	e Plan)			• Co	ontinuati	on Shee
For any emiss	sion units	which ar	e <u>not in c</u>	ompliand	<u>ce</u> at th	e time of p	permit ap	plication, the	applica	nt shall c	omp	lete the	following
Consent Orde	r		Certifie	ed progre	ss rep	orts are to	be subm	nitted every 6	months	beginnir	ng_	/	
Emission		Emission				_	Applicabl	e Federal Requ	uirement				
Unit	Process	Source	Title	Туре	Part	Sub Part	Section	Sub Division	Parag.	Sub Pa	rag.	Clause	Sub Cla
-											_		
		Remedi	al Measu	ure / Inter	media	te Milestor	nes	•		R/I			Date heduled
				 									meduled
												1	
					<u></u>							┨────	
			······							 		<u> </u>	



		Request for Emission Re	duction Credit	S	• Co	ntinuation Shee
EMISSION UNIT	-					
		Emission Reduction	Description			
·····		At /	1			
			1			
	- 	Contaminant Emission F	Reduction Data	1		
Baseline Period	//	to/	<u> </u>	Date	Reducti	on Method
CAS No.		Contaminant Name		Netting	ERC (lbs	offset
-	-	se la				
-	-	N/#				
_	<u> </u>	Facility to Use Future	Reduction			
Name				APPLIC	ATION ID	
Location Address	<u> </u>		-			
Location Address		· · · · · · · · · · · · · · · · · · ·			T	
• City / • Town / • Vill EMISSION UNIT		Use of Emission Redu Proposed Project D			Zip • Co	ntinuation Shee
			ction Credits			ntinuation Shee
			ction Credits			ntinuation Shee
EMISSION UNIT		Proposed Project D	ction Credits escription		• Co	
		Proposed Project D	ction Credits escription			
EMISSION UNIT		Proposed Project D	ction Credits escription		• Co	ntinuation Shee s/yr)
EMISSION UNIT		Proposed Project D	ction Credits escription	····	• Co PEP (Ib	s/yr)
EMISSION UNIT		Proposed Project D Proposed Project D Contaminant Emissions Contaminant Name N/A Statement of Com- prements under Section 114(a)(3)	ction Credits escription Increase Data Increase Data	icable requirem t Amendments	• Co PEP (Ib	s/yr)
EMISSION UNIT CAS No. - • All facilities under the including any complia schedule of a consent		Proposed Project D	ction Credits escription Increase Data Increase Data	icable requirem It Amendments Cillity	• Co PEP (Ibs nents and st of 1990, or	s/yr)
EMISSION UNIT CAS No. - • All facilities under the including any complia schedule of a consent Name		Proposed Project D Proposed Project D Contaminant Emissions Contaminant Name N/A Statement of Com- prements under Section 114(a)(3)	ction Credits escription Increase Data Increase Data	icable requirem It Amendments Cillity	• Co PEP (Ib	s/yr)
EMISSION UNIT CAS No. - • All facilities under the including any complia schedule of a consent Name Location Address	- ownership of this "own nce certification requir order. Sou	Proposed Project D Proposed Project D Contaminant Emissions Contaminant Name N/A Statement of Com- prements under Section 114(a)(3)	ction Credits escription Increase Data ppliance liance with all appliof the Clean Air Action on Credit - Factor	icable requirem It Amendments Cillity	• Co PEP (Ibs nents and st of 1990, or MIT ID	s/yr)
EMISSION UNIT CAS No. - - - - - - - - - - - - - - - - - - -		Proposed Project D Contaminant Emissions Contaminant Name Statement of Com- mership/firm" are operatingin comp rements under Section 114(a)(3) urce of Emission Reduction	ction Credits escription Increase Data Increase Data	icable requirem It Amendments Cillity	• Co PEP (Ibs nents and st of 1990, or	s/yr) ate regulations are meeting the
EMISSION UNIT CAS No. - • All facilities under the including any complia schedule of a consent Name Location Address		Proposed Project D Contaminant Emissions Contaminant Name Statement of Com pership/firm" are operatingin comp rements under Section 114(a)(3) urce of Emission Reduction Contaminant	ction Credits escription Increase Data Increase Data	icable requirem It Amendments Cillity	• Co PEP (lbs nents and st of 1990, or MIT ID Zip ERC (lb	s/yr) ate regulations are meeting the
EMISSION UNIT CAS No. - - - - - - - - - - - - - - - - - - -		Proposed Project D Contaminant Emissions Contaminant Name Statement of Com- mership/firm" are operatingin comp rements under Section 114(a)(3) urce of Emission Reduction	ction Credits escription Increase Data Increase Data	icable requirem t Amendments cility PER	• Co PEP (lbs nents and st of 1990, or MIT ID Zip ERC (lb	s/yr) ate regulations are meeting the //

Supporting Documentation			
 P.E. Certification (form attached) 			
 List of Exempt Activities (form attached) 			
Plot Plan			
 Methods Used to Determine Compliance (form attached) 			
Calculations	7		
() Air Quality Model (<u>818102</u>) Air Guide 1/ Scree	n 3		
Confidentiality Justification			
Ambient Air Monitoring Plan (/)			
Stack Test Protocols/Reports (//)			
Continuous Emissions Monitoring Plans/QA/QC (///	.)		
MACT Demonstration (//)			
Operational Flexibility: Description of Alternative Operating Scenarios a	and Protocols		
Title IV: Application/Registration			
ERC Quantification (form attached)			
 Use of ERC(s) (form attached) 			
Baseline Period Demonstration			
Analysis of Contemporaneous Emission Increase/Decrease			
LAER Demonstration (/)			
BACT Demonstration (/)	(,	,
Other Document(s):	<u>(</u>	/	/
	(1	1
	(
	(/	
	(/
	(/	
	l	,	
	(1 	1
	((
	((//
		/ / /	/ / _/

08/09/02 10:24:49 *** SCREEN3 MODEL RUN *** *** VERSION DATED 96043 *** NYSDEC - Heatset - 30 ft SIMPLE TERRAIN INPUTS: POINT = POINT EMISSION RATE (G/S) = 1.00000 STACK HEIGHT (M) SOURCE TYPE STACK HEIGHT (M) = STK INSIDE DIAM (M) = 9.1440 .1020 4″ STK INSIDE DIAM(M/S)11.5514STK EXIT VELOCITY(M/S)11.5514STK GAS EXIT TEMP(K)300.0000AMBIENT AIR TEMP(K)293.0000RECEPTOR HEIGHT(M).0000 300.0000 = URBAN URBAN/RURAL OPTION BUILDING HEIGHT (M) = MIN HORIZ BLDG DIM (M) = 6.1000 83.8200 MAX HORIZ BLDG DIM (M) = 106.6800 THE REGULATORY (DEFAULT) MIXING HEIGHT OPTION WAS SELECTED. THE REGULATORY (DEFAULT) ANEMOMETER HEIGHT OF 10.0 METERS WAS ENTERED. STACK EXIT VELOCITY WAS CALCULATED FROM VOLUME FLOW RATE = 200.00000(ACFM) .007 M**4/S**3; MOM. FLUX = .339 M**4/S**2. BUOY. FLUX = *** FULL METEOROLOGY *** ****** *** SCREEN AUTOMATED DISTANCES *** ******* *** TERRAIN HEIGHT OF 1. M ABOVE STACK BASE USED FOR FOLLOWING DISTANCES *** DIST CONC U10M USTK MIX HT PLUME SIGMA SIGMA Y (M) Z (M) DWASH _____ ____ NΑ SS
SS SS SS SS SS SS SS SS SS SS SS SS

1.0 10000.0 9.33 194.45 91.77 SS 1.0 10000.0 9.33 200.24 93.96 SS 1.0 10000.0 9.33 205.93 96.12 SS 1.0 10000.0 9.33 211.54 98.23 SS 1.0 10000.0 9.33 217.05 100.30 SS 1.010000.09.33222.49102.341.010000.09.33248.52112.001.010000.09.33272.88120.95 55 SS SS MAXIMUM 1-HR CONCENTRATION AT OR BEYOND 1. M: 3082. 1.0 1.0 320.0 8.33 6.78 6.20 30. .3 SS DWASH= MEANS NO CALC MADE (CONC = 0.0)DWASH=NO MEANS NO BUILDING DOWNWASH USED DWASH=HS MEANS HUBER-SNYDER DOWNWASH USED DWASH=SS MEANS SCHULMAN-SCIRE DOWNWASH USED DWASH=NA MEANS DOWNWASH NOT APPLICABLE, X<3*LB * SUMMARY OF TERRAIN HEIGHTS ENTERED FOR * + SIMPLE ELEVATED TERRAIN PROCEDURE * ****
 TERRAIN
 DISTANCE RANGE (M)

 HT (M)
 MINIMUM

 ----- -----

 1
 4000
 1. 1. 4000. ***** *** REGULATORY (Default) *** PERFORMING CAVITY CALCULATIONS WITH ORIGINAL SCREEN CAVITY MODEL (BRODE, 1988) ****** *** CAVITY CALCULATION - 1 ***
CONC (UG/M^{**3}) = .0000
CRIT WS @10M (M/S) = 99.99
CRIT WS @ HS (M/S) = 99.99
DILUTION WS (M/S) = 99.99
CAVITY HT (M) = 6.10
CAVITY LENGTH (M) = 34.75
ALONGWIND DIM (M) = 83.82*** CAVITY CALCULATION - 2 ***
CONC (UG/M^{**3}) = .0000
CRIT WS @10M (M/S) = 99.99
DILUTION WS (M/S) = 99.99
DILUTION WS (M/S) = 99.99
DILUTION WS (M/S) = 99.99
DILUTION WS (M/S) = 09.99
DILUTION WS (M/S) = 00.000
CAVITY LENGTH (M) = 0.000
CAVITY LENGTH (M) = 0.0000
CAVITY LENGTH (M) = 0.00000
CAVITY LENGTH (M) = 0.000000
CAVITY LENGTH (M) = 0.00 CAVITY CONC NOT CALCULATED FOR CRIT WS > 20.0 M/S. CONC SET = 0.0 ***** END OF CAVITY CALCULATIONS ***** ***** *** SUMMARY OF SCREEN MODEL RESULTS *** CALCULATIONMAX CONCDIST TOTERRAINPROCEDURE(UG/M**3)MAX (M)HT (M) ______ -----_____ _____ SIMPLE TERRAIN 1. 3082. 30. ****** ** REMEMBER TO INCLUDE BACKGROUND CONCENTRATIONS **

SVE System Emissions and Impacts NYSDEC Heatset-200 scfm-30ft **NYSDEC Heatset**

			1	Control	Needed							
		мw	Conc	Eff	Conc	Ext	naust	Unit Rate (1-hr)	24-hr (1-hr*0.4)	Annual (1-hr*0.08)	NYSDEC	NYSDEC
LFG Compound	HAP	(lb/lb-mol)	(ppmv) ^a	b, c	(ppmv) ^a	lb/hr	lb/yr	Impact (ug/m3)	Impact (ug/m3)	Impact (ug/m3)	SGC (ug/m3)	AGC (ug/m3)
1,1,1 - Trichloroethane (methyl chloroform)	X	133.42	4.00	0.00	4.00	1.7e-2	1.5e+2	6.55	2.62	0.52	68000	1000
Chioroform	x	119.39	1.00	0.63	0.37	1.4e-3	1.2e+1	0.54	0.22	0.043	150	0.043
Perchloroethylene (tetrachloroethylene)	x	165.83	1700.00	0.997	5.95	3.1e-2	2.7e+2	12.11	4.84	0.97	1000	1
c - 1,2 - Dichloroethene (1,2 dichloroethylene)		96.94	102.50	0.00	102.50	3.1e-1	2.8e+3	121.95	48.78	9.76		1900
t - 1,2 - Dichloroethene (1,2 dichloroethylene)		96.94	1.50	0.00	1.50	4.6e-3	4.0e+1	1.78	0.71	0.14		1900
Trichloroethylene (trichloroethene)	x	131.38	195.00	0.983	3.32	1.4e-2	1.2e+2	5.35	2.14	0.428	54000	0.45

400	scfm						
		Exh	aust				
LFG C	Compound	lb/hr	lb/yr				
1,1,1 - Trichloroethane (methyl chloroform)							
Cł	nloroform	2.8e-3	2.4e+1				
achloro	ethylene)	6.2e-2	5.5e+2				
	LFG (ethyl ch Cł	LFG Compound	Exh LFG Compound Ib/hr ethyl chloroform) 3.4e-2 Chloroform 2.8e-3				

c - 1,2 - Dichloroethene (1,2 dichloroethylene) 6.3e-1 5.5e+3

t - 1,2 - Dichloroethene (1,2 dichloroethylene) 9.2e-3 8.1e+1 Trichloroethylene (trichloroethene)

2.8e-2 2.4e+2 6689.64 lbs/year

802901 Impact8-9-02 NYSDEC Heatset-200 scfm-30ft 8/9/02

3344.82 lbs/year

Inlet flow 200 scfm

3082 ug/m3, Unit Emission Rate Impact 30ft STACK

SVE System Emissions and Impacts NYSDEC Heatset-200 scfm-25ft NYSDEC Heatset

1

ſ

Inlet flow 200 scfm

1

4614 ug/m3, Unit Emission Rate Impact 25ft STACK

				Control	Needed Outlet							
		мw	Conc	Eff	Conc	Ex	haust	Unit Rate (1-hr)	24-hr (1-hr*0.4)	Annual (1-hr*0.08)	NYSDEC	NYSDEC
LFG Compound	HAP	(lb/lb-mol)	(ppmv) ^a	b, c	(ppmv) ^a	lb/hr	lb/yr	Impact (ug/m3)	Impact (ug/m3)	Impact (ug/m3)	SGC (ug/m3)	AGC (ug/m3)
1,1,1 - Trichloroethane (methyl chloroform)	x	133.42	4.00	0.00	4.00	1.7e-2	1.5e+2	9.81	3.92	0.78	68000	1000
Chloroform	x	119.39	1.00	0.76	0.24	9.1e-4	7.9e+0	0.53	0.21	0.042	150	0.043
Perchloroethylene (tetrachloroethylene)	x	165.83	1700.00	0.998	3.40	1.8e-2	1.6e+2	10.36	4.14	0.83	1000) 1
c - 1,2 - Dichloroethene (1,2 dichloroethylene)		96.94	102.50	0.00	102.50	3.1e-1	2.8e+3	182.56	73.02	14.60		1900
t - 1,2 - Dichloroethene (1,2 dichloroethylene)		96.94	1.50	0.00	1.50	4.6e-3	4.0e+1	2.67	1.07	0.21		1900
Trichloroethylene (trichloroethene)	x	131.38	195.00	0.989	2.15	8.9e-3	7.8e+1	5.18	2.07	0.414	54000	0.45

3180.90 lbs/year

			1
Potential 400 scfm			
Flow	Ext	naust	
LFG Compound	lb/hr	lb/yr	
1,1,1 - Trichloroethane (methyl chloroform)	3.4e-2	3.0e+2	
Chloroform	1.8e-3	1.6e+1	
Perchloroethylene (tetrachloroethylene)	3.6e-2	3.1e+2	
c - 1,2 - Dichloroethene (1,2 dichloroethylene)	6.3e-1	5.5e+3	
t - 1,2 - Dichloroethene (1,2 dichloroethylene)	9.2e-3	8.1e+1	
Trichloroethylene (trichloroethene)	1.8e-2	1.6e+2	
		6361.80	lbs/year

Ched. By Proj. No. \underline{PQP} 									<u>)</u>	Sub	oject			He	aff	ef.		<u> </u>					She	et N	lo	00		of	
$\frac{lege 7}{lege 7}, loccy Excision Innary: lcE: ERI (#/hi) = 6.2E-2 = 20.66 = 20.7 Hi 0.003 cis-12-Dx4brethere : gourne 90% removal et?ciency ERI = 6.3E-7 = 6.3 Hir 1/11 - Tricklor ethere = 3.9E-2 = 0.34 Hir aro trans - 12-Dicklor ethere = 22E-3 = 9.2E-2 Hir .$	Chko	d. B	y		Dat	e	<u> </u>																Proj	. No)	84	270/	.25 in	. X .2
$f_{CF} := ER \left(\frac{\pi}{4} \right) := \frac{6.2E^{-2}}{0.033} = 20.76 + 20.7 + 40 = 0.003$ $C(s - 1)^{2} = 0x(4s) etheref := general = 90\% removal = Afficiency = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.3 + 1/4 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 = 0.10 =$					•		 }e	ats	eł	h	tir	ler,	nî +		ks	:				•						+			
$f_{CE} := ERI(2/4x) := 6.2E^{-2} - 20.66 = 20.7 4x 0.003 C(s-1)^2 - Drubbro ethere : genume 90% remeval ethiciency ERI = 6.3E^{-1} = 6.3 4/4x 0.10 1.11 - Trickloro ethere = 3.9E^{-2} = 0.34 4/x 0.10 1.11 - Trickloro ethere = 2.9E^{-3} = 0.2E^{-2} 4/x 0.10 1.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.10 0.10 1.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.10 1.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.10 1.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-2} 4/x 0.11 - Trickloro ethere = 2.2E^{-3} = 0.2E^{-3} + 0.2E^{$											-									-									
$Cis - 12 - Dx4hoethere : grunne 90% removal et dicercy$ $Ext = \frac{62E7}{9.10} = 6.3 t/4$ $1.11 - trichloro ethere = 3.9E-2 - 0.34 t/4$ $4.10 - 0.10 - 0.34 t/4$ $4.10 - 0.34 t/4$ $4.10 - 0.34 t/4$ $4.10 - 0.34 t/4$ $4.10 - 0.34 t/4$				la	ge i		lo	æ	t	m	الكر	on	[]	um	nan	<u>ş :</u>													
$ERP = \frac{63E^{-1}}{9.0} = \frac{63}{14}$ $\frac{1}{10} = \frac{100}{1000} = \frac{3.9E^{-2}}{9.000} = \frac{0.34}{1000} = \frac{1000}{10000} = \frac{10000}{10000} = \frac{10000}{100000} = 1000000000000000000000000000000000000$		ſĊ	Ę	;			E.L	1	(#)	hi,) =								2	0,0	66	7	20	þ. ⁻	2	# hy			
$E_{R}P = \frac{63E^{-7}}{9.70} = 6.3 \#_{4}$ $\frac{1}{1.70} = 6.3 \#_{4}$ $\frac{1}{1.70} = 0.34 \#_{4}$			1		12-	D.	rhp	ne	flu	ent	a ;		ass	un	æ	90	*/0	re	ms	sa/	-	e H	0 _c	-en	cy				
$\frac{1}{1,1/1} - \frac{1}{10} + \frac{1}{1$							G	. 	•								 								-				
$\frac{4}{240}$ $\frac{4}$							F,		-	 		2./(1	-	6	\$	74	с		•	· · · · ·						;		
$\frac{4}{240}$ $\frac{4}$										 																			
+nns - 12 - nichloro et lone = 92E - 3 = 92E - 2 Hr.		1,	Ι,Ϊ	-	tá	46	n e	the	re	-				2	=		2.39	<u>/</u>	the										
													9		r	3-			<u> </u>				#						<u> </u>
$\frac{1}{1} = \frac{1}{1} = \frac{1}$		<i>tn</i>	us	<i>+ </i>	2-	lic	hlo	e e	l læ	ve	17		Ś	0,	10		4	,	<i>]</i> ∙∑	E	-~) 	6,	<u> </u>		+	······) : :	,	
Voc: i $2.7EF$ $2.7K$ 4 0.70 4 4 1 1 1 1 1 1 1 1 1 1									 																				
		V	00	ż			\$				2	0.1	0	- 2		72	2	#	hr										
				 			+			 		 														 , 			
																								ļ				·	
					<u> </u>	: 																			 				

.

APPENDIX F

PID INFORMATION SHEET

Life Sciences

Attn: Marie Dowd

-

518-783-839

Optoelectronics

Fluid Sciences

Photovac

Instruments

2020 PHOTOIONIZATION AIR MONITOR

Size	25.4 cm (10") long, 7.6 cm, (3") wide, 5 cm (2") high
Weight	0.8 kg (1.75 lbs.)
Detector	Instant on photoionization detector with standard 10.6eV UV lamp, optional 11.7 eV lamp available
Keypad	6 keys, 3 function keys and 3 menu keys
Status Display	2-line, 16-character dot-matrix, backlit, liquid crystal display for alphanumeric readouts and menu key display
Méter Display	4-digit for real-time concentration readout with backlight
Datalogger Memory	16 kilobytes or 1000 entries
Serial Output	RS – 232, 9600 baud, 8 data bits with no parity, for tabular and graphic printouts and con- nection to Windows® based PC
Audio Output	95 decibels @ 2048Hz, on Alarm
Inlet Connection	1/8" compression fitting
Operating Temperature Range	0°C to 40°C (32'F to 105°F)
Operating Humidity Range	0 to 100% relative humidity (non-condensing)
Operating Concentration Rang	0.5 ppm to 2000 ppm isobutylene equivalent
Res ponse Time	Less than 3 seconds, to 90%
Accuracy	± 10 % or ± 2 ppm, whichever is greater
Low Detection Limi	a 0.5 ppm isobutyiene
Intrinsic Safety	Class I, Division I, Groups A, B, C, & D Zone I locations, Eex ib m IICT4, Demko No. 95D 119 472

PerkinElmer Instrumente Heddywerten Otticz 710 Bridgeport Avenue Shelton, UT 06484-4794 USA Phone: 1800) 782-4860 Jewegerkinet.com PerkinElmer Europa åjælen Alić 7A, P.O. Box 79 DK-3480 Alierød, Denmark (45) 48 100 400

/рнотоvа



Perkinklimer is a trademark of Perkinklimer, Inc. Microsoft Windows is a registered trademark of The Microsoft Corporation.



 $\langle n \rangle$

 \mathbf{v}

m

 \mathbf{O}

ורי

I C A

TIONS

APPENDIX G

SOIL SAMPLE COLLECTION PROCEDURE

The following steps may be used as a guideline for the collection of soil samples inside the site building at the National Heatset Printing Site to compare subsurface conditions to closure standards.

- Direct push drilling methods will be used to install the soil borings. The drilling equipment must be capable of coring through the concrete floor slab thickness of approximately eight inches. The soil borings will be approximately 1 to 2 inches in diameter.
- The sample collection tools must be decontaminated prior to initial use at the site. With the exception of the use of acetate liners, which are consumable materials, the sample collection tools must be decontaminated prior to reuse at subsequent soil boring locations. Decontamination of sampling equipment shall include, but not be limited to: washing and scrubbing the tools with a brush to remove adhered soil, rinsing the equipment with a water/cleaning agent mixture, and a subsequent rinse with distilled water. Liquids generated during decontamination shall be stored on-site on a drum pending disposal in accordance with State, Local and Federal regulations.
- As the borings are installed, soil samples will be collected in two-foot intervals. The soil samples shall be split vertically in half; one half shall be utilized for field screening and the other shall be stored in a jar pending laboratory analysis for VOCs.
- Each soil boring shall be advanced until the water table has been reached. Soils will be field screened for VOCs with a photo-ionization detection (PID) meter equipped with an 11.7 eV lamp. Soil descriptions with respect to geologic characteristics, lithology and field screening results will be recorded on an appropriate drill log.
- A soil sample with the highest PID reading from each boring location will be sent for laboratory analysis. Additional samples may be submitted for laboratory analysis at the discretion of the NYSDEC representative.
- Once each soil boring has been completed, it shall be filled with native soils and the concrete surface will be restored to existing grade.