# OPERATION, MAINTENANCE, AND MONITORING MANUAL

Sunnyside Yard — Operable Unit 3 39-29 Honeywell Street Queens, New York

Prepared for:

NATIONAL RAILROAD PASSENGER CORPORATION

400 West 31st Street, 6th Floor New York, New York 10001

# Remedial Engineering, P.C.

**Environmental Engineers** 

and ROUX ASSOCIATES, INC.

209 Shafter Street, Islandia, New York 11749 ♦ 631-232-2600

# TABLE OF CONTENTS

1.0 INTRODUCTION	1
2.0 OWNERS AND RESPONSIBILITIES	2
3.0 SITE DESCRIPTION AND SYSTEM DESIGN BACKGROUND	3
3.1 Site Description	
3.2 DPVE System Design Background	3
4.0 SYSTEM PROCESS DESCRIPTION	5
4.1 DPVE Wells	
4.2 Piping Network	
4.2.1 Aboveground Conveyance Piping and Network	
4.2.2 Underground Conveyance Piping and Network	
4.3 DPVE Treatment System	
4.3.1 Treatment Trailer	
4.3.1.1 Control Room.	
4.3.1.1.1 Electrical Equipment and Controls	
4.3.1.2 Process Room.	
4.3.2 DPVE Well Manifold	
4.3.3 Liquid Ring Pumps	
4.3.3.1 220-Gallon Knock-Out Tank	
4.3.3.2 Knock-Out Tank Transfer Pumps TP-200 and TP-202	12
4.3.4 Oil/Water Separator	
4.3.5 Treated Groundwater Transfer Pump TP-301	13
4.3.6 Bag Filtration	13
4.3.7 Organoclay Units	14
4.3.8 Liquid Phase Carbon Units	14
4.3.9 Treated Water Discharge	15
4.3.10 Product Recovery	15
4.3.11 Off-Gas Treatment	16
4.3.12 Utilities	16
5.0 OPERATIONAL PROCEDURES	17
5.1 DPVE Treatment System Start-Up Procedure	
5.2 DPVE Treatment System Alarms	
5.3 DPVE Treatment System Shutdown Procedure	
•	
6.0 MAINTENANCE AND INSPECTIONS	
6.1 Routine Maintenance and Inspections	
6.2 Non-Routine Equipment Maintenance	
6.3 Routine Maintenance Reports.	
6.4 Non-Routine Maintenance Reports	24
7.0 MONITORING	
7.1 Sampling Event Protocol	25
7.2 General Equipment Monitoring	26
8.0 RECORD KEEPING	27
8.1 Field Book	

#### TABLE OF CONTENTS

#### (Continued)

8.2 System Monitoring	27
8.2.1 DPVE Aboveground Piping Checklists	
9.0 HEALTH AND SAFETY	28
9.1 Emergency Response Overview	28
10.0 FIELD TEAM REVIEW / TRAINING SECTION	30

#### **TABLES**

- 1. DPVE System Inspection Checklist
- 2. DPVE System Non-routine Maintenance Form
- 3. DPVE Well Gauging Data Sheet
- 4. DPVE Treatment System Operating Log

#### **FIGURE**

1. Site Plan

#### **APPENDICES**

- A. Process and Instrumentation Diagram
- B. Treatment Trailer Layout
- C. Control Panel Parts Layout
- D. Panel 1 Electrical Schematic
- E. Air Compressor Information
- F. PLC Input/Output/Analog Wiring Drawings
- G. LRPs 101/102 Information
- H. Air Flow Meter/Transmitter Information
- I. Transfer Pumps TP-200/202 Information
- J. OWS Information
- K. Transfer Pump TP-301 Information
- L. Bag Filter Information
- M. Liquid Phase Organoclay Information
- N. Liquid Phase Carbon Information
- O. Liquid Flow Meter/Transmitter Information
- P. Transfer Pump TP-300 Information
- Q. Vapor Phase Carbon Units Information
- R. Electrical Power Wiring Drawings
- S. NYCDEP Discharge Permit Limits

# TABLE OF CONTENTS

(Continued)

# **ATTACHMENT**

Miscellaneous Treatment System Components (Provided on CD in Bound Copy)

# **DRAWINGS**

- 1. DPVE System Layout
- 2. DPVE Well Details
- 3. DPVE System Details

#### 1.0 INTRODUCTION

On behalf of the National Railroad Passenger Corporation (Amtrak) and the New Jersey Transit Corporation (NJTC), Remedial Engineering, P.C. (Remedial Engineering) and Roux Associates, Inc. (Roux Associates) collectively known as Roux Associates, have prepared this Operation, Maintenance and Monitoring (OM&M) manual for the Dual Phase Vacuum Extraction (DPVE) system to address the mobile separate-phase petroleum hydrocarbon (SPH) plume within Operable Unit 3 (OU-3) of the Sunnyside Yard (Yard) located at 39-29 Honeywell Street, Queens, New York (Figure 1). The Sunnyside Yard is listed as a Class II Site in the New York State Department of Environmental Conservation's (NYSDEC) Registry of Inactive Hazardous Waste Disposal Sites. As a result of the listing for the entire Yard, Amtrak, NJTC, and the NYSDEC entered into an Order on Consent (OOC) Index #W2-0081-87-06, effective October 1989.

This OM&M manual is a reference for operating and maintaining the DPVE system in conformance with its design, applicable regulations, and permit requirements. Detailed operation and maintenance manuals prepared by the equipment manufacturers for each major component of the System are also included within this manual. This OM&M manual also presents the OM&M activities, which will occur from the time of System start-up and throughout the operation of the system. Performance monitoring (i.e., product well gauging) will also be performed as part of the OM&M activities. Should these activities be changed, modifications to this OM&M manual shall be documented through the preparation of manual revisions or addenda. Amtrak assumes the overall responsibility for the operation and maintenance of the DPVE system. Equipment specific maintenance, or those activities which would not be considered routine, will be contracted out by Amtrak, as required.

#### 2.0 OWNERS AND RESPONSIBILITIES

The designated owner of this OM&M manual described herein is Amtrak. Roux Associates, Inc. is the designated operator. Roux Associates will be responsible for the operation and maintenance of the DPVE treatment system and DPVE wells described within this OM&M manual. The key personnel involved in the operations and maintenance at OU-3, located in Queens, New York are as follows:

• Richard Mohlenhoff – Owner Representative

• Glenn Netuschil, P.E. – Lead Design Engineer

• Charles J. McGuckin, P.E. – Engineer of Record

Rob Kovacs
 Project Manager / Senior Hydrogeologist

John LoMeli – Senior Field Technician

Emergency contact numbers are provided in Section 9.0.

#### 3.0 SITE DESCRIPTION AND SYSTEM DESIGN BACKGROUND

The following sections provide the Site description and describe the DPVE system to be operated within OU-3 at the Site.

#### 3.1 Site Description

The Yard is located in an urban area in northwestern Queens County (Figure 1). The East River is located approximately one mile to the west while Newtown Creek, which defines the border between Queens and Kings Counties, is located less than 0.5 mile south of the western portion of the Yard. The Yard consists of a railroad maintenance and storage facility that currently encompasses approximately 133 acres. The Yard functions as a maintenance facility for electric locomotives and railroad cars for Amtrak and a train layover storage yard for NJTC. The land use surrounding the Yard is a combination of commercial, light industrial, and residential areas. The Metropolitan Transportation Agency (MTA) currently owns a portion of the original Yard along the northern boundary and maintains rights of way through the Yard.

Based on historic investigations completed at the Yard, the Yard has been divided into six Operable Units (OU-1 through OU-6):

- OU-1: Soil above the water table within the footprint of the High Speed Trainset Facility Service and Inspection (HSTF S&I) Building. A ROD was issued for OU-1 in August 1997, and the remedial work was completed in April 1998.
- OU-2: Soil above the water table within the footprint of the HSTF S&I Building ancillary structures. A No Further Action ROD was issued for OU-2 in November 1997.
- OU-3: Soil and SPH above the water table within approximately eight acres in the north central portion of the Yard (includes property owned by the LIRR).
- OU-4: Soil above the water table (unsaturated zone) in the remainder of the Yard.
- OU-5: Sewer system (water and sediment) beneath the Yard.
- OU-6: Saturated soil and the groundwater beneath the Yard.

# 3.2 DPVE System Design Background

The use of a DPVE system was proposed as an alternative remedial technology in lieu of open excavation below the water table in OU-3 to address the mobile SPH plume in a letter work plan dated August 6, 2009 and approved by the NYSDEC on September 29, 2009. The letter work

plan outlined a DPVE pilot study to be completed to evaluate the effectiveness of this alternative technology. This DPVE pilot study was completed in July and August 2010 and the results were submitted to the NYSDEC in the DPVE Pilot Study and Conceptual Design Work Plan Report (Roux Associates, 2011). The Revised Remedial Design/Remedial Action Work Plan for OU-3, Sunnyside Yard, Queens, New York (RD/RA Work Plan) was submitted to the NYSDEC on July 26, 2011 for the use of DPVE for the removal of SPH from OU-3. An addendum to the RD/RA Work Plan was submitted to the NYSDEC on March 15, 2012. The NYSDEC approved the use a DPVE treatment system on July 5, 2012.

The DPVE treatment system has been installed in a fenced area of OU-3. The DPVE treatment system trailer, existing product storage tank, electrical transformer and concrete pad, and DPVE wells and aboveground piping are located within the fenced area. Outside of the fenced area to the north are two tracks, the North Runner track, and the new service track (located south of the North Runner). Additional DPVE wells, DPVE pre-cast concrete well vaults, and underground piping are located outside the fenced area of the two tracks. The DPVE treatment system location is shown on Drawing No. 1.

#### 4.0 SYSTEM PROCESS DESCRIPTION

This section provides a description of the major components of the DPVE treatment system installed at OU-3. The description includes the primary function of individual components of the systems and their relation to the system as a whole.

#### 4.1 DPVE Wells

The DPVE system consists of 41 DPVE wells (additional wells may be added as necessary during operation of the system) that will be operated in two areas of OU-3 (Area A and Area B). Area A consists of 19 DPVE wells (DPVE-1A to DPVE-19A) that are located generally in the northern area of OU-3 surrounding the two tracks. Area B consists of 22 DPVE wells (DPVE-17B to DPVE-37B and MW-93) that are located generally in the southern area of OU-3 and within a fenced in area. Within each Area, the DPVE wells have been broken down into zones with each zone consisting of three to five DPVE wells. The DPVE wells and zones are summarized below:

DPVE Well Schedule			
Zone	DPVE Wells		
A1	DP-1A TO DP-4A, AND DP-10A		
A2	DP-5A TO DP-9A		
A3	DP-11A TO DP-14A, AND DP-19A		
A4	DP-15A TO DP-18A		
A5	CONTINGENCY		
A6	CONTINGENCY		
A7	CONTINGENCY		
B1	DP-17B TO DP-21B		
B2	DP-22B TO DP-24B, AND DP-27B		
В3	DP-25B, DP-28B TO DP-30B, AND MW-93		
B4	DP-26B, DP-31B TO DP-34B		
В5	DP-35B TO DP-37B		
В6	CONTINGENCY		
В7	CONTINGENCY		

The DPVE wells are constructed of 4-inch diameter Schedule 40 polyvinyl chloride (PVC) with 1-inch diameter Schedule 80 PVC drop tubes and are screened from 2 to 10 feet below land surface (bls). The drop tube extends to approximately 6 inches off the bottom of the DPVE well. A union connection is provided on the drop tube at the top of the DPVE well to allow for the adjustment of the drop tube depth. A vacuum gauge (0 to 30 inches of mercury [in. of Hg]) is provided at the DPVE well head. The DPVE wells have been designed for flow rates ranging from 20 to 40 cubic feet per minute (cfm) at 18 to 20 in. of Hg. The DPVE well and piping layout are shown on Drawing No. 1. The well construction details for each DPVE well are shown on Drawing No. 2.

# **4.2 Piping Network**

The piping network constructed within OU-3 allows for the conveyance of product, groundwater, and vapor for treatment. The DPVE wells within each zone are manifolded together to a common header using 4-inch diameter aboveground and buried Schedule 80 PVC piping. The zones will be manually gauged and operated, as needed, to optimize SPH recovery.

#### **4.2.1** Aboveground Conveyance Piping and Network

Generally, the DPVE wells for Area B are linked together using aboveground piping. The 4-inch common header aboveground Schedule 80 PVC piping is installed on pipe supports 18 to 24 inches above the ground and spaced approximately 8 feet apart. The pipe supports consist of Kindorf struts anchored with concrete. A U-clamp is used to attach the pipe at the supports. Two-inch diameter Schedule 80 PVC pipe connects each DPVE well to the common header.

#### 4.2.2 Underground Conveyance Piping and Network

Generally, buried piping is used to connect the DPVE wells in Area A located outside of the fenced area. Two buried 4-inch diameter Schedule 80 PVC pipes are connected to two underground pre-cast concrete DPVE vaults at the locations shown on Drawing No. 1. The DPVE pre-cast concrete vaults are 3 feet by 4 feet and 2 feet deep and were manufactured by Atlantic Pre-Cast. Each DPVE vault has a single-door hatch manufactured by Bilco and rated for H-20 loading. The 4-inch diameter header pipe enters each DPVE vault where it is

manifolded into individual 2-inch diameter Schedule 80 PVC pipes. The 2-inch individual lines are equipped with 2-inch ball valves to control the flow to the DPVE wells. The pre-cast concrete DPVE vaults are used to control zones A1 and A2.

#### **4.3 DPVE Treatment System**

The product, groundwater and vapor extracted during product recovery operations from the DPVE wells is conveyed to the DPVE treatment system trailer located in the fenced area in OU-3. The treatment trailer includes a control room and a process room. The DPVE treatment system includes the following major treatment components/processes:

- 1. Treatment system control;
- 2. Liquid ring pumps (LRPs);
- 3. Oil/water separation;
- 4. Recovered groundwater treatment;
- 5. Product recovery; and
- 6. Off-gas treatment.

The process and instrumentation diagram (P&ID) is provided in Appendix A. The P&ID shows the DPVE treatment system instrumentation and controls and how the treatment system components are integrated together for operational control. Each of these treatment system components is further described below.

#### 4.3.1 Treatment Trailer

A 53-foot long by 8-foot wide by 9-foot high treatment trailer is used to house the controls/instrumentation, LRPs, DPVE zone manifold and actuated valves, transfer pumps, oil water separator (OWS), liquid phase organoclay and carbon units, treated water holding tank, interconnecting piping, and valves. Three personnel doors and a double-wide door provide access to the treatment trailer. Stairs with handrails are provided for each personnel door. There are no doors between the control room and process room. The double-wide doors are at the back of the trailer and will be used to access the organoclay and liquid carbon units for change outs, etc. The vapor phase carbon treatment units and the product storage tank are installed outside and adjacent to the trailer. The controls and electrical equipment are provided in a separate room. The main electrical disconnect is mounted on the trailer exterior in the

front of the trailer (adjacent to the control room). A schematic showing the treatment trailer layout is provided in Appendix B.

#### 4.3.1.1 Control Room

The control room has been designed to be non-explosion proof and houses the motor control panel (MCP), motor control center (MCC), and an Allen Bradley CompactLogix programmable logic controller (PLC) with a G310 Red Lion human machine interface (HMI) touchscreen. The control panel layout drawings are provided in Appendix C. The control room has an exhaust fan and heater. The thermostats for both the control and process room exhaust fans and heaters are located in the control room.

A single phase circuit breaker panel is provided to control power to the fans, heaters, interior and exterior lights, MCP panel lights, air compressor, ground fault circuit interrupter (GFCI) outlet, and the actuated valve manifold. The single phase electrical schematic is provided in Appendix D.

The control room also houses the 2-Hp Ingersoll Rand air compressor, Model No. P1.5IU-A9. The air compressor is used to control the pneumatic valves and the double-diaphragm product pump. A compressed air line has also been installed in the process room to assist with the replacement of the bag filters. Additional information for the air compressor is provided in Appendix E.

#### **4.3.1.1.1** Electrical Equipment and Controls

The MCP, PLC and the HMI touchscreen will be used to control operation of the DPVE treatment system. The MCP houses the following:

- PLC;
- HMI touchscreen control panel interface;
- ZIP port (panel interface connector);
- Main system disconnect switch;
- Running (green) and alarm (red) indicating lights;
- Alarm reset button;

- Emergency stop button (E-Stop)button; and
- HAND/OFF/AUTO (HOA) switches for the control room and process room exhaust fans.

The PLC receives inputs (discrete and analog) from the various switches and transmitters located throughout the DPVE system and responds in accordance with the program loaded for this specific application. The PLC discrete input/output and analog drawings are provided in Appendix F.

The HMI uses a liquid crystal display (LCD) for displaying text and graphics. The HMI has an eight-button keypad for the on-screen menus. The on-screen menus will display the DPVE system operating conditions and allow the operator to modify the DPVE system operating conditions using the touchscreen. The HMI touchscreen has the following menu pages:

- Main menu;
- DPE Valves 1-5 (AV-1 TO AV-5);
- DPE Valves 6-9 (AV-6 TO AV-9);
- DPE Valves 10-14 (AV-10 TO AV-14);
- KO Tank TP-200 TP-202;
- OWS/TP-300;
- TP-301/Bag Filters/Clay Vessels;
- Carbon Vessel/Treated Water;
- LRP-101/102;
- Current Runtimes and Flow Totals;
- ACC Runtimes and Flow Totals;
- Mode Select;
- Trend Select;
- System Setup; and
- Alarms.

A cellular modem (wireless router, Multitech Model No. MTCBA-EV2-EN2-N3) allows for communication with the PLC and HMI via the internet to allow for remote access (password

protected) to the DPVE system operating conditions. A dedicated laptop computer is also housed in the control room.

#### 4.3.1.2 Process Room

The process room of the treatment trailer has been designed according to the NFPA Class 1 Division 2 requirements and houses the DPVE well manifold header with pneumatic actuated valves, LRPs, OWS, transfer pumps, organoclay and liquid phase carbon units, and treated water holding tank. Two floor sumps are located in the process room (one sump is located next to the 220-gallon knock-tank and the other is located next to the liquid phase carbon units) and have a level switch to shut down the treatment system if liquid were to accumulate in the floor sumps. The process room has an exhaust fan and two explosion-proof heaters.

#### 4.3.2 DPVE Well Manifold

The 6-inch diameter steel piping manifold header consists of 14 pneumatic actuated valves (AV-1 to AV-14) to control vacuum and flow to the zones. Each line on the manifold header has a gate valve, clear PVC piping and vacuum transmitters (VT-1 to VT-14). Each actuated valve and number is associated with the same DPE valve and number on the HMI screen, for example, DPE-1 is associated with AV-1. The following table shows the DPVE well zone and corresponding actuated valve:

Actuated Valve Schedule			
Actuated Valve	DPVE Zone and Wells		
AV-1	B8 (CONTINGENCY)		
AV-2	B7 (CONTINGENCY)		
AV-3	B5 (DP-35B TO DP-37B)		
AV-4	B3 (DP-25B, DP-28B TO DP-30B, AND MW-93)		
AV-5	B4 (DP-26B, DP-31B TO DP-34B)		
AV-6	B2 (DP-22B TO DP-24B, AND DP-27B)		
AV-7	B1 (DP-17B TO DP-21B)		
AV-8	A3 (DP-11A TO DP-14A, AND DP-19A)		

Actuated Valve Schedule			
AV-9	A4 (DP-15A TO DP-18A)		
AV-10	A1 (DP-1A TO DP-4A, AND DP-10A)		
AV-11	A2 (DP-5A TO DP-9A)		
AV-12	A7 (CONTINGENCY)		
AV-13	A6 (CONTINGENCY)		
AV-14	A5 (CONTINGENCY)		

# 4.3.3 Liquid Ring Pumps

The LRPs will draw vapor, product and groundwater via the buried and abovegrade piping connected to the DPVE well zones to the manifold header located at the treatment trailer. Two 40-Hp Travaini Model No. TRO-600V liquid ring pumps (LRPs), LRP-101 and LRP-102, are used to apply the vacuum to the DPVE wells. Each LRP is capable of a vacuum of up to 28 in. of Hg and an air flow of 600 cfm. Each LRP has the following components:

- Oil seal fluid reservoir tank with sight level indicators, temperature gauges, back pressure gauge and drain valve;
- Discharge separator element;
- High efficiency air-cooled heat exchanger with cooling fan;
- Sealing fluid inline Y-strainer;
- High temperature switch;
- High and low oil level switches;
- Inlet check valve;
- Vacuum gauge;
- Pressure transducer;
- Inlet Filter assembly;
- Auto unloading valve with filter assembly; and
- Vacuum relief valve with filter assembly.

A 2-inch manual air dilution valve is provided on the manifold header. The manifold header is connected to a common 220-gallon knock-out tank via 6-inch diameter carbon steel pipe with a 6-inch Y-strainer. Additional information for the LRPs is provided in Appendix G.

The vapor flow rate from each LRP is measured utilizing a pitot tube in-line flow sensor, Dwyer Model No. DS-300 with a Dwyer Model No. ISDP flow transmitter and display. Additional information on the Dwyer flow meter and transmitter is provided in Appendix H.

#### 4.3.3.1 220-Gallon Knock-Out Tank

The common 220-gallon knock-out tank has level switches located in the side-mounted site glass, and a 6-inch Solberg Model No. CSL-375P-601 L-Style vacuum filter. The vacuum filter has a differential pressure transducer, DPT-1 (Dwyer Model No. ISPD). The knock-out tank also has a vacuum relief valve (Kunkel Model No. 215), and vacuum transducer (American Sensor Technologies, Inc. Model No. AST4400).

#### 4.3.3.2 Knock-Out Tank Transfer Pumps TP-200 and TP-202

The recovered total fluids (groundwater and product) are pumped from the knockout tank to the oil water separator (OWS) via two 1-Hp Moyno Model No. 35601 progressive cavity transfer pumps, TP-200 and TP-202, each capable of producing a design flow rate of 20 gallons per minute (gpm) at 15 feet of total dynamic head (TDH). Additional information for transfer pumps TP-200 and TP-202 is provided in Appendix I.

#### 4.3.4 Oil/Water Separator

The OWS is sized for 200 gpm and has a coalescing pack constructed of hydrocarbon resistant polypropylene to assist with separation. The separator design was oversized to improve performance and accommodate the potential for oil emulsification. The parallel-corrugated plate, coalescer oil water separator is manufactured by the Hydro Quip, Inc. (Model No. HQI AG-5CS-IP). The OWS will remove non-emulsified oil droplets larger than 20 microns in diameter with a specific gravity of 0.90 or less. The separator is constructed of 3/16" thick carbon steel and is 66 inches wide, 64 inches high and 10 feet long. The OWS includes the following:

• 2-inch inlet – female nominal pipe thread (FNPT) fitting;

- 2-inch groundwater outlet FNPT fitting;
- 1-inch oil outlet FNPT fitting;
- 1-inch vent nominal pipe thread (NPT) fittings and (2) 1-inch drain NPT fittings;
- product level switches;
- treated groundwater level switches;
- Parallel-corrugated plate coalescer designed to remove oil droplets greater than 20 microns;
- with a Reynolds Number of less than 500;
- sludge baffle;
- 75-gallon capacity integral oil storage compartment; and
- Gasketed removable vapor tight covers for access to chamber compartments.

Additional information for the OWS is provided in Appendix J.

# 4.3.5 Treated Groundwater Transfer Pump TP-301

After the OWS, the groundwater is pumped using TP-301, a 2-Hp Goulds Model No. 2ST1H7B centrifugal pump rated for 40 gpm and 65 feet of TDH to the skid-mounted bag filters arranged in parallel. Please note that this pump has been sized to pump through the organoclay and liquid phase carbon units to the treated effluent water storage tank. Additional information on TP-301 is provided in Appendix K.

#### **4.3.6 Bag Filtration**

The bag filtration system consists of two (2) downward flowing carbon steel units manufactured by Rosedale Products, Inc. (Model No. NLC08). Each filtration unit utilizes P12 filter bag sizes (10 microns), for the removal of suspended solids. The bag filters have a differential pressure transducer, DPT-2 (Inter Technology, Inc. Model No. 315Z). The maximum suggested flow rate by the manufacturer through each unit is 40 gpm and the suggested maximum pressure is 150 psi. Additional information on the bag filters is provided in Appendix L.

Each filter has the ability to be isolated, via 2-inch butterfly valves located upstream and downstream of the filters, to allow for the replacement of filter bags without shutting down the

process water flow throughout the treatment system. In addition, a compressed airline (from air compressor in control room) has been provided to assist with the bag filter removal and replacement. Following the bag filters, the process water passes through two 1,000-pound organoclay units and two 1,000-pound liquid phase carbon units (arranged in series) prior to discharge to a 750-gallon aboveground groundwater holding tank.

# 4.3.7 Organoclay Units

The two 1,000 pound stainless steel organoclay units are arranged in series. The process water is pumped through the bag filters by TP-301 to the top of the first organoclay unit and out the bottom to the top of the second organoclay unit and discharged out the bottom. The organoclay units consist of the following:

- 2-inch cam lock male fittings for influent and effluent connections;
- 2-inch diameter interconnecting hoses;
- 1-inch manual drain valves;
- ¼-inch hose barb sample ports (SP-22 and SP-23) with ball valves;
- pressure gauges (PI-16 and PI-17) with 0 to 60 pounds per square inch [psi] scale;
- pressure transmitters (PT-7 and PT-8); and
- air bleed valve.

The organoclay is an 8 x 30 mesh zeolite based clay material manufactured by Hydrosil, Part Number HS-200. Additional information on the organoclay and units is provided in Appendix M.

#### **4.3.8 Liquid Phase Carbon Units**

The two 1,000 pound stainless steel liquid phase carbon units are arranged in series. The process water is pumped through the organoclay units by TP-301 to the top of the first liquid phase carbon unit and out the bottom to the top of the second liquid phase carbon unit and discharged out the bottom to the 750-gallon aboveground groundwater holding tank. The liquid phase carbon units consist of the following:

• 2-inch cam lock male fittings for influent and effluent connections;

- 2-inch diameter interconnecting hoses;
- 1-inch manual drain valves;
- ¼-inch hose barb sample ports (SP-24 and SP-25) with ball valve;
- pressure gauges (PI-18 and PI-19) with 0 to 60 psi scale;
- pressure transmitters (PT-9 and PT-10); and
- air bleed valve.

The liquid phase carbon is granular reactivated carbon manufactured by Envirotrol, Product Number EI-30R. Additional information on the liquid phase carbon and units is provided in Appendix N.

# **4.3.9** Treated Water Discharge

The treated groundwater is gravity discharged from the 750-gallon aboveground groundwater holding tank, via a 2-inch diameter PVC pipe, to the below-grade 4-inch diameter PVC line that is connected to the sewer manhole (Amtrak Manhole MH-6) for discharge to the NYCDEP sewer.

The flow rate and total number of gallons of treated water is measured utilizing a 1-inch Blancett turbine flow meter, Model No. B111-110 outfitted with a Blancett Flow Monitor, Model No. B2800, to measure the flow rate and the total volume of treated water being pumped to the 750-gallon treated water holding tank. Additional information on the Blancett flow meter is provided in Appendix O.

#### 4.3.10 Product Recovery

The recovered product is pumped from the OWS to the existing 2,000-gallon product holding tank with secondary containment, located outside near the treatment trailer, via buried 2-inch double-walled PVC pipe using the pneumatic double-diaphragm pump, TP-300, Dayton Model No. 6PY44 rated for 35 gpm. Additional information on TP-300 is provided in Appendix P. The recovered product will ultimately be pumped out using a vacuum truck as necessary, and transported and properly disposed off-site. The product storage tank has a one position high high level float switch and alarm (LSHH-15).

The flow rate and total number of gallons of recovered product is measured utilizing a 1-inch Blancett turbine flow meter (Model No. B111-110) outfitted with a Blancett Flow Monitor (Model No. B2800), to measure the flow rate and the total volume of product being pumped from the OWS to the exterior aboveground 2,000-gallon product holding tank. Additional information on the Blancett flow meter is provided in Appendix O.

#### 4.3.11 Off-Gas Treatment

The extracted vapor is transferred by the LRPs to the vapor phase treatment system prior to discharge to the atmosphere. The vapor phase treatment system consists of two 1,000-pound vapor phase carbon (VPGAC) units (arranged in series) prior to discharge to the atmosphere. The VPGAC units are located outside the treatment trailer. The vapor phase carbon units consist of the following:

- 4-inch cam lock male fittings for influent and effluent connections;
- 6-inch diameter interconnecting hoses;
- ¼-inch hose barb sample ports (SP-16 and SP-17) with ball valves; and
- pressure gauges (PI-4 to PI-7) with 0 to 160 inches of water scale.

The vapor phase carbon is granular activated carbon manufactured by Envirotrol, Product Number EI-410. Additional information on the vapor phase carbon and units is provided in Appendix Q.

#### 4.3.12 Utilities

Amtrak has provided the electrical power for the treatment trailer and it is a 200 Amp, 3-phase, 60-Hertz, 3-wire, 480 Volt service. The power is transferred via underground conduit from the power pole and transformer to the treatment trailer. The electrical power wiring drawings are provided in Appendix R.

#### 5.0 OPERATIONAL PROCEDURES

The following sections describe operational procedures for the following activities:

- DPVE Treatment System Start-Up Procedure;
- DPVE Treatment System Alarms; and
- DPVE Treatment System Shutdown Procedure.

Each of these is described below.

# 5.1 DPVE Treatment System Start-Up Procedure

Prior to system start-up, the appropriate personnel (i.e., system operator) and the equipment manufacturer representative will walk-through the treatment system to verify equipment installation was performed in accordance with the Technical Specifications, approved Shop Drawings and P&ID. Several equipment checks will be performed by the OM&M personnel. These equipment checks will be performed after any extended shutdown period and after routine maintenance shutdown periods. The treatment equipment checks are listed below:

- Check individual DPVE well piping and vaults for tightness and evidence of leaks;
- Check that the valves at each DPVE well or vault are closed;
- Check the equipment in the treatment trailer for evidence of leaks or unsafe conditions;
- Verify that the valve positions are in the appropriate position for the treatment system piping and components;
- Confirm hook-up of electrical service;
- Confirm presence of air supply from the air compressor to all pneumatic actuators and double-diaphragm pump;
- If initial start-up, ensure sufficient quantity of potable water is available to perform the following:
  - Prime transfer pumps TP-200 and TP-202; and
  - "Wetting" the organoclay and liquid phase carbon units to remove any trapped air by pumping water through with the units.
- Verify main disconnect on the MCC is in ON position, and the main power switch on the control panel is ON;
- Verify all equipment breakers in MCC and control panel are in ON position;

- Check for any alarm conditions and clear any alarms, if needed; and
- Verify PLC and HMI are working correctly.

Following the treatment equipment checks, the observation and DPVE wells will be gauged for product. Once it is determined which DPVE wells to operate in each zone, the valves at the selected DPVE wells or DPVE well vaults will be opened.

The system checks described above will be conducted if, in the course of the DPVE system lifetime, significant changes are made to the system, and the system must be restarted.

Upon completing the mechanical and electrical start-up activities listed above, the DPVE system will be started using the following sequence. The manufacturer's operating instructions should be reviewed prior to operating the system. It should be noted that the DPVE wells and/or zones that will be operated has already been determined through product gauging of the observation and DPVE wells and the proper valves to the DPVE wells, and/or zones have been opened or closed as necessary.

- 1. Turn on circuit breaker (CB240) in the MCP to supply power to the single phase transformer. The appropriate circuit breakers in the single phase panel should be turned on. These include the lights, fans, heaters, and air compressor.
- 2. Energize the air compressor in the control room. Allow tank pressure to build and adjust pressure regulator to desired pressure to operate solenoid manifold and double-diaphragm pump.
- 3. Activate the appropriate manifold automated valves (AV-1 to AV-14) by placing the appropriate manifold icons in the HMI in the AUTO position. This will activate the pneumatic actuated valves. As discussed above, the DPVE wells and/or zones valves will be opened or closed in the field based on the product gauging.
- 4. Verify valves (i.e., unloading valve) on the LRPs are in the proper open or closed position. Activate the LRPs, LRP-101 and LRP-102, by placing the LRP icons in the HMI in the AUTO position. This will contact motor starters MS-206 and MS-211 which will signal the PLC that the motor starters are energized. The green run light on the MCP should activate.
- 5. Activate the knockout transfer pumps, TP-200 and TP-202, by placing the transfer pump icons in the HMI in the AUTO position (please note these pumps are self-priming). This will contact motor starters MS-216 and MS-221 which will signal the PLC that the motor starters are energized. In AUTO, the primary transfer pump will operate when the knockout tank level switch high, LSH-2, is contacted and the secondary transfer pump will

turn on when the knockout tank level switch high high, LSHH-3 is contacted. The transfer pumps will alternate between primary and secondary at the end of each cycle when the transfer pump icons are placed in AUTO.

- 6. Activate the product transfer pump, TP-300, by placing the transfer pump icon in the HMI in the AUTO position. This will provide compressed air (from the air compressor) to operate the double-diaphragm pump. In AUTO, the product transfer pump will operate when the OWS product high float switch, LSH-13 is contacted. The product transfer pump will shut down when the OWS product low float switch, LSL-12 is contacted.
- 7. Prior to activating OWS groundwater transfer pump, the pump needs to be primed. After the pump has been primed, activate the OWS groundwater transfer pump, TP-301, by placing the transfer pump icon in the HMI in the AUTO position. This will contact motor starter MS-228 which will signal the PLC that the motor starter is energized. In AUTO, the groundwater transfer pump will operate when the OWS high float switch, LSH-10 is contacted. The groundwater transfer pump will shut down when the OWS low float switch, LSL-9 is contacted.

#### **5.2 DPVE Treatment System Alarms**

The following devices and alarm conditions will shut down the entire DPVE treatment system and send an alarm signal to the PLC:

- E-stop Contact. There is an E-stop contact in the control room (on the MCP) and two in the process room (one by each personnel door).
- Power fail alarm (power relay contact).

The following devices and alarm conditions will shut down the LRPs and send an alarm signal to the PLC:

- Overload contacts (MS-206 and MS-211).
- High Temperature Switches (TSH-1 and TSH-2) for each LRP to indicate high temperature in case oil seal flow to each LRP is interrupted.
- Float Switch Low (LSL-5 and LSL-7) and Level Alarm Low (LAL) for each LRP oil seal reservoir to indicate a low oil level.
- Float Switch High (LSH-6 and LSH-8) and Level Alarm High (LAH) for each LRP oil seal reservoir to indicate a high oil level.
- LRP high pressure discharge transmitters (PT-1 and PT-2) and combined high pressure transmitter (PT-3).
- LRP vacuum transmitters (VT-16 and VT-17) are high or low.

- Float Switch High High (LSHHH-4) and Level Alarm High High (LAHHH) for the knock out tank to indicate a high liquid level in the knock out tank.
- Knock-out tank vacuum filter differential pressure transducer (DPT-1).
- Knock-out tank vacuum transmitter (VT-15) is high or low.
- Floor sumps high float switches (LSH-17 and LSH-18).

The following devices and alarm conditions will shut down transfer pumps TP-200 and TP-202 and send an alarm signal to the PLC:

- Overload contacts (MS-216 and MS-221).
- Float Switch High High (LSHH-11) and Level Alarm High High (LAHH) for the OWS to indicate a high water level.
- Float Switch High High (LSHH-14) and Level Alarm High High (LAHH) for the OWS to indicate a high product level in the oil water separator and prevent product from entering the water chamber.
- Floor sumps high float switches (LSH-17 and LSH-18).
- Transfer pumps high pressure discharge transducers (PT-4 and PT-5).

The following device and alarm condition will shut down transfer pump TP-300 and send an alarm signal to the PLC:

• Float Switch High High (LSHH-15) and Level Alarm High High (LAHH) for the product holding tank to indicate a high product level in the holding tank.

The following devices and alarm conditions will shut down transfer pump TP-301 and send an alarm signal to the PLC:

- Overload contact (MS-228).
- Float Switch High (LSH-16) and Level Alarm High High (LAHH) for treated groundwater storage tank to indicate a high water level in the storage tank.
- Pre and mid organoclay units high pressure transmitters (PT-7 and PT-8).
- Pre, mid and post liquid phase carbon units high pressure transmitters (PT-9 to PT-11).
- Bag filter housing high pressure differential transmitter (DPT-2).

If an alarm condition occurs, the red alarm banner at the bottom of the HMI screen will be activated. The cause of the alarm should be investigated and if corrected, the alarm reset button on the MCP should be pressed and the alarm acknowledged and cleared, if warranted.

# **5.3 DPVE Treatment System Shutdown Procedure**

The DPVE system components should be shut down separately (one at a time) as follows:

- De-energize LRPs, and transfer pumps by turning each to their icon on the HMI to "off".
- De-energize the air compressor.
- Turn the main power switch on the MCP to off.
- Turn the main disconnect on the MCP off.

If the DPVE system is to be shut down for an extended period, the following should be performed:

- Inspect and clean all clear piping on the valve manifold;
- Inspect and clean all flow elements; and
- Check the oil seal level at each LRP.

In addition, if the system is shut down in the winter, any accumulated liquid in the aboveground piping shall be drained to the appropriate DPVE well(s). The manual drain valves in the DPVE pre-cast concrete well vaults shall be opened and any liquid collected and introduced to the DPVE treatment system. The heaters in the control and process rooms shall be kept on.

#### 6.0 MAINTENANCE AND INSPECTIONS

This section provides a brief description of the required equipment maintenance and inspections. Records of all maintenance and inspections should be maintained at the Site. Detailed maintenance manuals prepared by the equipment manufacturers for each major component of the DPVE system are provided in their respective appendix. Additional information on miscellaneous treatment system components are provided on the attached CD.

# **6.1 Routine Maintenance and Inspections**

The routine maintenance activities will include general maintenance and visual inspections. Visual inspection is the routine part of the system operator's activities. The system operator will note any conditions on the inspection checklist (Table 1) which present a potential hazard or could cause future system shutdown. In the field, special attention will be paid to the condition of the DPVE wellheads, DPVE well vaults, and DPVE aboveground piping and supports specifically for evidence of damage and accumulation of dirt or water in the DPVE wellheads or vaults. At the treatment trailer, special attention should be given to any unusual or excessive noise or vibrations from the piping, LRPs, and transfer pumps. The piping and valves should be inspected for leaks.

Several system components require routine maintenance to ensure proper performance. All equipment maintenance will be performed in accordance with manufacturer's instructions. Specific routine maintenance tasks are outlined below:

- Electric motors with grease fittings should be greased, as per the manufacturer's instructions, with a lithium-based grease.
- Inspect DPVE manifold to confirm operation of appropriate valves.
- Inspect flow meters for both air, water, and product for proper operation.
- Check lubricant level on air compressor and fill as needed. Inspect air compressor filter element and clean or replace if needed. Inspect air compressor mist separator. Drain air compressor receiver tank condensate.
- Check and clean sediment strainer on knockout tank discharge piping (prior to transfer pumps TP-200 and TP-202).
- Check coalescing filter on each LRP for accumulation of oil particles and replace if needed.

- Check oil reservoir on each LRP by visually inspecting sight gauge to ensure adequate supply of oil is present and make-up oil if needed.
- Check for sludge accumulation in the sludge chamber of the OWS.
- Check OWS for presence of recovered product in the water effluent chamber.
- Check differential pressure gauge on particulate bag filter housing and replace bag filters, if needed.
- Check volume and clarity of the water in the treated water holding tank.
- Check volume of recovered product in the product storage tank and arrange for transportation and disposal, if needed.

# **6.2** Non-Routine Equipment Maintenance

Non-routine equipment maintenance consists of maintenance activities that will be performed with less frequency than the routine (i.e., semi-annually) on several system components. Non-routine equipment maintenance will be performed in accordance with manufacturer's instructions. Specific non-routine maintenance tasks are outlined below:

- Change the oil in each LRP oil reservoir for every 10,000 working hours;
- Lubricate bearings on each LRP for every 2,000 working hours with grease as per manufacturer's instructions; and
- Change air compressor oil for every 500 working hours, as per the manufacturer's instructions.

#### **6.3 Routine Maintenance Reports**

As discussed in Section 6.1, an inspection checklist will be filled out for each routine maintenance event. A copy of the checklist is provided as Table 1. The checklist includes, but not limited, to the following information:

- Date:
- Name of person(s) conducting maintenance activities;
- Maintenance activities conducted;
- Any modifications to the system;
- Where appropriate, color photographs or sketches showing the approximate location of any problems or incidents noted (included either on the checklist/form or on an attached sheet);
   and

• Other documentation such as copies of invoices for maintenance work, receipts for replacement equipment, etc., (attached to the checklist).

#### **6.4 Non-Routine Maintenance Reports**

During each non-routine maintenance event, a non-routine maintenance form (Table 2) will be completed which will include, but not be limited to, the following information:

- Date;
- Name, company, and position of person(s) conducting non-routine maintenance/repair activities;
- Presence of leaks:
- Date of leak repair;
- Other repairs or adjustments made to the system;
- Where appropriate, color photographs or sketches showing the approximate location of any problems or incidents (included either on the form or on an attached sheet); and
- Other documentation such as copies of invoices for repair work, receipts for replacement equipment, etc. (attached to the checklist/form).

Unscheduled inspections and/or sampling may take place when a suspected failure of the DPVE system has been reported or an emergency occurs that is deemed likely to affect the operation of the system. Monitoring deliverables for the DPVE system are specified later in this OM&M manual.

#### 7.0 MONITORING

To ensure that the DPVE treatment system performs as designed and meets the performance objectives, a monitoring and sampling plan will be implemented. The system monitoring will be performed by collecting operating data such as flow rates, vacuums and pressures from the treatment system components on a weekly basis. In addition, the product levels in the DPVE wells and/or observation wells will be monitored every two weeks. The monitoring frequency may be adjusted based on system operational performance after the initial operation period of three months.

The product levels will be used to optimize the performance of the system by selecting DPVE wells, as needed, to optimize product recovery (i.e., DPVE wells with no measurable product will be taken off-line). The product levels will be recorded using Table 3.

Treated groundwater samples will be collected from the clean water holding tank to evaluate the performance and effectiveness of the treatment system in treating the groundwater to acceptable levels for the discharge to the NYCDEP sewer system (Refer to Appendix S for the NYCDEP Discharge Permit and Sewer Discharge Limits). The treated groundwater samples will be collected on a monthly basis. The effluent of the VPGAC units will be monitored periodically with a PID to determine breakthrough. Air samples of the effluent of the VPGAC units will also be collected at start-up and on a quarterly basis to verify achievement of the air discharge criteria as specified in the NYSDEC Division of Air Resources. The air samples will also be collected using 6-liter Summa Canisters and analyzed for USEPA TO-15 to verify achievement of the air discharge criteria as specified in the NYSEC Division of Air Resources.

#### 7.1 Sampling Event Protocol

All DPVE system sampling activities will be recorded in the dedicated field book for the Site. The sampling protocol will follow the procedures discussed in the OU-3 Site Management Plan (SMP) (under separate cover).

#### 7.2 General Equipment Monitoring

General equipment monitoring will be conducted during each routine O&M visit. DPVE system components to be monitored include, but are not limited to, the following:

- Vacuum readings at the DPVE well manifold;
- Vacuum and air flow at each LRP;
- Product flow rate;
- Treated water flow rate; and
- PID readings of effluent of VPAC units.

A complete list of components to be checked is provided in the DPVE Treatment System Operating Log (Table 4). If any equipment readings are not within their typical range, any equipment is observed to be malfunctioning, or the system is not performing within specifications, maintenance and repair activities will be performed immediately (as per Section 6.0 of this OM&M manual), and the DPVE system restarted.

#### 8.0 RECORD KEEPING

Maintenance reports and any other information generated during regular operations at the site will be kept on-Site on a dedicated laptop computer. All reports, forms, and other relevant information generated will be available upon request to the NYSDEC and submitted as part of the Periodic Review Report, as specified in the SMP.

In order to properly maintain the DPVE treatment system and minimize downtime, record keeping must be performed. Detailed records for the DPVE treatment system will be recorded as per Tables 1, 3 and 4 and filed electronically on the laptop computer.

#### 8.1 Field Book

A daily field book will be kept in the control room for a time-specific daily record of maintenance and operations of the treatment system and the DPVE wells. The field book will be kept by the Roux Associates' technicians whenever personnel are on-Site.

# 8.2 System Monitoring

System monitoring will be achieved through system trend monitoring and the operations log. The DPVE treatment system operations log, the DPVE well gauging log and the product storage tank pump out log will be completed each day work is performed.

#### **8.2.1 DPVE Aboveground Piping Checklists**

DPVE well inspection checklists are completed on a weekly basis to ensure that the recovery well components are functioning correctly and that the recovery wells are accessible and covers are intact.

#### 9.0 HEALTH AND SAFETY

As a result of the hazards at the Site and the conditions under which operations are conducted, the possibility of an emergency exists. A Health and Safety Plan (HASP) is required by OSHA (29 CFR 1910.120) to be available for use. The HASP for OU-3 is available and a copy is kept in the control room. The HASP identifies and assesses potential hazards associated with work in OU-3, and outlines steps and procedures to mitigate such hazards. Further, the HASP contains Job Safety Analyses (JSAs) of specific work tasks that are expected to be completed in OU-3. JSAs identify existing or potential hazards associated with each step of a work task, and determine the best actions to follow in order to avoid those hazards.

Within the OU-3 HASP is a detailed Emergency Plan, which outlines the critical actions that should be followed in the event of an emergency, such as a fire, explosion, or a spill or release to the environment. In the event of an emergency, the procedures described in the Emergency Plan should be followed.

# 9.1 Emergency Response Overview

In the case of an emergency (i.e., spill or release, fire or immediate threat to personal or public health), immediately contact the police and fire authorities to inform them of the possible or immediate need for assistance and if there is a need for an evacuation. If a significant release (above the reportable quantity as described in 40 CFR 302) has occurred, the National Response Center and other appropriate groups (such as NYSDEC) should be contacted. Those groups will alert National or Regional Response Teams as necessary. Below is a list of personnel that shall be notified as necessary.

#### **Emergency Telephone Numbers**

Туре	Name	Telephone #
Fire Department / HazMat Emergency Response / Ambulance	New York City Fire Department	<b>911</b> 718-965-8283
Law Enforcement	New York City Police Department	911
Law Enforcement	Amtrak Police	800-331-0008
Hospital	Mount Sinai Hospital of Queens 25-10 30 <sup>th</sup> Avenue Long Island City, Queens, New York 11102	<b>911</b> 718-932-1000

Туре	Name	Telephone #
National Response Center (Release or Spill)		800-424-8802
NYSDEC Spills Hotline		800-457-7362
NYSDEC Case Manager	Hasan Ahmed	Office: 718-482-6405
Electric Utility (Amtrak)	Fred Ascoli	Office: 718-643-4050 Cell: 347-245-8027
Amtrak Project Manager	Richard Mohlenhoff	Office: 212-630-7249 Cell: 917-692-2127
Amtrak –Superintendent NY Mechanical Dept.	Frank Ross	Office: 212-630-7776
Amtrak – SSY Environmental, Health and Safety Officer	Chris Benson	Office: 212-630-7039 Cell: 917-538-2982
Amtrak – Penn Station Control Center		212-630-7465
Roux Project Manager	Rob Kovacs	Office: 631-232-2600 Cell: 516-250-0359
Roux Senior Field Technician	John LoMeli	Office: 631-232-2600 Cell: 631-445-8643
Roux Corporate Health and Safety Manager	Joseph Gentile, CIH	Office: 856-423-8800 Cell: 610-844-6911
Roux Office Health and Safety Officer	Ray Fitzpatrick	Office: 631-232-2600 Cell: 631-445-4498

In addition to the Emergency Response information provided in the HASP, additional information regarding the 2,000 gallon product recovery AST can be found in the Integrated Spill Prevention Control and Countermeasures Plan and Hazardous Waste Contingency Plan for Sunnyside Yard.

# 10.0 FIELD TEAM REVIEW / TRAINING SECTION

Each person performing work or visiting at this Site shall sign this section after Site-specific training is completed and before being permitted to access the Site.

I have read and understand this Operations, Monitoring and Maintenance manual. I will comply with the provision contained therein.

Site / Project: Amtrak / OU-3 DPVE Treatment System

Name Printed	Signature	Date
		·
·		-

# **TABLES**

- 1. DPVE System Inspection Checklist
- 2. DPVE System Non-routine Maintenance Form
- 3. DPVE Well Gauging Data Sheet
- 4. DPVE Treatment System Operating Log

Table 1. DPVE System Inspection Checklist, Amtrak, OU-3, Sunnyside Yards, Queens, New York

Date:	
Completed By:	

		Status				
			Action			
D		Ok	Req.	N/A	A - Government	
Description		OK	Keq.	IN/A	Actions Taken / Comments	
A. Treatment Area and Treatment Tra						
1 Inspect condition of fence and l		+				
	garbage adjacent to treatment trailer.		-			
3 Inspect condition of stairs and h		-				
4 Check overall condition of treat 5 Check emergency contact sign (		-				
B. DPVE Vaults	(condition / correctness).	-				
1 Check condition of vault.						
2 Inspect condition and operation	of yoult doors and yoult looks	1				
	vater or product / staining and remove / clean as necessary	1				
4 Inspect condition of piping and						
5 Inspect drainage valve for leaks						
C. Piping and Mechanical	•	1				
1 Inspect aboveground piping for	cracks, leaks and support issues					
	ut-off / control valves, check valves, and sample ports					
	ves for staining / leaks, corrosion and proper operation					
	s and flowmeters for proper operation					
5 Inspect and test vacuum release						
	auges and flowmeters are clearly labeled with ID and flow					
	piping, shutoff valves, gauges, meters, etc.).					
D. Electrical						
1 Check that all electrical / control	ol panels and are closed / secured and clearly labeled					
	l(s) is assembled properly and all breakers are labeled					
	ats are operational and provide adequate lighting.					
E. Controls						
1 Check that all control panel ligh	nts and switches are clearly labeled					
2 Check that all control panel ligh						
3 Check for proper operation of F						
	MI Screen matches local sensor measurements (i.e., pressure					
gauges / transmitters, flowmeter	rs).					
F. Heating and Ventilation						
1 Inspect proper operation and ter	mperature setting for control and process room heaters and					
thermostats during heating seas	on (October through March). Turn heat off during warmer					
seasons.						
2 Inspect condition of control and	process rooms fans and shutters.					
G. 220-Gallon Knock-out Tank						
<ol> <li>Check condition of vacuum filte</li> </ol>						
2 Check and clean Y-Strainer, if i						
3 Check dilution valve for noises						
4 Check sight tube for sediment a	ccumulation.					
H. LRPs						
1 Check oil reservoir on each LR						
2 Check that oil temperature is be						
3 Check for abnormal vibrations of						
4 Check for leaks from mechanic			-			
5 Check the vacuum gauges for p		-				
6 Check air flow meters for prope	er operation.		1			
I. OWS	in aludes showher					
1 Check for sludge accumulation			<del>                                     </del>			
2 Check for product in water efflu     3 Check operation of float switch		-				
4 Check condition of coalescing p		-				
J. Organoclay and Liquid Carbon Uni	oack.					
1 Check for any piping leaks.	1.5					
2 Inspect and check pressure gaug	TAC					
K. Vapor Phase Carbon Units	500.		1			
1 Inspect and check pressure gauge	TAS					
2 Check for any leaks on piping,						
L. Clean Water Holding Tank	nungs, etc.	-	-			
1 Check for presence of product i	n tank					
2 Check the float switch for prope		-	<del>                                     </del>			
M. Product Holding Tank	operation.		<del>                                     </del>			
1 Visually confirm volume of pro	duct in tank					
2 Check for leaks from piping.						
3 Check float switch for proper or	peration.	1	i i			

Table 2. DPVE System Non-Routine Maintenance Form, Amtrak, OU-3, Sunnyside Yard, Queens, New York

DATE	DESCRIPTION OF WORK DONE	CAUSE (Use as many lines as required to define the problem)	<b>Completed By</b>

Table 3. DPVE System Well Gauging Data Sheet, Amtrak, OU-3, Sunnyside Yard, Queens, NY

Date:
Gauged by:

			1	Tauged by.	
Well	DTP (FT)	DTW (FT)	PT (FT)	DPVE Well Valve Status	Actuated Valve Manifold Number
OW-1				N/A	N/A
OW-2				N/A	N/A
OW-3				N/A	N/A
OW-4				N/A	N/A
OW-5				N/A	N/A
OW-6				N/A	N/A
OW-7				N/A	N/A
OW-8				N/A	N/A
OW-9				N/A	N/A
Zone A1					477.12
DP-1A					AV-12
DP-2A					AV-12
DP-3A					AV-12
DP-4A DP-10A					AV-12 AV-12
Zone A2					AV-12
DP-5A					AV-11
					AV-11 AV-11
DP-6A DP-7A			-		AV-11 AV-11
DP-7A DP-8A		<del> </del>	<del> </del>		AV-11 AV-11
DP-8A DP-9A		<del> </del>			AV-11 AV-11
Zone A3		+	<del> </del>		AV-11
DP-11A					AV-10
DP-11A DP-12A					AV-10 AV-10
DP-12A DP-13A					AV-10 AV-10
DP-13A DP-14A					AV-10 AV-10
DP-19A					AV-10 AV-10
Zone A4					A V-10
DP-15A					AV-9
DP-16A					AV-9
DP-17A					AV-9
DP-18A					AV-9
Zone B1					11 7
DP-17B					AV-8
DP-18B					AV-8
DP-19B					AV-8
DP-20B					AV-8
DP-21B					AV-8
Zone B2					
DP-22B					AV-7
DP-23B					AV-7
DP-24B					AV-7
DP-27B					AV-7
Zone B3		1			
DP-26B					AV-6
DP-31B					AV-6
DP-32B					AV-6
DP-33B					AV-6
DP-34B					AV-6
Zone B4					
DP-25B					AV-5
DP-28B					AV-5
DP-29B					AV-5
DP-30B					AV-5
MW-93					AV-5
Zone B5					
DP-35B					AV-4
DP-36B					AV-4
DP-37B					AV-4
E		-	-	•	•

Note: AV-1 to AV-3, and AV-13 and AV-14 are spare (contingency) actuated valves.


Table 4. DPVE Treatment System Operating Log, Amtrak, OU-3, Sunnyside Yards, Queens, New York

Source of Reading	Units	Values	Comments
Air Compressor Discharge Pressure	PSI		<del></del>
Vacuum Transmitter VT-1	Inches of Hg		
Vacuum Transmitter VT-2	Inches of Hg		
Vacuum Transmitter VT-3	Inches of Hg		
Vacuum Transmitter VT-4	Inches of Hg		
Vacuum Transmitter VT-5	Inches of Hg		
Vacuum Transmitter VT-6	Inches of Hg		
Vacuum Transmitter VT-7	Inches of Hg		
Vacuum Transmitter VT-8	Inches of Hg		
Vacuum Transmitter VT-9	Inches of Hg		
Vacuum Transmitter VT-10	Inches of Hg		
Vacuum Transmitter VT-11	Inches of Hg		
Vacuum Transmitter VT-12	Inches of Hg		
Vacuum Transmitter VT-13	Inches of Hg		
Vacuum Transmitter VT-14	Inches of Hg		
Knock-Out Tank Vacuum	Inches of Hg		
LRP-101 Inlet Vacuum	Inches of Hg		
LRP-101 Discharge Pressure	PSI		
LRP-101 Air Flow	SCFM		
LRP-102 Inlet Vacuum	Inches of Hg		
LRP-102 Discharge Pressure	PSI		
LRP-102 Air Flow	SCFM		
Knockout Tank Transfer Pump			
(TP-200/TP-202) Discharge Pressure	PSI		
Product Transfer Pump TP-300			
Discharge Pressure	PSI		
Groundwater Transfer Pump TP-301			
Discharge Pressure	PSI		
Product Flow Rate	GPM		
Groundwater Flow Rate	GPM		
Inlet Pressure Bag Filter Housing 1	PSI		
Inlet Pressure Bag Filter Housing 2	PSI		
Differential Pressure Bag Filters	PSI		
Inlet Pressure First Liquid Carbon Unit	PSI		
Outlet Pressure Second Liquid Carbon Unit	PSI		
Inlet Pressure First Organoclay Unit	PSI		
Outlet Pressure Second Organoclay Unit	PSI		
Inlet Pressure First VPGAC Unit	PSI		
Outlet Pressure Second VPGAC Unit	PSI		
Second VPGAC Unit PID Reading	PPMV		
Product Storage Tank Volume	GALLONS		
Is the System operating within the acce	eptable conditions?		
If no, was the condition of	corrected and how?		

Inlet Pressure Bag Filter Housing 2	PSI		
Differential Pressure Bag Filters	PSI		
Inlet Pressure First Liquid Carbon Unit	PSI		
Outlet Pressure Second Liquid Carbon Unit	PSI		
Inlet Pressure First Organoclay Unit	PSI		
Outlet Pressure Second Organoclay Unit	PSI		
Inlet Pressure First VPGAC Unit	PSI		
Outlet Pressure Second VPGAC Unit	PSI		
Second VPGAC Unit PID Reading	PPMV		
Product Storage Tank Volume	GALLONS		
Is the System operating within the acce	ptable conditions?		
If no, was the condition c	orrected and how?		
Form Completed By:		Signature:	Date & Time:
REMEDIAL ENGINEERING, P.C.	1 of	1	AM0055.0045Y020.298/T4

**FIGURE** 

1. Site Plan




#### **APPENDICES**


- A. Process and Instrumentation Diagram
- **B.** Treatment Trailer Layout
- C. Control Panel Parts Layout
- D. Panel 1 Electrical Schematic
- **E.** Air Compressor Information
- F. PLC Input/Output/Analog Wiring Drawings
- G. LRPs 101/102 Information
- H. Air Flow Meter/Transmitter Information
- I. Transfer Pumps TP-200/202 Information
- J. OWS Information
- K. Transfer Pump TP-301 Information
- L. Bag Filter Information
- M. Liquid Phase Organoclay Information
- N. Liquid Phase Carbon Information
- O. Liquid Flow Meter/Transmitter Information
- P. Transfer Pump TP-300 Information
- Q. Vapor Phase Carbon Units Information
- **R.** Electrical Power Wiring Drawings
- S. NYCDEP Discharge Permit Limits

<b>Operation, Maintenance and Monitoring (C</b>	)M&M	) Manual
---	------	----------

**APPENDIX A** 

Process and Instrumentation Diagram






<b>Operation, Maintenance and Monitoring (C</b>	)M&M	) Manual
---	------	----------

**APPENDIX B** 


Treatment Trailer Layout




	<b>Operation</b>	Maintenance	and Monitoring	(OM&M)	) Manual
--	------------------	-------------	----------------	--------	----------

**APPENDIX C** 

Control Panel Parts Layout






	<b>Operation</b>	Maintenance	and Monitoring	(OM&M)	) Manual
--	------------------	-------------	----------------	--------	----------

**APPENDIX D** 

Panel 1 Electrical Schematic



<b>Operation, Maintenance and Monitoring (C</b>	)M&M	) Manual
---	------	----------

**APPENDIX E** 

Air Compressor Information



Reciprocating Single- and Two-stage Air Compressors 2-25 hp






# Legendary Performance

For more than a century, Ingersoll Rand has inspired progress by driving innovation through revolutionary technology and talented people.

It's a legacy of creating new standards for how the world gets work done. We're the technology leader in compressed air not only because we develop best-in-class products, but also because we stand behind our customers in all aspects of what we do. No matter what your product, process or location, Ingersoll Rand has the expertise, the technology and the unmatched service to meet your needs.

INGERSOLL-RAND

# T-30 Legendary Performance



of Type-30 design with vertical cooling fins; combination of concave and convex tank heads.



1950s

Updraft air cleaner added.



#### 1970s

First units from Campbellsville, KY plant establish a new reputation for workmanship and



## 1872

tradition begins with its first reciprocating air compressor.

### 1940s

Design enhanced with large U-frame motor and



#### 1960s

Modern Type-30 design emerges with horizontal cooling fans, smaller T-frame motor, convex tank heads, fully-welded construction



#### **Providing Customer-driven Compressor Solutions**


When you've been delivering reliable reciprocating compressor results for more than 100 years, it's natural that your corporate culture supports a strong tradition of evolutionary enhancements. Every new generation of employees builds on the experience and insights of their mentors. Today's legendary Ingersoll Rand air compressors started with an original rocksolid design and have steadily improved with added control and performance upgrades over the years.

They are world-renowned for their impressive legacy of long-life performance, ease of service and evolutionary design enhancements.

#### Efficient. Reliable. Built to last.

Ingersoll Rand has sold millions of reciprocating compressors worldwide.





# Efficiency, Reliability, Built to Last

Time-tested design and enhancements establish Ingersoll Rand single- and two-stage reciprocating compressors as the benchmark for:

#### **Efficiency and Reliability**

With a proven design and stellar track record, the Ingersoll Rand reciprocating compressor family has earned worldwide recognition for reliable, trustworthy performance that saves money and enhances business success through:

- Lower life-cycle costs
- An ability to thrive in punishing applications
- Optimum solutions for greater efficiency
- Configurations that meet varying needs

#### **Built to Last**

Due to the laws of physics, there are certain aspects of reciprocating compressor design, construction and performance that have never changed – like cast-iron durability, copperfinned cooling coils, reliable lubrication and easy maintenance. That's where Ingersoll Rand design and operating experience really pays off in terms of long-term productivity and return on investment. Ask any one of the millions of active Ingersoll Rand reciprocating compressor users around the world.

#### Serviceability

Ingersoll Rand designed the reciprocating compressors to last a lifetime – thanks to quick, easy maintenance with renewable components. Easy access to the pump components allows for quick routine maintenance and replacement of parts like the stainless steel valve, individually cast cylinders, piston rings and gaskets, and the 15,000-hour bearings. This key serviceability aspect extends the life of the compressor and lets you amortize your initial capital cost over a much longer equipment life span for a superior payback on your investment.



# The Ideal Design for Applications Where Air is Taken for Granted

#### Innovation

For more than 100 years, Ingersoll Rand has maintained the delicate balance between known performance and new developments by keeping the best features and upgrading others as new technology becomes available. The result is higher efficiency for today's energy-conscious world and enhanced value for the extended life of your investment.


#### **Customer-driven Solutions**

Another residual benefit of compressor longevity is our cumulative experience with how different users prefer, need and operate their compressors. Years of experience in the reciprocating compressor business and servicing a variety of users have taught us what is most important to compressor users. And that means more choices for you to satisfy your specific needs.

Your choices range from the size of the units and the sophistication of the features to popular packaged solutions. There are even gas-powered packages perfect for field service, fleet maintenance, remote pneumatic applications or emergency back-up needs.



Ingersoll Rand single- and two-stage reciprocating air compressors are an ideal choice for applications that demand a reliable air supply for everyday use, but where running an air compressor ranks a distant second to running your business.



- Light Manufacturing
- Construction
- Commercial Applications
- Fabrication
- Pneumatic Equipment
- Processing Lines



# It's All About Choices

Better choices lead to better solutions for saving money and improving overall return on investment in your unique application.

That's why Ingersoll Rand single- and two-stage reciprocating compressors offer you more choices of compressor sizes and compressor features to suit your needs. If you define unsurpassed performance by maximum operating pressure, increased air flow and extended duty cycles, count on an Ingersoll Rand reciprocating air compressor to deliver it reliably.

Take advantage of Ingersoll Rand expertise, product selection, service and system solutions to help you identify the optimum compressor size, performance features and package options for your applications. And learn how you can strengthen your business through:

- Lower operating costs
- Increased productivity
- Improved quality
- A better working environment

Feature	Value Package (5, 7.5, 10 & 15hp)	Value Plus Package (10 & 15hp)	Premium Package (5, 7.5, 10, 15 & 20hp)
100% Cast Iron Pump	<i>V</i>	<b>v</b>	V
ASME Coded Receiver Tank	V	<b>V</b>	V
NEMA 1 & ODP Motor	<b>✓</b>	<b>✓</b>	V
Magnetic Motor Starter	(Except 2340 packages with single-phase voltage)	V	(Except 2340 packages with single-phase voltage
Automatic Start/Stop Control with Pressure Switch	<b>V</b>	<b>V</b>	✓ (5 & 7.5hp only)
Oil Sight Glass	✓ (10 & 15hp only)	<b>v</b>	
Manual Drain	V		
Electric Drain		<b>✓</b>	<b>V</b>
Air-Cooled Aftercooler		<b>V</b>	V
Low Oil Level Switch			V
Dual Control with Centrifugal Unloader			✓ (10 & 15hp only)

Value Package (5, 7.5, 10 & 15hp) An economical choice in a dependable compressed air source, the Value Package offers the perfect solution for commercial, automotive and light industrial applications with intermittent load demands.

Value Plus Package (10 & 15hp) For applications that demand a heavier-duty cycle. Step up to this enhanced version of our base package. It is ideal for light industry applications. The Value Plus Package comes factory-fitted with options shown above for unmatched reliability in most diversified applications.

Premium Package (5, 7.5, 10, 15 & 20hp) For applications that are the most demanding or require greater control over compressed air supply. Step up to our top-of-the-line Premium Package. These air compressors come standard with factory-fitted options shown above for unmatched reliability in 100% continuous-duty applications

#### **Single-stage Air Compressor**

Configured in space-saving stationary and portable models, these durable compressors are a favorite with DIY homeowners and in the construction industry.

Key features include:

- Industry-leading 5,000-8,000 hour design life
- Industrial-quality cast iron construction
- Reliable high-speed valve design
- Fully-balanced crankshaft that reduces vibration
- 135 psi max. discharge pressure
- Honda engine-driven wheel barrow compressor




#### **Two-stage Gas-powered Air Compressors**

Ingersoll Rand's two-stage gasoline engine driven air compressors are designed to provide compressed air where electric power is not readily available. They're used in fleet and field service applications, remote pneumatic applications and emergency production lines.

- Available with easy-starting Honda, or Kohler engines
- Fuel-efficient idle control
- Advanced safety features including low oil level shutdown for gas engines



# Why Ingersoll Rand Pumps Are Better... Excellence in Design!



- **Two-stage Design:** Delivers pressures up to 175 psiq
- 2 Radial Fins for Maximum Cooling: Even 360° cooling of barrel cylinders eliminates hot spots
- **One-piece Connecting Rod:** Fewer wearing parts
- **Low Oil Level Switch:** Provides constant protection
- **5 Centrifugal Unloader:** Ensures loadless starts, for maximum starter protection
- 6 Integral Fan Blade/Finned Copper Intercooler: Runs cooler, even in the most demanding conditions
- **Overhung Crankshaft:** Precision balanced to run smoothly and quietly; simplifies maintenance and wear-sleeve replacement
- **8 Splash Lubrication:** Simple and reliable.
- 9 100% Cast Iron: Designed for a lifetime

# Selection Guide for Electric-drive Stationary Air Compressors

### 1. Select Your Compressor

Stationar	ry Compressors
Applications	Recommended Package
Intermittent Duty	Two-stage Value
Medium Duty	Two-stage Value Plus
100% Continuous Duty	Two-stage Premium
DIY	Single-stage

Porta	able Compressors
Applications	Recommended Package
Remote/Fleet/ Field Service	Two-stage Gas-driven
DIY/Construction	Single-stage



### 2. Choose Your Air Quality

Ingersoll Rand compressed air treatment equipment is used to remove contaminants present in a compressed air system.

#### **Shop Quality Air**

General system protection removes bulk liquid and solid contaminates:



- Light manufacturing
- Light auto service shop
- Pneumatic tools
- Dry cleaning

#### Dry, Clean Air

Complete system protection removes liquid and solid contaminates:



Refrigerated Dryer

- Medium-to-heavy manufacturing
- Large auto service shop
- Auto body shop
- Printing
- Laundry
- Instrumentation

### **Critical Quality Air**

Applications that require virtually no water vapor or contaminates:

- Advanced pneumatics and instrumentation
- Spray application booths
- Piping exposed to freezing temperatures



G - General Purpose H - High Efficiency D - Dust Protection



Ingersoll Rand accessories are available for all power sources.

### IntelliFlow Pneumatic Flow Controller

- Energy savings
- Control pressure ± 1 psig (.07 bar g)
- Single point control system
- Reduce leak losses
- Increase system productivity
- Protect all downstream equipment

#### **EZ-line SimplAir Compressed Air Piping**

- High-quality anodized aluminum pipe
- Non-corrosive piping
- Reduced pressure loss
- Higher flow rates than other piping
- Easy and fast installation

#### **EDV Electronic Drain Valve**

■ Automatically removes moisture from tanks, compressors, filters, drip legs





#### Filters, Regulators and Lubricators (FRLs)

FRLs provide point-of-use air conditioning to enhance tool longevity and process quality. Filters remove rust, scale and condensation that increase wear on tools regulators and provide constant pressure with varying upstream pressure. Lubricators provide lubricating oil to tools, cylinders, valves and other equipment.

#### **Oil Water Separators**

- Removes oil from drain condensate
- Allows for clean water discharge



# Global Reach, Local Touch

No matter what the industry or location, Ingersoll Rand is committed to serving you 24 hours a day, seven days a week. Our worldwide network of distributors, engineers and certified, factory-trained technicians, are a phone call away — ready to support you with innovative and cost-effective service solutions that will keep you running at peak performance.









### Start-up Kits

Ingersoll Rand offers All Season Select® start-up kits to provide improved protection. Each kit contains all the parts needed to correctly start up and maintain your compressor for the first year. The start-up kits provide everything you need for 2,000 hours of service between changes under normal operating conditions, along with the added protection of a two-year extended warranty.

All start-up kits include:

- All Season Select® lubricant, our synthetic, all-temperature blend designed to increase efficiency, reduce wear and prevent carbon build-up
- Replacement air filter elements

# **Specifications**

Two-stage	Two-stage Electric-powered – Value Package											
Model	hp	Tank Size/ Configuration	Stationary or Portable	Capacity (cfm) @ 175 psig	Max Pressure (psig)	Dimensions (L x W x H in)	Net Weight (lbs)	Tank Outlet (in)	Startup Kit			
2340L5-V	5.0	60-Gal. Vertical	S	14.0	175	48 x 40 x 76	435	0.50	32305880			
2340N5-V	5.0	80-Gal. Vertical	S	14.0	175	48 x 40 x 76	505	0.50	32305880			
2475N5-V	5.0	80-Gal. Vertical	S	16.8	175	48 x 40 x 76	505	0.75	32305880			
2475N7.5-V	7.5	80-Gal. Vertical	S	24.0	175	48 x 40 x 76	611	0.75	32305880			
2545E10-V	10.0	120-Gal. Horizontal	S	35.0	175	83 x 36 x 65	920	0.75	32305898			
2545K10-V	10.0	120-Gal. Vertical	S	35.0	175	51 x 46 x 83	1,104	1.00	32305898			
7100E15-V	15.0	120-Gal. Horizontal	S	50.0	175	83 x 36 x 65	1,239	0.75	32305898			

Available voltages: 230/1/60 (5-7.5 hp only), 200/3/60, 230/3/60, 460/3/60 and 575/3/60 voltages

Packages include magnetic starter (except 2340 models with single-phase voltage), manual drain, automatic start/stop control with pressure switch

Two-stage l	Two-stage Electric-powered – Value Plus Package											
Model	hp	Tank Size/ Configuration	Stationary or Portable	Capacity (cfm) @ 175 psig	Max Pressure (psig)	Dimensions (L x W x H in)	Net Weight (lbs)	Tank Outlet (in)	Startup Kit			
2545E10-VP	10.0	120-Gal. Horizontal	S	35.0	175	83 x 36 x 65	1,104	0.75	32305898			
2545K10-VP	10.0	120-Gal. Vertical	S	35.0	175	51 x 46 x 83	1,104	1.00	32305898			
7100E15-VP	15.0	120-Gal. Horizontal	S	50.0	175	83 x 36 x 65	1,297	0.75	32305898			

Available voltages: 200/3/60, 230/3/60, 460/3/60 and 575/3/60 voltages

Packages include magnetic starter, electric drain, Automatic start/stop control with pressure switch, air-cooled aftercooler

Two-stage	Electric-	powered – Premiun	n Package						
Model	hp	Tank Size/ Configuration	Stationary or Portable	Capacity (cfm) @ 175 psig	Max Pressure (psig)	Dimensions (L x W x H in)	Net Weight (lbs)	Tank Outlet (in)	Startup Kit
2475N5-P	5.0	80-Gal. Vertical	S	16.8	175	48 x 40 x 76	597	0.75	32305880
2475N7.5-P	7.5	80-Gal. Vertical	S	24.0	175	48 x 40 x 76	611	0.75	32305880
2545E10-P	10.0	120-Gal. Horizontal	S	35.0	175	83 x 36 x 65	1,104	0.75	32305898
2545K10-P	10.0	120-Gal. Vertical	S	35.0	175	51 x 46 x 83	1,104	1.00	32305898
7100E15-P	15.0	120-Gal. Horizontal	S	50.0	175	83 x 36 x 65	1,297	0.75	32305898

 $\label{eq:available} \textit{Available voltages: } 230/1/60 \ (5-7.5 \ \text{hp only}), \ 200/3/60, \ 230/3/60, \ 460/3/60 \ \text{and } 575/3/60 \ \text{voltages}$ 

Packages include magnetic starter, electric drain, automatic start/stop control with pressure switch (5 hp & 7.5hp), dual control with centrifugal unloader (10hp & 15hp), air-cooled aftercooler, low oil level switch

Single-stag	Single-stage Electric-powered										
Model	hp	Tank Size/ Configuration	Stationary or Portable	Capacity (cfm) @ 90 psig	Max Pressure (psig)	Dimensions (L x W x H in)	Net Weight (lbs)	Tank Outlet (in)	Startup Kit		
P1IU-A9	2.0	4-Gal. Twin	Р	4.30	135	19 x 19 x 19	77	0.25	_		
P1.5IU-A9	2.0	20-Gal. Vertical	Р	5.20	135	22 x 23 x 43	200	0.25	_		
SS3J2-WB	2.0	8-Gal. Twin	Р	5.70	135	43 x 18 x 25	175	0.25	97338099		
SS3J3-WB	3.0	8-Gal. Twin	Р	11.3	135	43 x 18 x 25	175	0.25	97338099		
SS3L3	3.0	60-Gal. Vertical	S	11.3	135	20 x 23 x 66	300	0.50	97338099		
SS5L5	5.0	60-Gal. Vertical	S	18.1	135	20 x 30 x 71	310	0.50	20100251		

Available voltages: 120/1/60 (P1IU-A9), 115/1/60 (P1.5IU-A9), and 230/1/60 (SS3, SS5) voltages

Two-stage	Two-stage Gas-powered										
Model	hp	Engine	Tank Size/ Configuration	Stationary or Portable	Capacity (cfm) @ 175 psig	Max Pressure (psig)	Dimensions (L x W x H in)	Net Weight (lbs)	Tank Outlet (in)	Startup Kit	
2475F13GH	13	Honda	30-Gal. Horizontal	Р	25.0	175	51 x 33 x 44	469	0.50	32312936	
2475X13GH	13	Honda	Baseplate Mounted	Р	25.0	175	33 x 36 x 36	440	0.50	32312936	
2475F12.5G	13	Kohler	30-Gal. Horizontal	Р	24.0	175	51 x 33 x 44	469	0.50	32305872	
2475X12.5G	13	Kohler	Baseplate Mounted	Р	24.0	175	33 x 36 x 36	440	0.50	32305872	

Single-stage	Gas-	powered								
Model	hp	Engine	Tank Size/ Configuration	Stationary or Portable	Capacity (cfm) @ 90 psig	Max Pressure (psig)	Dimensions (L x W x H in)	Net Weight (lbs)	Tank Outlet (in)	Startup Kit
SS3J5.5GH-WB	5.5	Honda	8-Gal. Twin	Р	11.8	135	43 x 18 x 26	175	0.25	97339501



Ingersoll Rand Industrial Technologies provides products, services and solutions that enhance our customers' energy efficiency, productivity and operations. Our diverse and innovative products range from complete compressed air systems, tools and pumps to material and fluid handling systems and environmentally friendly microturbines. We also enhance productivity through solutions created by Club Car®, the global leader in golf and utility vehicles for businesses and individuals.

www.ingersollrandproducts.com





Ingersoll Rand compressors are not designed, intended or approved for breathing air applications. Ingersoll Rand does not approve specialized equipment for breathing air applications and assumes no responsibility or liability for compressors used for breathing air service.

Nothing contained on these pages is intended to extend any warranty or representation, expressed or implied, regarding the product described herein. Any such warranties or other terms and conditions of sale of products shall be in accordance with Ingersoll Rand's standard terms and conditions of sale for such products, which are available upon request.

Product improvement is a continuing goal at Ingersoll Rand. Designs and specifications are subject to change without notice or obligation.



### Owner's Manual

for Model P1.5IU-A9

#### IMPORTANT INFORMATION! READ AND FOLLOW THESE INSTRUCTIONS. RETAIN FOR REFERENCE.

#### SAFETY

#### **DEFINITIONS**

**△** DANGER

WILL cause DEATH, SEVERE INJURY or

substantial property damage.

**△ WARNING** 

CAN cause DEATH, SEVERE INJURY or

substantial property damage.

**△** CAUTION

WILL or CAN cause MINOR INJURY or property

#### **GENERAL SAFETY PRECAUTIONS**

**△** DANGER

INTAKE AIR. Can contain carbon monoxide or other contaminants. Will cause serious injury or death. Ingersoll Rand air compressors are not designed, intended or approved for breathing air. Compressed air should not be used for breathing air applications unless treated in accordance with all applicable codes and regulations.

**△ WARNING HAZARDOUS VOLTAGE. Can cause serious** injury or death. Disconnect power and bleed pressure from tank before servicing. Lockout/Tagout machine. Compressor must be connected to properly grounded circuit. See grounding instructions in manual. Do not operate compressor in wet conditions. Store indoors.

> MOVING PARTS. Can cause serious injury. Do not operate with guards removed. Machine may start automatically. Disconnect power before servicing. Lockout/Tagout machine.

HOT SURFACES. Can cause serious injury. Do not touch. Allow to cool before servicing. Do not touch hot compressor or tubing.

HIGH PRESSURE AIR. Bypassing, modifying or removing safety/relief valves can cause serious injury or death. Do not bypass, modify or remove safety/relief valves. Do not direct air stream at body. Rusted tanks can cause explosion and severe injury or death. Drain tank daily or after each use. Drain valve located at bottom of tank.

**△** CAUTION

RISK OF BURSTING. Use only suitable air handling parts acceptable for pressure of not less than the maximum allowable working pressure of the machine.

#### **GENERAL INFORMATION**

Your air compressor unit is suitable for operating air tools, caulking guns, grease guns, sandblasters, etc. Depending on your application, the following accessories may be required:

- An air pressure regulator to adjust the air pressure entering the tool or accessory.
- An air line filter for removal of moisture and oil vapor in compressed air.
- An in-line lubricator to prolong the life of air tools.
- Separate air transformers which combine the functions of air regulation and/or moisture and dirt removal.

Contact your nearest authorized dealer or call 1-800-AIR-SERV for more information on air tools and accessories for your application.

#### PREPARATION FOR USE

#### TRANSPORTING THE UNIT

**△ CAUTION** The wheels and handle do not provide adequate clearance, stability or support for pulling the unit up and down stairs or steps. The unit must be lifted or pushed up a ramp. Do not use the handle to lift the unit.

#### SELECTING A LOCATION

GENERAL. Select a clean, dry, well-lighted area with plenty of space for proper cooling air flow and accessibility. Locate the unit on a solid level surface at least 12 inches (30 cm) from walls. Ensure unit is as level as possible.

**TEMPERATURE.** Ideal operating temperatures are between 32°F and 104°F (0°C and 40°C). In lower temperatures, you must protect safety/relief valves and drain valves from freezing.

△ CAUTION Never operate in temperatures below 20°F (-6.6°C) or above 125°F (51.0°C).

**HUMID AREAS.** In frequently humid areas, moisture may form in the bare pump and produce sludge in the lubricant, causing running parts to wear out prematurely. Excessive moisture is especially likely to occur if the unit is located in an unheated area that is subject to large temperature changes. Two signs of excessive humidity are external condensation on the bare pump when it cools down and a "milky" appearance in petroleum compressor lubricant. You may be able to prevent moisture from forming in the bare pump by increasing ventilation or operating for longer intervals.

NOISE CONSIDERATIONS. Consult local officials for information regarding acceptable noise levels in your area. To reduce excessive noise, use vibration mounts or intake silencers, relocate the unit or construct total enclosures or baffle walls. Contact your dealer for assistance.

C.C.N.: 80444425

REV. : B

DATE : FEBRUARY 2008

#### INSTALLING THE AIR INLET FILTER

#### **△ CAUTION** Do not operate without air inlet filter.

Install the air inlet filters at the inlet connections at the bare pump. If heavy duty filtration is required, contact your dealer for information.

#### INSTALLING DISCHARGE PIPING

If it is necessary to install air discharge piping or condensate discharge piping, adhere to the following general guidelines. Contact your dealer for more information.

△ WARNING If an aftercooler, check valve, block valve, or any other restriction is added to the compressor discharge, install a properly-sized ASME approved safety/relief valve between the compressor discharge and the restriction.

**△** CAUTION

If you will be using All Season Select synthetic compressor lubricant, all downstream piping material and system components must be compatible. Refer to the following material compatibility list. If there are incompatible materials present in your system, or if there are materials not included in the list, contact your dealer.

#### Suitable:

Viton®, Teflon®, Epoxy (Glass Filled), Oil Resistant Alkyd, Fluorosilicone, Fluorocarbon, Polysulfide, 2-Component Urethane, Nylon, Delrin®, Celcon®, High Nitrile Rubber (Buna N. NBR more than 36% Acrylonitrile), Polyurethane, Polyethylene, Epichlorohydrin, Polyacrylate, Melamine, Polypropylene, Baked Phenolics, Epoxy, Modified Alkyds

(® indicates trademark of DuPont Corporation)

#### Not Recommended:

Neoprene, Natural Rubber, SBR Rubber, Acrylic Paint, Lacquer, Varnish, Polystyrene, PVC, ABS, Polycarbonate, Cellulose Acetate, Low Nitrile Rubber (Buna N. NBR less than 36% Acrylonitrile), EPDM, Ethylene Vinyl Acetate, Latex, EPR, Acrylics, Phenoxy, Polysulfones, Styrene Acrylonitrile (San), Butyl

GENERAL REQUIREMENTS. The piping, fittings, receiver tank, etc. must be certified safe for at least the maximum working pressure of the unit. Use hard-welded or threaded steel or copper pipes, cast iron fittings and hoses that are certified safe for the unit's discharge pressure and temperature. DO NOT USE PVC PLASTIC. Use pipe thread sealant on all threads, and make up joints tightly to prevent air leaks.

**CONDENSATE DISCHARGE PIPING.** If installing a condensate discharge line, the piping must be at least one size larger than the connection, as short and direct as possible, secured tightly and routed to a suitable drain point. Condensate must be disposed of in accordance with local, state, and federal laws and regulations.

NOTE: All compressed air systems generate condensate which accumulates in any drain point (e.g. tanks, filters, drip legs, aftercoolers, dryers). This condensate contains lubricating oil and/or substances which may be regulated and must be disposed of in accordance with local, state, and federal laws and regulations.

#### **ELECTRICAL WIRING & GROUNDING**

△ WARNING Any electrical installation and service required should be performed by a qualified electrician who is familiar with all applicable local, state and federal laws and regulations.

GENERAL. The motor rating, as shown on the motor nameplate, and the power supply must have compatible voltage, phase and hertz characteristics.

FUSES. Refer to the National Electric Code to determine the proper fuse or circuit breaker rating required. When selecting fuses, remember the momentary starting current of an electric motor is greater than its full load current. Time-delay or "slow-blow" fuses are recommended.

GROUNDING. The unit is equipped with a power cord having a grounding wire an an appropriate grounding plug. The plug must be used with an outlet that has been installed and grounded in accordance with all local codes and ordinances. The outlet must have the same configuration as the plug. DO NOT USE AN ADAPTER.

**△ WARNING** 


In the event of a short circuit, grounding reduces the risk of shock by providing an escape for the electric current. The unit must be properly

**△** DANGER

Improper installation of the grounding plug can result in a risk of electric shock. If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire.

Check with a qualified electrician or serviceman if the grounding instructions are not completely understood, or if in doubt as to whether the product is properly grounded. Do not modify the plug provided; if it will not fit the outlet, have the proper outlet installed by a qualified electrician.

This product is for use on a nominal 120-volt circuit and has a grounding plug that looks like the plug illustrated below. Make sure the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product.



EXTENSION CORDS. It is preferable to use extra air hose instead of an extension cord to avoid voltage drop and power loss to the motor, and to prevent overheating. If an extension cord must be used, ensure it meets the following criteria:

- Three wire cord with a three blade grounding plug, and a three slot receptacle that will accept the plug on the unit.
- Good condition
- No longer than 50 feet.
- 12 gauge or larger.

NOTE

Wire size increases as gauge number decreases. For example, 10 AWG and 8 AWG wire is acceptable, whereas 14 or 16 AWG are NOT acceptable.

#### **COMPRESSOR LUBRICATION**

**△** CAUTION

Do not operate without lubricant or with inadequate lubricant. Ingersoll Rand is not responsible for compressor failure caused by inadequate lubrication.

SYNTHETIC LUBRICANT. We recommend All Season Select synthetic compressor lubricant from start-up. See the WARRANTY section for extended warranty information.

http://air.irco.com P1.5IU-A9 **ALTERNATE LUBRICANTS.** You may use a petroleum-based lubricant that is premium quality, does not contain detergents, contains only anti-rust, anti-oxidation, and anti-foam agents as additives, has a flashpoint of 440°F (227°C) or higher, and has an auto-ignition point of 650°F (343°C) or higher.

See the petroleum lubricant viscosity table below. The table is intended as a general guide only. Heavy duty operating conditions require heavier viscosities. Refer specific operating conditions to your dealer for recommendations.


Temperatu	re Around Unit	1	ty @ 100°F 7.8°C)	Viscosity Grade		
°F	°C	SUS	Centistoke s	ISO	SAE	
40 & below	4.4 & below	150	32	32	10	
40 - 80	4.4 - 26.7	500	110	100	30	
80 - 125	26.7 - 51.0	750	165	150	40	

If you use a petroleum-based compressor lubricant at start-up and decide to convert to All Season Select synthetic compressor lubricant later on, the compressor valves must be thoroughly decarbonized and the crankcase must be flushed before conversion.

#### **COMPRESSOR PUMP FILLING PROCEDURES:**

- 1. Unscrew and remove the oil fill plug (A).
- Slowly fill the crankcase with lubricant until the lubricant reaches the "full" level of the sight glass as shown. Crankcase capacity is one (1) pint (0.5 liters).
- 3. Replace the oil fill plug HAND TIGHT ONLY.

#### Filling Procedures



#### **OPERATION**

#### GENERAL

Your air compressor was designed for 100% continuous duty operation with the use of All Season Select synthetic compressor lubricant and 60% continuous duty operation with the use of petroleum lubricant. In other words, synthetic lubricant allows the compressor to pump continuously without cycling. Petroleum lubricant limits the compressor to a maximum of 36 minutes of


pumping time per hour. The compressor should not cycle more than 10 times per hour.

#### NORMAL START-UP

1. Set the pressure switch lever to "OFF".

#### Pressure Switch Lever





2. Close the regulator by turning it fully counterclockwise (-).

#### Regulator



- 3. Attach hose and accessory.
- 4. Move the pressure switch lever to "ON/AUTO". The unit will start.
- Allow tank pressure to build. The motor will stop when tank pressure reaches cut-out pressure.
- Adjust the regulator to the desired secondary pressure by turning it clockwise (+) to increase the pressure or counterclockwise (-) to decrease the pressure.

NOTE:

When the receiver tank pressure drops below the factory pre-set minimum, the pressure switch resets and restarts the unit.

#### SHUTDOWN

- 1. Set the pressure switch lever to "OFF".
- 2. Close the service valve fully.
- 3. Remove the air tool or accessory.
- Slowly open the service valve to bleed air pressure down to 20 psig.
- Slowly open the manual drain valve at the bottom of the tank to drain all condensate (water).
- 6. Close the drain valve and the service valve for the next use.
- 7. Wrap the power cord firmly around the handle.
- 8. Store the unit indoors.

http://air.irco.com P1.5IU-A9

#### **MAINTENANCE**

△ WARNING Unplug the unit and release air pressure from the

tank before performing maintenance.

**△ WARNING** Wear appropriate personal safety equipment

such as safety glasses and gloves.

NOTE All compressed air systems contain maintenance

parts (e.g. lubricating oil, filters, separators) which are periodically replaced. These used parts may be, or may contain, substances that are regulated and must be disposed of in accordance with local, state, and federal laws

and regulations.

NOTE Take note of the positions and locations of parts

during disassembly to make reassembly easier. The assembly sequences and parts illustrated

may differ for your particular unit.

NOTE Follow engine owner's manual for engine

maintenance schedules and procedures.

NOTE Any service operations not included in this section should be performed by an authorized

service representative.

#### ROUTINE MAINTENANCE SCHEDULE

Daily or Before **Each Operation** 

- Check lubricant level. Fill as needed.
- Drain receiver tank condensate. Open the manual drain valve and collect and dispose of condensate accordingly.
- Check for unusual noise and vibration.
- Ensure and covers are securely in place.
- Ensure area around compressor is free from rags, tools, debris, and flammable or explosive materials.

Weekly

Inspect air filter element. Clean or replace if necessary.

Monthly

- Inspect for air leaks. Squirt soapy water around joints during compressor operation and watch for bubbles.
- Check tightness of screws and bolts. Tighten as needed.
- Clean exterior.

3/500 \*


Change petroleum lubricant while crankcase is warm.

12/2000 \*

- Change synthetic lubricant while crankcase is warm.
- Replace filter element.

#### FILTER REPLACEMENT \_


- 1. Unscrew and remove the wing nut (A).
- Remove the filter cover (B) and element (C) from the base (D).
- Install a new element and reassemble the filter assembly.



Filter Replacement

#### **COMPRESSOR PUMP OIL CHANGE**

- 1. Remove the oil drain plug (A) and allow the lubricant to drain into a suitable container.
- Replace the oil drain plug.
- Follow the filling procedures in PREPARATION FOR USE section



Compressor Pump Oil Change

#### BELT ADJUSTMENT


CHECKING BELT TENSION Check belt tension occasionally, especially if looseness is suspected. A quick check to determine if adjustment is proper may be made by observing the slack side of the belt for a slight bow when the unit is in operation. If a slight bow is evident, the belt is usually adjusted satisfactorily.

TENSIONING BELTS Belt tensioning can be achieved by loosening the motor anchor screws, pushing the motor away from the pump, and retightening the motor anchor screws. The motor can be easily moved by placing a prying tool beneath it. A commercially available spreader or other belt tensioning device can also be helpful should tensioning be necessary.

Follow the procedures outlined below to correctly set and measure belt tension.

- 1. Lay a straight edge across the top outer surface of the belt drive from pulley to sheave.
- At the center of the span, perpendicular to the belt, apply pressure to the outer surface of the belt with a tension gauge. Force the belt to the deflection indicated in the table at right. Compare the reading on the tension gauge to the table below.

Deflection in Inches	Min. Tension (Lbs.)	Max. Tension (Lbs.)
0.17	3.0	6.0



http://air.irco.com P1.5IU-A9

<sup>\*</sup> indicates months/operating hours, whichever occurs first.

Ensure the pulley and sheave are properly aligned and the motor anchor screws are adequately retightened prior to restarting the compressor.

#### **△** CAUTION

Improper pulley/sheave alignment and belt tension can result in motor overload, excessive vibration, and premature belt and/or bearing failure.

To prevent these problems from occurring, ensure the pulley and sheave are aligned and belt tension is satisfactory after installing new belts or tensioning existing belts.

#### TANK INSPECTION

The life of an air receiver tank is dependent upon several factors including, but not limited to, operating conditions, ambient

environments, and the level of maintenance. The exact effect of these factors on tank life is difficult to predict; therefore, Ingersoll Rand recommends that you schedule a certified tank inspection within the first five years of compressor service. To arrange a tank inspection, contact the nearest Ingersoll Rand Customer Center or distributor, or call 1-800-AIR SERV.

If the tank has not been inspected within the first 10 years of compressor service, the receiver must be taken out of service until it has passed inspection. Tanks that fail to meet requirements must be replaced.

 $\triangle$  WARNING Failure to replace a rusted air receiver tank could result in air receiver tank rupture or explosion, which could cause substantial property damage, severe personal injury, or death. Never modify or repair tank. Obtain replacement from service center.

http://air.irco.com P1.5IU-A9

#### **TROUBLESHOOTING PROBLEM** POSSIBLE CAUSE POSSIBLE SOLUTION Abnormal piston, ring or cylinder 1. Lubricant viscosity too low. 1. Drain existing lubricant and refill with proper lubricant. Lubricant level too low. Add lubricant to crankcase to proper level. wear Detergent type lubricant being used. Drain existing lubricant and refill with proper lubricant. Cylinder(s) or piston(s) scratched, worn or scored. Repair or replace as required. Extremely dusty atmosphere. Install remote air inlet piping and route to source of 6. Worn cylinder finish. cleaner air. Install more effective filtration. Deglaze cylinder with 180 grit flex-hone 1. Clean or replace. 1. Clogged or dirty inlet and/or discharge line filter. Air delivery drops off Air leaks in air discharge piping. Check tubing and connections. 3. Lubricant viscosity too high. Drain existing lubricant and refill with proper lubricant. Compressor valves leaky, broken, carbonized or loose. Inspect valves. Clean or replace as required. Install valve Piston rings damaged or worn (broken, rough or kit. scratched). Excessive end gap or side clearance. 5. Install ring kit Piston rings not seated, are stuck in grooves or end gaps Adjust piston rings. 6. not staggered. Repair or replace as required. 7. Cylinder(s) or piston(s) scratched, worn or scored. 8. Replace. 8. Defective safety/relief valve Unit does not come up to speed 1. Loose beltwheel or motor pulley, excessive end play in 1. Check beltwheel, motor pulley, crankshaft, drive belt motor shaft or loose drive belts. tension and alignment. Repair or replace as required. Lubricant viscosity too high. Drain existing lubricant and refill with proper lubricant. Check line voltage and upgrade lines as required. 3. Improper line voltage. Compressor valves leaky, broken, carbonized or loose. Contact electrician. 5. Defective ball bearings on crankshaft or motor shaft. Inspect valves. Clean or replace as required. Install valve kit. 5. Inspect bearings and replace crankshaft assembly if required. Unit is slow to come up to speed 1. Lubricant viscosity too high. Drain existing lubricant and refill with proper lubricant. 2. Leaking check valve or check valve seat blown out. Replace check valve. 3. Ambient temperature too low. Relocate unit to warmer environment. 4. Bad motor. Install crankcase heater kit. Replace. Unit runs excessively hot 1. Inadequate ventilation around beltwheel. 1. Relocate unit for better air flow. 2. Drive belts too tight or misaligned. Adjust belts to proper tension and alignment. 3. Compressor valves leaky, broken, carbonized or loose. Inspect valves. Clean or replace as required. Install valve 4. Wrong beltwheel direction of rotation. 4. Check motor wiring for proper connections. Reverse two leads on three-phase motors. Excessive noise during 1. Loose beltwheel or motor pulley, excessive end play in Check beltwheel, motor pulley, crankshaft, drive belt motor shaft or loose drive belts. tension and alignment. Repair or replace as required. operation Lubricant viscosity too high. Drain existing lubricant and refill with proper lubricant. 3. Lubricant level too low. Add lubricant to crankcase to proper level. Compressor valves leaky, broken, carbonized or loose. Inspect valves. Clean or replace as required. 5. Carbon build-up on top of piston(s). Install valve kit. Defective ball bearings on crankshaft or motor shaft. Clean piston(s). Repair or replace as required. Leaking check valve or check valve seat blown out. Inspect bearings and replace crankshaft assembly if required Replace check valve. Excessive starting and stopping 1. Air leaks in air discharge piping. 1. Check tubing and connections. 2. Pressure switch differential too narrow. Adjust pressure switch to increase differential, if 3. Leaking check valve or check valve seat blown out. differential adjustment is provided. Install pressure switch 4. Excessive condensate in receiver tank. with differential adjustment feature if differential adjustment is desired. 3. Replace check valve. Drain receiver tank with manual drain valve. High oil consumption 1. Clogged or dirty inlet and/or discharge line filter. Clean or replace. 2. Lubricant viscosity too low. Drain existing lubricant and refill with proper lubricant. Detergent type lubricant being used. Drain existing lubricant and refill with proper lubricant. 3. Piston rings damaged or worn (broken, rough or Install ring kit. 4. scratched). Excessive end gap or side clearance. 5. Adjust piston rings. Piston rings not seated, are stuck in grooves or end gaps 6. Repair or replace as required. not staggered. Inspect all. Repair or replace as required. 7. Cylinder(s) or piston(s) scratched, worn or scored. Replace seal or crankshaft assembly. Deglaze cylinder with 180 grit flex-hone. Connecting rod, piston pin or crankpin bearings worn or scored. 8. Crankshaft seal worn or crankshaft scored. 9. Worn cylinder finish 1. Check beltwheel, motor pulley, crankshaft, drive belt Knocking or rattling 1. Loose beltwheel or motor pulley, excessive end play in motor shaft or loose drive belts. tension and alignment. Repair or replace as required. Compressor valves leaky, broken, carbonized or loose. Inspect valves. Clean or replace as required. 3. Carbon build-up on top of piston(s). Install valve kit. Clean piston(s). Repair or replace as required. Cylinder(s) or piston(s) scratched, worn or scored. Repair or replace as required. Connecting rod, piston pin or crankpin bearings worn or

http://air.irco.com P1.5IU-A9

Defective ball bearings on crankshaft or motor shaft.


Inspect all. Repair or replace as required.

Inspect bearings and replace crankshaft assembly if

scored

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
Lights flicker or dim when running	<ol> <li>Improper line voltage.</li> <li>Wiring or electric service panel too small.</li> <li>Poor contact on motor terminals or starter connections.</li> <li>Improper starter overload heaters.</li> <li>Poor power regulation (unbalanced line).</li> </ol>	<ol> <li>Check line voltage and upgrade lines as required. Contact electrician.</li> <li>Install properly sized wire or service box. Contact electrician.</li> <li>Ensure good contact on motor terminals or starter connections.</li> <li>Install proper starter overload heaters. Contact electrician.</li> <li>Contact power company.</li> </ol>
Moisture in crankcase or "milky" appearance in petroleum lubricant or rusting in cylinders	<ol> <li>Detergent type lubricant being used.</li> <li>Extremely light duty cycles.</li> <li>Unit located in damp or humid location.</li> </ol>	<ol> <li>Drain existing lubricant and refill with proper lubricant.</li> <li>Run unit for longer duty cycles.</li> <li>Relocate unit.</li> </ol>
Motor overload trips or draws excessive current	<ol> <li>Lubricant viscosity too high.</li> <li>Improper line voltage.</li> <li>Wiring or electric service panel too small.</li> <li>Poor contact on motor terminals or starter connections.</li> <li>Improper starter overload heaters.</li> <li>Poor power regulation (unbalanced line).</li> <li>Drive belts too tight or misaligned.</li> <li>Compressor valves leaky, broken, carbonized or loose.</li> <li>Cylinder(s) or piston(s) scratched, worn or scored.</li> <li>Connecting rod, piston pin or crankpin bearings worn or scored.</li> <li>Defective ball bearings on crankshaft or motor shaft.</li> <li>Leaking check valve or check valve seat blown out.</li> <li>Ambient temperature too low.</li> <li>Bad motor.</li> </ol>	<ol> <li>Drain existing lubricant and refill with proper lubricant.</li> <li>Check line voltage and upgrade lines as required. Contact electrician.</li> <li>Install properly sized wire or service box. Contact electrician.</li> <li>Ensure good contact on motor terminals or starter connections.</li> <li>Install proper starter overload heaters. Contact electrician.</li> <li>Contact power company.</li> <li>Adjust belts to proper tension and alignment.</li> <li>Inspect valves. Clean or replace as required. Install valve kit.</li> <li>Repair or replace as required.</li> <li>Inspect all. Repair or replace as required.</li> <li>Inspect bearings and replace crankshaft assembly if required.</li> <li>Replace check valve.</li> <li>Relocate unit to warmer environment. Install crankcase heater kit. Convert to synthetic lubricant.</li> <li>Replace</li> </ol>
Motor will not start	<ol> <li>Improper line voltage.</li> <li>Wiring or electric service panel too small.</li> <li>Poor contact on motor terminals or starter connections.</li> <li>Improper starter overload heaters.</li> <li>Bad motor.</li> </ol>	<ol> <li>Check line voltage and upgrade lines as required. Contact electrician.</li> <li>Install properly sized wire or service box. Contact electrician.</li> <li>Ensure good contact on motor terminals or starter connections.</li> <li>Install proper starter overload heaters. Contact electrician.</li> <li>Replace</li> </ol>
Oil in discharge air (oil pumping)	<ol> <li>Lubricant viscosity too low.</li> <li>Detergent type lubricant being used.</li> <li>Piston rings damaged or worn (broken, rough or scratched). Excessive end gap or side clearance.</li> <li>Piston rings not seated, are stuck in grooves or end gaps not staggered.</li> <li>Cylinder(s) or piston(s) scratched, worn or scored.</li> <li>Worn cylinder finish.</li> <li>Excessive condensate in receiver tank.</li> </ol>	<ol> <li>Drain existing lubricant and refill with proper lubricant.</li> <li>Drain existing lubricant and refill with proper lubricant.</li> <li>Install ring kit.</li> <li>Adjust piston rings.</li> </ol>
Oil leaking from shaft seal	Crankshaft seal worn or crankshaft scored.	Replace seal or crankshaft assembly.
Safety/relief valve "pops"	<ol> <li>Clogged or dirty inlet and/or discharge line filter.</li> <li>Compressor valves leaky, broken, carbonized or loose.</li> <li>Defective safety/relief valve.</li> </ol>	<ol> <li>Clean or replace.</li> <li>Inspect valves. Clean or replace as required. Install valve kit.</li> <li>Replace</li> </ol>

http://air.irco.com P1.5IU-A9



# PUMP COMPONENTS

REF.	PART NO.	DESCRIPTION	QTY.	REF.
_	23191851	HEAD - CYLINDER	2	_
2	23191869	SET - ALLEN BOLT	8	2
3	23191877	SET - IN. & EX. VALVE	2	3
4	23191885	SET - DOUBLE HEAD SCREW	8	4
5	23191893	CYLINDER	2	2
9	23191901	GASKET - CYLINDER	2	9
7	23191919	SET - PISTON RING	2	7
8	23191927	SET - PISTON	2	80
6	23191935	SET - ROD	2	6
10	23191943	CRANKCASE	_	10
11	23191950	PLUG - OIL DRAINING	_	7
12	23191968	SET - OIL SIGHT GAUGE	_	12
13	23191976	SET - OIL FILLING PLUG	_	13
14	23191984	BEARING	_	14
15	23191992	CRANKSHAFT & BALANCER	_	15
16	23192008	BEARING	_	16
17	23192016	GASKET - REAR BEARING SEAT	_	17
18	23192024	SEAL - OIL	_	18
19	23192032	SEAT - REAR BEARING	_	19
20	23194442	COVER - BREATHING	_	20
21	23192057	BOLT - HEXAGON	4	21
22	23192065	PULLEY	_	22
23	23192073	WASHER - PLATE	_	23
24	23192081	SET - HEXAGON BOLT	_	24
25	23192099	ELBOW - EXHAUST	_	25
26	23192107	PIPE - THREE WAY EXHAUST	_	26
27	23192115	SET - EXHAUST TUBE	_	27
28	23192123	SET - AIR FILTER	2	28
29	23192131	ELEMENT - FILTER	2	29
30	23192149	VALVE - PRESSURE RELIEF	-	30
31	23192040	GASKET - CYLINDER HEAD	2	31
32	23213044	ASSEMBLY - IN. & EX. VALVE	2	32
33	23213051	GASKET - VALVE SEAT	2	33

# RECEIVER TANK COMPONENTS

<b>}</b> :	REF.	PART NO.	DESCRIPTION	QTY.
	_	23192305	TANK - AIR	7
~	2	23192313	VALVE - BALL	_
	3	23192321	BOLT - TANK WHEEL	2
	4	23192339	WHEEL - TANK	2
-	2	23192347	SET - RUBBER PAD	2
	9	23192354	GRIP	1
	7	23192362	BUSHING	1
	8	23192370	VALVE - CHECK	1
	6	23192388	ELBOW - UNLOADING	1
	10	23192396	TUBE - UNLOADING	7
	7	23192404	SET - EXHAUST TUBE	_
	12	23192412	PULLEY - MOTOR	_
	13	23192420	BOLT - ALLEN	2
	14	23192438	BELT - V	_
	15	23192446	SET - HEXAGON BOLT	4
	16	23192453	GUARD - BELT	_
	17	23192461	BRACKET	_
	18	23192479	SET - HEXAGON BOLT	9
	19	23192487	SWITCH - PRESSURE	_
	20	23192495	VALVE - PRESSURE RELIEF	_
	21	23192503	GAUGE - PRESSURE	1
	22	23192511	NIPPLE	1
	23	23192529	REGULATOR	1
	24	23192537	GAUGE - PRESSURE	_
	25	23192545	COUPLER - QUICK	_
	26	23192552	CABLE	_
	27	23192560	CABLE - POWER	_
	28	23192578	SET - MOTOR FEET BOLT	4
	29	23192586	SET - HEXAGON BOLT	4
	30	23192594	MOTOR	_
	31	23244411	BUSHING - STRAIN RELIEF	_
	32	23244429	BUSHING - STRAIN RELIEF	_
	33	23244437	BUSHING - STRAIN RELIEF	_
	34	23244445	BRACKET	7

# NOTE: FOR COMPLETE PUMP ORDER PART NO. 42660597

# REPAIR KITS \_\_\_\_\_

DESCRIPTION	PART NO.	KIT CONTENTS
START UP AND	42661561	(1) LITER OF OIL — PART NO. 38436721
MAINTENANCE KIT		(2) INLET FILTER COMPLETE — PART NO. 70243399
GASKET KIT	42665463	(2) CYLINDER GASKET — PART NO. 23191901
		(1) REAR BEARING SEAT GASKET — PART NO. 23192016
		(2) CYLINDER HEAD GASKET — PART NO. 23192040
		(2) VALVE SEAT GASKET — PART NO. 23213051
COMPLETE PUMP	42660597	ALL PARTS IN "PUMP COMPONENTS" ILLUSTRATION, COMPLETELY ASSEMBLED.
VALVE KIT	23191877	(2) CYLINDER HEAD GASKETS — PART NO. 23192040
		(2) IN. & EX. VALVE ASSEMBLY — PART NO. 23213044
		(2) VALVE SEAT GASKETS — PART NO. 23213051
PISTON RING KIT	42665950	(2) CYLINDER GASKETS — PART NO. 23191901
		(2) PISTON RING SETS — PART NO. 23191919

http://air.irco.com P1.5IU-A9

#### WARRANTY

Ingersoll-Rand Company warrants that the Equipment manufactured by it and delivered hereunder shall be free of defects in material and workmanship for a period of twelve (12) months from the date of delivery to the customer. Should any failure to conform to this Warranty be reported in writing to the Company within said period, the Company shall, at its option, correct such nonconformity by suitable repair to such Equipment, or furnish a replacement part F.O.B. point of shipment, provided the purchaser has installed, maintained and operated such equipment in accordance with good industry practices and has complied with specific recommendations of the Company. Accessories or equipment furnished by the Company, but manufactured by others, shall carry whatever warranty the manufacturer conveyed to Ingersoll-Rand Company and which can be passed on to the Purchaser. The Company shall not be liable for any repairs, replacements, or adjustments to the Equipment or any costs of labor performed by the Purchaser without the Company's prior written approval.

The Company makes no performance warranty unless specifically stated within its proposal and the effects of corrosion, erosion and normal wear and tear are specifically excluded from the Company's Warranty. In the event performance warranties are expressly included, the Company's obligation shall be to correct in the manner and for the period of time provided above.

THE COMPANY MAKES NO OTHER WARRANTY OF REPRESENTATION OF ANY KIND WHATSOEVER, EXPRESSED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY DISCLAIMED.

Correction by the Company of nonconformities, whether patent or latent, in the manner and for the period of time provided above, shall constitute fulfillment of all liabilities of the Company and its Distributors for such nonconformities with respect to or arising out of such Equipment.

#### LIMITATION OF LIABILITY

THE REMEDIES OF THE PURCHASER SET FORTH HEREIN ARE EXCLUSIVE, AND THE TOTAL LIABILITY OF THE COMPANY, ITS DISTRIBUTORS AND SUPPLIERS WITH RESPECT TO CONTRACT OR THE EQUIPMENT AND SERVICES FURNISHED, IN CONNECTION WITH THE PERFORMANCE OR BREACH THEREOF, OR FROM THE MANUFACTURE, SALE, DELIVERY, INSTALLATION, REPAIR OR TECHNICAL DIRECTION COVERED BY OR FURNISHED UNDER CONTRACT, WHETHER BASED ON CONTRACT, WARRANTY, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE SHALL NOT EXCEED THE PURCHASE PRICE OF THE UNIT OF EQUIPMENT UPON WHICH SUCH LIABILITY IS BASED.

THE COMPANY, ITS DISTRIBUTORS AND ITS SUPPLIERS SHALL IN NO EVENT BE LIABLE TO THE PURCHASER, ANY SUCCESSORS IN INTEREST OR ANY BENEFICIARY OR ASSIGNEE OF THE CONTRACT FOR ANY CONSEQUENTIAL, INCIDENTAL, INDIRECT, SPECIAL OR PUNITIVE DAMAGES ARISING OUT OF THIS CONTRACT OR ANY BREACH THEREOF, OR ANY DEFECT IN, OR FAILURE OF, OR MALFUNCTION OF THE EQUIPMENT, WHETHER OR NOT BASED UPON LOSS OF USE, LOSS PROFITS OR REVENUE, INTEREST, LOST GOODWILL, WORK STOPPAGE, IMPAIRMENT OF OTHER GOODS, LOSS BY REASON OF SHUTDOWN OR NON-OPERATION, INCREASED EXPENSES OF OPERATION, COST OF PURCHASE OF REPLACEMENT POWER, OR CLAIMS OF PURCHASER OR CUSTOMERS OF PURCHASER FOR SERVICE INTERRUPTION WHETHER OR NOT SUCH LOSS OR DAMAGE IS BASED ON CONTRACT, WARRANTY, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE.

Retain your receipt as proof of purchase in the event of a claim under warranty.


# Questions? Parts? Service? 1-800 AIR SERV


Visit our website: www.air.irco.com


http://air.irco.com P1.5IU-A9


#### **APPENDIX F**


PLC Input/Output/ Analog Wiring Drawings


















Op	eration,	Maintenance	and	Monitoring	(OM&M)	Manual

**APPENDIX G** 

LRPs 101/102 Information



www.travaini.com



www.travaini 🗘 com






Figure 1

Pump discharge Pump inlet

Figure 2




Figure 3

#### **Principle of Operation**

A multi-bladed impeller mounted on a shaft is positioned eccentrically in a cylindrical housing, partially filled with liquid. Portplates with inlet and discharge openings are positioned on each side of the impeller (Figure 1). As the impeller rotates, centrifugal force pushes the liquid outward, forming a liquid ring (Figure 2). Looking at the YELLOW area of the impeller chambers (Figure 3), we see that on the right hand side, from the top down, the chamber volume increases as the liquid ring moves outward, creating a vacuum in the impeller chamber. on the left hand side, the volume decreases as the liquid moves inward, increasing the pressure in the chambers until the discharge takes place through the discharge opening. A continuous flow of fresh sealing liquid is supplied to the pump.

#### **Seal Fluid Technology**

In our ongoing search for better solutions, we can offer alternative sealing fluids that are environmentally friendly. Unlike other types of vacuum pumps, our liquid ring design requires no internal lubrication because there is no metal to metal contact between rotating and stationary parts and the bearings are located external to the pumping chamber. This allows for more diversity when choosing the sealing fluid because the lubricating properties of the fluid are not critical.

The Travaini **DynaSeal**™ system offers a simple, low maintenance design with low noise and vibration levels, as well as reduced operating costs.

Count on Travaini for in-depth experience, technology and innovation. Our extensive inventory of pumps and replacement parts can, in most instances, be shipped the same day. Superior service is our #1 goal.

DynaSeal™, you can't beat the system.

# DynaSeal<sup>™</sup> Benefits

#### **DynaSeal™ Standard Specifications:**

≥ 15" Hg Vacuum; 60-120° F Ambient Temperatures; 180° F Inlet Gas Temperature Max; 180° F Discharge Gas/Oil Temperature; If conditions differ, consult factory for recommended design modifications.

200° F Inlet Gas – Consult factory.

#### **Capacity Range Standards**

15-1000 ACFM. Larger systems available **upon request**.

#### Low Noise Level.

Unlike rotary screw vacuum pumps, which run at rotor speeds as high as 9000-rpm, **DynaSeal™** systems operate at conservative speeds (1750-rpm) resulting in low noise levels (75-80 dBA at 3-ft.) acceptable to the environment without the need for sound enclosures.

#### Minimal Maintenance.

**DynaSeal™** systems typically only require an oil change and replacement of discharge filter every 10,000 hours under normal operating conditions. No other maintenance is required except for periodic greasing of bearings.

#### Not affected by carry-over of soft solids or liquids.

**DynaSeal™** systems can handle carry-over of soft solids and liquids without damage to the system components. We do however recommend to install an inlet filter/strainer or knock-out pot in those applications where a high carry-over of either solids or liquids is expected.

#### **Designed for continuous operation.**

**DynaSeal™** systems are designed for continuous operation over the full vacuum range without overheating.

#### **Automatic Temperature Control.**

Prevents low temperature operation, reduces accumulation of water and other liquids in the reservoir and decreases the risk of bacteria growth. This optional feature is very important in hospital and other intermittent duty applications.

#### Low Vibration.

**DynaSeal™** systems require no special foundations or anti-vibration mountings as a standard.

#### High-Quality Manufacturing Standards.

Travaini pumps are manufactured under ISO 9001 quality control standards.

#### **Quality Control**

**DynaSeal**<sup>™</sup> systems are a "proven design". Combine this with our inline quality procedures and outgoing inspection, this provides you with the leading quality in the industry.

#### **Custom Solutions**

**DynaSeal™** systems can be provided in single or multiple system configurations with programmable controllers to meet your specific requirements. Explosion proof designs for those stringent environments. Wide range of materials including stainless steel, copper, etc.

# **DynaSeal**<sup>™</sup>

# Air-cooled Liquid Ring Vacuum Systems



Made in the USA. DynaSeal™ systems are designed, built, and tested at our facility in Yorktown, Virginia.

# **Typical System Features & Options**

ADVANCED LIQUID RING VACUUM PUMP DESIGN Offers high efficiency, reliability and minimum maintenance. External bearings and ample clearance between rotating parts eliminate the need for internal lubrication.

2 ELECTRIC CONTROL PANEL Each system includes a NEMA 12 electrical control panel complete with magnetic starter and overload protection, 110-volt control circuit and hour meter as standard. Wiring to motor and control switches is completed at the factory.

HIGH TEMPERATURE SWITCH Shuts unit down at 225°F in case oil flow to unit is interrupted.

**BACK PRESSURE GAUGE** Shows condition of demister element and if element requires service. It also indicates back pressure from piping system.

**AIR/OIL SEPARATOR** Includes a highly efficient demister element to remove oil mist from discharge air. Exhaust is 99.9% oil-free.

OIL RESERVOIR Mounted overhead for positive oil flow pressure and sized for adequate oil capacity, cooling

14

and efficient separation by internal baffles. A sight gauge complete with temperature gauge is included.

7 INLET CHECK VALVE Properly sized and suitable for vacuum.

HIGH EFFICIENCY AIR-COOLED HEAT EXCHANGER Allows system to operate at moderate temperatures with ambient temperatures as high as 110°. Water-cooled units are available.

PUMP OR MOTOR-MOUNTED COOLING FAN Provides high air flow for maximum cooling without the need for a separate fan motor, except for units of 50-hp and larger which have electric-drive fan units.

**SOLENOID VALVE** Shuts down oil flow to pump when unit is stopped.

MONOBLOCK MOTOR MOUNTING DESIGN Standard up to 25-hp, eliminates misalignment problems by flange mounting to a standard NEMA C-face motor. (TEFC motors with a 1.15 service factor are standard) a heavy-duty flexible coupling ensures trouble-free service.

MANUAL UNLOADER VALVE WITH FILTER SILENCER Aids in vacuum unloading and/or relief of the pump prior to start-up and shutdown. (Electric unloading-optional)

VACUUM RELIEF VALVE WITH SILENCER (OPTIONAL) Field adjustable to control maximum vacuum level.

TEMPERATURE CONTROL VALVE (OPTIONAL) Allowing the system to reach operating temperature very quickly which is important especially for outdoor installations and intermittent duties.

15 HIGH AND LOW OIL LEVEL SWITCH (OPTIONAL) To protect pump from loss of oil.

**EXPLOSION PROOF DESIGN** (Optional)

# DynaSeal™ Systems are used extensively in industries such as:

- Hospitals, healthcare and pharmaceutical
- Solvent and vapor recovery
- Soil remediation
- Wood working and wood impregnation
- Electronics and semi-conductors
- Printing and paper converting
- Food and meat processing
- Plastics, automotive and aircraft
- Sterilization and impregnation
- Plus numerous others



# The "Mini" Series Models – TRO-075VM, TRO-110VM AND TRO-160VM



### **Latest concept of our patented DynaSeal™ System**

#### **Features:**

- Space Saving
- Vastly Improved Mist Elimination
- Cost Savings
- 3 Models Available

Using our 3 monoblock vari-ported pump designs, models TRM 40-110, 40-150, and 40-200, we offer these three systems, 5, 7.5, and 10 hp, configured to incorporate the above features.

The traditional oil sealed systems has a footprint almost twice the length and 50% wider than the "MINI" Series. By incorporating the monoblock pump design, we have developed the "MINI" package to fit within equipment or locations that require economies of space.

Traditional oil-sealed packages have been designed to handle vacuums beyond 15" HgV, as the majority of applications require. Below 15" HgV, the coalescing filters are not designed to fully handle the oil mist. The new "MINI" Series was designed to coalesce from o-30" Hg vacuum through our unique filter element and specially formulated synthetic oil.

The simplicity of the "MINI" design has resulted in reduced costs which allow us to pass the savings on to you, our customers. Cost is always a priority without sacrificing the quality you've come to expect from Travaini products.

# **Standard DynaSeal<sup>™</sup> Models**

System Model	Nominal Capacity ACFM	Motor HP	Maximum End Vacuum in. Hg	Approximate Dimensions (in) L x W x H	Approximate Weight (Lbs)
TRO015H	15	2	29	38 x 17 x 40	340
TRO015S	15	1.5	26	38 x 17 x 40	340
TRO035S	35	3	26	38 x 17 x 40	340
TROo35H	35	3	29	38 x 17 x 40	340
TROo5oH	50	5	29.5	38 x 17 x 40	435
TRO075S	75	5	27	43 X 17 X 40	530
TROo75-VM**	75	5	29	32 X 25 X 43	500
TRO110V	110	7.5	29.5	55 X 25 X 51	920
TRO110-VM**	110	7.5	29	32 X 25 X 43	540
TRO140H	140	10	29.5	55 X 25 X 51	1005
TRO160V	160	10	29.5	65 x 26 x 51	1070
TRO160-VM**	160	10	29	32 X 25 X 43	570
TRO200V	200	15	29.5	65 x 26 x 56	1300
TRO200H	200	15	29.5	65 x 26 x 56	1325
TRO250H	250	20	29.5	65 x 26 x 56	1350
TRO300V	300	20	29.5	65 x 26 x 56	1355
TRO300H	300	25	29.5	65 x 26 x 56	1430
TRO400S	380	25	28	83 x 35 x 64	1900
TRO425H	425	40	29.5	83 x 35 X 64	2250
TRO500S	500	40	28	83 x 35 x 64	2150
TRO700S*	700	50	26	80 X 63 X 58	3550
TRO750H*	750	50	29.5	80 X 63 X 58	3750
TRO900S*	900	60	26	80 X 63 X 58	3650
TRO950H*	950	60	29.5	80 X 63 X 58	4016
TRO1000S*	1000	75	26	80 X 63 X 58	3750
TRO1000H*	1050	100	29.5	80 X 63 X 58	4302

<sup>\*\*</sup>VM = Mini Series

#### **DynaSeal**<sup>™</sup> **Standard Specifications:**

≥ 15" Hg Vacuum; 60-120° F Ambient Temperatures; 180° F Inlet Gas Temperature Max; 180° F Discharge Gas/Oil Temperature; If conditions differ, consult factory for recommended design modifications.

#### • Explosion proof designs are available upon request.

- Larger capacity systems are available upon request.
- **DynaSeal**™ systems are available in multiple pump configurations with a wide range of optional accessories.
- **DynaSeal™** systems can be customized per O.E.M. specification and for special applications.
- **DynaSeal™** systems are sold and serviced through a nation-wide distributor network.

<sup>\*</sup>PUMPS ARE V-belt driven.



#### WARRANTY

#### TRAVAINI PUMPS USA

Subject to the terms and conditions hereof, Travaini Pumps U.S.A., Inc. (hereafter referred to as the "Company") warrants that the products and parts of its manufacture specified below, when shipped, and its services when performed, will be free from defects in material and workmanship for following warranty time periods:

PRODUCT DESCRIPTION	WARRANTY PERIOD FROM DATE OF SHIPMENT
Liquid Ring Vacuum Pump system or pump products	Two (2) years
Rotary vane system or pump products	24 / 18 months if TPUSA oil used / not used
Centrifugal pump products	18 months, or 12 months from date of installation, whichever occurs first
Mechanical seals	3 months
Repaired pumps / systems	6 months for the repair / work performed

This Warranty shall apply to liquid ring vacuum products only if they are operated with Company approved seal fluids and to rotary vane products only if they are operated with Company approved lubricants. In-warranty repaired or replaced products are warranted only for the remaining unexpired portion of the warranty period applicable to the repaired or replaced product(s).

This Warranty does not extend to equipment such as electric motors, starters, heat exchangers and other accessories furnished to the Company by third party manufacturers and/or suppliers. Said accessories are warranted only to the extent of any warranty extended to the Company by such third party manufacturers and/or suppliers. Replacement of maintenance items, including, in particular, seals, bearings, filters, etc. supplied in connection with standard maintenance service provided by the Company are not covered by this Warranty. Any technical assistance, advice, or comments provided by the Company regarding system components, other than those manufactured by the Company, are not covered under this Warranty; the Company disclaims any liability in connection with same. The Company disclaims any liability in connection with the malfunctioning of any system(s) or component(s) of system(s) which conform to designs, specifications and/or instructions mandated by purchasers.

This Warranty is limited exclusively to products and/or parts of the Company properly installed, serviced and maintained in full compliance with the Operating and Maintenance manual of the Company. This Warranty shall not extend to products and/or parts which

have been misused or neglected or not used for the purpose(s) for which they were intended, including, in particular, products operated at/in excessive temperature or dirty environments, products used in conjunction with corrosive, erosive or explosive liquids or gasses, and/or products malfunctioning as a result of build-up of material in the internal parts thereof. Products which are disassembled without the prior written consent of the Company and/or which are repaired, modified, altered or otherwise tampered with in any manner inconsistent with the Operating and Maintenance manual of the Company are not covered under this Warranty. Products and/or parts which are kept in "long term" storage, as such terms are defined in the Operations & Maintenance manual of the Company, and not maintained in accordance with Company long term care procedures specified by the Company are not covered under this Warranty.

Warranty claims must be made within the warranty period specified above for each of the Company's products and services and include the serial number thereof. The Company's obligations under this Warranty are limited, in the Company's sole discretion, to repair, replacement or refund of the purchase price received by the Company for the product, part or service. Notwithstanding the foregoing, the Company shall have the option to provide alternative solutions of a different design. In no event shall the purchaser and/or any subsequent owner or beneficiary of the products, parts and/or services be entitled to recover incidental, special or consequential damages arising out of the breach of this Warranty or any defect, failure or malfunction of the products and/or services supplied by the Company.

A written return authorization must be obtained from the Company prior to the return of any product and/or part under this Warranty. Products and parts are to be returned only to the Company's facilities or such facilities as the Company may designate in writing. Costs of uninstalling/ reinstalling the product and/or any part under Warranty, as well as all costs associated with the shipment thereof to and from the facilities of the Company shall be at the owner's sole expense.

THIS WARRANTY AND THE COMPANY'S OBLIGATIONS HEREUNDER ARE EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. ALL WARRANTIES WHICH EXCEED THE AFOREMENTIONED OBLIGATIONS ARE HEREBY DISCLAIMED BY THE COMPANY AND EXCLUDED FROM THIS WARRANTY, WHETHER BASED ON CONTRACT, WARRANTY, NEGLIGENCE, INDEMNITY, STRICT LIABILITY OR OTHERWISE. NO EMPLOYEE OF THE COMPANY OR OTHER PERSON IS AUTHORIZED TO GIVE ANY OTHER WARRANTY OR TO ASSUME ANY OTHER LIABILITY ON THE COMPANY'S BEHALF.

Effective as of January 2007

<b>Operat</b>	ion, Ma	aintenance	and M	Ionitori	ng (	OM&M)	Manual


**APPENDIX H** 

Air Flow Meter/Transmitter Information



# **In-Line Flow Sensors**

#### Use with the Dwyer® Differential Pressure Gages or Transmitters



In-Line Flow Sensors are averaging Pitot tubes that provide accurate and convenient flow rate sensing for schedule 40 pipe. When purchased with a Dwyer® Capsuhelic® differential pressure gage of appropriate range, the result is a flow indicating system delivered off the shelf at an economical price. Pitot tubes have been used in flow measurement for years. Conventional pitot tubes sense velocity pressure at only one point in the flowing stream. Therefore, a series of measurements must be taken across the stream to obtain a meaningful average flow rate. The Dwyer® flow sensor eliminates the need for "traversing" the flowing stream because of its multiple sensing points and builtin averaging capability.

The Series DS-300 flow sensors are designed to be inserted in the pipeline through a compression fitting. They are furnished with instrument shut-off valves on both pressure connections. Valves are fitted with 1/8" female NPT connections. Accessories include adapters with 1/4" SAE 45° flared ends compatible with hoses supplied with the Model A-471 Portable Capsuhelic® gage kit. Standard valves are rated at 200 psig (13.7 bar) and 200°F (93.3°C). Where valves are not required, they can be omitted at reduced cost. Series DS-300 flow sensors are available for pipe sizes from 1  $^{\prime\prime}$  to 10  $^{\prime\prime}$ .

 $\textbf{DS-400 Averaging Flow Sensors} \ {\rm are \ quality \ constructed \ from \ extra \ strong}$ 3/4" dia. stainless steel to resist increased forces encountered at higher flow rates with both air and water. This extra strength also allows them to be made in longer insertion lengths up to 24 inches (61 cm). All models include convenient and quick-acting quarter-turn ball valves to isolate the sensor for zeroing. Process connections to the valve assembly are 1/8" female NPT. A pair of  $1/8\,^{\prime\prime}$  NPT X  $1/4\,^{\prime\prime}$  SAE  $45^{\circ}$  flared adapters are included, compatible with hoses used in the Model A-471 Portable Capsuhelic® Gage Kit. Supplied solid brass mounting adapter has a 3/4" dia. compression fitting to lock in required insertion length and a 3/4" male NPT thread for mounting in a Threaded Branch Connection.

Select model with suffix which matches pipe size

Model DS-300-1"

Model DS-300-1-1/4"

Model DS-300-1-1/2"

Model DS-300-2"

Model DS-300-2-1/2"

Model DS-300-3"

Model DS-300-47

Model DS-300-6"

Model DS-300-8"

Model DS-300-10"

Model DS-400-6"

Model DS-400-8" Model DS-400-10"

Model DS-400-12"

Model DS-400-14"

Model DS-400-16"

Model DS-400-18"

Model DS-400-20"

Model DS-400-24"

#### **OPTIONS & ACCESSORIES**

DS-300 or DS-400 Less Valves. To order, add suffix -LV A-160, Threaded Branch Connection, 3/8" NPT, forged steel, 3000 psi A-161, Brass Bushing, 1/4" x 3/8"


#### How To Order

Merely determine the pipe size into which the flow sensor will be mounted and designate the size as a suffix to Model DS-300. For example, a flow sensor to be mounted in a 2" pipe would be a Model No. DS-300-2".

For non-critical water and air flow monitoring applications, the chart below can be utilized for ordering a stock Capsuhelic® differential pressure gage for use with the DS-300 flow sensor. Simply locate the maximum flow rate for the media being measured under the appropriate pipe size and read the Capsuhelic® gage range in inches of water column to the left. The DS-300 sensor is supplied with installation and operating instructions, Bulletin F-50. It also includes complete flow conversion information for the three media conditions shown in the chart below. This information enables the user to create a complete differential pressure to flow rate conversion table for the sensor and differential pressure gage employed. Both the Dwyer® Capsuhelic® gage and flow sensor feature excellent repeatability so, once the desired flow rate is determined, deviation from that flow in quantitative measure can be easily determined. You may wish to order the adjustable signal flag option for the Capsuhelic® gage to provide an easily identified reference point for the proper flow.

Capsuhelic® gages with special ranges and/or direct reading scales in appropriate flow units are available on special order for more critical applications. Customer supplied data for the full scale flow (quantity and units) is required along with the differential pressure reading at that full flow figure. Prior to ordering a special Capsuhelic® differential pressure gage for flow read-out, we recommend you request Bulletin F-50 to obtain complete data on converting flow rates of various media to the sensor differential pressure output. With this bulletin and after making a few simple calculations, the exact range gage required can easily be determined.

# Large 3/4 Inch Diameter for Extra Strength in Lengths to 24 Inches



Gage Range	Media		F	ull Rai	nge Flov	vs by P	ipe Siz	e (Ap	oroxima	ite)	
(in w.c.)	@ 70°F	1″	1-1/4"	1-1/2"	2″	2-1/2"	3″	4"	6″	8″	10"
2	Water (GPM)	4.8	8.3	11.5	20.5	30	49	86	205	350	560
	Air @ 14.7 PSIA (SCFM)	19.0	33.0	42.0	65.0	113	183	330	760	1340	2130
	Air @ 100 PSIG (SCFM)	50.0	90.5	120.0	210.0	325	510	920	2050	3600	6000
5	Water (GPM)	7.7	14.0	18.0	34.0	47	78	138	320	560	890
	Air @ 14.7 PSIA (SCFM)	30.0	51.0	66.0	118.0	178	289	510	1200	2150	3400
	Air @ 100 PSIG (SCFM)	83.0	142.0	190.0	340.0	610	820	1600	3300	5700	10000
10	Water (GPM)	11.0	19.0	25.5	45.5	67	110	195	450	800	1260
	Air @ 14.7 PSIA (SCFM)	41.0	72.0	93.0	163.0	250	410	725	1690	3040	4860
	Air @ 100 PSIG (SCFM)	120.0	205.0	275.0	470.0	740	1100	2000	4600	8100	15000
25	Water (GPM)	18.0	32.0	40.5	72.0	108	173	310	720	1250	2000
	Air @ 14.7 PSIA (SCFM)	63.0	112.0	155.0	255.0	390	640	1130	2630	4860	7700
	Air @ 100 PSIG (SCFM)	185.0	325.0	430.0	760.0	1200	1800	3300	7200	13000	22000
50	Water (GPM)	25.0	44.0	57.5	100.0	152	247	435	1000	1800	
	Air @ 14.7 PSIA (SCFM)	90.0	161.0	205.0	360.0	560	900	1600	3700	6400	
	Air @ 100 PSIG (SCFM)	260.0	460.0	620.0	1050.0	1700	2600	4600	10000	18500	
100	Water (GPM)	36.5	62.0	82.0	142.0	220	350	620	1500		
	Air @ 14.7 PSIA (SCFM)	135.0	230.0	300.0	505.0	800	1290	2290	5000		
	Air @ 100 PSIG (SCFM)	370.0	660.0	870.0	1500.0	2300	3600	6500	15000		

#### Model A-471 Portable Kit

The Dwyer® Series 4000 Capsuhelic® differential pressure gage is ideally suited for use as a read-out device with the DS-300 Flow Sensors. The gage may be used on system pressures of up to 500 psig even when the flow sensor differential pressure to be read is less than  $0.5\,^{\circ}$  w.c. With accuracy of  $\pm 3\%$  of full scale, the Capsuhelic® gage can be used in ambient temperatures from 32 to 200°F (0 to 93.3°C). Zero and range adjustments are made from outside the gage. The standard gage with a die cast aluminum housing can be used with the flow sensor for air or oil applications. For water flow measurements, the optional forged brass housing should be specified. The Capsuhelic® gage may be panel or surface mounted and permanently plumbed to the flow sensor if desired. The optional A-610 pipe mounting bracket allows the gage to be easily attached to any  $1-1/4\,^{\circ}$ -  $2\,^{\circ}$  horizontal or vertical pipe.

For portable operation, the A-471 Capsuhelic® Portable Gage Kit is available complete with tough polypropylene carrying case, mounting bracket, 3-way manifold valve, two 10' high pressure hoses, and all necessary fittings. See pages 10 and 11 for semplets information and the

See pages 10 and 11 for complete information on the Capsuhelic® gage



#### Series DS-300 Flow Sensors



#### Installation and Operating Instructions Flow Calculations




Series DS-300 Flow Sensors are averaging pitot tubes that provide accurate, convenient flow rate sensing. When purchased with a Dwyer Capsuhelic® for liquid flow or Magnehelic® for air flow, differential pressure gage of appropriate range, the result is a flow-indicating system delivered off the shelf at an economical price. Series DS-300 Flow Sensors are designed to be inserted in the pipeline through a compression fitting and are furnished with instrument shut-off valves on both pressure connections. Valves are fitted with 1/8" female NPT connections. Accessories include adapters with 1/4" SAE 45° flared ends compatible with hoses supplied with the Model A-471 Portable Capsuhelic® kit. Standard valves are rated at 200°F (93.3°C). Where valves are not required, they can be omitted at reduced cost. Series DS-300 Flow Sensors are available for pipe sizes from 1" to 10".

#### **INSPECTION**

Inspect sensor upon receipt of shipment to be certain it is as ordered and not damaged. If damaged, contact carrier.

#### **INSTALLATION**

**General -** The sensing ports of the flow sensor must be correctly positioned for measurement accuracy. The instrument connections on the sensor indicate correct positioning. The side connection is for total or high pressure and should be pointed upstream. The top connection is for static or low pressure.



**Location -** The sensor should be installed in the flowing line with as much straight run of pipe upstream as possible. A rule of thumb is to allow 10 - 15 pipe diameters upstream and 5 downstream. The table below lists recommended up and down piping.

#### PRESSURE AND TEMPERATURE

Maximum: 200 psig (13.78 bar) at 200°F (93.3°C).

		stream Dimen Diameter of P	
Hardwar Oan Pilan			er of Straight Pipe
Upstream Condition	In-Plane	Out of Plane	Downstream
One Elbow or Tee	7	9	5
Two 90° Bends in Same Plane	8	12	5
Two 90° Bends in Different Plane	18	24	5
Reducers or Expanders	8	8	5
All Valves**	24	24	5

<sup>\*</sup> Values shown are recommended spacing, in terms of internal diameter for normal industrial metering requirements. For laboratory or high accuracy work, add 25% to values.

A. Fax

Phone: 219/879-8000 www.dwyer-inst.com


Fax: 219/872-9057 e-mail: info@dwyer-inst.com


<sup>\*\*</sup> Includes gate, globe, plug and other throttling valves that are only partially opened. If valve is to be fully open, use values for pipe size change. CONTROL VALVES SHOULD BE LOCATED AFTER THE FLOW SENSOR.

#### **POSITION**

Be certain there is sufficient clearance between the mounting position and other pipes, walls, structures, etc, so that the sensor can be inserted through the mounting unit once the mounting unit has been installed onto the pipe.

Flow sensors should be positioned to keep air out of the instrument connecting lines on liquid flows and condensate out of the lines on gas flows. The easiest way to assure this is to install the sensor into the pipe so that air will bleed into, or condensate will drain back to, the pipe.





#### **INSTALLATION**

- 1. When using an A-160 thred-o-let, weld it to the pipe wall. If replacing a DS-200 unit, an A-161 bushing  $(1/4^{\prime\prime} \times 3/8^{\prime\prime})$  will be needed.
- 2. Drill through center of the thred-o-let into the pipe with a drill that is slightly larger than the flow sensor diameter.
- 3. Install the packing gland using proper pipe sealant. If the packing gland is disassembled, note that the tapered end of the ferrule goes into the fitting body.
- 4. Insert sensor until it bottoms against opposite wall of the pipe, then withdraw 1/16" to allow for thermal expansion.
- 5. Tighten packing gland nut finger tight. Then tighten nut with a wrench an additional 1-1/4 turns. Be sure to hold the sensor body with a second wrench to prevent the sensor from turning.


#### INSTRUMENT CONNECTION


Connect the slide pressure tap to the high pressure port of the Magnehelic® (air only) or Capsuhelic® gage or transmitting instrument and the top connection to the low pressure port.

See the connection schematics below.

Bleed air from instrument piping on liquid flows. Drain any condensate from the instrument piping on air and gas flows.

Open valves to instrument to place flow meter into service. For permanent installations, a 3-valve manifold is recommended to allow the gage to be zero checked without interrupting the flow. The Dwyer A-471 Portable Test Kit includes such a device.





#### Flow Calculations and Charts

The following information contains tables and equations for determining the differential pressure developed by the DS-300 Flow Sensor for various flow rates of water, steam, air or other gases in different pipe sizes.

This information can be used to prepare conversion charts to translate the differential pressure readings being sensed into the equivalent flow rate. When direct readout of flow is required, use this information to calculate the full flow differential pressure in order to specify the exact range of Dwyer Magnehelic® or Capsuhelic® gage required. Special ranges and calculations are available for these gages at minimal extra cost. See bulletins A-30 and F-41 for additional information on Magnehelic® and Capsuhelic® gages and DS-300 flow sensors.

For additional useful information on making flow calculations, the following service is recommended: Crane Valve Co. Technical Paper No. 410 "Flow of Fluids Through Valves, Fittings and Pipe." It is available from Crane Valve Company, www.cranevalve.com.

Using the appropriate differential pressure equation from Page 4 of this bulletin, calculate the differential pressure generated by the sensor under normal operating conditions of the system. Check the chart below to determine if this value is within the recommended operating range for the sensor. Note that the data in this chart is limited to standard conditions of air at 60°F (15.6°C) and 14.7 psia static line pressure or water at 70°F (21.1°C). To determine recommended operating ranges of other gases, liquids an/or operating conditions, consult factory.

**Note:** the column on the right side of the chart which defines velocity ranges to avoid. Continuous operation within these ranges can result in damage to the flow sensor caused by excess vibration.

Pipe Size (Schedule 40)	Flow Coefficient "K"	Operating Ranges Air @ 60°F & 14.7 psia (D/P in. W.C.)	Operating Ranges Water @ 70°F (D/P in. W.C.)	Velocity Ranges Not Recommended (Feet per Second)	
1	0.52	1.10 to 186	4.00 to 675	146 to 220	
1-1/4	0.58	1.15 to 157	4.18 to 568	113 to 170	
1-1/2	0.58	0.38 to 115	1.36 to 417	96 to 144	
2	0.64	0.75 to 75	2.72 to 271	71 to 108	
2-1/2	0.62	1.72 to 53	6.22 to 193	56 to 85	
3	0.67	0.39 to 35	1.43 to 127	42 to 64	
4	0.67	0.28 to 34	1.02 to 123	28 to 43	
6	0.71	0.64 to 11	2.31 to 40	15 to 23	
8	0.67	0.10 to 10	0.37 to 37	9.5 to 15	
10	0.70	0.17 to 22	0.60 to 79	6.4 to 10	

#### **FLOW EQUATIONS**

#### 1. Any Liquid

Q (GPM) = 
$$5.668 \times K \times D^2 \times \sqrt{\Delta P/S_f}$$

Q (lb/Hr) = 359.1 x K x D<sup>2</sup> x 
$$\sqrt{p \times \Delta P}$$

Q (SCFM) = 128.8 x K x D<sup>2</sup> x 
$$\sqrt{\frac{P \times \Delta P}{(T + 460) \times S_s}}$$

#### DIFFERENTIAL PRESSURE EQUATIONS

$$\Delta$$
P (in. WC) =  $\frac{Q^2 \times S_f}{K^2 \times D^4 \times 32.14}$ 

2. Steam or Any Gas

$$\Delta P \text{ (in. WC)} = \frac{Q^2}{K^2 \times D^4 \times p \times 128,900}$$

3. Any Gas

$$\Delta P \text{ (in. WC)} = \frac{Q^2 \times S_8 \times (T + 460)}{K^2 \times D^4 \times P \times 16,590}$$

#### **Technical Notations**

The following notations apply:

 $\Delta P$  = Differential pressure expressed in inches of water column

Q = Flow expressed in GPM, SCFM, or PPH as shown in equation

K = Flow coefficient— See values tabulated on Pg. 3.

D = Inside diameter of line size expressed in inches.

For square or rectangular ducts, use: D = 
$$\sqrt{\frac{4 \text{ x Height x Width}}{\pi}}$$

P = Static Line pressure (psia)

T = Temperature in degrees Fahrenheit (plus 460 = °Rankine)

p = Density of medium in pounds per square foot

S<sub>f</sub> = Sp Gr at flowing conditions

 $S_s = Sp Gr at 60°F (15.6°C)$ 

#### **SCFM TO ACFM EQUATION**

SCFM = ACFM X 
$$\left(\frac{14.7 + PSIG}{14.7}\right) \left(\frac{520^*}{460 + °F}\right)$$

ACFM = SCFM X 
$$\left(\frac{14.7}{14.7 + PSIG}\right)$$
  $\left(\frac{460 + {}^{\circ}F}{520}\right)$ 

POUNDS PER STD. = POUNDS PER ACT. X 
$$\left(\frac{14.7}{14.7 + PSIG}\right)$$
  $\left(\frac{460 + {}^{\circ}F}{520^{*}}\right)$ 

POUNDS PER ACT. = POUNDS PER STD. X 
$$\left(\frac{14.7 + PSIG}{14.7}\right)$$
  $\left(\frac{520^*}{460 + °F}\right)$ 

1 Cubic foot of air = 0.076 pounds per cubic foot at 60° F (15.6°C) and 14.7 psia.

\* (520° = 460 + 60°) Std. Temp. Rankine

©Copyright 2004 Dwyer Instruments, Inc.

Printed in U.S.A. 7/04

FR# 72-440451-01 Rev. 2

DWYER INSTRUMENTS, INC. P.O. BOX 373 • MICHIGAN CITY, INDIANA 46361, U.S.A.

Phone: 219/879-8000 www.dwyer-inst.com Fax: 219/872-9057

e-mail: info@dwyer-inst.com




**Series ISDP** 

# **Intrinsically Safe Differential Pressure Transmitter**

#### For Hazardous Zone Pressure and Flow Applications





The ISDP Differential Pressure Transmitter provides a 4-20 mA process output, a robust NEMA 4X enclosure, plus a large LCD display that can be programmed to read in pressure, velocity or flow. The ISDP offers simplified programming via a Menu key that enables the user to select: security level; English or Metric engineering units; pressure, velocity or flow operation, K-factor for use with various Pitot tubes and flow sensors, circular or rectangular duct size for volumetric flow operation plus many more. The Series ISDP Differential Pressure Transmitter is powered on its two wire loop with 10-35 VDC via its integral M-12 four pin male connector. The ISDP provides a 0.5% full scale accuracy on ranges from 0.25 " w.c. to 100 " w.c. as well as bi-directional models up to 10 " w.c. These features make the Series ISDP Differential Pressure Transmitter the ideal instrument for monitoring pressures or air flows in hazardous zones having a Class I Div. I Groups A, B, C, D; Class II Div. I Groups E, F, G; Class III Div. I ratings.

Model	Range
ISDP-002	0 - 0.25 in w.c.
ISDP-004	0 - 1 in w.c.
ISDP-006	0 - 5 in w.c.
ISDP-007	0 - 10 in w.c.
ISDP-008	0 - 25 in w.c.
ISDP-009	0 - 50 in w.c.
ISDP-010	0 - 100 in w.c.
ISDP-012	-0.25 / +0.25 in w.c.
ISDP-014	-1.0 / +1.0 in w.c.
ISDP-015	-2.5 / +2.5 in w.c.
ISDP-016	-5.0 / +5.0 in w.c.
ISDP-017	-10 / +10 in w.c.

#### **ACCESSORIES**

A-231, 16' (5 m) Shielded Cable with 4 Pin Female M-12 Connection A-486, 4.9' (1 m) Shielded Cable with 4 Pin Female M-12 Connection A-487, 9.8' (3 m) Shielded Cable with 4 Pin Female M-12 Connection A-488, 33' (10 m) Shielded Cable with 4 Pin Female M-12 Connection

A-295, Female 4 Pin M-12 to Cable Gland Connector MTL5041, Intrinsically Safe Galvanic Isolator

A-438, Surface Mounting Brackets

MTL7706, Intrinsically Safe Zener Barrier

#### **SPECIFICATIONS**

Service: Air and non-corrosive gases.

Wetted Materials: Ranges 5" and greater: glass, PVC, silicon, alumina ceramic, epoxy, RTV, gold, aluminum, stainless steel and nickel; Ranges 1" and lower: stainless steel, silicone, gold and ceramic.

Housing Materials: Aluminum, glass.

Accuracy: ±0.5% at 77°F (25°C) including hysteresis and repeatability (after 1 hour warm-up)

Stability: < ±1% per year.

**Pressure Limits:** Ranges ≤ 2.5 in. w.c. = 2 psi; 5": 5 psi; 10": 5 psi; 25": 5 psi; 50":

5 psi; 100": 9 psi.

Temperature Limits: 32 to 140°F (0 to 60°C).

Compensated Temperature Limits: 32 to 140°F (0 to 60°C). Thermal Effects: 0.020%/°F (0.036/°C) from 77°F (25°C).

Power Requirements: 10-35 VDC. Output Signal: 4-20 mA DC.

Zero & Span Adjustments: Accessible via menus.

Response Time: 250 ms (damping set to 1).

Display: 4 digit LCD 0.6" height.

Electrical Connections: M-12 4 PIN Connector. Process Connections: 1/8" female NPT.

Enclosure Rating: Designed to meet NEMA 4X (IP66). Mounting Orientation: Mount unit in horizontal plane.

Weight: 2 lb 10 oz (1.19 kg).

Agency Approvals: FM Intrinsically Safe CLI Div I GR: A, B, C, D; CLII Div I GR: E, F, G; CLIII Div I. CE: CENELEC EN 61326/55024: 2003; IEC 61000-4-2/3/4/6: 2001/2006/2004/2005; CENELEC EN 55011: 2006; 2004/108/EC EMC Directive.

#### **APPENDIX I**

Transfer Pumps TP-200/202 Information




Section: MOYNO® 500 PUMPS

**Page:**1 of 4

Date: March 30, 1996

# MOYNO<sup>®</sup> 500 PUMPS


300 SERIES 331, 332, 333, 344, 356 AND 367 MODELS



MODELS	СР	Α	A <sup>1</sup>	D	Е	F	F <sup>1</sup>	Н	K	L	М	N	R	U	Х	Υ	SUCT (NPT)	DISCH (NPT)
33101, 33201 33301, 33104 33204, 33304 34401, 34404	12 <sup>5</sup> / <sub>8</sub>	3 <sup>1</sup> / <sub>8</sub>	4 <sup>3</sup> / <sub>4</sub>	23/4	1	1 <sup>13</sup> / <sub>16</sub>	6 <sup>15</sup> / <sub>16</sub>	<sup>13</sup> / <sub>32</sub>		5 <sup>11</sup> / <sub>16</sub>	6 <sup>1</sup> / <sub>16</sub>	1 <sup>7</sup> / <sub>16</sub>		<sup>5</sup> / <sub>8</sub>	2 <sup>3</sup> / <sub>8</sub>	1 <sup>1</sup> / <sub>4</sub>	<sup>3</sup> / <sub>4</sub>	<sup>3</sup> / <sub>4</sub>
*34411	$13^{15}/_{16}$	$3^{1}/_{4}$	$4^{3}/_{4}$	$2^{3}/_{4}$	1 <sup>1</sup> / <sub>8</sub>	_	$7^3/_{16}$	<sup>13</sup> / <sub>32</sub>	$2^{7}/_{8}$	7	$6^{1}/_{16}$	$1^{3}/_{8}$	<sup>1</sup> / <sub>4</sub>	<sup>5</sup> / <sub>8</sub>	$2^{5}/_{16}$	1 <sup>1</sup> / <sub>4</sub>	3/4	3/4
35601, 35604	$17^{1}/_{2}$	$6^{1}/_{2}$	7 <sup>9</sup> / <sub>16</sub>		$1^{3}/_{4}$	2	10 <sup>19</sup> / <sub>32</sub>			$7^{3}/_{8}$	8 <sup>5</sup> / <sub>8</sub>	$2^{3}/_{8}$	<sup>15</sup> / <sub>32</sub>	3/4	$3^{25}/_{32}$	2 <sup>1</sup> / <sub>8</sub>	1 <sup>1</sup> / <sub>2</sub>	1 <sup>1</sup> / <sub>4</sub>
*35611, *35613	19 <sup>3</sup> / <sub>8</sub>	$6^{1}/_{2}$	$7^9/_{16}$	$4^{9}/_{32}$	$1^{3}/_{4}$	$2^{1}/_{2}$	10 <sup>19</sup> / <sub>32</sub>	<sup>13</sup> / <sub>32</sub>	4	$9^{11}/_{32}$	8 <sup>5</sup> / <sub>8</sub>	$2^{13}/_{32}$	<sup>9</sup> / <sub>16</sub>	3/4	$3^{25}/_{32}$	2 <sup>1</sup> / <sub>8</sub>	1 <sup>1</sup> / <sub>2</sub>	1 <sup>1</sup> / <sub>4</sub>
36701, 36704	$20^{15}/_{16}$	5 <sup>1</sup> / <sub>4</sub>	8	4 <sup>1</sup> / <sub>2</sub>	2	2 <sup>5</sup> / <sub>16</sub>	13	<sup>9</sup> / <sub>16</sub>	4 <sup>1</sup> / <sub>16</sub>	$7^{15}/_{16}$	11 <sup>3</sup> / <sub>16</sub>	$2^{1}/_{8}$	_	1	4	2 <sup>1</sup> / <sub>2</sub>	2	2

<sup>\*</sup>Packing Gland Model

# 331, 332, 333 and 344 MODELS PERFORMANCE (water at 70°F)




NOTE: For fluids with viscosity over 200 CP (1000 SSU), pump capacity is reduced by 20%.

#### MATERIALS OF CONSTRUCTION


	MODELS					
COMPONENT	33101, 33201 33301, 34401	33104, 33204 33304, 34404	33108, 33208 33308, 34408	*34411		
Housing	Cast iron	316 SS	Nylon	Cast iron		
Rotor	416 SS/CP	316 SS/CP	416 SS/CP	416 SS/CP		
Stator	NBR (Nitrile)	NBR (Nitrile)	NBR (Nitrile)	NBR (Nitrile)		
Weight (lbs)	16	16	8	16		

<sup>\*</sup> Packing Gland Model CP = Chrome plated



NOTE: For fluids with viscosity over 200 CP (1000 SSU), pump capacity is reduced by 20%.

#### 356 and 367 MODELS PERFORMANCE (water at 70°F)



NOTE: For fluids with viscosity over 200 CP (1,000 SSU), pump capacity is reduced by 20%.

#### **MATERIALS OF CONSTRUCTION**

COMPONENT	MODELS					
COMPONENT	35601, 35611		35604, 35613		36701	36704
Housing	Cast iron		316 SS		Cast iron	316 SS
Rotor	416 SS/CP		316 S	SS/CP	416 SS/CP	316 SS/CP
Stator	NBR	(Nitrile)	NBR (Nitrile)		NBR (Nitrile)	NBR (Nitrile)
Weight (lbs)	37	40	37	40	54	54

CP=Chrome plated



Always the Right Solution™

Section:

MOYNO® 500 PUMPS

Page: 1 of 8

Date: March 1, 1998

# SERVICE MANUAL MOYNO® 500 PUMPS

300 SERIES 331, 332, 333, 344, 356 AND 367 MODELS



**Mechanical Seal Models** 



**Packing Gland Models** 

	MODELS				
DESIGN FEATURES	33101 34401 33201 35601 33301 36701	33104 34404 33204 35604 33304 36704	33108 33308 33208 34408	34411 35611	35613
Housing:	Cast Iron	AISI 316 SS	Nylon	Cast Iron	AISI 316 SS
Pump Rotor:	Chrome plated	Chrome plated	Chrome plated	Chrome plated	Chrome plated
i amp recen	416 SS	316 SS	416 SS	416 SS	316 SS
Pump Stator:	NBR (Nitrile)	NBR (Nitrile)	NBR (Nitrile)	NBR (Nitrile)	NBR (Nitrile)
Shaft:	416 SS	316 SS	416 SS	416 SS	316 SS
Flexible Joint:	Carbon steel/	316 SS/	Carbon steel/	Carbon steel/	316 SS/
	NBR	NBR	NBR	NBR	NBR
Bearings:	Ball (sealed)	Ball (sealed)	Ball (sealed)	Ball (sealed)	Ball (sealed)
Mechanical Seal:	Carbon-ceramic	Carbon-ceramic	Carbon-ceramic		
Packing:				Braided PTFE	Braided PTFE

Note: Alternate elastomers available. Refer to Repair/Conversion kit numbers, page 8.

#### **INSTALLATION**

**Mounting Position**. Pump may be mounted in any position. When mounting vertically, it is necessary to keep bearings above seals to prevent possible seal leakage into bearings.

**Pre-Wetting.** Prior to connecting pump, wet pump elements and mechanical seal or packing by adding fluid to be pumped into suction and discharge ports. Turn shaft over several times in a clockwise direction to work fluid into elements.

**Piping.** Piping to pump should be self-supporting to avoid excessive strain on pump housings. See Table 1 for suction and discharge port sizes of each pump model. Use pipe "dope" or tape to facilitate disassembly and to provide seal.

**Drive.** On belt driven units, adjust belt tension to point of non-slip. Do not overtighten.

On direct drive units, coupling components should be aligned and spaced at least 1/16" apart.

Pump rotation must be clockwise when facing shaft to prevent damage to pump. Check direction of rotation before startup.

Water Flush of Packing (356 Models Only). The packing may be either grease lubricated through a grease fitting in the stuffing box or have plumbing connected to the housing to allow a water flush.

Maximum speed is 1750 rpm.

When the material being pumped is abrasive in nature, it may be advantageous to flush the packing to prevent leakage under packing and excessive shaft wear.

Clean water can be injected through a 1/8" NPT tapped hole that normally houses the grease fitting for lubricating the packing. The water can be permitted to leak axially along the shaft in either direction or can be removed from the second tapped hole in the stuffing box. In both cases, the discharge from the stuffing box should be throttled slightly to maintain 10-15 PSI higher pressure in the stuffing box than is present in the discharge housing.

Table 1. Pump Data

Duman Madala	224	222	222	244	250	207
Pump Models	331	332	333	344	356	367
Suction Port (NPT)	3/4*	3/4*	3/4*	3/4*	1-1/2	2
Discharge Port (NPT)	3/4	3/4	3/4	3/4	1-1/4	2
Discharge Pressure (psig)	150	100	50	40	50	50

<sup>\*08</sup> versions = 1" NPT

**Table 2. Temperature Limits** 

Elastomer	Temperature Limits			
*NBR	10°-160°F			
*EPDM	10°-210°F			
*FPM	10°-240°F			

<sup>\*</sup>NBR = Nitrile

#### OPERATION

Self-Priming. With wetted pumping elements, the pump is capable of 25 feet of suction lift when operating at 1750 rpm with pipe size equal to port size.

DO NOT RUN DRY. Unit depends on liquid pumped for lubrication. For proper lubrication, flow rate should be at least 10% of rated capacity.

Pressure and Temperature Limits. See Table 1 for maximum discharge pressure of each model. Unit is suitable for service at temperatures shown in Table 2.

Storage. Always drain pump for extended storage periods by removing suction housing bolts and loosening suction housing.

#### TROUBLE SHOOTING

WARNING: Before making adjustments, disconnect power source and thoroughly bleed pressure from system. Failure to do so could result in electric shock or serious bodily harm.

#### Failure To Pump.

- 1. Belt or coupling slip: Adjust belt tension or tighten set screw on coupling.
- 2. Stator torn; possibly excessive pressure: Replace stator, check pressure at discharge port.
- Wrong rotation: Rotation must be clockwise when facing shaft.

- 4. Threads in rotor or on shaft stripped: Replace part. Check for proper rotation.
- 5. Excessive suction lift or vacuum.

#### Pump Overloads.

- 1. Excessive discharge pressure: Check discharge pressure for maximum rating given in Table 1. Check for obstruction in discharge pipe.
- 2. Fluid viscosity too high: Limit fluid viscosity to 20,000 CP or 100,000 SSU.

Viscosity CP	Limit RPM
1-300	1750
300-1,000	1200
1,000-2,000	700
2,000-5,000	350
5,000-10,000	180
10,000-20,000	100

3. Insufficient motor HP: Check HP requirement.

#### **Noisy Operation.**

- 1. Starved suction: Check fluid supply, length of suction line, and obstructions in pipe.
- 2. Bearings worn: Replace parts; check alignment, belt tension, pressure at discharge port.
- 3. Broken flexible joint: Replace part, check pressure at discharge port.
- 4. Insufficient mounting: Mount to be secure to firm base. Vibration induced noise can be reduced by using mount pads and short sections of hose on suction and discharge

# Mechanical Seal Leakage (Mechanical Seal Models

- 1. Leakage at startup: If leakage is slight, allow pump to run several hours to let faces run in.
- 2. Persistent seal leakage: Faces may be cracked from freezing or thermal shock. Replace seal.

#### Packing Leakage (Packing Models Only).

1. Leakage at startup: Adjust packing as outlined in maintenance instructions.

Note: Slight leakage is necessary for lubrication of packing.

2. Persistent leakage: Packing rings and/or shaft may be worn. Replace parts as required.

#### Pump Will Not Prime.

1. Air leak on suction side: Check pipe connections.

#### MAINTENANCE

General. These pumps have been designed for a minimum of maintenance, the extent of which is routine lubrication and adjustment of packing. The pump is one of the easiest to work on in that the main elements are very accessible and require few tools to disassemble.

Packing Lubrication (356 Models Only). The zerk fitting on the side of the suction housing leads to the lantern ring halves in the mid-section of the packings. At least once a week, inject a small quantity of good quality grease, such as MPG-2 Multi Purpose Grease (Du Bois Chemical), or equivalent, into the zerk fitting to lubricate the packings.

Note: For Model 34411, lubricate packing by applying a liberal amount of grease during assembly.

<sup>\*</sup>EPDM = Ethylene-Propylene-Diene Terpolymer

<sup>\*</sup>FPM = Fluoroelastomer

Packing Adjustment (Packing Models Only). Packing gland attaching nuts should be evenly adjusted so they are little more than finger tight. Over-tightening of the packing gland may result in premature packing failure and possible damage to the shaft and gland.

When the packing is new, frequent minor adjustments are recommended for the first few hours of operation in order to compress and seat the packing. Be sure to allow slight leakage for lubrication of packing.

When excessive leakage can no longer be regulated by tightening the gland nuts, remove and replace the packings in accordance with the DISASSEMBLY and REASSEMBLY instructions. The entire pump need not be disassembled to replace the packings.

**Bearing Lubrication.** The prelubricated, fully sealed bearings do not require additional lubrication.

#### **PUMP DISASSEMBLY**

WARNING: Before disassembling pump, disconnect power source and thoroughly bleed pressure from system. Failure to do so could result in electric shock or serious bodily harm.

#### To Disassemble Mechanical Seal Models:

- 1. Disconnect suction and discharge piping.
- Remove screws (112) holding suction housing (2) to pump body (1). Remove suction housing and stator (21).
- Remove rotor (22) from flexible joint (24) by turning counter-clockwise (RH thread). Use 3/16 inch diameter punch to remove rotor pin (45) on Model 36701.
- 4. Flexible joint (24) can be removed from shaft (26) by using a 3/16 inch allen wrench in end of joint (1/4 inch wrench on 356 Models) and turn counter-clockwise. Use 3/16 inch diameter punch to remove shaft pin (46) on Model 36701.
- 5. Carefully slide mechanical seal (69) off shaft (26). Carefully pry seal seat out of pump body (1). If any parts of mechanical seal are worn or broken, the complete seal assembly should be replaced. Seal components are matched parts and are not interchangeable.
- 6. The bearings (29) and shaft (26) assembly can be removed from pump body (1) after snap ring (66) has been removed. To remove the assembly, lightly tap the shaft at threaded end using a block of wood to protect the threads. The bearings may be pressed off the shaft.

#### To Disassemble Packing Models:

- 1. Disconnect suction and discharge piping.
- Remove screws (112) which hold suction housing (2) to pump body (1). Remove suction housing and stator (21).
- Remove rotor (22) from flexible joint (24) by turning in a counter-clockwise direction (RH thread).
- Flexible joint (24) can be removed by using a 3/16 inch allen wrench in end of joint (1/4 inch wrench on 356 Models) and turn in a counter-clockwise direction.
- 5. The packing (42) can be removed without removing the shaft (26) using the following procedure:
  - a. Remove gland bolts (47).
  - b. Slide gland (41) away from packing (42).
  - Pull out packing (42) (and lantern ring halves (57) on 356 Models) using a packing removing tool.

- Note: Packing can be removed after shaft has been removed by pushing out from pump side of pump body after gland (41) has been detached.
- The bearings (29) and shaft (26) assembly can be removed from pump body (1) after snap ring (66) has been removed. To remove the assembly, lightly tap the shaft at threaded end using a block of wood to protect the threads.
- To disassemble shaft assembly, remove snap ring (66A) from shaft (26) and press bearings (29) and bearing spacer (33) off the shaft.

#### **PUMP ASSEMBLY**

#### To Assemble Mechanical Seal Models:

1. Press bearings (29) on shaft (26), and locate slinger ring (77) near bearing on threaded end of shaft.

Note: When replacing bearings, always press on the inner race when assembling to shaft, and on the outer race when pressing bearings into the housings.

- 2. Press shaft assembly into pump body (1) securing with snap ring (66).
- Install mechanical seal (69) using the following procedure:
  - Clean and oil sealing faces using a clean light oil (not grease).

#### Caution: Do not use oil on EPDM parts. Substitute glycerin or soap and water.

- b. Oil the outer surface of the seal seat, and push the assembly into the bore in the pump body (1), seating it firmly and squarely.
- c. After cleaning and oiling the shaft, slide the seal body along the shaft until it meets the seal seat.
- d. Install seal spring and spring retainer on shaft.
- 4. Thread flexible joint (24) into shaft (26) in a clockwise direction (RH thread). On 356 Models, install seal spacer (69A) and washer (116) before threading flexible joint onto shaft in a clockwise direction. On Model 36701, use shaft pin (46) to pin flexible joint (24) to shaft.
- Thread rotor (22) onto flexible joint (24) in a clockwise direction (RH thread). On Model 36701, pin rotor (22) to joint using rotor pin (45).
- Slide stator (21) on rotor (22). On 331 and 332 Models, insert rounded end of stator ring (135) into end of stator prior to installing stator on rotor.
- 7. Secure stator (21) and suction housing (2), with suction port vertically up, to pump body (1) using screws (112).
- 8. Proceed as in installation instructions.

#### To Assemble Packing Models:

1. Press bearings (29), with bearing spacer (33) in between, on shaft (26) and secure in place using snap ring (66A).


Note: When replacing bearings, always press on the inner race when assembling to shaft, and on the outer race when pressing bearings into the housings.


#### Page 4

- Install packing (42) before installing shaft assembly using the following procedure:
  - a. Lubricate each individual ring of packing with a grease that is insoluble in the fluid being pumped.
  - b. Individually assemble each ring of packing loosely in the packing chamber of the pump body (1). Stagger splits on rings. (Four rings, 3/16 inch square required on Model 34411; four rings, 1/4 inch square and two lantern ring halves (57) assembled between two rings on 356 Models).
  - c. Loosely install packing gland (41) on pump body (1) using gland bolts (47).
- Press shaft assembly into pump body (1) positioning slinger ring (77) between packing gland (41) and bearing end of pump body. Secure the shaft assembly with snap ring (66).
- 4. Thread flexible joint (24) into shaft (26) in a clockwise direction (RH thread).
- Thread rotor (22) onto flexible joint (24) in a clockwise direction (RH thread).
- Slide stator (21) on rotor (22). On 331 and 332 Models, insert rounded end of stator ring (135) into end of stator prior to installing stator on rotor.
- Secure stator (21) and suction housing (2), with suction port vertically up, to pump body (1) using screws (112).
- Proceed as in installation instructions.

Note: Adjust newly installed packing as described in maintenance procedure.

WARNING: Replace belt or coupling guards before reconnecting power.





PARTS LIST — 331, 332, 333, AND 344 MODELS

Item No.	Description	Mechanical Seal Mo	dels		Packing Gland Models
		33101 33201 33301 34401	33104 33204 33304 34404	33108 33208 33308 34408	34411
1	Pump Body	330-1065-002	330-1910-002	04400	340-1000-001
1A	Discharge Housing			340-2362-000	
1B	Bearing Housing			330-4587-000	
1C	Pump Base			340-2369-000	
2	Suction Housing	330-1064-002	330-1911-002	330-4536-000	330-1064-002
*21	Stator	See Stator section below.			
*22	Rotor	See Rot	tor section below with	circled	
		nu	imbers for each series	S.	
		(1)	(2)	(1)	(1)
24	Joint	Carbon Steel/NBR 320-1511-000	316 SS/NBR 320-3759-000		Steel/NBR 511-000
26	Drive Shaft	320-1499-000	320-2938-000	320-1499-000	320-2448-000
29	Bearing (2 req.)		630-05	02-031	•
33	Bearing Spacer				320-1900-000
41	Packing Gland				320-0101-004
42	Packing				340-3396-005
47	Gland Bolt				619-1520-161
66	Snap Ring		320-15	06-000	
66A	Snap Ring				320-4182000
69	Mechanical Seal		320-2424-000		
77	Slinger Ring		320-6382-000		320-6384-000
100	Pipe Plug (3 req.)			610-0120-021	
112	Screws (8 req.)	619-1430-103	320-5968-000	619-0860-081	619-1430-103
112C	Screws (4 req.)			61 9-0890-281	
135	Stator Ring (331 -332 only)		320-7812-000	·	
215	Lock Washer (8 req.)		320-64	64-000	

<sup>\*</sup>Recommended spare parts.

STA	TORS	Models						
		331	332	333	344			
21	Standard Stator, NBR All Models	340-3501-120	340-3502-120	340-3503-120	340-3504-120			
21	EPDM Stator	340-3501-320	340-3502-320	340-3503-320	340-3504-320			
21	FPM Stator	340-3501-520	340-3502-520	340-3503-520	340-3504-520			
ROT	ORS							
22	1 416SS - All Models	320-2729-000	330-0906-000	320-1394-000	320-1841-000			
22	2 316SS – All Models	320-2933-000	320-2942-000	320-2936-000	320-2934-000			

See page 8 for Repair/Conversion Kits

### PARTS LIST — 356 AND 367 MODELS

Item	Description	Mechanical	Seal Models	Packing Gla	and Models	Mechanical	Seal Model
No.	Description	35601	35604	35611	35613	36701	36704
1	Pump Body	Cast Iron 340-0636-000	316SS 340-1550-000	Cast Iron 350-0420-000	316SS 350-0491-000	Cast Iron 350-0423-000	316SS 350-0423-007
2	Suction Housing	350-0280-000	350-0489-000	350-0280-000	350-0489-000	350-0302-000	350-0302-007
*21	Stator	340-35	3R 05-120	NE 340-35	05-120	NE 340-35	06-120
22	Rotor	416SS 320-2304-000	316SS 320-4431-000	416SS 320-2304-000	316SS 320-4431-000	416SS 330-2042-000	316SS 330-3077-000
24	Flex Joint	Carbon Steel 320-1583-000	316SS 320-4427-000	Carbon Steel 320-1583-000	316SS 320-4427-000	Carbon Steel 320-1749-000	316SS 320-4436-000
26	Drive Shaft	320-1759-000	320-4430-000	320-2765-000	320-4435-000	330-1805-000	330-1805-015
29	Bearing (2 req.)	630-0552-051				630-0552-061	
33	Bearing Spacer			320-27	64-000		
41	Packing Gland			320-0003-004	320-0003-007		
*42	Packing			340-33	96-008		
45	Rotor Pin					320-44	39-002
46	Shaft Pin					320-44	39-001
47	Gland Bolt			619-15	30-241		
57	Lantern Ring Half**			320-65	85-000		
66	Snap Ring		320-175	8-000		320-27	94-000
66A	Snap Ring			320-35	33-000		
*69	Mechanical Seal	320-39	45-000			320-17	50-000
69A	Seal Spacer	320-44	34-000				
77	Slinger Ring	320-63	83-000	320-63	85-000	320-63	85-000
112	Screws (6 req.)		619-153	0-161		619-15	30-161
115	Zerk Fitting			320-25	03-001		
135	Stator Spacer			330-7594	1-000		
202	Shaft Key	·				611-00	40-240
215	Lock Washer (6 req.)			623-0010	)-411		·
261	Pipe Plug	610-0120-011	610-0420-010	610-0120-011	610-0420-010	610-0120-011	610-0420-010

<sup>\*</sup>Recommended spare parts.
\*\*2 Required

See page 8 for Repair/Conversion Kits

### **REPAIR/CONVERSION KIT NUMBERS**

### **ELASTOMER REPAIR/CONVERSION KITS**

Item No.	Description	331 Models			332 Models		
		NBR	EPDM	FPM	NBR	EPDM	FPM
_	Kit No.	311-9026-000	311-9025-000	311-9054-000	311-9027-000	311-9038-000	311-9055-000
21	Stator	340-3501-120	340-3501-320	340-3501-520	340-3502-120	340-3502-320	340-3502-520
24	Joint	320-1511-000‡	320-6367-000†	320-4670-000†	320-1511-000‡	320-6367-000†	320-4670-000†
69	Seal	320-2424-000	320-6379-000	320-6501-000	320-2424-000	320-6379-000	320-6501-000
Item No.	Description	333 Models			344 Models		
		NBR	EPDM	FPM	NBR	EPDM	FPM
_	Kit No.	311-9029-000	311-9028-000	311-9056-000	311-9031-000	311-9030-000	311-9057-000
21	Stator	340-3503-120	340-3503-320	340-3503-520	340-3504-120	340-3504320	340-3504520
24	Joint	320-1511-000‡	320-6367-000†	320-4670-000†	320-1511-000‡	320-6367-000†	320-4670-000†
69	Seal	320-2424-000	320-6379-000	320-6501-000	320-2424-000	320-6379-000	320-6501-000

t316SS/with appropriate elastomer.

‡Carbon steel. NBR kits are available only with carbon steel joints; a 316SS/NBR joint for 331-344 Models is available as 320-3759-000.

Item	Description		356 Models			367 Models	
No.	Description	NBR	EPDM	FPM	NBR	EPDM	FPM
_	Kit No. (Mech. Seal Models)	311-9033-000	311-9032-000	311-9058-000	311-9060-000	311-9036-000	311-9124-000
21	Stator	340-3505-120	340-3505-320	340-3505-520	340-3506-120	340-3506-320	340-3506-520
24	Flex Joint	320-1583-000‡	320-6369-000†	320-4671-000†	320-1749-000‡	320-6378-000‡	3206515-000‡
69	Seal	320-3945-000	320-6380-000	320-6510-000	320-1750-000	320-6390-000	320-6517-000
45	Rotor Pins				320-4439-002	320-4439-002	320-4439-002
46	Shaft Pin				320-4439-001	320-4439-001	320-4439-001
_	Kit No (Packing Gland Models)	311-9035-000	311-9034-000	311-9059-000			
21	Stator	340-3505-120	340-3505-320	340-3505-520			
24	Joint	320-1583-000‡	320-6369-000†	320-4671-000†			

### †316SS/with appropriate elastomer.

‡Carbon steel. NBR kits are available only with carbon steel joints; a 316SS/NBR joint for Model 35604 and 35613 pumps is available as 320-4427-000; a 316SS/NBR joint for model 36704 is available as 320-4436-000.

### **ABRASION RESISTANT SEALS**

	Models		
Elastomer	331-344	356	36701
NBR	3206460000	3206505000	3206511000
EPDM	3206502000	3206506000	3206512000
FPM	3206503000	3206507000	3206513000

NBR = Nitrile

EPDM = Ethylene-Propylene-Diene Terpolymer

FPM = Fluoroelastomer



# BALDOR · RELIANCE II

## **Product Information Packet**

M7014T

1//.75HP,1750//1450RPM,3PH,60//50HZ,143T


Part Detail								
Revision:	F	Status:	INA/A	Change #:		Proprietary:	No	
Type:	AC	Prod. Type:	3516M	Elec. Spec:	35WGP674	CD Diagram:		
Enclosure:	XPFC	Mfg Plant:		Mech. Spec:	35E362	Layout:		
Frame:	143T	Mounting:	F1	Poles:	04	Created Date:	10-18-2007	
Base:	RG	Rotation:	R	Insulation:	В	Eff. Date:	02-23-2011	
Leads:	9#18	Literature:		Elec. Diagram:		Replaced By:		
Nameplate NF	1426XP							
NO.				co	)			
SER.						<u>,                                      </u>		
SPEC.		35E362P674H1						
CAT.NO.		EXPORT ONLY						
HP		1//.75		T.	CODE	T3C		
VOLTS		230/460//190/380						
AMPS		3.2/1.6//3/1.5						
RPM		1750//1450						
HZ		60//50		PH		3	CL	В
SER.F.		1.00		DE	S	В	CODE	М
RATING		40C AMB-CONT						
FRAME		143T		NE	MA-NOM-EFF	82.5	PF	73
USABLE AT 208V	,							-

Parts List		
Part Number	Description	Quantity
SA164676	SA 35E362P674H1	1.000 EA
RA153102	RA 35E362P674H1	1.000 EA
35CB3001A02SP	EXPL PROOF CONDUIT BOX, 3/4"PIPE TAP LEA	1.000 EA
11XW1032G06	10-32 X .38, TAPTITE II, HEX WSHR SLTD U	1.000 EA
HW3001B01	003SS CUP WASHER, FOR #8 SCREW	1.000 EA
35EP3700A01SP	FR ENDPLATE, XPFC	1.000 EA
HW5100A03SP	WAVY WASHER (W1543-017)	1.000 EA
35EP3701A01	PU ENDPLATE, XPFC - 205 BRG	1.000 EA
XY3118A12	5/16-18 HEX NUT DIRECTIONAL SERRATION	4.000 EA
51XB1214A16	12-14X1.00 HXWSSLD SERTYB	1.000 EA
35FH4005A01SP	IEC FH NO GREASER W/AUTOPHORETIC PRIMER	1.000 EA
51XW1032A06	10-32 X .38, TAPTITE II, HEX WSHR SLTD S	3.000 EA
35CB3500A01SP	CONDUIT BOX LID, MACH	1.000 EA
10XN2520A16	1/4-20 X 1 HEX HEAD CAP SCR, ZINC PLATED	4.000 EA
HW1001A25	LOCKWASHER 1/4, ZINC PLT .493 OD, .255 I	4.000 EA
HW2501D13SP	KEY, 3/16 SQ X 1.375	1.000 EA
HA7000A01	KEY RETAINER 7/8" DIA SHAFT	1.000 EA
85XU0407S04	4X1/4 U DRIVE PIN STAINLESS	6.000 EA
NP0018	NP- XP CONDUIT BOX DO NOT MAKE SELLABLE	1.000 EA
MJ1000A75	GREASE, POLYREX EM EXXON	0.050 LB
35FN3002A05SP	EXFN, PLASTIC, 6.376 OD, .638 ID	1.000 EA
MG1025Z20	ACTIVATOR WILKOFAST 060.32	0.010 GA
MG1025G29	PAINT 789.205 DARK GRAY METALLIC (USE W/	0.017 GA
HA3104A06	THRUBOLT 5/16-18 X 8.50 OHIO ROD	4.000 EA

Parts List (continued)		
Part Number	Description	Quantity
LB1119	WARNING LABEL	1.000 EA
LB1172A01	CUSTOM MTR CARTON LABEL LASER PRINTER	1.000 EA
LC0145B01	CONNECTION LABEL	1.000 EA
NP1426XP	UL/CSA, CLI GP-D,CLII GP-F&G,CC	1.000 EA
36PA1000	PACK GROUP W/LB5001	1.000 EA


Performance Date	ta at 460V, 60Hz	1.0HP (Typical perf	ormance - Not guara	anteed values)			
General Characterist	ics						
Full Load Torque:		2.99 LB-FT		Start Configuration	on:	DOL	
No-Load Current:		1.04 Amps		Break-Down Tor	que:	17.8 LB-FT	
Line-line Res. @ 25°	C.:	16.3 Ohms A Ph	0.0 Ohms B Ph	Pull-Up Torque:		8.32 LB-FT	
Temp. Rise @ Rated	Load:	41 C		Locked-Rotor To	orque:	10.4 LB-FT	
Temp. Rise @ S.F. L	.oad:			Starting Current:		13.2 Amps	
Load Characteristics							
% of Rated Load	25	50	75	100	125	150	S.F.
Power Factor:	32.0	50.0	63.0	72.0	79.0	83.0	0.0
Efficiency:	66.6	78.0	81.4	82.6	82.5	81.6	0.0
Speed:	1788.0	1776.0	1764.0	1750.0	1735.0	1719.0	0.0
Line Amperes:	1.11	1.2	1.36	1.56	1.77	2.06	0.0


Performance Graph at 460V, 60Hz, 1.0HP Typical performance - Not guaranteed values




Performance Data	a at 380V, 50Hz, 0.75	HP (Typical performa	ance - Not guarantee	d values)			
General Characteristic	cs						
Full Load Torque:		2.7 LB-FT		Start Configuration:		DOL	
No-Load Current:		1.02 Amps		Break-Down Torque:		16.0 LB-FT	
Line-line Res. @ 25°C	).:	16.3 Ohms A Ph / 0.0 O	hms B Ph	Pull-Up Torque:		8.1 LB-FT	
Temp. Rise @ Rated	Load:	37 C		Locked-Rotor Torque:		10.1 LB-FT	
Temp. Rise @ S.F. Lo	oad:			Starting Current:		12.1 Amps	
Load Characteristics							
% of Rated Load	25	50	75	100	125	150	S.F.
Power Factor:	31.0	48.0	61.0	71.0	78.0	82.0	0.0
Efficiency:	64.3	76.4	80.2	81.5	81.4	80.3	0.0
Speed:	1489.0	1478.0	1467.0	1454.0	1440.0	1426.0	0.0
Line Amperes:	1.08	1.16	1.29	1.47	1.66	1.92	0.0

### Performance Graph at 380V, 50Hz, 0.75HP Typical performance - Not guaranteed values







Operation, Maintenance and Monitoring (OM&M) Mar
--

**APPENDIX J** 

**OWS** Information

## HYDRO QUIP, INC.

## Water Treatment Equipment

### 11/7/2012

John Mackellar ProAct Services Corp. 1140 Conrad Industrial Drive Ludington, MI 49431

Phone: 231-843-2711 Fax: 231-843-4081

Subject: HQI Quotation # AG-10-01-MI-12-3

Dear John:

We are pleased to submit our revised proposal.

Item 1: (1) HQI AG-4CS-IP-1H parallel-corrugated plate Oil/Water Separator will remove essentially 100 % of all free and dispersed non-emulsified oil droplets larger than 20 microns in diameter with a specific gravity of 0.90 or less. The separator is designed for above-grade installation and will be constructed of 3/16" thick carbon steel and coated inside and out.

### Included with the system:

- Design Flow: 1-200 GPM Size 52" Wide X 76" High X 120" Long.
- 6" Inlet/Outlet FNPT fitting
- 2" Oil outlet FNPT Fitting
- 2" vent NPT fittings and (2) 2" drain NPT fittings
- Parallel-corrugated plate coalescer designed to remove oil droplets greater than 20 microns with a Reynolds Number of less than 500.
- Sludge baffle to capture and contain settleable solids.
- 60 gallon integral oil storage compartment.
- Gasketed removable vapor tight covers for access to chamber compartments.

### DESIGN DATA:

HQI will provide analysis, which indicates that, at the calculated overflow rate, the separator will be provided with the required square feet of projected plate separation area to achieve the specified performance under laminar flow (i.e. Reynolds number of less than 500) conditions. Calculations shall take into account the rate of flow, potential surge flow, influent concentrations, particle characteristics, fluid temperature, fluid specific gravities, and PH. If require, calculations signed by a registered professional engineer can be provided for an additional fee.

### TERMS OF PAYMENT:

Net 30 days from date of shipment

### WARRANTY:

- a. Oil/Water Separator Tank per attached HQI Warranty
- b. Oil/Water Separator Accessories and Treatment Equipment Two (2) year.

### TAXES:

Our price does not include any taxes or duties that may apply to this transaction.

### DELIVERY:

Delivery 4-5 weeks after receipt of purchase order or approved drawings.

We look forward to working with you on this project. If you have any questions or require additional information, please contact me.

Sincerely yours,

A 1. Que

Paul Desmarais.

Product Manager.

## HYDRO QUIP, INC.

## Water Treatment Equipment

## 1.0) INTRODUCTION

Hydro Quip, Inc. (HQI) Oil Water Separator (OWS) Model AG-4CS-IP-1H will remove essentially all free and dispersed, non-emulsified oil, and settleable solids from the oil water mixture at a flow rate of 200 GPM at a temperature of 55 degrees F. The design utilizes the difference in specific gravity between oil and water (buoyancy force) enhanced by the use of 60 cubic feet of 3/4" Unipack Plates and 20 cubic feet of HD Q-PAC coalescing plates. The separator is designed to receive oily water by gravity/pumped flow that will not mechanically emulsify the oil and will process it on a once through basis. The tank will be a single wall, rectangular unit installed above grade. It will be constructed of carbon steel and coated inside and out. The HD Q-PAC coalescing plates are manufactured of UV-Resistant Polypropylene material.

### **2.0 SYSTEM DESCRIPTION AND REQUIREMENTS**

- 2.1 *FABRICATION:* The oil water separator is a special purpose prefabricated parallel corrugated plate, rectangular, gravity displacement, type oil water separator. The separator shall be comprised of a tank containing an inlet compartment, separation chamber, sludge chamber, and clean water outlet chamber.
- 2.2 TANK: The tank shall be a single wall construction of 3/16" thick carbon steel conforming to ASTM A36, carbon steel. Welding will be in accordance with AWS D1.1 to provide a watertight tank that will not warp or deform under load. Pipe connections to the exterior shall be as follows:
- 2.2.1 *PIPE CONNECTIONS*: All connections 3" and smaller are FNPT couplings. All connections 4" and larger are flat face flanges with ANSI 150 pound standard bolt circle. Use flanged piping connections that conform to ANSI B16.5.
- 2.3 SEPARATOR CORROSION PROTECTION: (For Carbon Steel Only) after shop hydrostatic test has been successfully completed, a coating system will be applied to the interior and exterior surfaces of the separator. Interior and exterior shall be sandblasted to SSPC-SP10 & SSPC-SP6; Interior lined with Potable Water Epoxy liner to 10 mils MDFT; Exterior coated with polyamide epoxy to 6 mils MDFT.
- 2.4 *LIFTING LUGS*: The tank shall be provided with properly sized lifting lugs for handling and installation.
- 2.5 COVERS: The tank will be provided with vapor tight covers for vapor control. Gas vents and suitable access openings to each compartment will be provided. The covers shall be constructed of marine grade aluminum and will be fastened in place. A gasket shall be provided for vapor tightness. 3/8-16 bolts and threaded knobs will be provided for cover attachment.

## HYDRO QUIP, INC.


## Water Treatment Equipment


- 2.6 *INLET COMPARTMENT*: The inlet chamber shall be comprised of a non-clog diffuser to distribute the flow across the width of the separation chamber. The inlet compartment shall be of sufficient volume to effectively reduce influent suspended solids, dissipate energy and begin separation. The media will sit elevated on top of a sludge baffle. The sludge baffle will be provided to retain settleable solids and sediment from entering the separation chamber.
- 2.7 SEPARATION CHAMBER: The oil separation chamber shall contain HD Q-PAC Coalescing Media containing a minimum of 132 square feet per cubic foot of effective coalescing surface area. The medias needle like elements (plates) shall be at 90 degrees to the horizontal or longitudinal axis of the separator. Spacing between these elements shall be spaced 3/16" apart for the removal of a minimum of 99.9% of free droplets 20 micron in size or greater. The elements are positioned to create an angle of repose of 90 degrees to facilitate the removal of solids that may tend to build up on the coalescing surfaces, which would increase velocities to the point of discharging an unacceptable effluent. Laminar flow with a Reynolds Number of less than 500 at a maximum designed flow rate shall be maintained throughout the separator packed bed including entrance and exit so as to prevent re-entrainment of oils with water. Flow through the polypropylene coalescing media shall be crossflow perpendicular to the vertical media elements such that all 132 square feet/cubic foot of coalescing media is available for contact with the coalescing surfaces. None of the coalescing media surfaces shall be pointing upward so as not to be available for contact with the crossflowing oily water. The media shall have a minimum of 87% void volume to facilitate sludge and dirt particles as they fall off the vertical elements and settle in the sludge compartment. The media when installed in crossflow OWS shall meet US EPA Method 413.2 and also European Standard 858-1.
- 2.8 BAFFLES: An oil retention & underflow weir, and overflow weir. Position underflow weir to prevent resuspension of settled solids.
- 2.9 SLUDGE BAFFLE: The sludge baffle shall be located prior to the coalescing compartment for the settling of any solids. It shall also prevent any solids from entering the clean water chamber.
- 2.10 *OIL SKIMMER*: The oil separation chamber will be provided with a rotatable pipe skimmer for gravity decanting of the separated oil to a 60 gallon integral product storage tank.
- 2.11 CLEAN WATER CHAMBER: The tank will be provided with a 400-gallon clean water chamber that allows the water to leave the separator by pumped flow through the clean water outlet port.
- 2.12 *VENTS*: 2" vents will be provided with vent piping to atmosphere.

ITEM	QTY	DESCRIPTION	ITEM	QTY	DESCRIPTION
1	1	6"-150# FLG. INLET	7	1	PVC OIL SKIMMER
2	1	6"-150# FLG. OUTLET	8	3	REMOVABLE COVER
3	1	2" FNPT OIL OUTLET	9	1	OIL STOP WEIR
4	2	2" FNPT VENT	10	1	ADJ. OVERFLOW WEIR
5	2	2" FNPT DRAIN	11	0	NOT USED
6	1	COALESCING PLATES			

SHIPPING WEIGHT
OPERATING WEIGHT
SEPARATOR VOLUME
EFFLUENT TANK VOLUME
SLUDGE VOLUME
COALESCING AREA
OIL STORAGE VOLUME

2691 LBS 16180 LBS 1620 GALLONS 400 GALLONS 48 GALLONS 80 FT<sup>3</sup> 60 GALLONS





### **NOTES**

1. MATERIAL: 3/16" CARBON STEEL COATED INSIDE AND OUT.

2. GASKET: NEOPRENE.

3. HARDWARE: 18-8 STAINLESS STEEL

4. INTERNAL PIPE SCH 80 PVC

REV.		DATE	INIT.		
	Water Ti	reatment Sy	ystems		
GENERAL ARRANGEMENT					PND
MODEL AG-4CS-IP-2H					
PROJECT:					5/26/05
REF: FILE: AG-4CS-IP-2H			SCALE:	1/4" = 1'	
THIS DRAWING IS PROPERTY OF HYDRO QUIP INC. AND MUST NOT BE COPIED, LOANED OR DISTRIBUTED WITHOUT WRITTEN PERMISSION.					

## Operation, Maintenance and Monitoring (OM&M) Manual

### **APPENDIX K**

Transfer Pump TP-301 Information

### **TECHNICAL BROCHURE**

BNPF



# NPE

316L SS

NPE SERIES END SUCTION CENTRIFUGAL PUMPS BOMBAS CENTRÍFUGAS DE SUCCIÓN FINAL SERIE NPE



# A FULL RANGE OF PRODUCT FEATURES UNA GAMA TOTAL DE CARACTERÍSTICAS DEL PRODUCTO

### Superior Materials of Construction: Complete AISI 316L stainless steel liquid handling components and mounting bracket for corrosion resistance, quality appearance, and improved strength and ductility.

### **High Efficiency Impeller:**

Enclosed impeller with unique floating seal ring design maintains maximum efficiencies over the life of the pump without adjustment.

### **Casing and Adapter**

Features: Stainless steel construction with NPT threaded, centerline connections, easily accessible vent, prime and drain connections with stainless steel plugs. Optional seal face vent/flush available.

### **Mechanical Seal:**

Standard John Crane Type 21 with carbon versus silicon-carbide faces, Viton elastomers, and 316 stainless metal parts. Optional high temperature and chemical duty seals available.

**Motors:** NEMA standard open drip-proof, totally enclosed fan cooled or explosion proof enclosures. Rugged ball bearing design for continuous duty under all operating conditions.

The various versions of the NPE are identified by a product code number on the pump label. This number is also the catalog number for the pump. The meaning of each digit in the product code number is shown at left.

## Materiales Superiores de Construcción:

Componentes completos para manejo de líquidos en acero inoxidable AISI 316L y consola para el montaje para resistencia a la corrosión, apariencia de calidad, y fuerza y ductilidad mejoradas.

### Impulsor de Eficiencia Superior: El impulsor encerrado con un diseño único de anillo del sello flotante, mantiene sin ajustes, la eficiencia máxima sobre la vida de la

## Características de la Carcasa y del Adaptador:

Construcción en acero inoxidable con NPT roscado, conexiones centrales, válvulas de fácil acceso, conexiones de cebado y drenaje con enchufes de acero inoxidable. Cara del sello válvula/chorro opcional disponible.

Sello Mecánico: Estándar John Crane Tipo 21 con carbón en contraste con caras de silicón-carbide, elastómeros de Viton, y partes metálicas de acero inoxidable 316. Sellos de alta temperatura y productos químicos están disponibles.

Motores: Estándar NEMA a prueba de goteo, ventilador totalmente encerrado o recintos a prueba de explosión. Diseño robusto de balineras de bolas para trabajo continuo en todas las condiciones de funcionamiento.

Las diferentes versiones de la NPE se identifican con un número de código del producto en la etiqueta de la bomba. Este número es también el número del catálogo para la bomba. El significado de cada dígito en el número de código del producto se muestra a la izquierda.

### NPE PRODUCT LINE NUMBERING SYSTEM LÍNEA DE PRODUCTO NPE SISTEMA DE NUMERACIÓN

## **Example Product Code, Ejemplo Código del Producto**

1 ST 2 C 1 A 4 F

Seal Vent/Flush Option,
Opción de Sello Válvula/ChorroSeal Ven
Mechanical Seal and O-ring

4 = Pre-engineered standard For optional mechanical seal modify catalog order no. with seal code listed below.

Sello Mecánico y Anillo 'O'

4 = Estándar aprobado

Para sello mec<sup>'</sup>anico opcional modificar el número de orden del catálogo con el código del sello anotado abajo.

John Crane Type 21 Mechanical Seal (¾" seal), Sello Mecánico John Crane Tipo 21 (sello de ¾")							
Seal Code, Código del Sello	Rotary, Rotativo	-	Elastomers, Elastómeros	Metal Parts, Partes Metálicas	Part No., Pieza Número		
2	Carlana		EPR		10K18		
4	Carbon	Silicon	Viton	316 SS	10K55		
5	Silicon	Carbide	EPR	31022	10K81		
6	Carbide		Viton		10K62		

### Impeller Option . . . No Adder Required

For optional impeller diameters modify catalog order no. with impeller code listed. Select optional impeller diameter from pump performance curve.

### Código del Impulsor Opcional

Para impulsores con diámetros opcionales modificar el número de orden del catálogo con el código del impulsor anotado. Escoger el impul con diámetro opcional de la curva de funcionamiento de la

Impeller Code,	Pump Size, Tamaño de la Bomba					
Código del	1 x 1¼ - 6	1¼ x 1½ - 6	1½ x 2 - 6			
Impulsor	Diameter	Diameter	Diameter			
K	-	61/8	-			
G	-	515/16	5%			
Н	-	51/2	5			
A	61/8	51/4	43/4			
В	5¾	51/ <sub>16</sub>	45/8			
С	5¾ <sub>16</sub>	47/8	43/8			
D	43/4	45%	41/16			
E	47/16	41/4	3%			
F	41/16	31//8	-			

### **Driver, Conductor**

5 = 3 PH, TEFC 0 = 1 PH,

6 = 575 V, TEFC

### HP Rating, HP Potencia

 $C = \frac{1}{2}HP$  E = 1HP G = 2HP J = 5HP

 $D = \frac{3}{4} HP F = \frac{11}{2} HP H = \frac{3}{4} HP$ 

### Driver: Hertz/Pole/RPM, Conductor: Hercios/Polo/RPM

### 1 = 60 Hz, 2 pole, 3500 RPM

2 = 60 Hz, 4 pole, 1750 RPM 3 = 60 Hz, 6 pole, 1150 RPM

4 = 50 Hz, 2 pole, 2900 RPM 5 = 50 Hz, 4 pole, 1450 RPM

### Material

ST = Stainless steel, Acero inoxidable

 $3 = 1\frac{1}{2} \times 2 - 6$ 

For frame

mounted

substitute the

letters "FRM" in

these positions.

Para la versión

con el armazón

montado,

en estas


sustituya las

letras "FRM"

posiciones.

version.

## PERFORMANCE COVERAGE (60 HZ) ALCANCE DE FUNCIONAMIENTO (60 HZ)



### **NOTES:**

Not recommended for operation beyond printed H-Q curve.

For critical application conditions consult factory.

Not all combinations of motor, impeller and seal options are available for every pump model. Please check with G&L on noncataloged numbers.

All standard 3500 RPM ODP and TEFC motors supplied by Goulds Pumps, have minimum of 1.15 service factor. Standard catalog units may utilize available service factor. Any motors supplied other than Goulds Pumps check available service factor.

### **NOTAS:**


No se recomienda para funcionamiento superior al impreso en la curva H-Q.

Para condiciones de aplicaciones críticas consultar con la fábrica.

No todas las combinaciones de las opciones de motor, impulsor y sello están disponibles para cada modelo de bombas. Por favor verifique con G&L en los números no catalogados.

Todos los motores estándar de 3500 RPM, ODP (abiertos resguardados) y TEFC (totalmente encerrados con enfriamiento forzado) provistos por Goulds Pumps tienen un factor mínimo de servicio de 1,15. Las unidades estándar de catálogo pueden utilizar el factor de servicio disponible. Verificar el factor de servicio disponible de todo motor no provisto por Goulds Pumps.

# NPE CLOSE COUPLED PUMP MAJOR COMPONENTS: MATERIALS OF CONSTRUCTION BOMBA CERRADA ACOPLADA NPE COMPONENTES PRINCIPALES: MATERIALES DE CONSTRUCCIÓN



Item No., Parte No.	Description, Descripción	Materials, Materiales
100	Casing; Carcasa	
101	Impeller; Impulsor	AISI 316LSS;
108	Motor adapter; Adaptador del motor	AISI 316L
108A	Motor adapter seal vent/flush; Sello válvula/chorro del adaptador del moto	Acero inoxidable r
123	Deflector; Deflector	BUNA-N
184	Seal housing; Alojamiento del sello	
184 A	Seal housing seal vent/flush; Sello válvula/chorro del alojamiento del sello	AISI 316L SS; AISI 316L Acero inoxidable
347	Guidevane; Difusor	Accio moxidable
349	Seal ring, guidevane; Anillo del sello, difusor	Viton
370	Socket head screws, casing; Encajes cabezas de tornillos, carcasa	AISI 410 SS; AISI 410 Acero inoxid-
able	,	
371	Bolts, motor; Tornillos, motor	Plated steel; Acero chapeado
383	Mechanical seal; Sello mecánico	**see chart, ver tabla
408	Drain and vent plug, casing; Enchufes de drenaje y válvula, carcasa	AISI 316L SS; AISI 316L Acero inoxid-
able		
412B	O-ring, drain and vent plug; Anillo 'O', enchufe de drenaje y válvula	Viton (Standard, estándar)
513	O-ring, casing; Anillo 'O', carcasa	EPR (Optional, Opcional)
Motor Motor	NEMA standard, 56J flange; NEMA estándar, brida 56J	




1/2, 3/4 and 1 HP 1/2, 3/4 y 1 HP

Footed motor for 5 HP ODP and TEFC, all explosion proof motors, see page 13.

Motor con pie para 5 HP ODP y TEFC, a prueba de explosiones motores, en la página 13.


# NPE FRAME MOUNTED PUMP MAJOR COMPONENTS: MATERIALS OF CONSTRUCTION BOMBA NPE DE ARMAZÓN MONTADO COMPONENTES PRINCIPALES: MATERIALES DE CONSTRUCCIÓN



Item No., Parte No.	Description, Descripción	Materials, Materiales
100	Casing; Carcasa	
101	Impeller; Impulsor	– AISI 316L SS;
108	Adapter; Adaptador	AISI 316L
108A	Motor adapter seal vent/flush; Sello válvula/chorro del adaptador del mot	-Acero inoxidable tor
109	Bearing cover; Cubierta de balineras	Cast iron; Hierro fundido
112	Ball bearing (outboard); Balineras de bolas (exterior)	Steel; Acero
122	Shaft; <i>Eje</i>	AISI 316 SS; AISI 316 Acero inoxidable
138	Lip-seal (inboard); Sello cubierto (interior)	BUNA/steel; BUNA/acero
139	Lip-seal (outboard); Sello cubierto (exterior)	BUNA/steel; BUNA/acero
168	Ball bearing (inboard); Balineras de bolas (interior)	Steel; Acero
184	Seal housing; Alojamiento del sello	AICL 2471 CC
184 A	Seal housing seal vent/flush; Sello válvula/chorro del alojamiento del sello	–AISI 316L SS; AISI 316L Acero inoxidable
228	Bearing frame; Armazón de balineras	Cast iron, Hierro fundido

Item No., Parte No.	Description, Descripción	Materials, Materiales	
304	Impeller locknut; Contratuerca del impulsor	AISI 316 SS;	
347	Guidevane; Difusor	AISI 316 Acero inoxidable	
349	Seal ring, guidevane; Anillo del sello, difusor	Viton	
361	Retaining ring; Anillo de retención	Steel; Acero	
370	Socket head screws, casing; Encaje cabeza del tornillo, carcasa	AISI 410 SS; AISI 410 Acero inoxidable	
370C	Hex head screw, bearing cover; Tornillo de cabeza hexagonal, cubierta de balineras	Plated steel; Acero chapeado	
371	Hex head screw, bearing frame; Tornillo de cabeza hexagonal, armazón de balineras	Plated steel; Acero chapeado	
383	Mechanical seal; Sello mecánico	**see chart; ver tabla	
400	Shaft key; <i>Llave del eje</i>	Steel; Acero	
408	Drain and vent plug, casing; Enchufes de drenaje y válvula, carcasa	AISI 316 SS; AISI 316 Acero inoxid-	
able			
412B	0-ring, drain and vent plug; Anillo 'O', enchufe de drenaje y válvula	Viton (Standard, estándar)	
513	O-ring, casing; Anillo 'O', carcasa	EPR (Optional, Opcional)	

## PERFORMANCE CURVES - 60 HZ, 3500 RPM CURVAS DE FUNCIONAMIENTO - 60 HZ, 3500 RPM



Ordering Code, Código de Pedido	Standard HP Rating, Estándar HP Potencia	lmp. Dia.
Е	1/2	47/16"
D	3/4	4¾
С	1	53/16
В	11/2	5¾
А	2	61//8

**NOTE:** Although not recommended, the pump may pass a  $\frac{1}{16}$ " sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de ½.".


METERS METROS	FEET PIES		<b>/ 1ST Size</b> Jurve ( <i>Curva</i> ) (	( <b>Tamaño) 1 x</b> CN0231R01		peller Selection ecciones del Imp				of
50	<del>-</del> 160		NPSH <sub>R</sub> = F	EET (PIES)		TA: Not recomment TA: No se recomien impreso en la cu	da para funciona			curve.
A 707AL) H		B 5 <sup>3</sup> v"		45 /	181	,6' 8 0 '51 '	10'	)1		
TOTAL DYNAMIC HEAD (CARGA DINAMICA TOTAL) H	100	C 5 <sup>3</sup> 46"				53	51, 50	.\	FF %	
NAMIC HEAD (C	80 - 60							24/0		
TOTAL DY	40	Spec.	8,1	10' 1	2'	× Mp	- · · · · · · · · · · · · · · · · · · ·	77 PHP		
0	- 0	0	10	20	30	40		50	6	0 U.S. GPM
	(	)		5	CAPACITY (	CAPACIDAD) Q	10			m³ vhr

Ordering Code, Código de Pedido	Standard HP Rating, Estándar HP Potencia	lmp. Dia.
F	1/2	4½" spec.
E	3/4	4 <sup>7</sup> / <sub>16</sub>
D	1	43/4
С	11/2	53/16
В	2	5¾
А	3	61/8

**NOTE:** Although not recommended, the pump may pass a 1/16" sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de ½.6".


# PERFORMANCE CURVES - 60 HZ, 3500 RPM CURVAS DE FUNCIONAMIENTO - 60 HZ, 3500 RPM



Ordering Code, Código de Pedido	Standard HP Rating, Estándar HP Potencia	lmp. Dia.
F	3/4	37/8"
E	1	41/4
D	11/2	45//8
С	2	47/8
В	3	51/16
А	3	51/4
Н	5	5½
G	5	515/16

**NOTE:** Although not recommended, the pump may pass a  $\frac{3}{16}$ " sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de ¾6".




Ordering Code, Código de Pedido	Standard HP Rating, Estándar HP Potencia	lmp. Dia.
F	1	37/8"
Е	11/2	41/4
D	2	45//8
B	(3)	51/16

**NOTE:** Although not recommended, the pump may pass a  $\frac{3}{16}$ " sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de <sup>3</sup>/<sub>16</sub>".


# PERFORMANCE CURVES - 60 HZ, 3500 RPM CURVAS DE FUNCIONAMIENTO - 60 HZ, 3500 RPM



Ordering Code, Código de Pedido	Standard HP Rating, Estándar HP Potencia	lmp. Dia.
Е	1	35/8"
D	11/2	41/16
С	2	43//8
В	3	45//8
А	3	43/4
Н	5	5
G	5	5¾

**NOTE:** Although not recommended, the pump may pass a <sup>1</sup>/<sub>32</sub>" sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de 11/32".




Ordering Code, Código de Pedido	Standard HP Rating, Estándar HP Potencia	lmp. Dia.
E	11/2	35/8"
D	2	41/16
В	3	45//8

**NOTE:** Although not recommended, the pump may pass a <sup>11</sup>/<sub>32</sub>" sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de 11/32".


# PERFORMANCE CURVES - 60 HZ, 1750 RPM CURVAS DE FUNCIONAMIENTO - 60 HZ, 1750 RPM



Optional Impeller, Impulsor Opcional				
Ordering Code, Código de Pedido	Dia.			
А	61%"			
В	5¾			
С	53/16			
D	43/4			
E	47/16			
F	41/16			

**NOTE:** Although not recommended, the pump may pass a  $\frac{1}{16}$ " sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de ½.6".




Optional Impeller, Impulsor Opcional				
Ordering Code, Código de Pedido Dia.				
K	61/8"			
G	515/16"			
Н	5½			
А	51/4			
В	51/16			
С	47/8			
D	45//8			
E	41/4			
F	31//8			

**NOTE:** Although not recommended, the pump may pass a  $\frac{3}{16}$ " sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de 3/16".

# PERFORMANCE CURVES - 60 HZ, 1750 RPM CURVAS DE FUNCIONAMIENTO - 60 HZ, 1750 RPM




Optional Impeller, Impulsor Opcional			
Ordering Code, Código de Pedido	Dia.		
G	53/8"		
Н	5		
А	43/4		
В	45//8		
С	43//8		
D	41/16		
E	35//8		

**NOTE:** Although not recommended, the pump may pass a <sup>11</sup>/<sub>32</sub>" sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de <sup>1</sup>/<sub>32</sub>".

# PERFORMANCE CURVES - 50 HZ, 2900 RPM CURVAS DE FUNCIONAMIENTO - 50 HZ, 2900 RPM




Optional Impeller, Impulsor Opcional				
Ordering Code, Código de Pedido	Dia.			
А	61/8"			
В	5¾			
С	53/16			
D	43/4			
E	47/16			
F	41/16			

**NOTE:** Although not recommended, the pump may pass a 1/16" sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de ½16".


## PERFORMANCE CURVES - 50 HZ, 2900 RPM CURVAS DE FUNCIONAMIENTO - 50 HZ, 2900 RPM



Optional Impeller, Impulsor Opcional				
Ordering Code, Código de Pedido Dia.				
K	61/8"			
G	515/16"			
Н	5½			
А	51/4			
В	51/16			
С	47/8			
D	45/8			
E	41/4			
F	37//8			

**NOTE:** Although not recommended, the pump may pass a  $\frac{3}{16}$ " sphere.

**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de ¾6".




Optional Impeller, Impulsor Opcional				
Ordering Code, Código de Pedido	Dia.			
G	53/8"			
Н	5			
А	43/4			
В	45%			
С	43/8			
D	41/16			
E	35%			

**NOTE:** Although not recommended, the pump may pass a <sup>11</sup>/<sub>32</sub>" sphere.


**NOTA:** Si bien no se recomienda, la bomba puede pasar una esfera de <sup>11</sup>/<sub>32</sub>".

## NPE CLOSE COUPLED - DIMENSIONS, WEIGHTS AND SPECIFICATIONS NPE ACOPLE CERRADO - DIMENSIONES, PESOS Y ESPECIFICACIONES

Clockwise Rotation Viewed from Drive End Rotación en Dirección de las Agujas del Reloj Visto desde el Extremo del Motor



ODP and TEFC ½, ¾ and 1 HP (standard), ODP y TEFC ½, ¾ y 1 HP (estándar)



ODP and TEFC 11/2, 2 and 3 HP (standard), ODP y TEFC 11/2, 2 y 3 HP (estándar)

### **SPECIFICATIONS - ESPECIFICACIONES**

### Capacities to:

85 GPM (322L/min) at 1750 RPM 170 GPM (643L/min) at 3500 RPM

### Heads to:

39 feet (12 m) at 1750 RPM 150 feet (46 m) at 3500 RPM

**Working pressures to:** 125 PSIG (9 bars)

**Maximum temperatures to:** 250° F (121° C)

**Direction of rotation:** 

Clockwise when viewed from motor end.

### **Motor specifications:**

NEMA 56J frame, 1750 RPM, ½ HP. 3500 RPM ½ through 5 HP. Open dripproof, totally enclosed fancooled or explosion proof enclosures. Stainless steel shaft with ball bearings.

**Single phase:** Voltage 115/230 ODP and TEFC. (3 and 5 HP model - 230 V only) Built-in overload with auto-reset provided.

**Three phase:** Voltage 208-230/460 ODP, TEFC and EX PROOF.

**NOTE:** For three phase motors, overload protection must be provided in starter unit. Starter and heaters must be ordered separately.

### Capacidades:

85 GPM (322L/min) a 1750 RPM 170 GPM (643L/min) a 3500 RPM

### Cargas:

39 pies (12 m) a 1750 RPM 150 pies (46 m) a 3500 RPM

**Presión de trabajo:** 125 PSIG (9 baras)

**Temperatura máxima:** 250° F (121° C)

### Dirección de rotación:

En dirección de las agujas del reloj visto desde el extremo final del motor.

### Motores:

Armazón 56J NEMA, 1750 RPM ½ HP. 3500 RPM ½ a 5 HP. Cubiertas abiertas resguardadas, totalmente encerradas enfriadas por ventilador o a prueba de explosiones. Eje de acero inoxidable con balineras de bolas.


**Monofásicos:** Voltaje 115/230 ODP y TEFC. (modelo 3 y 5 HP - 230 voltios solamente) Se proporciona protección térmica contra sobrecarga construida con reseteo automático.

**Trifásicos:** Voltaje 208-230/460 ODP, TEFC y EX PROOF.

**NOTA:** Para motores trifásicos se debe de proporcionar la protección térmica contra sobrecarga en la unidad de arranque. El arrancador y los calentadores se deben pedir por separado.

# NPE CLOSE COUPLED WITH FOOTED MOTOR, EXPLOSION-PROOF AND 5 HP MOTORS NPE ACOPLE CERRADO CON MOTOR CON PATAS, MOTORES A PRUEBA DE EXPLOSIÓN Y 5 HP

All Explosion Proof Motors and 5 HP ODP and TEFC
Todos los motores son a prueba de explosiones, 5 HP, ODP
(abiertos resguardados) y TEFC (totalmente encerrados con
enfriamiento forzado)



## Dimensions - Determined by Pump, Dimensiones - Determinadas por la Bomba

Pump, Bomba	Suction, Succión	Discharge, Descarga	НР	w	х	Υ	L	М
1ST	11/4	1	1/2 - 3	3 5/16	43/8	2	4%16	75/16
2ST	11/2	11/4	3/4 - 5	3¾	41/2	21/8	5 1/8	7 1/8
3ST	2	11/2	1 – 5	3¾	45/8	21//8	5 1/8	7 1/8

### Available Motor Weights and Dimensions Pesos y Dimensiones Disponibles del Motor

		Motor	r Weights, Pesos del Mo		Motor	lotor	
HP	1 Pha	se, Mono	fásicos	3 Phase, Trifásicos			C Max. Length,
	ODP	TEFC	EXP	ODP	TEFC	EXP	(Longitud)
1/2	16	21	47	19	18	27	103/16
3/4	19	24	41	21	21	30	107/16
1	22	26	49	23	21	30	1111/16
11/2	28	35	56	27	27	37	1115/16
2	33	39	60	32	33	44	1211/16
3	40	43	_	41	37	_	131/16
5	42	_	_	42	45	_	13%16

Dimensions in inches, weights in pounds. Dimensiones en pulgadas, pesos en libras.


### **NOTES**:

- 1. Pump will be shipped with top vertical discharge position as standard. For other orientations, remove casing bolts, rotate discharge to desired position, replace and tighten 6mm bolts to 5 6 lbs.-ft.
- 2. Motor dimensions may vary with motor manufacturers.
- Dimensions in inches, weights in pounds.
- 4. For explosion proof motor dimensions consult factory for information.
- 5. Not to be used for construction purposes unless certified.

### **NOTAS:**

- 1. Las bombas se transportarán con la descarga vertical superior como estándar. Para otras orientaciones, retirar los tornillos de la carcasa, rotar la descarga a la posición deseada, y reemplazar y apretar los tornillos de 6mm a 5 6 libras-pies.
- Las dimensiones del motor puede que varíen con los fabricantes.
- 3. Dimensiones en pulgadas, pesos en libras.
- Para las dimensiones de los motores a prueba de explosión consultar con la fábrica para información.
- 5. No usar para propósitos de construcción sin certificar.

## NPE FRAME MOUNTED - DIMENSIONS, WEIGHTS AND SPECIFICATIONS NPE ARMAZÓN MONTADO - DIMENSIONES, PESOS Y ESPECIFICACIONES



## SPECIFICATIONS ESPECIFICACIONES

### **Capacities to:**

85 GPM (322L/min) at 1750 RPM 170 GPM (643L/min) at 3500 RPM

### Heads to:

39 feet (12 m) at 1750 RPM 150 feet (47 m) at 3500 RPM

**Working pressures to:** 125 PSIG (9 bars)

**Maximum temperatures to:** 250°F (121°C)

### **Direction of rotation:**

Clockwise when viewed from motor end.

### **Motor specifications:**

T-frame single and three phase. Open drip-proof, TEFC or explosion proof enclosures are available for 60 Hz, 3500 and 1750 RPM operation.

For three phase motors, overload protection must be provided in starter unit. Starter and heaters must be ordered separately.

### Capacidades:

85 GPM (322L/min) a 1750 RPM 170 GPM (643L/min) a 3500 RPM

### Cargas:

39 pies (12 m) a 1750 RPM 150 pies (47 m) a 3500 RPM

## **Presión de trabajo:** 125 PSIG (9 baras)

**Temperatura máxima:** 250°F (121°C)

### Dirección de rotación: En


dirección de las agujas del reloj visto desde el extremo final del motor.

### **Motores:**

Armazón T- monofásico y trifásico. A prueba de goteo, TEFC o recintos a prueba de explosión están disponibles para funcionamiento de 60 Hz, 3500 y 1750 RPM.

Para motores trifásicos se debe de proporcionar la protección térmica contra sobrecarga en la unidad de arranque. El arrancador y los calentadores se deben pedir por separado.

### **NPE-F**



### Dimensions and Weights Dimensiones y Pesos

Dimensions and Weights - Determined by Pump,
Dimensiones y Pesos - Determinados por la Bomba

Dim. "HL" Determined
by Pump and Motor,
Dim. "HL"
Determinadas por la
Bomba y el Motor

Pump, Bomba	Suct. NPT, Succión NPT	Disch. NPT, Descarga NPT	СР	L	w	x	Y	Wt., Peso	Frame, Armazón		
									56	140	180
1ST	11/4	1	1215/16	6 1/16	35/16	43/8	2	221/2	4 %6		6 <sup>7</sup> /16
2ST	1½	11//4	13½	7	3 3/4	4 1/2	2 <sup>1</sup> /8	23	5%		7
3ST	2	1½	13 /2			4 %		23			

### Available Motor and Bedplate Dimensions and Weights, Pesos y Dimensiones Disponibles de la Fundación y del Motor

Motor Frame, Armazón del Motor	на	НВ	HD	HE	HF	HG	НР	Wt. Max., Peso Máx	Shims, Deflector
56 143T 145T	8	26	67/8	31/8	22 3/8	23/8	1	30	1"
182T 184T	10	26	71/4	3 3/4	24	23/4	7//8	43	_

### **NOTES:**

- 1. Pump will be shipped with top vertical discharge position as standard. For other orientations, remove casing bolts, rotate discharge to desired position, replace and tighten 6mm bolts to 5 6 lbs.-ft.
- 2. Motor dimensions may vary with motor manufacturers.
- Dimensions in inches, weights in pounds.
- 4. For explosion proof motor dimensions consult factory for information.
- 5. Not to be used for construction purposes unless certified.

### **NOTAS:**

- 1. Las bombas se transportarán con la descarga vertical superior como estándar. Para otras orientaciones, retirar los tornillos de la carcasa, rotar la descarga a la posición deseada, y reemplazar y apretar los tornillos de 6mm a 5 6 libras-pies.
- 2. Las dimensiones del motor puede que varíen con los fabricantes.
- 3. Dimensiones en pulgadas, pesos en libras.
- 4. Para las dimensiones de los motores a prueba de explosión consultar con la fábrica para información.
- 5. No usar para propósitos de construcción sin certificar.

		Horsepo		Wt.		
Frame Size, Tamaño del		350				
	Single <i>Mono</i>	Phase, fásicos		Phase, sicos	C Max.	Max., Peso Máx.
Armazón	ODP	TEFC	ODP	TEFC		
56	1/2 - 11/2	1/2 - 11/2	1/2 - 1	1/2 - 1	13	45
143T	-	_	11/2	1½	13 3/8	45
145T	2	2	1½ - 3	1½ - 2	14 1/4	52
182T	3	3	5	3	16 %	63
184T	5	5	_	5	181//8	112

### TYPICAL APPLICATIONS, APLICACIONES TÍPICAS

Specifically designed for a broad range of general applications traditionally requiring various materials such as all iron, bronze fitted or all bronze construction.


- Water circulation
- Booster service
- Liquid transfer
- Spray system
- Chillers
- Washing/cleaning systems
- Injection molding cooling
- Reverse osmosis
- Air scrubbers
- Heat exchangers
- Filtration systems
- Jockey pumps
- OEM applications
- General water services

Diseñadas específicamente para una amplia variedad de aplicaciones generales, requiriendo tradicionalmente varios materiales, tales como hierro, bronce empotrado o todas las construcciones de bronce.


- Circulación de agua
- Aumento de presión
- Transferencia de líquidos
- Sistemas de aspersión
- Enfriadores
- Sistemas de lavado/limpieza
- Enfriamiento con molde por inyección
- Osmosis reversa
- Depuradores de aire
- Termopermutadores
- Sistemas de filtración
- Bombas auxiliares
- Aplicaciones OEM
- Servicios generales de agua



Brewery, Fábrica de Cerveza




Car Wash, Lavadero de Autos



Pressure Booster System, Sistema de Aumento de Presión



Pure Water/OEM, Agua Pura/OEM



Chiller, Enfriador



Xylem Inc. 2881 East Bayard Street Ext., Suite A Seneca Falls, NY 13148 Phone: (866) 325-4210

Fax: (888) 322-5877

www.xyleminc.com/brands/gouldswatertechnology

Goulds is a registered trademark of Goulds Pumps Inc. and is used under license. © 2012 Xylem Inc. BNPE R1  $\,$  June 2012





# **Goulds Pumps**

G&L SERIES MODEL NPE/NPE-F

Installation, Operation and Maintenance Instructions





Goulds Pumps is a brand of ITT Corporation.

www.goulds.com

Engineered for life

## Table of Contents

SUBJECT	PAGE
Safety Instructions	3
Important	3
Installation	3
Suction Piping	4
Discharge Piping	4
Motor-To-Pump Shaft Alignment	4
Rotation	
Operation	5
Maintenance	5
Disassembly	5
Reassembly	6
Troubleshooting Chart	6
NPE Standard Repair Parts List	7
Mechanical Seal Application Chart	7
Limited Warranty	8
Declaration of Conformity	24

## Owner's Information

Pump Model Number:								
Pump Serial Num	nber:							
Dealer:								
Dealer Phone No	·:							
Date of Purchase	Date of Purchase:							
Date of Installation:								
Current Readings at Startup:								
1 Ø	3 Ø	L1-2	L2-3	L3-1				
Amps:	Amps:							
Volta.	Volta.							

#### SAFETY INSTRUCTIONS

TO AVOID SERIOUS OR FATAL PERSONAL INJURY OR MAJOR PROPERTY DAMAGE, READ AND FOLLOW ALL SAFETY INSTRUCTIONS IN MANUAL AND ON PUMP.

THIS MANUAL IS INTENDED TO ASSIST IN THE INSTALLATION AND OPERATION OF THIS UNIT AND MUST BE KEPT WITH THE PUMP.



This is a SAFETY ALERT SYMBOL. When you see this symbol on the pump or in the manual, look for one of the following signal words and be alert to the potential for personal injury or property damage.

**DANGER** 

Warns of hazards that WILL cause serious personal injury, death or major property damage.

**A WARNING** Warns of hazards that CAN cause serious personal injury, death or major property damage.

**A** CAUTION

Warns of hazards that CAN cause personal injury or property damage.

NOTICE: INDICATES SPECIAL INSTRUCTIONS WHICH ARE VERY IMPORTANT AND MUST BE FOLLOWED.

THOROUGHLY REVIEW ALL INSTRUCTIONS AND WARNINGS PRIOR TO PERFORMING ANY WORK ON THIS PUMP.

MAINTAIN ALL SAFETY DECALS.



UNIT NOT DESIGNED FOR USE WITH HAZARDOUS LIQUIDS OR FLAMMABLE GASES. THESE FLUIDS MAY BE PRESENT IN CONTAINMENT AREAS.

#### **DESCRIPTION & SPECIFICATIONS:**

The Models NPE (close-coupled) and NPE-F (framemounted) are end suction, single stage centrifugal pumps for general liquid transfer service, booster applications, etc. Liquid-end construction is all AISI Type 316 stainless steel, stamped and welded. Impellers are fully enclosed, non-trimable to intermediate diameters. Casings are fitted with a diffuser for efficiency and for negligible radial shaft loading.

Close-coupled units have NEMA 48 J or 56 J motors with C-face mounting and threaded shaft extension. Framemounted units can be coupled to motors through a spacer coupling, or belt driven.

#### 1. IMPORTANT:

- 1.1. Inspect unit for damage. Report any damage to carrier/dealer immediately.
- 1.2. Electrical supply must be a separate branch circuit with fuses or circuit breakers, wire sizes, etc., per national and local electrical codes. Install an all-leg disconnect switch near pump.

## **A** CAUTION

Always disconnect electrical power when handling pump or controls.

- 1.3. Motors must be wired for proper voltage. Motor wiring diagram is on motor nameplate. Wire size must limit maximum voltage drop to 10% of nameplate voltage at motor terminals, or motor life and pump performance will be lowered.
- 1.4. Always use horsepower-rated switches, contactor and starters.

#### **1.5.** Motor Protection

- 1.5.1. Single-phase: Thermal protection for singlephase units is sometimes built in (check nameplate). If no built-in protection is provided, use a contactor with a proper overload. Fusing is permissible.
- **1.5.2.** Three-phase: Provide three-leg protection with properly sized magnetic starter and thermal overloads.
- 1.6. Maximum Operating Limits:

Liquid Temperature: 250° F (120° C)

125 PSI Pressure:

Starts Per Hour: 20, evenly distributed

1.7. Regular inspection and maintenance will increase service life. Base schedule on operating time. Refer to Section 8.

#### 2. INSTALLATION:

#### 2.1. General

- 2.1.1. Locate pump as near liquid source as possible (below level of liquid for automatic operation).
- **2.1.2.** Protect from freezing or flooding.
- 2.1.3. Allow adequate space for servicing and ventila-
- **2.1.4.** All piping must be supported independently of the pump, and must "line-up" naturally.

## **A** CAUTION

Never draw piping into place by forcing the pump suction and discharge connections.

2.1.5. Avoid unnecessary fittings. Select sizes to keep friction losses to a minimum.

## 2.2. Close-Coupled Units

**2.2.1.** Units may be installed horizontally, inclined or

## **A** CAUTION

Do not install with motor below pump. Any leakage or condensation will affect the motor.

- 2.2.2. Foundation must be flat and substantial to eliminate strain when tightening bolts. Use rubber mounts to minimize noise and vibration.
- 2.2.3. Tighten motor hold-down bolts before connecting piping to pump.

#### 2.3. Frame-Mounted Units

**2.3.1.** It is recommended that the bedplate be grouted to a foundation with solid footing. Refer to Figure 1.




Figure 1

- 2.3.2. Place unit in position on wedges located at four points (two below approximate center of driver and two below approximate center of pump). Adjust wedges to level unit. Level or plumb suction and discharge flanges.
- **2.3.3.** Make sure bedplate is not distorted and final coupling alignment can be made within the limits of movement of motor and by shimming, if necessary.
- 2.3.4. Tighten foundation bolts finger tight and build dam around foundation. Pour grout under bedplate making sure the areas under pump and motor feet are filled solid. Allow grout to harden 48 hours before fully tightening foundation bolts.
- **2.3.5.** Tighten pump and motor hold-down bolts before connecting the piping to pump.

#### 3. SUCTION PIPING:

- **3.1.** Low static suction lift and short, direct, suction piping is desired. For suction lift over 10 feet and liquid temperatures over 120 F, consult pump performance curve for Net Positive Suction Head Required.
- **3.2.** Suction pipe must be at least as large as the suction connection of the pump. Smaller size will degrade performance.
- **3.3.** If larger pipe is required, an eccentric pipe reducer (with straight side up) must be installed at the pump.
- 3.4. Installation with pump below source of supply
  - **3.4.1.** Install full flow isolation valve in piping for inspection and maintenance.

# **A CAUTION** Do not use suction isolation valve to throttle pump.

- 3.5. Installation with pump above source of supply
  - **3.5.1.** Avoid air pockets. No part of piping should be higher than pump suction connection. Slope piping upward from liquid source.
  - **3.5.2.** All joints must be airtight.
  - **3.5.3.** Foot valve to be used only if necessary for priming, or to hold prime on intermittent service.
  - **3.5.4.** Suction strainer open area must be at least triple the pipe area.

- **3.6.** Size of inlet from liquid source, and minimum submergence over inlet, must be sufficient to prevent air entering pump through vortexing. See Figures 2-5.
- **3.7.** Use 3-4 wraps of Teflon tape to seal threaded connections.




Figure 4

Figure 5

#### 4. DISCHARGE PIPING:

- **4.1.** Arrangement must include a check valve located between a gate valve and the pump. The gate valve is for regulation of capacity, or for inspection of the pump or check valve.
- **4.2.** If an increaser is required, place between check valve and pump.
- **4.3.** Use 3-4 wraps of Teflon tape to seal threaded connections.

#### 5. MOTOR-TO-PUMP SHAFT ALIGNMENT:

- **5.1.** Close-Coupled Units
  - 5.1.1. No field alignment necessary.
- 5.2. Frame-Mounted Units
  - **5.2.1.** Even though the pump-motor unit may have a factory alignment, this could be disturbed in transit and must be checked prior to running. See Figure 6.




Figure 6

- **5.2.2.** Tighten all hold-down bolts before checking the alignment.
- **5.2.3.** If re-alignment is necessary, always move the motor. Shim as required.

- 5.2.4. Parallel misalignment shafts with axis parallel but not concentric. Place dial indicator on one hub and rotate this hub 360 degrees while taking readings on the outside diameter of the other hub. Parallel alignment occurs when Total Indicator Reading is .005", or less.
- 5.2.5. Angular misalignment shafts with axis concentric but not parallel. Place dial indicator on one hub and rotate this hub 360 degrees while taking readings on the face of the other hub. Angular alignment is achieved when Total Indicator Reading is .005", or less.
- **5.2.6.** Final alignment is achieved when parallel and angular requirements are satisfied with motor hold-down bolts tight.

**A** CAUTION

Always recheck both alignments after making any adjustment.

#### 6. ROTATION:

- **6.1.** Correct rotation is right-hand (clockwise when viewed from the motor end). Switch power on and off quickly. Observe shaft rotation. To change rotation:
  - **6.1.1.** Single-phase motor: Non-reversible.
  - **6.1.2.** Three-phase motor: Interchange any two power supply leads.

#### 7. OPERATION:

7.1. Before starting, pump must be primed (free of air and suction pipe full of liquid) and discharge valve partially open.

Pumped liquid provides lubrication. If pump is run dry, rotating parts will seize and mechanical seal will be damaged. Do not operate at or near zero flow. Energy imparted to the liquid is converted into heat. Liquid may flash to vapor. Rotating parts require liquid to prevent scoring or seizing.

7.2. Make complete check after unit is run under operating conditions and temperature has stabilized. Check for expansion of piping. On frame-mounted units coupling alignment may have changed due to the temperature differential between pump and motor. Recheck alignment.

## 8. MAINTENANCE:

- **8.1.** Close-Coupled Unit. Ball bearings are located in and are part of the motor. They are permanently lubricated. No greasing required.
- 8.2. Frame-Mounted Units
  - 8.2.1. Bearing frame should be regreased every 2,000 hours or 3 month interval, whichever occurs first. Use a #2 sodium or lithium based grease. Fill until grease comes out of relief fittings, or lip seals, then wipe off excess.
  - **8.2.2.** Follow motor and coupling manufacturers' lubrication instructions.
  - **8.2.3.** Alignment must be rechecked after any maintenance work involving any disturbance of the unit.

#### 9. DISASSEMBLY:

Complete disassembly of the unit will be described. Proceed only as far as required to perform the maintenance work needed.

- 9.1. Turn off power.
- 9.2. Drain system. Flush if necessary.
- **9.3.** Close-Coupled Units: Remove motor hold-down bolts.

Frame-Mounted Units: Remove coupling, spacer, coupling guard and frame hold-down bolts.

- 9.4. Disassembly of Liquid End
  - 9.4.1. Remove casing bolts (370).
  - **9.4.2.** Remove back pull-out assembly from casing (100).
  - 9.4.3. Remove impeller locknut (304).

CAUTION Do not insert screwdriver between impeller vanes to prevent rotation of close-coupled units. Remove cap at opposite end of motor. A screwdriver slot or a pair of flats will be exposed. Using them will prevent impeller damage.

9.4.4. Remove impeller (101) by turning counterclockwise when looking at the front of the pump. Protect hand with rag or glove.

## **▲** CAUTION

Failure to remove the impeller in a counter-clockwise direction may damage threading on the impeller, shaft or both.

- 9.4.5. With two pry bars 180 degrees apart and inserted between the seal housing (184) and the motor adapter (108), carefully separate the two parts. The mechanical seal rotary unit (383) should come off the shaft with the seal housing.
- **9.4.6.** Push out the mechanical seal stationary seat from the motor side of the seal housing.
- 9.5. Disassembly of Bearing Frame
  - 9.5.1. Remove bearing cover (109).
  - 9.5.2. Remove shaft assembly from frame (228).
  - **9.5.3.** Remove lip seals (138 and 139) from bearing frame and bearing cover if worn and are being replaced.
  - **9.5.5.** Use bearing puller or arbor press to remove ball bearings (112 and 168).

#### 10. REASSEMBLY:

- 10.1. All parts should be cleaned before assembly.
- **10.2.** Refer to parts list to identify required replacement items. Specify pump index or catalog number when ordering parts.
- 10.3. Reassembly is the reverse of disassembly.
  - **10.3.1.** Impeller and impeller locknut assembled onto motor shaft with 10 ft-lbs of torque.
- **10.4.** Observe the following when reassembling the bearing frame.
  - 10.4.1. Replace lip seals if worn or damaged.
  - **10.4.2.** Replace ball bearings if loose, rough or noisy when rotated.
  - **10.4.3.** Check shaft for runout. Maximum permissible is .002" T.I.R.
- **10.5.** Observe the following when reassembling the liquid-end.
  - 10.5.1. All mechanical seal components must be in good condition or leakage may result. Replacement of complete seal assembly, whenever seal has been removed, is good standard practice.

It is permissible to use a light lubricant, such as glycerin, to facilitate assembly. Do not contaminate the mechanical seal faces with lubricant.

- 10.5.2. Inspect casing O-ring (513) and replace if damaged. This O-ring may be lubricated with petroleum jelly to ease assembly.
- **10.5.3.** Inspect guidevane O-ring (349) and replace if worn.

#### **A** CAUTION

Do not lubricate guidevane O-ring (349). Insure it is not pinched by the impeller on reassembly.

- **10.6.** Check reassembled unit for binding. Correct as required.
- **10.7.** Tighten casing bolts in a star pattern to prevent Oring binding.

## 11. TROUBLE SHOOTING CHART:

MOTOR NOT RUNNING:

(See causes 1 thru 6)

LITTLE OR NO LIQUID DELIVERED: (See causes 7 thru 17)

POWER CONSUMPTION TOO HIGH: (See causes 4, 17, 18, 19, 22)

EXCESSIVE NOISE AND VIBRATION: (See causes 4, 6, 9, 13, 15, 16, 18, 20, 21, 22)

#### PROBABLE CAUSE:

- 1. Tripped thermal protector
- 2. Open circuit breaker
- 3. Blown fuse
- 4. Rotating parts binding
- 5. Motor wired improperly
- 6. Defective motor
- 7. Not primed
- 8. Discharge plugged or valve closed
- 9. Incorrect rotation
- 10. Foot valve too small, suction not submerged, inlet screen plugged
- 11. Low voltage
- 12. Phase loss (3-phase only)
- 13. Air or gasses in liquid
- 14. System head too high
- 15. NPSHA too low:
  Suction lift too high or suction losses excessive.
  Check with vacuum gauge.
- 16. Impeller worn or plugged
- 17. Incorrect impeller diameter
- 18. Head too low causing excessive flow rate
- 19. Viscosity or specific gravity too high
- 20. Worn bearings
- 21. Pump or piping loose
- 22. Pump and motor misaligned

#### NPE STANDARD REPAIR PARTS LIST


Item No.	Description	Materials of Construction
100	Casing	
101	Impeller	
108A	Motor adapter with foot	AISI 316L
108B	Motor adapter less foot	Stainless Steel
108C	Motor adapter with foot and flush	
108D	Motor adapter less foot with flush	
123	Deflector	BUNA-N
184A	Seal housing std.	- AISI 316L S.S.
184B	Seal housing with seal flush	AISI 3 I OL 3.3.
240	Motor support	300 S.S.
240	Rubber channel	Rubber
304	Impeller locknut	AISI 316 S.S.
347	Guidevane	AISI 316L S.S.
		Viton (standard)
349	Seal-Ring, guidevane	EPR
		BUNA
370	Socket head screw, casing	AISI 410 S.S.
371	Bolts, motor	Steel/plated
383	Mechanical seal	
408	Drain and vent plug, casing	AISI 316 S.S.
		Viton (standard)
412B	O-Ring, drain plugs	EPR
		BUNA
		Viton (standard)
513	O-Ring, casing	EPR
		BUNA

## MECHANICAL SEAL APPLICATION CHART

Item 383 Mechanical Seal (5/8" seal)						
Rotary	Stationary Elastomers Metal Parts Part					
Carbon		EPR		10K18		
Carbon	Sil-Carbide	Viton	316SS	10K55		
Sil-Carbide	SII-Carbide	EPR	31033	10K81		
311-Carbide		Viton		10K62		

**NOTE:** Close coupled units supplied with  $\frac{1}{2}$  HP 1750 RPM,  $\frac{1}{2}$  - 3 HP Explosion Proof or 5 HP motors, utilize motor adapter less foot and a footed motor.

**NOTE:** Frame mounted units (NPE-F) utilize the XS Power frame and motor adapter less foot. For repair parts for the power frame refer to the XS-Power frame repair parts page in the parts section of your catalog. To order the power frame complete order item 14L61.





## **Commercial Water**

#### **GOULDS PUMPS LIMITED WARRANTY**

This warranty applies to all water systems pumps manufactured by Goulds Pumps.

Any part or parts found to be defective within the warranty period shall be replaced at no charge to the dealer during the warranty period. The warranty period shall exist for a period of twelve (12) months from date of installation or eighteen (18) months from date of manufacture, whichever period is shorter.

A dealer who believes that a warranty claim exists must contact the authorized Goulds Pumps distributor from whom the pump was purchased and furnish complete details regarding the claim. The distributor is authorized to adjust any warranty claims utilizing the Goulds Pumps Customer Service Department.

#### The warranty excludes:

- (a) Labor, transportation and related costs incurred by the dealer;
- (b) Reinstallation costs of repaired equipment;
- (c) Reinstallation costs of replacement equipment;
- (d) Consequential damages of any kind; and,
- (e) Reimbursement for loss caused by interruption of service.

#### For purposes of this warranty, the following terms have these definitions:

- (1) "Distributor" means any individual, partnership, corporation, association, or other legal relationship that stands between Goulds Pumps and the dealer in purchases, consignments or contracts for sale of the subject pumps.
- (2) "Dealer" means any individual, partnership, corporation, association, or other legal relationship which engages in the business of selling or leasing pumps to customers.
- (3) "Customer" means any entity who buys or leases the subject pumps from a dealer. The "customer" may mean an individual, partnership, corporation, limited liability company, association or other legal entity which may engage in any type of business.

#### THIS WARRANTY EXTENDS TO THE DEALER ONLY.



SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.

April, 2008

© 2008 ITT Corporation

Engineered for life

	<b>Operation</b>	Maintenance	and Monitoring	(OM&M)	) Manual
--	------------------	-------------	----------------	--------	----------

APPENDIX L

Bag Filter Information

# Model NCO Bag or Cartridge Filter Housings

Low cost filter housings for flow rates to 100 gpm\*

NCO high-capacity filters offer an exceptional value in basic filtration applications. Offered in a size 2 and size 12 bag housing, the NCO is also available with our Platinum 700 cartridge series.


NCO housings provide large dirt-holding capacity combined with a rugged design rated to 150 psi. The housings incorporate a newly designed hinged, eyenut cover that is easily removed, reducing time spent on bag or cartridge change-out. The NCO bag housing offers versatility for any piping arrangement, utilizing our unistyle design (side and bottom outlet). Two connection sizes are available for both bag and cartridge filters.

The NCO housings are electropolished creating a smooth, easy-to-clean surface. Customize them with several options including, gauges and switches. A variety of filter bags or cartridges (rated  $0.5\mu$  absolute to  $100\mu$  nominal) can be utilized in this housing. Keep your filtration process cost effective without sacrificing quality.

## **Features**

- Permanently piped housings are opened without special tools
- Carbon or stainless steel housings
- Covers are O-ring sealed
- O-ring seals: Buna N, EPR and Viton®
- 150 psi rated housing
- Heavy-duty basket, over 50% open area
- Uses standard number 1, 2 or 12 size bags and 500 or 700 series cartridges







- \* Based on housing only. Fluid viscosity, filter bag used, and expected dirt loading should be considered when sizing a filter.
- Filter selection surface area is:
  2.3 square feet (number 1 size bag),
  4.4 square feet (number 2 size bag),
  5.6 square feet (number 12 size bag)
  85 square feet (500 series cartridge)
  125 square feet (700 series cartridge)
- 1-1/2-inch or 2-inch NPT inlet and outlet
- 1/4-inch NPT vent connection
- Adjustable leg assembly

# How To Order

Build an ordering code as shown in the example.









## Rosedale Products, Inc.

3730 W. Liberty Rd, Ann Arbor, MI 48103 Tel: 800-821-5373 or 734-665-8201

Fax: 734-665-2214

http://www.rosedaleproducts.com/ E-mail: filters@rosedaleproducts.com




Call us today for our complete catalog or visit our web site to see our entire product line.

Sheet NCO-100 5M605 Printed in USA

## **APPENDIX M**

Liquid Phase Organoclay Information





1180 St. Charles Street Elgin, IL 60120

Phone: 1-800-787-7531 Emergency Phone: 1-847-741-1600 Telex\*: 1-847-741-1616

Hydrosil HS-200

Identity (Trade Name As Used On Label)



MSDS Number\*

CAS Number\*

January 1, 2012 to December 31, 2012

Date Prepared

William J. Waldschmidt

Prepared By\*

Blank spaces are not permitted. If any item is not applicable, or no information is available, the space must be marked to indicate that. Note:

## **SECTION 1 - MATERIAL IDENTIFICATION AND INFORMATION**

COMPONENTS - Chemical Name & Common Names (Hazardous Components 1% or greater; Carcinogens 0.1% or greater)	%*	OSHA PEL	ACGIH TLV	OTHER LIMITS RECOMMENDED
N-Hexadecyl-N,N,N-trimethylammonium chloride	4.16%	N/A	N/A	None
Non-Hazardous Ingredients zeolite/water	95.84%			
TOTAL	100			

## **SECTION 2 - PHYSICAL / CHEMICAL CHARACTERISTICS**

Boiling Point N/A	Density 57.0-59.0 pounds/cubic foot
Vapor Pressure (mm Hg and Temperature) $N/A$	Melting Point N/A
Vapor Density (Air = 1) N/A	Evaporation Rate ( = 1) N/A
Solubility In Water N/A	Water Reactive N/A

Appearance

white irregularly shaped solid, no odor

## **SECTION 3 - FIRE AND EXPLOSION HAZARD DATA**

Flash Point and Method Used N/A	Auto-Ignition Temperature $N/A$	Flammability Limits in Air % by Volume  N/A	LEL N/A	UEL N/A
---------------------------------	---------------------------------	---	---------	---------

Extinguisher Media

If involved in fire, flood with plenty of water

Special Fire

None Fighting Procedures

Unusual Fire and

**Explosion Hazards** Products of combustion are toxic

STABILITY	Conditions		ZARD DATA			
■ Stable □ Unstable	To Avoid	None known				
Incompatability (Materials to A	,	Strong oxidiz	ing and reduci	ng agents		
Hazardous Decomposition	Products	Organic chlor	ides, amines,	hydrogen chlo	ride may be pro	oduced
HAZARDOUS  ☐ May Occur  ☐ Will Not Oc		Conditions To Avoid	one known			
SECTION	ON 5 - HI	EALTH HAZARI	D DATA			
PRIMARY RO	UTES	☐ Inhalation☐ Skin Absorption	☐ Ingestion ■ Not Hazardous	CARCINOGEN LISTED IN	☐ NTP ☐ IARC Monograph	☐ OSHA ■ Not Listed
HEALTH HAZARDS		Acute None		·		
		Chronic None				
Signs and Syr of Exposure	nptoms Non	ie				
Medical Condi Generally Agg	tions ravated by Expo	osure None				
EMERGENCY	FIRST AID PR	OCEDURES - Seek medical	assistance for further treatm	ent, observation and suppo	rt if necessary	
Eye Contact	Immedia	ately flush wi	th large amoun	ts of water f	or 15 minutes	
	Get imr	mediate medica	l attention			
Skin Contact	Wash af	ffected areas	with plenty of	water and so	ap if available	e, for several
	minutes	s. Seek medica	l attention if	irritation d	evelops.	
Inhalation	Remove	from area to	fresh air. See	k medical att	ention if respi	iratory irritation
	develor	ps or if breat	hing becomes d	ifficult.		
Ingestion	Give 3-	-4 glasses of	milk (if unava	ilable, give	water), but do	not induce
	vomitir	ng. If vomitin	g does occur,	give fluids a	gain. Seek med:	ical attention.
SECTION	ON 6 - C	ONTROL AND F	PROTECTIVE M	EASURES		
Respiratory Pr (Specify Type)		eat as low lev	el nuisance du	ıst, Use NIOSH	/MSA #TC-21C-1	32
Protective Glo	V00	er or neoprene	when needed	Eye Protection Use	safety glasses	with side shields
VENTILATION TO BE USED	l	Local Exhaust	<b>■</b> M	echanical (general)	☐ Special	
IO BE USED		Other (specify) Non	e			
Other Protectiv		re wash, safety	y shower, prote	ective clothin	ng as appropria	ite
Hygienic Work Practices						
	2N.7 DI	DECAUTIONS F	OD CAFE HAN		ELLEAK DDOC	EDUDES
Steps to be Tal					E/ LEAK PROCI	EDUKE9
is Spilled Or Re		Keep containe	rs closed unti	l used.		
Waste Disposa	d .					
Methods	" Dispo	se of in accor	dance with lo	ocal, state, a	nd federal reg	ulations.
Precautions to	ho Tokon					
in Handling and	d Storage			ysical damage	. Store in a co	ool dry area in
Other Precaution	nne	losed containe				
and/or Special		et carbon/coal	removes oxyge	n from air ca	using a severe	hazard to
NFPA	WC	orkers inside	carbon vessels	or confined	spaces	
INCEA						

## **HS-200 Series**

Media to remove oil, heavy metals and similar organics from water.

The Key to successful water treatment and filtration is selecting the right combination of media and hardware. For treatment of hydrocarbons, heavy metals, and other organic contaminants, the optimal solution is eficient oil and water separation followed by the HS-200 series. Because HS-200 series can absorb up to 70% of its weight in hydrocarbons, its life inside a still bed canister is much longer than that of other process media such as granular activated carbon.

## **HS-200 King of Liquid Filtration**

- No swelling upon water exposure
- More active ingredients per cubic foot then other organoclays
- Can be used at full strength or custom blended
- Prolongs life of activated carbon and resins thereby reducing costs and increasing efficiency
- Cost effective and environmentally sound technology

## **HS-200 Series Veratility**

## • Free Standing Mode:

Used on its own, HS-200 series can be loaded in drums for use as an efficient stillbed filtration medium. Other applications include tank cleaning, oil spill mitigation, and lining/capping projects.

## • Pre-Treatment Mode

HS-200 Series can be used upstream to enhance the performance and extend the useful life of other filtration processes and media such as reverse osmosis, activated carbon and resins.

#### • Post-Treatment Mode:

HS-200 Series utilized downstream of an oil-water separator or coalesce filter, has the ability to act as an effective cleaning and polishing agent.

The liquid phase filtration media HS-200 shall be 8 x 14 mesh zeolite impregnated with no less than 125 milimoles cetyl trimethyl ammonium chloride per kilogram of zeolite. The density of the product shall be 57-59 pounds per cubic foot.

## **HS-200 Removes**

## **Oil and Grease**

All types

## **Heavy Metals**


- Aluminum
- Cadmium
- Chromium
- Copper
- Lead
- Mercury
- Nickel
- Selenate
- Zinc

# **Hydrocarbons and other contaminants**

- Acenaphthene
- Ammonia
- Anthracene
- Benzo (a) Anthracene
- Benzo (b) Flouranthene
- Benzo (a) Pyrene
- Benzo (g,h,i) Perylene
- BOD's
- BTEX
- 4-chloro-3-Methylphenol
- Chromate
- Chrysene
- COD's

- 1,1 Dichloroethane
- 1,2 Dichloroethane
- 1,4 Dioxane
- Flouranthene
- Flourine
- Gas Range Hydrocarbons
- 2-Methylnaphthalene
- Motor Oil
- Naphthalene
- PCP (pentachlorophenol)
- Phenanthrene
- Phenolics (recoverable)
- Pyrene
- TCE
- TOC
- Total Phosphorus
- TPH (Total-Petroleum Hydrocarbons)
- TSS's
- Vinyl Chloride

Constituents have had a 95%+ Reductions when treated with these media



The Media Is The Key....

The KEY to successful water treatment and filtration is selecting the right combination of media and hardware. For treatment of hydrocarbons, heavy metals, and other organic contaminants, the optimal solution is efficient oil and water separation followed by the HS-200 series. Because HS-200 series can adsorb up to 70% of its weight in hydrocarbons, its life inside a still bed canister is much longer than that of other process media such as granular activated carbon.

## **HS-200 KING OF LIQUID FILTRATION**

- NO SWELLING UPON WATER EXPOSURE
- MORE ACTIVE INGREDIENTS PER CUBIC FOOT THEN OTHER ORGANOCLAYS
- CAN BE USED AT FULL STRENGTH OR CUSTOM BLENDED
- PROLONGS LIFE OF ACTIVATED CARBON AND RESINS THEREBY REDUCING COSTS AND INCREASING EFFICIENCY
- COST EFFECTIVE AND ENVIRONMENTALLY SOUND TECHNOLOGY

HYDROSIL INTERNATIONAL LIMITED is a modified Zeolite provider setting new standards in economical water treatment, including treatment of processed water and wastewater. Hydrosil's corporate headquarters and manufacturing facilities are located in Elgin, IL. With over 16 years of filtration experience, we specialize in our own Zeolite based organoclay products called HS-200.

ZEOLITE BASE Zeolite is the base of our filtration media. Zeolite belongs to a family of naturally occurring volcanic minerals with unique physical and chemical characteristics. Generally speaking, natural zeolites are hydrated aluminosilicates. They consist of an open, three-dimensional cage-like structure and a vast network of open channels extending throughout. Loosely bound, positively charged atoms called cations are attached at the junctures of the negatively charged aluminosilicate lattice structure. Zeolite has a crystalline structure (similar to a honeycomb) consisting of a network of interconnected tunnels and cages. Zeolite has a high specific surface area; it's rigid framework eliminates shrinking and swelling. Perhaps the most commercially valuable and dynamic property of zeolite is its cation exchange capacity. The most common exchangeable cations found in zeolite molecules are ammonia, sodium, calcium, potassium, and magnesium, many which are desirable in numerous biological and industrial processes. The ability to release beneficial elements while capturing and binding other, often less desirable, materials makes zeolite an ideal media for selective adsorption of certain elements and compounds from soil, water and air.

The cornerstone of Hydrosil International's success is the HS-200 series, the future of Zeolite based organoclays. Our proprietary modification process transforms high-grade Zeolite into a powerful, selective water treatment adsorbent that bonds with hydrocarbons, organics and other contaminants upon contact, locking them inside its molecular structure. Hydrosil's Contaminant Encapsulation Technology yields a granular filtration media capable of adsorping approximately 70% of its weight in hydrocarbons. Extensive application use and field testing of the HS-200 series, analyzed by independent laboratories, has demonstrated removal of a wide range of contaminants to nondetectable levels. The resulting discharge water meets or exceeds typical regulatory requirements.

## **HS-200 Applications**

HS-200 series has been used against a wide array of industrial waste streams:

- Creosote Plants
- Wood Processing
- Pulp and Paper Mills
- Carbon Black Plants
- Oil Production
- · Firefighting Academy
- Industrial Laundry Services
- Shipyards

BTEX

Cadmium

Chromate

Chromium

4-Chloro-3-Methylphenol

- Plastic Manufactures
- Tank and Storage Vessel Cleaning
- Pesticide Manufacturers
- Condensate Systems
- Pipeline Pressure Testing Runoff
- Industrial Water Runoff





## The HS-200 Series Blends

HS-250 a blend of HS-200 and 8x30 Anthracite Coal

Contains 66% more active ingredient per cubic foot than activated clays on the market

HS-250-AC a blend of HS-200 and 6x12 Virgin Activated Carbon

This blend is the best of both worlds with the added benefits of Virgin Activated Carbon

HS-270 a blend of HS-200 and 8x30 Anthracite Coal

· Was created to be a 1 to 1 replacement for Organoclays/Activated Clays on the market that have swelling issues

## HS-200 Series, the Results Are In

The following Constituents have had a 95%+ Reduction when treated with the HS-200 series

Chrysene Acenaphthene COD's Acenaphthylen Ammonia Copper Anthracene 1.1 Dichloroethane 1,2 Dichloroethene Arsenate 1.4 Dioxane Arsenic Benzo (a) Anthracene Fluoranthene Benzo (b) Fluoranthene Fluorene Benzo (a) Pyrene Gasoline Range Hydrocarbons Benzo (g,h,i) Perylene Lead BOD's

Motor Oil

Nickel

Naphthalene

Mercury 2-Methylnaphthalene Zinc

PCP (Pentachlorophenol)

Phenanthrene

Phenolics (recoverable)

Pyrene Selenate

TCE (Trichloroethylene)

TOC (Total Organic Compounds)

Total Phosphorous

TPH (Total-Petroleum Hydrocarbons)

TSS's

Vinyl Chloride



1180 St. Charles St. Elgin, IL 60120 phone: 1-847-741-1600 phone: 1-800-PURPLE.1 Hydrosilintl.com

## **HS-200 Series Versatility**


- Free Standing Mode:
   Used on its own, HS-200 series can be loaded in drums for use as an efficient stillbed filtration medium. Other applications include tank cleaning, oil spill mitigation, and lining/capping projects.
- Pre-Treatment Mode:
   HS-200 Series can be used upstream to enhance the performance and extend the useful life of other filtration processes and media such as reverse osmosis, activated carbon and resins.
- Post-Treatment Mode:
   HS-200 Series utilized downstream of an oil-water separator or coalesce filter, has the ability to act as an effective cleaning and polishing agent.

## **Application Parameters:**

Bulk Density: 58 lbs/Ft³ (928 kg/M³)
10 - 15 minutes depending on solubility of contaminant(s) to be removed.

Temperature Range: 33 - 170 F° (1 - 77 C°) pH Range: 4 - 10

Pre-treatment prior to activated carbon and ion exchange resin columns; Pre-treatment for RO systems; Polishing for oil and water separators and DAF units.






# Operation, Maintenance and Monitoring (OM&M) Manual

## **APPENDIX N**

Liquid Phase Carbon Information



# EI-30R | EI-840R

# **Product Description**

Envirotrol's EI-30R and EI-840R are reactivated liquid phase carbons from Envirotrol's custom segregated reactivation process. EI-30R is our premium grade reactivated carbon which provides superior performance in the removal of a wide variety of organic contaminants in liquid applications. Our EI-840R is a reactivated carbon that has excellent adsorptive properties for a wide range of applications. These products will provide performance equivalent to virgin carbon but at a significant cost savings.

EI-30R and 840R grades of carbon are available in 1000 lb bulk sacks or in bulk. All other packaging is available at a premium. EI-30R and EI-840R are produced by steam activated process and are therefore excluded from IATA#395, IMCO CLass 4.2 or UN1362, Freight Classification: NMFC #40560; UFC - #20460.



## WET ACTIVATED CARBON DEPLETES OXYGEN FROM AIR.

All precautions must be taken since dangerously low levels of oxygen may be encountered.

# **Product Specifications**

	<u>EI-30R</u>	EI-840R
lodine Number (mg/g) min.:	900	750
Molasses Number (Typical):	200	200
Abrasion Number (Ro-Tap) min.:	75	75
Moisture (as packed, weight %):	2.0%	2.0%
U.S. Standard Sieve Size:	8x30	8x40
Greater than 8 mesh (max.):	15%	15%
Less than 30 mesh (max.):	5%	5%
Apparent Density (dense packing, g/ml):	.4752	.47575
Total Surface Area (N <sub>2</sub> BET, m <sup>2</sup> /g):	900-1000	750-900

The information and recommendations in this publication are, to the best of our knowledge, reliable. Suggestions made concerning uses or applications are only the opinion of Envirotrol Inc., and users should make their own tests to determine the suitability of these products for their own particular purposes. However, because of numerous factors affecting results, Envirotrol Inc., makes no warranty of any kind, expresses or implied, including those of merchantability and fitness for purpose, other than that the material conforms to its applicable current Standard Specifications. Statements herein, therefore, should not be construed as representations or warranties.

The responsibility of Envirotrol for claims arising out of breach of warranty, negligence, strict liability, or otherwise is limited to the purchase price of the materials. Statements concerning the use of the products or formulations described herein are not to be construed as recommending the infringement of any patent and no liability for infringement arising out of any such use is assumed.

Standards specifications, although, current at the time of publication, are subject to change without notice.

Shipping Infortmation: F.O.B. Points: Rochester, PA

EI-30R | EI-840R

# Operation, Maintenance and Monitoring (OM&M) Manual

## **APPENDIX O**

Liquid Flow Meter/ Transmitter Information



Flow Meters



Model 1100

## **Turbine Flow Meter**

- Accurate and repeatable flow measurement from 0.6 3 gpm (20 100 BPD) to 500 5,000 gpm (17,000 171,000 BPD)
- Capable of electronic integration, to provide displayed flow rate, totalization, current or voltage outputs
- Capable of measuring flow on piping systems from 1/2" to 10"
- Superior materials of construction for high performance in aggressive environments
- Only one moving part for reduced maintenance costs

1-800-235-1638 www.blancett.com







## Introduction

The Model 1100 Turbine Flow Meter is designed to withstand the demands of the most rigorous flow measurement applications. Originally developed for the secondary oil recovery market, the Model 1100 is an ideal meter for liquid flow measurement on or off the oilfield.

The meter features a rugged 316 stainless steel housing and rotor support assemblies, CD4MCU stainless steel rotor, and abrasive-resistant tungsten carbide rotor shaft and journal bearings. The Model 1100 maintains measurement accuracy and mechanical integrity in the corrosive and abrasive fluids commonly found in oil field water flood projects and many industrial applications.

Designed to operate with the Model B2800 Flow Monitor, the Model 1100 turbine meter meets a wide range of measurement requirements. This makes it ideal for applications such as pipelines, production/injection fields, in-situ mining operations, offshore facilities, and other industrial applications.



#### **Features**

- Offers accurate and repeatable flow measurement in ranges from 0.6 to 5,000 GPM (20 to 171,000 BPD)
- Cost-effective solution for turbine flow meter applications
- Rugged 316 stainless steel construction offers long service life in severe operating environments
- Available in NPT, BSP, Victaulic®, Flange, or Hose Barbed end connections
- NIST traceable calibration
- Installation in pipe sizes from 1/2" to 10"
- Integrate electronically with B2800 Flow Monitor,
   K-factor Scaler, or the F to I/F to V Intelligent Converter
- Field replaceable repair kits allow for turbine replacement without loss of accuracy

## **Operating Principle**

Fluid entering the meter passes through the inlet flow straightener which reduces its turbulent flow pattern and improves the fluid's velocity profile. Fluid then passes through the turbine, causing it to rotate at a speed proportional to fluid velocity. As each turbine blade passes through the magnetic field at the base of the transducer, an AC voltage pulse is generated in the pickup coil. These pulses produce an output frequency proportional to the volumetric flow through the meter.

## Specifications

#### **Materials of Construction:**

Body; 316 Stainless Steel Rotor; CD4MCU Stainless Steel Rotor Support; 316 Stainless Steel Rotor Shaft; Tungsten Carbide

**Turndown Ratio: 10:1** 

Flow Accuracy: ±1% of reading for %" and larger meters

 $\pm 1\%$  of reading over the upper 70% of the measuring range for %, 1/2" and 3/4" meters

Repeatability: ± 0.1%

Calibration: Water (NIST traceable calibration)
Pressure Rating: 5,000 psi (maximum)
Turbine Temperature: -150 °F to +350 °F (-101 °C to 177 °C)

End Connections: NPT, BSP, Victaulic®,

Flange, Hose Barbed


**Approvals:** CSA Class I Div 1, Groups C & D;


Class II Div 1, Groups E, F & G: intrinsically safe\* CSA Class I Div 1 Groups C,D; Complies to UL 1203

and CSA 22.2 No. 30

Met Labs File No. E112860 (For Explosion proof models only)

\*Contact factory for ordering options





## Model 1100 Turbine Meters & Repair Kits

Part	Bore	End	Max.		Flow Ranges		Recommended Strainer	Approx. K-Factor	Meter	End to End	Repair Kit
Number*	Size	Connections	PSI	GPM	BPD	M <sup>3</sup> /D	Mesh	Pulses/Gal	Weight	Length	Part Number
B110-375-1/2	3/8"	1/2" Male NPT	5,000	0.6 - 3	20 - 100	3.3 - 16	60	18,000	1	3"	B251-102
B110-500-1/2	1/2"	1/2" Male NPT	5,000	0.75 - 7.5	25 - 250	4.1 - 41	60	13,000	1	3"	B251-105
B110-750-1/2	3/4"	1/2" Male NPT	5,000	2 - 15	68 - 515	10.9 - 81.75	60	3,300	1	3"	B251-108
B110-375	3/8"	1" Male NPT	5,000	0.6 - 3	20 - 100	3.3 - 16	60	18,000	2	4"	B251-102
B110-500	1/2"	1" Male NPT	5,000	0.75 - 7.5	25 - 250	4.1 - 41	60	13,000	2	4"	B251-105
B110-750	3/4"	1" Male NPT	5,000	2 - 15	68 - 515	10.9 - 81.75	60	3,300	2	4"	B251-108
B110-875	7/8"	1" Male NPT	5,000	3 - 30	100 - 1,000	16 - 160	60	3,100	2	4"	B251-109
B111-110	1"	1" Male NPT	5,000	5 - 50	170 - 1,700	27.25 - 272.5	40	870	2	4"	B251-112
B111-115	1-1/2"	1-1/2" Male NPT	5,000	15 - 180	515 - 6,000	82 - 981	20	330	5	6"	B251-116
B111-121	1-1/2"	2" Male NPT	5,000	15 - 180	515 - 6,000	82 - 981	20	330	6	6"	B251-116
B111-120	2"	2" Female NPT	5,000	40 - 400	1,300 - 13,000	218 - 2,180	20	52	14	10"	B251-120
B111-130	3"	3" Grooved End	800	60 - 600	2,100 - 21,000	327 - 3,270	10	57	15	12-1/2"	B251-131
B111-140	4"	4" Grooved End	800	100 - 1,200	3,400 - 41,000	545 - 6,540	10	29	20	12"	B251-141
B111-160	6"	6" Grooved End	800	200 - 2,500	6,800 - 86,000	1,090 - 13,626	4	7	46	12"	B251-161
B111-180	8"	8" Grooved End	800	350 - 3,500	12,000 - 120,000	1,363 - 19,076	4	3	56	12"	B251-181
B111-200	10"	10" Grooved End	800	500 - 5,000	17,000 - 171,000	2,725 - 27,252	4	1.6	80	12"	B251-200

<sup>\*</sup> Part number includes turbine meter and standard magnetic pickup. For other pickup options, see table below. Note: Insert a "C" before dash for turbine meters with explosion proof rating. No pick-up included. Example: B111C-110

#### Installation

The Model 1100 Turbine Meter is simple to install and service. It operates in any orientation (horizontal to vertical) as long as the "flow direction" arrow is aligned in the same direction as the actual line flow. For optimum performance, the flow meter should be installed with a minimum of 10 diameters upstream straight pipe length and 5 diameters downstream straight pipe length.

## Repair Kits

Factory calibrated replacement kits are available for field or factory service. This is of particular importance when fluids contain abrasive contaminants and meters require frequent service.

A repair kit contains two retaining rings, two rotor supports, one rotor assembly, and a K-factor tag. The rotor support assembly is retained in proper position within the meter body by retainer rings. These rings allow for quick and easy disassembly and replacement of the meter's internal components. The Model 1100 repair kits are designed and manufactured for use with Blancett turbines and other flow meters of similar design; contact the factory or refer to Form #4300 for further details.

#### K-factor

The K-factor represents the number of output pulses transmitted per gallon of fluid passing through the turbine meter. Each turbine has a unique K-factor. However, turbine meters are not functionally consistent throughout the full flow range of the meter.


There are several forms of "friction" inherent in turbine meters that retard the rotational movement of the turbine rotor. These frictional forces include: magnetic drag, created by electromagnetic force of pickup transducers; mechanical drag, due to bearing friction; and viscous drag, produced by flowing fluid. See charts at right.


As flow increases, the frictional forces are minimized and the free-wheeling motion of the turbine rotor becomes more linear (proportional to flow). The K-factor becomes relatively constant and linear throughout the balance of the linear flow range. This is approximately a 10:1 turndown ratio from the maximum flow rate down to the minimum flow rate.

## Model 1100 Pickup Options

Part Number	Magnetic Pickup	Temperature Range
B111109	Standard	-150 °F to +330 °F (-101 °C to +165 °C)
B220111	High Temperature	-150 °F to +450 °F (-101 °C to +232 °C)
B220210	with Preamplifier	-20 °F to +160 °F (-29 °C to +71 °C)
B220243	Intrinsically Safe, FM rated	-150 °F to +330 °F (-101 °C to +165 °C)
B111126	ATEX (Ex) II 1G; EEx ia IIC T5	-58 °F to + 248 °F (-50 °C to +120 °C)

#### Typical K-factor Curve (Pulses per Gallon)





## Related Blancett Products

## **B2800 Flow Monitor**

- Microprocessor-based flow monitor and totalizer
- Use with Blancett turbine flow meters as well as other flow meters with a frequency output
- Battery (1.5 VDC) and loop-powered (4-20 mA) versions
- Meter, remote, panel and swivel mounting options
- Hand-held and explosion-proof models also available
- CSA and CE approved
- Class 1, Division 1 (Intrinsically Safe) certification



## K-Factor Scaler Frequency Divider

- Scales turbine meter output to desired engineering units
- Amplifies turbine meter pulse output
- Converts frequency outputs into recognizable units for PLCs and other devices
- Switch-selectable or programmable versions available
- CSA approved





## F to I / F to V Intelligent Converter

- Converts turbine frequency output into scaled analog output
- Linearized output capability
- Choice of 4-20 mA or 0-5 VDC output
- Enables integration with data acquisition devices
- Frequency measurement accuracy ±1%
- CSA approved





- 8635 Washington Avenue, Racine, WI 53406-3738 U.S.A.
- Toll Free: 800-235-1638 Technical Toll Free: 877-722-4631 Tel: 262-639-6770 Fax: 262-639-2267

Flow Meters

**■** E-mail: info@blancett.com

Blancett is a registered trademark of Racine Federated Inc. Victaulic is a registered trademark of Victaulic Company. CSA is a registered trademark of Canadian Standards Association. MET is a registered trademark of MET Laboratories, Inc. © 2009 Racine Federated Inc., all rights reserved

Printed in USA 11/09 Form No. 1100











# Flow Meters



Model B2800

Flow Monitor

- Microprocessor-based flow monitor and totalizer
- Use with Blancett® turbine flow meters as well as other flow meters with a frequency output
- Battery (1.5 VDC) and Loop-powered (4-20 mA) versions available
- Meter, Remote, Panel and Swivel mount versions available
- Hand-Held and Explosion-Proof models also available

1-800-235-1638 **www.blancett.com** 





## Introduction

The B2800 is a technologically advanced flow monitor designed to be comprehensive, user-friendly, flexible and cost efficient. This microprocessor-based display comes pre-calibrated by the factory when purchased with a Blancett turbine flow meter, or it can easily be configured in the field. The user may choose between the Simplified model which is programmed in seven simple steps and the Advanced model which provides additional programming options.

The B2800 is offered in six mounting configurations: meter, remote, swivel and hand-held, as well as a panel version and explosion-proof display allowing for flexible installation. The B2800, when paired with a rugged, reliable Blancett turbine flow meter, will provide dependable and accurate flow information for many years to come. The B2800 may also be used with almost any flow sensor that outputs a low-amplitude AC signal.

#### **Features**

- Displays rate and/or total
- Large 8 digit by 3/4" display for easy viewing (meter, remote and swivel mount plus hand-held versions)
- Battery-powered unit utilizes one "D" size 1.5 volt alkaline battery for up to 3-1/2 years of service
- Loop-powered, 4-20 mA version available
- User friendly front panel programming
- Ten point linearization (Advanced model only)
- NEMA 4X enclosure suitable for outdoor monitoring (meter, remote, and swivel mount versions)
- Intrinsically safe (meter, remote and swivel mount versions)
- Microprocessor-based, low power consumption
- Six mounting options: meter, remote, swivel, hand-held, panel or explosion-proof
- Simplified model displays in five selectable units of measure: GPM/gallons, LPM/liters, M3PD/cubic meters, BPD/barrels, or M3PH/cubic meters
- Advanced model offers thirteen selectable units of measure: gallons, oil barrels, liters, cubic meters, Mgal, MCF, MMCF, cubic ft, Mliters, acre ft, liquid barrels, lbs, or kgs
- Advanced model allows selection of time intervals for rate measurement in either day, hour, minute, or second
- Advanced model includes gas measurement with correction software for pressure and temperature



METER MOUNT VERSION

## **Operating Principle**

The B2800 flow monitor accepts a low-level frequency input, such as the input from a Blancett turbine meter, to calculate flow rate and total. These calculations are then displayed in user selected units of measurement. All B2800 flow monitors come pre-calibrated from the factory if ordered with a Blancett flow meter. However, they can be easily reconfigured in the field. The B2800 is available in a battery-powered or loop-powered version. The battery version utilizes one "D" size, 1.5 volt alkaline battery that provides up to 3-1/2 years of service.

The loop-powered B2800 offers a 2-wire 4-20 mA output for electronic integration. The meter mount, remote, swivel and hand-held monitors are equipped with a large 8 digit by 3/4" numerical LCD making extended range viewing practical. The second 8 character by 3/8" alphanumeric display provides for selectable units viewing in run mode and prompts variables in programming mode. Additionally, the user can choose between displaying rate, total or alternating between both rate and total.

## **Specifications**

LCD Display: Rate & total, fixed or toggle modes of operation

8 digit, 0.7 inches (18 mm) numeric (top line)

8 character, 0.35 inches (9 mm) alphanumeric (bottom line); resettable

**LCD Display:** Rate & total, fixed or toggle modes of operation

8 digit, 0.5 inches (13 mm) numeric (top line) (Panel Mount & Explosion-Proof Models only)

8 character, 0.25 inches (6.4 mm) alphanumeric (bottom line); resettable

Power:

1 "D" size 1.5 VDC alkaline battery included Battery

Less than 1 milliwatt (~3.5 years on 1 "D" battery)

4-20 mA, two-wire current loop Loop-Powered 25 mA maximum consumption

One pulse for each increment of the least **Pulse Output Signal:** 

significant digit of totalizer

Pulse Type Opto-isolated open collector transistor

Max Voltage

Pulse Width (ON State) 20 ms/max pulse rate 20 Hz

Current (ON State) 0.9 V drop @ 5.0 mA or

0.7 V drop @ 0.1 mA

Inputs: Magnetic pickup Frequency Range 1 to 3500 Hz

Trigger Sensitivity 30 mV p-p

Over Voltage Protected 30 VDC

Frequency Measurement

+0.1%

Analog Output:

4-20 mA (Loop-Powered Version)

Operating

Accuracy:

-22 °F (-30 °C) to 158 °F (70 °C) Temperature:


**Humidity:** 0-90% non-condensing

**Enclosure Rating:** Meter, Remote and Swivel mount:

NEMA/UL/CSA Type 4X (IP-66) Panel mount: NEMA 4 (front only)

Hand-Held: General Purpose

Explosion-proof: NEMA 4X (IP-66)



#### Certifications:

CSA Intrinsically Safe: Class I, Division 1, Groups C & D (Meter, Remote & Swivel Mount) Class II, Division 1, Groups E, F & G

CE: (Meter, Remote & Swivel Mount) IEC 61326-1 CSA: (Panel Mount Only) Ordinary Area

CSA Hazardous Locations:

Class I, Division 1, Groups B, C & D (Explosion-Proof Model Only)

Class II, Groups E, F & G Class III, Type 4, T6 @ 70 C

Units of Measure (Rate/total):

GPM/gallons, LPM/liters, M3PD/ (Simplified Version - user selectable) cubic meters. BPD/barrels.

M3PH/cubic meters

Units of Measure (Total):

(Advanced Version - user selectable)

Gallons, Oil Barrels, Liters, Cubic Meters, MGal, Cubic Ft, MLiters, MCF, MMCF, Acre Ft, Liquid Barrels,

Lbs, Kas

Time Intervals (Rate):

(Advanced Version - user selectable)

Day, Hour, Minute, Second

## Flow Monitor Part Numbering Information

#### B 2 8 X X X - XX Program Level A = Advanced S = Simplified **Power Option** B = BatteryMounting Style L = LoopM= Meter Mount

R = Remote Mount S = Swivel Mount

H = Hand-Held

P = Panel Mount X = Explosion-Proof

### Units of Measure

AB = Gallons

ED = Barrels

HB = I iters

ID = Cubic Meters

CS = Customer Selectable\*

\*Note: Advanced B2800 monitors only. The default is gallons per minute.

## **B2800 Mounting Configurations**

#### **Meter Mount**

- Monitor is assembled to the flow meter, creating a compact flow measurement system
- NEMA 4X (IP-66) enclosure
- 8 digit 0.7 inches (18 mm) numeric rate/total display
- 8 digit 0.35 inches (9 mm) alphanumeric display
- Fixed or toggle modes of operation for flow rate and total display

#### **Remote Mount**

- Ideal for installations where flow sensor is located in a challenging environment such as high temperature, excessive noise or inaccessible area
- NEMA 4X (IP-66) enclosure
- 8 digit 0.7 inches (18 mm) numeric (rate/total display; programming choices)
- 8 digit 0.35 inches (9 mm) alphanumeric display (run/programming mode)
- Mounting hardware included
- Fixed or toggle modes of operation for flow rate and total display
- Cable lengths from 10' (3 meters) up to 100' (30.5 meters) sold separately

#### **Swivel Mount**

- Capable of adjusting orientation up to 180 degrees
- Offers additional protection from the sun/elements
- Increased visibility in difficult viewing installations
- Remote swivel mount also available, consult factory for details
- NEMA 4X (IP-66) enclosure
- 8 digit 0.7 inches (18 mm) numeric display (rate/total display: programming choices)
- 8 digit 0.35 inches (9 mm) alphanumeric display (run/programming mode)
- Fixed or toggle modes of operation for flow rate and total display

## Hand-Held

- Battery-powered
- Portable, includes handle, extendable cable and sensor dock
- On/Off switch for power conservation
- Magnetic pickup included with monitor
- 8 digit 0.7 inches (18 mm) numeric display (rate/total display; programming choices)
- 8 digit 0.35 inches (9 mm) alphanumeric display (run/programming mode)
- Fixed or toggle modes of operation for flow rate and total display
- General Purpose enclosure

## **Panel Mount**

- NEMA 4 (front only)
- Designed to be mounted in 3.6" x 3.6" (91 x 91 mm) opening
- Fixed or toggle modes of operation for flow rate and total display
- 8 digit 0.5 inches (12.7 mm) numeric display (rate/total display; programming choices)
- 8 digit 0.25 inches (6.4 mm) alphanumeric display (run/programming mode)

## **Explosion-Proof**

- Ideal for hazardous locations
- Rugged compact design
- 8 digit 0.5 inches (12.7 mm) numeric display (rate/total display; programming choices)
- 8 digit 0.25 inches (6.4 mm) alphanumeric display (run/programming mode)
- Fixed or toggle modes of operation for flow rate and total display
- NEMA 4X (IP-66) enclosure












## Dimensions - Inches (mm)



4.00 (101.6)

7.00 (177.8)


1.25 (31.8)

25 (6.4) DIA (4 HOLES)


REMOTE MOUNT

4.00 (101.6) (146.0) (146.0) (177.8) (177.8) (177.8) (177.8)





**SWIVEL MOUNT** 



**PANEL MOUNT** 

**EXPLOSION-PROOF** 

## Related Blancett Products

## Model 1100 In-Line Turbine Flow Meter

- Accuracy : ±1% of reading
- Repeatability: ±0.1%
- Flow ranges from 0.6-3 GPM to 500-5,000 GPM in line sizes from 1/2 to 10 inches (12.7 to 254 mm)
- Rugged 316 stainless steel construction
- NIST traceable calibration certificates available
- Manufactured in the USA



## QuikSert™ In-Line Turbine Flow Meter

- Modified flow straighteners for enhanced fluid dynamics
- Body dimensions allow for installation in confined areas
- "Between the flange" design eliminates the need for mating flanges
- Flow ranges from 0.6-3 GPM to 500-5,000 GPM in line sizes from 1/2 to 10 inches (12.7 to 254 mm)
- NIST traceable calibration certificates available
- Optional installation kit available



## 3A Sanitary In-Line Turbine Flow Meter

- Meets 3A sanitary standard number 28-03 requirements
- Available in CIP/SIP and COP/SOP environments
- Accuracy: ±1% of reading
- Repeatability: ±0.1%
- Flow ranges from 0.6-3 GPM to 40-400 GPM
- Meter sizes 3/8 to 2 inches (9.5 to 50 mm)
- Connection sizes: 3/4, 1-1/2, and 2-1/2 inches





- 8635 Washington Avenue, Racine, WI 53406-3738 U.S.A.
- Toll Free: 800-235-1638 Tel: 262-639-6770 Fax: 262-639-2267
- E-mail: info@blancett.com

© 2006 Blancett Printed in USA 5/06 Form No. 2800

# Operation, Maintenance and Monitoring (OM&M) Manual

## **APPENDIX P**

Transfer Pump TP-300 Information





#### Pump, Diaphragm, 1 In

Air Operated Diaphragm Pump, Metallic Double Diaphragm, Air Inlet 3/8 In, Flow 35 GPM, Max Flow 30 CFM, Max Flow 49 GPM, Max Operating PSI 100, Inlet 1 In FNPT, Outlet 1 In FNPT, Port Type Single, Max Dia Solids 3/16 In, Max Temp 180 F, Buna N Ball Material, Aluminum Body Material, Stainless Steel Check Seat Material, Buna N Diaphragm Material, Self Priming Dry 18 Ft, Self Priming Wet 28 Ft

Grainger Item # 6PY44 \$766.00 Price (ea.) Brand DAYTON Mfr. Model # 6PY44 Ship Qty. Sell Qty. (Will-Call) 1 Ship Weight (lbs.) 30.55 Availability Ready to Ship

Catalog Page No. 3955

Price shown may not reflect your price. Log in or register.

#### **Additional Info**

#### Metallic Air-Operated Double Diaphragm Pumps

#### General-Purpose (Dayton®)

Self-priming pumps can run dry and are capable of pumping slurries, solvents, and highviscosity liquids, such as paints and waste oils. Spring-assisted air valve has proprietary seal rings and never requires lubrication.

#### **Tech Specs**

Inlet/Outlet: 1"

Item: Air Operated Double Diaphragm Pump

Flow: 35 gpm Max. Flow GPM: 49 Max. Flow: 30 cfm Max. Operating PSI: 100 Body Material: Aluminum Diaphragm Material: Buna N

Ball Material: Buna N

Check Seat Material: Stainless Steel

Air Inlet (F)NPT: 3/8" Manifold Connection: Single Max. Dia. Solids: 3/16" Max. Temp.: 180 Degrees F Self-Priming Dry: 18 ft. Self-Priming Wet: 28 ft.

Manufacturers Warranty Length: 1 Year

#### **Notes & Restrictions**

There are currently no notes or restrictions for

#### **Optional Accessories**

#### Pump Repair Kit, Fluid



Item #: 6PY67 **Brand: DAYTON** 

Usually Ships: Ready to Ship

Price (ea): \$218.75

#### Pump Repair Kit, Air



Item #: 6PY79 **Brand: DAYTON** 

Usually Ships: Ready to Ship

Price (ea): \$146.15

Hose, Push On, 3/8 In ID x 250 Ft,

Green

Photo Not Available

Item #: 4KT71

**Brand: GOODYEAR ENGINEERED** 

**PRODUCTS** 

Usually Ships: Ready to Ship

Price (ea): \$450.00

#### this item.

#### **MSDS**

This item does not require a  ${\bf Material\ Safety\ Data\ Sheet\ (MSDS)}.$ 

#### **Required Accessories**

There are currently no required accessories for this item.

#### Filter/Regulator



Item #: 4ZK84 **Brand: SPEEDAIRE** 

Usually Ships: Ready to Ship

Price (ea): \$65.00

#### Push On Hose Barb, 3/8 In ID x 3/8 MNPT



Item #: 5A254

**Brand:** GRAINGER APPROVED

**VENDOR** 

Usually Ships: Ready to Ship

Price (ea): \$2.77

#### Pressure Gauge, 2 In, 0 to 160 Psi



Item #: 5WZ41

**Brand:** GRAINGER APPROVED

**VENDOR** 

Usually Ships: Clearance - limited

quantity available Price (ea): \$10.86

#### Pressure Gauge, 2 In, 160 Psi, Back



Item #: 4FMC7

**Brand:** GRAINGER APPROVED

VENDOR

Usually Ships: Ready to Ship

Price (ea): \$11.95

#### **Alternate Products**

#### Pump, Diaphragm, 3/4 In



Item #: 6PY43 **Brand: DAYTON** 

Usually Ships: Ready to Ship

Price (ea): \$669.50

#### **Repair Parts**



Repair Parts Information is available for this

# APPENDIX Q

Vapor Phase Carbon Units Information



## 1,000lbs Vapor Media Vessels

## **Environmental Treatment Specialists**



General Specifications: Flow max 750 CFM

Main Equipment: 2 – 1,000 lb Vapor media vessels

3' diameter x 7' high

Equipment Features: Stainless Steel slotted screen for water collection &

backwash distribution

Standard Absorption System Piping including:
Air Eliminators to remove air from headspace

Schedule 40 carbon steel process piping w/cast iron

fittings

Cast Iron butterfly valves for process piping

4" ball valves for GAC discharge

Pressure rating: 75 psig & 14 psig vacuum

Water Hose Connection: Male camlocks 4" inlet fitting

Air Hose Connection: 3/4" Chicago hose connection

Carbon Hose Connection: 5" camlock

Process Pipe Connection: 6" 150# ANSI flange

Maintenance Access: 20" round flanged man-way one side

2- 14" x 18" manway on top

Weight: 1200 lbs. empty /2200 lbs. Operating weight

Options: Manifold for between vessels

Power Requirements: None

**ProAct Services Corporation** 

**Corp Office**: 231-843-2711 **Gulf Coast**: 210-862-6467

or 713-202-63<u>5</u>1

Midwest Office: 231-342-1115 East Coast Office: 203-262-1200

www.proact-usa.com

Texas • Colorado • Michigan • New Jersey • Connecticut


# EI-46 | EI-410

# **Product Description**

El-46 and El-410 grade virgin activated carbons are manufactured from select grades of bituminous coal, which are activated at high temperatures under rigidly controlled conditions. The resulting product is characterized by high internal surface area, offering superior gas phase adsorption properties for a broad spectrum of organic compounds.

EI-46 and EI-410 grade activated carbons are very hard and attrition resistant resulting in low dust and high durability during operation and reactivation. Typical applications for EI-46 and EI-410 include: solvent recovery, odor control, tank vent adsorbers, HVAC, VOC control, Soil Vapor Extraction, Air Stripper Off-Gas, and Sub Part CC Compliance.

Grades are available in 200 lb net weight fiber drums or in bulk sacks containing 1000 lbs. net each. They are produced by steam activated process and are therefore excluded from IATA#395, IMCO CLass 4.2 or UN1362, Freight Classification: NMFC #40560; UFC - #20460



EI 440

#### WET ACTIVATED CARBON DEPLETES OXYGEN FROM AIR.

All precautions must be taken since dangerously low levels of oxygen may be encountered.

EI 46

# **Product Specifications**

	E1-46	EI-410
Carbon Tetrachloride Activity (base):	60%	60%
Hardness Number (min.):	95	95
Mean Particle Diameter (mm):	3.7	3.0
Moisture (as packed, weight %):	2.0%	2.0%
U.S. Standard Sieve Size:	4x6	4x10
Greater than 4 mesh (max.):	5%	5%
Less than 7 mesh (max.):	10%	NA
Less than 10 mesh (max):	NA NA	4%
Apparent Density (dense packing, g/ml)	.4450	.4450
Total Surface Area (N2 BET, m2/g):	1050-1150 m <sub>2</sub> /g	1050-1150 m <sub>2</sub> /g
Ignition Temperature (Deg. C):	450	450

The information and recommendations in this publication are, to the best of our knowledge, reliable. Suggestions made concerning uses or applications are only the opinion of Envirotrol Inc., and users should make their own tests to determine the suitability of these products for their own particular purposes. However, because of numerous factors affecting results, Envirotrol Inc., makes no warranty of any kind, expresses or implied, including those of merchantability and fitness for purpose, other than that the material conforms to its applicable current Standard Specifications. Statements herein, therefore, should not be construed as representations or warranties. The responsibility of Envirotrol for claims arising out of breach of warranty, negligence, strict liability, or otherwise is limited to the purchase price of the materials.


Statements concerning the use of the products or formulations described herein are not to be construed as recommending the infringement of any patent and no liability for infringement arising out of any such use is assumed.


Shipping Infortmation: F.O.B. Points: Rochester, PA


	<b>Operation</b>	. Maintenance	and Monitoring	(OM&M)	) Manual
--	------------------	---------------	----------------	--------	----------

APPENDIX R

Electrical Power Wiring Drawings








<b>Operation, Maintenance and Monitoring (C</b>	)M&M	) Manual
---	------	----------

**APPENDIX S** 

NYCDEP Discharge Permit Limits





Carter H. Strickland, Jr. Commissioner

Vincent Sapienza
Deputy Commissioner
Bureau of Wastewater
Treatment
vsapienza@dep.nyc.gov

96-05 Horace Harding Expressway Corona, NY 11368 T: (718) 595-4906 F: (718) 595-6950 National Railroad Passenger Corporation 400 West 31<sup>st</sup> Street, 4<sup>th</sup> Floor New York, NY 10001

Attn: Richard Mohlenhoff

Re: Groundwater Discharge, Sunnyside Yard - OU-3 Remediation,

File # C-5201

Dear Mr. Mohlenhoff:

This is in response to the July 30 and August 20, 2012 submissions, requesting for permission to discharge up to **28,800 gallons per day** (gpd) of groundwater generated during the remediation located at 39-29 Honeywell Street, Queens, NY 11101 (New York State Department of Environmental Conservation State Superfund Site #2-41-006). The groundwater will be treated through two 120 gallon knock-out tanks, one 200 gpm oil/water separator, 10 micron bag filters, two 1,000 lb organoclay units, two 1,000 lb carbon units, and one 4,000 gallon settling tank, per provided schematic and information, before discharging to an existing on-site manhole. The manhole leads to the existing 48" combined sewer that runs parallel and South of Northern Boulevard between Honeywell and 39<sup>th</sup> Streets in Queens, NY.

Based upon the information, schematic and analytical data submitted, you are hereby conditionally authorized, to discharge up to 28,800 gpd of groundwater, treated through the above system, per provided schematic and information, as specified in your submissions, for a period of one year, to the combined sewer at the above mentioned location. This Letter of Approval shall expire at midnight on September 12, 2013.

This conditional approval, however, is subject to your obtaining a groundwater discharge Approval, specifying allowable flow rates, from the Chief of Permitting and Compliance, Bureau of Water and Sewer Operations. You are also required to follow manufacturer specifications for the operation and maintenance of the selected equipment. This Letter of Approval is contingent upon the permittee's compliance with any other Federal, State or Local laws applicable to the permitted activity.

Payment shall be made to and permit obtained from the Bureau of Customer Service for groundwater discharge into the New York City Wastewater System in accordance with the Water and Wastewater Rate Schedule established by the New York City Water Board.

You must notify this section in writing prior to the commencement of discharge. In addition, you are required to hold the groundwater to the maximum extent practicable during heavy wet weather events. Refer to File # C-5201 in any correspondence to this office.

The permittee must collect samples of the groundwater after the pretreatment system in each month of the calendar year. The samples must be analyzed for the parameter(s) included in the attached chart by a New York State Department of Health certified laboratory. The results must be submitted to this office within 14 days after each sampling date. If the sampling results, or any other sampling results, exceed the DEP limits, the discharge must cease and the Bureau of Wastewater Treatment must be notified immediately by phone at (718) 595-4715 and by fax at (718) 595-4771.

You are prohibited from discharging any groundwater that exceeds the attached discharge limit(s), as well as those contained in Title 15 Rules of the City of New York Chapter 19.

This Letter of Approval is an Order of the Commissioner of the Department of Environmental Protection. Please be advised that failure to comply with this Letter of Approval may result in the issuance of Notices of Violation (returnable to the New York City Environmental Control Board) and/or revocation of the Letter of Approval. Notices of Violation carry penalties of up to \$10,000 a day, per violation.

If you have any questions concerning this matter, please contact Sean Hulbert, Assistant Chemical Engineer, at (718) 595-4715.

Sincerely.

Frances Leung, P.E., Chief, Industrial Inspections and

Permitting Section

enc: Sampling Requirements and Limitations

#### SAMPLING REQUIREMENTS AND LIMITATIONS

Parameter <sup>1</sup>	Daily Limit	Units	Sample Type	Monthly Limit
Non-polar material <sup>2</sup>	50	mg/l	Instantaneous	
рН	5-12	SUs	Instantaneous	2.0
Temperature	< 150	Degree F	Instantaneous	
Flash Point	> 140	Degree F	Instantaneous	
Cadmium	2	mg/l	Instantaneous	
	0.69	mg/l	Composite	
Chromium (VI)	5	mg/l	Instantaneous	
Copper	5	mg/l	Instantaneous	
Lead	2	mg/l	Instantaneous	
Mercury	0.05	mg/l	Instantaneous	
Nickel	3	mg/l	Instantaneous	
Zinc	5	mg/l	Instantaneous	
Benzene	134	ppb	Instantaneous	57
Carbontetrachloride			Composite	
Chloroform			Composite	
1,4 Dichlorobenzene			Composite	
Ethylbenzene	380	ppb	Instantaneous	142
MTBE (Methyl-Tert-Butyl-	50	ppb	Instantaneous	
Ether)				
Naphthalene	47	ppb	Composite	19
Phenol			Composite	
Tetrachloroethylene (Perc)	20	ppb	Instantaneous	
Toluene	74	ppb	Instantaneous	28
1,2,4 Trichlorobenzene			Composite	
1,1,1 Trichloroethane			Composite	
Xylenes (Total)	74	ppb	Instantaneous	28
PCBs (Total) <sup>3</sup>	1	ppb	Composite	
Total Suspended Solids	350	mg/l	Instantaneous	
(TSS)			0 1	
CBOD <sup>4</sup>			Composite	
Chloride <sup>4</sup>			Instantaneous	
Total Nitrogen <sup>4</sup>			Composite	
Total Solids <sup>4</sup>			Instantaneous	
Other				

- All handling and preservation of collected samples and laboratory analyses of samples shall be performed in accordance with 40 C.F.R. pt. 136. If 40 C.F.R. pt. 136 does not cover the pollutant in question, the handling, preservation, and analysis must be performed in accordance with the latest edition of "Standard Methods for the Examination of Water and Wastewater." All analyses shall be performed using a detection level less than the lowest applicable regulatory discharge limit. If a parameter does not have a limit, then the detection level is defined as the least of the Practical Quantitation Limits identified in NYSDEC's <u>Analytical Detectability and Quantitation Guidelines for Selected Environmental Parameters</u>, December 1988.
- Non-Polar Material shall mean that portion of the oil and grease that is not eliminated from a solution containing N-Hexane, or any other extraction solvent the EPA shall prescribe, by silica gel absorption.
- Analysis for PCBs is required if *both* conditions listed below are met:

  1) if proposed discharge ≥ 10,000 gpd;

  2) if duration of a discharge > 10 days.

  Analysis for PCBs must be done by EPA method 608 with MDL=<65 ppt. PCBs (total) is the sum of PCB-1242 (Arochlor 1242), PCB-1254 (Arochlor 1254), PCB-1221 (Arochlor 1221), PCB-1232 (Arochlor 1232), PCB-1248 (Arochlor 1248), PCB-1260 (Arochlor 1260) and PCB-1016 (Arochlor 1016)
- Analysis for Carbonaceous Biochemical Oxygen Demand (CBOD), Chloride, Total Solids and Total Nitrogen are required if proposed discharge  $\geq 10,000$  gpd. Total Nitrogen = Total Kjeldahl Nitrogen (TKN) + Nitrite (NO<sub>2</sub>) + Nitrate (NO<sub>3</sub>).

## **ATTACHMENT**

# **Miscellaneous Treatment System Components**

(Provided on CD in Bound Copy)

## **ATTACHMENT**

# **Miscellaneous Treatment System Components**

(Provided on CD in Bound Copy)

# PROACT SERVICES CORPORATION Operation and Maintenance Manual

Job Number: 1630

**Dual Phase Extraction Treatment System** 

Prepared For: Mr. Richard Mohlenhoff, PE

**Director of Field Operations** 

**EHS** Department

Amtrak

400 West 31st Street

4<sup>th</sup> Floor

New York, NY 10001

Site: Amtrak Sunnyside Yard

Queeens, NY

© PROACT SERVICES CORPORATION 1140 Conrad Industrial Drive Ludington, MI 49431 Phone 231.843.2711 • Fax 231.843.4081 www.proact-usa.com 3/22/2013 4:43 PM

# **Table of Contents**

Introduction	3
1.0 Before Operating Your System	4
1.1 Potential Hazards	4
1.2 System Power	6
1.3 System Layout	
1.4 System Operation	10
1.5 Cold Weather Operation	12
1.6 Emergency Shut-Down Procedure	13
1.7 Towing	13
2.0 System Components Description	15
2.1 Allen Bradley CompactLogix & Red Lion Touchscreen	15
2.2 Liquid Ring Pumps (LRP-101, LRP-102)	
2.3 Knock-Out Tank	23
2.4 Vapor Carbon Vessels	24
2.5 Transfer Pumps	25
2.6 Oil Water Separator	28
2.7 Bag Filters	29
2.8 Liquid Clay Vessels	29
2.9 Liquid Carbon Vessels	
2.10 Water Storage Tank	30
2.11 Product Tank	31
2.12 Floor Sump	31
2.13 Air Compressor	31
2.14 Automated Valves and Solenoid Manifold	32
2.15 Miscellaneous Transducers and Meters	33
2.16 Vent Fan and Heaters	35
3.0 Standard Operating Procedures	36
3.1 Connecting the System to the Main Power Supply	36
3.2 System Start-up	38
3.3 Sampling and Monitoring	42
3.4 Normal Shut-down	
4.0 System Faults and Troubleshooting	
4.1 Touch Screen Warning and Alarm Messages	
4.2 Troubleshooting	
5.0 Preventative Maintenance	
5.1 Weekly	
5.2 Monthly	
5.3 Quarterly	
6.0 Servicing	
6.1 Particulate Filter Bag Change	
6.2 Carbon Servicing and Disposal	
6.3 Swapping Lead and Lag Vapor Carbon	40

# Introduction

Thank you for choosing ProAct Services for your Dual Phase Extraction treatment system. We know there are a lot of choices on the market today...and want to congratulate you for making the right choice! We at ProAct Services Corporation are confident in our products since they are designed and built to exceed customer expectations. We strive to be a "proactive" company that delivers the highest quality products and customer service.

This manual has been prepared to acquaint you with the operation and maintenance of your ProAct Environmental Treatment System, and to provide you with important safety information. It is important that you study the entire Manual. It will answer most of your questions about the system. If you require additional information or assistance, please contact ProAct Services Corporation

PROACT SERVICES CORPORATION Phone 231.843.2711 www.proact-usa.com

This manual should be considered a permanent part of this system. It should stay with the system at all times

# IMPORTANT NOTICE! Safety Definitions

Statements in this manual preceded by the following words and graphics are of special significance:



WARNING indicates a potentially hazardous situation which if not avoided, could result in death or serious injury.

# **CAUTION**

CAUTION indicates a potential situation which if not avoided, could result in equipment or property damage.

#### Note:

All information, illustrations, and specifications in this manual are based upon the latest product information available at the time of printing. We reserve the right to make changes at any time without notice.

# 1.0 Before Operating Your System

This system is designed to treat soil vapor contaminated with organic constituents. This section summarizes the hazards associated with using this remedial system, the basic operation and layout of the system, cold weather operation, and emergency shutdown procedures. It is very important to read this section first!

### 1.1 Potential Hazards

Due to the nature of the soil vapors and groundwater contaminants, a variety of conditions may exist that could cause serious health and safety hazards.

# **WARNING**

Please be careful and ask knowledgeable personnel if there are any doubts about what is or is not a hazard.

#### Vapors

This remediation system is treating organic compounds such as BTEX (BENZENE, TOLUENE, ETHYL BENZENE, AND XLENES) and chlorinated compounds which may be highly volatile organics. Vapors may become concentrated in the trailer and within system components.

# **WARNING**

If vapors (gasoline type odor) are observed within the control room, the system should be shut down immediately.

#### **Explosions**

The presence BTEX or other organic constituents in high concentrations or free product form will increase the potential for explosions.

# **WARNING**

No Smoking or open flame is allowed within or near the complete treatment system skid trailer.

#### **High Pressure**

There is always potential for high pressure leaks or breaks in the plumbing. It is common to observe system vacuum and pressure readings at 25Hg and 135 PSI during normal system operation.

# **WARNING**

Do not adjust any valves or fittings without taking proper precautions.

#### **Electricity**

This treatment system contains high and low voltage components. All unqualified personnel should remain outside of the NFPA 70E Limited Approach Boundary of 42"

Limited Approach Boundary: 3'-6" Restricted Approach Boundary: 1' Prohibited Approach Boundary: 1"

#### **CAUTION**

The electrical system for this unit is configured for a specific power supply. Failure to connect the correct power will result in system damage

# **WARNING**

Do not disassemble any electrical parts without properly securing the power. When in doubt...consult a professional.

#### **Granular Activated Carbon**

Activated carbon is capable of depleting oxygen supply.

# **WARNING**

Proper ventilation precautions should be taken when servicing the carbon vessels or when any carbon is directly exposed to the atmosphere.

# WARNING

Chemical-Impervious gloves, safety glasses, and protective clothing should be worn to avoid contact with contaminated liquids.

## 1.2 System Power

This system requires power from an external source to operate; it is not equipped with a generator. In addition, the treatment system can be configured to accept more than one type of power supply with slight modification. See Section 3.1 for connecting the remediation system power.

# CAUTION


The electrical system for this unit is configured for a specific power supply. Failure to connect the correct power to the remediation system will result in substantial damage

## 1.3 System Layout

ProAct Services Corporation installed the Dual Phase Extraction System in a 53'  $\times$  8'- 6" trailer which allows the system to be readily mobile.


#### Layout

The inside of the treatment system is divided into two sections called the "process room" and the "control room" (the two rooms are separated by a partition wall). The process room is where the DPE system components have been placed, and all equipment in this room meets explosion proof standards (Class 1 Div. 2). The small room in the front of the trailer houses the electrical circuit panels, system control panel (including the Program Logic Controller). This room is referred to as the "control" room. This room is unclassified and any electrical signal from the control room entering the process room is intrinsically safe.




The following is a list of major components located in the control room:

- 15 KVA Transformer
- Control Panel
- Emergency Shut Down (ESD) Pushbutton
- Touch Screen HMI Interface
- Breaker Panel
- Program Logic Controller (PLC)
- 3.0 KW Forced Air Heater and Exhaust Fan
- Air Compressor and Solenoid Manifold
- Pressure Transducer and Gauge
- Lights
- Ventilation Shutters




The following is a list of major components located in the process room:

- Liquid Ring Pumps (LRP-101, LRP-102) 40 HP
- Progressive Cavity Transfer Pumps (TP-200, TP-202)
- Diaphragm Pump (TP-300)
- Centrifugal Transfer Pump (TP-301)
- 6 Inch manifold Header with Fourteen-Four Inch Manifold Strings
- Knock Out Tank
- Oil Water Separator
- Bag Filters
- 1000 lb. Liquid Clay Media Vessels
- 1000 lb. Liquid Carbon Media Vessels
- 750 Gallon Clean Water Poly Tank
- Emergency Shut Down Pushbuttons
- Forced Air Heaters 7.5KW (Front and Rear)
- Exhaust Fan
- Floor Sumps
- Level and Temperature Switches,
- Gauges, Flow Meters, and Automated Valves
- Vacuum, Pressure, and Differential Pressure Transducers
- Light Switch and Lights



This system was also designed to be externally functional. In order to meet the requirement, the following components have been installed on the outside of the trailer:

- 480 Volt 3 Phase Main Disconnect
- Exterior Flood Lights
- LRP Ventilation Shutters
- Doors and Door Ventilation Shutters
- Fourteen DPE Influent Well Connections (4" male cam-lock)
- Vapor Discharge Connection (6" flange)
- Water Discharge Connection (2" male cam-lock)
- Product Discharge Connection (2" male cam-lock)
- Product Tank Float Switch Interconnect Box
- 1000 lb. Vapor Carbon Vessels



## **1.4 System Operation**

The following section is a basic description of the control interface and system operation from the standpoint of how water and vapor enters, progresses, and exits the remediation system.

#### **Basic System Control**

The control panel is the main control interface "or driver's seat" for the operation and control of the treatment system. The following items are located on the control panel:

- PLC (Program Logic Controller)
- Touch Screen PLC HMI Interface
- Process Room Fan (HAND OFF AUTO) Selector Switch
- Control Room Fan (HAND OFF AUTO) Selector Switch
- Emergency Shut Down (ESD) Button
- Emergency Stop Reset Button
- Emergency Stop Ready 'Amber' Indicator LED
- Power 'Green' Indicator LED
- System Alarm 'Red' Indicator LED
- System Alarm Clear 'Green' Indicator LED

The PLC works in combination with the Touch Screen Interface. Each of the Liquid Ring Pumps, Transfer Pumps, or Actuator Valves can be independently set to (HAND-OFF-AUTO) 3 position modes for system control on the Touch Screen Interface (See section 2.1 for detailed interface controls). Also, inputs from various vacuum, pressure, and differential pressure transducers, float and temperature switches, and flow meters are used to actively monitor and control the treatment system. The control panel switches include (2) H-O-A (HAND-OFF-AUTO) 3 position switches for the control room and process room fans. The PLC will trip an alarm (fault) and shutdown any malfunctioning component(s) or the entire treatment system if necessary. In an emergency, pushing the ESD on the control panel box will shut down the entire system. A reset pushbutton is used to reset the Emergency stop.

#### **Basic System Operation**

#### **DPE (Dual Phase Extraction)**

Contaminated soil vapors "wet gases" are extracted from wells through a manifold string that consists of fourteen 4" DPE well intakes into a 220 gallon Knock-Out Tank. The contaminated water and vapor that enter the Knock-Out Tank follow separate paths as they pass through the treatment system.

The contaminated vapor that enters the Knock-Out Tank passes through a particulate filter and into a manifold that enters two Travaini TRO600V-1A-XP Liquid Ring Pumps (LRP-101 & LRP-102) each rated at 40 HP. Each LRP string contains a totalizing vapor flow meter. After each LRP, the vapor flow is directed through another manifold and the vapor exits the trailer through a 6" flanged connection. Outside of the treatment trailer the vapors enter two Vapor Carbon Vessels in series for additional treatment. The remaining vapor is discharged to atmosphere through a plumbing stack on top of the last Vapor Carbon Vessels.

The water that collects inside Knock-Out Tank will gravity feed through a Y-Strainer and into the Moyno 35601 progressive cavity Transfer Pumps (TP-200 & TP-202). Each progressive cavity Transfer Pump displaces the Knock-Out Tank water into the Oil Water Separator.

The contaminated water/oil mixture is separated within the Oil Water Separator. The Grainger 6PY44 Transfer Diaphragm Pump (TP-300) removes the oil product from the Oil Water Separator. The product is pushed and passes through a totalizing liquid flow meter and then is discharged effluent of the trailer before it enters the Product Storage Tank. Centrifugal Transfer Pump (TP-301) Goulds 2ST1H7B, transfers water out of the Oil Water Separator. TP-301 pushes water through the Bag Filters, Liquid Clay Vessels, Liquid Carbon Vessels, through a totalizing liquid flow meter, and into a 750 gallon Treated Water Poly Tank. The water that collects inside of the 750 gallon Treated Water Poly Tank is manually gravity drained effluent of the trailer.

## 1.5 Cold Weather Operation

Warning for cold weather operation...

Water can accumulate within the storage tanks, transfer pumps, and system plumbing. If this water freezes then damage to the system will most likely occur.


### **CAUTION**

When operating the system in outside air temperatures (OAT) less than 32°F (0°C), the system must be protected from freezing if a power failure or extended shutdown occurs. Failure to do so will result in equipment damage

## 1.6 Emergency Shut-Down Procedure

If an emergency or unsafe condition exists (i.e., Fire, Flooding, etc) the water treatment system may be shut down by pushing "IN" the RED Emergency Shut Down (ESD) button located on the system control panel, or any of three inside the trailer process room.

It is important to become familiar with the location of the Emergency Shut Down buttons before operating your system



### Procedures for Emergency Shutdown

#### **Control Panel**

- 1. Push "IN" Emergency Shut Down button
- 2. If possible, turn "OFF" the main power disconnect switch
- 3. Contact the appropriate emergency response personnel

#### **Trailer Process Room**

- 1. Push "IN" Emergency Shut Down button
- 2. If possible, turn "OFF" the main power disconnect switch
- Contact the appropriate emergency response personnel

## 1.7 Towing

The tow vehicle and trailer must be correctly matched for safe towing. It's essential that the tow vehicle can handle the trailer Gross Vehicle Weight Rating (GVWR). It is also very important that the tongue weight of the trailer does not exceed the hitch weight carrying capacity of the tow vehicle.

#### Trailer Hitch Requirements

Item	Minimum Recommended
Tow Vehicle Hitch	Class V (weight carrying type)
Ball Mount	Class V
Hitch Ball	Class V – 2 <sup>5/16</sup> "
Vehicle Wiring	7- way connector type
Trailer Brake Control	Electric

#### Electric Brake Requirements

Since the trailer is equipped with electric brakes, the tow vehicle must have the proper electronic trailer brake control installed. In addition, the tow unit must accept a 7 way wire connector. The diagram below shows the wiring schematic for the trailer's 7-way connector.



- 1. Ground
- 2. Brakes
- 3. Running Lights
- 4. Hot Line
- 5. Left Turn
- 6. Right Turn
- 7. Auxiliary

#### Synchronize Trailer Brakes

Synchronize the trailer brakes with the tow vehicle brakes prior to towing. The trailer brakes are designed to stop only the trailer. Improper synchronization between the trailer and tow vehicle brakes can overload the brakes and generate excessive heat and subsequent brake fade or failure. Brake synchronization is accomplished by adjusting the brake controller in the tow vehicle (see manufacturer's specifications).

# **WARNING**

Before towing, reconfirm that the trailer is properly connected to the tow vehicle, and be sure to properly secure the trailer safety chains to the tow vehicle hitch. Always perform a road test before exceeding 25 MPH.

# 2.0 System Components Description

This section describes the operating characteristics of each major component in the system in greater detail. A user that has a better understanding of the overall operation will be more effective in troubleshooting if the need arises. It is important for the user to understand that this "system" is a collection of smaller systems working simultaneously, and a failure of one system (or component) may shut down additional systems.

## 2.1 Allen Bradley CompactLogix & Red Lion Touchscreen



### **Description**


This system is equipped with a PLC (Program Logic Controller) manufactured by Allen Bradley and combined with a Red Lion 10" touchscreen. This combination can perform many simultaneous tasks that include system operations, remote access, email alarming, and data logging. These components communicate over Ethernet.

#### **Touchscreen**

The touchscreen is the HMI (Human – Machine Interface) for the treatment system. The touchscreen communicates with the PLC through Ethernet. This allows the user to control system components, view analog and discrete feedback, adjust setpoints, and view a simplified system layout. The HMI also has a webserver feature that allows for remote access.

#### **Main Menu Screen**

The main/startup screen for the system displays all of the other pages included in the HMI. Pressing the MENU button in the lower left corner at any time will return the touchscreen to the Main Menu screen. The green buttons will display system flow and conditions for different sections of the system. There is an alarm banner at the bottom of each screen and it cycles through active warnings and alarms.



#### HMI Touch screen Pages/Buttons

- 1. Main Menu
- 2. DPE Valves 1-5
- 3. DPE Valves 6-9
- 4. **DPE Valves 10-14**
- 5. KO Tank-TP-200-TP-202
- 6. OWS/TP-300
- 7. TP-301/Bag Filters/Clay Vessels
- 8. Carbon Vessel/Treated Water
- 9. LRP-101/102

- 10. Current Runtimes and Flow Totals
- 11. ACC Runtimes and Flow Totals
- 12. Mode Select
- 13. Trend Select
- 14. System Setup (See Section 3.2)
- 15. Alarms

## **DPE Valve Screens**

These three screens display the influent manifold strings 1 through 14. Each Automated Valve can be set to operate by time of day or open/closed by touching any AV on the touchscreen. The vacuum pressure is monitored on each well string.

Displayed Data (Realtime)	Description
	DPE Valves 1-5
AV1 Status	Automated Valve 1 Open/Closed Status
AV2 Status	Automated Valve 2 Open/Closed Status
AV3 Status	Automated Valve 3 Open/Closed Status
AV4 Status	Automated Valve 4 Open/Closed Status
AV5 Status	Automated Valve 5 Open/Closed Status
VT1 Measurement	Vacuum Transducer 1 IHG Reading
VT2 Measurement	Vacuum Transducer 2 IHG Reading
VT3 Measurement	Vacuum Transducer 3 IHG Reading
VT4 Measurement	Vacuum Transducer 4 IHG Reading
VT5 Measurement	Vacuum Transducer 5 IHG Reading
	DPE Valves 6-9
AV6 Status	Automated Valve 6 Open/Closed Status
AV7 Status	Automated Valve 7 Open/Closed Status
AV8 Status	Automated Valve 8 Open/Closed Status
AV9 Status	Automated Valve 9 Open/Closed Status
VT6 Measurement	Vacuum Transducer 6 IHG Reading
VT7 Measurement	Vacuum Transducer 7 IHG Reading
VT8 Measurement	Vacuum Transducer 8 IHG Reading
VT9 Measurement	Vacuum Transducer 9 IHG Reading
	DPE Valves 10-14
AV10 Status	Automated Valve 10 Open/Closed Status
AV11 Status	Automated Valve 11 Open/Closed Status
AV12 Status	Automated Valve 12 Open/Closed Status
AV13 Status	Automated Valve 13 Open/Closed Status
AV14 Status	Automated Valve 14 Open/Closed Status
VT10 Measurement	Vacuum Transducer 10 IHG Reading
VT11 Measurement	Vacuum Transducer 11 IHG Reading
VT12 Measurement	Vacuum Transducer 12 IHG Reading
VT13 Measurement	Vacuum Transducer 13 IHG Reading
VT14 Measurement	Vacuum Transducer 14 IHG Reading

## KO Tank-TP-200-TP-202 Screen

This screen displays the soil vapor influent to the system provided by vacuum from both of the Liquid Ring Pumps. The soil vapors enter the Knock Out Tank where the vapors and liquids are separated. The vapors flow toward the Liquid Ring Pumps 101 & 102, while the liquids are pumped by Transfer Pumps 200 & 202 toward the Oil Water Separator.

Displayed Data (Realtime)	Description
TP-200 Operation Mode	Transfer Pump 200 HAND-OFF-AUTO Operation Mode
TP-202 Operation Mode	Transfer Pump 202 HAND-OFF-AUTO Operation Mode
DPT1 Measurement	Differential Pressure Transducer 1 IWC Reading
VT15 Measurement	Vacuum Transducer 15 IHG Reading
LSL1	Knock Out Tank Level Float Switch 1 Low Activated
LSH2	Knock Out Tank Level Float Switch 2 High Activated
LSHH3	Knock Out Tank Level Float Switch 3 High High Activated
LSHHH4	Knock Out Tank Level Float Switch 4 High High Activated
LSH17	Floor Sump 1 Level Float Switch 17 High Activated

### OWS/TP-300 Screen

Liquids effluent of the Transfer Pumps 200 & 202 is displayed on this screen entering the Oil water Separator. Product collects in the product chamber and the water passes through the weir inside of the Oil Water Separator. Transfer Pump 300 pumps product out of the Oil Water Separator chamber and into an external Product Tank.

Displayed Data (Realtime)	Description
TP-300 Operation Mode	Transfer Pump 300 HAND-OFF-AUTO Operation Mode
PT4 Measurement	Pressure Transducer 4 PSI Reading
PT5 Measurement	Pressure Transducer 5 PSI Reading
FT3 Measurement	Flow Transducer 3 GPM Reading
LSL9	Oil Water Separator Level Float Switch 9 Low Activated
LSH10	Oil Water Separator Level Float Switch 10 High Activated
LSHH11	Oil Water Separator Level Float Switch 11 High High Activated
LSL12	Oil Water Separator Product Level Float Switch 12 Low Activated
LSH13	Oil Water Separator Product Level Float Switch 13 High Activated
LSHH14	Oil Water Separator Product Level Float Switch 14 High High Activated
LSHH15	External Product Tank Level Float Switch 15 High High Activated

## TP-301/Bag Filters/Clay Vessels

This screen displays effluent water from the Oil water Separator. Transfer Pump 301 pushes water through the Bag Filters and Liquid Clay Vessels.

Displayed Data (Realtime)	Description	
TP-301 Operation Mode	Transfer Pump 301 HAND-OFF-AUTO Operation Mode	
DPT2 Measurement	Differential Pressure Transducer 2 PSID Reading	
PT6 Measurement	Pressure Transducer 6 PSI Reading	
PT7 Measurement	Pressure Transducer 7 PSI Reading	
PT8 Measurement	Pressure Transducer 8 PSI Reading	

## **Carbon Vessel/Treated Water**

This screen is a continuation of the TP-301/Bag Filters/Clay Vessels screen displaying effluent water from the Oil water Separator. Pressurized water from Transfer Pump 301 displaces water through the Liquid Carbon Vessels before entering the Treated Water Tank. The control room Air Compressor is also displayed on this screen.

Displayed Data (Realtime)	Description
PT9 Measurement	Pressure Transducer 9 PSI Reading
PT10 Measurement	Pressure Transducer 10 PSI Reading
PT11 Measurement	Pressure Transducer 11 PSI Reading
PT12 Measurement	Pressure Transducer 12 PSI Reading
FT4 Measurement	Flow Transducer 4 GPM Reading
LSHH16	Treated Water Tank Level Float Switch 16 High High Activated
LSH18	Floor Sump 2 Level Float Switch 18 High Activated

## LRP-101/102

This screen displays the vapors after passing through the Knock-Out Tank and entering both Liquid Ring Pumps. The vapors are discharged effluent of the trailer for further treatment by the Vapor Carbon Vessels.

Displayed Data (Realtime)	Description
LRP-101 Operation Mode	Liquid Ring Pump 101 HAND-OFF-AUTO Operation Mode
LRP-102 Operation Mode	Liquid Ring Pump 102 HAND-OFF-AUTO Operation Mode
FT1 Measurement	Flow Transducer 1 SCFM Reading
FT2 Measurement	Flow Transducer 2 SCFM Reading
VT16 Measurement	Vacuum Transducer 16 IHG Reading
VT17 Measurement	Vacuum Transducer 17 IHG Reading
PT1 Measurement	Pressure Transducer 1 IWC Reading
PT2 Measurement	Pressure Transducer 2 IWC Reading
PT3 Measurement	Pressure Transducer 3 IWC Reading

#### **Current & Previous Run Times Screen**

The run times of all of the major components are displayed on this screen. Motor run hours and flow meter totals are monitored by the HMI daily and monthly.

#### **ACC Run Times and Flow Totals Screen**

The accumulated and trip run time hours of all of the major components are displayed on this screen. Motor run hours and flow meter totals are monitored by the HMI. The blue reset buttons will reset the totalized hours of operation.

#### **Mode Select Screen**

This screen is where you change the operational mode of the major motor operated components to HAND-OFF-AUTO. Components in HAND mode will run with an alarm condition present. Components in AUTO mode will operate until an alarm exists and this will shut down the motor. The individual screens that display each motor can be operated in HAND-OFF-AUTO on each specific screen by touching the component.

#### **Trend Menu Screen**

These ten screens display a Graphical User Interface (GUI) of the transducers in the system controls. The readings of pressure, differential pressure, vacuum, and flow are continuously monitored and updated. All transducer data can be observed over a period of time.

#### **Alarm Screen**

This screen shows all active warnings and alarms. Warnings will clear on their own and do not require anything more than the removal of the abnormal condition. Alarms shutdown a portion or the entire system and require the ALARM RESET button to be pressed before they will clear. A list of the warnings and alarms can be found in **Section 4.1** 

## **2.2 Liquid Ring Pumps (LRP-101, LRP-102)**

The Liquid Ring Pumps (LRP) are the core of the Dual Phase Extraction system. They are rotating "positive displacement" vacuum pumps that generates suction at the DPE well points. Each LRP is capable of extracting particle filled soil vapors and water reliably and continuously with very little maintenance.

In this system, the LRP pulls contaminated soil vapors through the well into a manifold that connects directly to a Knock-Out Tank. Water pulled into the Knock-Out Tank flows into the progressive cavity Transfer Pumps, while the vapors pass through a particulate filter and into both of the LRPs. After the LRPs, the vapor passes effluent of the treatment trailer and through two Vapor Carbon Vessels.

The operation of the LRP-101 is monitored by the system PLC. The LRP-101 has 3 modes that can be selected using the touchscreen on the control panel. Descriptions of the 3 modes are as follows:

#### Liquid Ring Pump 101 Operations

Mode	RUN	STOPS WHEN
HAND	CONTINUOUS	AFTER 10 MINUTES
OFF	NEVER	
AUTO	CONTINUOUS	<ul> <li>LRP-101 mode is turned to the "OFF" position</li> <li>LRP-101 discharge pressure transducer (PT-1) is high</li> <li>LRP combined discharge pressure transducer (PT-3) is high</li> <li>Knock-Out Tank level switch high high high (LSHHH-4) is activated</li> <li>Knock-Out Tank filter differential pressure (DPT-1) is high</li> <li>Knock-Out Tank vacuum (VT-15) is high or low</li> <li>LRP-101 vacuum (VT-16) is high or low</li> <li>LRP-101 oil level switch low (LSL-5) is activated</li> <li>LRP-101 oil level switch high (LSH-6) is activated</li> <li>LRP-101 oil temperature switch high (TSH-1) is activated</li> <li>Floor Sump 1 level switch high (LSH-17) is activated</li> <li>Floor Sump 2 level switch high (LSH-18) is activated</li> <li>LRP-101 motor electrical overload is tripped</li> <li>System power has been interrupted</li> <li>Emergency shut-down button was pushed IN</li> </ul>

The operation of the LRP-102 is monitored by the system PLC. The LRP-102 has 3 modes that can be selected using the touchscreen on the control panel. Descriptions of the 3 modes are as follows:

#### **Liquid Ring Pump 102 Operations**

Mode	RUN	STOPS WHEN
HAND	CONTINUOUS	AFTER 10 MINUTES
OFF	NEVER	
AUTO	CONTINUOUS	<ul> <li>LRP-102 mode is turned to the "OFF" position</li> <li>LRP-102 discharge pressure transducer (PT-2) is high</li> <li>LRP combined discharge pressure transducer (PT-3) is high</li> <li>Knock-Out Tank level switch high high high (LSHHH-4) is activated</li> <li>Knock-Out Tank filter differential pressure (DPT-1) is high</li> <li>Knock-Out Tank vacuum (VT-15) is high or low</li> <li>LRP-102 vacuum (VT-17) is high or low</li> <li>LRP-102 oil level switch low (LSL-7) is activated</li> <li>LRP-102 oil level switch high (LSH-8) is activated</li> <li>LRP-102 oil temperature switch high (TSH-2) is activated</li> <li>Floor Sump 1 level switch high (LSH-17) is activated</li> <li>Floor Sump 2 level switch high (LSH-18) is activated</li> <li>LRP-102 motor electrical overload is tripped</li> <li>System power has been interrupted</li> <li>Emergency shut-down button was pushed IN</li> </ul>

#### 2.3 Knock-Out Tank

This DPE system is equipped with one 220 gallon Knock-Out Tank.

#### **Knock-Out Tank**

Soil vapor and water that initially enter this remediation system begin their processing in the Knock-Out Tank. The water and vapor is separated since they follow separate paths through the system (It is important to protect the LRP from ingesting water). The water collected in the Knock-Out Tank gravity feeds into TP-200 and TP-202. The vapors are directed out of the top of the Knock-Out Tank to the LRPs. See the table below for a description of the Knock-Out Tank float level logic.

#### **Knock-Out Tank Level Float Switch Logic**

Float Position	System Response
Water Level = LO (LSL-1)	PLC shuts down TP-200 and TP-202
Water Level = HI (LSH-2)	PLC turns TP-200 or TP-202 ON in Cycles
Water Level = HI HI (LSHH-3)	PLC turns TP-200 and TP-202 ON
Water Level = HI HI HI (LSHHH-4)	PLC shuts down LRP-101, LRP-102

#### **Knock-Out Tank Filter**

The L-style inlet vacuum filter is mounted on the top of the Knock-Out Tank. The vapors that exit the Knockout Tank flow into the filter. This filter is used to remove contaminants from the vapors before entering the LRPs. The filter is equipped with a differential pressure transmitter to monitor the clean pressure drop. See the table below for a description of the differential pressure transmitter logic.

#### **Differential Pressure Transmitter 1**

SETPOINTS	OPERATIONS
High Alarm Setpoint	Shuts down LRP-101 and LRP-102

## 2.4 Vapor Carbon Vessels

This system is equipped with dual 1000lb Vapor Carbon Adsorption (GAC) tanks used to remove additional contaminants from the soil vapor.

#### **Vapor Carbon Adsorber Tanks**

The Liquid Ring Pumps push the soil vapor outside of the treatment trailer and into the bottom of the first carbon vessel. The vapor is then forced up through the carbon and ejected out the top of the first tank and into the bottom of the second. Next, the vapor is forced up through the carbon in the second tank and discharged out the stack (mounted on the top of the second tank).

The dual carbon tank system allows for lower pressure drops, and provides continuous operation since one side can be serviced while the other is still functioning.

# **WARNING**

Proper ventilation precautions should be taken when servicing the carbon vessels or when any carbon is directly exposed to the atmosphere.

### 2.5 Transfer Pumps

There are 4 transfer pumps that are utilized to transfer water and product through and to exit the remediation system. The operation of each transfer pump is monitored and controlled by the system PLC, and have 3 modes of operation that can be selected on the system control panel.

### Transfer Pump 200 (TP-200)

TP-200 is a progressive cavity pump that is gravity fed by the water that collects in the Knock-Out Tank. The operation of TP-200 is monitored by the system PLC. TP-200 has 3 modes that can be selected using the touchscreen on the control panel. Descriptions of the 3 modes are as follows:

#### **Transfer Pump 200 Operations**

Mode	RUNS WHEN	STOPS WHEN
HAND	CONTINUOUS	AFTER 10 MINUTES
OFF	NEVER	
AUTO	Knock out tank HI float switch is activated (LSH-2) (TP-200 and TP-202 alternate operation based on the Knock-Out Tank HI float activation) or  Knock out tank HI HI float switch is activated (LSHH-3) (TP-200 and TP-202 both operate based on the Knock-Out Tank HI HI float activation)	<ul> <li>TP-200 mode is turned to the "OFF" position</li> <li>Knock-Out Tank Lo float switch is deactivated (LSL-1)</li> <li>TP-200 effluent pressure (PT-4) is low or high</li> <li>Oil Water Separator level switch high high (LSHH-11) is activated</li> <li>Oil Water Separator product level switch high high (LSHH-14) is activated</li> <li>Floor Sump 1 level switch high (LSH-17) is activated</li> <li>Floor Sump 2 level switch high (LSH-18) is activated</li> <li>TP-200 motor electrical overload is tripped</li> <li>System power has been interrupted</li> <li>Emergency shut-down button was pushed IN</li> </ul>

#### Transfer Pump 202 (TP-202)

TP-202 is a progressive cavity pump that is gravity fed by the water that collects in the Knock-Out Tank. The operation of TP-202 is monitored by the system PLC. TP-202 has 3 modes that can be selected using the touchscreen on the control panel. Descriptions of the 3 modes are as follows:

#### **Transfer Pump 202 Operations**

Mode	RUNS WHEN	STOPS WHEN
HAND	CONTINUOUS	AFTER 10 MINUTES
OFF	NEVER	
AUTO	Knock out tank HI float switch is activated (LSH-2) (TP-202 and TP-200 alternate operation based on the Knock-Out Tank HI float activation) or  Knock out tank HI HI float switch is activated (LSHH-3) (TP-202 and TP-200 both operate based on the Knock-Out Tank HI HI float activation)	<ul> <li>TP-202 mode is turned to the "OFF" position</li> <li>Knock-Out Tank Lo float switch is deactivated (LSL-1)</li> <li>TP-202 effluent pressure (PT-5) is low or high</li> <li>Oil Water Separator level switch high high (LSHH-11) is activated</li> <li>Oil Water Separator product level switch high high (LSHH-14) is activated</li> <li>Floor Sump 1 level switch high (LSH-17) is activated</li> <li>Floor Sump 2 level switch high (LSH-18) is activated</li> <li>TP-202 motor electrical overload is tripped</li> <li>System power has been interrupted</li> <li>Emergency shut-down button was pushed IN</li> </ul>

### Transfer Pumps 300 (TP-300)

TP-300 is a pneumatic operated diaphragm pump used to remove product that collects within the Oil Water Separator. TP-300 pumps the product through a totalizing flow meter, effluent of the treatment trailer, and into an existing 2000 gallon Product Tank. The operation of TP-300 is monitored by the system PLC. TP-300 has 3 modes that can be selected using the touchscreen on the control panel. Descriptions of the 3 modes are as follows:

#### **Transfer Pump 300 Operations**

Mode	RUN	STOPS WHEN
HAND	CONTINUOUS	AFTER 10 MINUTES
OFF	NEVER	
AUTO	Oil Water Separator HI product float switch is activated (LSH-13)	<ul> <li>TP-300 mode is turned to the "OFF" position</li> <li>Oil Water Separator LO product float switch is deactivated (LSL-12)</li> <li>Product Tank level switch high high (LSHH-15) is activated</li> <li>System power has been interrupted</li> <li>Emergency shut-down button was pushed IN</li> </ul>

#### Transfer Pump 301 (TP-301)

TP-301 is a centrifugal pump used to deliver water out of the Oil Water Separator and through the remaining filtration components. TP-301 pushes water through the Bag Filters, Liquid Clay Vessels, Liquid Carbon Vessels, through a totalizing liquid flow meter, and into a 750 gallon Treated Water Poly Tank. The water that collects inside of the 750 gallon Treated Water Poly Tank is manually gravity drained effluent of the trailer. The operation of TP-301 is monitored by the system PLC. TP-301 has 3 modes that can be selected using the touchscreen on the control panel. Descriptions of the 3 modes are as follows:

# **Transfer Pump 301 Operations**

Mode	RUNS WHEN	STOPS WHEN
HAND	CONTINUOUS	AFTER 10 MINUTES
OFF	NEVER	
AUTO	Oil Water Separator HI float switch is activated (LSH-10)	<ul> <li>TP-301 mode is turned to the "OFF" position</li> <li>Oil Water Separator LO float switch is deactivated (LSL-9)</li> <li>TP-301 effluent pressure (PT-6) is low or high</li> <li>Pre-Clay Vessel pressure (PT-7) is high</li> <li>Mid-Clay Vessel pressure (PT-8) is high</li> <li>Pre-Carbon Vessel pressure (PT-9) is high</li> <li>Mid-Carbon Vessel pressure (PT-10) is high</li> <li>Discharge pressure (PT-11) is high</li> <li>Bag Filter differential pressure (DPT-2) is high</li> <li>Clean Water Tank level switch high (LSH-16) is activated</li> <li>TP-301 motor electrical overload is tripped</li> <li>System power has been interrupted</li> <li>Emergency shut-down button was pushed IN</li> </ul>


# 2.6 Oil Water Separator

The oil-water separator is designed to remove all free and dispersed non-emulsified oil and various settled solids from the water. The oil water separator is a gravity displacement type unit comprised of an inlet chamber, sludge chamber, separation chamber, and clean water output chamber.

#### Oil -Water Separator

Water from the wells are pumped by TP-200 and TP-202 into the oil water separator inlet chamber where the turbulence water is calmed and the solid particles begin to settle. Then the oily water flows through coalescing media where two things happen. First, additional solids are trapped in the media and settle into the sludge baffle, and secondly, the media (plates) intercept tiny oil droplets and combine (coalesce) them with additional tiny droplets to create a large droplet that readily rises to the surface of the separation chamber. The larger oil droplets are then trapped behind the oil retention weir. The remaining water then passes the underflow and overflow weir into the clean water chamber and discharges into the holding tank.

#### Gravity Displacement Oil Water Separator



The main function of the water chamber is to serve as a liquid level indication for the oil-water separator.

The water chamber has a 3 level float system (LO, HI, HI HI), and each position is continuously monitored by the system PLC for overall system management. See the table below for a description of the oil water separator level logic.

#### Oil Water Separator Float Level Logic

Float Position	System Response
Water Level = LO (LSL-9)	PLC shuts down TP-301
Water Level = HI (LSH-10)	PLC turns TP-301 ON
Water Level = HI HI (LSHH-11)	PLC shuts down TP-200 and TP-202

#### **Product Chamber**

The main function of the product chamber is to serve as a liquid level indication for the oil-water separator product that collects.

The product chamber has a 3 level float system (LO, HI, HI HI), and each position is continuously monitored by the system PLC for overall system management. See the table below for a description of the oil water separator level logic.

#### **Product Float Level Logic**

Float Position	System Response
Product Level = LO (LSL-12)	PLC shuts down TP-300
Product Level = HI (LSH-13)	PLC turns TP-300 ON
Product Level = HI HI (LSHH-14)	PLC shuts down TP-200 and TP-202

## 2.7 Bag Filters

This system is equipped with one set of dual high-capacity particulate filters utilized to carry out gross particulate removal.

The dual system allows for lower pressure drops, and provides continuous operation since one side can be serviced while the other is still functioning. The filter housings are equipped with pressure gauges and a differential pressure transmitter to monitor the clean pressure drop (when the clean pressure drop exceeds a 15 psig, the bag filters require replacement -See *Section 6, Servicing*). The filter housings are equipped with a quick clamp cover to expedite filter replacement.

#### **Differential Pressure Transmitter 2**

SETPOINTS	OPERATIONS
High Alarm Setpoint	Shuts down TP301

# 2.8 Liquid Clay Vessels

This system is equipped with two 1000lbs Liquid Clay Adsorption tanks used to remove additional contaminants from the water after it passes through the bag filters.

There are two parallel sets of Liquid Clay Vessels set up in lead lag. After passing through the Bag Filters, TP-301 pushes the water into the top of the first clay vessel. The liquid is then forced down through the clay and ejected out of the bottom of the first vessel and into the top of the second vessel. Next, the liquid is forced down through the second vessel and discharged out of the bottom.

# 2.9 Liquid Carbon Vessels

This system is equipped with two 1000lbs Liquid Carbon Adsorption (GAC) tanks used to remove additional contaminants from the water after it passes through the clay vessels.

Like the Clay Vessels, there are two parallel sets of Liquid Carbon Vessels set up in lead lag. Pressurized water from TP-301 pushes the water into the top of the first carbon vessel. The liquid is then forced down through the carbon and ejected out of the bottom of the first tanks and into the top of the second tank. Next, the liquid is forced down through the second carbon vessel and discharged out of the bottom. The water then flows through a totalizing flow meter before entering the 750 gallon Poly Tank.

# **WARNING**

Proper ventilation precautions should be taken when servicing the carbon vessels or when any carbon is directly exposed to the atmosphere.

## 2.10 Water Storage Tank

This DPE system is equipped with one 750 gallon PolyTank. This is where treated water is stored until it is manually drained.

The water collected in the water holding tank is stored until it is manually drained. The holding tank has a 1 position (HI HI) float switch installed, and is continuously monitored by the PLC for overall system management. See the table below for a description of the holding tank float switch logic for your system.

#### Treated Water Poly Tank Float Switch Logic

Float Position	System Response
Water Level = HI HI (LSHH-16)	PLC shuts down TP-301

#### 2.11 Product Tank

This DPE system pumps product external of the treatment trailer to an existing Product Storage Tank.

The product from the Oil Water Separator exits the trailer and enters the 2000 gallon Product Tank. The Product Tank has a 1 position (HI HI) float switch installed, and is continuously monitored by the PLC for overall system management. See the table below for a description of the holding tank float switch logic for your system.

#### Product Tank Float Switch Logic

Float Position	System Response
Water Level = HI HI (LSHH-15)	PLC shuts down TP-300

## 2.12 Floor Sump

This remediation system has two Floor Sump level float switches in the process room that are used to alarm the system when water has flooded the system trailer floor.

See the table below for a description of the Floor Sump float switch logic for your system.

#### Front Floor Sump Float Logic

Level Position	System Response
Level Switch NC opened = HI (LSH-17)	Alarm - Shuts down LRP-101, LRP-102, TP-200, TP-202, TP-300, TP-301

#### Rear Floor Sump Float Logic

Level Position	System Response
Level Switch NC opened = HI (LSH-18)	Alarm - Shuts down LRP-101, LRP-102, TP-200, TP-202, TP-300, TP-301

# 2.13 Air Compressor

The 2 HP air compressor is used to operate the pneumatic valves and provide air to operate TP-300 in the DPE system. This system does monitor and regulate the pressure of the incoming compressed air. The Air Compressor is also available for the Bag Filter blow down replacement procedure.

Section 2

# 2.14 Automated Valves and Solenoid Manifold

The Automated Valves are located on each manifold string.

# Automated Valve 1 (AV1 - AV14)

AV1 – AV14 can be set to operate on/off or based on time of day cycle on the HMI. They are pneumatic operated valves that are driven by the solenoid manifold.

# 2.15 Miscellaneous Transducers and Meters

This system is equipped with transducers and flow meters that provide pressure, vacuum, and flow measurements. Outputs from transducers are monitored by the system PLC and are either used for system control or just recorded for statistics.

#### **Pressure Transmitters**

The table below is a list of pressure transducers that send inputs to the program logic controller.

Tag Name	Measures	Units	Location Description	Range
PT 1	Pressure	PSI	Liquid Ring Pump 101 Discharge Pressure	0-5
PT 2	Pressure	PSI	Liquid Ring Pump 102 Discharge Pressure	0-5
PT 3	Pressure	PSI	Combined Liquid Ring Pump Discharge Pressure	0-5
PT 4	Pressure	PSI	Transfer Pump 200 Discharge Pressure	0-50
PT 5	Pressure	PSI	Transfer Pump 202 Discharge Pressure	0-50
PT 6	Pressure	PSI	Transfer Pump 301 Discharge Pressure	0-50
PT 7	Pressure	PSI	Before Clay Vessel Pressure	0-50
PT 8	Pressure	PSI	Mid Clay Vessel Pressure	0-50
PT 9	Pressure	PSI	Before Carbon Vessel Pressure	0-50
PT 10	Pressure	PSI	Mid Carbon Vessel Pressure	0-50
PT 11	Pressure	PSI	Trailer Discharge Pressure	0-50
PT 12	Pressure	PSI	Compressed Air Pressure	0-200
DP 1	Differential Pressure	IWC	KO Tank Filter Differential Pressure	0-50
DP 2	Differential Pressure	PSID	Bag Filter Differential Pressure	0-50

#### **Flow Meters**

The table below is a list of flow meters that send inputs to the program logic controller.

Tag Name	Measures	Units	<b>Location Description</b>	
FT 1	Flow	SCFM	Liquid Ring Pump 101 Inlet Vapor Flow	0-740
FT 2	Flow	SCFM	Liquid Ring Pump 102 Inlet Vapor Flow	0-740
FT 3	Flow	GPM	Product Discharge Flow	0-50
FT 4	Flow	GPM	Water Discharge Flow	0-180

# Section 2

#### **Vacuum Transmitters**

The table below is a list of vacuum transducers that send inputs to the program logic controller.

Tag Name	Measures	Units	Location Description	Range
VT 1	Vacuum	PSIG	Manifold String 1 Vacuum	-14.7 – 30
VT 2	Vacuum	PSIG	Manifold String 2 Vacuum	-14.7 – 30
VT 3	Vacuum	PSIG	Manifold String 3 Vacuum	-14.7 – 30
VT 4	Vacuum	PSIG	Manifold String 4 Vacuum	-14.7 – 30
VT 5	Vacuum	PSIG	Manifold String 5 Vacuum	-14.7 – 30
VT 6	Vacuum	PSIG	Manifold String 6 Vacuum	-14.7 – 30
VT 7	Vacuum	PSIG	Manifold String 7 Vacuum	-14.7 – 30
VT 8	Vacuum	PSIG	Manifold String 8 Vacuum	-14.7 – 30
VT 9	Vacuum	PSIG	Manifold String 9 Vacuum	-14.7 – 30
VT 10	Vacuum	PSIG	Manifold String 10 Vacuum	-14.7 – 30
VT 11	Vacuum	PSIG	Manifold String 11 Vacuum	-14.7 – 30
VT 12	Vacuum	PSIG	Manifold String 12 Vacuum	-14.7 – 30
VT 13	Vacuum	PSIG	Manifold String 13 Vacuum	-14.7 – 30
VT 14	Vacuum	PSIG	Manifold String 14 Vacuum	-14.7 – 30
VT 15	Vacuum	PSIG	Knock-Out Tank Vacuum	-14.7 – 30
VT 16	Vacuum	PSIG	Liquid Ring Pump 101 Vacuum	-14.7 – 30
VT 17	Vacuum	PSIG	Liquid Ring Pump 102 Vacuum	-14.7 - 30

#### 2.16 Vent Fan and Heaters

Both the control room and process room are equipped with heaters and exhaust fans. The control room heater, process room heaters, process room vent fan, and control room vent fan all have separate thermostats.

Note - The vent fans are single phase and only turn in one direction.

#### **Vent Fans**

The mode for each vent fan is controlled by a 3 position (H-O-A) switch located on the control panel. The switch for the control room vent fan is labeled "C-FAN", and the process room vent fan switch is labeled "P-FAN". The thermostats (and temperature probes) that control the fans are located in the control room near the control panel. It is recommended to set the fan thermostats to 80° F.

#### Control Room Fan and Process Room Fan

There are three modes of operation for the vent fans are as follows:

#### **Hand Operations**

 The vent fan will run continuously. The only conditions that shut down the vent fan are thermal or electrical overload.

#### **Off Operations**

• The vent fan will not operate.

#### **Auto Operations**

• The vent fan will run according to the vent fan thermostat located near control panel

#### **Heaters**

#### Control Room Heat

The control room heater is controlled by a thermostat (dial) located on the heater. It is recommended to have this set at 45°F minimum during winter operations.

#### **Process Room Heat**

The process room heater is controlled by a thermostat located in the control room near the control panel. It is recommended to have this set at 45°F minimum during winter operations.

# 3.0 Standard Operating Procedures

Standard procedure is to connect the system to the main power supply and start the system.

# 3.1 Connecting the System to the Main Power Supply


It is recommended to use a professional electrical contractor or a certified ProAct technician to connect the main power supply to your remediation system.

#### CAUTION

Never power up the system unless there is absolutely no doubt the correct power supply has been connected. Considerable damage to the electrical components will most likely occur if the wrong power supply is connected and the system is powered up.

- 1) Turn "OFF" the main power disconnect switch on the front of the trailer.
- 2) Shut OFF all **circuit breakers** in the control panel and in the single phase breaker box (to the left of the control panel). Make sure that the disconnect on the front of the main control panel door is in the OFF position before attempting to open the door

For the initial startup it may be easier to use a wrench or pliers to turn the disconnect to the ON position with the door open. Only qualified, knowledgeable personnel should do this.



3) Connect the *correct* electrical power to the trailer main disconnect

The correct power supply for your system is as follows:

Power Supply 480-3-60

Recommended Minimum Service: 200 AMPS

Max Fuse: 200 AMPS

- 4) Have a qualified person use a multimeter and verify the voltage is correct. It can often be useful to record these voltages.
- 5) Turn ON the main disconnect on the outside of the trailer
- 6) Open the Main Control Panel Door. Power is live inside the panel. **ALWAYS** exercise extreme caution when working near electricity
- 7) Turn "ON" CB240 in the Main Control Panel. This supplies power to the single phase transformer
- 8) In the panel 1 single phase breaker box turn ON the 15 amp circuit breaker 1 "INT LIGHTS" for the interior lights
- 9) Turn on the overhead light and verify that it looks normal.
- 10) If the overhead light seems unusually dim or unusually bright then go to Step 11, if the light appears normal proceed to Step 12.

#### CAUTION

Abnormally bright: system voltage too high Abnormally dim: system voltage too low

- 11) Execute the following steps:
  - a) Turn OFF the "LIGHTS" circuit breaker in the breaker box
  - b) Turn OFF the main power disconnect switch on the front of the trailer.
  - c) Find a professional electrician to confirm the main power supply voltage
  - d) Return Step 1 in this section
- 12) In the panel 1 single phase breaker box turn ON the 15 amp circuit breaker 3 "EXT LIGHTS" for exterior lights
- 13) Bump test the Liquid Ring Pump 101 (3 phase) to ensure proper motor rotation
  - a) Have a qualified person open the Main Control Panel. Exercise caution the panel is live
  - b) Turn ON the Motor Starter breaker MS206 inside of the control panel
  - c) Momentarily energize LRP-101contactor
  - Have an assistant verify that the motor is rotating in the proper direction indicated by the rotation label on the motor housing
  - e) If rotation is correct, proceed to step 15, otherwise go to step 14.
- Have an electrician swap any 2 of the 3 main power (hot) lines that feed the main disconnect on the outside of the trailer All motors in the system have been wired to turn the same direction. If one 3 phase motor is turning the wrong direction, then all others will follow in suit. Return to Step 13.
- 15) The system is properly connected to the main power supply. Continue to Section 3.2

# 3.2 System Start-up

### **System Setup**

These pages are password protected and should only be changed by knowledgeable personnel. The pages hold the settings for system warnings, alarms, and delays. A brief description of each is given below.

### **System Setup Pages**

System Setup Configuration Fields	Type	Description			
Screen 1 - ADJUST SHUTDOWN SETPOINTS					
VT15 High Alarm Setpoint	Alarm Setpoint	Knock Out Tank Vacuum High Alarm Setpoint (IHG)			
VT15 Low Alarm Setpoint	Alarm Setpoint	Knock Out Tank Vacuum Low Alarm Setpoint (IHG)			
VT15 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Knock Out Vacuum Alarm			
VT16 High Alarm Setpoint	Alarm Setpoint	LRP-101 Vacuum High Alarm Setpoint (IHG)			
VT16 Low Alarm Setpoint	Alarm Setpoint	LRP-101 Vacuum Low Alarm Setpoint (IHG)			
VT16 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for LRP-101 Vacuum Alarm			
VT17 High Alarm Setpoint	Alarm Setpoint	LRP-102 Vacuum High Alarm Setpoint (IHG)			
VT17 Low Alarm Setpoint	Alarm Setpoint	LRP-102 Vacuum Low Alarm Setpoint (IHG)			
VT17 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for LRP-102 Vacuum Alarm			
PT1 High Alarm Timer	Alarm Setpoint	LRP-101 Pressure High Alarm Setpoint (IWC)			

# Section 3

System Setup Configuration Fields	Туре	Description			
PT1 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for LRP-101 Pressure Alarm			
	Screen 2 - ADJU	ST SHUTDOWN SETPOINTS			
PT2 High Alarm Timer	Alarm Setpoint	LRP-102 Pressure High Alarm Setpoint (IWC)			
PT2 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for LRP-102 Pressure Alarm			
PT3 High Alarm Timer	Alarm Setpoint	LRP-101, LRP-102 Combined Pressure High Alarm Setpoint (IWC)			
PT3 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for LRP-101, LRP-102 Combined Pressure Alarm			
PT4 High Alarm Setpoint	Alarm Setpoint	TP-200 Pressure High Alarm Setpoint (PSI)			
PT4 Low Alarm Setpoint	Alarm Setpoint	TP-200 Pressure Low Alarm Setpoint (PSI)			
PT4 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for TP-200 Pressure Alarm			
PT5 High Alarm Setpoint	Alarm Setpoint	TP-202 Pressure High Alarm Setpoint (PSI)			
PT5 Low Alarm Setpoint	Alarm Setpoint	TP-202 Pressure Low Alarm Setpoint (PSI)			
PT5 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for TP-202 Pressure Alarm			
	Screen 3 - ADJUST SHUTDOWN SETPOINTS				
PT6 High Alarm Setpoint	Alarm Setpoint	TP-301 Pressure High Alarm Setpoint (PSI)			
PT6 Low Alarm Setpoint	Alarm Setpoint	TP-301 Pressure Low Alarm Setpoint (PSI)			
PT6 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for TP-301 Pressure Alarm			

System Setup Configuration Fields	Туре	Description		
PT7 High Alarm Setpoint	Alarm Setpoint	Pre-Clay Pressure High Alarm Setpoint (PSI)		
PT7 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Pre-Clay Pressure Alarm		
PT8 High Alarm Setpoint	Alarm Setpoint	Mid-Clay Pressure High Alarm Setpoint (PSI)		
PT8 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Mid-Clay Pressure Alarm		
PT9 High Alarm Setpoint	Alarm Setpoint	Pre-Carbon Pressure High Alarm Setpoint (PSI)		
PT9 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Pre-Carbon Pressure Alarm		
PT10 High Alarm Setpoint	Alarm Setpoint	Mid-Carbon Pressure High Alarm Setpoint (PSI)		
PT10 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Mid-Carbon Pressure Alarm		
Screen 4 - ADJUST ALARM/SHUTDOWN SETPOINTS				
PT11 High Alarm Setpoint	Alarm Setpoint	Post-Carbon Pressure High Alarm Setpoint (PSI)		
PT11 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Post-Carbon Pressure Alarm		
PT12 Low Alarm Setpoint	Alarm Setpoint	Air Compressor Low Alarm Setpoint (PSI)		
PT12 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Air Compressor Pressure Alarm		
DPT1 High Alarm Setpoint	Alarm Setpoint	KO Tank Differential Pressure High Alarm Setpoint (IWC)		
DPT1 High High Alarm Setpoint	Alarm Setpoint	KO Tank Differential Pressure High High Alarm Setpoint (IWC)		

System Setup Configuration Fields	Туре	Description		
DPT1 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for KO Tank Differential Pressure Alarm		
DPT2 High High Alarm Setpoint	Alarm Setpoint	Bag Filter Differential Pressure High High Alarm Setpoint (PSID)		
DPT2 Alarm Timer	Time Delay Setpoint	Alarm Delay Time (Seconds) for Bag Filter Differential Pressure Alarm		
Screen 5 - MAINTENANCE OPTIONS				
CHANGE TIME / DATE	System Setting	Allows The Time and Date to be Manually Changed		
SECURITY	System Setting	Allows User to Enter or Edit Password to have Access to the System Controls		
CHANGE TIME / DATE PLC	System Setting	Allows The Time and Date to be Manually Changed on the Program Logic Controller		

Section 3

## 3.3 Sampling and Monitoring

# Sampling

Sampling ports should be sampled per discharge permit requirements, or as required.

Please use the following sample collection instructions

- 1) Allow the water or vapor from the sample port(s) to run for 10 seconds to ensure a representative sample is collected
- 2) Follow proper sampling instructions.
- 3) Make sure you are wearing the proper safety clothing and equipment.

Note - It is essential that samples reach the appropriate laboratory as soon as possible after sampling collection. If you are mailing sample(s) to the laboratory, check your local postal schedule beforehand, and plan the sample collection accordingly.

### Monitoring

The treatment equipment should be monitored weekly during continuous operation to record operating flow rates, pressure measurements, and the volume of material treated.

The weekly monitoring allows the operator to evaluate the system operations. It is important to visually inspect the treatment equipment on a monthly basis. Any variation from normal operations may require additional maintenance or repair.

#### 3.4 Normal Shut-down

The system may require shut down (deactivation) for repairs, maintenance, or general servicing. It is recommended to use the following procedures:

- 1) Prior to deactivation of the system, record all flow rates, pressures, and other applicable information if required
- 2) On the Red Lion mode select screen, press the "OFF" button on all components
- If applicable, turn OFF all disconnects and breakers in the Control Panel and in Breaker Panel 1.

Note – If treatment is complete and the system is being removed, then all valves should be opened and all vessels and pumps drained and decontaminated

# 4.0 System Faults and Troubleshooting

# 4.1 Touch Screen Warning and Alarm Messages

The control panel for your system has fault condition lights that illuminate on the Red Lion touchscreen interface as necessary to warn the user of certain fault conditions, and they also aid in troubleshooting. A description of faults that activate the lights and the associated system response is detailed on the next pages.

ALARM ON TOUCH SCREEN	DESCRIPTION	TEXT BACKGROUND
SYSTEM ESTOPPED	The Emergency Stop has been triggered	RED
POWER FAIL ALARM	There has been an interruption of Main Line Power to the control system	RED
ANALOG OUTPUT SIGNAL IS OUT OF RANGE	An analog Output signal is out of range (3.8mA>AS>20mA)	YELLOW
KNOCK OUT TANK VACUUM HIGH ALARM SETPOINT	Knock Out Tank Vacuum is High (VT15)	RED
KNOCK OUT TANK VACUUM LOW ALARM	Knock Out Tank Vacuum is Low (VT15)	RED
LRP-101 VACUUM HIGH ALARM	Liquid Ring Pump 101 Vacuum is High (VT16)	RED
LRP-101 VACUUM LOW ALARM	Liquid Ring Pump 101 Vacuum is Low (VT16)	RED
LRP-102 VACUUM HIGH ALARM	Liquid Ring Pump 102 Vacuum is High (VT17)	RED
LRP-102 VACUUM LOW ALARM	Liquid Ring Pump 102 Vacuum is Low (VT17)	RED
LRP-101 PRESSURE HIGH ALARM	Liquid Ring Pump 101 Pressure is High (PT1)	RED
LRP-102 PRESSURE HIGH ALARM	Liquid Ring Pump 102 Pressure is High (PT2)	RED
LRP-101, LRP-102 COMBINED PRESSURE HIGH ALARM	Liquid Ring Pump 101 and Liquid Ring Pump 102 Combined Pressure is High (PT3)	RED
TP-200 PRESSURE HIGH ALARM	Transfer Pump 200 Pressure Is High (PT4)	RED
TP-200 PRESSURE LOW ALARM	Transfer Pump 200 Pressure Is Low (PT4)	RED
TP-202 PRESSURE HIGH ALARM	Transfer Pump 202 Pressure Is High (PT5)	RED
TP-202 PRESSURE LOW ALARM	Transfer Pump 202 Pressure Is Low (PT5)	RED
TP-301 PRESSURE HIGH ALARM	Transfer Pump 301 Pressure Is High (PT6)	RED

# Section 4

ALARM ON TOUCH SCREEN	DESCRIPTION	TEXT BACKGROUND
TP-301 PRESSURE LOW ALARM	Transfer Pump 301 Pressure Is Low (PT6)	RED
PRE-CLAY PRESSURE HIGH ALARM	Before Clay Vessel Pressure Is High (PT7)	RED
MID-CLAY PRESSURE HIGH ALARM	Mid-Stage Clay Vessel Pressure Is High (PT8)	RED
PRE-CARBON PRESSURE HIGH ALARM	Before Carbon Vessel Pressure Is High (PT9)	RED
MID-CARBON PRESSURE HIGH ALARM	Mid-Stage Carbon Vessel Pressure Is High (PT10)	RED
POST-CARBON PRESSURE HIGH ALARM	Discharge Pressure Is High (PT11)	RED
AIR COMPRESSOR LOW PRESSURE ALARM	Air Compressor Pressure is Low (PT12)	YELLOW
KO TANK DIFFERENTIAL PRESSURE HIGH ALARM	Knock-Out Tank Filter Differential Pressure is High (DPT1)	RED
KO TANK DIFFERENTIAL PRESSURE HIGH HIGH ALARM	Knock-Out Tank Filter Differential Pressure is High High (DPT1)	RED
BAG FILTER DIFFERENTIAL PRESSURE HIGH HIGH ALARM	Bag Filter Differential Pressure is High High (DPT2)	RED

# **4.2 Troubleshooting**

The following chart should be used to troubleshoot system malfunctions. Each component OMM also has a troubleshooting guide which should be used to address component specific troubleshooting.

ALARM ON TOUCH SCREEN	POSSIBLE CAUSES
SYSTEM ESTOPPED	An emergency stop has been activated by pushing in one of the E-Stop switches Sometimes this is triggered by turning off the disconnect on the main control panel door
POWER FAIL ALARM	Power failure that has exhausted other power backups Disconnect on front of main control panel was left off
ANALOG OUTPUT SIGNAL IS OUT OF RANGE	The mA value is out of spec A wiring short or break could cause this
KNOCK OUT TANK VACUUM HIGH ALARM SETPOINT	Liquid Ring Pump not running in AUTO mode Process Gate Valves on manifold strings too far closed Faulty vacuum transducer
KNOCK OUT TANK VACUUM LOW ALARM	Air Dilution Valve on manifold header too far open Process Gate Valves on manifold strings too far open Faulty vacuum transducer
LRP-101 VACUUM HIGH ALARM	Liquid Ring Pump 101 not running in AUTO mode Faulty vacuum transducer
LRP-101 VACUUM LOW ALARM	Knock Out Tank Filter needs replacement Faulty vacuum transducer
LRP-102 VACUUM HIGH ALARM	Liquid Ring Pump 102 not running in AUTO mode Faulty vacuum transducer
LRP-102 VACUUM LOW ALARM	Knock Out Tank Filter needs replacement Faulty vacuum transducer
LRP-101 PRESSURE HIGH ALARM	A downstream obstruction in plumbing Process Ball Valve after Pressure Transducer too far closed LRP-101 worn or not running in AUTO mode Faulty Pressure Transducer
LRP-102 PRESSURE HIGH ALARM	A downstream obstruction in plumbing Process Ball Valve after Pressure Transducer too far closed LRP-102 worn or not running in AUTO mode Faulty Pressure Transducer
LRP-101, LRP-102 COMBINED PRESSURE HIGH ALARM	A downstream obstruction in plumbing Vapor Carbon has depleted Faulty Pressure Transducer
TP-200 PRESSURE HIGH ALARM	A downstream obstruction in plumbing Check valve malfunction Oil Water Separator backed up Faulty Pressure Transducer
TP-200 PRESSURE LOW ALARM	Influent plumbing to Transfer Pump 200 is obstructed or not primed Knock-Out Tank is full of sediment Y-Strainer or influent pipe is clogged or broken Faulty Pressure Transducer

# Section 4

ALARM ON TOUCH SCREEN	POSSIBLE CAUSES
TP-202 PRESSURE HIGH ALARM	A downstream obstruction in plumbing Check valve malfunction Oil Water Separator backed up Faulty Pressure Transducer
TP-202 PRESSURE LOW ALARM	Influent plumbing to Transfer Pump 200 is obstructed or not primed Knock-Out Tank is full of sediment Y-Strainer or influent pipe is clogged or broken Faulty Pressure Transducer
TP-301 PRESSURE HIGH ALARM	A downstream obstruction in plumbing Check valve malfunction Carbon or Clay Vessels need media change out Faulty Pressure Transducer
TP-301 PRESSURE LOW ALARM	Influent plumbing to Transfer Pump 301 is obstructed or not primed Oil Water Separator effluent valve too far closed Faulty Pressure Transducer
PRE-CLAY PRESSURE HIGH ALARM	Particulate filters need replacement Influent valve to particulate filters too far closed Plumbing between Bag Filters and Clay Vessels is clogged Faulty Pressure Transducer
MID-CLAY PRESSURE HIGH ALARM	Plumbing between Clay Vessels is obstructed Faulty Pressure Transducer
PRE-CARBON PRESSURE HIGH ALARM	Plumbing between Clay Vessels and Carbon Vessels is obstructed Faulty Pressure Transducer
MID-CARBON PRESSURE HIGH ALARM	Plumbing between Carbon Vessels is obstructed Faulty Pressure Transducer
POST-CARBON PRESSURE HIGH ALARM	Plumbing between Carbon Vessels and Treated Water Tank is obstructed Faulty Pressure Transducer
AIR COMPRESSOR LOW PRESSURE ALARM	Air line Ball Valve on Air Compressor too far closed Faulty Pressure Transducer
KO TANK DIFFERENTIAL PRESSURE HIGH ALARM	Knock-Out Tank Filter needs replacement Faulty Pressure Transducer
KO TANK DIFFERENTIAL PRESSURE HIGH HIGH ALARM	Bag Filter needs replacement Faulty Pressure Transducer
BAG FILTER DIFFERENTIAL PRESSURE HIGH HIGH ALARM	Bag Filter needs replacement Faulty Pressure Transducer

All other technical or unknown problems should be directed to a ProAct technician. Please call (231) 843-2711.

# **5.0 Preventative Maintenance**

Maintenance of the environmental treatment system should be scheduled on a monthly and quarterly basis.

### 5.1 Weekly

Record operational information Inspect all plumbing for integrity Inspect DPE dilution air filter Inspect LRP oil levels Inspect knock out tank filter

In harsh environments, it will be necessary to exercise all ball valves to ensure good working order. Ball valves left in the same position for long periods of time may seize.

### 5.2 Monthly

Inspect Liquid Ring Pump
Inspect Transfer Pumps
Inspect all tanks
Inspect Air Compressor
Inspect all electrical connections
Grease Liquid Ring Pump bearings
Test motor conditions (Amps and Volts)
Inspect flow meters
Inspect/clean vent screens
Verify shutters open and close freely
Test Emergency Stops

# **5.3 Quarterly**

Inspect and test pressure, and vacuum transducers Inspect tank O-rings Inspect air bleeds, pressure gauges, sample ports Inspect cam locks & fittings Test alarm conditions to verify shutdown sequences

# 6.0 Servicing

## **6.1 Particulate Filter Bag Change**

It is recommended to change particulate filter elements (bags) when the pressure drops across the filters reach 15 psig. (Clean pressure drop  $\approx$  2psig). The following procedure should be used to change the particulate filter bags. Please note that the system does not need to be shut down.

#### Blow out the Filter Housing with Compressed air

- 1. Close the influent and effluent valve on the bag filter housing that requires a bag change.
- 2. Connect one end of a drain hose to the filter housing drain valve (1" cam-lock) and place the other end in your drain vessel.
- 3. Observe the pressure gage on the filter housing. Open the drain valve and be prepared for a high pressure discharge out the drain hose. If necessary, have an assistant or other setup secure the drain hose.
- 4. Connect an air hose to the air chuck located on the respective filter housing.
- 5. Refer to Appendix B and read the "Operating" manual for the Ingersoll Rand air compressor.
- 6. Turn on the air compressor and supply 5-10 PSI air pressure to the respective filter housing.
- 7. Open the ball valve just past the air chuck and allow the compressed air to blow out the filter housing. It may be necessary to cycle this ball valve open and closed a few times to allow sufficient pressure to repeatedly build and remove as much water as possible from the filter.
- 8. Close the air chuck ball valve on the filter housing. Allow any residual air pressure in the filter housing to bleed off and verify that the pressure gage reads "0" PSI

#### Remove and Replace the Filter Element

- 9. Unclamp the retaining ring for the housing lid
- 10. Open lid and remove bag filter
- 11. Place new bag filter in bag filter housing
- 12. Replace and fasten the lid.
- 13. Reopen the influent and effluent valves on the bag filter housing (Always open influent valve first)
- 14. Proceed Steps 1-13 for the remaining particulate filters

# 6.2 Carbon Servicing and Disposal

This servicing of the spent carbon is recommended to be done by trained individuals. Spent carbon typically will need to be classified to determine if the carbon is hazardous or non-hazardous. Spent carbon is typically brought to a regeneration facility and reactivated. In special cases, the spent carbon may be sent to a land fill.

# **WARNING**

Extreme care must be exercised when handling spent activated carbon. If the adsorbed materials are carcinogenic and their toxic exposure routes are adsorption, inhalation, or ingestion; personnel who handle this material should be equipped with respirator, safety glasses, neoprene or buna-n Gloves, as well as an impervious laboratory apron or clothing.

## 6.3 Swapping Lead and Lag Vapor Carbon

When the carbon's adsorbtion capacity is nearing depletion it is possible to swap lead and lag vessels to allow time to schedule a carbon replacement.

- 1. Turn off the LRP-101, LRP-102
- 2. Change hose connections to correspond to the desired setup
- 3. Restart system

# Appendix A

# **DRAWINGS**

<u>Drawing</u>	<u>Description</u>	Sheet
Plan	PLAN VIEW LAYOUT	1
P & ID	PROCESS & INSTRUMENTATION DIAGRAM	2
P & ID Legend	PROCESS & INSTRUMENTATION LEGEND	3
E-001	ABBREVIATIONS & SYMBOLS - ELECTRICAL	1
E-002	480VAC POWER WIRING	2
E-003	120VAC POWER WIRING	3
E-004	PLC INPUT CARD WIRING	4
E-004A	PLC INPUT CARD WIRING	5
E-004B	PLC INPUT CARD WIRING	6
E-005	PLC OUTPUT CARD WIRING	7
E-006	PLC ANALOG INPUT CARD WIRING	8
E-007	PLC ANALOG INPUT CARD WIRING	9
E-008	PLC ANALOG INPUT CARD WIRING	10
E-009	PANEL 1 ELECTRICAL SCHEMATIC	11
E-010	CONTROL PANEL PARTS LAYOUT INT	12
E-011	CONTROL PANEL PARTS LAYOUT EXT	13

# Appendix B

# **CONTROL ROOM COMPONENTS**

<u>Component</u>	<u>PID</u>	<u>Description</u>	<u>Manufacturer</u>	<u>Part Number</u>
Transformer		15kVA Transformer – Single Phase	Dongan	85-1070SH
Controller	PLC	Programmable Automation Controller	Allen Bradley CompactLogix	1769-L32E
Discrete Input Module		Discrete Input Module 32 Inputs, DC	Allen Bradley	1769-IQ32
Discrete Input Module		Discrete Input Module 16 Inputs, DC	Allen Bradley	1769-IQ16
Discrete Output Module		Discrete Output Module 16 Outputs	Allen Bradley	1769-OW16
Analog Input Module		Analog Input Module 8 Inputs, 4-20mA	Allen Bradley	1769-IF8
Touchscreen		10" Color Touchscreen Interface (HMI)	Red Lion	G310C210
Cellular Modem		Cellular Communications for system	MultiTech	MTCBA-EV2-EN2-N3
UPS		Uninterrupted Power Supply 120 VAC, 60HZ, SDU series	Sola	SDU850
Air Compressor		Air Compressor - 2HP, 20 Gallon Capacity, 4.6CFM, 135PSI, 120V, 60HZ	Ingersoll Rand	P1.5IU-A9

Component	PID	<u>Description</u>	<u>Manufacturer</u>	Part Number
Manifold for Solenoids		Solenoid Valve Manifold - 4 Station Dual	SMC	VV5Q21-04
Solenoid for Automated Valves		Solenoid Valve - 4 Position Dual 3 Port Valve	SMC	VQ2000
Air Filter		Air Filter for Air Compressor - 3/8" NPT Inlet and Outlet, NO Float	SMC	AF30-N03D-Z Filter Element: AF30P-060S
Mist Separator		Mist Separator for Air Compressor - 3/8" NPT Inlet and Outlet, NO Float	SMC	AFM30-N03D-Z Filter Element: AFM30P-060AS
Heater		Control Room Convection Heater 3kW, 240/208V, 1 PH, 12.5/11A	Dayton	2YU58
C-Fan		12" Control Room Ventilation Fan	Dayton	1HKL4
P-Fan Thermostat		Thermostat - Process Room Fan	Honeywell	T6031A
P-Heat Thermostat		Thermostat - Process Room Heat	Honeywell	T6031A
C-Fan Thermostat		Thermostat - Control Room Fan	Honeywell	T6031A
Shutter		12" x 12" Shutter for Control Room Man Door	Dayton	4C556
Shutter		12" x 12" Shutter for Vent Fan	Dayton	4C556
Pressure Transducer	PT12	Pressure Transducer - Air Compressor (0 - 200 PSI)	Dwyer	628-12

Component	PID	<u>Description</u>	<u>Manufacturer</u>	Part Number
Pressure Gauge	PI21	Pressure Indicator - Air Compressor (0 - 200 PSI)	Precision Instrument Co	201L 202L
Light (Flood)		Flood Light Outside - Near Control Room door	RAB	WPTS70



# **Single Phase - General Purpose**

# Primary Volts 240 X 480, Secondary Volts 120 / 240


	General Infor	mation		Winding Specifications			าร	Dimensions			
kVA Cap.	Catalog Number	Hz.	Wgt. Lbs	Taps		m Amps	Conn Dia. Pg. 15	Λ	Width B	Depth C	Outline Dwg.
					Pri.	Sec.	Ŭ				
.050	35-1005	50/60	3.3	0	.2 / .1	.4 / .2	1	6.37	3.75	3.37	1
.100	35-1010	50/60	5	0	.4 / .2	.8 / .4	1	6.37	3.75	3.37	1
.150	35-1015	50/60	7	0	.6 / .3	1.2 / .6	1	7.00	4.00	3.63	2
.250	85-1020SH	50/60	14	0	1.0 / .52	2.0 / 1.0	4	12.00	4.87	5.25	3
.500	85-1025SH	50/60	18	0	2.0 / 1.0	4.1 / 2.0	4	12.00	4.87	5.25	3
.750	85-1030SH	50/60	22	0	3.1 / 1.6	6.2 / 3.1	4	12.00	4.87	5.25	3
1.0	85-1035SH	60	29	0	4.1 / 2.0	8.3 / 4.1	4	15.25	5.75	5.87	3
1.5	85-1040SH	60	37	0	6.2 / 3.1	12.5 / 6.2	4	15.25	5.75	5.87	3
2.0	85-1045SH	60	42	0	8.3 / 4.1	16.6 / 8.3	4	15.25	5.75	5.87	3
3.0	85-1050SH	60	62	0	12.5 / 6.2	25.0 / 12.5	4	15.25	8.25	7.87	3
3.0	85-1450SH	60	62	4	12.5 / 6.2	25.0 / 12.5	2	15.25	8.25	7.87	3
5.0	85-1055SH	60	102	0	20.8 / 10.4	41.6 / 20.8	4	15.25	8.25	7.87	3
5.0	85-1455SH	60	102	4	20.8 / 10.4	41.6 / 20.8	2	15.25	8.25	7.87	3
7.5	85-1060SH	60	131	0	31 / 15.6	62 / 31	4	15.75	14.25	8.75	4
7.5	85-1460SH	60	131	4	31 / 15.6	62 / 31	2	15.75	14.25	8.75	4
10	85-1065SH	60	152	0	41 / 20	83 / 41	4	15.75	14.25	8.75	4
10	85-1465SH	60	152	4	41 / 20	83 / 41	2	15.75	14.25	8.75	4
15	85-1070SH	60	270	0	62 / 31	125 / 62	4	19.38	17.56	11.50	4
15	85-1470SH	60	270	4	62 / 31	125 / 62	2	19.38	17.56	11.50	4
25	85-1075SH	60	300	0	104 / 52	208 / 104	4	19.38	17.56	11.50	4
25	85-1475SH	60	300	4	104 / 52	208 / 104	2	19.38	17.56	11.50	4

# Floor Mount, Cabinet Style Enclosure


7.5	61-1460SH	60	125	4	31 / 15.6	62 / 31	2	22.00	16.00	14.00	5
10	61-1465SH	60	133	4	41 / 20	83 / 41	2	22.00	16.00	14.00	5
15	61-1470SH	60	185	4	62 / 31	125 / 62	2	23.50	18.62	16.00	5
25	61-1475SH	60	281	4	104 / 52	208 / 104	2	23.50	18.62	16.00	5
37.5	61-1680SH	60	384	6	156 / 78	312 / 156	3	32.00	27.00	26.25	5
50	61-1685SH	60	445	6	208 / 104	416 / 208	3	32.00	27.00	26.25	5
75	61-1690SH	60	663	6	312 / 156	625 / 312	3	41.00	34.00	26.75	5
100	61-1695SH	60	732	6	416 / 208	833 / 416	3	41.00	34.00	26.75	5

# Primary Volts 240 X 480, Secondary Volts 120 - Fused


(	General Infor	mation		Winding Specifications			าร	Dimensions			
kVA	Catalog Number	Hz.	wgt. Tans waximum Amps Dia		Maximum Amps		Conn Dia.	Height	Width B		Outline Dwg.
Cap.	Number		Lbs		Pri.	Sec.	Pg. 16	Α	ь	С	Pg. 24
.100	35-2010	50/60	5	0	.4 / .2	.8	11	6.37	3.75	3.38	6
.150	35-2015	50/60	7	0	.6 / .3	1.2	11	7.00	4.00	3.63	7
.250	35-2020	50/60	11	0	1.0 / .52	2.0	11	7.50	4.50	4.00	7
.500	35-2025	50/60	20	0	2.0 / 1.0	4.1	11	9.16	5.38	4.56	7
.750	35-2030	50/60	29	0	3.1 / 1.6	6.2	11	10.75	5.50	4.75	7
1.0	80-2035	50/60	29	0	4.1 / 2.0	8.3	11	10.88	5.50	4.75	7
1.5	80-2040	50/60	37	0	6.2 / 3.1	12.5	11	10.19	6.50	5.66	7




Outline Drawing 1
Wall Mount - Ventilated - NEMA 1




Outline Drawing 2
Wall Mount - Ventilated - NEMA 3R



Outline Drawing 3
Wall Mount - Encapsulated - NEMA 3R
Note: 3 kVA & 5kVA 85 Series are also
available in Outline Drawing 4
Configuration



Wall Mount - Encapsulated - NEMA 3R




Outline Drawing 5
Floor Mount - Ventilated - NEMA 3R


# DONG

# **Single Phase Connection Diagrams**


Dia. 1	Catalog Series 35-10XX & 80-10XX								
Tap Arrangement		None							
% High Voltage	High Voltage 240 X 480	Inter- Connect	Connect High Voltage Lines To						
100	240	H1 To H3 H2 To H4	H1H3 & H2H4						
100	480	H2 To H3	H1 & H4						
% Low Voltage	Low Voltage 120 / 240	Inter- Connect	Connect Low Voltage Lines To						
100	120	X1 To X3 X2 To X4	X1X3 & X2X4						
100	120 / 240	X2 To X3	X1 & X2X3 & X4						
100	240	Y2 To Y3	X1 & X4						



Dia. 4	Catalog Series 85-10XXSH							
Tap Arrangement		None						
% High Voltage	High Voltage 240 X 480	Inter- Connect	Connect High Voltage Lines To					
100	240	H1 To H3 H2 To H4	H1H3 & H2H4					
100	480	H2 To H3	H1 & H4					
% Low Voltage	Low Voltage 120 / 240	Inter- Connect	Connect Low Voltage Lines To					
100	120	X1 To X3 X2 To X4	X1X3 & X2X4					
100	120 / 240	X2 To X3	X1 & X2X3 & X4					
100	240	X2 To X3	X1 & X4					




Dia. 7	Catalog Series 61-34XXSH									
Tap Arrangement			acity Above Normal) acity Below Normal)							
% High Voltage	High Voltage 208	Inter- Connect	Connect High Voltage Lines To							
105	218	1 To 2								
102.5	213	2 To 3								
100	208	3 To 4	H1 & H2							
97.5	203	4 To 5								
95	198	5 To 6								
% Low Voltage	Low Voltage 120 / 240	Inter- Connect	Connect Low Voltage Lines To							
100	120	X1 To X3 X2 To X4	X1X3 & X2X4							
100	120 / 240	X2 To X3	X1 & X2X3 & X4							
100	240	X2 To X3	X1 & X4							
H1		-	H2							



Dia. 2	Catalog Series 85-14XXSH & 61-14XXSH		
Tap Arrangement	2 - 2½ FCAN (Full Capacity Above Normal) 2 - 2½ FCBN (Full Capacity Below Normal)		
% High Voltage	High Voltage 240 X 480	Inter- Connect	Connect High Voltage Lines To
105	252	H1 To 2 H2 To 1	
100	240	H1 To 4 H2 To 3	
95	228	H1 To 6 H2 To 5	
105	504	1 To 2	H1 & H2
102.5	492	2 To 3	
100	480	3 To 4	
97.5	468	4 To 5	
95	456	5 To 6	
% Low Voltage	Low Voltage 120 / 240	Inter- Connect	Connect Low Voltage Lines To
100	120	X1 To X3 X2 To X4	X1X3 & X2X4
100	120 / 240	X2 To X3	X1 & X2X3 & X4
100	240	X2 To X3	X1 & X4
H1	-	1	H2

H1	5 3 1	2 4	6 H2
SH X4	, (	2 X3	X1

Dia. 5	Catalog Series 35-30XX & 80-30XX		
Tap Arrangement	None		
% High Voltage	High Voltage 208	Inter- Connect	Connect High Voltage Lines To
100	208		H1 & H2
% Low Voltage	Low Voltage 120 / 240	Inter- Connect	Connect Low Voltage Lines To
100	120	X1 To X3 X2 To X4	X1X3 & X2X4




X2 To X3

100

Dia. 3	Catalog Series 61-16XXSH		
Tap Arrangement	2 - 21/2 FCAN (Full Capacity Above Normal)		
% High Voltage	High Voltage 240 X 480	Inter- Connect	Connect High Voltage Lines To
105	252	H1 To 2 H2 To 1	
100	240	H1 To 4 H2 To 3	
95	228	H1 To 6 H2 To 5	
90	216	H1 To 8 H2 To 7	
105	504	1 To 2	H1 & H2
102.5	492	2 To 3	
100	480	3 To 4	
97.5	468	4 To 5	1
95	456	5 To 6	
92.5	444	6 To 7	
90	432	7 To 8	
% Low Voltage	Low Voltage 120 / 240	Inter- Connect	Connect Low Voltage Lines To
100	120	X1 To X3 X2 To X4	X1X3 & X2X4
100	120 / 240	X2 To X3	X1 & X2X3 & X4
100	240	X2 To X3	X1 & X4
H1 7 5 3 1 2 4 6 8 H2			

Dia. 6	Catalog Series 85-30XXSH		
Tap Arrangement	None		
% High Voltage	High Voltage 208	Inter- Connect	Connect High Voltage Lines To
100	208		H1 & H2
% Low Voltage	Low Voltage 120 / 240	Inter- Connect	Connect Low Voltage Lines To
100	120	X1 To X3 X2 To X4	X1X3 & X2X4
100	120 / 240	X2 To X3	X1 & X2X3 & X4
100	240	X2 To X3	X1 & X4





# 1769 CompactLogix Controllers User Manual

Catalog Numbers 1769-L31, 1769-L32C, 1769-L32E, 1769-L35CR, 1769-L35E











### **Important User Information**

Solid-state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls (publication SGI-1.1 available from your local Rockwell Automation sales office or online at <a href="http://www.rockwellautomation.com/literature/">http://www.rockwellautomation.com/literature/</a>) describes some important differences between solid-state equipment and hard-wired electromechanical devices. Because of this difference, and also because of the wide variety of uses for solid-state equipment, all persons responsible for applying this equipment must satisfy themselves that each intended application of this equipment is acceptable.

In no event will Rockwell Automation, Inc. be responsible or liable for indirect or consequential damages resulting from the use or application of this equipment.

The examples and diagrams in this manual are included solely for illustrative purposes. Because of the many variables and requirements associated with any particular installation, Rockwell Automation, Inc. cannot assume responsibility or liability for actual use based on the examples and diagrams.

No patent liability is assumed by Rockwell Automation, Inc. with respect to use of information, circuits, equipment, or software described in this manual.

Reproduction of the contents of this manual, in whole or in part, without written permission of Rockwell Automation, Inc., is prohibited.

Throughout this manual, when necessary, we use notes to make you aware of safety considerations.



**WARNING:** Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.



**ATTENTION:** Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss. Attentions help you identify a hazard, avoid a hazard, and recognize the consequence.



**SHOCK HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that dangerous voltage may be present.



**BURN HAZARD:** Labels may be on or inside the equipment, for example, a drive or motor, to alert people that surfaces may reach dangerous temperatures.

**IMPORTANT** 

Identifies information that is critical for successful application and understanding of the product.

Allen-Bradley, Rockwell Automation, Rockwell Software, CompactLogix, ControlFLASH, Logix5000, RSLinx, RSLogix, PanelView, PhaseManager, ControlLogix, PanelView, Ultra, PowerFlex, FlexLogix, PLC-5, DriveLogix, SLC, MicroLogix, and TechConnect are trademarks of Rockwell Automation, Inc.

Trademarks not belonging to Rockwell Automation are property of their respective companies.

This manual contains new and updated information. Changes throughout this revision are marked by change bars, as shown to the right of this paragraph.

# New and Updated Information

This table contains the changes made to this revision.

Торіс	Page
Updated the Verify Compatibility section	18

Notes:

Preface	Additional Resources	9
	Chapter 1	
1769 CompactLogix Controllers	About the 1769 CompactLogix Controller	11
Overview	Design a CompactLogix System	
	Chapter 2	
Install the 1769-L3x Controllers	Verify Compatibility	
	Before You Begin Parts List	19
	Set the Node Address	
	(ControlNet only)	
	Connect the 1769-BA Battery	
	Install a CompactFlash Card (optional)	
	Assemble the System	
	Mount the System	
	Minimum Spacing	
	Dimensions	
	Ground the Wiring	
	Mount the Controller on the DIN Rail	
	Make RS-232 Connections to the Controller	
	RS-232 Cable	
	Optical Isolator (1769-L31 only)	
	Default Serial Configuration	
	Using the Channel 0 Default Communication Push Button	
	Make Ethernet Connections to the Controller	
	Assign an IP Address	29
	Make ControlNet Connections to the Controller	32
	Connect the Controller to the Network via a ControlNet Tap Connect a Programming Terminal to the Network via a 1786-CP	
	Cable	
	Install the Appropriate EDS Files	
	Load the Controller Firmware	36
	Use the ControlFLASH Utility to Load Firmware	37
	Use AutoFlash to Load Firmware	
	Use a CompactFlash Card to Load Firmware	
	Select the Controller's Operating Mode	39
	Chapter 3	
Connect to the Controller via the	Connect to the Controller via the Serial Port	41
Serial Port	Configure the Serial Driver	43
	Select the Controller Path	

	Controller Options	. 46
	Chapter 4	
Communicate over Networks	EtherNet/IP Network Communication	. 48
	Connections over an EtherNet/IP Network	
	ControlNet Network Communication	. 50
	Connections over ControlNet Network	
	DeviceNet Communication	. 53
	Serial Communication	. 55
	Configure an Isolator	. 57
	Communicate with DF1 Devices	
	DF1 Radio Modem Support	. 61
	Modbus Support	
	Broadcast Messages over a Serial Port	
	DH-485 Network Communication	
	Chapter 5	
Manage Controller Communication	Produce and Consume Data.	. 75
	Send and Receive Messages	
	Determine Whether to Cache Message Connections	. 77
	Connections	. 77
	Calculate Total Connections	. 78
	Connections Example	. 79
	Chapter 6	
Place, Configure, and Monitor I/O	Select I/O Modules	. 81
, , ,	Validate I/O Layout	
	Estimate Requested Packet Interval	
	Calculate System Power Consumption	
	Validate Placement of I/O Modules	
	Place Local I/O Modules.	
	Configure I/O	. 87
	I/O Connections	. 88
	Configure Distributed I/O on an EtherNet/IP Network	. 88
	Configure Distributed I/O on a ControlNet Network	. 89
	Configure Distributed I/O on a DeviceNet Network	
	Address I/O Data	
	Determine When Data Is Updated	. 92
	Monitor I/O Modules	
	Display Fault Data	. 93
	End-cap Detection and Module Faults	
	Reconfigure an I/O Module	
	Reconfigure a Module via RSLogix 5000 Programming Software	
	Reconfigure a Module via a MSG Instruction	. 95

	Chapter /	
Develop Applications	Manage Tasks	. 97
	Develop Programs	. 98
	Define Tasks	. 99
	Define Programs	
	Define Routines	101
	Sample Controller Projects	
	Organize Tags	
	Select a Programming Language	
	Add-on Instructions	
	Monitor Connections	
	Determine if Device Communication Has Timed Out	
	Determine if I/O Module Communication Has Timed Out	
	Interrupt the Execution of Logic and Execute the Fault Handler	
	Select a System Overhead Time Slice Percentage	109
	Chapter 8	
Configure PhaseManager Application	PhaseManager Overview	113
J	State Model Overview	
	How Equipment Changes States	116
	Manually Change States	117
	Compare PhaseManager to Other State Models	
	Minimum System Requirements	118
	Equipment Phase Instructions	118
	Chapter 9	
Use a CompactFlash Card	Locate the Controller Serial Number in RSLinx Software	110
ose a compactitusii cara	Locate the Controller Serial Number	
	Use a CompactFlash Card to Load/Store a User Application	
	Manually Change Which Project Loads	
	Manually Change the Load Parameters	
	Use a CompactFlash Card for Data Storage	
	Read and Write User Data to the CompactFlash Card	
	Chantar 10	
Maintain the Datton.	Chapter 10	105
Maintain the Battery	Battery Handling	
	Check If the Battery Is Low	
	Estimate 1769-BA Battery Life	
	Store Lithium Batteries	
	Battery Removal	
	Additional Resources	130
	Appendix A	
Status Indicators	1769-L3xx Controllers Status Indicators	131
	CompactFlash Indicator	

	RS-232 Serial Port Status Indicators	133
	ControlNet Indicators	133
	Module Status (MS) Indicator	134
	Network Channel Indicators	135
	EtherNet/IP Indicators	135
	Module Status (MS) Indicator	135
	Network Status (NS) Indicator	
	Link Status (LNK) Indicator	136
	Appendix B	
Dynamic Memory Allocation in	Messages	138
CompactLogix Controllers	RSLinx Tag Optimization	138
tomputting in tollinois	Trends	
	DDE/OPC Topics	139
	Specify Connections per PLC Controller	139
	Number of Connections Needed to Optimize Throughput	141
	View the Number of Open Connections	141
	<del>-</del>	

Index

Use this manual to become familiar with the CompactLogix  $^{\text{\tiny TM}}$  controller and its features.

This manual describes the necessary tasks to install, configure, program, and operate a CompactLogix system. In some cases, this manual includes references to additional documentation that provides the more comprehensive details.

### **Additional Resources**

These documents contain additional information concerning related products from Rockwell Automation.

Resource	Description
1769 CompactLogix Controllers Specifications Technical Data, publication <u>1769-TD005</u>	Contains technical specifications and certifications for all CompactLogix controllers.
1769-L3x CompactLogix System Quick Start, publication IASIMP-QS001	Provides examples of using a 1769-L3x CompactLogix controller to connect to multiple devices over various networks.
Logix5000 Controller Design Considerations Reference Manual, publication <u>1756-RM094</u>	Provides guidelines you can follow to optimize your system. This manual also provides system information you need to make system design choices.
Logix5000 Controllers Common Procedures Manual, publication <u>1756-PM001</u>	Guides the development of projects for Logix5000™ controllers. It provides links to individual guides.
Logix5000 Controllers General Instruction Set Reference Manual, publication 1756-RM003	Provides a programmer with details about each available instruction for a Logix5000 controller. You should already be familiar with how the Logix5000 controller stores and processes data.
Logix5000 Controllers Process Control/Drives Instruction Set Reference Manual, publication 1756-RM006	Provides a programmer with details about each function block instruction available for a Logix5000 controller. You should already be familiar with how the Logix5000 controller stores and processes data.
EtherNet/IP Modules in Logix5000 Control Systems User Manual, publication <a href="mailto:ENET-UM001">ENET-UM001</a>	Describes how to install and configure EtherNet/IP modules in Logix5000 control systems.
ControlNet Communication Modules in Logix5000 Control Systems User Manual, publication CNET-UM001	Describes how to install and configure ControlNet modules in a Logix5000 control system.
Industrial Automation Wiring and Grounding Guidelines, publication 1770-4.1	Provides general guidelines for installing a Rockwell Automation® industrial system.
Product Certifications website, <a href="http://www.ab.com">http://www.ab.com</a>	Provides declarations of conformity, certificates, and other certification details.

You can view or download publications at <a href="http://www.rockwellautomation.com/literature/">http://www.rockwellautomation.com/literature/</a>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

г	ıc	ıa	Ľ

Notes:


## 1769 CompactLogix Controllers Overview

This chapter introduces the 1769 CompactLogix controllers. These controllers offer state-of-the-art control, communication, and I/O elements in a distributed control package.

# About the 1769 CompactLogix Controller

The 1769 CompactLogix controller offers state-of-the-art control, communication, and I/O elements in a distributed control package.


Figure 1 - CompactLogix Controller and 1769 I/O Modules



For a more flexible system, use:

- multiple controllers in a single chassis.
- multiple controllers joined across networks.
- I/O in multiple platforms that is distributed in many locations and connected over multiple I/O links.

Figure 2 - CompactLogix System Overview



The CompactLogix controller, part of the Logix family of controllers, provides a small, powerful, cost-effective system consisting of the following:

- RSLogix<sup>™</sup> 5000 programming software
- Built-in communication ports for EtherNet/IP (1769-L32E and 1769-L35E only) and ControlNet (1769-L32C and 1769-L35CR only) networks
- A 1769-SDN communication interface module providing I/O control and remote device configuration over DeviceNet
- A built-in serial port on every CompactLogix controller
- Compact I/O modules providing a compact, DIN-rail or panel-mounted I/O system

**Table 1 - CompactLogix Controller Combinations** 

Controller	Available Memory	Communication Options	Number of Tasks Supported	Number of Local I/O Modules Supported
1769-L35CR	1.5 MB	1 port ControlNet - supports redundant media 1 port RS-232 serial (system or user protocols)	8	30
1769-L35E		1 port EtherNet/IP 1 port RS-232 serial (system or user protocols)		
1769-L32C	750 KB	1 port ControlNet 1 port RS-232 serial (system or user protocols)	6	16
1769-L32E		1 port EtherNet/IP 1 port RS-232 serial (system or user protocols)		
1769-L31	512 KB	1 port RS-232 serial (system or user protocols) 1 port RS-232 serial (system protocol only)	4	

## Design a CompactLogix System

When designing a CompactLogix system, determine the network configuration and the placement of components in each location. To design your CompactLogix system, you must select the following:

- I/O devices
- A communication network
- Controllers
- Power supplies
- Software

Notes:

## Install the 1769-L3x Controllers

Торіс	Page
Verify Compatibility	18
Before You Begin	19
Set the Node Address (ControlNet only)	19
Connect the 1769-BA Battery	20
Install a CompactFlash Card (optional)	21
Assemble the System	22
Mount the System	23
Make RS-232 Connections to the Controller	26
Make Ethernet Connections to the Controller	28
Make ControlNet Connections to the Controller	32
Install the Appropriate EDS Files	36
Load the Controller Firmware	36
Select the Controller's Operating Mode	39

Use this chapter to install the CompactLogix™ controller, which must be the leftmost module in the first bank of the system.



**WARNING:** This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC publication 60664-1), at altitudes up to 2000 meters (6562 ft) without derating.

This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR Publication 11. Without appropriate precautions, there may be potential difficulties ensuring electromagnetic compatibility in other environments due to conducted as well as radiated disturbance.

This equipment is supplied as open-type equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present and appropriately designed to prevent personal injury resulting from accessibility to live parts. The enclosure must have suitable flame-retardant properties to prevent or minimize the spread of flame, complying with a flame spread rating of 5VA, V2, V1, V0 (or equivalent) if non-metallic. The interior of the enclosure must be accessible only by the use of a tool. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

In addition to this publication, see the following:

- Industrial Automation Wiring and Grounding Guidelines, Allen-Bradley® publication <u>1770-4.1</u>, for additional installation requirements
- NEMA 250 and IEC 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosure



**WARNING:** This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
- · Wear an approved grounding wriststrap.
- Do not touch connectors or pins on component boards.
- Do not touch circuit components inside the equipment.
- Use a static-safe workstation, if available.
- Store the equipment in appropriate static-safe packaging when not in use.

**Table 2 - North American Hazardous Location Approval** 

## The following information applies when operating this equipment in hazardous locations.

Products marked "CL I, DIV 2, GP A, B, C, D" are suitable for use in Class I Division 2 Groups A, B, C, D, Hazardous Locations and nonhazardous locations only. Each product is supplied with markings on the rating nameplate indicating the hazardous location temperature code. When combining products within a system, the most adverse temperature code (lowest "T" number) may be used to help determine the overall temperature code of the system. Combinations of equipment in your system are subject to investigation by the local Authority Having Jurisdiction at the time of installation.

## Informations sur l'utilisation de cet équipement en environnements dangereux.

Les produits marqués "CL I, DIV 2, GP A, B, C, D" ne conviennent qu'à une utilisation en environnements de Classe I Division 2 Groupes A, B, C, D dangereux et non dangereux. Chaque produit est livré avec des marquages sur sa plaque d'identification qui indiquent le code de température pour les environnements dangereux. Lorsque plusieurs produits sont combinés dans un système, le code de température le plus défavorable (code de température le plus faible) peut être utilisé pour déterminer le code de température global du système. Les combinaisons d'équipements dans le système sont sujettes à inspection par les autorités locales qualifiées au moment de l'installation.



#### **WARNING: Explosion Hazard -**

- Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous.
- Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product.
- Substitution of components may impair suitability for Class I, Division 2.
- If this product contains batteries, they must only be changed in an area known to be nonhazardous.



#### AVERTISSEMENT: Risque d'Explosion –

- Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement.
- Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs externes reliés à cet équipement à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens fournis avec ce produit.
- La substitution de composants peut rendre cet équipement inadapté à une utilisation en environnement de Classe I, Division 2.
- S'assurer que l'environnement est classé non dangereux avant de changer les piles.

#### Table 3 - European Hazardous Location Approval

## European Zone 2 Certification (The following applies when the product bears the Ex or EEx Marking)

This equipment is intended for use in potentially explosive atmospheres as defined by European Union Directive 94/9/EC and has been found to comply with the Essential Health and Safety Requirements relating to the design and construction of Category 3 equipment intended for use in potentially explosive atmospheres, given in Annex II to this Directive. Compliance with the Essential Health and Safety Requirements has been assured by compliance with EN 60079-15 and EN 60079-0.



#### **WARNING:**

- This equipment must be installed in an enclosure providing at least IP54 protection when applied in Zone 2 environments.
- This equipment shall be used within its specified ratings defined by Allen-Bradley.
- Provisions shall be made to prevent the rated voltage from being exceeded by transient disturbances of more than 40% when applied in Zone 2 environments.
- Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product.
- Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous.



**ATTENTION:** This equipment is not resistant to sunlight or other sources of UV radiation.

## **Verify Compatibility**

#### **IMPORTANT**

The series B controllers are compatible only with the controller firmware and the RSLogix 5000 software versions as indicated in the table below.

Attempting to use controllers with incompatible software and firmware revisions can result in the following:

- An inability to connect to the series B controller in RSLogix 5000 software
- Unsuccessful firmware upgrades in ControlFLASH™ or AutoFlash utilities

This table shows the compatible pairs of RSLogix 5000 software versions and controller firmware revisions.

Controller	RSLogix 5000 Software Version or Later	Controller Firmware Revision or Later
1769-L31, 1769-L32C, 1769-L32E, 1769-L35CR,	16.00.00	16.023
1769-L35E	17.01.02	17.012
	19.01.00	19.015
	20.01.00	20.013

## **Before You Begin**

Consider the following when planning your CompactLogix system:

- The CompactLogix controller is always the leftmost module in the system.
- The controller must be within four modules of the system power supply. Some I/O modules may be up to eight modules away from the power supply. See the documentation for your 1769 I/O modules for details.
- The 1769-L32E controller supports as many as 16 I/O modules and the 1769-L35E controller supports as many as 30 I/O modules. Both controllers can use a maximum of 3 I/O banks with 2 expansion cables.
- Each I/O bank requires its own power supply.
- Only one controller can be used in a CompactLogix system.
- A 1769-ECR right end cap or 1769-ECL left end cap is required to terminate the end of the communication bus.

#### **Parts List**

These components are shipped with the controller.

Component	Description
	1769-BA battery
<[	1747-KY controller key

You may also use these components with the controller.

If you want to	Then use this component
Connect a device to the RS-232 port	1756-CP3 or 1747-CP3 serial cable
Add nonvolatile memory	1784-CF128 Industrial CompactFlash card
Connect a device to the EtherNet/IP port	Standard Ethernet cable with RJ-45 connector
Connect a device to the ControlNet port	<ul> <li>ControlNet taps for connections from controller channels A or B to the ControlNet network</li> <li>1786-CP cable for connections from a programming terminal to the ControlNet network via the controller's network access port (NAP)</li> </ul>

# Set the Node Address (ControlNet only)

Every ControlNet network requires at least one module that can store parameters and configure the network with those parameters upon startup. The CompactLogix controller is called a keeper because it keeps the network configuration.

The CompactLogix controller can keep the network parameters at any legal node address (01...99). Multiple devices on any one network can act as the network keepers. Each device capable of being the network keeper acts to back up the current keeper. This back-up function is automatic and requires no action on your part.


Node address switches are set to the 99 position at shipment, as shown in the figure.



43868


Use these steps to set the node address.

1. Slide the side cover forward.



43860

2. Use a small screwdriver to set the node address via the controller switches.



31504-M

**3.** Write the node address on the front panel overlay after setting the node address switches.

## **Connect the 1769-BA Battery**

The controller is shipped with the 1769-BA battery that is packed separately. To connect the battery, follow this procedure.



**ATTENTION:** The 1769-BA battery is the only battery you can use with the 1769-L32E and 1769-L35E controllers. The 1747-BA battery is not compatible with the 1769-L32E and 1769-L35E controllers and may cause problems.



**WARNING:** When you connect or disconnect the battery, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

For safety information on the handling of lithium batteries, including handling and disposal of leaking batteries, see Guidelines for Handling Lithium Batteries Technical Data, publication AG-5.4NOVO4.


1. Remove the battery door by sliding it forward.



#### **IMPORTANT**

Do not remove the plastic insulation covering the battery. The insulation is necessary to protect the battery contacts.

- Insert the battery connector into the connector port.
   The connector is keyed to be installed with the correct polarity.
- **2.** Insert the battery into the battery port in the battery door.



- **3.** Slide the battery door back until it clicks into position.
  - TIP At the end of its life, the used battery should be collected separately from any unsorted municipal waste and recycled.



# Install a CompactFlash Card (optional)



**ATTENTION:** Do not remove the CompactFlash card while the controller is reading from or writing to the card, as indicated by a flashing green CF status indicator. This could corrupt the data on the card or in the controller, as well as corrupt the latest firmware in the controller.

The optional industrial CompactFlash card provides nonvolatile memory for a CompactLogix controller. The card is not required for controller operation.




**WARNING:** When you insert or remove the CompactFlash card while power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding.

To install a CompactFlash card, push the locking tab to the right and insert the industrial CompactFlash card into the socket on the front of the controller.

The label of the CompactFlash card faces toward the left. Match the orientation arrow on the card with the arrow on the front of the controller.





4473

## **Assemble the System**

The controller can be attached to an adjacent I/O module or power supply before or after mounting.




**WARNING:** The CompactLogix controller is not designed for removal and insertion under power.

If you insert or remove the module while backplane power is on, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding.

Refer to the illustration when installing a controller.



- 1. Disconnect line power.
- 2. Check that the lever of the adjacent module (A) is in the unlocked (fully right) position.

- **3.** Use the upper and lower tongue-and-groove slots (B) to secure the modules together.
- **4.** Move the module back along the tongue-and-groove slots until the bus connectors line up with each other.
- 5. Use your fingers or a small screwdriver to push the module's bus lever back slightly to clear the positioning tab (C).
- **6.** Move the module's bus lever fully to the left (D) until it clicks, being sure it is locked firmly in place.



**ATTENTION:** When attaching the controller, power supply, and I/O modules, make sure the bus connectors are securely locked together to be sure of proper electrical connection.

This equipment is not resistant to sunlight or other sources of UV radiation.

- 7. Attach an end-cap terminator (E) to the last module in the system by using the tongue-and-groove slots as before.
- **8.** Lock the end-cap bus terminator (F).


## **Mount the System**




**ATTENTION:** During panel or DIN-rail mounting of all devices, be sure that all debris (such as metal chips or wire strands) is kept from falling into the controller. Debris that falls into the controller could cause damage while the controller is energized.

## **Minimum Spacing**

Maintain spacing from enclosure walls, wireways, and adjacent equipment. Allow 50 mm (2 in.) of space on all sides, as shown. This provides ventilation and electrical isolation.



#### **Dimensions**



All dimensions are in mm (in.).

**IMPORTANT** 

Compact I/O expansion cables have the same dimensions as the end caps. Expansion cables can be used on either the right or left end. A 1769-ECR right-end cap or 1769-ECL left-end cap terminates the end of the communication bus.

### **Ground the Wiring**



**ATTENTION:** This product is grounded through the DIN rail to chassis ground. Use zinc-plated yellow-chromate steel DIN rail to assure proper grounding. The use of other DIN rail materials (such as aluminum or plastic) that can corrode, oxidize, or are poor conductors, can result in improper or intermittent grounding. Secure DIN rail to mounting surface approximately every 200 mm (7.8 in.) and use end-anchors appropriately.

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel. Additional grounding connections from the controller's mounting tabs or DIN rail (if used) are not required unless the mounting surface cannot be grounded.

Refer to Allen-Bradley Industrial Automation Wiring and Grounding Guidelines, publication <u>1770-4.1</u>, for additional information.

#### **Mount the Panel**

Mount the controller to a panel by using two screws per module. Use M4 or #8 panhead screws. Mounting screws are required on every module. This procedure lets you use the assembled modules as a template for drilling holes in the panel.

## **IMPORTANT** Due to module-mounting hole tolerance, it is important to follow these procedures.

- 1. On a clean work surface, assemble no more than three modules.
- 2. Using the assembled modules as a template, carefully mark the center of all module-mounting holes on the panel.
- **3.** Return the assembled modules to the clean work surface, including any previously mounted modules.
- **4.** Drill and tap the mounting holes for the recommended M4 or #8 screw.
- 5. Place the modules back on the panel and check for proper hole alignment.
  - TIP The grounding plate, that is, where you install the mounting screws, enables the module to be grounded when it is panel-mounted.
- **6.** Attach the modules to the panel by using the mounting screws.
  - TIP If you are mounting more modules, mount only the last one of this group and put the others aside. This reduces remounting time when you are drilling and tapping the next group of modules.
- 7. Repeat steps 1...6 for any remaining modules.

#### Mount the Controller on the DIN Rail

The controller can be mounted on the following DIN rails:

- EN 50 022 35 x 7.5 mm (1.38 x 0.30 in.)
- EN 50 022 35 x 15 mm (1.38 x 0.59 in.)



**ATTENTION:** This product is grounded through the DIN rail to chassis ground. Use zinc-plated yellow-chromate steel DIN rail to assure proper grounding. The use of other DIN rail materials (for example, aluminum or plastic) that can corrode, oxidize, or are poor conductors, can result in improper or intermittent grounding. Secure DIN rail to mounting surface approximately every 200 mm (7.8 in.) and use end-anchors appropriately.

- 1. Before mounting the controller on a DIN rail, close the DIN rail latches.
- Press the DIN-rail mounting area of the controller against the DIN rail.The latches will momentarily open and lock into place.

# Make RS-232 Connections to the Controller

Connect the 9-pin female end of the serial cable to the serial port of the controller.






**WARNING:** If you connect or disconnect the serial cable with power applied to this module or the serial device on the other end of the cable, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding.


#### RS-232 Cable



**TIP** This cable must be shielded and tied to the connector housing.

### **Optical Isolator (1769-L31 only)**

Channel 0 is fully isolated and does not need a separate isolation device. Channel 1 is nonisolated. If you connect channel 1 to a device outside of the system's enclosure, consider installing an isolator (such as the 1761-NET-AIC interface converter) between the controller and device.



Select the appropriate cable.

Isolator Use	Cable				
No	If you make y the ends of the	The 1756-CP3 cable attaches the controller directly to the controller.  If you make your own cable, it must be shielded and the shields must be tied to the metal shell surrounding the pins on the ends of the cable.  You can also use a 1747-CP3 cable. This cable has a taller right-angle connector housing than the 1756-CP3 cable.			
Yes	controller) at		port 2 on the 1761-NET-AIC isc	ne 1761-CBL-PM02 cable (straig olator. The mini-DIN connector i	
	Pin	DB-9 End	Mini-DIN End	3	3
	1	DCD	DCD		12
	2	RxD	RxD	DB-9 Right-angle or	8-pin, Mini-DIN
	3	TxD	TxD	Straight Cable End	Cable End
	4	DTR	DTR		
	5	Ground	Ground		
	6	DSR	DSR		
	7	RTS	RTS		
	8	CTS	CTS		
	Q	N/A	N/A		

## **Default Serial Configuration**

Channel 0 and Channel 1 (both serial ports) have the following default communication configuration.

Parameter	Default	
Protocol	DF1 Full-duplex	
Communication Rate	19.2 Kbps	
Parity	None	
Station Address	0	
Control Lines	No Handshaking	

Parameter	Default
Error Detection	BCC
Embedded Responses	Auto Detect
Duplicate Packet (Message) Detect	Enabled
ACK Timeout	50 (x 20 ms)
NAK Receive Limit	3 Retries
ENQ Transmit Limit	3 Retries
Data Bits	8
Stop Bits	1

**TIP** Only Channel 0 has a default communication push button.

### Using the Channel O Default Communication Push Button

The Channel 0 default communication push button is located on the front of the controller in the lower right corner as shown in the illustration. Use the Channel 0 default communication push button to change from the user-defined communication configuration to the default Communication mode. The Channel 0 default communication (DCH0) status indicator turns on (green, steady) to indicate that the default communication configuration is active.



#### **IMPORTANT**

The default communication push button is recessed.

Before pressing the default communication push button, be sure to note the present communication configuration for Channel O. Pushing the default communication push button resets all configured parameters back to their default settings.

To return the channel to its user-configured parameters, you must enter them manually while online with the controller or download them as part of an RSLogix 5000 software project file. To do this online with RSLogix 5000 software, access the Controller Properties dialog box and enter parameters on the Serial Port, System Protocol, and User Protocol tabs.

## Make Ethernet Connections to the Controller

The 1769-L32E and 1769-L35E controller are shipped with the BOOTP utility enabled. You must assign an IP address to the Ethernet port for the controller to communicate over an EtherNet/IP network.




**WARNING:** If you connect or disconnect the communication cable with power applied to this module or any device on the network, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding

Connect the RJ-45 connector of the Ethernet cable to the Ethernet port (top port) on the controller.



**ATTENTION:** Do not plug a DH-485 network cable or a NAP cable into the Ethernet port. Undesirable behavior or damage to the port may result.



### **Assign an IP Address**

You can set the IP address by using any of these utilities:

- Rockwell BOOTP Utility (available with RSLinx® and RSLogix 5000 software)
- RSLinx software
- RSLogix 5000 software

#### Use BOOTP to Set the IP Address

The BOOTP utility is a standalone program in one of the following directories:

 RSLinx Tools directory in the Rockwell Software® program folder on the Start menu


The utility is automatically installed when you install RSLinx software.

• Utils directory on the RSLogix 5000 software installation CD

Follow this procedure to use the BOOTP utility.


- 1. Start the BOOTP software.
- 2. Select Tools>Network Settings.
- 3. Enter the Ethernet mask and gateway.

4. Click OK.



In the BOOTP Request History dialog box, you see the hardware addresses of devices issuing BOOTP requests.

**5.** Double-click the hardware address of the device you want to configure.




TIP The hardware address is on the sticker on the left-side circuit board of the controller next to the battery.

The hardware address will be in this format: 00-0b-db-14-55-35.

The New Entry dialog box displays the device's Ethernet Address (MAC).

- **6.** Enter the IP address.
- 7. Click OK.




**8.** To permanently assign this configuration to the device, highlight the device and click Disable BOOTP/DHCP.


When you cycle power, the device uses the configuration you assigned and does not issue a BOOTP request.

#### Use RSLinx Software to Set the IP Address

- 1. You can use RSLinx software, version 2.41 or later, to set the IP address.
- 2. Make sure the controller that uses the IP address is installed and running.
- **3.** Connect to the controller via the serial connection (see page 26).
- Start RSLinx software.
   The RSWho dialog box opens.
- 5. Navigate to the Ethernet network via the serial network.



- **6.** Right-click the Ethernet port (not the controller) and select Module Configuration.
- 7. Select the Port Configuration tab.
- **8.** Click the appropriate radio button to choose the Network Configuration type.




**9.** Enter the IP address, network (subnet) mask, and gateway address (if needed).

#### Use RSLogix 5000 Software to Set the IP Address

You can use RSLogix software to set the IP address.

- 1. Make sure the controller that uses the IP address is installed and running.
- 2. Connect to the controller via the serial connection (see page 26).
- 3. Start RSLogix 5000 software.
- 4. In the Controller Organizer, select properties for the Ethernet port.



- 5. Choose the Port Configuration tab.
- **6.** Specify the IP address.
- 7. Click Apply.
- 8. Click OK.


This sets the IP address in the hardware. This IP address should be the same IP address you assigned under the General tab.

# Make ControlNet Connections to the Controller

The CompactLogix 1769-L32C and 1769-L35CR controllers connect to the ControlNet network. The CompactLogix 1769-L32C controller supports channel A connections only. The CompactLogix 1769-L35CR controller supports channels A and B (redundant media) connections.

For permanent connections to the network, you connect the module to the ControlNet network by using a ControlNet tap (for example, 1786-TPR, 1786-TPYR, 1786-TPYS).

The figure shows an example ControlNet network using redundant media.



Item	Description
1	ControlNet node
2	Redundant media available on 1769-L35CR only
3	ControlNet link

When connecting the CompactLogix controller to a ControlNet network, also refer to the following documentation:

- ControlNet Coax Tap Installation Instructions, publication <u>1786-IN007</u>
- ControlNet Coax Media Planning and Installation Guide, publication <u>CNET-IN002</u>
- ControlNet Fiber Media Planning and Installation Guide, publication <u>CNET-IN001</u>

IMPORTANT	For network connections we recommend taps with a straight connector
	(catalog number 1786-TPS or 1786-TPYS) because of the location of the BNC
	connectors on the bottom of the module.

## Connect the Controller to the Network via a ControlNet Tap


Typically, ControlNet taps are used to make permanent connections from the CompactLogix controller to the network. Perform the following steps to connect the module to the network by using a ControlNet tap.



**ATTENTION:** Do not allow any metal portions of the tap to contact any conductive material.


If you disconnect the tap from the module, place the dust cap back on the straight or right angle connector to prevent the connector from accidentally contacting a metallic grounded surface.

1. Remove and save the dust caps from the ControlNet taps.



ltem	Description
1	Segment 1
2	Segment 2
3	Dust caps

2. Connect the tap's straight or right-angle connector to the module's BNC connector as shown in the figure.



Item	Description
1	Segment 1
2	Segment 2
3	Tap connected to a CompactLogix controller not using redundant media
4	Tap connected to a CompactLogix controller using redundant media (1769-L35CR unit only)
5	Тар

#### **IMPORTANT**

To prevent inadvertent reversal of the tap connections (resulting in incorrect status displays requiring troubleshooting), check the tap drop cable for the label indicating the attached segment before making your connection.




**WARNING:** If you connect or disconnect the communication cable with power applied to this module or any device on the network, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding

### Connect a Programming Terminal to the Network via a 1786-CP Cable

You can use the CompactLogix controller's network access port (NAP) to connect a programming terminal to the ControlNet network. The figure shows the 1786-CP cable connections.





**WARNING:** The NAP port is intended for temporary local-programming purposes only and not intended for permanent connection. If you connect or disconnect the NAP cable with power applied to this module or any device on the network, an electrical arc can occur. This could cause an explosion in hazardous location installations.


Be sure that power is removed or the area is nonhazardous before proceeding.



**ATTENTION:** Use the 1786-CP cable when you connect a programming terminal to the network through the NAP.

Using another cable could result in possible network failures or product damage.

Connect one end of the 1786-CP cable to the CompactLogix controller and the other end to the NAP of the programming terminal.





**ATTENTION:** Do not plug a DH-485 network cable or an RJ45 connector for the EtherNet/IP network to the NAP. Undesirable behavior and/or damage to the port may result.

## **Install the Appropriate EDS Files**

If you have RSLinx software, version 2.42 or later, the most current EDS files were installed with the software. If you are using an earlier version of RSLinx software, you might need to install EDS files.

You need EDS files for these devices:

- 1769-L32E and 1769-L35E controllers
- 1769 CompactBus
- 1769 local adapter

All of these EDS files, except for the 1769 CompactBus file, are updated for each firmware revision. There is also a version 1 of the controller EDS file that you need for new controllers. Each controller is shipped with revision 1 firmware. To update the firmware, you must have the revision 1 EDS file (0001000E00410100.eds) installed for the controller.

The EDS files are available on the RSLogix 5000 Enterprise Series software CD. The files are also available at <a href="http://www.ab.com/networks/eds">http://www.ab.com/networks/eds</a>.

**Load the Controller Firmware** You must download the current firmware before you can use the controller.

To load firmware, you can use any of the following:

- ControlFLASH utility that is shipped with RSLogix 5000 programming software
- AutoFlash that launches through RSLogix 5000 software when you download a project and the controller does not have the matching firmware revision
- CompactFlash card (catalog number 1784-CF128) with valid memory already loaded

If you use the ControlFLASH or AutoFlash utilities, you need a network connection to the controller.

The firmware is available with RSLogix 5000 software or you can download it from the support website. Go to http://www.rockwellautomation.com/support/.

Follow these steps to download firmware from the support website.

- 1. On the Rockwell Automation Support Page, click Software Updates, Firmware and Other Downloads under the Other Tools heading.
- 2. Click Firmware Updates.
- 3. Select the appropriate firmware update.
- **4.** Select the firmware revision.
- **5.** Click a revision file to unzip the data.

#### **Use the ControlFLASH Utility to Load Firmware**

You can use the ControlFLASH utility to load firmware through a serial connection.

- 1. Make sure the appropriate network connection is made before starting.
- 2. Start the ControlFLASH utility.
- 3. When the Welcome dialog box appears, click Next.
- **4.** Choose the catalog number of the controller and click Next.
- **5.** Expand the network until you see the controller.
- **6.** If the required network is not shown, first configure a driver for the network in RSLinx software.
- 7. Choose the controller and click OK.
- **8.** Choose the revision level to which you want to update the controller and click Next.
- **9.** To start the update of the controller, click Finish and then click Yes.
- After the controller is updated, the status dialog box displays Update complete.
- 11. Click OK.
- 12. To close the ControlFLASH utility, click Cancel and then click Yes.

#### **Use AutoFlash to Load Firmware**

You can use AutoFlash to load firmware through a network connection.

#### **IMPORTANT**

When upgrading your controller firmware, it is extremely important to allow the upgrade to complete without interruption.

If you interrupt the firmware upgrade either in the software or by disturbing the physical media, you may render the controller inoperable.

For more information about upgrading your CompactLogix controller firmware, see information posted at

http://www.rockwellautomation.com/knowledgebase/.

- 1. Make sure the appropriate network connection is made and your network driver is configured in RSLinx software.
- 2. Use RSLogix 5000 programming software to create a controller project.
- 3. Click RSWho to specify the controller path.

4. Select your controller and click Download.

You may also choose to click Update Firmware to complete this process. If you do so, skip to step <u>8</u>.

A dialog box displays indicating that the project revision and controller firmware revision are different.

- 5. Click Update Firmware.
- Use the checkbox and pull-down menu to select your controller and firmware revision.
- 7. Click Update.
- **8.** Click Yes.

The firmware upgrade begins.

#### **IMPORTANT**

#### DO NOT INTERRUPT THE FIRMWARE UPGRADE ONCE IT HAS BEGUN.

Interrupting the firmware upgrade may result in an inoperable controller.

When the firmware upgrade is complete, the Download dialog box appears and you may continue by downloading your project to the controller.

## Use a CompactFlash Card to Load Firmware

If you have an existing controller that is already configured and has firmware loaded, you can store the current controller user program and firmware on the CompactFlash card and use that card to update other controllers.

- 1. Use RSLogix 5000 software to store the controller user program and firmware of a currently configured controller to the CompactFlash card.
- 2. Access the Nonvolatile Memory tab of the Controller Properties dialog box.

Be sure to select Load Image On Powerup when you save to the card.

**3.** Remove the card and insert it into a controller that will use the same firmware and controller user program.

When you apply power to the second controller, the image stored on the CompactFlash card is loaded into the controller.

# Select the Controller's Operating Mode

Use the keyswitch on the front panel of the controller to determine the controller's operating mode.

Keyswitch Position	Description		
Run	<ul> <li>Upload projects.</li> <li>Run the program and enable outputs.</li> <li>You cannot create or delete tasks, programs, or routines. You cannot create or delete tags or edit online while the keyswitch is in the Run position.</li> <li>You cannot change the mode by using the programming software while the keyswitch is in the Run position.</li> </ul>		
Prog	<ul> <li>Disable outputs.</li> <li>Upload/download projects.</li> <li>Create, modify, and delete tasks, programs, or routines.</li> <li>The controller does not execute (scan) tasks while the keyswitch is in the Prog position.</li> <li>You cannot change the mode through the programming software while the keyswitch is in the Prog position.</li> </ul>		
Rem	Upload/download projects.     Change between Remote Program, Remote Test, and Remote Run modes through the programming software.  Remote Run     The controller executes (scans) tasks.     Enable outputs.     Edit online.		
	Remote Program	Disable outputs. Create, modify, and delete tasks, programs, or routines. Download projects. Edit online. The controller does not execute (scan) tasks.	
Remote Test  - Execute tasks w - Edit online.			

Notes:

## Connect to the Controller via the Serial Port

This chapter describes how to connect to the controller via the serial port so that you can configure the controller and upload or download a project to the controller.

Торіс	Page
Connect to the Controller via the Serial Port	41
Configure the Serial Driver	43
Select the Controller Path	45


For the CompactLogix controller to operate on a serial network, you need:

- a workstation with a serial port.
- RSLinx software to configure the serial communication driver.
- RSLogix5000 programming software to configure the serial port of the controller.

## Connect to the Controller via the Serial Port

Channel 0 on the CompactLogix controllers is fully isolated and does not need a separate isolation device. Channel 1 on the 1769-L31 is not an isolated serial port.

Figure 3 - Serial Connection to Controller




If you connect channel 1 of the 1769-L31 controller to a modem or an ASCII device, consider installing an isolator between the controller and modem or ASCII device. An isolator is also recommended when connecting the controller directly to a programming workstation. One possible isolator is the 1761-NET-AIC interface converter.


For more information on installing an isolator, see Configure an Isolator on page 57.

To connect a serial cable, perform this procedure.


1. Obtain a 1747-CP3 or 1756-CP3 serial cable.



- **TIP** If you make your own serial cable, complete this procedure.
  - Limit the length to 15.2 m (50 ft).
  - Wire the connectors.




2. Connect the cable to your controller and workstation.




## **Configure the Serial Driver**

Use RSLinx software to configure the RS-232 DF1 Device driver for serial communication. To configure the driver, perform this procedure.

1. From the communication pull-down menu, choose Configure Drivers.



The Configure Drivers dialog box appears.




- **2.** From the Available Driver Types pull-down menu, choose the RS-232 DF1 Device driver.
- 3. Click Add New to add the driver.

The Add New RSLinx Driver dialog box appears.



**4.** Specify the driver name and click OK.



The Configure RS-232 DF1 Devices dialog box appears.

- 5. Specify the serial port settings.
  - a. From the Comm Port pull-down menu, choose the serial port on the workstation to which the cable is connected.
  - b. From the Device pull-down menu, choose Logix 5550-Serial Port.
  - c. Click Auto-Configure.
- 6. Verify that the Auto-Configuration was successful.


If	Then
Yes	Click OK.
No	Go to step $\underline{5}$ and verify that you selected the correct communication port.

7. Click Close.

## **Select the Controller Path**

To select the controller path, perform this procedure.


1. In RSLogix 5000 programming software, open a project for the controller.



2. From the Communications pull-down menu, choose Who Active.



The Who Active dialog box appears.



- **3.** Expand the communication driver to the level of the controller.
- **4.** Select the controller.

## **Controller Options**


Once you have selected a controller, you have several options.

То	Choose
Monitor the project in the controller	Go Online
Transfer a copy of the project from the controller to RSLogix 5000 software	Upload
Transfer the open project to the controller	Download

## **Communicate over Networks**

This chapter explains how CompactLogix controllers support additional networks to enable various functions.

Table 4 - CompactLogix Controller Network Support



Торіс	Page
EtherNet/IP Network Communication	48
ControlNet Network Communication	50
DeviceNet Communication	53
Serial Communication	55
DH-485 Network Communication	72

## EtherNet/IP Network Communication

The EtherNet/IP network offers a full suite of control, configuration and data collection services by layering the Common Industrial Protocol (CIP) over the standard Internet protocols, such as TCP/IP and UDP. This combination of well-accepted standards provides the capability required to both support information data exchange and control applications.

The EtherNet/IP network also uses commercial, off-the-shelf Ethernet components and physical media, providing you with a cost-effective plant-floor solution.

For EtherNet/IP communication, you can use these CompactLogix controllers with a built-in EtherNet/IP communication port:

- 1769-L32E CompactLogix controller
- 1769-L35E CompactLogix controller

You can use several software products with a 1769 CompactLogix controller on an EtherNet/IP network.

Table 5 - EtherNet/IP Network Software Combinations

Software	Functions	Requirement
RSLogix 5000 programming software	Configure the CompactLogix project     Define EtherNet/IP communication	Yes
BOOTP/DHCP utility with RSLogix 5000 programming software	Assign IP addresses to devices on an EtherNet/IP network	No
RSNetWorx software for an EtherNet/IP network	Configure EtherNet/IP devices by IP addresses and/or host names	No

The EtherNet/IP communication modules:

- support messaging, produced/consumed tags, HMI, and distributed I/O.
- encapsulate messages within standard TCP/UDP/IP protocol.
- share a common application layer with ControlNet and DeviceNet.
- interface via RJ45, category 5, unshielded, twisted-pair cable.
- support half/full-duplex 10 Mbps or 100 Mbps operation.
- support standard switches.
- require no network scheduling.
- require no routing tables.

#### In this example:

- the controllers produce and consume tags amongst themselves.
- the controllers initiate MSG instructions that send and receive data or configure devices.
- the personal computer uploads or downloads projects to the controllers.
- the personal computer configures devices on an EtherNet/IP network.




Figure 4 - CompactLogix EtherNet/IP Overview

### **Connections over an EtherNet/IP Network**

You indirectly determine the number of connections the controller uses by configuring the controller to communicate with other devices in the system. Connections are allocations of resources that provide more reliable communication between devices than unconnected messages.

All EtherNet/IP connections are unscheduled. An unscheduled connection is a message transfer between controllers that is triggered by the requested packet interval (RPI) or the program, such as a MSG instruction. Unscheduled messaging lets you send and receive data when needed.

The 1769-L32E and 1769-L35E controllers support 100 connections. However, the built-in EtherNet/IP port supports only 32 CIP connections over an EtherNet/IP network. With these controllers, the number of end-node connections they effectively support depends on a connection's RPI.

Requested Packet Interval	Max EtherNet/IP Port Communication Connections
2 ms	2
4 ms	5
8 ms	10
16 ms	18
32 ms+	25+

You can use all 32 communication connections on the built-in EtherNet/IP port. However, we recommend that you leave some connections available for tasks such as going online and non-I/O purposes.

## ControlNet Network Communication

ControlNet is a real-time control network that provides high-speed transport of both time-critical I/O and interlocking data and messaging data, including uploading and downloading of programming and configuration data on a single physical-media link. The ControlNet network's highly-efficient data transfer capability significantly enhances I/O performance and peer-to-peer communication in any system or application.

The ControlNet network is highly deterministic and repeatable and remains unaffected as devices are connected or disconnected from the network. This robust quality results in dependable, synchronized, and coordinated real-time performance.

The ControlNet network often functions as:

- the default network for the CompactLogix platform.
- a substitute/replacement for the remote I/O (RIO) network because the ControlNet network adeptly handles large numbers of I/O points.
- a backbone to multiple distributed DeviceNet networks.
- a peer interlocking network.

For ControlNet communication, you can use these CompactLogix controllers with a built-in ControlNet communication port:

- 1769-L32C CompactLogix controller
- 1769-L35CR CompactLogix controller

You can use these software products with a 1769 CompactLogix controller on a ControlNet network.

**Table 6 - ControlNet Network Software Combinations** 

Software	Functions	Requirement
RSLogix 5000 programming software	Configure the CompactLogix project     Define EtherNet/IP communication	Yes
RSNetWorx for ControlNet software	Configure the ControlNet network     Define the NUT (network update time)     Schedule the ControlNet network	

#### The ControlNet communication modules:

- support messaging, produced/consumed tags and distributed I/O.
- share a common application layer with DeviceNet and EtherNet/IP networks.
- require no routing tables.
- support the use of coax and fiber repeaters for isolation and increased distance.

### In this example:

- the controllers produce and consume tags amongst themselves.
- the controllers initiate MSG instructions that send and receive data or configure devices.
- the personal computer uploads or downloads projects to the controllers.
- the personal computer configures devices on ControlNet, and configures the network itself.

Communicate over Networks




Figure 5 - CompactLogix ControlNet Overview

## **Connections over ControlNet Network**

You indirectly determine the number of connections the controller uses by configuring the controller to communicate with other devices in the system. Connections are allocations of resources that provide more reliable communication between devices compared to unconnected messages.

**Table 7 - ControlNet Connection Methods** 

Connection Method	Description
Scheduled	A scheduled connection is unique to ControlNet communication. A scheduled connection lets you send and receive data repeatedly at a set interval, which is the requested packet interval (RPI). For example, a connection to an I/O module is a scheduled connection because you repeatedly receive data from the module at a specified interval. Other scheduled connections include connections to:  - communication devices.  - produced/consumed tags.  On a ControlNet network, you must use RSNetWorx for ControlNet to enable all scheduled connections and establish a network update time (NUT). Scheduling a connection reserves network bandwidth to specifically handle the connection.
Unscheduled	An unscheduled connection is a message transfer between nodes that is triggered by ladder logic or the program (such as a MSG instruction). Unscheduled messaging lets you send and receive data when needed. Unscheduled messages use the remainder of network bandwidth after scheduled connections are allocated.

The 1769-L32C and 1769-L35CR controllers support 100 connections. However, the built-in ControlNet port only supports 32 communication connections. With these controllers, the number of end-node connections they effectively support depends on the connection's NUT and RPI.

NUT	RPI	Supported ControlNet Communication Connections <sup>(1)</sup>	
2 ms	2 ms	01	
3 ms	3 ms	12	
5 ms	5 ms	34	
10 ms	10 ms	69	
14 ms	14 ms	1012	
5 ms	20 ms	1216	
4 ms	64 ms	31	

<sup>(1)</sup> For each NUT/RPI combination, the number of connections supported is listed in a range. The lower number is the number of connections we recommend you make to maintain reasonable ControlNet port CPU utilization rates. The higher number is the maximum number of connections possible for that NUT/RPI combination.

You can use all 32 communication connections on the built-in ControlNet port. However, we recommend that you leave some connections available for tasks such as going online and unscheduled network traffic.

## **DeviceNet Communication**

The DeviceNet network uses the Common Industrial Protocol (CIP) to provide the control, configuration, and data collection capabilities for industrial devices. The DeviceNet network uses the proven Controller Area Network (CAN) technology, which lowers installation costs and decreases installation time and costly downtime.

A DeviceNet network provides access to the intelligence present in your devices by letting you connect devices directly to plant-floor controllers without having to hard wire each device into an I/O module.

Table 8 - CompactLogix DeviceNet Communication Interfaces

If your application	Select
<ul> <li>Communicates with other DeviceNet devices</li> <li>Uses the controller as a master or slave on DeviceNet</li> <li>Uses a controller ControlNet, Ethernet or serial port for other communication</li> </ul>	1769-SDN DeviceNet scanner module
<ul> <li>Accesses remote Compact I/O over a DeviceNet network</li> <li>Sends remote I/O data for as many as 30 modules back to scanner or controller</li> </ul>	1769-ADN DeviceNet adapter module <sup>(1)</sup>

<sup>(1)</sup> This table specifically describes using the 1769-ADN module to access remote Compact I/O over DeviceNet. However, CompactLogix controllers can access other Allen-Bradley remote I/O over DeviceNet. In those cases, you must select the appropriate interface. For example, if accessing remote POINT I/O modules, you must select the 1734-ADN.

Figure 6 - CompactLogix DeviceNet Overview CompactLogix PLC-5 Controller with 1771-SDN ControlLogix® Controller with Controller with 1769-SDN Scanner Module 1756-DNB Module DeviceNet Network 0000 Sensor Pushbutton Motor CompactLogix System with Cluster **PanelView** Starter 1769-ADN Laptop Terminal Ultra™ 5000 Servo Drive Bar Code Scanner Input/Output Indicator Devices PowerFlex AC Lights

You can use these software products with a 1769 CompactLogix controller on a DeviceNet network.

Table 9 - CompactLogix DeviceNet Software Combinations

Software	Functions	Requirement
RSLogix 5000 programming software	Configure the CompactLogix project     Define EtherNet/IP communication	Vec
RSNetWorx software for DeviceNet	Configure DeviceNet devices     Define the scan list for DeviceNet devices	Yes


The DeviceNet communication module:

- supports messaging to devices, not controller to controller.
- shares a common application layer with ControlNet and EtherNet/IP.
- offers diagnostics for improved data collection and fault detection.
- requires less wiring than traditional, hardwired systems.

You can use a linking device as a:

- gateway to connect information.
- control-level network to device-level network for programming, configuration, control or data collection.
- router/bridge to connect the EtherNet/IP or ControlNet network to the DeviceNet network.

Figure 7 - CompactLogix Linking Device Overview



## **Serial Communication**

CompactLogix controllers have a built-in RS-232 port.

- 1769-L32C, -L32E, -L35CR, and -L35E CompactLogix controllers have one built-in RS-232 port. By default, that port is channel 0 on these controllers.
- The 1769-L31 CompactLogix controller has two RS-232 ports. One port only allows DF1 protocol only. The second port accepts DF1 and ASCII protocol.

**IMPORTANT** Limit the length of serial (RS-232) cables to 15.2 m (50 ft).

You can configure the serial port of the controller for several modes.

## Table 10 - CompactLogix Serial Port Configuration

Mode	unctions	
DF1 Point-to-Point	Communicate between the controller and one other DF1-protocol-compatible device.  This is the default system mode. Default parameters are:  Baud Rate: 19,200  Data Bits: 8  Parity: None  Stop Bits: 1  Control Line: No Handshake  RTS send Delay: 0  RTS Off Delay: 0  This mode is typically used to program the controller through its serial port.	
DF1 Master	<ul> <li>Control polling and message transmission between the master and slave nodes.</li> <li>The master/slave network includes one controller configured as the master node and as many as 254 slave nodes. Link slave nodes using modems or line drivers.</li> <li>A master/slave network can have node numbers from 0254. Each node must have a unique node address. Also, at least 2 nodes must exist to define your link as a network (1 master and 1 slave station are the two nodes).</li> </ul>	
DF1 Slave	<ul> <li>Use a controller as a slave station in a master/slave serial communication network.</li> <li>When there are multiple slave stations on the network, link slave stations using modems or line drivers to the master. When you have a single slave station on the network, you do not need a modem to connect the slave station to the master. You can configure the control parameters for no handshaking. You can connect 2255 nodes to a single link. In DF1 slave mode, a controller uses DF1 half-duplex protocol.</li> <li>One node is designated as the master and it controls who has access to the link. All the other nodes are slave stations and must wait for permission from the master before transmitting.</li> </ul>	
DF1 Radio Modem	<ul> <li>Compatible with SLC™ 500 and MicroLogix™ 1500 controllers.</li> <li>This mode supports master and slave, and store and forward modes.</li> </ul>	
User (channel 0 only)	Communicate with ASCII devices. This requires your program to use ASCII instructions to transmit data to and from ASCII device.	
DH-485	<ul> <li>Communicate with other DH-485 devices.</li> <li>This multi-master, token-passing network allows programming and peer-to-peer messaging.</li> </ul>	


## **Configure an Isolator**

Channel 0 on the CompactLogix controllers is fully isolated and does not need a separate isolation device. Channel 1 on the 1769-L31 controller is not an isolated serial port. To configure an isolator, perform this procedure.

1. Determine whether you need an isolator.

If you connect channel 1 of the 1769-L31 controller to a modem or an ASCII device, consider installing an isolator between the controller and modem or ASCII device. An isolator is also recommended when connecting the controller directly to a programming workstation.

One possible isolator is the 1761-NET-AIC interface converter.



## 2. Select the appropriate cable.

Are you using an isolator?	Then use this cable			
No	The 1756-CP3 cable a	attaches the controller dire	ctly to the controller.	
	I 2 3 4 CON 6 7 8 9 If you make your own ends of the cable.	CD RDX TXD DTR MMON DSR RTS CTS  a cable, it must be shielded	1 CD 2 RDX 3 TXD 4 DTR COMMON 6 DSR 7 RTS 8 CTS 9 , and the shields must be tie	ed to the metal shell (that surrounds the pins) on both as a taller right-angle connector housing than that of
Yes	the 1756-CP3 cable.			CBL-PM02 cable (straight connector to the controller)
	cannot make this cab	ole.	3-4-12	l connector is not commercially available, so you
	DB-9 Right-an	gle or Straight Cable End	8-pin, Mini-DIN Cable End	
	DB-9 Right-an	DB-9 End	8-pin, Mini-DIN Cable End  Mini-DIN End	
	Pin	DB-9 End	Mini-DIN End	
	<b>Pin</b> 1	DB-9 End	Mini-DIN End DCD	
	Pin 1 2	DB-9 End DCD RxD	Mini-DIN End  DCD  RxD	
	Pin 1 2 3 4 5	DB-9 End DCD RxD TxD	Mini-DIN End DCD RxD TxD	
	Pin 1 2 3 4	DB-9 End  DCD  RxD  TxD  DTR	Mini-DIN End  DCD  RxD  TxD  DTR	
	Pin 1 2 3 4 5 6 7	DB-9 End  DCD  RxD  TxD  DTR  Ground	Mini-DIN End  DCD  RxD  TxD  DTR  Ground	
	Pin 1 2 3 4 5	DB-9 End DCD RxD TxD DTR Ground DSR	Mini-DIN End  DCD  RxD  TxD  DTR  Ground  DSR	

3. Connect the appropriate cable to the serial port.


## **Communicate with DF1 Devices**

You can configure the controller as a master or slave on a serial communication network. Use serial communication when:

- the system contains three or more stations.
- communication occur regularly and require leased-line, radio, or power-line modem.




**ATTENTION:** Only the 1769-L31 controller has more than one RS-232 port. All other 1769 controllers are limited to one RS-232 port.




1. In RSLogix 5000 programming software, right-click your controller and select Properties.





The Controller Properties dialog box appears.

- 2. Click the Serial Port tab.
- **3.** From the Mode pull-down menu, choose System.
- 4. Specify communication settings.
- 5. Click the System Protocol tab.



- 6. From the Protocol pull-down menu, choose a DF1 protocol.
- 7. Specify DF1 settings.


## **DF1 Radio Modem Support**

Your ControlLogix controller includes a driver that lets it to communicate over the DF1 Radio Modem protocol. This driver implements a protocol, optimized for use with radio modem networks, that is a hybrid between DF1 full-duplex protocol and DF1 half-duplex protocol, and therefore is not compatible with either of these protocols.

#### **IMPORTANT**

The DF1 radio modem driver should be used only among devices that support and are configured for the DF1 radio modem protocol.

Additionally, there are some radio modem network configurations that will not work with the DF1 radio modem driver. In these configurations, continue to use DF1 half-duplex protocol.



Like DF1 full-duplex protocol, DF1 radio modem lets any node to connect to any other node at any time (if the radio modem network supports full-duplex data port buffering and radio transmission collision avoidance). Like DF1 half-duplex protocol, a node ignores any packets received that have a destination address other than its own, with the exception of broadcast packets and pass-through packets.


Unlike either DF1 full-duplex or DF1 half-duplex protocols, DF1 radio modem protocol does not include ACKs, NAKs, ENQs, or poll packets. Data integrity is assured by the CRC checksum.

### Using the DF1 Radio Modem Driver


The DF1 radio modem driver can be configured as the system mode driver by using RSLogix 5000 programming software, version 17 or later.

To configure the controller for DF1 Radio Modem communication, perform this procedure.


1. In the Controller Organizer of RSLogix 5000 programming software, right-click your controller and select Properties.



The Controller Properties dialog box appears.



**2.** Click the System Protocol tab.



3. From the Protocol pull-down menu, choose DF1 Radio Modem.

#### 4. Specify DF1 Radio Modem system protocol settings.

Setting	Description	
Station Address	Specifies the node address of the controller on the serial network. Select a number 1 254 decimal, inclusive.  To optimize network performance, assign node addresses in sequential order. Initiators, such as personal computers, should be assigned the lowest address numbers to minimize the time required to initialize the network.	
Error Detection	Click one of the radio buttons to specify the error detection scheme used for all messages.  BCC - the processor sends and accepts messages that end with a BCC byte. CRC - the processor sends and accepts messages with a 2-byte CRC.	
Enable Store and Forward	Check the Enable Store and Forward checkbox if you want to enable the store and forward functionality. When enabled, the destination address of any received message is compared to the Store and Forward tag table. If there is a match, the message is then forwarded (re-broadcasted) from the port.  From the Store and Forward Tag pull-down menu, choose an integer (INT[16]) tag.  Each bit represents a station address. If this controller reads a message destined for a station that has its bit set in this table, it forwards the message.  Also note, the Enable Store and Forward function is usable only if the controller is connected to the master radio modem.	

#### **5.** Click OK.

#### Advantage of Using DF1 Radio Modem Protocol

The primary advantage of using DF1 radio modem protocol for radio modem networks is in transmission efficiency. Each read/write transaction (command and reply) requires only one transmission by the initiator (to send the command) and one transmission by the responder (to return the reply). This minimizes the number of times the radios need to key-up to transmit, which maximizes radio life and minimizes radio power consumption. In contrast, DF1 half-duplex protocol requires five transmissions for the DF1 master to complete a read/write transaction with a DF1 slave - three by the master and two by the slave.

The DF1 radio modem driver can be used in a pseudo master/slave mode with any radio modems, as long as the designated master node is the only node initiating MSG instructions, and as long as only one MSG instruction is triggered at a time.

For modern serial radio modems that support full-duplex data port buffering and radio transmission collision avoidance, the DF1 radio modem driver can be used to set up a masterless peer-to-peer radio network. In a peer-to-peer radio network, any node can initiate communication to any other node at any time, as long as all of the nodes are within radio range so that they receive each other's transmissions.

#### DF1 Radio Modem System Limitations

The following questions need to be answered to determine if you can implement the new DF1 radio modem driver in your radio modem network.

- If all of the devices on the network are ControlLogix controllers, you must configure them with the DF1 radio modem driver by using RSLogix 5000 programming software, version 17 or later. If not, then make sure that all of the nodes can support the DF1 radio modem protocol.
- If each node receives the radio transmissions of every other node, being both within radio transmission/reception range and on a common receiving frequency (either via a Simplex radio mode or via a single, common, full-duplex repeater) the radio modems must handle full-duplex data port buffering and radio transmission collision avoidance.

If this is the case, you can take full advantage of the peer-to-peer message initiation capability in every node (for example, the ladder logic in any node can trigger a MSG instruction to any other node at any time).

If not all modems can handle full-duplex data port buffering and radio transmission collision avoidance, you may still be able to use the DF1 radio modem driver, but only if you limit MSG instruction initiation to a single master node whose transmission can be received by every other node.


- If not all nodes receive the radio transmission of every other node, you may
  still be able to use the DF1 radio modem driver, but only if you limit MSG
  instruction initiation to the node connected to the master radio modem
  whose transmissions can be received by every other radio modem in the
  network.
- You can take advantage of the ControlLogix controller channel-to-channel
  pass-through to remotely program the other nodes using RSLinx and
  RSLogix 5000 programming software running on a personal computer
  connected to a local ControlLogix controller via DH-485, DH+, or
  Ethernet.

#### Communicate with ASCII Devices

You can use the serial port to interface with ASCII devices when the controller is configured for user mode. For example, you can use the serial port to:


- read ASCII characters from a weigh scale module or bar code reader.
- send and receive messages from an ASCII triggered device, such as a MessageView terminal.

**Figure 8 - ASCII Device Serial Communication** 




To configure the controller for ASCII communication, perform this procedure.

1. In RSLogix 5000 programming software, right-click your controller and select Properties.




The Controller Properties dialog box appears.



- 2. Click the Serial Port tab.
- 3. From the Mode pull-down menu, choose User.
- **4.** Specify communication settings.

5. Click the User Protocol tab.



- **6.** From the Protocol pull-down menu, choose ASCII.
- 7. Specify ASCII settings.

The controller supports several instructions to manipulate ASCII characters. The instructions are available in ladder diagram (LD) and structured text (ST).

### Read and Write ASCII Characters

Instruction Code	Description	
ABL	Determine when the buffer contains termination characters	
ACB	Count the characters in the buffer	
ACL	Clear the buffer	
	Clear out ASCII Serial Port instructions that are currently executing or are in the queue	
AHL	Obtain the status of the serial port control lines	
	Turn on or off the DTR signal	
	Turn on or off the RTS signal	
ARD	Read a fixed number of characters	
ARL	Read a varying number of characters, up to and including the first set of termination characters	
AWA	Send characters and automatically append one or two additional characters to mark the end of the data	
AWT	Send characters	

## Create and Modify Strings of ASCII Characters

Instruction Code	Description
CONCAT	Add characters to the end of a string
DELETE	Delete characters from a string
FIND	Determine the starting character of a substring
INSERT	Insert characters into a string
MID	Extract characters from a string

#### Convert Data to or from ASCII Characters

Instruction Code	Description	
STOD	Convert the ASCII representation of an integer value to a SINT, INT, DINT, or REAL value	
STOR	Convert the ASCII representation of a floating-point value to a REAL value	
DTOS	Convert a SINT, INT, DINT, or REAL value to a string of ASCII characters	
RTOS	Convert a REAL value to a string of ASCII characters	
UPPER	Convert the letters in a string of ASCII characters to upper case	
LOWER	Convert the letters in a string of ASCII characters to lower case	

## **Modbus Support**

To use Logix5000 controllers on Modbus, connect the controllers through the serial port and execute specific ladder logic routines.

A sample controller project is available with RSLogix 5000 Enterprise programming software.

## **Broadcast Messages over a Serial Port**

You can broadcast messages over a serial port connection from a master controller to all of its slave controllers by using several communication protocols. Those protocols are the following:

- DF1 Master
- DF1 Radio Modem
- DF1 Slave

Broadcasting over a serial port is achieved using the 'message' tag. Because messages are sent to receiving controllers, only the 'write' type messages can be used for broadcasting.

The broadcast feature can be set up by using ladder logic programming software or Structured Text programming software.


The broadcast feature can also be set by modifying the path value of a message tag in the tag editor.

For this example, Ladder Logic programming software will be used.

### Step 1: Set Broadcast-Controller Properties

First, set the System Protocol by following these steps.

- 1. In the Controller Organizer, right-click on the controller and choose Properties.
- **2.** In the Controller Properties dialog box, from the System Protocol tab, choose the settings for the controller, then choose OK.



Field	DF-1 Master Protocol	DF-1 Slave Protocol	DF-1 Radio Modem Protocol
Station Address	Controller station address number	Controller station address number	Controller station address number
Transmit Retries	3	3	N/A
ACK Timeout	50	N/A	N/A
Slave Poll Timeout	N/A	3000	N/A
Reply Message Wait	5	N/A	N/A
Polling Mode	Message: polls the slave by using the Message instruction Slave: initiates messages for slave-to-slave broadcast. Standard: schedules polling for the slave.	N/A	N/A
EOT Suppression	N/A	Disable	N/A
Error Detection	BCC	BCC	BCC
Duplicate Detection	Enabled	Enabled	N/A
Enable Store and Forward	N/A	N/A	Choose enable if you want to use the store and forward tag. The last bit of the INT[16] Enable Store and Forward array must be 'enabled'. For example, say you create an INT[16] tag named EnableSandF. Then EnableSandF[15].15 must be set to 1 for broadcast to work on radio modem.

### Step 2: Set Broadcast - Create Controller Scope Message Tag


Next, create a Message tag by following these steps.

1. In the Controller Organizer, right-click on the Controller Tags folder and choose New Tag.

The new tag must be a 'message' tag.

2. Name the tag and select the Data Type 'Message', then choose OK.

The Message tag in the Controller Scope's Controller Tags folder will look similar to the following.




Step 3: Ladder Logic Programming Software

Then, to set broadcasting over a serial port, follow these steps.

- 1. In the Controller Organizer, from the Tasks folder, choose Main Routine to display the ladder logic programming software interface.
- **2.** Open a MSG instruction from the Input/Output tab.
- 3. Double-click in the Message Control field to enable the pull-down menu and select the tag you created.
- **4.** Launch the View Configuration dialog box.


**5.** In the Message Configuration dialog box, from the Configuration tab, select the message type from the Message Type field.



Valid 'Write' Message Types include the following:

- CIP Generic
- CIP Data Table Write
- PLC2 Unprotected Write
- PLC3 Typed Write
- PLC3 Word Range Write
- PLC5 Typed Write
- PLC5 Word Range Write
- SLC Typed Write
- 6. Fill in any other fields needed.

7. From the Communication tab, select the Broadcast Radio button and the Channel from the pull-down, then choose OK.





**ATTENTION:** When using structured text programming software, broadcast over serial is set by typing MSG(aMsg) and right-clicking on aMSG to display the Message Configuration dialog box.

## DH-485 Network Communication


For DH-485 communication, use the controller's serial port.

However, with a CompactLogix controller, we recommend that you use NetLinx networks, such as EtherNet/IP, ControlNet, or DeviceNet, because excessive traffic on a DH-485 network may make it impractical to connect to a controller with RSLogix 5000 programming software.

**IMPORTANT** If your application uses connections to DH-485 networks, select built-in serial ports.

The DH-485 protocol uses RS-485 half-duplex as its physical interface. RS-485 is a definition of electrical characteristics, not a protocol. You can configure the CompactLogix controller's RS-232 port to act as a DH-485 interface. By using a 1761-NET-AIC converter and the appropriate RS-232 cable (1756-CP3 or 1747-CP3), a CompactLogix controller can send and receive data on a DH-485 network.

Figure 9 - CompactLogix DH-485 Communication Overview



On the DH-485 network, the CompactLogix controller can send and receive messages to and from other controllers.

**IMPORTANT** A DH-485 network consists of multiple cable segments. Limit the total length of all the segments to 1219 m (4000 ft).

For the controller to operate on a DH-485 network, you need a 1761-NET-AIC interface converter for each controller you want to put on the DH-485 network.


You can have two controllers for each 1761-NET-AIC converter, but you need a different cable for each controller.

To establish DH-485 communication, perform this procedure.


- 1. Connect the serial port of the controller to either port 1 or port 2 of the 1761-NET-AIC converter.
- 2. Use the RS-485 port to connect the converter to the DH-485 network. The cable you use to connect the controller depends on the port you use on the 1761-NET-AIC converter.

Connection	Required Cable
Port 1 DB-9 RS-232, DTE connection	1747-CP3 or 1761-CBL-AC00
Port 2 mini-DIN 8 RS-232 connection	1761-CBL-AP00 or 1761-CBL-PM02

**3.** In RSLogix 5000 programming software, right-click on your controller and choose Properties.



The Controller Properties dialog appears.




- 4. Click the Serial Port tab.
- 5. From the Mode pull-down menu, choose System.
- **6.** Specify communication settings.

#### **IMPORTANT**

The baud rate specifies the communication rate for the DH-485 port. All devices on the same DH-485 network must be configured for the same baud rate. Select 9600 or 19200 KB.

7. Click the System Protocol tab.



- 8. From the Protocol pull-down menu, choose DH485.
- 9. Specify DH-485 settings.
- 10. From the Protocol pull-down menu, choose DF1 Radio.

**Table 11 - System Protocol Specifications** 

Characteristic	Description			
Station Address	Specifies the node address of the controller on the DH-485 network. Select a number 131 decimal, inclusive.  To optimize network performance, assign node addresses in sequential order. Initiators, such as personal computers, should be assigned the lowest address numbers to minimize the time required to initialize the network.			
Token Hold Factor	Number of transmissions plus retries that a node holding a token can send onto the data link each time it receives the token. Enter a value between 14. The default is 1.			
Maximum Station Address	Specifies the maximum node address of all the devices on the DH-485 network. Select a number 131 decimal, inclusive.  To optimize network performance, make sure:  the maximum node address is the highest node number being used on the network.  that all the devices on the same DH-485 network have the same maximum node address.			

# **Manage Controller Communication**


This chapter explains how to manage controller communication.

Торіс	Page
Produce and Consume Data	75
Send and Receive Messages	76
Connections	77
Calculate Total Connections	78
Connections Example	79

## **Produce and Consume Data**

The controller supports the ability to produce (broadcast) and consume (receive) system-shared tags over ControlNet or EtherNet/IP networks. Produced and consumed tags each require connections. Over ControlNet, produced and consumed tags are scheduled connections.

**Table 12 - Controller Communication Overview** 



Тад Туре	Description
Produced	A produced tag allows other controllers to consume the tag, which means that a controller can receive the tag data from another controller. The producing controller uses one connection for the produced tag and another for each consumer. The controller's communication device uses one connection for each consumer.  As you increase the number of controllers that can consume a produced tag, you also reduce the number of connections the controller and communication device have available for other operations, like communication and I/O.
Consumed	Each consumed tag requires one connection for the controller that is consuming the tag. The controller's communication device uses one connection for each consumer.

For two controllers to share produced or consumed tags, both controllers must be attached to the same control network, such as a ControlNet or Ethernet/IP network. You cannot bridge produced and consumed tags over two networks.

The number of available connections limits the total number of tags that can be produced or consumed. If the controller uses all of its connections for I/O and communication devices, no connections are left for produced and consumed tags.

## **Send and Receive Messages**

Messages transfer data to other devices, such as controllers or operator interfaces. Messages use unscheduled connections to send or receive data. Connected messages can leave the connection open (cache) or close the connection when the message is done transmitting.

Table 13 - Message Transmission

Message Type	Communication Method	Connected Message	Can the message be cached?
CIP data table read or write	NA	Yes	Yes
PLC-2, PLC-3, PLC-5, or SLC	CIP	No	No
(all types)	CIP with Source ID	No	No
	DH+	Yes	Yes
CIP generic	NA	Optional <sup>(1)</sup>	Yes <sup>(2)</sup>
Block-transfer read or write	NA	NA	Yes

<sup>(1)</sup> You can connect CIP generic messages. However, for most applications we recommend you leave CIP generic messages unconnected.

Connected messages are unscheduled connections on both ControlNet and EtherNet/IP networks.

Each message uses one connection, regardless of how many devices are in the message path. You can program the target of a MSG instruction to optimize message transfer time.

<sup>(2)</sup> Consider caching only if the target module requires a connection.

## **Determine Whether to Cache Message Connections**

When you configure a MSG instruction, you can cache or not cache the connection.

**Table 14 - Caching Messages** 

Message Execution	Function
Repeatedly	Cache the connection. This keeps the connection open and optimizes execution time. Opening a connection each time the message executes increases execution time.
Infrequently	Do not cache the connection. This closes the connection upon completion of the message, freeing up that connection for other uses.

#### **Connections**

A Logix5000 system uses a connection to establish a communication link between two devices. Connections can be:

- a controller to local I/O modules or local communication modules.
- a controller to remote I/O or remote communication modules.
- a controller to remote I/O (rack-optimized) modules.
- produced and consumed tags.
- messages.
- controller access by RSLogix 5000 programming software.
- controller access by RSLinx software for HMI or other applications.

The limit of connections may ultimately reside in the communication module you use for the connection. If a message path routes through a communication module, the connection related to the message also counts towards the connection limit of that communication module.

**Table 15 - Connections Overview** 

Device	Supported Connections
CompactLogix controller (1769-L31)	
Built-in ControlNet communication port (1769-L32C and 1769-L35CR controllers only)	100
Built-in EtherNet/IP communication port (1769-L32E and 1769-L32E controllers only)	

## **Calculate Total Connections**

You can calculate the total number of local and remote connections the controller uses.

**Table 16 - Local Connections Calculation** 

Local Connection Type	Device Quantity	Connections per Device	Total Connections
Local I/O module (always a direct connection)		1	
Built-in ControlNet communication port (1769-L32C and 1769-L35CR controllers only)		0	
Built-in EtherNet/IP communication port (1769-L32E and 1769-L35E controllers only)		0	
1769-SDN DeviceNet scanner module		2	
	,	Total	

The number of remote connections a communication module supports determines how many connections the controller can access through that module.

**Table 17 - Remote Connections Calculation** 

Remote Connection Type	Device Quantity	Connections per Device	Total Connections
Remote ControlNet communication module  • I/O configured as direct connection (none)		0 or	
<ul> <li>I/O configured as rack-optimized connection</li> </ul>			
Remote I/O module over ControlNet (direct connection)		1	
Remote EtherNet/IP communication module              I/O configured as direct connection (none)              I/O configured as rack-optimized connection		0 or 1	
Remote I/O module over a EtherNet/IP network (direct connection)		1	
Remote device over a DeviceNet network (accounted for in rack-optimized connection for local 1769-SDN module)		0	
Other remote communication adapter (POINT and FLEX adapters, for example)		1	
Produced tag Each consumer		1	
Consumed tag		1	
Message (depending on type)		1	
Block-transfer message		1	
		Total	

# **Connections Example**

In this example system the 1769-L35E CompactLogix controller:

- controls local digital I/O modules in the same chassis.
- controls remote I/O devices on a DeviceNet network.
- sends and receives messages to/from a ControlLogix controller on an EtherNet/IP network.
- produces one tag that the 1794 FlexLogix controller consumes.
- is programmed via RSLogix 5000 programming software.

Figure 10 - Example - CompactLogix System Connections




Table 18 - Example - CompactLogix Connection Types

Connection Type	Device Quantity	Connections per Device	Total Connections
Controller to local I/O modules (rack-optimized)	2	1	2
Controller to 1769-SDN scanner module	1	2	2
Controller to built-in EtherNet/IP communication port (rack-optimized)	1	0	0
Controller to RSLogix 5000 programming software	1	1	1
Message to ControlLogix controller	2	1	2
Produced tag consumed by FlexLogix controller	2	1	2
Total			

Notes:

# Place, Configure, and Monitor I/O

This chapter explains how to place, configure, and monitor CompactLogix I/O modules.

Торіс	Page
Select I/O Modules	81
Place Local I/O Modules	86
Configure I/O	87
Configure Distributed I/O on an EtherNet/IP Network	88
Configure Distributed I/O on a ControlNet Network	89
Configure Distributed I/O on a DeviceNet Network	90
Address I/O Data	91
Determine When Data Is Updated	92
Reconfigure an I/O Module	94

## **Select I/O Modules**

When choosing 1769 I/O modules, select:

• specialty I/O modules when appropriate.

Some modules have field-side diagnostics, electronic fusing, or individually-isolated inputs and outputs.

- a 1492 wiring system for each I/O module as an alternative to the terminal block that comes with the module.
- 1492 PanelConnect modules and cables if you are connecting input modules to sensors.

## Validate I/O Layout

After you have selected your I/O modules, you need to validate the system you want to design. Before you begin to place your I/O modules, consider that the minimum backplane RPI increases as you add modules. Also, the I/O modules must be distributed so that the current consumed from the left or right side of the power supply never exceeds 2.0 A at 5V DC or 1.0 A at 24V DC.

## **Estimate Requested Packet Interval**

The requested packet interval (RPI) defines the frequency at which the controller sends and receives all I/O data on the backplane. Each module on the backplane can have its own individual RPI setting.

The effective scan frequency for any individual module is still impacted by the other modules in the system and those modules' RPI settings. The following table provides relative scanning durations for various types of modules. This information should be taken into account when setting an individual module's RPI in order to achieve the desired effective scan frequency for any module in the system.

Type of Module	Request Packet Interval		
Digital and analog (any mix)	<ul> <li>14 modules can be scanned in 1 ms.</li> <li>530 modules can be scanned in 2 ms.</li> <li>Some input modules have a fixed 8 ms filter, so selecting a greater RPI has no effect.</li> </ul>		
Specialty	<ul> <li>Full-sized 1769-SDN modules add 2 ms per module.</li> <li>1769-HSC modules add 1 ms per module.</li> <li>Full-sized 1769-ASCII modules add 1 ms per module.</li> </ul>		

You can always select an RPI that is slower than these. The RPI shows how quickly modules can be scanned, not how quickly an application can use the data. The RPI is asynchronous to the program scan. Other factors, such as program execution duration, affect I/O throughput.

## **Calculate System Power Consumption**

To validate your proposed system, calculate the total 5V DC current and 24V DC to be consumed.

Table 19 - I/O Module Power Consumption Calculation Table

Catalog Number	Number of Modules	Module Current Requirements		Requirements Calculated Current = (Number of Modules) x (Module Current Requirements)	
		at 5V DC (in mA)	at 24V DC (in mA)	at 5V DC (in mA)	at 24V DC (in mA)
1769-L31		330	40		
1769-L32C		650	40		
1769-L32E		660	90		
1769-L35CR		680	40		
1769-L35E		660	90		
	•	1	otal Current Required <sup>(1)</sup> :		

<sup>(1)</sup> This number must not exceed the power supply current capacity.

**Table 20 - Power Supply Current Capacity** 

Specification	Power Supply and Capacity			
	1769-PA2	1769-PB2	1769-PA4	1769-PB4
Output Bus Current Capacity 055 °C (32131 °F)	2 A at 5V DC and 0.8 A at 24V DC		4 A at 5V DC and 2 A at 2	4V DC
24V DC User Power Capacity 055 °C (32131 °F)	250 mA (maximum)	NA NA		

## **Validate Placement of I/O Modules**


The controller you use determines how many local I/O modules you can configure.

Table 21 - Controller I/O Support

Controller	Supported Local I/O Modules	I/O Banks
1769-L35CR	30	3
1769-L35E	30	3
1769-L32C, 1769-L32E and 1769-L31	16	3

To validate the proposed placement of I/O modules in your CompactLogix system, perform this procedure.

1. Verify that your 1769-L3x controller resides on the leftmost side of the bank.



2. Verify that you have placed no more than three I/O modules between your controller and power supply (bank 0).

Placing more than three I/O modules in bank 0 would exceed the distance rating of four and invalidate your system.

3. Validate the number of I/O modules your power supply can support.
In a single-bank system, make sure you have not placed more than eight I/O modules between the power supply and end cap (bank 1).

#### **IMPORTANT**

In a single-bank system, the power supply can support up to eight I/O modules as long as the modules' power consumption does not exceed the power supply's capacity.

So, in a single-bank system, you may not have more than eleven total I/O modules, three to the left of your power supply and eight to the right.

If your system requires additional I/O modules, you must add an additional bank.


In a multi-bank system, make sure that your additional bank(s) do not have more than eight I/O modules on either side of the additional power supply.

#### **IMPORTANT**

In a multi-bank system, you may place up to eight I/O modules on either side of the additional power supply so long as the power consumed by these modules does not exceed the power supply's capacity.

In this example, the I/O modules 12...30 could be arranged in any way as long as the power supplies' capacity was not exceeded. In other words, the first additional bank could contain fewer than 16 I/O modules This is just 1 possible arrangement.

Example of Multi-Bank System



4. Verify that all banks have end caps.

#### **IMPORTANT**

If you place and configure more I/O modules and I/O banks than your controller can support, your system may run well for a period of time. Nothing alerts you to the fact that you have exceeded your controller's capacity.

However, by exceeding your controller's I/O capacity, you put your system at risk of intermittent faults, the most common being Major Fault Type 03 (I/O Fault) Code 23.


## Place Local I/O Modules

Use the 1769-CRR1/-CRR3 or 1769-CRL1/-CRL3 expansion cable to connect banks of I/O modules.

Each I/O module also has a power supply distance rating, the number of modules from the power supply. The distance rating is printed on each module's label. Each module must be located within its distance rating.

Figure 11 - Controller I/O Placement

Horizontal Orientation





**ATTENTION:** The CompactLogix system does not support Removal and Insertion Under Power (RIUP). While the CompactLogix system is under power:

- any break in the connection between the power supply and the controller (for example, removing the power supply, controller, or an I/O module) may subject the logic circuitry to transient conditions above the normal design thresholds and may result in damage to system components or unexpected behavior.
- removing an end cap or an I/O module faults the controller and may also result in damage to system components.


The CompactLogix controller also supports distributed (remote) I/O via these networks:

- EtherNet/IP
- ControlNet
- DeviceNet

# **Configure I/0**

To communicate with an I/O module in your system, add the module to the I/O Configuration folder of the controller.

Figure 12 - I/O Module Configuration



When you add a module, you also define a specific configuration for the module. While the configuration options vary from module to module, there are some common options that you typically configure

Table 22 - I/O Configuration Options

Configuration Option	Description	
Requested packet interval (RPI)	<ul> <li>The RPI specifies the interval at which data updates over a connection. For example, an input module sends data to a controller at the RPI that you assign to the module.</li> <li>Typically, you configure an RPI in milliseconds (ms). The range is 0.1750 ms.</li> <li>If a ControlNet network connects the devices, the RPI reserves a slot in the stream of data flowing across the ControlNet network. The timing of this slot may not coincide with the exact value of the RPI, but the control system guarantees that the data transfers at least as often as the RPI.</li> </ul>	
Change of state (COS)	Digital I/O modules use COS to determine when to send data to the controller. If a COS does not occur within the RPI timeframe, the module multicasts data at the RPI.	
	Because the RPI and COS functions are asynchronous to the logic scan, it is possible for an input to change state during program scan execution. If this is a concern, buffer input data so your logic has a stable copy of data during its scan. Use the Synchronous Copy (CPS) instruction to copy the input data from your input tags to another structure and use the data from that structure.	
Communication format	Many I/O modules support different formats. The communication format that you choose also determines:	
Electronic keying	When you configure a module, you specify the slot number for the module. However, it is possible to purposely or accidentally place a different module in that slot. Electronic keying lets you protect your system against the accidental placement of the wrong module in a slot. The chosen keying option determines how closely any module in a slot must match the configuration for that slot before the controller opens a connection to the module. There are different keying options depending on your application needs.	

#### I/O Connections

A Logix5000 system uses connections to transmit I/O data.

Table 23 - Logix5000 I/O Connections

Connection	Description	
Direct	A direct connection is a real-time, data-transfer link between the controller and an I/O module. The controller maintains and monitors the connection between the controller and the I/O module. Any break in the connection, such as a module fault or the removal of a module while under power, causes the controller to set fault status bits in the data area associated with the module.  Typically, analog I/O modules, diagnostic I/O modules, and specialty modules require direct connections.	
Rack-optimized	For digital I/O modules, you can select rack-optimized communication. A rack-optimized connection consolidates connection usage between the controller and all the digital I/O modules on a rack (or DIN rail). Rather than having individual, direct connections for each I/O module, there is one connection for the entire rack (or DIN rail).	

# Configure Distributed I/O on an EtherNet/IP Network


To communicate with distributed I/O modules over an EtherNet/IP network:

- choose a 1769-L32E or 1769-L35E CompactLogix controller with a builtin EtherNet/IP communication port.
- add an EtherNet/IP adapter, and I/O modules to the I/O Configuration folder of the controller.

Within the I/O Configuration folder, organize the modules into a hierarchy of tree/branch and parent/child.

Figure 13 - EtherNet/IP Distributed I/O Configuration

#### For a typical distributed I/O network...



# Configure Distributed I/O on a ControlNet Network


To communicate with distributed I/O modules over a ControlNet network:

- choose a 1769-L32C or 1769-L35CR CompactLogix controller with a built-in ControlNet communication port.
- add a ControlNet adapter, and I/O modules to the I/O Configuration folder of the controller.

Within the I/O Configuration folder, organize the modules into a hierarchy of tree/branch and parent/child.

Figure 14 - ControlNet Distributed I/O Configuration

For a typical distributed I/O network...





# Configure Distributed I/O on a DeviceNet Network

To communicate with the I/O modules over a DeviceNet network, add the DeviceNet bridge to the I/O Configuration folder of the controller. RSNetWorx for DeviceNet software is used to define the scanlist within the DeviceNet scanner to communicate data between the devices and the controller through the scanner.

Figure 15 - DeviceNet Distributed I/O Configuration

#### For a typical distributed I/O network...





## Address I/O Data

I/O information is presented as a set of tags.

- Each tag uses a structure of data, depending on the specific features of the I/O module.
- The name of the tags is based on the location of the I/O module in the system.


#### Figure 16 - I/O Address Format



Where	Is	
Location	Network location.	
	Local = same chassis or DIN rail as the controller.	
	Adapter_Name = identifies remote communication adapter or bridge module.	
Slot	Slot number of I/O module in its chassis or DIN rail.	
Туре	Type of data.	
	I = input.	
	0 = output.	
	C = configuration.	
	S = status.	
Member	Specific data from the I/O module, depending on what type of data the module can store.	
	For a digital module, a data member usually stores the input or output bit values.	
	For an analog module, a channel member (CH#) usually stores the data for a channel.	
SubMember	Specific data related to a member.	
Bit	Specific point on a digital I/O module, depending on the size of the I/O module (031 for a 32-point module).	

# Determine When Data Is Updated

CompactLogix controllers update data asynchronously with the execution of logic. This flowchart illustrates when producers send data. Controllers, input modules and bridge modules are producers.



TIP If you need to ensure that the I/O values being used during logic execution are from one moment in time, such as at the beginning of a ladder program, use the Synchronous Copy instruction (CPS) to buffer I/O data.

#### Monitor I/O Modules

With the CompactLogix controller, you can monitor I/O modules at different levels by:

• using the programming software to display fault data.

Refer to Display Fault Data on page 93.

programming logic to monitor fault data so you can take appropriate action

### **Display Fault Data**


Fault data for certain types of module faults can be viewed through the programming software.

To display fault data, perform this procedure.

1. In RSLogix 5000 programming software, select Controller Tags in the Controller Organizer and right-click to select Monitor Tags.




The display style for the fault data defaults to decimal.



2. Change the display style to Hex to read the fault code.

If the module faults, but the connection to the controller remains open, the controller tags database displays the fault value 16#0E01\_0001. The fault word uses this format.



Bit	Description
Fault_Bit	This bit indicates that at least one bit in the fault word is set (1). If all the bits in the fault word are cleared (0), this bit is cleared (0).
Connection_Closed	This bit indicates whether the connection to the module is open (0) or closed (1). If the connection is closed (1), the Fault_Bit is set (1).

#### **End-cap Detection and Module Faults**

If a module not adjacent to an end cap experiences a fault and the connection to the controller is not broken, only the module enters the fault state. If a module adjacent to an end cap experiences a fault, both the module and the controller transition to the fault state.

# Reconfigure an I/O Module


If an I/O module supports reconfiguration, you can reconfigure the module via:

- the Module Properties dialog box in RSLogix 5000 programming software.
- a MSG instruction in program logic.

## Reconfigure a Module via RSLogix 5000 Programming Software

To reconfigure an I/O module via RSLogix 5000 programming software, perform this procedure.

1. Highlight the module in the I/O Configuration tree and right-click to choose Properties.



👪 Controller Properties - Example\_for\_1769\_ASCII\_Module SFC Execution File Nonvolatile Memory Serial Port | System Protocol | User Protocol | Major Faults | Minor Faults Vendor: Allen-Bradley 1769-L35CR CompactLogix5335CR Controller Type: Change Controller. Revision: Name: Example\_for\_1769\_ASCII\_Module Sample logic using the 1769 ASCII module with Description: CompactLogix. Connect cable from computer to channel zero of ASCII module.

The Controller Properties dialog box appears.

2. Reconfigure the module.

## Reconfigure a Module via a MSG Instruction


To reconfigure an I/O module, use a Module Reconfigure MSG instruction. During the reconfiguration:

- input modules continue to send input data to the controller.
- output modules continue to control their output devices.

A Module Reconfigure message requires the property Message Type and a selection of Module Reconfigure.

To reconfigure an I/O module, perform this procedure.

- Set the required member of the configuration tag of the module to the new value.
- 2. Send a Module Reconfigure message to the module.



Notes:

# **Develop Applications**

This chapter explains how to develop applications.

Topic	Page
Manage Tasks	97
Develop Programs	98
Organize Tags	103
Select a Programming Language	104
Monitor Controller Status	106
Monitor Connections	107
Select a System Overhead Time Slice Percentage	109

# **Manage Tasks**

With a Logix5000 controller, you can use multiple tasks to schedule and prioritize the execution of your programs based on specific criteria. This divides your controller's processing time among the different operations in your application. Remember that:

- the controller executes only one task at one time.
- one exception task can interrupt another and take control.
- in any given task, only one program executes at one time.


# **Develop Programs**

The controller's operating system is a preemptive multitasking system that is IEC 1131-3 compliant. This environment provides:

- tasks to configure controller execution.
- programs to group data and logic.
- routines to encapsulate executable code written in a single programming language.

Figure 19 - Program Development

**Control Application** 



#### **Define Tasks**

Tasks provide scheduling and priority information for programs. You can configure tasks as continuous, periodic, or event tasks. Only one task can be continuous.

Table 24 - Task Support

Controller	Tasks Supported
1769-L35 <i>x</i>	8
1769-L32 <i>x</i>	6
1769-L31	4

A task can have as many as 32 separate programs, each with its own executable routines and program-scoped tags. Once a task is triggered (activated), all the programs assigned to the task execute in the order in which they are grouped. Programs can only appear once in the Controller Organizer and cannot be shared by multiple tasks.

#### Specify Task Priorities

Each task in the controller has a priority level. The operating system uses the priority level to determine which task to execute when multiple tasks are triggered. You can configure periodic tasks to execute from the lowest priority of 15 up to the highest priority of 1. A higher-priority task will interrupt any lower-priority task. The continuous task has the lowest priority and is always interrupted by a periodic task.

The CompactLogix controller uses a dedicated periodic task at priority 6 to process I/O data. This periodic task executes at the RPI you configure for the CompactBus, which can be as fast as once each millisecond. Its total execution time is as long as it takes to scan the configured I/O modules.

How you configure your tasks affects how the controller receives I/O data. Tasks at priorities 1...5 take precedence over the dedicated I/O task. Tasks in this priority range can impact I/O processing time. For example, if you use the following configuration:

- I/O RPI = 1 ms
- a task of priority = 1...5 that requires 500  $\mu$ s to execute and is scheduled to run every millisecond


this configuration leaves the dedicated I/O task 500  $\mu$ s to complete its job of scanning the configured I/O.

However, if you schedule two high priority tasks 1...5 to run every millisecond, and they both require 500 µs or more to execute, no CPU time would be left for the dedicated I/O task. Furthermore, if you have so much configured I/O that the execution time of the dedicated I/O task approaches 2 ms (or the combination of the high priority tasks and the dedicated I/O task approaches 2 ms) no CPU time is left for low priority tasks 7...15.

For example, if your program needs to react to inputs and control outputs at a set rate, configure a periodic task with a priority higher than 6 (1...5). This keeps the dedicated I/O task from affecting the periodic rate of your program. However, if your program contains a lot of math and data manipulation, place this logic in a task with priority lower than 6 (7...15), such as the continuous task, so that the dedicated I/O task is not adversely affected by your program.

Table 25 - Multiple Tasks Example

Task	Priority Level	Task Type	Example Execution Time	Worst-Case Completion Time
1	5	20 ms periodic task	2 ms	2 ms
2	7	Dedicated I/O task 5 ms selected RPI	1 ms	3 ms
3	10	10 ms periodic task	4 ms	8 ms
4	None (lowest)	Continuous task	25 ms	60 ms



#### Remember that:

- the highest priority task interrupts all lower priority tasks.
- the dedicated I/O task can be interrupted by tasks with priority levels 1...5.

The dedicated I/O task interrupts tasks with priority levels 7...15. This task runs at the selected RPI rate scheduled for the CompactLogix system (2 ms in this example).

- the continuous task runs at the lowest priority and is interrupted by all other tasks.
- a lower priority task can be interrupted multiple times by a higher priority task.
- when the continuous task completes a full scan it restarts immediately, unless a higher priority task is running.

## **Define Programs**

Each program contains:

- program tags.
- a main executable routine.
- other routines.
- an optional fault routine.

Each task can schedule as many as 32 programs.

The scheduled programs within a task execute to completion from first to last. Programs unattached to any task show up as unscheduled programs. You must specify (schedule) a program within a task before the controller can scan the program.

#### **Define Routines**

A routine is a set of logic instructions in a single programming language, such as ladder logic. Routines provide the executable code for the project in a controller. A routine is similar to a program file or subroutine in a PLC or SLC controller.

Each program has a main routine. This is the first routine to execute when the controller triggers the associated task and calls the associated program. Use logic, such as the Jump to Subroutine (JSR) instruction, to call other routines.


You can also specify an optional program fault routine. The controller executes this routine if it encounters an instruction-execution fault within any of the routines in the associated program.

#### **Sample Controller Projects**


RSLogix 5000 Enterprise programming software includes sample projects that you can copy and then modify to fit your application.

To view a set of sample controller projects, perform this procedure.

1. From the Help pull-down menu, choose Vendor Sample Projects.



2. Scroll down to select a set of sample projects.




# **Organize Tags**

With a Logix5000 controller, you use a tag (alphanumeric name) to address data (variables). In Logix5000 controllers, there is no fixed, numeric format. The tag name itself identifies the data. This lets you:

- organize your data to mirror your machinery.
- document (through tag names) your application as you develop it.

Figure 20 - Tag Organization



When you create a tag, assign these properties to the tag:

- Tag type
- Data type
- Scope

# Select a Programming Language

The CompactLogix controller supports these programming languages, both online and offline.

**Table 26 - Programming Language Selection** 

Required Language	Program
Ladder diagram (LD)	Continuous or parallel execution of multiple operations (not sequenced)
	Boolean or bit-based operations
	Complex logical operations
	Message and communication processing
	Machine interlocking
	Operations that service or maintenance personnel may have to interpret in order to troubleshoot the machine or process
Function block diagram (FBD)	Continuous process and drive control
	Loop control
	Calculations in circuit flow
Sequential function chart (SFC)	High-level management of multiple operations
	Repetitive sequence of operations
	Batch process
	Motion control using structured text
	State machine operations
Structured text (ST)	Complex mathematical operations
	Specialized array or table loop processing
	ASCII string handling or protocol processing

#### **Add-on Instructions**

With version 18 of RSLogix 5000 programming software, you can design and configure sets of commonly used instructions to increase project consistency. Similar to the built-in instructions contained in Logix 5000 controllers, these instructions you create are called Add-on Instructions. Add-on Instructions reuse common control algorithms. With them, you can:


- ease maintenance by animating logic for a single instance.
- protect intellectual property with locking instructions.
- reduce documentation development time.

You can use Add-on Instructions across multiple projects. You can define your instructions, obtain them from somebody else, or copy them from another project.

Once defined in a project, Add-on Instructions behave similarly to the built-in instructions in Logix5000 controllers. They appear on the instruction tool bar for easy access, as do internal RSLogix 5000 software instructions.

Feature	Description	
Save Time	With Add-on Instructions, you can combine your most commonly used logic into sets of reusable instructions. You save time when you create instructions for your projects and then share them with others. Add-on Instructions increase project consistency since commonly used algorithms all work in the same manner, regardless of who implements the project.	
Use Standard Editors	You create Add-on Instructions by using one of three RSLogix 5000 software programming editors.  Standard Ladder  Function Block Diagram  Structured Text Once you have created instructions, you can use them in any RSLogix 5000 editor.	
Export Add-on Instructions	You can export Add-on Instructions to other projects as well as copy and paste them from one project to another. Give each instruction a unique name so that you don't accidentally overwrite another instruction of the same name.	
Add-on InstructionsUse Context Views	Context views let you visualize an instruction's logic for a specific instant, simplifying online troubleshooting of your Add-on Instructions. Each instruction contains a revision, a change history, and an auto-generated help page.	
Create Custom Help	When you create an instruction, you enter information for the description fields in software dialog boxes, information that becomes what is known as Custom Help. Custom Help makes it easier for users to get the help they need when implementing the instructions.	
Apply Source Protection	As the creator of Add-on Instructions, you can limit users of your instruction(s) to read-only access, or you can bar access to the internal logic or local parameters used by the instruction(s). This source protection lets you prevent unwanted changes to your instruction(s) and protects your intellectual property.	

#### Monitor Controller Status



The CompactLogix controller uses Get System Value (GSV) and Set System Value (SSV) instructions to get and set (change) controller data. The controller stores system data in objects. There is no status file, as in the PLC-5 processor.

The GSV instruction retrieves the specified information and places it in the destination. The SSV instruction sets the specified attribute with data from the source.

When you enter a GSV/SSV instruction, the programming software displays the:

- valid object classes.
- object names.
- attribute names.

For the GSV instruction, you can get values for all the available attributes. For the SSV instruction, the software displays only those attributes you are allowed to set.

In some cases, there will be more than one of the same type of object, so you might also have to specify the object name. For example, there can be several tasks in your application. Each task has its own TASK object that you access by the task name.

You can access these object classes:

- AXIS
- CONTROLLER
- CONTROLLERDEVICE
- CST
- DF1
- FAULTLOG
- MESSAGE
- MODULE
- MOTIONGROUP

- PROGRAM
- ROUTINE
- SERIALPORT
- TASK
- WALLCLOCKTIME

#### **Monitor Connections**


If communication with a device in the I/O configuration of the controller does not occur for 100 ms or 4 times the RPI, whichever is less, the communication times out, and the controller produces these warnings:

- The I/O status indicator on the front of the controller flashes green.
- A \( \text{\text{\text{displays over the I/O configuration folder and the device (s) that has timed out.} \)
- A module fault code is produced, which you can access via:
  - the Module Properties dialog box for the module.
  - a GSV instruction.

#### **Determine if Device Communication Has Timed Out**

If communication times out with at least one device (module) in the I/O configuration of the controller, the I/O status indicator on the front of the controller flashes green.

- The GSV instruction gets the status of the I/O status indicator and stores it in the I\_O\_LED tag.
- If I\_O\_LED equals 2, the controller has lost communication with at least one device.




I\_O\_LED is a DINT tag that stores the status of the I/O status indicator on the front of the controller.

#### **Determine if I/O Module Communication Has Timed Out**

If communication times out with a device (module) in the I/O configuration of the controller, the controller produces a fault code for the module.

- The GSV instruction gets the fault code for IO\_Module and stores it in the Module\_Status tag.
- If Module\_Status is any value other than 4, the controller is not communicating with the module.


Figure 21 - I/O Module Communication




#### Interrupt the Execution of Logic and Execute the Fault Handler

To interrupt the execution of logic and execute the fault handler, perform this procedure.

1. In the Controller Organizer of RSLogix 5000 programming software, right-click the module and choose Properties.



The Module Properties dialog box appears.



- 2. Click the Connection and check Major Fault On Controller If Connection Fails While in Run Mode checkbox.
- 3. Click OK.
- 4. Develop a routine for the Controller Fault Handler.

# Select a System Overhead Time Slice Percentage

With RSLogix 5000 programming software, you can specify a percentage for the system overhead time slice. A Logix 5000 controller communicates with other devices (I/O modules, controllers, HMI terminals) at either a specified rate (scheduled) or when there is processing time available to service the communication (unscheduled).

Service communication is any communication that you do not configure through the I/O configuration folder of the project.


- The system overhead time slice specifies the percentage of time (excluding the time for periodic or event tasks) that the controller devotes to service communication.
- The controller performs service communication for up to 1 ms at a time and then resumes the continuous task.

To select a system overhead percentage, perform this procedure.

1. In the Controller Organizer of RSLogix 5000 programming software, right-click on your controller and choose Properties.



The Controller Properties dialog box appears.



- 2. Click the Advanced tab.
- 3. From the System Overhead Time Slice menu, choose a percentage.

System overhead time slice functions include:


- communicating with programming and HMI devices, such as RSLogix 5000 software.
- responding to messages.
- sending messages.

The controller performs system overhead functions for up to 1 millisecond at a time. If the controller completes the overhead functions in less than one millisecond, it resumes the continuous task.


As the system overhead time slice percentage increases, time allocated to executing the continuous task decreases. If there are no communication for the controller to manage, the controller uses the communication time to execute the continuous task. While increasing the system overhead percentage does increase communication performance, it also increases the amount of time it takes to execute a continuous task, increasing overall scan time.

	V15 and Lower		V16 and Higher	
Time Slice (SOTS)	Comms	Continuous Task	Comms	Continuous Task
10%	1 msec	9 msec	1 msec	9 msec
20%	1 msec	4 msec	1 msec	4 msec
33%	1 msec	2 msec	1 msec	2 msec
50%	1 msec	1 msec	1 msec	1 msec
66%	1 msec	0.5 msec	2 msec	1 msec
80%	1 msec	0.2 msec	4 msec	1 msec
90%	1 msec	0.1 msec	9 msec	1 msec


At a time slice of 10%, system overhead interrupts the continuous task every 9 ms of continuous task time.



The interruption of a periodic task increases the elapsed time (clock time) between the execution of system overhead functions.




If you use the default time slice of 20%, the system overhead interrupts the continuous task every  $4\,\mathrm{ms}$ .




Elapsed Time (ms)

If you increase the time slice to 50%, the system overhead interrupts the continuous task every 1 ms.



Elapsed Time (ms)

If the controller contains only a periodic task(s), the system overhead time slice value has no effect. System overhead runs whenever a periodic task is not running.



Elapsed Time (ms)

# **Configure PhaseManager Application**

This chapter explains how to configure a PhaseManager™ application.

The PhaseManager option of RSLogix 5000 programming software gives you a state model for your equipment.


Торіс	Page
PhaseManager Overview	113
State Model Overview	114
Compare PhaseManager to Other State Models	117
Minimum System Requirements	118
Equipment Phase Instructions	118

For additional information, consult PhaseManager User Manual, publication\_LOGIX-UM001

# **PhaseManager Overview**

PhaseManager lets you add equipment phases to your controller. An equipment phase helps you lay out your code in sections that are easier to write, find, follow, and change.

Term	Description
Equipment phase	<ul> <li>As with a program, an equipment phase is run in a task and is given a set of routines and tags.</li> <li>Unlike a program, an equipment phase runs by a state model and lets you do one activity.</li> </ul>
State model	A state model divides the operating cycle of your equipment into a series of states. Each state is an instant in the operation of the equipment. It's the actions or conditions of the equipment at a given time.  The state model of an equipment phase is similar to the S88 and PackML state models.
State machine	<ul> <li>An equipment phase includes an embedded state machine that:</li> <li>calls the main routine (state routine) for an acting state.</li> <li>manages the transitions between states with minimal coding.</li> <li>makes sure that the equipment goes from state to state along an allowable path.</li> </ul>
PHASE tag	When you add an equipment phase, RSLogix 5000 programming software makes a tag, using the PHASE data type.



#### **State Model Overview**


A state model divides the operating cycle of your equipment into a series of states. Each state is an instant in the operation of the equipment, an action or condition at a given time.

In a state model, you define what your equipment does under different conditions, such as run, hold, and stop. You don't need to use all the states for your equipment. Use only needed states.

**Table 27 - Types of States** 

State	Description
Acting	Does something or several things for a certain time or until certain conditions are met. An acting state runs one time or repeatedly.
Waiting	Shows that certain conditions are met and the equipment is waiting for the signal to go to the next state.

Figure 23 - PhaseManager States



With a state model, you define the behavior of your equipment and put it into a brief functional specification. In this way you show what happens and when it happens.


State	Question To Be Asked
Stopped	What happens when you turn on power?
Resetting	How does the equipment get ready to run?
Idle	How do you tell that the equipment is ready to run?
Running	What does the equipment do to make product?
Holding	How does the equipment temporarily stop making product without making scrap?
Held	How do you tell if the equipment is safely holding?
Restarting	How does the equipment resume production after holding?
Complete	How do you tell when the equipment has finished what it had to do?
Stopping	What happens during a normal shutdown?
Aborting	How does the equipment shut down if a fault or failure happens?
Aborted	How do you tell if the equipment is safely shut down?

#### **How Equipment Changes States**

The arrows in the state model show how your equipment can transition from one state to another.

- Each arrow is called a transition.
- A state model lets the equipment make only certain transitions. This transition restriction standardizes equipment behavior so that another piece of equipment using the same model will behave the same way.

Table 28 - PhaseManager Transitions Overview




**Table 29 - PhaseManager Transition Types** 

Transition Type	Description
Command	A command tells the equipment to start doing something or do something different. For example the operator pushes the start button to start production and the stop button to halt production.  PhaseManager uses these commands:  Reset  Start  Stop  Hold  Restart  Abort
Done	Equipment goes to a waiting state when it has completed a task. You don't have to command equipment to stop. Instead, set up your code to signal when a task is complete.
Fault	A fault tells you that something unusual has occurred. Set up your code to find and take action for faults. Suppose you want your equipment to shut down as fast as possible in case of a certain fault. In that case, set up your code to look for that fault and give the abort command if it finds it.

## **Manually Change States**

With RSLogix 5000 programming software, you can monitor and command an equipment phase. To manually change states, perform this procedure.

**Current State of Equipment Phase** 



# Compare PhaseManager to Other State Models

You can compare PhaseManager's state models to other common state models.

**Table 30 - State Model Comparisons** 

\$88	Pack <i>ML</i>	PhaseManager
Idle	Starting ? Ready	Resetting ? Idle
Running ? Complete	Producing	Running ? Complete
Pausing ? Paused	Standby	Subroutines and/or breakpoints
Holding ? Held	Holding ? Held	Holding ? Held
Restarting	None	Restarting
Stopping ? Stopped	Stopping ? Stopped	Stopping ? Stopped
Aborting ? Aborted	Aborting ? Aborted	Aborting ? Aborted

# Minimum System Requirements

To develop PhaseManager programs, you need:

- a CompactLogix controller with firmware revision 16.0 or later.
- a communication path to the controller.
- RSLogix 5000 programming software, version 15.0 or later.

To enable PhaseManager support, you need the full or professional editions of RSLogix 5000 programming software or the optional PhaseManager add-on (9324-RLDPMENE) to your RSLogix 5000 programming software package.

# **Equipment Phase Instructions**

With CompactLogix controllers, you can issue many ladder diagram (LD) and structured text (ST) instructions to begin various equipment phases.

Instruction Code	Instruction
PSC	Signal a phase that the state routine is complete so go to the next state
PCMD	Change the state or substate of a phase
PFL	Signal a failure for a phase
PCLF	Clear the failure code of a phase
PXRQ	Initiate communication with RSBizWare Batch software
PRNP	Clear the NewInputParameters bit of a phase
PPD	Set up breakpoints within the logic of a phase
PATT	Take ownership of a phase to either:  • prevent another program or RSBizWare Batch software from commanding a phase  or
	make sure another program or RSBizWare Batch software does not already own a phase
PDET	Relinquish ownership of a phase
POVR	Override a command

# **Use a CompactFlash Card**

This chapter explains how to use a CompactFlash card for nonvolatile memory or data storage.

Торіс	Page
Use a CompactFlash Card to Load/Store a User Application	122
Use a CompactFlash Card for Data Storage	125
Read and Write User Data to the CompactFlash Card	125

CompactLogix controllers only support nonvolatile storage through CompactFlash removable media. CompactLogix controllers support the 1784-CF128 Industrial CompactFlash memory cards for nonvolatile memory.

CompactLogix controllers 1769-L31, 1769-L32E, 1769-L32C, 1769-L35E, and 1769-L35CR can save and restore user applications to CompactFlash memory.


Of the 1769 CompactLogix controllers, only the 1769-L32E and 1769-L35E can store user data (for example, a recipe) to the CompactFlash card during runtime. This feature is supported on 1769-L35E controllers with serial numbers starting with SS0OR9GE, or greater, and 1769-L32E controllers with serial numbers starting with SS0QZ000, or greater. To find the controller's serial number, look on the label on the outside of the controller, or access it electronically in RSLinx software or RSLogix 5000 programming software. You must use firmware version V16, or greater.

#### Locate the Controller Serial Number in RSLinx Software


To find the controller's serial number in RSLinx software, follow these steps.

1. Open RSLinx software and from the Communication pull-down menu, choose RSWho.

**2.** Right-click on the controller in the RSWho browse window and select Device Properties.




The Device Properties dialog box displays, showing the serial number.




#### **Locate the Controller Serial Number**

#### Via the RSLogix 5000 Project

To find the controller's serial number in your RSLogix 5000 project when using ladder logic or structured text, use the Get System Value (GSV) instruction to obtain the value of the Serial Number attribute of the ControllerDevice object.



The value can be shown in RSLogix 5000 programming software's data monitor. When the style is set to Hex, the displayed value is the same as shown in RSLinx software.



TIP If the user wants to access the serial number programmatically, additional logic is needed to obtain the serial number's value.

#### Via RSLogix 5000 Programming Software

To find the controller's serial number in RSLogix programming software, follow these steps.

- 1. In the controller organizer, right-click on the controller and select Properties from the pull-down menu.
  - The Controller Properties dialog box displays.
- 2. Click the Advanced tab to see the serial number.

# Use a CompactFlash Card to Load/Store a User Application

You can load the user application/project from nonvolatile memory/ CompactFlash to the user memory of the controller:

- on every power-up.
- on corrupt memory.
- anytime through RSLogix 5000 programming software.



**ATTENTION:** Fault conditions can occur if the controller types do not match. For example, if the CompactFlash user program and controller firmware were created for a 1769-L35E controller, and then an attempt was made to load that program and/or firmware into a 1769-L32E controller.

#### **IMPORTANT**

The user application and firmware version on the CompactFlash card is loaded into the controller. If the contents of the CompactFlash card are a different revision than the revision that is on the controller, then the controller will be updated to the revision on the CompactFlash card.



**ATTENTION:** Do not remove the CompactFlash card while the controller is reading from or writing to the card, as indicated by a flashing green CF status indicator. Doing so could corrupt the data on the card or in the controller, as well as corrupt the latest firmware in the controller.

#### **IMPORTANT**

CompactFlash card memory stores the contents of the user memory when you store the project.\

- Changes made after you store the project are not reflected in CompactFlash card memory.
- If you change the project but do not store those changes, you overwrite
  them when you load the project from the CompactFlash card. If this occurs,
  you have to upload or download the project to go online.
- If you want to store changes such as online edits, tag values, or a ControlNet network schedule, store the project again after you make the changes.


When you store a project to a 1784-CF128 Industrial CompactFlash memory card, the controller formats the card, if required.

## Manually Change Which Project Loads

A CompactFlash card stores multiple projects. By default, the controller loads the project that you most recently stored, according to the load options of that project.

#### **IMPORTANT**

Be aware that when loading a different project, the firmware revisions must be the same.



To assign a different project to load from the CompactFlash card, edit the Load.xml file on the card.

- **1.** To change which project loads from the card, open *Load.xml*. Use a text editor to open the file.
- 2. Edit the name of the project that you want to load.
  - Use the name of an XML file that is in the CurrentApp folder.
  - In the CurrentApp folder, a project is comprised of an XML file and a P5K file.


#### **Manually Change the Load Parameters**

When you store a project to a CompactFlash card, you define:


- when the project is to load (On Power Up, On Corrupt Memory, User Initiated).
- mode to which to set the controller (if the keyswitch is in REM and the load mode is not User Initiated).

**IMPORTANT** Be aware that when loading a different project, the firmware revisions must be the same.

To assign a different project to load from the CompactFlash card, edit the Load.xml file on the card.



1. To change the load parameters for a project, open the XML file with the same name as the project. Use a text editor to open the file.



2. Edit the Load Image option of the project.

If you want to set the Load Image option to	Then enter
On Power Up	ALWAYS
On Corrupt Memory	CORRUPT_RAM
User Initiated	USER_INITIATED

**3.** Edit the Load Mode option of the project (doesn't apply if the Load Image option is *User Initiated*).

If you want to set the Load Mode option to	Then enter
Program (Remote Only)	PROGRAM
Run (Remote Only)	RUN

# Use a CompactFlash Card for Data Storage

You can also store data to the CompactFlash memory card.

#### For example:

- A PanelView terminal changes tag values in a controller project. If power
  to the controller is lost (and the controller is not battery backed up), the
  program running in the controller, along with any values that were
  changed by the PanelView terminal, will be lost. Use the CompactFlash
  file system and logic in the project to store tag values as they change. When
  the project reloads from the CompactFlash card, it can check the
  CompactFlash card for any saved tag values and reload those into the
  project.
- Store a collection of recipes on the CompactFlash card. When you need to change a recipe, program the controller to read data for the new recipe from a CompactFlash card.
- Program the controller to write data logs at specific time intervals.

# Read and Write User Data to the CompactFlash Card

A sample controller project that reads and writes from a CompactFlash card is available with RSLogix 5000 Enterprise programming software.

Notes:

# **Maintain the Battery**

This chapter explains how to maintain your battery.

Topic	Page
Battery Handling	127
Check If the Battery Is Low	128
Estimate 1769-BA Battery Life	128
Store Lithium Batteries	129
Battery Removal	129

CompactLogix controllers support the 1769-BA battery.



**ATTENTION:** The 1769-BA battery is the only battery you can use with the CompactLogix controllers. The 1747-BA battery is not compatible with the CompactLogix controllers and may cause problems.

# **Battery Handling**

Lithium batteries are primary (not rechargeable) cells that give extended memory support for Rockwell Automation products.



**ATTENTION:** This product contains a sealed lithium battery that may need to be replaced during the life of the product.


At the end of its life, the battery contained in this product should be collected separately from any unsorted municipal waste.

The collection and recycling of batteries helps protect the environment and contributes to the conservation of natural resources as valuable materials are recovered.

# **Check If the Battery Is Low**

The battery indicator (BAT) warns when the battery is low. Once the controller is powered down, the battery retains controller memory as long as the BAT indicator remains on. Temperature dictates how long the BAT indicator remains on.

Figure 24 - Battery Status Indicator



**Table 31 - BAT Indicator Duration** 

Temperature	Duration
60 °C (140 °F)	8 days
25 °C (77 °F)	25 days

# Estimate 1769-BA Battery Life

Certain conditions affect typical battery life.

**Table 32 - Battery Life Estimations** 

Time On/Off	At 25 °C (77 °F)	At 40 °C (104 °F)	At 60 °C (140 °F)	
Always off	14 months	12 months	9 months	
On 8 hours per day 5 days per week	18 months	15 months	12 months	
On 16 hours per day 5 days per week	26 months	22 months	16 months	
Always On	There is almost no drain on the	There is almost no drain on the battery when the controller is always on.		

#### **Store Lithium Batteries**



**ATTENTION:** Follow these general rules to store your batteries.

- Store batteries in a cool, dry environment. We recommend 25 °C (77 °F) with 40...60% relative humidity.
- Regularly monitor the temperature and humidity of the storage area.
- Use a first-in/first-out system for handling stored batteries.
- Store in the original containers away from flammable materials.
- Keep track of storage time. Reference storage time to the date of manufacture.
- Do not store batteries longer than 10 years.
- Do not store used batteries longer than 3 months before disposal.
- Clearly mark the contents of the storage area.
- Place a Lith-X or Class D Powder fire extinguisher in a readily accessible area in or around the storage area.
- Ventilate and protect the storage area against fire. You must have a system that automatically detects and extinguishes fires and automatically activates an alarm signal.
- Do not smoke in the storage area.

Table 33 - Storage Temperatures for 1769-BA Lithium Batteries

Storage Temperature	Capacity Loss	
40 °C (104 °F) for 5 years	Loses up to 4% of original capacity	
60 °C (140 °F)	Loses 2.5 % of capacity each year	

- You may store batteries for up to 30 days between -45...85 °C (-49...185 °F) such as during transportation. Do not store in temperatures above 85° C (185 °F).
- To avoid leakage or other hazards, do not store batteries above 60° C for more than 30 days.
- The rate of capacity loss increases as storage temperature increases.

# **Battery Removal**



**WARNING:** When you connect or disconnect the battery, an electrical arc can occur. This could cause an explosion in hazardous location installations. Be sure that power is removed or the area is nonhazardous before proceeding.

# **Additional Resources**

For additional information, consult this publication.

Resource	Description
Guidelines for Handling Batteries, publication <u>AG 5-4</u>	Detailed information on battery-handling procedures for the 1769-BA lithium battery.

# **Status Indicators**

This appendix explains how to interpret the status indicators on your CompactLogix controllers.

Торіс	Page
1769-L3xx Controllers Status Indicators	131
RS-232 Serial Port Status Indicators	133
ControlNet Indicators	133
EtherNet/IP Indicators	135

# 1769-L3xx Controllers Status Indicators

These are the 1769-L3xx CompactLogix controller status indicators.

Indicator	Condition	Interpretation	
RUN	Off	The controller is in program or test mode.	
	Steady green	The controller is in run mode.	
FORCE	Off	<ul> <li>No tags contain I/O force values.</li> <li>I/O forces are inactive (disabled).</li> </ul>	
	Steady amber	<ul><li>I/O forces are active (enabled).</li><li>I/O force values may or may not exist.</li></ul>	
Flashing amber		One or more input or output addresses have been forced to an On or Off condition, but the forces have not been enabled.	
BAT	Off	The battery supports memory.	
	Steady red	<ul> <li>The battery is:</li> <li>not installed.</li> <li>95% discharged and should be replaced.</li> </ul>	
		The state to devices in the 1/0 configuration of the controller.	
	Steady green	The controller is communicating with all the devices in its I/O configuration.	
	Flashing green	One or more devices in the I/O configuration of the controller are not responding.	
	Flashing red	<ul> <li>The controller is not communicating with any devices.</li> <li>The controller is faulted.</li> </ul>	

Indicator	Condition	Interpretation				
OK	Off	No powe	r is applied.			
	Flashing red	• The co	ontroller requ	iires a firmware updat	е.	
		<ul> <li>A major recoverable fault occurred on the controller. To clear the fault, perform this procedure.</li> <li>a. Turn the controller keyswitch from PROG to RUN to PROG.</li> </ul>				
		b. 6	b. Go online with RSLogix 5000 programming software.			
				major fault occurred o ys a steady red status	n the controller. In this case, the controller: indicator.	
		b. r	esets itself.			
		с. с	lears the proj	ect from its memory.		
		d. s	ets the status	s indicator to flashing	red.	
		e. p	roduces a ma	ajor recoverable fault.		
		f. g	enerates a fa	ult code in the RSLogi	x 5000 project.	
					programming software, and the subsequent fault recovery method, a CompactFlash card in the controller.	
			Code	Condition	Fault recovery method	
			60	CompactFlash card is not installed.	1. Clear the fault. 2. Download the project. 3. Change to Remote Run/Run mode.  If the problem persists: 1. Before you cycle power to the controller, record the state of the OK and RS232 status indicators. 2. Contact Rockwell Automation support. See the back cover.	
			61	CompactFlash is installed.	Clear the fault.     Download the project.     Change to Remote Run/Run mode.	
					If the problem persists, contact Rockwell Automation support. See the back cover.	
				•		
	Steady red	fault, per 1. Cycle 2. Down 3. Chang	The controller detected a nonrecoverable major fault, so it cleared the project from memory. To recover from a major fault, perform this procedure.  1. Cycle power to the chassis. 2. Download the project. 3. Change to Run mode.  If the OK status indicator remains steady red, contact your Rockwell Automation representative or local distributor.			
	Steady green	Controller is OK.				
	Flashing green	The controller is storing or loading a project to or from nonvolatile memory.				

## **CompactFlash Indicator**

This is the CompactFlash card status indicator present on all CompactLogix controllers.



**ATTENTION:** Do not remove the CompactFlash card while the controller is reading from or writing to the card, as indicated by a flashing green CF status indicator. This could corrupt the data on the card or in the controller, as well as corrupt the latest firmware in the controller.

.

Indicator	Condition	Interpretation	
CF	Off	There is no activity.	
	Flashing green	The controller is reading from or writing to the CompactFlash card.	
	Flashing red	CompactFlash card does not have a valid file system.	

# RS-232 Serial Port Status Indicators

These are the RS-232 serial port status indicators present on all CompactLogix controllers.

Indicator	Condition	Interpretation	
DCHO Off Channel O configuration differs from		Channel 0 configuration differs from the default serial configuration.	
	Steady green	Channel 0 has the default serial configuration.	
CHO Off		No RS-232 activity.	
	Flashing green	RS-232 activity.	
CH1	Off	No RS-232 activity.	
(1769-L31 only)	Flashing green	RS-232 activity.	

### **ControlNet Indicators**

The ControlNet indicators are only on the 1769-L32C and 1769-L35CR controllers.

Use these indicators to determine how your CompactLogix 1769-L32C or 1769-L35CR controller is operating on the ControlNet network:

- Module Status
- Network Status

These indicators provide information about the controller and network when the controller is connected to ControlNet via the BNC connectors.

**Table 34 - ControlNet Network Status Indicator States** 

Status Indicator State	Interpretation	
Steady	The indicator is on continuously in the defined state.	
Alternating	When viewed together, two indicators alternate between two defined states; the two indicators are always in opposite states, out of phase.	
Flashing	When viewed independent of another, an indicator alternates between the two defined states; if both indicators are flashing, they flash together, in phase.	

#### **IMPORTANT**

Keep in mind that the Module Status indicator reflects the module state (for example, self-test, firmware update, normal operation but no connection established). The network status indicators, A and B, reflect network status. Remember that the host is able to engage in local messaging with the card although it is detached from the network. Therefore, the Module Status indicator is flashing green if the host has successfully started the card. Note, however, that until the host removes reset, all communication port status indicators.

When you view the indicators, always view the Module Status indicator first to determine the state of the communication port. This information may help you to interpret the network indicators. As a general practice, view all indicators (Module Status and Network Status) together to gain a full understanding of the daughtercard's status.

#### **Module Status (MS) Indicator**

These are the ControlNet module indicators.

Indicator	Condition	Recommended Action
Off	The controller has no power.	Apply power.
	The controller is faulted.	Make sure that the controller is firmly seated in the slot.
Steady red	A major fault has occurred on the controller.	Cycle power.     If the problem persists, replace the controller.
Flashing red	A minor fault has occurred because a firmware update is in progress.	Normal operation - No action is required.
	A node address switch change has occurred. The controller's node address switches may have been changed since power-up.	Change the node address switches back to the original setting. The module will continue to operate properly.
	The controller uses invalid firmware.	Update the controller firmware with the ControlFlash Update utility.
	The controller's node address duplicates that of another device.	<ol> <li>Remove power.</li> <li>Change the node address to a unique setting.</li> <li>Reapply power.</li> </ol>
Steady green	Connections are established.	Normal operation - No action is required.
Flashing green	No connections are established.	Establish connections, if necessary.
Flashing red/green	The controller is diagnosing a problem.	Wait briefly to see if problem corrects itself.  If problem persists, check the host. If the daughtercard cannot communicate with the host, the card may remain in self-test mode.

### **Network Channel Indicators**

These are the ControlNet network channel indicators.

Channel B is only labelled on the 1769-L35CR controller. The 1769-L32C controller only has channel A but uses the second indicator in some status indicator patterns as described below.

Indicator	Condition	Recommended Action
Off	A channel is disabled.	Program network for redundant media, if necessary.
Steady green	Normal operation is occurring.	Normal operation - No action is required.
Flashing green/off	Temporary network errors have occurred.	<ol> <li>Check media for broken cables, loose connectors, and missing terminators.</li> <li>If condition persists, refer to the ControlNet Planning and Installation Manual, publication 1786-6.2.1.</li> </ol>
	The node is not configured to go online.	Make sure the network keeper is present and working and the selected address is less or equal to the UMAX <sup>(1)</sup> .
Flashing red/off	Media fault has occurred.	<ol> <li>Check media for broken cables, loose connectors, and missing terminators.</li> <li>If condition persists, refer to the ControlNet Planning and Installation Manual, publication 1786-6.2.1.</li> </ol>
	No other nodes are present on the network.	Add other nodes to the network.
Flashing red/green	The network is configured incorrectly.	Reconfigure the ControlNet network so that UMAX is greater than or equal to the card's node address.
Off	You should check the MS indicators.	Check the MS indicators.
Steady red	The controller is faulted.	<ol> <li>Cycle power.</li> <li>If the fault persists, contact your Rockwell Automation representative or distributor.</li> </ol>
Alternating red/green	The controller is performing a self test.	Normal operation - No action is required.
Alternating red/off	The node is configured incorrectly.	Check the card's network address and other ControlNet configuration parameters.

<sup>(1)</sup> UMAX is the highest node address on a ControlNet network that can transmit data.

### **EtherNet/IP Indicators**

The EtherNet/IP indicators are only on 1769-L32E and 1769-L35E controllers.

#### **Module Status (MS) Indicator**

These are the EtherNet/IP module indicators.

Indicator	Condition	Recommended Action
Off	The controller does not have power.	Check the controller power supply.
Flashing green	The port is in standby mode; it does not have an IP address and is operating in BOOTP mode.  Verify that the BOOTP server is running.	
Steady green	The port is operating correctly.	Normal operation - No action is required.
Steady red	The controller is holding the port in reset or the controller has faulted.	Clear the controller fault.     If the fault will not clear, replace the controller.
	The port is performing its power-up self test.	Normal operation - No action is required.
	A nonrecoverable fault has occurred.	Cycle power to the controller.     If the fault will not clear, replace the controller.
Flashing red	The port firmware is being updated.	Normal operation - No action is required.

# Network Status (NS) Indicator

These are the EtherNet/IP network indicators.

Indicator	Condition	Recommended Action
Off	The port is not initialized; it does not have an IP address and is operating in BOOTP mode.	Verify that the BOOTP server is running.
Flashing green	The port has an IP address, but no CIP connections are established.	If no connections are configured, no action is required.     If connections are configured, check connection originator for connection error code.
Steady green	The port has an IP address and CIP connections (Class 1 or Class 3) are established.  Normal operation - No action is required.	
Steady red	The port has detected that the assigned IP address is already in use.	Verify that all IP addresses are unique.
Flashing red/green	The port is performing its power-up self test.	Normal operation - No action is required.

# **Link Status (LNK) Indicator**

Indicator	Condition	Recommended Action	
Off	The port is not connected to a powered Ethernet device. Therefore, the port cannot communicate on Ethernet.	Verify that all Ethernet cables are connected.     Verify that Ethernet switch is powered.	
Flashing green	The port is performing its power-up self-test.		
	The port is communicating on Ethernet.	Normal operation - No action is required.	
Steady green	The port is connected to a powered Ethernet device. Therefore, the port can communicate on Ethernet.		

# Dynamic Memory Allocation in CompactLogix Controllers

This appendix explains the dynamic allocation of memory in CompactLogix controllers.

Topic	Page
Messages	138
RSLinx Tag Optimization	138
Trends	139
DDE/OPC Topics	139

Certain operations cause the controller to dynamically allocate and remove user-available memory, affecting the space available for program logic. As these functions become active, memory is allocated. Memory is then removed when these functions become inactive.

Operations that dynamically allocate memory are:

- messages.
- connections to processors with RSLogix 5000 programming software.
- RSLinx tag optimization.
- trends.
- DDE/OPC topics.

## Messages

Messages come in and go out of the controller via the Ethernet, ControlNet, and serial ports, causing memory allocation. The memory allocations for messages destined to I/O are accounted for in these allocations. To prevent message instructions from using too much memory, do not send messages simultaneously.

Table 35 - Message Types

Message Path		Connection Established?	Memory Allocated
ControlNet Port	Incoming	Yes - The message is connected.	1200 bytes
		No - The message is unconnected.	1200 bytes
	Outgoing	All outgoing messages whether connected or unconnected	1200 bytes
Ethernet Port	Incoming	Yes - The message is connected.	1200 bytes
		No - The message is unconnected.	1200 bytes
	Outgoing	All outgoing messages whether connected or unconnected	1200 bytes
Serial Port	Incoming	All incoming messages whether connected or unconnected	1200 bytes
	Outgoing	All outgoing messages whether connected or unconnected	1200 bytes

# **RSLinx Tag Optimization**

With tag optimization, trend objects, trend drivers, and connections allocate memory.

**Table 36 - Tag Functions** 

ltem	Description	Memory Allocated
Trend Object	Object is created in the controller to group the requested tags. One trend object can handle approximately 100 tags.	80 bytes
Trend Driver	Drive is created to communicate with the trend object.	36 bytes
Connection	Connection is created between the controller and RSLinx software.	1200 bytes

EXAMPLE	To monitor 100 points:
	100 points x 36 bytes = 3600 bytes (Trend Driver)
	3600 (Trend Driver) $+ 80$ (Trend Object) $+ 1200$ (Connection) $=$ approximately 4000 bytes
	We estimate that one tag consumes about 40 bytes of memory.

#### **Trends**

Each trend created in a controller creates a trend object and allocates a buffer for logging.

Table 37 - Controller Trends

Item	Memory Allocated
Trend Object	80 bytes
Log Buffer	4000 bytes

## **DDE/OPC Topics**

A DDE/OPC topic uses connections based on these variables:

- Maximum number of messaging connections per PLC controller configured in RSLinx software
- Number of connections needed to optimize throughput
- Configuration of RSLinx software to use connections for writing to a ControlLogix processor


# **IMPORTANT** These variables are per path. For example, if you set up two different DDE/OPC topics, with different paths to the same controller, the variables limit the connections for each path. Therefore, if you have a limit of 5 connections, it is possible to have 10 connections, with 5 over each path.

### **Specify Connections per PLC Controller**

To specify the maximum messaging connections per PLC controller, perform this procedure.

1. In RSLinx programming software, from the Communication pull-down menu, choose Configure CIP Options.





The Configure CIP Options dialog box appears.

- 2. In the Max. Messaging Connections per PLC field, enter the maximum number of read connections you want a particular workstation to make to a ControlLogix controller.
- 3. Click OK.

Specify Number of Connections Needed to Optimize Throughput

To specify the number of connections needed to optimize throughput, perform this procedure.

- 1. Repeat step 1 from the previous procedure.
- 2. In the Configure CIP Options dialog box, click the Use Connections for Writes to ControlLogix processor checkbox.

**IMPORTANT** Once you have selected this feature, you cannot limit the number of connections established.

#### **Number of Connections Needed to Optimize Throughput**

RSLinx software only opens the number of connections required to optimize throughput. For example, if you have one tag on scan, but have configured RSLinx software to allow five connections as the maximum number of connections, RSLinx software only opens one connection for the tag. Conversely, if you have thousands of tags on scan and limit the maximum number of CIP connections to five, RSLinx software cannot establish more than five connections to the CompactLogix controller. RSLinx software then funnels all of the tags through those five available connections.


#### **View the Number of Open Connections**

To view the number of open connections made from your workstation to the CompactLogix controller, perform this procedure.

1. In RSLinx programming software, from the Communication pull-down menu, choose CIP Diagnostics.




The CIP Diagnostics dialog box appears.



2. Click the Connections tab.

Here you see an itemized list of open connections.

3. Click the Dispatching tab.



In the Connections Established box you see the total number of connections open to the CompactLogix controller.

Numerics	CompactFlash
1769-L3x controllers	data storage 125
status indicator 131	install 21
Status illuicator 131	read and write user data 125
	reader 125
A	CompactLogix address I/O data 91
add-on instructions 105	address 170 data 91 applications development 97
address data 91	battery maintenance 127
<b>AOI</b> 105	configure I/O 87
applications	connections example 79
• •	ControlNet network communication 50
develop 97 architecture 12	ControlNet software combinations 51
ASCII devices	COS 87
	define programs 101 define routines 101
serial communication 64 assemble the system 22	define tasks 99
assemble the system 22	design a system 13
	DeviceNet network communication 53
В	DeviceNet software combinations 54
hatton	DH-485 network communication 72
battery	display I/O fault data 93
connect 20 life 128	dynamic memory allocation 137
Lithium 129	estimate battery life 128 EtherNet/IP network communication 48
maintenance 127	EtherNet/IP software combinations 48
storage 129	I/O communication format 87
before you begin 19	I/O connections 88
<b>BOOTP</b> 29	I/O electronic keying 87
broadcast	Logix5000 connections 77
messages over serial 67	manage controller communication 75
,	manage tasks 97 monitor connections 107
	monitor confrections 107
C	monitor I/O modules 93
cables	network communication 47
1769 expansion 86	organize tags 103
serial 42	overview 11
cache messages 77	place local I/O modules 86
calculate	RPI 87 select I/O modules 81
system power consumption 83	select 1/0 modules 81 select programming language 104
total connections 78	serial communication 55
change	serial modbus support 67
equipment states 116	serial port configuration 56
change of state 87	start 11
channel 0 default 28	use CompactFlash reader 125
check	validate I/O layout 82  CompactLogix controllers
low battery 128	
communicate	dynamic memory allocation 137 compatibility 18
EtherNet/IP network 48	configuration
over networks 47 communication	DF1 55
ControlNet network 50	serial 27
determine timeout with any device 107	configure 43
determine timeout with I/O module 108	distributed I/O on ControlNet 89
DeviceNet network 53	distributed I/O on DeviceNet 90
DH-485 network 72	distributed I/O on EtherNet 88
format 87	I/O 81, 87
	PhaseManager 113

connect	DeviceNet network
battery 20	communication 53
ControlNet 32	configure distributed I/O 90
EtherNet/IP 28	example configuration 55
programming terminal 35	software combinations 54
RS-232 26	DF1
connections 77	configuration 55
calculate 78	master 67
consume data 75	radio modem support 61
ControlNet network 52	DH-485 network
determine timeout with any device 107	communication 72
determine timeout with I/O module 108	dimensions 24
EtherNet/IP network 49	DIN rail 25
example 79	display
monitor 107	
number needed to optimize throughput 141	fault data 93
produce data 75	dynamic memory allocation 137
view number of open 141	CompactLogix controllers 137
connections per PLC	messages 138
specify 139	RSLinx tag optimization 138
consume data	
connection use 75	E
controller	_
communication management 75	EDS files 36
design 13	electronic keying 87
fault handler 109	electrostatis discharge 16
firmware 36	end cap 94
operating modes 39	equipment states
path selection 45	change 116
status monitoring 106	estimate
controller properties 67	
ControlNet network	battery life 128 requested packet interval 82
communication 50	EtherNet/IP network
configure distributed I/O 89	
connections 32, 52	communication 48 configure distributed I/O 88
example configuration 51	connections 28, 49
module status indicator 134	example configuration 48
node address 19	network LED indicators 136
software combinations 51	software combinations 48
tap 33 <b>COS</b> 87	European hazardous location approval 17
(03 6/	
	example system 12
D	expansion cables
	configuration 86
data	
update 92	F
data storage	•
CompactFlash 125	fault data
DDE/OPC topics 139	display 93
default serial configuration 27	fault handler 109
define	<b>FBD</b> 104
programs 101	firmware 36
routines 101	function block diagram 104
tasks 99	
design 13	
CompactLogix system 13	G
develop	•
applications 97	ground 24
develop application	
fault handler 109	

1	monitor
1/0	connections 107
	controller status 106
address data 91 communication format 87	1/0 81
configure 81, 87	I/O modules 93
connections 88	mount
COS 87	DIN rail 25
electronic keying 87	panel 25 system 23
layout validation 82	system 25
monitor 81	
monitor connection 108 place 81	N
I/O modules	network communication 47
display fault data 93	network LED indicators
end cap detection 94	EtherNet/IP network 136
monitor 93	node address 19
reconfigure 94	North American Haxardous location approval
select 81	17
install 15	
IP address 29	_
isolator 27	0
	operating modes 39
L	optical isolator 27
	organize
ladder diagram 104	tags 103
link status indicator	•
status indicator 136 <b>Lithium</b>	n
	Р
battery 129 LNK	parts list 19
status indicator 136	path selection
load	controller 45
firmware 36	PhaseManager
local I/O modules	configure 113 terms 113
place 86	place
low battery 128	1/0.81
	local I/O modules 86
M	point-to-point 55
	port configuration
maintain	serial 55, 56
battery 127 <b>manage</b>	produce data
controller communications 75	connection use 75
tasks 97	program definition 101
manual state changes 117	programming language select 104
master mode 55	programming terminal 35
messages 138	programs
broadcast over serial 67	define 101
cache 77	pushbutton 28
receive 76	F
reconfigure I/O module 95 send 76	_
minimum spacing 23	R
modbus support 67	radio modem 67
modem	read and write user data
radio 67	CompactFlash 125
modes 39	receive
module status indicator	messages 76
ControlNet network 134	reconfigure
FtherNet/ID network 135	I/O module 94

requested packet interval	Ī
description 87	tags
estimate 82	organize 103
routines	tasks
define 101	define 99
RS-232 connections 26	manage 97
RS-232 serial port	management 97
status indicator 133	total connections
RSLinx tag optimization 138	calculate 78
	trends 139
S	
_	
select	U
controller path 45	update
I/O modules 81	data 92
programming language 104	use
send	CompactFlash reader 125
messages 76 sequential function chart 104	•
-	17
serial	V
cables 42	validate
communication 55, 67 communication with ASCII devices 64	I/O layout 82
default configuration 27	verify
driver 43	compatibility 18
port configuration 55, 56	view
port direct connection to controller 41	number of open connections 141
pushbutton 28	·
series B 18	147
set node address 19	W
<b>SFC</b> 104	wiring 24
slave 67	
slave mode 55	
software combinations	
ControlNet network 51	
DeviceNet network 54	
spacing 23	
specify	
connections per PLC 139	
<b>ST</b> 104	
state model 114	
comparisons 117	
states	
manually change 117	
status indicator	
1769-L3x 131	
link status indicator 136	
LNK 136	
module 135	
RS-232 serial port 133 store batteries 129	
structured text 104	
system layout 12	
system overhead time slice 109	
system power consumption	
estimate 83	

# **Rockwell Automation Support**

Rockwell Automation provides technical information on the Web to assist you in using its products. At <a href="http://www.rockwellautomation.com/support">http://www.rockwellautomation.com/support</a>, you can find technical manuals, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools. You can also visit our Knowledgebase at <a href="http://www.rockwellautomation.com/knowledgebase">http://www.rockwellautomation.com/knowledgebase</a> for FAQs, technical information, support chat and forums, software updates, and to sign up for product notification updates.

For an additional level of technical phone support for installation, configuration, and troubleshooting, we offer TechConnect<sup>SM</sup> support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <a href="http://www.rockwellautomation.com/support/">http://www.rockwellautomation.com/support/</a>.

### **Installation Assistance**

If you experience a problem within the first 24 hours of installation, review the information that is contained in this manual. You can contact Customer Support for initial help in getting your product up and running.

United States or Canada	1.440.646.3434
Outside United States or Canada	Use the Worldwide Locator at http://www.rockwellautomation.com/support/americas/phone en.html, or contact your local Rockwell Automation representative.

### **New Product Satisfaction Return**

Rockwell Automation tests all of its products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned, follow these procedures.

United States	Contact your distributor. You must provide a Customer Support case number (call the phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for the return procedure.

# **Documentation Feedback**

Your comments will help us serve your documentation needs better. If you have any suggestions on how to improve this document, complete this form, publication <u>RA-DU002</u>, available at <a href="http://www.rockwellautomation.com/literature/">http://www.rockwellautomation.com/literature/</a>.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat: 634752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

### www.rockwellautomation.com

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444 Europe/Middle East/Africa: Rockwell Automation NV, Pegasus Park, De Kleetlaan 12a, 1831 Diegem, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640 Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846





# Compact 32-point 24V dc Sink/Source Input Module

# Catalog Number 1769-IQ32

Use this document as a guide when installing a Compact  $^{\text{TM}}$  32-point 24V dc sink/source input module.

Topic	Page
Important User Information	2
Module Description	3
Module Installation	4
System Assembly	5
Mounting Expansion I/O	6
Replacing a Single Module within a System	8
Field Wiring Connections	9
I/O Memory Mapping	12
Spare/Replacement Module Parts	12
Specifications	13
Hazardous Location Considerations	15
For More Information	16

### **Important User Information**

Because of the variety of uses for the products described in this publication, those responsible for the application and use of these products must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards. In no event will Rockwell Automation be responsible or liable for indirect or consequential damage resulting from the use or application of these products.

Any illustrations, charts, sample programs, and layout examples shown in this publication are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Rockwell Automation does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation and Maintenance of Solid-State Control* (available from your local Rockwell Automation office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this publication, notes may be used to make you aware of safety considerations. The following annotations and their accompanying statements help you to identify a potential hazard, avoid a potential hazard, and recognize the consequences of a potential hazard:

# WARNING

Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.




Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss.



Identifies information that is critical for successful application and understanding of the product.

# **Module Description**



Item	Description
1	bus lever (with locking function)
2a	upper panel mounting tab
2b	lower panel mounting tab
3	I/O diagnostic LEDs
4	module door with terminal identification label
5a	movable bus connector with female pins
5b	stationary bus connector with male pins
6	nameplate label
7a	upper tongue-and-groove slots
7b	lower tongue-and-groove slots
8a	upper DIN rail latch
8b	lower DIN rail latch
9	write-on label (user ID tag)
10	removable terminal block (RTB) with finger-safe cover
10a	RTB upper retaining screw
10b	RTB lower retaining screw

### **Module Installation**

Compact I/O is suitable for use in an industrial environment when installed in accordance with these instructions. Specifically, this equipment is intended for use in clean, dry environments (Pollution degree  $2^{(1)}$ ) and to circuits not exceeding Over Voltage Category II<sup>(2)</sup> (IEC 60664-1).<sup>(3)</sup>

### **Prevent Electrostatic Discharge**



Electrostatic discharge can damage integrated circuits or semiconductors if you touch bus connector pins. Follow these guidelines when you handle the module:

- Touch a grounded object to discharge static potential.
- Wear an approved wrist-strap grounding device.
- Do not touch the bus connector or connector pins.
- Do not touch circuit components inside the module.
- If available, use a static-safe work station.
- When not in use, keep the module in its static-shield box.

### **Remove Power**



Remove power before removing or inserting this module. When you remove or insert a module with power applied, an electrical arc may occur. An electrical arc can cause personal injury or property damage by:

- sending an erroneous signal to your system's field devices, causing unintended machine motion
- causing an explosion in a hazardous environment
   Electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance.

<sup>(1)</sup> Pollution Degree 2 is an environment where, normally, only non-conductive pollution occurs except that occasionally a temporary conductivity caused by condensation shall be expected.


Over Voltage Category II is the load level section of the electrical distribution system. At this level transient voltages are controlled and do not exceed the impulse voltage capability of the product's insulation.

<sup>(3)</sup> Pollution Degree 2 and Over Voltage Category II are International Electrotechnical Commission (IEC) designations.

# System Assembly

The module can be attached to the controller or an adjacent I/O module *before* or *after* mounting. For mounting instructions, see Panel Mounting on page 6, or DIN Rail Mounting on page 8. To work with a system that is already mounted, see Replacing a Single Module within a System on page 8.

The following procedure shows you how to assemble the Compact I/O system.



- 1. Disconnect power.
- Check that the bus lever of the module to be installed is in the unlocked (fully right) position.
- **3.** Use the upper and lower tongue-and-groove slots (1) to secure the modules together (or to a controller).
- **4.** Move the module back along the tongue-and-groove slots until the bus connectors (2) line up with each other.
- **5.** Push the bus lever back slightly to clear the positioning tab (3). Use your fingers or a small screw driver.
- **6.** To allow communication between the controller and module, move the bus lever fully to the left (4) until it clicks. Ensure it is locked firmly in place.



When attaching I/O modules, it is very important that the bus connectors are securely locked together to ensure proper electrical connection.

- **7.** Attach an end cap terminator (5) to the last module in the system by using the tongue-and-groove slots as before.
- **8.** Lock the end cap bus terminator (6).



A 1769-ECR or 1769-ECL right or left end cap must be used to terminate the end of the serial communication bus.


# Mounting Expansion I/O



During panel or DIN rail mounting of all devices, be sure that all debris (metal chips, wire strands, etc.) is kept from falling into the module. Debris that falls into the module could cause damage on power up.

### **Minimum Spacing**


Maintain spacing from enclosure walls, wireways, adjacent equipment, etc. Allow 50 mm (2 in.) of space on all sides for adequate ventilation, as shown:



# **Panel Mounting**

Mount the module to a panel using two screws per module. Use M4 or #8 panhead screws. Mounting screws are required on every module.

### Panel Mounting Using the Dimensional Template



Locate holes every 17.5 mm (0.689 in.) to allow for a mix of single-wide and one-and-a-half-wide modules (e.g., 1769-OA16).

### Panel Mounting Procedure Using Modules as a Template

This procedure lets you use the assembled modules as a template for drilling holes in the panel. If you have sophisticated panel mounting equipment, you can use the dimensional template provided on page 7. Due to module mounting hole tolerance, it is important to follow these procedures:

- 1. On a clean work surface, assemble no more than three modules.
- **2.** Using the assembled modules as a template, carefully mark the center of all module-mounting holes on the panel.
- **3.** Return the assembled modules to the clean work surface, including any previously mounted modules.
- **4.** Drill and tap the mounting holes for the recommended M4 or #8 screw.
- 5. Place the modules back on the panel, and check for proper hole alignment.
- **6.** Attach the modules to the panel using the mounting screws.

**NOTE:** If mounting more modules, mount only the last one of this group and put the others aside. This reduces remounting time during drilling and tapping of the next group.

7. Repeat steps 1 to 6 for any remaining modules.

### **DIN Rail Mounting**

The module can be mounted using these DIN rails:  $35 \times 7.5 \text{ mm}$  (EN 50 022 -  $35 \times 7.5 \text{$ 

Before mounting the module on a DIN rail, close the DIN rail latches. Press the DIN rail mounting area of the module against the DIN rail. The latches will momentarily open and lock into place.

# Replacing a Single Module within a System

The module can be replaced while the system is mounted to a panel (or DIN rail).

- **1.** Remove power. See important note on page 4.
- 2. On the module to be removed, remove the upper and lower mounting screws from the module (or open the DIN latches using a flat-blade or phillips style screw driver).
- 3. Move the bus lever to the right to disconnect (unlock) the bus.
- **4.** On the right-side adjacent module, move its bus lever to the right (unlock) to disconnect it from the module to be removed.
- **5.** Gently slide the disconnected module forward. If you feel excessive resistance, check that the module has been disconnected from the bus, and that both mounting screws have been removed (or DIN latches opened).

**NOTE:** It may be necessary to rock the module slightly from front to back to remove it, or, in a panel-mounted system, to loosen the screws of adjacent modules.

- 6. Before installing the replacement module, be sure that the bus lever on the module to be installed, and on the right-side adjacent module are in the unlocked (fully right) position.
- 7. Slide the replacement module into the open slot.

- **8.** Connect the modules together by locking (fully left) the bus levers on the replacement module and the right-side adjacent module.
- **9.** Replace the mounting screws (or snap the module onto the DIN rail).

# **Field Wiring Connections**

### **Grounding the Module**

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel. Additional grounding connections from the module's mounting tabs or DIN rail (if used), are not required unless the mounting surface cannot be grounded. Refer to *Industrial Automation Wiring and Grounding Guidelines*, Allen-Bradley publication 1770-4.1, for additional information.


### **Input Wiring**

Basic wiring of input devices<sup>(1)</sup> to the 1769-IQ32 is shown below.



- Miswiring of the module to an AC power source will damage the module.
- Be careful when stripping wires. Wire fragments that fall into a module could cause damage at power up. Once wiring is complete, ensure the module is free of all metal fragments.

<sup>(1)</sup> Sinking/Sourcing Inputs - Sourcing/sinking describes the current flow between the I/O module and the field device. Sourcing I/O circuits supply (source) current to sinking field devices. Sinking I/O circuits are driven by a current sourcing field device. Field devices connected to the negative side (DC Common) of the field power supply are sinking field devices. Field devices connected to the positive side (+V) of the field supply are sourcing field devices. Europe: DC sinking input and sourcing output module circuits are the commonly used options.



A removable write-on label is included with the module. Remove the label from the door, mark the identification of each terminal with permanent ink, and slide the label back into the door. Your markings (ID tag) will be visible when the module door is closed.




### **Removing the Finger-safe Terminal Block**

When wiring field devices to the module, it is not necessary to remove the terminal block. If you remove the terminal block, use the write-on label on the side of the terminal block to identify the module slot leation and type. RTB position can be indicated by circling either the 'R' for right side or 'L' for left side.

To remove the terminal block, loosen the upper and lower retaining screws. The terminal block will back away from the module as you remove the screws. When replacing the terminal block, torque the retaining screws to 0.46 Nm (4.1 in-lbs).

### Wiring the Finger-safe Terminal Block



When wiring the terminal block, keep the finger-safe cover in place.

- **1.** Loosen the terminal screws to be wired
- 2. Route the wire under the terminal pressure plate. You can use the bare wire or a spade lug. The terminals will accept a 6.35 mm (0.25 in.) spade lug.

**NOTE:** The terminal screws are non-captive. Therefore, it is possible to use a ring lug [max. 1/4" o.d. with a 0.139" minimum i.d. (M3.5)] with the module.

**3.** Tighten the terminal screw making sure the pressure plate secures the wire. Recommended torque when tightening terminal screws is 0.68 Nm (6 in-lbs).

**NOTE:** If you need to remove the finger-safe cover, insert a screw driver into one of the square, wiring holes and gently pry the cover off. If you wire the terminal block with the finger-safe cover removed, you will not be able to put it back on the terminal block because the wires will be in the way.

## **Wire Size and Terminal Screw Torque**

Each terminal accepts as many as two wires with these restrictions:

Wire Type		Wire Size	Terminal Screw Torque	Retaining Screw Torque	
Solid	Cu-90°C (194°F)	#14 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)	
Stranded	Cu-90°C (194°F)	#16 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)	

# I/O Memory Mapping

### **Input Data File**

For each input module, slot x, word 0 in the input data file contains the current state of the field input points.

ord	Bit Position															
Š	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r
1	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r

r=read

# **Spare/Replacement Module Parts**

• Terminal Block: 1769-RTBN18 (1 per kit)

# **Specifications**

# **General Specifications**

Specification	Value			
Dimensions	118 mm (height) x 87 mm (depth) x 52.5 mm (width) height including mounting tabs is 138 mm 4.65 in. (height) x 3.43 in (depth) x 2.07 in (width) height including mounting tabs is 5.43 in.			
Approximate Shipping Weight (with carton)	440g (0.97 lbs.)			
Storage Temperature	-40°C to +85°C (-40°F to +185°F)			
Operating Temperature	0°C to +60°C (32°F to +140°F)			
Operating Humidity	5% to 95% non-condensing			
Operating Altitude	2000 meters (6561 feet)			
Vibration	Operating: 10 to 500 Hz, 5G, 0.030 inches maximum peak-to-peak Relay Operation: 2G			
Shock	Operating: 30G panel mounted (20G DIN rail mounted) Relay Operation: 7.5G panel mounted (5G DIN rail mounted) Non-Operating: 40G panel mounted (30G DIN rail mounted)			
Agency Certification	<ul> <li>C-UL certified (under CSA C22.2 No. 142)</li> <li>UL 508 listed</li> <li>CE compliant for all applicable directives</li> </ul>			
Hazardous Environment Class	Class I, Division 2, Hazardous Location, Groups A, B, C, D (UL 1604, C-UL under CSA C22.2 No. 213)			
Radiated and Conducted Emissions	EN50081-2 Class A			
Electrical /EMC:	The module has passed testing at the following levels:			
ESD Immunity (IEC1000-4-2)	4kV contact, 8 kV air, 4 kV indirect			
Radiated Immunity (IEC1000-4-3)	10 V/m, 80 to 1000 MHz, 80% amplitude modulation, +900 MHz keyed carrier			
Fast Transient Burst (IEC1000-4-4)	2 kV, 5 kHz			
Surge Immunity (IEC1000-4-5)	2 kV common mode, 1 kV differential mode			
Conducted Immunity (IEC1000-4-6)	10V, 0.15 to 80 MHz <sup>(1)</sup>			

<sup>(1)</sup> Conducted Immunity frequency range may be 150 kHz to 30 MHz if the Radiated Immunity frequency range is 30 MHz to 1000 MHz.

### **Input Specifications**

Specification	1769-IQ32
Voltage Category	24V dc (sink/source <sup>(1)</sup> )
Operating Voltage Range	10 to 30V dc at 30°C (86°F)
	10 to 26.4V dc at 60°C (140°F)
Number of Inputs	32
Bus Current Draw (max.)	170 mA at 5V dc (0.85W)
Heat Dissipation	4.6 Total Watts (The Watts per point, plus the minimum Watts, with all points energized.)
Signal Delay (max.)	On Delay: 8.0 ms Off Delay: 8.0 ms
Off-State Voltage (max.)	5V dc
Off-State Current (max.)	1.5 mA
On-State Voltage (min.)	10V dc
On-State Current (min.)	2.0 mA
Inrush Current (max.)	250 mA
Nominal Impedance	5.2kohm at 24V dc, 6.1kohm at 30V dc
IEC Input Compatibility	Type 1+
Power Supply Distance Rating	8 (The module may not be more than 8 modules away from the power supply or controller.)
Input Point to Bus (Compact Bus)	Verified by one of the following dielectric tests: 1200V ac for 1 sec. or
Isolation	1697V dc for 1 sec.
	75V dc working voltage (IEC Class 2 reinforced insulation)
Isolated Groups	Group 1: inputs 0 to 7
	Group 2: inputs 8 to 15 Group 3: inputs 16 to 23
	Group 4: inputs 16 to 25
	Isolated groups operate in either sink or source configurations.
Input Group to Input Group Isolation	Verified by one of the following dielectric tests: 1200V ac for 1 sec. or
	1697V dc for 1 sec.
	75V dc working voltage (IEC Class 2 reinforced insulation)
Vendor I.D. Code	1
Product Type Code	7
Product Code	68

<sup>(1)</sup> Sinking/Sourcing Inputs - Sourcing/sinking describes the current flow between the I/O module and the field device. Sourcing I/O circuits supply (source) current to sinking field devices. Sinking I/O circuits are driven by a current sourcing field device. Field devices connected to the negative side (DC Common) of the field power supply are sinking field devices. Field devices connected to the positive side (+V) of the field supply are sourcing field devices. Europe: DC sinking input and sourcing output module circuits are the commonly used options.

### **Hazardous Location Considerations**

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only. The following WARNING statement applies to use in hazardous locations.

# WARNING

### EXPLOSION HAZARD

- Substitution of components may impair suitability for Class I, Division 2.
- Do not replace components or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- Do not connect or disconnect components unless power has been switched off or the area is known to be non-hazardous.
- This product must be installed in an enclosure.
- All wiring must comply with N.E.C. article 501-4(b).

# **Environnements dangereux**

Cet équipement est conçu pour être utilisé dans des environnements de Classe 1, Division 2, Groupes A, B, C, D ou non dangereux. La mise en garde suivante s'applique à une utilisation dans des environnements dangereux.





### DANGER D'EXPLOSION

- La substitution de composants peut rendre cet équipement impropre à une utilisation en environnement de Classe 1, Division 2.
- Ne pas remplacer de composants ou déconnecter l'équipement sans s'être assuré que l'alimentation est coupée et que l'environnement est classé non dangereux.
- Ne pas connecter ou déconnecter des composants sans s'être assuré que l'alimentation est coupée ou que l'environnement est classé non dangereux.
- Ce produit doit être installé dans une armoire.

### For More Information

For	Refer to this Document	Pub. No.
A more detailed description of how to install and use your Compact I/O with MicroLogix 1200 & 1500 programmable controller.	MicroLogix 1200 and MicroLogix 1500 Programmable Controllers User Manual	1764-RM001B-US-P
A more detailed description of how to install and use your Compact I/O with the 1769-ADN DeviceNet Adapter.	1769-ADN DeviceNet Adapter User Manual	1769-UM001A-US-P
A more detailed description of how to install and use your Compact I/O with the CompactLogix <sup>™</sup> System.	CompactLogix System User Manual	1769-UM007C-EN-P
More information on proper wiring and grounding techniques.	Industrial Automation Wiring and Grounding Guidelines	1770-4.1

### If you would like a manual, you can:

- download a free electronic version from the internet: www.ab.com/micrologix or www.theautomationbookstore.com
- purchase a printed manual by:
  - contacting your local distributor or Rockwell Automation representative
  - visiting www.theautomationbookstore.com and placing your order
  - calling 1.800.9NEWLIT(800.963.9548) (USA/Canada) or 001.330.725.1574 (Outside USA/Canada)

Compact and MicroLogix are trademarks of Rockwell Automation.

#### www.rockwellautomation.com

#### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444
Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640
Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1769-IN032A-EN-P - April 2003

PN 40071-154-01(1)

Copyright © 2003 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.








# Compact<sup>™</sup> 24V dc Sink/Source Input Module

(Catalog Number 1769-IQ16)

Installation Instructions

### Inside

# **Module Description**



Item	Description
1	
2a	
2b	
3	
4	
5a	
5b	
6	
7a	
7b	
8a	
8b	
9	
10	
10a	
10b	

### Module Installation

Compact I/O is suitable for use in an industrial environment when installed in accordance with these instructions. Specifically, this equipment is intended for use in clean, dry environments (Pollution degree 2<sup>1</sup>) and to circuits not exceeding Over Voltage Category II<sup>2</sup> (IEC 60664-1).<sup>3</sup>

### **Prevent Electrostatic Discharge**



**ATTENTION:** Electrostatic discharge can damage integrated circuits or semiconductors if you touch bus connector pins. Follow these guidelines when you handle the module:

- Touch a grounded object to discharge static potential.
- Wear an approved wrist-strap grounding device.
- Do not touch the bus connector or connector pins.
- Do not touch circuit components inside the module.
- If available, use a static-safe work station.
- When not in use, keep the module in its static-shield box.

### Remove Power



**ATTENTION:** Remove power before removing or inserting this module. When you remove or insert a module with power applied, an electrical arc may occur. An electrical arc can cause personal injury or property damage by:


- sending an erroneous signal to your system's field devices, causing unintended machine motion
- causing an explosion in a hazardous environment

Electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance.

### System Assembly

The module can be attached to the controller or an adjacent I/O module *before* or *after* mounting. For mounting instructions, see "Panel Mounting" on page 5, or "DIN Rail Mounting" on page 6. To work with a system that is already mounted, see "Replacing a Single Module within a System" on page 7.

The following procedure shows you how to assemble the Compact I/O system.



- Disconnect power.
- 2. Check that the bus lever of the module to be installed is in the unlocked (fully right) position.
- 3. Use the upper and lower tongue-and-groove slots (1) to secure the modules together (or to a controller).
- 4. Move the module back along the tongue-and-groove slots until the bus connectors (2) line up with each other.
- 5. Push the bus lever back slightly to clear the positioning tab (3). Use your fingers or a small screw driver.
- 6. To allow communication between the controller and module, move the bus lever fully to the left (4) until it clicks. Ensure it is locked firmly in place.



**ATTENTION:** When attaching I/O modules, it is very important that the bus connectors are securely locked together to ensure proper electrical connection.

- 7. Attach an end cap terminator (5) to the last module in the system by using the tongue-and-groove slots as before.
- 8. Lock the end cap bus terminator (6).

**IMPORTANT:** A 1769-ECR or 1769-ECL right or left end cap must be used to terminate the end of the serial communication bus.


## Mounting Expansion I/O



**ATTENTION:** During panel or DIN rail mounting of all devices, be sure that all debris (metal chips, wire strands, etc.) is kept from falling into the module. Debris that falls into the module could cause damage on power up.

### Minimum Spacing


Maintain spacing from enclosure walls, wireways, adjacent equipment, etc. Allow 50 mm (2 in.) of space on all sides for adequate ventilation, as shown:



### **Panel Mounting**

Mount the module to a panel using two screws per module. Use M4 or #8 panhead screws. Mounting screws are required on every module.

### Panel Mounting Using the Dimensional Template



±0.4 mm (0.016 in.)

### Panel Mounting Procedure Using Modules as a Template

The following procedure allows you to use the assembled modules as a template for drilling holes in the panel. If you have sophisticated panel mounting equipment, you can use the dimensional template provided on page 5. Due to module mounting hole tolerance, it is important to follow these procedures:

- 1. On a clean work surface, assemble no more than three modules.
- 2. Using the assembled modules as a template, carefully mark the center of all module-mounting holes on the panel.
- 3. Return the assembled modules to the clean work surface, including any previously mounted modules.
- 4. Drill and tap the mounting holes for the recommended M4 or #8 screw.
- 5. Place the modules back on the panel, and check for proper hole alignment.
- 6. Attach the modules to the panel using the mounting screws.
  - **Note:** If mounting more modules, mount only the last one of this group and put the others aside. This reduces remounting time during drilling and tapping of the next group.
- 7. Repeat steps 1 to 6 for any remaining modules.

### DIN Rail Mounting

The module can be mounted using the following DIN rails:  $35 \times 7.5 \text{ mm}$  (EN 50 022 -  $35 \times 7.5$ ) or  $35 \times 15 \text{ mm}$  (EN 50 022 -  $35 \times 15$ ).

Before mounting the module on a DIN rail, close the DIN rail latches. Press the DIN rail mounting area of the module against the DIN rail. The latches will momentarily open and lock into place.

### Replacing a Single Module within a System

The module can be replaced while the system is mounted to a panel (or DIN rail).

- 1. Remove power. See important note on page 3.
- 2. On the module to be removed, remove the upper and lower mounting screws from the module (or open the DIN latches using a flat-blade or phillips style screw driver).
- 3. Move the bus lever to the right to disconnect (unlock) the bus.
- 4. On the right-side adjacent module, move its bus lever to the right (unlock) to disconnect it from the module to be removed.
- 5. Gently slide the disconnected module forward. If you feel excessive resistance, check that the module has been disconnected from the bus, and that both mounting screws have been removed (or DIN latches opened).
  - **Note:** It may be necessary to rock the module slightly from front to back to remove it, or, in a panel-mounted system, to loosen the screws of adjacent modules.
- 6. Before installing the replacement module, be sure that the bus lever on the module to be installed, and on the right-side adjacent module are in the unlocked (fully right) position.
- 7. Slide the replacement module into the open slot.
- 8. Connect the modules together by locking (fully left) the bus levers on the replacement module and the right-side adjacent module.
- 9. Replace the mounting screws (or snap the module onto the DIN rail).

## **Field Wiring Connections**

### **Grounding the Module**

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel. Additional grounding connections from the module's mounting tabs or DIN rail (if used), are not required unless the mounting surface cannot be grounded. Refer to *Industrial Automation Wiring and Grounding Guidelines*, Allen-Bradley publication 1770-4.1, for additional information.


### **Input Wiring**

Basic wiring of input devices<sup>1</sup> to the 1769-IQ16 is shown below.




### ATTENTION:

- Miswiring of the module to an AC power source will damage the module.
- Be careful when stripping wires. Wire fragments that fall into a module could cause damage at power up. Once wiring is complete, ensure the module is free of all metal fragments.



A removable, write-on label is provided with the module. Remove the label from the door, mark the identification of each terminal with permanent ink, and slide the label back into the door. Your markings (ID tag) will be visible when the module door is closed.



### Removing the Finger-Safe Terminal Block

To remove the terminal block, loosen the upper and lower retaining screws. The terminal block will back away from the module as you remove the screws. When replacing the terminal block, torque the retaining screws to 0.46 Nm (4.1 in-lbs).

### Wiring the Finger-Safe Terminal Block

When wiring the terminal block, keep the finger-safe cover in place.

- 1. Loosen the terminal screws to be wired.
- 2. Route the wire under the terminal pressure plate. You can use the bare wire or a spade lug. The terminals will accept a 6.35 mm (0.25 in.) spade lug.

**Note:** The terminal screws are non-captive. Therefore, it is possible to use a ring lug [max. 1/4" o.d. with a 0.139" minimum i.d. (M3.5)] with the module.

3. Tighten the terminal screw making sure the pressure plate secures the wire. Recommended torque when tightening terminal screws is 0.68 Nm (6 inlbs).

**Note:** If you need to remove the finger-safe cover, insert a screw driver into one of the square, wiring holes and gently pry the cover off. If you wire the terminal block with the finger-safe cover removed, you will not be able to put it back on the terminal block because the wires will be in the way.

## Wire Size and Terminal Screw Torque

Each terminal accepts up to two wires with the following restrictions:

Wire Type		Wire Size	Terminal Screw Torque	Retaining Screw Torque		
	Cu-90°C (194°F)	#14 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)		
	Cu-90°C (194°F)	#16 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)		

# I/O Memory Mapping

### **Input Data File**

For each input module, slot x, word 0 in the input data file contains the current state of the field input points.

p	Bit Position															
Word	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0																

# **Spare/Replacement Module Parts**

Terminal Block: 1769-RTBN18 (1 per kit)
 Door Label: 1769-RL1 (2 per kit)
 Door: 1769-RD (2 per kit)

# **Specifications**

# **General Specifications**

Specification	Value
	2000
	0
	2000
Electrical /EMC:	The module has passed testing at the following levels:
□ □□□ □□□□□□□1000□I2□	
0000000	

### **Input Specifications**

Specification	1769-IQ16
	2
	10
	10 112 1110 1110 1110 1110
	10
	110000000000000
	3 IIII IIIIII (The Watts per point, plus the minimum Watts, with all points energized.)
	1000
	10 🗆
	210 🗆
	2.0
	3□Ω
	IIII 1 0

### **Hazardous Location Considerations**

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only. The following ATTENTION statement applies to use in hazardous locations.



### **ATTENTION: EXPLOSION HAZARD**

- Substitution of components may impair suitability for Class I, Division 2.
- Do not replace components or disconnect equipment unless power has been switched off or the area is known to be nonhazardous.
- Do not connect or disconnect components unless power has been switched off or the area is known to be non-hazardous.
- This product must be installed in an enclosure.
- All wiring must comply with N.E.C. article 501-4(b).

### **Environnements dangereux**

Cet équipement est conçu pour être utilisé dans des environnements de Classe 1, Division 2, Groupes A, B, C, D ou non dangereux. La mise en garde suivante s'applique à une utilisation dans des environnements dangereux.



### **ATTENTION: DANGER D'EXPLOSION**

- La substitution de composants peut rendre cet équipement impropre à une utilisation en environnement de Classe 1, Division 2.
- Ne pas remplacer de composants ou déconnecter l'équipement sans s'être assuré que l'alimentation est coupée et que l'environnement est classé non dangereux.
- Ne pas connecter ou déconnecter des composants sans s'être assuré que l'alimentation est coupée ou que l'environnement est classé non dangereux.
- Ce produit doit être installé dans une armoire.

### For More Information

For	Refer to this Document	Pub. No.
	MicroLogix 1200 and MicroLogix 1500 Programmable Controllers User Manual	1764-RM001B-US-P
	1769-ADN DeviceNet Adapter User Manual	1001
	Industrial Automation Wiring and Grounding Guidelines	1770-4.1

### If you would like a manual, you can:

- download a free electronic version from the internet:
   www.ab.com/micrologix or www.theautomationbookstore.com
- purchase a printed manual by:
  - contacting your local distributor or Rockwell Automation representative
  - visiting www.theautomationbookstore.com and placing your order
  - calling 1.800.9NEWLIT(800.963.9548) (USA/Canada) or 001.330.725.1574 (Outside USA/Canada)

Compact and MicroLogix are trademarks of Rockwell Automation.

### Reach us now at www.rockwellautomation.com

Wherever you need us, Rockwell Automation brings together leading brands in industrial automation including Allen-Bradley controls, Reliance Electric power transmission products, Dodge mechanical power transmission components, and Rockwell Software. Rockwell Automation's unique, flexible approach to helping customers achieve a competitive advantage is supported by thousands of authorized partners, distributors and system integrators around the world.



Americas Headquarters, 1201 South Second Street, Milwaukee, WI 52204, USA, Tel. (1) 414 382-2006, Fax: (1) 414 382

Rockwell Automation

PN 40071-097-01(B)

Publication 1769-IN007B-EN-P - June 2000

Supercedes 1769-IN007A-EN-P - April 2000 & 1769-5.3 - January 1999

© 2000 Rockwell International Corporation. All rights reserved. Printed in the U.S.A.







# Compact<sup>™</sup> 16-Point AC/DC Relay Output Module


(Catalog Number 1769-0W16)

### Inside

Module Description	2
Module Installation	
System Assembly	
Mounting Expansion I/O	
Replacing a Single Module within a System	7
Field Wiring Connections	
/O Memory Mapping	. 11
1769-0W16 Configuration File	. 12
Spare/Replacement Module Parts	. 13
Specifications	. 14
Hazardous Location Considerations	. 17
Environnements dangereux	. 17
For More Information	1.9

# **Module Description**

The 1769-OW16 is a 16 point relay output module that can control AC or DC loads. The module has 2 isolated groups of 8 points each. This allows you to mix both AC and DC loads on one module.



ltem	Description			
1	bus lever (with locking function)			
2a	upper panel mounting tab			
2b	lower panel mounting tab			
3	I/O diagnostic LEDs (Logic Side)			
4	module door with terminal identification label			
5a	movable bus connector with female pins			
5b stationary bus connector with male pins				
6	nameplate label			
7a	upper tongue-and-groove slots			
7b	lower tongue-and-groove slots			
8a	upper DIN rail latch			
8b	lower DIN rail latch			
9	write-on label (user ID tag)			
10	removable terminal block (RTB) with finger-safe cover			
10a	RTB upper retaining screw			
10b	RTB lower retaining screw			

## Module Installation

Compact I/O is suitable for use in an industrial environment when installed in accordance with these instructions. Specifically, this equipment is intended for use in clean, dry environments (Pollution degree  $2^{(1)}$ ) and to circuits not exceeding Over Voltage Category II<sup>(2)</sup> (IEC 60664-1).<sup>(3)</sup>

## **Prevent Electrostatic Discharge**

#### **ATTENTION**



Electrostatic discharge can damage integrated circuits or semiconductors if you touch bus connector pins. Follow these guidelines when you handle the module:

- Touch a grounded object to discharge static potential.
- Wear an approved wrist-strap grounding device.
- Do not touch the bus connector or connector pins.
- Do not touch circuit components inside the module.
- If available, use a static-safe work station.
- When not in use, keep the module in its static-shield box.

#### Remove Power

## ATTENTION



Remove power before removing or inserting this module. When you remove or insert a module with power applied, an electrical arc may occur. An electrical arc can cause personal injury or property damage by:

- sending an erroneous signal to your system's field devices, causing unintended machine motion
- causing an explosion in a hazardous environment

Electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance.

<sup>(1)</sup> Pollution Degree 2 is an environment where, normally, only non-conductive pollution occurs except that occasionally a temporary conductivity caused by condensation shall be expected.


<sup>(2)</sup> Over Voltage Category II is the load level section of the electrical distribution system. At this level transient voltages are controlled and do not exceed the impulse voltage capability of the product's insulation.

<sup>(3)</sup> Pollution Degree 2 and Over Voltage Category II are International Electrotechnical Commission (IEC) designations.

# System Assembly

The module can be attached to the controller or an adjacent I/O module *before* or *after* mounting. For mounting instructions, see "Panel Mounting" on page 5, or "DIN Rail Mounting" on page 7. To work with a system that is already mounted, see "Replacing a Single Module within a System" on page 7.

The following procedure shows you how to assemble the Compact I/O system.



- 1. Disconnect power.
- **2.** Check that the bus lever of the module to be installed is in the unlocked (fully right) position.
- **3.** Use the upper and lower tongue-and-groove slots (1) to secure the modules together (or to a controller).
- **4.** Move the module back along the tongue-and-groove slots until the bus connectors (2) line up with each other.
- **5.** Push the bus lever back slightly to clear the positioning tab (3). Use your fingers or a small screw driver.
- **6.** To allow communication between the controller and module, move the bus lever fully to the left (4) until it clicks. Ensure it is locked firmly in place.



When attaching I/O modules, it is very important that the bus connectors are securely locked together to ensure proper electrical connection.

- **7.** Attach an end cap terminator (5) to the last module in the system by using the tongue-and-groove slots as before.
- **8.** Lock the end cap bus terminator (6).

IMPORTANT

A 1769-ECR or 1769-ECL right or left end cap must be used to terminate the end of the serial communication bus

# **Mounting Expansion I/O**


# ATTENTION



During panel or DIN rail mounting of all devices, be sure that all debris (metal chips, wire strands, etc.) is kept from falling into the module. Debris that falls into the module could cause damage on power up.

# **Minimum Spacing**


Maintain spacing from enclosure walls, wireways, adjacent equipment, etc. Allow 50 mm (2 in.) of space on all sides for adequate ventilation, as shown:



# **Panel Mounting**

Mount the module to a panel using two screws per module. Use M4 or #8 panhead screws. Mounting screws are required on every module.

#### Panel Mounting Using the Dimensional Template



Locate holes every 17.5 mm (0.689 in.) to allow for a mix of single-wide and one-and-a-half-wide modules (e.g. 1769-OA16).

#### Panel Mounting Procedure Using Modules as a Template

The following procedure allows you to use the assembled modules as a template for drilling holes in the panel. If you have sophisticated panel mounting equipment, you can use the dimensional template provided on page 6. Due to module mounting hole tolerance, it is important to follow these procedures:

- 1. On a clean work surface, assemble no more than three modules.
- 2. Using the assembled modules as a template, carefully mark the center of all module-mounting holes on the panel.
- **3.** Return the assembled modules to the clean work surface, including any previously mounted modules.
- **4.** Drill and tap the mounting holes for the recommended M4 or #8 screw.
- **5.** Place the modules back on the panel, and check for proper hole alignment.
- **6.** Attach the modules to the panel using the mounting screws.



If mounting more modules, mount only the last one of this group and put the others aside. This reduces remounting time during drilling and tapping of the next group.

**7.** Repeat steps 1 to 6 for any remaining modules.

## **DIN Rail Mounting**

The module can be mounted using the following DIN rails:  $35 \times 7.5$  mm (EN 50 022 -  $35 \times 7.5$ ) or  $35 \times 15$  mm (EN 50 022 -  $35 \times 15$ ).

Before mounting the module on a DIN rail, close the DIN rail latches. Press the DIN rail mounting area of the module against the DIN rail. The latches will momentarily open and lock into place.

# Replacing a Single Module within a System

The module can be replaced while the system is mounted to a panel (or DIN rail).

- 1. Remove power. See attention note on page 3.
- 2. On the module to be removed, remove the upper and lower mounting screws from the module (or open the DIN latches using a flat-blade or phillips style screw driver).
- 3. Move the bus lever to the right to disconnect (unlock) the bus.
- **4.** On the right-side adjacent module, move its bus lever to the right (unlock) to disconnect it from the module to be removed.
- **5.** Gently slide the disconnected module forward. If you feel excessive resistance, check that the module has been disconnected from the bus, and that both mounting screws have been removed (or DIN latches opened).



It may be necessary to rock the module slightly from front to back to remove it, or, in a panel-mounted system, to loosen the screws of adjacent modules.

- **6.** Before installing the replacement module, be sure that the bus lever on the module to be installed, and on the right-side adjacent module are in the unlocked (fully right) position.
- 7. Slide the replacement module into the open slot.
- **8.** Connect the modules together by locking (fully left) the bus levers on the replacement module and the right-side adjacent module.
- 9. Replace the mounting screws (or snap the module onto the DIN rail).

# **Field Wiring Connections**

## **Grounding the Module**

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel. Additional grounding connections from the module's mounting tabs or DIN rail (if used), are not required unless the mounting surface cannot be grounded. Refer to *Industrial Automation Wiring and Grounding Guidelines*, Allen-Bradley publication 1770-4.1, for additional information. \


## **Output Wiring**

Basic wiring<sup>(1)</sup> of output devices to the 1769-OW16 is shown below.





Be careful when stripping wires. Wire fragments that fall into a module could cause damage at power up. Once wiring is complete, ensure the module is free of all metal fragments.



 Surge Suppression - Connecting surge suppressors across your external inductive load will extend the life of the relay contacts. For additional details, refer to *Industrial Automation Wiring and Grounding Guidelines*, Allen-Bradley publication 1770-4.1. A removable, write-on label, (see page 2, item 9) is provided with the module. Remove the label from the door, mark the identification of each terminal with permanent ink, and slide the label back into the door. Your markings (ID tag) will be visible when the module door is closed.


## **Removing the Finger-Safe Terminal Block**

When wiring field devices to the module, it is not necessary to remove the terminal block. If you remove the terminal block, use the write-on label on the side of the terminal block to identify the module slot location and type.



To remove the terminal block, loosen the upper and lower retaining screws. The terminal block will back away from the module as you remove the screws. When replacing the terminal block, torque the retaining screws to 0.46 Nm (4.1 in-lbs).

# Wiring the Finger-Safe Terminal Block



When wiring the terminal block, keep the finger-safe cover in place.

1. Loosen the terminal screws to be wired.

2. Route the wire under the terminal pressure plate. You can use the bare wire or a spade lug. The terminals will accept a 6.35 mm (0.25 in.) spade lug.




The terminal screws are non-captive. Therefore, it is possible to use a ring lug [maximum 1/4 inch o.d. with a 0.139 inch minimum i.d. (M3.5)] with the module.

**3.** Tighten the terminal screw making sure the pressure plate secures the wire. Recommended torque when tightening terminal screws is 0.68 Nm (6 in-lbs).



If you need to remove the finger-safe cover, insert a screw driver into one of the square, wiring holes and gently pry the cover off. If you wire the terminal block with the finger-safe cover removed, you will not be able to put it back on the terminal block because the wires will be in the way.

# **Simplified Output Circuit Diagram**



# Wire Size and Terminal Screw Torque

Each terminal accepts up to two wires with the following restrictions:

Wire Type		Wire Size	Terminal Screw Torque	Retaining Screw Torque		
Solid	Cu-90°C (194°F)	#14 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)		
Stranded	Cu-90°C (194°F)	#16 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)		

# I/O Memory Mapping

## **Output Data File**

Data output bits are turned on or off using the bit positions in Word 0.

1 = output on

0 = output off

Example: To turn on bit position 12, type 1 in Word 0, Bit 12.

For each module, slot x, word 0 in the output data file contains the control program's directed state of the discrete output points.

ord		Bit Position														
š	15	5 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0														
0	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W

w = write only

# **Output Module's Input Data File**

For each module, slot x, input data file word 0 contains the state of the module's output data (output data echo) file word 0. During normal operation, these input bits represent the logic state that the outputs are directed to by the control program. They are also dependent upon the:

- Program Mode configuration (if supported by the controller)
- The Fault Mode configuration (if supported by the controller).

ord		Bit Position														
Š	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r	r

r = read only

# **IMPORTANT**

The output module's input data file reflects the output data echo of the module, not necessarily the electrical state of the output terminals. It does not reflect shorted or open outputs.

It is important to use this input word if the controller adapter supports the Program Mode or Fault Mode function, and if it is configured to use them.

# 1769-OW16 Configuration File

The read/writable configuration data file allows the setup of the hold last state and user-defined safe state conditions.

The manipulation of the bits from this file is normally done with programming software (e.g. RSLogix 500, RSNetworx for DeviceNet, etc.) during initial configuration of the system. In that case, graphical screens are provided via the programmer to simplify configuration. However, some systems (e.g. 1769-ADN DeviceNet Adapter) also allow the bits to be altered as part of the control program using communication rungs. In that case, it is necessary to understand the bit arrangement.

Vord		Bit Position														
Š	15	5   14   13   12   11   10   9   8   7   6   5   4   3   2   1   0														
0	0	0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 PFE														
1		Program State for Output Array Word 0														
2		Program Value for Output Array Word 0														
3		Fault State for Output Array Word 0														
4						Fault	t Value	for Ou	tput A	rray Wo	ord O					

#### Program State Word

Word 1, the program state word, selects the hold last state or user-defined safe state condition for each individual output on a system transition from Run to Program.

Condition	Bit Setting
User-defined Safe State	0
Hold Last State	1

#### Program Value Word

The program value word, word 2, is used to program the user-defined safe state value (0=Off, 1=On). Each output is individually configurable for on or off.

Value	Bit Setting
Off	0
On	1

#### Fault State Word

Word 3, the fault state word, selects the hold last state or user-defined safe state condition for each individual output on a system transition from Run to Fault.

Condition	Bit Setting
User-defined Safe State	0
Hold Last State	1

#### Fault Value Word

The fault value word, word 4, is used to program the fault state value (0=Off, 1=On). Each output is individually configurable for on or off.

Value	Bit Setting
Off	0
On	1

### Program to Fault Enable Bit (PFE)

Word 0, bit 0, allows the selection of which data value, the program or fault value, to apply to the output if a system in Program mode undergoes a system fault, resulting in a change to the Fault mode

Value Applied	Bit Setting
Program	0
Fault	1

#### Module Default Condition

The modules default condition is all zeros, programming the conditions shown below.

Word or Bit Affecte	d	Condition Applied
Word 0, Bit 0:	Program-to-Fault Enable	Program Value
Word 1:	Program State	User-defined Safe State
Word 2:	Program Value	Off
Word 3:	Fault State	User-defined Safe State
Word 4:	Fault Value	Off

# **Spare/Replacement Module Parts**

• Terminal Block:1769-RTBN18 (1 per kit)

# **Specifications**

# **General Specifications**

Specification	Value
Dimensions	118 mm (height) x 87 mm (depth) x 52.5 mm (width) height including mounting tabs is 138 mm 4.65 in. (height) x 3.43 in (depth) x 2.07 in (width) height including mounting tabs is 5.43 in.
Approximate Shipping Weight (with carton)	450g (0.99 lbs.)
Storage Temperature	-40°C to +85°C (-40°F to +185°F)
Operating Temperature	0°C to +60°C (32°F to +140°F)
Operating Humidity	5% to 95% non-condensing
Operating Altitude	2000 meters (6561 feet) <sup>(1)</sup>
Vibration	Operating: 10 to 500 Hz, 5G, 0.030 inches maximum peak-to-peak Relay Operation: 2.0G
Shock	Operating: 30G panel mounted (20G DIN rail mounted) Relay Operation: 10G panel mounted (5G DIN rail mounted) Non-Operating: 40G panel mounted (30G DIN rail mounted)
Agency Certification	C-UL certified (under CSA C22.2 No. 142)     UL 508 listed     CE and C-Tick compliant for all applicable directives
Hazardous Environment Class	Class I, Division 2, Hazardous Location, Groups A, B, C, D (UL 1604, C-UL under CSA C22.2 No. 213)
Radiated and Conducted Emissions	EN50081-2 Class A
Electrical /EMC:	The module has passed testing at the following levels:
ESD Immunity (IEC61000-4-2)	4kV contact, 8 kV air, 4 kV indirect
Radiated Immunity (IEC61000-4-3)	10 V/m, 80 to 1000 MHz, 80% amplitude modulation, +900 MHz keyed carrier
Fast Transient Burst (IEC61000-4-4)	• 2 kV, 5 kHz
Surge Immunity (IEC61000-4-5)	2 kV common mode, 1 kV differential mode
Conducted Immunity (IEC61000-4-6)	• 10V, 0.15 to 80 MHz <sup>(2)</sup>

<sup>(1)</sup> For operation above 2000 meters, consult the factory.

<sup>(2)</sup> Conducted Immunity frequency range may be 150 kHz to 30 MHz if the Radiated Immunity frequency range is 30 MHz to 1000 MHz.

# **Output Specifications**

Specification	1769-OW16
Voltage Category	AC/DC normally open relay
Operating Voltage Range	5 to 265V ac 5 to 125V dc
Number of Outputs	16
Bus Current Draw (max.)	205 mA at 5V dc line 180 mA at 24V dc line
Heat Dissipation	4.75 Total Watts (The Watts per point, plus the minimum Watts, with all points energized.)
Signal Delay (max.) – resistive load	turn-on = 10 ms turn-off = 10 ms
Off-State Leakage (max.)	0 mA
On-State Current (min.)	10 mA at 5V dc
Continuous Current per Point (max.)	2.5A (Also see "Relay Contact Ratings" on page 16.)
Continuous Current per Common (max.)	10A
Continuous Current per Module (max.)	20A
Power Supply Distance Rating	8 (The module may not be more than 8 modules away from the power supply.)
Output Point to Bus Isolation	Verified by one of the following dielectric tests: 1836V ac for 1 sec. or 2596V dc for 2 sec. 265V ac working voltage (IEC Class 2 reinforced insulation)
Isolated Groups	Group 1: outputs 0 to 7 Group 2: outputs 8 to 15
Output Group to Output Group Isolation	Verified by one of the following dielectric tests: 1836V ac for 2 sec. or 2596V dc for 2 sec. 265V ac working voltage (basic insulation) 150V ac working voltage (IEC Class 2 reinforced insulation)
Vendor I.D. Code	1
Product Type Code	7
Product Code	85

# **Relay Contact Ratings**

Volts (max.)	Continuous Amps per Point (max.) <sup>(1)</sup>	Amperes	(2)	Voltamper	es	NEMA ICS 2-125
	per Point (max.)**	Make	Break	Make	Break	100 2 123
240V ac	2.5A	7.5A	0.75A	1800 VA	180 VA	C300
120V ac		15A	1.5A			
125V dc	1.0A	0.22A <sup>(3)</sup>		28 VA		R150
24V dc	2.0A	1.2A <sup>(3)</sup>		1		

<sup>(1)</sup> The continuous current per module must be limited so the module power does not exceed 1440 VA.

<sup>(2)</sup> Surge Suppression - Connecting surge suppressors across your external inductive load will extend the life of the relay contacts. For additional details, refer to Industrial Automation Wiring and Grounding Guidelines, Allen-Bradley publication 1770-4.1.

<sup>(3)</sup> For dc voltage applications, the make/break ampere rating for relay contacts can be determined by dividing 28 VA by the applied dc voltage. For example, 28 VA/48V dc = 0.58A. For dc voltage applications less than 48V, the make/break ratings for relay contacts cannot exceed 2A.

## **Hazardous Location Considerations**

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only. The following WARNING statement applies to use in hazardous locations.

#### WARNING



#### EXPLOSION HAZARD

- Substitution of components may impair suitability for Class I, Division 2.
- Do not replace components or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- Do not connect or disconnect components unless power has been switched off or the area is known to be non-hazardous.
- This product must be installed in an enclosure.
- All wiring must comply with N.E.C. article 501-4(b).

# **Environnements dangereux**

Cet équipement est conçu pour être utilisé dans des environnements de Classe 1, Division 2, Groupes A, B, C, D ou non dangereux. La mise en garde suivante s'applique à une utilisation dans des environnements dangereux.

#### **AVERTISSEMENT**



#### DANGER D'EXPLOSION

- La substitution de composants peut rendre cet équipement impropre à une utilisation en environnement de Classe 1, Division 2
- Ne pas remplacer de composants ou déconnecter l'équipement sans s'être assuré que l'alimentation est coupée et que l'environnement est classé non dangereux.
- Ne pas connecter ou déconnecter des composants sans s'être assuré que l'alimentation est coupée ou que l'environnement est classé non dangereux.
- Ce produit doit être installé dans une armoire.

# For More Information

For	Refer to this Document	Pub. No.				
A more detailed description of how to install and use your Compact $^{\text{TM}}$ $I/O$ with MicroLogix $^{\text{TM}}$ $I/O$ & 1500 programmable controller.	MicroLogix 1500 Programmable Controllers User Manual	1764-UM001B-US-P				
A more detailed description of how to install and use your Compact I/O with the CompactLogix™ System.	CompactLogix System User Manual	1769-UM007C-EN-P				
More information on proper wiring and grounding techniques.	Industrial Automation Wiring and Grounding Guidelines	1770-4.1				

If you would like a manual, you can:

- download a free electronic version from the internet:
   www.ab.com/micrologix or www.theautomationbookstore.com
- purchase a printed manual by:
  - contacting your local distributor or Rockwell Automation representative
  - visiting www.theautomationbookstore.com and placing your order
  - calling 1.800.963.9548 (USA/Canada)
     or 001.330.725.1574 (Outside USA/Canada)

Compact, MicroLogix, CompactLogix, RSLogix and RSNetworx are trademarks of Rockwell Automation. DeviceNet is a trademark of Open DeviceNet Vendor Association (ODVA).

#### Reach us now at www.rockwellautomation.com

Wherever you need us, Rockwell Automation brings together leading brands in industrial automation including Allen-Bradley controls, Reliance Electric power transmission products, Dodge mechanical power transmission components, and Rockwell Software. Rockwell Automation's unique, flexible approach to helping customers achieve a competitive advantage is supported by thousands of authorized partners, distributors and system integrators around the world.



Americas Headquarters, 1201 South Second Street, Milwaukee, WI 53201-2496, USA, Tel: (1) 414 382-2000, Fax: (1) 141-382-4444

European Headquarters SANN), Bollevard du Souverain 36, 1170 Brussels, Belgium: Tel: 132, 663 0800, Fax: (3) 2 168 30040

Asia Paolific Headquarters, 27/F Citicorp Centre, 181 Whitfield Road, Cussewsyl 8yk, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Rockwell Automation

Publication 1769-IN062A-EN-P - December 2001

PN 40072-119-01 (1)

© 2001 Rockwell International Corporation. Printed in the U.S.A.








# **Compact I/O 1769-IF8 Analog Input Module**

#### Inside

Module Description	2
Module Installation	
System Assembly	
Mounting Expansion I/O	
Replacing a Single Module within a System	
Module Spare/Replacement Parts	
Field Wiring Connections	
I/O Memory Mapping	
Specifications	
Hazardous Location Considerations	
Environnements dangereux	
For More Information	

# **Module Description**



ltem	Description
1	bus lever (with locking function)
2a	upper panel mounting tab
2b	lower panel mounting tab
3	module status LED
4	module door with terminal identification label
5a	movable bus connector with female pins
5b	stationary bus connector with male pins
6	nameplate label
7a	upper tongue-and-groove slots
7b	lower tongue-and-groove slots
8a	upper DIN rail latch
8b	lower DIN rail latch
9	write-on label (user ID tag)
10	removable terminal block (RTB) with finger-safe cover
10a	RTB upper retaining screw
10b	RTB lower retaining screw

## **Module Installation**

Compact I/O is suitable for use in an industrial environment when installed in accordance with these instructions. Specifically, this equipment is intended for use in clean, dry environments (Pollution degree  $2^{(1)}$ ) and to circuits not exceeding Over Voltage Category II<sup>(2)</sup> (IEC 60664-1).<sup>(3)</sup>

# **Prevent Electrostatic Discharge**

#### ATTENTION



Electrostatic discharge can damage integrated circuits or semiconductors if you touch bus connector pins or the terminal block. Follow these guidelines when you handle the module:

- Touch a grounded object to discharge static potential.
- Wear an approved wrist-strap grounding device.
- Do not touch the bus connector or connector pins.
- Do not touch circuit components inside the module.
- If available, use a static-safe work station.
- When not in use, keep the module in its static-shield box.

#### **Remove Power**

## **ATTENTION**



Remove power before removing or inserting this module. When you remove or insert a module with power applied, an electrical arc may occur. An electrical arc can cause personal injury or property damage by:

- sending an erroneous signal to your system's field devices, causing unintended machine motion
- causing an explosion in a hazardous environment

Electrical arcing causes excessive wear to contacts on both the module and its mating connector. Worn contacts may create electrical resistance.

<sup>(1)</sup> Pollution Degree 2 is an environment where, normally, only non-conductive pollution occurs except that occasionally a temporary conductivity caused by condensation shall be expected.


Over Voltage Category II is the load level section of the electrical distribution system. At this level transient voltages are controlled and do not exceed the impulse voltage capability of the product's insulation.

Pollution Degree 2 and Over Voltage Category II are International Electrotechnical Commission (IEC) designations.

# System Assembly

The module can be attached to the controller or an adjacent I/O module *before* or *after* mounting. For mounting instructions, see "Panel Mounting" on page 6, or "DIN Rail Mounting" on page 7. To work with a system that is already mounted, see "Replacing a Single Module within a System" on page 7.

The following procedure shows you how to assemble the Compact I/O system.



- 1. Disconnect power.
- **2.** Check that the bus lever of the module to be installed is in the unlocked (fully right) position.
- **3.** Use the upper and lower tongue-and-groove slots (1) to secure the modules together (or to a controller).
- **4.** Move the module back along the tongue-and-groove slots until the bus connectors (2) line up with each other.
- **5.** Push the bus lever back slightly to clear the positioning tab (3). Use your fingers or a small screwdriver.

**6.** To allow communication between the controller and module, move the bus lever fully to the left (4) until it clicks. Ensure it is locked firmly in place.

## ATTENTION



When attaching I/O modules, it is very important that the bus connectors are securely locked together to ensure proper electrical connection.

- 7. Attach an end cap terminator (5) to the last module in the system by using the tongue-and-groove slots as before.
- **8.** Lock the end cap bus terminator (6).

**IMPORTANT** 

A 1769-ECR or 1769-ECL right or left end cap must be used to terminate the end of the communication bus.

# Mounting Expansion I/O


### ATTENTION



During panel or DIN rail mounting of all devices, be sure that all debris (metal chips, wire strands, etc.) is kept from falling into the module. Debris that falls into the module could cause damage on power up.

# **Minimum Spacing**


Maintain spacing from enclosure walls, wireways, adjacent equipment, etc. Allow 50 mm (2 in.) of space on all sides for adequate ventilation, as shown:



## **Panel Mounting**

Mount the module to a panel using two screws per module. Use M4 or #8 panhead screws. Mounting screws are required on every module.

#### Panel Mounting Using the Dimensional Template



#### Panel Mounting Procedure Using Modules as a Template

The following procedure allows you to use the assembled modules as a template for drilling holes in the panel. If you have sophisticated panel mounting equipment, you can use the dimensional template provided on page 6. Due to module mounting hole tolerance, it is important to follow these procedures:

- 1. On a clean work surface, assemble no more than three modules.
- **2.** Using the assembled modules as a template, carefully mark the center of all module-mounting holes on the panel.
- **3.** Return the assembled modules to the clean work surface, including any previously mounted modules.
- **4.** Drill and tap the mounting holes for the recommended M4 or #8 screw.
- 5. Place the modules back on the panel and check for proper hole alignment.
- **6.** Attach the modules to the panel using the mounting screws.

NOTE

If mounting more modules, mount only the last one of this group and put the others aside. This reduces remounting time during drilling and tapping of the next group.

7. Repeat steps 1 to 6 for any remaining modules.

## **DIN Rail Mounting**

The module can be mounted using the following DIN rails:  $35 \times 7.5$  mm (EN 50 022 -  $35 \times 7.5$ ) or  $35 \times 15$  mm (EN 50 022 -  $35 \times 15$ ).

Before mounting the module on a DIN rail, close the DIN rail latches. Press the DIN rail mounting area of the module against the DIN rail. The latches will momentarily open and lock into place.

# Replacing a Single Module within a System

The module can be replaced while the system is mounted to a panel (or DIN rail). Follow these steps in order:

- 1. Remove power. See important note on page 3.
- 2. On the module to be removed, remove the upper and lower mounting screws from the module (or open the DIN latches using a flat-blade or phillips-style screwdriver).
- **3.** Move the bus lever to the right to disconnect (unlock) the bus.
- **4.** On the right-side adjacent module, move its bus lever to the right (unlock) to disconnect it from the module to be removed.
- **5.** Gently slide the disconnected module forward. If you feel excessive resistance, check that the module has been disconnected from the bus and that both mounting screws have been removed (or DIN latches opened).

#### NOTE

It may be necessary to rock the module slightly from front to back to remove it, or, in a panel-mounted system, to loosen the screws of adjacent modules.

- 6. Before installing the replacement module, be sure that the bus lever on the module to be installed, and on the right-side adjacent module are in the unlocked (fully right) position.
- 7. Slide the replacement module into the open slot.
- **8.** Connect the modules together by locking (fully left) the bus levers on the replacement module and the right-side adjacent module.
- 9. Replace the mounting screws (or snap the module onto the DIN rail).

# Module Spare/Replacement Parts

• Terminal block, catalog number 1769-RTBN18 (1 per kit)

# **Field Wiring Connections**

## **Grounding the Module**

This product is intended to be mounted to a well-grounded mounting surface such as a metal panel. Additional grounding connections from the module's mounting tabs or DIN rail (if used), are not required unless the mounting surface cannot be grounded. Refer to *Industrial Automation Wiring and Grounding Guidelines*, Allen-Bradley publication 1770-4.1, for additional information.

## **System Wiring Guidelines**

Consider the following when wiring your system:

- All module commons (ANLG COM) are connected in the analog module.
   The analog common (ANLG COM) is not connected to earth ground inside the module.
- Do not use the analog module's NC terminals as connection points.
- · Channels are not isolated from each other.
- Use Belden™ 8761, or equivalent, shielded wire.
- Under normal conditions, the drain wire and shield junction must be connected to earth ground via a panel or DIN rail mounting screw at the analog I/O module end. Keep the shield connection to ground as short as possible.<sup>(1)</sup>
- To ensure optimum accuracy, limit overall cable impedance by keeping your cable as short as possible. Locate the I/O system as close to your sensors or actuators as your application will permit.
- If multiple power supplies are used with analog inputs, the power supply commons must be connected.

<sup>(1)</sup> In environments where high-frequency noise may be present, it may be necessary to directly ground cable shields to earth at the module end and via a 0.1µF capacitor at the sensor end.


- The 1769-IF8 module does not provide loop power for analog inputs. Use a
  power supply that matches the input transmitter specifications.
- Differential analog inputs are more immune to noise than single-ended analog inputs.
- Voltages on Vin+, V/Iin-, and Iin+ of the 1769-IF8 module must be within ±10V dc of analog common.

### **ATTENTION**




Be careful when stripping wires. Wire fragments that fall into a module could cause damage at power up. Once wiring is complete, ensure the module is free of all metal fragments.

## **Wiring Differential Inputs**




# Wiring Single-Ended Sensor/Transmitter Types




Wiring for channels 4-7 are identical.

# **Wiring Mixed Transmitter Types**



## **Labeling the Terminals**

A removable, write-on label is provided with the module. Remove the label from the door, mark the identification of each terminal with permanent ink, and slide the label back into the door. Your markings (ID tag) will be visible when the module door is closed.



# **Removing the Finger-Safe Terminal Block**

When wiring field devices to the module, it is not necessary to remove the terminal block. If you remove the terminal block, use the write-on label on the side of the terminal block to identify the module slot location and type. RTB position can be indicated by circling either the 'R' for right side or 'L' for left side.

To remove the terminal block, loosen the upper and lower retaining screws. The terminal block will back away from the module as you remove the screws. When replacing the terminal block, torque the retaining screws to 0.46 Nm (4.1 in-lbs).

## Wiring the Finger-Safe Terminal Block

When wiring the terminal block, keep the finger-safe cover in place.

- 1. Loosen the terminal screws to be wired.
- 2. Route the wire under the terminal pressure plate. You can use the bare wire or a spade lug. The terminals will accept a 6.35 mm (0.25 in.) spade lug.

#### NOTE

The terminal screws are non-captive. Therefore, it is possible to use a ring lug [maximum 1/4 inch o.d. with a 0.139 inch minimum i.d. (M3.5)] with the module.

Tighten the terminal screw making sure the pressure plate secures the wire. Recommended torque when tightening terminal screws is 0.68 Nm (6 in-lbs).

#### NOTE

If you need to remove the finger-safe cover, insert a screw driver into one of the square wiring holes and gently pry the cover off. If you wire the terminal block with the finger-safe cover removed, you will not be able to put it back on the terminal block because the wires will be in the way.

# **Wire Size and Terminal Screw Torque**

Each terminal accepts up to two wires with the following restrictions:

	Wire Type	Wire Size	Terminal Screw Torque	Retaining Screw Torque			
Solid	Cu-90°C (194°F)	#14 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)			
Stranded	Cu-90°C (194°F)	#16 to #22 AWG	0.68 Nm (6 in-lbs)	0.46 Nm (4.1 in-lbs)			

# I/O Memory Mapping

**IMPORTANT** 

If you are using RSLogix 5000, version 15, please refer to RSLogix 5000, Version 15, Controller Tags on page 18.

## **Input Data File**

For each input module, slot x, words 0-7 in the input data file contain the analog values of the inputs.

- E	Bit Posi	tion														
Word	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	SGN						Ana	log Inp	ut Dat	a Char	nel 0					
1	SGN		Analog Input Data Channel 1													
2	SGN		Analog Input Data Channel 2													
3	SGN		Analog Input Data Channel 3													
4	SGN						Ana	log Inp	ut Dat	a Char	nel 4					
5	SGN						Ana	log Inp	ut Dat	a Char	nel 5					
6	SGN						Ana	log Inp	ut Dat	a Char	nel 6					
7	SGN						Ana	log Inp	ut Dat	a Char	inel 7					
8	Nu							Time	Stamp	Value						
9	Nu	Nu	Nu	Nu	Nu	Nu	Nu	Nu	S7	S6	S5	S4	S3	S2	S1	S0
10	L3	Н3	U3	03	L2	H2	U2	02	L1	H1	U1	01	LO	H0	U0	00
11	L7	H7	U7	07	L6	H6	U6	06	L5	H5	U5	05	L4	H4	U4	04

The bits are defined as follows:

- SGN = Sign bit in two's complement format
- Nu = Not used. Bit set to 0.
- Sx = General status bit for input channels 0 through 7.
- Lx = Low alarm flag bits for input channels 0 through 7.
- Hx = High alarm flag bits for input channels 0 through 7.
- Ux = Under-range flag bits for channels 0 through 7. When set, the input signal is under normal range or an open circuit condition exists, in the case of the 4-20 mA range.
- Ox = Over-range flag bits for channels 0 through 7.

# **Output Data File**

For each input module, slot x, word 0 in the output data file contains alarm unlatch control bits.

2	Bit Posi	tion														
Wor	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	CL <sup>(1)</sup>	CL <sup>(2)</sup>	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL	CL
	L7	H7	L6	H6	L5	H5	L4	H4	L3	H3	LZ	HZ	LI	H1	LU	H0

<sup>(1)</sup> CL Lx = Cancel Low Process Alarm Latch x. This lets you individually cancel each low process alarm latch. Cancel = 1.

<sup>(2)</sup> CL Hx = Cancel High Process Alarm Latch x. This lets you individually cancel each high process alarm latch.

# **Configuration Data File**

The manipulation of the bits from this file is normally done with programming software (e.g. RSLogix 500, RSNetworx for DeviceNet, etc.) during initial configuration of the system. In that case, graphical screens are provided by the programmer to simplify configuration. However, some systems, like the 1769-ADN DeviceNet Adapter, also allow the bits to be altered as part of the control program, using communication rungs. In that case, it is necessary to understand the bit arrangement. Refer to the *Compact™ Analog I/O User Manual*, publication number 1769-UM002 for additional details.

臣			Bit Position													
Word	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0						•	Real	Time Sa	ample	Value				•	•	
1	ERTS							F	leserve	ed						
2	EC		Rese	erved		EA	AL	EI		Rese	erved		Inp	ut Filt	er Sel (	ChIO
3		R	eserve	d		Inpt	Dta Fm	ChI0		Rese	erved		Inpt	Tp/Rr	ngeSel	ChI0
4	S					Proc	ess Al	arm Hi	gh Dat	a Valu	e Chan	nel 0				
5	S					Prod	cess Al	arm Lo	w Data	a Value	Chan	nel 0				
6	S		Alarm Dead Band Value Channel 0													
7			Pad  Reserved EA AL EI Reserved Inpt Filter Sel Chl1													
8	EC		Rese	erved		EA	AL	El		Rese	erved		Inp	ot Filte	r Sel C	:hl1
9		R	Reserved Inpt Dta Fm Chl1 Reserved Inpt Tp/RngeSel Chl												Chl1	
10	S						ess Al		-							
11	S		Process Alarm Low Data Value Channel 1													
12	S		Alarm Dead Band Value Channel 1													
13								Pa	nd							
14	EC		Rese	erved		EA	AL	El		Rese	erved		Inp	ut Filt	er Sel (	ChI2
15		R	eserve	d			Dta Fm				erved		Inpt	Tp/Rr	ngeSel	ChI2
16	S						ess Al									
17	S						cess Al									
18	S						Alarm I			alue Ch	annel	2				
19								Pa	nd				1			
20	EC		Rese			EA	AL	El			erved				er Sel (	
21		R	eserve	d			Dta Fm				erved		Inpt	Tp/Rr	ngeSel	Chl3
22	S						ess Al									
23	S						cess Al									
24	S						Alarm I	Dead B	and Va	alue Ch	annel	3				
25						•		Pa	nd				•			
26	EC		Rese	erved		EA	AL	El		Rese	erved		Inp	ut Filt	er Sel (	ChI4

rd								Bit Po	sition							
Word	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
27		R	eserve	d		Inpt	Dta Fm	ChI4		Rese	rved		Inpt	Tp/Rn	geSel	ChI4
28	S					Proc	ess Ala	arm Hiç	gh Data	a Value	Chan	nel 4				
29	S					Prod	ess Ala	arm Lo	w Data	Value	Chanı	nel 4				
30	S					,	Alarm [	Dead B	and Va	lue Ch	annel -	4				
31								Pa	d							
32	EC		Rese	rved		EA	AL	EI		Rese	rved		Inp	ut Filte	r Sel (	ChI5
33		R	eserve	d		Inpt	Dta Fm	ChI5		Rese	rved		Inpt	Tp/Rn	geSel	ChI5
34	S					Proc	ess Ala	arm Hiç	gh Data	a Value	Chan	nel 5				
35	S					Prod	ess Al	arm Lo	w Data	ı Value	Chanı	nel 5				
36	S		Alarm Dead Band Value Channel 5													
37			Pad													
38	EC		Rese	rved		EA	AL	EI		Rese	rved		Inp	ut Filte	r Sel (	ChI6
39		R	eserve	d			Dta Fm			Rese			Inpt	Tp/Rn	geSel	Chl6
40	S					Proc	ess Ala	arm Hi	gh Data	a Value	Chan	nel 6				
41	S					Prod	ess Al	arm Lo	w Data	ı Value	Chanı	nel 6				
42	S					,	Alarm [	Dead B	and Va	lue Ch	annel	6				
43								Pa	d							
44	EC		Rese	rved		EA	AL	EI		Rese	rved		Inp	ut Filte	r Sel (	ChI7
45		R	eserve	d		Inpt	Dta Fm	ChI7		Rese	rved		Inpt	Tp/Rn	geSel	ChI7
46	S					Prod	ess Ala	arm Hiç	gh Data	a Value	Chan	nel 7				
47	S				,	Prod	ess Al	arm Lo	w Data	Value	Chanı	nel 7				
48	S	Alarm Dead Band Value Channel 7														
49								Pa	d						-	

- EC = Enable Channel
- Inpt Dta Fm Chlx = Input Data Format Select.
- EA = Enable Alarm.
- AL = Alarm Latch.
- EI = Enable Interrupt.
- Inpt Tp/Rnge Sel Chlx = Input Type/Range Select.
- Inpt Filter Sel Chlx = Input Filter Select.
- Reserved = Allows for future expansion.
- ERTS = Enable Real Time Sample.

Define	To Select	Mak	e thes	e bit	settin	gs								
		15	14	13	12	11	10	9	8	7-4	3	2	1	0
Input Filter	60 Hz										0	0	0	0
Selection/	50 Hz										0	0	0	1
-3 dB	10 Hz										0	0	1	0
Frequency	250 Hz										0	0	1	1
	500 Hz										0	1	0	0
Enable	Enable								1					
Interrupt	Disable								0					
Process	Enable						1							
Alarm Latch	Disable						0							
Enable	Enable					1								
Process Alarms	Disable					0								
Enable	Enable	1												
Channel	Disable	0												

Define	Indicate this				Thes	e bit settings				
		15-11	10	9	8	7-4	3	2	1	0
Input	-10 to +10V dc						0	0	0	0
Range Select	0 to 5V dc						0	0	0	1
001001	0 to 10V dc						0	0	1	0
	4 to 20 mA						0	0	1	1
	1 to 5V dc						0	1	0	0
	0 to 20 mA						0	1	0	1
Input Data Select	Raw/Proportional Counts		0	0	0					
	Engineering Units		0	0	1					
	Scaled for PID		0	1	0					
	Percent Range		0	1	1					

# **RSLogix 5000, Version 15, Controller Tags**

Use the following controller tags with RSLogix 5000, version 15.

## **Channel 0 and 1 Configuration Data**

Channel 0 and 1 configuration data is shown below. The same information applies to all channels.

- Loc	al:1:C	AB:1769_IF8:C:0	_
+	Local:1:C.RTSInterval	INT	Decimal
	Local:1:C.RTSEn	BOOL	Decimal
+	Local:1:C.Ch0Filter	SINT	Decimal
	Local:1:C.Ch0AlarmInterruptEn	BOOL	Decimal
	Local:1:C.Ch0AlarmLatchEn	BOOL	Decimal
	Local:1:C.Ch0AlarmEn	BOOL	Decimal
	Local1:C.Ch0En	BOOL	Decimal
+	Local:1:C.Ch0Range	SINT	Decimal
+	Local:1:C.Ch0DataFormat	SINT	Decimal
+	Local:1:C.Ch0HAlarmLimit	INT	Decimal
+	Local:1:C.Ch0LAlarmLimit	INT	Decimal
+	Local:1:C.Ch0AlarmDeadband	INT	Decimal
+	Local:1:C.Ch1Filter	SINT	Decimal
	Local:1:C.Ch1AlarmInterruptEn	BOOL	Decimal
	Local:1:C.Ch1AlarmLatchEn	BOOL	Decimal
	Local:1:C.Ch1AlarmEn	BOOL	Decimal
	Local:1:C.Ch1En	BOOL	Decimal
+	Local:1:C.Ch1Range	SINT	Decimal
+	Local:1:C.Ch1DataFormat	SINT	Decimal
+	Local:1:C.Ch1HAlarmLimit	INT	Decimal
+	Local:1:C.Ch1LAlarmLimit	INT	Decimal
+	Local:1:C.Ch1AlarmDeadband	INT	Decimal

Tag Name	To Select	Make These Bit Settings <sup>(1)</sup>								
		15-8	7	6	5	4	3	2	1	0
Ch#Filter	60 Hz							0	0	0
	50 Hz							0	0	1
	10 Hz							0	1	0
	250 Hz							0	1	1
	500 Hz							1	0	0
Ch#AlarmInterruptEn	Enable									1
	Disable									0
Ch#AlarmLatchEn	Enable									1
	Disable									0
Ch#AlarmEn	Enable									1
	Disable									0
Ch#En	Enable									1
	Disable									0
Ch#Range	-10+10V dc							0	0	0
	05V dc							0	0	1
	010V dc							0	1	0
	420 mA							0	1	1
	15V dc							1	0	0
	020 mA							1	0	1
Ch#DataFormat	Raw/proportional								0	0
	counts									
	Engineering units								0	1
	Scaled for PID								1	0
	Percent range								1	1

<sup>(1)</sup> All bit positions left blank in table must be set to 0.

# **Input Data**

Loc	al:1:l	AB:1769_IF8:I:0	)
+	Local:1:I.Fault	DINT	Binary
+	Local:1:l.Ch0Data	INT	Decimal
+	Local:1:I.Ch1Data	INT	Decimal
+	Local:1:I.Ch2Data	INT	Decimal
+	Local:1:I.Ch3Data	INT	Decimal
+	Local:1:I.Ch4Data	INT	Decimal
+	Local:1:I.Ch5Data	INT	Decimal
+	Local:1:I.Ch6Data	INT	Decimal
+	Local:1:I.Ch7Data	INT	Decimal
+	Local:1:I.RealTimeSample	INT	Decimal
+	Local:1:I.CombinedStatus	SINT	Binary
	Local:1:I.Ch0Status	BOOL	Decimal
	Local:1:I.Ch1Status	BOOL	Decimal
	Local:1:1.Ch2Stattus	BOOL	Decimal
	Local:1:I.Ch3Status	BOOL	Decimal
	Local:1:I.Ch4Status	BOOL	Decimal
	Local:1:I.Ch5Status	BOOL	Decimal
	Local:1:I.Ch6Status	BOOL	Decimal
	Local:1:I.Ch7Status	BOOL	Decimal
+	Local:1:I.Ch0_1Status	SINT	Binary
	Local:1:I.Ch0OverRange	BOOL	Decimal
	Local:1:I.Ch0UnderRange	BOOL	Decimal
	Local:1:I.Ch0HAlarm	BOOL	Decimal
	Local:1:I.Ch0LAlarm	BOOL	Decimal
+	Local:1:I.Ch1OverRange	BOOL	Decimal
	Local:1:I.Ch1UnderRange	BOOL	Decimal
	Local:1:I.Ch1HAlarm	BOOL	Decimal
	Local:1:I.Ch1LAlarm	BOOL	Decimal

+	Local:1:I.Ch2_3Status	SINT	Binary
	Local:1:I.Ch2OverRange	BOOL	Decimal
	Local:1:I.Ch2UnderRange	BOOL	Decimal
	Local:1:I.Ch2HAlarm	BOOL	Decimal
	Local:1:I.Ch2LAlarm	BOOL	Decimal
	Local:1:I.Ch3OverRange	BOOL	Decimal
	Local:1:I.Ch3UnderRange	BOOL	Decimal
	Local:1:I.Ch3HAlarm	BOOL	Decimal
	Local:1:I.Ch3LAlarm	BOOL	Decimal
+	Local:1:I.Ch4_5Status	SINT	Binary
	Local:1:I.Ch4OverRange	BOOL	Decimal
	Local:1:I.Ch4UnderRange	BOOL	Decimal
	Local:1:I.Ch4HAlarm	BOOL	Decimal
	Local:1:I.Ch4LAlarm	BOOL	Decimal
	Local:1:I.Ch5OverRange	BOOL	Decimal
	Local:1:I.Ch5UnderRange	BOOL	Decimal
	Local:1:I.Ch5HAlarm	BOOL	Decimal
	Local:1:I.Ch5LAlarm	BOOL	Decimal
+	Local:1:I.Ch6_7Status	SINT	Binary
	Local:1:I.Ch6OverRange	BOOL	Decimal
	Local:1:I.Ch6UnderRange	BOOL	Decimal
	Local:1:I.Ch6HAlarm	BOOL	Decimal
	Local:1:I.Ch6LAlarm	BOOL	Decimal
	Local:1:I.Ch7OverRange	BOOL	Decimal
	Local:1:I.Ch7UnderRange	BOOL	Decimal
	Local:1:I.Ch7HAlarm	BOOL	Decimal
	Local:1:I.Ch7LAlarm	BOOL	Decimal

Tag	Bit Indicates This							
Name	7	6	5	4	3	2	1	0
Combined Status	Ch7 Status	Ch6 Status	Ch5 Status	Ch4 Status	Ch3 Status	Ch2 Status	Ch1 Status	Ch0 Status
Ch0_1 Status	Ch1 LAlarm	Ch1 HAlarm	Ch1 Under Range	Ch1 Over Range	Ch0 LAlarm	Ch0 HAlarm	Ch0 Under Range	Ch0 Over Range
Ch2_3 Status	Ch3 LAlarm	Ch3 HAlarm	Ch3 Under Range	Ch3 Over Range	Ch2 LAlarm	Ch2 HAlarm	Ch2 Under Range	Ch2 Over Range
Ch4_5 Status	Ch5 LAlarm	Ch5 HAlarm	Ch5 Under Range	Ch5 Over Range	Ch4 LAlarm	Ch4 HAlarm	Ch4 Under Range	Ch4 Over Range
Ch6_7 Status	Ch7 LAlarm	Ch7 HAlarm	Ch7 Under Range	Ch7 Over Range	Ch6 LAlarm	Ch6 HAlarm	Ch6 Under Range	Ch6 Over Range

# **Output Data**

-	Loca	al:1:0	AB:1769_IF8:0:	0
,	+	Local:1:0.AlarmUnlatch	INT	Binary
		Local:1:0.Ch0HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch0LAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch1HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch1LAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch2HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch2LAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch3HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch3LAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch4HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch4LAlarmUnlatch	BOOL	Binary
		Local:1:0.Ch5HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch5LAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch6HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch6LAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch7HAlarmUnlatch	BOOL	Decimal
		Local:1:0.Ch7LAlarmUnlatch	BOOL	Decimal

# **Specifications**

## **General Specifications**

Specification	Value
Dimensions	118 mm (height) x 87 mm (depth) x 52.5 mm (width)
	height including mounting tabs is 138 mm
	4.65 in. (height) x 3.43 in (depth) x 2.07 in (width)
	height including mounting tabs is 5.43 in.
Approximate Shipping Weight (with carton)	450g (0.99 lbs.)
Storage Temperature	-40°C to +85°C (-40°F to +185°F)
Operating Temperature	0°C to +60°C (32°F to +140°F)
Operating Humidity	5% to 95% non-condensing
Operating Altitude	2000 meters (6561 feet)
Vibration	Operating: 10 to 500 Hz, 5G, 0.030 in. peak-to-peak
Shock	Operating: 30G, 11 ms panel mounted
	(20G, 11 ms DIN rail mounted)
	Non-Operating: 40G panel mounted
	(30G DIN rail mounted)
Agency Certification	C-UL certified (under CSA C22.2 No. 142)
	UL 508 listed
	CE compliant for all applicable directives
Hazardous Environment Class	Class I, Division 2, Hazardous Location, Groups A, B, C, D (UL 1604, C-UL under CSA C22.2 No. 213)
Radiated and Conducted Emissions	EN50081-2 Class A
Electrical /EMC:	The module has passed testing at the following levels:
ESD Immunity (IEC1000-4-2)	4 kV contact, 8 kV air, 4 kV indirect
Radiated Immunity (IEC1000-4-3)	10 V/m , 80 to 1000 MHz, 80% amplitude modulation, +900 MHz keyed carrier
Fast Transient Burst (IEC1000-4-4)	• 2 kV, 5kHz
Surge Immunity (IEC1000-4-5)	1 kV galvanic gun
• Conducted Immunity (IEC1000-4-6)	• 10 V, 0.15 to 80MHz <sup>(1)</sup>

<sup>1)</sup> Conducted Immunity frequency range may be 150 kHz to 30 MHz if the Radiated Immunity frequency range is 30 MHz to 1000 MHz.

## **Input Specifications**

Specification	1769-IF8
Analog Normal Operating Ranges <sup>(1)</sup>	Voltage: ± 10V dc, 0 to 10V dc, 0 to 5V dc, 1 to 5V dc Current: 0 to 20 mA, 4 to 20 mA
Full Scale Analog Ranges <sup>(1)</sup>	Voltage: ± 10.5V dc, 0 to 10.5V dc, 0 to 5.25V dc, 0.5 to 5.25V dc Current: 0 to 21 mA, 3.2 to 21 mA
Number of Inputs	8 differential or single-ended
Bus Current Draw (max.)	120 mA at 5V dc 70 mA at 24V dc
Heat Dissipation	3.24 Total Watts (The Watts per point, plus the minimum Watts, with all points energized.)
Converter Type	Delta Sigma
Response Speed per Channel	Input filter and configuration dependent. See your user's manual.
Resolution (max.) <sup>(2)</sup>	16 bits (unipolar) 15 bits plus sign (bipolar)
Rated Working Voltage <sup>(3)</sup>	30V ac/30V dc
Common Mode Voltage Range <sup>(4)</sup>	±10V dc maximum per channel
Common Mode Rejection	greater than 60 dB at 50 and 60 Hz with the 10 Hz filter selected, respectively.
Normal Mode Rejection Ratio	-50 dB at 50 and 60 Hz with the 10 Hz filter selected, respectively.
Input Impedance	Voltage Terminal: 220K $\Omega$ (typical) Current Terminal: 250 $\Omega$
Overall Accuracy <sup>(5)</sup>	Voltage Terminal: ±0.2% full scale at 25°C Current Terminal: ±0.35% full scale at 25°C

<sup>(1)</sup> The over- or under-range flag will come on when the normal operating range (over/under) is exceeded. The module will continue to convert the analog input up to the maximum full scale range. The flag automatically resets when within the normal operating range.

<sup>(2)</sup> Resolution is dependent upon your filter selection. The maximum resolution is achieved with the 10 Hz filter selected. For resolution with other filter selections, refer to the user manual, publication 1769-UM002A-EN-P.

<sup>(3)</sup> Rated working voltage is the maximum continuous voltage that can be applied at the input terminal, including the input signal and the value that floats above ground potential (for example, 10V dc input signal and 20V dc potential above ground).

<sup>(4)</sup> For proper operation, both the plus and minus input terminals must be within ±10V dc of analog common.

<sup>(5)</sup> Includes offset, gain, non-linearity and repeatability error terms.

Specification	1769-IF8
Accuracy Drift with Temperature	Voltage Terminal: ±0.003% per °C Current Terminal: ±0.0045% per °C
Calibration	The module performs autocalibration on channel enable and on a configuration change between channels.
Non-linearity (in percent full scale)	±0.03%
Repeatability <sup>(1)</sup>	±0.03%
Module Error over Full Temperature Range	Voltage: ±0.3%  Current: +0.5%
(0 to +60°C [+32°F to +140°F])	
Input Channel Configuration	via configuration software screen or the user program (by writing a unique bit pattern into the module's configuration file). Refer to your controller's user manual to determine if user program configuration is supported.
Module OK LED	On: module has power, has passed internal diagnostics, and is communicating over the bus.  Off: Any of the above is not true.
Channel Diagnostics	Over- or under-range by bit reporting, process alarms
Maximum Overload at Input Terminals <sup>(2)</sup>	Voltage Terminal: ±30V dc continuous, 0.1 mA Current Terminal: ±32 mA continuous, ±7.6 V dc
System Power Supply Distance Rating	8 (The module may not be more than 8 modules away from the system power supply.)
Recommended Cable	Belden™ 8761 (shielded)
Input Group to Bus Isolation	500V ac or 710V dc for 1 minute (qualification test) 30V ac/30V dc working voltage (IEC Class 2 reinforced insulation)
Vendor I.D. Code	1
Product Type Code	10
Product Code	38

<sup>[1]</sup> Repeatability is the ability of the input module to register the same reading in successive measurements for the same input signal.

<sup>(2)</sup> Damage may occur to the input circuit if this value is exceeded.

## **Hazardous Location Considerations**

This equipment is suitable for use in Class I, Division 2, Groups A, B, C, D or non-hazardous locations only. The following ATTENTION statement applies to use in hazardous locations.

#### WARNING



#### EXPLOSION HAZARD

- Substitution of components may impair suitability for Class I, Division 2.
- Do not replace components or disconnect equipment unless power has been switched off or the area is known to be non-hazardous.
- Do not connect or disconnect components unless power has been switched off or the area is known to be non-hazardous.
- This product must be installed in an enclosure.
- All wiring must comply with N.E.C. article 501-4(b).

## **Environnements dangereux**

Cet équipement est conçu pour être utilisé dans des environnements de Classe 1, Division 2, Groupes A, B, C, D ou non dangereux. La mise en garde suivante s'applique à une utilisation dans des environnements dangereux.

#### **AVERTISSEMENT**



#### DANGER D'EXPLOSION

- La substitution de composants peut rendre cet équipement impropre à une utilisation en environnement de Classe 1, Division 2.
- Ne pas remplacer de composants ou déconnecter l'équipement sans s'être assuré que l'alimentation est coupée et que l'environnement est classé non dangereux.
- Ne pas connecter ou déconnecter des composants sans s'être assuré que l'alimentation est coupée ou que l'environnement est classé non dangereux.
- Ce produit doit être installé dans une armoire.

## For More Information

For	Refer to this Document	Pub. No.
A more detailed description of how to install and use your Compact I/O with MicroLogix 1500 programmable controller.	MicroLogix 1500 Programmable Controllers User Manual	1764-UM001
Detailed information on installing, programming, and troubleshooting your Compact Analog I/O modules.	Compact I/O Analog Modules User Manual	1769-UM002
A detailed description of how to install and use your Compact I/O with the 1769-ADN DeviceNet Adapter.	1769-ADN DeviceNet Adapter User Manual	1769-UM001
An overview of the MicroLogix 1500 system, including Compact I/O.	MicroLogix 1500 Programmable Controller with Compact I/O for Expansion	1764-S0001
More information on proper wiring and grounding techniques.	Industrial Automation Wiring and Grounding Guidelines	1770-4.1

If you would like a manual, you can:

- download a free electronic version from the internet: **www.ab.com/micrologix** or **www.theautomationbookstore.com**
- purchase a printed manual by:
- contacting your local distributor or Rockwell Automation representative
- visiting www.theautomationbookstore.com and placing your order
- calling 1.800.963.9548 (USA/Canada)
   or 001.330.725.1574 (Outside USA/Canada)

MicroLogix and Compact are trademarks of Rockwell Automation. Belden is a trademark of Belden, Inc.

# **Notes:**

# **Notes:**

# **Notes:**

## **Rockwell Automation Support**

Rockwell Automation provides technical information on the web to assist you in using our products. At http://support.rockwellautomation.com, you can find technical manuals, a knowledge base of FAQs, technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

For an additional level of technical phone support for installation, configuration and troubleshooting, we offer TechConnect Support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <a href="http://support.rockwellautomation.com">http://support.rockwellautomation.com</a>.

#### **Installation Assistance**

If you experience a problem with a hardware module within the first 24 hours of installation, please review the information that's contained in this manual. You can also contact a special Customer Support number for initial help in getting your module up and running:

United States	1.440.646.3223 Monday – Friday, 8am – 5pm EST
Outside United States	Please contact your local Rockwell Automation representative for any technical support issues.

#### **New Product Satisfaction Return**

Rockwell tests all of our products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned:

	Contact your distributor. You must provide a Customer Support case number (see phone number above to obtain one) to your distributor in order to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for return procedure.

#### www.rockwellautomation.com

1769-IN067A-EN-P March 2004

#### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444 Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640 Asia Pacific: Rockwell Automation, Level 14, Cove F, Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1769-IN067B-EN-P - September 2005

PN 40071-171-01(2)

Copyright © 2005 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.





# MODEL G310 - GRAPHIC LCD OPERATOR INTERFACE TERMINAL WITH VGA DISPLAY AND TOUCHSCREEN





FOR USE IN HAZARDOUS LOCATIONS: Class I, Division 2, Groups A, B, C, and D Class II, Division 2, Groups F and G Class III, Division 2

- CONFIGURED USING CRIMSON® SOFTWARE (VERSION 2.0 OR LATER)
- UP TO 5 RS-232/422/485 COMMUNICATIONS PORTS (2 RS-232 AND 1 RS-422/485 ON BOARD, 1 RS-232 AND 1 RS-422/485 ON OPTIONAL COMMUNICATIONS CARD)
- 10 BASE T/100 BASE-TX ETHERNET PORT TO NETWORK UNITS AND HOST WEB PAGES
- USB PORT TO DOWNLOAD THE UNIT'S CONFIGURATION FROM A PC OR FOR DATA TRANSFERS TO A PC
- UNIT'S CONFIGURATION IS STORED IN NON-VOLATILE MEMORY (8MBYTE FLASH)
- COMPACTFLASH® SOCKET TO INCREASE MEMORY CAPACITY
- 10.4-INCH TFT 256 COLOR VGA 640X480 PIXEL LCD
- OUTDOOR UNIT WITH UV RATED OVERLAY AVAILABLE
- 8-BUTTON KEYPAD FOR ON-SCREEN MENUS
- THREE FRONT PANEL LEDS
- POWER UNIT FROM 24VDC ±20% SUPPLY
- RESISTIVE ANALOG TOUCHSCREEN



#### **GENERAL DESCRIPTION**

The G310 Operator Interface Terminal combines unique capabilities normally expected from high-end units with a very affordable price. It is built around a high performance core with integrated functionality. This core allows the G310 to perform many of the normal features of the Paradigm range of Operator Interfaces while improving and adding new features.

The G310 is able to communicate with many different types of hardware using high-speed RS232/422/485 communications ports and Ethernet 10 Base T/100 Base-TX communications. In addition, the G310 features USB for fast downloads of configuration files and access to trending and data logging. A CompactFlash socket is provided so that Flash cards can be used to collect your trending and data logging information as well as to store larger configuration files.

In addition to accessing and controlling of external resources, the G310 allows a user to easily view and enter information. An outdoor version is available for direct sunlight applications. Users can enter data through the touchscreen or front panel 8-button keypad.

## **SAFETY SUMMARY**

All safety related regulations, local codes and instructions that appear in the manual or on equipment must be observed to ensure personal safety and to prevent damage to either the instrument or equipment connected to it. If equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.

Do not use the controller to directly command motors, valves, or other actuators not equipped with safeguards. To do so can be potentially harmful to persons or equipment in the event of a fault to the controller.





The protective conductor terminal is bonded to conductive parts of the equipment for safety purposes and must be connected to an external protective earthing system.



WARNING - EXPLOSION HAZARD - SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2/CLASS III, DIVISION 2



**CAUTION:** Risk Of Danger. Read complete instructions prior to installation and operation of the unit.



CAUTION: Risk of electric shock.

#### CompactFlash is a registered trademark of CompactFlash Association.

#### **CONTENTS OF PACKAGE**

- G310 Operator Interface.
- Panel Gasket.
- This hardware bulletin.
- Template for panel cutout.
- Hardware packet for mounting unit into panel.
- Terminal block for connecting power.

#### ORDERING INFORMATION

MODEL NO.	DESCRIPTION	PART NUMBER
	Operator Interface for indoor applications only, textured finish with embossed keys	G310C000
G310	Operator Interface for indoor or outdoor applications, glossy finish with UV rated overlay (keys are not embossed)	G310S000
G3CF	CompactFlash Card <sup>5</sup>	G3CFxxxx
G3RS	RS 232/485 Optional Communication Card	G3RS0000
G3CN	CANopen Optional Communication Card	G3CN0000
G3PBDP	Profibus DP Optional Communication Card	G3PBDP00
G3GSM	GSM/GPRS Modem Option Card for G3 operator interface <sup>6</sup>	G3GSM000
SFCRM2	Crimson <sup>2</sup>	SFCRM200
	RS-232 Programming Cable	CBLPROG0
CBL	USB Cable	CBLUSB00
	Communications Cables <sup>1</sup>	CBLxxxxx
DR	DIN Rail Mountable Adapter Products <sup>3</sup>	DRxxxxxx
	Replacement Battery <sup>4</sup>	BNL20000
	G310C Backlight Replacement <sup>6</sup>	CONSULT
	G310S Backlight Replacement <sup>6</sup>	FACTORY
G3FILM	Protective Films	G3FILM10

- <sup>1</sup> Contact your Red Lion distributor or visit our website for complete selection.
- <sup>2</sup> Use this part number to purchase Crimson on CD with a printed manual, USB cable, and RS-232 cable. Otherwise, download for free from www.redlion.net.
- <sup>3</sup> Red Lion offers RJ modular jack adapters. Refer to the DR literature for details.
- <sup>4</sup> Battery type is lithium coin type CR2025
- <sup>5</sup> Industrial grade two million write cycles. SMART Modular Technologies model SG9CF (UL Listed Directory Category NWGQ).
- <sup>6</sup> For use in non-hazardous locations only.

# **SPECIFICATIONS**

#### 1. POWER REQUIREMENTS:

G310C: +24 VDC ±20% @ 33 W maximum.

G310S: +24 VDC ±20% @ 25 W maximum.

Must use Class 2 or SELV rated power supply.

Power connection via removable three position terminal block.

Notes:

- 1. The front panel PWR LED indicates power.
- 2. The G310's circuit common is not connected to the enclosure of the unit. See "Connecting to Earth Ground" in the section "Installing and Powering the G310."
- 2. BATTERY: Lithium coin cell. Typical lifetime of 10 years.

#### 3. LCD MODULE DISPLAYS:

MODEL	G310C	G310S
SIZE	10.4-inch	10.4-inch
TYPE	TFT	TFT
COLORS	256 VGA	256 VGA
PIXELS	640 X 480	640 X 480
BRIGHTNESS	450 cd/m <sup>2</sup>	850 cd/m <sup>2</sup>
BACKLIGHT TYPE	CCFL	LED
BACKLIGHT LIFE *	50,000 HR TYP.	50,000 HR TYP.

- \*Lifetime at room temperature. Refer to "Display" in the "Software/Unit Operation" section.
- 4. 8-KEY KEYPAD: for on-screen menus.
- 5. TOUCHSCREEN: Resistive analog
- 6. MEMORY:

On Board User Memory: 8 Mbyte of onboard non-volatile Flash memory.
Memory Card: CompactFlash Type II slot for Type I and Type II CompactFlash cards.

7. COMMUNICATIONS:

USB Port: Adheres to USB specification 1.1. Device only using Type B connection.



WARNING - DO NOT CONNECT OR DISCONNECT CABLES WHILE POWER IS APPLIED UNLESS AREA IS KNOWN TO BE NON-HAZARDOUS. USB PORT IS FOR SYSTEM SET-UP AND DIAGNOSTICS AND IS NOT INTENDED FOR PERMANENT CONNECTION.

Serial Ports: Format and Baud Rates for each port are individually software programmable up to 115,200 baud.

PGM Port: RS232 port via RJ12.

COMMS Ports: RS422/485 port via RJ45, and RS232 port via RJ12.

DH485 TXEN: Transmit enable; open collector,  $V_{OH}$  = 15 VDC,  $V_{OL}$  = 0.5 V @ 25 mA max.

Note: For additional information on the communications or signal common and connections to earth ground please see the "Connecting to Earth Ground" in the section "Installing and Powering the G310."

Ethernet Port: 10 BASE-T / 100 BASE-TX

RJ45 jack is wired as a NIC (Network Interface Card).

#### 8. ENVIRONMENTAL CONDITIONS:

**Operating Temperature Range**: 0 to 50 °C **Storage Temperature Range**: -20 to 70 °C

Operating and Storage Humidity: 80% maximum relative humidity (non-

condensing) from 0 to 50  $^{\circ}\text{C}.$ 

Vibration According to IEC 68-2-6: Operational 10 to 55 Hz, in X, Y, Z direction for 1.5 hours, 1 g.

**Shock According to IEC 68-2-27**: Operational 30 g/s, 9 msec in 3 directions. **Altitude**: Up to 2000 meters.

#### 9. CERTIFICATIONS AND COMPLIANCES:

#### **SAFETY**

UL Recognized Component, File #E179259, UL61010-1, CSA 22.2 No.61010-1 Recognized to U.S. and Canadian requirements under the Component Recognition Program of Underwriters Laboratories, Inc.

UL Listed, File #E211967, UL61010-1, UL1604, CSA 22.2 No. 61010-1, CSA 22.2 No. 213-M1987

LISTED by Und. Lab. Inc. to U.S. and Canadian safety standards

Type 4X Enclosure rating (Face only), UL50

IECEE CB Scheme Test Report #E179259-A1-CB-1

Issued by Underwriters Laboratories Inc.

IEC 61010-1, EN 61010-1: Safety requirements for electrical equipment for measurement, control, and laboratory use, Part 1.

IP66 Enclosure rating (Face only), IEC 529

#### **ELECTROMAGNETIC COMPATIBILITY**

Emissions and Immunity to EN 61326: Electrical Equipment for Measurement, Control and Laboratory use.

#### **Immunity to Industrial Locations:**

Immunity to Industrial Locati	ons:	
Electrostatic discharge	EN 61000-4-2	Criterion A
		4 kV contact discharge
		8 kV air discharge
Electromagnetic RF fields	EN 61000-4-3	Criterion A
		10 V/m
Fast transients (burst)	EN 61000-4-4	Criterion A
		2 kV power
		2 kV signal
Surge	EN 61000-4-5	Criterion A
		1 kV L-L,
		2 kV L&N-E power
RF conducted interference	EN 61000-4-6	Criterion B
		3 V/rms
Emissions:		
Emissions	EN 55011	Class A

Notes:

- 1. Criterion A: Normal operation within specified limits.
- 2. Criterion B: Temporary loss of performance from which the unit self-
- 10. CONNECTIONS: Compression cage-clamp terminal block.


Wire Gage: 12-30 AWG copper wire

Torque: 5-7 inch-pounds (56-79 N-cm)

- 11. **CONSTRUCTION**: Steel rear metal enclosure with NEMA 4X/IP66 aluminum front plate when correctly fitted with the gasket provided. Installation Category II, Pollution Degree 2.
- MOUNTING REQUIREMENTS: Maximum panel thickness is 0.25" (6.3 mm). For NEMA 4X/IP66 sealing, a steel panel with a minimum thickness of 0.125" (3.17 mm) is recommended.

Maximum Mounting Stud Torque: 17 inch-pounds (1.92 N-m)

13. **WEIGHT**: 5.53 lbs (2.51 Kg)




# Installing and Powering the G310

## MOUNTING INSTRUCTIONS

This operator interface is designed for through-panel mounting. A panel cutout diagram and a template are provided. Care should be taken to remove any loose material from the mounting cut-out to prevent that material from falling into the operator interface during installation. A gasket is provided to enable sealing to NEMA 4X/IP66 specification. Install the 14 kep nuts provided and tighten evenly for uniform gasket compression.

Note: Tightening the kep nuts beyond a maximum of 17 inch-pounds (1.92 N-m) may cause damage to the front panel.



All tolerances ±0.010" (±0.25 mm).



ALL NONINCENDIVE CIRCUITS MUST BE WIRED USING DIVISION 2 WIRING METHODS AS SPECIFIED IN ARTICLE 501-4 (b), 502-4 (b), AND 503-3 (b) OF THE NATIONAL ELECTRICAL CODE, NFPA 70 FOR INSTALLATION WITHIN THE UNITED STATES, OR AS SPECIFIED IN SECTION 19-152 OF CANADIAN ELECTRICAL CODE FOR INSTALLATION IN CANADA.

#### CONNECTING TO EARTH GROUND



The protective conductor terminal is bonded to conductive parts of the equipment for safety purposes and must be connected to an external protective earthing system.

Each G310 has a chassis ground terminal on the back of the unit. Your unit should be connected to earth ground (protective earth).

The chassis ground is not connected to signal common of the unit. Maintaining isolation between earth ground and signal common is not required to operate your unit. But, other equipment connected to this unit may require isolation between signal common and earth ground. To maintain isolation between signal common and earth ground care must be taken when connections are made to the unit. For example, a power supply with isolation between its signal common and earth ground must be used. Also, plugging in a USB cable may connect signal common and earth ground.<sup>1</sup>

 USB's shield may be connected to earth ground at the host. USB's shield in turn may also be connected to signal common.

#### POWER SUPPLY REQUIREMENTS

The G310C requires a 24 VDC power supply rated at 33 W, and the G310S requires a 24 VDC power supply rated at 25 W. Your unit may draw considerably less the rated power depending upon the options being used. As additional features are used your unit will draw increasing amounts of power. Items that could cause increases in current are additional communications, optional communications card, CompactFlash card, and other features programmed through Crimson.

In any case, it is very important that the power supply is mounted correctly if the unit is to operate reliably. Please take care to observe the following points:

- The power supply must be mounted close to the unit, with usually not more than 6 feet (1.8 m) of cable between the supply and the operator interface. Ideally, the shortest length possible should be used.
- The wire used to connect the operator interface's power supply should be at least 22-gage wire. If a longer cable run is used, a heavier gage wire should be used. The routing of the cable should be kept away from large contactors, inverters, and other devices which may generate significant electrical noise.
- A power supply with a Class 2 or SELV rating is to be used. A Class 2 or SELV power supply provides isolation to accessible circuits from hazardous voltage levels generated by a mains power supply due to single faults. SELV is an acronym for "safety extra-low voltage." Safety extra-low voltage circuits shall exhibit voltages safe to touch both under normal operating conditions and after a single fault, such as a breakdown of a layer of basic insulation or after the failure of a single component has occurred.

# COMMUNICATING WITH THE G310

#### **CONFIGURING A G310**

The G310 is configured using Crimson software. Crimson is available as a free download from Red Lion's website, or it can be purchased on CD. Updates to Crimson for new features and drivers are posted on the website as they become available. By configuring the G310 using the latest version of Crimson, you are assured that your unit has the most up to date feature set. Crimson software can configure the G310 through the RS232 PGM port, USB port, or CompactFlash.

The USB port is connected using a standard USB cable with a Type B connector. The driver needed to use the USB port will be installed with Crimson. If this driver has not been installed, it can be downloaded from the website.

The RS232 PGM port uses a programming cable made by Red Lion to connect to the DB9 COM port of your computer. If you choose to make your own cable, use the "G310 Port Pin Out Diagram" for wiring information.

The CompactFlash can be used to program a G3 by placing a configuration file and firmware on the CompactFlash card. The card is then inserted into the target G3 and powered. Refer to the Crimson literature for more information on the proper names and locations of the files.

#### CABLES AND DRIVERS

Red Lion has a wide range of cables and drivers for use with many different communication types. A list of these drivers and cables along with pin outs is available from Red Lion's website. New cables and drivers are added on a regular basis. If making your own cable, refer to the "G310 Port Pin Outs" for wiring information.

# USB, DATA TRANSFERS FROM THE COMPACTFLASH CARD



WARNING - DO NOT CONNECT OR DISCONNECT CABLES WHILE POWER IS APPLIED UNLESS AREA IS KNOWN TO BE NON-HAZARDOUS. USB PORT IS FOR SYSTEM SET-UP AND DIAGNOSTICS AND IS NOT INTENDED FOR PERMANENT CONNECTION.

In order to transfer data from the CompactFlash card via the USB port, a driver must be installed on your computer. This driver is installed with Crimson and is located in the folder C:\Program Files\Red Lion Controls\Crimson 2.0\ Device\ after Crimson is installed. This may have already been accomplished if your G310 was configured using the USB port.

Once the driver is installed, connect the G310 to your PC with a USB cable, and follow "Mounting the CompactFlash" instructions in the Crimson 2 user manual.

#### **ETHERNET COMMUNICATIONS**

Ethernet communications can be established at either 10 BASE-T or 100 BASE-TX. The G310 unit's RJ45 jack is wired as a NIC (Network Interface Card). For example, when wiring to a hub or switch use a straight-through cable, but when connecting to another NIC use a crossover cable.

The Ethernet connector contains two LEDs. A yellow LED in the upper right, and a bi-color green/amber LED in the upper left. The LEDs represent the following statuses.

LED COLOR	DESCRIPTION
YELLOW solid	Link established.
YELLOW flashing	Data being transferred.
GREEN	10 BASE-T Communications
AMBER	100 BASE-TX Communications

The Crimson manual contains additional information on Ethernet communications.

#### **RS232 PORTS**


The G310 has two RS232 ports. There is the PGM port and the COMMS port. Although only one of these ports can be used for programming, both ports can be used for communications with a PLC.

The RS232 PGM port can be used for either master or slave protocols with any G310 configuration.


Examples of RS232 communications could involve another Red Lion product or a PC. By using a cable with RJ12 ends on it, and a twist in the cable, RS232 communications with another G3 product or the Modular Controller can be established. Red Lion part numbers for cables with a twist in them are CBLPROG0  $^1$ , CBLRLC01  $^2$ , or CBLRC02  $^3$ .

#### G3 RS232 to a PC

Connections			
G3: RJ12	Name	PC: DB9	Name
4	СОММ	1	DCD
5	Tx	2	Rx
2	Rx	3	Tx
	N/C	4	DTR
3	СОМ	5	GND
	N/C	6	DSR
1	CTS	7	RTS
6	RTS	8	CTS
	N/C	9	RI




- <sup>1</sup> CBLPROG0 can also be used to communicate with either a PC or an ICM5.
- <sup>2</sup> DB9 adapter not included, 1 foot long.
- <sup>3</sup> DB9 adapter not included, 10 feet long.



#### RS422/485 COMMS PORT

The G310 has one RS422/485 port. This port can be configured to act as either RS422 or RS485.



Note: All Red Lion devices connect A to A and B to B, except for Paradigm devices. Refer to www.redlion.net for additional information.

#### **DH485 COMMUNICATIONS**

The G310's RS422/485 COMMS port can also be used for Allen Bradley DH485 communications.

WARNING: DO NOT use a standard DH485 cable to connect this port to Allen Bradley equipment. A cable and wiring diagram are available from Red Lion.

#### G3 to AB SLC 500 (CBLAB003)

Connections			
RJ45: RLC	Name	RJ45: A-B	Name
1	TxB	1	A
2	TxA	2	В
3, 8	RxA	-	24V
4, 7	RxB	-	COMM
5	TxEN	5	TxEN
6	COMM	4	SHIELD
4, 7	TxB	-	COMM
3, 8	TxA	-	24V

## **Examples of RS485 2-Wire Connections**

G3 to Red Lion RJ11 (CBLRLC00) DLC, IAMS, ITMS, PAXCDC4C

Connections			
G3: RJ45	Name	RLC: RJ11	Name
5	TxEN	2	TxEN
6	COM	3	СОМ
1	TxB	5	B-
2	TxA	4	A+

#### G3 to Modular Controller (CBLRLC05)

Connections			
G3	Name	Modular Controller	Name
1,4	TxB	1,4	TxB
4,1	RxB	4,1	RxB
2,3	TxA	2,3	TxA
3,2	RxA	3,2	RxA
5	TxEN	5	TxEN
6	СОМ	6	СОМ
7	TxB	7	TxB
8	TxA	8	TxA

# SOFTWARE/UNIT OPERATION

#### **CRIMSON SOFTWARE**

Crimson software is available as a free download from Red Lion's website or it can be purchased on a CD, see "Ordering Information" for part number. The latest version of the software is always available from the website, and updating your copy is free.

#### DISPLAY

This operator interface uses a liquid crystal display (LCD) for displaying text and graphics. The G310C and older G310S displays utilize a cold cathode fluorescent tube (CCFL) for lighting the display. The newer G310S units use an LED backlight. Both backlight types can be dimmed for low light conditions.

Display backlights have a limited lifetime. Backlight lifetime is based upon the amount of time the display is turned on at full intensity. Turning the backlight off when the display is not in use can extend the lifetime of your backlight. This can be accomplished through the Crimson software when configuring your unit.

#### **BACKLIGHT REPLACEMENT**



#### CAUTION: LED Backlight

The LED backlight is not field replaceable. Unit must be returned to Red Lion Controls for repair.

#### **CCFL Backlight**

Backlight is not field replaceable for hazardous location applications. Unit must be returned to Red Lion Controls for repair.

The backlight assembly is field replaceable in non-hazardous locations only. Refer to the instructions included in the appropriate backlight replacement kit.

#### FRONT PANEL LEDS

There are three front panel LEDs. Shown below is the default status of the LEDs.

LED	INDICATION
RED (TOP, LA	ABELED "PWR")
FLASHING	Unit is in the boot loader, no valid configuration is loaded.1
STEADY	Unit is powered and running an application.
YELLOW (MI	DDLE)
OFF	No CompactFlash card is present.
STEADY	Valid CompactFlash card present.
FLASHING RAPIDLY	CompactFlash card being checked.
FLICKERING	Unit is writing to the CompactFlash, either because it is storing data, or because the PC connected via the USB port has locked the drive. <sup>2</sup>
FLASHING SLOWLY	Incorrectly formatted CompactFlash card present.
GREEN (BOT	TOM)
FLASHING	A tag is in an alarm state.
STEADY	Valid configuration is loaded and there are no alarms present.

- The operator interface is shipped without a configuration. After downloading a configuration, if the light remains in the flashing state continuously, try cycling power. If the LED still continues to flash, try downloading a configuration again.
- 2. Do not turn off power to the unit while this light is flickering. The unit writes data in two minute intervals. Later Microsoft operating systems will not lock the drive unless they need to write data; Windows 98 may lock the drive any time it is mounted, thereby interfering with logging. Refer to "Mounting the CompactFlash" in the Crimson 2 User Manual.

#### **KEYPAD**

The G310 keypad consists of eight keys for on-screen menus.

#### **TOUCHSCREEN**

This operator interface utilizes a resistive analog touchscreen for user input. The unit will only produce an audible tone (beep) when a touch on an active touchscreen cell in sensed. The touchscreen is fully functional as soon as the operator interface is initialized, and can be operated with gloved hands.

## **TROUBLESHOOTING YOUR G310**

If for any reason you have trouble operating, connecting, or simply have questions concerning your new G310, contact Red Lion's technical support. For contact information, refer to the back page of this bulletin for phone and fax numbers

EMAIL: <u>techsupport@redlion.net</u> Web Site: <u>http://www.redlion.net</u>

#### **BATTERY & TIME KEEPING**



WARNING - EXPLOSION HAZARD - THE AREA MUST BE KNOWN TO BE NON-HAZARDOUS BEFORE SERVICING/REPLACING THE UNIT AND BEFORE INSTALLING OR REMOVING I/O WIRING AND BATTERY.



WARNING - EXPLOSION HAZARD - DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN DISCONNECTED AND THE AREA IS KNOWN TO BE NON-HAZARDOUS.

A battery is used to keep time when the unit is without power. Typical accuracy of the G310 time keeping is less than one minute per month drift. The battery of a G310 unit does not affect the unit's memory, all configurations and data is stored in non-volatile memory.



#### CAUTION: RISK OF ELECTRIC SHOCK


The inverter board, attached to the mounting plate, supplies the high voltage to operate the backlight. Touching the inverter board may result in injury to personnel.



**CAUTION**: The circuit board contains static sensitive components. Before handling the operator interface without the rear cover attached, discharge static charges from your body by touching a grounded bare metal object. Ideally, handle the operator interface at a static controlled clean workstation. Also, do not touch the surface areas of the circuit board. Dirt, oil, or other contaminants may adversely affect circuit operation.


To change the battery of a G310, remove power, cabling, and then the rear cover of the unit. To remove the cover, remove the five screws designated by the arrows on the rear of the unit. Then, by lifting the top side, hinge the cover, thus providing clearance for the connectors on the bottom side of the PCB as shown in the illustration below. Install in the reverse manner.


Remove the old battery\* from the holder and replace with the new battery. Replace the rear cover, cables, and re-apply power. Using Crimson or the unit's keypad, enter the correct time and date.



\* Please note that the old battery must be disposed of in a manner that complies with your local waste regulations. Also, the battery must not be disposed of in fire, or in a manner whereby it may be damaged and its contents come into contact with human skin.

The battery used by the G310 is a lithium type CR2025.





# **OPTIONAL FEATURES AND ACCESSORIES**

#### INDOOR VERSUS OUTDOOR

Red Lion offers two versions of its G310 unit. The G310C000 uses an overlay with a textured finish and keys that are embossed. This overlay is not rated for outdoor use. The G310S000 uses an overlay with a glossy finish that uses UV rated material for outdoor use. The keys on this overlay are not embossed. The display is significantly brighter than the G310C000.


#### OPTIONAL COMMUNICATION CARD

Red Lion offers optional communication cards for fieldbus communications. These communication cards will allow your G310 to communicate with many of the popular fieldbus protocols.

Red Lion is also offering a communications card for additional RS232 and RS422/485 communications. Visit Red Lion's website for information and availability of these cards.

#### **CUSTOM LOGO**


Each G3 operator interface has an embossed area containing the Red Lion logo. Red Lion can provide custom logos to apply to this area. Contact your distributor for additional information and pricing.



#### **COMPACTFLASH SOCKET**

CompactFlash socket is a Type II socket that can accept either Type I or II cards. Use cards with a minimum of 4 Mbytes and a maximum of 2 Gbytes with the G310's CompactFlash socket. Cards are available at most computer and office supply retailers.

CompactFlash can be used for configuration transfers, larger configurations, data logging, and trending.



Information stored on a CompactFlash card by a G310 can be read by a card reader attached to a PC. This information is stored in IBM (Windows®) PC compatible FAT16 file format.

#### NOTE

For reliable operation of this and other Red Lion products, one of the following brands of CompactFlash card must be used...

SimpleTech SMART® Modular SanDisk® Silicon Systems

Not all of the above manufacturers offer CompactFlash cards recognized to UL standards, which may be required for your application.

#### LIMITED WARRANTY

The Company warrants the products it manufactures against defects in materials and workmanship for a period limited to two years from the date of shipment, provided the products have been stored, handled, installed, and used under proper conditions. The Company's liability under this limited warranty shall extend only to the repair or replacement of a defective product, at The Company's option. The Company disclaims all liability for any affirmation, promise or representation with respect to the products

The customer agrees to hold Red Lion Controls harmless from, defend, and indemnify RLC against damages, claims, and expenses arising out of subsequent sales of RLC products or products containing components manufactured by RLC and based upon personal injuries, deaths, property damage, lost profits, and other matters which Buyer, its employees, or sub-contractors are or may be to any extent liable, including without limitation penalties imposed by the Consumer Product Safety Act (P.L. 92-573) and liability imposed upon any person pursuant to the Magnuson-Moss Warranty Act (P.L. 93-637), as now in effect or as amended hereafter.

No warranties expressed or implied are created with respect to The Company's products except those expressly contained herein. The Customer acknowledges the disclaimers and limitations contained herein and relies on no other warranties or affirmations.

Red Lion Controls Headquarters 20 Willow Springs Circle York PA 17406 Tel +1 (717) 767-6511 Fax +1 (717) 764-0839

Red Lion Controls India 54, Vishvas Tenement GST Road, New Ranip, Ahmedabad-382480 Gujarat, India Tel +91 987 954 0503 Fax +91 79 275 31 350 Red Lion Controls China Unit 101, XinAn Plaza Building 13, No.99 Tianzhou Road ShangHai, P.R. China 200223 Tel +86 21 6113-3688 Fax +86 21 6113-3683

# MultiModem® rCell Intelligent Wireless Router User Guide





#### MultiModem® rCell User Guide

Intelligent Wireless Router MTCBA-Xx-EN2 , MTCBA-Xx-EN2-GP S000485D, Revision D

#### Copyright

This publication may not be reproduced, in whole or in part, without prior expressed written permission from Multi-Tech Systems, Inc. All rights reserved.

Copyright © 2011 by Multi-Tech Systems, Inc.

Multi-Tech Systems, Inc. makes no representation or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose.

Furthermore, Multi-Tech Systems, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Multi-Tech Systems, Inc., to notify any person or organization of such revisions or changes. Check Multi-Tech's Website for current versions of our product documentation.

#### Revisions

Revision	Date	Description
Α	08/31/10	Initial release of MultiModem rCell with GPS and without GPS for C1,E1,G2,H4, and EV2 models.
В	10/25/10	Added Sprint and Verizon Activation into a new Carrier Activation chapter (Chapter 3) and restructured installation.
С	12/27/10	Changed Carrier Activation chapter to incorporate new website activation.
D	10/19/11	Applied template. Removed references to product CD and to printed quick start guide.

#### **Trademarks**

Trademarks and registered trademarks of Multi-Tech Systems, Inc. include MultiModem, the Multi-Tech logo, and Multi-Tech. Windows is a registered trademark of Microsoft Corporation in the United States and other countries. All other products or technologies referenced in this manual are the trademarks or registered trademarks of their respective holders.

#### **Contacting Multi-Tech Support**

#### Online Support Portal: https://support.multitech.com

To better serve our customers, manage support requests and shorten resolution times, we have created the online web portal allowing you to submit questions regarding Multi-Tech products directly to our technical support team. Get answers to your most complex questions, ranging from implementation, troubleshooting, product configuration, firmware upgrades and much more.

To create an account and submit a Support Case on the Portal, visit <a href="https://support.multitech.com">https://support.multitech.com</a>.

#### Knowledge Base and Support Services: www.multitech.com/support.go

The Knowledge Base provides immediate answers to your questions and gives you access to support resolutions for all Multi-Tech products. Visit our support area on the website for other support services.

#### **World Headquarters**

Multi-Tech Systems, Inc.

2205 Woodale Drive, Mounds View, Minnesota 55112 U.S.A. Phone: 763-785-3500 or 800-328-9717 Fax: 763-785-9874

Internet Address: www.multitech.com

#### **Technical Support**

Business Hours: M-F, 9am to 5pm CST

CountryBy EmailBy PhoneEurope, Middle East, Africa:support@multitech.co.uk(44) 118 959 7774

U.S., Canada, all others: support@multitech.com (800) 972-2439 or (763) 717-5863

#### Warranty

Warranty information can be found at: http://www.multitech.com/warranty.go

# **Contents**

Chapter 1 – Product Overview	7
Related Documentation	8
Safety Warnings	9
Ethernet Ports Caution	
Handling Precautions	
RF Interference Issues  Vehicle Safety	
Internal Lithium Battery	
Front Panel	
Package Contents	12
Unbundled Package with No Accessories	12
Bundled Package with Accessories	
Specifications	
RF Specifications	
Cellular Information	
Antenna System for Cellular Devices	
PTCRB Requirements for the Antenna  FCC Requirements for the Antenna	
Antenna Specifications	
Global Positioning System (GPS)	
Technical Specifications	
Global Positioning System (GPS) – Underwriters Laboratories, Inc. Statement	18
RS232 9-Pin Functions of the Female End Connector	18
Chapter 2 – Installing the Router	19
Inserting the SIM Card into Holder, for GSM Network Access	19
Making the Connection	19
Using Optional Direct DC Power	20
Powering Down and Resetting Hardware for MTCBA-C1 Router	
Optional – Attaching the Router to a Flat Surface	
Setting TCP/IP Address	
Setting a Static IP Address	
Configuring Ethernet Interface	
Quickly Configuring the Router by Using Wizard Setup	
Verifying Signal Strength	
Before You Begin	
Activating an Account for Wireless Devices	
Setting Up the Account to Enable Remote Configuration	
Chapter 3 - Using the WEB Management Software	
Software Interface Overview	
Menu Bar Overview	
Submitting, Saving and Restarting Overview	
Overview of the Web Management Software's Interface	
Navigation bar	27

Submenus	_
IP Setup, General Configuration Parameters	29
General Configuration Group	30
IP Configuration Group	
Auto Dial out Configuration Group	30
Syslog Configuration Group	30
Auto Discovery Group	30
Auto Reboot Timer Configuration Group	
Telnet Configuration Group	
Submitting and Saving Your Changes	
IP Setup, HTTP Configuration Parameters	
HTTP Configuration Group	32
Authentication Group	
Submitting and Saving Your Changes	
IP Setup, DDNS Configuration Parameters	
General Group	
·	
Authentication Group	
IP Setup, SNTP Configuration Parameters	
General Configuration Group	
Time Zone Configuration Group	
Daylight Configuration Group	
Daylight Saving Start Time Group	
Daylight Saving End Time Group	
Submitting and Saving Your Changes	
IP Setup, Static Routes Parameters	
Add Static Routes Group	
IP Setup, Remote Configuration Parameters	37
Remote Configuration Group	
IP Setup, GPS Configuration Parameters	38
Local Configuration Group	
Remote Configuration Group	
NMEA Configuration Group	
Communication Examples	
PPP, PPP Configuration Parameters	
· · · · · · · · · · · · · · · · · · ·	
NAT Configuration Group	
PPP General Group	
ICMP Keep Alive Check	
Modem Configuration Group	
Submitting and Saving Your Changes	
PPP, Wakeup-on-Call Parameters	
•	
Wakeup-on-Call Configuration Group	
Caller ID Configuration Group	
Submitting and Saving Your Changes	
Wakeup-On-Call Examples	
PPP, Power-On Configuration Parameters	
PPP, Modem Commands Parameters	51
Modem AT Commands Configuration Group	51
Networks & Services, Network Configuration Parameters	
Network Configuration Group	
Configuring the Network	
Networks & Services, Service Configuration Parameters	
· · · · · · · · · · · · · · · · · · ·	

Service Configuration Group	
Packet Filters, Packet Filters Parameters	
Packet Filter Group	
Packet Filters, DNAT Configuration Parameters	56
DNAT Configuration Group	
Example: Setting Up DNAT and Port Forwarding to an Internal Device	
Packet Filters, Advanced Parameters	58
Connection Tracking Group	58
ICMP Configuration Group	58
Submitting and Saving Your Changes	
GRE Tunnels	58
GRE Tunnels > GRE Tunnels	59
GRE Tunnel Configuration Group	59
GRE Tunnels > GRE Routes Configuration	60
DHCP Server, Subnet Settings	61
General Configuration	61
DHCP Server > Fixed Addresses	62
IPSec	
Authentication and Encryption Overview	63
IPSec > IPSec	
Add an IKE Connection	65
Add Manual Connection	67
Serial-Port, Serial Port Settings Parameters	69
Serial-Port Configuration Group	69
Serial Port, Client Settings Parameters	70
TCP/UDP – Client Configuration Group	
Serial Port, Server Settings Parameters	
TCP/UDP – Server Configuration Group	71
Tools, Tools Parameters	
DDNS Group	73
Modem Group	
Tools, Firmware Upgrade Parameters	
Firmware Upgrade Group	
Tools, Load Configuration Parameters	
Load Configuration Group	
Tools, Save Configuration	
•	
Statistics & Logs	
Statistics & Logs > System Information	
Statistics & Logs > Ethernet	
Statistics & Logs > PPP	
Statistics & Logs > PPP Trace	
Statistics & Logs > DHCP Statistics	
Statistics & Logs > GRE Statistics	
Statistics & Logs > Service Status	
Statistics & Logs > TCP/UDP Client Live Log	
Statistics & Logs > TCP/ODP Client Live Log	
Statistics & Logs > IPSec Live Log	
Statistics & Logs > IPSec Log Traces	
pendix A – Commonly Supported Subnets	
pendix B – Regulatory Compliance	
EMC, Safety, and R&TTE Directive Compliance	86

## Contents

FCC Part 15 Class A Statement	86
Industry Canada	86
Appendix C – Environmental Information	
REACH Statement	87
Restriction of the Use of Hazardous Substances (RoHS)	88
China ROHS	80


# **Chapter 1 - Product Overview**

This User Guide describes the MultiModem® rCell intelligent wireless routers with an Ethernet II interface. You can configure the MultiModem rCell Router for one of three connectivity modes: always-on, wake-up on ring, or dial-on demand.

The always-on network connection automatically establishes a wireless data connection and allows for around the clock surveillance, monitoring or real time data acquisition of any remote Ethernet device such as a Web camera. If the data link is dropped due to poor reception or a complete loss of service, this feature automatically reestablishes the data link.

The wake-up on ring configuration allows the router to "wake up" and initiate a connection when it detects an incoming ring. For security reasons, you can setup the router to wake up based on a particular caller ID number. This configuration is ideal for reducing the costs associated with the modem being online and available 24/7.

When configured for dial-on demand, the router only accesses the Internet when data is present. This configuration is ideal for sharing Internet access among networked computers.



Model	Description
MTCBA-E1-EN2	Quad-band E-GPRS Class 12 performance without GPS option
MTCBA-E1-EN2-GP	Quad-band E-GPRS Class 12 performance with GPS option
MTCBA-G2-EN2	Quad-band GPRS Class 10 performance without GPS option
MTCBA-G2-EN2-GP	Quad-band GPRS Class 10 performance with GPS option
MTCBA-C1-EN2	Multi-band CDMA2000 1xRTT performance without GPS option
MTCBA-C1-EN2-GP	Multi-band CDMA2000 1xRTT performance with GPS option
MTCBA-H4-EN2	Tri-band UMTS/HSPA 7.2 performance without GPS option
MTCBA-H4-EN2-GP	Tri-band UMTS/HSPA 7.2 performance with GPS option
MTCBA-EV2-EN2	Dual-band 800/1900 MHz EV-DO Rev A performance without GPS option
MTCBA-EV2-EN2-GP	Dual-band 800/1900 MHz EV-DO Rev A performance with GPS option

# **Related Documentation**

The following table describes additional documentation for each model.

Model	Additional Documentation
MultiModem MTCBA-E1-EN2 (EDGE)	You can configure the MultiModem MTCBA-E1-EN2 wireless router using the EDGE AT Commands. For more information refer to the Reference Guide for the MultiModem Wireless EDGE Modems, part number S000474x.
MultiModem MTCBA-G2-EN2 (GPRS)	You can configure the MultiModem MTCBA-G2-EN2 wireless modem using the GPRS AT Commands. For more information, refer to the Reference Guide for the MultiModem Wireless GPRS Modems, part number S000463x
MultiModem MTCBA-C1-EN2 (CDMA)	You can configure the MultiModem MTCBA-C1-EN2 wireless router using the CDMA-C1 AT Commands. For more information, refer to the Reference Guide for the MultiModem Wireless CDMA-C1 Modems, part number S000478x.
MultiModem MTCBA-H4-EN2 (HSPA)	You can configure the MultiModem MTCBA-H4-EN2 wireless router using the HSPA AT Commands. These commands are documented in the Reference Guide part number S000483x.
MultiModem MTCBA-EV2-EN2 (EV-DO)	You can configure the MultiModem MTCBA-EV2-EN2 wireless router using the EV-DO AT Commands. These commands are documented in the Reference Guide part number S000482x.

# **Safety Warnings**

#### **Ethernet Ports Caution**

The Ethernet ports are **not** designed to be connected to a Public Telecommunication Network or used outside the building.

## **Handling Precautions**

All devices must be handled with certain precautions to avoid damage due to the accumulation of static charge. Although input protection circuitry has been incorporated into the devices to minimize the effect of this static build up, proper precautions should be taken to avoid exposure to electrostatic discharge during handling and mounting.

**Caution:** Maintain a separation distance of at least 20 cm (8 inches) between the transmitter's antenna and the body of the user or nearby persons. The router is not designed for, nor intended to be, used in applications within 20 cm (8 inches) of the body of the user.

#### **RF Interference Issues**

It is important to follow any special regulations regarding the use of radio equipment due in particular to the possibility of radio frequency, RF, interference. Please follow this safety advice:

- Switch OFF your Wireless MultiModem when in an aircraft. The use of cellular telephones in an aircraft may
  endanger the operation of the aircraft, disrupt the cellular network and is illegal. Failure to observe this
  instruction may lead to suspension or denial of cellular telephone services to the offender, or legal action or
  both.
- Switch OFF your Wireless MultiModem when around gasoline or diesel-fuel pumps and before filling your vehicle with fuel.
- Switch OFF your Wireless MultiModem in hospitals and any other place where medical equipment may be in use.
- Respect restrictions on the use of radio equipment in fuel depots, chemical plants or where blasting operations are in progress.
- There may be a hazard associated with the operation of your Wireless MultiModem close to inadequately
  protected personal medical devices such as hearing aids and pacemakers. Consult the manufacturers of the
  medical device to determine if it is adequately protected.
- Operation of your Wireless MultiModem close to other electronic equipment may also cause interference if the equipment is inadequately protected. Observe any warning signs and manufacturers' recommendations.

# **Vehicle Safety**

- Do not use your Router while driving, unless equipped with a correctly installed vehicle kit allowing 'Hands-Free' Operation.
- Respect national regulations on the use of cellular telephones in vehicles. Road safety always comes first.
- If incorrectly installed in a vehicle, the operation of router telephone could interfere with the correct functioning of vehicle electronics. To avoid such problems, be sure that qualified personnel have performed the installation. Verification of the protection of vehicle electronics should be part of the installation.
- The use of an alert device to operate a vehicle's lights or horn on public roads is not permitted.

## **Internal Lithium Battery**

- A lithium battery located within product provides backup power for the timekeeping capability. The battery has an estimated life expectancy of ten years.
- When the battery starts to weaken, the date and time may be incorrect. If the battery fails, the board must be sent back to Multi-Tech Systems for battery replacement.
- Lithium cells and batteries are subject to the Provisions for International Transportation. Multi-Tech Systems
  Inc. confirms that the Lithium batteries used in the Multi-Tech product(s) referenced in this manual comply
  with Special Provision 188 of the UN Model Regulations, Special Provision A45 of the ICAO-TI/IATA-DGR
  (Air), Special Provision 310 of the IMDG Code, and Special Provision 188 of the ADR and RID (Road and Rail
  Europe).


**Warning!** There is danger of explosion if the battery is incorrectly replaced!

# **Front Panel**

The front panel contains the following LEDs:

- Power and Status LEDs—The Power LED indicates that DC power is present. The Status LED blinks when the unit is functioning normally
- Two Ethernet LEDs—The two Ethernet LEDs indicate transmit and receive activity and connection speed of 10 or 100Mbps on the Ethernet link.
- Two modem LEDs—The two modem LEDs indicate carrier detection and link status.
- Three signal LEDs—The three signal LEDs display the signal strength level of the wireless connection.

The SIM door on the right side of the router provides access to the SIM card holder on the E1, G2, and H4 versions.



	LED Indicators						
Power							
Status	The LED is a solid light when the rCell is booting up, saving the configuration, restarting, or updating the firmware. When the Status LED begins to blink, the router is ready.						
LNK	<b>Link.</b> Blinks when there is transmit and receive activity on the Ethernet link. It shows a steady light when there is a valid Ethernet connection.						
SPD	Speed. Lit when the Ethernet is linked at 100 Mbps. If it is not lit, the Ethernet is linked at 10 Mbps.						
CD	Carrier Detect. Lit when data connection has been established.						
LS		Link Status Depender	nt on Model				
	-E1 version* (AT^SSYNC=1)	G2 version	C1version	-H4 and EV2 versions			
	Permanently off. ME is in one of the following modes: Power Down mode, Airplane mode Non-Cyclic Sleep mode with no temporary wake-up event in progress.  600 ms on/600 ms off	Permanently On: Not registered on network. Flashing states: 200 ms on/2 sec off Registered on	Permanently On: Not registered on network. Flashing states: 200 ms on/2 sec off	Permanently On: Powered on and connected, but not transmitting or receiving. Slow flashing state (5)			
	Limited Network Service: No SIM card inserted or no PIN entered, or network search in progress or ongoing user authentication, or network login in progress.  75 ms on/3 sec off  Idle mode: The mobile is registered to the GSM network (monitoring control channels and user interactions). No call is in progress.  75 ms on/75 ms off/75 ms on/3 sec off  One or more GPRS contexts activated.  500 ms on/25 ms off  Packet switched data transfer in progress.  Permanently on  CSD call — Connected to remote	network.  200 ms on/600 ms off  Registered on the network and communications in progress  100 ms on/200 ms off  Software downloaded is either corrupted or non-compatible ("bad software")	Registered on network.  200 ms on/600 ms off  Registered on the network and communications in progress  100 ms on/200 ms off  Software downloaded is either corrupted or noncompatible ("bad software")	Seconds)  Powered on searching for a connection.  Fast flashing state (0.3 seconds) Transmitting and receiving.			
Signal	party.  ALL OFF - Unit is off, not registered of	n network or extremely we	 				
2.5.101	ALL OFF - Unit is off, not registered on network, or extremely week signal (0 < = RSSI < 6).  1 Bar "ON" – Very weak signal (7 < = RSSI <14)  1 Bar and 2 Bar "ON" – Weak signal (15 < = RSSI <23)  1 Bar, 2 Bar, and 3 Bar "ON" – Good signal (24 <= RSSI > = 31)						

<sup>\*</sup> To be accurate, the AT^SSYNC command must be set to 1 so that the factory default LED timings are used.

# **Package Contents**

This section describes items in the MultiModem rCell package.

Your wireless provider supplies the SIM card.

# **Unbundled Package with No Accessories**

1 router

**Note:** You supply mounting screws, AC or DC power supply, and an antenna.

# **Bundled Package with Accessories**

1 router

1 antenna

1 Ethernet cable

1 RS-232 cable

1 power supply

**Note:** You supply mounting screws.

# **Specifications**

Features	MTCBA-E1-EN2	MTCBA-C1-EN2	MTCBA-G2-EN2	MTCBA-H4-EN2	MTCBA-EV2-EN2
Performance	EDGE: E-GPRS Class 12,	CDMA2000 1xRTT	GPRS Class 10	HSPA	CDMA2000 1xRTT
	GPRS: Class 10				EV-DO Rev. A
Band, Frequency	Quad-band GSM/GPRS/EDGE 850/900/1800/1900 MHz	Dual-band 800/1900 MHz CDMA; 800 MHz and 800/1900 MHz with R-UIM support	Quad-band GSM 850/900/1800/1900 MHz	HSUPA / HSDPA / UMTS Triple-band: 2100/1900/850 MHz with Rx diversity	Dual-band 800/1900 MHz CDMA; 800 MHz and 800/1900 MHz with R-UIM support
Packet Data	EDGE: E-GPRS Up to 240K bps, coding scheme MCS1-9, mobile station Class B, LLC layer, 4 time slots  GPRS: Full PBCCH support, coding scheme 1-4, mobile station Class B	Up to 153.6K bps forward and reverse	Up to 85.6K bps, coding schemes CS1 to CS4	HSDPA data service of up to 7.2 Mbps HSUPA data service of up to 5.76 Mbps	Peak download 3.1 Mbps, peak upload 1.8 Mbps
Circuit-Switched Data	Up to 14.4K bps, non-transparent	IS-95A, IS-95B up to 14.4K bps forward and reverse	Up to 14.4K bps transparent and non-transparent	Up to 14.4K bps transparent and non-transparent	IS-95A, IS-95B up to 14.4K bps forward and reverse
Short Message Services-SMS	Text & PDU, Point-to-Point (MO/MT), cell broadcast	Text & PDU, Point-to-Point (MO/MT), cell broadcast	Text & PDU, Point-to-Point, cell broadcast	Text & PDU, Point-to-Point (MO/MT), cell broadcast	Text & PDU, Point-to-Point (MO/MT), cell broadcast
Antenna	RF Antenna: 50 ohm SMA (female	RF Antenna: 50 ohm SMA (female	RF Antenna: 50 ohm SMA (female		RF Antenna: 50 ohm SMA (female
Connector	connector)	connector)	connector)	connector)	connector)
SIM Connector	Standard 1.8 and 3V SIM receptacle	-	Standard 1.8 and 3V SIM receptacle	Standard 1.8 and 3V SIM receptacle	-
RS232 Connector	DE9				
Power Connector	2.5mm miniature (screw-on)				
Voltage	9V to 32 VDC				
Physical Description	7"W x 1.24"H x 2.93"D 0.75lbs 17.78cmW x3.15cmH x7.44cmD 0.340Kg				
Operating Temperature *	-35° to +75° C*	-40° to +85° C*	-40° to +85° C*	-30° to +60° C*	-40° to +75° C*
Storage Temp	-40° to +85° C				
Humidity	Relative humidity 20% to 90% noncondensing				
Certifications	EMC Compliance	EMC Compliance	EMC Compliance	EMC Compliance	EMC Compliance
	FCC Part 15	FCC Part 15	FCC Part 15	FCC Part 15	FCC Part 15
	EN55022	Radio Compliance	EN55022	EN55022	Radio Compliance
	EN55024	FCC Part 22, 24	EN55024	EN55024	FCC Part 22, 24
	Radio Compliance	RSS132,133	Radio Compliance	Radio Compliance	RSS132,133

Features	MTCBA-E1-EN2	MTCBA-C1-EN2	MTCBA-G2-EN2	MTCBA-H4-EN2	MTCBA-EV2-EN2
	FCC Part 22, 24	Safety: UL60950-1	FCC Part 22, 24	FCC Part 22, 24	<b>Safety:</b> UL60950-1
	RSS132,133	cUL60950-1	RSS132,133	RSS132,133	cUL60950-1
	EN301 489-1	IEC60950-1	EN301 489-1	EN301 489-1	IEC60950-1
	EN489-3 (-GP only)	Network: CDG 1&2	EN489-3 (-GP only)	EN489-3 (-GP only)	Network: CDG 1&2
	EN301 489-7		EN301 489-7	EN301 489-7	
	EN301 511		EN301 511	EN301 511	
	AS/ACIF S042.1, S042.3		AS/ACIF S042.1, S042.3	AS/ACIF S042.1, S042.3	
	<b>Safety:</b> UL60950-1		<b>Safety:</b> UL60950-1	<b>Safety:</b> UL60950-1	
	cUL60950-1		cUL60950-1	cUL60950-1	
	IEC60950-1		IEC60950-1	IEC60950-1	
	Network: PTCRB		AS/NZS60950-1	Network: PTCRB	
			Network: PTCRB		

<sup>\*</sup> UL Listed @ 40° C, limited by power supply. UL Certification does not apply or extend to an ambient above 40° C and has not been evaluated by UL for ambient greater than 40° C.

### **Power Specifications**

MTCBA-E1-EN2	MTCBA-C1-EN2	MTCBA-G2-EN2	MTCBA-H4-EN2	MTCBA-EV2-EN2
Sleep:0.175A,1.6W@9V,	Sleep: 0.186A,1.7W @ 9V,	Sleep:0.163A,1.5W @ 9V,	GSM 850	CDMA2000
0.090A,1.8W@ 20V,	0.091A,1.8W @ 20V,	0.082A,1.6W @ 20V,	Sleep 0.205A, 1.89W @9v, 0.110A,	Sleep 0.125A, 1.15W @9v, 0.060A,
0.060A,1.9W @ 32V	0.061A, 2.0W @ 32V	0.055A,1.8W @ 32V	2.20W @20v, 0.068A, 2.18W @32v	1.20W @20v, 0.044A, 1.41W @32v <b>Typical</b> 0.215A, 1.98W @9v,
Typical: 0.277A, 2.5W@9V,	<b>Typical:</b> 0.283A, 2.6W @ 9V,	Typical: 0.240A, 2.2W @ 9V,	<b>Typical</b> 0.240A, 2.21W @9v, 0.114A, 2.28W @20v, 0.077A, 2.46W @32v	0.130A, 2.60W @20v, 0.085A, 2.72W @32v
0.133A, 2.7W@ 20V,	0.137A, 2.7W @ 20V,	0.114A, 2.3W @ 20V,	Max 0.429A, 3.91W @9v, 0.153A,	Max 0.600A, 5.45W @9v, 0.297A,
0.089A, 2.8W @ 32V	0.088A, 2.8W @ 32V	0.077A, 2.5W @ 32V	3.06W @20v, 0.100A, 3.20W @32v	5.94W @20v, 0.195A, 6.05W @32v
Max: 0.506A, 4.5W @ 9V,	Max: 0.457A, 4.1W, @ 9V,	Max: 0.340A, 3.0W @ 9V,	Peak 2.50A @9v, 0.812A @20v, 0.500A @32v	<b>EV-DO Sleep</b> 0.125A, 1.15W @9v, 0.060A,
0.240A, 4.8W @ 20V,	0.214A, 4.3W, @ 20V,	0.153A, 3.1W @ 20V,	HSPA	1.20W @20v, 0.044A, 1.41W @32v
0.150A, 4.8W @ 32V	0.138A, 4.4W @ 32V	0.100A, 3.2W @ 32V	Sleep 0.205A, 1.89W @9v, 0.110A,	<b>Typical</b> 0.335A, 3.08W @9v, 0.190A, 3.30W @20v, 0.125A,
Peak: 2.50A @ 9V, 1.00A @ 20V,		Peak: 1.300A @ 9V,0.518A @	2.20W @20v, 0.068A, 2.18W @32v	4.00W @32v
0.60A @ 32V		20V, 0.343A @ 32V	<b>Typical</b> 0.480A, 4.38W @9v, 0.230A, 4.60W @20v, 0.148A, 4.74W @32v	Max 0.672A, 6.10W @9v, 0.320A, 6.40W @20v, 0.204A, 6.53W @32v
			Max 0.640A, 5.79W @9v, 0.290A,	

<sup>&</sup>quot; UL has evaluated this device for use in ordinary locations only. Installation in a vehicle or other outdoor locations has not been evaluated by UL. UL Certification does not apply or extend to use in vehicles or outdoor applications or in ambient above 40° C."

		5.80W @20v, 0.190A, 6.08W @32v	
MTCBA-C1-EN2-GP	MTCBA-G2-EN2-GP	1. MTCBA-H4-FN2 <b>-GP</b>	2. MTCBA-EV2-EN2-GP
		<u></u>	
<b>Sleep:</b> 0.186A,1.7W @ 9V,	<b>Sleep:</b> 0.195A,1.8W @ 9V,	GSM 850	CDMA2000
0 091A 1 8W @ 20V	0.099A 2.0W @ 20V	Sloop 0 270A 2 48W @0v 0 120A	Sleep 0.245A, 2.26W @9v, 0.125A,
0.00,	0.000.1,2.011 @ 201,	•	2.50W @20v, 0.083A, 2.66W @32v
0.061A,2.0W @ 32V	0.066A,2.1W @ 32V	2.000V @20V, 0.007A, 2.70VV @32V	Typical 0.340A, 3.12W @9v,
Typical: 0.394A 3.5W @ 0V	Typical: 0.2954, 2.6W/ @ 0V/	Typical 0.320A, 2.94W @9v, 0.160A,	0.166A, 3.32W @20v, 0.110A,
Typical. 0.364A, 3.5W @ 9V,	Typical. 0.205A, 2.000 @ 90,	3.20W @20v, 0.104A, 3.33W @32v	3.52W @32v
0.193A, 3.9W @ 20V,	0.136A, 2.7W @ 20V,	Max 0.590A, 5.37W @9v, 0.280A,	Max 0.690A, 6.27W @9v, 0.330A,
	0.0004 0.004 0.004	5.60W @20v, 0.180A, 5.76W @32v	6.60W @20v, 0.210A, 6.72W @32v
0.122A, 3.9W @ 32V	0.093A, 3.0W @ 32V	Peak 2 50A @9v 0 812A @20v 0 500A	EV-DO
Max: 0.541A 4.8W @ 9V	Max: 0 408A 3 7W @ 9V		
			Sleep 0.0465A, 2.27W @9v, 0.125A,
0.256A, 5.1W, @ 20V,	0.183A, 3.7W @ 20V,	I I I I I	2.50W @20v, 0.238A, 7.62W @32v
0.1634 5.314 @ 3314	0.1204 2.814 @ 2214	Sleep 0.270A, 2.48W @9v, 0.130A,	<b>Typical</b> 0.370A, 3.40W @9v, 0.220A,
0.162A, 5.2VV @ 32V	0.120A, 3.6VV @ 32V	2.60W @20v, 0.087A, 2.78W @32v	4.40W @20v, 0.145A, 4.64W @32v
	Peak: 2.25A @ 9V, 0.960A@	Typical 0.540A, 4.93W @9v, 0.265A,	Max 0.780A, 7.13W @9v, 0.374A,
	001/ 0.0504 @ 001/	5.30W @20v, 0.172A, 5.50W @32v	7.48W @20v, 0.385A, 7.62W @32v
	20V, 0.650A @ 32V	Max 0.780A. 7.06W @9v. 0.370A.	
	Typical: 0.384A, 3.5W @ 9V, 0.193A, 3.9W @ 20V, 0.122A, 3.9W @ 32V  Max: 0.541A, 4.8W, @ 9V,	Sleep: 0.186A,1.7W @ 9V,	MTCBA-C1-EN2-GP  Sleep: 0.186A,1.7W @ 9V,

Note: Multi-Tech Systems, Inc. recommends that the customer incorporate a 10% buffer into their power source when determining product load.

# **RF Specifications**

	GSM 850	EGSM 900	GSM 1800	GSM 1900	CDMA 800	CDMA 1900
Frequency RX	869 to 894 MHz	925 to 960 MHz	1805 to 1800 MHz	1930 to 1990 MHz	869 to 894 MHz	1930 to 1990 MHz
Frequency TX	824 to 849 MHz	880 to 915 MHz	1710 to 1785 MHz	1850 to 1910 MHz	824 to 849 MHz	1850 to 1910 MHz
RF Power Stand	2W at 12.5% duty cycle	2W at 12.5% duty cycle	1W at 12.5% duty cycle	1W at 12.5% duty cycle	-	-

## **Cellular Information**

## **Antenna System for Cellular Devices**

The cellular/wireless performance depends on the implementation and antenna design. The integration of the antenna system into the product is a critical part of the design process; therefore, it is essential to consider it early so the performance is not compromised. If changes are made to the certified antenna system of the MultiModem, then recertification is required by specific network carriers such as Sprint. The Antenna System is defined as the UFL connection point from the MultiModem to the specified cable specifications and specified antenna specifications.

## PTCRB Requirements for the Antenna

There cannot be any alteration to the authorized antenna system. The antenna system must maintain the same specifications. The antenna must be the same type, with similar in-band and out-of-band radiation patterns.

## **FCC Requirements for the Antenna**

The antenna gain, including cable loss, for the radio you are incorporating into your product design must not exceed the requirements at 850 MHz and 1900 MHz as specified by the FCC grant for mobile operations and fixed mounted operations as defined in 2.1091 and 1.1307 of the FCC rules for satisfying RF exposure compliance. The antenna used for transmitting must be installed to provide a separation distance of at least 20cm from all persons and must not transmit simultaneously with any other antenna transmitters. User and installers must be provided with antenna installation instructions and transmitter operating conditions to satisfying RF exposure compliance.

## **Antenna Specifications**

### **CDMA RF Specifications**

	CDMA 800	CDMA 1900	
Frequency RX	869 to 894 MHz	1930 to 1990 MHz	
Frequency TX	824 to 849 MHz	1850 to 1910 MHz	

### **CDMA Antenna Requirements/Specifications**

Frequency Range 824 – 894 MHz / 1850 – 1990 MHz	
Impedance	50 Ohms
VSWR	VSWR shall not exceed 2.0:1 at any point across the bands of operation
Typical Radiated Gain	3 dBi on azimuth plane
Radiation	Omni-directional
Polarization	Vertical
Antenna Loss	Free space not to exceed -3dB
TRP/TIS	The total radiated power (TRP) at the antenna shall be no less than +21/20 dBm for PCS/CELL channels respectively, and the total isotropic sensitivity (TIS) at the antenna shall be no less than -104/104 dBm for PCS/CELL channels respectively.

### **GSM/EGSM RF Specifications**

	GSM 850	EGSM 900	GSM 1800	GSM 1900
Frequency RX	869 to 894 MHz	925 to 960 MHz	1805 to 1880 MHz	1930 to 1990 MHz
Frequency TX	824 to 849 MHz	880 to 915 MHz	1710 to 1785 MHz	1850 to 1910 MHz

## **GSM Antenna Requirements/Specifications**

Frequency Range	824 – 960 MHz / 1710 – 1990 MHz	
Impedance	50 Ohms	
VSWR	VSWR shall not exceed 2.0:1 at any point across the bands of operation	
Typical Radiated Gain	3 dBi on azimuth plane	
Radiation	Omni-directional	
Polarization	Vertical	
Antenna Loss Free space not to exceed -3db		
TRP/TIS	Including cable loss the total radiated power (TRP) at the antenna shall be no less than +22/24.5 dBm for 850/1900 MHz respectively, and the total isotropic sensitivity (TIS) at the antenna shall be no less than -99/101.5 dBm for 850/1900 MHz respectively.	

### **GPS (Global Positioning) RF Specifications**

	GPS L1
Frequency RX	1575.42
LNA Bias Voltage	5V
LNA Current Consumption	40mA Max

## **GPS Antenna Requirements/Specifications**

Frequency	1575MHz
Impedance	50 Ohms
VSWR	1.5db
Input voltage	3.0V +/- 0.3V
GPS TIS	The total isotropic sensitivity (TIS) at the antenna shall be no less than 47 dBm

# **Global Positioning System (GPS)**

Point the GPS toward the sky, as the GPS antenna needs to find the satellites that provide location information.

# **Technical Specifications**

Receiver Type L1 Frequency, GPS C/A code, SBAS Capable, 51 Channel Acquisitions, 14 Channel Tracking		
Accuracy	Position 2.5m CEP, Velocity 0.1m/sec	
Open Sky TTFF	Hot start 1 second, Cold start 29 seconds average, Reacquisition <1s	
Sensitivity Tracking	-161dBm	
Update Rate	1 Hz standard	
Dynamics	4G	
Operational Limits	Altitude <18,000m or Velocity < 515m/s	
Datum	Default WGS-84	
Interface	UART	
Protocol NMEA-0183, V3.01, GGA, GLL, GSA, GSV, RMC, VTG		

# Global Positioning System (GPS) - Underwriters Laboratories, Inc. Statement

Underwriters Laboratories Inc. ("UL") has not tested the performance or reliability of the Global Positioning System ("GPS") hardware, operating software or other aspects of this product. UL has only tested for fire, shock or casualties as outlined in UL's Standard(s) for Safety.UL60950-1 Certification does not cover the performance or reliability of the GPS hardware and GPS operating software. UL MAKES NO REPRESENTATIONS, WARRANTIES OR CERTIFICATIONS WHATSOEVER REGARDING THE PERFORMANCE OR RELIABILITY OF ANY GPS RELATED FUNCTIONS OF THIS PRODUCT.

## **RS232 9-Pin Functions of the Female End Connector**

The following table explains the pin functions.

External Power		Serial Cable
Signal	IN/OUT	Female Connector
Pin 1 CD	0	Pin 5, Pin 1
Pin 2 RX	0	,
Pin 3 TX	I	
Pin 4 DTR	I	
Pin 5 GND		
Pin 6 DSR*	0	
Pin 7 RTS	I	Pin 9 Pin 6
Pin 8 CTS	0	
Pin 9 RI	0	

**Note:** The DSR signal on pin 6 is always asserted by the router.


# Chapter 2 - Installing the Router

## Inserting the SIM Card into Holder, for GSM Network Access

The router requires the power supply connection to begin operation. It also requires a SIM card (Subscriber Identity Module) to operate on a GSM network. To install the SIM, do the following:

1. Using a small Phillips screwdriver, remove the two SIM door screws and remove the SIM door.

**Note:** When changing a SIM, ensure that power is removed from the unit.



- 2. Insert the SIM card into the card holder. The above graphic illustrates the correct SIM card orientation.
- 3. Verify that the SIM card fits into the holder properly and then replace the cover.

# **Making the Connection**



- 1. Connect a suitable antenna to the SMA connector (see antenna specifications in Chapter 1)
- 2. Optional: If you have the GPS version, connect a suitable GPS antenna to the GPS connector. Ensure that when you position the GPS antenna, the antenna can see the sky to locate the satellites for accurate values.
- 3. Using an Ethernet cable, connect one end of the cable to the ETHERNET connector on the back of the router and the other end to your computer either directly or through a switch or hub.
- 4. If you are connecting a customer's serial legacy device to the router, connect the serial, RS-232 cable from the customer's device to the RS232 connector on the back of the router.
- **5.** Depending on the power source, connect either the power supply module with the appropriate blade or the optional DC power cable. If you are using the power supply module, remove the protective shipping cover. Attach the appropriate interchangeable blade piece to the power supply module.



**6.** Screw on the power lead from the power supply module into the power connection on the router. Plug the power supply into your power source.

## **Using Optional Direct DC Power**

- 1. Screw-on the DC power cable to the power connector on the router.
- 2. Then attach the two wires at the other end of the DC power cable to a DC fuse/terminal block in which you are mounting the router.
- 3. Connect the red wire to the "+" (positive) terminal and the black wire to the "-" (negative) terminal. Be sure the GND connection is correct.

**Warning:** Over-voltage protection is provided on the device. To ensure complete protection, you may want to add additional filtering to the DC input.

#### **Notes:**

- For an application involving a battery: you can use permanent "+" or key-switched "+" source. Connect the power supply to its source (for example, in a mobile situation, to the DC fuse/terminal block).
- The POWER LED. The POWER LED lights after power-up.
- The **Status** LED is a solid ON when the router is booting up, saving a configuration, or updating firmware. When the **Status** LED begins to blink, the router is ready.

#### **Using the Reset Button**

Press and hold in the **Reset** button until the Status Light goes out. Then release the button. This sets the username and password back to admin and admin, as well as sets the IP address to the default of 192.168.2.1.

## Powering Down and Resetting Hardware for MTCBA-C1 Router

Before you turn off power to the router, and before you reset the hardware, it is recommended you complete the following sequence.

The shutdown sequence informs the network that the mobile station is going offline, and saves critical data to the module's non-volatile memory (flash).

1. Issue the following command:

AT+CFUN=0 (issue this command)

2. Wait for this response from the modem

+WIND:10 ()

You can now power off the router or reset it.

If you do not see the +WIND:10 response, you may need to activate the unsolicited message by using the command AT+WUSLMSK=00020000,0

# **Optional - Attaching the Router to a Flat Surface**

Before you mount your router to a permanent surface, verify signal strength. For more information, refer to Verify Signal Strength in this chapter.


The router can be panel mounted with screws spaced according to the measurement shown.

Note: Use either #6 or #8 pan head screws for all four mount locations.

# **Setting TCP/IP Address**


This section describes how to configure a TCP/IP address so the computer can communicate with the router.

1. From the **Start** menu, select **Control Panel**. In the window that opens, double-click **Network Connections**. The **Network Connections** window opens.




2. Right-click Local Area Connection. From the menu that appears, select Properties.

The Local Area Connection Properties window opens.



- 3. Select Internet Protocol [TCP/IP].
- 4. Click **Properties**. The Internet Protocol (TCP/IP) Properties window opens.



**Note:** If this window displays your current IP configuration, it is recommended that you record this information for future reference. This information is handy, for example, if you want to return the computer to its original settings.

## **Setting a Static IP Address**

To set a static IP address:

- 1. Select Use the following IP address.
- 2. In the IP address field type the IP address of the computer, for example 192.168.2.x.

Note: The x in the address stands for numbers 101 and up.

- 3. In the Subnet mask field, type the number of the subnet mask, for example: 255.255.255.0
- 4. In the **Default Gateway** field, type the default gateway, for example, 192.168.2.1

**Note:** The computer settings must be in the same subnet range as the router.

The factory default settings for the router are:

**IP Address**: 192.168.2.1

Subnet Mask: 255.255.255.0

- 5. Select Use the following DNS server addresses.
  - a. Enter the IP Address for the Preferred DNS Server. Example: 205.171.3.65
  - b. Click OK.
- 6. To close the Local Area Properties window, click **OK**.
- 7. Close the Control Panel.
- 8. Repeat these steps for each computer on your network.

# **Configuring Ethernet Interface**

You use the router's factory-installed Web Management software to configure the Ethernet interface. Access this software using a Web browser.

- 1. Ensure that the Status LED is blinking, indicating that the router is ready.
- 2. On the computer, open a Web browser
- 3. In the browser's address field, type the default Gateway Address: http://192.168.2.1
- 4. After entering the Address, the Login page opens.



- a. In the **User Name** field, type the default user name: **admin** (all lower-case).
- b. In the **Password** field, type the default password: **admin** (all lower-case).
- c. Click **Login**. The Web Management Home page opens.

The user name and password are case-sensitive. You must use lower-case for both.

A password can be up to 12 characters. If Windows displays the **AutoComplete** message, click **No** so that the operating system does not remember the password. This helps maintain computer security.

It is recommended that you change the default password to better protect the security of your router. Use a safe password.

## **Quickly Configuring the Router by Using Wizard Setup**

The Wizard Setup tool helps you quickly configure the router. Benefits of using this tool include:


- Saves time by allowing you to configure the basic setup in one place.
- The information entered defaults to other windows that require this information.
- Lets you enter and save information needed to create a connection to the Internet.

This section describes how to configure the basic parameters to start using your router. You can configure more than the basics by using other features of the Web Management software. For more information, see Chapter 3.

To use Wizard Setup to setup basic router features:

1. From the Web Management software's menu bar, select Wizard Setup.

2. The Wizard Setup page opens, where a minimum router configuration is provided.



The table that follows describes the basic parameters you need to set before you can connect to the Internet.

IP Configuration				
IP Address	The default is 192.168.2.1. To change it, type a new IP address.			
Mask	The default is 255.255.255.0			
DNS	Enter the primary DNS IP address for the system. The default is 0.0.0.0			
PPP Configuration				
PPP	The default is <b>disable</b> . To connect to the Internet, you need to enable PPP.			
	Depending on the model, commands may need to be issued to the integrated cellular modem			
	before connecting to the wireless service. To issue commands to the integrated cellular			
	modem, PPP must be disabled and telnet port 5000 used.			
Dial-on-Demand	The default is <b>disable</b> .			
Idle Time Out	Sets the time the PPP link stays active before disconnecting. Setting the value to zero causes			
	the link to stay active continuously.			
Dial Number	Enter the dial number. This number connects you to the Internet.			
	For GSM, the number is *99***1#.			
	For CDMA, the Dial Number is <b>#777</b> .			
APN	For GSM models, enter the APN (Access Point Name). Your wireless service provider assigns the			
	APN. If you don't know the name, ask your provider for it.			
	An access point is an IP network to which a MultiModem rCell Router connects. The Web			
	Management software asks for the APN on the Wizard Setup and the PPP screen.			
	For CDMA models, the APN does not apply.			
Init String	You can set up to 4 router initialization strings.			
PPP Authentication				
Authentication Type	Select the radio button of the authentication protocol used to negotiate with the remote peer:			
·	PAP, CHAP, or PAP-CHAP. The default is PAP-CHAP			
Username	Enter the PPP Username. This name authenticates the remote peer.			
Password	Enter the PPP Password. This password authenticates the remote peer.			

- 3. To save changes, click **Submit**.
- **4.** To cause your changes to go into effect, from the Menu bar, click **Save & Restart**. The router reboots.

You don't need to click **Save & Restart** after every change you make. You can submit several changes on various pages, and then click **Save & Restart**.

# **Verifying Signal Strength**

This section describes how to verify signal strength by using telnet to communicate directly with the modem.

## **Before You Begin**

- Ensure that the Status LED is blinking, indicating that the router is ready.
- Ensure that PPP is disabled.

To verify signal strength:

- 1. Use one of the following methods to open a command prompt:
  - From the Start menu, select Run. In the Open window, enter cmd and then press ENTER.
  - From the Start menu, select All Programs, Accessories, Command Prompt
- 2. In the command window, type telnet 192.168.2.1 5000
- 3. At the Login prompt, type the default user name: admin (all lower-case). Press ENTER
- 4. At the Password prompt, type the default password: admin (all lower-case). Press ENTER
- 5. In the command window, type AT+CSQ. The router responds with the received signal strength (rssi).

Signal Strength – RSSI				
10 – 31	Sufficient			
0 – 9	Weak or Insufficient			
99	Insufficient			

6. To find the best location in which to run the router, check the signal from a few different locations.

# **Verifying Provider Fees**

Your provider charges you for data usage so be aware of your payment obligations. If you use the router for large data transfers, Multi-Tech recommends an unlimited data plan with your account. Multi-Tech is not responsible for any charges relating to your cellular bill.

# **Activating an Account for Wireless Devices**

See Multi-Tech's Cellular Activation Website at <a href="http://www.multitech.com/activation.go">http://www.multitech.com/activation.go</a> for information on activating your cellular modem.

## **Setting Up the Account to Enable Remote Configuration**

You can remotely configure the MultiModem over the Internet if your wireless provider has provisioned some features for you.

- Make sure your wireless network provider has provisioned for mobile terminated data.
- The provider also needs to setup a fixed or dynamic public IP address to which the network can redirect any incoming connection.

# Chapter 3 - Using the WEB Management Software

This chapter describes how to configure the router by using the Web Management software.

## **Software Interface Overview**

This section explains the menu structure and the navigation buttons of the router's Web Management software.

### **Menu Bar Overview**



You can select the following items from the menu bar:


IP Setup	Sets up a General Configuration, HTTP, DDNS, SNTP, Static Routes, and Remote Configuration.
PPP	Used to configure the PPP authentication, dial-on-demand, router authentication, and Wakeup on Call.
Networks & Services	Used to configure networks and services to make them available to other functions such as allowed packet filters, static routes, remote configuration, DNAT, and GRE tunnels and routes.
Packet Filters	Defines filter rules, DNAT configuration, and ICMP rules.
GRE Tunnels	Used to define Generic Routing Encapsulation (GRE). Defines the remote network and the tunnel through which traffic is routed.
DHCP Server	Used to configure the DHCP server settings.
IPSec	Allows the device to support LAN-to-LAN VPN tunneling with 3DES and AES 128-192-256 encryption support
Serial Port	Adds support for RS-232 serial port so that Ethernet and legacy serial devices can share the same cellular connection.
Tools	Sets DDNS Force Update, displays DDNS Status, resets the modem, and provides interfaces for Firmware Upgrade, Load Configuration, and Save Configuration.
Statistics & Logs	Shows statistics and logs maintained by the router.
Save & Restart	Saves your settings and reboots your router.
Help Index	Opens the online Help file.

# **Submitting, Saving and Restarting Overview**

Nearly every page of the software's interface includes a Submit button. This button allows you to save changes you make to the software pages and their parameters.

To ensure your changes go into effect, you must eventually use **Save & Restart**, located on the Menu bar. You do not need to click Save& Restart after each change you make. You can change several areas, and then click Save & Restart.

# Overview of the Web Management Software's Interface



# **Navigation bar**


Home	To return to the home page, click <b>Home</b> .
Wizard Setup	To use the Wizard Setup tool for quick set up of your MultiModem, click Wizard Setup. This tool helps you configure basic settings needed to run the rCell Router.
Logout	To log out of the software, click <b>Logout</b> . You return to the login screen.
Help	To open an online help file, click <b>Help</b> .

## **Submenus**

The submenus display on the left side of the page. The following table lists the submenu selections under each main menu category.

IP Setup	PPP	Networks & Services	Packet Filters	GRE Tunnels
General Configuration HTTP Configuration DDNS Configuration SNTP Configuration Static Routes Remote Configuration GPS Configuration	PPP Configuration Wakeup on Call Power On Config Modem Commands	Network Configuration Service Configuration	Packet Filters DNAT Configuration Advanced	GRE Tunnels GRE Routes
DHCP Server	IPSec	Serial Port	Tools	Statistics & Logs
Subnet Settings Fixed Addresses	IP Sec	Serial Port Settings Client Settings Server Settings	Tools Firmware Upgrade Load Configuration Save Configuration	SysInfo Ethernet PPP PPP Trace DHCP Statistics GRE Statistics Modem Info Service Status TCP/UDP Client Live Log TCP/UDP Server Live Log IPSec Live Log IPSec Log Traces

# **IP Setup, General Configuration Parameters**



## **General Configuration Group**

In the General Configuration group, set the general system-based parameters.

**Date** The system date: **MM/DD/YYYY** 

**Time HH:MM:SS**. A real time clock is part of SNTP to display proper time.

## **IP Configuration Group**

Use the IP Configuration group to configure the Ethernet interface. If desired see Appendix A for a table of commonly supported subnets.

IP Address (Default is 192.168.2.1),

Mask (Default 255.255.255.0),

Default Gateway (Default 0.0.0.0),
Primary DNS (Default 0.0.0.0),
Secondary DNS (Default 0.0.0.0).

## **Auto Dial out Configuration Group**

Auto Dialout Check the box to enable or disable Auto Dialout. Default is Enable. The Auto Dialout settings allow you

to use the integrated cellular modem directly with no router functions. This is accomplished using redirector software on your computer. This software creates a virtual serial port allowing your

computer to communicate with the integrated cellular modem over IP using telnet.

**Raw Dialout** Check the box to enable or disable raw mode for an Auto Dialout session. Default is Disable.

**Auto Dialout** 

Login

Check the box to enable or disable Auto Dialout Login feature. Default is Enable. The Auto Dialout port is the telnet port used by the redirector software on your computer to communicate to the integrated

cellular modem.

**Auto Dialout Port** Enter the serial Auto Dialout Port number. Default is 5000.

Handle EIA Signal Check the box to enable or disable the EIA standard signal characteristics (time and duration) used

between different electronic devices.

**Inactivity** Enter the seconds that the auto dialout session stays active before going inactive.

## **Syslog Configuration Group**

**Syslog** Check the box to enable or disable Syslog. Default is Disable.

**Syslog Server IP** 

**Address** 

If a Remote Syslog Server IP Address is specified, the syslog feature acts as a remote Syslog.

## **Auto Discovery Group**

Auto Discovery Check the box to enable or disable Auto Discovery to broadcast (MAC level), the MAC Address, IP

Address, and DHCP information to the configured server port. Default is Enable. The router sends a broadcast packet on the specified server port every 10 seconds or whatever interval the broadcast

timer is set to.

**Server Port** Enter the Server Port Number. Default port is 1020.

**Broadcast Timer** Enter the amount of time in seconds for the auto-discovery packet granularity of periodic

broadcasting. Default is 10 seconds.

## **Auto Reboot Timer Configuration Group**

**Auto Reboot Timer:** Enter the hours that lapse between each automatic reboot. The default of zero deactivates the timer. Range is 0 to 999.

## **Telnet Configuration Group**


Enables or disables the Telnet port. The default is Enable. This is specifically for telnet port 23 for technical support debug. You can still access the integrated cellular modem using port 5000 when this is disabled. Ensure that PPP is also disabled before telnetting to the port.

## **Submitting and Saving Your Changes**

Click **Submit** to save these settings.

Click Save and Restart after you complete and submit all the pages where you changed parameters.

# **IP Setup, HTTP Configuration Parameters**



## **HTTP Configuration Group**

**HTTP Port** Enter the port number on which the HTTP server listens for requests. The default is 80.

HTTP Time-Out Set the HTTP session in seconds. The default is 120 seconds.

## **Authentication Group**

Use the Authentication group to change the user name and password. The Username and password combination provide access the Web Management software, as well as telnet access to the router and integrated cellular modem.

**Username** Enter the name of a user who is allowed access to the Web Management software. Default is

admin.

Password Enter the Password associated with the user who is allowed access to the Web Management

software. Default is **admin**. It can be up to100 characters. Use a safe password. Your first name spelled backwards is not a sufficiently safe password; a password similar to xfT35\$4 is better.

## **Submitting and Saving Your Changes**

To save these settings, click Submit.


To ensure your changes go into effect, click **Save and Restart**.

# **IP Setup, DDNS Configuration Parameters**

DDNS (Dynamic Domain Naming System) allows you to have a static domain name with a dynamic IP address.

When the dynamic IP address changes, it is submitted to the DDNS server. Here, the domain name is updated to point to the new IP address.

You must register with a DDNS server to use this feature.



## **General Group**

This section describes the parameters that you can configure in the General group.

**DDNS** Check the Enable or Disable box. This enables/disables DDNS. Default is Disable.

Use Check IP Check the Enable or Disable box. If enabled, the program queries the server to determine the

IP address before it performs the DDNS update (the IP address is still assigned by the wireless provider and the DDNS is updated based on the address returned by Check IP Server). If disabled, the program performs the DDNS update using the IP address that it obtains from

the PPP link. Default is Enable.

**Check IP Server** Enter the Server name from which the currently assigned IP address is obtained. This server is

a server the router accesses to check its current IP address.

**Check IP Port** Enter the port number of the Check IP Server. Default is 80.

**Server** Enter the Server name to which the IP Address change is registered; for example,

members.dyndns.org

**Port** Enter the Server port number. Default is 80.

**Max Retries** Enter the maximum number of tries that are allowed if the update fails. Default is 5. Range is

0 - 100.

**Update Interval** Enter the interval, in days, that lapse before the IP Address can change. At the end of this

interval, the existing IP Address is updated in the server so that it does not expire. Default is

28 days. Range is 1 – 99 days.

**System** Sets the system registration type as either Dynamic or Custom. Default is Dynamic.

**Domain** Enter the registered Domain name.

## **Authentication Group**

This section describes the parameters that you can configure in the Authentication group.

**Username** Enter the Username of the person who can access the DDNS Server. Default is NULL. You

received your username when you registered with the DDNS service.

Password Enter the Password of the user who can access the DDNS Server. Default is NULL. You


received your password when you registered with the DDNS service.

## **Submitting and Saving Your Changes**

To save the changes you made to these parameters, click **Submit**.

To ensure your changes go into effect, click **Save and Restart**.

# **IP Setup, SNTP Configuration Parameters**



## **General Configuration Group**

**SNTP Client** Enable or disable the SNTP Client to contact the configured server on the UDP port 123 and set

the local time. The default is Disable.

**Server** Enter the SNTP server name or IP address that the SNTP Client contacts to update the time. No

default.

**Polling Time** Enter the time, in minutes, after which the SNTP client requests the server to update the time.

Default is 300 minutes.

## **Time Zone Configuration Group**

**Time Zone:** Enter the time zone. Default is UTC (Universal Coordinated Time, Universal Time). See the following website for Time Zone information:

http://wwp.greenwichmeantime.com/info/current-time.htm

**Time Zone Offset:** Enter +/- hh:mm. Default is +00:00. Offset is the amount of time varying from the standard time of a Time Zone.

## **Daylight Configuration Group**

**Daylight Saving** Enable or disable Daylight Saving mode. The default is Enable.

Daylight Saving Set the offset to use during Daylight Saving mode. Default is +60 minutes. Enter the time in + /

Offset - minutes

**Daylight Saving Start Time Group** 

**Start Ordinal** Set the start ordinal to use during Daylight Saving mode. Options are first, second, third, fourth

and last. Default is second. Daylight Saving time usually starts at the same time on the same day of the week in the same month every year. Each day of the week occurs four or five times a month. Therefore, select the week in which daylight saving time starts, either the first, second,

third, fourth or the last of the month.

**Start Month** Set the start month to use during Daylight Saving mode. Default is March.

**Start Day** Set the start weekday to use during Daylight Saving mode. Default is Sunday.

**Start Time** Set the start time to use during Daylight Saving mode. Default is 02:00 (hh:mm).

**Daylight Saving End Time Group** 

**End Ordinal** Set the end ordinal to use during Daylight Saving mode. Select the week in which daylight saving

time ends. Options are first, second, third, fourth and last. Default is first.

**End Month** Set the end month to use during Daylight Saving mode. Default is November.

**End Day** Set the end weekday to use during Daylight Saving mode. Default is Sunday.

**End Time** Set the end time to use during Daylight Saving mode. Default is 02:00 (hh:mm).

## **Submitting and Saving Your Changes**


To save your changes, click Submit.

To ensure your changes go into effect, click **Save and Restart**.

## **IP Setup, Static Routes Parameters**

Networked computers use routing information to identify whether they are sending data packets directly to the firewall or to another network.

After you define and add a route, you can use the table at the bottom of the group to delete or edit the route.




## **Add Static Routes Group**

IP packets destined for the network indicated in the drop down list are routed to the IP address in field pointed to by the arrow. You can define the networks in the drop down list under the 'Networks & Services' tab. The Static Route page does not display until the network is defined under **Networks & Services.** 

**Static Route:** Select a static route from the drop down list, and then click **Add**.

**Add Button:** After you click **Add**, the new route appears in the table.

# **IP Setup, Remote Configuration Parameters**



## **Remote Configuration Group**

To add a network or host for remote configuration:

- 1. From the drop down list, select a network or host. Options are Any, LAN, and WAN Interface.
  - To define more networks or hosts use the Network & Services tab.
- 2. Click Add. The network or host is added and appears in the table.
- 3. Repeat these steps for all that apply.
- 4. To delete **Any** and **WAN Interface** in the **Options** columns after either is added, click **Delete**.

# IP Setup, GPS Configuration Parameters


An rCell unit with a -GP build option enables the GPS Configuration. The -GP option allows you to configure forwarding of NMEA (National Marine Electronics Association) sentences from the built in GPS receiver to a device connected to the serial port or over the network to a remote host.

The TCP Server, TCP/UDP Client and Serial Port Dump can be enabled simultaneously.

All enabled sentences are forwarded periodically using the interval specified in the NMEA Configuration group. Before forwarding, the rCell inserts an ID Prefix and ID to each enabled NMEA sentence.

Available NMEA sentences are: GPGGA, GPGSA, GPGSV, GPGLL, GPRMC, GPVTG.

For detailed descriptions of the supported NMEA sentences, see the Universal IP AT Commands Reference Guide. You can download this guide from the Multi-Tech website.



## **Local Configuration Group**

The Local Configuration group allows you to configure the TCP server port and allows for a serial port dump.

**TCP Server** Enable or disable TCP Server. The default is Disable.

Sets the port on which the server is listening. The default is 5445. The port range is from 1 to 5 **Port** 

digits, each digit between 0 and 9 inclusive. Note that numbers above 65,535 are illegal as the

port identification fields are 16 bits long in the TCP header.

**Password** If a password is supplied, the TCP server requests that the remote client supply a password

before sending the NMEA sentences.

Enable or disable the Serial Port. The default is Disable. The serial port configuration settings **Serial Port Dump** 

are used to configure the port. The serial port client/server must be disabled in order to use

the serial port for GPS.

## **Remote Configuration Group**

The Remote Configuration group allows the device to connect to a remote server using the IP and port information for uploading GPS data.

TCP/UDP Client Enable or disable the TCP/UDP Client and defines the protocol of the client. The defaults are

Disable and TCP.

**Remote Host** Displays the IP address and port number of the Remote Host.

**Password** If the Remote Host requests a password, the password entered here is sent to the server in

response.

## **NMEA Configuration Group**

The NMEA Configuration allows you to configure the time interval, any additional prefix or ID information and forward NMEA sentences.

**Interval** The Interval is defined in seconds. The default is 10 seconds. The range is 1 to 255 seconds.

Add ID Prefix The ID Prefix is 0 to 10 character prefix added to the ID.

Add ID The ID is a unique remote asset identification string. You can specify up to 20 characters for

the ID string. The & and \$ are invalid characters. The ID must follow the standard NMEA sentence structure. The Universal IP AT Commands Reference Guide, which you can download

from the Multi-Tech website, describes sentence structure.

NMEA GGA, GSA, GSV, GLL, RMC, and VTG are the NMEA sentences. You can turn each sentence On

**Sentences** or Off. The default is On.

## **Communication Examples**

Communication is shown from the remote side.

### **TCP Server example**

read: "PASSWORD\r\n"

write: "serverpasswd\r\n"

read: "OK\r\n"

read: "&&rcell\$GPGGA,192913.002,4505.9845,N,09311.7705,W,1,10,1.0,249.0,M,-29.0,M,,0000\*6F\r\n"

read: "&&rcell\$GPGSA,A,3,13,07,03,05,19,06,23,08,16,10,,,1.8,1.0,1.6\*3F\r\n"

read: "&&rcell\$GPGSV,3,1,12,07,59,308,33,13,59,202,32,03,55,083,33,19,50,136,33\*76\r\n"

read: "&&rcell\$GPGSV,3,2,12,06,43,065,26,23,35,177,26,08,24,296,27,16,19,059,21\*79\r\n"

read: "&&rcell\$GPGSV,3,3,12,10,14,286,29,05,07,321,28,24,06,087,23,21,01,029,\*76\r\n"

read: "&&rcell\$GPGLL,4505.9845,N,09311.7705,W,192913.002,A,A\*43\r\n"

read: "&&rcell\$GPRMC,192913.002,A,4505.9845,N,09311.7705,W,000.0,117.3,220710,,,A\*76\r\n"

read: "&&rcell\$GPVTG,117.3,T,,M,000.0,N,000.0,K,A\*09\r\n"

read: "&&rcell\$GPGGA,192915.002,4505.9842,N,09311.7699,W,1,10,1.0,248.9,M,-29.0,M,,0000\*62\r\n"

read: "&&rcell\$GPGSA,A,3,13,07,03,05,19,06,23,08,16,10,,,1.8,1.0,1.6\*3F\r\n"

read: "&&rcell\$GPGSV.3.1.12.07.59.308.33.13.59.202.33.03.55.083.33.19.51.136.33\*76\r\n"

read: "&&rcell\$GPGSV,3,2,12,06,43,065,25,23,35,177,26,08,24,296,27,16,19,059,21\*7A\r\n"

read: "&&rcell\$GPGSV,3,3,12,10,14,286,28,05,07,321,28,24,06,087,23,21,01,029,\*77\r\n"

read: "&&rcell\$GPGLL,4505.9842,N,09311.7699,W,192915.002,A,A\*46\r\n"


read: "&&rcell\$GPRMC,192915.002,A,4505.9842,N,09311.7699,W,000.0,117.3,220710,,,A\*73\r\n"

read: "&&rcell\$GPVTG,117.3,T,,M,000.0,N,000.0,K,A\*09\r\n"

### TCP Client Example with password

write: "PASSWORD\r\n" read: "clientpasswd\r\n" write: "OK\r\n" read: "&&rcell\$GPGGA,193038.002,4505.9798,N,09311.7646,W,1,10,1.0,230.2,M,-29.0,M,,0000\*6B\r\n" read: "&&rcell\$GPGSA,A,3,13,07,03,05,19,06,23,08,16,10,,,1.8,1.0,1.5\*3C\r\n" read: "&&rcell\$GPGSV,3,1,12,07,60,309,31,13,59,201,30,03,54,082,30,19,51,135,28\*75\r\n" read: "&&rcell\$GPGSV,3,2,12,06,42,064,21,23,34,177,25,08,24,297,20,16,18,060,20\*70\r\n" read: "&&rcell\$GPGSV,3,3,12,10,13,285,31,05,07,320,28,24,07,086,26,21,01,028,\*7E\r\n" read: "&&rcell\$GPGLL,4505.9798,N,09311.7646,W,193038.002,A,A\*4B\r\n" read: "&&rcell\$GPRMC,193038.002,A,4505.9798,N,09311.7646,W,000.0,117.3,220710,,,,A\*7E\r\n" read: "&&rcell\$GPVTG,117.3,T,,M,000.0,N,000.0,K,A\*09\r\n" read: "&&rcell\$GPGGA,193040.002,4505.9796,N,09311.7646,W,1,10,1.0,230.1,M,-29.0,M,,0000\*69\r\n" read: "&&rcell\$GPGSA,A,3,13,07,03,05,19,06,23,08,16,10,,,1.8,1.0,1.5\*3C\r\n" read: "&&rcell\$GPGSV,3,1,12,07,60,309,32,13,59,201,29,03,54,082,31,19,51,135,28\*7F\r\n" read: "&&rcell\$GPGSV,3,2,12,06,42,064,22,23,34,177,26,08,24,297,19,16,18,060,21\*7B\r\n" read: "&&rcell\$GPGSV,3,3,12,10,13,285,32,05,07,320,28,24,07,086,25,21,01,028,\*7E\r\n" read: "&&rcell\$GPGLL,4505.9796,N,09311.7646,W,193040.002,A,A\*4A\r\n" read: "&&rcell\$GPRMC,193040.002,A,4505.9796,N,09311.7646,W,000.0,117.3,220710,,,,A\*7F\r\n" read: "&&rcell\$GPVTG,117.3,T,,M,000.0,N,000.0,K,A\*09\r\n"

# **PPP, PPP Configuration Parameters**



# **NAT Configuration Group**

NAT: Enable or disable NAT (Network Address Translation). The default is Enable.

**Note:** For routing to take effect, enable then save the configuration.

### **Enabling NAT**

Your LAN can use one set of IP addresses for internal traffic and a second set of addresses for external traffic. The router with NAT does the simple IP routing between the LAN interface and the WAN interface. NAT hides the LAN address behind a single IP address on the wireless side.

Your internal addresses are shielded from the public Internet.

### **Disabling NAT**

The router functions without performing any address translation on the packets passing through it.

Masguerading of packets originating from the LAN is disabled.

Address translation of packets arriving from the WAN is also disabled.

Any DNAT Configuration previously setup in the DNAT Configuration screen is disabled. This prevents the user from adding any DNAT rules, which if allowed defeat the purpose of enabling Routing.

### **PPP General Group**

**PPP:** Enable or disable PPP. The default is Disable. When enabled, the unit functions as a router. PPP must be disabled to access the integrated cellular modem directly using telnet port 5000. If PPP is enabled, you cannot access the integrated cellular modem.

**Dial-on-Demand:** Enable or disable Dial-on-Demand. The default is Disable. If you disable it, the router always stays connected unless the Idle Time Out expires. When Dial-on-Demand is enabled, use the 'Wakeup on Call' settings under the PPP menu to configure the settings for re-establishment of the connection.

**Idle Time Out:** Set the amount of idle time that passes before the router timeouts. The default is 180 seconds. If the time expires, the PPP connection to the Internet disconnects. Any IP packets from the LAN side or IP traffic from the wireless side resets this timer and prevents the connection from dropping.

Connect Time Out: Set the number of seconds to wait for a connection while in receive mode before timing out.

**Dialing Max Retries:** Enter the number of dialing retries allowed. The default is zero, which means an infinite number is allowed. Range 0 to 100.

## **Authentication Group**

**Authentication Type:** Set the authentication protocol type that negotiates with the remote peer: pap/chap/pap-chap. Default is pap-chap.

**Username:** Enter the Username with which the remote peer authenticates. You can leave this field blank, if desired. Username is limited to 60 characters.

**Password:** Enter the Password with which the remote peer authenticates. You can leave this field blank, if desired. Password is limited to 60 characters.

## **ICMP Keep Alive Check**

**Keep Alive Check:** Enable or disable Keep Alive Check. The default is Disable. This is used to periodically check that the Internet connection is up. If it is not, the router tries to reconnect.

Keep Alive Type: Select ICMP or TCP (the protocol type for Keep Alive).

Host Name: Enter the Host Name or IP Address for Keep Alive Check. No default.

**TCP Port:** Enter the TCP Port number to connect with the TCP server.

Interval: Set the number of seconds for Keep Alive Check. Default is 60 seconds.

ICMP Count: Set the number of ICMP Keep Alive Checks to be sent to the specified host. Default is 10.

## **Modem Configuration Group**

To know the proper information to enter into this group, refer to the Customer Activation Notices included with the product.

Dial Number: Set the dial number to be dialed. Default is NULL.

For GSM models, the Dial Number is \*99\*\*\*1#

For CDMA models, the Dial Number is #777

Dial Prefix: Set the modem dial prefix. The default is ATDT.

**Connect String:** Set the modem Connect String. The default is CONNECT.

APN: Enter the APN (Access Point Name). The APN is assigned by your wireless service provider.

**Init String 1-4:** Configure the modem init strings. You can set up to 4 modem initialization strings.

**Baud Rate:** The Baud Rate option is only displayed on certain models and is set at 230.4K, by default. The default setting is set for maximum performance. Setting the baud rate higher, particularly on the G2 models, is not recommended as it may adversely affect the performance.

## **Submitting and Saving Your Changes**

To save these settings, click **Submit**.


To ensure your changes go into effect, click **Save and Restart**.

# PPP, Wakeup-on-Call Parameters

The Wakeup-on-Call feature allows the router to wake up and initiate a connection when there is an incoming call or LAN activity. . The Wakeup-on-Call feature reduces the cost incurred when a router is online and available 24/7.

If you desire some security with this feature, you can set up the router to wake up based on Caller ID or SMS instead of allowing all incoming calls to wake up the router. Dial-on-Demand in the IP Setup menu must be enabled for wakeup-on-call features to go into effect.

Note: When provisioning this feature, you must allow incoming calls, SMS capability, and caller-id.



## **Wakeup-on-Call Configuration Group**

**Wakeup on Call:** Enable or disable the Wakeup-on-Call feature. The default is Disable. Wakeup on Call occurs when a ring or caller ID is detected. This triggers the router to reconnect after the 'Time Delay' expires.

**Time Delay:** Enter the amount of time that you want to pass between the reception of a call and the initiation of the Wakeup-on-Call connection. A time delay is needed to make sure that the incoming call has ended before the connection is initiated. The default is 10 seconds.

**Dial-on-Demand from LAN:** The default is disable. When enabled, the router reconnects when it sees IP traffic on the LAN is needed to route. If this feature is disabled, Dial-on-Demand initiates a PPP connection to the Internet only from the WAN, not from the LAN.

**Init Strings:** Configure the router initialization strings. These init strings need to be specific to the integrated cellular modem. Some initialization may be required for the integrated cellular modem to accept SMS for 'Wakeup on Call'. Init-num can range from 1-5. The default is NULL. Refer to the following table for examples of Init Strings depending on model.

Model	Init 1	Init 2	Init 3	Init 4	Ack	Comment
C1-EN2-GP			AT+CNMI=2,2,0,0,1	AT+CLIP=1	AT+CNMA	Ring with CLI, SMS with ACK
E1-EN2-GP	AT+CMGF=1	AT+CSMS=1	AT+CNMI=2,2,0,0,1	AT+CLIP=1	AT+CNMA	Ring with CLI, SMS with ACK
G2-EN2-GP	AT+CMGF=1	AT+CSMS=1	AT+CNMI=2,2,0,0,1	AT+CLIP=1	AT+CNMA	Ring with CLI, SMS with ACK
H4-EN2*			AT+CLIP=1			Ring with CLI
H4-EN2- GP*			AT+CLIP=1			Ring with CLI
EV2-EN2*			AT+CLIP=1			Ring with CLI
EV2-EN2- GP*			AT+CLIP=1			Ring with CLI

<sup>\*</sup>Does NOT support Wakeup On Call using SMS.

**Submit:** Click **Submit** to save these settings.

## **Caller ID Configuration Group**

**Add "Wakeup on Call" Caller ID:** To add Caller ID to the Wakeup-on-Call function, enter the Caller ID that can wake up the router. Enter 'RING' (all Caps) to wake up on any call. Enter a CID phone number or an SMS message. Ensure the SMS message string does not contain any spaces between words.

After entering the Caller ID, click the **Add** button. The Caller ID displays at the bottom of the page. You can enter any number of IDs.

A Caller ID can be edited or deleted using Options, which are available once a Caller ID is displayed.

Caller Acknowledgement Configuration

**Acknowledgement String to Caller:** The configured string of (0 to 40 characters) that is sent to the integrated cellular modem upon receiving a valid caller ID from the WAN. The default is NULL string.

Note: If the string is not configured, acknowledgement to the caller is not sent upon successful caller ID reception.

## **Submitting and Saving Your Changes**

To save these settings, click Submit.

To ensure your changes go into effect, click **Save and Restart**.

## **Wakeup-On-Call Examples**

### Example 1 – Set Up the Ethernet Router to Activate on Incoming SMS Message

- 1. On the PPP > PPP Configuration page, configure the following parameters:
  - PPP General

Make sure that **PPP** is Enabled (the default).

Make sure Dial-on-Demand is Enabled (the default).

Set the Idle Time Out to the number of seconds you desire.

Authentication

Your wireless service provider may require you to have a separate PPP Username and Password. If so, enter them here.

Note: If a username and password are required, your wireless provider likely gave these items to you when you activated your account.

Modem Configuration

Make sure your Dial Number is entered correctly.

For GSM models, the Dial Number is \*99\*\*\*1#

For CDMA models, the Dial Number is #777

Enter your APN. Your wireless service provider assigns the APN.

Example: AT+CGDCONT=1,"IP","Internet" The Example: AT+CGDCONT=1,"IP","Internet" needs to be removed. Just the APN name needs to be entered in the APN field.

2. To save the changes made on this page, click **Submit**.

- 3. On the PPP > Wakeup-on-Call screen, configure the following parameters:
  - Wakeup-on-Call Configuration

Select Enable for Wakeup-on-Call.

Set the Time Delay. You can use the 10 second default.

Enter the Init Strings from the model dependent table described in the Wakeup-on-Call Configuration.

- 4. To save the changes made on this page, click **Submit**.
  - Caller ID Configuration

Enter an SMS to add to the Caller ID list.

**Note:** Add the SMS message string into the Caller ID list. The SMS message string must not contain any spaces between words. When the configured string matches the SMS message string, it activates the Wakeup-on-Call feature.

To save each message as it is entered into the Caller ID list click Add.

• Caller Acknowledgement Configuration

Enter a configured string (0 to 40 characters) that is sent to the integrated cellular modem upon receiving a valid Caller ID from the WAN.

Set the Wakeup Acknowledgement string configuration with the command at+cnma

To save the Acknowledgement Configuration, click the Submit.

**5.** To ensure your changes go into effect, click **Save and Restart**. The device saves all the settings and reboots the computer.

### Example 2 – Determine if the router Is Supporting Incoming Calls and Caller ID

- 1. On the PPP > PPP Configuration page, make sure that PPP is Disabled.
- 2. On the PPP > Wakeup-on-Call screen, make sure that Wakeup-on-Call is Disabled.
- 3. To open a command prompt, from the **Start** button and select **Run**.
- 4. Type **CMD** to open the command window. Click **OK**.
- 5. When the command window opens, telnet to the router.

**Note:** 5000 is the router port number.

- d. Enter your username and password to login.
- e. Enter an AT command to make sure you receive a response; i.e., OK.
- f. To determine the dial number of your router, enter the command AT+CNUM.

  For the Wakeup-on-Call function to work the RING or CALLER ID information must appear.
- **6.** To determine if the RING message shows, from another phone, call your router using the dial number of your router.
- 7. To enable Caller ID, enter the **AT+CLIP=1** command. Make the call again to verify Caller ID information. Some wireless providers do not provide caller ID information if you have only a data plan.

### Example 3 – Set Up the Ethernet Router to Activate on ALL Incoming Calls

1. On the *PPP >PPP Configuration* page, set up the following parameters:

#### **PPP General**

- Make sure that PPP is Enabled.
- Make sure Dial-on-Demand is Enabled.
- Set the Idle Time Out to the number of seconds you desire.

#### Authentication

• Your wireless service provider may require you to have a separate PPP User name and Password. If so, enter them here.

**Note:** If a username and password are required, your wireless provider likely gave you these items when you activated your account.

### **Modem Configuration**

- Make sure your Dial Number is entered correctly:
- For GSM models, the Dial Number is \*99\*\*\*1#
  - For CDMA models, the Dial Number is #777

### Submit

• Click the **Submit** button to save the changes made on this screen.

2. On the *PPP > Wakeup-on-Call* screen, set up the following parameters:

Wakeup-on-Call Configuration

- Select Enable for Wakeup-on-Call.
- Set the Time Delay to 3 seconds. You can use the 10 second default.
- Ensure all Init Strings are empty.
- Submit Button
- Click the Submit button to save these settings.

### Caller ID Configuration

- Enter the string RING to the Caller ID list.
- Click the Add Button to save the string to the Caller ID list.
- **3.** To ensure your changes go into effect, click **Save and Restart**. The device saves all the settings and reboots the computer.

### **Example 4 – Set Up the Ethernet Router to Activate on Matching Caller IDs Only:**

1. On the *PPP > PPP Configuration* screen, set up the following parameters:

#### PPP General

- Make sure that PPP is Enabled.
- Make sure Dial-on-Demand is Enabled.
- Set the Idle Time Out to the number of seconds you desire.

#### Authentication

• Your wireless service provider may require you to have a separate PPP username and password. If so, enter them here.

**Note:** If a username and password are required, your wireless provider likely gave you these items when you activated your account.

#### **Modem Configuration**

• Make sure your Dial Number is entered correctly:

For GSM models, the Dial Number is \*99\*\*\*1#

For CDMA models, the Dial Number is #777

- To save the changes, click Submit.
- On the PPP > Wakeup-on-Call screen, set up the following parameters:

Wakeup-on-Call Configuration


- Select Enable for Wakeup-on-Call.
- Set the Time Delay. You can use the 10 second default.
- Enter the Init Strings:
- To set Wakeup Init String 1 type AT+CLIP=1.
- To save settings, click Submit.

#### Caller ID Configuration

- To add a caller's ID, to the Caller ID list, type that id.
- Click Add.
- To save each Caller ID as it is entered to the Caller ID list, click Add.
- To ensure your changes go into effect, click Save and Restart. The device saves all the settings and reboots the computer.

## **PPP, Power-On Configuration Parameters**

The Power-On Configuration feature allows you to set an initialization string that is sent to the router upon boot up.



**Power-On Init String:** You can enter a string of 0 to 40 characters that is sent to the router upon boot up. All commands initializes before you proceed with regular PPP related activity.

**Note:** When no initialization string is configured, regular functions of the router is retained.


To save this setting click **SUBMIT**.

To ensure your changes go into effect, click **Save and Restart**.

## **PPP, Modem Commands Parameters**

You can configure modem commands to allow an external application to query modem information.

- The application can use the URL <a href="http://xxx.xxx.xxx/modeminfor.html">http://xxx.xxx.xxx/modeminfor.html</a> to determine the IP address that is currently assigned to the integrated cellular modem after the PPP connection is established.
- You can also display the results of up to ten AT commands.



### **Modem AT Commands Configuration Group**

These commands are sent when a PPP connection to the network is initiated.

Useful HSDPA AT commands include:

Command	Description
AT+CGSN	Product Serial Number
AT+CGMR	Software Version
AT+CNUM	Wireless Subscriber Number
AT+COPS?	Network Information (Operator)
AT+CREG?	Network Registration
AT+CSQ	Signal Quality

#### **Retrieving Modem Information without using a browser:**

To obtain the integrated cellular modem information without using a browser:


- 1. Make a TCP connection to port 80 (same as the Web Admin port) and send data as: GET /atinfor.html HTTP/1.1
- 2. Press Enter twice.

Refer to the AT Command Reference Guides for other commands.

# **Networks & Services, Network Configuration Parameters**

### **Network Configuration Group**

Use this group to add networks or hosts. After you define and add a network, you can delete or edit it by using the table.



### **Configuring the Network**

Before you configure the network, note the following:

- You cannot edit a Network/Host Name.
- You cannot delete a Network/Host another configuration is using it.
- Network/Host changes are reflected in all the configurations in the Web Management software where they
  are used.
- Network/Hosts that you add here are displayed in the following sections: Static Routes, DNAT, and Packet Filters.

#### To configure:

- 1. In the **Name** field, type the name of the Network/Host. Make sure the same address-mask pair does not already appear in the list. The Name is limited to 15 characters maximum.
- 2. In the IP Address field, type the IP Address of the Network/Host. Make sure the same address-mask pair does not already appear in the list.
- 3. In the **Subnet Mask** field, type the Network Mask of the Network/Host. For Host addresses, the mask is entered as 32.


Note: See Appendix A -- Table of Commonly Supported Subnets.

**4.** To add the network, click **Add**. The defined network appears in the table.

## **Networks & Services, Service Configuration Parameters**

## **Service Configuration Group**

These parameters let you specify the standard set of well known services available on the system. These services enable the configuration of the user-defined services. You can delete or edit services after defining and adding them. Use the table at the bottom of the screen.



#### **Configuring New Services**

Before you configure the network, note the following:

- A Service Name cannot be edited.
- A Service cannot be deleted if it is used in another configuration.
- Service changes are reflected in all the configurations in the Web Management software where they are used.
- Services added here are displayed in the following sections: DNAT, Packet Filters.

#### To configure:

1. For the new service, configure the following parameters:

Name: Enter the name of the Service which is limited to 16 characters. It has to be unique.

**Protocol:** Enter the type of protocol (TCP, UDP).


**Source Port:** Enter the Destination Port for this service. The source and destination ports can be entered either as a single port or a range using a colon as the separator.

**Destination Port:** Enter the name of the Destination Port for the service.

2. Click **Add**. The new service is added and appears on the page.

## **Packet Filters, Packet Filters Parameters**

You can Delete or Edit a packet filter rule after it has been defined and added by using the table at the bottom of the screen.



## **Packet Filter Group**

**From (Host/Networks):** Enter the network/host from which the packet must originate for the filter rule to match. The Any option, which matches all IP addresses regardless of whether they are officially assigned addresses or private addresses, may also be entered. The network/host must be pre-defined in the Networks section.

**Service:** Enter the service that is to be matched with the filter rule. These services must be pre-defined in the Services section. These services precisely define the traffic to be filtered.

**To (Host/Networks):** Enter the network/host to which the packet must send for the filter rule to match. The Any option, which matches all IP addresses regardless of whether they are officially assigned addresses or private addresses, may also be entered. The network/host must be pre-defined in the Networks section.

**Action:** Enter the action that the packet filter executes if the rule matches any traffic traversing the firewall. Types of actions defined are:

- Accept: Allows/accepts all packets that match this rule.
- **Reject:** Blocks all packets that match this rule. The host sending the packet is informed that the packet has been rejected.
- **Drop:** Blocks all packets that match this rule, but the host is not informed; that is, this is a silent drop.
- Log: Packets matching the rule; that is, the corresponding source address, destination address, and service are logged.

Add Button: Click the Add button. The defined packet filter rule is added and appears at the bottom of the screen.

## **Packet Filters, DNAT Configuration Parameters**

### **DNAT Configuration Group**

Destination Network Address Translation (DNAT) allows you to place servers within the protected network and make them available for a certain service to the outside world. The DNAT process running on the router translates the destination address of incoming packets to the address of the real network server on the LAN. The packets are then forwarded.

You can Delete or Edit a DNAT rule after it has been defined and added by using the table at the bottom of the screen.

Note: When adding rules, at least one host must be defined in the Network Configuration section.



**Allow Access:** Select a network or host to which IP packets are allowed and re-routed. The network/host must be pre-defined in the Network Configuration section.

**External Service:** Select the External Service that you want allowed. The service must be defined in the Service Configuration section.

**LAN IP:** Select the LAN IP to which the packets are to be diverted. Only one host can be defined as the destination.

Internal Service: Select the Internal Service to be the destination.

**Internal Source:** Select the source address for packets that are going to be sent. If you do not want to change the address, select **NOCHANGE**.

**Save Button:** Click **Save**. The defined DNAT configuration is added and appears at the bottom of the page. Entries can be deleted or edited by clicking the **Edit** or the **Delete** buttons.

## **Example: Setting Up DNAT and Port Forwarding to an Internal Device**

**Note:** The internal device can be camera, meter, security device, and so on.

**Situation:** Assume the device is on a LAN with an IP address of 192.168.2.100 and the port to access the device is port 7700.

1. In the Network & Services > Network Configuration group, define the following parameters:

Name - Enter a name for the LAN device.

IP Address and Subnet Address – Enter the IP address and subnet address of the device.

**Example:** Name = MeterIP

IP Address = 192.168.2.100

Subnet Address = 255.255.255.255.255. The subnet mask in the network configuration is not defined using x.x.x.x notation. It uses 'bit' notation. So 255.255.255.255.255 = 32.

- To save this configuration, click Add.
- 3. In the **Network & Services > Service Configuration** group, define a service name. For this example, the service is a meter.

Name – Enter a name for the service (use a name that identifies the service for you). Example: MeterPort

Protocol – Select a protocol. Example: tcp or udp

S-Port / Client – Enter the source port for this service. Example: 1:65535

**D-Port / Server –** Enter the destination port for this service. Example: 7700

**Add** – Click the **Add** button to save this configuration.

4. In the Packet Filters > DNAT Configuration group, define the DNAT rule.

**Allow Access** – Select the original target network/host of the IP packets that you now want rerouted. The original target network/host is the one previously defined in the Network Configuration section. **Example:** Any

**External Service** – Select the External Service that you want allowed. The service must be defined in the Service Configuration section.

**LAN IP** – Select the LAN IP to which the packets are to be diverted. Only one host can be defined as the destination.

Internal Service - Select the Internal Service to be the destination.

**Pre DNAT Service** – Select the service for the Pre-DNAT destination. This service was just defined in the Service Configuration section. **Example:** MeterPort

**Post DNAT IP** – Select the destination to which the IP packets are to be diverted. Only one host can be defined as the Post DNAT destination. **Example:** MeterIP

Post DNAT Service – Select the service for the Post DNAT configuration. Example: MeterPort

**Internal Source** – Select the source address for packets that are going to be sent. If you do not want to change the address, select **NOCHANGE**. **Example**: NOCHANGE

5. To save this configuration, click **Save.** 

**Note:** You must click **Save and Restart** once you have completed and submitted all the screens on which you have made changes. The device saves all the settings and reboot the computer.

## Packet Filters, Advanced Parameters



### **Connection Tracking Group**

**H323:** Enable or disable the forwarding of H323 packets across the firewall.

PPTP: Enable or disable PPTP Packet Pass-through (PPTP NAT support).

Note: H323 and PPTP are disabled by default.

## **ICMP Configuration Group**

Use the Internet Control Message Protocol (ICMP) to test the network connections and the firewall. You can also use ICMP for diagnostic purposes. ICMP on Firewall and ICMP Forwarding always apply to all IP addresses; i.e., Any. When these are enabled, all IP hosts can Ping the firewall (ICMP on Firewall) or the network behind it (ICMP Forwarding).

**ICMP on LAN:** Enable or disable the transfer of ICMP packets on the LAN interface.

ICMP on WAN: Enable or disable the transfer of ICMP packets on the WAN interface.

**ICMP Forward:** Enable or disable the forwarding of ICMP packets through the firewall into the local network.

Note: ICMP on the LAN, WAN, and Forward are enabled by default.

## **Submitting and Saving Your Changes**

To save these settings, click Submit.

To ensure your changes go into effect, click **Save and Restart**.

## **GRE Tunnels**

Generic Routing Encapsulation (GRE) includes GRE tunneling and GRE routing

First, you create the GRE Tunnels by using the GRE Tunnel Configuration group.

Then, you configure the routes for the remote networks that are routed through a tunnel, by using the GRE Routes Configuration group. All the traffic destined to remote networks associated to a tunnel are routed through that tunnel.

#### **GRE Tunnels > GRE Tunnels**

Tunneling allows the use of a public network to convey data on behalf of two remote private networks. It is also a way to transform data frames to allow them to pass networks with incompatible address spaces or even incompatible protocols. If you want to read more about how this works, see the online Help.



## **GRE Tunnel Configuration Group**

Tunnel Name: Enter a name for the new tunnel.

**Local IP:** Select the local interface on which the tunnel is created. Eventually, the packets destined for this tunnel are routed through it.

**Note:** When adding a tunnel, use only one of the following: **Remote IP** or **FQDN**.


**Remote IP:** Select the Remote IP address that marks the other end point of the tunnel. This is where the routed packets are received).

OR

**FQDN:** Enter the FQDN (Fully Qualified Domain Name) for the Remote IP, which can be either the IP Address or an FQDN.

**Add Button:** Click the **Add** button. The defined GRE tunnel configuration is added and appears at the bottom of the screen.

## **GRE Tunnels > GRE Routes Configuration**




**Remote Network:** Select the remote network for which the traffic destined to it must be routed through the given tunnel.

**Tunnel Name:** Select the name of the tunnel through which the traffic is routed.

**Note:** To add a tunneled route, the remote network and the tunnel must have been defined in Network Configuration. The tunnel configuration must be completed before setting the GRE route configuration.

**Add Button:** Click **Add**. The defined GRE route configuration is added and appears at the bottom of the page.

## **DHCP Server, Subnet Settings**



## **General Configuration**

DHCP (Dynamic Host Configuration Protocol) is a protocol that allows individual devices on an IP network to get their own network configuration information (IP address, subnet mask, broadcast address, etc.) from a DHCP server. The overall purpose of DHCP is to make it easier to administer a large network.

**DHCP:**Enable or disable the DHCP server.

**Subnet:** Enter the subnet address. If you want to change the DHCP subnet address, you first have to delete all the subnet settings below.

Mask: Enter the subnet mask.

Gateway: Enter the gateway address.

**DNS:** Enter the DNS address.

**Lease Time:** Select the DHCP Lease Time from the selection box. Lease time is set in days, hours, and minutes. A Lease Time of 00-00-00 is an Infinite Lease Time.

To save your changes, click SUBMIT.

To ensure your changes go into effect, click **Save and Restart**.


#### **Subnet Settings**

**From-To Range:** Enter the range of IP addresses to be assigned by DHCP.

**Add:** Click the **Add** button. The address range is added and appears in the table at the bottom of the screen. Once the range displays, you can delete if necessary.

Note: See Appendix A Commonly Supported Subnets.

#### **DHCP Server > Fixed Addresses**



#### **DHCP Fixed Configuration**

The DHCP server can be made to assign a fixed IP address for a particular user by identifying the MAC address. This binding can be made permanent by configuring it here. The same IP address is not be used for any DHCP client with a different MAC address, even if there is no active DHCP connection with that IP address.

MAC Address: Enter the MAC address to which the specified IP address binds.

IP Address: Enter the fixed IP address to be assigned.

**Add:** Click the **Add** button. The addresses are added and appear in the table at the bottom of the page from where they can be deleted or changed.

### **IPSec**

The IPSec (IP Security) protocol suite, based on modern cryptographic technologies, provides security services like encryption and authentication at the IP network layer. It secures the whole network traffic providing guaranteed security for any application using the network.

You can use IPSec to create private secured tunnels between two hosts, two security gateways, or a host and a security gateway. Up to three tunnels can be active at any given time. You can save more than three active tunnels, but they are not active.

IPSec provides encryption and authentication services at the IP level of the protocol stack. IPSec can protect any traffic carried over IP.

### **Authentication and Encryption Overview**


IPSec provides the following services:

- Authentication only
- Encryption only

To transmit and receive data securely over an unprotected network:

- 1. Select the type of IPSec service—authentication or encryption—required for the connection.
- 2. Establish a secure connection by a key exchange process, using one of the following:
  - Manual Keying where the authentication and encryption keys are provided manually on both sides of the connection.
  - Auto Keying using IKEv2 Protocol where the authentication and encryption keys are generated on either side of the connection and exchanged by different methods.
- 3. Transfer data using the connection.

### IPSec > IPSec



#### **IPSec**


VPN Status: Check the VPN Status checkbox to enable IPSec. Click Save.

#### **Add a New Connection**

**Add IKE Connection:** Click **Add IKE Connection**. A page opens where you can configure an IKE connection.

**Add Manual Connection:** Click **Add Manual Connection**. A page opens where you can configure a manual connection.

#### **Add IKE Connection**



#### Add an IKE Connection

**Connection Name**: Type a name for the connection.

**Compression:** Check the compression checkbox to enable IPCOMP, the compression algorithm.

**Perfect Forward Secrecy (PFS):** Check the PFS checkbox to enable PFS, a concept in which the newly generated keys are unrelated to the older keys). This is enabled by default.

**Authentication Method:** Authentication can be done using Pre-Shared Secrets.

**Pre-Shared Key:** The Pre-Shared Key must be agreed upon and shared by the VPN endpoints. Configured it at both endpoints of the tunnel.

**Select Encryption:** Select the encryption method. 3DES is recommended. Options include 3DES, AES-128, AES-192, AES-256

**IKE Life Time:** The duration for which the ISAKMP SA lasts, from successful negotiation to expiration. The default value is one hour and the maximum is 8 hours.

**Key Life:** The duration for which the IPSec SA lasts, from successful negotiation to expiration. The default value is one hour and the maximum is 24 hours.

Number of Retries: Specify the number of retries for the IPSec tunnel. Enter zero for unlimited retries.

Local WAN IP: This is the interface initiating the IPSec tunnel.

**Local LAN:** Internal subnet of the local security gateway for which the security services are provided. If the router acts as a host, configured as None.

**Remote Gateway IP:** Interface where the IPSec tunnel ends. In the case of a Road Warrior with a Dynamic IP address, configure to **ANY**.

**FQDN:** FQDN is a Fully Qualified Domain Name that resolves to the Local Wan IP of the router or in the case of GRE/IPSEC, it is used to identify the Wan IP of the remote location. This is provided by your ISP or created by you if you are using a Dynamic DNS service. When FQDN is selected, leave the Remote Gateway IP blank.

**Remote LAN:** Internal subnet of the remote security gateway for which the security services are provided. If the remote end is the host, set this to None.

**UID (Unique Identifier String):** Check the UID box to enable the Local ID and Remote ID. Local ID and Remote ID are active only when UID is enabled.

Local ID

Enter a string identifier for the local security gateway.


Remote ID

Enter a string identifier for the remote security gateway.

**NetBIOS Broadcast:** Check this option to enable broadcasts over the connection. It allows computers on the network to share Microsoft file and printer sharing information.

Save Button: Click the Save button to save these settings.

#### **Add Manual Connection**



**Connection Name:** Type name to identify the connection.

**Compression:** Check the compression checkbox to enable IPCOMP, the compression algorithm.

**Authentication Method:** Select the authentication algorithms used for the respective security services. Options are MD5-96 and SHA1-96.

**Authentication Key:** The VPN firewall can use either MD5-96 or SHA1-96 for authentication. For example, MD5-96 with a key of abcdefgh12345678.

Authentication Protocol	Key Length	Accepted Characters
SHA1-96	Must be 20 characters	Alphanumeric characters
MD5-96	Must be 16 characters	Alphanumeric characters

**Encryption Method:** Select the encryption method. Options include 3DES, AES-128, AES-192, AES-256, and NULL (no encryption).

**Encryption Key:** The router can use any one of the methods specified in its encryption algorithm. For example 3DES uses 24 alphanumeric characters (192 bits) as its encryption key. Example: 1234567890abcdefabcdabcd

<b>Encryption Protocol</b>	Key Length	Accepted Characters
Null	Must be 24 characters	Alphanumeric Characters
3DES	Must be 24 characters	Alphanumeric Characters
AES-128	Must be 16 characters	Alphanumeric Characters
AES-192	Must be 24 characters	Alphanumeric Characters
AES-256	Must be 32 characters	Alphanumeric Characters

SPI Base: The Security Parameter Index identifies a manual connection. The SPI is a unique identifier in the SA (Secure Association – a type of secure connection) that allows the receiving computer to select the SA under which a packet is processed. The SPI Base is a number needed by the manual keying code. Enter any 3-digit hexadecimal number, which is unique for a security association. Enter in the format of 0xhex (0x100 through 0xfff is recommended). If you have more than one manual connection, then the SPI Base must be different for each one.

**Left Next Hop:** Next Hop is the address of the next device in a routing table's path that moves a packet to its destination. You can configure this setting or leave it as a static value: 0.0.0.0. When not configured, the value is set to the Gateway of the Box/Gateway configured on the Interface/Right IP. The selection is based on the Left and Right IP.

Local WAN IP: Select the Interface to initiate the IPSec tunnel (Left Security Gateway).

**Local LAN:** Select the internal subnet of the local security gateway for which the security services are to be provided. If the router acts as a host, configure as **None**. Other options are Any, LAN, LAN Interface, WAN 1, WAN 1 Interface.

**Remote Gateway IP:** Select the interface in which the IPSec tunnel ends. In the case of Road Warriors with a Dynamic IP addresses, set to **ANY**. Other options include: LAN, LAN Interface, WAN 1, WAN 1 Interface, and None.

**FQDN:** FQDN is a Fully Qualified Domain Name that resolves to the Local Wan IP of the router or in the case of GRE/IPSEC, it is used to identify the Wan IP of the remote location. This is provided by your ISP or created by you if you are using a Dynamic DNS service. When FQDN is selected, leave the Remote Gateway IP blank.

**Remote LAN:** This is the internal subnet of the remote security gateway for which the security services are to be provided. If the remote end is a host, set to **None**.

**NetBIOS Broadcast:** Check this option to enable broadcasts over the connection. This allows computers on the network to share Microsoft file and printer sharing information.

**Save Button:** Click **Save** to save these settings.

## **Serial-Port, Serial Port Settings Parameters**



### **Serial-Port Configuration Group**

Serial-Port Configuration lets you configure the serial terminal connected to the RS-232 connector DE9 on the back of the unit.

Baud Rate: Sets the baud-rate at which the serial terminal is communicating. The default is 115200.

Flow Control: Sets the flow control for the serial port. Options are None or RTS-CTS. The default is None.

Data Bits: Sets the data bits for the serial port. Data bit selection is 7 or 8. The default is 8.

**Stop Bits:** Sets the stop bits for the serial port. Options are 1 or 2. The default is 1.

Parity: Sets the parity for the serial port. Options are None, Even, or Odd. The default is None.

**Buffer Length:** Sets the length up to which the data from the serial device is buffered before IP transmission. The default length is 32-characters.


**Timeout:** Sets the timeout value for the serial terminal of how long it waits before IP transmission. The default is 1-second.


Submit Button: Click Submit to save these settings.

## **Serial Port, Client Settings Parameters**

The TCP/UDP client feature enables the router to act as a proxy TCP/UDP client to the serial terminal connected to the DE9, RS232 port on the router thus facilitating the serial terminal to access any TCP/UDP server on the LAN/WAN. Once the session, serial terminal to TCP/UDP server, is opened successfully, it allows two-way traffic between the serial device and the remote server.

Initial connection setup for the TCP/UDP client is as follows:





## **TCP/UDP - Client Configuration Group**

Configures TCP/UDP Client through which the serial terminal connected to the RS-232 connector, DE9 on the back of the unit communicates with the remote TCP/UDP server on the LAN/WAN.

Status: Sets the client status to either Enable or Disable. The default is Disable.

Client Type: Sets the client to either TCP or UDP. The default is TCP.

**Primary Server:** Enter the Primary Server IP address or Hostname. The default is blank.

Port: If a Primary Server IP address or hostname is enabled, enter the port number of the server.

Secondary Server: Enter the Secondary Server IP address or Hostname. The default is blank.

Port: If a Secondary Server IP address or hostname is enabled, enter the port number of the server.

**Connection start By:** Sets the trigger (Carriage Return (CR), DTR Assert, or Always on) in the serial port by which the connection starts. The default is Carriage Return (CR).

**Connection Terminate By:** Sets the connection terminate sequence as follows:

**Escape Sequence:** Set the escape sequence characters at which the connection terminates.

**Inactivity timeout:** Set the inactivity timeout at which the connection terminates.

Others: Use to set the other terminating sequences: DTR-toggle or Always-On.

**DTR-toggle:** If DTR status goes low, the connection terminates.


Always-On: Sets the terminate sequence as Always-on.


Submit Button: Click Submit to save these settings.

## **Serial Port, Server Settings Parameters**

This feature enables a TCP/UDP client on the Ethernet network to connect to the remote serial terminal connected to the DE9, RS232 port on the router. The router acts as a TCP/UDP server which allows two way traffic between the TCP/UDP client and the remote terminal on the serial port.

The initial connection setup for the TCP/UDP server is shown in the figure that follows.





## **TCP/UDP - Server Configuration Group**

Configures TCP/UDP Server through which the serial terminal connected to the RS-232 connector, DE9 on the back of the unit listens for the remote TCP/UDP client to communicate on the LAN/WAN.

Status: Sets the client status to either Enable or Disable. The default is Disable

**Server Type:** Sets the client to either TCP or UDP. The default is TCP.

Port: Sets the server port. The default is None

**Connection Terminate By:** Sets the connection's terminate sequence as follows:

**Escape Sequence:** Set the escape sequence characters at which the connection terminates.

**Inactivity timeout:** Set the inactivity timeout at which the connection terminates.

**Others:** The other terminating sequences are: DTR-toggle or Always-On.

**DTR-toggle:** If DTR status goes low, the connection terminates.

**Always-On:** Sets the terminate sequence as Always-on.

**Submit Button:** Click Submit to save these settings.

## **Tools, Tools Parameters**



### **DDNS Group**


**DDNS Force Update:** Click **Update** to update the DDNS server with your current dynamically assigned IP address.

DDNS Status: Click Refresh to display the DDNS Status after a forced update.

## **Modem Group**

**Reset Modem:** Click **Reset** to reset the integrated cellular modem.

## **Tools, Firmware Upgrade Parameters**



## Firmware Upgrade Group

Use the Firmware Upgrade group to upgrade the firmware for the router. You can find and download all Multi-Tech firmware upgrades from the Multi-Tech Website.

Before you upgrade your firmware, note the following:

- Save your present configuration in case you want to use it again.
- The new firmware is written into flash memory.
- A firmware upgrade takes at least 4 minutes. Do not turn off power during this time because the firmware is being downloaded.
- Do not upgrade the firmware remotely through the Cellular wireless connection.


#### To upgrade firmware:

- 1. Navigate to the area where you stored the firmware upgrade. To do so, click **Browse**.
- 2. Select the mtcba-en2-u-xxx.bin file and press **Enter**. The file name displays in the **Browse file for upgrade** field. Make sure you select the correct BIN file; otherwise, your router can become inoperable.
- 3. Click Upgrade.

When upgrade is completed, the program returns to the main login screen.

- **4.** After the firmware upgrade is complete, verify the configuration is as expected.
  - In particular, check that the DHCP scope settings are set properly.
  - Also, up to four IPSEC tunnels can be active at any given time. You can save more than four active tunnels, but they are not active.

## **Tools, Load Configuration Parameters**



### **Load Configuration Group**

**Browse File for Load Configuration:** Click **Browse** to open the file that allows you to locate the configuration file. When found, highlight the file name and press **Enter** so that the file name displays in the field. Then click **Load**.

#### **Notes:**

- The new configuration is written into the flash.
- A Configuration Upgrade takes at least 3 seconds to download and 60 seconds to install the settings and reboot. Reboot happens automatically.

When you click **Load**, the following dialog box opens. It shows the name of the file you selected.



Click the Find, Save, or Cancel buttons as desired.

## **Tools, Save Configuration**

Click this option to save the configuration.

## **Statistics & Logs**


## **Statistics & Logs > System Information**

This is an example of the Statistics & Logs System Information.




## **Statistics & Logs > Ethernet**

This is an example of the Ethernet Statistics & Logs page. It shows Ethernet statistics.



## **Statistics & Logs > PPP**

This is an example of the PPP Statistics & Logs page. It shows PPP statistics when PPP is enabled.



## **Statistics & Logs > PPP Trace**

This is an example of the PPP Trace Statistics & Logs page. It shows the PPP trace messages.



## **Statistics & Logs > DHCP Statistics**

This is an example of the DHCP Statistics & Logs page. It shows the statistics of DHCP leases.



## **Statistics & Logs > GRE Statistics**

This page displays the statistics of active tunnels.




### Statistics & Logs > Modem Information

This page displays the modem commands set on the **PPP > Modem Commands** page and also displays the results of the commands.



### **Statistics & Logs > Service Status**

This page displays the summary of the service status.



### Statistics & Logs > TCP/UDP Client Live Log

This page displays the TCP/UDP Client Live Log.




## Statistics & Logs > TCP/UDP Server Live Log

This page displays the TCP/UDP Server Live Log.



## Statistics & Logs > IPSec Live Log

This page displays the IPSec Live Log.



## **Statistics & Logs > IPSec Log Traces**

This page displays the IPSec Log Traces.



# Appendix A – Commonly Supported Subnets

This table lists commonly supported subnets organized by address.

	Network Number	<b>Hosts Available</b>	Broadcast Address
255.255.255.128	N.N.N.0	N.N.N.1-126	N.N.N.127
/25	N.N.N.128	N.N.N.129-254	N.N.N.255
	Network Number	Hosts Available	Broadcast Address
255.255.255.192	N.N.N.O	N.N.N.1-62	N.N.N.63
/26	N.N.N.64	N.N.N.65-126	N.N.N.127
	N.N.N.128	N.N.N.129-190	N.N.N.191
	N.N.N.192	N.N.N.193-254	N.N.N.255
	Network Number	Hosts Available	Broadcast Address
255.255.255.224	N.N.N.O	N.N.N.1-30	N.N.N.31
/27	N.N.N.32	N.N.N.33-62	N.N.N.63
	N.N.N.64	N.N.N.65-94	N.N.N.95
	N.N.N.96	N.N.N.97-126	N.N.N.127
	N.N.N.128	N.N.N.129-158	N.N.N.159
	N.N.N.160	N.N.N.161-190	N.N.N.191
	N.N.N.192	N.N.N.193-222	N.N.N.223
	N.N.N.224	N.N.N.225-254	N.N.N.255
	Network Number	Hosts Available	Broadcast Address
255.255.255.240	N.N.N.O	N.N.N.1-14	N.N.N.15
/28	N.N.N.16	N.N.N.17-30	N.N.N.31
	N.N.N.32	N.N.N.33-46	N.N.N.47
	N.N.N.48	N.N.N.49-62	N.N.N.63
	N.N.N.64	N.N.N.65-78	N.N.N.79
	N.N.N.80	N.N.N.81-94	N.N.N.95
	N.N.N.96	N.N.N.97-110	N.N.N.111
	N.N.N.112	N.N.N.113-126	N.N.N.127
	N.N.N.128	N.N.N.129-142	N.N.N.143
	N.N.N.144	N.N.N.145-158	N.N.N.159
	N.N.N.160	N.N.N.161-174	N.N.N.175
	N.N.N.176	N.N.N.177-190	N.N.N.191
	N.N.N.192	N.N.N.193-206	N.N.N.207
	N.N.N.208	N.N.N.209-222	N.N.N.223
	N.N.N.224	N.N.N.225-238	N.N.N.239
	N.N.N.240	N.N.N.241-254	N.N.N.255

	Network Number	Hosts Available	Broadcast Address
255.255.255.248	N.N.N.0	N.N.N.1-6	N.N.N.7
/29	N.N.N.8	N.N.N.9-14	N.N.N.15
	N.N.N.16	N.N.N.17-22	N.N.N.23
	N.N.N.24	N.N.N.25-30	N.N.N.31
	N.N.N.32	N.N.N.33-38	N.N.N.39
	N.N.N.40	N.N.N.41-46	N.N.N.47
	N.N.N.48	N.N.N.49-54	N.N.N.55
	N.N.N.56	N.N.N.57-62	N.N.N.63
	N.N.N.64	N.N.N.65-70	N.N.N.71
	N.N.N.72	N.N.N.73-78	N.N.N.79
	N.N.N.80	N.N.N.81-86	N.N.N.87
	N.N.N.88	N.N.N.89-94	N.N.N.95
	N.N.N.96	N.N.N.97-102	N.N.N.103
	N.N.N.104	N.N.N.105-110	N.N.N.111
	N.N.N.112	N.N.N.113-118	N.N.N.119
	N.N.N.120	N.N.N.121-126	N.N.N.127
	N.N.N.128	N.N.N.129-134	N.N.N.135
	N.N.N.136	N.N.N.137-142	N.N.N.143
	N.N.N.144	N.N.N.145-150	N.N.N.151
	N.N.N.152	N.N.N.153-158	N.N.N.159
	N.N.N.160	N.N.N.161-166	N.N.N.167
	N.N.N.168	N.N.N.169-174	N.N.N.175
	N.N.N.176	N.N.N.177-182	N.N.N.183
	N.N.N.184	N.N.N.185-190	N.N.N.191
	N.N.N.192	N.N.N.193-198	N.N.N.199
	N.N.N.200	N.N.N.201-206	N.N.N.207
	N.N.N.208	N.N.N.209-214	N.N.N.215
	N.N.N.216	N.N.N.217-222	N.N.N.223
	N.N.N.224	N.N.N.225-230	N.N.N.231
	Network Number	Hosts Available	Broadcast Address
	N.N.N.232	N.N.N.233-238	N.N.N.239
	N.N.N.240	N.N.N.241-246	N.N.N.247
	N.N.N.248	N.N.N.249-254	N.N.N.255

	Network Number	Hosts Available	Broadcast Address
255.255.255.252	N.N.N.0	N.N.N.1-2	N.N.N.3
/30	N.N.N.4	N.N.N.5-6	N.N.N.7
	N.N.N.8	N.N.N.9-10	N.N.N.11
	N.N.N.12	N.N.N.13-14	N.N.N.15
	N.N.N.16	N.N.N.17-18	N.N.N.19
	N.N.N.20	N.N.N.21-22	N.N.N.23
	N.N.N.24	N.N.N.25-26	N.N.N.27
	N.N.N.28	N.N.N.29-30	N.N.N.31
	N.N.N.32	N.N.N.33-34	N.N.N.35
	N.N.N.36	N.N.N.37-38	N.N.N.39
	N.N.N.40	N.N.N.41-42	N.N.N.43
	N.N.N.44	N.N.N.45-46	N.N.N.47
	N.N.N.48	N.N.N.49-50	N.N.N.51
	N.N.N.52	N.N.N.53-54	N.N.N.55
	N.N.N.56	N.N.N.57-58	N.N.N.59
	N.N.N.60	N.N.N.61-62	N.N.N.63
	N.N.N.64	N.N.N.65-66	N.N.N.67
	N.N.N.68	N.N.N.69-70	N.N.N.71
	N.N.N.72	N.N.N.73-74	N.N.N.75
	N.N.N.76	N.N.N.77-78	N.N.N.79
	N.N.N.80	N.N.N.81-82	N.N.N.83
	N.N.N.84	N.N.N.85-86	N.N.N.87
	N.N.N.88	N.N.N.89-90	N.N.N.91
	N.N.N.92	N.N.N.93-94	N.N.N.95
	N.N.N.96	N.N.N.97-98	N.N.N.99
	N.N.N.100	N.N.N.101-102	N.N.N.103
	N.N.N.104	N.N.N.105-106	N.N.N.107
	N.N.N.108	N.N.N.109-110	N.N.N.111
	N.N.N.112	N.N.N.113-114	N.N.N.115
	N.N.N.116	N.N.N.117-118	N.N.N.119
	N.N.N.120	N.N.N.121-122	N.N.N.123
	N.N.N.124	N.N.N.125-126	N.N.N.127
	N.N.N.128	N.N.N.129-130	N.N.N.131
	N.N.N.132	N.N.N.133-134	N.N.N.135
	N.N.N.136	N.N.N.137-138	N.N.N.139
	N.N.N.140	N.N.N.141-142	N.N.N.143
	N.N.N.144	N.N.N.145-146	N.N.N.147
	N.N.N.148	N.N.N.149-150	N.N.N.151
	N.N.N.152	N.N.N.153-154	N.N.N.155
	N.N.N.156	N.N.N.157-158	N.N.N.159
	N.N.N.160	N.N.N.161-162	N.N.N.163
	N.N.N.164	N.N.N.165-166	N.N.N.167
	N.N.N.168	N.N.N.169-170	N.N.N.171
	N.N.N.172	N.N.N.173-174	N.N.N.175
	N.N.N.176	N.N.N.173-174 N.N.N.177-178	N.N.N.179
	N.N.N.180	N.N.N.181-182	N.N.N.173 N.N.N.183
	N.N.N.184	N.N.N.185-186	N.N.N.187
	N.N.N.188	N.N.N.189-190	N.N.N.191
	N.N.N.192	N.N.N.193-194	N.N.N.191 N.N.N.195
	N.N.N.196	N.N.N.197-198	N.N.N.199
	N.N.N.200	N.N.N.201-202	N.N.N.203
	N.N.N.204	N.N.N.205-206	N.N.N.207
	N.N.N.208	N.N.N.209-210	N.N.N.211

N.N.N.212	N.N.N.213-214	N.N.N.215
N.N.N.216	N.N.N.217-218	N.N.N.219
N.N.N.220	N.N.N.221-222	N.N.N.223
N.N.N.224	N.N.N.225-226	N.N.N.227
N.N.N.228	N.N.N.229-230	N.N.N.231
N.N.N.232	N.N.N.233-234	N.N.N.235
N.N.N.236	N.N.N.237-238	N.N.N.239
N.N.N.240	N.N.N.241-242	N.N.N.243
N.N.N.244	N.N.N.245-246	N.N.N.247
N.N.N.248	N.N.N.249-250	N.N.N.251
N.N.N.252	N.N.N.253-254	N.N.N.255

# **Appendix B - Regulatory Compliance**

# ( (

# **EMC, Safety, and R&TTE Directive Compliance**

The CE mark is affixed to this product to confirm compliance with the following European Community Directives:

Council Directive 2004/108/EC of 15 December 2004 on the approximation of the laws of Member States relating to electromagnetic compatibility;

and

Council Directive 2006/95/EC of 12 December 2006 on the harmonization of the laws of Member States relating to electrical equipment designed for use within certain voltage limits;

and

Council Directive 1999/5/EC of 9 March 1999 on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity.

### FCC Part 15 Class A Statement

This equipment has been tested and found to comply with the limits for a **Class A** digital device, pursuant to 47 CFR Part 15 regulations. The stated limits in this regulation are designed to provide reasonable protection against harmful interference in a commercial installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Plug the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the CFR 47 rules. Operation of this device is subject to the following conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# **Industry Canada**

This Class A digital apparatus meets all requirements of the Canadian Interference-Causing Equipment Regulations.

Cet appareil numérique de la classe A respecte toutes les exigences du Règlement Canadien sur le matériel brouilleur.

# Appendix C - Environmental Information

July, 2005

#### Waste Electrical and Electronic Equipment (WEEE)

The WEEE directive places an obligation on EU-based manufacturers, distributors, retailers and importers to take-back electronics products at the end of their useful life. A sister Directive, ROHS (Restriction of Hazardous Substances) complements the WEEE Directive by banning the presence of specific hazardous substances in the products at the design phase. The WEEE Directive covers all Multi-Tech products imported into the EU as of August 13, 2005. EU-based manufacturers, distributors, retailers and importers are obliged to finance the costs of recovery from municipal collection points, reuse, and recycling of specified percentages per the WEEE requirements.

#### Instructions for Disposal of WEEE by Users in the European Union

The symbol shown below is on the product or on its packaging, which indicates that this product must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of their waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or where you purchased the product.



# **REACH Statement**

Registration of Substances:

After careful review of the legislation and specifically the definition of an "article" as defined in EC Regulation 1907/2006, Title II, Chapter 1, Article 7.1(a)(b), it is our current view Multi-Tech Systems, Inc. products would be considered as "articles". In light of the definition in § 7.1(b) which requires registration of an article only if it contains a regulated substance that "is intended to be released under normal or reasonable foreseeable conditions of use," our analysis is that Multi-Tech Systems, Inc. products constitute nonregisterable articles for their intended and anticipated use.

Substances of Very High Concern (SVHC):

Per the candidate list of Substances of Very high Concern (SVHC) published October 28, 2008 we have reviewed these substances and certify the Multi-Tech Systems, Inc. products are compliant per the EU "REACH" requirements of less than 0.1% (w/w) for each substance.

If new SVHC candidates are published by the European Chemicals Agency, and relevant substances have been confirmed, that exceeds greater than 0.1% (w/w), Multi-Tech Systems, Inc. will provide updated compliance status.

Multi-Tech Systems, Inc. also declares it has been duly diligent in ensuring that the products supplied are compliant through a formalized process which includes collection and validation of materials declarations and selective materials analysis where appropriate. This data is controlled as a part of a formal quality system and will be made available upon request.

# Restriction of the Use of Hazardous Substances (RoHS)



Multi-Tech Systems, Inc.

#### **Certificate of Compliance**

#### 2002/95/EC

Multi-Tech Systems, Inc. confirms that this product now complies with the chemical concentration limitations set forth in the directive 2002/95/EC of the European Parliament (Restriction Of the use of certain Hazardous Substances in electrical and electronic equipment - RoHS)

These Multi-Tech Systems, Inc. products do not contain the following banned chemicals:

Lead, [Pb] < 1000 PPM

Mercury, [Hg] < 1000 PPM

Hexavalent Chromium, [Cr+6] < 1000 PPM

Cadmium, [Cd] < 100 PPM

Polybrominated Biphenyl, [PBB] < 1000 PPM

Polybrominated Diphenyl Ether, [PBDE] < 1000 PPM

#### **Notes:**

- 1. Lead usage in some components is exempted by the following RoHS annex; therefore, higher lead concentration could be found
  - a. Lead in high melting temperature type solders (i.e., tin-lead solder alloys containing more than 85% lead).
  - b. Lead in electronic ceramic parts (e.g., piezoelectronic devices).

# **China ROHS**

### 依照中国标准的有毒有害物质信息

根据中华人民共和国信息产业部 (MII) 制定的电子信息产品 (EIP) 标准 - 中华人民共和国《电子信息产品污染控制管理办法》(第 39 号),也称作中国

RoHS,下表列出了 Multi-Tech Systems Inc. 产品中可能含有的有毒物质 (TS) 或有害物质 (HS) 的名称及含量水平方面的信息。

	有害/有毒物 <b>质</b> /元素					
成分名称	铅 (PB)	汞 (Hg)	镉 (CD)	六价 <b>铬</b> (CR6+)	多 <b>溴联</b> 苯 (PBB)	多 <b>溴</b> 二苯醚 (PBDE)
印刷电路板	0	0	0	0	0	О
电阻器	Х	0	0	0	0	0
电容器	Х	0	0	0	0	0
铁氧体磁环	Ο	0	О	0	О	О
继电器/光学部 件	0	0	0	0	О	О
IC	0	0	0	0	0	0
二极管/晶体管	0	0	0	0	0	0
振 <b>荡</b> 器和晶振	X	0	О	О	0	0
调节器	0	0	0	0	0	О
电压传感器	0	0	0	0	0	О
变压器	0	0	0	0	0	0
扬声器	0	0	0	0	0	0
连接器	0	0	0	0	0	О
LED	0	0	0	0	0	0
螺丝、螺母以及 其它五金件	X	0	0	0	0	0
交流-直流 <b>电</b> 源	0	0	0	0	0	0
软件/文档 CD	0	0	0	0	0	0
手册和纸页	0	0	0	0	0	0
底 <b>盘</b>	0	0	0	0	0	0

- X 表示所有使用类似材料的设备中有害/有毒物质的含量水平高于 SJ/Txxx-2006 限量要求。
- **O** 表示不含**该物质**或者**该物质**的含量水平在上述限量要求

# **Index**

${f A}$	GRE routing	
	GRE tunnel configuration	
Access Point Name24	GRE tunnelingGSM RF Specifications	
AH Key67	OSW KI Specifications	10
Authentication Algorithms67	TT	
Auto Dialout configuration30	Н	
Autodiscovery configuration30	H323 packets connection tracking	58
	Handling Precautions	
В	HTTP authentication	
Day 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1	HTTP configuration	
Broadcast timer		
Browse File for Upgrade in Tools	I	
Browse File to Load Configuration75	1	
	ICMP configuration	58
C	ICMP Keep Alive Check	
Caller ID for Wakeup on Call46	IP Configuration	30
Canadian Regulations	IP Server	33
CDMA Antenna Specifications	ITCP	54
CDMA RF Specifications16		
Circuit Switched Data	L	
Configure Ethernet interface		
25	Load Configuration	75
D	$\mathbf{M}$	
Daylight Savings Time configuration36	Managaran	20
DDNS Client33	Menu structure	
DDNS configuration33	Modem Information	82
DDNS Status in Tools73	N.T.	
DHCP configuration61	N	
DHCP fixed addresses62	NAT configuration	41
DHCP Lease Time61	Navigating	
DHCP server61	Network configuration	
Dial-on-Demand42	Network/Host for Remote Configuration	
DNAT configuration	1,000,011,11000,101,11011000,000,00111,0011	
DNAT example56	P	
Dynamic DNS configuration33		
	Packet Filter	54
${f E}$	Packet filter rules	54
EMC Coffee and DOTTE Disasting Compliance	Perfect Forward Secrecy	65
EMC, Safety, and R&TTE Directive Compliance86	Pin Functions	18
Ethernet ports caution9	Polling time	35
<b>T</b>	Power Requirements	15
${f F}$	Power-On Configuration	50
Firmware Upgrade74	PPP authentication	42
Tilliware Opgrade74	PPP configuration	42
	PPTP connection tracking	58
${f G}$	protocol	54
General Configuration – IP Setup30	<u>_</u>	
GPS Antenna Specifications	R	
GPS RF Specifications17	Pay Dislant configuration	20
GRE route configuration60	Raw Dialout configuration	
	Remote Configuration	3/

Reset Modem in Tools73	Т	
Route configuration36	•	
č	Technical Specifications	
S	Temperatures	14
S	Time zone configuration	35
Safe password32	Tools	73
Save configuration in Tools75		
Select encryption method67	U	
Server Port30	Č	
Service Configuration53	UDP	54
SNTP configuration35		
Static Routes configuration	${f V}$	
Statistics & Logs > DHCP Statistics79		
Statistics & Logs > Ethernet77	Vehicle Safety	9
Statistics & Logs > Modem Information80		
Statistics & Logs > PPP78	${f W}$	
Submenus28	W. I. C. II	
Subnets82	Wakeup on Call	
Syslog configuration30	Wakeup on Call Examples	
System domain name 33	Wizard Setup	23, 24

# **CDMA 1xEV-D0**

# AT Commands Reference Guide



#### CDMA 1xEV-D0 AT Commands Reference Guide for the following products:

SocketModem® (MTSMC-EV2)
MultiModem® Cell (MTCBA-EV2)
MultiModem® iCell (MTCMR-EV2)
MultiModem® rCell (MTCBA-EV2-EN2)

#### PN S000482B, Version B

#### Copyright

This publication may not be reproduced, in whole or in part, without prior expressed written permission from Multi-Tech Systems, Inc. All rights reserved.

Copyright © 2010 by Multi-Tech Systems, Inc.

Multi-Tech Systems, Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaim any implied warranties of merchantability or fitness for any particular purpose. Furthermore, Multi-Tech Systems, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Multi-Tech Systems, Inc. to notify any person or organization of such revisions or changes.

#### **Revisions**

**Revision Level Date Description** A 08/10/10 Initial release.

**B** 08/24/10 Add MultiModems to the list of products that this AT command set supports.

#### **Trademarks**

Multi-Tech Systems, Inc. registered trademarks include: **SocketModem**, **MultiModem** and the Multi-Tech logo.

#### **World Headquarters**

Multi-Tech Systems, Inc. 2205 Woodale Drive Mounds View, Minnesota 55112 Phone: 763-785-3500 or 800-328-9717

Fax: 763-785-9874

Internet Address: http://www.multitech.com

#### **Technical Support**

Please refer to the Copyright/Technical Support page in the product User Guide or Developer Guide.

# **Contents**

Chapter 1 – Introduction	7
Document Structure	7
Conventions	7
Modem Basics	8
Host Connection Basics	9
State Transitions	11
Modem Buffers	11
Command Handling	12
Responses and Result Codes	13
Chapter 2 – Overview of Commands	15
Introduction	15
AT Commands Summary by Function	15
Basic Operation Action Commands	
Basic Modem Configuration Commands	
Advanced Modem Configuration Commands	
Device and Service Interrogation Commands	17
SMS Messages Commands	
Chapter 3 – ! Prefix Commands	18
!APPSUBTYPES Negotiated Subtypes	
!CNTSMS Count SMS	
!DASMS Delete All SMS	
!DSMS= Delete SMS (Selective)	
!ECIO? Ec/lo	
!GMODE Mode of the Modem	
!GSMS? Get SMS	
!MDMVER? Version of the Modem Firmware	
!MUFWDRESET Reset Data in !MUFWDSTATS	
!MUFWDSTATS Current Traffic Channel Statistics	
!PERSONALITY? Displays Current Personality	
!PRLVER? PRL Version	
!PROTSUBTYPES? Negotiated Subtypes	
!RSSI? Received Signal Strength Indication	
!SCPCUSTCONFIG? Current Session Configuration Protocol Customer Configuration	
!SESSIONSTATUS Current Session Status	
!SIPID= User ID Information for Simple IP Setup	
!SIPPWD= Password Information for Simple IP Setup	
!SLEEPPARMS Sleep Parameters	
!SSMS= Send SMS	24
!STATUS Status of the Modem	
!SUFWDCCSTATS Current Single User Forward Channel Statistics on DRCs	
!SUFWDCRCS Current Single User Forward Channel Statistics on CRCs	26
!SUFWDRESET Resets Data	26
!SUFWDTCSTATS Current Single User Forward Channel Statistics	
!SYSTIME? CDMA Time	27

Chapter 4 – \$ Prefix Commands	28
\$QCCAV Answer Voice	28
\$QCMIP Mobile IP (MIP) Behavior	28
\$QCMIPEP Enables/Disables the Currently Active Mobile IP User Profile	28
\$QCMIPGETP Query a User Profile	29
\$QCMIPNAL Set the Network Access ID (NAI) for the Currently Active Profile	
\$QCMIPP Select One of the Mobile IP User Profiles to Be the Current Active Profile	
\$QCVAD= Sets or Reads the Mode for Answering Data Calls	
Chapter 5 – & Prefix Commands	
&C Data Carrier Detect Control	
&D Data Terminal Ready Options	_
&F Factory Settings Restore	
&V View Configuration	
•	
Chapter 6 – +C Prefix Commands	
+CAD? Analog or Digital Service	
+CBIP? Base Station IP Address (Read-only)	
+CDV Dial Voice	
+CFG= Configuration String	
+CHV Hang-up Voice	
+CMIP? Mobile Station IP Address	
+CMUX= Multiplex Option	
+CQD= Command State Inactivity Timer	
+CRC= Cellular Result Codes	
+CRM= Local (Rm) Interface Protocol	
+CSQ? Signal Quality	35
+CSS? Serving System	
+CTA= Packet Data Inactivity Timer	36
+CXT= Cellular Extension	36
Chapter 7 – +F Prefix Command	37
+FCLASS= Modem Operating State	37
Chapter 8 – +G Prefix Commands	38
+GCAP Get Capabilities	
+GMR Get Revision	
+GMI Get Manufacturer	
+GMM Get Model Number	
+GOI Get ISO ID	
+GSN Get ESN	
Chapter 9 – +I Prefix Commands	
+ICF= Character Framing	
+ILRR Local Rate Reporting	
+IPR – Set Serial Speed	
Chapter 10 – +M Prefix Commands	
+MA= Modulation Auto Mode	
+MR= Modulation Reporting	
+MS= Modulation Selection	
+MV18R= V.18 Reporting	
+MV18S= V.18 Selection	43

Chapter 11 – +W Prefix Commands	.44
+WGETWK Request Wake-Up Reason	.44
+WWKUP= Wake-Up Events Mask	.44
Chapter 12 – No Prefix Commands	.45
+++ Escape	
A Answer (Manual)	
D Dial46	
E Echo	47
H Hook Control	
I Product Identification Information	
L Loudness (Speaker Volume)	
M Mute (Speaker Control)	
O Online (Remote)	
P Pulse Dialing	
Q Quiet (Result Code Display Option)	
S <n>= S-Register Set/Query</n>	
T Tone (Set DTMF Dialing)	
V Verbose (Result Code Form)	
X Result Code Select/Call Progress Control	
Z Profile Restore	
Chapter 13 Prefix Commands	
-DTMFB= DTMF Burst	
-DTMFK= DTMF Key	
-ECHO= Echo Cancellation Level	.51
-HDSET= Headset Detection Option	
-MICMUT= Microphone Mute	.52
-NAMLCK= NAM Lock	.52
-NAMVAL= NAM Values	.53
-RESET Soft Reset	.53
-SHTDWN Shutdown	.53
-SPKMUT= Speaker (Headset) Mute	.54
-SPKVOL= Speaker (Headset) Volume	.54
-STGLVL= Side Tone Gain Level	.54
-TONDUR= Tone Duration	.55
-TONMUT= Tone Mute	.55
Chapter 14 – Status Registers	-56
Table of S-Registers	
Chapter 15 – Result Codes	58
Basic Result Codes	
Extended Cellular Result Codes	
Extended Cellular Call Progress Result Codes	.59
Chapter 16 – Stored Profile Settings	.60
Appendix A – Working With the IWF	.61
Introduction	
Local and Remote Commands	
Local Only	
Shared	
Remote-only	
Airlink Control	.62

	. 45.0 0. 00
Establishing the Airlink	62
Initializing the Airlink	62
Pass through and Reflection	63
Closing the Airlink	
Modem Defaults and Configurations	
Appendix B – ASCII Table	64
Appendix C – Acronyms and Definitions	65
Index	66

# **Chapter 1 - Introduction**

### **Document Structure**

Following this introduction is a section on basic elements important to understanding and communicating with the modem. This includes discussions of the QNC (Quick Net Connect) call setup process and interaction with the CDMA Interworking Function (IWF), as well as notes on the connection between the host (DTE) and the Wireless modem (DCE).

The document then presents the commands, registers, result codes, and defaults provided in the command state of the modem.

Commands are often termed AT commands since this character sequence (originated by Hayes $^{\text{TM}}$ ) is used to prefix each specific command.

In addition to the commands, the definitions and use of status registers are also described.

Commands are referenced in strict alphabetical order. This facilitates searches for the syntax, parameters, and operation of specific commands. To help locate whether or not a command exists to perform a desired function, tables organize the commands into these groups:

- Basic modem operation actions commands that make the modem execute an immediate action, such as dialing, or restoring settings.
- Basic modem configuration settings governing the modem's behavior when executing basic operations.
- Advanced modem configuration settings governing the modem's behavior related to advanced operations (for example, Mobile IP).
- Account activation and management commands.
- Device and service interrogation commands commands to determine the services available, information about and the status of the modem.
- Voice operation related to configuring, making, and controlling voice calls.
- SMS operations commands to check, receive, and delete, incoming messages, and to originate outgoing messages.
- GPS commands (See Universal IP AT Commands Guide).

In addition to the commands, the definitions and use of status registers are also described. The factory / reset defaults are listed in a separate table.

Result codes, both numeric and verbose, are provided in a separate table.

Extended Cellular Result Codes are also listed separately.

### Conventions

The following format conventions are used in this reference.

Character codes or keystrokes that are described with words or standard abbreviations are shown within angle brackets using a different font: such as <CR> for Carriage Return and <space> for a blank space character.

Numeric values are decimal unless prefixed as noted below.

Hexadecimal values are shown with a prefix of 0x, i.e. in the form 0x3D.

Binary values are shown with a prefix of 0b, i.e. in the form 0b00111101.

Command and register syntax is noted using an alternate font: !DSMS=<i>[,m].

The "AT" characters are not shown, but must be included before all commands except as noted in the reference tables.

Characters that are required are shown in uppercase; parameters are noted in lowercase. Required parameters are enclosed in angle brackets (<i>) while optional parameters are enclosed within square brackets ([m]). The brackets are not to be included in the command string.

The default settings are noted in the command tables. Note that these are the factory default settings and not the default parameter value assumed if no parameter is specified. The factory defaults are also noted in a section at the end of each operational mode reference.

**Result Code** – This is a numeric or text code that is returned after all commands (except resets). Only one result code is returned for a command line regardless of the number of individual commands contained on the line.

**Response** – This term indicates a response from the modem that is issued prior to a result code. Reading registers or issuing commands that report information will provide a response followed by a result code unless the command generates an error.

For a discussion of how the modem frames these two elements, see "Framing".

Responses and result codes from the modem, or host system software prompts, are shown in this font:

CONNECT 14400

#### **Modem Basics**

#### **CDMA Basics**

To help understand the call connection process in CDMA modems, a basic knowledge of the CDMA network helps. Two primary services are available using a CDMA 1xEVDO modem:

- IS-95B, a circuit switched type of connection; and
- 1x/1xEVDO, a packet switched connection.


#### Traditional Wire Line

Before looking at the call setup process in CDMA, let's take a moment to review the traditional wire line modem. A call is established by the local modem placing the call over the Public-Switched Telephone Network (PSTN). The local and remote modems are connected and handshake the data protocol to use. The local modem can monitor the call progress by picking up the dial tone, busy, ring, and answer from the PSTN wire line connection.

#### CDMA IS-95B

Not being connected to the PSTN, the modem must first connect to the CDMA network. The CDMA service provider connects the call to either the PSTN or (by using QNC) the Internet. This environment uses an Interworking Function (IWF) to bridge the two systems.

#### **CDMA IS-95B Call Connection Block Diagram**



When using IS 95, there is special handling of AT commands. For a detailed explanation, consult Appendix A Where traditional wire line has only the local host and modem on one side, the CDMA IS-95 model requires two modems on the local side: the IWF and the Wireless radio modem. These two modems must work as a team to make a data connection.

For Internet connections, the interworking function can use a special feature called QNC (Quick Net Connect). The IWF provides a link to the Internet without going through the PSTN.

Establishing a standard point-to-point call requires the cellular modem to configure a modem at the IWF. It is the IWF modem that actually connects to the PSTN and dials the number. Call progress is not directly available to the local modem, although some information can be exchanged. When the IWF has completed the handshake with the remote modem, the local modem is advised and the connection is complete.

#### CDMA 1X

In areas where this service is provided, the modem can connect much like a local area network card. The connection can be "always on" and only actively used when there is packet data to send or receive.

CDMA 1X offers higher speed data operations than are available with IS-95 service. IS 95 is limited to 14.4 kbps. The packet services of CDMA 1X use a fundamental channel at 9600 bps and can add supplemental channels when needed to boost speed to as high as 153.6 kbps.

#### CDMA 1xEV-DO

In areas where this service is provided, the modem can provide packet data services at a much higher data rate, as shown in the following table.

Data Service		Theoretical Maximum Data Rate	Typical Data Rate		
1xEV-DO rev. 0	Upload	153 kbps	40-80 kbps		
	Download	2.4 Mbps	400–700 kbps		
1xEV-DO rev. A	Upload	1.8 Mbps	300–400 kbps		
	Download	3.1 Mbps	600-1300 kbps		

#### **Voice Service**

Also added to the modem is the ability to make and receive voice calls. This allows the modem to serve as a cellular telephone.

#### **Host Connection Basics**

The embedded modem provides a USB interface and optional serial port interfaces. To support the high data rate of the 1xEVDO service the USB is highly recommended. The "Modem Port" presented is the interface available for performing AT commands.

#### Modes, States, and Conditions

Discussion of the operation of the modem requires understanding the settings of the modem and just how it is handling the data being sent to it. Describing the modem as being in a particular "mode" is not sufficient to capture the various characteristics of the modem in any given case.

To improve clarity, this document uses the words "mode", "state", and "condition" to reflect different elements of the modem's configuration. This section describes the various modes, states, and conditions that are used in the reference.

The CDMA 1X modems operate very much like a landline modem. There are, however, some differences in that the modem supports multiple connection options.

One method of operation is to place a call just like a landline modem would (asynchronous serial). We call this a CSC (Circuit Switched Cellular) call. This type of connection supports data communication, and is available in IS-95 service areas.

An alternate (and more common) method is to place a QNC call by dialing a special number provided by your carrier. QNC provides a mechanism to connect to the Internet using PPP, without using an intermediate modem. This is functionally identical to using Dial-Up Networking for a PPP connection to an Internet Service Provider (TCP/IP) on a standard landline modem. QNC offers a faster call connection time than standard CSC calls. This is also available in IS-95 coverage.

EV-DO products introduce a third data connection type, using 1X service. This is a packet data connection that does not tie up a circuit (or channel), but rather operates like a packet switched network, in which multiple users share the resources and only use them when there is data to send or receive.

These three calling options are simply different methods of placing what amounts to a data call. As such they are not included in the classification of modes, states, and conditions.

The commands and registers used depend on the modem's operating mode. The state of the modem and its condition also determine how the modem will behave in any given situation.

#### Modes

For the purposes of this document, the following are the modes of operation: Data and Voice.

#### Data (CSC, QNC, or Packet)

Connections to a PCS or cellular network for data transfers. This includes asynchronous (CSC) calls, PPP packet connections to the network (QNC), and 1X packet service connections.

#### **Voice**

The product is being used for voice communication. In addition to the basic modes (data and voice), there are states and conditions to consider.

#### States

The modem's state, in conjunction with its condition, governs how the modem handles traffic to and from the host (DTE), and to and from a remote modem. Data mode can support up to three states: Command, Pass through, and Data.

#### Command

The modem exchanges data with the host (DTE) as AT commands and replies. This state handles commands at the modem without the use of the airlink to the IWF modem. Voice modes are always in command state.

#### **Passthrough**

The modem has an active airlink with the IWF but is otherwise in the Command state. Data from the local host is passed through the modem to the IWF where it is executed as an AT command and then reflected back for execution by the local modem. This state only applies to IS-95 calls, not 1X packet connections.

#### Data

Communication is passed between the host and a remote terminal or network as computer data.

**Note:** Voice modes do not support the data state. Even while off hook with a voice call active, the modem still communicates over the serial connection in command state. Commands can be issued and executed while a voice call is in progress.

#### **Conditions**

In addition to mode and state the modem can be in one of two conditions: online and offline.

#### **Online**

Actively connected to a remote terminal or network (off-hook).

#### Offline

Disconnected from any remote terminal or network (on-hook).

While in offline condition the modem can only be:

- In command state (without an airlink), or
- In pass through state with an airlink to the IWF modem but without an active call.

In the online condition, the modem can be:

- In data state, which passes data through the modem between the host (DTE) and the remote terminal or network.
- In pass through state (IS-95B), which exchanges commands and replies between the host (DTE) and the IWF modem (DCE). The data is not sent all the way through the active connection to the remote terminal. The remote connection is still active (carrier is maintained) but data is not forwarded to the remote end.

#### **State Transitions**

On power up the modem is in command state.

#### **Command to Data State**

The modem changes to data state when a session is opened either by dialing a connection (or answering a data or fax call). When a session opens, the modem issues the CONNECT message and asserts the DCD control signal.

**Note:** Due to multi-processing in the modem, the DCD signal may be asserted slightly before the modem has completed the transition to data state. The host device should allow a delay of 100 ms after receiving the complete CONNECT message and DCD signal before beginning transmission; otherwise some data may be lost.

#### **Data to Command State**

When the modem changes to command state, an OK result is issued. This may be preceded by another result (such as NO CARRIER) to indicate that the session was closed by an event outside the modem. A closed session requires the modem to return to command state.

Several events can cause the modem to transition from data to command state based on mode.

SLIP mode transitions:

- DTR is deasserted, with a configuration to use DTR (&D1 or &D2)
- The modem receives the escape sequence as a SLIP frame: (0xC0 +++ 0xC0)
- The modem is reset or power-cycled

PPP mode transitions:

- DTR is deasserted, with a configuration to use DTR (&D1 or &D2)
- PPP negotiates command state
- The modem is reset or power-cycled

### **Modem Buffers**

Communication with the modem is buffered to allow the modem to provide a variety of features and speed configurations. This section provides an introduction to the types of buffering performed by the modem.

#### **Command Buffer**

When in command state, the modem buffers the input from the host until a <CR> is entered. The buffered data can be edited using the backspace <BS>. The modem (with Echo enabled) may echo the sequence <BS><space><BS> for human readability.

There is a limit of 518 characters to one command line, excluding the AT prefix and the <CR> termination. If the command buffer length is exceeded, the modem continues to echo input (which is not buffered) until the <CR> is received. When the <CR> is entered, the modem returns the ERROR result code without executing any commands in the line. Once over the limit, the <BS> does not bring you back under the limit; the ERROR code is still returned.

The command buffer is distinct from the data receive and transmit buffers. The command buffer retains the contents of the last issued command until the AT command prefix is received for the next command.

#### **Data Buffers**

Data being transmitted or received is buffered in several ways depending on the mode and nature of the connection. Some caution must be taken when disconnecting to ensure that any buffered data in the modem has been properly processed prior to breaking the connection.

Specific settings for buffer controls are described in the relevant commands and registers. Normal configuration of the modem does not require you to adjust these settings.

#### Speed Buffering

The simplest form of buffering allows for line speed differences and busy conditions between the host (DTE) and modem and between the modem and the remote terminal or network. The network side of the connection can have rates up 153.6 kbps, while the local host connection can be at one of many different speeds from 300 bps to 230.4 kbps.

Where large amounts of data are being exchanged, local hardware flow control must be used to prevent buffer overflows. To reduce packet loss, the CDMA protocol incorporates flow control on the network connection.

# **Command Handling**

AT can be issued as a command without parameters. It acts like a "ping" to the modem and always gives a result code of "OK". If there is no response from the modem, try issuing ATQ0 (Quiet mode off). If this fails, try the "+++" escape sequence or resetting the modem.

Commands may be entered in upper or lower case.

#### Concatenation

More than one command can be included in a single line, although some commands or their parameters must be placed at the end of the line. When concatenating commands, a space between basic commands is optional. Where extended commands (those beginning with a non-alphabetic character) are concatenated, they must be separated by a semi-colon.

Commands are executed in the order entered. If a command results in the ERROR result code, the balance of the command line is ignored. Only one result code is returned for the entire command line.

#### **Parameters**

Most AT commands support one or more parameters, usually a number. Parameter ranges are specified in the reference.

Commands that normally accept a single numeric option switch ([n]) and are issued without that parameter assume a value of zero (0).

Defaults shown in the command tables are those for the factory settings of the modem and are not the defaults assumed for a command issued without parameters.

#### Registers

Some registers are read only. If an attempt is made to write to a read only register, the ERROR result code is returned.

Some registers store the setting of commands. Changing the register is equivalent to changing the command setting. See the Table of S-Registers for the standard default values.

See the Table of Stored Profile Settings for the factory defaults.

# **Responses and Result Codes**

Most commands return only a result code however some commands request information, which is provided by the modem as a response prior to the result code.

#### Possible Result Codes

Result codes are not shown in the command tables unless special conditions apply. Generally the result code OK is returned when the command has been executed. ERROR may be returned if parameters are out of range, and is returned if the command is not recognized, or the command is not permitted in the current mode, state, or condition of the modem.

See the Table of Result Codes, giving both the numeric and verbose results.

#### Human vs. Machine Interface

The AT command interface was designed for human interaction. When an intelligent host is managing a modem, the interface may need to be altered; result code words replaced with numbers, for example. Framing characters (line feeds and carriage returns) must be properly understood to ensure the host system properly parses the responses and result codes.

As shipped the modem is configured with these settings:

- Echo enabled (E1): which causes the modem to echo characters received from the host back to it while in command state. The backspace is echoed as <BS>.
- Quiet result codes disabled (Q0): which enables the modem to issue result codes following commands. Quiet on (Q1) suppresses result codes entirely; responses remain unaffected.
- Verbose result codes (V1): which provides results in English text appended with <CR><LF>.
   Verbose off (V0) returns the results as ASCII numeral codes. Numeric codes are much easier to process.

With Echo on (E1 - the default), data received from the local host while in command state is echoed back to the host. This can present problems to machine control, which is not interested in an echo of its own commands to the modem. In some configurations the echo should be turned off (E0).

The configuration for most machine-controlled hosts is more likely to be set to Echo Off, and Verbose Off or possibly Quiet On.

#### **Framing**

The framing of the response and result elements by <CR><LF> depends heavily on the settings of the modem. In particular the settings of Verbose (V) and Quiet (Q) modes alter the framing of both responses and result codes.

These elements are normally formatted for human reading with a terminal program, however users wishing to have software read and adjust to these responses and result codes must understand how they are framed.

#### Framing Characters

The modem will frame replies with carriage return and line feed characters as they are defined in registers S3 and S4 respectively. These are normally the ASCII values 13 <CR> and 10 <LF>. For the purposes of the discussion here, they are referred to as <CR> and <LF>.

If there are any problems determining the exact framing of the response and result codes, use a protocol analyzer to monitor the exchanges.

#### Response Framing

Regardless of command settings, responses are in ASCII text with a trailing <CR><LF>. Where a response has more than one line, each line is terminated with a <CR><LF>. The programmer must know the number of lines expected in the response.

The setting of Verbose (V) on (=1) triggers a leading <CR><LF> prior to the first line of the response. If Verbose is off (=0), there are no leading characters prior to the first line of response.

The setting of Quiet (Q) has no impact on responses.

#### Result Code Framing

Every command returns a result code unless the Quiet command is enabled. If Quiet (Q) is on (=1), then there are no framing characters nor any result code returned; the modem is truly silent with respect to result codes.

A leading <CR><LF> is inserted ahead of the result code if Verbose (V) is on (=1), otherwise there are no leading characters prior to the ASCII numeral result.

The result code is always followed by a <CR>. There is a trailing <LF> only if Verbose is on. Samples:

V=1 <CR><LF>OK<CR><LF>

V=0 0<CR>

# Chapter 2 – Overview of Commands

#### Introduction

The modem supports commands for:

- IS 95B data service
- 1X packet service
- SMS
- GPS (See Universal IP AT Commands Guide)

# **AT Commands Summary by Function**

The reference tables are presented in strict ASCII alphabetical order (including prefixes). This format allows quick look-up of each command to verify syntax, parameters, and behaviors. It does not lend itself to finding whether or not the modem has a command to perform a particular service or setting.

The summary in this section organizes the commands into functional groups to allow you to more quickly locate a desired command when the operation is known but the command is not.

#### **Basic Operation Action Commands**

Command	Description
&F	Factory Settings Restore
&V	View Configuration
+++	Escape from Data State to Command State
Α	Answer – Manual
D	Dial
Н	Hook Control
0	Online (Remote)
Z	Profile Restore
-DTMFB	DTMF Burst
-DTMFK	DTMF Key
-RESET	Reset
-SHTDWN	Shutdown
-TONMUT	Tone Mute

#### **Basic Modem Configuration Commands**

Command	Description
&C	Data Carrier Detect Control
&D	Data Terminal Ready Options
+CFG	Configuration String
+CMUX	Multiplex Option
+CQD	Command State Inactivity Timer
+CRC	Cellular Result Codes
+CRM	Local (Rm) Interface Protocol
+CTA	Packet Data Inactivity Timer
+CXT	Cellular Extension
+FCLASS	Modem Operating State

**Command Description** 

+ICF Character Framing
+ILRR Local Rate Reporting
+IPR Fixed Port (Rm) Rate
+MA Modulation Auto mode
+MR Modulation Reporting
+MS Modulation Selection
+MV18R V.18 Reporting

+WWKUP
 E Wake-up Events Mask
 E Echo (Command State)
 L Loudness (Speaker Volume)
 M Mute (Speaker Control)

P Pulse Dialing

+MV18S

Q Quiet – Result Code Display Option

V.18 Selection

S S-Register Read and Write

T Tone Dialing

V Verbose – Result Code Form
X Result Code/Call Progress Control

-HDSET Headset Detection Option

-TONDUR Tone Duration

#### **Advanced Modem Configuration Commands**

Command Description

!APPSUBTYPESApplication subtypes negotiated for the four streams!MUFWDRESETResets all the data reported by !MUFWDSTATS.!MUFWDSTATSCurrent Multi-User Forward Traffic Channel Statistics!PERSONALITYCurrent personality and its negotiated protocol subtypes!PROTSUBTYPESNegotiated subtypes for all protocols in all stored personalities

!SCPCUSTCONFIGCurrent Session Configuration Protocol Customer configuration!SESSIONSTATUSCurrent HDR session status!SIPIDSimple IP setup (user ID)

!SIPID Simple IP setup (user ID)
!SIPPWD Simple IP setup (password)

!SIPPWD Simple IP setup (password)

!SLEEPPARMS 1xEV-DO Rev. A sleep parameters (slot cycle indexes and sleep periods)
!SUFWDCCSTATS Current Single User Forward Channel Statistics (Single User packet early

slot termination count for all supported DRCs on Forward Control Channel)

!SUFWDCRCS Current Single User Forward Channel Statistics (Single User packet CRCs

and Packet Error Rate).

!SUFWDRESET Resets the data reported by !SUFWDCCSTATS, !SUFWDCRCS, and

!SUFWDTCSTATS.

!SUFWDTCSTATS Current Single User Forward Channel Statistics (Single User packet early

slot termination count for all supported DRCs on Forward Traffic Channel)

\$QCMIP Mobile IP behavior

\$QCMIPEP Enables/disables the currently active Mobile IP user profile.

\$QCMIPGETP Query a user profile

\$QCMIPNAI Set the Network Access ID (NAI) for the currently active profile

\$QCMIPP Select one of the Mobile IP user profiles to be the current active profile

#### **Account Activation Commands**

The modem supports modem account activation via the AT command interface.

**Command** Description

-NAMLCK NAM Lock—enter the subsidy lock or SPC required to write account data

-NAMVAL NAM Values—query or set the account data

#### Device and Service Interrogation Commands

**Command Description** 

I Product identification information

!ECIO Ec/lo

!GMODE Mode of the modem

!MDMVER Version of the modem firmware

PREV Protocol Revision
PRLVER PRL version

!RSSI Received Signal Strength Indication

!STATUS Modem status report

!SYSTIME CDMA time

+CAD? Analog or Digital Service (Read-only) (local only)

+CBIP? Base Station IP Address (Read-only)
+CMIP Mobile Station IP Address (Read-only)

+CSQ Signal Quality (Read-only) +CSS? Serving System (Read-only)

+GCAP Get Capabilities
+GMI Get Manufacturer
+GMM Get Model Number
+GMR Get Revision
+GOI Get ISO ID
+GSN Get ESN

+WGETWK Request Wake-up Reason

#### SMS Messages Commands

The modem supports sending and receiving SMS (Short Message Service) messages.

Command Description

!CNTSMS Count of SMS messages in the modem

!DASMS Delete All SMS messages

!DSMS Delete SMS message (selective) !GSMS Get SMS message from the modem

!SSMS Send SMS message, or query the send status

# Chapter 3 – ! Prefix Commands

Result codes are not shown in the following commands unless special conditions apply. Generally, the result code OK is returned when the command has been executed. ERROR may be returned if parameters are out of range and is returned if the command is not recognized or is not permitted in the current state or condition of the modem. A full list of result codes (verbose and numeric) is provided in the Result Code Table later in this manual.

# !APPSUBTYPES Negotiated Subtypes

Syntax: AT!APPSUBTYPES

**Description:** Application subtypes negotiated for the four streams.

**Example:** AT!APPSUBTYPES

Stream0: Default Signaling Application Stream1: Default Packet Application for SN Stream2: Default Packet Application for AN

Stream3: Default Test Application

OK

#### !CNTSMS Count SMS

Syntax: AT!CNTSMS

**Description:** Reports the number of messages stored in the modem as follows:

New Urgent Msg {Index = 1}: <n>
New Regular Msg {Index = 2}: <r>
Old Messages {Index = 3}: <o>
Voice Messages {Index = 4}: <v>

The Index number corresponds to the SMS list index used to retrieve and delete messages. The counters n, r, o, and v indicate the number of messages in each list. When retrieving (!GSMS) or deleting (!DSMS), the message number is base 1, so the

highest message number in any list is the same as the reported count.

# **!DASMS Delete All SMS**

Syntax: AT!DASMS

Description: Deletes all SMS messages from all four SMS lists. Use this command with care, as

confirmation is not required.

### **!DSMS= Delete SMS (Selective)**

**Syntax:** !DSMS=<i>[,m]

Description: Deletes one or all messages from one of the index lists (for the definitions of the SMS

index lists, see !CNTSMS). **Parm Meaning** 

i Message list (index 1, 2, 3, or 4)

m Message number

Message number 1 is the oldest message, and the number reported by !CNTSMS, is the

most recent message.

If the message number parameter is omitted, then all messages in the specified index list

are deleted.

Normally messages are only deleted from list 3 (old).

#### !ECIO? Ec/Io

Syntax: AT!ECIO?

Description: If there is an active pilot, returns the current Ec/lo in units of 1dB. See also !RSSI.

### !GMODE Mode of the Modem

Syntax: AT!GMODE

Description: Asks for the mode of the modem. Returns either "ONLINE" or "OFFLINE"

#### **!GSMS?** Get SMS

**Syntax:** AT!GSMS?<i,m>

Description: Read an SMS message from the modem. The message read is determined by the

parameters:

Parm Meaning

i message list (index 1, 2, or 3)

m message number

Message number 1 is the oldest message, and the number reported by !CNTSMS, is the most recent message.

After a new message is read, it is placed in message list index 3 (old messages).

The following information may be displayed:

- Message center timestamp (optional)
- Originating address
- Priority (optional)
- User data

# !MDMVER? Version of the Modem Firmware

Syntax: AT!MDMVER?

**Description:** Returns the firmware version being run on the modem.

See also +GMR (Get Revision).

### !MUFWDRESET Reset Data in !MUFWDSTATS

AT!MUFWDRESET Syntax:

**Description:** Resets all the data reported by !MUFWDSTATS.

# **!MUFWDSTATS** Current Traffic Channel Statistics

AT!MUFWDSTATS Syntax:

**Description:** Current Multi-User Forward Traffic Channel Statistics.

!MUFWDRESET resets the data reported by this command.

**Example:** 

at!mufwdstats

FORWARD TRAFFIC CHANNEL

CRC Count			Te	rmii	natio	on Slo	ot Coun
Good (	CRCs-	Bad CRCs	1	2	3	4	
DRC3_128	0	-	0	0	0	0	
DRC3_256	0	-	0	0	0	0	
DRC3_512	0	-	0	0	0	0	
DRC3_1024	0	0	0	0	0	0	
DRC5_2048	0	0	0	0	0	0	
DRC8_3072	0	0	0	0			
DRC10_4096	6 <b>0</b>	0	0	0			
DRC13_5120	0 (	0	0	0			
Packet Error	Rate (	%)· 0 000					

Packet Error Rate (%): 0.000

OK

# !PERSONALITY? Displays Current Personality

AT!PERSONALITY? Syntax:

**Description:** Displays the Current Personality and its negotiated protocol subtypes.

**Example:** at!personality?

Current Personality: 0

Physical Layer Protocol Subtype: 0 Control Channel MAC Protocol Subtype: 0 Access Channel MAC Protocol Subtype: 0 Fwd Traffic Channel MAC Protocol Subtype: 0 Rev Traffic Channel MAC Protocol Subtype: 0

Key Exchange Protocol Subtype: 0 Authentication Protocol Subtype: 0 Encryption Protocol Subtype: 0 Security Protocol Subtype: 0 Idle State Protocol Subtype: 0

Generic MM Cap Disc Protocol Subtype: 0 Generic Virtual Stream Protocol Subtype: 0

### !PREV? Protocol Revision

Syntax: AT!PREV?

**Description:** Queries the modem for the current protocol revision reported by the current base station

the modem is communicating with. The response is a decimal digit as noted below.

Value Meaning
1 JSTD-008 (PCS)
2 IS-95
3 IS-95A (cellular)
4 Minimum requirements for IS-95B
5 Full requirements for IS-95B
6 CDMA 1X Rev. 0
7 CDMA 1X Rev. 1

### !PRLVER? PRL Version

**Syntax:** AT!PRLVER?

**Description:** Returns the version of the PRL stored in the modem.

# !PROTSUBTYPES? Negotiated Subtypes

**Syntax:** AT!PROTSUBTYPES?

**Description:** Displays Negotiated Subtypes for all protocols in all stored personalities.

**Example:** at!protsubtypes

Number of Stored Personalities: 1

Current Personality: 0

Personality: 0

Physical Layer Protocol Subtype: 0

Control Channel MAC Protocol Subtype: 0 Access Channel MAC Protocol Subtype: 0 Fwd Traffic Channel MAC Protocol Subtype: 0 Rev Traffic Channel MAC Protocol Subtype: 0

Key Exchange Protocol Subtype: 0 Authentication Protocol Subtype: 0 Encryption Protocol Subtype: 0 Security Protocol Subtype: 0 Idle State Protocol Subtype: 0

Generic MM Cap Disc Protocol Subtype: 0 Generic Virtual Stream Protocol Subtype: 0

# !RSSI? Received Signal Strength Indication

Syntax: AT!RSSI?

Description: Reports the current RSSI (P(AGC)+Ec/Io) in dBm using a (N-1)/N IIR filter for smoother

display. When no signal is present it reports -125. Reported values can be interpreted as

follows:

< -90 = very poor -90 to -86 = poor -85 to -81 = fair -80 to -76 = good > -76 = excellent

This command is supported in the online command state and in the command state.

# !SCPCUSTCONFIG? Current Session Configuration Protocol Customer Configuration

**Syntax:** AT!SCPCUSTCONFIG?

**Description:** Sets or reads the current Session Configuration Protocol Customer configuration.

Example:

at!scpcustconfig?

1 - Custom Configuration is Active

#### **Protocol Subtypes:**

1 - Subtype 2 Physical Layer

0 - Enhanced CCMAC

1 - Enhanced ACMAC

1 - Enhanced FTCMAC

0 - Enhanced 3 RTCMAC

0 - Enhanced 1 RTCMAC

0 - Enhanced Idle

#### Broadcast Subtypes:

0 - Generic Broadcast Enabled

#### **Applications Subtypes:**

1 - SN Multiflow Packet App

OK

#### To set this item, enter 13 hex bytes. Example:

at!scpcustconfig=01.0D.00.00.00.00.00.00.00.01.00.00.00

#### **!SESSIONSTATUS Current Session Status**

Syntax: AT!SESSIONSTATUS=<lower\_byte>,<upper\_byte>

Description: !SESSIONSTATUS (Sets the current Session Status)

ISESSIONSTATUS? (Reads the current Session Status)

!SESSIONSTATUS? (Reads the current Session Status)

### Value Meaning

- 0 Inactive—there is no session
- 1 Default—there is a session, but no negotiation has been completed
- Active—there is a session, and all parameters have had at least one chance to be negotiated

In testing and debugging procedures, it is useful to force the session status to Inactive, so that Session negotiation and configuration occur upon the next power up. For the change to occur, the modem must be reset.

When the HDR session is negotiated, the session status is stored in NV RAM. Upon next power up, if the session status is Active, the session parameters are not renegotiated, unless a new network is acquired.

#### **Example:**

at!sessionstatus

HDR Session Status: 2

OK

at!sessionstatus=00,00

OK

at!sessionstatus? HDR Session Status: 0

OK

# **!SIPID= User ID Information for Simple IP Setup**

Syntax: AT!SIPID=<user id>

**Description:** Sets the User ID information for a simple IP setup.

# !SIPPWD= Password Information for Simple IP Setup

**Syntax:** AT!SIPPWD=<passwrd>

**Description:** Sets the password information for a simple IP setup.

### **!SLEEPPARMS Sleep Parameters**

Syntax: AT!SLEEPPARMS

Description: Returns 1xEV-DO Rev. A sleep parameters (slot cycle indexes and sleep periods). Slot

cycle timeouts are listed in Julian time format (year month day day-of-week

hour:minutes:seconds).

Example 1:

at!sleepparms Slot Cycle1:3 Slot Cycle2:0 Slot Cycle3:0

Slot Cycle1 Timeout:1980 01 06 6 00:00:00 Slot Cycle2 Timeout:1980 01 06 6 00:00:00

OK

Example 2:

at!sleepparms

HDR Rev. A not currently available

OK

### !SSMS= Send SMS

**Syntax:** AT!SSMS=,<dest>,[cb],"<text>"

AT!SSMS? Reports the progress of the last message sent

**Description:** !SSMS= sends an SMS message using these parameters:

Parm	Meaning	Range
р	priority	0 = normal
		1 = interactive
		2 = urgent
		3 = emergency
		(Actual priority transmitted depends on the carrier.)
dest	destination #	Phone number of destination, maximum of 32 characters; only 0–9, #, and * permitted.
cb	callback #	(this is optional) Phone number for reply, same 32 character limit
text	message body	Up to 227 bytes of data (not including the compulsory quote marks).

The text is enclosed in quotations. The quote character cannot appear in the body text. Body text over the carrier-defined limit is truncated and sent anyway. Messages of length 228 or greater result in an ERROR.

The query form (!SSMS?) reports the progress of the last message sent.

Possible responses are:

none No SMS messages being sent.

pending Message has not left the modem (an attempt to use !SSMS= again yields

an ERROR result code.)

sent Successfully sent to the network. failed Sending failed and should be retried.

If you send a second message after receiving the "sent" response for the first message, subsequent queries will report the status of the second message.

### **!STATUS Status of the Modem**

Syntax: AT!STATUS

**Description:** Reports the modem's status as follows:

Current band: <band>
Current channel: <chan>

SID: <sid> NID: <nid> 1xRoam: <n>

HDRRoam: <n>

Temp: <temp> State: <state> Sys Mode:<mode>

Pilot [NOT] acquired

Modem has [NOT] registered HDR revision: <HRD\_rev>

PCS, or HDR Cellular

<n> for the roaming indicator. Values larger than 2 indicate ERI usage; to obtain the ERI

banner, icon state, and icon image, parse the carrier's ERI file.

<temp> is the radio temperature in degrees C.

<mode> is either NO SRV, CDMA or HDR

**NOT** appears if the pilot has not been found or the modem has not registered.

<HRD\_rev> is displayed only if the modem has 1xEV-DO service.
The value is either 0 or A. See also +CSS? (Serving System).

# !SUFWDCCSTATS Current Single User Forward Channel Statistics on DRCs

Syntax: AT!SUFWDCCSTATS

Description: Reports the current Single User Forward Channel Statistics (Single User packet early slot

termination count for all supported DRCs on Forward Control Channel; (columns are tab

separated).

!SUFWDRESET resets the data reported by this command.

**Example:** 

at!sufwdccstats

FORWARD CONTROL CHANNEL - Early Termination

Slot Count

123456789101112

13 14 15 16

DRC0000000000000

0000

DRC10000000

# **!SUFWDCRCS** Current Single User Forward Channel Statistics on CRCs

Syntax: AT!SUFWDCRCS

Description: Reports the current Single User Forward Channel Statistics (Single User packet CRCs and

Packet Error Rate).

!SUFWDRESET resets the data reported by this command.

Example:

at!sufwdcrcs

FORWARD	TRAFFIC	CHANNEL	
		Good CRCs	<b>Bad CRCs</b>
DRC0		0	0
DRC1		0	0
DRC2		0	0
DRC3		0	0
DRC4		0	0
DRC5		0	0
DRC6		0	0
DRC7		0	0
DRC8		0	0
DRC9		0	0
DRC10		0	0
DRC11		0	0
DRC12		0	0
DRC13		0	0
DRC14		0	0
FORWARD	CONTROL	CHANNEL	
		Good CRCs	Bad CRCs
DRC0		0	0
DRC1		0	0
Packet Error OK	Rate (%): 0.0	000	

#### **!SUFWDRESET Resets Data**

Syntax: AT!SUFWDRESET

**Description:** Resets the data reported by !SUFWDCCSTATS, !SUFWDCRCS, and !SUFWDTCSTATS.

# !SUFWDTCSTATS Current Single User Forward Channel Statistics

Syntax: AT!SUFWDTCSTATS

Description: Current Single User Forward Channel Statistics (Single User packet early slot termination

count for all supported DRCs on Forward Traffic Channel). !SUFWDRESET resets the data reported by this command.

**Example:** 

at!sufwdtcstats

FORWARD TRAFFIC CHANNEL - Early Termination

Slot Count

1234567891011

12 13 14 15 16

DRC000000000000

00000

DRC100000000000

00000

DRC20000000

DRC10 0 0 DRC11 0

DRC12 0 DRC13 0 0

DRC13 0 C

OK

# **!SYSTIME? CDMA Time**

**Syntax:** AT!SYSTIME?

Description: Queries the CDMA time. If the modem has not acquired a system, then the system time

may not be available; some time in 1980 is displayed.

The format is:

YYYYMMDDWHHMMSS (W is day of week, 0=Monday)

For example:

200309183180142 = Thursday, Sep 18, 2003, 18:01:42

# Chapter 4 – \$ Prefix Commands

### **\$QCCAV** Answer Voice

Syntax: AT\$QCCAV

Description: (Voice builds only). Answers an incoming call as a voice call. Use -SPKMUT (Speaker

Mute) to manually turn off mute on the audio path before answering the call.

Contrast with A (Answer).

See also +CDV (Dial Voice) and +CHV (Hang-up Voice).

### **\$QCMIP** Mobile IP (MIP) Behavior

Syntax: AT\$QCMIP

**Description:** Sets the Mobile IP (MIP) behavior.

Value Meaning

0 Mobile IP disabled. Simple IP only.

Mobile IP preferred.

- In the initial MIP registration, if the network does not support Mobile IP, then the mobile automatically reverts to Simple IP. However, if a Mobile IP session is registered and then the mobile enters a network that does not support Mobile IP, the mobile will drop the session and inform the upper layers of the failure.
- 2 Mobile IP only.

The mobile will make data calls only when Mobile IP is supported in the network. During a MIP session, if the mobile hands off to a network that does not support MIP, then the mobile will drop the session and inform the upper layers of the failure.

If a connected data device wants to use its own Mobile IP implementation, the mobile's IP implementation should be disabled by setting AT\$QCMIP to 0.

# \$QCMIPEP Enables/Disables the Currently Active Mobile IP User Profile

Syntax: AT\$QCMIPEP

**Description:** Enables/Disables the currently active Mobile IP user profile.

Value Meaning

To disable the currently active profile, use AT\$QCMIPEP = 0.

To enable the currently active profile, use AT\$QCMIPEP = 1.

See also \$QCMIPP.

# **\$QCMIPGETP** Query a User Profile

Syntax: AT\$QCDMIPGETP

**Description:** \$QCDMIPGETP = 1-5 (profile number). The command returns the following parameters for the selected profile:

- NAI
- Home Addr
- Primary HA
- Secondary HA
- MN-AAA SPI
- MN-HA SPI
- Rev Tun (Reverse Tunneling)
- MN-AAA SS
- MN-HA SS

If a profile number is not entered, then the AT command returns all the information corresponding to the currently active profile.

# **\$QCMIPNAI** Set the Network Access ID (NAI) for the Currently Active Profile

Syntax: AT\$QCMIPNAI

**Description:** Sets the Network Access ID (NAI) for the Currently Active Profile:

AT\$QCMIPNAI= "user@domain", 0 or 1

Value Meaning

0 Do not store in NOVRAM

1 Store in NOVRAM

The double quotes ("") are required only if the string contains a comma.

# **SQCMIPP** Select One of the Mobile IP User Profiles to Be the Current Active Profile

Syntax: AT\$QCMIPP

**Description:** AT\$QCMIPP can be used to configure specific dial-up for various user profiles.

AT\$QCMIPP = 1-5 (profile number)

To enable/disable a currently active profile, see \$QCMIPEP.

# **\$QCVAD=** Sets or Reads the Mode for Answering Data Calls

**Syntax:** AT\$QCVAD=<n> (Set Command)

AT\$QCVAD? (Read Command)

Description: \$QCVAD= sets the mode for answering data calls with A (Answer) or auto answer via

S0=1.

\$QCVAD? reads the mode for answering data calls with A (Answer) or auto answer via S0=1.

Value	Setting
0	OFF (answer as voice). Default.
1	Fax (Fax not supported) for next call, then revert to OFF (voice)*
2	Fax (Fax not supported )for all calls
3	Async data for next call, then revert to OFF (voice)*
4	Async data for all calls

<sup>\*</sup>Reverting to voice happens at the first of these events:

- An incoming call arrives (answered or not)
- Ten minutes elapse without receiving a call
- The modem is reset (or power-cycled)
- The setting is changed by command

The CDMA network requires the call type to be negotiated before the call is answered. This command sets the call negotiation the modem makes prior to answering.

# Chapter 5 – & Prefix Commands

#### &C Data Carrier Detect Control

Syntax: AT&C<value>

**Description:** The modem controls the RLSD output in accordance with the parameter supplied. This

command sets the DCD On or Off.

Value Setting

**0** Sets DCD to remain On at all times.

Sets DCD to follow the physical connection. Default
 DCD follows the state of the TCP/UDP connection.

Response: OK

Otherwise ERROR

# &D Data Terminal Ready Options

**Syntax:** AT&D[n]>

Description: Determines what actions the modern takes in response to the Data Terminal Ready (DTR)

signal from the host (DTE). For action to be taken, DTR must be off for a period of 2–10

milliseconds.

Note: This command has no impact on the use of DTR to terminate a voice call on the

modem, nor does it affect the use of DTR to control modem shutdown.

Value Setting
0 Ignore DTR

1 Enter command state for an on-to-off DTR transition.

The modem condition (on or offline) is not affected.

(Currently not supported.)

2 Hang up and enter command state for an on-to-off DTR transition. Auto-

answer is disabled if DTR is off. Default.

### **&F Factory Settings Restore**

Syntax: AT&F

Description: Reloads the factory-stored default configurations into active memory. For information on

factory settings, see the Stored Profile Settings Table later in this manual.

This command is functionally the same as Z (Reset). If there is an active call, the

command executes and the call is dropped.

#### **&V View Configuration**

**Syntax:** AT&V[n]

**Description:** Displays the active profile (commands and S-register contents).

Any numeric parameter is ignored.

# Chapter 6 – +C Prefix Commands

# +CAD? Analog or Digital Service

**Syntax:** AT+CAD? (Read-only) (local only)

**Description:** Reports the current service mode of the modem in the form +CAD: n.

Value	Meaning
0	No service available
1	CDMA Digital service is available
2	TDMA Digital service is available
3	Analog service is available

## +CBIP? Base Station IP Address (Read-only)

Syntax: AT+CBIP? (Read-only) (local only)

**Description:** Reports the IP address (in dotted-decimal format) of the Base Station if there is a currently

active call. If there is no active call, the following response is returned:

0.0.0.0 OK

See also +CMIP (Mobile IP Address).

#### **+CDV** Dial Voice

**Syntax:** AT+CDV [options]

**Description:** Initiates a voice call. Because of the options available in this command, another AT

command cannot follow it on the same line. All characters following the +CDV command are taken as parameter options. For a list of dialing option parameters and restrictions, see the D (Dial) command. The options available are the same as those described for async

data dialing.

Voice dialing leaves the modem in command state. This allows use of commands to control microphone and speaker options, and to generate DTMF tones if needed.

See also +CHV (Hang-up Voice).

Note: This command is needed for Verizon

#### +CFG= Configuration String

**Syntax:** AT+CFG="<str>" (Sets a configuration)

AT+CFG? (Reads a configuration)

**Description:** This command sets a configuration string of up to 248 characters. The string parameter

must be enclosed within quotation marks (0x22). You cannot append any other commands

after it in the same command line.

This string is transmitted to the Base Station as the last step of establishing the transport layer of the airlink. The default setting is null. Any setting replaces the previous value.

#### +CHV Hang-up Voice

Syntax: AT+CHV [0]

Description: Terminates a voice connection previously established with +CDV (Dial Voice) or \$QCCAV

(Answer Voice). The only valid parameter is zero, which is optional.

See also H (Hook Control).

#### +CMIP? Mobile Station IP Address

**Syntax:** AT+CMIP? (Read only)

Description: Returns the IP address assigned to the modem for this connection. This address is

temporary only. The network assigns an IP address on an as-needed basis.

If there is no current network connection, hence no local IP address, the modem issues no

response, only the OK result code.

See also +CBIP (Base Station IP Address).

# +CMUX= Multiplex Option

**Syntax:** AT+CMUX=<f[,r]> (Sets the Multiplex Option)

AT+CMUX? (Reads the Multiplex Option)

Description: Selects the maximum number of multiplex options for the forward and reverse links valid

within the context of the data service selected by the +CRM (Local Interface Protocol) command. The first parameter is for the forward link (from the Base Station to the modem)

and the second is for the reverse link (from the modem to the Base Station).

Parm	Value	Meaning
f	1 - F	Hexadecimal value for Multiplex Option for the forward link.
r	1 - 2	Multiplex Option for the reverse link.

If parameter **r** is omitted, it is assumed to have the same value as **f**, provided **f** is 1 or 2; otherwise, the ERROR result is returned.

Values for the two parameters must be either both odd or both even. If odd values are used, the modem originates data calls using Rate Set 1. If both are even, originated calls use Rate Set 2.

Note: This command is included for compatibility.

#### **+CQD= Command State Inactivity Timer**

**Syntax:** AT+CQD=<n> (Sets the Command State Inactivity Timer)

AT+ CQD? (Reads the Command State Inactivity Timer)

Description: This timer determines when (or if) the modem will release a call if there is no activity on the

connection between the modem and the IWF, for the specified period. The entry represents a multiple of five seconds. That is, each unit represents 5 seconds.

Value Meaning

0 Disables the timer

1–255 Indicates timer value in steps of five seconds.

The default value is 10 – meaning a timer setting of 50 seconds.

See also +CTA (Packet mode Inactivity Timer).

Note: This command is included for compatibility.

#### **+CRC= Cellular Result Codes**

**Syntax:** AT+CRC=<n> (Enables or disables cellular result codes)

AT+CRC? (Reads the cellular result code value)

**Description:** Enables or disables cellular result codes for call progress.

Value Meaning

0 Disables cellular result codes. Default.

1 Enables cellular result codes

The extended cellular result codes are in Extended Cellular Result Codes Table.

Extended cellular call progress codes are in the Extended Cellular Call Progress Codes

Table later in this manual.

## +CRM= Local (Rm) Interface Protocol

**Syntax:** AT+CRM=<n> (Sets the Local Interface Protocol)

AT+CRM? (Reports the protocol for local (DCE - DTE) interface.

Description: Reports (or sets) the protocol for the local (DCE - DTE) interface. This value is set

automatically by the modem, based on the data received.

Value Meaning
0 Asynchronous Data or Fax

Packet data service, Relay Layer interface
 Packet data service, Network Model (Default)

### **+CSQ?** Signal Quality

**Syntax:** AT+CSQ? (Read-only)

Description: Reports the received Signal Quality Measure (SQM) and Frame Error Rate (FER). The

response is in the form +CSQ: <SQM>, <FER>. If no cellular service is available, the values reported are both 99. If the modem has acquired service but is not in an active call,

the SQM value is valid but the FER is still undetectable.

SQM	Meaning
0-31	00 is lowest quality signal, 31 is the highest. This is based on received signal strength.
99	Value not known or is not detectable.
FER	Meaning
0	<0.01%
1	0.01% >= FER < 0.1%
2	0.1% >= FER < 0.5%
3	0.5% >= FER < 1.0%
4	1.0% >= FER < 2.0%
5	2.0% >= FER < 4.0%
6	4.0% >= FER < 8.0%
7	FER >= 8.0%
99	Value is not known or is not detectable.

See also !RSSI for received signal strength in dBm.

# **+CSS?** Serving System

**Syntax:** AT+CSS? (Read-only)

**Description:** Reports the cellular band and system on which the modem is registered. The response is in the form +CSS: <class>, <band>, <system>.

<class></class>	Meaning
0	Current band class is unsupported by this command.
1	800 MHz Cellular
3	1900 MHz PCS
<band></band>	Meaning
A - F	Registered on a band system indicated.
Z	Not registered system Meaning
0-32767	System ID of the network that the modem is currently registered with.
99999	Modem is not registered.

See also !STATUS (Status).

#### +CTA= Packet Data Inactivity Timer

**Syntax:** AT+CTA=<n> (Sets the Packet Data Inactivity Timer)

AT+CTA? (Reads the value)

Description: This timer determines when (or if) the modem will use dormant mode on the network. If a

timer value is set, the modem releases the radio resource if there is no activity (RLP data frames) on the connection between the modem and the network for the specified period.

The modem maintains the PPP session with the local host, and the network retains the PPP session at its end, only the intervening "physical link" layer is dropped. The modem restores the link when traffic resumes.

Each unit represents 1 second.

Value Meaning

0 Disables the timer (default)
1–255 Indicates timer value in seconds.

Note: When set to 0, the network governs the dormant mode timing.

See also +CQD (Command State Inactivity Timer).

#### +CXT= Cellular Extension

**Syntax:** AT+CXT=<n> (Enables/disables the passing of unrecognized AT commands)

AT+ CXT? (Reads the value)

**Description:** Enables and disables the passing of unrecognized AT commands to the IWF. If disabled,

the modem replies with ERROR to unrecognized commands. If enabled, the modem

opens the transport layer airlink and enters pass through state.

Use H0 (on-hook) to close the airlink.

Value Meaning
0 Do not pass unrecognized commands. (Default)
1–255 Open a transport layer connection and pass the unrecognized command to the IWF.

# Chapter 7 – +F Prefix Command

# **+FCLASS=** Modem Operating State

**Syntax:** AT+FCLASS=[n]

**Description:** Sets the modem's data state.

Value Setting
0 Data. Default
Note: Fax is not supported.

# Chapter 8 – +G Prefix Commands

#### **+GCAP** Get Capabilities

Syntax: AT+GCAP

**Description:** Reports the modem's additional capabilities in one or more lines of text containing AT+

commands. This is used to determine if services the user needs can be performed by the

modem. The services and commands reported can be any or all of:

Response +FCLASS Fax support (Fax not supported)
+MS Modulation control (+MS, +MR)

+MV18S V.18 modulation control (+MV18S, +MV18R) +ES Error control (+ES, +EB, +ER, +EFCS, +ETBM) +CIS707-A (High Speed Packet Data Services) IS-856 (High Rate Packet Data Air Interface)

+DS Data compression (+DS, +DR)
See also +CGCAP (Get IWF Capabilities).

#### +GMR Get Revision

Syntax: AT+GMR

**Description:** Reports the modem firmware version: revision level (see the following paragraphs) and

date, followed by the version for the Preferred Roaming List (PRL) in use. It also reports

the hardware revision.

Example of interpreting the firmware revision level: p2006001:

P: Production release

The next two digits indicate the product ID:

Value Product 28 MC5728V

The next three digits indicate the firmware build version: for example, 060 corresponds to firmware build version 0.60.

The next two digits (in some cases, four) indicate the point release within the above build version. In our example, 06001 means point release .01 in firmware build 0.60.

The command also returns version information on some or all of the following:

Description

QCOM Boot images

BOOT SWI Boot Loader: Product/product family description (for example, SWI6800

or SWI6800V2), followed by:

• "FP" (Full Production), "FD" (Full Development), or "PP" (Point Production)

Major revision number (2 digits)

Minor revision number (2 digits)

Point release number (optional)

Note: Depending on the modem model, the above information may not

apply.

APPL Application code

SWOC Software on Card image: "CDPC", followed by the 5-digit decimal CDPC

(CD Product Code), followed by the CD version:

Major revision number (2 digits)

Minor revision number (2 digits)

Point release number (2 digits)

USBD USB descriptor table USB VID USB Vendor ID

#### **Examples with Interpretation of Each Line of the Modem's Response:**

AT+GMR

p2110100,5077 [Aug 07 2007 14:29:37]

**Production Release** (p). Firmware version 1.01. Point release 00.

QCOM: SWI6800V2 FD.00.32

Boot Image: SWI6800V2 family. Major revision 00. Minor

revision 32.

BOOT: SWI6800V2 FP.01.01 2007/08/09 10:37:43

SWI Boot Loader: SWI6800V2 family. Major revision 01. Minor revision 01. Build

date Aug 9, 2007.

APPL: SWI6800V2\_FP.01.01 2007/08/09 10:37:43

Application Code: SWI6800V2 family. Major revision 01. Minor revision 01. Build

date Aug 9, 2007.

USBD: SWI6800V2 GENERIC.00.00

USB Descriptor Table: SWI6800V2 family. Generic build. Major revision 00. Minor

revision 00.

SWOC: CDPC\_00004\_01.01.02

**Software on Card image**, CDPC (CD Product Code) = 00004. CD version: major

revision 01, minor revision 01, point release 02.

USB VID: 0x1199 PID: 0x0028

USB Vendor ID 0x1199; product: 28.

See also +CGMR (Get IWF Revision) and I (Product Identification Information).

#### **+GMI Get Manufacturer**

Syntax: AT+GMI

**Description:** Reports the modem's manufacturer.

See also +CGMI (Get IWF Manufacturer).

#### **+GMM** Get Model Number

Syntax: AT+GMM

**Description:** Reports the modem model.

See also +CGMM (Get IWF Model).

#### +GOI Get ISO ID

Syntax: AT+GOI

Description: Reports the modem's ISO system registration code (if any). The code provides a method

of uniquely defining an object. The cellular modems have no ID string (null).

See also +CGOI (Get IWF ISO ID).

#### **+GSN** Get ESN

Syntax: AT+GSN

**Description:** Reports the modem's electronic serial number. The modem reports an eight character

ASCII string of hexdigits (no spaces).

See also +CGSN (Get IWF ESN).

# Chapter 9 – +I Prefix Commands

#### **+ICF= Character Framing**

**Syntax:** AT+ICF=<[f],[p]>

AT+ICF? (Queries the settings)

Description: Settings with this command are ignored. Normally, this command sets the local serial port

(DTE - DCE) connection character framing.

The modem uses a true serial interface, but the modem's support is limited to:

8-bit data 1 stop bit

no parity (the parity setting is ignored) **Note:** These are the default values.

Parm Value Meaning

f (format) 3 8 data bits, 1 stop bit (no other values are permitted)

p (parity) 0–3 value is ignored

See also +IPR (Fixed Port Rate).

# **+ILRR Local Rate Reporting**

Syntax: AT+ILRR[=0]

AT+ILLR? (Queries the settings)

**Description:** Enables and disables the reporting of the local rate to the host (DTE).

Note: The modems do not support local rate reporting. This command is provided for

compatibility only and only accepts a setting of 0 (off).

#### **+IPR - Set Serial Speed**

**Description:** Sets the serial speed.

Syntax: AT+IPR=<serial speed value>

Values: 300 to 921600

**Display**: AT+IPR? Displays the current serial speed.

AT+IPR=? Displays a list of all possible values (serial speeds).

**Default:** 115200

# Chapter 10 – +M Prefix Commands

#### +MA= Modulation Auto Mode

Syntax: AT+MA=<str>

AT+MA? (Queries the settings)

**Description:** Sets the additional modulations that the Base Station may use to connect with the

destination modem in Auto Mode operation. This is used for originating and answering operations on data calls and is additional to the modulation setting using the +MS

(Modulation Selection) command.

The default setting is null.

For details on parameters and use, see IS-131.

### +MR= Modulation Reporting

Syntax: AT+MR=<n>

AT+MR? (Queries the settings)

Description: Enables or disables the extended intermediate result codes for +MCR:<carrier> and

+MRR:<rate>[,rx\_rate] from the IWF to the modem. For details on the intermediate result

codes possible, see IS-131.

To guery the IWF for confirmation that the command is supported, use +GCAP (Get

Capabilities). The +MS result must be in that response.

If reporting is enabled, the intermediate result is sent when modulation has been

determined and before error control or data compression are negotiated. This is before the

final result code (e.g. CONNECT) is sent.

Value Meaning

0 Disables reporting of modulation connection. Default.

1 Enables reporting.

#### +MS= Modulation Selection

**Syntax:** AT+MS=<parms>

AT+MS? (Queries the settings)

Description: Controls the manner and operation of the modulation capabilities in the IWF. To query the

IWF for confirmation that the command is supported, use +GCAP (Get Capabilities). The

+MS result must be in that response.

The default setting is null.

For details on parameters and use, see IS-131.

#### +MV18R= V.18 Reporting

Syntax: AT+MV18R=<n>

AT+MV18R? (Queries the settings)

**Description:** Enables or disables the extended result codes for +MV18R: from the IWF to the modem.

To query the IWF for confirmation that the command is supported, use +GCAP (Get

Capabilities). The +MV18S result must be in that response.

Value	Meaning
0	Disables reporting of V.18 result codes. Default.
1	Enables reporting.

The possible intermediate result codes are:

+MV18: 5BIT	Indicates connection with 5-bit (Baudot) mode
+MV18: EDT	Indicates connection with EDT
+MV18: DTMF	Indicates connection with DTMF
+MV18: V21	Indicates connection with V.21
+MV18: V23	Indicates connection with V.23
+MV18: B103	Indicates connection with Bell 103-type modulation
+MV18: V18	Indicates connection with V.18

#### +MV18S= V.18 Selection

**Syntax:** AT+MV18S=[m],[ans],[fb]

AT+MV18S? (Queries the settings)

Description: Controls the manner and operation of the V.18 capabilities in the IWF (if present in the

IWF).

To query the IWF for confirmation that the command is supported, use +GCAP (Get Capabilities). The +MV18S result must be in that response.

Parm	Value	Meaning
m	0	Disable V.18 operation. Default.
	1	V.18 operation, auto detect mode
	2	V.18, connect in 5-bit (Baudot) mode
	3	V.18, connect in DTMF mode
	4	V.18, connect in EDT mode
	5	V.18, connect in V.21 mode
	6	V.18, connect in V.23 mode
	7	V.18, connect in Bell 103-type mode
S	0	Disable V.18 answer operation. Default.
	1	No default specified (auto-detect)
	2	V.18 operation, connect in 5-bit (Baudot) mode
	3	V.18, connect in DTMF mode
	4	V.18, connect in EDT mode
fb	0	Disable fallback. Default.
	1	Enable fallback to re-acquisition after 2 seconds of no transmission.

The default setting is +MV18S=0,0,0 – meaning V.18 operation is disabled.

# Chapter 11 – +W Prefix Commands

### **+WGETWK** Request Wake-Up Reason

Syntax: AT+ WGETWK

Description: Responds with the reason of the last wake-up event. The response is a decimal digit

representing the bit-mask below.

If no events have triggered, the response is a zero.

Value	Meaning If Set to This Value
0	No event
1	Ring received
2	Radio coverage restored
2	SMS message received

#### +WWKUP= Wake-Up Events Mask

Syntax: AT+WWKUP=<n>

AT+WWKUP? (Reports the settings)

Description: Sets or reports the bit-mask used to identify events that generate a wake-up from the

modem to the host device. A setting of zero disables all wake-up signals. The default

setting is 5; wake on ring and SMS received.

When this command is issued, the last wake-up event reason (see +WGETWK on page

76) is reset to 0.

Bit Meaning when set 0 Wake-up on ring received (Default is set)

1 Wake-up on radio coverage restored (Default is clear)

2 Wake on SMS received (Default is set)

3-7 Reserved

# Chapter 12 – No Prefix Commands

#### +++ Escape

Syntax: +++

Description: The +++ Escape Sequence is not preceded by AT. Applies only to asynchronous calls.

Used to exit data state and enter command state; this is not preceded by AT and does not

require <CR>.

The escape character is fixed as the plus sign "+" (0x2B). The guard time between normal transmission data and the escape sequence is specified as 1 second and cannot be changed. Therefore, the modem requires a minimum of 1 second of inactivity on the serial

input, three plus sign characters, followed by 1 second of inactivity. If a PPP session is active, then use PPP to escape data state.

## A Answer (Manual)

Syntax: ATA

**Description:** Instructs the modem to immediately go off-hook and attempt to establish a connection

without waiting for a ring. This is used to answer an incoming call if auto answer (S0) is

disabled.

The command presumes a RING has been received. If the command is issued without a RING, behavior depends on the state. If the modem is in command state, it replies with OK and remains in command state. Should the modem be in pass through state without a call pending, the Answer command is sent to the IWF modem. This typically goes off-hook and looks for the carrier. When none is detected, the NO ANSWER or NO CARRIER result is returned. This is, however, dependent on the IWF modem.

The modem looks for the carrier to negotiate the connection and issues either:

- CONNECT and enters data state; or,
- NO CARRIER and remains in command state.

#### **D** Dial

Syntax: ATD

**Description:** Initiates a data call. To dial a voice call, use +CDV.

Because of the options available in this command, another AT command cannot follow it on the same line. All characters following the D command are taken as parameter options. Several types of data calls are possible, based on the option(s) entered.

#### **Packet Data Calls**

Traditional CDMA data call dialing uses the parameter "#777". This triggers the modem to try a connection using the detected service type: 1X or QNC (IS-95). It is possible that 1X service may be detected in an area that offers 1x voice service, but only IS-95 data service. The use of passwords can differ between a QNC and 1X call on some networks as well. In these situations the call is likely to fail.

You should force the modem to attempt one service type or the other by using dedicated dial strings dictated by the carrier. Typically (but not in all cases) the strings are:

- #762 "QNC" Connect to QNC using IS-95 service
- #19788 "1XRTT" Connect PPP using 1X service

Your connection software must manage use of the correct password for the type of service used.

#### Async (CSC) Data

The type of call opened depends on the setting of +FCLASS. The modem does not actually dial the number in the string. For an IS-95 call, the dial string is passed to the IWF where a modem there issues the dial over the PSTN. Prior to passing the dial command, the modem sends the IWF modem the string defined in +CFG (Configuration String) to configure the IWF modem for the call.

For dialing an async data call, the parameter string options are included on one command line with or without spaces. There is a limit of 35 characters in the dial options string. Upon successful answer and connection, the modem goes into data state. There is a time limit set in register S7

(Wait for Carrier) for the entire process.

The options listed below are commonly supported, but specific IWF modem capabilities govern the list of supported parameters.

Opt.	Meaning
0 - 9	Any digit (0-9) (*, #, A, B, C, or D are also permitted). The phone number may also include the formatting characters brackets ( and ), hyphen -, and <space>. These characters are ignored.</space>
T	Tone (DTMF) dialing - ignored by the modem.
Р	Pulse dialing - ignored by the modem.
W	Wait for dial tone before processing the remaining characters in the dial string. The duration of the wait is limited by register S7 (Wait for Carrier).
,	Pause before processing the remaining characters in the dial string. The pause time is set by register S8 (Comma Pause Time).
\$	Wait for billing (bong) tone before processing balance of string.
@	Wait for quiet answer; limited by register S7 (Wait for Carrier).
!	Hook flash. Causes the modem to go on-hook briefly and then returns to off-hook. This is used to access certain calling features on the PSTN.

#### **Result Codes:**

The possible result codes are determined by the call monitoring set by X[n] (Result Code Select). See the table of possible result codes later in this manual.

#### Echo E

Syntax: ATE[n]

Description: Controls echoing of characters received from the host (DTE) back to the host when in

command state. This also affects framing of responses. For details, see "Framing".

Value Setting 0 Disable echo

1 Enable echo. Default.

#### **H** Hook Control

Syntax: ATH[0]

Description: Go ON-Hook to disconnect a data/fax call. (To end a voice call, use +CHV)

If the modern was already on-hook, no change is made. The only parameter allowed is 0 (zero), which is optional. The modem goes from online condition to offline condition.

See also +CHV (Hang-up Voice).

#### I Product Identification Information

Syntax: ATI

**Description:** Shows Product Identification Information.

Note: Depending on your modem model, the types of information may vary.

**Example:** 

ATI

Manufacturer: Multi-Tech Systems, Inc.

Model: C597 Rev 1.0 (2)

Revision: p2314500,4012 [Mar 06 2008 17:19:08]

For information and examples on interpreting the (firmware) Revision, QCOM and other

return values, see +GMR.

QCOM: SWI6800V2 FD.00.32

BOOT: SWI6800V2 FP.01.45 2008/03/07 16:36:13 APPL: SWI6800V2 FP.01.45 2008/03/07 16:36:13

USBD: SWI6800V2 GENERIC.00.01 SWOC: CDPC 00005 01.01.01 USB VID: 0x1199 PID: 0x0023

ESN: 0x60684203

+GCAP: +CIS707-A, CIS-856, CIS-856-A, +MS, +ES, +DS, +FCLASS

See +GCAP.

SKU: 0x2BAF

# L Loudness (Speaker Volume)

Syntax:

**Description:** This command is provided for compatibility reasons; the modem takes no action.

Parameters are ignored.

For control of voice mode speaker levels, see -SPKVOL.

#### **M** Mute (Speaker Control)

**Syntax:** ATM[n]

**Description:** This command is provided for compatibility reasons; the modem takes no action.

Parameters are ignored.

For control of voice mode microphone and speaker muting, see –MICMUT and -SPKMUT.

#### O Online (Remote)

Syntax: ATO

Description: Currently not supported.

Causes the modem to go from command state (online condition) to data state. The modem responds with the normal CONNECT response codes (if enabled) as if the connection were new.

This command is executed by the IWF modem. If the CDMA modem was in an offline condition and without an airlink, the NO CARRIER and OK result codes are returned. If the modem was offline and the airlink was established (pass through state) but without a call in place, the IWF modem attempts to process the command. The typical result is either NO ANSWER or NO CARRIER. This is, however, dependent on the IWF modem.

## P Pulse Dialing

Syntax: ATP

**Description:** This command is provided for compatibility reasons; the modem takes no action.

## **Q** Quiet (Result Code Display Option)

**Syntax:** ATQ[n]

Description: Controls the return or suppression of result codes to the host (DTE).

Value Setting

O Disables Quiet mode (enables return of result codes.) Default.

1 Enables Quiet mode (disables return of result codes).

**Result Codes:** 

OK n = 0

Otherwise the result code is suppressed (n=1).

#### S<n>= S-Register Set/Query

**Syntax:** ATS<n>=<x> (Sets S-Register)

ATS<n>? (Queries S-Register)

**Description:** Sets or queries the contents of the specified S-register (n) to the new value (x). Where

parameter values are omitted, zeros are assumed.

Var. Range

n Valid S-register number (for values, see the Table of S-Registers later in this

manual.

x as determined by the S-register (n).

**Result Codes:** 

OK S-register n set to x.

ERROR Invalid S-register value (n) or setting (x) outside of permitted range.

## T Tone (Set DTMF Dialing)

Syntax: ATT

**Description:** This command is provided for compatibility reasons; the modem takes no action. For

information on DTMF tone generation on the modem. See -DTMFB, -DTMFK, -TONDUR,

and -TONMUT.

### V Verbose (Result Code Form)

**Syntax:** ATV[n]

**Description:** Specifies whether the modem displays the result codes in numeric format or as words

(verbose). For a numerical list of the Table of Result Codes later in this manual.

Note that numeric codes are returned as ASCII character numerals.

This command also affects framing of responses. For details, see "Response framing".

Value Setting

Numeric result codes

Verbose result codes. Default.

**Result Codes:** 

OK (0) n = 0, 1 (returned in the new setting)

ERROR (4) otherwise

## X Result Code Select/Call Progress Control

Syntax: ATX<n>

**Description:** Enables tone detection options used in the dialing and handshaking process. As options

are chosen, the result codes are also affected. The prime function is to control the modem

call response capabilities when the D (Dial) command is issued.

#### **Dial Tone Detection**

When disabled, the modem waits for the period set in register S6 (Wait for Blind Dial) and blind dials. When enabled, the modem allows five seconds to receive at least 1 second of dial tone. If none is detected, then the result code is NO DIAL TONE.

#### **Busy Signal Detection**

When disabled, the modem waits for the period set in register S7 (Wait for Carrier). If no connection is made, then the result code is NO CARRIER. When enabled, the modem can return the result code BUSY if detected.

Values enable (✓or disable (×) tone detection and result codes as indicated in the chart below:

Value	No Dial Tone	<b>Busy Signal</b>
1	×	×
2	$\checkmark$	×
3	×	✓
4	✓	✓ Default

#### **Z** Profile Restore

Syntax: ATZ

Description: The modem goes on-hook (drops any active call) and then resets the command and

register parameters to the defaults.

For information on factory settings, see the Table of Stored Profile Settings later in this

manual.

# Chapter 13 - - Prefix Commands

#### -DTMFB= DTMF Burst

**Syntax:** AT-DTMFB=<key1> [<key2>,<key3>,...]

**Description:** Generates a string of DTMF tones under the timings defined by -TONDUR (Tone

Duration). This command can be overridden by -TONMUT (Tone Mute). The values of <key> can be any of 0–9, \*, and #, up to a total of 32 keys. Spaces, quotes, brackets,

dashes, and commas are not permitted in the string.

#### -DTMFK= DTMF Key

Syntax: AT-DTMFK=<key>

**Description:** Generates a single key DTMF tone for the duration set by -TONDUR (Tone Duration). This

command can be overridden by -TONMUT (Tone Mute). The values of "key" can be any of

0-9, \*, and #.

#### -ECHO= Echo Cancellation Level

**Syntax:** AT-ECHO=<n> (Sets Echo Cancellation Level)

AT-ECHO? (Queries Echo Cancellation Level)

Description: Sets and queries the environment for the echo cancellation profile. The modem has five

environments available.

The setting is stored in non-volatile memory.

Parm	Meaning
0	Factory default (headset) (same as 3) (Default)
1	No echo cancellation
2	Handset
3	Headset
4	Acoustic (AEC)
5	Speaker-phone

## -HDSET = Headset Detection Option

Syntax: AT-HDSET=<n> (Sets Headset Detection Option)

AT-HDSET? (Queries Headset Detection Option)

**Description:** Sets and queries the detection option for the voice headset. The setting is stored in non-

volatile memory.

Parm Meaning

 Do not use headset detection. Always report "not inserted" via CnS message.

 Do not use headset detection. Always report "inserted" via CnS message. Default.
 Use headset detection. Report current headset detected state via CnS message.

There is no AT command to report whether a headset is detected when setting 2 is used. Headset detection is only reported via CnS messages.

## -MICMUT = Microphone Mute

**Syntax:** AT-MICMUT=<n> (Sets Microphone Mute)

AT-MICMUT? (Queries Headset Detection Option)

**Description:** Sets and queries the state of the microphone mute. This value is not stored in non-volatile

memory. The setting is considered temporary, and reverts to the default (OFF) at the beginning of a new call, and when the modem is power-cycled, reset, or when the profile is

restored (&F and Z).

Parm Meaning

0 Microphone mute is OFF. Default.

1 Mute is ON

## -NAMLCK= NAM Lock

**Syntax:** AT-NAMLCK=<n>

Description: Stores a pass code number for comparison to the modem's 6-digit OTSL (One Time

Subsidy Lock), MSL (Master Subsidy Lock), or SPC (Service Provisioning Code). The

service provider provides this number to you at the time of service activation.

If the number is an acceptable format, the OK result code is returned. If the parameter's

format is rejected (such as too many digits), the ERROR result is returned.

The actual comparison of the pass code entered with this command and the lock codes encoded in the modem does not take place until an attempt is made to write a NAM profile

account using -NAMVAL.

#### -NAMVAL= NAM Values

**Syntax:** AT-NAMVAL=<nam> [,<MDN>,<MIN>,<SID>,<NID>] (Set command)

AT-NAMVAL?<nam> (Reads the current account information)

**Description:** This command has three functions related to the account or NAM (Number Assignment

Module):

#### **Set the Active Account Index**

The modem supports one account. Using only the <nam> parameter (0) sets that account as the active account used by the modem.

#### **Read the Current Account Information**

The guery form of the command will report the details of the specified account (0):

MDN: 999999999 (10 digit phone number)

MIN: 999999999 10-digit MIN (encoded and stored into MIN1 and MIN2)

SID: 99999 (System ID) NID: 99999 (Network ID)

#### **Write Account Activation Data**

This form requires the optional parameters. The modem will first compare the pass code stored using –NAMLCK (page 84). If the pass code fails to match, the ERROR result is returned. If the OK result is received, the NAM profile account was successfully activated.

The parameter values are as noted for the query form of the command. The service provider will tell you what numbers to enter for NUM, MIN, SID, and NID.

NAM must be 0.

Following writing the values, the modem must be reset to have the values take effect.

#### -RESET Soft Reset

Syntax: AT-RESET

**Description:** Resets the modern gracefully, shutting down any active connection. The modern issues

the OK result before completing the reset cycle. The reset is complete after approximately

5–15 seconds, after CTS has been deasserted and then reasserted.

#### -SHTDWN Shutdown

Syntax: AT-SHTDWN

**Description:** Forces the modem into a shutdown state, gracefully closing any open connection. This

shutdown is deeper than the one achieved by using the control signals on the modem; it

includes closing the serial connections.

Following this command, the modem can be restarted only by power cycling or a hardware

reset.

The Shutdown Acknowledge control line is asserted when the shutdown is complete.

#### **Speaker (Headset) Mute** -SPKMUT=

Syntax: AT-SPKMUT=<n> (Set command)

AT-SPKMUT? (Query command)

Description: Sets and queries the state of the speaker mute. This value is not stored in non-volatile

memory. The setting is considered temporary, and reverts to the default (OFF) when a new call is started, or the modem is power cycled, reset, or when the profile is restored

(&F and Z).

**Parm** Meaning 0 Speaker mute is OFF. Default. Mute is ON

**Note:** This setting does not affect the setting of –SPKVOL (Speaker Volume).

#### Speaker (Headset) Volume -SPKVOL=

Syntax: AT-SPKVOL=<n> (Set command)

AT-SPKVOL? (Query command)

**Description:** Sets and gueries the volume level of the voice circuit speaker.

The value is stored in non-volatile memory, making it persistent across resets and powercycles.

Parm	Meaning
0	muted
1	-20 dB
2	-16 dB
3	-12 dB (Default)
4	-18 dB
5	-4 dB
6	0 dB

#### -STGLVL= Side Tone Gain Level

Syntax: AT-STGLVL=<n> (Set command)

AT-STGLVL? (Query command)

Description: Sets or queries the amount of side tone gain; that is the volume of the speaker's own voice

(microphone input) that is presented to the earpiece (speaker output).

Parm	weaning
0	-84 dB
1	-36 dB
2	-32 dB (Default)
3	-28 dB
4	-24 dB
5	-20 dB
6	-16 dB

### -TONDUR = Tone Duration

**Syntax:** AT-TONDUR=<key,on,off> (Set command)

AT-TONDUR? (Query command)

Description: Sets and queries the timing, in milliseconds, for generating DTMF tones using single key

tones (-DTMFK) and bursts (-DTMFB). Settings are stored in non-volatile memory.

Parm	Range	Meaning
key	100–3000	Key duration for single key tones (-DTMFK) Default = 300 ms
on		On time for tones in bursts (-DTMFB)
	95–144	95 ms
	145-194	150 ms
	195–244	200 ms (Default)
	245-294	250 ms
	295-344	300 ms
	345-350	350 ms
off		Off time between tones in bursts.
	60-109	60 ms
	110–159	100 ms (Default)
1	60-200	150 ms

#### -TONMUT= Tone Mute

**Syntax:** AT-TONMUT=<n> (Set command)

AT-TONMUT? (Query command)

Description: Sets and queries the mute setting on the generation of DTMF tones via -DTMFK and

-DTMFB. Settings are stored in non-volatile memory.

Parm	Meaning
0	DTMF mute is OFF (tones can be generated) (Default)
1	Mute is ON

# Chapter 14 – Status Registers

Some of these registers relate to the call progress timing at the IWF with the PSTN connection. These are noted below using the (Remote) tag.

Table of S-Registers

Reg.	Description	Range	Default	Units
0	Auto answer	0–255	000	(n-1)*6 s
	The modem auto answers after a delay specified by S0.			
	If S0=0, then auto answer is turned off.			
	The delay is equivalent to [ <value> - 1] x 6 seconds.</value>			
	Examples:			
	1 = no delay			
3	3 = 12 seconds	0–127	012 (CD)	ASCII
3	Carriage Return Character	0-127	013 (CR)	ASCII
	The standard end of line character used to indicate the end of an AT command. This character is also used as the carriage return			
	character for framing responses and result codes in command state.			
4	Line Feed Character	0–127	010 (LF)	ASCII
	The standard line feed character sent by the modem to the host at		, ,	
	the end of a response or return code in command state.			
5	Backspace Character	0–127	008 (BS)	ASCII
	This register sets the character recognized as a backspace during			
	command entry.			
6	Wait for Blind Dial (Remote)	2–10	002	Seconds
	This register denotes the wait time, in seconds, before a blind dial (no dial tone detection).			
	The value of S6 is used when the X (Result Code Select/Call Progress Control) command is set to 1, or 3.			
	X settings of 2 and 4 enable dial tone detection and disable blind dialing.			
	Therefore, when X is set to 2 or 4, the value of S6 is irrelevant.			
7	Wait For Carrier (Remote)	1–255	060	Seconds
	If no carrier from the remote modem is detected within the specified time, the modem goes on-hook.			
8	Comma Pause Time (Dial Modifier)	0–255	002	Seconds
	(Remote)		002	200000
	Whenever a dial command contains the comma character, the			
	contents of this register specify the pause time for each comma.			
9	Carrier Detect Response Time	0–255	006	0.1 s
	(Remote)			
	Specifies the time that the received carrier must be present for the modem to recognize it and turn on Data Carrier Detect (DCD) if			
	applicable.			
	The implementation is entirely at the IWF modem.			
			•	

10	Lost Carrier Hang-up Delay (Remote)	1–255	014	0.1 s
	Specifies the amount of time that the carrier from the remote modem can be lost before the modem goes on-hook. This allows temporary disruptions to carrier without disconnecting.  A setting of 255 causes the modem to disable Carrier Detect and presume carrier is always present.			
11	DTMF Dialing Speed (Remote)	50–255	095	0.001 s
	This specifies the duration of tones in DTMF dialing. This register is not used by the -DTMFB command. See -TONDUR (Tone Duration).			

# Chapter 15 – Result Codes

This table provides a numerical list of the standard result codes possible.

#### **Basic Result Codes**

Code	Verbose	Meaning			
0	OK	Command executed without errors			
1	CONNECT	Connected at any of the supported speeds			
2	RING	Alerting Signal (Ring) signal received from the network			
3	NO CARRIER	Carrier signal lost or not detected. Unable to activate the service.			
4	ERROR	Command not recognized or could not be executed. Illegal command. Error in command line. Command line exceeds buffer size. Parameters out of range.			
6	NO DIAL TONE	Dial tone not detected within timeout and subsequent commands not processed			
7	BUSY	Reorder (Busy) signal detected and subsequent commands not processed			
8	NO ANSWER	Five seconds of silence not detected after ring back when "@" (quiet answer) dial modifier is used			

#### **Extended Cellular Result Codes**

This table provides a numerical list of extended result codes that may be supported by the IWF. Note that IWF systems may not support some or all of these codes.

Code	Verbose	Meaning
11	RING ASYNC	Indicates an incoming CSC call
12	RING FAX	(Fax Not Supported) Indicates an incoming CSC Fax call
13	RING PACKET	Indicates an incoming packet data mode call
21	NO SERVICE	Origination was attempted while the modem was not able to acquire a CDMA Paging Channel
22	NO ASYNC SERVICE	The base station rejected the async service option request
23	NO FAX SERVICE	The base station rejected the fax service option request
25	BAD REQUEST	An intercept was received after call origination
26	PAGED	The modem attempted to originate a call after receiving a page
27	RETRY	Reorder received after call origination
28	PAGE FAIL	The modem received a page but not an alert
29	LINK FAIL	The modem has lost the Traffic Channel
30	RELEASE	The call has been released

#### Extended Cellular Call Progress Result Codes

The following extended result codes may be enabled when the +CRC=1 setting is used. Support for these rests with the IWF. These are primarily call progress indications. Note that if Verbose is off (V0), these codes are suppressed; there are no numeric equivalents for call progress codes.

Code	Verbose	Meaning			
	+CERROR: INIT FAILED	Initialization String failed during transport layer initialization. If			
	<failed command=""></failed>	+CRC=0 then result code 4 ERROR is returned			
	+CPROG: ANSWER	Indicated remote DCE has answered			
	+CPROG: BONGTONE	Billing tone was detected			
	+CPROG: DIALING <num></num>	Indicates PSTN dialing			
	+CPROG: DIALTONE	Dial tone was detected			
	+CPROG: QUIET ANSWER	Indicates Quiet Answer			
	+CPROG: RINGING	Indicates PSTN ringing			
	+CPROG: VOICE	Voice detected on PSTN connection			
*	+RING <service mode=""></service>	Indicates an incoming call to the modem in the service mode			
		indicated: ASYNC or STU-III (not supported)			
* See nu	mbers 11-13 in Table of Extended (	Cellular Result Codes on previous page			

# Chapter 16 – Stored Profile Settings

The CDMA 1X modems do not support a user- defined profile. Both Z (Reset) or &F (Factory Settings Restore) restore the following settings.

#### **Stored Profile Settings for Commands**

Command	Description	Factory Settings
\$QCMIP	Mobile IP behavior	Carrier dependent
\$QCMIPNAI	Network Access ID (NAI) for the Mobile IP general	Carrier dependent
	user profile	
\$QCMIPP	Active Mobile IP user profile	
E	Echo (Command State)	1 (enabled)
L	Loudness - Speaker Control	0 (ignored)
M	Mute - Speaker Control	0 (ignored)
Q	Quiet - Result Code Display Option	0 (Codes returned)
V	Verbose - Result Code Form	1 (Words)
Χ	Result Code Select/Call Progress Control	4 (all codes)
&C	Data Carrier Detect Control	2 (UNIX wink)
&D	Data Terminal Ready Options	2 (Hang up)
+CFG	Configuration String	(null)
+CMUX	Multiplex Option	C (Forward link)
		2 (Reverse link)
+CQD	Command State Inactivity Timer	10 (50 seconds)
+CRC	Cellular Result Codes	0 (disabled)
+CRM	Local (Rm) Interface Protocol	0 (async data)
+CXT	Cellular Extension	0 (do not pass)
+ICF	Character Framing	3, 3 (ignored)
+ILRR	Local Rate Reporting	0 (off)
+IPR	Fixed Port (Rm) Rate	115200 (ignored)
+MA	Modulation Auto Mode	(null)
+MR	Modulation Reporting	0
+MS	Modulation Selection	(null)
+MV18R	V.18 Reporting	0 (disabled)
+MV18S	V.18 Selection	0, 0, 0

#### **Stored Profile Setting for S-Registers**

Command	Description	Factory Settings
S0	Auto-answer mode	0 (disabled)
S3	Carriage Return Character	013 (CR)
S4	Line Feed Character	010 (LF)
S5	Backspace Character	008 (BS)
S6	Wait for Blind Dial (Remote)	002 (2 seconds)
S7	Wait for Carrier (Remote)	060 (60 seconds)
S8	Comma Pause Time (Remote)	002 (2 seconds)
S9	Carrier Detect Response Time (Remote)	006 (0.6 seconds)
S10	Lost Carrier Hang-up Delay (Remote)	014 (1.4 seconds)
S11	DTMF Dialing Speed (Remote)	095 (0.095 s)

# Appendix A – Working With the IWF

#### Introduction

**Note:** The information in Appendix A applies to cellular accounts with Circuit-Switched Data service. Check with your service provider to see which services are enabled for your account.

When operating a CDMA modem in IS 95B Circuit-Switched Cellular (CSC) service, the local modem and the IWF modem must work as a team to perform the duties that a traditional wire line modem handles alone. To support this teamwork, the modem has an extensive set of commands to query the PCS network and IWF for information about the services and capabilities available. There are also commands to configure the IWF modem as well as commands to configure the local modem.

The modem is designed to keep this dependency as transparent as possible. Commands that configure the IWF modem are typically stored at the local modem until a connection request is made. At that time, the commands are sent as a block to the IWF to set up the modem team for the call. Settings stored at the local modem will report the user setting even though the command is intended for execution / implementation at the IWF.

The airlink radio connection between these two modems operates on two levels. There is the traditional link to exchange user data between the local and remote terminal applications, and a second link to exchange operational information between the local modem and the IWF modem. This second link is largely transparent to the user.

The modem control information is exchanged using a transport layer of the airlink that is independent of an active data call. The modem can open the airlink specifically to exchange command settings without having an incoming or outgoing call on the usual data link. Normal call setup will trigger the local modem to open the airlink for the transport of the dial command. The data aspect of the link is not opened until the IWF has established the call through to the remote terminal.

The two modems use the transport layer of the airlink to stay synchronized. In simple operation, the user would not be aware that there are actually two modems on the local side of the connection. The local modem and the IWF modem co-ordinate their functions without specific user actions.

#### **Local and Remote Commands**

Some commands in this reference are noted as "(Remote)". This indicates that the command is related to query or configuration of the IWF modem.

There are essentially three classes of commands: Local Only, Shared, and Remote-only.

#### Local Only

These are commands that control or query the local modem only. There are only a very few commands like this that are not shared. Local only commands return an ERROR result when the airlink to the IWF is active, but return valid results when the modem is on-hook. I5 is an example.

#### Shared

These commands appear to execute on the local modem. In fact these commands only store settings that are later used to configure the IWF, which must actively use the settings in establishing a call on the PSTN. The local modem does not need to create an airlink to the IWF for these commands. When an airlink is needed, the settings are sent to the IWF as part of the initialization of the link.

#### Remote-only

Some commands require the IWF to provide the response. The local modem treats these as unrecognized commands. If configured (using +CXT), the local modem will open the airlink and pass the command to the IWF, then relay the response to the local host; otherwise the local modem returns ERROR for unrecognized commands. These commands work on the transport layer in the airlink between the two modems. A command such as +CGCAP is in this class.

Still other commands are only meaningful if there is an established call because the data involved is transient and only exists in the presence of a call. +CMIP (page 61) is used to query for the current IP address of the modem. The modem is assigned an IP address by the network only when there is an active IS 95B call.

This is an example of another type of remote-only command.

Remote-only commands are noted in the reference with the tag "(Remote)". If the tag is not shown, the command may be shared. Shared commands are "stored" at the local modem and are sent to configure the IWF when the airlink is established.

#### **Airlink Control**

Most of the time, the modem is operating independently (idle)—without an airlink established to the IWF or beyond. When AT commands are issued to query, configure, and set up a call, the modem may automatically establish the airlink as needed. When the call is terminated, or the modem is not actively configuring the IWF, the airlink is dropped to free the radio band for other users.

Knowing when the transport layer is active and when it is not is critical to proper interpretation of the result codes. If the link is not in place, remote-only commands give the ERROR result code. The command is unknown to the local modem or is related to a data object only available from the IWF. The same command responds differently when the airlink is established.

#### Establishing the Airlink

For the local modem to communicate with the IWF, an airlink is opened between them. The local modem can open this link without initiating a call through the PSTN or Quick Net Connect to a remote system. There are two primary methods to establish the airlink:

- Initiate or answer a call. Using ATD to initiate a call or ATA to answer a call causes the local modem to open the link.
- Issue a remote-only command (or any command unrecognized by the local modem) with the modem set using +CXT=1 (Cellular Extension enabled).

If +CXT=0 (disabled), then the local modem gives the ERROR result code for unrecognized commands. When the cellular extension is enabled, the modem will open the airlink and pass the command to the IWF for processing.

If the modem can find a channel but is not permitted to register, it attempts to establish the airlink result in the NO CARRIER result.

#### Initializing the Airlink

Note: To control the configuration process, the local modem and the IWF have a standard default setting. Unlike standard wire line modems that allow a user configuration (profile) to be saved and restored on reset, CDMA modems support only the factory defaults on reset. A nonstandard user configuration must be sent to the local modem after any reset, ATZ, or power-cycle.

The local modem automatically initializes the airlink each time it is opened. The initialization process involves first sending the IWF all needed AT commands to configure it to match the (non-default) settings of the local modem itself. This ensures that both modems are synchronized. The second step to initializing the link is to send the IWF the contents of the +CFG string (page 59). These are commands selected by the user to configure the IWF for a particular operation.

Once the airlink is established, the local modem will pass the command that initiated the link (ATD, ATA, or the unrecognized command line) to the IWF.

#### Pass through and Reflection

In many respects, the local modem operates as a pass through modem providing the local host device with a radio link to the IWF modem. In many cases commands are passed through the local modem for execution at the IWF. The IWF then reflects the command back to the local modem on the transport layer of the airlink. Both modems are kept synchronized with respect to their configuration.

When a command is entered into the local modem (with the airlink active) the command is passed through to the IWF without any processing locally. The IWF controls the command line echo (if enabled). There is a noticeable delay in the echo time when the airlink is active and when it is not.

The IWF processes the command line and reflects it back to the local modem. Only if the IWF is successful at executing the command is the command reflected back to the local modem for processing locally. If the command fails, the ERROR result is passed back and through to the local host. This ensures the two modems are kept synchronized.

For further details on how the command line is processed, see "Command Handling".

#### Closing the Airlink

The airlink is closed whenever a call terminates through:

- Normal disconnection (ATH)
- Loss of carrier (disconnection at the remote end or break in the PSTN connection)
- Loss of cellular coverage

If the modem has an airlink established but is not in an active call, the link can be closed by the IWF if there is no traffic (commands or replies) for the duration set with +CQD. This timer defaults to 50 seconds. The link can be closed before this time by issuing the H command.

When the airlink is closed, the local modem reports to the host (DTE) with the NO CARRIER result code.

# **Modem Defaults and Configurations**

To summarize the discussion above:

- Both the local modem and the IWF share common defaults.
- The user cannot save a non-standard default configuration.
- Upon initialization of the airlink, the IWF is reset to default, and then any non-default values stored at the local modem are sent to the IWF to configure both modems to the same settings.
- When the airlink is active, all commands are executed by the IWF first.
   Settings are reflected back to the local modem to keep them synchronized.

When the airlink connection is closed, the local modem retains the settings last used, while the IWF modem is reset to defaults. When the next airlink is opened, the local modem may connect to a different modem at the IWF, so the local modem must repeat the initialization process. The user does not need to reconfigure the local modem for each call, although reconfiguration will be needed if the local modem is reset or power-cycled.

# Appendix B - ASCII Table

Char	Dec	Hex	Char	Dec	Hex	Char	Dec	Hex	Char	Dec	Hex
NUL	0	00	SP	32	20	@	64	40	í	96	60
SOH	1	01	!	33	21	Α	65	41	а	97	61
STX	2	02	"	34	22	В	66	42	b	98	62
ETX	3	03	#	35	23	С	67	43	С	99	63
EOT	4	04	\$	36	24	D	68	44	d	100	64
ENQ	5	05	%	37	25	E	69	45	е	101	65
ACK	6	06	&	38	26	F	70	46	f	102	66
BEL	7	07	,	39	27	G	71	47	g	103	67
BS	8	08	(	40	28	н	72	48	h	104	68
HT	9	09	)	41	29	- 1	73	49	İ	105	69
LF	10	0A	*	42	2A	J	74	4A	j	106	6A
VT	11	0B	+	43	2B	K	75	4B	k	107	6B
FF	12	0C	,	44	2C	L	76	4C	- 1	108	6C
CR	13	0D	-	45	2D	М	77	4D	m	109	6D
so	14	0E		46	2E	N	78	4E	n	110	6E
SI	15	0F	1	47	2F	0	79	4F	0	111	6F
DLE	16	10	0	48	30	P	80	50	р	112	70
XON	17	11	1	49	31	Q	81	51	q	113	71
DC2	18	12	2	50	32	R	82	52	r	114	72
XOFF	19	13	3	51	33	s	83	53	s	115	73
DC4	20	14	4	52	34	Т	84	54	t	116	74
NAK	21	15	5	53	35	U	85	55	u	117	75
SYN	22	16	6	54	36	V	86	56	v	118	76
ETB	23	17	7	55	37	w	87	57	w	119	77
CAN	24	18	8	56	38	Х	88	58	х	120	78
EM	25	19	9	57	39	Υ	89	59	у	121	79
SUB	26	1A	:	58	3A	Z	90	5A	z	122	7A
ESC	27	1B	;	59	3B	]	91	5B	{	123	7B
FS	28	1C	<	60	3C	١	92	5C	-	124	7C
GS	29	1D	=	61	3D	1	93	5D	}	125	7D
RS	30	1E	>	62	3E	^	94	5E	~	126	7E
US	31	1F	?	63	3F	_	95	5F	DEL	127	7F

# Appendix C – Acronyms and Definitions

Acronym or Term	Definition
AGC	Automatic Gain Control
Cellular	800MHz radio spectrum air interface
dB	Decibel = 10 x log <sub>10</sub> (P1/P2) (Power dB)
	Decibel = 20 x log <sub>10</sub> (V1/V2) (Voltage dB)
dBm	Decibels, relative to 1 mW - Decibel(mW) = 10 x log <sub>10</sub>
	(Pwr (mW)/1mW)
FER	Frame Error Rate – a measure of receive sensitivity
GPS	Global Positioning System—a system that uses a series of 24
	geosynchronous satellites to provide navigational data
IS-95	2G radio standards targeted for voice (cdmaONE)
MHz	MegaHertz = 1e6 Hertz (Hertz = 1/second)
PCS	Personal Communication System - PCS spans the 1.9GHz radio spectrum
PDE	Position Determination Entity—the device that the mobile communicates
	with for assistance in acquiring a GPS location fix
response	A response from the modem that is issued prior to a result code
result code	A numeric or text code that is returned after all commands (except resets)
RF	Radio Frequency
Sensitivity (RF)	Measure of lowest power signal that the receiver can measure

# Index

	&D Data Terminal Ready Options	. 31
!	&F Factory Settings Restore	
	&V View Configuration	. 31
!APPSUBTYPES Negotiated Subtypes18		
!CNTSMS Count SMS	<b>+</b>	
!DASMS Delete All SMS	_	
!DSMS= Delete SMS (Selective)19	+++ Escape	
!ECIO? Ec/lo	+CAD? Analog or Digital Service	
!GMODE Mode of the Modem	+CBIP? Base Station IP Address (Read-only)	
!GSMS? Get SMS	+CDV Dial Voice	
!MDMVER? Version of the Modem Firmware 19	+CFG= Configuration String	
!MUFWDRESET Reset Data in !MUFWDSTATS 20	+CHV Hang-up Voice	. 33
!MUFWDSTATS Current Traffic Channel Statistics	+CMIP? Mobile Station IP Address	
	+CMUX= Multiplex Option	
!PERSONALITY? Displays Current Personality20	+CQD= Command State Inactivity Timer	
!PREV? Protocol Revision	+CRC= Cellular Result Codes	
!PRLVER? PRL Version	+CRM= Local (Rm) Interface Protocol	
!PROTSUBTYPES? Negotiated Subtypes21	+CSQ? Signal Quality	
!RSSI? Received Signal Strength Indication 22	+CSS? Serving System	
!SCPCUSTCONFIG? Current Session	+CTA= Packet Data Inactivity Timer	
Configuration Protocol Customer Configuration. 22	+CXT= Cellular Extension	
!SESSIONSTATUS Current Session Status 23	+FCLASS= Modem Operating State	.31
!SIPID= User ID Information for Simple IP Setup 23	+GCAP Get Capabilities	
!SIPPWD= Password Information for Simple IP	+GMI Get Manufacturer	
Setup	+GMM Get Model Number	
!SLEEPPARMS Sleep Parameters	+GMR Get Revision	
!SSMS= Send SMS	+GOI Get ISO ID	
!STATUS Status of the Modem	+GSN Get ESN	
!SUFWDCCSTATS Current Single User Forward	+ICF= Character Framing	
Channel Statistics on DRCs25	+ILRR Local Rate Reporting	
!SUFWDCRCS Current Single User Forward	+MA= Modulation Auto Mode	
Channel Statistics on CRCs	+MR= Modulation Reporting	
!SUFWDRESET Resets Data	+MS= Modulation Selection	
!SUFWDTCSTATS Current Single User Forward	+MV18R= V.18 Reporting	
Channel Statistics	+MV18S= V.18 Selection	
!SYSTIME? CDMA Time27	+WGETWK Request Wake-Up Reason	
<u> </u>	+WWKUP= Wake-Up Events Mask	. 44
<i>\$</i>		
\$QCCAV Answer Voice28	$\boldsymbol{A}$	
\$QCCAV Allswel Voice28 \$QCMIP Mobile IP (MIP) Behavior28	A Answer (Manual)	15
\$QCMIPEP Enables/Disables the Currently Active	Account Activation Commands	
Mobile IP User Profile28	Account Activation Commands	
\$QCMIPGETP Query a User Profile29	Advanced Modem Configuration Commands	
\$QCMIPNAL Set the Network Access ID (NAI) for	Airlink Control	
the Currently Active Profile29	ASCII Table	
\$QCMIPP Select One of the Mobile IP User	AOOII Table	. 04
Profiles to be the Current Active Profile29	D	
\$QCVAD= Sets or Reads the Mode for Answering	$\boldsymbol{B}$	
Data Calls30	Basic Modem Configuration Commands	15
Data Gallo	Basic Operation Action Commands	
0	Basic Operation Action Commands	. 13
<b>&amp;</b>		
&C Data Carrier Detect Control31		

$\boldsymbol{\mathcal{C}}$	N	
CDMA 1X9	-NAMLCK= NAM Lock	52
CDMA 1xEV-DO9	-NAMVAL= NAM Values	
CDMA IS-95B8		
Closing the Airlink63	0	
Command Buffer11	U	
Command Handling12	O Online (Remote)	48
Command to Data State	G Grillio (RGINGLO)	
Concatenation	n	
Conditions 10	$\boldsymbol{P}$	
Conventions 7	P Pulse Dialing	18
OUTVETRIOTIS	Parameters	
D	Possible Result Codes	
D	r ossible result codes	10
D Dial46	Q	
Data Buffers12		
Data to Command State11	Q Quiet (Result Code Display Option)	48
Defaults and Configurations63		
Device and Service Interrogation Commands 17	$\boldsymbol{R}$	
Document Structure7	**	
-DTMFB= DTMF Burst51	Registers	12
-DTMFK= DTMF Key51	-RESET Soft Reset	
•	Response Framing	13
$\boldsymbol{E}$	Responses and Result Codes	
L	Result Code Framing	
E Echo47	Result Codes	
-ECHO= Echo Cancellation Level51		
Extended Cellular Call Progress Result Codes 59	<b>S</b>	
<b>27</b>	S <n>= S-Register Set/Query</n>	40
$\boldsymbol{F}$	-SHTDWN Shutdown	<del>4</del> 3
Framing	SMS Messages Commands	
Framing Characters	Speed Buffering	
Training Orlaracters13	-SPKMUT= Speaker (Headset) Mute	
**	-SPKVOL= Speaker (Headset) Wolume	
H	State Transitions	
H Hook Control47	States	
-HDSET= Headset Detection Option	-STGLVL= Side Tone Gain Level	
Host Connection Basics9	Stored Profile Settings	
	Stored Profile Settings	60
Human vs. Machine Interface13	<b>70</b> 7	
I	$oldsymbol{T}$	
1	T Tone (Set DTMF Dialing)	49
I Product Identification Information47	Table of S-Registers	
Initializing the Airlink62	-TONDUR= Tone Duration	
•	-TONMUT= Tone Mute	
$\boldsymbol{L}$		
_	$oldsymbol{V}$	
L Loudness (Speaker Volume)47	•	
Local and Remote Commands61	V Verbose (Result Code Form)	49
M	X	
M Mute (Speaker Control)	X Result Code Select/Call Progress Control	50
-MICMUT= Microphone Mute52	_	
Modem Basics8	$oldsymbol{Z}$	
Modem Buffers11	7 0 6 0	
Modes	Z Profile Restore	50



#### SDU Series, DIN Rail AC UPS

The SDU DIN Rail UPS combines an industry leading compact design with a wide operation temperature range and unique installation options. The SDU series provides economical protection from damaging impulses and power interruptions. These units include easy to wire screw terminations for critical devices needing battery back up such as computer based control systems.

#### **Applications**

- Programmable Logic Controllers
- Factory Automation
- Robotics
- Conveying Equipment
- Computer-based Control Systems

#### **Features**

- Lightweight, compact industrial design
- Wide operation temperature range (0°C to 50°C)
- · Cold start capability
- Phone/dataline surge protection
- Software and cable included for easy installation
- Simulated sinewave output
- RS232 communication port
- USB communication port (optional)
- Form C dry contact relay (optional)
- Panel/wall mounting brackets (optional)
- · Remote turn-on and shut-off capabilities
- Two year limited warranty

# 



#### **Certifications and Compliances**

#### 120V Models

- chius UL Recognized Component, UPS Equipment
- UL 60950-1/CSA C22.2 No. 60950-1
- Suitable for UL 508, CSA C22.2 No. 107.1 Ind. Control Equipment Applications with no derating
  - Overvoltage Cat III, Pollution Degree III

#### 230V Models

- (€
  - EN62040-1-1

#### **Related Products**

- Portable MCR Power Conditioners
- STV Surge Protective Devices
- SDN DIN Rail Power Supplies
- STFV Plus Active Tracking® Filters

#### Selection Table

Capacity (VA/W)	Catalog Number	Volts, Frequency In/Out	Typical Back–up Time (minutes) *	Input/Output Connections	Approx. Ship Weight — lbs (kg)
500/300	SDU 500	100 Voc 50/60 Uz	4		10.7 (4.70)
850/510	SDU 850	120 Vac, 50/60 Hz	2	IP20 touch proof, screw terminals.	11.4 (5.00)
500/300	SDU 500-5	000 Von F0/60 LI-	4	Wire range: 10 ~ 24 AWG.	11.5 (5.20)
850/510	SDU 850-5	230 Vac, 50/60 Hz	2		11.9 (5.40)

<sup>\*</sup> At full load.

#### **SDU Accessories**

Catalog Number	Description	Approx. Ship Weight – Ibs (kg)
RELAYCARD-SDU	Dry contact I/O relay box, IP20 touch proof screw terminals, wire size range 12~22 AWG (IEC 2.5mm); N.O./N.C. form "C" contact. Relay contact signal for "On Battery", "Low Battery" and "UPS Shutdown".	1.0 (0.45)
UPSMON-USB	RS232 to USB adapter cable	1.0 (0.45)
SDU-PMBRK	Mounting brackets to secure UPS to wall, back of panel or enclosure.	1.0 (0.45)



#### **Specifications**

Catalog Number	SDU 500	SDU 850	SDU 500-5	SDU 850-5		
Capacity (VA/Watts)	500/300	850/510	500/300	850/510		
Load Power Factor		0.6				
		Dimensions – inches (mm)				
Unit (H x W x D) – in. (mm)		4.88 x 11.1 x 4.55 (124.	.0 x 281.0 x 116.0)			
Weight – Ibs (kg)	10.7 (4.70)	11.4 (5.00)	11.5 (5.20)	11.9 (5.40)		
		Input Parameters				
Voltage	120 V (+	10%, -20%)	230 V (+/-	- 20%)		
Frequency		50 +/- 5 Hz or 60 Hz +/-	6 Hz (auto sensing)			
		Output AC Parameters				
Voltage (Battery Mode)		Step sinev				
J- ()		+/- 5%				
Frequency (On Battery)		50 or 60 +/- 0.3				
Overload Protection	UPS automatic shutdown if c	overload exceeds 105% of nominal		onds, 130% at 3 seconds		
Short Circuit	UPS output cut off immediately					
		Battery Parameters	<u> </u>			
Battery Type						
Transfer Time		4 - 6 ms typical				
Back-up Time * (minutes)	4.5/18 2.5/10 4.5/18 2.5/10					
Recharge Time	8 hours to 90% capacity after full discharge					
		Environmental				
Operating Temperature		0°C to 50	D°C			
Storage Temperature	-15°C to 60°C					
Relative Humidity	1% to 95%, non-condensing					
Ambient Operation	1-95% humidity non-condensing, 0-50°C up to 5,000 ft. (1500m)					
Audible Noise	< 40dBA (1 meter from surface)					
Standards						
ЕМС	FCC Part 15, Subpart B, Class A; EMC: EN50091-2, EN61000-3-2, EN61000-3-3, IEC60801-2, IEC60801-3, IEC60801-4, IEC61000-2-2					
Elevation		5000 ft. without derating				
Shock & Vibration	Acco	According to the International Safe Transit Association standard ISTA 2A.				
Mounting	To be mounted on DIN TS35/7.5 or TS35/15 rail system. Chassis mounting permissible via optional brackets.  Unit handles normal shock and vibration of industrial use and transportation without coming off rail.					

<sup>\*</sup> At full load/half load.



## **Uninterruptible Power Systems**

# **SDU Series** 500, 850, 500-5, 850-5



## **Instruction Manual**

While every precaution has been taken to ensure accuracy and completeness in this manual, SolaHD assumes no responsibility, and disclaims all liability for damages resulting from use of this information or for any errors or omissions.

©2008 SolaHD. All rights reserved throughout the world. Specifications are subject to change without notice.

®SolaHD name and logo are registered trademarks of EGS Electrical Group, LLC. All names referred to are trademarks or registered trademarks of their respective owners.

Aunque se han tomado todas las precauciones para asegurar la exactitud y acuciosidad de este manual, SolaHD no asume responsabilidad alguna, y rechaza toda responsabilidad por daños que pudieran resultar debido al uso de esta información o por cualquier error u omisión.

©2008 SolaHD. Todos los derechos reservados en el mundo entero. Las especificaciones pueden cambiar sin previo aviso.

El nombre y el logotipo de ®SolaHD son marcas registradas de EGS Electrical Group, LLC. Todos los nombre mencionados son marcas comerciales o registradas de sus respectivos titulares.

Bien que toutes les précautions aient été prises afin d'assurer que les renseignements du présent manuel sont complets et exacts, Sola/Hevi-Duty n'assume aucune responsabilité, et décline toute responsabilité pour des dommages découlant de l'utilisation de cette information ou de toute erreur ou omission.

©2008 SolaHD Tous droits réservés mondialement. Les caractéristiques techniques sont sujettes à modification sans préavis.

Le nom et le logo ®SolaHD sont des marques déposées de EGS Electrical Group, LLC. Tous les noms évoqués sont des marques de commerce ou des marques déposées de leurs propriétaires respectifs.

## Table of Contents/Índice/Table des matières

English	
1.0 Important Safety Instructions	4–5
2.0 Warnings Defined	5
3.0 Introduction	6
4.0 System Description	7–8
5.0 Installation Instructions	
6.0 Operating Instructions	9–10
7.0 Battery Overload Alarms	10
8.0 PIN-Out Configuration for DB9 Connector	1′
9.0 Battery Backup Times	11
10.0 Troubleshooting	12
11.0 Storage	12
12.0 Specifications	13
13.0 Conditions for Safe Use of SDU 500 & 850	14–15
14.0 Product Registration & Warranty Information	15
Español	
1.0 Instrucciones importantes de seguridad	16–17
2.0 Definición de advertencias	17
3.0 Introducción	18
4.0 Descripción de sistema	19–20
5.0 Instrucciones de instalación	2′
6.0 Instrucciones de operación	21–22
7.0 Tiempo de autonomía de la batería (Alarma)	23
8.0 Configuración de disposición de las clavijas del conector DB9	23
9.0 Tiempo de reserva de la batería	24
10.0 Almacenamiento	24
11.0 Solución de problemas	25
12.0 Especificaciones	26
13.0 Registro del Producto y Información sobre la Garantía	27
Français	
1.0 Instructions importantes sur la sécurité	28–29
2.0 Définition des avertissements	29
3.0 Introduction	30
4.0 Description du système	31–32
5.0 Instructions d'installation	33
6.0 Instructions d'utilisation	33–34
7.0 Alarmes de la batterie de secours	35
8.0 Configuration des broches de sortie du connecteur DB9	35
9.0 Temps de secours de batterie	36
10.0 Entreposage	36
11.0 Dépannage	37
12.0 Spécifications	38
13.0 Enregistrement du produit et information sur la garantie	39

## 1.0 Important Safety Instructions

This manual contains important safety instructions that should be followed during the installation of the Uninterruptible Power System (UPS). Please read all safety, installation, and operating instructions before attempting to install or operate the UPS. Please adhere to all warnings on the unit and in this manual during installation and operation.

The UPS is designed for Industrial or Commercial use and can be installed and operated by individuals without previous training.

#### 1.1 Safety Precautions—Warnings

 To prevent the risk of fire or electric shock, install the UPS in a temperature and humidity controlled ventilated enclosure, free of conductive contaminants, moisture, flammable liquids, gases, and corrosive substances.



- Operate the UPS only from a properly grounded (earthed) ac supply.
- To reduce the risk of electric shock, do not remove the cover, as it has no userserviceable parts inside. Some components are live, even when ac power is disconnected. For service, contact a qualified technician.

Although your UPS has been designed and manufactured to assure personal safety, improper use can result in electrical shock or fire. To ensure safety, please observe the following rules:

- Turn OFF UPS and disconnect the ac supply before cleaning. Do not use liquid or aerosol cleaners. A dry cloth is recommended to remove dust from the surface of your UPS.
- Do not install or operate the UPS in or near water.
- Do not place the UPS on an unstable cart, stand, or table.
- Do not place the UPS under direct sunlight or close to heat-emitting sources.
- To allow proper ventilation of the UPS, do not block or cover the top and bottom sides of the unit.
- Never block or insert any objects into the ventilation holes or other openings of the UPS. Keep all vents free of dust accumulation that could restrict airflow.

- Follow all warnings and instructions marked on the UPS. Do not attempt to service the UPS, as it has no user-serviceable parts inside. Refer all repairs to qualified service personnel.
- Do not dispose of batteries in a fire; they may explode.
- Do not open or damage the battery. Released electrolyte is harmful to the skin and eyes and may be toxic.

If your UPS demonstrates any of the following conditions, turn OFF the UPS, disconnect the ac supply and contact your local distributor, SolaHD representative or SolaHD Technical Support at 1-800-377-4384.

- Liquid has been spilled on the UPS.
- The circuit breaker opens frequently.
- The UPS does not operate in accordance with the user manual.

#### 1.2 Conditions of Use

Your UPS provides conditioned power to connected equipment. The maximum load must not exceed that shown on UPS rating label. If uncertain, contact your distributor or SolaHD Technical Support at 1-800-377-4384.

**U.S. Only:** For Conditions of Acceptability in accordance with UL 508A, see "13.0 Conditions for Safe Use of SDU 500 & 850".

## 2.0 Warnings Defined



**Danger:** Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury. This signal word is limited to the most extreme situations.



**Warning:** Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.



**Caution:** Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

#### 3.0 Introduction

Congratulations on your choice of the SDU Uninterruptible Power System (UPS). The SDU is a compact, "Off-Line" DIN rail mountable UPS, which provides conditioned power to sensitive electronic equipment. It supplies connected equipment with stepped approximation to sinewave power to simulate the power generated by the utility.


The SDU is a powerful, microprocessor-controlled UPS. Input voltage range is 80% to 110% (ideal protection for the critical connected loads). Battery charging occurs automatically when ac power is applied, no need to switch ON the UPS. When power fails, the UPS can be automatically turned OFF, as long as the connected loads are not operating to save the battery energy. The SDU also includes an automatic self-test feature to test the UPS function and battery. If the battery is no longer useful, the unit will sound an alarm and an LED indicator will illuminate.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in an industrial installation. This equipment uses, generates and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference with radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment OFF and ON, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the UPS and the receiver.
- Connect the UPS into a circuit different from that which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## 4.0 System Description

#### 4.1 Front Panel




- Power ON/OFF/Test Button: Press the button for more than one second to turn the UPS ON. Press the button for less than one second to activate the self-testing. Press for more than five seconds to turn OFF.
- 2. Battery Warning/Overload Indicator (Red LED): The LED flashes when the battery needs to be recharged and tested. The LED will illuminate when the unit is subjected to an overload condition. If the unit shuts down due to overload, the LED and alarm will continue for two minutes.
- ON Battery Indicator (Yellow LED): The LED illuminates when the UPS is supplying battery power to the loads.
- 4. Ac Input Normal Indicator (Green LED): The LED illuminates when the line input voltage is normal.
- 5. IP20-rated Input Screw Terminals (see table below)
- 6. IP20-rated Output Screw Terminals (see table below)

Screw	M3.0; Current rating = 30 A, Ac 300 V
Insulation Withstands Volts	Ac 2000 V min.
PCB Hole Diameter	1.8 mm, wire strip length = 8 mm
Wire Range	10–24 AWG
Screw Torque	5.5 lbin.

- 7. Input Circuit Breaker: Protection from ac overload and short circuit.
- Remote ON/OFF: The remote switch provides the same functions as the front panel switch including ON/OFF/Test functions with Green Mode enabled or disabled.

#### 4.2 Bottom Panel



- V Output: Output terminal providing 12 V power source to the optional relay card.
- 10. Remote: RS232 communication port; DB-9 connector.
- 11. Tel/Surge Protection: Data line surge protection for phones (UL497A).

#### 4.3 What's Included

The SDU UPS is shipped with the following items:

- User manual
- UPSMON software CD

**NOTE:** Monitoring/diagnostic software is included on the UPSMON CD. The software is compatible with Windows NT and Windows 2000 (including XP operating systems).

- UPSMON DB-9 serial cable
- RJ-11 cord
- Electrical shock warning label

#### 4.4 Accessories

- UPSMON-USB: RS232 to USB adapter cable
- RELAYCARD-SDU: Dry contact relay box
- SDU-PMBRK: Mounting brackets to secure the UPS to the wall, back of the panel or enclosure

#### 5.0 Installation Instructions


- Placement: Install the UPS in a protected area with adequate airflow and free
  of excessive dust. Do not operate the UPS outdoors.
- Connect to Utility: To power up the UPS, connect the ac input connector to the utility power.
- Charge the Battery: The UPS charges its battery whenever it is connected to utility power. For best results, charge the battery for four hours during initial use.
- **4. Connect the Loads:** Connect the loads to the output hardwire connector.
- 5. Apply the Electrical Shock Warning Label: Apply the electrical shock warning label to the panel, in a way that is clearly visible to the user.



## 6.0 Operating Instructions

- **1. Output Connector:** The output connector will provide protection from surges and power failures to the critical loads.
- 2. Switch ON Green Mode Enabled: After connecting the UPS to the utility power, press the ON button until you hear the first beep, then release the button immediately. The Green Mode is enabled, i.e. if a load less than forty watts (or no load) is connected and the UPS operates in the Backup Mode. The UPS will enter into the Green Mode status after three minutes of backup time; the green light will flash every three to five seconds and after a short period of time; and the unit will enter a "power save" status by shutting down to prevent deep discharge of the battery. To reactivate the unit, power the unit OFF then ON again or reapply utility power.
- 3. Switch ON Green Mode Disabled: After connecting the UPS to the utility power, press the ON button and keep pressing it until you hear two short beeps "Bi-Bip", then release the button immediately. The Green Mode is now disabled. Any kind of load, whether smaller than forty watts or larger, will not affect the normal operation of the UPS under Ac or Battery Mode.
- **4. Switch OFF:** To switch OFF the UPS, press and hold the Power ON/OFF/Test button until the "Ac Power Normal" LED or "ON Battery" LED turns OFF.

- 5. Self-test: Use the self-test to verify both the operation of the UPS and the condition of the battery. In normal utility power, push the Power ON/OFF/Test button for less than one second; the UPS will perform a self-test. During the self-test, the UPS runs in Backup Mode. If the UPS passes the self-test, it returns to "Ac Input Normal" operation.
- 6. Remote ON/OFF: To ensure the remote ON/OFF function, connect a remote push-button switch in series with 5–30 V dc voltage source to the ON/OFF terminal as shown below.



The remote switch provides the same functions as the front panel switch including ON/OFF/Test functions with Green Mode enabled or disabled. If the Green Mode is not needed, a remote toggle switch can be used.

## 7.0 Battery Overload Alarms

- 1. ON Battery (slow beeping): When in ON Battery Mode, the yellow LED illuminates and the UPS sounds an audible alarm. The alarm stops when the UPS returns to Ac Input Normal operation.
- 2. Low Battery (rapid beeping): In ON Battery Mode when the battery energy runs low, the UPS beeps rapidly until the UPS shuts down from battery exhaustion or returns to Ac Input Normal operation.
- 3. Overload (continuous alarm): When the UPS is overloaded (the connected loads exceed the maximum rated capacity), the UPS sounds a continuous alarm and LED to warn of an overload condition. Reduce the load to eliminate the overload.

## 8.0 PIN-Out Configuration for DB9 Connector

Female Connector PIN No.	RS-232 Signal	Open Collector Signal	
1			
2	TX		
3	RD	Remote shutdown*	
4	DTR (+12 V)		
5	GND	GND	
6		Ac failure	
7	RTS (-12 V)		
8		Battery low	
9	TX		

DTR = Data terminal ready

RTS = Request to send

RD = Transmitted data

GND = Signal Ground

TX = Received data

## 9.0 Battery Backup Times

	SDU 500, SDU 500-5	SDU 850, SDU 850-5
VA/Watts	500/300	850/510
Battery	YUASA NP7-12	YUASA REW45-12
Load Level	Backup Time (Minutes)	Backup Time (Minutes)
10%	130	80
20%	55	37
30%	36	20
40%	23	13
50%	18	10
60%	13	7
70%	10	5
80%	9	4
90%	6	3
100%	5	2.5

<sup>\*</sup>When a remote shutdown signal is applied for one second, the UPS will shut down in three minutes.

## 10.0 Troubleshooting

Problem	Probable Cause	Required Action
	UPS is OFF or the ON/OFF/Test button was not pushed for 1+ seconds	Press the ON/OFF/Test button for more than 2 seconds
UPS is not ON; LED will not light	Battery voltage is less than 10 V	Recharge the UPS for at least 4 hours. If the unit still does not start, check the input fuse.
	Other failure	Call SolaHD Technical Support
	Load is less than 20 W in Backup Mode	Normal condition
	Loose ac input power connection	Tighten the ac power connection
UDC is shown in Destruct Made	Circuit breaker trips	Reset the breaker
UPS is always in Backup Mode	Line voltage too high, too low, or blackout	Normal condition
	Other failure	Call SolaHD Technical Support
Dealum time is too short	Battery is not fully charged	Recharge the UPS for at least 4 hours
Backup time is too short	Other failure	Call SolaHD Technical Support
Continuous beep & LED overload indication	Overload condition	Remove the overload
Red LED is flashing	Battery failure	Recharge the UPS for at least 8 hours. Perform UPS self-test.



Do not attempt to open the UPS or replace the battery. Call SolaHD Technical Support for further instructions.

## 11.0 Storage

#### 11.1 Storage Conditions

Store the UPS covered and upright in a cool, dry location, with its battery fully charged. Before storing, charge the UPS for at least four hours. Remove any accessories in the accessory slot and disconnect any cables connected to the computer interface port to avoid unnecessary draining of the battery.

#### 11.2 Extended Storage

During extended storage in environments where the ambient temperature is -15 to +30  $^{\circ}$ C (+5 to +86  $^{\circ}$ F), charge the UPS battery every six months.

During extended storage in environments where the ambient temperature is +30 to +45 °C (+86 to +113 °F), charge the UPS battery every three months.

## 12.0 Specifications

December the co	Catalog Number				
Description	SDU 500	SDU 850	SDU 500-5	SDU 850-5	
INPUT			•		
Capacity VA/Watts	500/300	850/510	500/300	850/510	
Voltage (Single Phase)	120 V + 1	0%, -20%	230 V	+/ -20%	
Frequency		50 or 60 Hz, +/ -1	0% (auto-sensing)		
OUTPUT					
Valtage (on bettern)		Simulated	sine wave		
Voltage (on battery)	120 V	+/-5%	230 V	+/-5%	
Frequency (on battery)		50 or 60 Hz, +/-0	0.5% auto-sensing		
Transfer Time		<4 milli	seconds		
PROTECTION					
Unit Input	Ci	rcuit breaker for overload	and short circuit protecti	on	
Overload Protection	UPS automatic shutdov	vn if overload exceeds 10	5% of nominal at 20 s, 12	0% at 10 s, 130% at 3 s	
Short Circuit		UPS output cut	off immediately		
BATTERY					
Туре	Sealed, maintenance-free, lead acid batteries				
Typical Recharge Time (to 90% of full capacity)	8 hours				
Backup Time (at full load)	4 min.	2 min.	4 min.	2 min.	
ALARM	ALARM				
ON Battery	Slow beeping every 4 seconds				
Battery Low		Rapid beeping	g every second		
Overload		Continuous b	peeping sound		
ENVIRONMENT					
Ambient Operation	0–95%	humidity, non-condensin	g. 50°C up to 10,000 ft. (3	3000 m).	
Audible Noise		<40 dBA (1 m	from surface)		
WEIGHT & DIMENSI	ONS				
Net Weight, lb. (kg)	10.7 (4.7)	11.4 (5.0)	11.5 (5.2)	11.9 (5.4)	
H x W x D, in. (mm)		4.88 x 11.1 x 4.55	(124 x 281 x 116)		
SAFETY/APPROVAL	.S				
	UL 1778 C-UL Recognized* for industrial applications in accordance with UL 508A without derating. Overvoltage Category 3, Pollution Degree 3. FCC Part 15, Subpart B, Class A.			3-2, EN61000-3-3,	

<sup>\*</sup>For Conditions of Acceptability in accordance with UL 508A, see "13.0 Conditions for Safe Use of SDU 500 & 850".

### 13.0 Conditions for Safe Use of SDU 500 & 850

**NOTE:** Applicable for U.S. only.

Considerations shall be given to the following:

- **1.** The equipment shall be installed in compliance with the enclosure, mounting, spacing, casualty, and segregation requirements of the ultimate application.
- 2. The equipment has been judged on the basis of the required spacings for use in Overvoltage Category III and Pollution Degree 3 and in the Second Edition of the Standard for Uniterruptible Power Supply Equipment, UL 1778, par. 23 and table 23.1, which would cover the component itself if submitted for unrestricted listing.
- The suitability of grounding connection shall be determined in the end-use product.
- **4.** The equipment is provided with means for permanent mounting, the suitability of assembly shall be determined in the end-use product.
- 5. Equipment is considered acceptable for use in a maximum ambient of 50°C.
- **6.** The equipment inside live parts are energized from the battery supply even when the input ac power is disconnected.
- 7. For CNR investigation, total harmonic distortion of 44.8% and maximum single harmonic of 33.1%.
- 8. The equipment was investigated under 20 amperes branch circuit in accordance with the National Electrical Code, ANSI/NFPA 70, to reduce the risk of fire, connect only to a circuit provided with 20 amperes maximum branch circuit over current protection.
- 9. Use No. 18 AWG, 90°C copper wire and 9 lb.-in. Torque force when connecting to terminal block.
- **10.** Polarity Identification in UPS unit for filed wiring terminals: Provided with label adjacent to the unit supply connections. See below for details.

	Input			Output	
<b>=</b>	N	L	$\bigoplus$	N	L

 The following tests were additionally conducted at specified conditions as noted below, in accordance with the Standard for Industrial Control Equipment, UL 508A, 17th Edition.

Temperature Test: Models SDU 850 and SDU 500 were mounted in an enclosure (150% of the dimensions of the device, overall 420 by 180 by 160 mm), in accordance with par. 42.6 of UL 508A. The suitability usage of industrial control equipment shall be considered in end application.

Breakdown of Components Test: Model SDU 850 had been conducted through a 30-ampere non-time-delay fuse, in accordance with par. 57.5 of UL 508A.

12. The products, Models SDU 850 and SDU 500 were evaluated based on Pollution Degree 3 and Overvoltage Category III criteria and a minimum end use ambient of 40°C, so that these devices do not have to be derated when installed within an industrial control panel.

## 14.0 Product Registration & Warranty Information

#### 14.1 Product Registration

To register your product for updates and information on service and support:

- Visit the Technical Support section of our Web site at: http://www.solahd.com/support/registration.htm
- Click on the Product Registration link and fill in the form. This will register your product with SolaHD.

#### **14.2 Warranty Information**

Please see "Terms and Conditions of Sale".

## 1.0 Instrucciones importantes de seguridad

Este manual contiene instrucciones importantes de seguridad que deberán seguirse durante la instalación del Sistema de Energía Eléctrica Ininterrumpible (UPS). Por favor lea este manual completamente antes de intentar instalar u operar este UPS.

Lea todas las instrucciones de seguridad, instalación y operación antes de operar el UPS. Cumpla con todas las advertencias indicadas en la unidad y en este manual. Siga todas las instrucciones de operación y deuso.

Este equipo está diseñado para uso Industrial o Comercial. Este equipo puede ser instalado y operado por personas no capacitadas previamente para hacer estas funciones.

#### 1.1 Precauciones de seguridad—Advertencia

 Para evitar el riesgo de incendio o choque eléctrico, instale el UPS en una habitación con temperatura y humedad controladas, libre de contaminantes conductivos, humedad, líquidos inflamables, gases y sustancias corrosivas.



- Opere el UPS únicamente desde una fuente de suministro de CA debidamente conectada a tierra (unida a tierra).
- Para reducir el riesgo de choque eléctrico, no retire la cubierta, ya que la unidad no contiene piezas que el usuario puede reemplazar o reparar. Algunos de los componentes tienen energía eléctrica, aún cuando la energía de CA está desconectada. Para obtener servicio, póngase en contacto con un técnico calificado.

Aunque su UPS ha sido diseñado y fabricado para garantizar la seguridad personal del usuario, el uso indebido del mismo puede resultar en un choque eléctrico o incendio. Para garantizar su seguridad, por favor observe las siguientes normas:

- Apague el UPS y desconecte el suministro de energía de CA antes de limpiarlo.
   No utilice limpiadores líquidos o aerosol. Se recomienda utilizar un trapo seco para quitar el polvo de la superfi cie de su UPS.
- No instale ni opere su UPS en o cerca del agua.
- No coloque el UPS en un carro, soporte o mesa inestable.
- No coloque el UPS bajo la luz directa del sol o cerca de fuentes emisoras de calor.

- Para permitir una ventilación adecuada del UPS, no bloquee ni cubra los lados superior e inferior de la unidad.
- Nunca bloquee ni inserte ningún objeto en los orificios de ventilación u otras aberturas del UPS. Mantenga todas las aberturas de ventilación libre de acumulaciones de polvo que puedan restringir el fl ujo del aire.
- Siga todas las advertencias e instrucciones marcadas en el UPS. No intente darle servicio al UPS, ya que este no contiene ninguna pieza que usted pueda reparar o reemplazar. Refi era todas las reparaciones al personal de servicio técnico califi cado.
- No deseche la batería o las baterías en el fuego. La batería podría explotar.
- No abra ni dañe la batería. El electrolito derramado es peligroso para la piel y los ojos. Podría ser tóxico.

Si su UPS exhibe cualquiera de las siguientes condiciones, apague el UPS, desconecte el suministro de energía de CA y póngase en contacto con su distribuidor local, representante de SolaHD o Servicios Técnicos de SolaHD.

- Se ha derramado o vertido líquido en el UPS.
- · El cortacircuito se abre frecuentemente.
- El UPS no funciona de acuerdo con el manual del usuario.

#### 1.2 Condiciones de Uso

Su UPS le proporciona energía eléctrica acondicionada al equipo conectado. La carga máxima no deberá exceder la capacidad indicada en la etiqueta o placa del UPS. Si no está seguro, póngase en contacto con su distribuidor o SolaHD.

#### 2.0 Definición de advertencias



**Peligro:** Indica una situación de riesgo inminente que, si no se evita, causará lesiones graves o letales. Esta palabra de señal se utilizará sólo en las situaciones más extremas.



**Advertencia:** Indica una situación potencialmente riesgosa, que si no se evita, podría causar lesiones graves o letales.



**Precaución:** Indica una situación potencialmente riesgosa, que si no se evita, podría causar lesiones leves o moderadas. También se puede utilizar para indicar prácticas poco seguras.

## 3.0 Introducción

Felicitaciones por su elección de un Sistema de Energía Eléctrica Ininterrumpible (UPS) de la Serie SDU Sola. Éste proporciona energía eléctrica acondicionada a los equipos electrónicos sensibles.

La Serie SDU es un UPS compacto "Fuera de línea", montable en Riel DIN. El mismo le proporciona al equipo conectado una aproximación escalonada de alimentación eléctrica sinusoidal para simular la energía generada por la fuente pública.

La unidad SDU es un potente UPS controlado por microprocesador. La gama del voltaje de entrada es de un 80% a un 110%, una protección ideal para las cargas críticas conectadas. La recarga de la batería se realiza automáticamente cuando se conecta el suministro de energía de CA, no es necesario encender (poner en ON) el UPS. Cuando se corta la energía eléctrica, puede apagarse automáticamente el UPS si ninguna de las cargas conectadas está funcionando, para conservar la energía de la batería. La unidad SDU incluye una función de autocomprobación automática que verifi ca el funcionamiento del UPS y la batería.


Si se detecta que la batería ya no funciona, la unidad se pone en alarma y un indicador LED se ilumina.

NOTA: Este equipo ha sido sometido a prueba y se ha determinado que cumple con los límites para un dispositivo digital de Clase A, según la parte 15 de las Normas de la FCC. Estos límites están diseñados para proporcionar una protección razonable contra las interferencias dañinas en una instalación industrial. Este equipo utiliza, genera y puede emitir energía de radiofrecuencia y, si no se instala y se utiliza de acuerdo con las instrucciones, es posible que pueda causar interferencia dañina con las comunicaciones por radio. Sin embargo, no hay ninguna garantía de que la interferencia no se producirá en una instalación en particular. Si este equipo produce interferencia dañina en la recepción de las señales de radio o televisión, lo cual puede determinarse apagando y encendiendo el equipo, el usuario debe tratar de corregir la interferencia mediante una o más de las siguientes medidas:

- Vuelva a orientar o ubicar la antena de recepción.
- Aumente la separación entre el UPS y el receptor.
- Conecte el UPS en un circuito diferente al que esté conectado el receptor.
- Consulte con su distribuidor o un técnico especializado en radio/televisión para obtener ayuda.

## 4.0 Descripción de sistema

#### 4.1 Panel frontal




- 1. Botón "POWER ON/OFF/TEST" (Encendido/Apagado/Prueba): Presione el botón durante más de 1 segundo para encender el UPS. Presione el botón durante menos de 1 segundo para activar la autocomprobación del UPS. Presione el botón durante más de 5 segundos para apagar.
- 2. Indicador (LED ROJO) "BATTERY WARNING/OVERLOAD" (Advertencia de Batería/Sobrecarga): El LED destella cuando es necesario recargar y comprobar la batería del UPS. El LED se enciende cuando la unidad está en condición de sobrecarga. Si la unidad se apaga debido a una condición de sobrecarga, el LED y la alarma permanecerán activados durante 2 minutos.
- 3. Indicador (LED AMARILLO) "ON-BATTERY" (En Batería): El LED se enciendecuando el UPS suministra energía de la batería a las cargas.
- **4. Indicador (LED VERDE) "AC INPUT NORMAL" (Entrada de CA Normal):** El LED se enciende cuando el voltaje de entrada de línea es normal.
- 5. Terminales de entrada con tornillos de capacidad IP20 (vea la tabla abajo)
- 6. Terminales de salida con tornillos de capacidad IP20 (vea la tabla abajo)

Tornillo	M3.0, capacidad de corriente = 30 Amp CA 300V
Voltaje no disruptivo del aislamiento	CA 2000 V mín.
Diámetro de agujero PCB	1.8 mm, longitud de alambre pelado = 8 mm
Gama de tamaños de alambre	10 a 24 AWG
Par torsor para los tornillos	5.5 libras - pulgada

- 7. Cortacircuito de entrada: Protección contra sobrecargas de CA y cortocircuitos.
- 8. Encendido/Apagado Remoto: El interruptor remoto proporciona las mismas funciones que el interruptor en el panel frontal, incluyendo las funciones ON/ OFF/TEST con la modalidad verde habilitada o no habilitada.

#### 4.2 Panel inferior



- V Out (salida de voltaje): Terminal de salida que proporciona un suministro de energía de 12 voltios a la tarjeta opcional de relés.
- 10. Remoto: Puerto de comunicación RS-232 con conector DB9.
- **11. Protección contra sobretensiones en la línea de teléfono:** Protección contra sobretensiones para línea de datos telefónica (UL497A).

#### 4.3 Qué se incluye

El UPS SDU se envía con los siguientes artículos:

- Manual del usuario del SDU
- CD con el software UPSMON

**NOTA:** Junto con la unidad se suministran un CD UPSMON que incluye un software de monitoreo y diagnóstico. El programa es compatible con Windows NT y Windows 2000 (incluyendo el Protocolo XP).

- Cable serie UPSMON
- Cordón RJ-11
- Etiqueta de advertencia de descarga eléctrica

#### 4.4 Accesorios

- UPSMON-USB: Cable de adaptación de RS232 a USB
- RELAYCARD-SDU: Caja de relés de contacto seco
- SDU-PMBRK: Soportes de montaje para sujetar el UPS en la pared, detrás de un panel o en un recinto

#### 5.0 Instrucciones de instalación


- Ubicación: Instale el UPS en una zona protegida con un fl ujo de aire adecuado y libre de polvo excesivo. No opere el UPS en el exterior.
- 2. Conecte el UPS a la fuente eléctrica pública: Acople el conector de entrada de CA a la fuente de energía eléctrica pública para energizar el UPS.
- 3. Cargue la batería: El UPS recarga su batería siempre que está conectado a la fuente de energía pública. Para obtener los mejores resultados, cargue la batería durante 4 horas en el uso inicial de la unidad.
- 4. Conecte las cargas: Acople las cargas al conector cableado de salida.
- 5. Aplicar la etiqueta de advertencia de descarga eléctrica: Aplicar la etiqueta de advertencia de descarga eléctrica al grupo de una manera que sea claramente visible para el usuario.



## 6.0 Instrucciones de operación

- Conector de salida: El Conector de salida proporcionará protección contra sobretensiones e interrupciones del suministro eléctrico a las cargas críticas suyas.
- 2. Encendido con el 'Modo verde' habilitado: Luego de conectar el UPS (Sistema de Energía Eléctrica Ininterrumpible) al suministro de energía pública, presione el botón de encendido (ON) hasta que escuche el primer pitido después de transcurridos menos de 3 segundos, y luego suéltelo de inmediato. El modo Verde se encuentra habilitado, por ejemplo, si una carga inferior a 40 vatios (o ninguna carga) está conectada y el UPS funciona en el modo de respaldo, el UPS pasará al estado de modo verde luego de transcurridos 3 minutos del tiempo de respaldo; la luz verde destellará cada 3 a 5 segundos y tras un corto período de tiempo, la unidad pasará al modo de 'ahorro de energía' y se desactivará para impedir que la batería se descargue demasiado. Para reactivar la unidad, apague y encienda la unidad, o reconecte el suministro de energía pública al UPS y la energía se encenderá nuevamente.

- 3. Encendido con el 'Modo verde' inhabilitado: Luego de conectar el UPS (Sistema de Energía Eléctrica Ininterrumpible) al suministro de energía pública, presione el botón de encendido (ON) y continúe presionándolo hasta que escuche dos pitidos cortos; luego suéltelo de inmediato y el modo verde quedará inhabilitado. Ningún tipo de carga, ya sea menor o mayor que 40 vatios, afectará de manera alguna el funcionamiento normal del UPS bajo el modo batería o CA.
- 4. Apagado: Para apagar el UPS, presione y no suelte el botón Power ON/OFF/ Test (Encendido / Apagado /Prueba) hasta que se apague el LED "AC INPUT NORMAL" (Entrada de CA Normal) o el LED "ON BATTERY" (En Batería).
- 5. Autocomprobación: Utilice la autocomprobación para verifi car el funcionamiento del UPS y la condición de la batería. Con el suministro de energía pública, presione el botón Power ON/OFF/Test (Encendido/Apagado/Prueba) durante menos de 1 segundo y el UPS realizará la función de autocomprobación. Durante la autocomprobación, el UPS funciona en la modalidad de respaldo (en batería). Si el UPS pasa la autocomprobación, éste regresa al funcionamiento de Entrada de CA Normal ("AC INPUT NORMAL").
- 6. Encendido/Apagado Remoto: Para asegurar la función CON./DESC. alejada, conecte un interruptor de botón alejado en serie con fuente del voltaje de 5~30 VDC con el terminal con./desc. según lo demostrado en la figura siguiente.



El interruptor remoto proporciona las mismas funciones que el interruptor en el panel frontal, incluyendo las funciones ON/OFF/TEST con la modalidad verde habilitada o no habilitada. Si no necesita el modo verde, se puede usar uninterruptor de palanca.

## 7.0 Tiempo de autonomía de la batería (Alarma)

- 1. "EN BATERÍA" (pitidos lentos): Cuando la unidad está en la modalidad EN BATERÍA, el LED AMARILLO se enciende y el UPS emite una alarma audible. La alarma cesa cuando el UPS regresa al funcionamiento con ENTRADA DE CA NORMAL (AC INPUT NORMAL).
- 2. "BATERÍA BAJA" (pitidos rápidos): En la modalidad EN BATERÍA, cuando la carga de energía de la batería está baja, el UPS emite pitidos rápidos hasta que el UPS se apaga porque la batería ya no tiene carga o el UPS regresa al funcionamiento con ENTRADA DE CA NORMAL (AC INPUT NORMAL).
- 3. "SOBRECARGA" (alarma continua): Cuando el UPS está en condición de sobrecarga (las cargas conectadas ex-ceden la capacidad nominal máxima de la unidad), el UPS emite un sonido de alarma continuo y un LED se enciende y permanece encendido para advertir sobre la condición de sobrecarga. Disminuya la carga para eliminar la condición de sobrecarga.

# 8.0 Configuración de disposición de las clavijas del conector DB9

Número de clavija del conector hembra DB9	Señal RS-232	Señal de colector abierto	
1			
2	TX		
3	RD	Desactivación Remota*	
4	DTR (+12 V)		
5	GND	GND	
6		Fallo de CA	
7	RTS (-12 V)		
8		Batería Baja	
9	TX		

DTR = Terminal de datos listo

RTS = Petición para enviar

RD = Datos transmitidos

GND = Señal de Tierra

TX = Datos recibidos

<sup>\*</sup>Cuando se aplica la señal de desactivación remota durante 1 segundo, el UPS se desactivará (o apagará) al cabo de 3 minutos.

## 9.0 Tiempo de reserva de la batería

	SDU 500, SDU 500-5	SDU 850, SDU 850-5	
VA/Watts	500/300 850/510		
Batería	YUASA NP7-12	YUASA REW45-12	
Nivel de la carga	Tiempo de reserva (Minutos)	Tiempo de reserva (Minutos)	
10%	130	80	
20%	55	37	
30%	36	20	
40%	23	13	
50%	18	10	
60%	13	7	
70%	10	5	
80%	9	4	
90%	6	3	
100%	5	2.5	

#### 10.0 Almacenamiento

#### 10.1 Condiciones de almacenamiento

Almacene el UPS cubierto y en posición vertical en un lugar seco y frío, con su batería plenamente cargada. Antes de almacenarlo, cargue el UPS durante 4 horas como mínimo. Retire todo accesorio de la ranura de accesorios y desconecte todo cable que esté conectado al puerto interfaz para computadora, a fi n de impedir el drenaje innecesario de la batería.

#### 10.2 Almacenamiento prolongado

Durante los almacenamientos prolongados en los entornos donde la temperatura ambiente es de -15 a +30°C (+5 a +86°F), cargue la batería del UPS cada 6 meses. Durante los almacenamientos prolongados en los entornos donde la temperatura ambiente es de +30 +45°C (+86 +113°F), cargue la batería del UPS cada 3 meses.

## 11.0 Solución de problemas

Problema	Causa probable	Acción a tomar	
	El UPS está apagado o no se ha presionado el botón On/Off/Test (Encendido/Apagado/Prueba) la cantidad de tiempo suficiente	Presione el botón On/Off/Test (Encendido/Apagado/Prueba) durante más de 2 segundos	
El UPS no enciende; el LED está apagado	Voltaje de batería inferior a 10V	Recargue el UPS durante 4 horas como mínimo. Si la unidad no en- ciende, verifi que el fusible de entrada	
	Otra avería	Llame a Servicios Técnicos	
	Carga inferior a 20 vatios en modali- dad de respaldo (en batería)	Condición normal	
El UPS permanece en la modalidad de respaldo (en batería)	Conexión de entrada de energía de CA suelta o floja	Apriete la conexión de energía de CA	
	El cortacircuito se dispara	Reponga el cortacircuito	
	Voltaje de línea demasiado alto, de- masiado bajo o se produjo un apagón	Condición normal	
	Otra avería	Llame a Servicios Técnicos	
Tiempo de respaldo demasiado corto	La batería no está totalmente cargada	Recargue el UPS durante 4 horas como mínimo	
	Otra avería	Llame a Servicios Técnicos	
Pitido continuo y se enciende el LED de indicación de sobrecarga	Condición de sobrecarga	Elimine la sobrecarga	
LED rojo intermitente	Fallo de la batería	Recargue el UPS durante 8 horas como mínimo, luego realice la auto- comprobación del UPS	



PRECAUCIÓN

No intente abrir el UPS ni reemplazar la batería. Llame a Servicios Técnicos para obtener más explicaciones.

## 12.0 Especificaciones

<b>.</b> ,	Modelo			
Descripción	SDU 500	SDU 850	SDU 500-5	SDU 850-5
ENTRADA		•	•	
Capacidad VA/Vatios	500/300	850/510	500/300	850/510
Voltaje (Monofásico)	120 V + 1	0%, -20%	230 V	+/-20%
Frecuencia		50 ó 60Hz +/-10°	% (autodetección)	
SALIDA				
	Onda sinusoidal simulada			
Voltaje (en batería)	120 V	+/-5%	230 V	+/-5%
Frecuencia (en batería)		50 ó 60Hz: +/-0.	5% autodetección	
Tiempo de transferencia			egundos	
PROTECCIÓN	ļ.			
Entrada de la unidad	Corta	circuito para proteger con	ntra sobrecargas y cortocir	cuitos
Protección contra	Cortacircuito para proteger contra sobrecargas y cortocircuitos			
sobrecargas	El UPS se apaga automáticamente si la sobrecarga excede el 105% del valor nominal a 20 segundos, 120% a 10 segundos, 130% a 3 segundos			
Cortocircuito		La salida del UPS se	corta automáticamente	
BATERÍA				
Tipo	Baterías	selladas de plomo y ácid	lo que no requieren manto	enimiento
Tiempo de recarga típico (hasta el 90% de plena capacidad)	8 horas			
Tiempo de autonomía en minutos a plena carga	4 min.	2 min.	4 min.	2 min.
ALARMA		•	•	
En batería		Pitidos lentos a	cada 4 segundos	
Batería baja	Pitidos rápidos cada segundo			
Sobrecarga		Sonido de pitido continuo		
AMBIENTE				
Operación ambiental	0-95% de humedad sin condensación; 50°C hasta 10,000 pies (3000 m)			
Ruido audible		<40 dBA (a 1 met	ro de la superficie)	
PESO/DIMENSIONES	S			
Peso neto, lb. (kg)	10.7 (4.7)	11.4 (5.0)	11.5 (5.2)	11.9 (5.4)
Altura x Anchura x Profundidad, pulg. (mm)	4.88 x 11.1 x 4.55 (124 x 281 x 116)			
SEGURIDAD/APROE	BACIONES		,	
	Clasificación UL 1778 C-UL, reconocida para aplicaciones industriales de acuerdo con UL508 sin ninguna corrección. Categoría 3 de sobrevoltaje, grado 3 de contaminación. Parte 15, Subparte B, Clase A de la FCC.		Clasificación CE; LVD: EN62040-1-1;EMC: EN50091-2, EN61000-3-2, EN61000-3-3, IEC801-2, IEC801-3, IEC801-4, IEC1000-2-2	

## 13.0 Registro del producto y información sobre la garantía

#### 13.1 Registro del producto

A fin de registrar su producto para obtener actualizaciones e información sobre servicio y apoyo:

- Visite la sección Apoyo Técnico o nuestro sitio Web en: http://www.solahd.com/support/registration.htm
- Haga clic en el enlace de Registro de Productos y complete el formulario. Así, su producto quedará registrado con SolaHD. Vous pourrez ainsi enregistrer votre produit chez SolaHD.

#### 13.2 Información sobre la garantía

Sírvase consultar "Términos y Condiciones".

## 1.0 Instructions importantes sur la sécurité

Ce manuel contient des instructions importantes sur la sécurité, qui doivent être respectées lors de l'installation de l'UPS. Veuillez lire attentivement ce manuel avant de commencer à installer ou utiliser cet UPS.

Lire toutes les instructions sur la sécurité, l'installation et le fonctionnement avant d'utiliser l'UPS. Respecter tous les avertissements indiqués sur l'appareil et dans ce manuel. Suivre toutes les instructions d'utilisation et celles destinées à l'utilisateur.

Cet équipement est conçu pour un usage industriel ou commercial. Cet équipement peut être installé et utilisé par des personnes n'ayant reçu aucune formation préalable.

#### 1.1 Mesures de sécurité—avertissements

 Afin d'éviter les risques d'incendie ou de décharge électrique, installer l'UPS dans une enceinte dont la température et l'humidité sont contrôlées, exempte de contaminants conducteurs, d'humidité, de liquides et gaz infl ammables et de substances corrosives.



- Utiliser l'UPS seulement à partir d'une source d'alimentation en courant alternatif correctement mise à la terre.
- Afin de réduire les risques de décharge électrique, ne pas enlever le couvercle, car aucune pièce réparable par l'utilisateur ne se trouve à l'intérieur. Certains composants sont sous tension, même lorsque l'alimentation c.a est coupée.
   Pour obtenir du service, contacter un technicien qualifié.

Bien que l'UPS ait été conçu et fabriqué pour assurer la sécurité personnelle, une utilisation incorrecte peut entraîner une décharge électrique ou un incendie. Afin d'assurer la sécurité, observer les règles suivantes :

- Mettre l'UPS hors tension et couper l'alimentation c.a avant de le nettoyer. Ne pas utiliser de nettoyants liquides ou aérosols. On recommande d'utiliser un chiffon sec pour enlever la poussière de la surface de l'UPS.
- Ne pas installer ou utiliser l'UPS dans ou à proximité d'un plan d'eau.
- Ne pas placer l'UPS sur un chariot, un support ou une table instable.
- Ne pas placer l'UPS sous les rayons directs du soleil ou à proximité d'une source de chaleur.

- Pour assurer une ventilation adéquate de l'UPS, ne pas bloquer ou recouvrir le dessus et les côtés inférieurs de l'appareil.
- Ne jamais bloquer ou insérer un quelconque objet dans les trous de ventilation ou dans les autres ouvertures de l'UPS. Faire en sorte qu'aucune poussière susceptible de restreindre le débit d'air ne s'accumule sur aucun des évents.
- Suivre tous les avertissements et les instructions apposés sur l'UPS. Ne pas tenter de réparer l'UPS, aucune pièce réparable par l'utilisateur ne se trouve à l'intérieur. Consulter du personnel qualifi é pour effectuer des réparations.
- Ne pas jeter la ou les batteries dans un feu. La batterie pourrait exploser.
- Ne pas ouvrir ou endommager la batterie. Une fuite d'électrolyte est nocive pour la peau et les yeux. Ca peut être toxique.

Si votre UPS présente une des anomalies suivantes, mettre l'UPS hors tension, couper l'alimentation c.a. et contacter votre distributeur local, un représentant SolaHD ou les services techniques de SolaHD.

- En cas de liquide versé sur l'UPS.
- Le disjoncteur déclenche fréquemment.
- L'UPS ne fonctionne pas suivant les indications du manuel de l'utilisateur.

#### 1.2 Conditions d'utilisation

Votre UPS fournit une l'alimentation conditionnée à l'équipement raccordé. La charge maximale ne doit pas excéder celle indiquée sur l'étiquette. En cas de doute, contacter votre distributeur ou SolaHD.

#### 2.0 Définition des avertissements



**Danger:** Indique une situation éminemment dangereuse qui, si elle n'est pas évitée, peut causer la mort ou des blessures graves. Ce signal n'est utilisé que pour les situations les plus dangereuses.



**Avertissement:** Indique une situation potentiellement dangereuse qui, si elle n'est pas évitée, peut causer la mort ou des blessures graves.



Attention: Indique une situation potentiellement dangereuse qui, si elle n'est pas évitée, peut causer des blessures légères ou modérées. Elle peut aussi être utilisée pour mettre en garde contre les pratiques non sécuritaires.

#### 3.0 Introduction

Félicitations pour avoir choisi l'UPS de Sola, série SDU. Il assure une l'alimentation conditionnée aux l'équipements électroniques sensibles.

L'UPS de la série SDU est compact, « autonome », montable sur rail DIN. Il fournit à l'équipement raccordé une approximation par étape de puissance d'ondes sinusoïdales pour simuler la puissance générée par le fournisseur d'électricité.


Le SDU est un UPS puissant commandé par microprocesseur. La plage de tension d'entrée se situe entre 80 % et 110 %, une protection idéale pour les charges critiques raccordées. La recharge de la batterie est automatique lorsque l'alimentation c.a. est appliquée; aucun besoin de mettre l'UPS sous tension. En cas de panne de courant, l'UPS peut être mis HORS TENSION automatiquement si aucune des charges raccordées ne fonctionne, afi n d'économiser l'énergie de la batterie. Le SDU inclut une fonction d'auto-vérifi cation du fonctionnement de l'UPS et de la batterie. Si la batterie n'est plus utile, l'appareil déclenche une alarme et la DÉL s'allume.

**REMARQUE**: Cet équipement a été mis à l'essai et déclaré conforme aux limites prévues pour un appareil numérique de classe A, conformément à la partie 15 du règlement de la FCC. Ces limites ont pour but d'assurer une protection raisonnable contre une interférence nuisible dans une installation résidentielle. Cet équipement utilise, génère et peut émettre de l'énergie en radiofréquence et, s'il n'est pas installé et utilisé conformé-ment aux directives, il peut causer un brouillage nuisible dans les communications radio. Cependant, il est impossible de garantir qu'aucune interférence ne se produira dans une installation particulière. Si cet équipement cause un brouillage de la réception de radio ou de télévision (que vous pouvez déterminer en éteignant puis en rallumant l'appareil), l'utilisateur est prié d'essayer d'éviter le brouillage au moyen de l'une ou de plusieurs des mesures suivantes :

- Réorienter ou déplacer l'antenne de réception.
- Éloigner davantage l'UPS du récepteur.
- Raccorder l'UPS à un circuit différent de celui du récepteur.
- Consulter le concessionnaire ou un technicien en radio / télévision qualifié pour obtenir de l'aide.

## 4.0 Description du système

#### 4.1 Panneau avant




- 1. Bouton « POWER ON/OFF/TEST » : Appuyer sur le bouton pendant plus d'une (1) seconde pour mettre l'UPS sous tension. Appuyer sur le bouton pendant moins d'une seconde pour activer l'auto-vérification de l'UPS. Appuyerpendant plus de 5 secondes pour mettre hors tension.
- 2. Voyant « BATTERYWARNING / OVERLOAD » (DÉL ROUGE) : La DÉLclignote lorsque la batterie de l'UPS doit être rechargée et vérifiée. La DÉL s'allume lorsque l'appareil est en surcharge. Si l'appareil s'éteint suite à une surcharge, la DÉL et l'alarme sont activées pendant 2 minutes.
- 3. Voyant « ON BATTERY » (DÉL JAUNE) : La DÉL s'illumine lorsque l'UPS alimente les charges en courant de la batterie.
- **4. Voyant «AC INPUT NORMAL » (DÉL VERTE) :** La DÉL s'allume lorsque la tension d'entrée de ligne est normale.
- 5. Bornes à vis d'entrée classifiées IP-20 (voir le tableau ci-dessous)
- 6. Bornes à vis de sortie classifiées IP-20 (voir le tableau ci-dessous)

Vis	M3.0, courant nominal = 30A c.a. 300 V
L'isolation résiste à la tension	c.a. 2000 V min
Diamètre du trou PCB	1,8 mm, longueur de dénudage de câble = 8 mm
Calibre du fil	10 ~ 24AWG
Couple de serrage des vis	5,5 lb - po

- Disjoncteur du circuit d'entrée : Protection contre une surcharge de c.a. et des courts-circuits.
- **8. Commande à distance marche/arrêt :** La commande à distance marche/ arrêt offre les mêmes fonctions que L'interrupteur marche/arrêt sur le panneau.

#### 4.2 Panneau inférieur



- Sortie V : Borne de sortie fournissant une source d'alimentation de 12 V à la carte de relais en option.
- 10. Distant: Port de communication RS 232, connecteur DB9.
- **11. Protection contre Téléphone/surtension :** Protection contre la surtension de ligne de données pour téléphone (UL497A).

#### 4.3 Ce qui est inclus

L'UPS SDU est expédié avec les articles suivants :

- Manuel utilisateur du SDU
- CD delogiciel UPSMON

**REMARQUE**: Le logiciel de surveillance / diagnostic est inclus sur le CD UPSMON. Le programme est compatible avec Windows NT et Windows 2000, incluant le protocole XP.

- Câble série UPSMON DB-9
- Cordon RJ-11
- Etiquette indiquant Choc électrique de mise en garde

#### 4.4 Accessoires

- UPSMON-USB : RS232 à câble adaptateur USB
- RELAYCARD-SDU: Boîte à relais avec contact sec
- SDU-PMBRK : Supports de montage pour fixer solidement l'UPS à un mur, à l'arrière d'un panneau ou dans une enceinte

#### 5.0 Instructions d'installation


- Placement: Installer l'UPS dans une zone protégée, avec une circulation d'air adéquate et exempte de poussière excessive. Ne pas utiliser l'UPS à l'extérieur.
- Branchement à la source d'alimentation électrique : Brancher le connecteur d'entrée de c.a. au secteur pour mettre l'UPS sous tension.
- 3. Recharge de la batterie : L'UPS recharge sa batterie dès qu'il est branché au secteur. Pour obtenir de meilleurs résultats, recharger la batterie pendant 4 heures avant son utilisation initiale.
- Raccordement des charges : Raccorder les charges au connecteur câblé de sortie.
- 5. Appliquer l'étiquette indiquant la mise en garde contre le choc électrique : Appliquer l'étiquette indiquant la mise en garde contre le choc électrique sur le panneau de façon à être clairement visible à l'utilisateur.



#### 6.0 Instructions d'utilisation

- Connecteur de sortie: Le connecteur de sortie protège vos charges critiques contre les surtensions et les pannes de courant.
- 2. Mise en marche avec le « Mode vert » activé : Après avoir connecté l'UPS à l'alimentation secteur, appuyer sur le bouton de mise en marche « ON » jusqu'à ce que le premier bip se fasse entendre après moins de trois secondes, puis relâcher immédiatement le bouton. Le mode vert est activé, c.-à-d. que si une charge inférieure à 40 watts (ou aucune charge) est connectée et que l'UPS fonctionne en mode de secours; l'UPS passe en mode vert après avoir été trois minutes en mode de secours; le voyant vert clignote à toutes les trois ou cinq secondes, puis, après une brève période, passe en mode « économie d'énergie » en s'éteignant pour éviter une décharge excessive de la batterie. Pour réactiver l'appareil, le mettre hors tension puis sous tension ou remettre l'alimentation secteur vers l'appareil après que l'alimentation secteur soit revenue.

- 3. Mise en marche avec le « Mode vert » désactivé : Après avoir connecté l'UPS à l'alimentation secteur, appuyer sur le bouton de mise en marche « ON » jusqu'à ce que deux bi-bip courts se fassent entendre, puis relâcher immédiatement le bouton; le mode vert est désactivé. Toute charge, qu'elle soit inférieure à 40 watts ou plus, ne modifiera pas le fonctionnement normal de l'UPS en mode c.a. ou de batterie.
- **4. Mise hors tension :** Pour mettre l'UPS hors tension, maintenir enfoncé le bouton POWER ON /OFF / TEST, jusqu'à ce que la DÉL « AC POWER NORMAL » ou « ON BATTERY » s'éteigne.
- 5. Auto-vérification: Utiliser l'auto-vérification pour contrôler le fonctionnement de l'UPS et l'état de la batterie. Si l'alimentation secteur est normale, appuyer sur le bouton POWER ON / OFF / TEST pendant moins d'une (1) seconde et l'UPS exécute une autovérification. Pendant l'auto-vérification, l'UPS fonctionne en mode de secours. Si l'UPS réussit l'auto-vérification, elle reprend son mode de fonctionnement « AC INPUT NORMAL ».
- 6. Commande à distance marche/arrêt : Pour assurer la fonction commande a distance marche/arrêt, connecter un interrupteur a bouton poussoir en série avec une source de tension continue 5~30Vdc au bornes « On/Off » comme indiqué sur la figure suivante :



La commande à distance marche/arrêt offre les mêmes fonctions que L'interrupteur marche/arrêt sur le panneau. Si le mode vert n'est pas nécessaire, un interrupteur à bascule marche/arrêt peut être utilisé au lieu de l'interrupteur à bouton poussoir.

#### 7.0 Alarmes de la batterie de secours

- 1.« ON BATTERY » (bip lent): Lorsqu'en mode ON BATTERY, la DÉL JAUNE s'allume et l'UPS émet une alarme audible. L'alarme arrête lorsque l'UPS retourne au mode de fonc-tionnementAC INPUT NORMAL.
- 2.« LOW BATTERY » (bip rapide) : En mode ONBATTERY,lorsque l'énergie de la batterie faiblit,l'UPS émet un bip rapide jusqu'à ce que l'UPS arrête de fonctionner en raison de l'épuisement de la batterie ou qu'il retourne au mode de fonctionnementAC INPUT NORMAL.
- 3.« OVERLOAD » (alarme continue) : Lorsque l'UPS est surchargé (les charges raccordées excèdent la capacité nominale maximale), l'UPS émet un son d'alarme continu et la DÉL indique une condition de surcharge. Réduire la charge pour éliminer la surcharge.

# 8.0 Configuration des broches de sortie du connecteur DB9

Connecteur UPS DB9 femelle, broche no	Signal RS-232	Signal de collecteur ouvert		
1				
2	TT			
3	RD	Coupure à distance*		
4	DTR (+12 V)			
5	TERRE	TERRE		
6		Défaillance c.a.		
7	RTS (-12 V)			
8		Batterie faible		
9	TT			

DTR = Terminal prêt

RTS = Demande d'émission

RD = Données transmises

TERRE = Retour commun du signal

TT = Données reçues

\*Cuando se aplica la señal de desactivación remota durante 1 segundo, el UPS se desactivará (o apagará) al cabo de 3 minutos.

## 9.0 Temps de secours de batterie

	SDU 500, SDU 500-5	SDU 850, SDU 850-5		
VA/Watts	500/300	850/510		
Batterie	YUASA NP7-12	YUASA REW45-12		
Niveau de charge	Temps de secours (Minutes)	Temps de secours (Minutes)		
10%	130	80		
20%	55	37		
30%	36	20		
40%	23	13		
50%	18	10		
60%	13	7		
70%	10	5		
80%	9	4		
90%	6	3		
100%	5	2.5		

## 10.0 Entreposage

#### 10.1 Conditions d'entreposage

Entreposer l'UPS en le recouvrant, en le plaçant en position verticale dans un endroit frais et sec, avec la batterie à pleine charge. Avant d'entreposer, charger l'UPS pendant au moins 4 heures. Enlever tous les accessoires de la fente aux accessoires et débrancher tous les câbles connectés au port de l'interface ordinateur, afi n d'éviter une décharge inutile de la batterie.

#### 10.2 Entreposage de longue durée

Lors d'un entreposage prolongé dans un environnement où la température ambiante est de -15 à +30 °C (+5 à +86 °F), recharger la batterie tous les 6 mois.

Lors d'un entreposage prolongé dans un environnement où la température ambiante est de +30 à +45 °C (+86 à +113 °F), recharger la batterie tous les 3 mois.

# 11.0 Dépannage

Probléme	Cause Probable	Action Corrective
	L'UPS est hors tension ou le bouton ON / OFF / TEST n'a pas été enfoncé suffi samment longtemps	Appuyer sur POWER / ON / OFF / TEST pendant plus de 2 secondes
UPS hors tension, la DÉL ne s'allume pas	La tension de la batterie est inférieure à 10 V	Recharger l'UPS pendant au moins 4 heures. Si l'appareil ne se met toujours pas en marche, vérifi er le fusible d'entrée.
	Autre défaillance	Appeler les services techniques
	La charge est inférieure à 20 W en mode de secours	Condition normale
	Desserrer la connexion de l'alimentation d'entrée de c.a.	Resserrer la connexion d'alimentation c.a.
L'UPS est toujours en mode de	Déclenchement du disjoncteur	Réenclencher le disjoncteur
secours	La tension de ligne est trop élevée, trop faible ou en panne	Condition normale
	Autre défaillance	Appeler les services techniques
Temps de fonctionnement en secours trop court	La batterie n'est pas complètement chargée	Recharger l'UPS pendant au moins 4 heures
Secours trop court	Autre défaillance	Appeler le service technique
Bip continu et indication de DÉL de surcharge	Condition de surcharge	Éliminer la surcharge
La DÉL rouge clignote	Défaillance de la batterie	Recharger l'UPS pendant au moins 8 heures, effectuer l'auto-vérifi cation de l'UPS.



Ne pas essayer d'ouvrir l'UPS ou de remplacer la batterie. Appeler les servic-es techniques pour obtenir des explications supplémentaires.

# 12.0 Spécifications

		Мо	dèle								
Description	SDU 500	SDU 850	SDU 500-5	SDU 850-5							
ENTRÉE		•									
Capacité V A / Watts	500/300	850/510	500/300	850/510							
Tension (Monophasé)	120 V + 1	0%, -20%	230 V -	+/-20%							
Fréquence		50 ou 60 Hz +/-10	) % (auto-détection)								
SORTIE											
		Onde sinus	oïdale simulée								
Tension (sur batterie)	120 V	+/-5%	230 V	+/-5%							
Fréquence (sur batterie)	-	50 ou 60 Hz. +/-0	),5% auto-détection								
Temps de transfert			isecondes								
PROTECTION											
Entrée de l'appareil	Diciono	etour protógoant contro la	es surcharges et les courts	circuite							
Protection contre les surcharges			ge dépasse 105 % de la ch econdes, 130 % à 3 secon								
Court-circuit		La sortie UPS est co	oupée immédiatement								
BATTERIE											
Type	e Accumulateurs au plomb, sans entretien et hermétiques										
Temps typique de recharge (à 90 % de la pleine charge)		8 h	eures								
Durée en utilisation secours – minutes à pleine charge	4 min.	2 min.	4 min.	2 min.							
ALARME											
Sur la batterie		Bip lent toutes	s les 4 secondes								
Batterie faible			naque seconde								
Surcharge		Bip	continu								
ENVIRONNEMENT	1										
Fonctionnement à température ambiante	0 à 95 % d'	humidité, sans condensa	ation50 °C jusqu'à 3000 m	n (10 000 pi)							
Bruit audible		< 40 dBA (1 mè	etre de la surface)								
POIDS / DIMENSION	S										
Poids net en kg (livres)	4,7 (10,7)	5,0 (11,4)	5,2 (11,5)	5,4 (11,9)							
H x L x P, mm (po)		124 x 281 x 116	(4,88 x 11,1 x 4,55)								
SÉCURITÉ / AUTORI	SATIONS										
	Reconnu UL 1778 C-UI industrielles, conformér déclassement. Surtensi degré de pollution : 3. F partie B, classe A.	040-1-1;EMC: 3-2, EN61000-3-3, C801-4, IEC1000-2-2									

# 13.0 Enregistrement du produit et information sur la garantie

#### 13.1 Enregistrement du produit

Pour enregistrer votre produit afin de recevoir des mises à jour et de l'information sur le service et le soutien :

- Visiter la section du Soutien technique sur notre site Web au : http://www.solahd.com/support/registration.htm
- Cliquer sur le lien d'enregistrement du produit et remplir le formulaire. Vous pourrez ainsi enregistrer votre produit chez SolaHD.

#### 13.2 Informations sur la garantie

Veuillez voir le « Termes et conditions générales de Sale » .



Technical Support U.S.: (800) 377-4384 International: (847) 268-6000 E-mail: www.solahd.com

Servicio Técnico EE.UU. (800) 377-4384 Internacional: (847) 268-6000 Correo electrónico: www.solahd.com

> Assistance technique États-Unis: (800) 377-4384 International: (847) 268-6000 Courriel: www.solahd.com



# Body Ported Metal Seal/Rubber Seal Series VQ

# A variety of product groups meet all FA needs.

Flip type

- Flip type demonstrates space-saving effect.
- Cassette type enables flexible, speedy station increasing/decreasing.

Thin compact design with large flow capacity

(Flip type)

VQC

SQ

VQ0

VQ4

VQ5

**VQZ** 


VQD

	Manifold pitch (mm)	Flow cha	0 11 1	
Model		Metal seal	Rubber seal	Cylinder size
		C [dm³/(s·bar)]	C [dm³/(s·bar)]	Size
VQ0000	10.5	0.50	0.59	Up to ø40
<b>VQ1000</b> 11		0.84	1.0	Up to ø50
VQ2000	16	2.3	2.7	Up to ø80

<sup>\*</sup> Flow characteristics:  $4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{R1/R2)}$ 



**VQ2000** 



A variety of options

# Cassette type VQ1000

# Unprecedented high speed response and long service life


		g							
(Metal seal,	Single, With in	dicator light/surge voltage suppressor)							
VQ0000	10 ms	7							
VQ1000	10 ms	<ul> <li>200 million cycles</li> </ul>							
VQ2000	20 ms								
Dispersion accuracy +2 ms									

# Innovative mounting methods

A valve can be changed without entirely disassembling the manifold.

Built-in One-touch fittings for easier piping.

# A variety of common wiring methods are standardized.






# **Valve Specifications**

					So	nic	Type of actuation Voltage			Δ.	Electrical entry				Manual override						
					condu	ctance:					_										
					C [dm <sup>3</sup> ] $ \begin{cases} 4/2 - \\ (A/B \rightarrow \end{cases} $		()	Double	Closed center	Exhaust center	Pressure center	12 V 24 V DC	100 V 110 V AC	200 V 220 V AC	Plug-in	Grommet	plug connector	M plug connector	ol required	Locking type	(Manual)
					Double Single	3 position Closed center			Close	Exhau	Pressu		Hz )	(50/60) Hz			L plug c	M plug c	Push type, Tool required	Poc	Locking type (Manual)
	Plug-in	Series VQ1000	VQ1□30	0.84	0.73	•	<b>6</b>	•	•		•	•		•						•	
	PI	P. 2-4-8	Metal seal	VQ1□31	1.0	0.84		Latching					P	2-4-	10						
		Series	Rubber seal	VQ0□40	0.50	0.36									10	<u>۲</u>					
		P. 2-4-30	Metal seal	VQ0□41	0.59	0.42		Latching (					D	2-4-	36	Single/ 3 position only					
orted		Series VQ1000 P. 2-4-30	Rubber seal	VQ1□40	0.84	0.73		•	•		•				<u> </u>	• ×			•		
<b>Body Ported</b>			Metal seal	VQ1□41	1.0	0.84		Latching (					P.	2-4-	36	Single/ 3 position only					
		Series	Rubber seal	VQ2□40	2.3	_	•	•					•			•					•
		VQ2000 P. 2-4-30	Metal seal	VQ2□41	2.7	_		Latching					P.	2-4-	36	Single only					
,	Cassette		Rubber seal	VQ1□70	0.60	0.58		•	•			•	•			ا <sub>۷</sub>					
	Cas		Metal seal	VQ1□71	0.80	0.70		Latching					P.	2-4-	74	Single/ 3 position only					

_										
									D-sub connector 15P	
P.		ص.	.ت		٦.		.P	•	Flat ribbon cable 10P, 16P, 20P	0
2-4-92		Except S kit	2-4-	Except S kit	2-4-	Except S kit	2-4-	Except S kit	Negative common specifications	Option
.92		68	Ó		Ó		.28	•	One-touch fitting Inch size	Š
		Except L kit		Except L kit		Except L kit		Except L kit	For special wiring spec.	
						•		•	Blanking plate	
									Individual SUP/EXH	
						•		•	SUP/EXH passage spacer	<b>S</b>
									Name plate	ani
P. 2-	Standard	P. 2-	7. 2-		7. 2-		P. 2-	•	DIN rail mounting style	Manifold
2-4-87		2-4-63	4-60		4-59		4-23		Built-in silencer	
7					-		J.	•	Silencer for EXH port	Option
									Elbow fitting for cylinder port	ĭ
								•	Plug for cylinder port	
									Double check block	



# Series VQ/Body Ported: Variations

# **Manifold Variations** Flat ribbon cable Flat ribbon cable **Terminal block D-sub connector** connector connector (26, 20, 16, 10 pins) (20 pins) Conforming to MIL flat Conforming to MIL flat. ribbon Conforming to MIL D-sub connector Two kinds of terminal are available in ribbon cable connector cable connector PC Wiring accordance with the number of stations. System compatible **Series VQ1000** P. 2-4-14 P/J kit **Series VQ0000** P. 2-4-38 P. 2-4-42 P. 2-4-46 **Series VQ1000** P. 2-4-38 P. 2-4-42 P. 2-4-46 P kit **Series VQ2000** P. 2-4-42 P. 2-4-46 P kit **Series VQ1000** Cassette P. 2-4-78 P. 2-4-76 P kit

# **Manifold Variations**

	L C	S	Port	size
	kit	kit	SUP EXH port	Cylinder port
	Lead wire	Serial transmission unit	P, R	A, B
	Direct electrical entry type	Enables single-wire solenoid valve-PLC operation		
kit			C6 (ø6)	C3 (ø3.2) C4 (ø4) C6 (ø6) M5 (M5 thread)
	000000		N7 (ø1/4")	N1 (ø1/8") N3 (ø5/32") N7 (ø1/4")
	P. 2-4-18	P. 2-4-20	<option> Built-in silencer</option>	
kit			C6 (ø6)	C3 (ø3.2) C4 (ø4) M5 (M5 thread)
		The second secon	N7 (ø1/4")	N1 (ø1/8") N3 (ø5/32")
	P. 2-4-50	P. 2-4-54	<option> Built-in silencer</option>	
kit			C6 (ø6)	C3 (ø3.2) C4 (ø4) C6 (ø6) M5 (M5 thread)
			N7 (ø1/4")	N1 (ø1/8") N3 (ø5/32") N7 (ø1/4")
	P. 2-4-50	P. 2-4-54	<option> Built-in silencer</option>	
C kit			C8 (ø8)	C6 (ø6) C8 (ø8)
			N9 (ø5/16")	N7 (ø1/4") N9 (ø5/16")
	P. 2-4-50	P. 2-4-54	<option> Built-in silencer</option>	
kit			C6 (ø6)	C3 (ø3.2) C4 (ø4) C6 (ø6) M5 (M5 thread)
			N7 (ø1/4")	N1 (ø1/8") N3 (ø5/32") N7 (ø1/4")
	P. 2-4-82	P. 2-4-84	<option> Built-in silencer</option>	

VQC

SQ

VQ0

VQ4


VQ5

VQZ

VQD

# **Cylinder Speed Chart**

Use as a guide for selection. Please confirm the actual conditions with SMC Sizing Program.



\* The average velocity of the cylinder is what the stroke is divided by the total stroke time.

\* Load factor: ((Load weight x 9.8)/Theoretical force) x 100%

#### **Conditions**


Bod	y ported	Series CJ2	Series CM2	Series MB, CA1				
	Tube bore x Length							
VQ0149-C4	Speed controller		AS2001F-04					
	Silencer	AN103-X233						
	Tube bore x Length	T0604 x 1 m						
VQ11 <sup>30</sup> -C6	Speed controller	AS3001F-06						
	Silencer	AN103-X233						
	Tube bore x Length	T0806 x 1 m						
VQ2149-C8	Speed controller							
	Silencer							

<sup>\*</sup> It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open.

# Series VQ1000 **Body Ported**

# Plug-in Unit: Flip Type

#### **How to Order Manifold**




Note 1) Besides the above, F and P kits with different number of pins are available. For details, refer to page 2-4-28.

Note 2) For details, refer to page 2-4-29.

Note 3) Please consult with SMC for the following serial transmission kits: Matsushita Electric Works, Ltd.; Rockwell Automation, Inc.; SUNX Corporation; Fuji Electric Co., Ltd.; OMRON Corporation.

# Plug-in Unit: Flip Type Series VQ1000



**SMC** 

# Series VQ1000 Body Ported Plug-in Unit: Flip Type

#### Model

						F	low cha	racteristics	Response time (2)(ms)					
Series	1	mber of	iviodei		1 → 4	$1 \rightarrow 4/2 \; (P \rightarrow A/B)$			$4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{R1/R2)}$			Low wattage:	40	Weight (g)
	solenoids				C [dm³/(s·bar)]	b	Cv	C [dm³/(s-bar)]	b	Cv	H: 1.5 W	0.5 W	AC	(9)
	٦	Cinala	Metal seal	VQ1130	0.77	0.14	0.18	0.84	0.14	0.19	12 or less	15 or less	29 or less	
	osition	Single	Rubber seal	VQ1131	0.91	0.19	0.21	1.0	0.21	0.25	15 or less	20 or less	34 or less	57
	2 po	Double	Metal seal	VQ1230	0.77	0.14	0.18	0.84	0.14	0.19	12 or less	15 or less	29 or less	0,
	(1	(Latching)	Rubber seal	VQ1231	0.91	0.19	0.21	1.0	0.21	0.25	15 or less	20 or less	34 or less	
VQ1000		Closed center	Metal seal	VQ1330	0.67	0.13	0.16	0.73	0.13	0.17	20 or less	26 or less	40 or less	
VQ1000	_		Rubber seal	VQ1331	0.78	0.22	0.18	0.84	0.21	0.20	25 or less	33 or less	47 or less	
	position	Exhaust	Metal seal	VQ1430	0.74	0.14	0.17	0.84	0.16	0.20	20 or less	26 or less	40 or less	105
		center	Rubber seal	VQ1431	0.78	0.28	0.19	1.0	0.21	0.24	25 or less	33 or less	47 or less	] 103
	က	Pressure	Metal seal	VQ1530	0.74	0.14	0.17	0.82	0.16	0.20	20 or less	26 or less	40 or less	
		center	Rubber seal	VQ1531	0.78	0.28	0.19	0.84	0.21	0.22	25 or less	33 or less	47 or less	



Note 1) Cylinder port size C6

Note 2) As per JIS B 8375-1981 (Supply pressure: 0.5 MPa; with indicator light/surge voltage suppressor; clean air). Subject to the pressure and air




#### JIS Symbol

2 position single



2 position double (Latching)



3 position closed center



3 position exhaust center




3 position pressure center



#### **Standard Specifications**

	Valve construction		Metal seal	Rubber seal			
	Fluid		Air/Inert gas	Air/Inert gas			
	Maximum operating	pressure (3)	0.7 MPa (High pressure type: 0.8 MPa) (3)				
ions		Single	0.1 MPa	0.15 MPa			
iicat	Minimum	Double (Latching)	0.1 MPa	0.15 MPa			
Decil	operating pressure	3 position	0.1 MPa	0.2 MPa			
Valve specifications	Ambient and fluid te	emperature	−10 to	50°C <sup>(1)</sup>			
Valv	Lubrication		Not re	quired			
	Manual override		Push type/Locking type (To	ol required, Manual) Option			
	Impact/Vibration res	sistance <sup>(2)</sup>	150/30 m/s²				
	Enclosure		Dust-pr	otected			
	Coil rated voltage		12, 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)				
	Allowable voltage fl	uctuation	±10% of rated voltage				
	Coil insulation type		Class B or equivalent				
bic		24 VDC	1 W DC (42 mA), 1.5 W DC (6	63 mA) <sup>(3)</sup> , 0.5 W DC (21 mA) <sup>(4)</sup>			
Solenoid		12 VDC	1 W DC (83 mA), 1.5 W DC (1	25 mA) <sup>(3)</sup> , 0.5 W DC (42 mA) <sup>(4)</sup>			
လိ	Power consumption	100 VAC	Inrush 0.75 VA (7.5 mA),	Holding 0.75 VA (7.5 mA)			
	(Current)	110 VAC	Inrush 0.83 VA (7.5 mA),	Holding 0.83 VA (7.5 mA)			
		200 VAC	Inrush 1.0 VA (5 mA), Holding 1.0 VA (5 mA)				
		220 VAC	Inrush 1.1 VA (5 mA), Holding 1.1 VA (5 mA)				
Note 1	) Use dry air to prever	nt condensation v	vhen operating at low tem				



Note 2) Impact resistance ...... No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once

for each condition. (Values at the initial period)

Vibration resistance ···· No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and deenergized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Note 3) Values in the case of high pressure type (1.5 W).


Note 4) Values in the case of low wattage (0.5 W) specifications.

# Plug-in Unit: Flip Type Series VQ1000

**Manifold Specifications** 

			Por	ting specification	ons	Applicable (2)		5 station
Series	Base model	Type of connection	Port	One-touch fitting/Port size (1)		Applicable stations	Applicable solenoid valve	weight
			location	1(P), 3(R)	4(A), 2(B)	Stations	Solonola valve	(g)
VQ1000	VV5Q13-□□□	■ F kit—D-sub connector ■ P kit—Flat ribbon cable connector ■ J kit— Flat ribbon cable connector (20P) ■ L kit—Lead wire cable ■ S kit—Serial transmission unit	Side	C6 (Ø6) Option Built-in silencer, Direct exhaust	C3 (ø3.2) C4 (ø4) C6 (ø6) M5 (M5 thread)	1 to 16 stations	VQ1□30 VQ1□31	424

Note 1) Inch-size One-touch fittings are also available. For details, refer to page 2-4-29. Note 2) For details, refer to page 2-4-29.



VQC

SQ


VQ0

VQ4

VQ5

VQZ

VQD



- The D-sub connector reduces installation labor for electrical connections
- Using the D-sub connector (25P), (15P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.


#### Porting specifications Applicable Series Port size Port stations location 4(A), 2(B) 1(P), 3(R) Max. 16 **VQ1000** Side C<sub>6</sub> C3, C4, C6, M5 stations

## D-sub Connector (25 pins)

#### Cable assembly

# AXT100-DS25-030

The D-sub connector cable assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold.



D-sub	Connector	-
Cable	Assembly (	(Option)

Cable length (L)	Assembly part no.	Note
	AXT100-DS25-015	0 11 05
3 m	AXT100-DS25-030	Cable 25 core
5 m	AXT100-DS25-050	A 2-7/1/VG

For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308.

#### Connector manufacturers' example

- Fuiitsu Limited
- · Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.
- · Hirose Electric Co., Ltd

#### Wire Color by Terminal No. of D-sub Connector Cable Assembly

Terminal Lead wire

no.	color	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Gray	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Gray	Red
24	Black	White
25	White	None

resistance MΩkm, 20°C Note) The min. bending radius of D-sub cable assembly is

Characteristics

Characteristics

65

or less

1000

5 or more

Item

Conductor

resistance Ω/km, 20°C


Voltage limit

V 1 min AC


Insulation



Note) Types with 15 pin are also available. For details, refer to page 2-4-29.



#### Electrical wiring specifications



(connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 12 stations or less, regardless of valve and option types.

Mixed single and double wiring is available as an option. For details, refer to page 2-4-29.

Terminal no A B A B A B A B A B (\*) A B (\*) side B side Stations-1 2 3 4 5 Double wiring (Standard


3 position uses two stations. The A side solenoid of a 3 position valve is connected to SOL.A at the station with the smaller number in the above figure and the B side solenoid to SOL.A at the next station.

Note) When using the negative common specifications, use valves for negative common. (Refer to page 2-4-29.)

#### **How to Order Manifold**

16

16 stations



Note) For details, refer to page 2-4-29

With cable (1.5 m) With cable (3 m)


3 With cable (5 m)

Connector entry direction

U	Top entry
S	Side entry

#### Option

Nil	None				
D	DIN rail mounting style				
K <sup>(2)</sup>	Special wiring specifications				
	(Except double wiring)				
N	With name plate				
S	Built-in silencer, direct exhaust				



Note 2) Specify the wiring specifications on the manifold specification sheet.



**VQC** 

SQ


VQ0

VQ4

VQ5

VQZ

VQD



D side U side }======*>* 2-C6 (7.5)1(P) SUP port 2n-C3, C4, C6, M5 19.2 C3: One-touch fitting for ø3.2

Stations---1---2--3--4--5--6--7--8---n

The broken lines indicate the DIN rail mounting style [-D] and the top entry connection [-FU].

> Note) 3 position types need two stations.

> > Cylinder port is located at U side of body

#### manaiana


Note 2) Except double (latching).

Dillie	Formula L1 = $11n + 15.5$ , L2 = $11n + 60$ n: Station (Maximum 16 static									stations)						
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
L2	71	82	93	104	115	126	137	148	159	170	181	192	203	214	225	236
(L3)	100	100	112.5	125	137.5	150	162.5	175	187.5	200	212.5	212.5	225	237.5	250	262.5
(L4)	110.5	110.5	123	135.5	148	160.5	173	185.5	198	210.5	223	223	235.5	248	260.5	273

C4: One-touch fitting for ø4

C6: One-touch fitting for ø6

M5: M5 thread



2-C6

3(R) EXH port,

## **How to Order Manifold Assembly**


Specify the part numbers for valves and options together beneath the manifold base part number.

<Example> D-sub connector kit with 3 m cable

VV5Q13-08FU2···· 1 set — Manifold base no. \*VQ1130-5-C6..... 4 sets — Valve part no. (Stations 1 to 4)  $*\mbox{VQ1230-5B-C6}....4$  sets — Valve part no. (Stations 5 to 8))

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specify by using the manifold specification sheet.







- MIL flat ribbon cable connector reduces installation labor for electrical connection.
- Using the connector for flat ribbon cable (26P), (10P, 16P, 20P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.


	Po				
Series	Port	Po	ort size	Applicable	
	location	1(P), 3(R)	4(A), 2(B)	stations	
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations	

#### Flat Ribbon Cable (26 pins)

#### Cable assembly •

## AXT100-FC26-103

Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold.




#### Flat Ribbon Cable Connector Assembly (Option)

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC26-1	0.11.00
3 m	AXT100-FC26-2	Cable 26 core x 28AWG
5 m	AXT100-FC26-3	X ZOAWG

\* For other commercial connectors, use a 26 pins type with strain relief conforming to MIL-C-83503.


#### Connector manufacturers' example

- Sumitomo 3M Limited
- Fujitsu Limited
- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.
- Oki Electric Cable Co., Ltd.




Note) For details, refer

to page 2-4-29.



#### **●** Electrical wiring specifications




3 position type uses two stations. The A side solenoid of a 3 position valve is connected to SOL. A at the station with the smaller number in the above figure and the B side solenoid to SOL. A at the next station.



For details, refer to page 2-4-29.

Note) When using the negative common specifications, use valves for negative common. (Refer to page 2-4-29.)

#### **How to Order Manifold**



Side entry

S

Note 2) Specify the wiring specifications on the manifold specification sheet.

**VQC** 

SQ

VQ0


VQ4

VQ5

VQZ

VQD

# Plug-in Unit: Flip Type Series VQ1000



D side -- 7 -- 8 ---n U side --2--3---4--5--6 Stations 2-C6 1(P) SUP port 14 44-44-----------⊭≡≡≡≢≡≡≢≕ 2-C6 2n-C3, C4, C6, M5 2 C3: One-touch fitting for ø3.2 P = 11 7 3(R) EXH port C4: One-touch fitting for ø4 C6: One-touch fitting for ø6 M5: M5 thread

 $\mathcal{Q}$ 

The broken lines indicate the DIN rail mounting style [-D] and the top entry connection [-PU].

Note) 3 position types need two stations.


Cylinder port is located at U side of body.

Note 1) For power consumption of AC type, refer to page

Note 2) Except double (latching).

#### Dimensions

Dimer	JIMENSIONS Formula L1 = 11n + 15.5, L2 = 11n + 55 n: Station (Maximum 16 station)									stations)						
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
L2	66	77	88	99	110	121	132	143	154	165	176	187	198	209	220	231
(L3)	87.5	100	112.5	125	137.5	150	162.5	162.5	175	187.5	200	212.5	225	237.5	250	262.5
(L4)	98	110.5	123	135.5	148	160.5	173	173	185.5	198	210.5	223	235.5	248	260.5	273



# **VQ1000** Kit (Flat ribbon cable connector)

- MIL flat ribbon cable connector reduces installation labor savings for electrical connection.
- Using the connector for flat ribbon cable (20P) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.


#### Porting specifications Applicable Series Port Port size stations location 1(P), 3(R) 4(A), 2(B) Max. 16 **VQ1000** Side C<sub>6</sub> C3, C4, C6, M5 stations

# Flat Ribbon Cable (20 pins)

#### Cable assembly

#### AXT100-FC20-1 to 3

Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order




#### Flat Ribbon Cable Connector Assembly (Option)

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC20-1	0.11.00
3 m	AXT100-FC20-2	Cable 20 core x 28AWG
5 m	AXT100-FC20-3	X ZOATTO


For other commercial connectors, use a 20 pins with strain relief conforming to MIL-C-83503.

#### Connector manufacturers' example

- Hirose Electric Co., Ltd.
- Japan Aviation Electronics Industry, Ltd.
- Oki Flectric Cable Co. Ltd.
- Sumitomo 3M Limited
- J.S.T. Mfg. Co., Ltd.
- Fujitsu Limited



Electrical wiring specifications




As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 8 stations or less, regardless of valve and option types. Mixed single and double wiring is available as an option. For details, refer to page 2-4-29.



Note) When using the negative common specifications, use valves for negative common. (Refer to page 2-4-29.)

#### **How to Order Manifold**



**VQC** 

SQ

VQ0


VQ4

VQ5

VQZ


VQD


# Plug-in Unit: Flip Type Series VQ1000



Note 2) Except double (latching).

**Dimensions** Formula L1 = 11n + 15.5. L2 = 11n + 55n: Station (Maximum 16 stations) 2 3 4 5 6 9 10 12 13 15 16 L1 26.5 37.5 48.5 59.5 70.5 81.5 92.5 103.5 114.5 125.5 136.5 147.5 158.5 169.5 180.5 191.5 L2 66 77 88 99 110 121 132 143 154 165 176 187 198 209 220 231 (L3) 100 112.5 125 137.5 162.5 162.5 175 187.5 200 212.5 225 237.5 250 262.5 87.5 150 (L4) 98 110.5 123 135.5 148 160.5 173 173 185.5 198 210.5 223 235.5 248 260.5 273









- It is the standard type which lead wire is extracted directly.
- Maximum stations are 16.


	Po				
Series	Port	Po	ort size	Applicable	
	locaition	1(P), 3(R)	4(A), 2(B)	stations	
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations	


#### Wiring specifications: Positive COM





#### Wiring specifications: Negative COM (Option)





**VQC** 

SQ


VQ0


VQ4

VQ5

VQZ

VQD





D side Stations --- -- 1 -- 2 -- 3 -- 4 -- 5 -- 6 -- 7 -- 8 --- n U side 1(P) SUP por ###========= 2n-C3, C4, C6, M5 C3: One-touch fitting for ø3.2 C4: One-touch fitting for ø4 C6: One-touch fitting for ø6


The broken lines indicate the DIN rail mounting style [-D].


The lead wire entry is on D side (LD□) in this case.

Note) 3 position types need two  $\overline{3(R) EXH}$  port stations.

Cylinder port is located at U side of body.


Dimensions									rmula L1	= 11n +	15.5, L2 :	= 11n + 2	8 n: Sta	ation (Max	imum 16	stations)
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
L2	39	50	61	72	83	94	105	116	127	138	149	160	171	182	193	204
(L3)	62.5	75	87.5	100	112.5	125	125	137.5	150	162.5	175	187.5	200	212.5	212.5	225
(L4)	73	85.5	98	110.5	123	135.5	135.5	148	160.5	173	185.5	198	210.5	223	223	235.5





- The serial transmission system reduces wiring work, while minimizing wiring and saving space.
- The system comes in an type SA (generic for small scale systems) for equipment with a small number of I/O points, or 32 points max., type SB (applicable to Mitsubishi Electric models) for controlling 512 I/O points max., type SC (applicable to OMRON models), and type SD (applicable to SHARP models; 504 points max.).
- 16 stations max. (Specify a model with 9 to 16 stations by using the manifold specification sheet.)

	Po				
Series	Port	Po	ort size	Applicable stations	
	location	1(P), 3(R)	4(A), 2(B)		
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations	



to SOL. A and SOL. B) is


adopted for the internal wiring of each station for 8 stations or less, regardless of valve and option types. Mixed single and double wiring is available as an option. For details, refer to page 2-4-29.

Item	Specifications
External power supply	24 VDC±10%
Current consumption (Internal unit)	SA, SB, SD, SFI, SH: 0.1 A/SC: 0.3 A

	Type SA With general type SI unit (Series EX300)	Type SB Mitsubishi Electric Corporation MELSECNET/MINI-S3 Data Link System				
nal block (LED)	ACOPESS NO.  IN SUN. IL THO  ACOPESS NO.  IN SUN. IL THO  ACOPESS NO.  ACOPES NO.  ACOPESS NO.  ACOPESS NO.  ACOPESS NO.  ACOPESS NO.  ACOPES NO.  ACOPESS NO.  ACOPESS NO.  ACOPESS NO.  ACOPESS NO.  ACOPES NO.	POWER RIAN SO RO ERR STATION MO OV (SDA) (SDB) (SG) (RDA) (RDB) (FG)				
Name of terminal block (LED)	LED Description TRD Lighting during data reception RUN/ERR Blinking when received data is normal; Lighting when data reception	LED Description  POWER Lighting when power is turned ON  RUN Lighting when data transmission with the master station is normal  RD Lighting during data reception  SD Lighting during data error occurs. Lighting when reception data error occurs. Light ums off when the error is corrected.				
Note	T unit Can be connected with PLC I/O card for serial transmission.  EX300-TMB1For models of Mitsubishi Electric Corporation  EX300-TTA1For models of OMRON Corporation  EX300-TFU1For models of Fuji Electric Co., Ltd.  EX300-T001For general models  * Up to 32 points per unit.  No. of output points, 16 points	Master station: PLC made by Mitsubishi Electric Corporation Series MELSEC-A AJ71PT32-S3, AJ71T32-S3 A1SJ71PT32-S3 *Max. 64 stations, connected to remote I/O stations (Max. 512 points). No. of output points, 16 points. No. of sta. occupied, 2 stations				

 $\ast$  For details on specifications and handling, refer to the separate technical instruction manual.

#### **How to Order Manifold**



# 08

#### Model 0 Without SI unit Α With general type SI unit (Series EX300) В Mitsubishi Electric Corp.: MELSECNET/MINI-S3 Data Link System С OMRON Corp.: SYSBUS Wire System D SHARP Corp.: Satellite I/O Link System F1 NKE Corp.: Uni-wire System (16 output points) Н NKE Corp.: Uni-wire H System Note) Please consult with SMC for the following serial

transmission kits: Matsushita Electric Works, Ltd.; Rockwell Automation, Inc.; SUNX Corporation, Fuji Electric Co., Ltd.; OMRON Corporation.

\* The dust-protected type SI unit is applicable, too. For details, please contact SMC.

## Option

<b>D</b> (2)	2
K (3)	Special wiring specifications (Except double wiring
N	With name plate
S	Built-in silencer, direct exhaust (U side only)

Note 1) When two or more symbols are specified, indicate alphabetically.
Example) -DNS
Note 2) S kits are DIN rail mounting styles,

so include suffix D.

Note 3) Specify the wiring specifications on the manifold specification sheet.

**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ

VQD

#### SI unit output and coil numbering

#### <Wiring example 1> Double wiring (Standard)

SI unit output no. 0 1 2 3 4 5 **6** (Locked by double solenoid valve.) В В Α SOL. location Double m A side B side Dou 3 position  $\overline{S}$ Stations 2 3

The places of asterisk are not used.

3 position uses two stations for wiring. The A side solenoid of 3 position valve is connected to A at the station with the smaller number in the above figure.

#### <Wiring example 2>

Single/Double Mixed Wiring (Option)
Mixed wiring is available as an option.
Use the manifold specification sheet to specify.

SI unit output no. -----0 1 2 3 4 (Locked by double solenoid valve.) Α В ABAB ABAB SOL. location Double unit A side B side Don Sin 3 position  $\bar{s}$ Stations 2 5 1 3 4

Type SC Type SD **OMRON Corporation SHARP Corporation** SYSBUS Wire System Satellite I/O Link System Name of terminal block (LED) □ ¤ TRI LED Description LED Lights when transmission is normal **POWER** ON when power supply is ON RUN Lights when power is ON and slave stations are operating normally and PLC is in operation mode RUN T/R Blinks during data transmission/reception Lights when slave station switch setting ON when transmission is abnormal FRROR is abnormal, communication is abnormal. PLC stopped and defective slave unit R.SET ON for master unit control input · Master station unit: Master station unit: SHARP's PLC OMBON PLC New Satellite Series W SYSMAC C(CV) series Types C500-RM201 and C200H-RM201 ZW-31LM Note New Satellite Series JW \* 32 units max., transmission terminal JW-23LM, JW-31LM connection (512 points max.) Max. 31 units, I/O slave stations connected

(504 points max.)

No. of output points, 16 points

#### **How to Order Valves** Cylinder port Series VQ1000 With One-touch fitting for ø3.2 Type of actuation C4 With One-touch fitting for ø4 2 position single With One-touch fitting for ø6 2 position double (Latching) M5 M5 thread 3 Note 3 position closed center inch-size Note) For One-touch 3 position exhaust center fittings, refer to "Option" on 5 Note) 3 position pressure center page 2-4-29. Note) 3 position types need Manual override two stations Non-locking push type (Tool required) Seal В Locking type (Tool required) Metal seal 0 С Locking type (Manual) 1 Rubber seal Note) A manual override for pilot valve is provided to the standard **Function** model for double type. DC Specifications Symbol Coil voltage (1.0 W)Nil Standard type 5 24 VDC/With indicator light/surge voltage suppressor H<sup>Note)</sup> (1.5 W) High pressure type

(0.5 W)

## **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.


<Example>

Serial transmission kit

VV5Q13-08SA-D···1 set — Manifold base part no. \*VQ1230-5-C6······4 sets — Valve part no. (Stations 1 to 4)

\*VQ1230-5B-C6...4 sets — Valve part no. (Stations 5 to 8)

Prefix the asterisk to the part nos. of the solenoid valve, etc. Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specify by using the manifold specification sheet.




Note) Except double (latching)


Low wattage type


Y<sup>Note)</sup>

. No. of output points, 16 points











Dimer	<b>Dimensions</b> Formula L1 = 11n + 15.5, L2 = 11n + 55 n: Station (Maximum 16 station												stations)			
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
L2	66	77	88	99	110	121	132	143	154	165	176	187	198	209	220	231
L3	187.5	200	212.5	225	237.5	250	262.5	275	275	287.5	300	312.5	325	337.5	350	362.5
L4	198	210.5	223	235.5	248	260.5	273	285.5	285.5	298	310.5	323	335.5	348	360.5	373

#### **Manifold Option Parts**

#### Blanking plate assembly VVQ1000-10A-3

It is used when a blanking plate is mounted to a manifold in advance for possible valve mounting, etc.





# **VQC**

SQ

VQ0

VQ4

VQ5

VQZ


VQD

#### **Individual SUP spacer** VVQ1000-P-3-C6

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.)

Since the SUP passage on the spacer's D side is blocked in advance, it is mounted on the D side the valves U side. (Refer to the application example.)

- \* Specify the spacer mounting position and SUP block plate mounting position on the manifold specification sheet.
- \* Electric wiring is connected to the position of the manifold station where the individual SUP spacter is mounted.




#### Individual EXH spacer VVQ1000-R-3-C6

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (1 station space is occupied.)

Since the EXH passage on the spacer's D side is blocked in advance, it is mounted on the D side of the valve for individual supply while blocking the valves U side. (Refer to the application example.)

- \* Specify the spacer mounting position and EXH block plate mounting position on the manifold specification sheet.
- \* Electric wiring is connected to the position of the manifold station where the individual EXH spacer is mounted.



## PR Block valve VQ1230-□-□---


For a flip plug-in unit, block plate is built in the valve for blocking SUP and EXH passages. Since the no. is classified by the passage to be blocked, specify it by attaching the option no. to the valve no. The block valve is constructed so that D sides of SUP and EXH passages are blocked

\* Specify the number of stations on the manifold specification sheet.

#### <Shut off label>

When using block plates for SUP, EXH passage, indication label for confirmation of the blocking positionfrom outside is attached. (One label for each)


 When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold.







passage blocked



passage blocked


## Series VQ1000

#### **Manifold Option Parts**

# Name plate [-N3] VVQ1000-N3-Station (1 to Max. stations)


It is a transparent resin plate for placing a label that indicates solenoid valve function, etc.

Insert it into the groove on the side of the end plate and bend it as shown in the figure.





\* When ordering assemblies incorporated with a manifold, add suffix N to the manifold no.




# Blanking plug KQ2P- 04 Plug

It is inserted into an unused cylinder port and SUP/EXH ports.

Purchasing order is available in units of 10 pieces.






#### **Dimensions**


Applicable fittings size ød	Model	Α	L	D
3.2	KQ2P-23	16	31.5	5
4	KQ2P-04	16	32	6
6	KQ2P-06	18	35	8


# DIN rail mounting bracket VVQ1000-57A-3

It is used for mounting a manifold on a DIN rail. The DIN rail mounted bracket is fixed to the manifold end. (The specification is the same as that for the option "-D".)

1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).







#### **Built-in silencer, Direct exhaust [-S]**


This is an exhaust port on top of the manifold end plate. The built-in silencer exhibits an excellent noise suppression effect.

F, P and S kits are provided with single exhaust on U side.

Note) A large quantity of drainage generated in the air.




• For maintenance, refer to page 2-4-27.




\* When ordering assemblies incorporated with a manifold, add suffix -S to the manifold no.

#### Silencer AN103-X233

This is inserted into the centralized type EXH port (One-touch fitting).





#### **Dimensions**


Series	Applicable fittings size ød	Model	A	L	D	Effective area (mm²)	Noise reduction (dB)
VQ1000	6	AN103-X233	20	37	11	7	25


#### Port plug VVQ0000-58A

The plug is used to block the cylinder port when using a 4 port valve as a 3 port valve.

When ordering it incorporated with a manifold, suffix A or B, the symbol of the plug port, to the valve no.

Example) VQ1130-5L-C6-A
L A port, Plug





#### Double check block (Separated type) VQ1000-FPG-□□

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the double check block with a built-in pilot type double check valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time. The combination with a two position single/double solenoid valve will permit this block to be used for preventing the dropping at the cylinder stroke end when the SUP residual pressure is released.

#### **Specifications**

Max. operating pressure	0.8 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temperature	−5 to 50° C
Flow characteristics: C	0.60 dm3/(s·bar)
Max. operating frequency	180 CPM



Note) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa)

# (Check valve operation principle) Cylinder pressure SUP side pressure (P1) VVQ1000-FPG-02 1 set \*VQ1000-FPG-C6M5-D 2 sets TO CYL POR

**VQC** 

SQ

VQ0


VQ4

VQ5


**VQZ** 

VQD

#### **Dimensions**



#### **How to Order**



Stations 01

#### 1 station 16 16 stations

#### <Example>

VVQ1000-FPG-06--6 types of manifold

\*VQ1000-FPG-C4M5-D, 3 sets Double Check block \*VQ1000-FPG-C6M5-D, 3 sets

- Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for a long time. Check the leakage using neutral household detergent, such as dish washing soap
- Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.

  Since One-touch fittings allow slight air leakage, screw piping (with M5 thread) is recommended when stopping the cylinder in the middle for a long time.
- Combining double check block with 3 position closed center or pressure center solenoid valve will not work.
- M5 fitting assembly is attached, not incorporated into the double check block.
   After screwing in the M5 fittings, mount the assembly on the double check block. {Tightening torque: 0.8 to 1.2 N·m} • If the exhaust of the double check block is throttled too much, the cylinder may not operate properly and may not stop
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure

## Series VQ1000


## 


Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.

#### **Light/Surge Voltage Suppressor**

#### 

The lighting positions are concentrated on one side for both single solenoid and double (latching) type. In the double (latching) type. A side and B side energization are indicated by two colors which match the colors of the manual overrides.





#### Double (Latching solenoid) Type

#### 

Different from the conventional double solenoid, the double uses a latching (self-holding system) solenoid. Although the appearance is the same as the single solenoid, it is constructed so that the movable iron core in the solenoid is held in the ON position on A and B sides by instantaneous energization (20 ms or more). The usage and function is the same as the double solenoid.

#### <Special Cautions for Latching Solenoid>

- 1. Select the circuit in which ON and OFF signals are not energized simultaneously.
- 2. 20 ms energization time is necessary for self-holding.
- 3. Avoid using the latching solenoid valves in environments where impact or collisions with the valve might occur. Also, do not use in places where strong magnetic fields are present.
- 4. Even though the armature in the solenoid of this valve is held on to B side, ON position (Reset), verify either A side, ON position or B side, ON position by energizing prior to use. After manual operation, the main valve will return to its original position.
- 5. Manual override on the pilot valve side can retain its switching position after manipulation.
- 6. Please contact SMC for long-term energization applications.
- 7. If the metal seal type goes down below the minimum operating pressure of supply air (0.1 MPa or less), the main valve will get back the home position (B side ON position). Therefore, in the event of shutting the supply air or applying the air with being A side ON position remained, cylinder may be pulsated. In the event of manipulating the supply air, the valve's switching position has to be set in the home position side (B side ON position side).

#### **How to Mount/Remove Solenoid Valve**

# **⚠** Caution Γie-rod bolt A <Procedure> Light cover Tie-rod bolt B

How to remove

- 1. Loosen tie-rod bolt B. (Two to four turns)
- 2. After fully loosening the tie-rod bolt, take off bold A upward as shown above.
- 3. Slide the valves aside to make a 1 mm clearance between the valve to betaken off and the others. As shown above, remove the whole valve while holding up the (a) side.

Reverse the sequence of steps above to remount. Torque applied to tie-rod bolt should be 1.0 to 1.4 N·m. Tighten evenly.

Note) Be careful not to push on the light cover while mounting/removing the valve.

#### **Manual Override**

## 🗥 Warning

Without an electric signal for the solenoid valve the manual override is used for switching the main valve.

#### ■ Push type (Tool required)



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

#### ■ Locking slotted type



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it.

#### ■ Locking lever type (Option)




Push down completely on the manual override button with a small screwdriver While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

#### ■ Manual override for double (latching) type

In the case of a double (latching) type, a manual override is provided not only on the body side but to the pilot as a standard. After manual operation, the main valve of the manual on the body side returns to the position before the manual operation, however. the pilot valve manual override maintains the change-over position.

Body side manual override Self-holding of the main valve is impossible. (Returns to the main valve position before operation.) Turn before pushing.



- If the manual override is turned by 180° clockwise and the ▶ mark is adjusted to A, then pushed in the direction of an arrow (♠), it will be back to the reset condition. (passage P → A)
- If the manual override is turned by 180° counterclockwise and the ▶ mark is adjusted to B, then pushed in the direction of an arrow (4), it will be back to the reset condition. (passage  $P \rightarrow B$ ) (It is in the reset state at the time of shipment.)

#### 

Do not apply excessive torque when turning the locking type manual override. (0.1 N·m or less)




## **Replacement of Cylinder Port Fittings**

# **A** Caution

The cylinder port fittings are a cassette for easy replacement. The fittings are blocked by a clip inserted from the top of the valve.

Remove the clip with a screwdriverto remove fittings. For replacement, insert the fitting assembly until it strikes against the inside wall and then re-insert the clip to the specified position.



	Fitting assemly part no.
Applicable tubing O.D.	VQ1000
Applicable tubing ø3.2	VVQ1000-50A-C3
Applicable tubing ø4	VVQ1000-50A-C4
Applicable tubing ø6	VVQ1000-50A-C6

Purchasing order is available in units of 10 pieces

#### Caution


- 1. Use caution that O-rings must be free from scratches and dust. Otherwise, air leakage may result.
- 2. The tightening torque for inserting fittings to the M5 thread assembly should be 0.8 to 1.4 N·m.

#### Mounting/Removing from the DIN Rail

# **Caution**


#### Removing

- **1.** Loosen the clamp screw of the end plate on both sides.
- 2. Lift side (a) of the manifold base and side the end plate in the direction of (2) shown in the figure to remove.



#### Mounting

- Hook side (b) of the manifold base on the DIN rail.
- 2. Press down side (a) and mount the end plate on the DIN rail. Tighten the clamp screw on side (a) of the end plate. The proper tightening torque for screws is 0.4 to 0.6 N·m.



#### **Built-in Silencer Replacement Element**

# **⚠** Caution


A silencer element is incorporated in the end plate on both sides of the base. A dirty and choked element may reduce cylinder speed or cause manifunction. Clean or replace the dirty element.

#### **Element Part No.**

Tuno	Element part no.
Туре	VQ1000
Built-in silencer, direct exhaust (-S)	VVQ1000-82A-3

\* The minimum order quantity is 10 pcs.

Remove the cover from the side of the end plate and remove the old element with a screwdriver, etc.



VQC

SQ

VQ0

VQ4

VQ5

VQZ

VQD

#### **How to Calculate the Flow Rate**

For obtaining the flow rate, refer to pages 2-1-8 to 2-1-11.

#### Series VQ1000


#### **Option**

#### **Different Number of Connector Pins**


F and P kits with the following number of pins are available. Besides the standard number (F = 25; P = 26) select the desired number of pins and cable length from the cable assembly list. Place an order for the cable assembly separately.



## kit (D-sub connector) 15 pins



#### How to order manifold




D-sub connector, 15 pins Connector location—Side (horizontal) Without cable

#### Kit/Electrical entry •

Pins	Тор	entry	Side entry			
15P(Max. 7 stations)	Kit F	UA	Kit F	SA		

#### **Wiring Specifications**

\* As in the case of 25-pin models (standard), terminal no. 1 is the first station SOL.A and the terminal no. 8 is COM.



#### Wire Color by Terminal No. of D-sub Connector Cable Assembly


Terminal no.	Lead wire color	Dot marking		
1	Black	None		
2	Brown	None		
3	Red	None		
4	Orange	None		
5	Yellow	None		
6	Pink	None		
7	Blue	None		
8	Purple	White		
9	Gray	Black		
10	White	Black		
11	White	Red		
12	Yellow	Red		
13	Orange	Red		
14	Yellow	Black		
15	Pink	Black		

#### **D-sub Connector Cable Assembly**


Cable length (L)	15P
1.5 m	AXT100-DS15-1
3 m	AXT100-DS15-2
5 m	AXT100-DS15-3

<sup>\*</sup> For other commercial connectors, use a type conforming to MIL-C-24308.

# kit (Flat ribbon cable connector) 10 pins, 16 pins, 20 pins



#### How to order manifold



Connector location—Side (horizontal)


Without cable

#### Kit/Electrical entry -

Pins	Тор	entry	Side entry		
10P (Max. 4 stations)	Kit	UA	Kit	SA	
16P (Max. 7 stations)	Р -	UB	P	SB	
20P (Max. 9 stations)		UC		SC	

#### Wiring Specifications

\* As in the case of 26-pin models (standard), terminal no. 1 is the first station SOL.A and the last two terminal numbers are used for COM.



#### Flat Ribbon Cable Assembly

Pins 10P		16P	20P						
1.5 m	AXT100-FC10-1	AXT100-FC16-1	AXT100-FC20-1						
3 m	AXT100-FC10-2	AXT100-FC16-2	AXT100-FC20-2						
5 m	AXT100-FC10-3	AXT100-FC16-3	AXT100-FC20-3						
Connector width (W)	17.2	24.8	30						

<sup>\*</sup> For other commercial connectors, use a type with strain relief that conform to MIL-C-83503.

#### Option

#### **Special Wiring Specifications**

In the internal wiring of F kit, P kit, and JS kit, double wiring (connected to SOL. A and SOL. B) is adopted for each station regardless of the valve and option types.

Mixed single and double wiring is available as an option.

#### 1. How to order valves

Indicate an option symbol, -K, for the manifold no. and be sure to specify the mounting position and number of stations of the single and double wiring by means of the manifold specification sheet.


#### Example)



Others, option symbols: of to be indicated alphabetically.

#### 2. Wiring specifications

Connector terminal numbers are connected from solenoid station 1 on the A side in the order indicated by the arrows without shipping any terminal numbers.



#### 3. Max. number of stations

(25P)

The maximum number of stations depends upon the number of solenoids. Assuming one for a single and two for a double, determine the number of stations so that the total number is not more than the maximum number given in the following table.

(20P)


(26P)

kit	F kit (D-sub connector)		(Flat rib	P kit bon cable	J kit (Flat ribbon cable connector)	S kit (Serial)		
Туре	F s □ 25P	F s A 15P	P s □ 26P	P s C 20P	P s B 16P	P s A 10P	J % □ 20P	S□
Max. points	24 ( 16 stations )	14	24 (16 stations)	18 (16 stations)	14	8	16	16


## **Negative Common Specifications**

Specify the valve model no. as shown below for negative COM specification. The manifold no. shown below is for the L kits. For other kits the standard manifold can be used. Please contact for negative COM S kit.

#### How to order negative COM valves



#### How to order negative COM manifold



#### Inch-size One-touch Fittings

Refer to following model no. for inch-size One-touch fittings.

How to order manifold

VV5Q13-08FSO-DN-00T

1(P), 3(R) port size: ø1/4

How to order valves

VQ1130 - 5 N7 Cylinder ports

 Symbol
 N1
 N3
 N7

 Applicable tube O.D. (Inch)
 Ø1/8"
 Ø5/32"
 Ø1/4"

**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ

VQD

## **DIN Rail Mounting**

Each manifold can be mounted on a DIN rail.

Order it by indicating an option symbol for DIN rail mounting style, -D. In this case, a DIN rail which is approx. 30 mm longer than the manifold with the specified number of stations is attached. Besides, it is also available in the following cases.

#### When DIN rail is unnecessary (Except S kit)

(DIN rail mounting brackets only are attached.) Indicate the option symbol, -DO, for the manifold no. **Example**)

## VV5Q13-08LD1-DOS

 Others, option symbols: to be indicated alphabetically.

 When using DIN rail longer than the manifold with specified number of stations

Clearly indicate the necessary number of stations next to the option symbol, -D, for the manifold no.

Example)

## VV5Q13-08FS1-D09S

Others, option symbols: to be indicated alphabetically.


 When changing the manifold style into a DIN rail mount Order brackets for mounting a DIN rail. (Refer to "Option" on page 2-4-24.)

No. VVQ1000-57A-3 2 pcs. per one

#### When ordering DIN rail only

DIN rail no.: AXT100-DR-n

\* Refer to the DIN rail dimension table for determining the length.




L Din	<b>L Dimension</b> L = 12.5 x n + 10.5									ı + 10.5
No.	1	2	3	4	5	6	7	8	9	10
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5
No.	11	12	13	14	15	16	17	18	19	20
L dimension	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5
No.	31	32	33	34	35	36	37	38	39	40
L dimension	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5



### Plug Lead Unit: Flip Type

### **How to Order Manifold**




Note 1) Besides the above, F and P kits with different number of pins are available. For details, refer to page 2-4-68.

Note 2) See page 2-4-69 for details.


Note 3) Please consult with SMC for the following serial transmission kits: Matsushita Electric Works, Ltd.; Rockwell Automation, Inc.; SUNX Corporation; Fuji Electric Co., Ltd.; OMRON Corporation.

### **How to Order Valves**



### **Manifold Option**

#### Blanking plate assembly VVQ0000-10A-4




VVQ0000-P-4-C4

C4 (SUP) port

One-touch


fitting for ø4

Name plate [-N4] VVQ0000-N4-Station (1 to Max. stations)




Note 2) Connector assembly will be required when the F, P, T, S kits add a valve. For model no., refer to "Option" on page 2-4-69


**Double Check block** 



Individual EXH spacer VVQ0000-R-4-C4





DIN rail mounting bracket VVQ0000-57A-4



Built-in silencer, Direct exhaust [-S]


P. 2-4-59






KQ2P- 04

### Blanking plug



### How to Order Manifold Assembly






specification sheet.

• For replacement parts, refer to page 2-4-105.



### Plug Lead Unit: Flip Type



Note 1) Besides the above, F and P kits with different number of pins are available. For details, refer to page 2-4-68.

Note 2) See page 2-4-69 for details.

2 No. of terminals: 16, 2 rows Applicable stations 5 to 16


Max. 16

NKE Corp.: Uni-wire H System

Connector kit

Note 3) Please consult with SMC for the following serial transmission kits: Matsushita Electric Works, Ltd.; Rockwell Automation, Inc.; SUNX Corporation; Fuji Electric Co., Ltd.; OMRON Corporation.

### **How to Order Valves**




SUP/EXH passage block

VVQ0000-58A


Blanking plug

Port plug


#### Blanking plate assembly VVQ1000-10A-4



Individual SUP spacer VVQ1000-P-4-C6




Individual EXH spacer VVQ1000-R-4-C6




Name plate [-N4] VVQ1000-N4-Station (1 to Max. stations)




### Double check block VQ1000-FPG-□□




DIN rail mounting bracket VVQ1000-57A-4




Built-in silencer, direct exhaust [-S]



Silencer (For EXH port)





VV5Q14-08FU2-D .... 1 set (F kit 8 station manifold base no.) \*VQ1140-5LO-C6 .... 4 sets (Single solenoid part no.) \*VQ1240-5LOB-C6 ···· 4 sets (Double solenoid part no.)

The asterisk denotes the symbol for assembly Prefix it to the part nos. of the solenoid valve, etc.

Please indicate manifold base type, corresponding valve, and option parts. When entry of part numbers becomes complicated, indicate on the manifold specification sheet.




For replacement parts, refer to page 2-4-107.



### Plug Lead Unit: Flip Type

### **How to Order Manifold**




Note 1) Besides the above, F and P kits with different number of pins are available. For details, refer to page 2-4-68.

Note 2) See page 2-4-69 for details.

Note 3) Please consult with SMC for the following serial transmission kits: Matsushita Electric Works, Ltd.; Rockwell Automation, Inc.; SUNX Corporation; Fuji Electric Co., Ltd.; OMRON Corporation.


### **How to Order Valves**



Manifold Option P. 2-4-59

Silencer (For EXH port)

### Blanking plate assembly VVQ2000-10A-4




CB (SUP) port

fitting for ø8


### Name plate [-N4] VVQ2000-N4-Station (1 to Max. stations)

Note 2) Connector assembly will be required when

the F, P, T, S kits add a valve. For part nos., refer to "Option" on page 2-



AN200-KM8




attached to the manifold.

DIN rail mounting bracket VVQ2000-57A-4




B Block valve VQ2 141 - - - R




### Individual EXH spacer VVQ2000-R-4-C8

VVQ2000-P-4-C8



Built-in silencer. direct exhaust [-S]




Port plug VVQ1000-58A



#### KQ2P-06 Blanking plug




### **How to Order Manifold Assembly**





For replacement parts, refer to page 2-4-109

#### Double check block VQ2000-FPG-□□





## Series VQ0000/1000/2000

# Body Ported Plug Lead Unit: Flip Type

### Model

						F	low cha	racteristics			F	esponse time	(2) (ms)	
Series		umber of olenoids	Mod	el	1 → 4,	/2 (P → /	4/B)	4/2 → 5/3	3 (A/B →	R1/R2)	Standard: 1 W	Low wattage:	4.0	Weigh (g)
	50	Dienolus			C [dm <sup>3</sup> /(s·bar)]	b	Cv	C [dm <sup>3</sup> /(s·bar)]	b	Cv	H: 1.5 W	0.5 W	AC	(9)
	_	Single	Metal seal	VQ0140	0.43	0.20	0.10	0.50	0.19	0.12	12 or less	15 or less	29 or less	
	position	Sirigle	Rubber seal	VQ0141	0.49	0.34	0.13	0.59	0.19	0.14	15 or less	20 or less	34 or less	57
		Double	Metal seal	VQ0240	0.43	0.20	0.10	0.50	0.19	0.12	12 or less	15 or less	29 or less	] "
V00000	2	(Latching)	Rubber seal	VQ0241	0.49	0.34	0.13	0.59	0.19	0.14	15 or less	20 or less	34 or less	
VQ0000	ے	Closed	Metal seal	VQ0340	0.34	0.12	0.08	0.36	0.38	0.10	20 or less	26 or less	40 or less	
	position	center	Rubber seal	VQ0341	0.37	0.25	0.09	0.42	0.45	0.12	25 or less	33 or less	47 or less	105
	3 po	Exhaust	Metal seal	VQ0440	0.36	0.21	0.09	0.48	0.18	0.12	20 or less	26 or less	40 or less	105
	center	Rubber seal	VQ0441	0.37	0.31	0.11	0.59	0.24	0.14	25 or less	33 or less	47 or less		
	ت	0: 1	Metal seal	VQ1140	0.77	0.14	0.18	0.84	0.14	0.19	12 or less	15 or less	29 or less	
	position	Single	Rubber seal	VQ1141	0.91	0.19	0.21	1.0	0.21	0.25	15 or less	20 or less	34 or less	57
	2 po	Double	Metal seal	VQ1240	0.77	0.14	0.18	0.84	0.14	0.19	12 or less	15 or less	29 or less	37
		(Latching)	Rubber seal	VQ1241	0.91	0.19	0.21	1.0	0.21	0.25	15 or less	20 or less	34 or less	
V04000		Closed	Metal seal	VQ1340	0.67	0.13	0.16	0.73	0.13	0.17	20 or less	26 or less	40 or less	
VQ1000	_	center	Rubber seal	VQ1341	0.78	0.22	0.18	0.84	0.21	0.20	25 or less	33 or less	47 or less	
	position	Exhaust	Metal seal	VQ1440	0.74	0.14	0.17	0.84	0.16	0.20	20 or less	26 or less	40 or less	70
	3 po	center	Rubber seal	VQ1441	0.78	0.28	0.19	1.0	0.21	0.24	25 or less	33 or less	47 or less	72
	(,	Pressure	Metal seal	VQ1540	0.74	0.14	0.17	0.82	0.18	0.20	20 or less	26 or less	40 or less	
		center	Rubber seal	VQ1541	0.80	0.28	0.19	0.84	0.21	0.22	25 or less	33 or less	47 or less	
	ءِ	Cinala	Metal seal	VQ2140	2.0	0.13	0.43	2.3	0.15	0.58	22 or less	29 or less	49 or less	
V00000	position	Single	Rubber seal	VQ2141	2.3	0.21	0.54	2.7	0.25	0.62	24 or less	31 or less	51 or less	103
VQ2000	2 pg	Double	Metal seal	VQ2240	2.0	0.13	0.43	2.3	0.15	0.58	22 or less	29 or less	49 or less	] 103
	(1	(Latching)	Rubber seal	VQ2241	2.3	0.21	0.54	2.7	0.25	0.62	24 or less	31 or less	51 or less	

Note 1) Cylinder port size C4: (VQ0000), C6: (VQ1000), C8: (VQ2000)


Note 2) As per JIS B 8375-1981 (Supply pressure: 0.5 MPa; with indicator ligh/surge voltage suppressor; clean air) Subject to the pressure and air quality.

#### JIS Symbol






2 position double (Latching)






3 position closed center







(R1)(P)(R2)



	Valve construct	tion	Metal seal	Rubber seal					
	Fluid		Air/Inert gas	Air/Inert gas					
Valve specifications	Maximum oper	ating pressure	0.7 MPa (High press	ure type: 0.8 MPa) (3)					
atio		Single	0.1 MPa	0.15 MPa					
ciffic	Min. operating	Double (Latching)	0.1 MPa	0.15 MPa					
spec	pressure	3 position	0.15 MPa 0.2 MPa						
ve s	Ambient and flu	uid temperature	-10 to 50°C <sup>(1)</sup>						
Val	Lubrication		Not required						
	Manual overrid	е	Push type/Locking type (Tool required, Manual type) Option						
	Impact resistance/Vi	bration resistance (2)	150/3	0 m/s <sup>2</sup>					
	Enclosure		Dust-pr	otected					
	Coil rated volta	ge	12, 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)						
	Allowable volta	ge fluctuation	±10% of rated voltage						
	Coil insulation t	ype	Class B or equivalent						
pic		24 VDC	1 W DC (42 mA), 1.5 W DC (6	3 mA) <sup>(3)</sup> , 0.5 W DC (21 mA) <sup>(4)</sup>					
lenc	Power	12 VDC	1 W DC (83 mA), 1.5 W DC (12	25 mA) <sup>(3)</sup> , 0.5 W DC (42 mA) <sup>(4)</sup>					
So		100 VAC	Inrush 0.5 VA (5 mA),	Holding 0.5 VA (5 mA)					
	consumption	110 VAC	Inrush 0.55 VA (5 mA),	Holding 0.55 VA (5 mA)					
	(Current)	200 VAC	Inrush 1.0 VA(5 mA), I	Holding 1.0 VA (5 mA)					
		220 VAC	Inrush 1.1 VA (5 mA), Holding 1.1 VA (5 mA)						
→ Not	o 1) Lleo dry air to r	rovent condensatio	on when enerating at low temperatures						

Note 1) Use dry air to prevent condensation when operating at low temperatures.

Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Note 3) Values in the case of high pressure type (1.5 W) specifications.

Note 4) Values in the case of low wattage type (0.5 W) specifications.




### Plug Lead Unit: Flip Type Series VQ0000/1000/2000


### **Manifold Specifications**

	a opcomoducióne							
			Р	orting specificat	ions	(2)	Applicable	5 station
Series	Base model	Type of connection	Port location	Port	size (1)	Applicable (2)	solenoid	weight
			Port location	1(P), 3(R)	4(A), 2(B)	Stations	valve	(g)
VQ0000	VV5Q04-□□□	■ F kit—D-sub connector ■ P kit—Flat cable connector ■ T kit—Terminal block ■ C kit—Individual connector ■ S kit—Serial transmission unit	Side	C6 (ø6) Option Built-in silencer, direct exhaust	C3 (ø3.2) C4 (ø4) M5 (M5 thread)		VQ0□40 VQ0□41	225
VQ1000	VV5Q14-□□□	■ F kit—D-sub connector ■ P kit—Flat cable connector ■ T kit—Terminal block ■ C kit—Individual connector ■ S kit—Serial transmission unit	Side	C6 (ø6) Option Built-in silencer, direct exhaust	C3 (ø3.2) C4 (ø4) C6 (ø6) M5 (M5 thread)	1 to 16 stations	VQ1□40 VQ1□41	380
VQ2000	VV5Q24-□□□	■ F kit—D-sub connector ■ P kit—Flat cable connector ■ T kit—Terminal block ■ C kit—Individual connector ■ S kit—Serial transmission unit	Side	C8 (Ø8) Option Built-in silencer, direct exhaust	C4 (Ø4) C6 (Ø6) C8 (Ø8)		VQ2□40 VQ2□41	671

Note 1) Inch-size One-touch fittings are also available. For details, refer to page 2-4-69.

Note 2) See page 2-4-69 for details.





VQC

SQ


VQ0

VQ4

VQ5

VQZ

VQD



- VV5Q04 VV5Q14 VV5Q24
- The D-sub connector reduces installation labor for electrical connections.
- Using the D-sub connector (25P), (15P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.

### Manifold Specifications VV5Q14


	Po	rting spe	ecifications	A months a late			
Series	Port		Port size	Applicable			
	location	1(P), 3(R)	4(A), 2(B)	stations			
VQ0000	Side	C6	C3, C4, M5	Max. 16 stations			
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations			
VQ2000	Side	C8	C4, C6, C8	Max. 16 stations			

### D-sub Connector (25 pins)

Cable assembly



The D-sub connector cable assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold.



D-sub Connector Cable Assembly (Option)	

	iengin (L)		
	1.5 m	AXT100-DS25-015 AXT100-DS25-030	0-11-05
	3 m	AXT100-DS25-030	Cable 25 core x 24AWG
ĺ	5 m	AXT100-DS25-050	X Z4AVVG

\* For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308.

### Connector manufacturers' example

- Fuiitsu Limited
- Japan Aviation Electronics Industry, Ltd
- J.S.T. Mfg. Co., Ltd.

Wire Color by Terminal No. of D-sub Connector Cable Assembly Terminal no. Lead wire color Dot marking

Į.	ыаск	Ivone
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Gray	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Gray	Red
24	Black	White
25	White	None

MΩ/km. 20°C Note) The minimum bending radius of D-sub cable assembly is 20 mm.

**Electric Characteristics** 

Characteristics

65 or less

1000

5 or more

Item

Conductor


O/km 20°C

Insulation resistance V, 1 min, AC


Insulation

resistance

Note) Types with 15 pin are also available. For details, refer to page 2-4-68.




Electrical wiring specifications on the D side.



As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 8 stations or less, regardless of valve and option types. Mixed single and double wiring is available as an option. For details, refer to page 2-4-69.

Note) When using the negative common specifications, use valves for negative common. (Refer to page 2-4-69.)

### **How to Order Manifold**





Side entry


include suffix -D.


Note 3) Specify the wiring specifications on the manifold specification sheet.


### Plug Lead Unit: Flip Type Series VQ0000/1000/2000











### **Dimensions: Side Entry Connector [-FS]**

	L1 = 11n + 15.5		
Formula	L2 = 11n + 28	n: Stations (Maximum	16 stations

L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
L2	39	50	61	72	83	94	105	116	127	138	149	160	171	182	193	204
L3	112.5	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	262.5	275	287.5
L4	123	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	273	285.5	298

### **Dimensions: Top Entry Connector [-FU]**

L	n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	L3	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	212.5	225	225	237.5	250	262.5
I	L4	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	223	235.5	235.5	248	260.5	273

**VQC** 

SQ

VQ0


VQ4


VQ5

**VQZ** 

VQD

### **VQ2000**






Dim	ension	s: Side	e Entr	y Con	necto	r [-FS]	F	Formula L1 = 16n + 29, L2 = 16n + 40 n: Stations (Maximum 16 station								
	n 1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	45	61	77	93	109	125	141	157	173	189	205	221	237	253	269	285
L2	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296
L3	137.5	150	162.5	187.5	200	212.5	225	250	262.5	275	300	312.5	325	337.5	362.5	375
L4	148	160.5	173	198	210.5	223	235.5	260.5	273	285.5	310.5	323	335.5	348	373	385.5

**Dimensions: Top Entry Connector [-FU]** 

L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L3	112.5	137.5	150	162.5	175	200	212.5	225	237.5	262.5	275	287.5	312.5	325	337.5	350
L4	123	148	160.5	173	185.5	210.5	223	235.5	248	273	285.5	298	323	335.5	348	360.5



- VV5Q04 VV5Q14
- MIL flat ribbon cable connector reduces installation labor savings for electrical connection.
- Using the connector for flat ribbon cable (26P), (10P, 16P, 20P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.

### Flat Ribbon Cable (26 pins)

### **Manifold Specifications**


	Po	A			
Series	Port	Р	Applicable stations		
	location	1(P), 3(R)	4(A), 2(B)	otation.	
VQ0000	Side	C6	C3, C4, M5	Max. 16 stations	
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations	
VQ2000	Side	C8	C4, C6, C8	Max. 16 stations	

Stations

### Cable assembly •

### AXT100-FC26-1 to 3

Flat ribbon cable connector assembly can be ordered individually or included ackslash in a specific manifold model no. Refer to How to Order Manifold.



### Flat Ribbon Cable Connector Assembly (Option)

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC26-1	0.11.00
3 m	AXT100-FC26-2	Cable 26 core x 28AWG
5 m	AXT100-FC26-3	X ZOAWG

\* For other commercial connectors, use a 26 pins type with strain relief conforming to MIL-C-83503.


### Connector manufacturers' example

- Hirose Flectric Co. Ltd.
- Japan Aviation Electronics Industry, Ltd.
- Sumitomo 3M Limited Fujitsu Limited
- J.S.T. Mfg. Co., Ltd.
- Oki Electric Cable Co., Ltd.
- Note) Types with 10, 16, or 20 pin are also available. For details, refer to page 2-4-69.

### VV5Q14

VV5Q24


#### The total number of stations is tabulated starting from station Electrical wiring specifications • one on the D side.



As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for  $8\,$ stations or less, regardless of valve and option types. Mixed single and double wiring is available as an option. For details, refer to page 2-4-69.

> so include suffix -D. Note 3) Specify the wiring specifications on the manifold specification sheet.

### **How to Order Manifold**



S

Side entry


Cylinder port is located at U

side of body



78.5 (L plug connector)
73.5 (L plug connector)


4.





Dimensions: Side Entry Connector [-PS] Formula L1 = 10.5n + 14.5 L2 = 10.5n + 25 n: Station (Maximum 16 stations) 9 10 11 12 13 14 16 5 6 8 15 119.5 130 151 172 182.5 35.5 109 140.5 161.5 46 56.5 67 88 98.5 119.5 130 140.5 151 5 200 212.5 212.5 225 35.5 46 77.5 88 98.5 109 L2 56.5 67 161.5 172 182.5 193 137.5 150 150 162.5 175 (L3) 112.5 125 187.5 200 237.5 250 262.5 275 **(L4)** 123 | 135.5 | 148 | 160.5 | 160.5 | 173 | 185.5 | 198 210.5 223 223

**Dimensions: Top Entry Connector [-PU]** 

<u>l</u>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L3	87.5	100	112.5	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250
L4	98	110.5	123	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5








Dimer	<b>Dimensions: Side Entry Connector [-PS]</b> Formula L1 = 11n + 15.5, L2 = 11n + 28 n: Stations (Maximum 16 stations)															
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
L2	39	50	61	72	83	94	105	116	127	138	149	160	171	182	193	204
L3	112.5	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	262.5	275	287.5
L4	123	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	273	285.5	298


### **Dimensions: Top Entry Connector [-PU]**

	n 1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L3	87.5	100	112.5	125	137.5	150	162.5	162.5	175	187.5	200	212.5	225	237.5	250	262.5
L4	98	110.5	123	135.5	148	160.5	173	173	185.5	198	210.5	223	235.5	248	260.5	273





Top entry connector [-PU] 55.5 (M plug connector AC, Latching) 50.5 (M plug connector) 49 (L plug connector AC, Latching) 44 (L plug connector) Indicator light 115 (L pug connector) 109 (M plug connector)




Dimensions: Side Entry Connector [-PS]		ula L1 = '							
0 1 0 0 7	_	_	40	44	10	40	4.4	4-	4.0

Dimensions: Side Entry Connector [-PS]								Formula L1 = 16n + 29, L2 = 16n + 40 n: Stations (Maximum 16 stations)						stations)		
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	45	61	77	93	109	125	141	157	173	189	205	221	237	253	269	285
L2	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296
L3	137.5	150	162.5	187.5	200	212.5	225	250	262.5	275	287.5	312.5	325	337.5	362.5	375
L4	148	160.5	173	198	210.5	223	235.5	260.5	273	285.5	298	323	335.5	348	373	385.5

### **Dimensions: Top Entry Connector [-PU]**

L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L3	112.5	125	137.5	162.5	175	187.5	200	225	237.5	250	262.5	287.5	300	312.5	337.5	350
L4	123	135.5	148	173	185.5	198	210.5	235.5	248	260.5	273	298	310.5	323	348	360.5





- It is a standard terminal block type.
- Two quantities of terminals can be selected in accordance with the number of stations.


(8 terminals/16 terminals)

Maximum stations are 16.

### **Manifold Specifications**

	Po	rting spe	ecifications		
Series	Port		Port size	Applicable	
	location	1(P), 3(R)	4(A), 2(B)	stations	
VQ0000	Side	C6	C3, C4, M5	Max. 16 stations	
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations	
VQ2000	Side	C8	C4, C6, C8	Max. 16 stations	

### Electrical wiring specifications



T1 (Terminal block of 1 row): 1 to 4 stations
T2 (Terminal block of 2 rows): 5 to 8 stations

T1 and T2 can be optionally chosen by adopting the combinations of single and double wiring (optional spec.), etc.

The quantity of terminal blocks used depends on the number of manifold stations.


Manifold	No. of terminals
1 to 4 stations	1 row
5 to 8 stations	2 rows

Wiring other than those above is possible. See page 2-4-69 for details.



Double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station, regardless of valve and option types. Mixed single and double wiring is available as an option.

For details, refer to page 2-4-69.




#### How to connect wires to terminal block

Open the terminal block cover to connect the wires to the terminal block.

(With M3 thread)

### **How to Order Manifold**



1 VQ1000 2 VQ2000

Plug lead unit/Flip

Stations



Note 1) For negative common specifications, refer to "Option" on page 2-4-69.

Note 2) As option, the maximum number of stations can be increased based on special wiring specifications. For details, refer to page 2-4-69.

### Option

<b>D</b> (2)	DIN rail mounting style
K (3)	Special wiring specifications (Except double wiring)
N	With name plate
S	Built-in silencer, direct exhaust (U side only)

Note 1) When two or more symbols are specified, indicate them alphabetically.


Example) -DNS

Note 2) T kits are DIN rail mounted type, so include suffix -D.


Note 3) Specify the wiring specifications in the manifold specification sheet.

#### Number of terminals

1	8 terminals in 1 row	Applicable stations 1 to 4 stations (Double), 8 stations (Single)						
2	16 terminals in 2 rows	Applicable stations 5 to 8 stations (Double), 16 stations (Single)						
■ N++>=								



### Plug Lead Unit: Flip Type Series VQ0000/1000/2000



**SMC** 

Note 1) 2 stations space are occupied.

Note 1) For negative common specifications, refer to "Option" on page 2-4-69.

Note 2) Connector assembly will be required when the T kits add a valve. For model no., refer to "Option" on page 2-4-69.

Note 2) L plug connector is used for AC

LO L plug connector without connector


MO M plug connector without connector

Note) Plug connector and lead wire

layers are attached to the manifold.

### Series VQ0000/1000/2000

### **VQ1000**



me		

ı	חוט	ensi	ons					Form	ula L1 =	= 11n + <sup>-</sup>	15.5, L2	= 11 n -	+ 28 n	: Station	(Maxim	um 16 s	stations)
į	L n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
ĺ	L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
Ī	L2	39	50	61	72	83	94	105	116	127	138	149	160	171	182	193	204
	L3	112.5	112.5	125	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5	275
Ī	L4	123	123	135.5	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273	285.5

**VQC** 

SQ

VQ0


VQ4

VQ5

VQZ

**VQD** 

### **VQ2000**



The drawing shows the case of VV5Q24-□T2.

Dim	ensi	ons	Formula L1 = $16n + 29$ , L2 = $16n + 40$ n: Station (Maximum 16 stations)									stations)				
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	45	61	77	93	109	125	141	157	173	189	205	221	237	253	269	285
L2	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296
L3	125	137.5	150	175	187.5	200	225	237.5	250	262.5	287.5	300	312.5	337.5	350	362.5
L4	135.5	148	160.5	185.5	198	210.5	235.5	248	260.5	273	298	310.5	323	348	360.5	373







- Standard with lead wires connected to each valve individually.
- Maximum stations are 16.


### **Manifold Specifications**

	Po	rting spe	ecifications			
Series	Port		Applicable stations			
	location	1(P), 3(R)	stations			
VQ0000	Side	C6	C3, C4, M5	Max. 16 stations		
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations		
VQ2000	Side	C8	C4, C6, C8	Max. 16 stations		






### Wiring specifications: Positive COM



• The lead wires are connected to the valve as shown below.



• Plug connector lead wire length Note) The lead wire length of the valves with lead wire is 300 mm. When ordering a valve with a lead wire of 600 mm or longer, be sure to indicate the model number of the valve without connector and connector assembly.

White (Gray) [Gray]:
B side solenoid (-)

Example) Lead wire length 1000 mm
VQ1140-5LO-C6... 3 pcs.
AXT661-14A-10 ... 3 pcs.


### Connector Assembly Part No. (For DC)


Lead wire length	Single/3 position part no.	Double solenoid part no.
Socket only (3 pcs.)	AXT66	61-12A
300 mm	AXT661-14A	AXT661-13A
600 mm	AXT661-14A-6	AXT661-13A-6
1000 mm	AXT661-14A-10	AXT661-13A-10
2000 mm	AXT661-14A-20	AXT661-13A-20
3000 mm	AXT661-14A-30	AXT661-13A-30

Note 1) 100/110 VAC for single: AXT661-31A-\*; for double: AXT661-32A-\* 200/220 VAC for single: AXT661-34A-\*; for double: AXT661-35A-\* are in accordance with the above table.

Note 2) 3 position type requires 2 sets for A side and B side.

### Wiring specifications: Negative COM (Option)





with a lead wire of 600 mm or longer, be sure to indicate the model number of the valve without connector and connector assembly.

Example) Lead wire length 1000 mm VQ1140-5LO-C6...3 pcs. AXT661-14A-10 ...3 pcs.

White: B side solenoid (+)


### **Connector Assembly Part No.**

Lead wire length	Single/3 position part no.	Double solenoid part no.				
Socket only (3 pcs.)	AXT661-12A					
300 mm	AXT661-14AN	AXT661-13AN				
600 mm	AXT661-14AN-6	AXT661-13AN-6				
1000 mm	AXT661-14AN-10	AXT661-13AN-10				
2000 mm	AXT661-14AN-20	AXT661-13AN-20				
3000 mm	AXT661-14AN-30	AXT661-13AN-30				


Note 1) When using the negative common specifications, use valves for negative common.


Note 2) 3 position type requires 2 sets for A side and B side.

### **How to Order Manifold**



### Plug Lead Unit: Flip Type Series VQ0000/1000/2000





3 position (L/M plug connector) 3 position (Grommet)

 $\otimes$ 

8 串串


Dim	ensi	ons		Formula L1 = 11n + 15.5, L2 = 11n + 28 r								n: Sta	ation (M	/laximu	m 16 st	tations)
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
L2	39	50	61	72	83	94	105	116	127	138	149	160	171	182	193	204
(L3)	62.5	75	87.5	100	112.5	125	125	137.5	150	162.5	175	187.5	200	212.5	212.5	225
(L4)	73	85.5	98	110.5	123	135.5	135.5	148	160.5	173	185.5	198	210.5	223	223	235.5

2n-C3, C4, C6, M5

M5: M5 thread

C3: One-touch fitting for ø3.2

C4: One-touch fitting for ø4 C6: One-touch fitting for ø6 P = 11




Di	im	ensi	ons		Formula $L1 = 16n + 29$ , $L2 = 16n + 40$							ı + 40	n: Station (Maximum 16 stations)				
	n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L	_1	45	61	77	93	109	125	141	157	173	189	205	221	237	253	269	285
L	_2	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296
(L	_3)	87.5	100	112.5	125	150	162.5	175	187.5	212.5	225	237.5	262.5	275	287.5	300	325
(L	_4)	98	110.5	123	135.5	160.5	173	185.5	198	223	235.5	248	273	285.5	298	310.5	335.5

C8: One-touch fitting for ø8
01: R 1/8 thread

## VQ0000/1000/2000 Kit (Serial transmission unit)

- The serial transmission system reduces wiring work, while minimizing wiring and saving space.
- The system comes in an type SA (generic for small scale systems) for equipment with a small number of I/O points, or 32 points max., type SB (applicable to Mitsubishi Electric models) for controlling 512 I/O points max., type SC (applicable to OMRON models), and type SD (applicable to SHARP models; 504 points

Maximum 8 stations, optional 16 stations possible. (16 stations available as an option. Indicate 9 to 16 stations on the manifold



Item	Specifications
External power supply	24 VDC±10%
Current consumption (Internal unit)	SA, SB, SD, SFI, SH: 0.1 A/SC: 0.3 A

Mixed

### **Manifold Specifications**

VV5Q04

	Po	rting sp	ecifications	
Series	Port		Port size	Applicable
	location	P, R	A, B	stations
VQ0000	Side	C6	C3, C4, M5	Max. 16 stations
VQ1000	Side	C6	C3, C4, C6, M5	Max. 16 stations
VQ2000	Side	C10	C4, C6, C8	Max. 16 stations

VV5Q14

VV5Q24

	Type SA With general type SI unit (Series EX300)	Type SB Mitsubishi Electric Corporation MELSECNET/MINI-S3 Data Link System
Name of terminal block (LED)	ADDRESS NO.	POWER RUN SO RO SRID WITH UT UT UT UT UT UT UT UT UT UT UT UT UT
Name of termir	LED Description TRD Lighting during data reception RUN/ERR Blinking when received data is normal; Lighting when data reception	LED Description  POWER Lighting when power is turned ON  RUN Lighting when data transmission with the master station is normal  RD Lighting during data reception  SD Lighting during data transmission  ERR. Lighting when reception data error occurs. Light turns off when the error is corrected.
Note	Tunit Can be connected with PLC I/O card for serial transmission.  EX300-TMB1 For models of Mitsubishi Electric Corporation  EX300-TTA1 For models of OMRON Corporation  EX300-TFU1 For models of Fuji Electric Co., Ltd.  EX300-T001 For general models  *Up to 32 points per unit.  No. of output points, 16 points	Master station: PLC made by Mitsubishi Electric Corporation Series MELSEC-A AJ71PT32-S3, AJ71T32-S3 A1SJ71PT32-S3 * Max. 64 stations, connected to remote I/O stations (Max. 512 points). No. of output points, 16 points. No. of sta. occupied, 2 stations


### **How to Order Manifold**

VV5Q

regardless of valve and option types.

single and double wiring is available as an option. For details, refer to page

2-4-69



08 S

16 16 stations (Single) As option, the max. number of stations can be increased based on special wiring specifications. For details, refer to page 2-4-69.

serial transmission kits: Matsushita Electric Works, Ltd.; Rockwell Automation, Inc.; SUNX Corporation; Fuji Electric Co., Ltd.; OMRON Corporation.

\* The dust-protected type SI unit is applicable, too. For details, please contact SMC.

### Option

<b>D</b> (2)	DIN rail mounting style
<b>K</b> (3)	Special wiring specifications (Except double wiring)
N	With name plate
S	Built-in silencer, direct exhaust (U side only)

Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -DNS

Note 2) S kits are DIN rail mounting styles, so include suffix -D

Note 3) Specify the wiring specifications in the manifold specification sheet.

**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ

VQD

### Plug Lead Unit: Flip Type Series VQ0000/1000/2000

### SI unit output and coil numbering

<Wiring example 1> Double wiring (Standard)

2 3 4 5 6 SI unit output no. (Looked by double solenoid valve) SOL. location ----Double 3 position Single Single Dou  $\overline{S}$ 2 5 Stations

<Wiring example 2> Single/Double Mixed Wiring (Option) Mixed wiring is available as an option. Use the manifold specification sheet to specify.

SI un outpu	t no.	0	1	2	3	4		5		6	7
(Looked by do solenoid valve) SOL. location	uble ) 	Α	В	A	В	Α	В	A	В	A	В
	SI Unit	4	Double	4	Double	1	eligine	3	Single	c cition	o position
	Stations		1	2	2	•	3	4	4	Ę	5

The places of asterisk are not used.

**How to Order Valves** 

Type of actuation VQ0000 VQ1000 VQ2000

Note 1) 2 stations space are occupied

Note 2) L plug connector is used for AC.

Series 6 VQ0000

VQ1000 VQ2000

1 2 position single

2 position double (Latching)

3 | 3 position closed center 4 3 position exhaust center

5 3 position pressure center

1

Type SC Type SD OMRON Corporation SYSBUS Wire System **SHARP Corporation** Satellite I/O Link System Name of terminal block (LED) POWER RUN SO RD FRE RUN ¤TRD LED Description LED Description Lights when transmission is normal **POWER** ON when power supply is ON RUN Lights when power is ON and and PLC is in operation mode slave stations are operating normally T/R Blinks during data transmission/reception Lights when slave station switch setting is abnormal, communication is abnormal **ERR** ON when transmission is abnormal **ERROR** PLC stopped and defective slave unit ON for master unit control input · Master station unit: Master station unit: **OMRON PLC** SHARP's PLC SYSMAC C(CV) series New Satellite Series W Types C500-RM201 and C200H-RM201 ZW-31LM \* 32 units max., transmission terminal connection New Satellite Series JW (512 points max.) JW-23LM, JW-31LM . No. of output points, 16 points Max. 31 units, I/O slave stations connected (504 points max.) • No. of output points, 16 points

0 | Y | 5 | LO

Seal

**(**2)

**(**2)

(1)

0 Metal seal

1 Rubber seal

5

Function

Nil

H

Symbol Specifications DC

Standard type

High pressure type (1.5 W)

Low wattage type (0.5 W)

Note) Except double

(latching).

24 VDC/With light/surge voltage suppressor

a valve.

Note 1) Connector assembly will be

required when the S kits add

For part nos., refer

"Option" on page 2-4-69.

(1.0 W)

Coil voltage



Specify the part numbers for valves and options together beneath the manifold base part number.

Cylinder port

		<u> </u>								
	Symbol	Port size	VQ0000	VQ1000	VQ2000					
	C3	With One-touch fitting for ø3.2	•	•	_					
	C4	With One-touch fitting for ø4	•	•	•					
	C6	With One-touch fitting for ø6	-	•	•					
	C8	With One-touch fitting for ø8	_	_	•					
	M5	M5 thread	•	•	_					
	Note) For inch-size One-touch fittings, refer to "Option" on page 2-4-69.									
M	Manual override									


Nil	Non-locking push type (Tool required)					
В	Locking type (Tool required)					
C Locking type (Manual)						
	Note 1) All double latching valves of VQ0000 are non-locking push type. (Refer to page 2-4-66.)					

ル Note 2) A manual override for pilot valve is provided to the standard model for double type.

Electrical entry

LO L plug connector without connector MO M plug connector without connector


Note 1) Plug connector and lead wire layers are attached to the manifold.




**Dimensions** Formula L1 = 10.5n + 14.5, L2 = 10.5n + 25 n: Station (Maximum 16 stations) /5 1 2 3 4 5 6 9 10 11 12 13 14 15 16 L1 46 77.5 161.5 172 182.5 25 35.5 56.5 67 88 98.5 109 119.5 130 140.5 151 35.5 46 56.5 67 77.5 88 98.5 109 119.5 130 140.5 151 161.5 172 **L3** 200 212.5 225 275 287.5 300 312.5 312.5 325 337.5 350 362.5 237.5 250 250 262.5 **L4** 210.5 223 235.5 248 260.5 260.5 273 285.5 298 310.5 323 323 335.5 348 360.5 373

Note 2) 3 position needs two stations.

Cylinder port is located U side of body.



ı	<b>Dimensions</b> Formula L1 = 11n + 15.5, L2 = 11n + 28 n: Station (Maximum 16 stations)											tations)					
Ì		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	L1	26.5	37.5	48.5	59.5	70.5	81.5	92.5	103.5	114.5	125.5	136.5	147.5	158.5	169.5	180.5	191.5
	L2	39	50	61	72	83	94	105	116	127	138	149	160	171	182	193	204
	L3	212.5	212.5	225	237.5	250	262.5	275	287.5	300	300	312.5	325	337.5	350	362.5	375
	L4	223	223	235.5	248	260.5	273	285.5	298	310.5	310.5	323	335.5	348	360.5	373	385.5




Dim	<b>Dimensions</b> Formula L1 = 16n + 29, L2 = 16n + 40 n: Station (Maximum 16 stations)															
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	45	61	77	93	109	125	141	157	173	189	205	221	237	253	269	285
L2	56	72	88	104	120	136	152	168	184	200	216	232	248	264	280	296
L3	225	237.5	250	275	287.5	300	325	337.5	350	362.5	387.5	400	412.5	437.5	450	462.5
L4	235.5	248	260.5	285.5	298	310.5	335.5	348	360.5	373	398	410.5	423	448	460.5	473

### Plug Lead Unit: Flip Type Series VQ0000/1000/2000

### **Manifold Option Parts for VQ0000**

### Blanking plate assembly VVQ0000-10A-4

It is used when a blanking plate is mounted to a manifold in advance for possible valve mounting, etc.






### Individual SUP spacer VVQ0000-P-4-C4

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.) Since the SUP passage on the spacer's D side is blocked in advance, it is mounted on the D side of the valve for individual supply while blocking the valve's U side. (See the application ex.)

 Specify the spacer mounting position and SUP block plate mounting position on the manifold specification sheet.

# Shut off label C4 (SUP) port One-touch fitting for ø4 SUP passage blocked

Note) P block valve is mounted in the blocking position when ordering an individual SUP spacer incorporated with a manifold. When separately ordering an individual SUP spacer, separately order a P block valve.



VQ0 VQ4

**VQC** 

SQ

VQ4


VQZ

VQD


### Individual EXH spacer VVQ0000-R-4-C4

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.) Since the EXH passage on the spacer's D side is blocked in advance, it is mounted on the D side of the valve for individual supply while blocking the valve's U side. (See the application ex.)

 Specify the spacer mounting position and EXH block plate mounting position on the manifold specification sheet.



Note) R block valve is mounted in the blocking position when ordering an individual EXH spacer incorporated with a manifold. When separately ordering an individual EXH spacer, separately order a R block valve.



R block valve

### Block valve

VQ01 41 - - - - R


For a flip plug-in unit, block plate is built in the valve for blocking SUP and EXH passages. Since the no. is classified by the passage to be blocked, specify it by attaching the option no. to the valve no. The block valve is constructed so that U sides of SUP and EXH passages are blocked.

\* Specify the number of stations on the manifold specification sheet.


### <Shut off label>


When using block plates for SUP, EXH passage, indication label for confirmation of the blocking position from outside is attached. (One label for each)


- \* When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold.
- \* Caution on handling P/RP block valve For manifold other than C kit which is silencer built-in, there's no exhaust port on the D side end plate. Install a spacer for individual EXH on the 1st station separately.












### Name plate [-N4] VVQ0000-N4-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.






\* When ordering assemblies incorporated with a manifold, suffix -N to the manifold no

### Blanking plug KQ2P-23 CA

It is inserted into an unused cylinder port and SUP/EXH ports.

Purchasing order is available in units of 10 pieces.





Dimensions	;
Applicable fittings	

Applicable fittings size ød	Model	A	L	D
3.2	KQP-23	16	31.5	3.2
4	KQP-04	16	32	6
6	KQ2P-06	18	35	8

### Series VQ0000/1000/2000

### Manifold Option Parts for VQ0000

### DIN rail mounting bracket VVQ0000-57A-4

It is used for mounting a manifold on a DIN rail. The DIN rail mounted bracket is fixed to the manifold end plate.

(The specification is the same as that for the option

1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).


### Built-in silencer, Direct exhaust [-S]

This is a type with an exhaust port atop the manifold end plate. The built-in silencer exhibits an excellent noise suppression effect.

F, P, T and S kits are provided with exhaust on one side

with drainage.








When ordering assemblies incorporated with a manifold, add suffix -D to the manifold no.








U side


When ordering assemblies incorporated with a manifold, add suffix -S to the manifold no.



### Manifold Option Parts for VQ1000


### Blanking plate assembly VVQ1000-10A-4

It is used when a blanking plate is mounted to a manifold in advance for possible valve mounting, etc



Exhaus


D side




### Individual SUP spacer VVQ1000-P-4-C6

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.) Since the SUP passage on the spacer's D side is blocked in advance, it is mounted on the D side of the valve for individual supply while blocking the valve's U side. (See the application ex.)

\* Specify the spacer mounting position and SUP blocked block plate mounting position on the manifold specification sheet.





Note) P block valve is mounted in the blocking position when ordering an individual SUP spacer incorporated with a manifold. When separately ordering an individual SUP spacer, separately order a P block valve.


### Individual EXH spacer VVQ1000-R-4-C6

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.)

Since the EXH passage on the spacer's D side is blocked in advance, it is mounted on the D side of the valve for individual supply while blocking the valve's U side. (Refer to the application example.) EXH pass

- Specify the spacer mounting position and EXH blocked block plate mounting position on the manifold specification sheet.
- When the electrical entry is F, P, T, S kit, and if you choose the option with built-in silencer, no exhaust port will be supplied on the D side end

In this case, install a spacer for individual EXH on the 1st station.



Note) R block valve is mounted in the blocking position when ordering an individual EXH spacer incorporated with a manifold. When separately ordering an individual EXH

spacer, separately order an R block valve.

### Plug Lead Unit: Flip Type Series VQ0000/1000/2000

### **Manifold Option Parts for VQ1000**

### 点 Block valve VQ1240-□-E


For a flip plug-in unit, block plate is built in the valve for blocking SUP and EXH passages. Since the no. is classified by the passage to be blocked, specify it by attaching the option no. to the valve no. The block valve is constructed so that D sides of SUPand EXH passages are blocked.

\* Specify the number of stations on the manifold specification sheet

#### <Shut off label>

When using block plates for SUP, EXH passage, indication label for confirmation of the blocking position from outside is attached. (One label for each)

- \*When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold.
- \*Caution on using R/PR block valve If the electrical entry is selected for an option for builtin silencer when F, P, T, S kit, there will not be the exhaust port on the D side end plate. In this case, mount an individual EXH spacer for the 1st station



SUP pass

EXH passage blocked

SUP/EXH ge blocke

For SUP passage block VQ1 ½4° -□-□□-P For EXH passage block For SUP/EXH passage block VQ1 ½41°-□-□□-R VQ1 1/2 41 - □ - □ - PR

**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ


VQD

### Name plate [-N4]

#### VVQ1000-N4-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that Indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.






When ordering assemblies incorporated with manifold. suffix [-N] to the manifold no.

### **Blanking plug** KQ2P- 04

It is inserted into an unused cylinder port and SUP/EXH ports.

Purchasing order is available in units of 10 pieces.





### **Dimensions**


Applicable fittings size ød	Model	Α	L	D
3.2	KQ2P-23	16	31.5	5
4	KQ2P-04	16	32	6
6	KQ2P-06	18	35	8

### DIN rail mounting bracket VVQ1000-57A-4

It is used for mounting a manifold on a DIN rail. The DIN rail mounted bracket is fixed to the manifold end plate. (The specification is the same as that for the option -D.)

1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).

### DIN rail clamp screw






When ordering assemblies incorporated with manifold, add suffix manifold no. -D

### Built-in silencer, Direct exhaust [-S]

This is an exhaust port on top of the manifold end plate. The built-in silencer exhibits an excellent noise suppression effect. F, P, T and S kits are provided with exhaust on one side.

Note) A large quantity of drainage generated in the airsource results in exhaust of air together with drainage

For maintenance, refer to page 2-4-67.





When ordering assemblies incorporated with manifold, add suffix -S to the manifold no.

### Silencer (For EXH port)

This is inserted into the centralized type EXH port (One-touch fitting).





#### **Dimensions**

>	Series	Applicable fittings size ød	Model	A	L	D	Effective area (mm²)	Noise reduction (dB)
	VQ1000	6	AN103-X233	20	37	11	7	25

#### Port plug VVQ0000-58A

The plug is used to block the cylinder port when using a 4 port valve as a 3 port valve.

When ordering it incorporated with a manifold, suffix A or B, the symbol of the plug port, to the valve no

valve no. Example) **VQ1140-5L-C6-A** L

A port, Plug







### Series VQ0000/1000/2000

### **Manifold Option Parts**

### Double check block (Separated type): For VQ0000/1000


**VQ1000-FPG-**□□

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the double check block with a built-in pilot type double check valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time.

The combination with a two position single/double solenoid valve will permit this block to be used for preventing the dropping at the cylinder stroke end when the SUP residual pressure is released.

#### **Specifications**


Max. operating pressure	0.8 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temperature	−5 to 50° C
Flow characteristics: C	0.60 dm3/(s.bar)
Max. operating frequency	180 CPM






Note) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa)

#### **Dimensions**





VVQ1000-FPG- 06 **Stations** 

> 01 16 16 stations

### <Example>

VVQ1000-FPG-06····6 types of manifold \*VQ1000-FPG-C4M5-D, 3 sets Double

Double check block \*VQ1000-FPG-C6M5-D, 3 sets

### 

- Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for a long time. Check the leakage using neutral household detergent, such as dish washing soap. Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.
  Since One-touch fittings allow slight air leakage, screw piping (with M5 thread) is recommended when
- stopping the cylinder in the middle for a long time.

  Combining double check block with 3 position closed center or pressure center solenoid valve will not
  - M5 fitting assembly is attached, not incorporated into the double check block. After screwing in the M5 fittings, mount the assembly on the double check block. {Tightening torque: 0.8 to 1.2
- If the exhaust of the double check block is throttled too much, the cylinder may not operate properly and
- may not stop intermediately.

   Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.



**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ


VQD


### Plug Lead Unit: Flip Type Series VQ0000/1000/2000

### **Manifold Option Parts for VQ2000**

### Blanking plate assembly VVQ2000-10A-4

It is used when a blanking plate is mounted to amanifold in advance for possible valve mounting, etc






### Individual SUP spacer VVQ2000-P-4-C8

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.)

Since the SUP passage on the spacer's D side is blocked in advance, it is mounted on the D side the valves U side. (Refer to the application example.)

\* Specify the spacer mounting position and SUP block plate mounting position on the manifold specification sheet.




Note) P block valve is mounted in the blocking position when ordering an individual SUP spacer incorporated with a manifold. When separately ordering an individual SUP spacer, separately order a P block valve.

### Individual EXH spacer VVQ2000-R-4-C8

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (1 station space is occupied.)

Since the EXH passage on the spacer's D side is blocked in advance, it is mounted on the D side of the valve for individual supply while blocking the valves U side. (Refer to the application example.)

- \* Specify the spacer mounting position and EXH block plate mounting position on the manifold specification sheet
- \* When the electrical entry is F, P, T, S kit, and if you choose the option with built-in silencer, no exhaust port will be supplied on the D side end plate. In this case, mount a spacer for individual FXH on the 1st station



### Block valve VQ2 14 1-----

For a flip plug-in unit, block plate is built in the valve for blocking SUP and EXH passages. Since the no. is classified by the passage to be blocked, specify it by attaching the option no. to the valve no. The block valve is constructed so that U sides of SUP and EXH passages are blocked.

\* Specify the number of stations on the manifold specification sheet.

### <Shut off label>

When using block plates for SUP, EXH passage, indication label for confirmation of the blocking position from outside is attached.

(One label for each)


- \* When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold.
- \* Caution on handling P/RP block valve When the electrical entry is F, P, T, S kit, and if you choose the option with built-in silencer, no exhaust port will be supplied on the D side end plate. In this case, mount a spacer for individual EXH on the 1st station





SUP passage blocked












For SUP passage block	VQ2 ½41 -□-□□-P
For EXH passage block	VQ2 ½41 -□-□□-R
For SUP/EXH passage block	VQ2 ½41°-□-□□-PR




### Series VQ0000/1000/2000

### **Manifold Option Parts for VQ2000**

### Name plate [-N4] VVQ2000-N4-Station (1 to Max. stations)


It is a transparent resin plate for placing a label that Indicates solenoid valve function, etc.

Insert it into the groove on the side of the end plate and bend it as shown in the figure.





 When ordering assemblies incorporated with a manifold, add suffix N to the manifold no.




### **Blanking plug**

### KQ2P-04

It is inserted into an unused cylinder port and SUP/EXH ports.

Purchasing order is available in units of 10 pieces.






#### **Dimensions**

Applicable fittings size ød	Model	Α	L	D
4	KQ2P-04	16	32	6
6	KQ2P-06	18	35	8
8	KQ2P-08	20.5	39	10

### DIN rail mounting bracket VVQ2000-57A-4

It is used for mounting a manifold on a DIN rail. The DIN rail mounting bracket is fixed to the manifold end plate. (The specification is the same as that for the option -D.)

1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).



### **Built-in silencer, Direct exhaust [-S]**


This is type with an exhaust port atop the manifold endplate. The built-in silencer exhibits an excellent noise suppression effect.

F, P, T and S kits are provided with exhaust on one side

Note) A large quantity of drainage generated in the air source results in exhaust of air together with drainage



• For maintenance, refer to page 2-4-67.







\* When ordering assemblies incorporated with a manifold, add suffix -S to the manifold no.

### Silencer (For EXH port)

This silencer is to be inserted into the EXH port (One-touch fittings) of the common exhaust.






### Port plug VVQ1000-58A

The plug is used to block the cylinder port when using 4 port valve as a 3 port valve.

When ordering it incorporated with a manifold, suffix A or B, the symbol of the plug port, to the valve no.

Example) VQ2140-5L-C8-A

A port, Plug





### Plug Lead Unit: Flip Type Series VQ0000/1000/2000

### **Manifold Option**

### Double check block (Separated type)

**VQ2000-FPG-**□□-□

It is used on the outlet side piping.

Combining the double check block with built-in pilot double check valve and a two-position single/double solenoid valve will prevent the dropping at the cylinder stroke end when the SUP residual pressure is released.

### **Specifications**

Maximum operating pressure	0.8 MPa
Ambient and fluid temperature	0.15 MPa
Ambient and fluid temp.	–5 to 50° C
Flow characteristics: C	3.0 dm <sup>3</sup> /(s·bar)
Max. operating frequency	180 c.p.m

Note) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa)

# <Check valve operation principle> Cylinder side SUP side pressure (P1)

**VQC** 

SQ

VQ0


VQ4

VQ5


VQZ

VQD

### **Dimensions**



### **How to Order**



### VVQ2000-FPG- 06 Stations 1 station <Ordering Example>

VVQ2000-FPG-06....6 stations manifold

\*VQ2000-FPG-C6C6-D: 3 sets } Double check block \*VQ2000-FPG-C8C8-D: 3 sets }

- Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for a long time. Check the leakage using neutral household detergent, such
  - Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.
- Since One-touch fittings allow slight air leakage, screw piping (with M5 thread) is recommended when stopping the cylinder in the middle for a long time.

Rc 1/8

Rc 1/4

- When screwing the fittings in the double check block, proper tightening torque is as shown below:
- If the exhaust of the double check block is throttled too much, the cylinder may not properly and may not stop intermediately
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.



Connection threads Proper tightening torque (N·m)

7 to 9

12 to 14


#### ♠ Precautions


Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.

#### Light/Surge Voltage Suppressor

#### **⚠** Caution

The lighting positions are concentrated on one side for both single solenoid and double (latching) type. In the double (latching) type, A side and B side energization are indicated by two colors which match the colors of the manual overrides.





#### **Double (Latching solenoid) Type**

#### **⚠** Caution

Different from the conventional double solenoid, the double type uses a latching (self-holding system) solenoid. Although the appearance is the same as the single solenoid, it is constructed so that the movable iron core in the solenoid is held in the ON position on A and B sides by instantaneous energization (20 ms or more).

The usage and function is the same as the double solenoid.

#### <Special Cautions for Latching Solenoid>

- 1. Select the circuit in which ON and OFF signals are not energized simultaneously.
- 2. 20 ms energization time is necessary for self-holding.
- 3. Avoid using the latching solenoid valves in environments where impact or collisions with the valve might occur. Also, do not use in places where strong magnetic fields are present.
- 4. Even though the armature in the solenoid of this valve is held on to B side, ON position (Reset), verify either A side, ON position or B side, ON position by energizing prior to use.
- 5. After manual operation, the main valve will return to its original position. Manual override on the pilot valve side can retain its switching position after manipulation.
- 6. Please contact SMC for long-term energization applications.
- 7. If the metal seal type goes down below the minimum operating pressure of supply air (0.1 MPa or less), the main valve will get back the home position. (B side ON position) Therefore, in the event of shutting the supply air or applying the air with being A side ON position remained, cylinder may be pulsated. In the event of manipulating the supply air, the valve's switching position has to be set in the home position side (B side ON position side).

#### **How to Mount/Remove Solenoid Valve**


#### $oldsymbol{\Delta}$ Caution

#### <Procedure>

#### How to Remove

- 1. Loosen tie-rod bolt B. (Two to four turns) 2. After fully loosening the tie-rod bolt, take
- off bolt A upward as shown above. 3. Slide the valves aside to make a 1 mm clearance between the valve to be taken off and the others. As shown above, remove the whole valve while

holding up the (a) side. (Avoid rough handing of the connector.)



ie-rod bolt A

#### Mounting

Reverse the sequence of steps above to remount.

Tighten the tie-rod bolts with the tightening torque at the right table while using caution not to tighten the only one side unevenly.

#### **Torque Applied to Tie-rod Bolt** VQ0000 0.5 to 0.7 N·m VQ1000 1.0 to 1.4 N·m VQ2000

1.0 to 1.4 N·m


Note) Be careful not to push on the light cover while mounting/removing the valve

#### **Double (Latching solenoid) Type**


#### 🕰 Warning

Without an electric signal for the solenoid valve the manual override is used for switching the main valve.


#### ■ Push type (Tool required)



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.




If the manual override is turned by 180° clockwise and the mark is adjusted to 1, then pushed in the direction of an arrow ( $\downarrow$ ), it will be locked in the ON state. If the manual override is turned by 180 counterclockwise and ▶ mark is adjusted to 0, locking will be released and the manual override will return.



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.


#### ■ Locking lever type (Option)



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it

#### ■ Manual override for double (latching) type

In the case of a double (latching) type, a manual override is provided not only on the body side but to the pilot as a standard. (VQ0000: Pilot valve only). After manual operation, the main valve of the manual on the body side returns to the position before the manual operation, however, the pilot valve manual override maintains the change-over position.



- Manual override body side If the manual override is turned by 180° clockwise and the ▶ mark is adjusted to A, then pushed in the direction of an arrow (♠), it will be back to the reset condition. (passage P → A)

  If the manual override is turned by 180°counterclockwise and the ▶ mark is adjusted to B, then pushed in the direction of an arrow (♠), it will
  - be back to the reset condition. (passage  $P \rightarrow B$ ) (It is in the reset state at the time of shipment.)

#### **⚠** Caution

Do not apply excessive torque when turning the locking type manual override. (0.1 N·m or less)

2-4-66

SQ

VQ0

VQ4

VQ5

VQZ


VQD

#### **Replacement of Cylinder Port Fittings**

#### **⚠** Caution

The cylinder port fittings are a cassette for easy replacement. (Except VQ1000)

The fittings are blocked by a clip inserted from the top of the valve. Remove the clip with a screwdriver to remove fittings. For replacement, insert the fitting assembly until it strikes against the inside wall and then re-insert the clip to the specified position.



Applicable	Fitting assembly part no.			
tubing O.D	VQ1000	VQ2000		
Applicable tubing ø3.2	VVQ1000-50A-C3			
Applicable tubing ø4	VVQ1000-50A-C4	VVQ1000-51A-C4		
Applicable tubing ø6	VVQ1000-50A-C6	VVQ1000-51A-C6		
Applicable tubing ø8	_	VVQ1000-51A-C8		

Purchasing order is available in units of 10 pieces.

#### Caution

- 1. Protect O-rings from scratches and dust to prevent air leakage.
- 2. The tightening torque for inserting fittings to the M5 thread assembly should be 0.8 to 1.4 N·m

#### Mounting/Removing from the DIN Rail


#### **∕** Caution

#### <Procedure>

#### **How to Remove**

1. Loosen the clamp screw on side (a) of the end plate on both sides.


2. Lift side (a) of the manifold base and slide the end plate in the direction of (2) shown in the figure to remove.



#### Mounting

- 1. Hook side (b) of the manifold base on the DIN rail.
- 2. Press down side (a) and mount the end plate on (a) the DIN rail. Tighten the clamp screw on side (a) of the end plate.

The proper tightening torque for screws is 0.4 to 0.6 N·m.



#### How to Calculate the Flow Rate

For obtaining the flow rate, refer to pages 2-1-8 to 2-1-11.

#### **Built-in Silencer Replacement Element**


#### **⚠** Caution

A silencer element is incorporated in the end plate on both sides of the manifold base. A dirty and choked element may reduce cylinder speed or cause malfunction. Clean or replace the dirty element.

#### **Element Part No.**

Type	Element part no.			
туре	VQ0000	VQ1000	VQ2000	
Built-in silencer, direct exhaust (-S)	VVQ0000-82A-4	VVQ1000-82A-4	VVQ2000-82A-4	


\* The minimum order quantity is 10 pcs.



#### **How to Use Plug Connector**

#### **⚠** Caution

#### Attaching and detaching connectors




To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.

Lead wire 0.2 to 0.33 mm<sup>2</sup> (Max. cover diameter ø1.7 mm) To detach a connector, remove the pawl from

#### Crimping the lead wire and socket

Peel 3.2 to 3.7 mm of the tip of lead wire, enter the core wires and press contact it by a press tool. Be careful so that the cover of lead wire does not enter into the core press contacting part.




#### Attaching and detaching lead wires with sockets Attaching

Insert a socket in the square hole (Indicated as +, -) of connector, push in the lead wire and lock by hanging the hook of socket to the seat of connector. (Pushing-in can open the hook and lock it automatically.) Then confirm the lock by lightly pulling on the lead wire.

#### Detaching

To detach a socket from a connector, pull out the lead wire while pressing the socket's hook with a stick having a thin tip (approx. 1

mm). If the socket will be used again, first spread the hook outward.




#### Series VQ0000/1000/2000

#### Option


#### **Different Number of Connector Pins**

F and P kits with the following number of pins are available. Besides the standard number (F = 25; P = 26) select the desired number of pins and cable length from the cable assembly list. Place an order for the cable assembly separately.





#### How to order manifold




#### Kit/Electrical entry •

Pins	Top entry		Side entry		
15P (Max. 7 stations)	Kit F	UA	Kit F	SA	

#### Wiring specifications

\* In the same way as the 25-pin models (standard) the terminal no. 1 is for SOL.A at the 1st station, the terminal no. 9 for SOL.B at the 1st station, and the terminal no. 8 for COM.



Wire Color by Terminal No. of
D-sub Connector Cable Assemb


Terminal no.	Lead wire color	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black

#### D-sub Connector Cable Assembly


Cable length (L)	15P
1.5 m	AXT100-DS15-1
3 m	AXT100-DS15-2
5 m	AXT100-DS15-3

<sup>\*</sup> For other commercial connectors, use a type conforming to MIL-C-24308.

#### kit (Flat ribbon cable connector) 10 pins, 16 pins, 20 pins



#### How to order manifold




Kit/Electrical entry •					
Pins Location	Тор	entry	Side	entry	
10P (Max. 4 stations)	Kit	UA	Kit	SA	
16P (Max. 7 stations)	P	UB	P	SB	
20P (Max. 8 stations)	r	UC	r r	SC	

Without cable

#### Wiring Specifications

\*In the same way as the 26-pin models (standard) the terminal no. 1 is for SOL.A at the 1st station, the terminal no. 2 for SOL.B at the 1st station, and two pins from the max. terminal numbers are for COM.



#### Flat Ribbon Cable Assembly

		<del>- ,</del>	
Cable length (L)	10P	16P	20P
1.5 m	AXT100-FC10-1	AXT100-FC16-1	AXT100-FC20-1
3 m	AXT100-FC10-2	AXT100-FC16-2	AXT100-FC20-2
5 m	AXT100-FC10-3	AXT100-FC16-3	AXT100-FC20-3
Connector width (W)	17.2	24.8	30

 $<sup>\</sup>ast$  For other commercial connectors, use a type with strain relief conforming to MIL-C-83503.

SQ

VQ0

VQ4

VQ5

VQZ

VQD

#### **Special Wiring Specifications**

In the internal wiring of F kit, P kit, T kit and S kit, double wiring (connected to SOL. A and SOL. B) is adopted for each station regardless of the valve and option types.

Mixed single and double wiring is available as an option.

#### 1. How to order valves

Indicate an option symbol, -K, for the manifold no. and be sure to specify the mounting position and number of stations of the single and double wiring by means of the manifold specification sheet.


Example)

## VV5Q14-09FS0-DKS

Others, option symbols: to be indicated alphabetically.

#### 2. Wiring specifications

Connector terminal numbers are connected from solenoid station 1 on the A side in the order indicated by the arrows without skipping any terminal numbers.



#### 3. Max. number of stations

The maximum number of stations depends upon the number of solenoids. Assuming one for a single and two for a double, determine the number of stations so that the total number is not more than the maximum number given in the following table.

kit	F (D-sub co		(Flat rib	P k bon cab		nector)	T (Termina		S kit (Serial)
Туре	F ⅓ □ 25P	F&A 15P	P ⅓ □ 26P	P&C 20P	P \ B 16P	P \ A 10P	T1	T2	S□
Max. points	Note) 16	14	Note) 16	Note) 16	14	8	8	16	16

Note) Due to the limitation of internal wiring.

#### **Negative Common Specifications**

Specify the valve model no. as shown below for negative COM specification. The standard manifold no. can be used. Please contact SMC for negative COM S kit.

How to order negative COM valves



#### **Inch-size One-touch Fittings**

Refer to following model no. for inch-size One-touch fittings.

How to order manifold

VV5Q14-08FSO-DN-00T

P, R port size

VQ0000	ø1/4"
VQ1000	ø1/4"
VQ2000	ø5/16"

How to order valves

VQ1140 - 5M - N

Cylinder port							
Syı	Symbol N1 N3 N7 N9						
	ole tubing (Inch)	ø1/8"	ø5/32"	ø1/4"	ø5/16"		
^ D	VQ0000	0	0		_		
A, B port	VQ1000	_	0	0	_		
port	VQ2000	_	0	0	0		

#### **Plug Connector Assembly Model**

Connector assembly will be required when the F, P, T, S kits add a valve.

Specify the type of valve and connector assembly.

#### **Connector Assembly Part No.**

Specifications	Part no.	
Single	Positive common	AXT661-14A-F
(2-wire)	Negative common	AXT661-14AN-F
Double (latching) (3-wire)	Positive common	AXT661-13A-F
	Negative common	AXT661-13AN-F

Note) Lead wire length: 300 mm

Note) The parts numbers above are applicable to VQ0000/1000 (2 to 16 stations) and VQ2000 (2 to 10 stations). VQ2000 (11 to 16 stations) uses AXT661- <sup>13</sup>/<sub>14</sub> A(N) -F425.

#### Series VQ0000/1000/2000

#### Option

#### **DIN Rail Mounting**

Each manifold can be mounted on a DIN rail.

Order it by indicating an option symbol for DIN rail mounting style, -D. In this case, a DIN rail which is approx. 30 mm longer than the manifold with the specified number of stations is attached. Besides, it is also available in the following cases.

When DIN rail is unnecessary (C kit only.)
 (DIN rail mounting brackets only are attached.)
 Indicate the option symbol, -DO, for the manifold no.

#### Example)

#### **VV5Q14-08C-DOS**

Others, option symbols: to be indicated alphabetically.

 When using DIN rail longer than the manifold with specified number of stations

Clearly indicate the necessary number of stations next to the option symbol, -D, for the manifold no.

Example)

#### VV5Q14-08FS1-D09S

Others, option symbols: to be indicated alphabetically.


 When changing the manifold style into a DIN rail mount Order brackets for mounting a DIN rail. (Refer to "Option" on pages 2-4-60, 61 and 64.)

No. VQ0000-57A4 (For VQ0000) VQ1000-57A-4 (For VQ1000) VQ2000-57A-4 (For VQ2000) 2 pcs. per one set

 When ordering DIN rail only DIN rail no.: AXT100-DR-n

L dimension | 398 | 410.5 | 423 | 435.5

\* Refer to the DIN rail dimension table for determining the length.



#### L Dimension $L = 12.5 \times n + 10.5$ No 10 4 6 35.5 48 60.5 73 85.5 98 110.5 123 135.5 23 L dimension 14 16 17 No 11 12 13 15 18 19 20 L dimension 148 160.5 173 185.5 198 210.5 223 235.5 248 260.5 No 21 30 22 23 24 25 26 27 28 L dimension | 273 | 285.5 | 298 310.5 323 335.5 348 360.5 373 385.5 40 No. 31 32 33 34 35 36 37 38 39

448 | 460.5

473 | 485.5

498 510.5

SQ

VQ0

VQ4

VQ5


VQZ

VQD

# Series VQ1000 Body Ported

## Plug Lead Unit: Cassette Type

#### **How to Order Manifold**



SQ

VQ0


VQ4

VQ5

VQZ

VQD

#### **How to Order Valves**




#### **Manifold Option**


C6 (SUP) port One-touch fitting for ø6

> Block bushing (2 pcs. attached)


Individual SUP spacer SUP/EXH block bush assembly VVQ1000-P-7-C6 VVQ1000-87A-B-50




#### **Double Check block** VQ1000-FPG-□□




#### Blanking plug KQ2P-




#### Individual EXH spacer VVQ1000-R-7-C6




Elbow fitting assembly VVQ1000-F7-L




Silencer




#### Individual SUP/EXH spacer VVQ1000-PR-7-C6




Name plate [-N7] VVQ1000-N7-station (1 to Max. stations)



Port plug VVQ0000-58A



#### **How to Order Manifold Assembly**



\*VQ1170-5MO-C6 ..... 4 sets (Single solenoid part no.) \*VQ1270-5MOB-C6 ... 4 sets (Double latching solenoid part no.)

The asterisk denotes the symbol for assembly. Prefix it to the part nos. of the solenoid valve, etc.

Add the valve and option part number under the manifold base part number. In the case of complex arrangement, specify them on the manifold specification sheet.

See page 2-4-91 for cylinder port fittings.

• For replacement parts, refer to page 2-4-111.



## Plug Lead Unit: Cassette Type




#### Model

						F	low char	acteristics			Response	e time (ms)	5)	
Series	_	mber of lenoids	Model		1 → 4	/2 (P →	A/B)	4/2 → 5/3 (A/B → R1/R2)			Standard:	Low	AC	Weight (g)
	30	neriolas			C [dm³/(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv	H: 1.5 W	wattage: 0.5 W		(9)
	_	0:	Metal seal	VQ1170	0.56	0.15	0.13	0.60	0.12	0.14	12 or less	15 or less	29 or less	
	position	Single	Rubber seal	VQ1171	0.71	0.20	0.17	0.80	0.16	0.19	15 or less	20 or less	34 or less	67
		Double	Metal seal	VQ1270	0.56	0.15	0.13	0.60	0.12	0.14	12 or less	15 or less	29 or less	
	2	(Latching)	Rubber seal	VQ1271	0.71	0.20	0.17	0.80	0.16	0.19	15 or less	20 or less	34 or less	
VQ1000		Closed	Metal seal	VQ1370	0.53	0.16	0.12	0.58	0.12	0.14	20 or less	26 or less	40 or less	
VQ1000		center	Rubber seal	VQ1371	0.65	0.23	0.16	0.70	0.20	0.17	25 or less	33 or less	47 or less	
	position	Exhaust	Metal seal	VQ1470	0.54	0.16	0.12	0.60	0.12	0.14	20 or less	26 or less	40 or less	82
		center	Rubber seal	VQ1471	0.65	0.23	0.16	0.80	0.16	0.19	25 or less	33 or less	47 or less	
	က	Pressure	Metal seal	VQ1570	0.54	0.16	0.12	0.58	0.12	0.14	20 or less	26 or less	40 or less	
	center	Rubber seal	VQ1571	0.70	0.20	0.17	0.72	0.20	0.17	25 or less	33 or less	47 or less		

Note 1) Cylinder port size C6

Note 2) As per JIS B 8375-1981 (Supply pressure: 0.5 MPa; with indicator light/surge voltage suppressor; clean air. Subject to the pressure and air quality.)

#### JIS Symbol



#### **Standard Specifications**

	•						
	Valve construction		Metal seal	Rubber seal			
	Fluid		Air/Inert gas	Air/Inert gas			
40	Maximum operatin	g pressure	0.7 MPa (High pressure type: 0.8 MPa) (3)				
ions		Single	0.1 MPa	0.15 MPa			
ficat	Minimum	Double (Latching)	0.1 MPa	0.15 MPa			
)eci	operating pressure	3 position	0.15 MPa	0.2 MPa			
Valve specifications	Ambient and fluid	emperature	10 to	50°C <sup>(1)</sup>			
Valv	Lubrication		Not re	quired			
	Manual override		Push type/Locking type (Tool required, Manual) Option				
	Impact/Vibration re	esistance (2)	150/30	O m/s <sup>2</sup>			
	Enclosure		Dust-pr	otected			
	Coil rated voltage		12, 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)				
	Allowable voltage	fluctuation	±10% of rated voltage				
	Coil insulation type	)	Class B or equivalent				
ë		24 VDC	1 W DC (42 mA), 1.5 W DC (63 mA) <sup>(3)</sup> , 0.5 W DC (21 mA) <sup>(4)</sup>				
Solenoid		12 VDC	1 W DC (83 mA), 1.5 W DC (1	25 mA) <sup>(3)</sup> , 0.5 W DC (42 mA) <sup>(4)</sup>			
တိ	Power consumption	100 VAC	Inrush 0.5 VA (5 mA),	Holding 0.5 VA (5 mA)			
	(Current)	110 VAC	Start-up 0.55 VA (5 mA),	Holding 0.55 VA (7.5 mA)			
		200 VAC	Inrush 1.0 VA(5 mA), I	Holding 1.0 VA (5 mA)			
		220 VAC	Inrush 1.1 VA (5 mA),	Holding 1.1 VA (5 mA)			

Note 1) Use dry air to prevent condensation when operating at low temperatures.

Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial

direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz.

Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Note 3) Values in the case of high pressure type (1.5 W).

Note 4) Values in the case of low wattage (0.5 W) specifications.



## Plug Lead Unit: Cassette Type Series VQ1000

#### **Manifold Specifications**

			Po	rting specificat	ions	(2)		5 station	
Series	Base model	Type of connection	Port location	Port	size <sup>(1)</sup>	Applicable stations	Applicable solenoid valve	weight	
			Port location	1(P), 3(R)	4(A), 2(B)	Stations	Soleriola valve	(g)	
VQ1000	VV5Q17-□□□-D	■ F kit—D-sub connector ■ P kit—Flat ribbon cable connector ■ T kit—Terminal block ■ C kit—Individual connector ■ S kit—Serial transmission unit	Тор	C6 (ø6)	C3 (Ø3.2) C4 (Ø4) C6 (Ø6) M5 (M5 thread)	1 to 16 stations	VQ1□70 VQ1□71	405	

Note 1) Inch-size One-touch fittings are also available. For details, refer to page 2-4-93. Note 2) For details, refer to page 2-4-93.

VQC

SQ


VQ0


VQ4

VQ5

VQZ

VQD





- The D-sub connector reduces installation labor for electrical connections.
- Using the D-sub connector (25P), (15P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.

#### **Manifold Specifications**

	Po			
Series	Port	Port	Applicable	
	location	1(P), 3(R)	4(A), 2(B)	stations
VQ1000	Тор	C6	C3, C4, C6, M5	Max. 16 stations

#### **D-sub Connector (25 pins)**

#### Cable assembly

None

None

None

None

None

White

White

Red


Red

None

White

Wire Color by Terminal No.

of D-sub Connector Cable



#### Terminal no. Lead wire color Dot marking Black Brown 3 Red 4 Orange

Assembly

-		
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Gray	None
19	Orange	Black

Red

Brown

Pink

Gray

Black

White

#### D-sub Connector Cable Assembly (Option) Electric Characteristics

Cable length (L)	Assembly part no.	Note
3 m	AXT100-DS25-019	Cable 25 core
5 m	AXT100-DS25-050	X Z4AVVG

\* For other commercial connectors, use a 25 pins type with female conforming to MIL-C-24308.

## Connector manufacturers' example • Fujitsu Limited • J.S.T. Mfg. Co., Ltd.

- Japan Aviation Electronics Industry, Ltd.
- · Hirose Electric Co., Ltd. Note) Types with 15 pin are also available. Refer to page 2-4-92 for details.

Note) The minimum bending radius of D-sub cable

Item

Conductor

resistance Ω/km, 20°C

Insulation resistance /, 1 min, AC

Insulation

resistance MΩ/km, 20°C

Characteristics

65

or less

5 or less

20

21

22


23

24


25

assembly is 20 mm.

Note) For details, refer to page 2-4-93.



#### Electrical wiring specifications







As the standard electrical wiring specifications, double wiring (connected to SOL, A and SOL, B) is adopted for the internal wiring of each station for 8 stations or less, regardless of valve and option types


Mixed single and double wiring is available as an option. For details, refer to page 2-4-93.

Note) When using the negative common specifications, use valves for negative common. (Refer to page 2-4-93.)

#### **How to Order Manifold**







212.5

225

250

237.5

248

262.5

262.5 273

275

287.5

187.5

198

200

210.5

200

210.5

137.5

148

150

160.5 173

162.5

185.5

137.5

148

## VQ1000 Kit (Flat ribbon cable connector)

- MIL flat ribbon cable connector reduces installation labor savings for electrical connection.
- Using the connector for flat ribbon cable (26P), (10P, 16P, 20P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.

Flat Ribbon Cable (26 pins)

#### **Manifold Specifications**


		ications			
	Series	Port	Port	Applicable	
		location	1(P), 3(R)	4(A), 2(B)	stations
ĺ	VQ1000	Тор	C6	C3, C4, C6, M5	Max. 16 stations

# The total number of stations is tabulated starting from station one on the D side.

#### Cable assembly €

#### AXT100-FC26-to

Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold.



#### Flat Ribbon Cable Connector Assembly (Option)

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC26-1	0.11.00
3 m	AXT100-FC26-2	Cable 26 core x 28AWG
E m	AVT100 ECGE 2	X ZOAWG


 For other commercial connectors, use a 26 pins type with strain relief conforming to MIL-C-83503.

#### Connector manufacturers' example

- Sumitomo 3M Limited
- Japan Aviation Electronics Industry, Ltd.
- Fujitsu Limited
- J.S.T. Mfg. Co., Ltd.
- Oki Electric Cable Co., Ltd.

Note) Types with 10, 16, or 20 pin are also available. For details, refer to page 2-4-92.


#### Electrical wiring specifications




As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 8 stations or less, regardless of valve and option types. Mixed single and double wiring is available as an option. For details, refer to page 2-4-93.


Note) When using the negative common specifications, use valves for negative common. (Refer to page 2-4-93.)

#### **How to Order Manifold**



## Plug Lead Unit: Cassette Type Series VQ1000





**Dimensions: Top Entry Connector [-PU]** 


L1 = 10.5n + 24, L2 = 10.5n + 44 n: Station (Maximum 16 stations)

		•	•			•				,				`		,
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	34.5	45	55.5	66	76.5	87	97.5	108	118.5	129	139.5	150	160.5	171	181.5	192
L2	54.5	65	75.5	86	96.5	107	117.5	128	138.5	149	159.5	170	180.5	191	201.5	212
L3	112.5	112.5	125	137.5	150	162.5	175	175	187.5	200	212.5	225	237.5	237.5	250	262.5
L4	123	123	135.5	148	60.5	173	185.5	185.5	198	210.5	223	235.5	248	248	260.5	273

**Dimensions: Side Entry Connector [-PS]** 

2-4-93.

n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L3	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5	262.5	275	287.5
L4	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273	273	285.5	298



#### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.


#### <Example>

Connector kit

VV5Q17-08PU2-D ... 1 set -Manifold base part no. \*VQ1170-5MO-C6 ... 4 sets -Valve part no. (Stations 1 to 4)] \*VQ1270-5MOB-C6... 4 sets -Valve part no. (Stations 5 to 8)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Enter in order starting from the first station on the D side. Besides, when the arrangement will be complicated, fill out the Manifold Specification Sheet to instruct us.



VQ0 VQ4

**VQC** 

SQ

VQ5

VQZ

VQD



- It is a standard terminal block type.
- Two quantities of terminals can be selected in accordance with the number of stations.


(8 terminals/16 terminals)

Maximum stations are 16.



	Р			
Series	Port	Port	Applicable	
	location	1(P), 3(R)	4(A), 2(B)	stations
VQ1000	Тор	C6	C3, C4, C6, M5	Max. 16 stations

#### Electrical wiring specifications




T1 (Terminal block of 1 row): 1 to 4 station
T2 (Terminal block of 2 rows): 5 to 8 stations
T1 and T2 can be optionally chosen by adopting
the combinations of single and double wiring
(optional spec.), etc.


The quantity of terminal blocks used depends on the number of manifold stations.

Manifold	Number of terminals
1 to 4 stations	1 row
5 to 8 stations	2 rows

Wiring other than those above is

For details, refer to page 2-4-93.






#### How to connect wires to terminal block

Open the terminal block cover to connect the wires to the terminal block. (With M3 thread)

#### **How to Order Manifold**



wiring specification is special.

SQ


VQ0


VQ4

VQ5

VQZ

VQD





#### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.


<Example>

Connector kit

etc

VV5Q17-08T2-D ·····1 set-Manifold base part no. \*VQ1170-5MO-C6 ....4 sets-Valve part no. (Stations 1 to 4) <u>★</u>VQ1270-5MOB-C6 …4 sets–Valve part no. (Stations 5 to 8)

Prefix the asterisk to the part nos. of the solenoid valve, Enter in order starting from the first station on the D side. Besides, when the arrangement will be complicated, fill out the Manifold Specification Sheet to



2-4-81




Standard with lead wires connected to each valve individually.

Maximum stations are 16.




		<u></u>		
	ı	Porting specific		
Series	Port	Port	Applicable	
	location	1(P), 3(R)	4(A), 2(B)	stations
VQ1000	Top	C6	C3, C4, C6, M5	Max. 16 stations



100/110 VAC for single: AXT661-31A-\*; for double: AXT661-32A-\* 200/220 VAC for single: AXT661-34A-\*; for double: AXT661-35A-\* are in accordance with the above table.

Note 2) 3 position type requires 2 sets for A side and B side

#### Wiring specifications: Negative COM (Option)




AXT661-14AN-30 Note 1) When using the negative common specifications, use valves for negative common.

Note 2) 3 position type requires 2 sets for A side and B side.

AXT661-13AN-30

3000A

#### **How to Order Manifold**



SQ

VQ0


VQ4

VQ5

VQZ


VQD

## Plug Lead Unit: Cassette Type Series VQ1000




3 position (Grommet) 3 position (L/M plug connector)

Dimensions							F	ormula	L1 = 10.5	5n + 24,	L2 = 10.	5n + 44	n: Stati	on (Maxi	mum 16	stations)
Ln	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	34.5	45	55.5	66	76.5	87	97.5	108	118.5	129	139.5	150	160.5	171	181.5	192
L2	54.5	65	75.5	86	96.5	107	117.5	128	138.5	149	159.5	170	180.5	191	201.5	212
L3	75	87.5	100	112.5	125	137.5	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5
L4	85.5	98	110.5	123	135.5	148	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248




## **VQ1000** Kit (Serial transmission unit)

- The serial transmission system reduces wiring work, while minimizing wiring and saving space.
- The system comes in an type SA (generic for small scale systems) for equipment with a small number of I/O points, or 32 points max., type SB (applicable to Mitsubishi Electric models) for controlling 512 I/O points max., type SC (applicable to OMRON models), and type SD (applicable to SHARP models; 504 points max.).
- 16 stations max. (Specify a model with more than 8 stations by using a manifold specification sheet.)




#### **Manifold Specifications**

Series	Port	Po	Applicable	
	locaition	1(P), 3(R)	4(A), 2(B)	stations
VQ1000	Тор	C6	C3, C4, C6, M5	Max. 16 stations



- Stations are counted from station 1 on the D side.
- As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for




Item	Specifications					
External power supply	24 VDC +10%, -5%					
Current consumption (Internal unit)	SA, SB, SD, SE, SF, SG, SH, SJ, SK, SQ, SV, SR: 0.1 A, SC: 0.3 A					

		Type SA general type SI unit Series EX300)			Type SB bishi Electric Corporation NET/MINI-S3 Data Link System	
Name of terminal block (LED)	224V (0V	ME RIAN II THO  SS SS SS SS R1 R2 FG		PK (24V)	OV SDA SOB SG RDA ROBB FG	
Ē	LED	Description		LED	Description	
tē	TRD	Lighting during data reception		POWER	Lighting when power is turned ON	
ō	RUN/ERR	Blinking when received data is normal;		RUN	Lighting when data transmission with the master station is normal	
ä		Lighting when data reception		RD	Lighting during data reception	
Na				SD	Lighting during data transmission	
				ERR.	Lighting during data transmission Lighting when reception data error occurs. Light turns off when the error is corrected.	
	• T unit		•	Master sta	ation:	
		nnected with PLC I/O card for			e by Mitsubishi Electric	
	serial trans			Corporation		
	EX300-TM	B1 ···For models of	Series MELSEC-A AJ71PT32-S3, AJ71T32-S3			
		Mitsubishi Electric				
Note	EX300-TT	Corporation A1For models of OMRON	A1SJ71PT32-S3			
ž		Corporation	* Max. 64 stations, connected to remote I/O stations (Max. 512 points).			
	EX300-TF	U1 ···For models of Fuji	No. of output points, 16 points. No. of			
		Electric Co., Ltd.		sta. occup	pied, 2 stations	
	EX300-TO	O1 ···For general models				
		oints per unit.				
	No. of outp	out points, 16 points				

<sup>\*</sup> For details on specifications and handling, refer to the separate technical instruction manual.

#### **How to Order Manifold**

7 Plug lead unit/Cassette




Stations •

01	1 station				
:	:				
08	8 station (Double)				
16 Note)	16 stations (Single)				

Note) As an option, the maximum number of stations can be increased based on special wiring specifications. For details, refer to page 2-4-93.

#### Without SI unit With general type SI unit (Series EX300) В Mitsubishi Electric Corp.: MELSECNET/MINI-S3 Data Link System OMRON Corp.: SYSBUS Wire System С D SHARP Corp.: Satellite I/O Link System Max. 16 Matsushita Electric Works: MEWNET-F System Ε stations F1 NKE Corp.: Uni-wire System (16 output points) G Rockwell Automation: Allen Bradley Remote I/O (RIO) System н NKE Corp.: Uni-wire H System SUNX Corp.: S-LINK System (16 output points) J1 SUNX Corp.: S-LINK System (8 output points) J2 Max. 8 Fuji Electric Co.: T-LINK Mini System Max. 16 C DeviceNet, CompoBus/D (OMRON Corp.) stations R1 OMRON Corp.: CompoBus/S System (16 output points) R2 OMRON Corp.: CompoBus/S System (8 output points) Max. 8 Mitsubishi Electric Corp.: CC-LINK System

For the general purpose type, a transmission unit is required on the CPU side.



DIN rail, and so suffix -D to the part number. Note 2) Specify the

specifications in the manifold specification sheet.

Note 3) Unmountable when the valve's manual override is a

locking lever type.
Note 4) When two or more symbols

are specified, indicate them alphabetically.

#### SI unit output and coil numbering

<Wiring example 1> Double wiring (Standard)

**How to Order Valves** 

#### 0 1 2 3 4 5 6 7 (Looked by double solenoid valve) В А В Α В Α В Α SOL. location Double Single m 3 Stations 2 3 5

The places of asterisk are not used.

<Wiring example 2> Single/Double mixed wiring (Option) Mixed wiring is available as an option. Use the manifold specification sheet to specify.

(Looked by double	SI unit output no Looked by double				3	4	5	6 7
solenoid valve) SOL. location		Α	В	Α	В	АВ	АВ	АВ
	SI unit	ماطيام		oldriod		Single	Single	3 position
	Stations			2	2	3	4	5

VQC

SQ


VQ0

VQ4

VQ5

VQZ

VQD



#### 5 **MO** Cylinder ports Series VQ1000 C3 With One-touch fitting for ø3.2 Type of actuation • C4 With One-touch fitting for ø4 1 2 position single C6 With One-touch fitting for ø6 2 position double (Latching) M5 M5 thread 3 position closed center Seal The code is L for elbow piping Note 1) 3 position exhaust center for all manifold stations. 0 Metal seal Example) L6: Elbow with One-touch fittings for ø6 3 position pressure center 1 Rubber seal L type plug connector is used Note) L Note 2) For inch-size One-touch fittings, refer to "Option" on page 2-4-93. for 3 position AC. Function • Manual override Symbol Specifications Non-locking push type (Tool required) (1.0 W) B No Locking type (Tool required) Standard type С Locking type (Manual) H (1.5 W) High pressure type Note) A manual override for pilot (0.5 W) Low wattage type valve is provided to standard model for double type. Note) Except double (latching). **Electrical entry** Coil voltage L plug connector without connector 24 VDC, With indicator light and 5 M plug connector without connector surge voltage suppressor Connector assembly will be required Note) Plug connector and lead wire when the S kits add a valve. For model no., refer to "Option" on page layers are attached to the

#### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

<Example>


Serial transmission unit kit

VV5Q17-08SA-D ··· 1 set-Manifold base part no. \*VQ1170-5MO-C6 ··· 4 sets-Valve part no. (Stations 1 to 4)

\*VQ1270-5MOB-C6 ··· 4 sets-Valve part no. (Stations 5 to 8)


Prefix the asterisk to the part nos. of the solenoid valve, etc

Enter in order starting from the first station on the D side. Besides, when the arrangement will be complicated, fill Manifold Specification Sheet to



manifold.

## VQ1000 Kit (Serial transmission unit)




#### **Manifold Option Parts**

#### Individual SUP spacer VVQ1000-P-7-C6

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.) Block both sides of the station, for which the supply pressure from the individual SUP spacer is used, with SUP block plates. (See the application ex.)

- Specify the spacer mounting position and SUP block plate mounting position on the manifold specification sheet. The block plate are used in two places for one set. (Two SUP block plates for blocking SUP station are attached to the individual SUP spacer.)
- \* The spacer's specification can be changed (from an individual SUP spacer to an individual EXH spacer) by changing the coupling of the fittings and bushing.



**VQC** 

SQ

VQ0

VQ4

VQ5

**VQZ** 


VQD

#### Individual EXH spacer VVQ1000-R-7-C6

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.)

Block both sides of the individual valve EXH station.

- Specify the spacer mounting position and EXH block plate mounting position on the manifold specification sheet. The block plate are used in two places for one set. (Four EXH block plates for blocking EXH station are attached to the individual EXH spacer.)
- The spacer's specification can be changed (from an individual EXH spacer to an individual SUP spacer) by changing the coupling of the fittings and bushing.




#### Individual SUP/EXH spacer VVQ1000-PR-7-C6

This spacer has both functions of the above individual SUP and EXH spacers. (Refer to the application example.)

Specify the spacer mounting position and SUP/EXH block plate mounting position on the manifold specification sheet. The blockplates are used in two places for one set.

(A SUP/EXH block plates for blocking SUP/EXH station are attached to the individual SUP/EXH spacer.)

- When using the spacer not for individual SUP/EXH but for improving the ability to supply/exhaust air, it is unnecessary to block the SUP/EXH passage. In this case, place an order via VVQ1000-PRA-7-C6.
- The spacer's specification can be changed by changing the coupling of the fittings and bushing.



#### Series VQ1000

#### **Manifold Option Parts**

#### SUP Block bushing assembly VVQ1000-87A-B-50

<For SUP>

When one manifold is to be used for different, high and low pressures, this block bushing assembly is used between the stations under a different pressure. The block assembly is mounted on the U side of the valve's SUP passage.

Specify the number stations on the manifold specification sheet.


#### <For EXH>


When a valve exhaust affects other stations due to the circuit configuration, this block bushing assembly is used between the stations whose EXH passages are to be separated each other. Since the block bushing assembly is mounted on the U side of the valve's R1 and R2 passages, two assemblies are necessary for one station.


\* Specify the number stations on the manifold specification sheet.

#### <Shut off label>

When using block bushing assembly for SUP, EXH passage, indication label for confirmation of the blocking position from outside is attached. (One label for each)







assembly bush assembly 5(R1) 1(P) 3(R2) 2(B) 4(A) 2(B) 4(A) <Example>

Can be included in manifold model no.

SUP Block

U side



D side SUP/EXH

When ordering a block bush incorporated with the manifold, a block indication label is attached to the manifold.









#### Elbow fitting assembly VVQ1000-F7-L (C3, C4, C6)

It is used in a side-valve-port application.






#### Name plate [-N7] VVQ1000-N7-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc. Insert it into the groove on the side of the end plate and bend it as shown in the figure.


Open the face plate seating when the manual override is operating.

\* It is not applicable to locking manual override.





When ordering assemblies incorporated with a manifold, suffix -N to the manifold




## Blanking plug

KQ2P-04

Used for unused cylinder port, SUP and EXH port. Purchasing order is available in units of 10 pieces.







#### **Dimensions** Applicable fittings Model size ød 3.2 KQ2P-23 16 31.5 5 KQ2P-04 16 32 6

#### Silencer AN103-X233

This silencer is to be inserted into the EXH port (One-touch fittings) of the common exhaust type.





6


#### **Dimensions**

Series	Applicable fittings Mc	Model	A	L	D	Effective area (mm²)	Noise reduction (dB)
VQ1000	6	AN103-X233	20	37	11	7	25

#### Port plug VVQ0000-58A

The plug is used to block the cylinder port when using a 4 port valve as a 3 port valve.

When ordering it incorporated with a manifold, suffix A or B, the symbol of the plug port, to the alve no. Example) **VQ1170-5L-C6-A** — A port, Plug valve no





#### Plug Lead Unit: Cassette Type Series VQ1000

#### Double check block (Separated type) VQ1000-FPG-□□

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the double check block with a built-in pilot type double check valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time.

The combination with a two position single/double solenoid valve will permit this block to be used for preventing the dropping at the cylinder stroke end when the SUP residual pressure is released.

Max. operating pressure	0.8 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temperature	−5 to 50°C
Flow characteristics: C	0.60 dm <sup>3</sup> /(s·bar)
Max. operating frequency	180 CPM

Note) Based on JIS B 8375-1981 (Supply pressure: 0.5

## (Check valve operation principle) SUP side pressure (P1) TO CYL PORT VVQ1000-FPG-02 1 set VQ1000-FPG-C6M5-D 2 pcs.

**VQC** 

SQ

VQ0


VQ4


VQ5

VQZ

VQD

#### **Dimensions**





**Stations** 1 station

#### <Example>

VVQ1000-FPG-06-6 types of manifold

16

16 stations

\*VQ1000-FPG-C4M5-D, 3 sets Double Check block

#### **Bracket Assembly**

-		
Ī	Part no.	Tightening torque
	VQ1000-FPG-FB	0.22 to 0.25 N·m

- Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for a long time. Check the leakage using neutral household detergent, such as dish
- Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.
  Since One-touch fittings allow slight air leakage, screw piping (with M5 thread) is recommended when stopping the cylinder in the middle for a long time.
- Combining double check block with 3 position closed center or pressure center solenoid valve will not
  work. M5 fitting assembly is attached, not incorporated into the double check block.
- After screwing in the M5 fittings, mount the assembly on the double check block. {Tightening torque: 0.8 to 1.2 N·m} If the exhaust of the double check block is throttled too much, the cylinder may not operate properly and may not stop intermediately.
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.




#### **⚠ Precautions**


Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.

#### **Light/Surge Voltage Suppressor**

#### **⚠** Caution

The standard model is equipped with an indicator light and surge voltage suppressor. The lighting positions are concentrated on one side for both single solenoid type and double (latching) type. In the double (latching) type, A side and B side energization are indicated by two colors which match the colors of the manual overrides.





#### **Double (Latching solenoid) Type**

#### **⚠** Caution

Different from the conventional double solenoid, the double type uses a latching (self-holding system) solenoid. Although the appearance is the same as the single solenoid, it is constructed so that the movable iron core in the solenoid is held in the ON position on A and B sides by instantaneous energization (20 ms or more). The usage and function is the same as the double solenoid type.

#### <Special Cautions for Latching Solenoid>

- Select the circuit in which ON and OFF signals are not energized simultaneously.
- 2. 20 ms energization time is necessary for self-holding.
- 3. Avoid using the latching solenoid valves in environments where impact or collisions with the valve might occur.
- Also, do not use in places where strong magnetic fields are present.


  4. Even though the armature in the solenoid of this valve is held on to B side, ON position (Reset), verify either A side, ON position or B side. ON position by operating prior to use
- side, ON position by energizing prior to use. After manual operation, the main valve will return to its original position.
- Manual override on the pilot valve side can retain its switching position after manipulation.
- **6.** Please contact SMC for long-term energization applications.
- 7. In the case of metal seal type, if the supply air goes down below the minimum operating pressure (0.1 MPa or less), the main valve will be back to the home position (B side ON position). Therefore, when the supply air is shut off or applied while leaving A side ON position, cylinder may be pulsated. The valve's switching position when the supply air is operated should be installed on the home position side (B side ON position).

#### **Manual Override**

#### **⚠** Warning


Without an electric signal for the solenoid valve the manual override is used for switching the main valve.

#### ■ Push type (Tool required)




Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

#### ■ Locking slotted type



Push down on the manual override button with a small screwdriver until it stops. While down, turn clockwise by 90° to lock it. Turn it counterclockwise to release it.

#### ■ Locking lever type (Option)




Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

#### ■ Manual override for double (latching) type

In case of a double (latching) type, a manual override is provided not only on the body side but to the pilot as a standard specification.

After manual operation, the main valve of the manual override on the body side returns to the position before the manual operation, however, the pilot valve manual override maintains the change-over position.

Turn before pushing.



- If the manual override is turned by 180° clockwise and the ► mark is adjusted to A, then pushed in the direction of an arrow (♠), it will be back to the reset condition. (passage P → A)
- If the manual override is turned by 180° counterclockwise and the
   ▶ mark is adjusted to B, then pushed in the direction of an arrow (♠), it will be back to the reset condition. (passage P → B) (It is in the reset state at the time of shipment.)

Self-holding of the main valve possible.


#### **⚠** Caution

Do not apply excessive torque when turning the locking type manual override. (0.1 N·m or less)

#### **How to Mount/Remove Solenoid Valve**

#### 

#### <Procedure>



#### **How to Remove**

- 1. Loosen the clamp screw on one side.
- 2. Slightly slide a part the valve stations on both sides of the station to be removed.
- 3. Pull up side (a) of the valve station and remove it from the DIN

#### How to mount

- 1. Take procedures 1 and 2 above to make an open space in the position for mounting a new valve station.
- 2. Diagonally insert the clip on the side (b) of the valve station to the DIN rail.
- 3. Press down on the valve station and insert the clip on the side (a) of the valve station to the DIN rail.
- 4. Slide the valve stations together so that there is no clearance between them. Position the clamp screw and tighten. (Proper tightening torque: 0.7 to 1.0 N·m)

Note) Be careful to keep O-ring or gallery dust free since dirt may cause air leakage.

Be sure both hooks of the bracket are fixed to the DIN rail.

Use caution not to apply force on the light cover when mounting or dismounting the valve.

#### Replacement of Cylinder Port Fittings

#### 

The cylinder port fittings are a cassette for easy replacement. The fittings are blocked by a clip inserted from the side of the valve. Remove the clip with a screwdriver and remove fittings. For replacement, insert the fitting assembly until it strikes against the inside wall and then reinsert the clip to the specified position.

Applicable tubing O.D	Fitting assembly part no.
Applicable tubing ø3.2	VVQ1000-50A-C3
Applicable tubing ø4	VVQ1000-50A-C4
Applicable tubing ø6	VVQ1000-50A-C6

\* Purchasing order is available in units of 10 pieces.

## 

- 1. Protect O-rings from scratches and dust to prevent air leakage.
- 2. The tightening torque for inserting fittings to the M5 thread ass'y should be 0.8 to 1.4 N·m.

#### **How to Use Plug Connector**

#### **⚠** Caution

For details, refer to page 2-4-67.

#### How to Calculate the Flow Rate

#### **⚠** Caution

For obtaining the flow rate, refer to pages 2-1-8 to 2-1-11.

**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ

VQD

Fitting assembly

#### Series VQ1000


#### Option

#### **Different Number of Connector Pins**


F and P kits with the following number of pins are available besides the standard number (F = 25; P = 26). Select the desired number of pins and cable length from the cable assembly list. Place an order for the cable assembly separately.



#### kit (D-sub connector) 15 pins



#### How to order manifold




#### Kit/Electrical entry •

Pins	Top entr	γ	Side entry		
15 pins (Max. 14 stations)	Kit F	UA	Kit F	SA	

#### Wiring Specifications


Like 25-pin models (standard), terminal no. 1 will be the 1st station SOL.A, and terminal no. 9 for the 1st station SOL.B. Then COM will be the terminal no. 8.




#### **D-sub Connector Cable Assembly**


Cable length (L)	15P
1.5 m	AXT100-DS15-1
3 m	AXT100-DS15-2
5 m	AXT100-DS15-3

<sup>\*</sup> For other commercial connectors, use a type conforming to MIL-C-24308.





#### How to order manifold




#### Kit/Electrical entry •

Pins Location	Top entry		Side	entry
10 pins (Max. 8 stations)	Kit	UA	Kit	SA
16 pins (Max.14 stations)	D	UB	P	SB
20 pins (Max.16 stations)	F	UC		SC

#### Wiring Specifications

Similarly to 26-pin models (standard), the terminal no. 1 will be allocated to SOL.A of the 1st. station, and terminal no. 2 for SOL.B of the 1st. station. COM occupies 2 pins from the maximum no. of terminal.



#### Flat Ribbon Cable Assembly

		•	
Cable length (L)	10P	16P	20P
1.5 m	AXT100-FC10-1	AXT100-FC16-1	AXT100-FC20-1
3 m	AXT100-FC10-2	AXT100-FC16-2	AXT100-FC20-2
5 m	AXT100-FC10-3	AXT100-FC16-3	AXT100-FC20-3
Connector width (W)	17.2	24.8	30

For other commercial connectors, use a type with strain relief conforming to MIL-C-83503.



SQ

VQ0

VQ4

VQ5

VQZ


VQD

#### Special Wiring Specifications

In the internal wiring of F kit, P kit, J kit, G kit, T kit and S kit, double wiring (connected to SOL. A and SOL. B) is adopted for each station regardless of the valve and option types. Mixed single and double wiring is available as an option.

#### 1. How to order valves


Indicate an option symbol, -K, for the manifold no. and be sure to specify the mounting position and number of stations of the single and double wiring by means of the manifold specification sheet.



Others, option symbols: to be indicated alphabetically.

#### 2. Wiring specifications

Connector terminal numbers are connected from solenoid station 1 on the A side in the order indicated by the arrows without shipping any terminal numbers.



#### 3. Max. number of stations

The maximum number of stations depends upon the number of solenoids. Assuming one for a single and two for a double, determine the number of stations so that the total number is not more than the maximum number given in the following table.

kit	F (D-sub co		P kit (Flat ribbon cable connector)				T (Termina	S kit (Serial)	
Туре	Fs⊔ 25P	F s A 15P	Ps⊔ 26P	P s C 20P	P s B 16P	P s A 10P	T1	T2	S□
Max. points	Note) 16	14	Note) 16	Note) 16	14	8	8	16	16

Note) Due to the limitation of internal wiring

#### Negative Common Specifications

Specify the valve model no. as shown below for negative COM specification. The standard manifold no. can be used. Please contact SMC for negative COM S kit.

How to order negative COM valves



#### Inch-size One-touch Fittings

Refer to following model no. for inch-size One-touch fittings.

How to order manifold

VV5Q17-08FSO-DN-00T

1(P), 3(R) port size ø1/4"

How to order valves

VQ1170 - 5M

Cylinder port

· o y post								
Symbol	N1	N3	N7					
Applicable tube O.D. (Inch)	ø1/8"	ø5/32"	ø1/4"					

#### Plug Connector Assembly Model

Connector assembly will be required when the F, P, T, S kits add a valve

Specify the valve and connector assembly.

#### Connector Assembly Part No.

Specifi	Part no.	
Single	Positive common	AXT661-14A-F
(2-wire)	Negative common	AXT661-14AN-F
Double (latching)	Positive common	AXT661-13A-F
(3-wire)	Negative common	AXT661-13AN-F

Note) Lead wire length: 300 mm

#### DIN Rail Mounting

Each manifold can be mounted on a DIN rail.

Order it by indicating an option symbol for DIN rail mounting style, -D. In this case, a DIN rail which is approx. 30 mm longer than the manifold with the specified number of stations is attached. Besides, it is also available in the following cases.

When using DIN rail longer than the manifold with specified number of stations

Clearly indicate the necessary number of stations next to the option symbol, -D, for the manifold no.


#### Example)

#### VV5Q17-08FU1-D09S

Others, option symbols: to be indicated DIN rail for 9 stations alphabetically.

When ordering DIN rail only DIN rail no.: AXT100-DR-n

\* Refer to the DIN rail dimension table for determining the length.



L Dim	ensic	n						L = '	12.5 x r	า + 10.5
No.	1	2	3	4	5	6	7	8	9	10
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5
No.	11	12	13	14	15	16	17	18	19	20
L dimension	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5
No.	31	32	33	34	35	36	37	38	39	40
L dimension	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

## Series VQ Single Unit

For individual use of a single valve.




#### Model

Series Number of Model				Flow characteristics						Response time (ms) (2)									
		Number of solenoids								Mode	el	1 → 4	/2 (P →	A/B)	4/2 → 5/3	3 (A/B →	R1/R2)	Standard: 1 W	Low wattage:
		5	Jieriolas			C [dm³/(s·bar)]	b	Cv	C [dm <sup>3</sup> /(s·bar)]	b	Cv	H: 1.5 W	0.5 W	AC .	(g)				
		_	Single	Metal seal	VQ1160	0.56	0.15	0.13	0.60	0.12	0.14	12 or less	15 or less	29 or less					
		position	Sirigle	Rubber seal	VQ1161	0.71	0.20	0.17	0.80	0.16	0.19	15 or less	20 or less	34 or less	50				
			Double	Metal seal	VQ1260	0.56	0.15	0.13	0.60	0.12	0.14	12 or less	15 or less	29 or less	30				
þ	VO1000	2	(Latching)	Rubber seal	VQ1261	0.71	0.20	0.17	0.80	0.16	0.19	15 or less	20 or less	34 or less					
ported	VQ1000 Cassette		Closed	Metal seal	VQ1360	0.53	0.16	0.12	0.58	0.12	014	20 or less	26 or less	40 or less					
	- Diversional	L	center	Rubber seal	VQ1361	0.65	0.23	0.16	0.70	0.20	0.17	25 or less	33 or less	47 or less					
Body		position	Exhaust	Metal seal	VQ1460	0.54	0.16	0.12	0.60	0.12	014	20 or less	26 or less	40 or less	65				
			center	Rubber seal	VQ1461	0.65	0.23	0.16	0.80	0.16	0.19	25 or less	33 or less	47 or less	0.5				
		3	Pressure	Metal seal	VQ1560	0.54	0.16	0.12	0.58	0.12	0.14	20 or less	26 or less	40 or less					
			center	Rubber seal	VQ1561	0.70	0.20	0.17	0.72	0.20	0.17	25 or less	33 or less	47 or less					

Note 1) Cylinder port size C6 (VQ1000)

Note 2) As per JIS B 8375-1981 (Supply pressure: 0.5 MPa; with indicator light/surge voltage suppressor; clean air. Subject to the pressure and air

#### JIS Symbol



#### **Standard Specifications**

	Valve construct	ion	Metal seal	Rubber seal			
	Fluid		Air/Inert gas Air/Inert gas				
(0	Maximum opera	ating pressure	0.7 MPa (High pres	sure type: 0.8 MPa)			
ions		Single	0.1 MPa	0.15 MPa			
icati	Min. operating pressure	Double (Latching)	0.1 MPa	0.15 MPa			
ecif	p	3 position	0.15 MPa	0.2 MPa			
ds e	Ambient and flu	id temperature	-10 to 5	50°C <sup>(1)</sup>			
Valve specifications	Lubrication		Not re	quired			
	Manual override	· <sup>(2)</sup>	Push type/Locking type (Tool I	required, Manual type) Option			
	Impact/Vibration	resistance	150/30 m/s <sup>2</sup>				
	Enclosure		Dust tight				
	Coil rated voltage		12 , 24 VDC, 100 , 110 , 200, 220 VAC (50/60 Hz)				
	Allowable voltag	ge fluctuation	±10% of rated voltage				
	Coil insulation ty	/pe	Class B or equivalent				
biot		24 VDC	1 W DC (42 mA), 1.5 W DC (63	mA) (3), 0.5 W DC (21 mA) (4)			
Solenoid		12 VDC	1 W DC (83 mA), 1.5 W DC (12	5 mA) <sup>(3)</sup> , 0.5 W DC (42 mA) <sup>(4)</sup>			
Ó	Power	100 VAC	Inrush 0.5 VA (5 mA), I	Holding 0.5 VA (5 mA)			
	consumption (Current)	110 VAC	Inrush 0.55 VA (5 mA), I	Holding 0.55 VA (5 mA)			
		200 VAC	Inrush 1.0 VA (5 mA), Holding 1.0 VA (5 mA)				
		220 VAC	Inrush 1.1 VA (5 mA), Holding 1.1 VA (5 mA)				
	a 1) Lies dry air to provent condensation when energing at law temperatures						

Note 1) Use dry air to prevent condensation when operating at low temperatures. Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the

axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and

armature. (Values at the initial period)

Note 3) Values in the case of high pressure type (1.5 W) specifications.

Note 4) Values in the case of low wattage type (0.5 W) specifications.



VQ0


VQ4

VQ5


VQZ

VQD

#### **How to Order Valves**



#### Wiring Specifications: Positive COM



200/220 VAC for single: AXT661-34A-\*; for double: AXT661-35A-\* are in accordance with the above table.

Note 2) 3 position type requires 2 sets for A side and B side.

2

3

4

5


200 VAC (50/60 Hz)

110 VAC (50/60 Hz)

220 VAC (50/60 Hz)

24 VDC **12 VDC** 

#### Wiring Specifications: Negative COM (Option)



AXT661-14AN-30

Note 2) 3 position type requires 2 sets for A side and B side.

Note 1) When using the negative common specifications, use valves for


3000 mm

negative common


AXT661-13AN-30

## Series VQ

#### **Dimensions**



#### 3 position closed center/exhaust center/pressure center: VQ1 $\frac{3}{5}6$ $\frac{0}{1}$



EXH blow out hole Built-in silencer




# Series VQ Construction Main Parts, Replacement Parts

#### Construction: VQ1000/Plug-in Unit, Flip Type

## 

## 3 position




VQ1330	VQ1430	VQ1530
5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)

#### **Component Parts**


No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

#### 4 Pilot valve assembly

Single/3 position	VQ111(H) - □ F Voltage 1 to 6	
Double (Latching)	VQ110L-□F Voltage 1 to 6	




## Rubber seal Single/Double (Latching)



VQ1131	VQ1231
(A)(B)	(A)(B)
4 2	4 2
<b>∞</b> €∭, 🎮	
5 1 3	5 1 3
(R1)(P)(R2)	(R1)(P)(R2)

#### 3 position




VQ1331	VQ1431	VQ1531
AN 12 11 AS		
5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)

#### **Component Parts**


No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool valve	Aluminum/HNBR	
3	Piston	Resin	

#### 4 Pilot valve assembly

Single/3 position	VQ111(H) -□F Voltage 1 to 6	
Double (Latching)	VQ110L-□F Voltage 1 to 6	



#### Construction: VQ0000, 1000, 2000/Plug Lead Unit, Flip Type




#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

#### 4 Pilot valve assembly

<u> </u>	•	
Single 3 position (VQ1000)	VQ111 (H) -	
Double (Latching)	VQ110L - M -2 (VQ1000) Voltage 1 to 6	
3 position (VQ1000)	VQ111 (H) Note) L (Y) — MA X18 (A side (Bottom side)) (Y) Voltage G Nil (B side (Top side)) 1 to 6	The direction of the L and M connectors of a pilot valve is opposite to that of the single and double type.
	00 0 = 144 0 + 00 +	

Note 1) (H): 1.5 W, (Y): 0.5 W, G type: DC only



#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool valve	Aluminum/HNBR	
3	Piston	Resin	

#### 4 Pilot valve assembly

Single 3 position (VQ1000)	VQ111 (H) -	
Double (Latching)	VQ110L - M -2 (VQ1000) Voltage 1 to 6	
3 position (VQ1000)	VQ111 (H) Note) L (Y) — MA X18 (A side (Bottom side)) (Y) Noltage G Nil (B side (Top side)) 1 to 6	The direction of the L and M connectors of a pilot valve is opposite to that of the single and double type.

Note 1) (H): 1.5 W, (Y): 0.5 W, G type: DC only



VQC

SQ

VQ0

VQ4


VQ5


VQZ

**VQD** 


#### Construction: VQ1000/Plug Lead Unit, Cassette Type

#### Metal seal Single/Double (Latching)





#### 3 position




VQ1370	VQ1470	VQ1570
4, 2		
5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)

#### **Component Parts**


No.	Description	Material Note	
1	Body	Zinc die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

#### 4 Pilot valve assembly

Single	VQ111(H)-□ M -2 Voltage	
Double (Latching)	VQ110L -□M-2 Voltage ↓ 1 to 6	
3 position	VQ111(H)- L (Y) - M - X18 {A side (Bottom side)} Voltage	The direction of the L and Mconnectors of a pilot valve is opposite to that of the single and double type.




## Rubber seal Single/Double (Latching)



VQ1171	VQ1271
(A)(B) 4 2	(A)(B) 4 2
Z₽,\\\\\\\\	513
(R1)(P)(R2)	(R1)(P)(R2)

#### 3 position




VQ1371	VQ1471	VQ1571
5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)	5 1 3 (R1)(PXR2)

#### **Component Parts**

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool valve	Aluminum/HNBR	
3	Piston	Resin	

#### 4 Pilot valve assembly


Single	VQ111(H)-□M-2 Voltage → G 1 to 6	
Double (Latching)	VQ110L - □ M - 2  Voltage   1 to 6	
3 position	VQ111(H) L A Side (Bottom side)} Voltage G Nil {B side (Top side)} 1 to 6	The direction of the L and Mconnectors of a pilot valve is opposite to that of the single and double type.




#### Construction Main Parts, Replacement Parts Series VQ

#### **Construction: VQ1000/Single Unit**

#### Metal seal Single/Double (Latching)



#### 3 position




VQ1360	VQ1460	VQ1560
ANT THE REAL PROPERTY OF THE PARTY		
5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)

#### **Component Parts**


No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

#### 4 Pilot valve assembly


Single/3 position	Note) VQ111(H)-□M-2 Voltage 1 to 6	
Double (Latching)	VQ110L-□ L Voltage ↓ 1 to 6	



#### Rubber seal Single/Double (Latching)



3 position



VQ1361	VQ1461	VQ1561
5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)	5 1 3 (R1)(P)(R2)

**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ


VQD

#### **Component Parts**

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool valve	Aluminum/HNBR	
3	Piston	Resin	
_	-		


#### 4 Pilot valve assembly

Single/3 position	Note) VQ111(H)-□M-2 Voltage G 1 to 6	
Double (Latching)	VQ110L-□L-2 Voltage ↓ 1 to 6	



# **Exploded View of Manifold**

## VQ1000 (VV5Q13)/Plug-in Unit, Flip Type





## <Housing Assembly and SI Unit> Housing assembly and SI unit no.


No.	Manifold	Part no.	Description		
	(SA kit)	EX330-S001	General type SI unit (Series EX300)		
	(SB kit)	EX130-SMB1	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corporation)		
(1)	(SC kit)	EX130-STA1	SI unit for SYSBUS Wire System (OMRON Corporation)		
1	(SD kit)	EX130-SSH1	SI unit for Satellite I/O Link System (SHARP Corporation)		
	(SF1 kit)	EX130-SUW1	SI unit for 16 point Uni-wire System (NKE Corporation)		
	(SH kit)	EX130-SUH1	SI unit for 16 point Uni-wire H System (NKE Corporation)		
	P <sub>S</sub> <sup>U</sup> kit	AXT100-1-P <sub>S</sub> <sup>U</sup> □ (2)	Flat cable housing assembly □ = Number of pins: 26, 20, 16, 10		
2	J <sup>∪</sup> <sub>S</sub> kit	AXT100-1-J <sub>S</sub> <sup>U</sup> 20 <sup>(2)</sup>	Flat cable housing assembly		
3	F <sub>S</sub> kit	AXT100-1-F <sub>S</sub> <sup>U</sup> □ (2)	D-sub connector housing assembly □ = Number of pins: 25, 15		

Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-1-PU20) of ① SI unit and ② P kit (20 pins). Place an order for AXT-100-1-PS20 separately.

Note 2) Top/vertical entry connector for FU and PU while side (horizontal) entry connector for FS and PS.

## <D Side End Plate Assembly>

45 D side end plate assembly no.




Note 1) Applicable for L kit only

Note 2) The housing assembly and SI unit of F/P/J/S kit are not included. Separately place an order for ①, ②, and ③.

Note 3) The 10's fitting assembly is included.

## <U Side End Plate Assembly No.>

6 U side end plate assembly no.



Nil: Common exhaust

L: For L kit S: For S kit

S: Built-in silencer, direct exhaust

Note) The 10's fitting assembly is included.

## <Junction Box Assembly>

Junction box assembly no.

## VVQ1000-1A-3-□

 Electrical entry F1: For F kit

P1: P, G, T, S kit for 1 to 12 stations/Double wiring P2: G, S kit for 13 to 16 stations/Double wiring

P3: G, S kit for 1 to 16 stations/Single wiring L0□: L0 kit Note) L1□: L1 kit Note) □: Stations (1 to 16)

□: Stations (1 to 16)

L2□: L2 kit Note)

Note) Lead wire assembly for extensions is attached.

#### <Replacement Parts>

No.	Part no.	Description	Material	Number
8	VVQ1000-80A-3-2	Seal	HNBR	12
9	VVQ1000-80A-4	Clip	Stainless steel	12

Note) A set of parts containing 12 pcs. each is enclosed.

## <Fittings Assembly>

10 Fittings assembly part no.

VVQ1000-50A-

Port size

C3: Applicable tubing ø3.2

C4: Applicable tubing ø4

C6: Applicable tubing ø6 (1)



Note 1) Standard SUP/EXH port is C6.

Note 2) Purchasing order is available in units of 10 pieces.

## Station Increase Parts>

Stati	on increase Faits/	* THE Station	can be increased up t	U Z SIAIIUIIS.
No. <sup>(3)</sup>	Part no.	Description	Material	Number <sup>(1)</sup>
11)	VVQ1000-105A-3-□ (2)	Tie-rod bolt	Carbon steel	2
12		Junction cover	Stainless steel	1



Note 1) Each number of replacement parts are included in one set.

Note 2) □: Number of stations (01 to 16)

Note 3) 11 and 12 are in one set.



**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ


VQD

## Series VQ

## VQ0000 (VV5Q04)/Plug Lead Unit, Flip Type

(F, P, T, S kit)

\* For how to increase the stations, refer to the instruction manual.





Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PU20) of 1 SI unit and 2 P kit (20 pins).

Note 2) Since no connector assembly is included, order it separately. (Refer to page 2-4-69.)

Note 3) A housing assembly is not used for a C kit.

Note 4) A DIN rail clamping bracket is attached to each.

## <Housing Assembly and SI Unit>

## Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
	(SA kit)	EX330-S001	General type SI unit (Series EX300)
	(SB kit)	EX130-SMB1	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corporation)
①(1)	(SC kit)	EX130-STA1	SI unit for SYSBUS Wire System (OMRON Corporation)
U	(SD kit)	EX130-SSH1	SI unit for Satellite I/O Link System (SHARP Corporation)
	SF1 kit	EX130-SUW1	SI unit for 16 point Uni-wire System (NKE Corporation)
	SH kit	EX130-SUH1	SI unit for 16 point Uni-wire H System (NKE Corporation)
2	P <sub>S</sub> kit	AXT100-2-P <sub>S</sub> <sup>U</sup> □ (2)	Flat ribbon cable housing assembly □ = Number of pins: 26, 20, 16, 10
3	F <sub>S</sub> <sup>U</sup> kit	AXT100-2-F <sup>U</sup> <sub>S</sub> □ <sup>(2)</sup>	D-sub connector housing assembly □ = Number of pins: 25, 15
<b>4</b> )(3)	T kit	AXT100-2-TB1	Terminal block assembly (8 terminals)
⑤ <sup>(3)</sup>	T kit	AXT100-2-TB2	Terminal block assembly (8 terminals)

No

Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PS20) of ① SI unit and ② P kit (20 pins). Place an order for AXT100-2-PS20 separately.

Note 2) Top/vertical entry connector for FU and PU while side (horizontal) entry connector for FS and PS.

Note 3) In the case of standard specifications and double wiring, 4 is for 1 to 4 stations and 5 is for 5 to 8 stations.

Since no connector assembly is included, order it separately. (Refer to page 2-4-69.)

VQ4

**VQC** 

SQ

VQ0

VQ5

VQZ

VQD

## <D Side End Plate Assembly>

 $\ensuremath{\mathfrak{G}}$  D side end plate assembly no.

VVQ0000-3A-4-□

Option

S: Built-in silencer, direct exhaust

P: Exclusively for SUP

The end plate style is subject to the kit. The combination as standard is as follows.

Kit	Part no.	U side end plate assembly	D side end plateassembly
E D C Lit	Common exhaust type	VVQ0000-3A-4-P	VVQ0000-2A-4-R
F, P, S kit	Built-in silencer, direct exhaust	VVQ0000-3A-4-P	VVQ0000-2A-4-S
C kit	Common exhaust type	VVQ0000-3A-4-P	VVQ0000-2A-4-R
C KIL	Built-in silencer, direct exhaust	VVQ0000-3A-4-S	VVQ0000-2A-4-S

## <U Side End Plate Assembly No.>

① U side end plate assembly no.

VVQ0000-2A-4-□

→ Option

S: Built-in silencer, direct exhaust

R: Exclusively for EXH (Common exhaust type)

### <Replacement Parts>

No.	Part no.	Description	Material	Number
8	VVQ0000-80A-4-2	Seal	HNBR	12

Note) A set of parts containing 12 pcs. each is enclosed.

### <Station Increase Parts>

No. (3)	Part no.	Description	Material	Number (1)
9	VVQ0000-105A-4-□ <sup>(2)</sup>	Tie-rod bolt	Carbon steel	2
10		Guide rod	Stainless steel	1

Note 1) Each number of replacement parts are included in one set.

Note 2) □: Number of stations (01 to 16)


Note 3) 9 and 10 are in one set.


## Series VQ

## VQ1000 (VV5Q14)/Plug Lead Unit, Flip Type

(F, P, T, S kit)

\* For how to increase the stations, refer to the instruction manual.





Note 2) Since no connector assymbly is included, order it separately. (Refer to page 2-4-69.)

Note 3) A housing assembly is not used for a C kit.

Note 4) A DIN rail clamping bracket is attached to each.

## <Housing Assembly and SI Unit> Housing assembly and SI unit no.

No.	Manifold	Part no.	Description				
	(SA kit)	EX330-S001	General type SI unit (Series EX300)				
	(SB kit)	EX130-SMB1	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corporation)				
①(1)	(SC kit)	EX130-STA1	SI unit for SYSBUS Wire System (OMRON Corporation)				
U	(SD kit)	EX130-SSH1	SI unit for Satellite I/O Link System (SHARP Corporation)				
	(SF1 kit)	EX130-SUW1	SI unit for 16 point Uni-wire System (NKE Corporation)				
	(SH kit)	EX130-SUH1	SI unit for 16 point Uni-wire H System (NKE Corporation)				
2	P <sub>S</sub> <sup>U</sup> kit	AXT100-2-P <sub>S</sub> □ (2)	Flat ribbon cable housing assembly □ = Number of pins: 26, 20, 16, 10				
3	F <sub>S</sub> <sup>U</sup> kit	AXT100-2-F <sub>S</sub> □ (2)	D-sub connector housing assembly □ = Number of pins: 25, 15				
<b>4</b> (3)	T kit	AXT100-2-TB1	Terminal block assembly (8 terminals)				

**5**(3) Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PS20) of ① SI unit and ② P kit (20 pins). Place an order for AXT100-2-PS20 separately.

Terminal block assembly (8 terminals)


Note 2) Top/vertical entry connector for FU and PU while side (horizontal) entry connector for FS and PS.

Note 3) Since no connector assembly is included, order it separately. (Refer to page 2-4-69.)

Note 4) In the case of standard specifications and double wiring, 4 is for 1 to 4 stations and 5 is for 5 to 8 stations.

## <D Side End Plate Assembly>

6 D side end plate assembly no.



Option

AXT100-2-TB2

Nil: Common exhaust

S: Built-in silencer, direct exhaust (Applicable for C kit only)

## <U Side End PlateAssembly No.>

① U side end plate assembly no.

VVQ1000-2A-4-□

Option

Nil: Common exhaust

S: Built-in silencer, direct exhaust

Note) The 10's fitting assembly is included.

Note 1) Standard SUP/EXH port is C6.

Note) The 10's fitting assembly is included.

### <Replacement Parts>

No.	Part no.	Description	Material	Number
8	VVQ1000-80A-3-2	Seal	HNBR	12
9	VVQ1000-80A-4	Clip	Stainless steel	12

Note) A set of parts containing 12 pcs. each is enclosed.

## <Fittings Assembly>

10 Fittings assembly part no.

VVQ1000-50A-□

Port size

C3: Applicable tubing ø3.2

C4: Applicable tubing ø4

**C6**: Applicable tubing ø6 <sup>(1)</sup>

## <Station Increase Parts>

No. (3)	Part no.	Description	Material	Number (1)
11)	VVQ1000-105A-4-□ <sup>(2)</sup>	Tie-rod bolt	Carbon steel	2
12		Guide rod	Stainless steel	1



Note 1) Each number of replacement parts are included in one set.

Note 2) □: Number of stations (01 to 16)

Note 3) (1) and (12) are in one set.

Note 2) Purchasing order is available in units of 10 pieces.

SQ

**VQC** 

VQ0

VQ4

VQ5

VQZ


VQD

## Series VQ

## VQ2000 (VV5Q24)/Plug Lead Unit, Flip Type

(F, P, T, S kit)

\* For how to increase the stations, refer to the instruction manual.





Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PU20) of 1 SI unit and 2 P kit (20 pins).

Note 2) Since no connector assembly is included, order it separately. (Refer to page 2-4-69.)

Note 3) A housing assembly is not used for a C kit.

Note 4) A DIN rail clamping bracket is attached to each.

## <Housing Assembly and SI Unit>

Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
	(SA kit)	EX330-S001	General type SI unit (Series EX300)
	(SB kit)	EX130-SMB1	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corporation)
(1)	(SC kit)	EX130-STA1	SI unit for SYSBUS Wire System (OMRON Corporation)
①	(SD kit)	EX130-SSH1	SI unit for Satellite I/O Link System (SHARP Corporation)
	SF1 kit	EX130-SUW1	SI unit for 16 point Uni-wire System (NKE Corporation)
	SH kit	EX130-SUH1	SI unit for 16 point Uni-wire H System (NKE Corporation)
2	P <sub>S</sub> <sup>U</sup> kit	AXT100-2-P <sub>S</sub> <sup>U</sup> □ (2)	Flat ribbon cable housing assembly □ = Number of pins: 26, 20, 16, 10
3	F <sub>S</sub> kit	AXT100-2-F <sub>S</sub> <sup>U</sup> □ (2)	D-sub connector housing assembly □ = Number of pins: 25, 15
<b>4</b> )(3)	T kit	AXT100-2-TB1	Terminal block assembly (8 terminals)
<b>(5)</b> (3)	T kit	AXT100-2-TB2	Terminal block assembly (8 terminals)

Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PS20) of ① SI unit and ② P kit (20 pins). Place an order for AXT100-2-PS20 separately.

Note 2) Top/vertical entry connector for FU and PU while side (horizontal) entry connector for FS and PS.

Note 3) Since no connector assembly is included, order it separately. (Refer to page 2-4-93.)

Note 4) In the case of standard specifications and double wiring, (4) is for 1 to 4 stations and (5) is for 5 to 8 stations.

SQ

**VQC** 

VQ0

VQ4

VQ5

VQZ

VQD

## <D Side End Plate Assembly>

6 D side end plate assembly no.

VVQ2000-3A-4-□

Option

Nil: Common exhaust

S: Built-in silencer, direct exhaust (Applicable for C kit only) Note) The ®'s fitting assembly is included.

## <U Side End Plate Assembly No.>

① U side end plate assembly no.

VVQ2000-2A-4-□

Option

Nil: Common exhaust

S: Built-in silencer, direct exhaust

Note) The 10's fitting assembly is included.

### <Replacement Parts>

No.	Part no.	Description	Material	Number
8	VVQ2000-80A-3-2	Seal	HNBR	12
9	VVQ2000-80A-3-4	Clip	Stainless steel	12

Note) A set of parts containing 12 pcs. each is enclosed.

## <Fittings Assembly>

10 Fittings assembly part no.

VVQ1000-51A-□

→ Port size

C4: Applicable tubing ø4

**C6**: Applicable tubing ø6 **C8**: Applicable tubing ø8 <sup>(1)</sup>

Note 1) Standard SUP/EXH port is C8.
Note 2) Purchasing order is available in units of 10 pieces.

#### <Station Increase Parts>

No. (3)	Part no.	Description	Material	Number (1)
11)	VVQ2000-105A-4-□ <sup>(2)</sup>	Tie-rod bolt	Carbon steel	2
12	v vQ∠000-105A-4-□ (=)	Guide rod	Stainless steel	1

Note 1) Each number of replacement parts are included in one set.

Note 2) □: Number of stations (01 to 16)

Note 3) 11 and 12 are in one set.




## Series VQ

## VQ1000 (VV5Q17)/Plug Lead Unit, Cassette Type

(F, P, T, S kit)

\* For how to increase the stations, refer to the instruction manual.





Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PU20) of ① SI unit and ② P kit (20 pins).

Note 2) Since no connector assembly is included, order it separately. (Refer to page 2-4-93.)

Note 3) A housing assembly is not used for a C kit.

Note 4) A DIN rail clamping bracket is attached to each.



## <Housing Assemnly and SI Unit>

Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
	(SA kit)	EX321-S001(-XP)	General type SI unit (Series EX300)
	(SB kit)	EX121-SMB1(-XP)	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corporation)
	(SC kit)	EX121-STA1(-XP)	SI unit for SYSBUS Wire System (OMRON Corporation)
	(SD kit)	EX121-SSH1(-XP)	SI unit for Satellite I/O Link System (SHARP Corporation)
	(SE kit)	EX121-SPA1	SI unit for MEWNET-F System (Matsushita Electric Works Ltd.)
	(SF1kit)	EX121-SUW1(-XP)	SI unit for 16 point Uni-wire System (NKE Corporation)
	(SG kit)	EX121-SAB1(-XP)	SI unit for Allen Bradley Remote I/O (RIO) System (Rockwell Automation, Inc.)
① (1)	(SH kit)	EX121-SUH1(-XP)	SI unit for 16 point Uni-wire H System (NKE Corporation)
	(SJ1 kit)	EX121-SSL1(-XP)	SI unit for 16 point S-LINK System (SUNX Corporation)
	(SJ2 kit)	EX121-SSL2(-XP)	SI unit for 8 point S-LINK System (SUNX Corporation)
	(SK kit)	EX121-SFU1(-XP)	SI unit for T-LINK Mini System (Fuji Electric Co.,Ltd.)
	(SQ kit)	EX121-SDN1	SI unit for DeviceNet, CompoBus/D (OMRON Corporation)
	(SR1 kit)	EX121-SCS1(-XP)	SI unit for 16 point CompoBus/S System (OMRON Corporation)
	(SR2 kit)	EX121-SCS2(-XP)	SI unit for 8 point CompoBus/S System (OMRON Corporation)
	(SV kit)	EX121-SMJ1(-XP)	Mitsubishi Electric Corporation: CC-LINK System
2	P <sub>S</sub> kit	AXT100-2-P <sub>S</sub> <sup>U</sup> □ (2)	Flat ribbon cable housing assembly □ = Number of pins: 26, 20, 16, 10
3	F <sub>S</sub> kit	AXT100-2-F <sub>S</sub> <sup>U</sup> □ (2)	D-sub connector housing assembly □ = Number of pins: 25, 15
<b>4</b> (3)	T kit	AXT100-2-TA1	Terminal block assembly (8 terminals)
⑤(3)	T kit	AXT100-2-TA2	Terminal block assembly (8 terminals)

Note 1) A S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PS20) of ① SI unit and ② P kit (20 pins). Place an order for AXT100-2-PS20 separately. Suffix -XP for dustproof type SI unit.

Note 2) Top/vertical entry connector for FU and PU while side (horizontal) entry connector for FS and PS.

Note 3) Since no connector assembly is included, order it separately. (Refer to page 2-4-93.)

Note 4) In the case of standard specifications and double wiring, 4 is for 1 to 4 stations and 5 is for 5 to 8 stations.

## <D Side End Plate Assembly> 6 D side end plate assembly no.

VVQ1000-3A-7

Note) The  $\, @$ 's fitting assembly is included.

## <U Side End Plate Assembly No.>

7 U side end plate assembly no.

VVQ1000-2A-7

Note) The 10's fitting assembly is included.

## <Replacement Parts>

Ν	lo.	Part no.	Description	Material	Number
(8	8	VVQ1000-80A-7-2	Bushing assembly		3
(9	9	VVQ1000-80A-7-4	Clip	Stainless steel	12

<Fittings Assembly>

10 Fittings assembly part no.

VVQ1000-50A-□

Port size

C3: Applicable tubing ø3.2

C4: Applicable tubing ø4

**C6**: Applicable tubing ø6 <sup>(1)</sup>

Note 1) Standard SUP/EXH port is C6. Note 2) Purchasing order is available in units of 10 pieces.



**VQZ** 

**VQC** 

SQ

VQ0

VQ4

VQ5

VQD

# **Base Mounted** Metal Seal/Rubber Seal Series V

## Space-saving profile

All pilot valves are compactly mounted on one side. The space-saving design of mounting all fittings on one side permits mounting in three directions.

Space-saving ...... 45% less Capacity-saving ..... 50% less

# **Unprecedented high speed**

VQ1000 10 ms 200 million cycles VQ2000 20 ms

Dispersion accuracy ±2 ms

#### response and long service life (Metal seal, single, with indicator light/surge voltage suppressor) VQ0000 10 ms

VQ4 VQ5

VQC

SQ

VQ0


VQZ

VQD

## Thin compact design with large flow capacity

		Manifold	Flow char	acteristics	
	Model	Manifold pitch			Cylinder
	(mm)		C [dm³/(s·bar)]	C [dm <sup>3</sup> /(s·bar)]	size
	VQ0000	<b>VQ0000</b> 10.7		0.53	Up to ø40
ĺ	VQ1000	<b>VQ1000</b> 10.5		1.0	Up to ø50
ĺ	VQ2000	16	2.6	3.2	Up to ø80

\* Flow characteristics:  $4/2 \rightarrow 5/3$  (A/B  $\rightarrow$  R1/R2)



**VQ0000** 

**VQ1000** (VV5Q11)

Individual SUP spacer

Individual EXH spacer

(Bottom entry connector) \* The photo does not show an actual use example.

A variety of options

# **VQ2000** (VV5Q21)

## **Innovative** mounting methods

Elbow fitting assembly


(Top entry connector) Elbow fitting assembly

DIN rail

The non-bias, one-clamp structure permits easy valve replacement. (Plug-in unit)


**Built-in One-touch** fittings for easy piping.


## A variety of common wiring methods are standardized.



## Valve Specifications

					So condu	nic ctance /(s·bar)]	Type of actuation		Voltage		Electrical entry		try	Manual override		erride						
					Double Single	(s·bar)] → 5/3 R1/R2) Closed center	Single	Double	Closed center	Exhaust center	Pressure center	12 V 24 V DC	100 V 110 V AC (50/60) Hz	200 V 220 V AC (50/60) Hz	Plug-in	Grommet	L plug connector	M plug connector	Push type, Tool required	Locking type	Locking type (Manual)	
		Series	Rubber seal	VQ□00	0.72	0.72																
	Plug-in	<b>VQ1000</b> P. 2-4-120	Metal seal	VQ1□01	1.0	0.65							P. 2	F/L kit only)	128							
	Plug	Series	Rubber seal	VQ2□00	2.6	2.0																
ase Mounted		<b>VQ2000</b> P. 2-4-124	Wetal seal VQ2□01	VQ2□01	3.2	2.2							P. 2	(F/L kit only)	128							
Base M			Rubber seal	VQ0□50	0.44	0.32																
	Plug lead	<b>VQ0000</b> P. 2-4-182	Metal seal	VQ0□51	0.53	0.44							P. 2	2-4-	186							
	Plug	Series	Rubber seal	VQ1□10	0.72	0.72																
		<b>VQ1000</b> P. 2-4-184	Metal seal	VQ1□11	1.0	0.65							P. 2	2-4-	186							






## Series VQ/Base Mounted: Variations

## **Manifold Variations** Flat ribbon cable Flat ribbon cable Flat ribbon cable **D-sub connector** with power supply connector connector (26, 20, 16, 10 pins) (20 pins) terminal block Conforming to MIL D-sub connector Conforming to MIL flat ribbon cable connector Conforming to MIL flat ribbon cable connector PC Wiring System compatible Conforming to MIL flat ribbon cable Applicable to OMRON's serial transmission unit PC Wiring System compatible **Series VQ1000** P. 2-4-134 P/J kit **Series VQ2000** P. 2-4-134 P. 2-4-130 P/J kit P. 2-4-142 **Series VQ0000** P kit only P. 2-4-192 **Series VQ1000** P kit only P. 2-4-192

## **Manifold Variations**



**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ

VQD

## **Cylinder Speed Chart**

Use as a guide for selection.

Please confirm the actual conditions with SMC Sizing Program

**VQC** 

SQ


VQ0

VQ4

VQ5

**VQZ** 

VQD





<sup>\*</sup> It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open.

- \* The average velocity of the cylinder is what the stroke is divided by the total stroke time.
- \* Load factor: ((Load weight x 9.8)/Theoretical force) x 100%


#### **Conditions**


Series	Conditions	Series CJ2	Series CM2	Series MB, CA1			
	Tube bore x Length		T0425 x 1 m				
VQ0151	Speed controller		AS2001F-04				
	Silencer	AN103-X233					
	Tube bore x Length		T0604 x 1 m				
VQ1101	Speed controller	AS3001F-06					
	Silencer	AN103-X233					
	Tube bore x Length		T0806 x 1 m				
VQ2101	Speed controller	AS3001F-08					
	Silencer		AN200-KM8				



# Series VQ1000 Base Mounted Plug-in Unit

## **How to Order Manifold**





Note 1) Besides the above, F and P kits with different number of pins are available. Refer to page 2-4-177 for details. Note 2) For details, refer to page 2-4-178.

**VQC** 

SQ

VQ0


VQ4

VQ5

VQZ

VQD

## Plug-in Unit Series VQ1000




Note) Rubber seal type only

(B) A THE STATE OF N<sub>.O</sub>


N.O position dual 3 port valve

## **How to Order Manifold Assembly**



The asterisk denotes the symbol for assembly. Prefix it to the part nos, of the solenoid valve, etc.

Specify the part numbers for valves and options together beneath the manifold base part number. Besides, when the arrangement will be complicated, specify them by means of the manifold specification sheet.




## Series VQ1000


## **Manifold Option**

Double check block

## Blanking plate assembly VVQ1000-10A-1




Individual SUP spacer VVQ1000-P-1-C6



SUP block plate

EXH block base assembly VVQ1000-19A- [-]- Salar









Silencer (For EXH port) AN200-KM8/AN203-KM8







Blanking plug

Blanking plate with connector VVQ1000-1C□-□



Individual EXH spacer VVQ1000-R-1-C6






Back pressure check valve assembly [-B] DIN rail mounting bracket [-D] VVQ1000-18A VVQ1000-57A



Regulator unit VVQ1000-AR-1




• For cylinder port fittings part no., refer to page 2-4-

For replacement parts, refer to page 2-4-227.




175.




With vacuum ejector unit [-J□]





Name plate [-N] Built-in silencer, VVQ1000-NC -Station (1 to Max. stations) direct exhaust [-S]







Port plug VVQ0000-58A












2-4-122





## **How to Order Manifold**



**VQC** 

SQ

VQ0


VQ4

VQ5


VQZ

VQD


## Plug-in Unit Series VQ2000



## **How to Order Manifold Assembly**



the manifold specification sheet.



Note 1) Besides the above. F and P kits with different number of pins are available. Refer to page 2-4-177 for details.

Note 2) For details, refer to page 2-4-178.


Note 3) Refer to the pages on respective kits for IP65 type. (T, L and S kits)

Note 4) Kits with IP65 enclosure applicable to input/output are also available. Refer to page 2-4-162 for details.


## Series VQ2000

#### **Manifold Option** P. 2-4-210


## Blanking plate assembly VVQ2000-10A-1



Individual SUP spacer VVQ2000-P-1-C8



Individual EXH spacer VVQ2000-R-1-C8




Back pressure check valve assembly [-B] VVQ2000-18A



SUP block plate VVQ2000-16A



EXH block plate VVQ2000-19A



Name plate [-N] VVQ2000-N-Station (1 to Max. stations)




Elbow fitting assembly VVQ2000-F-L (C4, C6, C8)




DIN rail mounting bracket [-D] VVQ2000-57A



Built-in silencer, direct exhaust [-S]




Silencer (For EXH port) AN200-KM10




2 stations matching fitting assembly VVQ2000-52A-C10



Port plug VVQ1000-58A




Blanking plug KQ2P- %





- For cylinder port fittings part no., refer to page 2-4-175.
  For replacement parts, refer to page 2-4-227.

## Double check block VQ2000-FPG-□□



VQC

SQ

VQ0

VQ4

VQ5


VQZ

VQD

## Series VQ1000/2000

# **Base Mounted**

# **Plug-in Unit**



#### Model

						Flow	chara	cteristics (1)			Resp	onse time (m	s) <sup>(2)</sup>	Maial
Series		umber of olenoids	Mode	el	1 → 2/4 (P → A/B)			2/4 → 3/5 (A/B → R1/R2)			Standard: 1 W	Low wattage:	AC	Weigl (g)
	ľ	oleriolas			C [dm³/(s·bar)]	b	Cv	C [dm³/(s·bar)]	b	Cv	H: 1.5 W	0.5 W	AC	(9)
	_	0:! -	Metal seal	VQ1100	0.70	0.15	0.16	0.72	0.25	0.18	12 or less	15 or less	29 or less	64
	2 position	Single	Rubber seal	VQ1101	0.85	0.20	0.21	1.0	0.30	0.25	15 or less	20 or less	34 or less	04
	ŏ	Double	Metal seal	VQ1200	0.70	0.15	0.16	0.72	0.25	0.18	10 or less	13 or less	13 or less	
		Double	Rubber seal	VQ1201	0.85	0.20	0.21	1.0	0.30	0.25	15 or less	20 or less	20 or less	
		Closed	Metal seal	VQ1300	0.68	0.15	0.16	0.72	0.25	0.18	20 or less	26 or less	40 or less	
VQ1000	٦	center	Rubber seal	VQ1301	0.70	0.20	0.16	0.65	0.42	0.18	25 or less	33 or less	47 or less	
VQ1000	position	Exhaust	Metal seal	VQ1400	0.68	0.15	0.16	0.72	0.25	0.18	20 or less	26 or less	40 or less	78
	3 pc	center	Rubber seal	VQ1401	0.70	0.20	0.16	1.0	0.30	0.25	25 or less	33 or less	47 or less	10
		Pressure	Metal seal	VQ1500	0.70	0.15	0.16	0.72	0.25	0.18	20 or less	26 or less	40 or less	
		center	Rubber seal	VQ1501	0.85	0.20	0.21	0.65	0.42	0.18	25 or less	33 or less	47 or less	
	4 position	Dual 3 port valve	Rubber seal	VQ1B01	0.70	0.20	0.16	0.70	0.20	0.16	25 or less	33 or less	47 or less	
	_	Single	Metal seal	VQ2100	2.0	0.15	0.46	2.6	0.15	0.60	22 or less	29 or less	49or less	9
	2 position		Rubber seal	VQ2101	2.2	0.28	0.55	3.2	0.30	0.80	24 or less	31 or less	51or less	9
	pod 2	Double	Metal seal	VQ2200	2.0	0.15	0.46	2.6	0.15	0.60	15 or less	20 or less	20 or less	
		Double	Rubber seal	VQ2201	2.2	0.28	0.55	3.2	0.30	0.80	20 or less	26 or less	26 or less	
		Closed	Metal seal	VQ2300	2.0	0.15	0.46	2.0	0.18	0.46	29 or less	38 or less	58 or less	
VQ2000	E	center	Rubber seal	VQ2301	2.0	0.28	0.49	2.2	0.31	0.60	34 or less	44 or less	64 or less	
VQ2000	position	Exhaust	Metal seal	VQ2400	2.0	0.15	0.46	2.6	0.15	0.60	29 or less	38 or less	58 or less	11
	3 p	center	Rubber seal	VQ2401	2.0	0.28	0.49	3.2	0.30	0.80	34 or less	44 or less	64 or less	] ' '
		Pressure	Metal seal	VQ2500	2.4	0.17	0.57	2.0	0.18	0.46	29 or less	38 or less	58 or less	
		center	Rubber seal	VQ2501	3.2	0.28	0.80	2.2	0.31	0.60	34 or less	44 or less	64 or less	
	4 position	Dual 3 port valve	Rubber seal	VQ2B01	1.8	0.28	0.46	1.8	0.28	0.46	34 or less	44 or less	64 or less	

Note 1) Cylinder port size C6: (VQ1000), C8: (VQ2000) without check valve option for prevention of back pressure.


Note 2) As per JIS B 8375-1981 (Supply pressure; 0.5 MPa; with indicator light/surge voltage suppressor; clean air)

The response time is subject to the pressure and quality of the air. The values at the time of ON are given for double types.



## Plug-in Unit Series VQ1000/2000

## JIS Symbol



## **Standard Specifications**

<del></del>	Opermentions				
	Valve construction		Metal seal	Rubber seal	
	Fluid		Air/Inert gas Air/Inert gas		
	Maximum operating	g pressure	0.7 MPa (High pres	sure type: 0.8 MPa)	
ons		Single	0.1 MPa	0.15 MPa	
icati	Minimum	Double	0.1 MPa	0.1 MPa	
)ecif	operating pressure	3 position	0.1 MPa	0.2 MPa	
Valve specifications	Ambient and fluid t	emperature	-10 to	50°C <sup>(1)</sup>	
\al <sub>\</sub>	Lubrication		Not	required	
	Manual override		Push type/Locking type (Tool required, Manual type) Option		
	Impact/Vibration re	sistance (2)	150	/30 m/s²	
	Enclosure		Dust-protected, Dust tight	nt/Low jetproof type (IP65) (5)	
	Coil rated voltage		12 , 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)		
	Allowable voltage f	luctuation	±10% of rated voltage		
	Coil insulation type	1	Class B or equivalent		
ē		24 VDC	1 W DC (42 mA), 1.5 W DC	(63 mA) <sup>(3)</sup> , 0.5 W DC (21 mA) <sup>(4)</sup>	
Solenoid		12 VDC	1 W DC (83 mA), 1.5 W DC (	(125 mA) <sup>(3)</sup> , 0.5 W DC (42 mA) <sup>(4)</sup>	
So	Power	100 VAC	Inrush 1.2 VA (12 mA	), Holding 1.2 VA (12 mA)	
	consumption (Current)	110 VAC	Inrush 1.3 VA (12 mA	a), Holding 1.3 VA (12 mA)	
		200 VAC	Inrush 2.4 VA (12 mA	), Holding 2.4 VA (12 mA)	
		220 VAC	Inrush 2.6 VA (12 mA	), Holding 2.6 VA (12 mA)	

Note 1) Use dry air to prevent condensation when operating at low temperatures.

Note 2) Impact resistance ··· No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-

energized states every once for each condition. (Values at the initial period)

Vibration resistance ··· No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at

the right angles to the main valve and armature. (Values at the initial period)


Note 3) Value for high voltage type (1.5 W)


Note 4) Value for low voltage type (0.5 W)

Note 5) Dusttight/Low jetproof type (IP65) is available on T, L, S and M kits of VQ2000.

## **Manifold Specifications**

	Dia Opcom		_						
			Po	rting specificatio	ns	(2)		5 station	
Series	Base model	Type of connection	Dowt location	Port	size (1)	Applicable stations	Applicable solenoid valve	weight	
			Port location	1(P), 3(R)	4(A), 2(B)	Stations	Solellold valve	(g)	
		■ F kit–D-sub connector							
		■ P kit–Flat ribbon cable connector		00 ( 0)	C3 (ø3.2) C4(ø4) C6 (ø6)	F, P, T kits			
		■ J kit-Flat ribbon cable connector (20P)		C8 (ø8)  Option Built-in silencer,		2 to 24 stations		628	
VQ1000	VV5Q11-□□□	■ G kit-Flat ribbon cable connector with terminal block	Side			J, G, S kit 2 to 16 stations		(Single) 759	
		■ T kit–Terminal box		direct exhaust	M5 (M5 thread)	/ L kit \		(Double, 3 position)	
		■ L kit–Lead wire cable		,	(	1 to 8 stations		3 position)	
		■ S kit–Serial transmission unit							
		■ F kit–D-sub connector				/ F, P kits			
		■ P kit-Flat ribbon cable connector		C10 (ø10)		2 to 24 stations			
		■ J kit-Flat ribbon cable connector (20P)		` ′	C4 (ø4)	( J, G, S kit )	\ <u>'</u>	1051	
VQ2000	VV5Q21-□□□	■ G kit-Flat ribbon cable connector with terminal block	Side	Option Built-in	C6 (ø6)	2 to 16 stations	VQ2□00	(Single)	
* Q2000	110021-000	■ T kit–Terminal box	Side	silencer,	C8 (ø8)	L kit 1 to 8 stations	VQ2□01	1144 (Double,	
		■ L kit-Lead wire cable		\direct exhaust /	33 (30)	1		3 position)	
		■ S kit-Serial transmission unit				T kit 2 to 20 stations			
		■ M kit-Multi-connector				( 2 to 20 stations )			





**VQC** 


SQ

VQ0 VQ4

VQ5

**VQZ** 

VQD







- The D-sub connector reduces installation labor for electrical connections.
- Using the D-sub connector (25P), (15P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 24.

## **Manifold Specifications**

	Р	orting spec		
Series	Port	Po	Applicable stations	
	locaition 1(P)			
VQ1000	Side	C8	C3, C4, C6, M5	Max. 24 stations
VQ2000	Side	C10	C4, C6, C8	Max. 24 stations


## **D-sub Connector (25 pins)**

## Cable Assembly ●



The D-sub connector cable assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold.

Note) Types with 15 pin are also available. Refer to page 2-4-177 for details.



#### **D-sub Connector Cable Assembly (Option)**

Cable length (L)	Assembly part no.	Note	
1.5 m	AXT100-DS25-015	0 11 05	
3 m	AXT100-DS25-030	Cable 25 core x 24AWG	
5 m	AXT100-DS25-050	A Z IAWG	

\* For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308

#### Electric Characteristics

	Item	Characteristics	
	Conductor resistance Ω/km, 20°C	65 or less	
-	Voltage limit V, 1 min, AC	1000	
	Insulation resistance MΩkm, 20°C	5 or more	

Note) The min. bending radius of D-sub cable assembly is 20 mm.


#### Wire Color by Terminal No. of **D-sub Connector Cable Assembly**

Terminal no.	Lead wire color	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Gray	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Gray	Red
24	Black	White
25	White	None

#### Connector manufacturers' example

- Fujitsu Limited
- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.
- · Hirose Electric Co., Ltd.

## **How to Order Manifold**



#### Option

Symbol	Option	VQ1000	VQ2000	Note
Nil	None	•	•	11010
		_		(-)
В	With back pressure check valve	•	•	(2)
D	DIN rail mounting style	•	•	
G1	1 set of regulator unit			
G2	2 sets of regulator unit	•		(3)
G3	3 sets of regulator unit			
J□	With vacuum ejector unit	•		(4)
к	Special wiring specifications			
Α.	(Not double wiring)		)	(5)
N	With name plate	•	•	
R	External pilot	•	•	(6)
S	Built-in silencer, direct exhaust	•	•	



Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BRS Note 2) Models with a suffix "-B" have check

valves for prevention of back pressure at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) Specify the mounting position in the manifold specification sheet.

Note 4) Refer to page 2-4-170 for the details of ejector mounted styles. A combination of 'J" and "N" is unavailable.

Note 5) Specify the wiring by using of the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

available. For details, refer to page 2-4-

**VQC** 

SQ


VQ0

VQ4

VQ5

VQZ

VQD



#### **How to Order Valves** Series Manual override VQ1000 Nil Non-locking push type (Tool required) 2 VQ2000 Locking type (Tool required) Locking type (Manual) Type of actuation. 2 position single Light/Surge voltage suppressor 2 2 position double Yes 3 3 position closed center Ε None 4 3 position exhaust center 3 position pressure center Coil voltage 100 VAC (50/60 Hz) Function 200 VAC (50/60 Hz) Seal 4 Symbol Specifications DC AC 3 110 VAC (50/60 Hz) Metal seal Standard (1.0 W) 220 VAC (50/60 Hz) 4 Rubber seal type 5 24 VDC High (1.5 W) 12 VDC 6 Н pressure type Note) For external pilot and Low wattage (0.5 W) negative COM type specifications, refer to "Option" on pages 2-4-178 to 2-4-179. Note) For power consumption of

129.

## How to Order Manifold Assembly

Specify the part numbers for valves and options together beneath the manifold base part number.


#### <Example>

## D-sub connector kit with cable (3 m)


VV5Q11-09C6FU2 ···· 1 set -Manifold base no. \*VQ1100-5 .....2 sets-Valve part no. (Stations 1 to 2) VQ1200-5 .....4 sets-Valve part no. (Stations 3 to 6) \*VQ1300-5 .....2 sets-Valve part no. (Stations 7 to 8) \*VVQ1000-10A-1 ······ 1 set-Blanking plate part no. (Station 9)

Prefix the asterisk to the part nos, of the solenoid valve, etc.

Write sequentially from the 1st station on the D side. When part nos. writtencollectively are complicated, specified by using the manifold





AC type, refer to page 2-4-



## **VQ1000**

#### The broken lines indicate the DIN rail mounting style [-D] and the side entry connection [-FS].





<>: AC

## **Dimensions**

Formula L1 = 10.5n + 44.5, L2 = 10.5n + 62.5 n: Station (Maximum 24 stastions)

L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5	223	233.5	244	254.5	265	275.5	286	296.5
L2	83.5	94	104.5	115	125.5	136	146.5	157	167.5	178	188.5	199	209.5	220	230.5	241	251.5	262	272.5	283	293.5	304	314.5
(L3)	112.5	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5	275	287.5	300	312.5	325	325	337.5
(L4)	123	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5	323	335.5	335.5	348


Vacuum ejector unit style: Formula L1 = 10.5n + 28.7 + (Number of ejector units x 26.7)L2 = 10.5n + 46.3 + (Number of ejector units x 26.7)


L4 is L2 plus about 30.



## **VQ2000**

The broken lines indicate the DIN rail mounting style [-D] and the side entry connection [-FS].






<>: AC

#### **Dimensions**

Formula $L1 = 16n + 53$ , $L2 = 16n + 73$	n: Station (Maximum 24 stations)
---	----------------------------------

L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341	357	373	389	405	421	437
L2	105	121	137	153	169	185	201	217	233	249	265	281	297	313	329	345	361	377	393	409	425	441	457
(L3)	137.5	150	162.5	187.5	200	212.5	225	250	262.5	275	300	312.5	325	337.5	350	375	387.5	400	412.5	437.5	450	462.5	487.5
(L4)	148	160.5	173	198	210.5	223	235.5	260.5	273	285.5	310.5	323	335.5	348	360.5	385.5	398	410.5	423	448	460.5	473	498





- MIL flat ribbon cable connector reduces installation labor for electrical connection.
- Using the connector for flat ribbon cable (26P) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 24.

## **Manifold Specifications**


	F			
Series	Port	ı	Port size	Applicable
	location	1(P), 3(R)	4(A), 2(B)	stations
VQ1000	Side	C8	C3, C4, C6, M5	Max. 24 stations
VQ2000	Side	C10	C4, C6, C8	Max. 24 stations

## Flat Ribbon Cable (26 pins)

Cable assembly •

## AXT100-FC26-to

Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold.




#### Flat Ribbon Cable Connector Assembly (Option)


		• • • •
Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC26-1	0-61-00
3 m	AXT100-FC26-2	Cable 26 core x 28AWG
5 m	AXT100-FC26-3	1 20AVVQ

\* For other commercial connectors, use a 26 pins type with strain relief conforming to MIL-C-83503.

## Connector manufacturers' example

- Hirose Electric Co., Ltd. Japan Aviation Electronics Industry, Ltd.
- Sumitomo 3M Limited
- J.S.T. Mfg. Co., Ltd.
- Fujitsu Limited
- · Oki Electric Cable Co., Ltd.





The total number of stations is tabulated starting from one on the D side.

## **How to Order Manifold**

08 C6 P U Cable (Length) Series ! Connector entry Without cable VQ1000 direction With cable (1.5 m) VQ2000 Top entry With cable (3 m) s Side entry With cable (5 m) Cylinder port Manifold 6 Port size VQ1000 VQ2000 Plug-in unit With One-touch fitting for ø3.2 C4 With One-touch fitting for ø4 C6 With One-touch fitting for ø6

C8

M5

Stations -

02 2 stations 24 24 stations

Note) For details, refer to page 2-4-178.

With mixed size/with port plug Note 1) Insert "L" (top piping) or "B" (bottom piping) for elbow type.

Example) B6 (Elbow One-touch fittings for

With One-touch fitting for ø8

M5 thread

ø6, bottom piping.)
Note 2) Indicate "LM" for models with elbow fittings and mixed cylinder port sizes.

Note 3) Specify "Mixed size/with port plug" in the manifold specification sheet.

Note 4) Inch-size One-touch fittings are available. For details, refer to page 2-4-179.



ol	Option	VQ1000	VQ2000	Note
	None	•	•	
Back	pressure check valve	•	•	(2)
DIN	I rail mounting style	•	•	
1 s	et of regulator unit			
2 s	ets of regulator unit	•		(3)
3 s	ets of regulator unit			
With	vacuum ejector uni	t •		(4)
	0 1	•	•	(5)
1	With name plate	•	•	
	External pilot	•	•	(6)
Built-i	n silencer, direct exhaus	•	•	
2	Back DIN 1 s 2 2 ss 3 3 ss J With Spec	None Back pressure check valve DIN rail mounting style 1 set of regulator unit 2 sets of regulator unit 3 sets of regulator unit With vacuum ejector unit Special Wiring Specifications (Not double wiring) With name plate External pilot	None Back pressure check valve DIN rail mounting style 1 set of regulator unit 2 sets of regulator unit 3 sets of regulator unit With vacuum ejector unit Special Wiring Specifications (Not double wiring) With name plate	None Back pressure check valve DIN rail mounting style 1 set of regulator unit 2 sets of regulator unit 3 sets of regulator unit With vacuum ejector unit Special Wiring Specifications (Not double wiring) With name plate External pilot

Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BRS

Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) Specify the mounting position in the manifold

specification sheet.

Note 4) Refer to page 2-4-170 for the details of ejector mounted styles. A combination of "J' and "N" is unavailable.

Note 5) Specify the wiring specifications in the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

**VQC** 

SQ

VQ0


VQ4


VQ5

VQZ

VQD

## Electrical wiring specifications





## **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

<Example> Flat ribbon cable kit with 3 m cable


VV5Q11-09C6PU2 ... 1 set-Manifold base no. \*VQ1100-5 .....2 sets-Valve part no. (Stations 1 to 2)

\*VQ1200-5 ·······4 sets-Valve part no. (Stations 3 to 6) \*VQ1300-5 .....2 sets-Valve part no. (Stations 7 to 8)

\*VVQ1000-10A-1 ······1 set-Blanking plate no. (Station 9)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specified by using the manifold specification






type, refer to page 2-4-129.

**VQ1000** 

The broken lines indicate the DIN rail mounting style [-D] and the side entry connection [-PS].



### **Dimensions**

Formula L1 = 10.5n + 44.5, L2 = 10.5n + 57.5 n: Station (Maximum 24 stations)


L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5	223	233.5	244	254.5	265	275.5	286	296.5
L2	78.5	89	99.5	110	120.5	131	141.5	152	162.5	173	183.5	194	204.5	215	225.5	236	246.5	257	267.5	278	288.5	299	309.5
(L3)	112.5	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	225	237.5	250	262.5	275	287.5	287.5	300	312.5	325	337.5
(L4)	123	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	235.5	248	260.5	273	285.5	298	298	310.5	323	335.5	348


Vacuum ejector unit style: Formula L1 = 10.5n + 28.7 + (Number of ejector units x 26.7) L2 = 10.5n + 41.3 + (Number of ejector units x 26.7) L4 is L2 plus about 30.



## **VQ2000**

The broken lines indicate the DIN rail mounting style [-D] and the side entry connection [-PS].





< >: AC

#### **Dimensions**

Formula L1 = 16n + 53, L2 = 16n + 68 n: Station (Maximum 24 stations)

L	n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
	L1	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309	325	341	357	373	389	405	421	437
	L2	100	116	132	148	164	180	196	212	228	244	260	276	292	308	324	340	356	372	388	404	420	436	452
-	(L3)	125	150	162.5	175	187.5	212.5	225	237.5	262.5	275	287.5	300	312.5	337.5	350	362.5	387.5	400	412.5	425	450	462.5	475
	(L4)	135.5	160.5	173	185.5	198	223	235.5	248	273	285.5	298	310.5	323	348	360.5	373	398	410.5	423	435.5	460.5	473	485.5

# VQ1000/2000 Kit (Flat ribbon cable connector)


- MIL flat ribbon cable connector reduces installation labor for electrical connection.
- The use of flat ribbon cable connectors (20P) conforming to MIL standards provides a wide range of compatibility with conventional
- Top or side receptacle position can be selected in accordance with the available mounting space.
- Maximum stations are 16.

# **Manifold Specifications**


	P	orting spe	ecifications	
Series	Port		Port size	Applicable stations
	location	1(P), 3(R)	4(A), 2(B)	Stations
VQ1000	Side	C8	C3, C4, C6, M5	Max. 16 stations
VQ2000	Side	C10	C4, C6, C8	Max. 16 stations

# Flat Ribbon Cable (26 pins)

# Cable assembly • AXT100-FC20-1 Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold. Red 8 9 (15.6) Flat Ribbon Cable Connector Assembly (Option) Cable length (L) Assembly part no. 1.5 m AXT100-FC20-1 Cable 20 core 3 m AXT100-FC20-2 x 28AWG AXT100-FC20-3 5 m For other commercial connectors, use a 20 pins with strain relief conforming to MIL-C-83503. Connector manufacturers' example • Japan Aviation Electronics Industry, Ltd. • Hirose Electric Co., Ltd. Sumitomo 3M Limited • J.S.T. Mfg. Co., Ltd. • Fujitsu Limited • Oki Electric Cable Co., Ltd.



The total number of stations is tabulated starting from one on the D side.



Option Symbol VQ1000 VQ2000 Option Nil None В (2) Back pressure check valve • D DIN rail mounting style • • G1 1 set of regulator unit 2 sets of regulator unit G2 (3) G3 3 sets of regulator unit (4) J□ With vacuum ejector unit Special Wiring Specifications Κ (5) (Not double wiring) N With name plate R External pilot (6) s Built-in silencer, direct exhaust •

Note 1) When two or more symbols are specified, indicate them alphabetically. Example) BRS

Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) Specify the mounting position in the manifold specification sheet.

Note 4) Refer to page 2-4-170 for the details of ejector mounted styles. A combination of "J" and "N" is unavailable.

Note 5) Specify the wiring specifications in the manifold specification sheet.

Note 6) Indicate "R" for the valve with external

pilot.

manifold specification sheet.

Note 4) Inch-size One-touch fittings are available.
For details, refer to page 2-4-179.

SQ

VQ0


VQ4


VQ5

**VQZ** 

VQD

# • Electrical wiring specifications





# **How to Order Manifold Assembly**


Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>


Flat ribbon cable kit with 3 m cable

VV5Q11-09C6PU2 ··· 1 set-Manifold base no. \*VQ1100-5 ...... 2 sets-Valve part no. (Stations 1 to 2) \*VQ1200-5 ...... 4 sets-Valve part no. (Stations 3 to 6) \*VQ1300-5 ...... 2 sets-Valve part no. (Stations 7 to 8)

Prefix the asterisk to the part nos. of the solenoid valve, When ordering, specify the part nos, in order from the 1st. station in the D side. When part nos. written collectively are complicated, specify by using the manifold specification sheet.





The broken lines indicate the DIN rail mounting style [-D] and the side entry connection [-PS].



Dime	nsions	3					Fo	ormula L1	= 10.5n +	44.5, L2 =	= 10.5n +	57.5 n: S	Station (Ma	aximum 16	S stations)
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5
L2	78.5	89	99.5	110	120.5	131	141.5	152	162.5	173	183.5	194	204.5	215	225.5
(L3)	112.5	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	225	237.5	250
(L4)	123	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	235.5	248	260.5

The broken lines indicate the DIN rail mounting style [-D] and the side entry connection [-PS].






# **Dimensions**

Formula L1 = 16n + 53, L2 = 16n + 68 n: Station (Maximum 16 stations)

L_n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309
L2	100	116	132	148	164	180	196	212	228	244	260	276	292	308	324
(L3)	125	150	162.5	175	187.5	212.5	225	237.5	262.5	275	287.5	300	312.5	337.5	350
(L4)	135.5	160.5	173	185.5	198	223	235.5	248	273	285.5	298	310.5	323	348	360.5



- Terminal block for power supply equipped with a 20 pins flat cable connection for rationalized connection of valves.
- Solenoid valves and power supply can be connected by the same cable to a specific output unit that requires power supply from the output section to the internal circuit. (SI unit)
- Maximum stations are 16.

# **Manifold Specifications**


	F	orting sp	ecifications	
Series	Port		Port size	Applicable stations
	licaition	1(P), 3(R)	4(A), 2(B)	Stations
VQ1000	Side	C8	C3, C4, C6, M5	Max. 16 stations
VQ2000	Side	C10	C4, C6, C8	Max. 16 stations

# Flat Ribbon Cable (20 pins)

# Cable assembly •

# AXT100-FC20-10

Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to How to Order Manifold.




### Flat Ribbon Cable Connector Assembly (Option)


Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC20-1	0-61-00
3 m	AXT100-FC20-2	Cable 20 core x 28AWG
5 m	AXT100-FC20-3	X ZOAWA

\* For other commercial connectors, use a 20 pins with strain relief conforming to MIL-C-83503.

### Connector manufacturers' example

- Hirose Electric Co., Ltd.
- · Japan Aviation Electronics Industry, Ltd.
- Oki Electric Cable Co. Ltd.
- Sumitomo 3M Limited Fujitsu Limited
- J.S.T. Mfg. Co., Ltd.






Option

Symbol

# **How to Order Manifold**



Nil None В Back pressure check valve DIN rail mounting style

Option

VQ1000 VQ2000 Note

(2)

G1 1 set of regulator unit 2 sets of regulator unit (3) G3 3 sets of regulator unit With vacuum ejector unit (4) Special Wiring Specifications (5) (Not double wiring) Ν With name plate • External pilot R (6) Built-in silencer, direct exhaust

Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BRS Models with a suffix "-B" have check valves

for prevention of back pressure at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) Specify the mounting position in the manifold

specification sheet.

Note 4) Refer to page 2-4-170 for the details of ejector mounted styles. A combination of "J"

and "N" is unavailable.

Note 5) Specify the wiring specifications in the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

mixed cylinder port sizes.

Note 3) Specify "Mixed size/with port plug" in the

Note 4) Inch-size One-touch fittings are available. For details, refer to page 2-4-179.

manifold specification sheet.

SQ

VQ0


VQ4


VQ5

VQZ

VQD

Connector assembly





type

# **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>


Flat ribbon cable with power supply terminal block and 3 m cable

VV5Q11-08C6G2 ··· 1 set–Manifold base no. \*VQ1100-5 ··········· 4 sets–Valve part no. (Stations 1 to 4)

\*VQ1200-5 ...... 1 set-Valve part no. (Station 5) \*VQ1300-5 ...... 3 sets-Valve part no. (Stations 6 to 8)


Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specify by using the manifold specification sheet.



0

The broken lines and dimensions in parentheses indicate DIN rail mounting style [-D].



# **Dimensions**

Formula L1 = 10.5n + 45.5, L2 = 10.5n + 63 n: Station (Maximum 16 stations)

2-C8

1(P) SUP port

L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	66.5	77	87.5	98	108.5	119	129.5	140	150.5	161	171.5	182	192.5	203	213.5
L2	84	94.5	105	115.5	126	136.5	147	157.5	168	178.5	189	199.5	210	220.5	231
(L3)	112.5	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	262.5
(L4)	123	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	273

Vacuum ejector unit style: Formula L1 = 10.5n + 29.7 + (Number of ejector units x 26.7)

(7.5)

L2 = 10.5n + 46.8 + (Number of ejector units x 26.7)

2n-C3, C4, C6, M5

C3: One-touch fitting for ø3.2 C4: One-touch fitting for ø4

C6: One-touch fitting for ø6
M5: M5 thread

L4 is L2 plus about 30.



SQ

VQ0

VQ4


VQ5


**VQZ** 

**VQD** 

# **VQ2000**

The broken lines indicate the DIN rail mounting style [-D].





# **Dimensions**

Formula L1 = 16n + 53, L2 = 16n + 87 n: Station (Maximum 16 stations)

L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309
L2	119	135	151	167	183	199	215	231	247	263	279	295	311	327	343
(L3)	150	162.5	175	187.5	212.5	225	237.5	262.5	275	287.5	300	325	337.5	350	362.5
(L4)	160.5	173	185.5	198	223	235.5	248	273	285.5	298	310.5	335.5	348	360.5	373

Vacuum ejector unit style: Formula L1 =  $10.5n + 29.7 + (Number of ejector units \times 26.7)$ L2 =  $10.5n + 46.8 + (Number of ejector units \times 26.7)$ 

L4 is L2 plus about 30.



# VQ1000/2000 Kit (Terminal block box kit)


# IP65 compliant


- This kit has a small terminal box inside a junction box. The electrical entry port {VQ1000: G 1/2, VQ2000: G 3/4} permits connection of conduit fittings.
- Maximum stations are 24.
- Enclosure: Dusttight/Low jetproof type (IP65) compliant (Series

# **Manifold Specifications**

	Р	orting spe	ecifications	
Series	Port		Port size	Applicable stations
	location	1(P), 3(R)	4(A), 2(B)	
VQ1000	Side	C8	C3, C4, C6, M5	Max. 24 stations
VQ2000	Side	C10	C4, C6, C8	Max. 20 stations


### Terminal block connection ●





# ● Electrical wiring specifications: VQ1000

starting from station one on the D side.



Hook groove (a) on shaft (b) and close the cover.


For negative common specifications. refer to "Option" on page 2-4-178.

Step 3. How to replace

terminal block cover

Then tighten the screws.

2.5



Option

Symbol	Option	VQ1000	VQ2000	Note
Nil	None	•	•	
В	With back pressure check valve	•	•	(2)
D	DIN rail mounting style	•	•	
G1	1 set of regulator unit			
G2	2 sets of regulator unit	•		(3)
G3	3 sets of regulator unit			
J□	With vacuum ejector unit	•		(4)
K	Special wiring specifications (Not double wiring)	•	•	(5)
N	With name plate	•	•	
R	External pilot	•	•	(6)
S	Built-in silencer, direct exhaust	•	•	
W	Enclosure: Dusttight/Low jetproof type (IP65)		•	

Note 1) When two or more symbols are specified, indicate them

alphabetically. Example) -BRS
Note 2) Models with a suffix "-B" have check valves for prevention of Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) Specify the mounting position in the manifold specification sheet.

Note 4) Refer to page 2-4-170 for the details of ejector mounted styles. A combination of "I" and "N" is unavailable.

styles. A combination of "J" and "N" is unavailable.

Note 5) Specify the wiring specifications in the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

Note 4) For One-touch fittings in inch size, refer to "Option" on page 2-4-179.

SQ

VQ0


VQ4


VQ5

**VQZ** 


VQD


# • Special wiring specifications: VQ2000





The total number of stations is tabulated starting from station one on the D side.





# **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

# Terminal block box kit


VV5Q11-08C6T0 ··· 1 set–Manifold base no. \*VQ1100-5 ········· 2 sets–Valve part no. (Stations 1 to 2) \*VQ1200-5 ······· 4 sets–Valve part no. (Stations 3 to 6)

\*VQ1300-5 .......... 1 set–Valve part no. (Station 7)


\*VVQ1000-10A-1 ... 1 set–Blanking plate part no. (Station 8)

Prefix the asterisk to the part nos. of the solenoid valve,

Write sequentially from the 1st station on the D side. When part nos. written collectively are -complicated, specify by using the manifold specification sheet.



The broken lines and dimensions in parentheses indicate DIN rail mounting style [-D].



# **Dimensions**


Formula L1 = 10.5n + 45.5, L2 = 10.5n + 105 n: Station (Maximum 24 stations)

L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
L1	66.5	77	87.5	98	108.5	119	129.5	140	150.5	161	171.5	182	192.5	203	213.5	224	234.5	245	255.5	266	276.5	287	297.5
L2	126	136.5	147	157.5	168	178.5	189	199.5	210	220.5	231	241.5	252	262.5	273	283.5	294	304.5	315	325.5	336	346.5	357
(L3)	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	262.5	262.5	275	287.5	300	312.5	325	325	337.5	350	362.5	375	387.5
(L4)	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	273	273	285.5	298	310.5	323	335.5	335.5	348	360.5	373	385.5	398

Vacuum ejector unit style: Formula L1 = 10.5n + 29.7 + (Number of ejector units x 26.7) L2 = 10.5n + 88.8 + (Number of ejector units x 26.7)L4 is L2 plus about 30.



# The broken lines and dimensions in parentheses indicate DIN rail mounting style [-D].



<>: AC

	•							
		~	^	-	^	^	-	•
D					-	u		-

Dillie	113101	13						Formula $L1 = 16n + 118.5$ , $L2 = 16n + 13$						n: Station (Maximum 10 stations)					
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
L1	150.5	166.5	182.5	198.5	214.5	230.5	246.5	262.5	278.5	294.5	310.5	326.5	342.5	358.5	374.5	390.5	406.5	422.5	438.5
L2	163	179	195	211	227	243	259	275	291	307	323	339	355	371	387	403	419	435	451
(L3)	187.5	200	225	237.5	250	262.5	287.5	300	312.5	337.5	350	362.5	375	400	412.5	425	450	462.5	475
(1.4)	100	040 5	005.5	0.40	000 5	070	000	010 5	000	0.40	000 5	070	005.5	440.5	400	405.5	400 5	470	405.5

# VQ1000/2000 Kit (Lead wire cable)


# IP65 compliant

- Direct electrical entry. Models with one or more stations are
- (SUP) and R (EXH) ports are provided on one side for further space savings.
- Maximum stations are 8.
- Enclosure: Dusttight/Low jetproof type (IP65) compliant (Series VQ2000)

# Wiring specifications: Positive COM ●

Three lead wires are attached to each station regardless of the type of valve which is mounted.

The red wire is for COM connection.



**Lead Wire Assembly with Connector** 

Part no. VVQ1000-84A-6-\*

VVQ1000-84A-15-


VVQ1000-84A-30-\*

# **Manifold Specifications**

VV5Q11

Series	ı	Porting sp		
	Port	Applicable stations		
	location	1(P), 3(R)	4(A), 2(B)	Stations
VQ1000	Side	C8	C3, C4, C6, M5	Max. 8 stations
VQ2000	Side	C10	C6, C8	Max. 8 stations

VV5Q21



prevention of back pressure at all manifold

stations. If not all stations need this check valve, specify the stations where check valves are

installed by the manifold specification sheet.

Note 3) Specify the mounting position in the manifold specification sheet.

Note 4) Refer to page 2-4-170 for the details of ejector mounted styles. A combination of "J" and "N" is

Note 5) Indicate "R" for the valve with external pilot.

unavailable

**How to Order Manifold** 

Lead wire length


1.5 m

specifications, refer to

"Option" on page 2-4-

3 m

\* No. of stations 1 to 8





and mixed cylinder port sizes.

Note 3) Specify "Mixed size/with port plug" in the manifold specification sheet.

Note 4) Inch-size One-touch fittings are available.

For details, refer to page 2-4-179.

SQ


VQ0

VQ4

VQ5

VQZ


VQD




# Wiring specifications: Negative COM (Option)

Three lead wires are attached to each station regardless of the type of valve which is mounted.

The black wire is for COM connection.






# **Lead Wire Assembly with Connector**

Lead wire length	Part no.
0.6 m	VVQ1000-84AN-6-*
1.5 m	VVQ1000-84AN-15-*
3 m	VVQ1000-84AN-30-*

\* No. of stations 1 to 8



Note) When using the negative common specifications, use valves for negative common. For negative common specifications, refer to "Option" on page 2-4-178.



# **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.


# <Example>

Lead wire kit with cable (3 m)

VV5Q11-06C6L2 ···· 1 set-Manifold base no. \*VQ1100-5 ...... 2 sets-Valve part no. (Stations 1 to 2)) \*VQ1200-5 .......... 2 sets-Valve part no. (Stations 3 to 4)


\*VQ1300-5 ...... 1 set-Valve part no. (Station 5) \*VVQ1000-10A-1 ··· 1 set-Blanking plate part no. (Station 6)


Prefix the asterisk to the part nos. of the solenoid valve. Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specify by using the manifold specification sheet.






# The broken lines indicate DIN rail mounting style [-D].







<>: AC

# **Dimensions**

Formula $L1 = 16n + 35$ , $L2 = 16r$	+ 47 n. Station	(Maximum 8	stations)

L	1	2	3	4	5	6	7	8
L1	39	49.5	60	70.5	81	91.5	102	112.5
L2	48.5	59	69.5	80	90.5	101	111.5	122
(L3)	75	87.5	87.5	100	112.5	125	137.5	150
(L4)	85.5	98	98	110.5	123	135.5	148	160.5

Vacuum ejector unit style: Formula L1 = 10.5n + 28.5 + (Number of ejector units x 26.7)
L2 = 10.5n + 38 + (Number of ejector units x 26.7)
L4 is L2 plus about 30.

SQ

VQ0

VQ4


VQ5


**VQZ** 


**VQD** 

# **VQ2000**

# The broken lines indicate the DIN rail mounting style [-D].







<>: AC

Dimensi	ons	Formula L1 = 16n + 35, L2 = 16n + 47 n: Station (Maximum 8 stations)						num 8 stations)
L n	1	2	3	4	5	6	7	8
L1	51	67	83	99	115	131	147	163
L2	63	79	95	111	127	143	159	175
(L3)	87.5	100	125	137.5	150	162.5	184.5	200
(L4)	98	110.5	135.5	148	160.5	173	198	210.5



# VQ1000/2000 Kit (Serial transmission unit)

IP65 compliant


- The serial transmission system reduces wiring work, while minimizing wiring and saving space.
- The system comes in type SA (generic for small scale systems) for equipment with a small number of I/O points, or 32 points max., type SB (applicable to Mitsubishi Electric models) for controlling 512 I/O points max., type SC (applicable to OMRON models), type SD (applicable to SHARP models: 504 points max.), type SF (applicable to NKE models: 128 points max.), type SJ (applicable to SUNX models), type SK (applicable to Fuji Electric models), type SQ (applicable to OMRON's Compo Bus/D), and type SR (applicable to OMRON's Compo Bus/S).
- Max. 16 stations. (Specify a model with 9 to 16 stations by using the manifold specification sheet.)

Enclosure: Dusttight, Low jetproof type (IP65) compliant (Series VQ2000)

# G 1/2 VV5Q11 G 1/2 prepared hole Dusttight type (-XP) VV5Q11

# **Manifold Specifications**

	F	Porting sp			
Series	Port		Port size	Applicable stations	
	location	1(P), 3(R)	4(A), 2(B)	Stations	
VQ1000	Side	C8	C3, C4, C6, M5	Max. 16 stations	
VQ2000	Side	C10	C4, C6, C8	Max. 16 stations	



page =	
Item	Specifications
External power supply	24 VDC +10%, -5%
Current consumption (Internal unit)	SA, SB, SBB, SD, SE, SF1, SH, SG, SJ <sup>1</sup> <sub>2</sub> , SK, SQ, SR <sup>1</sup> <sub>2</sub> , SU, SV: 0.1A SC: 0.3A


### Type SA With general type SI unit (Series EX300)

LED	Description
TRD	Lighting during data reception
RUN/ERR	Blinking when received data is normal; Lighting when data reception

Can be connected with PLC I/O card for serial transmission. EX300-TMB1...For models of Mitsubishi Electric Corporation EX300-TTA1...For models of OMRON Corporation EX300-TFU1...For models of Fuji Electri Co., Ltd.

EX300-TOO1··· For general models Up to 32 points per unit.No. of output points, 16 points

# Type SB Mitsubishi Electric Corporation MELSECNET/MINI-S3 Data Link System



LED	Description
<b>POWER</b>	
RUN	Lighting when data transmission with the master station is normal
RD	Lighting during data reception
SD	Lighting during data transmission
ERR.	Lighting when reception data error occurs. Light turns off when the error is corrected.

- Master station: PLC made by Mitsubishi Electric Corporation Series MELSEC-A AJ71PT32-S3, AJ71T32-S3 A1SJ71PT32-S3
- Max. 64 stations, connected to remote I/O stations (Max. 512 points).
  No. of output points, 16 points. No. of sta.
- occupied, 2 stations

, , , ,		mical inatmustica manual
	* For details on specifications and handling, refer to the separate tech	micai instruction manual.

Name of terminal block (LED)

Note

# **How to Order Manifold**

page 2-4-178

### 80 Series 4 Manifold | 1 VQ1000 2 VQ2000 1 Plug-in unit Stations • 2 stations Note) For details, refer to page 2-4-178. 16 stations

Cylinder port

Symbol	Port size	VQ1000	VQ2000
СЗ	With One-touch fitting for ø3.2	•	
C4	With One-touch fitting for ø4	•	•
C6	With One-touch fitting for ø6	•	•
C8	With One-touch fitting for ø8		•
M5	M5 thread	•	
СМ	With mixed size/with port plug	•	● <sup>(3)</sup>

Note 1) Insert "L" (top piping) or "B" (bottom piping) for elbow type. (VQ1000 only). Example) B6 (Elbow One-touch

fittings for ø6, bottom piping.)

Note 2) Specify as "LM" for models with elbow fittings and mixed cylinder port sizes

Note 3) Specify "Mixed size/with port plug" in

the manifold specification sheet. Note 4) For inch-size One-touch fittings, refer to "Option" on page 2-4-179.

C6 SA Dust-protected type (-XP) Suffix "-XP" for the dustprotected type SI units. (Except SE and SQ) Model

0	Without SI unit	
Α	With general type SI unit (Series EX300)	
<b>B</b>	Mitsubishi Electric Corp.:	Su
В	MELSECNET/MINI-S3 Data Link System	l iĝ
ВВ	Mitsubishi Electric Corp.:	Ste
ьь	MELSECNET/MINI-S3 Data Link System (2 power supply lines)	Max.16 stations
С	OMRON Corp.: SYSBUS Wire System	ä.
D	SHARP Corp.: Satellite I/O Link System	Σ̈́
E	Matsushita Electric Works: MEWNET-F System	
F1	NKE Corp.: Uni-wire System (16 output points)	
G	Rockwell Automation: Allen Bradley Remote I/O (RIO) System	
Н	NKE Corp.: Uni-wire H System	
J1	SUNX Corp.: S-LINK System (16 output points)	
J2	SUNX Corp.: S-LINK System (8 output points)	Max. 8 stations
K	Fuji Electric Co.: T-LINK Mini System	M 10
Q	DeviceNet, CompoBus/D (OMRON Corp.)	Max.16 stations
R1	OMRON Corp.: CompoBus/S System (16 output points)	
R2	OMRON Corp.: CompoBus/S System (8 output points)	Max. 8 stations
U	JEMANET (JPCN-1)	Max. 16 stations
٧	Mitsubishi Electric Corp.: CC-LINK System	Max. 16 stations

Note 1) The general type requires a transmission unit on CPU

Note 2) SBB kit is usable only for VQ2000 dusttight/low jetproof type (IP65).

Option

Symbol	Option	VQ1000	VQ2000	Note
Nil	None	•	•	
В	With back pressure check valve	•	•	(2)
D	DIN rail mounting style	•	•	
G1	1 set of regulator unit			
G2	2 sets of regulator unit	•		(3)
G3	3 sets of regulator unit			
J□	With vacuum ejector unit	•		(4)
K	Special wiring specifications (Not double wiring)	•	•	(5)
N	With name plate	•	•	
R	with external pilot	•	•	(6)
S	Built-in silencer, direct exhaust	•	•	
w	Enclosure: Dust tight/Low jetproof type (IP65) (Except SE)		•	(8)

Note 1) When two or more symbols are specified, indicate them alphabetically

Example) -BRS.

Note 2) Models with a suffix "-B" have check valves for prevention of back pressure at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by manifold

check valves are installed by manifold specification sheet.

Note 3) Specify the mounting position in the manifold specification sheet.

Note 4) Refer to page 2-4-170 for the details of ejector mounted styles. A combination of "J" and "N" is unavailable.

Note 5) Specify the wiring specifications in the manifold specification sheet.

Note 6) Indicate "R" for the valve with external pilot.

Note 7) A combination of "W" and "XP" is unavailable.

unavaliable.

Note 8) Refer to "Dimensions" on page 2-4-157 for SI unit and valve, in case of W (dusttight/low



SQ

VQ0


VQ4

VQ5

VQZ

VQD

# Plug-in Unit Series VQ1000/2000



VV5Q21 Dust tight Low jetproof type (-W)

# SI unit output and coil numbering

<Wiring example 1> SI unit output no. Un-Un-Α В Α В А В Double Double Single SI unit Stations 2 3 4 5

Double wiring (Standard)

JW-23LM, JW 31LM

No. of output points, 16 points

(504 points max.)

\* Max. 31 units, I/O slave stations connected

<Wiring example 2>

Mixed wiring is available as an option.
Use the manifold specification sheet to specify.

SI unit output no		0	1	2	3	4	5	6	7
		Α	В	Α	В	Α	Α	Α	В
	SI unit	Double		Oplible		Single	Single	Single	oll gro
	Stations		1	2	2	3	4		5

Single/Double mixed wiring (Option)

Type SC Type SD **OMRON Corporation SHARP Corporation** SYSBUS Wire System Satellite I/O Link System BRUN STRE Name of terminal block (LED) LED LED Description Description Lights when transmission is normal and PLC is in operation mode **POWER** ON when power supply is ON RUN Lights when power is ON and RUN lave stations are operating normally Blinks during data transmission/reception ON when transmission is abnormal. ERR **ERROR** Lights when slave station switch setting s abnormal, communication is abnormal, PLC stopped and defective slave unit R.SET ON for master unit control input HOLD · Master station unit: Master station unit: **OMRON PLC** SHARP's PLC SYSMAC C (CV) series New Satellite Series W Types C500-RM201 and C200H-RM201 7W-31I M \* 32 units max., transmission terminal New Satellite Series JW

# **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

# <Example>

# Serial transmission kit

VV5Q11-08C6SA ... 1 set–Manifold base no.

\*VQ1100-5 ....... 2 sets-Valve part no. (Stations 1 to 2)


\*VQ1200-5 ....... 4 sets-Valve part no. (Stations 3 to 6)


\*VQ1300-5 ...... 1 set-Valve part no. (Station 7)

\*VVQ1000-10A-1 ... 1 set-Blanking plate part no. (Station 8)

Prefix the asterisk to the part nos. of the solenoid valve,

Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specify by using the manifold specification sheet.






connection (512 points max.)


. No. of output points, 16 points

For external pilot and negative COM specifications, refer to "Option" on pages 2-4-178 to


2-4-179





<del>•••••</del>				
Symbol	Specifications	DC		
Nil	Standard type	(1.0 W)		
н	High pressure type	(1.5 W)		
Υ	Low wattage type	(0.5 W)		



The broken lines indicate DIN rail mounting style [-D].







Vacuum ejector unit style: Formula

L1 = 10.5n + 28.7 + (Number of ejector units x 26.7)L2 = 10.5n + 56.3 + (Number of ejector units x 26.7)

L4 is L2 plus about 30.



Note) Manifolds with SI unit for Matsushita Electric Works' MEWNET FP and Rockwell Automation's model are the same with L5, L6 and L7 dimensions of dustproof SI unit.

# **Dimensions**

Dust-protected type SI unit: L5 = 10.5n + 97, L6 = L3 + 25, L7 = L4 + 25Formula L1 = 10.5n + 44.5, L2 = 10.5n + 72.5 n: Station (Maximum16 stations)

L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	65.5	76	86.5	97	107.5	118	128.5	139	149.5	160	170.5	181	191.5	202	212.5
L2	93.5	104	114.5	125	135.5	146	156.5	167	177.5	188	198.5	209	219.5	230	240.5
(L3)	125	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5
(L4)	135.5	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273



SQ

VQ0

VQ4


VQ5

**VQZ** 


**VQD** 

# Plug-in Unit Series VQ1000/2000






**Dusttight SI unit** 



< >: AC

(12)13




 $\begin{array}{lll} \mbox{Dust-protected type SI unit:} & \mbox{L5} = 16 + 108, \mbox{L6} = \mbox{L3} + 25, \mbox{L7} = \mbox{L4} + 25 \\ \mbox{Dusttight/Low jetproof SI unit:} & \mbox{L8} = 16n + 118.5, \mbox{L9} = 16n + 131 \\ \mbox{L10} = \mbox{L3} + 50, \mbox{L11} = \mbox{L4} + 50 \\ \mbox{Formula:} & \mbox{L1} = 16n + 53, \mbox{L2} = 16n + 83 \\ \mbox{n:} & \mbox{Stations} & \mbox{(Maximum 16 stations)} \\ \end{array}$ 

Dimer	Dimensions								L10 = L3 + 50, $L11 = L4 + 50Formula : L1 = 16n + 53, L2 = 16n + 83 n: Stations (Maximum 16 stations)$					6 stations)	
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	85	101	117	133	149	165	181	197	213	229	245	261	277	293	309
L2	115	131	147	163	179	195	211	227	243	259	275	291	307	323	339
( <b>L3</b> )	137.5	162.5	175	187.5	200	225	237.5	250	262.5	287.5	300	312.5	337.5	350	362.5
( <b>L4</b> )	148	173	185.5	198	210.5	235.5	248	260.5	273	298	310.5	323	348	360.5	373

**SMC** 

# VQ2000 Kit (Flat ribbon cable connector)

- MIL flat cable connector reduces installation labor for electrical connection.
- Manifold and connectors, both compliant with the IP65 rating (dusttight, low jetproof), provide a high degree of protection for the electrical parts.
- Maximum stations are 24.



# **Manifold Specifications**

	Po	rting specif	ications	Applicable		
Series	Port	Po	rt size			
	location	1(P), 3(R)	4(A), 2(B)	stations		
VQ2000	Side	C10	C4, C6, M8	Max. 24 stations		

# **Circular Connector (26 pins)**


### Cable assembly ●


### AXT100-MC26-030 050 Circular connector assembly included in

Circular connector assembly included in a specific manifold model no. Specific manifold model no. Refer to How to Order Manifold.

Plug terminal no.

Socket side





Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-MC26-015	0 11 05
3 m	AXT100-MC26-030	Cable 25 core x 24AWG
5 m	AXT100-MC26-050	X 24/11/0

### **Electric Characteristics**


Item	Characteristics
Conductor resistance $\Omega/km$ , 20°C	65 or less
Voltage limit V, 1 min, AC	1000
Insulation resistance MΩkm, 20°C	5 or more


Note) The minimum bending radius of circular connector cable is 20 mm.


# Circular Connector Cable Assembly Terminal No.

Terminai no.	Lead wire color	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Gray	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Gray	Red
24	Black	White
25	White	None
26	White	None

# **How to Order Manifold**









to 2-4-179.

The broken lines indicate the DIN rail mounting style [-D] and the side entry connection [-FS].





Dimer	nsions	3		Formula L	.1 = 16n +	77.5, L2	= 16n + 10	00.5 n: S	Station (Ma	ıximum 12	stations)
	2	3	4	5	6	7	8	9	10	11	12
L1	109.5	125.5	141.5	157.5	173.5	189.5	205.5	221.5	237.5	253.5	269.5
L2	132.5	148.5	164.5	180.5	196.5	212.5	228.5	244.5	260.5	276.5	292.5
(L3)	162.5	175	187.5	200	225	237.5	250	275	287.5	300	312.5
(L4)	173	185.5	198	210.5	235.5	248	260.5	285.5	298	310.5	323

SQ

VQ0

VQ4

VQ5

VQZ

VQD



# Applicable network | DeviceNet/PROFIBUS-DP


● The serial transmission system reduces wiring work, while minimizing wiring and saving space.

# SI unit for DeviceNet/PROFIBUS


# As a slave for DeviceNet/PROFIBUS, it is possible to control ON/OFF of a solenoid valve with the maximum of 32 points. Furthermore, by connecting a discrete input block, it is possible to input the sensor signal for 32 points at the maximum.

# Input block

Meaning of an expansion block, connecting with SI unit, for sensorinputting for auto switches, etc. Sensor-input is available up to 8 per one input block. By the NPN/PNP switch, it is able to adjust COM to sensor.



# VQ2000 IP65, Applicable to Input/Output, Serial Transmission Type



SQ

VQ0

VQ4

VQ5

VQZ

VQD

# Plug-in Unit Series VQ2000

# **Details in Connector**

# Input block SI Unit (DeviceNet) SI Unit (PROFIBUS-DP) Communication connector Power source connector

 Input connector: M12 5 pins (XS2F compatible made by OMRON Corp.) x 8 pcs.

Cable side connector example: XS2G made by OMRON Corp.



Number	Description	Function
1	SW+	Sensor power supply +
2	N.C.	Open *
3	SW-	Sensor power supply –
4	SIGNAL	Sensor input signal
5	PE	Protective sensor ground

\* No. 2 pin of the input no. 0, 2, 4, 6 connector (connectors aligned in the right side on the input block) is connected internally with no. 4 pin (sensor input no.) of the input no. 1, 3, 5, 7 respectively. Thereby, it is possible to directly input 2 points which is bundled into 1 cable by the cluster connector, etc.

Connector is	nput no.	Input no.: 1, 3, 5,			
SW +		1		1	
SIGNAL-n+1		2		2	
SW-		3		3	
SIGNAL-n		4		4	
PF		5		5	

# **⚠** Caution

When an enclosure equivalent to IP65 is required, place a waterproof cover on the unused input connector. As for waterproof cover, order it separately. Example: OMRON Corp. XS2Z-12

 Communication connector (PROFIBUS-DP): Made by CONINVERS GmbH RC-2RS1N12 12 pins
 Cable side connector example: Made by Siemens AG



6ES5 760-2CB11

Number	Description	Function
1	M5V	GND Terminal
2	Α	Signal-N
4	В	Signal-P
6	+5V	Terminal +5 V
9	SIELD	Shield ground
12	RTS	Optical fiber (Reserve)

Pin no. 3, 5, 7, 8, 10 and 11 marked with ● are

- Connector's shape and pin assignment is interchangeable with ET200C made by Siemens AG.
- Power source connector: Series 723 (made by Franz Binder GmbH) 5 pins (72309-0115-80-05)

Cable side connector example: Franz Binder GmbH 72309-0114-70-15, etc.

\* Din type 5 pins.



	Number	Description	Function
	1	SV24V	For solenoid valve +24 V
2	2	SV0V	For solenoid valve 0 V
,	3	PE	Protective ground
•	4	SW24V	<devicenet> For input block +24 V, <profibus interbus="" or=""> For input unit and SI unit +24 V</profibus></devicenet>
	5	SW0V	<devicenet> For input block 0 V, <profibus interbus="" or=""> For input unit and SI unit 0 V</profibus></devicenet>

Communication connector (DeviceNet): M12 5 pins (for DeviceNet compliant)

Example of corresponding cable assemblies with connector: OMRON Corporation: DCA1-5CN05F1 Karl Lumberg GmbH & Co. KG: RKT5-56




Numbe	Description	Function
1	Drain	Drain/Shield
2	V+	Circuit power supply +
3	V-	Circuit power supply -
4	CAN_H	Signal H
5	CAN_L	Signal L

Item conforming to Micro Style connector in DeviceNet specifications.


# Indicator Unit (LED) Descriptions and Functions

# ■ SI Unit (DeviceNet)



Description	Function
PWR(V)	ON when solenoid valve power supply is turned ON
PWR	ON when DeviceNet circuit power supply input is turned ON
	OFF: Power supply off, off line, or when checking duplication of MAC_ID
	Green blinking: Waiting for connection (On line)
MOD/NET	Green ON: Connection established (On line)
	Red blinking: Connection time out (Minor communication abnormality occurs)
	Red ON: MAC_ID duplication error, or BUSOFF error (Major communication abnormality occurs)

# ■ SI Unit (PROFIBUS-DP)



Description	Function
PWR	ON when solenoid valve power supply is turned ON OFF when the power supply voltage is less than 19 V
RUN	ON when operating (SI unit power supply is ON)
DIA	ON when self-diagnosis device detects abnormality
BF	ON for BUS abnormality

# ■ Input block




Description	Function
PWR	ON when sensor power is turned ON OFF when short circuit protection is working
0 to 7	ON when each sensor input goes ON



# VV5Q21S kit


(Serial transmission kit: EX240)




Dimen	sions	Formula L1 = 16n + 36.5, L2 = 16n + 186 (In the case of 1 pc. DI unit, 54 mm will be added for increasing every 1 pcs.)								n: Station					
L	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	68.5	84.5	100.5	116.5	132.5	148.5	164.5	180.5	196.5	212.5	228.5	244.5	260.5	276.5	292.5
L2	218	234	250	266	282	298	314	330	346	362	378	394	410	426	442


# Series VQ2000 VQ2000 Only

# **Sub-plate Single Unit**



Easy-to-use terminal block





**VQC** 

SQ

VQ0

VQ4

VQ5


**VQZ** 

**VQD** 

In the case of (sub-plate) alone

VQ2000 - PW - 02

# **Dimensions**




# Series VQ1000

# **Manifold Option Parts for VQ1000**

# Blanking plate assembly VVQ1000-10A-1

JIS Symbol

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.



# Individual SUP spacer VVQ1000-P-1-C6


When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.)

Block both sides of the station, for which the supply pressure from the individual SUP spacer is used, with SUP block plates. (Refer to the application ex.)

Specify the spacer mounting position and SUP block plate position on the manifold specification SUP block plate sheet.

The block plate are used in two places for one set. (Two SUP block plates for blocking SUP station are attached to the individual SUP spacer.)

Electric wiring is connected to the position of the manifold station where the individual SUP spacer is mounted.



# Individual EXH spacer VVQ1000-R-1-C6


When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.) Block both sides of the individual valve EXH station. (See example)


- \* Specify the mounting position, as well as the EXH block base or EXH block plate position on the manifold specification sheet. The block plate are used in two places for one set. (Two EXH block plates for blocking EXH station are attached to the individual EXH spacer.)


  \* An EXH block base assembly is used in the
- \* An EXH block base assembly is used in the blocking position when ordering an EXH spacer incorporated with a manifold no. However, do not order an EXH block base assembly because it is attached to the spacer.

When separately ordering an individual EXH spacer, separately order an EXH block base assembly because it is not attached to the spacer.

 Electric wiring is connected to the position of the manifold station where the individual EXH spacer is mounted.







# SUP block plate VVQ1000-16A


When different pressures, high and low, are supplied to one manifold, a SUP block plate is inserted between the stations under different pressures.

\* Specify the number of stations on the manifold specification sheet.


# <Shut off label>

When using block plates for SUP passage, indication label for confirmation of the blocking position from outside is attached. (One label of each)

 When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold




10.5



SUP passage block

52.2


SUP/EXH passage blocked




Blanking plate with a connector for individually outputting electricity to drive a single valve or equipment that are not on the manifold base.

\* When "N" is suffixed to the nameplate, the plate will be different from a standard shape.

Note) Electric current should be 1A or less. (Including the mounted valves.)





SQ

VQ0

VQ4

VQ5

VQZ

VQD

# Plug-in Unit Series VQ1000

# **EXH block base assembly** VVQ1000-19A-₽ (C3, C4, C6, M5)

# Manifold block assembly **Electrical entry**


	•			
F1	For F kit (2 to 12 stations)/Double wiring			
F2	For F kit (13 to 24 stations)/Double wiring			
F3	For F kit (2 to 24 stations)/Single wiring			
P1	For P, G, T, S kit (2 to 12 stations)/Double wiring			
P2	For P, G, T, S kit (13 to 24 stations)/Double wiring			
P3	For P, G, T, S kit (2 to 24 stations)/Single wiring			
L0 *	L0 kit )			
L1 *	L1 kit * 1 to 8 stations			
L2 *	L2 kit			

The manifold block assembly is used between stations for which exhaust is desired to be divided when valve exhaust affects other stations due to the circuit configuration. The EXH passage on the D-side is blocked in the EXH block base assembly. It is also used in combination with an individual EXH spacer for individual exhaust.

### <Blocking indication label>

When blocking the EXH passage with an EXH block base assembly, indication label for confirmation of the blocking position from outside is attached. (One label for each)

When ordering a EXH block base incorporated with the manifold no., a block indication label is attached to the manifold.



Specify the number of stations on the manifold specification sheet

When ordering by using the manifold specification form, specify the EXH block base assembly no. by adding suffix "\*" below the manifold no.






SUP/EXH passage blocked

### EXH passage blocked

# Back pressure check valve assembly [-B] VVQ1000-18A

It prevents cylinder malfunction caused by other valve exhaust. Insert it into R (EXH) port on the manifold side of a valve which is affected. It is effective when a single action cylinder is used or an exhaust center type solenoid valve is used.

Note) When a check valve for back pressure prevention is desired, and is to be installed only in certain manifold stations, write clearly the part no. and specify the number of stations by using the manifold specification





(Precautions)

- 1. The back pressure check valve assembly is assembly parts with a check valve structure. However, as slight air leakage is allowed for the back pressure, take care the exhaust air will not be throttled at the exhaust port.
- 2. When a back pressure check valve is mounted, the effective area of the valve will decrease, by about 20%.

# Name plate [-N] VVQ1000-NC N-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc.


Insert it into the groove on the side of the end plate and bend it as shown in the figure.

\* When the blanking plate with connector is mounted, it automatically will be "VVQ1000-NC-n" with an option symbol [-N]

N: Standard NC: For mounting blanking plate with connector




When ordering assemblies incorporated with a manifold, add suffix "-N" to the manifold no.



# Blanking plug (For One-touch fittings) KQ2P-

It is inserted into an unused cylinder port and SUP/EXH ports. Purchasing order is available in units of 10 pieces






# Dimensions

Applicable fittings size ød	Model	Α	L	D
3.2	KQ2P-23	16	31.5	3.2
4	KQ2P-04	16	32	6
6	KQ2P-06	18	35	8
8	KQ2P-08	20.5	39	10

### Port plug VVQ0000-58A

The plug is used to block the cylinder port when using a 4 port





- When ordering a plug incorporated with a manifold, indicate "CM" for the port size in the manifold no., as well as, the mounting position and number of stations and cylinder port mounting positions, A and B, on the manifold specification sheet
- Lightly screw an M3 screw in the port plug hole and pull it for removal.

# Elbow fitting assembly VVQ1000-F-L (C3, C4, C6, M5)


It is used for piping that extends upward or downward from the

When installing it in part of the manifold stations, specify the assembly no. and the mounting position and number of stations by means of the manifold specification sheet.

\* When mounting elbow fittings assembly on the edge of manifold station and a silencer on EXH port, select a silencer, AN203-KM8.

Silencer (AN200-KB8) is interfered with fittings





When ordering assemblies incorporated with a manifold, indicate "L□" or "B□" for the manifold port size. (When installed in all stations.)



Upward



# Series VQ1000

# **Manifold Option Parts for VQ1000**


# DIN rail mounting bracket VVQ1000-57A

It is used for mounting a manifold on a DIN rail. The DIN rail mounted bracket is fixed to the manifold end plate. (The specification is the same as that for the option "-D".)

1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).



When ordering assemblies incorporated with a manifold, add suffix "D" to the manifold no.




Mounting screws are attached

# Built-in silencer, Direct exhaust [-S]

This is a type with an exhaust port a top the manifold end plate. The built-in silencer exhibits an excellent noise suppression effect. (Silencing effect: 30 dB)



Note) A large quantity of drainage generated in the air source results in exhaust of air together with drainage. For maintenance, refer to page 2-4-176.




\* When ordering assemblies incorporated with a manifold, add suffix "S" to the manifold no.


# 2 stations matching fitting assembly VVQ1000-52A-C8

For driving a cylinder with a large bore, valves for two stations are operated to double the flow rate. This assembly for the cylinder port is used in that case. The assembly is equipped with One-touch fittings for a  $\emptyset 8$  bore.

- \* The bore for the manifold no. is "CM".

  Clearly indicate the 2 station matching fitting assembly
- Clearly indicate the 2 station matching fitting assembly no., and specify the number of stations and positions by means of the manifold specifications.
- In 2 station matching fitting assembly, a special clip which is combined in one-piece of 2 stations is attached as a holding clip.






### Silencer (For EXH port)

This silencer is to be inserted into the EXH port (One-touch fittings) of the common exhaust type

 When mounting elbow fittings assembly (VVQ1000-F-L□) on the edge of manifold station, select a silencer, AN203-KM8.

Silencer (AN200-KM8) is interfered with fittings.



# **Dimensions**

	Series	Applicable fittings size ød	Model	Α	L	D	Effective area (mm²)	Noise reduction (dB)
	VQ1000	8	AN200-KM8	59	78	22	20	30
		0	AN203-KM8	32	51	16	14	25 *

# Regulator unit VVQ1000-AR-1

The regulator controls the SUP air pressure in a manifold. Supply air from D side SUP port is regulated. SUP port on U side is plugged.

# **Specifications**

Maximum operating pressure	0.8 MPa
Set pressure range	0.05 to 0.7 MPa
Ambient and fluid temp.	5 to 50°C
Fluid	Air
Cracking pressure	0.02 MPa
Structure	Relieving type

Structure


Pressure gauge
G27-10-01

Pressure control screw

Number of

SUP port on U side is plugged


C8 (SUP) port
One-touch fitting for ø8




### • How to Order

Indicate an option symbol "-G"\* for the manifold no. and be sure to specify the mounting position and number of stations by means of the manifold specification form. One unit is counted as one station and occupies a space for three stations, therefore, pay attention to the manifold size.

The regulator valve unit, to which no wire is connected, valves can be mounted up to the standard max. number of stations of each kit.





# 

Pressure characteristics Conditions (Initial setting) Inlet pressure 0.7 MPa Outlet pressure 0.2 MPa

Outlet pressure 0.7 MPa

Initial setting value

Outlet pressure 0.7 MPa

Initial setting value

Outlet pressure 0.7 MPa

Outlet pressure 0.7 MPa

Outlet pressure 0.7 MPa

Outlet pressure 0.7 MPa

Outlet pressure 0.7 MPa

# **⚠** Caution

# Pressure setting

Check the supply pressure and then turn the pressure control screw to set the secondary pressure. Turning the screw clockwise will increase the secondary pressure while turning it counterclockwise decrease the pressure. (Set the pressure by turning the screw in the increase direction.)

### • Installation

Since some level of the actuator's operational frequency may lead to a sharp pressure change, pay attention to the pressure gauge durability.



SQ

VQ0

VQ4

VQ5

'QZ

'QD




It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the double check block with a built-in pilot type double check valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time.

The combination with a 2 position single/double solenoid valve will permit this block to be used for preventing the dropping at the cylinder stroke end when the SUP residual pressure is released.

# **Specifications**

Max. operating pressure	0.8 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temp.	−5 to 50°C
Flow characteristics: C	0.60 dm³/(s·bar)
Max. operating frequency	180 CPM




VVQ1000-FPG-02 1 set VQ1000-FPG-C6M5-D 2 pcs.


# **Dimensions**


Single unit C4: One-touch fitting for ø4

C6: One-touch fitting for ø6










Dimensions				Formula L1 = 11n + 20 n: Station (Maximum 24)								
L n	1	2	3	4	5	6	7	8	9	10	11	12
L1	31	42	53	64	75	86	97	108	119	130	141	152
L2	50	62.5	75	87.5	100	112.5	125	125	137.5	150	162.5	175
L3	60.5	73	85.5	98	110.5	123	135.5	135.5	148	160.5	173	185.5
_ n	13	14	15	16	17	18	19	20	21	22	23	24
L1	163	174	185	196	207	218	229	240	251	262	273	284
L2	187.5	187.5	200	212.5	225	237.5	250	250	262.5	275	287.5	300
L3	198	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5



000

# **How to Order**

# VQ1000-FPG- C4 M5 **OUT side port size** IN side port size .

C4 With One-touch fitting for ø4 C6 With One-touch fitting for Ø6

VVQ1000-FPG- 06

**Double check block** 

M5 M5 thread C3 One-touch fitting for ø3.2 C4 One-touch fitting for ø4 C6 One-touch fitting for ø6

16 stations

16

Option Nil None F With bracket DIN rail mounting D style (For manifold)

Ν Name plate Note) When two or more symbols are specified, indicate them alphabetically. Example) -DN

# **⚠** Caution

 Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for a long time. Check the leakage using neutral household detergent, such

as dish washing soap. Also check the cylinder's tube gasket, piston packing and rod packing for air leakage. Since One-touch fittings allow slight air leakage, screw piping (with M5 thread) is recommended when stopping

- the cylinder in the middle for a long time. Combining double check block with 3 position closed center or pressure center solenoid valve will not work.
- M5 fitting assembly is attached, not incorporated into the double check block. After screwing in the M5 fittings, mount the assembly on the double check block. {Tightening torque: 0.8 to 1.2 N·m}
- If the exhaust of the double check block is throttled too much, the cylinder may not operate properly and may
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.

# **Stations** 1 station

# <Example>

Manifold

VVQ1000-FPG-06--6 types of manifold

\*VQ1000-FPG-C4M5-D, 3 sets Double Check block \*VQ1000-FPG-C6M5-D, 3 sets

### **Bracket Assembly**

Part no.	Tightening torque				
VQ1000-FPG-FB	0.22 to 0.25 N·m				




exhaust center

Intermediate

# Series VQ1000/2000

# Manifold Option/Vacuum Ejector Unit: VQ1000

A vacuum ejector unit can be mounted on the manifold base for a solenoid valve. Instead of mounting the valve and vacuum ejector unit separately, this option reduces piping, wiring and creates additional space savings.



Note 1) SUP and EXH ports on the vacuum ejector unit manifold base are arranged on D side alone. The end plate on the U side is the same as that used in the L kit.

Note 2) Individual piping is provided for the supply and exhaust ports of the vacuum ejector unit.

Note 3) The manifold with an vacuum ejector unit type is mounted from the U side.

Note 4) One vacuum ejector unit corresponds to one station.

\* Specify the position of stations on the manifold specification sheet.

# **Specifications**

Unit no.	VVQ1000-J A	VVQ1000-J□-□□□-B		
Nozzle diameter (mm)	0.7	1.0		
Max. suction flow rate N (//min)	11	20		
Max. vacuum pressure	-630 mmHg			
Max. operating pressure	0.8 MPa			
Standard supply pressure	0.5 MPa			
Operating temperature	5 to 50°C			

# **Maximum Number of Ejector Units**


(Max. number of ejector units is subject to the number of valve stations.)

Max. number of	Max. number of mounted valves					
ejector units	F, P, T kit S, G, J kit		L kit			
1	11(20)	7(14)	7			
2	10(16)	6(12)	6			
3	9(12)	5(10)	5			
4	8(8)	4(8)	_			
5	4(4)	3(4)	_			




Note) The max. number of mounted valves applies to double wiring. Parenthesized numbers apply to single wiring. Please contact SMC for conditions other than the above or mixed wiring.

# **Dimensions**



# **How to Order**



SQ

VQ0


VQ4


VQ5

VQZ

VQD


# **How to Order Vacuum Ejector Valves**






Note 1) For power consumption of AC type, refer to page 2-4-129. Note 2) When two or more symbols are specified, indicate them alphabetically.

# **How to Order Vacuum Pressure Switches**





# Switch/Voltage (Solid state: 12 to 24 VDC)

14	NPN/1 setting, 3 revolution adjustment
15	NPN/1 setting, 200° adjustment
16	NPN/2 setting, 3 revolution adjustment
17	NPN/2 setting, 200° adjustment
18	NPN/1 setting, 3 revolution adjustment, analog
19	NPN/1 setting, 200° adjustment, analog

# Wiring specifications

Nil	Grommet type, Lead wire length 0.6 m
L	Grommet type, Lead wire length 3 m
С	Connector type, Lead wire length 0.6 m
CL	Connector type, Lead wire length 3 m
CN	Without connector Note)

Note) When ordering the switch with 5 m lead wire length, order separately the switch without connector and the connector. (Refer to below.) Besides, as for details, refer to the Vacuum Equipment catalog.

### How to order connectors

• Without lead wire (Connector 1 pc., Socket 4 pcs.) ····· ZS-20-A

 With lead wire ......... ..... ZS-20-5A-50


# Lead wire length

Nil	0.6 m
30	3 m
50	5 m


(The flow characteristics are for the supply pressure of 0.5 MPa.)

# Flow/Exhaust Characteristics of Ejector Unit


# Nozzle Diameter ø0.7 **Exhaust Characteristics**




# **Flow Characteristics**



# Nozzle Diameter ø1.0



### Flow Characteristics





# Series VQ2000


# **Manifold Option Parts for VQ2000**

# Blanking plate assembly VVQ2000-10A-1

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.








# **Individual SUP spacer** VVQ2000-P-1-C8

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is occupied.)

Block both sides of the station, for which the supply pressure from the individual SUP spacer is used, with SUP block plates. (Refer to the application ex.)


- Specify the spacer mounting position and SUP block plate position on the manifold specification sheet. The block plate are used in two places for one set. (Two SUP block plates for blocking SUP station are attached to the individual SUP spacer.)
- Electric wiring is connected to the position of the manifold station where the individual SUP spacer is mounted




# Individual EXH spacer VVQ2000-R-1-C8

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.) Block both sides of the individual valve EXH station (See example)

- Specify the mounting position, as well as the EXH block base or EXH block plate position on the manifold specification sheet. The block plates are used in two places for one set. (Two EXH block plates for blocking EXH station are attached to the individual EXH spacer.)
- Electric wiring is connected to the position of the manifold station where the individual EXH spacer is mounted






# SUP block plate VVQ2000-16A


When different pressures, high and low, are supplied to one manifold, a SUP block plate is inserted between the stations under different pressures

\* Specify the number of stations on the manifold

### <Blocking indication label>

When using block plates for SUP passage, indication label for confirmation of the blocking position from outside is attached. (One label of each)







SUP/EXH passage blocked

When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold.


# **EXH block plate** VVQ2000-19A

The EXH block plate is used between stations for which exhaust is desired to be divided when valve exhaust affects other stations due to the circuit configuration. It is also used in combination with an individual EXH spacer for individual exhaust.

Specify the number of stations on the manifold specification sheet.

# <Blocking indication label>

When blocking the EXH passage with an EXH block plate, an indication label for confirmation of the blocking position from outside is attached. (One label for each)










When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold.



SUP passage blocked

SUP/EXH passage blocked




# Plug-in Unit Series VQ2000

# Back pressure check valve assembly [-B] VVQ2000-18A

It prevents cylinder malfunction caused by other valve exhaust. Insert it into R (EXH) port on the manifold side of a valve which is affected. It is effective when a single action cylinder is used or an exhaust center type solenoid valve is used.

Note) When a check valve for back pressure prevention is desired, and is to be installed only in certain manifold stations, write clearly the part no. and specify the number of stations by using the manifold specification sheet.



When ordering assemblies incorporated with a manifold, add suffix "-B" to the manifold no.

### (Precautions)

- 1. The back pressure check valve assembly is assembly parts with a check valve structure. However, as slight air leakage is allowed for the back pressure, take care the exhaust air will not be throttled at the exhaust port.
- 2. When a back pressure check valve is mounted, the effective area of the valve will decrease, by about 20%.


# Name plate [-N] VVQ2000-N-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc.

Insert it into the groove on the side of the end plate and bend it as shown in the figure.

• Suffix "N" to the manifold part no.





\* When ordering assemblies incorporated with a manifold, add suffix "-N" to the manifold no.

SQ VQ0

**VQC** 

VQ4

VQ5


VQZ

VQD

# Blanking plug (For One-touch fittings)

It is inserted into an unused cylinder port and SUP/EXH ports. Purchasing order is available in units of 10 pieces.






# **Dimensions**

Applicable fittings size ød	Model	A	L	D
4	KQ2P-04	16	32	6
6	KQ2P-06	18	35	8
8	KQ2P-08	20.5	39	10

# Port plug VVQ1000-58A

The plug is used to block the cylinder port when using a 4 port valve as a 3 port valve.








When ordering a plug incorporated with a manifold, indicate "CM" for the port size in the manifold no., as well as, the mounting position and number of stations and cylinder port mounting positions, A and B, in the manifold specification sheet.

# **DIN rail mounting bracket** VVQ2000-57A

It is used for mounting a manifold on a DIN rail. The DIN rail mounted bracket is fixed to the manifold end plate. (The specification is the same as that for the option "-D".) 1 set of DIN rail mounting bracket is used for 1 manifold (2 DIN rail mounting brackets).








# Built-in silencer, Direct exhaust [-S]

This is a type with an exhaust port atop the manifold end plate. The built-in silencer exhibits an excellent noise suppression effect. (Silencing effect: 30 dB)



Note) A large quantity of drainage generated in the air source results in exhaust of air together with drainage.

For maintenance, refer to page 2-4-176.






When ordering assemblies incorporated with a manifold, add suffix "-S" to the manifold no.

# Silencer (For EXH port)

This silencer is to be inserted into the EXH port (One-touch fittings) of the common exhaust type.



# **Dimensions**


Series	Applicable fittings size ød	Model	A	L	D	Effective area (mm²) (Cv factor)	Noise reduction (dB)
VQ2000	10	AN200-KM10	59.6	80.8	22	26 (1.4)	30

# Elbow fitting assembly VVQ2000-F-L (C4, C6, C8)

It is used for piping that extends upward or downward from the

When installing it in part of the manifold stations, specify the assembly no. and the mounting position and number of stations by using the manifold specification sheet.






### 2 stations matching fitting assembly VVQ2000-52A-C10

For driving a cylinder with a large bore, valves for two stations are operated to double the flow rate. This assembly for the cylinder port is used in that case

This assembly for the cylinder port is used in that case.



The bore for the manifold no. is "CM". Clearly indicate the 2 station matching fitting assembly no., and specify the number of stations and positions in the manifold specification sheet.





#### Series VQ2000

#### **Manifold Option**

# Double check block (Separated type)


**VQ2000-FPG-**□□-□

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the double check block with a built-in pilot type double check valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time.


The combination with a 2 position single/double solenoid valve will prevent the dropping at the cylinder stroke end when the SUP residual pressure is released.

#### **Specifications**


Max. operating pressure	0.8 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temp.	−5 to 50°C
Flow characteristics: C	-3.0 dm³/(s·bar)
Max. operating frequency	180 c.p.m



#### **Dimensions**



#### **How to Order**



1 station 16 16 stations <Ordering Example>

VVQ2000-FPG-06....6 stations manifold

\*VQ2000-FPG-C6C6-D: 3 sets \*VQ2000-FPG-C8C8-D: 3 sets Double check block

**Bracket Assembly** 

Part no. Tightening torque VQ2000-FPG-FB 0.8 to 1.0 N·m

Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for a long time. Check the leakage using neutral household detergent, such as dish washing soap.

Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.

Since One-touch fittings allow slight air leakage, screw piping (with

- M5 thread) is recommended when stopping the cylinder in the middle
- for a long time.

  Combining double check block with 3 position closed center or pressure center solenoid valve will not work.

 M5 fitting assembly is attached, not incorporated into the double check block. After screwing in the M5 fittings, mount the assembly on the double check block.

[Tightening torque: 0.8 to 1.2 N·m]

Connection threads	Proper tightening torque (N·m)
Rc 1/8	7 to 9
Rc 1/4	12 to 14

- If the exhaust of the double check block is throttled too much, the cylinder may not operate properly
- and may not stop intermediately.
  Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.



SQ

VQ0

VQ4

VQ5

VQZ

VQD


# **⚠ Precautions 1**

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.


#### **Light/Surge Voltage Suppressor**

#### **⚠** Caution

The lighting positions are concentrated on one side for both single solenoid type and double solenoid type. In the double solenoid type, A side and B side energization are indicated by two colors which match the colors of the manual overrides.



(DWG shows a VQ1000 case.)



#### **Manual Override**


# **⚠** Warning

Without an electric signal for the solenoid valve the manual override is used for switching the main valve.

Push type is standard. (Tool required)


Option: Locking type (Tool required/Manual)

#### ■ Push type (Tool required)




Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

#### ■ Locking type (Tool required) <Option>



Push down on the manual override button with a small screwdriver or with your fingers until it stops. Turn clockwise by 90° to lock it. Turn it counterclockwise to release it.


#### ■ Locking type (Manual) <Option>



Push down on the manual override button with a small screwdriver or with your fingers until it stops. Turn clockwise by 90° to lock it. Turn it counterclockwise to release it.

#### **How to Mount/Remove Solenoid Valve**

#### **⚠** Caution



#### Removing

- 1. Loosen the clamp screw until it turns freely. (The screw is captive.)
- 2. Lift the coil side of the valve body while pressing down slightly on the screw head and remove it from the clamp bracket B. When the screw head cannot be pressed easily, gently press the area near the manual override of the valve.

#### Mounting

- Press down on the clamp screw. → Clamp bracket A opens. Diagonally insert the hook on the valve end plate side into clamp B.
- 2. Press the valve body downward. (When the screw is released, it will be locked by clamp bracket A.)
- 3. Tighten the clamp screw. (Proper tightening torque: VQ1000, 0.25 to 0.35 N·m; VQ2000, 0.5 to 0.7 N·m.)

#### **⚠** Caution

Dust on the sealing surface of the gasket or solenoid valve can cause air leakage.


#### Replacement of Cylinder Port Fittings

#### 

The cylinder port fittings are a cassette for easy replacement.

The fittings are blocked by a clip inserted from the top of manifold. Remove the clip with a screwdriver to remove fittings.

For replacement, insert the fitting assembly until it strikes against the inside wall and then reinsert the clip to the specified position.



Applicable tubing O.D.	Fitting asser	mbly part no.
Applicable tubing O.D.	VQ1000	VQ2000
Applicable tubing ø3.2	VVQ1000-50A-C3	_
Applicable tubing ø4	VVQ1000-50A-C4	VVQ1000-51A-C4
Applicable tubing ø6	VVQ1000-50A-C6	VVQ1000-51A-C6
Applicable tubing ø8	_	VVQ1000-51A-C8
M5	VVQ1000-50A-M5	_

\* Refer to "Option" on pages 2-4-172 to 2-4-173 for other types of fittings.

#### **⚠** Caution

- Use caution that O-rings must be free from scratches and dust. Otherwise, air leakage may result.
- After screwing in the fittings, mount the M5 fitting assembly on the manifold base. {Tightening torque: 0.8 to 1.2 N·m}
- 3. Purchasing order is available in units of 10 pieces.

Do not apply excessive torque when turning the locking type manual override

# **⚠ Precautions 2**


Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.

#### **Mounting/Removing from the DIN Rail**

#### **⚠** Caution

#### Removing

- 1. Loosen the clamp screw on side (a) of the end plate on both sides.
- 2. Lift side (a) of the manifold base and slide the end plate in the direction of (2) shown in the figure to remove.




#### Mounting

- Hook side (b) of the manifold base on the DIN rail.
- 2. Press down side (a) and mount the end plate on the DIN rail.

Tighten the clamp screw on side (a) of the end plate.

The proper tightening torque for screws is 0.4 to 0.6 N·m.



#### **Enclosure IP65**

#### 

Wires, cables, connectors, etc. used for models conforming to IP65 should also have enclosures equivalent to or of stricter than IP65.

#### **Built-in Silencer Replacement Element**

#### 


A silencer element is incorporated in the end plate on both sides of the A dirty and choked element may reduce cylinder speed or cause malfunction. Clean or replace the dirty element.

#### **Element Part No.**

Type	Element part no.						
"	VQ1000	VQ2000					
Built-in silencer, direct exhaust	VVQ1000-82A-1	VVQ2000-82A-1					

\* The minimum order quantity is 10 pcs.

Remove the cover from the top of the end plate and remove the old element with a screwdriver, etc.



#### How to Calculate the Flow Rate

For obtaining the flow rate, refer to pages 2-1-8 to 2-1-11.

SQ

VQ0

VQ4

VQ5

VQZ

VQD


#### Option

#### **Different Number of Connector Pins**


F and P kits with the following number of pins are available besides the standard number (F = 25; P = 26). Select the desired number of pins and cable length from the cable assembly list. Place an order for the cable assembly separately.



#### kit (D-sub connector) 15 pins



#### How to order manifold




#### Kit/Electrical entry

Pins Location	Top 6	entry	Side entry		
15P (Max. 7 stations)	Kit F	UA	Kit F	SA	

#### Wiring Specifications

\* In the same way as the 25-pin models (standard), the terminal no. 1 is for SOL.A at the 1st station, the terminal no. 9 for SOL.B at the 1st station, and the terminal no. 8 for COM.




#### **D-sub Connector Cable Assembly**


	otor Gabie Alegeria.
Cable length (L)	15P
1.5 m	AXT100-DS15-1
3 m	AXT100-DS15-2
5 m	AXT100-DS15-3

<sup>\*</sup> For other commercial connectors, use a type conforming to MIL-C-24308.

# kit (Flat ribbon cable connector) 10 pins, 16 pins, 20 pins



#### How to order manifold




#### Kit/Electrical entry

Pins	Тор	entry	Side entry			
10P (Max. 4 stations)	Kit	UA	Kit	SA		
16P (Max. 7 stations)	P	UB	D	SB		
20P (Max. 9 stations)	l f	UC	, r	SC		

#### Wiring Specifications

\* In the same way as the 26-pin models (standard), the terminal no. 1 is for SOL.A at the 1st station, the terminal no. 2 for SOL.B at the 1st station, and two pins from the max. terminal numbers are for COM.



#### Flat Ribbon Cable Assembly

Cable Pins length (L)	10P	16P	20P
1.5 m	AXT100-FC10-1	AXT100-FC16-1	AXT100-FC20-1
3 m	AXT100-FC10-2	AXT100-FC16-2	AXT100-FC20-2
5 m	AXT100-FC10-3	AXT100-FC16-3	AXT100-FC20-3
Connector width (W)	17.2	24.8	30

<sup>\*</sup> For other commercial connectors, use a type with strain relief conforming to MIL-C-83503.

#### Series VQ1000/2000

#### **Option**


#### **Special Wiring Specifications**

In the internal wiring of F kit, P kit, J kit, G kit, T kit and S kit, double wiring (connected to SOL. A and SOL. B) is adopted for each station regardless of the valve and option types. Mixed single and double wiring is available as an option.

#### 1. How to Order


Indicate an option symbol "-K", for the manifold no. and be sure to specify the mounting position and number of stations of the single and double wiring by means of the manifold specification sheet.

#### Example) VV5Q11-08C6FU1-D K S



#### 2. Wiring specifications

With the A side solenoid of the 1st station as no.1 (meaning, to be connected to no.1 terminal), without making any terminals vacant.



#### 3. Max. number of stations

The maximum number of stations depends upon the number of solenoids. Assuming one for a single and two for a double, determine the number of stations so that the total number is not more than the max. number given in the following table.


Kit		(D-sub nector)	P kit (Flat ribbon cable connector)			J kit (Flat ribbon cable connector)		G kit (Flat ribbon cable with terminal block)		
Туре	F <sub>S</sub> [ 25F	F <sub>S</sub> A 15P	P <sub>S</sub> □ 26P	PSC 20P	P S B 16P	P S / 10F			G	
Max. points	24	14	24	18	14	8		16	16	
Kit		(Te	T ki rminal	t block)		(	Seria	S kit al transmission)	M kit (Circular connector)	
Туре	00100 te	2 rows rminal b		termin		ks		S□	M□	
Max.	l'	10	20					16	24	


#### **Negative Common Specifications**

Specify the valve model no. as shown below for negative COM specification. The manifold no. shown below is for the T and L kits. For other kits the standard manifold can be used. For negative COM S or G kit, please contact SMC.



How to order negative COM manifold





#### **External Pilot Specifications**

When the supply air pressure is lower than the required minimum operating pressure (0.1 to 0.2 MPa) for the solenoid valve (or when the valve is used for vacuum), specify an external pilot model. Order a manifold or valve by suffixing the external pilot specification, "R".

The X-port of the manifold base is equipped with One-touch fittings for external pilot.

VQ1000: C4 (One-touch fitting for Ø4) VQ2000: C6 (One-touch fitting for Ø6)

#### How to order manifold

#### VV5Q11-08C6FU1-R S

Others, option symbols: to be indicated alphabetically.

#### How to order valves




Note 1) When low wattage type is also desired, specify as "RY". Note 2) In this valve pilot exhaust is connected to the EA passage of the

Note 2) In this valve pilot exhaust is connected to the EA passage of the manifold. Therefore, it is not possible to supply air from EXH port, nor vacuum from ports other than SUP port.

#### **Inch-size One-touch Fittings**

The valve with inch-size One-touch fittings is shown below.



Syr	mbol	N1	N3	N7	N9	M5T	NM
Applicable tub	ing O.D. (Inch)	ø1/8"	ø5/32"	ø1/4"	ø5/16"	10-32UNF (M5 thread)	Mixed
4(A), 2(B)	VQ1000	•	•	•	_	•	•
port	VQ2000	_	•	•	•		•

Note) When inch-size fittings are selected for the cylinder port, use inch size fittings for both P and R port.

1(P), 3(R) port size VQ1000 ...... ø5/16" (N9) VQ2000 ..... ø3/8" (N11) VQC

SQ

VQ0

VQ4

VQ5

VQZ

VQD

#### Series VQ1000/2000

#### Option

#### **DIN Rail Mounting**

Each manifold can be mounted on a DIN rail. Order it by indicating a DIN rail mounting option symbol, "-D". In this case, a DIN rail which is approx. 30 mm longer than the manifold with the specified number of stations is attached.

#### ● When DIN rail is unnecessary

(DIN rail mounting brackets only are attached.)

Indicate the option symbol, -DO, for the manifold no.

#### Example)

#### VV5Q11-08C6FU1-D0S

Others, option symbols: to be indicated alphabetically.

#### When using DIN rail longer than the manifold with specified number of stations

Clearly indicate the necessary number of stations next to the option symbol "-D" for the manifold no.

#### Example)

#### VV5Q11-08C6FU1-D09S

DIN rail for 9 stations

Others, option symbols: to be indicated alphabetically.

#### When changing the manifold style into a DIN rail mounting style.


Order brackets for mounting a DIN rail. (Refer to "Option" on pages 2-4-168 and 2-4-173.)

No. VVQ1000-57A (For VQ1000) VVQ2000-57A (For VQ2000) 2 pcs. per one set.

#### When ordering DIN rail only

DIN rail no.: AXT100-DR-□

As for  $\square$ , specify the number from the DIN rail table. For L dimension, refer to the dimensions of each kit.



#### Dimension

<b>L Dimension</b> L = 12.5 x n + 10.													
No.	1	2	3	4	5	6	7	8	9	10			
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5			
No.	11	12	13	14	15	16	17	18	19	20			
L dimension	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5			
No.	21	22	23	24	25	26	27	28	29	30			
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5			
No.	31	32	33	34	35	36	37	38	39	40			
L dimension	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5			

# Plug-in Unit Series VQ1000/2000

VQC

SQ

VQ0

VQ4


VQ5

VQZ

VQD

# Series VQ0000 Base Mounted Plug Lead Unit

#### **How to Order Manifold**




 $\eta$  Note 1) Besides the above, F and P kits with different number of pins are available. Refer to page 2-4-215 for details.


Note 2) For details, refer to page 2-4-216.

Note 3) Please consult with SMC for the following serial transmission kits: Matsushita Electric Works, Ltd.; Rockwell Automation, Inc.; SUNX Corporation; Fuji Electric Co., Ltd.; OMRON Corporation.

# Plug-in Unit Series VQ0000



#### **How to Order Valve Manifold Assembly**



**VQC** 

SQ

VQ0

VQ4

VQ5


**VQZ** 

VQD


Specify the part numbers for valves and options together beneath the manifold base part number. Besides, when the arrangement will be complicated, specify them by means of the manifold specification sheet.

# Manifold Option

Blanking plate assembly Name plate [-N\*]



SUP/EXH block plate VVQ0000-16A-5-



- For cylinder port fittings part no., refer to page 2-4-213.
- For replacement parts, refer to page 2-4-231.

#### DIN rail mounting bracket [-D] VVQ0000-57A-5

SMC for other kits




type


Note) For power consumption of AC type, refer to page 2-4-186.

0

Double check block VQ1000-FPG-□□




Individual SUP spacer VVQ0000-P-5-C4





Note) The C kits are applicable to

200/220 VAC. Please contact




Built-in silencer, direct exhaust [-S]






P. 2-4-208

**Blanking plug** KQ2P-




Individual EXH spacer VVQ0000-R-5-C4





# Series VQ1000 **Base Mounted Plug Lead Unit**

#### **How to Order Manifold**



Note 1) Besides the above, F and P kits with different number of pins are available. Refer to page 2-4-215 for details.


Note 2) For details, refer to page 2-4-216. 2-4-184




Simple specials are available with SMC Simple Specials System. For details about applicable models, please contact

# Plug-in Unit Series VQ1000






#### **How to Order Valve Manifold Assembly**




#### P 2-4-208

# **Manifold Option**


# Blanking plate assembly VVQ1000-10A-1



Individual SUP spacer VVQ1000-P-1-C6




Individual EXH spacer VVQ1000-R-1-C6



• For cylinder port fittings part no., refer to page 2-4-213.


• For replacement parts, refer to page 2-4-231.

# SUP/EXH block plate VVQ1000-16A-2



page 2-4-186.

Back pressure check valve assembly [-B] VVQ1000-18A




Name plate [-N\*] VVQ1000-N2-Station (1 to Max. stations)




# Double check block VVQ1000-FPG-□□


assembly when increasing valve stations. For part nos., refer to "Option" on page 2-4-216. For power consumption of AC type, refer to



Elbow fitting assembly VVQ1000-F-L $_{c6}^{C3}$ 



Built-in silencer, direct exhaust [-S]




# 2 stations matching fitting assembly VVQ1000-52A-C8




Silencer AN200-KM8


the manifold specification sheet.



Port plug VVQ0000-58A



Blanking plug KQ2P-04 Plug





# Series VQ0000/1000

# **Base Mounted Plug Lead Unit**





#### Model


	Number of					F	ow cha	racteristic (1)			Response time (ms) (2)			
Series		lumber of solenoids	l Model		1 → 4/2 (P → A/B)			4/2 → 5/3 (A/B → R1/R2)			Standard: 1 W	Low wattage:	(3)	Weight (g)
		oleriolus			C [dm <sub>3</sub> /(s·bar)]	b	Cv	C [dm <sub>3</sub> /(s·bar)]	b	Cv	H: 1.5 W	0.5 W	AC	(9)
	_	Cinala	Metal seal	VQ0150	0.41	0.20	0.10	0.44	0.26	0.11	12 or less	15 or less	29 or less	36
	position	Single	Rubber seal	VQ0151	0.53	0.20	0.12	0.53	0.22	0.13	15 or less	20 or less	34 or less	30
	2 po	Double	Metal seal	VQ0250	0.41	0.20	0.10	0.44	0.26	0.11	10 or less	13 or less	13 or less	
V00000		Bodbie	Rubber seal	VQ0251	0.53	0.20	0.12	0.53	0.22	0.13	15 or less	20 or less	20 or less	
VQ0000	ے	Closed	Metal seal	VQ0350	0.32	0.10	0.07	0.32	0.20	0.07	20 or less	26 or less	40 or less	
	position	center	Rubber seal	VQ0351	0.43	0.21	0.10	0.44	0.24	0.11	25 or less	33 or less	47 or less	50
	3 po	Exhaust center	Metal seal	VQ0450	0.32	0.10	0.07	0.44	0.26	0.11	20 or less	26 or less	40 or less	30
			Rubber seal	VQ0451	0.43	0.21	0.10	0.53	0.22	0.13	25 or less	33 or less	47 or less	
	_	Single	Metal seal	VQ1110	0.70	0.15	0.16	0.72	0.25	0.18	12 or less	15 or less	29 or less	
	2 position		Rubber seal	VQ1111	0.85	0.20	0.21	1.0	0.30	0.25	15 or less	20 or less	34 or less	
	2 po	Double	Metal seal	VQ1210	0.70	0.15	0.16	0.72	0.25	0.18	10 or less	13 or less	13 or less	64
			Rubber seal	VQ1211	0.85	0.20	0.21	1.0	0.30	0.25	15 or less	20 or less	20 or less	04
VQ1000		Closed	Metal seal	VQ1310	0.68	0.15	0.16	0.72	0.25	0.18	20 or less	26 or less	40 or less	
	_	center	Rubber seal	VQ1311	0.70	0.20	0.16	0.65	0.42	0.18	25 or less	33 or less	47 or less	
	position	Exhaust	Metal seal	VQ1410	0.68	0.15	0.16	0.72	0.25	0.18	20 or less	26 or less	40 or less	78
	3 po	center	Rubber seal	VQ1411	0.70	0.20	0.16	1.0	0.30	0.25	25 or less	33 or less	47 or less	_ ′°
		Pressure	Metal seal	VQ1510	0.70	0.15	0.16	0.72	0.25	0.18	20 or less	26 or less	40 or less	
		center	Rubber seal	VQ1511	0.85	0.20	0.21	0.65	0.42	0.18	25 or less	33 or less	47 or less	

Note 1) Cylinder port size C4: (VQ0000), C6: (VQ1000) without check valve option for prevention of back pressure. As per JIS B 8375-1981 (Supply pressure: 0.5 MPa; with indicator light/surge voltage suppressor; clean air)

Note 2) The response time is subject to the pressure and quality of the air. The values at the time of ON are given for double types.

Note 3) AC type is only for VQ0000.

#### JIS Symbol



#### **Standard Specifications**

	Valve construction			Metal seal	Rubber seal					
	Fluid			Air/Inert gas						
Ø	Maximum operating	pressure	0.7 MPa (High pressure type: 0.8 MPa)							
tion		Single		0.1 MPa	0.15 MPa					
fica	Min. operating	Double		0.1 N	MPa					
Valve specifications	pressure	3 position		0.1 MPa	0.2 MPa					
ds e	Ambient and fluid te	mperature		–10 to	50°C <sup>(1)</sup>					
alxe	Lubrication			Not required						
>	Manual override		Non-locking push type/Locking type (Tool required, Manually operated) Option							
	Impact/Vibration res	istance <sup>(2)</sup>		150/30	) m/s²					
	Enclosure			Dust	tight					
	Coil rated voltage		12, 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)							
	Allowable voltage flu	ıctuation	±10% of rated voltage							
	Coil insulation type		Equivalent to class B							
ë		24 VDC	1 W E	OC (42 mA), 1.5 W DC (6	63 mA) <sup>(3)</sup> , 0.5 W DC (21 mA) <sup>(4)</sup>					
enc		12 VDC	1 W D	C (83 mA), 1.5 W DC (1	25 mA) <sup>(3)</sup> , 0.5 W DC (42 mA) <sup>(4)</sup>					
Solenoid	Power consumption	100 VAC		Inrush 0.5 VA (5	mA), Holding 0.5 VA (5 mA)					
	(Current)	110 VAC	V00000	Inrush 0.55 VA (5	mA), Holding 0.55 VA (5 mA)					
		200 VAC	VQ0000	Inrush 1.0 VA (5 mA), Holding 1.0 VA (5 mA)						
		220 VAC	]	Inrush 1.1 VA (5 mA), Holding 1.1 VA (5 mA)						
	Lite 4) Here describe a consideration of the constraint of the con									

Note 1) Use dry air to prevent condensation when operating at low temperatures.

Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the

right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Note 3) Value for high pressure type (1.5 W)

Note 4) Value for low pressure type (0.5 W) Note 5) AC type is available only on VQ0000.



# Plug Lead Unit Series VQ0000/1000

#### **Manifold Specifications**

	_			Porting specifica	ations	(2)	Applicable	5 station
Series	Base model	Type of connection	Port	Port	size <sup>(1)</sup>	Applicable stations	solenoid	weight
			location	1(P), 3(R)	4(A), 2(B)	Stations	valve	(g)
VQ0000	VV5Q05-□□□	■ F kit— D-sub connector ■ P kit—Flat ribbon cable connector ■ T kit—Terminal block ■ C kit—Individual connector ■ S kit—Serial transmission	Side	C6 (Ø6) Option Built-in silencer, direct exhaust	C3 (ø3.2) C4 (ø4) M5 (M5 thread)	1 to 16 stations	VQ0□50 VQ0□51	330 (Single) 400 (Double, 3 position)
VQ1000	VV5Q12-□□□	■ F kit–D-sub connector ■ P kit–Flat ribbon cable connector ■ T kit–Terminal block ■ C kit–Individual connector ■ S kit–Serial transmission	Side	C8 (Ø8) Option  (Built-insilencer, direct exhaust)	C3 (ø3.2) C4 (ø4)C6 (ø6) M5 (M5 thread)	1 to 16 stations	VQ1□10 VQ1□11	818 (Single) 885 (Double, 3 position)

Note 1) Inch-size One-touch fittings are also available. For details, refer to page 2-4-216. Note 2) For details, refer to page 2-4-216.

VQC

SQ


VQ0

VQ4


VQ5

VQZ

VQD








- The D-sub connector reduces installation labor for electrical connections.
- Using the D-sub connector (25P), (15P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.

Top or side connector receptacle position can be selected in accordance with the available mounting space.

Maximum stations are 16.



#### **Manifold Specifications**


Ì						
	Series	Port	Applicable stations			
		location	1(P), 3(R)	4(A), 2(B)	Stations	
	VQ0000	Side	C6	C3, C4, M5	Max. 16 stations	
	VQ1000	Side	C8	C3, C4, C6, M5	Max. 16 stations	

#### **D-sub Connector (25 pins)**

#### Cable assembly ●



The D-sub connector cable assembly can be ordered individually or included with manifold. Refer to How to Order Manifold.



#### **D-sub Connector Cable Assembly (Option)**

Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-DS25-015	0 11 05
3 m	AXT100-DS25-030	Cable 25-core
5 m	AXT100-DS25-050	X 247WVG

 For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308.

#### Connector manufacturers' example

Fujitsu Limited

Note) Types with 15 pin are also available. Refer to page 2-4-215 for details.

- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.
- Hirose Electric Co., Ltd.

#### Electric Characteristics

Item	Characteristics					
Conductor resistance Ω/km, 20°C	65 or less					
Insulation resistance V, 1 min, AC	1000					
Insulation resistance MΩD. 20°C	5 or more					

Note) The minimum bending radius of D-sub cable assembly is 20 mm.

Option

Symbol

R

D

Κ

N

#### Wire Color by Terminal No. of D-sub Connector Cable Assembly


Terminal no.	Dot marking	Lead wire color
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Gray	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Gray	Red
24	Black	White
25	White	None

VQ0000 VQ1000

(3)

(4)

#### **How to Order Manifold**



Note 1) Specify "Mixed size/with port plug" on the

manifold specification sheet.

Note 2) For inch-size One-touch fittings, refer to

"Option" on page 2-4-216.

S Built-in silencer, direct exhaust 

Note 1) When two or more symbols are specified, indicate them alphabetically. 
Example) -BNS

Option

With back pussure check valve

DIN rail mounting style

Special wiring specifications


(Not double wiring)

With name plate


Note 2) Models with a suffix "-B" have the back pressure check valve at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) F kit of VQ0000 and all of VQ1000 are equipped with a DIN rail, so indicate suffix "n"

Note 4) Specify the wiring specifications on the manifold specification sheet.



The total number of stations is tabulated starting from station one on the D side.



the F kits add a valve. For part nos., refer to

"Option" on page 2-4-


Electrical wiring specifications

015 AXT100-DS25- 030 Wire color 050 D-sub connector Terminal no. Polarity Lead wire color Dot marking Black 0 SOL.B Yellow Black SOL.A None 2 stations SOL.B Pink Black (+)Red None SOL.B Blue White SOL.A (+)Orange None 4 stations SOL.A Yellow None SOL.B (+) Gray None SOL.A Pink None SOL.B Orange (+) Black SOL.A Blue None SOL.B Red (+) White 0 SOL.A Purple SOL.B (+) Brown White сом. (-) Connecto


As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 8 stations or less, regardless of valve and option types.

Mixed single and double wiring is available as an option.

For details, refer to page 2-4-216.



Note) When using the negative common specifications, use valves for negative common. (Refer to page 2-4-216.)



#### **How to Order Manifold Assembly**

Negative

specifications

Positive specifications

Specify the part numbers for valves and options together beneath the manifold base part number.

#### <Example>


D-sub connector kit with cable (3 m) VV5Q12-08C6FU2-D  $\cdots$  1 set-Manifold base no.

\*VQ1110-5LO ······ 4 sets-Valve part no. (Stations 1 to 4) \*VQ1210-5LO ······· 4 sets—Valve part no. (Stations 5 to 8)
\*VQ1310-5LO ······ 2 sets—Valve part no. (Stations 7 to 8)

\*VVQ1000-10A-1···· 1 set-Blanking plate part no. (Station 9)

Prefix the asterisk to the part nos. of the solenoid valve,

Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specified by using the manifold specification sheet.





2-4-189

**VQC** SQ


VQ0

VQ4


VQ5

VQZ

VQD




#### **VQ0000**




Dime	Dimensions: Top Entry Connector [-FU]										n: Station (Maximum 16 stations)						
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
L1	46.5	57.4	68.1	78.8	89.5	100.2	110.9	121.6	132.3	143	153.7	164.4	175.1	185.8	196.5	207.2	
L2	55.7	66.4	77.1	87.8	98.5	109.2	119.9	130.6	141.3	152	162.7	173.4	184.1	194.8	205.5	216.2	
L3	L3   112.5   125   137.5   150   162.5   175   175   187.5   200   212.5   225   237.5   250   250   262.5   275											275					
L4	123	135.5	148	160.5	173	185.5	185.5	198	210.5	223	235.5	248	260.5	260.5	273	285.5	
Dime	Dimensions: Side Entry Connector [-ES]																

ווט	Dimensions: Side Entry Connector [-FS]																
	n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L	3	137.5	150	150	162.5	175	187.5	200	212.5	225	225	237.5	250	262.5	275	287.5	300
L	4	148	160.5	160.5	173	185.5	198	210.5	223	235.5	235.5	248	260.5	273	285.5	298	310.5

#### **VQ1000**





Dime	<b>Dimensions: Top Entry Connector [-FU]</b>										Formula L1 = 10.5n + 72 n: Station (Maximum 16 stations)						
L_n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	
L1	82.5	93	103.5	114	124.5	135	145.5	156	166.5	177	187.5	198	208.5	219	229.5	240	
L2	137.5	150	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5	262.5	275	287.5	300	
L3	148	160.5	173	185.5	198	210.5	210.5	223	235.5	248	260.5	273	273	285.5	298	310.5	

**Dimensions: Side Entry Connector [-FS]** 


<u> </u>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L2	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5	275	287.5	300	312.5	312.5
L3	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5	323	323

# VQ0000/1000 Kit (Flat ribbon cable connector)

- MIL flat ribbon cable connector reduces installation labor savings for electrical connection.
- Using the connector for flat ribbon cable (26P), (10P, 16P, 20P as an option) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.

Top or side receptacle position can be selected in accordance with the available mounting space.

Maximum stations are 16.



#### **Manifold Specifications**


Cable assembly •

	F	orting spe			
Series	Port	Po	Applicable stations		
	location	1(P), 3(R)	4(A), 2(B)	Stations	
VQ0000	Side	C6	C3, C4, M5	Max.16 stations	
VQ1000	Side	C8	C3, C4, C6, M5	Max.16 stations	

#### Flat Ribbon Cable (26 pins)

# AXT100-FC26-

( Flat ribbon cable connector assembly can be ordered individually or included in a specific manifold model no. Refer to "How to Order Manifold".



#### Flat Ribbon Cable Connector Assembly (Option)


Cable length (L)	Assembly part no.	Note
1.5 m	AXT100-FC26-1	0.11.00
3 m	AXT100-FC26-2	Cable 26 cores x 28AWG
5 m	AXT100-FC26-3	X ZONWO

For other commercial connectors, use a 26 pins type with strain relief conforming to MIL-C-83503.

#### Connector manufacturers' example

- Hirose Electric Co., Ltd.
- Japan Aviation Electronics Industry, Ltd.
- Sumitomo 3M Limited
- J.S.T. Mfg. Co., Ltd.
- Fujitsu Limited
- Oki Electric Cable Co., Ltd.


Note) Types with 10, 16, or 20 pin are also available. Refer to page 2-4-215 for details.



The total number of stations is tabulated starting from one on the D side.

Option

#### **How to Order Manifold**



 Symbol
 Option
 VQ0000
 VQ1000

 B
 With back pressure check valve
 ● (2)

 D
 DIN rail mounting style
 ● (3)

 K
 Special wiring specification (Not double wiring)
 ● (4)

 N
 With name plate
 ● (4)

 S
 Built-in silencer (Direct exhaust)
 ● (4)

Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BNS

Note 2) Models with a suffix "-B" have the

Note 2) Models with a suffix "-B" have the back pressure check valve at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) P kit of VQ0000 and all of VQ1000 are equipped with a DIN rail, so indicate suffix "D".

Note 4) Specify the wiring specifications on the manifold specification sheet.

to "Option" on page 2-4-216.

SQ

VQ0

# VQ4


VQ5

VQZ

1 42

VQD

#### Electrical wiring specifications



As the standard electrical wiring specifications, double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station for 8 stations or less, regardless of valve and option types.

Mixed single and double wiring is available as an option.

For details, refer to page 2-4-216.

**How to Order Valves** 

Note) When using the negative commons specifications, use valves for negative common. (Refer to page 2-4-216.)

# How to Order Manifold Assembly

Specify the part numbers for valves and options together beneath the manifold base part number.

#### <Example>


Flat ribbon cable kit with 3 m cable


VV5Q12-08C6PU1-D ...1 set-Manifold base no.

\*VQ1110-5LO ······4 sets-Valve part no. (Stations 1 to 4))
\*VQ1210-5LO ······3 sets-Valve part no. (Stations 5 to 8)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specify by using the manifold specification sheet.





Low wattage (0.5 W)

Note) For power consumption


of AC type, refer to page 2-4-186.


type


Note 1) For negative common Note 2) specifications, refer to "Option" on page 2-4-126.
Connector assembly

Connector assembly will be required when the P kits add a valve. For part nos., refer to "Option" on page 2-4-









<>: AC

#### **Dimensions: Top Entry Connector [-PU]**

Formula L1 = 10.7n + 36, L2 = 10.7n + 45 n: Station (Maximum 16 stations)


14 196.5 207.2 46.7 57.4 68.1 78.8 89.5 100.2 110.9 121.6 132.3 143 153.7 164.4 175.1 185.8 L1 55.7 66.4 77.1 87.8 98.5 109.2 119.9 130.6 141.3 152 162.7 173.4 184.1 194.8 205.5 216.2 262.5 275 112.5 125 125 137.5 150 162.5 175 187.5 200 212.5 225 200 237.5 250 135.5 135.5 148 160.5 173 185.5 198 210.5 210.5 223 235.5 248 260.5 273 285.5


**Dimensions: Side Entry Connector [-PS]** 


۲ /ء	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L3	137.5	150	150	162.5	175	187.5	200	212.5	225	225	237.5	250	262.5	275	287.5	300
L4	148	160.5	160.5	173	185.5	198	210.5	223	235.5	235.5	248	260.5	273	285.5	298	310.5

U side

#### **VQ1000**








Dimensions: Top Entry Connector [-PU]									Fo	rmula L1	= 10.5	n + 72 r	n: Statio	n (Maxin	num 16	stations)
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	82.5	93	103.5	114	124.5	135	145.5	156	166.5	177	187.5	198	208.5	219	229.5	240
L2	137.5	150	150	162.5	175	187.5	200	212.5	225	225	237.5	250	262.5	275	287.5	287.5
L3	148	160.5	160.5	173	185.5	198	210.5	223	235.5	235.5	248	260.5	273	285.5	298	298


**Dimensions: Side Entry Connector [-PS]** 

L n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L2	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5	275	287.5	300	312.5	312.5
L3	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5	323	323




- It is a standard terminal block type.
- Two quantities of terminals can be selected in accordance with the number of stations. (8 terminals/16 terminals)
- Maximum stations are 8. (16 stations as an option)






#### **Manifold Specifications**


		Porting spe				
Series	Port	Applicable				
	location	1(P), 3(R)	4(A), 2(B)	stations		
VQ0000	Side	C6	C3, C4, M5	Max.16 stations		
VQ1000	Side	C6	C3, C4, C6, M5	Max.16 stations		



Open the terminal block cover to connect the wires to the terminal block. (With M3 thread)



#### Electrical wiring specifications




manifold stations

Manifold	Terminal blocks
1 to 4 stations	1 row
5 to 8 stations	2 rows

Note) Wiring other than those above is possible. For details, refer to page 2-4-216.

internal wiring of each station, regardless of valve and option types. Mixed single and double wiring is available as an option. For details, refer to page 2-4-216.

#### **How to Order Manifold**



Cylinder ports Symbol Port size C3 With One-touch fitting for ø3.2 C4 With One-touch fitting for ø4 C6 With One-touch fitting for ø6 M5 M5 thread CM With mixed size/with port plug Note)

Note 1) Specify "Mixed size/with port plug" on the manifold specification sheet. Note 2) For inch-size One-touch fittings refer to "Option" on page 2-4-216.

1	8 terminals in 1 row	Applicable stations 1 to 4 stations (Double wiring), 8 stations (Single wiring)
2	16 terminals in 2 rows	Applicable stations 5 to 8 stations (Double wiring), 16 stations (Single wiring)

Note) The number of terminal blocks can be chosen regardless of station qty. Suffix the option symbol, "K" when the wiring specifications are special.



Symbol	Option	VQ0000	VQ1000
В	With back pressure check valve		• (2)
D	DIN rail mounting style	•	<ul><li>(3)</li></ul>
K	Special wiring specifications (Not double wiring)	•	• (4)
N	With name plate	•	•
S	Built-in silencer, direct exhaust	•	•

When two or more symbols are specified, indicate them alphabetically. Example) -BNS

Note 2) Models with a suffix "-B" have the back pressure check valve at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

Note 3) T kit of VQ0000 and all of VQ1000 are equipped with a DIN rail, so indicate suffix "-D".

Note 4) Specify the wiring specifications on the manifold

specification sheet.



SQ


VQ0

VQ4

VQ5

VQZ

VQD



216.

#### How to Order Manifold Assembly

Specify the part numbers for valves and options together beneath the manifold base part number.


#### <Example>

Flat ribbon cable kit with 3 m cable

VV5Q12-07C6T2-D ... 1 set-Manifold base no. 
\*VQ1110-5LO ...... 4 sets-Valve part no. (Stations 1 to 4) 
\*VQ1210-5LO ...... 3 sets-Valve part no. (Stations 5 to 8)


Prefix the asterisk to the part nos. of the solenoid valve, etc.


Write sequentially from the 1st station on the D side. When part nos. written collectively are-complicated, specify by using the manifold specification sheet.





#### **VQ0000**





This drawing shows the case of VV5Q05-□□T2-D□.

<>: AC

#### **Dimensions**

Formula $L1 = 10.7n + 36$ , $L2 = 10.7n + 45$	n: Station (Maximum16 stations)

L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	46.7	57.4	68.1	78.8	89.5	100.2	110.9	121.6	132.3	143	153.7	164.4	175.1	185.8	196.5	207.2
L2	55.7	66.4	77.1	87.8	98.5	109.2	119.9	130.6	141.3	152	162.7	173.4	184.1	194.8	205.5	216.2
L3	125	137.5	150	150	162.5	175	187.5	200	212.5	225	225	237.5	250	262.5	275	287.5
L4	135.5	148	160.5	160.5	173	185.5	198	210.5	223	235.5	235.5	248	260.5	273	285.5	298

SQ

VQ0


VQ4


VQ5

VQZ

**VQD** 

#### **VQ1000**





This drawing shows the case of VV5Q12-□□T2-D□.


#### **Dimensions**

Formula $L1 = 10.5n + 72$	n: Station (Maximum 16 stations)


														,		
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	82.5	93	103.5	114	124.5	135	145.5	156	166.5	177	187.5	198	208.5	219	229.5	240
L2	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5	275	287.5	300	312.5
L3	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273	285.5	298	310.5	323


















#### **Manifold Specifications**

Series	Port	F	Applicable			
	location	1(P), 3(R)	4(A), 2(B)	stations		
VQ0000	Side	C6	C3, C4, M5	Max. 16		
VQ1000	Side	C8	C3, C4, C6, M5	Max.16 stations		











longer, be sure to indicate the Example) Lead wire length 1000 mm VQ1110-5LO------ 3 pcs. AXT661-14A-10 ---- 3 pcs. model number of the valve without connector and connector assembly.

#### Connector Assembly (For DC)


Lead wire length	Part no. for single & VQ0000 double	Part no. for VQ1000 double
Socket (3 pcs.)	AXT66	S1-12A
300 mm	AXT661-14A	AXT661-13A
600 mm	AXT661-14A-6	AXT661-13A-6
1000 mm	AXT661-14A-10	AXT661-13A-10
2000 mm	AXT661-14A-20	AXT661-13A-20
3000 mm	AXT661-14A-30	AXT661-13A-30

Note) 100/110 VAC for single: AXT661-31A-□; for double: AXT661-32A-□ 200/220 VAC for single: AXT661-34A-□; for double: AXT661-35A-□





#### **How to Order Manifold**



Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -BNS

Option

None

With back pressure check valve

DIN rail mounting style

With name plate

Built-in silencer, direct exhaust

Option Symbol

Nil

В

D

N

s

Note 2) Models with a suffix "-B" have the back pressure check valve at all manifold stations. If not all stations need this check valve, specify the stations where check valves are installed by using the manifold specification sheet.

VQ0000

•

VQ1000

• (3)

Note 3) VQ1000 are all equipped with a DIN rail, so indicate suffix "-D".



plug" on the Note 2) specification sheet.

2-4-216.

For One-touch fittings in inch sizes, refer to "Option" on page

SQ


VQ0

VQ4


VQ5

VQZ

VQD




(Series VQ0□50 has no polarity, so the negative common is applicable to standard models.)





#### **VQ0000**

The broken lines indicate DIN rail mounting style [-D].





<>: AC


Dime	<b>Dimensions</b> Formula L1 = 10.7n + 36, L2 = 10.7n + 45 n: Station (Maximum 16 stations)											stations)				
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	46.7	57.4	68.1	78.8	89.5	100.2	110.9	121.6	132.3	143	153.7	164.4	175.1	185.8	196.5	207.2
L2	55.7	66.4	77.1	87.8	98.5	109.2	119.9	130.6	141.3	152	162.7	173.4	184.1	194.8	205.5	216.2
(L3)	87.5	87.5	100	112.5	125	137.5	150	162.5	162.5	175	187.5	200	212.5	225	225	237.5
(L4)	98	98	110.5	123	135.5	148	160.5	173	173	185.5	198	210.5	223	235.5	235.5	248



#### **VQ1000**








Dime	<b>Dimensions</b> Formula L1 = 10.5n + 72 n: Station (Maximum 16 stations)													tations)		
n 1 2 3 4 5 6 7 8 9 10 11 12 13 -											14	15	16			
L1	82.5	93	103.5	114	124.5	135	145.5	156	166.5	177	187.5	198	208.5	219	229.5	240
L2	112.5	112.5	125	137.5	150	162.5	175	187.5	187.5	200	212.5	225	237.5	250	250	262.5
L3	123	123	135.5	148	160.5	173	185.5	198	198	210.5	223	235.5	248	260.5	260.5	273

# VQ0000/1000 Kit (Serial transmission unit)

The serial transmission system reduces wiring work, while minimizing wiring and saving space.


The system comes in type SA (generic for small scale systems) for equipment with a small number of I/O points, or 32 points max., type SB (applicable to Mitsubishi Electric models) for controlling 512 I/O points max., type SC (applicable to OMRON models), type SD (applicable to SHARP models: 504 points max.), type SF (applicable to NKE models: 128 points max.), type SJ (applicable to SUNX models), type SK (applicable to Fuji Electric models), type SQ (applicable to OMRON's Compo Bus/D), and type SR (applicable to OMRON's Compo Bus/S).

 Max. 8 stations. (Specify a option model with 9 to 16 stations by using the manifold specification sheet.)




#### **Manifold Specifications**

		Porting spe	cifications	A II In I		
Series	Port	Applicable stations				
	location	1(P), 3(R)	4(A), 2(B)	Stations		
<b>VQ0000</b> Side C6		C6	C3, C4, M5	Max.16 stations		
VQ1000	Side	C8	Max.16 stations			



Item	Specifications
External power supply	24 VDC, +10%, -5%
Current consumption (Internal unit)	SA, SB, SD, SE, SF, SG, SJ, SK, SQ, SR, SH, SV: 0.1A SC: 0.3A

	Type SA With general type SI unit (Series EX300)	Type SB Mitsubishi Electric Corporation MELSECNET/MINI-S3 Data Link System
Name of terminal block (LED)	ADDRESS NO.    Market	POWER RUNSO RO ERRO  UTO  UTO  UTO  UTO  UTO  UTO  UTO
er.u	LED Description	LED Description
of t	TRD Lighting during data reception	POWER Lighting when power is turned ON
шe	RUN/ERR Blinking when received data is normal; Lighting when data reception	RUN Lighting when data transmission with the master station is normal
Sa		RD Lighting during data reception
		SD Lighting during data transmission
		ERR. Lighting when reception data error occurs Light turns off when the error is corrected
Note	• T unit Can be connected with PLC I/O card for serial transmission.  EX300-TMB1···· For models of Mitsubishine Electric Corporation  EX300-TTA1···· For models of OMRON Corporation  EX300-TFU1···· For models of Fuji Electric Co., Ltd.  EX300-T001···· For general models  * Up to 32 points per unit. • No. of output points, 16 point  details on specifications and handling, refer to	Master station: PLC made by Mitsubishi Electric Corporation Series MELSEC-A AJ71PT32-S3, AJ71T32-S3 A1SJ71PT32-S3 * Max. 64 stations, connected to remote I/O stations (Max. 512 points). No. of output points, 16 points. No. of sta. occupied, 2 stations



unit on CPU side

Note 2) Usable only for VQ1000

the manifold specification sheet.

SQ

VQ0

VQ4


VQ5

**VQZ** 

VQD

# SI unit output and coil numbering

#### <Wiring example 1>




Double wiring (Standard)


#### **Wiring example 2>** Mixed wiring is available as an option.

Use the manifold specification sheet to specify.

SI uni		0	1	2	3	4	5	6	7
		Α	В	А	В	Α	A	Α	В
	SI Unit	14:30	nonple	1	elanon	Single	Single	4	Double
	Stations		1	:	2	3	4	į	5

Single/Double Mixed Wiring (Option)





#### **How to Order Manifold Assembly**

Please indicate manifold base corresponding valve, and option parts.

#### <Example>


#### Serial transmission kit

VV5Q12-08C6SA-D .... 1 set-Manifold base no.

\*VQ1110-5LO ·····4 sets-Valve part no. (Stations 1 to 4))
\*VQ1210-5LO ·····3 sets-Valve part no. (Stations 5 to 8)

the part nos. of the solenoid valve, etc.

Prefix the asterisk to Write sequentially from the 1st station on the D side. When part nos. written collectively are complicated, specify by using manifold specification the




Note) Connector assembly will be required when the S kits add a valve


For part nos., refer to "Option" on page 2-4-216.

	• • • • • • • • • • • • • • • • • • • •	
Symbol	Specifications	DC
Nil	Standard type	(1.0 W)
Н	High pressure type	(1.5 W)
Y	Low wattage type	(0.5 W)

#### **VQ0000**



<b>Dimensions</b> Formula L1 = 10.7n + 36, L2= 10.7n + 45 n: Station (Maximum 16 stations)																
n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	46.7	57.4	68.1	78.8	89.5	100.2	110.9	121.6	132.3	143	153.7	164.4	175.1	185.8	196.5	207.2
L2	55.7	66.4	77.1	87.8	98.5	109.2	119.9	130.6	141.3	152	162.7	173.4	184.1	194.8	205.5	216.2
L3	225	237.5	250	250	262.5	275	287.5	300	312.5	325	325	337.5	350	362.5	375	387.5
L4	235.5	248	260.5	260.5	273	285.5	298	310.5	323	335.5	335.5	348	360.5	373	385.5	398



Dillicitorio										Torrida ET = Total TTE The Station (Maximum To Stations							tationo
	<u>l</u> n	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
	L1	82.5	93	103.5	114	124.5	135	145.5	156	166.5	177	187.5	198	208.5	219	229.5	240
	L2	162.5	175	187.5	200	200	212.5	225	237.5	250	262.5	275	275	287.5	300	312.5	325
	1.2	172	105 5	100	210 5	210 5	222	225 5	240	260 5	272	205 5	205 5	വര	210 5	222	225 5

<sup>\*</sup> Manifolds with SI unit for Matsushita Electric Works' MEWNET FP and Rockwell Automation's model are the same with L4 and L5 dimensions of dustproof SI unit.


#### Series VQ0000


#### **Manifold Option Parts for VQ0000**

# Blanking plate assembly VVQ0000-10A-5

JIS Symbol


It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.






# Individual SUP spacer VVQ0000-P-5-C4


When the same manifold is to be used for different pressures, this spacer is mounted under the valve to equip each valve with an individual supply port.






# Individual EXH spacer VVQ0000-R-5-C4

When a valve exhaust affects other stations due to the circuit configuration, this spacer is mounted under the valve to equip each valve with an individual valve exhaust.





# SUP/EXH block plate VVQ0000-16A-5- $_{R\ (EXH)}^{P\ (SUP)}$ PR (SUP/EXH)

#### 1(P) (For SUP)

When different pressures, high and low, are supplied to one manifold, block a plate is inserted between the stations under different pressures.

#### 3(R) (For EXH)

When a valve exhaust affects other stations due to the circuit configuration, this plate is used between the stations where exhaust should be separated.

#### 1(P), 3(R) (For SUP/EXH)

When blocking SUP and EXH simultaneously, SUP/EXH block plate (PR) is used.

 Specify the number of stations on the manifold specification sheet.

#### <Blocking indication label>

When blocking the SUP, EXH passage with a SUP, EXH block plate, indication label for confirmation of the blocking position from outside is attached. (One label for each)

\* When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold.


# SUP passage blocked (VVQ0000-16A-5-PR) SUP passage blocked (VVQ0000-16A-5-PR)

#### Name plate [-N\*]


#### VVQ0000-N5-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc.

Insert it into the groove on the side of the end plate and bend it as shown in the figure.



\* When ordering assemblies incorporated with a manifold, add suffix "N" to the manifold no.



# Plug-in Unit Series VQ0000


#### Blanking plug (For One-touch fittings)

#### KQ2P- 04

It is inserted into an unused cylinder port and SUP/EXH ports.

Purchasing order is available in units of 10 pieces.






#### **Dimensions**

Applicable fitting size ød	Model	A	L	D
3.2	KQ2P-23	16	31.5	3.2
4	KQP-04	16	32	6
6	KQP-06	18	35	8

# DIN rail mounting bracket [-D] VVQ0000-57A-5 (VQ0000)


It is used for mounting a VV5Q05 type manifold on a DIN rail. The DIN rail mounting bracket is fixed to the manifold end plate. (The specification is the same as that for the option "-D".)

1 set of DIN rail mounting bracket is used for 1 set of manifold (2 DIN rail mounting brackets).



\* When ordering assemblies incorporated with a manifold, add suffix "-D" to the manifold no.





VQ4 VQ5

**VQC** 

SQ

VQ0

V07

VQZ

VQD


#### Built-in silencer, Direct exhaust [-S]

This is an exhaust port on the manifold end plate. The builtin silencer exhibits an excellent noise suppression effect. (Silencing effect: 20 dB)



Note) A large quantity of drainage generated in the air source results in exhaust of air together with drainage.


• For maintenance, refer to page 2-4-214.



\* When ordering assemblies incorporated with a manifold, add suffix "-S" to the manifold no.

#### Silencer (For EXH port)

This is inserted into the centralized type EXH port (One-touch fitting).



#### Dimensions


Series	Applicable fitting size ød	Model	A	L	D	Effective area (mm²)	Noise reduction (dB)
VQ0000	6	AN103-X233	20	37	11	7	25


#### **Manifold Option Parts for VQ1000**

#### Blanking plate assembly VVQ1000-10A-1

JIS Symbol

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc






#### Individual SUP spacer VVQ1000-P-2-C6

When the same manifold is to be used for different pressures, individual SUP spacers are used as SUP ports for different pressures. (One station space is

Block both sides of the station, for which the supply pressure from the individual SUP spacer is used, with SUP block plates. (Refer to the application ex.)


\* Specify the spacer mounting position and SUP block plate position on the manifold specification sheet. The block plates are used in two places for one set. (Two SUP block plates forblocking SUP station are attached to the individual SUP spacer.)



#### Individual EXH spacer VVQ1000-R-2-C6

When valve exhaust affects other stations due to the circuit configuration, this spacer is used for individual valve exhaust. (One station space is occupied.) Block both sides of the individual valve EXH station. (See example.)

\* Specify the mounting position, as well as EXH block base or EXH block plate position on the manifold specification sheet. The block plates are used in two places for one set.



#### SUP/EXH block plate VVQ1000-16A-2

When different pressures, high and low, are supplied to one manifold, a SUP block plate is inserted between the stations under different pressures.

When a valve exhaust affects other stations due to the circuit configuration, this plate is also used between the stations where exhaust should be separated. It is also used for individual exhaust by combining an EXH block plate with an individual EXH spacer.

(2 EXH plates are necessary for 1 station.)


Note) The SUP/EXH block plate is common.

\* Specify the number of stations on the manifold specification sheet.

#### <Blocking indication label>

When using block plates for SUP/EXH passage, the indication label for confirmation of the blocking position from outside is attached. (One label for each)

\* When ordering a block plate incorporated with the manifold no., a block indication label is attached to the manifold





SUP passage blocked



EXH passage blocked




SUP/EXH passage blocked

#### Back pressure check valve assembly [-B] VVQ1000-18A

It prevents cylinder malfunction caused by other valve exhaust. Insert it into R (EXH) port on the manifold side of a valve which is affected. It is effective when a single acting cylinder is used or an exhaust center type solenoid valve is used.


Note) When a check valve for back pressure prevention is desired to be installed only in certain manifold stations, write clearly the part no. and specify the station numbers by using the manifold specification sheet.



\* When ordering assemblies incorporated with a manifold, add suffix "-B" to the manifold no



- 1. Back pressure check valve assembly is assembled with a check valve structure. However, as slight air leakage allowed for the back pressure, take note exhaust air will not be throttled at the exhaust port.
- When a back pressure check valve is mounted, the effective orifice of the valve decrease by about 20%



SQ

VQ0

VQ4

VQ5

VQZ

VQD


#### Plug-in Unit Series VQ1000


#### Name plate [-N\*]

#### VVQ1000-N2-Station (1 to Max. stations)

It is a transparent resin plate for placing a label that indicates solenoid valve function, etc.

Insert it into the groove on the side of the end plate and bend it as shown in the figure.






#### Blanking plug (For One-touch fittings)

KQ2P-

It is inserted into an unused cylinder port and SUP/EXH ports. Purchasing order is available in units of 10 pieces.







#### Dimensions

Applicable fitting size ød	Model	A	L	D
3.2	KQ2P-23	16	31.5	3.2
4	KQP-04	16	32	6
6	KQP-06	18	35	8
8	KQP-08	20.5	39	10

#### Port plug VVQ0000-58A

The plug is used to block the cylinder port when using a 4 port valve as a 3 port valve.





- \* When ordering a plug incorporated with a manifold, indicate "CM" for the port size in the manifold no., as well as, the mounting position and number of stations andcylinder port mounting positions, A and B, by means of the manifold specification sheet.
- \* Lightly screw an M3 screw in the port plug hole and pull it for removal.


### Elbow fittings assembly VVQ1000-F-L calculus


It is used for piping that extends upward or downward from the manifold.

When not mounting it to all manifold stations, clearly write the elbow type fitting assembly no. and specify the station's qty and position by manifold specifications.

\* When mounting elbow fittings assembly on the edge of manifold station and a silencer on EXH port, select a silencer, AN203-KM8.

Silencer (AN200-KM8) is interfered with fittings.





\* When ordering assemblies incorporated with a manifold, indicate "L\sum or "B\sum for the manifold port size.

#### **Built-in silencer, Direct exhaust [-S]**


This is an exhaust port on the manifold end plate.

The built-in silencer exhibits an excellent noise suppression effect. (Silencing effect: 30 dB)

Note) A large quantity of drainage generated in the air source results in exhaust of air together with drainage.



• For maintenance, refer to page 2-4-214.






When ordering assemblies incorporated with a manifold, add suffix "-S" to the manifold no.


#### 2 stations matching fitting assembly VVQ1000-52A-C8


For driving a cylinder with a large bore, valves for two stations are operated to double the flow rate. This assembly for the cylinder port is used in that case. The assembly is equipped with One-touch fittings for a  $\emptyset 8$  bore.

\* The bore for the manifold no. is "CM"

Clearly indicate the 2 station matching fitting assembly no., and specify the number of stations and positions on the manifold specification sheet.








#### Silencer (For EXH port)

This is inserted into the centralized type EXH port (One-touch fitting).

 When mounting elbow fittings assembly (VVQ1000-F-L□) on the edge of manifold station, select a silencer, AN203-KM8.

Silencer (AN200-KM8) is interfered with fittings.



#### **Dimensions**

Series	Applicable fitting size ød	Model	A	L	D	Effective area (mm²)	Noise reduction (dB)
V04000		AN200-KM8	59	78	22	20	30
VQ1000	8	AN203-KM8	32	51	16	14	25 *

#### Manifold Option Parts for VQ0000/VQ1000

#### Double check block (Separated type)


VQ1000-FPG-□□

It is used on the outlet side piping to keep the cylinder in the intermediate position for a long time. Combining the double check block with a built-in pilot type double check valve and a 3 position exhaust center solenoid valve will enable the cylinder to stop in the middle or maintain its position for a long time.

The combination with a 2 position single/double solenoid valve will permit this block to be used for preventing the dropping at the cylinder stroke end when the SUP residual pressure is released.

#### **Specifications**


Max. operating pressure	0.8 MPa
Min. operating pressure	0.15 MPa
Ambient and fluid temperature	−5 to 50°C
Flow characteristics: C	0.60 dm3/(s·bar)
Max. operating frequency	180 CPM





Manifold


#### **Dimensions**


#### Single unit












Option



<Example>

Intermediate

stops

1(P) 1(P 3(R2) 3(R2

0

#### **How to Order**

#### Double check block

#### VQ1000-FPG-<u>C4 | M5</u>

#### IN side port size

C4	One-touch fitting for ø4		
C6	One-touch fitting for ø6		

#### OUT side port size

M	5	M5 thread
C	3	One-touch fitting for ø3.2
C4	ļ	One-touch fitting for ø4
C	3	One-touch fitting for ø6

## Nil None F With bracket D DIN rail mounting style (For manifold) N Name plate

Note) When two or more symbols are specified, indicate them alphabetically.

Example) -DN

#### Manifold

#### VVQ1000-FPG-06

#### 

#### <Example>

VVQ1000-FPG-06 ··· 6 types of manifold \*VQ1000-FPG-C4M5-D, 3 sets \*VQ1000-FPG-C6M5-D, 3 sets block

#### **Bracket Assembly**

Part no.	Tightening torque
VQ1000-FPG-FB	0.22 to 0.25 N·m

#### **⚠** Caution

 Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping for a long time. Check the leakage using neutral household detergent, such as dish washing soap.
 Also check the cylinder's tube gasket, piston packing and rod packing for air leakage.

Drop

prevention

- Since One-touch fittings allow slight air leakage, screw piping (with M5 thread) is recommended when stopping the
- cylinder in the middle for a long time.

   Combining double check block with 3 position closed center or pressure center solenoid valve will not work.
- M5 fitting assembly is attached, not incorporated into the double check block. After screwing in the M5 fittings, mount
  the assembly on the double check block.
- {Tightening torque: 0.8 to 1.2 N·m}
   If the exhaust of the double check block is throttled too much, the cylinder may not operate properly and may not stop intermediately.
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.



SQ

VQ0

VQ4

VQ5

**VQZ** 

VQD

#### **⚠ Precautions 1**


Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.

#### **Light/Surge Voltage Suppressor**

#### **⚠** Caution


In the case of VQ1000, the standard model is equipped with an indicator light and surge voltage suppressor. The lighting positions are concentrated on one side for both single solenoid type and double solenoid type.

For the double solenoid type, A side and B side energization are indicated by two colors which match the colors of the manual overrides.



\* In the case of VQ0000, solenoid and manual override on both sides.

#### VQ1000 (DC)/Single solenoid



 In the case of VQ0000, solenoid and manual override on both sides.

Note) A side energization:

DC circuit diagram


**VQ0000** 

A light (orange) illuminates. With wrong wiring preventing ability (stop diode)


B side energization:

B light (green) illuminates.
Equipped with a surge absorption

(surge absorption diode mechanism.



#### VQ1000/Double solenoid



#### **Manual Override**


#### ⚠ Warning

Without an electric signal for the solenoid valve the manual override is used for switching the main valve.

Push type is standard. (Tool required)

Option: Locking type (Tool required/Manual)

#### ■ Push type (Tool required)



Push down on the manual override button with a small screwdriver until it stops. Release the screwdriver and the manual override will return.

#### ■ Locking type (Tool required) <Option>


If the manual override is turned by 180° clockwise and the ► mark is adjusted to 1, it will be locked in the ON state.

1, it will be locked in the ON state.

If the manual override is turned by 180° counterclockwise and the ▶ mark is adjusted to 0, locking will be released and the manual override will return.

Push down completely on the manualoverride button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.

VQ1000



#### ■ Locking type (Manual) <Option>




Push down on the manual override button with a small screwdriver or with your fingers until it stops. Turn clockwise by  $90^\circ$  to lock it. Turn it counterclockwise to release it.

#### ↑ VQ1000

Do not apply excessive torque when turning the locking type manual override. (0.1 N·m or less)

#### **How to Mount/Remove Solenoid Valve**

#### **∧** Caution



#### How to Remove

- **1.** Loosen the clamp screw until it turns freely. (The screw is captive.)
- 2. Lift the coil side of the valve body while pressing down slightly on the screw head and remove it from the clamp bracket B. When the screw head cannot be pressed easily, gently press the area near the manual override of the valve.

#### **How to Remove**

- Press down on the clamp screw. → Clamp bracket A opens. Diagonally insert the hook on the valve end plate side into clamp B.
- 2. Press the valve body downward. (When the screw is released, it will be locked by clamp bracket A.)
- Tighten the clamp screw. (Proper tightening torque: 0.25 to 0.35 N·m)

#### Mounting

- Dust on the sealing surface of the gasket or solenoid valve can cause air leakage.
- 2. In the case of VQ0000, valve mounting screw clamping torque is 0.18 to 0.25 N·m.


#### **Replacement of Cylinder Port Fittings**

#### **⚠** Caution

The cylinder port fittings are a cassette for easy replacement.

The fittings are blocked by a clip inserted from the top of manifold. Remove the clip with a screwdriver to remove fittings.

For replacement, insert the fitting assembly until it strikes against the inside walland then re-insert the clip to specified position.



Take off the valve and remove the clip.

Remove the clip after taking off the manifold.

America de la Ambiento O.D.	Fitting assembly part no.		
Applicable tubing O.D.	VQ0000	VQ1000	
Applicable tubing ø3.2	VVQ1000-51A-C3	VVQ1000-50A-C3	
Applicable tubing ø4	VVQ1000-51A-C4	VVQ1000-50A-C4	
Applicable tubing ø6	_	VVQ1000-50A-C6	
M5	_	VVQ1000-50A-M5	

\* Refer to "Option" on pages 2-4-208 to 2-4-211 for other types of fittings.

#### **⚠** Caution

- Use caution that O-rings must be free from scratches and dust. Otherwise, air leakage may result.
- After screwing in the fittings, mount the M5 fitting assembly on the manifold base. (Tightening torque 0.8 to 1.2 N·m)
- 3. Purchasing order is available in units of 10 pieces.


#### **⚠ Precautions 2**

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.

#### **How to Use Plug Connector**

#### **⚠** Caution

#### Attaching and detaching connectors




To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.

#### Crimping the lead wire and socket

Peel 3.2 to 3.7 mm of the tip of lead wire, neatly into a socket and press contact it by a press tool.

Be careful so that the cover of lead wire does not enter into the core press contacting part. To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.




#### Attaching and detaching lead wires with sockets Attaching

Insert a socket in the square hole (Indicated as  $\bigoplus$ ,  $\bigoplus$ ) of connector, push in the lead wire and lock by hanging the hook of socket to the seat of connector. (Pushing-in can open the hook and lock it automatically.) Then confirm the lock by lightly pulling on the lead wire.

#### **Detaching**

For pulling-out the socket from the connector, pull out the lead wire while pushing the hook of the socket with a fine point (ca.1 mm) tool.

If the socket is to be re-used, spread the hook to the outside.




#### Mounting/Removing from the DIN Rail (VQ1000)


#### **⚠** Caution

#### Removing

1.Loosen the clamp screw on side (a) of the end plate on both sides.

2.Lift side (a) of the manifold base and slide the end plate in the direction of (2) shown in the figure to remove.





#### Hook side (b) of the manifold base on the DIN rail.

- **2.** Press side (a) and mount the end plate on the DIN rail.
- Tighten the clamp screw on side (a) of the end plate. The proper tightening torque for screws is 1.2 to 1.6 N·m.

#### **Enclosure IP65**

#### **⚠** Caution

Wires, cables, connectors, etc. used for models conforming to IP65 should also have enclosures equivalent to or of stricter than IP65.

#### How to Calculate the Flow Rate

#### **⚠** Caution

2-4-214

For obtaining the flow rate, refer to pages 2-1-8 to 2-1-11.

#### **Built-in Silencer Replacement**

#### **⚠** Caution



A silencer element is incorporated in the end plate on both sides of the manifold base. A dirty and choked element may reduce cylinder speed and cause malfunction. Clean or replace the dirty element.

Remove the cover from the top of the end plate and remove the old element with a screwdriver, etc.

#### Element part no.

Type	Element part no.		
туре	VQ0000	VQ1000	
Built-in silencer, direct exhaust (-S)	VVQ0000-82A-1	VVQ1000-82A-1	


\* The minimum order quantity is 10 pcs.

#### Manifold Base Station Increasing Procedure (VQ1000)


#### **⚠** Caution

1. Loosen the clamp screw on the top surface of the end plate on one side.


Turn the manual override between the manifold blocks with a regular screwdriver, etc. in a couterclockwise direction.



4. Mount the station increasing manifold block assembly and solenoid valve on the DIN rail. Install it to the DIN rail by applying the hook on the (b) side of the manifold block and pushing down



Slide the manifold base to the side where the screw is loosened. Make a clearance of 15 mm or more.



5. Slide the manifold bases with a slight clearance in-between and lock them by turning the manual override between the manifold blocks

clockwise.
6. Tighten the screw on the top surface of the end plate, and the station has been added.

(Proper tightening torque 1.2 to 1.6

#### **Manifold Block Assembly**

	<u> </u>
VQ1000	Port size
VVQ1000-1A-2-C3	With One-touch fitting for ø3.2
VVQ1000-1A-2-C4	With One-touch fitting for ø4
VVQ1000-1A-2-C6	With One-touch fitting for ø6
VVQ1000-1A-2-M5	M5 thread



SQ

VQ0

VQ4

VQ5

VQZ

VQD

#### Option


#### **Different Number of Connector Pins**

F and P kits with the following number of pins are available besides the standard number (F = 25; P = 26). Select the desired number of pins and cable length from the cable assembly list.


Place an order for the cable assembly separately.



#### kit (D-sub connector) 15 pins



#### How to order manifold




#### Kib Electrical entry

Pins	Тор	entry	Side	entry
15P (Max. 7 stations)	Kit F	Kit F UA		SA

#### Wiring Specifications

\* In the same way as the 25-pin models (standard), terminal no. 1 for is SOL.A at the 1st station, terminal no. 9 for SOL.B at the 1st station, and terminal no. 8 for COM.




Terminal no.	Lead wire color	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black

#### **D-sub Connector Cable Assembly**


Cable length (L)	15P
1.5 m	AXT100-DS15-1
3 m	AXT100-DS15-2
5 m	AXT100-DS15-3

<sup>\*</sup> For other commercial connectors, use a type conforming to MIL-C-24308.

#### kit (Flat ribbon cable connector) 10 pins, 16 pins, 20 pins



How to order manifold




#### Kit/Electrical entry•

Pins	Top 6	entry	Side	entry
10P (Max. 4 stations)	IZ'a	UA	IZ:	SA
16P (Max. 7 stations)	Kit	UB	Kit	SB
20P (Max. 9 stations)	Ρ	UC	Р	SC

#### Wiring Specifications

\* In the same way as the 26-pin models (standard), terminal no. 1 is SOL.A at the 1st station, terminal no. 2 for SOL.B at the 1st station, and two pins from the max.



#### Flat Ribbon Cable Assembly

Pins Cable length (L)	10P	16P	20P
1.5 m	AXT100-FC10-1	AXT100-FC16-1	AXT100-FC20-1
3 m	AXT100-FC10-2	AXT100-FC16-2	AXT100-FC20-2
5 m	AXT100-FC10-3	AXT100-FC16-3	AXT100-FC20-3
Connector width (W)	17.2	24.8	30

<sup>\*</sup> For other commercial connectors, use a type with strain relief conforming to MIL-C-83503.

#### Series VQ0000/1000

#### **Option**

#### **Special Wiring Specifications**

In the internal wiring of F kit, P kit, T kit and S kit, double wiring (connected to SOL. A and SOL. B) is adopted for each station regardless of the valve and option types.

Mixed single and double wiring is available as an option.

#### 1. How to Order


Indicate an option symbol "-K", for the manifold no. and be sure to specify the mounting position and number of stations of the single and double wiring by means of the manifold specification sheet.

#### Example) VV5Q05-08C4FU1-DKS

Others, option symbols: to be indicated alphabetically.

#### 2. Wiring specifications

With the A side solenoid of the 1st station as no. 1 (meaning, to be connected to no. 1 terminal), without making any terminals vacant.



#### 3. Max. number of stations

The maximum number of stations depends upon the number of solenoids. Assuming one for a single and two for a double, determine the number of stations so that the total number is not more than the max. number given in the following table.

Kit	F kit (	D-sub ector)			kit ribbon onnecto	(Ter	kit minal ock)	S kit (Serial transmission)	
Туре	F s □ 25P	F s A 15P	<b>P</b> <sup>∪</sup> <sub>S</sub> □ P <sup>∪</sup> <sub>S</sub> C P <sup>∪</sup> <sub>S</sub> B P <sup>∪</sup> <sub>S</sub> A 26P 16P 10P				T1	T2	S□
Max. points	16 <sup>Note)</sup>	14	16 <sup>Note)</sup>	16 <sup>Note)</sup>	14	8	8	16	16

Note) Due to the limitation of internal wiring.

#### Negative Common Specifications [Series VQ1□10]

The following valve part numbers are for negative COM specifications. Manifold model no. is the same as the standard products.

#### How to order negative COM valves




Negative common specifications

 $\ast$  Series VQ0 $\square$ 50 has no polarity, so the negative common is applicable to standard models.

#### **Inch-size One-touch Fittings**

Valve with inch-size One-touch fittings is shown below.



Note) When inch size fittings are selected for a cylinder port, use inch size fittings for both P and R port, too.

#### Plug Connector Assembly Model

Connector assembly will be required when the F, P, S kits add a valve. Specify the style of valve and connector assembly.

#### Connector Assembly Part No.

Specifi	cations	Part no.
Single VQ0000	Positive common	AXT661-14A-F
(2-wire)	Negative common	AXT661-14AN-F
Double (latching)	Positive common	AXT661-13A-F
(3-wire)	Negative common	AXT661-13AN-F

Note) Lead wire length: 300 mm

The part numbers above are applicable to 2 to 10 stations. 11 to 16 stations: "AXT661-\frac{14}{12}A(N)-F-425".

#### **DIN Rail Mounting**

Each manifold can be mounted on a DIN rail. Order it by indicating a DIN rail mounting option symbol, "-D". In this case, a DIN rail which is approx. 30 mm longer than the manifold with the specified number of stations is attached. Other than this, it is applicable for the following cases.

 When DIN rail is unnecessary (C kit VQ0000 only) Indicate the option symbol, -DO, for the manifold no.

Example)

#### VV5Q05-08C4C-DOS

Others, option symbols: to be indicated alphabetically.

 When using DIN rail longer than the manifold with specified number of stations (VQ0000/VQ1000)

Clearly indicate the necessary number of stations next to the option symbol. "D" for the manifold no.

Example)

#### VV5Q05-08C4FU1-D09S

DIN rail for 9 stations • Others, option symbols:

Others, option symbols: to be indicated alphabetically.

 When changing the manifold style into a DIN rail mounting style (VQ0000 only)


Order brackets for mounting a DIN rail. (Refer to "Option" on page 2-4-209.)

No. VVQ0000-57A-5 2 pcs. per one set.

When ordering DIN rail only (VQ0000 only)

DIN rail no.: AXT100-DR-□

As for  $\square$ , specify the number from the DIN rail table. For L dimension, refer to the dimensions of each kit.



#### **L** Dimension

L = 12.5 x n + 10.5

No.	1	2	3	4	5	6	7	8	9	10
L dimension	23	35.5	48	60.5	73	85.5	98	110.5	123	135.5
No.	11	12	13	14	15	16	17	18	19	20
L dimension	148	160.5	173	185.5	198	210.5	223	235.5	248	260.5
No.	21	22	23	24	25	26	27	28	29	30
L dimension	273	285.5	298	310.5	323	335.5	348	360.5	373	385.5
No.	31	32	33	34	35	36	37	38	39	40
L dimension	398	410.5	423	435.5	448	460.5	473	485.5	498	510.5

SQ

**VQC** 

VQ0

VQ4

VQ5

VQZ

VQD

## Series VQ Single Unit

#### Model

							FI	ow cł	naracteristic (1)			Respo	nse time (ı	ms) <sup>(2)</sup>				
	Series		ımber of	Model		1 → 4/2 (P →	$1 \rightarrow 4/2 \text{ (P} \rightarrow \text{A/B)}$ $4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{R1/R2)}$		Standard: 1W Low			Weight						
		solenoid				C [dm <sub>3</sub> /(s·bar)]	b	Cv	C [dm <sub>3</sub> /(s·bar)]	b	Cv	H: 1.5W	wattage: 0.5 W	AC	(g)			
		L	Single	Metal seal	VQ0150	0.41	0.20	0.10	0.44	0.26	0.11	12 or less	15 or less	29 or less				
		position 2 positi	د C	sitio	sitio (	Sirigle	Rubber seal	VQ0151	0.53	0.20	0.12	0.53	0.22	0.13	15 or less	20 or less	34 or less	50
ted	VQ0000			Double	Metal seal	VQ0250	0.41	0.20	0.10	0.44	0.26	0.11	10 or less	13 or less	13 or less	30		
mounted	Plug			2 00	7	Double	Rubber seal	VQ0251	0.53	0.20	0.12	0.53	0.22	0.13	15 or less	20 or less	20 or less	
	lead				Closed	Metal seal	VQ0350	0.32	0.10	0.07	0.32	0.20	0.07	20 or less	26 or less	40 or less		
Base	icuu				itio	iţi	center	Rubber seal	VQ0351	0.43	0.21	0.10	0.44	0.24	0.11	25 or less	33 or less	47 or less
			Exhaust	Metal seal	VQ0450	0.32	0.10	0.07	0.44	0.26	0.11	20 or less	26 or less	40 or less	05			
						center	Rubber seal	VQ0451	0.43	0.21	0.10	0.53	0.22	0.13	25 or less	33 or less	47 or less	

For individual use of a single valve.




Note 1) Cylinder port size C4: (VQ0000)

Note 2) Based on JIS B 8375-1981 (Supply pressure: 0.5 MPa; with indicator light and surge voltage suppressor; clean air) The response time is subject to the pressure and quality of the air. The valves at the time of ON are given for double types.

Note3) Weight including sub-plate.

#### JIS Symbol



#### **Standard Specifications**

	ими оросии				
	Valve construction	on	Metal seal	Rubber seal	
	Fluid		Air/Inert gas	Air/Inert gas	
	Maximum operat	ing pressure	0.7 MPa (High pres	sure type: 0.8 MPa)	
ons	N.4:	Single	0.1 MPa	0.15 MPa	
cati	Min. operating pressure	Double	0.1 MPa	0.1 MPa	
ecifi	pressure	3 position	0.1 MPa	0.2 MPa	
Valve specifications	Ambient and fluid	d temperature	-10 to	50°C <sup>(1)</sup>	
alve	Lubrication		Not re	quired	
Š	Manual override		Push type/Locking type (Tool required, Manual type) Option		
	Impact/Vibration	resistance (2)	150/30 m/s <sup>2</sup>		
	Enclosure		Dust tight		
	Coil rated voltage	Э	12, 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)		
	Allowable voltage	e fluctuation	±10% of rated voltage		
	Coil insulation typ	ре	Class B or equivalent		
O		24 VDC	1 W DC (42 mA), 1.5 W DC (	63 mA) <sup>(3)</sup> , 0.5 W DC (21 mA) <sup>(4)</sup>	
Solenoid		12 VDC	1 W DC (83 mA), 1.5 W DC (1	25 mA) <sup>(3)</sup> , 0.5 W DC (42 mA) <sup>(4)</sup>	
Sole	Power consumption	100 VAC	Inrush 0.5 VA (5 mA),	Holding 0.5 VA (5 mA)	
	(Current)	110 VAC	Inrush 0.55 VA (5 mA),	Holding 0.55 VA (5 mA)	
		200 VAC	Inrush 1.0 VA (5 mA),	Holding 1.0 VA (5 mA)	
		220 VAC	Inrush 1.1 VA (5 mA), Holding 1.1 VA (5 mA)		

Note 1) Use dry air to prevent condensation when operating at low temperatures.

Note 2) Impact resistance ··· No malfunction occurred when it is tested with a drop tester in the axial

--- No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance ··· No malfunction occurred in a one-sweep test between 45 and 2000 Hz.

Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature.

(Values at the initial period)

Note 3) Values for high pressure type (1.5 W) Note 4) Values for low wattage type (0.5 W)



SQ

VQ0


VQ4

VQ5

**VQZ** 

VQD

#### **How to Order Valves**




5

6


24 VDC

**12 VDC** 


#### Wiring Specifications



#### **Dimensions**




2 position double: VQ025 1



<>: AC

#### 3 position exhaust center: VQ0351



<>: AC

SQ

VQ0

VQ4


VQ5

VQZ

VQD

# Series VQ Construction Main Parts, Replacement Parts

#### Construction: VQ1000/Plug-in Unit





#### **Component Parts**

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

#### **Replacement Parts**

_				
	4	Pilot valve assembly	VQ111 (H)1 -1 Voltage1 to 6	Single
	(5)		Note)	






#### **Component Parts**

No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool valve	Aluminum/HNBR	
3	Piston	Resin	

#### **Replacement Parts**


4	Pilot valve assembly	VQ111 (H)1 -1 Voltage1 to 6	Single
(5)	Pilot valve assembly	VQ131 <sup>(H)</sup> <sub>(Y)</sub> -\( -1\) Voltage1 to 6	Double/3 position





## Construction Main Parts, Replacement Parts Series VQ

#### Construction: VQ2000/Plug-in Unit





#### **Component Parts**

	•		
No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

#### **Replacement Parts**

4	Pilot valve assembly	VQ111 <sup>(H)</sup> <sub>(Y)</sub> 1 Voltage1 to 6	Single
(5)		Note)	






#### **Component Parts**

	•		
No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool valve	Aluminum/HNBR	
(3)	Piston	Resin	

#### **Replacement Parts**


4	Pilot valve assembly	VQ111 <sup>(H)</sup> <sub>(Y)</sub>	Single
(5)	Pilot valve assembly	VQ131 <sup>(H)</sup>	Double/3 position








#### Construction: VQ0000/Plug Lead Unit


#### Metal seal















#### **Component Parts**


No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	


#### **Replacement Parts**


	4	Pilot valve assembly	VQ110 (H) M (Y) - Voltage1 to 6	
--	---	----------------------	---------------------------------	--





#### Rubber seal type















#### **Component Parts**

No.	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool valve	Aluminum/HNBR	
3	Piston	Resin	


#### **Replacement Parts**

▼ voltage i to 6	4	Pilot valve assembly	VQ110 (H) M (Y) - Voltage1 to 6	
------------------	---	----------------------	---------------------------------	--



## Construction Main Parts, Replacement Parts Series VQ

#### Construction: VQ1000/Plug Lead Unit




#### **Component Parts**


	-		
No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool/Sleeve	Stainless steel	
(3)	Piston	Resin	

#### **Replacement Parts**

4	Pilot valve assembly	VQ111 <sup>(H)</sup> <sub>(Y)</sub> 1 Voltage1 to 6	Single
(5)	Pilot valve assembly	VQ131 <sup>(H)</sup> <sub>(Y)</sub> 1 Voltage1 to 6	Double/3 position



#### Rubber seal type



VQC

SQ

VQ0

VQ4

VQ5

VQZ

VQD

VQ1311 (A)(B)

VQ1311 (A)(B)

VQ1411 (A)(B)

VQ1511 (A)(B)

VQ1511 (A)(B)

VQ1511 (A)(B)

#### **Component Parts**

	=		
No.	Description	Material	Note
1	Body	Zinc die-casted	
2	Spool valve	Aluminum/HNBR	
(3)	Piston	Resin	

#### **Replacement Parts**

4	Pilot valve assembly	VQ111 <sup>(H)</sup> <sub>(Y)</sub> 1 Voltage1 to 6	Single
(5)	Pilot valve assembly	VQ131 (H)1 -1 Voltage1 to 6	Double/3 position


Note) (H): 1.5 W, (Y): 0.5 W



## **Exploded View of Manifold**

#### Exploded view: VQ1000/Plug-in Unit

(F, P, J, L, Skit)



#### <Housing Assembly and SI Unit> Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
	(SA kit)	EX320-S001(-XP) (2)	General type SI unit (Series EX300)
	(SB kit)	EX120-SMB1(-XP) (2)	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corporation)
	(SC kit)	EX120-STA1(-XP) (2)	SI unit for SYSBUS Wire System (OMRON Corporation)
	(SD kit)	EX120-SSH1(-XP) (2)	SI unit for Satellite I/O Link System (SHARP Corporation)
	(SE kit)	EX120-SPA1	SI unit for MEWNET-F System (Matsushita Electric Works, Ltd.)
	(SF1kit)	EX120-SUW1(-XP) (2)	SI unit for 16 point Uni-wire System (NKE Corporation)
	(SG kit)	EX120-SAB1(-XP) (2)	SI unit for Allen Bradley Remote I/O (RIO) System (Rockwell Automation, Inc.)
1	(SH kit)	EX120-SUH1(-XP) (2)	SI unit for 16 point Uni-wire H System (NKE Corporation)
	(SJ1 kit)	EX120-SSL1(-XP) (2)	16 point S-LINK System (SUNX Corporation)
	(SJ2 kit)	EX120-SSL2(-XP) (2)	8 point S-LINK System (SUNX Corporation)
	(SK kit)	EX120-SFU1(-XP) (2)	T-LINK Mini System (Fuji Electric Co.,Ltd.)
	(SQ kit)	EX120-SDN1	DeviceNet, CompoBus/D (OMRON Corporation)
	(SR1 kit)	EX120-SCS1(-XP) (2)	OMRON Corporation: CompoBus/S (16 output points)
	(SR2 kit)	EX120-SCS2(-XP) (2)	OMRON Corporation: CompoBus/S (8 output points)
	(SV kit)	EX120-SMJ1(-XP) (2)	Mitsubishi Electric Corporation: CC-LINK System
(2)	P s kit	AXT100-1-P s □ (1)	Flat cable housing assembly □ = Number of pins: 26, 20, 16, 10
	J ∜ kit	AXT100-1-J §20 (1)	Flat cable housing assembly
3	F s kit	AXT100-1-F ⊌ □ (1)	D-sub connector housing assembly □ = Number of pins: 25, 15

Note 1) Top (vertical) entry connector for FU, PU and JU while side (horizontal) entry connector for FS, JS and PS. Note 2) Enter suffix "-XP" at the end of the part number for dust proof type SI unit.

#### <U Side End Plate Assembly>

6 U side end plate assembly no. (For F, P, J, S kit)

VVQ1000-2A-1-

	Nil	Common exhaust type
	R	External pilot
_	S	Built-in silencer, direct exhaust
$\bigcirc$	Note)	The 14's fitting assembly is
		included.

**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ

VQD

#### <D Side End Plate Assembly>

45 D side end plate assembly no.

VVQ1000-3A-1
Electrical entry

F For F kit
P For P kit
J For J kit
L For L kit

For S kit

P2

P3

L0□

**L1**□

L2□

= <b>6</b>		
Nil	Common exhaust type	
R (1)	External pilot	
S (1)	Built-in silencer, direct exhaust	

Note 1) When both options are specified, indicate as RS.

Note 2) The housing assembly and SI unit of F/P/S kit are not included.

Separately place an order for 1, 2, and 3.

#### <Manifold Block Assembly>

(8) Manifold block assembly no. Tie-rod (2 pcs.) and lead wire assembly VVQ1000-1ATie-rod (2 pcs.) and lead wire assembly for extensions are attached

F1 F kit for 2 to 12 stations/Double wiring
F2 F kit for 2 to 24 stations/Single wiring
P1 P, J, S kit for 2 to 12 stations/Double wiring
P1 P, J, S kit for 2 to 12 stations/Double wiring

Option

<Replacement Parts for Manifold Block>
Replacement Parts

P, J, S kit for 13 to 24 stations/Double wiring

P, J, S kit for 2 to 24 stations/Single wiring

L0 kit □Stations (1 to 8)

L1 kit □Stations (1 to 8)

L2 kit □Stations (1 to 8)

No.	Part no.	Description	Material	Number	
9	VVQ1000-80A-1	Gasket	NBR	12	
10	VVQ1000-80A-2	Packing	NBR	12	
11)	VVQ1000-80A-3	Clamp screw	Carbon steel	12	
12	VVQ1000-80A-4	Clip	Stainless steel	12	
Note) A set of parts containing 12 pcs. each is enclosed.					

① U side end plate assembly no. (For L kit) VVQ1000-2A-1-L

#### <Fitting Assembly>

13 Fitting assembly part no. (For cylinder port)

VVQ1000-50A
Port size

C3 Applicable tubing ø3.2

C4 Applicable tubing ø4

C6 Applicable tubing ø6

M5 M5 thread

14 Fitting assembly part no. (For P, R port)


VVQ1000-51A-<u>C8</u>

Applicable tubing ø8

Note) Purchasing order is available in units of 10 pieces.

#### Exploded View: VQ2000/Plug-in Unit

(F, P, J, L, G, S kit)



#### <Housing Assembly and SI Unit> Housing assembly and SI unit no.

No.	Manifold	Part no.	Description	
	(SA kit)	EX320-S001(-XP)(1) [EX323-S001] (2)	General type SI unit (Series EX300)	
	(SB kit)	EX120-SMB1(-XP)(1) [EX123-SMB1] (2)	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric)	
	(SBB kit)	[EX124-SMB1] (3)	SI unit for MELSECNET/MINI-S3 Data Link System (2 power supply lines) (Mitsubishi Electric Corp.)	
	(SC kit)	EX120-STA1(-XP)(1) [EX123-STA1] (2)	SI unit for SYSBUS Wire System (OMRON Corporation)	
	(SD kit)	EX120-SSH1(-XP) <sup>(1)</sup> [EX123-SSH1] <sup>(2)</sup>	SI unit for Satellite I/O Link System (SHARP Corporation)	
1)	(SE kit)	EX120-SPA1	SI unit for MEWNET-F System (Matsushita Electric Works, Ltd.)	VQC
	(SF1kit)	EX120-SUW1(-XP) <sup>(1)</sup> [EX123-SUW1] <sup>(2)</sup>	SI unit for 16 point Uni-wire System (NKE Corporation)	
	(SG kit)	EX120-SAB1	SI unit for Allen Bradley Remote I/O (RIO) System (Rockwell Automation, Inc.)	SQ
	(SH kit)	EX120-SUH1(-XP)(1) [EX123-SUH1] (2)	SI unit for 16 point Uni-wire H System (NKE Corporation)	U
	(SJ1 kit)	EX120-SSL1(-XP)(1) [EX123-SSL1] (2)	16 point S-LINK System (SUNX Corporation)	VQ0
	(SJ2 kit)	EX120-SSL2(-XP) <sup>(1)</sup> [EX123-SSL2] <sup>(2)</sup>	8 point S-LINK System (SUNX Corporation)	VQU
	(SK kit)	EX120-SFU1(-XP)(1) [EX123-SFU1] (2)	T-LINK Mini System (Fuji Electric Co., Ltd.)	1.0.1
	(SQ kit)	EX120-SDN1 [EX124-SDN1] (2)	SI unit for DeviceNet, CompoBus/D (OMRON Corporation)	VQ4
	(SR1 kit)	EX120-SCS1(-XP)(1) [EX124-SCS1] (2)	SI unit for 16 point Compo Bus/S System (OMRON)	
	(SR2 kit)	EX120-SCS2(-XP)(1) [EX124-SCS2] (2)	SI unit for 8 point Compo Bus/S System (OMRON)	VQ5
	(SV kit)	EX120-SMJ1(-XP)(1) [EX124-SMJ1] (2)	SI unit for CC-LINK System (2 power supply systems) (Mitsubishi Electric Corporation)	
( <u>2</u> )	P∜kit	AXT100-1-P <sub>S</sub> <sup>U</sup> (4)	Flat ribbon cable housing assembly □ = Number of pins: 26, 20, 16, 10	VQZ
(2)	J∜kit	AXT100-1-J <sup>U</sup> <sub>S</sub> □ <sup>(4)</sup>	Flat ribbon cable housing assembly	VQZ
3	G kit	AXT100-1-GU20	Flat ribbon cable housing assembly with terminal block	VOD
4	F∜kit	AXT100-1-F <sub>S</sub> <sup>U</sup> (4)	D-sub connector housing assembly □ = Number of pins: 25, 15	VQD

Note 1) Suffix "-XP" for dust-protected type SI unit. Note 2) Dusttight/Low jetproof type (IP65)

Note 3) SBB kit is usable only for dust tight/low jetproof type (IP65).

Note 4) Top entry connector for FU and PU while side entry connector for FS and PS.

#### <D Side End Plate Assembly>

56D side end plate assembly no.

VVQ2000-3A-1- □- □ Electrical entry •

F	For F kit
Р	For P kit
J	For J kit
L	For L kit
G	For G kit
S	For S kit

Nil	Common EXH
R (1)	External pilot
S (1)	Built-in silencer, direct exhaust


Note 1) When both options are specified, indicate as RS.

Note 2) The housing assembly and SI unit of F/P/J/G/S kit are not included.

Note 3) Separately place an order for ①, ②, ③, and ④. For Dusttight/Low jetproof type (IP65), please consult with

#### <U Side End Plate Assembly>

① U side end plate assembly no. (For F/P/G/S kits)



Option



Port size

C4 One-touch fitting for ø4

C6 One-touch fitting for ø6

C8 One-touch fitting for ø8

Note 1) The 15's fitting assembly is included.

Note 2) The housing assembly and SI unit of F/P/J/G/S kit are not included.


Separately place an order for ①, ②, ③, and ④. Note 3) For Dusttight/Low jetproof type (IP65), please consult with

8 U side end plate assembly no. (For L kit)

#### VVQ2000-2A-1-L

<Manifold Block Assembly> Tie-rod (2 pcs.) and lead wire assembly for extensions are attached

Manifold block assembly no.



#### <Replacement Parts for Manifold Block> **Replacement Parts**

No.	Part no.	Description	Material	Number
10	VVQ2000-80A-1	Gasket	HNBR	12
11)	VVQ2000-80A-2	Packing	HNBR	12
12	VVQ2000-80A-3	Clamp screw	Carbon steel	12
13	VVQ2000-80A-4	Clip	Stainless steel	12

#### Enclosure

Nil Dusttight		
W	Dusttight/Low jetproof type (IP65)	
Note) F, P, J, G kits are available with "Nil" only		
M kit is available with [W] only.		
S, L, T kits are selectable, depending		
ur	on the manifold type.	

#### <Fitting Assembly>

VVQ1000-51A-

(4) Fitting assembly part no. (For cylinder port)

Port size C4 Applicable tubing ø4 Note) Purchasing order is available C6 Applicable tubing ø6 in units of 10 pieces. C8 Applicable tubing ø8

(5) Fitting assembly part no. (For P, R ports)

VVQ2000-51A-C10


 Applicable tubing ø10 Note) Purchasing order is available Note) A set of parts containing in units of 10 pieces. 12 pcs. each is enclosed.



#### **Exploded View: VQ0000/Plug Lead Unit**

(F, P, C, S kit)

\* For how to increase the stations, refer to the instruction manual. Housing assembly and SI unit Note 3) Tie-rod U side end block assembly Manifold block assembly D side end block assembly Note 2) Connector assembly Skit S Note 1) Note 2) Connector assembly Pĸ∺ 7 The drawing shows PU. (Top entry connector) Connector assembly FĶ The drawing shows FU. (Top entry connector) Note 2) Connector assemb 至



Note 3) A housing assembly is not used for a C kit.

Note 4) A DIN rail clamping bracket is attached to each.

#### <Housing Assembly and SI Unit>

Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
	(SA kit)	EX330-S001	General type SI unit (Series EX300)
	(SB kit)	EX130-SMB1	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corp.)
(1) (1)	(SC kit)	EX130-STA1	SI unit for SYSBUS Wire System (OMRON Corporation)
	(SD kit)	EX130-SSH1	SI unit for Satellite I/O Link System (SHARP Corporation)
	(SF1 kit)	EX130-SUW1	16 point Uni-wire System (NKE Corporation)
	(SH kit)	EX130-SUH1	SI unit for 16 point Uni-wire H System (NKE Corporation)
2	P <sub>S</sub> <sup>U</sup> kit	AXT100-2-P <sup>U</sup> <sub>S</sub> □ <sup>(2)</sup>	Flat ribbon cable housing assembly I = Number of pins: 26, 20, 16, 10
3	F <sup>U</sup> <sub>S</sub> kit	AXT100-2-F <sup>U</sup> <sub>S</sub> □ <sup>(2)</sup>	D-sub connector housing assembly I = Number of pins: 25, 15
4	T kit	AXT100-2-TB1 (4)	Terminal block assembly (8 terminals)
(5)	T kit	AXT100-2-TB2 (4)	Terminal block assembly (8 terminals)

Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PS20) of ① SI unit and ② P kit (20 pins). Place an order for AXT100-2-PS20 separately.


Note 2) Top/vertical entry connector for FU and PU while side (horizontal) entry connector for FS and PS.

Note 3) Since no connector assembly is included, order it separately. (Refer to page 2-4-216.)

Note 4) In the case of standard specifications and double wring, 4 is for 1 to 5 stations and t is for 5 to 8 stations.

#### <D Side End Plate Assembly>

6 D side end plate assembly no.



Note) The 12's fitting assembly is included.

#### <U Side End Plate Assembly>

7 U side end plate assembly no.






Common exhaust type Nil Built-in silencer, direct exhaust

#### <Manifold Block Assembly>

8 manifold block assembly no.





#### <Replacement Parts for Manifold Block> **Replaceable Parts**

No.	Part no.	Description	Material	Number
9	VVQ0000-80A-5-2	Seal	HNBR	12
10	VVQ0000-80A-5-4	Clip	HNBR	12

Note) A set of parts containing 12 pcs. each is enclosed.

#### <Fitting Assembly>





#### <Tie-rod Bolt>

13 Tie-rod bolt







**VQC** 

SQ

VQ0

VQ4

VQ5

VQZ


VQD

#### **Exploded View: VQ1000/Plug Lead Unit**

Housing assembly and SI unit D side end block assembly SUP/EXH block assembly

(F, P, T, S kit)

 $\ast$  For how to increase the stations, refer to the instruction manual. Manifold block assembly SUP/EXH block assembly U side end block assembly





Note 1) S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PU20) of ① SI unit and ② P kit (20 pins).

Note 2) Since no connector assembly is included, order it separately. (Refer to page 2-4-216.)

Note 3) A housing assembly is not used for a C kit.

Note 4) A DIN rail clamping bracket is attached to each.

#### <Housing Assembly and SI Unit> Housing assembly and SI unit no.

No.	Manifold	Part no.	Description
140.	(SA kit)	EX321-S001(-XP) (5)	General type SI unit (Series EX300)
	(SB kit)	EX121-SMB1(-XP) (5)	SI unit for MELSECNET/MINI-S3 Data Link System (Mitsubishi Electric Corporation)
	(SC kit)	EX121-STA1(-XP) (5)	SI unit for SYSBUS Wire System (OMRON Corporation)
	(SD kit)	EX121-SSH1(-XP) (5)	SI unit for Satellite I/O Link System (SHARP Corpoation)
	(SE kit)	EX121-SPA1	SI unit for MEWNET-F System (Matsushita Electric Works, Ltd.)
	(SF1kit)	EX121-SUW1(-XP) (5)	SI unit for 16 point Uni-wire System (NKE Corporation)
	(SG kit)	EX121-SAB1(-XP) (5)	SI unit for Allen Bradley Remote I/O (RIO) System (Rockwell Automation, Inc.)
1	(SH kit)	EX120-SUH1(-XP) (5)	SI unit for 16 point Uni-wire H System (NKE Corporation)
	(SJ1 kit)	EX121-SSL1(-XP) (5)	16 point S-LINK System (SUNX Corporation)
	(SJ2 kit)	EX121-SSL2(-XP) (5)	8 point S-LINK System (SUNX Corporation)
	(SK kit)	EX121-SFU1(-XP) (5)	T-LINK Mini System (Fuji Electric Co., Ltd.)
	(SQ kit)	EX121-SDN1	DeviceNet, CompoBus/D (OMRON Corporation)
	(SR1 kit)	EX121-SCS1(-XP) (5)	OMRON Corporation: CompoBus/S System (16 output points)
	(SR2 kit)	EX121-SCS2(-XP) (5)	OMRON Corporation: CompoBus/S System (8 output points)
	(SV kit)	EX120-SMJ1(-XP) (5)	Mitsubishi Electric Corporation: CC-LINK System
2	P s kit	AXT100-2-P s □ (2)	Flat ribbon cable housing assembly □ = Number of pins: 26, 20, 16, 10
3	F s kit	AXT100-2-F <sup>U</sup> <sub>8</sub> □ <sup>(2)</sup>	D-sub connector housing assembly □ = Number of pins: 25, 15
4	T kit	AXT100-2-TB1 (4)	Terminal block assembly (8 terminals)
5	T kit	AXT100-2-TB2 (4)	Terminal block assembly (8 terminals)

Note 1) A S kit is composed of a flat ribbon cable housing assembly (AXT100-2-PS20) of ① SI unit and ② P kit (20 pins).

Place an order for AXT100-2-PU20 separately.

Note 2) Top/vertical entry connector for FU and PU while side (horizontal) entry connector for FS and PS.

Note 3) Since no connector assembly is included, order it separately. (Refer to page 2-4-216.)

Note 4) In the case of standard specifications and double wring, 4 is for 1 to 4 stations and 5 is for 5 to 8 stations.

Note 5) Suffix "-XP" for dust-protected type SI unit.

#### <D Side End Plate Assembly>

6 D side end plate assembly no. VVQ1000-3A-2

#### <U Side End Plate Assembly>

7 U side end plate assembly no.

VVQ1000-2A-2

#### <SUP/EXH block Assembly>

8 SUP/EXH block assembly no.

VVQ1000-PR-2-C8-□ Option •

Nil	Common exhaust type	
S	Built-in silencer, direct exhaust	
( <u>)</u> N	lote) The (5)'s fitting assembly is included	J.

With One-touch fitting for ø6 M5 thread

#### <Replacement Parts for Manifold Block> **Replaceable Parts**

No.	Part no.	Description	Material	Number
10	VVQ1000-80A-1	Gasket	HNBR	12
11)	VVQ1000-80A-2-2	O-ring	HNBR	12
12	VVQ1000-80A-3	Clamp screw	Carbon steel	12
13	VVQ1000-80A-2-4	Clip	Stainless steel	12

Note) A set of parts containing 12 pcs. each is enclosed.

#### <Fitting Assembly>

(4) Fitting assembly part no. (For cylinder port)

VVQ1000-50A-□

Note) Purchasing order is available in units of 10 pieces.

• Po	Port size								
<u>C3</u>	Applicable tubing ø3.2								
C4	Applicable tubing ø4								
C6	Applicable tubing ø6								
M5	With M5 thread								

#### <Manifold Block Assembly>

(8) Manifold block assembly no. VVQ1000-1A-2-□

> Port size C3 With One-touch fitting for ø3.2 With One-touch fitting for ø4

15 Fitting assembly part no. (For P, R port)

VVQ1000-51A-C8 Applicable tubing ø8

Note) Purchasing order is available in units of 10 pieces.

VQC SQ

VQ0

VQ4

VQ5

VQZ

VQD


#### 5 Port Solenoid Valve Metal Seal/Rubber Seal Base Mounted

## Series VQ4000

#### **Space-saving profile**

Clean space-saving design with all pilot valves concentrated to one side with no protrusions in any direction

Space-saving — 40% less
Capacity-saving — 50% less
(In-house comparison)



VQC

SQ

VQ0

VQ4

VQ5

VQZ

VQD

## Compact with large flow capacity (Ideal for driving cylinders up to Ø140)

#### Built-in One-touch fittings for easier piping

## Outstanding response times and long service life

(Metal seal with indicator light/surge suppressor)

VQ4100 17 mS
(Single)

VQ4200 12 mS
(Double)

Accuracy ±3 mS


(Metal seal with indicator light/surge

100 million cycles

\* According to
SMC life test
conditions

## A variety of common wiring methods are standardized.

<Plug-in type>



## **Enclosure IP65 compliant Dusttight/Low jetproof type**

#### **Cylinder Speed Chart**

Use as a guide for selection.

Please confirm the actual conditions with SMC Sizing

							P	rogram.				
						Bore	e size					
Series	Average speed (mm/s)         Series MB/CA1         Series CS           Load rate: 50%         Load rate: 50%         Stroke 500 mm         Stroke 100			Pressure 0.5 MPa oad rate: 50%				e 0.5 MPa e: 50%	a			
		ø40	ø50	ø60	ø80	ø100	ø125	ø140	ø160	ø180	ø200	
VQ4100-□-03 VQ4101-□-03	1100 1000 900 800 700 600 500 400 300 200 100									, ·	licular, actuation	

\* It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open.


\* The average velocity of the cylinder is what the stroke is divided by the total stroke time.


\* Load factor:((Load weight x 9.8)/Theoretical force) x 100%

**System Components** 

Speed controller	Silencer	SPG (Steel pipe) dia. x Length
AS420-03	AN300-03	10A x 1 m

#### Individual wiring type







#### 

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.


#### **Manual Override Operation**

#### $oldsymbol{\Lambda}$ Warning

Since connected equipment will be actuated when the manual override is operated, first confirm that conditions are safe.

Non-locking push type (tool required) is standard. As an option, slotted locking type (tool required) is available.


#### Push type (Tool required)




Push down on the manual override button with a small screwdriver until it stops.

Release the screwdriver and the manual override will return.

#### Locking type (Tool requied) <Option>



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.



#### **Mounting of Valves**

#### **⚠** Caution

After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.

# Proper tightening torque 0.8 to 1.2 Mounting screw (M3)

#### **Changing the One-touch Fittings**


The built-in One-touch fittings on the cylinder port side are easily replaceable because of the cassette type. Clip prevents the fittings to come off. After removing the corresponding valve and take out the clip with a screwdriver, etc., then replace the fittings. About mounting the fittings, after inserting the fitting until it stops, then put the clip into the prescribed position.

#### **Lead Wire Connection**

#### **⚠** Caution

#### Plug-in sub-plate (With terminal block)

 If the junction cover (1) of the sub-plate is removed, you can see the plug-in type terminal block (2) mounted inside the subplate.



 The terminal block is marked as follows. Connect wiring to each of the power supply terminals.


Terminal block marking	А	СОМ	В	Ť
VQ410 <sub>1</sub> 0	A side	СОМ	_	_
VQ4201	A side	СОМ	B side	_
VQ4 <sub>5</sub> <sup>3</sup> 0 <sub>1</sub> 0	A side	СОМ	B side	_

Note 1) There is no polarity. It can also be used as -COM. Note 2) Double wiring is used on sub-plate VQ410  $^{\circ}_{1}$ .

• Applicable terminal 1.25-3S, 1.25Y-3, 1.25Y-3N, 1.25Y-3.5

#### Plug lead: Grommet type

Make connections to each corresponding wire.



Sing	gie solellolu	Double solellolu
	Single solenoid	Double solenoid
Standard	Black: A side solenoid (-) Red: COM (+)	Black: A side solenoid (-) Red: COM (+) White: B side solenoid (-)
Enclosure IP65 compliant	Green: (Not used fo	Black: A side solenoid (–)  Red: COM (+)  White: B side solenoid (–) (Not used for single solenoid)  r single or double.)

Note) There is no polarity. It can also be used as -COM.



One-touch fittings

#### **⚠ Precautions 2**

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to pages 2-9-2.

#### **Installation and Removal of Light Cover**

#### **⚠** Caution


#### Installation/Removal of light cover

#### Removal

Open the cover by inserting a small flat head screwdriver into the slot on the side of the pilot assembly (see drawing below), lift the cover out about 1 mm and then pull off. If it is pulled off at an angle, the pilot valve may be damaged or the protective O-ring may be scratched.

#### Installation

Place the cover straight over the pilot assembly so that the pilot valve is not touched, and push it until the cover hook locks without twisting the protective O-ring. (When pushed in, the hook opens and locks automatically.)



#### Replacement of Pilot Valve

#### **⚠** Caution

#### Removal

 Remove the mounting screw that holds the pilot valve using a small screwdriver.


When equipped with light, remove the light circuit board which is installed on the pilot valve by pulling it straight off the connector pins.

#### Installation

 Insert the light circuit board straight onto the connector pins following the guide.

If it is pushed in forcibly without following the guide, there is a danger of possibly bending the board contacts.

After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.




#### Proper tightening torque (N·m)

#### 0.1 to 0.13

Note) The mounting of pilot valves is not directional with respect to the A and B sides.

However, the light circuit boards' A side is orange and the B side is green. It must be mounted on the pilot valve in accordance with the mounting indicators. The light will not go on if the mounting is reversed.



#### Light Circuit Board Part No.

SOL.A	VQZ100-47-A
SOL.B	VQZ100-47-B

Note) It can be used with all voltages.


#### For Plug Lead Type

#### Attaching and detaching connectors

To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.

To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.

Note) Do not pull on the lead wires with excessive force. This can cause faulty and/or broken contacts.



VQC

SQ

VQ0

VQ4


VQ5

VQZ

VQD


#### **Internal Wiring Specifications**

#### **⚠** Caution



Light circuit assembly (Orange)

DC: Single




A side light
circuit assembly
(Orange)


Com ()

Com ()

Com ()

B side light circuit assembly (Green)





#### **Enclosure IP65**

#### **∕** Caution

Wires, cables, connectors, etc. used for models conforming to IP65 should also have enclosures equivalent to or stricter rating than IP65.

#### **How to Calculate the Flow Rate**

For obtaining the flow rate, refer to pages 2-1-8 to 2-1-11.



## Plug-in/Plug Lead Single Unit


#### Model


					size			Flow cha	racteristics			Res	sponse time (	ms)	
Series	C	Configuration	Mode	el	<b>+</b>	1 →	4/2 (P →	A/B)	4/2 → 5	$4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{EA/EB)}$		Standard	Low wattage	AC	Weight (kg)
					Pol	C [dm³/(s•bar)]	b	Cv	C [dm³/(s•bar)]	b	Cv	1 W	0.5 W	AC	(1.9)
	اے	Single	Metal seal	VQ4150		6.2	0.19	1.5	6.9	0.17	1.7	20 or less	22 or less	22 or less	0.23
	2 position	Sirigle	Rubber seal	VQ41 <sub>5</sub> 1		7.2	0.43	2.1	7.3	0.38	2.0	25 or less	27 or less	27 or less	(0.29)
	sod	Double	Metal seal	VQ42 <sub>5</sub> 0		6.2	0.19	1.5	6.9	0.17	1.7	12 or less	14 or less	14 or less	0.26
		Double	Rubber seal	VQ42 <sub>5</sub> 1		7.2	0.43	2.1	7.3	0.38	2.0	15 or less	17 or less	17 or less	(0.32)
		Closed	Metal seal	VQ43 <sub>5</sub> 0	- 1	5.9	0.23	1.5	6.3	0.18	1.6	45 or less	47 or less	47 or less	0.28
VQ4000		center	Rubber seal	VQ43 <sub>5</sub> 1		7.0	0.34	1.9	6.4	0.42	1.9	50 or less	52 or less	52 or less	(0.34)
VQ4000		Exhaust	Metal seal	VQ44 <sub>5</sub> 0	nc 3/0	6.2	0.18	1.5	6.9	0.17	1.7	45 or less	47 or less	47 or less	0.28
	tion	center	Rubber seal	VQ44 <sub>5</sub> 1		7.0	0.38	1.9	7.3	0.38	2.0	50 or less	52 or less	52 or less	(0.34)
	3 position	Pressure	Metal seal	VQ45 <sub>5</sub> 0		6.2	0.18	1.6	6.4	0.18	1.6	45 or less	47 or less	47 or less	0.28
	က	center	Rubber seal	VQ45 <sub>5</sub> 1		7.0	0.38	1.9	7.1	0.38	2.0	50 or less	52 or less	52 or less	(0.34)
		Double	Metal seal	VQ46 <sub>5</sub> 0		2.7	_	_	3.7	_	_	55 or less	57 or les	57 or les	0.50 (0.56)
			Rubber seal	VQ46 <sub>5</sub> 1		2.8	_	_	3.9	_	_	62 or less	64 or less	64 or less	





#### JIS Symbol






Note 2) Based on JIS B 8375-1981 Supply pressure: 0.5 MPa, with indicator light and surge voltage suppressor, clean air. This will change depending on pressure and air quality.) The value when ON for the double type.

Note 3) Values inside () indicate the weight of plug lead units.

Table: Without sub-plate, With sub-plate: Add 0.41 kg for plug-in type, 0.30 kg for plug lead type.

#### Standard Specifications

	Valve construction		Metal seal	Rubber seal		
	Fluid		Air/Inert gas	Air/Inert gas		
	Maximum operating	pressure <sup>(3)</sup>	1.0 MPa	(0.7 MPa)		
ons		Single	0.15 MPa	0.20 MPa		
cati	Min. operating pressure	Double	0.15 MPa	0.15 MPa		
ecifi	procedio	3 position	0.15 MPa	0.20 MPa		
Valve specifications	Ambient and fluid ter	nperature	-10 to 50°C <sup>(1)</sup>	−5 to 50°C <sup>(1)</sup>		
/alv	Lubrication		Not rec	quired		
	Manual override		Push type/Locking type (Tool required) Option			
	Shock/Vibration resis	stance	150/30 m/s <sup>2</sup>			
	Enclosure		Dust tight (IP65 compatible)			
	Coil rated voltage		12, 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)			
ons	Allowable voltage flu	ctuation	±10% of rated voltage			
cati	Coil insulation type		Class B or equivalent			
ecifi		24 VDC	1 W DC (42 mA), 0	.5 W DC (21 mA)		
ds p		12 VDC	1 W DC (83 mA), 0	.5 W DC (42 mA)		
jor	Power consumption	100 VAC	Inrush 1.2 VA (12 mA), F	Holding 1.2 VA (12 mA)		
Solenoid specifications	(Current)	110 VAC	Inrush 1.3 VA (11.7 mA), F	Holding 1.3 VA (11.7 mA)		
		200 VAC	Inrush 2.4 VA (12 mA), F	Holding 2.4 VA (12 mA)		
		220 VAC	Inrush 2.6 VA (11.7 mA), Holding 2.6 VA (11.7			



e: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz.

Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature.

(Values at the initial period)

Note 3) Values inside ( ) denote the low wattage (0.5 W) specifications.




VQ<sub>0</sub>

VQ5

**VQZ** 

**VQD** 


#### **How to Order Valves**




#### **Plug-in Type**

#### **Conduit terminal**

#### 2 position single: VQ410<sup>0</sup><sub>1</sub>-□




#### **Bottom ported drawing**




2 position double: VQ420 1-

3 position closed center: VQ430 <sup>0</sup><sub>1</sub>-□ 3 position exhaust center: VQ440 <sup>0</sup><sub>1</sub>-□

3 position pressure center: VQ450 ¹-□



#### 3 position double check: VQ460 0-□



: 3 position (): Rc 3/8

VQ0

VQ4

VQ5


**VQZ** 

**VQD** 


#### **Plug Lead Type**


#### Grommet

2 position single: VQ415 <sup>0</sup><sub>1</sub>-□<sup>G</sup><sub>H</sub>




2 position double: VQ425 1-□G 3 position closed center: VQ435  $^0_1$ - $\square\,^G_H$ 3 position exhaust center: VQ445 1-□ GH 3 position pressure center: VQ455 <sup>0</sup><sub>1</sub>-□ <sup>G</sup><sub>H</sub>






#### 3 position double check: VQ465 1



# Series VQ4000 Base Mounted Plug-in Unit



G Rockwell Automation: Allen Bradley Remote I/O (RIO) System

SQ

VQ0

VQ4

VQ5

**VQZ** 

VQD

#### Plug-in Unit Series VQ4000

#### **Manifold Specifications**

				Porting specification	ations	Maximum	Applicable	
Series	Base model	Type of connection	4(A), 2(B)	10110120		applicable	solenoid	5 station weight (kg)
			port location	1(P), 5(R1), 3(R2)	4(A), 2(B)	stations	valve	(kg)
VQ4000	VV5Q41-□□□	■ F kit-D-sub connector ■ T kit-Terminal block box ■ L kit-Lead wire ■ S kit-Serial transmission		Ontion	C8 (For Ø8) C10 (For Ø10) C12 (For Ø12) Rc 1/4 Rc 3/8	F, T kit 12 stations L kit 16 stations	VQ4□00 VQ4□01	2.24 • L kit • Except solenoid valve weight
			Bottom		Rc 1/4	S kit 10 stations		

Note) For details about inch-size One-touch fittings and other thread standards, refer to page 2-5-39.

#### Flow Characteristics at the Number of Manifold Stations (Operated individually)


Model	Passage/St	tations	Station 1	Station 5	Station 10	Station 15
		C [dm³/(s·bar)]	5.9	5.9	5.9	5.9
2 position metal seal	$1 \rightarrow 4/2 \ (P \rightarrow A/B)$	b	0.23	0.23	0.23	0.23
VQ4 <sup>1</sup> <sub>2</sub> 00	, ,	Cv	1.5	1.5	1.5	1.5
VQ4 <sub>2</sub> 00	4/2 → 5/3 (A/B → EA/EB)	C [dm³/(s·bar)]	6.2	6.2	6.2	6.2
		b	0.19	0.19	0.19	0.19
	,	Cv	1.5	1.5	1.5	1.5
		C [dm³/(s·bar)]	6.8	6.8	6.8	6.8
	$1 \rightarrow 4/2 (P \rightarrow A/B)$	b	0.31	0.31	0.31	0.31
0	, ,	Cv	1.8	1.8	1.8	1.8
2 position rubber seal		C [dm³/(s·bar)]	7.0	7.0	7.0	7.0
VQ4 <sup>1</sup> <sub>2</sub> 01	4/2 → 5/3 (A/B → EA/EB)	b	0.38	0.38	0.38	0.38
	, , , , , , , , , , , , , , , , , , , ,	Cv	1.9	1.9	1.9	1.9





Note) Port size: Rc 3/8

Blanking plate assembly


#### **Manifold Option**








#### Individual EXH spacer VVQ4000-R-1-02




- Refer to pages 2-5-34 to 2-5-38
- for detailed dimensions of each option. For replacement parts, refer to page 2-5-47.
- Refer to pages 2-5-40 to 2-5-43 for control unit.




Release valve spacer


VVQ4000-24A-1D (1, 2)




SUP stop valve spacer




VVQ4000-37A-1




Double check spacer with residual pressure exhaust VVQ4000-25A-1 (1)




SUP/EXH block plate




Direct exhaust with silencer box



Interface regulator ARBQ4000-00-



For exhaust cleaner mounting [-C <sup>D</sup><sub>U</sub> ]<sup>(1)</sup>



Note 1) Release valve spacer, built-in silencer (direct exhaust), exhaust cleaner mounting and double check spacer for residual pressure exhaust cannot be combined with external pilot.

Note 2) Can be mounted on L kit only. For other kits, order E type control unit. (Refer to pages 2-5-40 to 2-5-43.)



## Kit (D-sub connector kit)

- Simplification and labor savings for wiring work can be achieved by using a D-sub connector for the electrical connection.
- Using connector for flat ribbon cable (25P) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Connector entry can be selected on either the U side or the D side according to the mounting orientation.
- Maximum stations are 18.

#### **Manifold Specifications**

	Porting specifications			
Series	4(A), 2(B) port	Port size		Applicable stations
	location	1(P), 5(R1), 3(R2)	4(A), 2(B)	
VQ4000	Side	Rc 1/2	C 8, 10, 12 Rc 1/4, 3/8	Max. 18 stations
	Bottom		Rc 1/4	

#### **D-Sub Connector Kit (25 pins)**

#### AXT100-DS25-030 050

D-sub connector cable assemblies can be ordered by with manifolds. Refer to How to Order Manifold.

#### Multi-core vinyl cable 0.3 mm<sup>2</sup> x 25C ≅ø10 4 SMC 2-M2.6 x 0.45 Socket side Terminal no.

#### **D-sub Connector Cable** Assembly (Option)

Cable length (L)	Assembly part no.	Note	
1.5 m	AXT100-DS25-015	O-bl- 05	
3 m	AXT100-DS25-030	Cable 25 cores	
5 m	AXT100-DS25-050	7 24700	

\* For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308.

#### Connector manufacturers' example

- Fujitsu, Ltd.
- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.
- Hirose Electric Co., Ltd.

Note) As an option, the maximum number of stations can be increased by special wiring specifications.

For details, refer to page 2-5-11.

#### **Electric** Characteristics

Item	Characteristics
Conductor resistance Ω/km, 20°C	65 or less
Voltage limit VAC, 1 min.	1000
Insulation resistance MΩkm, 20°C	5 or less


Note) The minimum bending radius for D-sub connector cables is 20 mm.

#### **D-sub Connector Cable Assembly Terminal No.**


Cable assembly •

Terminal no.	Lead wire color	Dot marking
1	Black	None
2	Brown	None
3	Red	None
4	Orange	None
5	Yellow	None
6	Pink	None
7	Blue	None
8	Purple	White
9	Gray	Black
10	White	Black
11	White	Red
12	Yellow	Red
13	Orange	Red
14	Yellow	Black
15	Pink	Black
16	Blue	White
17	Purple	None
18	Gray	None
19	Orange	Black
20	Red	White
21	Brown	White
22	Pink	Red
23	Gray	Red
24	Black	White
25	White	None


#### **How to Order Manifold**



#### Electrical wiring specifications



Stations are counted starting from the first station on the D side



#### **Special Wiring Specifications**


Double wiring (connected to SOL. A and SOL. B) is used for the internal wiring of each station regardless of valve and option types. Mixed single and double wiring is available as an option.

Indicate option symbol "-K" in the manifold part number and be sure to specify station positions for single or double wiring on the manifold specification sheet.


#### 2. Wiring specifications

interface is not possible. Note 3) When two or more symbols are specified, indicate them alphabetically. **多SMC** 

Connections begin with the A side solenoid of the first station being connected to terminal no. 1, and continue in the order indicated by the arrows in the drawing without skipping any terminals. Maximum stations are 18.




**D-sub connector** 



#### How to Order Manifold Assembly


Specify the part numbers for valves and options together beneath the manifold base part number.

#### D-sub connector kit with cable (3 m)



Enter in order starting from the first station

on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.



VQ5

**VQC** 

SQ


VQ0

VQ4


**VQZ** 

VQD

# Kit (D-sub connector kit)




#### **Bottom ported drawing**



Dimens	<b>Dimensions</b> Formula L1 = 25n + 63, L2 = 25n + 76										ı + 76	6 n: Station (Maximum standard 18 stations)						
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
L <sub>1</sub>	88	113	138	163	188	213	238	263	288	313	338	363	388	413	438	463	488	513
L2	101	126	151	176	201	226	251	276	301	326	351	376	401	426	451	476	501	526

# Kit (Terminal block box kit)



**IP65** compliant

- Enclosure IP65 compliant
- This type has a small terminal block inside a junction box.
   The provision of a G 3/4 electrical entry allows connection of conduit fittings.
- Maximum stations are 18.
- 2 stations are used for terminal box mounting.


#### **Manifold Specifications**

	Р	orting specific				
Series	4(A), 2(B) port	Port s	size	Applicable stations		
	location	ocation 1(P), 5(R1), 3(R2) 4				
VQ4000	Side	Rc 1/2	C 8, 10, 12 Rc 1/4, 3/8	Max. 18 stations		
	Bottom		Rc 1/4			

#### **Terminal Block Connections**

#### Step 1. How to remove terminal block cover

Loosen the 4 mounting screws (M4) and open the terminal block cover.



#### Step 3. How to attach the terminal block cover


Securely tighten the screws with the torque shown in thetable below, after confirming that the gasket is installed correctly.

Proper tightening torque (N·m)

0.7 to 1.2


Step 2. The diagram on the right shows the terminal block wiring. All stations are provided with double wiring regardless of the valves which are mounted.

Connect each wire to the power supply side, according to the markings provided inside the terminal block.



Applicable terminal 1.25-3S, 1.25Y-3, 1.25Y-3N, 1.25Y-3.5

#### **How to Order Manifold**



SQ


VQ0

VQ4

VQ5


VQZ

VQD



Stations are counted starting from the first station on the D side.

#### Electrical wiring specifications



#### **Special Wiring Specifications**


Double wiring (connected to SOL. A and SOL. B) is used for the internal wiring of each station regardless of valve and option types. The optional specification permits mixture of single and double wiring. However, the maximum number of stations is 16.

#### 1. How to Order


Indicate option symbol "-K" in the manifold part number and be sure to specify station positions for single or double wiring on the manifold specification sheet.

#### 2. Wiring specifications

Connections begin with the A side solenoid of the first station being connected to terminal no. 1, and continue in the order indicated by the arrowsin the drawing without skipping any terminals.



#### **How to Order Valves**



Nil	Standard type (1 W)						
Y (1)	Low wattage type (0.5 W)						
<b>R</b> (2)	External pilot						
Note 1) Applicable to DC specifications.  Note 2) Refer to page 2-5-39 for external							

pilot specification. Combination of external pilot and perfect interface is not possible.

Note 3) When two or more symbols are specified. indicate alphabetically


#### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

#### <Example> Terminal block box kit

VV5Q41-07C8T0....1 set —Manifold base part no. \*VQ4100-5----2 sets —Valve part no. (Stations 1 and 2) \*VQ4200-5----2 sets -Valve part no. (Stations 3 and 4) \*VQ4300-5.....1 set —Valve part no. (Station 5) Prefix the asterisk to the part nos. of the solenoid valve, etc.

Enter in order starting from the first station on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.





2

3

4

5

6


200 VAC (50/60 Hz)

110 VAC (50/60 Hz)

220 VAC (50/60 Hz)

**24 VDC** 12 VDC

## Kit (Terminal block box kit)



Note) Shown VV5Q41-08C12TO-W

SQ

VQ0


VQ4

VQ5

**VQZ** 

**VQD** 

#### **Bottom ported drawing**




Formula L1 = 25n + 63, L2 = 25n + 76 n: Station (Maximum standard 18 stations) \* Including 2 stations for terminal box.

imen	sion	S		
_ 	3	4	5	6

L	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
L1	138	163	188	213	238	263	288	313	338	363	388	413	438	463	488	513
L2	151	176	201	226	251	276	301	326	351	376	401	426	451	476	501	526

# Kit (Lead wire cable)




**IP65** compliant


- Enclosure IP65 compliant
- Direct electrical entry. Models with two or more stations are available.
- Electrical entry can be selected on either the U side or the D side according to the mounting orientation.
- Maximum stations are 16.


#### **Manifold Specifications**


	Po	rting specific					
Series	4(A), 2(B)	Poi	rt size	Applicable stations			
	port location	1(P), 5(R1), 3(R2)	4(A), 2(B)				
VQ4000	Side	Rc 1/2	C 8, 10, 12 Rc 1/4, 3/8	Max. 16 stations			
	Bottom		Rc 1/4				

#### Wiring Specifications









#### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

## <Example> Lead wire kit with cable (3 m)

VV5Q41-05C8LD2.... 1 set —Manifold base part no.


\*VQ4100-5.....2 sets —Valve part no. (Stations 1 and 2)

\*VQ4200-5........... 2 sets —Valve part no. (Stations 3 and 4)

\*VQ4300-5............ 1 set —Valve part no. (Station 5)


Prefix the asterisk to the part nos. of the solenoid valve, etc.

Enter in order starting from the first station on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.




external pilot and perfect interface is not possible. Note 3) When two or more symbols are specified, indicate them alphabetically.

# Kit (Lead wire cable)



#### **Bottom ported drawing**



Dimens	<b>Dimensions</b> Formula L1 = 25n + 63, L2 = 25n + 76 n: Station (Maximum 16 station										itions)					
L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L <sub>1</sub>	88	113	138	163	188	213	238	263	288	313	338	363	388	413	438	463
L2	101	126	151	176	201	226	251	276	301	326	351	376	401	426	451	476

**VQC** 

VO

ī				
ı				
ı	١V	r	١.	И
ı	N۷	v	ч	4

	-	_
١,	"	h
v		

V07	
٧ŲZ	


VQZ

VQD

# S Kit (Serial transmission unit)

#### IP65 compliant

- The serial transmission system reduces wiring work, while minimizing wiring and saving space.
- ●The system comes in an type SA (generic for small scale systems) for equipment with a small number of I/O points, or 32 points max., type SB (applicable to Mitsubishi Electric models) for controlling 512 I/O points max., type SC (applicable to OMRON models), type SD (applicable to SHARP models; 504 points max.), and type SF (applicable to NKE Uni-wire System; 128 points max.), type SJ (applicable to SUNX models), type SK (applicable to Fuji Electric models), type SQ (applicable to OMRON CompoBus/D), type SR (CompoBus/S).
- Maximum stations are 18.
- 2 stations are used for serial unit mounting.



- Stations are counted from station 1 on the D side.
- Double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station, regardless of valve and option types.

Item	Specifications
External power supply	24 VDC +10%, -5%
Current consumption (Internal unit)	SA, SB, SBB, SD, SF, SH, SJ, SK, SQ, SR, SV: 0.1A SC: 0.3A

#### **Manifold Specifications**

	F	ns					
Series	4(A), 2(B) port	Port	Port size				
	port location	1(P), 5(R1), 3(R2)	4(A), 2(B)				
VQ4000	Side	Rc 1/2	C 8, 10, 12 Rc 1/4, 3/8	Max. 18 stations			
	Bottom		Rc 1/4				

#### Type SA Type SB With general type SI unit Mitsubishi Electric Corporation (Series EX300) MELSECNET/MINI-S3 Data Link System Name of terminal block (LED M RUN M TRI LED LFD Description Description TRD Lighting during data reception **POWER** Lighting when power is turned ON Blinking when received data is normal; Lighting when data transmission **RUN/ERR** RUN Lighting when data reception with the master station is normal RD Lighting during data reception SD Lighting during data transmission ighting when reception data error occurs. FRR Light turns off when the error is corrected. • T unit Master station Can be connected with PLC I/O card for PLC made by Mitsubishi Electric Corporation serial transmission. Series MELSEC-A EX300-TMB1.....For models of Mitsubishi AJ71PT32-S3, AJ71T32-S3 **Electric Corporation** A1SJ71PT32-S3 Note EX300-TTA1.....For OMRON Max. 64 stations, connected to remote I/O EX300-TFU1.....For Fuji Electric stations (Max. 512 points). EX300-T001.....General purpose No. of output points, 16 points. No. of stations \* T units have 32 control points per unit occupied, 2 stations • No. of output points, 16 points


#### **How to Order Manifold** 08 C8 VV5Q Option Symbol Option Series • Nil None SI unit mounting position VQ4000 CD (2) Exhaust cleaner: D side mounting Nil U side mounting CU (2) Exhaust cleaner for Rc 1: U side exhaust Manifold • D D side mounting Special wiring specifications (Except double wiring) Plug-in unit Model • SD (2) Direct exhaust with silencer box: D side exhaust SU (2) Direct exhaust with silencer box: U side exhaust Without SI unit 0 **W** (2) Stations • IP65 enclosure Α With general type SI unit (Series EX300) 03 3 stations Mitsubishi Electric Corp.: MELSECNET/MINI-S3 Data Link System Note 1) When two or more symbols are specified, В indicate them alphabetically Example) -CDK Mitsubishi Electric Corp.: MELSECNET/MINI-S3 18 18 stations Note 2) Combination of [CD] and [SD] is not RR Data Link System (2 power supply systems) Note) Add 2 stations possible. OMRON Corp.: SYSBUS Wire System С for serial unit Note 3) Specify the wiring specifications in the D SHARP Corp.: Satellite I/O Link System manifold specification sheet. mounting. Note 4) Refer to pages 2-5-40 to 2-5-43 for with F1 NKE Corp.: Uni-wire System (16 output points) control unit.consumption of AC type. н NKE Corp.: Uni-wire H System Note 5) The release valve and the pressure switch Cylinder ports SUNX Corp.: S-LINK System (16 output points) J1 on the manifold with control unit are SUNX Corp.: S-LINK System (8 output points) J2 connected to another power supply. C8 With One-touch fitting for ø8 Κ Fuji Electric Co.: T-LINK Mini System Cable length is 0.6 m for L kit. C10 With One-touch fitting for Ø10 Q DeviceNet, CompoBus/D (OMRON Corp.) C12 With One-touch fitting for Ø12 R1 OMRON Corp.: CompoBus/S System (16 output points) 02 Rc 1/4 OMRON Corp.: CompoBus/S System (8 output points) R2 03 Rc 3/8 ٧ Mitsubishi Electric Corp.: CC-LINK System В Bottom ported Rc 1/4 G Rockwell Automation: Allen Bradley Remote I/O (RIO) System CM Mixed U JEMANET (JPCN-1)

<sup>\*</sup> For details on specifications and handling, refer to the separate technical instruction manual.

#### • Correspondence of SI unit output numbers and solenoid valve coils

Mixed wiring is available as an option. Use the manifold specification sheet to specify.

<Wiring example 1> Double wiring (Standard)



<Wiring example 2> Single/Double mixed wiring (Option) Double Double Double Double Double Single Single Slunit SI unit output no. ∀ B

VQC

U side

SQ

VQ0

VQ4

VQ5

VQZ

VQD

N O Type SD Type SC **OMRON** Corporation SHARP Corporation SYSBUS Wire System Satellite I/O Link System Name of terminal block (LED) LED LED Description Description POWER ON when power supply is ON Lights when transmission is normal RUN and PLC is in operation mode Lights when power is ON and slave RUN stations are operating normally T/R Blinks during data transmission/reception ERR ON when transmission is abnormal. Lights when slave station switch setting **ERROR** is abnormal, communication is abnormal, PLC stopped and defective slave unit R.SET ON for master unit control input HOLD Master station unit Master station unit SHARP Corporation PLC **OMRON PLC** New Satellite Series W SYSMAC C(CV) series ZW-31LM Types C500-RM201 and C200H-RM201 New Satellite Series JW \* 32 units max., transmission terminal JW-23LM, JW-31LM connection (512 points max.) Max. 31 units, I/O slave stations connected • No. of output points, 16 points (504 points max.) • No. of output points, 16 points

# Series d **Enclosure**


VQ4000 Type of actuation •

1	2 position single
2	2 position double
3	3 position closed center
4	3 position exhaust center
5	3 position pressure center
6	3 position double check

**How to Order Valves** 

## Seal

0	Metal seal
1	Rubber seal



Nil

w

Manual override

Dusttight

Dusttight/Low jetproof type

(IP65)

Y (1) Low wattage type (0.5 W) **R** (2) External pilot

Note 1) Applicable to DC specifications. Note 2) For external pilot specifications, refer to page 2-5-39.


Combination of the external pilot and perfect interface is not possible.

Note 3) When two or more symbols are specified, indicate them alphabetically.

#### **How to Order Manifold Assembly**


Specify the part numbers for valves and options together beneath the manifold base part number.

#### <Example> Serial transmission unit




When entry of part numbers becomes complicated,

indicate in the manifold specification sheet.



# S Kit (Serial transmission unit)



Note) In the case of EX124 for SI unit, conduit port (G 1/2) will be 4 locations.

Formula L1 = 25n + 63, L2 = 25n + 76 n: Station (Maximum standard 18 stations)

\* Including 2 stations for mounting SI unit box.

	moraumy 2 chance is moralismy or and so															
L	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18
L <sub>1</sub>	138	163	188	213	238	263	288	313	338	363	388	413	438	463	488	513
L2	151	176	201	226	251	276	301	326	351	376	401	426	451	476	501	526

Note) Shown VV5Q41-08C12SQ-W



**Dimensions** 



SQ


VQ0

VQ4

VQ5

**VQZ** 

**VQD** 



Formula L1 = 25n + 63, L2 = 25n + 76 n: Station (Maximum standard 18 stations)

Dimen	Dimensions											* Including 2 stations for mounting SI unit box.								
L	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18				
L1	138	163	188	213	238	263	288	313	338	363	388	413	438	463	488	513				
La	151	176	201	226	251	276	201	226	251	276	401	126	151	176	501	526				

# S

#### Kit (Serial transmission kit) for I/O

**IP65** compliant

#### Applicable network: DeviceNet/PROFIBUS-DP

• The serial transmission system reduces wiring work, while minimizing wiring and saving-space.


#### SI unit for DeviceNet/PROFIBUS

#### Input block

As a slave for DeviceNet/PROFIBUS, it is possible to control ON/OFF of a solenoid valve with the maximum of 32 points. Furthermore, by connecting a discrete input block, it is possible to input the sensor signal for 32 points at the maximum.

Meaning of an expansion block, connecting with SI unit, for sensor-inputting for auto switches, etc. Sensor-input is available up to 8 per one input block. By the NPN/PNP switch, it is able to adjust COM to sensor.

#### **Details in Connector**



## Communication connector (PROFIBUS-DP): Made by CONINVERS GmbH RC-2RS1N12 12 pins


Cable side connector example: Made by Siemens AG 6ES5 760-2CB11



Number	Description	Function							
1	M5V	GND Terminal							
2	Α	Signal-N							
4	В	Signal-P							
6	+5V	Terminal + 5V							
9	SIELD	Shield ground							
12	RTS	Optical fiber (Reserve)							

Pin no. 3, 5, 7, 8, 10 and 11 marked with ● are open.

 $\ast$  Connector's shape and pin assignment is interchangeable with ET200C made by Siemens AG.



#### SI unit COM

With no SI/Input unit (For SDOW)							
+COM	DeviceNet (SDQW)						
-COM	Profibus DP (SDNWN)						
	+COM	+COM DeviceNet (SDQW)					

Note) Only +COM is available for DeviceNet. Order a mounting valve with +COM.
Since PROFIBUS is -COM only, order -COM

for valves to be mounted.



SQ

VQ0

VQ4

VQ5

VQZ

VQD

#### **Details in Connector**

#### Input connector: M12 5 pins (XS2F compatible made by OMRON Corp.) x 8 pcs.

Cable side connector example: XS2G made by OMRON Corp.



	Number	Description	Function							
	1	SW+	Sensor power supply +							
	2	N.C.	Open*							
}	3	SW-	Sensor power supply –							
	4	SIGNAL	Sensor input signal							
	5	PE	Protective sensor ground							

\* No. 2 pin of the input no. 0, 2, 4, 6 connector (connectors aligned in the right side on the input block) is connected internally with no. 4 pin (sensor input no.) of the input no. 1, 3, 5, 7 respectively. Thereby, it is possible to directly input 2 points which is bundled into 1 cable by the cluster connector, etc.

Connector is	nput no.	Input no.: 1, 3, 5,						
SW +		1		1				
SIGNAL-n + 1		2		2				
SW-		3		3				
SIGNAL-n		4		4				
PE		5		5				

#### **⚠** Caution

When an enclosure equivalent to IP65 is required, place a waterproof cover on the unused input connector. As for waterproof cover, order it separately.

Example: OMRON Corp. XS2Z-12

## Power source connector: Series 723 (made by Franz Binder GmbH & Co. KG) 5 pins (72309-0115-80-05)

Cable side connector example: Franz Binder GmbH & Co. KG 72309-0114-70-15, etc.  $\ast$  DIN type 5 pins



	Number	Description	Function
	1	SV24V	For solenoid valve +24 V
2	2	SV0V	For solenoid valve 0 V
1	3	PE	Protective ground
	4	SW24V	<devicenet>For input block + 24 V, <profibus interbus="" or="">For input unit and SI unit + 24 V</profibus></devicenet>
	5	SW0V	<devicenet>For input block 0 V, <profibus interbus="" or="">For input unit and SI unit 0 V</profibus></devicenet>

## Communication connector (DeviceNet): M12 5 pins (for DeviceNet compliant)

Example of corresponding cable assemblies with connector: OMRON Corporation: DCA1-5CN05F1 Karl Lumberg GmbH & Co. KG: RKT5-56



Number	Description	Function							
1	Drain	Drain/Shield							
2	V+	Circuit power supply +							
3	V-	Circuit power supply –							
4	CAN_H	Signal H							
5	CAN_L	Signal L							

Item conforming to Micro style connector in DeviceNet specifications.

#### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

## <Example> Serial transmission unit

VV5Q41-05C8SDQW1-W---1 set —Manifold base part no.

\*VQ4100-5W------2 sets —Valve part no. (Stations 1 and 2)


\*VQ4200-5W------1 set —Valve part no. (Stations 3 and 4)


\*VQ4300-5W------1 set —Valve part no. (Station 5)

Prefix the asterisk to the part nos. of the solenoid valve, etc.

Enter in order starting from the first station

Enter in order starting from the first station on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.





Note 1) Applicable to DC specifications. Note 2) For external pilot specifications, refer to page 2-5-39.


Note 3) When two or more symbols are specified, indicate them alphabetically.

possible.

Combination of the external pilot and perfect interface is not

# S

### Kit (Serial transmission unit) for I/O




**Dimensions** 

Formula L1 = 25n + 63, L2 = 25n + 198 Stations \* In the case of DI unit, 1 pc., 54 mm is added per 1 pc.

Dillicit	31011	3		11.	11. Stations * In the case of Di unit, 1 pc., 54 min is added per 1 pc.										
_ n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	113	138	163	188	213	238	263	288	313	338	363	388	413	438	463
L2	248	273	298	323	348	373	398	423	448	473	498	523	548	573	598


#### Indicator Unit (LED) Descriptions and Functions

#### ■ SI Unit (DeviceNet)




Description	Function
PWR(V)	ON when solenoid valve power supply is turned ON
PWR	ON when DeviceNet circuit power supply input is turned ON
	OFF: Power supply off, off line, or when checking duplication of MAC_ID
	Green blinking: Waiting for connection (On line)
MOD/NET	Green ON: Connection established (On line)
	Red blinking: Connection time out (Minor communication abnormality occurs)
	Red ON: MAC_DI duplication error, or BUSOFF error
	(Major communication abnormality occurs)

#### ■ SI Unit (PROFIBUS-DP)



Description	Function
PWR	ON when solenoid valve power supply is turned ON OFF when the power supply voltage is less than 19 V
RUN	ON when operating (SI unit power supply is ON)
DIA	ON when self-diagnosis device detects abnormality
BF	ON for BUS abnormality

#### ■ Input block



Description	Function
PWR	ON when sensor power is turned ON OFF when short circuit protection is working
0 to 7	ON when each sensor input goes ON

SQ


VQ0

VQ4

VQ5

**VQZ** 

**VQD** 




Formula L1 = 25n + 63, L2 = 25n + 252n: Stations

Dimens	sion	S		* In the case of 2 pcs. DI unit, 105 mm will be added per 2 pc								2 pcs.			
L n	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	113	138	163	188	213	238	263	288	313	338	363	388	413	438	463
L2	302	327	352	377	402	427	452	477	502	527	552	577	602	627	652



# Series VQ4000 **Base Mounted**

# Plug Lead Unit: C Kit (Connector kit)



SQ

VQ0

VQ4

VQ5

**VQZ** 

VQD

## Plug Lead Unit Series VQ4000

#### **Manifold Specifications**

		Type of connection	Р	orting specification	ons	Maximum	Applicable		
Series	Base model		4(A), (B)	Port siz	Port size Note)		solenoid	5 station weight	
			port location	1(P), 5(R1), 3(R2)	4(A), 2(B)	stations	valve	(kg)	
VQ4000	VV5Q45-□□□	■ C kit–Grommet	Side	Rc 1/2 Option Direct exhaust with	C8 (For Ø8) C10 (For Ø10) C12 (For Ø12) Rc 1/4 Rc 3/8		VQ4□50 VQ4□51	2.0 • Except solenoid valve weight	
			Bottom	silencer box	Rc 1/4				

Note) For details about inch-size One-touch fittings and other thread standards, refer to page 2-5-39.


#### Flow Characteristics at the Number of Manifold Stations (Operated individually)


Model	Passage/St	tations	Station 1	Station 5	Station 10	Station 15
		C [dm³/(s·bar)]	5.9	5.9	5.9	5.9
	$1 \rightarrow 4/2 \ (P \rightarrow A/B)$	b	0.23	0.23	0.23	0.23
2 position metal seal		Cv	1.5	1.5	1.5	1.5
VQ4 <sup>1</sup> <sub>2</sub> 50		C [dm³/(s·bar)]	6.2	6.2	6.2	6.2
	$4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{EA/EB)}$	b	0.19	0.19	0.19	0.19
		Cv	1.5	1.5	1.5	1.5
		C [dm³/(s·bar)]	6.8	6.8	6.8	6.8
	$1 \rightarrow 4/2 \ (P \rightarrow A/B)$	b	0.31	0.31	0.31	0.31
2 position rubber seal		Cv	1.8	1.8	1.8	1.8
VQ4 <sup>1</sup> <sub>2</sub> 51		C [dm³/(s·bar)]	7.0	7.0	7.0	7.0
	$4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{EA/EB)}$	b	0.38	0.38	0.38	0.38
		Cv	1.9	1.9	1.9	1.9




Note) Port size: Rc 3/8

#### **Manifold Option**







**Individual SUP spacer** VVQ4000-P-5-02



Individual EXH spacer VVQ4000-R-5-02




- Refer to pages 2-5-34 to 2-5-38 for detail dimensions of each
- For replacement parts, refer to page 2-5-47.
- Refer to pages 2-5-40 to 2-5-43 for control unit.




Release valve spacer


VVQ4000-24A-5D Note)




SUP stop valve spacer VVQ4000-37A-5



Double check spacer with residual pressure exhaust VVQ4000-25A-5 Note)




SUP/EXH block plate VVQ4000-16A




< SUP blocking plate >


Direct exhaust with silencer  $\begin{array}{l} \textbf{box} \\ \textbf{[-S_U^D]} \end{array}^{\text{Note)}}$ 



Interface regulator ARBQ4000-00-B-5



For exhaust cleaner mounting [-C<sub>U</sub>] Note)







Note) Release valve spacer, built-in silencer (direct exhaust), exhaust cleaner mounting style and perfect double check spacer for residual pressure exhaust cannot be combined with external pilot.




# C Kit (Connector kit)





#### **Bottom ported drawing**




<b>Dimensions</b> Formula L1 = 25n + 63, L2 = 25n + 76 n: Station (Maximum 16 stations)										itions)						
_ L	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
L1	88	113	138	163	188	213	238	263	288	313	338	363	388	413	438	463
L2	101	126	151	176	201	226	251	276	301	326	351	376	401	426	451	476


#### **Manifold Option Parts**


#### Blanking plate assembly

#### VVQ4000-10A-1 (Plug-in type) VVQ4000-10A-5 (Plug lead type)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.











#### Individual SUP spacer

#### VVQ4000-P-1-02 (Plug-in type)

#### $VVQ4000-P-5-_{03}^{02}$ (Plug lead type)

By mounting individual SUP spacers on a manifold block, it is possible to provide individual supply ports for each valve.







#### Individual EXH spacer

#### VVQ4000-R-1-02 (Plug-in type)

#### VVQ4000-R-5- $\frac{02}{03}$ (Plug lead type)

By mounting individual EXH spacers on a manifold block, exhaust ports can be provided individually for each valve. (Common EXH type)








#### Throttle valve spacer

#### VVQ4000-20A-1 (Plug-in type) VVQ4000-20A-5 (Plug-lead type)

A throttle valve spacer is mounted on a manifold block to control cylinder speed by throttling exhaust air flow.







VQC

SQ

VQ0

VQ4

VOE

VQ5

VQZ

...


VQD


Rc 3/8


#### SUP stop valve spacer

#### VVQ4000-37A-1 (Plug-in type) VVQ4000-37A-5 (Plug-lead type)

A SUP stop valve spacer is mounted on a manifold block, making it possible to individually shut off supply air to each valve.







163 (Plug-in type)

### Release valve spacer: For D side mounting


#### VVQ4000-24A-1D (Plug-in type) VVQ4000-24A-5D (Plug-lead type)


Combination of VQ41 (Single) and release valve spacer can be used as air release valve


Note 1) Mounting on 2 position double and 3 position valve is not possible.

Note 2) Can be mounted on L kit only. For other kits order E type control unit

te 2) Can be mounted on L kit only. Fo other kits, order E type control unit. (Refer to pages 2-5-40 to 2-5-43.)










#### SUP/EXH block plate

#### VVQ4000-16A


When different pressures, high and low, are supplied tomanifold, a SUP block plate is inserted between the stations under different pressures.
















#### **Manifold Option Parts**

#### Direct exhaust with silencer box

VV5Q4½-□□□-SB (Exhaust from both sides)


VV5Q4 ½-□□□-SD (D side exhaust)


VV5Q4 $\frac{1}{5}$ - $\square\square\square$ -SU (U side exhaust)


The EXH outlet is placed on the top side of the manifold end plate. The built-in silencer provides highly effective noise reduction.


(Noise reduction of 35 dB or more)


Note) If a lot of drainage is generated at air supply source, both of exhaust air and drainage are exhausted.











Note) Figure shows VV5Q41-\(\subseteq\) = SD.

# Double check spacer with residual pressure exhaust

#### VVQ4000-25A-1 (Plug-in type) VVQ4000-25A-5 (Plug lead type)

Can hold an intermediate cylinder position for an extended time.

If the double check spacer with a built-in double check valve is combined, it will enable the cylinder to stop in the intermediate stroke and maintain its position for a long time without being affected by the leakage between the spools.

Besides, combination between 2 position solenoid valve ( $VQ4_2^1\square\square$ ) and double check spacer can't hold an intermediate position, but can prevent dropping at the cylinder stroke end.

# Plug-in type Plug lead type

#### **Specifications**

Double check	VVQ4000-25A-1								
spacer part no.	Intermediate	e stop	Drop prevention						
Applicable solenoid valve	VQ44□		VQ4 <sup>1</sup> □□						
	Solenoid one	1/D)	5(R <sub>1</sub> )	230					
	side energized	1(P)	3(R <sub>2</sub> )	or less					
Leakage *		1/D)	5(R <sub>1</sub> )	230					
N cm <sup>3</sup> /min	Both solenoids	1(P)	3(R <sub>2</sub> )	or less					
	unenergized	4(A)	5(R <sub>1</sub> )	0					
		2(B)	3(R <sub>2</sub> )	0					

\* Supply pressure: 0.5 MPa

# 163 (Plug-in type) 125.5 (Plug lead type) 73 73

## **⚠** Caution

#### **Handling Precautions**

- Air leakage from the pipe between the valve and cylinder or from the fittings will prevent the cylinder from stopping in the middle for a long time. Check for leakage using a neutral household detergent, such as dish washing soap. Also, check the cylinder sealing and piston seal for leakage.
- Since One-touch fittings allow slight air leakage, screw piping is recommended when stopping the cylinder in the middle for a long time.
- If exhaust side of double check spacer is narrowed down, this causes a decrease in intermediate stop accuracy and may malfunction.
- Combining perfect interface with 3 position valves "VQ45□□" will not work.
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.
- Combining double check spacer with external pilot will not work.

Manual override for residual pressure exhaust Slotted locking type (Tool required)



SQ

VQ0

VQ4

VQ5

**VQZ** 

**VQD** 


#### Series VQ4000

#### Manifold mounted exhaust cleaner

VV5Q4 $\frac{1}{5}$ - $\square\square$ -CD (D side mounting) VV5Q4 ½-□□□-CU (U side mounting)

An adapter plate for exhaust cleaner mounting is provided on the top of the manifold end plate. The exhaust cleaner collects drainage and oil mist (99.9% or more) and is highly effective for noise reduction.

(Noise reduction of 35 dB or more)






#### Applicable exhaust cleaners


#### AMC610-10 (Port size Rc 1)

Note 1) Exhaust cleaner AMC610-10 is not attached. (Order it separately.)

Note 2) Mount so that the exhaust cleaner is at the lower side.

Note 3) For details about the exhaust cleaner, refer to Best Pneumatics vol.5.





<b>Dimensions</b> Formula L1 = 25n + 63, L2 = 25n - n: Stations (Maximum 16 stations)								
L n	1	2	3	4	5	6	7	8
L1	88	113	138	163	188	213	238	263
L2	101	126	151	176	201	226	251	276
L	9	10	11	12	13	14	15	16
L <sub>1</sub>	288	313	338	363	388	413	463	463
L2	301	326	351	376	401	426	476	476

Dimens	<b>Dimensions</b> Formula L1 = 25n + 63, L2 = 25n + 76 n: Stations (Maximum 16 stations)										
L	1	2	3	4	5	6	7	8			
L1	88	113	138	163	188	213	238	263			
L2	101	126	151	176	201	226	251	276			
L	9	10	11	12	13	14	15	16			
L <sub>1</sub>	288	313	338	363	388	413	463	463			
L2	301	326	351	376	401	426	476	476			

#### **Manifold Option Parts**

Interface regulator (P, A, B port regulation)

ARBQ4000-00-□-1 (Plug-in type) ARBQ4000-00-□-5 (Plug lead type)

Spacer Interface regulators can be placed on top of the manifold block to reduce the pressure of each of the valves.


#### **Specifications**


Interface regulator			ARBQ4000						
Regulating port		A		В		Р			
Applicable solenoid valve	Plug-in	Plug lead	Plug-in	Plug lead	Plug-in	Plug lead			
Maximum operating pressure			1.0	MPa					
Set pressure range				0.05 to (	0.85 MPa				
Fluid		Air							
Ambient and fluid temperature	е	-5 to 60°C (No freezing)							
Port size for connection of pressi	ure gauge	M5 x 0.8							
Weight (kg)		0.33	0.30	0.33	0.30	0.33	0.30		
Effective area at supply side (mm²)	P→ A	-	15	31		14			
S at P <sub>1</sub> = 0.7 MPa/P <sub>2</sub> = 0.5 MPa	P→ B	3	35	16		15			
Effective area at exhaust side (mm²)	$A \rightarrow EA$	-	18	4	10	40			
S at P <sub>2</sub> = 0.5 MPa	$B \rightarrow EB$	;	37	1	19	37			


- Note 1) Set the pressure within the operating pressure range of the solenoid valve.
- Note 2) Operate an interface regulator only by applying pressure from the "P" port of the base, except when using it as a reverse pressure valve. Further, it cannot be used with reduced pressure at port P.
- Note 3) When using a perfect spacer, assemble a valve, a spacer regulator and a perfect spacer in this order to use it.
- Note 4) When using in A port regulation, B port regulation by closed center, since there is a problem in its operation, please contact SMC.
- Note 5) Dust tight/Low jetproof enclosure (IP65) is not available with interface regulator.

#### **How to Order**

Solenoid Valve	Interface regulator	Regulating port
	ARBQ4000-00-A-1	Α
VQ4□0□ (Plug-in type)	ARBQ4000-00-B-1	В
	ARBQ4000-00-P-1	Р
	ARBQ4000-00-A-5	Α
VQ4□5□ (Plug lead type)	ARBQ4000-00-B-5	В
	ARBQ4000-00-P-5	Р













#### **Flow Characteristics**

## Conditions Inlet pressure: 0.7 MPa ARBQ4000-00-A










#### **Pressure Characteristics**

Conditions
Inlet pressure: 0.7 MPa
Outlet pressure: 0.2 MPa



#### **Option**

#### **External Pilot Specifications**

- When the supply air pressure is:
  - lower than the required minimum operating pressure 0.15 to 0.2 MPa,
  - opposite air supply (R port supply), cylinder supply (A and B port supply),
  - used for vacuum specifications (please contact SMC), it can be used for external pilot specifications.


Order a valve by adding the external pilot specification [R] to the part number. External pilot is available as standard for manifolds and options.

• Internal/external pilot can be mounted in a manifold.

#### **Inch-size One-touch Fittings**

Valve with inch size One-touch fittings is shown below.

#### **How to Order Manifold**



**VQC** 

SQ

VQ0


VQ4


VQ5

**VQZ** 

VQD


#### **How to Order Manifold**





<Sub-plate>

<Manifold>



#### **Pressure Specifications**

Valve constru	uction	Metal seal	Rubber seal	
Operating pressur	e range	Vacuum to 1.0 MPa		
	Single		0.2 to 1.0 MPa (0.2 to 0.7 MPa)	
External pilot Note) pressure range	Double	0.15 to 1.0 MPa (0.15 to 0.7 MPa)	0.15 to 1.0 MPa (0.15 to 0.7 MPa)	
	3 position		0.2 to 1.0 MPa (0.2 to 0.7 MPa)	



Note ) Values inside ( ) denote the low wattage (0.5 W) specifications.



Combination of manifold options shown below and external pilot specification is not possible.


Release valve spacer	VVQ4000-24A-□D		
Direct exhaust with silencer box	VV5Q4□-□□□-S□		
For exhaust cleaner mounting	VV5Q4□-□□□-C <sup>U</sup>		
Manifold with control unit	VV5Q4 —— Control unit model no.		
Double check spacer with residual pressure exhaust	VVQ4000-25A-1 <sub>5</sub>		

#### International Thread Standards Other than Rc


Rc specifications are standard for all ports, however, NPT, NPTF and G are available for international markets.


Add the appropriate symbol following the port size in the standard part

#### **How to Order Single Valves (Example)**




#### **How to Order Manifold**





#### **How to Order Sub-plates and Options (Example)**



Nil	Rc		
N	NPT		
Т	NPTF		
F	G		

#### **Manifold with Control Unit**

- Mounting air filter, regulator, pressure switch for air release valve on manifold as unit is possible and permits piping labor savings.
- Maximum number of stations depends on each kit.
  - Refer to manifold specifications.
- 2 stations are used for control unit mounting.

(1 station is used for E type.)





**Plug Lead Type** 

#### 

In the case of air filters with auto-drain or manual drain, mount so that the air filter is at the bottom.

#### **Manifold Specifications**

	-		Porting spec	cifications	Note)	
Base model	Type of connection	4(A), 2(B)	Port	size	Applicable	Applicable
		port location	1(P), 5(R1), 3(R2)	4(A), 2(B)	max. stations	solenoid valve
VV5Q41 -□□□	F kit – D-sub connector T kit – Terminal block box L kit – Lead wire	Side	Rc 1/2 Option	C8 (For Ø8) C10 (For Ø10) C12 (For Ø12) Rc 1/4, Rc 3/8	F, T kit 14 stations	VQ4□00 VQ4□01
VV5Q45 -□□□	C kit – Connector	Bottom	Direct exhaust with silencer box	Rc 1/4	(13 stations) - L, C kit 18 stations (17 stations)	VQ4□50 VQ4□51

Note) Manifold for mounting is included. (): E type

#### **Control Unit Specifications**

Air filter (With auto-drain/With manual drain)						
Filtration	5 μm					
Regulator						
Set pressure (Outlet pressure)	0.05 to 0.85 MPa					
Pressure switch Note)						
Set pressure range: OFF	0.1 to 0.6 MPa					
Differential	0.08 MPa or less					
Contact	1a					
Light	LED (RED)					
Max. switch capacity	2 VA (AC), 2 W (DC)					
Max. operating current	50 mA at 24 VAC, DC or less 20 mA at 100 VAC, DC					

#### Air release valve (Single only)

0.15 to 1 MPa Operating pressure range (0.15 to 0.7 MPa)

Values inside ( ) denote the low wattage (0.5 W) specifications.

#### **Control Unit/Option**


Air release valve spacer	<plug-in type=""> VVQ4000-24A-1D</plug-in>				
	<plug lead="" type=""> VVQ4000-24A-5D</plug>				
Pressure switch		IS1000P-	2-1		
(3)	Regulat	tor with filter	MP2-3		
Blanking	Pressu	re switch	MP3-2		
plate	Release	Plug-in	VVQ4000-24A-10		
	valve	Plug lead	VVQ4000-24A-15		
Filter element	INA-13-854-12-5B				

Note1) Rated voltage: 24 VDC to 100 VAC Internal voltage drop: 4 V

Note 2) Combination of VQ41□□ (Single) and release valve spacer can be used as air release valve.

Note 3) Plug lead type can not be mounted later.

#### **How to Order Manifold**



#### **Use of Control Unit**

#### <Construction and piping >


- 1. The supply pressure (Po) passes through the filter regulator (1) and is adjusted to the prescribed pressure. Next, it goes through the release valve (2) (outlet residual pressure switching function used as normally ON) and is supplied to the manifold base side (P).
- Supply pressure from Po port is blocked when release valve (2) is OFF.
   Air supplied to manifold side P port is exhausted to R1 port through release valve (2).
- **3.** Pressure switch is piped at outlet side of release valve (2). (Release valve (2) is operated at energizing.)
  - Also, since there is an internal voltage drop of 4 V, it may not be possible to confirm the OFF and ON states with a tester, etc.


#### <Wiring>

 Electrical entry of manifold (except L and C kit) is individual wiring. For details, refer to internal wiring figure of each kit. Cable length is 0.6 m for L kit.

#### <Change of pressure switch piping>

- Pressure switch (3) is changed to piping on inlet side of release valve (2), remove the pressure switch, reverse the gasket up and down, and fix B mark.
- 2. When pressure switch is mounted, tightening torque of bolt is 0.8 to 1.2  $\mbox{N}\cdot\mbox{m}.$






Circuit of control unit manifold

#### **Manifold with Control Unit**

#### Plug-in type



<b>Dimensions</b> Formula L1 = 25n + 63, L2 = 25n + 76, L3 = 25n + 269.5 (262.5) n: Statio							Stations				
L	2	3	4	5	6	7	8	9	10	11	12
L1	113	138	163	188	213	238	263	288	313	338	363
L2	126	151	176	201	226	251	276	301	326	351	376
1.0	332	357	382	407	432	457	482	507	532	557	582
L3	(310.5)	(335.5)	(360.5)	(385.5)	(410.5)	(435.5)	(460.5)	(485.5)	(510.5)	(535.5)	(560.5)

\* L3 ( ): Type MP



SQ

VQ0


VQ4

VQ5

**VQZ** 

**VQD** 

#### Plug lead type




Dimens	sions		Formula	L1 = 25r	1 + 63, L2	2 = 25n +	- 76, L3 :	= 25n + 2	269.5 (26	2.5) n:	Stations
L	2	3	4	5	6	7	8	9	10	11	12
L1	113	138	163	188	213	238	263	288	313	338	363
L2	126	151	176	201	226	251	276	301	326	351	376
L3	332	357	382	407	432	457	482	507	532	557	582
L3	(310.5)	(335.5)	(360.5)	(385.5)	(410.5)	(435.5)	(460.5)	(485.5)	(510.5)	(535.5)	(560.5)
										. 1 - / )	T 140

\* L3 ( ): Type MP



# Construction

#### **Plug-in Unit**





#### **Component Parts**


Number	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

#### **Replacement Parts**

4	Pilot valve assembly	VQZ111P-□	*: Coil rated voltage Example) 24 VDC: 5
---	----------------------	-----------	---







#### **Component Parts**


Number	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool valve	Aluminum, NBR	
3	Piston	Resin	

#### **Replacement Parts**



# Series VQ4000 Construction

#### **Plug Lead Unit**





**Component Parts** 

Number	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool/Sleeve	Stainless steel	
(3)	Piston	Resin	

#### **Replacement Parts**

4	Pilot valve assembly	VQZ111P-□	*: Coil rated voltage Example) 24 VDC: 5
---	----------------------	-----------	---





#### **Component Parts**

Number Description		Material	Note
1	Body	Aluminum die-casted	
2 Spool valve		Aluminum, NBR	
3	Piston	Resin	

#### **Replacement Parts**

4	Pilot valve assembly	VQZ111P-□	*: Coil rated voltage Example) 24 VDC: 5
---	----------------------	-----------	---

VQC

SQ

VQ0


VQ4

VQ5

VQZ

VQD

# **Exploded View of Manifold**



Note 1) The electrical entry cannot be changed.

The drawing shows a plug-in type.

Note 2) Manifold block used is 2-station integrated type. For odd number of stations, 1 pc. of one-station manifold block is combined at U side; for even number of stations, 2 pcs. are combined, therefore making the increase/decrease of stations possible.

Example)

5 stations (Odd number)

6 stations (Even number)

D side

1 ......2 .....3 .....4 .....5 .....6 .....Stations


2 stations | 2 stations | 1 station |

2 stations | 2 stations | 1 station |

## Exploded View of Manifold Series VQ4000

#### <D Side End Plate Assembly>

1. D side end plate assembly no. (For F, L, S, T kit)



Nil	Standard		
W (2) IP65 enclosure			
CD For exhaust cleaner mounting			
SD Direct exhaust with silencer box			

Note 1) D-sub connector is not included. Note 2) Dripproof F kit is not available.


D side end plate assembly part no. (For input/output type for S kit)

#### VVQ4000 — 3A — 12

\* With connector on the SI unit

#### <Manifold Block Assembly>

3. Manifold block assembly part no.



F1	F kit Double wiring	02	Rc 1/4
F2	F kit Single wiring	03	Rc 3/8
T1	T kit Double wiring	В	Bottom ported Rc 1/4
T2	T kit Single wiring	C8	With One-touch fitting for ø8
S1	S kit Double wiring	C10	With One-touch fitting for ø10
S2	S kit Single wiring	C12	With One-touch fitting for ø12
L0□	L0 kit □: Stations (1 to 16)	N7	With One-touch fitting for ø1/4
L1□	L1 kit □: Stations (1 to 16)	N9	With One-touch fitting for ø5/16
L2□	L2 kit □: Stations (1 to 16)	N11	With One-touch fitting for ø3/8
С	C kit (Plug lead type)		



- Note 1) Tie-rods (2 pcs.) and lead wire assembly for station addition included.
- Note 2) Dripproof F kit is not available.
- Note 3) When ordering block assembly for L kit 2 stations, the lead wire should be ordered by the smaller numbers of the D side (no. of station).


#### <SI Unit>

#### SI Unit Part No.

Туре	Model symbol	SI unit part no.	Description	
	0	<u> </u>	Without SI unit	
	Α	EX323D-S001	General type SI unit (Series EX300)	
	В	EX123D-SMB1	Mitsubishi Electric Corporation: MELSECNET/MINI-S3 Data Link System	
	BB	EX124D-SMB1	Mitsubishi Electric Corp.: MELSECNET/MINI-S3 Data Link System (2 power supply systems)	
	С	EX123D-STA1	OMRON Corporation: SYSBUS Wire System	
	D	EX123D-SSH1	SHARP Corporation: Satellite I/O Link System	
	F1	EX123D-SUW1	16 output points Uni-wire System (NKE Corporation)	
	G	EX124D-SAB1	Allen Bradley Remote I/O (RIO) System (2 power supply systems) (Rockwell Automation, Inc.)	
Dedicated output	Н	EX123D-SUH1	SI unit for 16 output points Uni-wire H System (NKE)	
model	J1	EX123D-SSL1	16 output points S-LINK System (Sunx)	
	J2	EX123D-SSL2	8 output points S-LINK System (Sunx)	
	K	EX123D-SFU1	T-LINK Mini System (Fuji Electric Co.)	
	Q	EX124D-SDN1	SI unit for DeviceNet and CompoBus/D (OMRON)	_
	R1	EX124D-SCS1	SI unit for 16 output points CompoBus/S (OMRON)	
	R2	EX124D-SCS2	SI unit for 8 output points CompoBus/S (OMRON)	
	U	EX124D-SJN1	JEMANET (2 power supply systems)	
	V	EX124D-SMJ1	SI unit for CC-LINK System (2 power supply systems) (Mitsubishi Electric Corp.)	
	QW	EX240-SDN2	CC-LINK System	
For in/output model	NW	EX240-SPR1	PROFIBUS-DP (-COM)	
model		EX240-IE1	DI unit (For input) M12 8 number of inputs	

#### <U Side End Plate Assembly Part No.>

2. U side end plate assembly no. (For F, L, S, T kit)



Nil	Standard	
<b>W</b> (2)	IP65 enclosure	
CU	For exhaust cleaner mounting	
SU	Direct exhaust with silencer box	
Note 1) D-sub connector is not included Note 2) Dripproof F kit is not available.		

 $\mbox{\bf U}$  side end plate assembly part no. (For input/output type for  $\mbox{\bf S}$  kit)

#### VVQ4000 - 2A - 12

\* With connector on the SI unit

#### <Manifold Block Replacement Parts>

#### **Replacement Parts**

No.	Part no.	Description	Material	Number
4	VVQ4000-80A-1	Gasket	NBR	10
5	VVQ4000-80A-2	Gasket	NBR	10
6	VVQ4000-80A-4	Clip	Stainless steel	10

Note) Spare parts consist of sets containing 10 pcs. each.

#### <Fitting Assembly>

7. Fitting assembly part no. (For cylinder port)



-	
C8	Applicable tubing ø8
C10	Applicable tubing ø10
C12	Applicable tubing ø12
N7 Applicable tubing ø1/	
N9	Applicable tubing ø5/16
N11	Applicable tubing ø3/8

**VQC** 

SQ

VQ<sub>0</sub>

VQ4

VQ5

**VQZ** 

VQD

Note) Purchasing order is available in units of 10 pieces.


# **5 Port Solenoid Valve Metal Seal/Rubber Seal Base Mounted**

# Series VQ5000

### **Space-saving profile**

Clean space saving design with all pilot valves concentrated to one side with no protrusions in any direction

Space-saving —— 40% less Capacity-saving — 50% less (In-house comparison)



VQC

SQ

VQ0

VQ4

VQ5

VQZ

VQD

### **Compact with large** flow capacity (Ideal for driving cylinders

up to ø180)

### **Enclosure IP65 compliant** Dust tight/Low jetproof type

### **Outstanding** response times and long service life

(Metal seal with light/surge suppressor)								
VQ5100	32 mS -	7						
(Single)		-100 million cycles						
VQ5200	17 mS	* According to SMC life test						
(Double) Accuracy	±3 m	nS conditions						

<sup>\*</sup> For applications which demand high speed, high frequency, long life and a precise response time.

### Cylinder Speed Chart

Use as a guide for selection. Please confirm the actual conditions with SMC Sizing

						Bor	e size				
Series	Average speed (mm/s)	Press Load	s MB, sure 0.9 factor e 500 i	5 MPa 50%		Serie Press Load	s CS1 sure 0. factor	5 MPa 50% oke 10	00 mm		
		Ø50	Ø63	Ø80	Ø100	Ø125	Ø140	Ø160	Ø180	Ø200	Ø250
VQ5100-□-04 VQ5101-□-04								$\Box$		dicular, actuation tal actu	

It is when the cylinder is extending that is meter-out controlled by speed controller which is directly connected with cylinder, and its needle valve with being fully open.

\* The average velocity of the cylinder is what the stroke is divided by the total stroke time.

\* Load factor: ((Load weight x 9.8)/Theoretical force) x 100%


#### System Components

your components									
Speed controller	Silencer	SGP (Steel pipe) dia. x Length							
AS420-04	AN400-04	10A x 1 m							

### **多SMC**

### A variety of common wiring methods are standardized.

### <Plug-in type>




(Terminal block box)

standardized to facilitate easy wiring work and maintenance.

In addition, 3 of the wiring types are available with IP65 enclosures.

### Individual wiring type <Plug lead type>

Enclosure IP65 compatible



### ⚠ Precautions

Be sure to read before handling. For Safety Instructions and Solenoid Valve Precautions, refer to page 2-9-2.


### **Manual Override Operation**

### **⚠** Warning

Since connected equipment will be actuated when the manual override is operated, first confirm that conditions are safe.

Non-locking push type (Tool required) is standard. As an option, slotted locking type (Tool required) is available.


### Push type (Tool required)




Push down the manual override button with a small screwdriver, etc.

Release the screwdriver and the manual override will return.

### **Locking type (Option)**



Push down completely on the manual override button with a small screwdriver. While down, turn clockwise 90° to lock it. Turn it counterclockwise to release it.




### **Mounting of Valves**

### **⚠** Caution

After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.

### Proper tightening torque (N·m)

1 to 1.8




### **Lead Wire Connection**

### **△** Caution

### Plug-in sub-plate (With terminal block)

 If the junction cover (1) of the sub-plate is removed, you can see the plug-in type terminal block (2) mounted inside the subplate.



 The terminal block is marked as follows. Connect wiring to each of the power supply terminals.


Terminal block marking	A	СОМ	В	Ť
VQ510 <sub>1</sub> 0	A side	СОМ		_
VQ520 <sub>1</sub>	A side	СОМ	B side	_
VQ5 <sub>5</sub> <sup>3</sup> 00 <sub>1</sub>	A side	СОМ	B side	_

Note 1) There is no polarity. It can also be used as -COM. Note 2) The sub-plate is double wired even for the  $VQ510_1^{\circ}$ .

● Applicable terminal 1.25-3s, 1.25Y-3, 1.25Y-3N, 1.25Y-3.5.

### Plug lead: Grommet type

Make connections to each corresponding wire.



	Single solenoid	Double solenoid
Standard	Black: A side solenoid (–)  Red: COM (+)	Black: A side solenoid (–) Red: COM (+) White: B side solenoid (–)
Enclosure IP65 compliant	Green: (Not used for sin	Black: A side solenoid (-)  Red: COM (+)  White: B side solenoid (-) (Not used for single solenoid)  ngle or double.)

Note) There is no polarity. It can also be used as -COM.

### Installation and Removal of Light Cover

### **⚠** Caution


### Installation/Removal of light cover

#### Removal

To remove the pilot cover pull it straight off. If it is pulled off at an angle, the pilot valve may be damaged or the protective O-ring may be scratched.

#### Installation

Place the cover straight over the pilot assembly so that the pilot valve is not touched, and push it until the cover hook locks without twisting the protective O-ring. (When pushed in, the hook opens and locks automatically.)



### **Replacement of Pilot Valve**


### **⚠** Caution

### ■ Removal

- 1. Remove the mounting screw that holds the pilot valve using a small screwdriver.
- 2. When equipped with light, remove the light circuit board which is installed on the pilot valve by pulling it straight off the connector pins.

### Installation


- 1. Insert the light circuit board straight onto the connector pins following the guide. If it is pushed in forcibly without following the guide, there is danger of possibly bending the board contacts.
- 2. After confirming the gasket is correctly placed under the valve, securely tighten the bolts with the proper torque shown in the table below.



#### Proper tightening torque (N·m)

0.1 to 0.13

Note) The mounting of pilot valves is not directional with respect to the A and B sides. However, the light circuit boards' A side is orange and the B side is green. It must be mounted on the pilot valve in accordance with the mounting indicators. The light will not go on if the mounting is reversed.



### Light Circuit Board Part No.

SOL.A	VQZ100-47-A
SOL.B	VQZ100-47-B


Note) It can be used with all voltages.

### For Plug Lead Type

### Attaching and detaching connectors

- To attach a connector, hold the lever and connector unit between your fingers and insert straight onto the pins of the solenoid valve so that the lever's pawl is pushed into the groove and locks.
- To detach a connector, remove the pawl from the groove by pushing the lever downward with your thumb, and pull the connector straight out.

Note) Do not pull on the lead wires with excessive force. This can cause faulty and/or broken contacts.



**VQC** 

SQ

VQ0


VQ4

VQ5


VQZ


VQD


# $oldsymbol{\Lambda}$ Caution



**Internal Wiring Specifications** 







### **How to Calculate the Flow Rate**

For obtaining the flow rate, refer to pages 2-1-8 to 2-1-11.



# Series VQ5000 **Base Mounted**

# Plug-in/Plug Lead: Single Unit

### Model


							F	low Cha	racteristics			Respo	nse time	(ms)	
Series		Number solenoids	Model		Port	1 → 4,	1 → 4/2 (P → A/B)			4/2 → 5/3 (A/B → EA/EB)			Low wattage	AC	Weight (kg)
	011				5126	C[dm3/(s·bar)]	b	Cv	C[dm3/(s·bar)]	b	Cv	1 W	0.5 W	AC	(1.9)
	_	Cinala	Metal seal	VQ5150		12	0.14	2.9	14	0.18	3.4	35 or less	38 or less	38 or less	0.59 (0.67)
	position	Single	Rubber seal	VQ5151		16	0.33	4.4	17	0.31	4.7	40 or less	43 or less	43 or less	0.58 (0.66)
		N Double	Metal seal	VQ5250		12	0.14	2.9	14	0.18	3.4	20 or less	23 or less	23 or less	0.62 (0.70)
	~		Rubber seal	VQ52 <sub>5</sub> 1		16	0.33	4.4	17	0.31	4.7	25 or less	28 or less	28 or less	0.60 (0.68)
		Closed center	Metal seal	VQ5350	Rc 1/2	11	0.24	2.6	11	0.23	2.8	50 or less	53 or less	53 or less	0.65 (0.73)
VQ5000			Rubber seal	VQ5351		12	0.33	3.4	13	0.37	3.7	60 or less	63 or less	63 or less	0.58 (0.66)
V Q3000	_	- Exhaust	Metal seal	VQ5450		12	0.13	2.9	14	0.18	3.4	50 or less	53 or less	53 or less	0.65 (0.73)
	position	center	Rubber seal	VQ54 <sub>5</sub> 01		14	0.39	3.9	16	0.35	4.5	60 or less	63 or less	63 or less	0.58 (0.66)
		Pressure	Metal seal	VQ55 <sub>5</sub> 0		12	0.23	2.9	13	0.24	3.3	50 or less	53 or less	53 or less	0.65 (0.73)
	က	center	Rubber seal	VQ55 <sub>5</sub> 01		13	0.32	3.4	14	0.40	3.9	60 or less	63 or less	63 or less	0.58 (0.66)
		Double check	Metal seal	VQ5650		8.0	_	_	8.5	_	_	62 or less	65 or less	65 or less	1.17 (1.25)
			Rubber seal	VQ5651		8.3	_	_	9.0	_	_	75 or less	78 or less	78 or less	1.10 (1.18)

Note) Value for valve on sub-plate.





### JIS Symbol



### **Standard Specifications**

	Valve construction		Metal seal	Rubber seal			
	Fluid		Air/Inert gas				
	Maximum operating	pressure (3)	1.0	МРа			
		Single	0.10 MPa	0.20 MPa			
ons	Min. operating pressure	Double	0.10 MPa	0.15 MPa			
icati	p. coca. c	3 position	0.15 MPa	0.20 MPa			
Valve specifications	Proof pressure		1.5	MPa			
e sp	Ambient and fluid te	mperatnre	−5 to	50°C <sup>(1)</sup>			
/alv	Lubrication		Not required				
	Manual override		Push type/Locking type (Tool required) Option				
	Shock/Vibration resistance		150/30 m/s <sup>2 (2)</sup>				
	Protection structure		Dust tight (IP65 compatible)				
	Coil rated voltage		12, 24 VDC, 100, 110, 200, 220 VAC (50/60 Hz)				
SU	Allowable voltage flu	ctuation	±10% of rated voltage				
atio	Coil insulation type		Class B or equivalent				
cific		24 VDC	1 W DC (42 mA), 0	.5 W DC (21 mA) <sup>(3)</sup>			
Solenoid specifications		12 VDC	1 W DC (83 mA), 0.5 V	W DC (42 mA) Note (3)			
pioi	Power consumption	100 VAC	Inrush 1.2 VA (12 mA),	Holding 1.2 VA (12 mA)			
olen	(Current)	110 VAC	Inrush 1.3 VA (11.7 mA),	Holding 1.3 VA (11.7 mA)			
۷,		200 VAC	Inrush 2.4 VA (12 mA),	Holding 2.4 VA (12 mA)			
		220 VAC	Inrush 2.6 VA (11.7 mA), Holding 2.6 VA (11.7 mA				

Note 1) Use dry air to prevent condensation when operating at low temperatures.


Note 2) Impact resistance: No malfunction occurred when it is tested with a drop tester in the axial direction and at the right angles to the main valve and armature in both energized and de-energized states every once for each condition. (Values at the initial period)

Vibration resistance: No malfunction occurred in a one-sweep test between 45 and 2000 Hz. Test was performed at both energized and de-energized states in the axial direction and at the right angles to the main valve and armature. (Values at the initial period)

Note 3) Values inside ( ) denote the low wattage (0.5 W) specifications.




### **How to Order Valves**



### **Plug-in Type**

### **Conduit terminal**

### 2 position single: VQ510<sup>0</sup><sub>1</sub>




1(P), 4(A), 2(B), 5(R1), 3(R2) port


2 position double: VQ5201

3 position closed center: VQ530<sub>1</sub><sup>0</sup> 3 position exhaust center: VQ540<sub>1</sub><sup>0</sup>

3 position pressure center: VQ550<sup>0</sup><sub>1</sub>



### 3 position double check: VQ5601





SQ

VQ0

VQ4

VQ5


**VQZ** 


VQD


### **Plug Lead Type**

### Grommet

2 position single: VQ515<sup>0</sup><sub>1</sub>-□<sup>G</sup><sub>H</sub>









2 position double: VQ525<sup>0</sup><sub>1</sub>-□<sup>G</sup><sub>H</sub>

3 position closed center: VQ535 $_1^0$ - $\square_H^G$  3 position exhaust center: VQ545 $_1^0$ - $\square_H^G$ 

3 position pressure center: VQ555¹-□H




3 position double check: VQ565<sup>0</sup><sub>1</sub>-□<sup>G</sup><sub>H</sub>





# Series VQ5000 Base Mounted Plug-in Unit



Terminal block box

IP65 compatible

2 to 12 stations

Box mounting

position

D side U side

TU

TD

Q DeviceNet, CompoBus/D (OMRON Corp.)

R1 OMRON Corp.: CompoBus/S System (16 output points)

R2 OMRON Corp.: CompoBus/S System (8 output points)

JEMANET (JPCN-1)
Mitsubishi Electric Corp.: CC-LINK System
Rockwell Automation: Allen Bradley Remote I/O (RIO) System

NKE Corp.: Uni-wire H System

SQ

VQ0

VQ4

VQ5

**VQZ** 

VQD

### **Manifold Specifications**

				Porting specifica	ations	Maximum	Applicable		
Series	Base model	Type of connection	4(A), 2(B)	Port size Note)		applicable	solenoid	5 station weight (kg)	
			port location	1(P), 5(R1), 3(R2)	4(A), 2(B)	stations	valve	(Ng)	
VQ5000	VV5Q51-□□□	■ F kit–D-sub connector ■ T kit–Terminal block box ■ T1 kit–Individual terminal block kit ■ L kit–Lead wire ■ S kit–Serial transmission	Side	Rc 3/4 Option Direct exhaust with silencer box	Rc 3/8 Rc 1/2	F, L, T1 kits 12 stations T kit 11 stations S kit	VQ5L00 VQ5L01	4.1  L kit  Not including solenoid valve	
			Bottom	Silericer box	Rc 1/2	9 stations		weight.	


Note) For details about international standard threads other than Rc threads, refer to "Option" on page 2-6-39.

### Flow Characteristics at the Number of Manifold Stations (Operated individually)

Model	Passage/Statio	ons	Station 1	Station 5	Station 10
		C [dm <sup>3</sup> /(s·bar)]	11	11	11
	$1 \rightarrow 4/2 \; (P \rightarrow A/B)$	b	0.24	0.24	0.24
2 position metal seal		Cv	2.7	2.7	2.7
VQ5 <sup>1</sup> <sub>2</sub> 00		C [dm <sup>3</sup> /(s·bar)]	12	12	12
	$4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{EA/EB)}$	b	0.14	0.14	0.14
		Cv	2.9	2.9	2.9
		C [dm <sup>3</sup> /(s·bar)]	12	12	12
	$1 \rightarrow 4/2 \ (P \rightarrow A/B)$	b	0.33	0.33	0.33
2 position rubber seal		Cv	3.4	3.4	3.4
VQ5 <sub>2</sub> 101		C [dm <sup>3</sup> /(s·bar)]	16	16	16
	$4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{EA/EB)}$	b	0.33	0.33	0.33
		Cv	4.4	4.4	4.4

Note) For port size Rc 1/2

### **Manifold Option**



• Refer to pages 2-6-34 to 2-6-38 for detailed dimensions of each option.

• For replacement parts, refer to page 2-6-43.

# Kit (D-sub Connector kit)

- Simplification and labor savings for wiring work can be achieved by using a D-sub connector for the electrical connection.
- Using connector for flat ribbon cable (25P) conforming to MIL standard permits the use of connectors put on the market and gives a wide interchangeability.
- Connector entry can be selected on either the U side or the D side according to the mounting orientation.
- Maximum stations are 12.

**Manifold Specifications** 

	Po	าร		
Series	4(A), 2(B)	Port siz	e	Applicable stations
	port	1(P), 5(R1), 3(R2)	4(A), 2(B)	Stations
VQ5000	Side	Rc 3/4	Rc 3/8 Rc 1/2	Max. 12 stations
	Bottom		Rc 1/2	


### **D-Sub Connector Kit (25Pins)**

### Cable assembly ●



D-sub connector cable assemblies can be ordered with manifolds.

Refer to How to Order Manifold.



# D-sub Connector Cable Assembly (Option)

length (L)	Assembly part no.	Note
1.5 m	AXT100-DS25-015	Cable 25 cores
3 m	AXT100-DS25-030	x 24AWG
5 m	AXT100-DS25-050	X 2-1/W G

 For other commercial connectors, use a 25 pins type with female connector conforming to MIL-C-24308.

Connector manufacturers' example

- Fujitsu, Ltd.
- Japan Aviation Electronics Industry, Ltd.
- J.S.T. Mfg. Co., Ltd.
- Hirose Electric Co., Ltd.

### Electric Characteristics


Item	Characteristics
Conductor resistance $\Omega$ /km, 20°C	65 or less
Voltage limit VAC, 1 min.	1000
Insulation resistance MΩkm, 20°C	5 or less

Note) The min. bending radius of D-sub cable is 20 mm.

# D-sub Connector Cable Assembly Terminal No.

Terminal no.	Lead wire color	Dot marking		
1	Black	None		
2	Brown	None		
3	Red	None		
4	Orange	None		
5	Yellow	None		
6	Pink	None		
7	Blue	None		
8	Purple	White		
9	Gray	Black		
10	White	Black		
11	White	Red		
12	Yellow	Red		
13	Orange	Red		
14	Yellow	Black		
15	Pink	Black		
16	Blue	White		
17	Purple	None		
18	Gray	None		
19	Orange	Black		
20	Red	White		
21	Brown	White		
22	Pink	Red		
23	Gray	Red		
24	Black	White		
25	White	None		





SQ


VQ0

VQ4

VQ5

VQZ

VQD



Stations are counted starting from the first station on the D side.

#### Electrical wiring specifications Standard wiring D-sub connector assembly (AXT100-DS25- 030 ) Wire colors D-sub connector Terminal no. Polarity Lead wire Dot marking color SOL.A 0 1 Black None (-)(+)SOL.B 0 14 1 station Black (-)(+) Yellow 14 () SOL.A 0 2 02 15 O (-)(+) Brown None SOL.B 0 15 2 stations 03 16 () Pink Black (-)(+)SOL.A O 3 04 170 (-)(+) Red None 0.5 SOL.B 0 16 3 stations 18 () White 06 (-)(+)Blue SOL.A 0 4 19 O 07 Orange None (-)(+) 20 O SOL.B ○ 17 4 stations 08 (+)Purple None 21 () SOL.A o 5 0 22 O (-)(+) Yellow None SOL.B 0 18 5 stations 23 O Gray None (-)(+) 011 SOL.A 0 6 24 O (+)Pink None SOL.B 0 19 0 12 6 stations 25 () (-)Orange Black O 13 (+)SOL.A O 7 (-)(+) None SOL.B 0 20 7 stations (-)(+) Red White SOL.A 0 8 Purple White (-)(+)SOL.B 8 stations White (-)(+) Brown SOL.A 0 9 Black (-)(+)Grav SOL.B 0 22 Connector terminal no. 9 stations Red (-)Pink (+)SOL.A 0 10 Double wiring (connected to (-)(+)White Black SOL.B 023 SOL. A and SOL. B) is adopted 10 stations Red (-)(+)Grav SOL.A for the internal wiring of each White Red (-)(+)station, regardless of valve and SOL.B 024 11 stations Black White option types. (-)(+)SOL.A 0 12 Mixed single and double wiring Yellow (-)(+)Red SOL.B 0 25

### **Special Wiring Specifications**

Double wiring (connected to SOL. A and SOL. B) is used for the internal wiring of each station regardless of valve and option types. Mixed single and double wiring is available as an option.

#### 1. How to Order

Indicate option symbol "-K" in the manifold part number and be sure to specify station positions for single or double wiring on the manifold specification sheet.

### 2. Wiring specifications


12 stations

It can also be used as a negative common.

Connections begin with the A side solenoid of the first station being connected to terminal no. 1, and continue in the order indicated by the arrows in the drawing without skipping any terminals.

COM. ○ 13


However, the maximum number of stations



None

Red

D-sub connector



specified, indicate them alphabetically.

is available as an option. For

Note) There is no polarity.

details, refer to below

### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

### D-sub connector kit with cable (3 m)

(+)

(-)

common specifications specifications


(+)

Positive


White

Orange


Note)




Enter in order starting from the first station on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.



### Kit (D-sub Connector kit)





SQ

VQ0


VQ4

VQ5

**VQZ** 

**VQD** 

### **Bottom ported drawing**



**Dimensions** 

Formula: L1 = 41n + 76, L2 = 41n + 96 n: Stations (Maximum 12 stations)

L	1	2	3	4	5	6	7	8	9	10	11	12
L <sub>1</sub>	117	158	199	240	281	322	363	404	445	486	527	568
L2	137	178	219	260	301	342	383	424	465	506	547	588

# Kit (Terminal block box kit)

**IP65** compliant

- Enclosure IP65 compliant
- This type has a small terminal block inside a junction box.
   The provision of a G 3/4 electrical entry allows connection of conduit fittings.
- Maximum stations are 11. (12 stations as an option)
- •1 station is used for terminal block box mounting.


### **Manifold Specifications**

	Po				
Series	4(A), 2(B)	Port size	Applicable stations		
	port location	1(P), 5(R1), 3(R2)	4(A), 2(B)	Stations	
VQ5000	Side	Rc 3/4	Rc 3/8 Rc 1/2	Max. 12 stations	
	Bottom		Rc 1/2	Stations	

### **Terminal Block Connections**

#### Step 1. How to remove terminal block cover

Loosen the 4 mounting screws (M4) and open the terminal block cover.



### Step 3. How to attach the terminal block cover


Securely tighten the screws with the torque shown in the table below, after confirming that the gasket is installed correctly.

Proper tightening torque (N·m)
0.7 to 1.2

Step 2. The diagram on the right shows the terminal block wiring.


All stations are provided with double wiring regardless of the valves which are mounted.


Connect each wire to the power supply side, according to the markings provided inside the terminal block.



Applicable terminal 1.25-3s, 1.25Y-3, 1.25Y-3N, 1.25Y-3.5


### **How to Order Manifold**





Stations are counted starting from the first station on the D side.

Electrical wiring specifications (IP65 available)



### **Special Wiring Specifications**


Double wiring (connected to SOL. A and SOL. B) is used for the internal wiring of each station regardless of valve and option types. The optional specification permits mixture of single and double wiring. However, the maximum number of stations is 12.


#### 1. How to Order

Indicate option symbol ("-K") in the manifold part number and be sure to specify station positions for single or double wiring on the manifold specification sheet.

### 2. Wiring specifications

Connections begin with the A side solenoid of the first station being connected to terminal no. 1, and continue in the order indicated by the arrows in the drawing without skipping any terminals.





Note 2) Refer to page 2-6-39 for details

alphabetically.

on external pilot specifications. Note 3) When two or more symbols are specified, indicate them

### **How to Order Manifold Assembly**


Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example>

### Terminal block box kit

VV5Q51-0603TU ···· 1 set -- Manifold base part no. \* VQ5100-5 ..... 2 sets—Valve part no. (Stations 1 and 2) \* VQ5200-5 ..... 2 sets-Valve part no. (Stations 3 and 4) \* VQ5300-5 ...... 1 set —Valve part no. (Station 5) Prefix the asterisk to the part nos. of the solenoid valve, etc. Enter in order starting from the first station

on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.





6

12 VDC

VQ5

VQZ

VQC

SQ

VQ0


VQ4

VQD

2-6-15

# П

### Kit (Terminal block box kit)



SQ

VQ0


VQ4


VQ5

**VQZ** 

VQD

### **Bottom ported drawing**





 $\begin{array}{c} Formula: \, L1 = 41n + 76, \, L2 = 41n + 96 \\ n: \, Stations \, (Maximum \, 12 \, stations) \\ \hline \textbf{Dimensions} \\ * \, Including \, 1 \, station \, for \, terminal \, box \, mounting. \end{array}$ 

						-					
	2	3	4	5	6	7	8	9	10	11	12
L1	158	199	240	281	322	363	404	445	486	527	568
L2	178	219	260	301	342	383	424	465	506	547	588

# Kit (Individual terminal block kit)


Ī		Po	A Ii a a la la		
	Series	4(A), 2(B)	Port s	Applicable stations	
		port location	1(P), 5(R1), 3(R2)	4(A), 2(B)	Stations
	VQ5000	Side	Rc 3/4	Rc 3/8, 1/2	Max. 12 stations
		Bottom		Rc 1/2	


is installed in the manifold block. Lead wire from a solenoid is
connected with the terminals on the terminal box in the bottom
side. (The terminal box is connected with lead wire for both SOL.
A and SOL. B and they correspond with the marking 1, 2, 3, 4 on
the terminal box. Refer to how to connect with the terminal box.)
Maximum atations are 10


### **Terminal Block Connections**


Terminal block marking Model	1	3	2	4
VQ510 <sub>1</sub> 0	A side +	A side –		
VQ520 <sup>0</sup>	A side +	A side –	B side +	B side –
VQ5 <sup>3</sup> <sub>4</sub> 0 <sup>0</sup>	A side +	A side –	B side +	B side –

- · Compatible crimp terminals: 1.25-3S, 1.25Y-3, 1.25Y-3N, 1.25Y-3.5
- · There is no polarity (+, -).











### **How to Order Manifold**





SQ


VQ0

VQ4

VQ5

VQZ

VQD



Note 3) When two or more symbols are specified, indicate them

alphabetically.

### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example> Individual terminal block kit

VV5Q51-0503T1... 1 set —Manifold base part no.


\*VQ5100-5 ........ 2 sets—Valve part no. (Stations 1 and 2)

\*VQ5200-5 ........ 2 sets—Valve no. (Stations 3 and 4)

\*VQ5300-5 ....... 1 set —Valve part no. (Station 5)


Prefix the asterisk to the part nos. of the solenoid valve, etc.


Enter in order starting from the first station on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.



# Τí

### Kit (Individual terminal block kit)





SQ

VQ0


VQ4


VQ5

VQZ

VQD

### **Bottom ported drawing**





### **Dimensions**

Formula: L1 = 41n + 76, L2 = 41n + 96n: Stations (Maximum 12 stations)

L	1	2	3	4	5	6	7	8	9	10	11	12
L <sub>1</sub>	117	158	199	240	281	322	363	404	445	486	527	568
L2	137	178	219	260	301	342	383	424	465	506	547	588

# Kit (Lead wire cable)


IP65 compliant


- Enclosure IP65 compliant
- Direct electrical entry type available with two or more stations.
- Electrical entry can be selected on either the U side or the D side according to the mounting orientation.
- Maximum stations are 12.


### **Manifold Specifications**


	Po			
Series	4(A), 2(B)	Port siz	Applicable stations	
	port location	1(P), 5(R1), 3(R2)	4(A), 2(B)	Stations
VQ5000	Side	Rc 3/4	Rc 3/8 Rc 1/2	Max. 12 stations
	Bottom		Rc 1/2	

### Wiring Specifications









are specified, indicate them

alphabetically.

### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

### <Example> Lead wire kit with cable (3 m)

VV5Q51-0503LD2 ···1 set —Manifold base part no.


\*VQ5100-5 ·········2sets —Valve part no. (Stations 1 and 2)

\*VQ5200-5 ··········2 sets —Valve part no. (Stations 3 and 4)


\*VQ5300-5 ··········1 set —Valve part no. (Station 5)

Prefix the asterisk to the part nos. of the solenoid valve, etc.


Enter in order starting from the first station on the D side. When entry of part numbers becomes complicated, indicate in the manifold specification sheet.



# Kit (Lead wire cable)



### **Bottom ported drawing**



### **Dimensions**


Formula:  $L_1 = 41n + 76$ ,  $L_2 = 41n + 96$ n: Stations (Maximum 12 stations)

L	1	2	3	4	5	6	7	8	9	10	11	12
L <sub>1</sub>	117	158	199	240	281	322	363	404	445	486	527	568
L2	137	178	219	260	301	342	383	424	465	506	547	588

### Kit (Serial transmission unit)

**IP65** compliant

- The serial transmission system reduces wiring work, while minimizing wiring and saving space.
- The system is available in types such as the type SA for equipment with a maximum of 32 input/output points (a general purpose type for small scale systems), the type SB capable of controlling up to 512 points of input/output (Mitsubishi Electric compatible), the type SC (OMRON compatible), the type SD (SHARP compatible, 504 points max.), the type SF (NKE compatible, 128 points max.), the type SJ (SUNX compatible), the type SK (Fuji Electric compatible), the type SQ (OMRON Compo Bus/D compatible), and the type SR (OMRON Compo Bus/S compatible).
- Maximum 9 stations (12 stations available as an option. Indicate 10 to 12 stations on the manifold specification sheet.)
- One station is used for serial unit mounting.




- Stations are counted from station 1 on the D
- Double wiring (connected to SOL. A and SOL. B) is adopted for the internal wiring of each station, regardless of valve and option types. Mixed single and double wiring is available as an option.

Item	Specifications
External power supply	24 VDC +10%, -5%
Current consumption (Internal unit)	SA, SB, SBB, SD, SF, SJ, SK, SQ, SR, SV: 0.1A SC: 0.3A

### **Manifold Specifications**


	F			
Series	4(A), 2(B) port	Port siz	Applicable stations	
	location	1(P), 5(R1), 3(R2)	4(A), 2(B)	
VQ5000	Side	Rc 3/4	Rc 3/8 Rc 1/2	Max. 9 stations
	Bottom		Rc 1/2	

### Type SA With general type SI unit (Series EX300)



LED	Description
TRD	Lighting during data reception
RUN/ERR	Blinking when received data is normal; Lighting when data reception

### Type SB Mitsubishi Electric Corporation MELSECNET/MINI-S3 Data Link System



LED	Description					
POWER	Lighting when power is turned ON					
RUN	Lighting when data transmission with the master station is normal					
RD	Lighting during data reception					
SD	Lighting during data transmission					
ERR.	Lighting when reception data error occurs.  Light turns off when the error is corrected.					


• T unit

Name of terminal block (LED)

Note

- Can be connected with PLC I/O card for serial transmission
- EX300-TMB1..... For models of Mitsubishi **Electric Corporation** EX300-TTA1..... For OMRON
- EX300-TFU1..... For Fuji Electric EX300-T001 ...... General purpose
- \* T units have 32 control points per unit • No. of output points, 16 points
- Master station
  - PLC made by Mitsubishi Electric Corporation Series MELSEC-A AJ71PT32-S3, AJ71T32-S3 A1SJ71PT32-S3
- \*Max. 64 stations, connected to remote I/O stations (Max. 512 points).
- No. of output points, 16 points. No. of sta. occupied, 2 stations
- \* For details on specifications and handling, refer to the separate technical instruction manual.

### **How to Order Manifold**



Cylinder port

03 Rc 3/8 04 Rc 1/2 В Bottom ported Rc 1/2 СМ Mixed

# R2 OMRON Corp.: CompoBus/S System (8 output points) JEMANET (JPCN-1) U Mitsubishi Electric Corp.: CC-LINK System G Rockwell Automation: Allen Bradley Remote I/O (RIO) System

NKE Corp.: Uni-wire H System

### SI unit mounting position

D side mounting D U side mounting

н

### Option

_						
Symbol	Option					
Nil	None					
CD1 (2)	Exhaust cleaner for Rc 1: D side exhaust					
CD2 (2)	Exhaust cleaner for Rc 11/2: D side exhaust					
CU1 (2)	Exhaust cleaner for Rc 1: U side exhaust					
CU2 (2)	Exhaust cleaner for Rc 11/2: U side exhaust					
<b>K</b> (3)	Special wiring specifications (Except double wiring)					
<b>SD</b> (2)	Direct exhaust with silencer box: D side exhaust					
SU (2)	Direct exhaust with silencer box: U side exhaust					
W	IP65 enclosure					



Note 1) When two or more symbols are specified, indicate them alphabetically. Example) -CD1K. Note 2) Combination of  $[C_U^D \square]$  and  $[S_U^D]$  is not possible.

Note 3) Specify the wiring specifications on the manifold specification sheet.

SQ

VQ0

VQ4

VQ5

VQZ


VQD


#### • Correspondence of SI unit output numbers and solenoid valve coils

Mixed wiring is available as an option. Use the manifold specification sheet to specify.

<Wiring example 1> Double wiring (Standard)

<Wiring example 2> Single/Double mixed wiring (Option)





	0 ± 0 ω	4 5 9 C 8 8 6 C 7 C 7 C 7 C 7 C 7 C 7 C 7 C 7 C 7 C		O+0% 4		
		Type SC OMRON Corporation SYSBUS Wire System	Type SD SHARP Corporation Satellite I/O Link System			
Name of terminal block (LED)	244	ADDRESS NO.	POWER RAN SO RD ERR 010 01 01 01 01 01 02 056			
na	LED	Description	LED	Description		
Ē	RUN	Lights when transmission is normal	POWER	ON when power supply is ON		
of te	T/R	and PLC is in operation mode		Lights when power is ON and slave stations are operating normally		
Name ERR		ON when transmission is abnormal.	ERROR	Lights when slave station switch setting is abnormal, communication is abnormal, PLC stopped and defective slave unit		
			R.SET HOLD	ON for master unit control input		
Note	OMRON SYSMA Types C *32 units connect	station unit N PLC C C(CV) series 5500-RM201 and C200H-RM201 max., transmission terminal tion (512 points max.) utput points, 16 points	Master station unit     SKARP Corporation PLC     New Satellite Series W ZW-31LM     New Satellite Series JW JW-23LM, JW-31LM     * Max. 31 units, I/O slave stations connected     (504 points max.)     No. of output points, 16 points			

#### **How to Order Valves** VQ 5 Series • **Enclosure** VQ5000 Dusttight Dusttight/Low jetproof type Type of actuation (IP65) 2 position single 2 position double Manual override 3 3 position closed center Nil Non-locking push type (Tool required) 3 position exhaust center Locking type (Tool required) 5 3 position pressure center 3 position double check Coil voltage 24 VDC **Function** Seal e Nil Standard type (1 W) Metal seal Y (1) Low wattage type (0.5 W) Rubber seal **R**<sup>(2)</sup> External pilot Note 1) Applicable to DC specification. Note 2) Refer to page 2-6-39 for details on external pilot specifications. Note 3) When two or more symbols are specified, indicate them alphabetically.


### **How to Order Manifold Assembly**

Specify the part numbers for valves and options together beneath the manifold base part number.

#### <Example> Serial transmission unit


VV5Q51-0603SUA ··· 1 set —Manifold base part no. \*VQ5100-5 · 2 sets —Valve part no. (Stations 1 and 2) \*VQ5200-5 · 2 sets —Valve part no. (Stations 3 and 4) \*VQ5300-5 ·· 1 set —Valve part no. (Station 5) Prefix the asterisk to the part nos. of the solenoid valve, etc. Enter in order starting from the first station on the D side. When entry of part numbers

becomes complicated, indicate in the manifold specification sheet.



# S

### Kit (Serial transmission unit)



Note) In the case of two power supply systems (separate SI unit and solenoid drive power supplies), there are conduit ports (G 1/2) in four locations.

Other models have conduit ports in two locations.

SQ

VQ0


VQ4


VQ5

**VQZ** 

**VQD** 

### **Bottom port drawing**





Formula: L1 = 41n + 76, L2 = 41n + 96 n: Stations (Maxium 12 stations)

Dimensions


\* Including 1 station for SI unit box mounting


		<u> </u>									
Ln	2	3	4	5	6	7	8	9	10	11	12
L <sub>1</sub>	158	199	240	281	322	363	404	445	486	527	568
L2	178	219	260	301	342	383	424	465	506	547	588



# **Base Mounted**

# Plug Lead Unit: C Kit (Connector Kit)







length 1.5 m

200 VAC (50/60 Hz)

110 VAC (50/60 Hz)

24 VDC

12 VDC

SQ

VQ0

VQ4

VQ5

**VQZ** 

VQD

### **Manifold Specifications**

			Po	orting specificatio	ns	Maximum	Applicable solenoid valve		
Series Base model		Type of connection	4(A), 2(B)	Port size Note)		applicable		5 station weight (kg)	
	port location		1(P), 5(R1), 3(R2)	4(A), 2(B)	stations		(1.9)		
VQ5000 VV5Q55-□□□	■ C kit–Grommet	Side	Rc 3/4  Option  (Direct exhaust)  with silencer box	Rc 3/8 Rc 1/2	2 to 12 stations	VQ5□50 VQ5□51	3.7 • Except solenoid valve weight		
		Bottom		Rc 1/2					


Note) For details about international standard threads other than Rc threads, refer to "Option" on page 2-6-39.

### Flow Characteristics at the Number of Manifold Stations (Operated individually)

Model	Passage/Statio	ns	Station 1	Station 5	Station 10
		C [dm <sup>3</sup> /(s·bar)]	11	11	11
	1 → 4/2 (P → A/B)	b	0.24	0.24	0.24
2 position metal seal		Cv	2.7	2.7	2.7
VQ5 <sup>1</sup> <sub>2</sub> 00		C [dm <sup>3</sup> /(s·bar)]	12	12	12
	$4/2 \rightarrow 5/3 \text{ (A/B} \rightarrow \text{EA/EB)}$	b	0.14	0.14	0.14
		Cv	2.9	2.9	2.9
		C [dm <sup>3</sup> /(s·bar)]	12	12	12
	$1 \rightarrow 4/2 \ ( \rightarrow RA/B)$	b	0.33	0.33	0.33
2 position rubber seal		Cv	3.4	3.4	3.4
VQ5 <sub>2</sub> <sup>1</sup> 01		C [dm <sup>3</sup> /(s·bar)]	16	16	16
	4/2 → 5/3 (A/B → EA/EB)	b	0.33	0.33	0.33
		Cv	4.4	4.4	4.4


Note) For port size Rc 1/2


### **Manifold Option**




• Refer to pages 2-6-34 to 2-6-39 for detailed dimensions of each option. For replacement parts, refer to page 2-6-43.

# C Kit (Connector)





### **Bottom ported drawing**



### **Dimensions**

Formula:  $L_1 = 41n + 76$ ,  $L_2 = 41n + 96$ n: Stations (Maximum 12 stations)


								_				
L	1	2	3	4	5	6	7	8	9	10	11	12
L <sub>1</sub>	117	158	199	240	281	322	363	404	445	486	527	568
L2	137	178	219	260	301	342	383	424	465	506	547	588

### **Manifold Option Parts**


### Blanking plate assembly

### VVQ5000-10A-1 (Plug-in type) VVQ5000-10A-5 (Plug lead type)

It is used by attaching on the manifold block for being prepared for removing a valve for maintenance reasons or planning to mount a spare valve, etc.




Plug-in type Plug lead type




### **Individual SUP spacer**

### VVQ5000-P-1-03 (Plug-in type) VVQ5000-P-5-03 (Plug lead type)

By mounting individual SUP spacers on a manifold block, it is possible to provide individual supply ports for each valve.




Plug-in type Plug llead type




### Individual EXH spacer

VVQ5000-R-1-03 (Plug-in type) VVQ5000-R-5-03 (Plug lead type)

By mounting individual EXH spacers on a manifold block, exhaust ports can be provided individually for each valve. (Common EXH type)



Plug-in type Plug lead type



SQ

VQ0

VQ4

VQ5

**VQZ** 

VQD


### Throttle valve spacer


### VVQ5000-20A-1 (Plug-in type) VVQ5000-20A-5 (Plug lead type)

A throttle valve spacer is mounted on a manifold block to control cylinder speed by throttling exhaust air flow.









Plug-in type

Plug lead type


### SUP stop valve spacer

### VVQ5000-37A-1 (Plug-in type) VVQ5000-37A-5 (Plug lead type)


A SUP stop valve spacer is mounted on a manifold block, making it possible to individually shut off supply air to each valve.







Circuit diagram




Plug-in type


Plug lead type


### Release valve spacer: For D side mounting

### VVQ5000-24A-1D (Plug-in type) VVQ5000-24A-5D (Plug lead type)


A VQ51□□ (single) valve can be used as an air release valve by combining it with a release valve spacer. Note) 2 position double and 3 position cannot be mounted.







Circuit diagram





Plug-in type

Plug lead type

#### SUP block plate **EXH block plate** VVQ5000-16A-1 VVQ5000-16A-2


When different pressures, high and low, are supplied to manifold, a SUP block plate is inserted between the stations under different pressures.





< SUP blocking plate >

< EXH blocking plate >



SUP passage blocked EXH passage blocked SUP/EXH passage blocked

### **Manifold Option Parts**

### Double check spacer with residual pressure release valve

### VVQ5000-25A-1 (Plug-in type) VVQ5000-25A-5 (Plug lead type)


Can hold an intermediate cylinder position for an extended time.

When combined with a double check spacer with built-in double check valve, it is unaffected by air leakage between the spool valves, making it possible to hold a cylinder at an intermediate stopping position for an extended time.

Further, a combination of a 2 position type (VQ5½ □□) and a double check spacer can be used for drop prevention.

### Plug-in type

Plug lead type



### **Specifications**

Double check	VVQ5000-25A- <sub>5</sub>					
spacer part no.	Intermediate stop	Drop prevention				
Applicable solenoid valve	VQ54□□	VQ5 <sup>1</sup> □□				

Leakage N cm³/min	One solenoid	1(P)	5 (R1)	320 or less
	energized	.(.,	3 (R2)	020 01 1000
		1(0)	5 (R1)	320 or less
	Both solenoids unenergized	1(P)	3 (R2)	320 01 less
		4(A)	5 (R1)	•
		2(B)	3 (R2)	U

<sup>\*</sup> Supply pressure: 0.5 MPa

### **⚠** Caution

### **Handling Precautions**

- In the case of 3 position double check (VZS65%0), check the leakage from piping and fittings in between valve and cylinder by means of synthetic detergent solutions, and ensure that there is no such leakage found there. Also check the leakage from cylinder seal and piston seal. If there is any leakage, sometimes the cylinder, when valve is de-energized, can move without stopping at intermediate position.
- Use caution, as excessive throttling of the double check spacer exhaust can cause a loss of intermediate stopping accuracy and malfunction.
- Combination with a 3 position VQ5₅□□ is not possible.
- Set the cylinder load so that the cylinder pressure will be within two times that of the supply pressure.

### Direct exhaust with silencer box

VV5Q5<sub>5</sub><sup>1</sup>-□□□-SD (D side exhaust)


VV5Q5<sub>5</sub><sup>1</sup>-□□□-SU (U side exhaust)


VV5Q5<sup>1</sup>/<sub>5</sub>-□□□-SB (Double side exhaust)


The EXH outlet is placed on the top side of the manifold end plate. The built-in silencer provides highly effective noise reduction. (Noise reduction of 35 dB or more)





Note) Note that when excessive drainage occurs in the air supply, the drainage will be released along with the exhaust.












Note) The drawing shows a VV5Q51-□□□-SD.

### Manifold mounted exhaust cleaner

### VV5Q5₅-□□□-CD (D side mounting) VV5Q5₅-□□□-CU (U side mounting)

An adapter plate for exhaust cleaner mounting is provided on the top of the manifold end plate. The exhaust cleaner collects drainage and oil mist (99.9% or more) and is highly effective for noise

(Noise reduction of 35 dB or more)




### Applicable exhaust cleaners

### AMC610-10 (Port size Rc 1), AMC810-14 (Port size Rc 11/2)

Note 1) Exhaust cleaner: AMC610-10 and MC810-14 are not included. (Order separately)
Note 2) Mount so that the exhaust cleaner is at the lower side.

Note 3) For details about the exhaust cleaner, refer to Best Pneumatics vol.5.



## **VQC**

SQ

VQ0


VQ4

VQ5

**VQZ** 

**VQD** 

### Plug lead type



### Dimensions

Formula: L1 = 41n + 76, L2 = 41n + 96

n: Stations (Maximum 12 stations)					ations)						
L n	2	3	4	5	6	7	8	9	10	11	12
L <sub>1</sub>	158	199	240	281	322	363	404	445	486	527	568
L <sub>2</sub>	178	219	260	301	342	383	424	465	506	547	588

### **Dimensions**

Formula: L1 = 41n + 76, L2 = 41n + 96n: Stations (Maximum 12 stations)

L	2	3	4	5	6	7	8	9	10	11	12
L <sub>1</sub>	158	199	240	281	322	363	404	445	486	527	568
L2	178	219	260	301	342	383	424	465	506	547	588

### Series VQ5000

### **Manifold Option Parts**

Interface regulator (P, A, B port regulation)

ARBQ5000-00-□-1 (Plug-in type) ARBQ5000-00-□-5 (Plug lead type)

By mounting a spacer regulator on the manifold block, it enables to regulate pressure per every valve.

### **Specifications**

Interface regulator		ARBQ5000						
Regulating port		-	A	В		Р		
Applicable solenoid valve		Plug-in	Plug lead	Plug-in	Plug lead	Plug-in	Plug lead	
Maximum operating pressure			1.0 MPa					
Set pressure range			0.05 to 0.85 MPa					
Fluid		Air						
Ambient and fluid temperature	Ambient and fluid temperature		−5 to 60°C (No freezing)					
Port size for connection of pressur	e gauge	M5 x 0.8						
Weight (kg)		0.79	0.74	0.78	0.73	0.79	0.74	
Effective area at supply side (mm²)	$P \rightarrow A$	33		75		29		
S at P1 = 0.7 MPa/P2 = 0.5 MPa	$P \rightarrow B$	64		33		28		
Effective area at exhaust side (mm²)	$A \rightarrow EA$	3	36	75		78		
S at P2 = 0.5 MPa	$B \rightarrow EB$	6	88	3	38	69		





- Note 1) Set the pressure within the operating pressure range of the solenoid valve.
- Note 2) Use a spacer regulator by pressurizing from the P port on the base except the case of being used as a dual pressure valve. Besides, P port regulation is not allowed to use.
- Note 3) When using a perfect spacer, assemble a valve, a spacer regulator and a perfect spacer in this order to use it.
- Note 4) When using in A port regulation, B port regulation by closed center, since there is a problem in its operation, please contact SMC.
- Note 5) Dusttight/splash proof enclosure (IP65) is not available with interface regulator.

### **How to Order**

Solenoid valve	Interface regulator	Regulating port
	ARBQ5000-00-A-1	Α
VQ5□0□ (Plug-in type)	ARBQ5000-00-B-1	В
	ARBQ5000-00-P-1	Р
VQ5⊡5⊡ (Plug lead type)	ARBQ5000-00-A-5	Α
	ARBQ5000-00-B-5	В
	ARBQ5000-00-P-5	Р

### **Dimensions**






# Characteristics of the second


### Flow Characteristics

### **Conditions Inlet pressure: 0.7 MPa**


ARBQ5000-00-A (P → A)




### ARBQ5000-00-B (P → B)



### ARBQ5000-00-P (P $\rightarrow$ A)




### ARBQ5000-00-P (P $\rightarrow$ B)



### **Pressure Characteristics**

**Conditions** 

Inlet pressure: 0.7 MPa Outlet pressure: 0.2 MPa Flow rate: 20 ∉min(ANR)



VQC

SQ

VQ0

VQ4

VQ5

VQZ

VQD

### **Option**

### **External Pilot Specifications**


When the supply pressure is

- lower than the minimum solenoid valve operating pressure of 0.1 to 0.2 MPa, or when it drops below this level,
- used for reverse pressure (R port pressure) or cylinder pressure (A, B port pressure).
- used for vacuum specifications (please contact SMC), it can be used for external pilot specifications.

Order a valve by adding the external pilot specification [R] to the part number

External pilot is available as standard for manifolds and options.

### **How to Order Manifold**



Note) Mixed mounting of internal and external pilots is possible

### **Pressure Specifications**

Valve construction		Metal seal	Rubber seal		
Operating pressure range		Vacuum to 1.0 MPa			
External pilot Note) pressure range	Single	0.1 to 1.0 MPa	0.2 to 1.0 MPa (0.2 to 0.7 MPa)		
	Double	(0.1 to 0.7 MPa)	0.15 to 1.0 MPa (0.15 to 0.7 MPa)		
	3 position	0.15 to 1.0 MPa (0.15 to 0.7 MPa)	0.2 to 1.0 MPa (0.2 to 0.7 MPa)		


Note ) Values inside ( ) denote the low wattage (0.5 W) specifications.

### International Thread Standards Other than Rc


Rc specifications are standard for all ports, however, NPT, NPTF and G are available for international markets.

Add the appropriate symbol following the port size in the standard part number


### **How to Order Single Valves (Example)**



### **How to Order Manifold**




### **How to Order Sub-plates and Options (Example)**



# Series VQ5000 Construction


### **Plug-in Unit**



### **Component Parts**

Number	Description	Material	Note			
1	Body	Aluminum die-casted				
2	Spool/Sleeve	Stainless steel				
3	Piston	Resin				
Rep	Replacement Parts					

### \* Coil rated voltage VQZ111P-□ Pilot valve assembly Example) 24 VDC: 5




### **Component Parts**

Number	Description	Material	Note				
1	Body	Aluminum die-casted					
2	Spool valve	Aluminum, NBR					
3	Piston	Resin					
Rep	Replacement Parts						
4	Pilot valve assembly	VQZ111P-□	* Coil rated voltage Example) 24 VDC: 5				

# Series VQ5000

# Construction


### **Plug Lead Unit**





	•		
Number	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool/Sleeve	Stainless steel	
3	Piston	Resin	

	Replacement Parts					
	4	Pilot valve assembly	VQZ111P-□	* Coil rated voltage Example) 24 VDC: 5		



### **Component Parts**

Number	Description	Material	Note
1	Body	Aluminum die-casted	
2	Spool valve	Aluminum, NBR	
3	Piston	Resin	

### **Replacement Parts**

4	Pilot valve assembly	VQZ111P-□	* Coil rated voltage Example) 24 VDC: 5
---	----------------------	-----------	--

**VQC** 

SQ

VQ0


VQ4

VQ5

VQZ

VQD

# Series VQ5000 Exploded View of Manifold




Note) The electrical entry cannot be changed.

The drawing shows a plug-in type.

# Exploded View of Manifold Series VQ5000

### <D Side End Plate Assembly>

1. D side end plate assembly part no. (for F, L, S, T & T1 kits)




Nil	Standard	
<b>W</b> <sup>(2)</sup>	<b>W</b> <sup>(2)</sup> IP65 enclosure is dust	
CD1 Exhaust cleaner mounting Rc 1		
CD2 Exhaust cleaner mounting Rc 1 1/		
SD	Direct exhaust with silencer box	

Note 1) D-sub connector is not included. Note 2) Splashproof specifications is not available for F and T1.

### <Manifold Block Assembly>

3. Manifold block assembly part no.



03

В

Rc 1/2 Bottom ported Rc 1/2

F1	F kit Double wiring
F2	F kit Single wiring
T0	T1 kit (Individual terminal block) Double wiring
T1	T kit (Terminal box) Double wiring
T2	T kit (Terminal box) Single wiring
S1	S kit Double wiring
S2	S kit Single wiring
L0□	L0 kit □: Stations (1 to 12)
L1 🗆	L1 kit □: Stations (1 to 12)
L2□	L2 kit □: Stations (1 to 12)
С	C kit (Plug lead type)

Note 1) Tie-rods (2 pcs.) and lead wire assembly for station addition included.


Note 2) Splashproof specifications is not available for F and T1.

### <SI Unit>

### SI Unit Part No.

T	Madalaymbal	SI unit	part no.	Description
Type	Model symbol	For U side mounting	For D side mounting	Description
	Α	EX323U-S001	EX323D-S001	General type SI unit (Series EX300)
	В	EX123U-SMB1	EX123D-SMB1	Mitsubishi Electric Corporation: MELSECNET/MINI-S3 Data Link System
	BB	EX124U-SMB1	EX124D-SMB1	Mitsubishi Electric Corporation: MELSECNET/MINI-S3 Data Link System (2 power supply systems)
	С	EX123U-STA1	EX123D-STA1	OMRON: SYSBUS Wire System
	D	EX123U-SSH1	EX123D-SSH1	SHARP: Satellite I/O Link System
	F1	EX123U-SUW1	EX123D-SUW1	NKE: Uni-wire System (16 output points)
Dedicated	Н	EX123U-SUH1	EX123D-SUH1	NKE: Uni-wire H System
output model	J1	EX123U-SSL1	EX123D-SSL1	SUNX: S-LINK System (16 point outputs)
	J2	EX123U-SSL2	EX123D-SSL2	SUNX Corporation: S-LINK System (8 output points)
	К	EX123U-SFU1	EX123D-SFU1	Fuji Electric Co.: T-LINK Mini System
	Q	EX124U-SDN1	EX124D-SDN1	OMRON Corp.: DeviceNet, CompoBus/D (2 power supply systems)
	R1	EX124U-SCS1	EX124D-SCS1	OMRON Corp.: CompoBus/S (16 output points, 2 power supply systems)
	R2	EX124U-SCS2	EX124D-SCS2	OMRON Corp.: CompoBus/S (8 output points, 2 power supply systems)
	U	EX124U-SJN1	EX124D-SJN1	JEMANET (2 power supply systems)
	٧	EX124U-SMJ1	EX124D-SMJ1	Mitsubishi Electric Corporation: CC-Link System (2 power supply systems)
	G	EX124U-SAB1	EX124D-SAB1	Allen-Bradley Remote I/O (RIO) System (2 power supply systems) (Rockwell Automation, Inc.)

<u Side End Plate Assembly Part No.> 2. U side end plate assembly part no. (for F, L, S, T & T1 kits)



Nil	Standard
$W^{(2)}$	IP65 enclosure is dust
CU1	Exhaust cleaner mounting Rc 1
CU2	Exhaust cleaner mounting Rc 1 1/2
SU	Direct exhaust with silencer box

Note 1) D-sub connector is not included. Note 2) Splashproof specifications is not available for F and T1

### <Manifold Block Replacement Parts>

### **Replacement Parts**

No.	Part no.	Description	Material	Number							
4	VVQ5000-80A-1	Gasket	NBR	10							
(5)	VVQ5000-80A-2	Gasket	NBR	10							
	Note) Spare parts consist of sets containing 10 pcs. each.										

**VQC** 

SQ

VQ<sub>0</sub>

VQ4

VQ5

**VQZ** 

VQD

## **Air Filter**

Port size 10 20 30 40 50 60

1/8

1/4

3/4

М5 M5

02

03 3/8

04 1/2

06

10

# AF10 to 60

### **How to Order**

# AF 30 - F 03 BD

Body size

• •

ullet

•

•

 $\bullet$ • •

Port size

**Body size** 10 20 <mark>30</mark> 40 50 60

### Thread type

Nil	Metric thread (M5)
	Rc
Note 1)	NPT
F Note 2)	G

Note 1) Drain guide is NPT1/4 (applicable to AF30 to 60), and the exhaust port for auto drain comes with ø3/8" One-touch fitting (applicable to AF30 to 60).

Note 2) Drain guide is G1/4 (applicable to AF30 to 60).

•	***************************************											
Symbol	Description	Applicable model										
Nil	_	_										
<b>B</b> Note 3)	With bracket	AF20 to 60										
С	Float type Note 4) auto drain (N.C.)	AF10 to 60										
D	Float type Note 4) auto drain (N.O.)	AF30 to 60										

Note 3) Bracket is not assembled and is supplied loose at the time of shipment.

Applicable tube O.D for auto drain connection should be ø3/8" in case NPT thread port is chosen.

Optional specifications Applicable model Symbol Description 2 Metal bowl AF10 to 60 6 AF10 to 60 Nylon bowl 8 Metal bowl with level gauge AF30 to 60 С With bowl guard AF20 Drain guide 1/4 AF30 to 60 AF10 to 60 Flow direction: Right to left Drain cock with barb fitting: w AF30 to 60 ø6 x ø4 nylon tubing Note 6) Name plate and caution plate for AF10 to 60 bowl in imperial units (PSI, °F)

\* When more than one specification is required, indicate in ascending alphanumeric order

Note 5) Without a valve function.

Note 6) This product is for overseas use only according to the new Measurement Law. (The SI unit type is provided for use in Japan.)













With auto drain





### O: Combination available : Combination not available Accessory/Optional specification combinations O: Varies depending on the model A: Available only with NPT thread

	Combination		Ac	cess	ory		O	otion	al sp	ecifi	catio	n		Αŗ	oplicable filt	er
Acc	essory/Optional specifications	Symbol	В	С	D	2	6	8	С	J	R	W	Z	AF10	AF20	AF30 to 60
ries	With bracket	В		0	0	0	0	0	0	0	0	0	Δ		0	0
Accessories	Float type auto drain (N.C.)	С	0			0	0	0	0		0		Δ	0	0	0
Ag	Float type auto drain (N.O.)	D	0			0	0	$\odot$			0		Δ			0
SL	Metal bowl	-2	0	0	0					0	0		Δ	0	0	0
ᅙ	Nylon bowl	-6	0	0	0				0	0	0	0	Δ	0	0	0
<u>i</u>	Metal bowl with level gauge	-8	0	0	0					0	0		Δ			0
specifications	With bowl guard	-с	0	0			0				0		Δ		0	
sb	Drain guide 1/4	-J	0			0	0	0			0		Δ			0
Ja	Flow direction: Right to left	-R	0	0	0	0	0	0	0	0		0	Δ	0	0	0
Optional	Drain cock with barb fitting: ø6 x ø4 nylon tubing	-W	0				0				0		Δ			0
ဝီ	Name plate and caution plate for bowl in imperial units (PSI, °F)	-Z	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ		Δ	Δ	Δ

### Standard specifications

otandara opcomoditorio									
Model	AF10	AF20	AF30	AF40	AF40-06	AF50	AF60		
Port sizes	M5 x 0.8	1/8, 1/4	1/4, 3/8	1/4, 3/8, 1/2	3/4	3/4, 1	1		
Fluid	Air								
Proof pressure	1.5MPa								
Maximum operating pressure				1.0MPa					
Ambient and fluid temperature			-5 to 60	°C (with no f	reezing)				
Nominal filtration rating				5μm					
Bowl material			Р	olycarbonat	е				
Bowl guard	— Option Standard								
Drain capacity (cm³)	2.5	8	25	45	45	45	45		
Weight (kg)	0.06	0.18	0.22	0.45	0.49	0.99	1.05		

### Accessory part no.


Accessory	AF10	AF20	AF30		AF40	AF	40-06	ļ	\F50	Δ	\F60		
Bracket assembly Note 1)		_	AF20P-050AS	AF30P-050AS		AF40P-050AS	P-050AS AF40P-070AS		AF5	AF50P-050AS		AF50P-050AS	
Float type Note 2)	N.O.	_	_	AD38 AD38N	lote 3) A[	D48 AD48N <sup>Note 3)</sup>	AD48	AD48N <sup>Note 3)</sup>	AD48	AD48N <sup>Note 3)</sup>	AD48	AD48N <sup>Note 3)</sup>	
auto drain	N.C.	AD17	AD27	AD37 AD37N	lote 3) A[	D47 AD47N <sup>Note 3)</sup>	AD47	AD47N <sup>Note 3)</sup>	AD47	AD47N <sup>Note 3)</sup>	AD47	AD47N <sup>Note 3)</sup>	


Note 1) Assembly includes a bracket and 2 mounting screws.


Note 2) Minimum operating pressure: N.O. type-0.1MPa; N.C. type-0.1MPa (AD17/27) and 0.15MPa (AD37/47).


Note 3) When "N" is specified in the end of part number of auto drain, applicable tube O.D should be ø3/8".


### Flow Characteristics (Representative values)

















# **⚠** Specific Product Precautions

I Be sure to read before handling.

Refer to pages 75 through 78 for safety instructions and F.R.L. unit precautions.


### Maintenance

# **Marning**


 Replace the element every 2 years or when the pressure drop becomes 0.1MPa, whichever comes first, to prevent damage to the element.

### **Operation Principle: Float Type Auto Drain**


N.O. type: AD38, 48



### N.C. type: AD37, 47



# Compact auto drain N.C. type: AD17, 27



### When the pressure inside the bowl is released:

When pressure is released from the bowl  $\bigcirc$ , piston  $\bigcirc$  is lowered by spring  $\bigcirc$ .

The sealing action of seal (1) is interrupted, and the outside air flows inside the bowl (1), through housing hole (9) and drain cock (1).

Therefore, if there is an accumulation of condensate in the bowl ①, it will drain out through the drain cock.

# When pressure is applied inside the bowl:

When the pressure exceeds 0.1MPa, the force of piston  $\widehat{\mathcal{T}}$  surpasses the force of spring  $\widehat{\mathbb{G}}$ , and the piston goes up.

This pushes seal ① up so that the it creates a seal and the inside of the bowl ①, is shut off from the outside air.

If there is no accumulation of condensate in the bowl ①, at this time float ② will be pulled down by its own weight, causing valve ④, which is connected to lever ③, to seal valve seat ⑤.

### When there is an accumulation of condensate in the bowl:

Float ② rises due to its own buoyancy and pushes open the seal created by the valve seat, ⑤.

This allows the pressure inside the bowl  $\bigcirc$ , to enter the chamber  $\bigcirc$ 8. The result is that the combined pressure inside chamber  $\bigcirc$ 8 and the force of the spring  $\bigcirc$ 6, lower the piston  $\bigcirc$ 7.

This causes the sealing action of seal (10) to be interrupted, and the accumulated condensate in the bowl (1), drains out through the drain cock (11).

Turning drain cock ① manually counterclockwise lowers piston ⑦, which pushes open the seal created by seal ⑩, thus allowing the condensate to drain out.

### When the pressure inside the bowl is released:

Even when pressure inside the bowl  $\ensuremath{\mathbb{T}},$  is released, spring  $\ensuremath{\mathbb{G}}$  keeps piston  $\ensuremath{\mathbb{T}}$  in its upward position.

This keeps the seal created by the seal 10, in place, thus shutting the outside air from inside the bowl 1.

Therefore, even if there should be some condensate accumulation inside the bowl ①, it will not drain out.

### When pressure is applied inside the bowl:

Even when pressure is applied inside the bowl  $\bigcirc$ , the combined force of spring  $\bigcirc$  and the pressure inside the bowl  $\bigcirc$ , keeps piston  $\bigcirc$  in its upward position.

This maintains the seal created by the seal 10, in place, thus shutting the outside air from inside the bowl 1.

If there is no accumulation of condensate in the bowl  $\bigcirc$ , at this time float  $\bigcirc$  will be pulled down by its own weight, causing valve  $\bigcirc$ , which is connected to lever  $\bigcirc$ , to seal valve seat  $\bigcirc$ .

### When there is an accumulation of condensate in the bowl:

Float ② rises due to its own buoyancy and pushes open the seal created by the valve seat ⑤. Pressure passes from the bowl to chamber ③.

The result is that the pressure inside chamber 8 surpasses the force of the spring 6, and pushes piston 7 downwards.

This causes the sealing action of seal 0 to be interrupted and the accumulated condensate in the bowl 1, drains out through the drain cock 1.

Turning drain cock ① manually counterclockwise lowers piston ⑦, which pushes open the seal created by seal ⑩, thus allowing the condensate to drain out.

### When the pressure inside the bowl is released:

Even when pressure inside the bowl  $\bigcirc$ , is released, the weight of the float  $\bigcirc$  causes valve  $\bigcirc$ , which is connected to lever  $\bigcirc$ , to seal valve seat  $\bigcirc$ . As a result, the inside of the bowl  $\bigcirc$ , is shut off from the outside air.

Therefore, even if there is an accumulation of condensate in the bowl ①, it will not drain out.

### When pressure is applied inside the howl:

Even when pressure is applied inside the bowl ①, the weight of the float ②, and the differential pressure that is applied to valve ④ cause valve ④ to seal valve seat ⑤, and the outside air is shut off from the inside of the bowl ①.

### When the drain is accumulated in the bowl:


Float ② rises due to its own buoyancy and the seal at valve seat ⑤ is interrupted.

The condensate inside the bowl ① drains out through the knob, ⑥.

Turning knob (6) manually counterclockwise lowers it and causes the sealing action of valve seat (5) to be interrupted, thus allowing the condensate to drain out.



### Construction



### Parts list

No.	Description		Color		
INO.		AF10, 20	AF30, 40, 40-06	AF50, 60	Coloi
1	Body	Zinc die-cast	Aluminun	n die-cast	Platinum silver
6	Housing		_	Aluminum die-cast	Platinum silver

### Air filter replacement parts

No.	Description	Material -		Part no.									
INO.	Description		AF10	AF20	AF30	AF40	AF40-06	AF50	AF60				
2	Filter element	Non-woven fabric	AF10P-060S	AF20P-060S	AF30P-060S	AF40P-060S	AF40P-060S	AF50P-060S	AF60P-060S				
3	Baffle	PBT	AF10P-040S Note 1)	AF20P-040S	AF30P-040S	AF40P-040S	AF40P-040S	AF50P-040S	AF60P-040S				
4	Bowl O-ring	NBR	C1SFP-260S	C2SFP-260S	C3SFP-260S	C4SFP-260S	C4SFP-260S	C4SFP-260S	C4SFP-260S				
5	Bowl assembly Note 2)	PC	C1SF	C2SF	C3SF Note 3)	C4SF Note 3)	C4SF Note 3)	C4SF Note 3)	C4SF Note 3)				




Note 1) The material of the baffle for AF10 (AF10P-040S) only is POM.

Note 2) Contact SMC regarding the bowl assembly supply for PSI and °F unit specifications.

Note 3) Bowl assembly for AF30 to 60 models comes with a bowl guard (steel band material).

# AF10 to 60

### **Dimensions**



Applicable mode	AF10,	AF20		AF30, A	AF30, AF40, AF40-06, AF50, AF60						
	With auto drain (N.C.)	Metal bowl	With auto drain (N.O./N.C.)	Metal bowl	Metal bowl with level gauge	With drain guide	Drain cock with barb fitting				
Optional specifications	M5 x 0.8	<b>B</b>	N.O.: Black N.C.: Gray ø10 One-touch		8	m 1/4 Width across flats 17	Barb fitting Applicable tubing: T0604				

	Port size		Standard specification				Accessory specification								
Model			Standa	aru speciii	callon		Bracket mounting size With auto drain								
		Α	В	С	D	P	E	F	G	Н	J	K	L	M	В
AF10	M5 x 0.8	25	67	7	25	28	_	_	_	_	_	_	_	_	85
AF20	1/8, 1/4	40	97	10	40	_	18	30	27	22	5.4	8.4	40	2.3	115
AF30	1/4, 3/8	53	129	14	53	57	16	41	40	23	6.5	8	53	2.3	170
AF40	1/4, 3/8, 1/2	70	165	18	70	73	17	50	54	26	8.5	10.5	70	2.3	204
AF40-06	3/4	75	169	20	70	73	14	50	54	25	8.5	10.5	70	2.3	208
AF50	3/4, 1	90	245	24	90	_	23	70	66	35	11	13	90	3.2	284
AF60	1	95	258	24	95	_	23	70	66	35	11	13	90	3.2	297

		Optiona	I specification		
Model	With drain guide	With barb fitting	Metal bowl	Metal bowl with level gauge	
	В	В	В	В	
AF10	_	_	66	_	
AF20	_	_	97	_	
AF30	136	137	142	162	
AF40	172	173	178	198	
AF40-06	176	177	182	202	
AF50	252	253	258	278	
AF60	265	266	271	291	

# Air Filter AF20 to 60 **Made to Order Specifications**

Contact SMC for detailed dimensions, specifications, and lead times.



### (1) Special Temperature Environment

Special materials are used in the manufacturing of seals and resin parts to allow them to withstand various temperature conditions in cold or tropical (hot) climates.

### **Specifications**

Р	art no.	-X430	-X440				
Environment		Low temperature	High temperature				
Ambient	temperature	–30 to 60°C	–5 to 80°C				
Fluid ten	nperature	−5 to 60°C (wi	th no freezing)				
Material	Rubber parts	Special NBR	FPM				
Material	Main parts	Metal (Aluminum die-cast)					

### Applicable models

Model	AF30	AF40	AF40-06	AF50	AF60
Port sizes	1/4 3/8	1/4 3/8 1/2	3/4	3/4 1	1

How to Order

### **② High Pressure**

Strong materials are used in the manufacturing of air filters intended for high pressure operation.

### **Specifications**

Part no.	-X425
Proof pressure	3.0MPa
Maximum operating pressure	2.0MPa
Ambient and fluid temperature	-5 to 60°C (with no freezing)

### Applicable models

Nil

to AF30 to 60)

(applicable to AF30

Body size

•

•

•

•

40 50

Port size

•

•

60

Note 2) Drain guide is G1/4

to 60).

30

Port

size 20

1/4

3/4


1

Model	AF20	AF30	AF40	AF40-06	AF50	AF60
Port sizes	1/8 1/4	1/4 3/8	1/4 3/8 1/2	3/4	3/4 1	1

### AF 30 F 03 B 2 R X430 For high/low temperature Air filter X430 Low temperature Body size X440 High temperature 30 40 50 60 Thread type Optional specifications Ro Description Applicable model J Note 5) Drain guide 1/4 AF30 to 60 N Note 2) NPT Flow direction: F Note 3) G Right to left Note 1) Drain guide is NPT1/4 (applicable Name plate and caution plate for bowl in imperial AF30 to 60 to AC30 to 60) units (PSI, °F) Note 2) Drain guide is G1/4 (applicable to AF30 When more than one to 60). specification is required. indicate in ascending alphanumeric order Without a valve function. Note 6) For thread type NPT. This product is for overseas use only according to the new Port size Measurement Law. (The Body size SI unit type is provided for Port use in Japan.) size 30 40 50 60 **01** 1/8 02 1/4 Bowl 3/8 • • 03 Symbol Description Applicable model 1/2 03 3/8 2 Note 4) Metal bowl AF30 to 60 3/4 • • 04 1/2 06 Note 4) Only Metal Bowl available. 10 1 • 06

Option

Symbol Description Applicable model Nil B Note 3) With bracket AF30 to 60 Note 3) Bracket is not assembled and is supplied loose at the time of shipment.



Applicable model Symbol Description J Note 5) Drain guide 1/4 Thread type Flow direction: Rc AF20 to 60 Right to left Note 1 NPT Name plate and caution plate for bowl in imperial units (PSI, °F) Note 2) G Z Note 6 AF20 to 60 Note 1) Drain guide is NPT1/4 (applicable

\* When more than one specification is required. indicate in ascending alphanumeric order Note 5) Without a valve function.

Note 6) For thread type NPT. This product is for overseas use only according to the new Measurement Law. (The SI unit type is provided for use in Japan.)

### Bowl

Symbol	Description	Applicable model					
2 Note 4)	Metal bowl	AF20 to 60					
<b>8</b> Note 3)	Metal bowl with level gauge	AF30 to 60					

Note 4) Only metal bowl or metal bowl with level gauge available.

### Option

Symbol	Description	Applicable model				
Nil	_	_				
B Note 3)	With bracket	AF20 to 60				


Note 3) Bracket is not assembled and is supplied loose at the time of shipment.

Note) Contact SMC regarding the detailed dimensions and optional availability.



# Series AF10 to AF60

### Construction



### **Component Parts**

No.	Description	Material	Model	Color	
4	Body	Zinc die-cast	AF10, AF20	Platinum silver	
•	Бойу	Aluminum die-cast	AF30 to AF60		
6	Housing	Aluminum die-cast	AF50, AF60	Platinum silver	

### **Replacement Parts**

No.	Description	Material	Part no.											
NO.	Description	Materiai	AF10	AF20	AF30	AF40	AF40-06	AF50	AF60					
2	Filter element	Non-woven fabric	AF10P-060S	AF20P-060S	AF30P-060S	AF40P-060S		AF40P-060S AF50P-060S						
3	Baffle	PBT	AF10P-040S Note 1)	AF20P-040S	AF30P-040S	AF40F	P-040S	AF50P-040S	AF60P-040S					
4	Bowl O-ring	NBR	C1SFP-260S	C2SFP-260S	C3SFP-260S	C4SFP-260S								
5	Bowl assembly Note 2)	Polycarbonate	C1SF	C2SF	C3SF Note 3)	C4SF Note 3)								

Note 1) The material of the baffle for the AF10 (AF10P-040S) only is polyacetal.

Note 2) Bowl O-ring is included. Please contact SMC regarding the bowl assembly supply for psi and °F unit specifications.


Note 3) Bowl assembly for the AF30 to AF60 models comes with a bowl guard (steel band material).



# **Mist Separator**

# AFM20/30/40

### **How to Order**



AFM30 and 40). Note 2) Drain guide is G1/4 (applicable to AFM30 and 40).

\* When Those than one specimental in sequines, makes in a decision of the Note 5) Without a valve function.

Note 6) For NPT thread type.

This product is for overseas use only according to the new Measurement Law. (The SI unit type is provided for use in Japan.)

### Accessory/Optional specification combinations

① : Combination available : Varies depending on the model : Combination not available ∴ : Available only with NPT thread

	Combination		Accessory				-	Intio	nal ci	ooifi	catior			Applicable m	ist separator
		Symbol	AC	Accessory				JPIIO	iai S	Jecini	CallOI	ı		AFM20	AFM30 to 40
Α	ccessory/Optional specifications	S	В	С	D	2	6	8	С	J	R	W	Z	AFIVIZU	AFINISO 10 40
ries	With bracket	В		0	0	0	0	0	0	0	0	0	$\triangleright$	0	0
cessories	Float type auto drain (N.C.)	С	0			0	0	0	0		0		$\triangle$	0	0
Acc	Float type auto drain (N.O.)	D	0			0	0	0			0		$\triangle$		0
ns	Metal bowl	-2	0	0	0					0	0		$\triangleright$	0	0
atio	Nylon bowl	-6	0	0	0				0	0	0	0	$\triangleright$	0	0
ifica	Metal bowl with level gauge	-8	0	0	0					0	0		$\triangle$		0
eci	With bowl guard	-C	0	0			0				0		$\triangle$	0	
sb	Drain guide 1/4	<b>_</b> _J	0			0	0	0			0		$\triangleright$		0
nal	Flow direction: Right to left	-R	0	0	0	0	0	0	0	0		0	$\triangleright$	0	0
ptio	Drain cock with barb fitting: ø6 x ø4 nylon tubing	-W	0				0				0		$\triangleright$		0
õ	Name plate and caution plate for bowl in imperial units (PSI, °F)	-Z	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ	Δ		Δ	Δ





AFM40

Standard specifications

Model	AFM20	AFM30	AFM40	AFM40-06							
Port sizes	1/8 1/4	1/4 3/8	1/4 3/8 1/2	3/4							
Fluid	Air										
Proof pressure	1.5MPa										
Maximum operating pressure	1.0MPa										
Minimum operating pressure	0.05MPa										
Ambient and fluid temperature		−5 to 60°C (w	rith no freezing)								
Rated flow L/min (ANR) Note 1)	200	450	1100	1100							
Nominal filtration rating		0.3μm (95% filt	ered particle size)								
Outlet side oil mist concentration	Ma	ximum 1.0 <sup>mg</sup> /m³ (AN	R) (approx. 0.8ppm) No	ote 2)							
Bowl material		Polyca	ırbonate								
Bowl guard	option		Standard								
Drain capacity (cm³)	8	25	45	45							
Weight (kg)	0.18	0.22	0.44	0.49							

Note 1) When the inlet pressure is 0.7MPa. Flow rate varies depending on the inlet pressure. Note 2) When the compressor oil mist discharge concentration is 30mgf/m³ (ANR).



### Accessory part no.

Applicab Accessory	AFM20 AFM30		A	AFM40	AFM40-06			
Bracket assembly	Bracket assembly Note 1)		AF30P-050AS		AF40P-050AS		AF40P-070AS	
Float type Note 2)	N.O.	_	AD38	AD38NNote 3)	AD48	AD48N <sup>Note 3)</sup>	AD48	AD48N <sup>Note 3)</sup>
auto drain N.C. AD27		AD27	AD37	AD37N <sup>Note 3)</sup>	AD47	AD47N <sup>Note 3)</sup>	AD47	AD47N <sup>Note 3)</sup>

Note 1) Assembly includes a bracket and 2 mounting screws.

Note 2) Minimum operating pressure: N.O. type–0.1MPa; N.C. type–0.1MPa (AD17/27) and 0.15MPa (AD37/47). Note 3) When "N" is specified in the end of part number of auto drain, applicable tube O.D should be ø3/8".





### Flow Characteristics (Representative values)

: When saturated with oil

---: Initial state


# AFM20 Bay and a series and a s






### Construction


### AFM20







### AFM30, 40



### Parts list

Nia	Description		Material	Note
NO.	Description	AFM20	AFM30, AFM40, AFM40-06	Note
1	Body	Zinc die-cast	Aluminum die-cast	Platinum silver

### Replacement parts

	· · · · · · · · · · · · · · · · · · ·								
No.	Description	Motorial	Part no.						
	Description	Material	AFM20	AFM30	AFM40	AFM40-06			
2	Element assembly	_	AFM20P-060AS	AFM30P-060AS	AFM40P-060AS	AFM40P-060AS			
3	Bowl O-ring	NBR	C2SFP-260S	C3SFP-260S	C4SFP-260S	C4SFP-260S			
4	Bowl assembly Note 1)	PC	C2SF	C3SF Note 2)	C4SF Note 2)	C4SF Note 2)			

Note 1) Including O-Ring. Contact SMC regarding the bowl assembly supply for PSI and °F unit specifications. Note 2) Bowl assembly for AFM30 to AFM40-06 includes a bowl guard (steel band material).

### 

Be sure to read before handling. Refer to pages 75 through 78 for safety instructions and F.R.L. unit precautions.

### Air Supply

### **∧**Caution

- Install an air filter (Series AF) as a preliminary filter on the inlet side of the mist separator to prevent premature clogging.
- Do not install on the inlet side of the dryer as this can cause premature clogging of the element.

### Maintenance

# $\Delta$ Warning

 Replace the element every 2 years or when the pressure drop becomes 0.1MPa, whichever comes first, to prevent damage to the element.

### Design

# **<b> ∆** Caution

 Design the system so that the mist separator is installed in a pulsation-free location. The difference between internal and external pressure inside the element should be kept within 0.1MPa, as exceeding this value could cause damage.

### Selection

### **∕**\Caution


- Do not allow air flow that exceeds the rated flow. If the air flow is allowed outside the range of the rated flow even momentarily, drainage and lubricant may splash at the outlet side or cause damage to the component.
- 2. Do not use in a low pressure application (such as a blower). F.R.L. unit has its own minimum operating pressure depending on the equipment and is designed specifically to function with compressed air. If used below the minimum operating pressure, a loss of performance and malfunction can occur. Contact SMC if an application under such conditions cannot be avoided.




# AFM20/30/40

### **Dimensions**

### AFM20



### AFM30, 40, 40-06



Applicable model	AFN	M20	AFM30, AFM40, AFM40-06				
	With auto drain (N.C.)	Metal bowl	With auto drain (N.O./N.C.)	Metal bowl	Metal bowl with level gauge	With drain guide	Drain cock with barb fitting
Optional specifications	<b>M</b> 5 x 0.8	<b>B</b>	N.O.: Black N.C.: Gray ø10 One-touch fitting	<b>B</b>	a B	M 1/4 Width across flats 17	Barb fitting Applicable tubing: T0604

		Standard specification					Accessory specification								
Model	Port size		Standa	ra spec	itication			With bracket With auto dr					With auto drain		
		Α	В	С	D	Р	Е	F	G	Н	J	K	L	M	В
AFM20	1/8, 1/4	40	97	10	40	_	18	30	27	22	5.4	8.4	40	2.3	115
AFM30	1/4, 3/8	53	129	14	53	57	16	41	40	23	6.5	8	53	2.3	170
AFM40	1/4, 3/8, 1/2	70	165	18	70	73	17	50	54	26	8.5	10.5	70	2.3	204
AFM40-06	3/4	75	169	20	70	73	14	50	54	25	8.5	10.5	70	2.3	208

	Optional specification							
Model	With drain guide	With barb fitting	Metal bowl	Metal bowl with level gauge				
	В	В	В	В				
AFM20		_	97	_				
AFM30	136	137	142	162				
AFM40	172	173	178	198				
AFM40-06	176	177	182	202				





# Mist Separator Series AFM20/30/40


### Flow Characteristics (Representative values)

: When saturated with oil

- - : Initial state







F.R.L.

AU

**AF** 

AR

IR

**VEX** 

**AMR** 

ITV

IC

**VBA** 

 $\mathsf{VE}\Box$ 

VY1


G

**PPA** 

AL

### Construction


### AFM20





M5 x 0.8

### AFM30/40



### **Component Parts**

NI-	Description		Material	Note
NO.	lo. Description AFM20 A		AFM30, AFM40, AFM40-06	Note
1	Body	Zinc die-casted	Aluminum die-casted	Platinum silver

### **Replacement Parts**

NIo	Description	Material	Part no.					
No. Description		Material	AFM20	AFM30	AFM40	AFM40-06		
2	Element assembly	_	AFM20P-060AS	AFM30P-060AS	AFM40P-060AS	AFM40P-060AS		
3	Bowl O-ring	NBR	C2SFP-260S	C3SFP-260S	C4SFP-260S	C4SFP-260S		
4	Bowl assembly (1)	PC	C2SF	C3SF (2)	C4SF (2)	C4SF (2)		

Note 1) Including O-Ring. Please contact SMC regarding the bowl assembly supply for PSI and °F unit specifications. Note 2) Bowl assembly for AFM30 to AFM40-06 includes a bowl guard (steel band material).

# **⚠ Precautions**

Be sure to read before handling. Refer to pages 14-21-3 to 14-21-4 for Safety Instructions and Common Precautions.

### Air Supply

- 1. Install an air filter (Series AF) as a preliminary filter on the inlet side of the mist separator to prevent premature clogging.
- 2. Do not install on the inlet side of the dryer as this can cause premature clogging of the element.

### **Maintenance**

1. Replace the element every 2 years or when the pressure drop becomes 0.1 MPa, whichever comes first, to prevent damage to the element.

### Design

### **∕!\ Caution**

1. Design the system so that the mist separator is installed in a pulsation-free location. The difference between internal and external pressure inside the element should be kept within 0.1 MPa, as exceeding this value could cause damage.

### Selection

### **∕**∆ Caution

- 1. Do not allow air flow that exceeds the rated flow. If the air flow is allowed outside the range of the rated flow even momentarily, drainage and lubricant may splash at the outlet side or cause damage to the component.
- 2. Do not use in a low pressure application (such as a blower). F.R.L. unit has its own minimum operating pressure depending on the equipment and is designed specifically to function with compressed air. If used below the minimum operating pressure, a loss of performance and malfunction can occur. Please contact SMC if an application under such conditions cannot be avoided.



printed September 28, 2012





### Unit Heater, 3.0/2.2 Kw, 240/208 V

Fan Forced Electric Unit Heater, 3.0/2.2 kW, 240/208 Volt, 1 Phase, 16 Hx, 14 Wx, 8 1/2 D In, Neutral Gray Powder Coated Finish, Mounting Position Vertical or Horizontal, Built-In Features Totally Enclosed Fan Motor, 4 Top and 4 Back Threaded Reinforced Holes for Field Mounting with 5/16 In Threaded Rod (Not Included), Automatic Reset Linear Thermal Protector, Requires Field Supplied Control, 5/16 In-18 Threaded Rod for Ceiling Installation, Includes Adjustable Air Outlet Louvers

Grainger Item # 2YU58 Price (ea.) \$418.80 Brand DAYTON Mfr. Model # 2YU58 Ship Qty. Sell Qty. (Will-Call) 1 Ship Weight (lbs.) 24.0 Availability Ready to Ship Catalog Page No. 4437 Price shown may not reflect your price. Log in or register.

### **Additional Info**

### **Electric Unit Heaters**

Advanced pull-through airflow design for even air distribution and cooler element operation. Automatic reset thermal protection disconnects heater if normal operating temps. are exceeded. Heavy-duty, totally enclosed 60 Hz motors. Aluminum-finned, copper-clad steel sheath heating element. Neutral gray housing with threaded reinforced mounting holes (4 top and 4 back)—20-ga. steel for 3 to 20kW units, 18-ga. steel for 25 to 100kW units. Ceiling mounting requires 5/16-18 threaded rods, except 30" H units require 3/8-16 rods (see page 3061). Provide auxiliary, supplemental, or primary heat source in large exposed areas. 3-phase, 30 to 50kW units are wired for 1- or 2-stage control and contain 2-speed motor for High/Low fan selection. 60kW units are wired for 3-stage. 80 to 100kW are wired for 4-stage for greater flexibility in stage heating.

3 to 50kW units are UL and C-UL Listed. 60 to 100kW units are ETL Listed.

- Adjustable outlet louvers
- Fan-forced
- Ceiling
- or wall-mount, vertically or horizontally
- 24V low-voltage control circuit, except single-phase 3kW and 5kW units are wired for direct line voltage control

### **Tech Specs**

Item: Electric Unit Heater
Type: Fan Forced

kW: 3.0/2.2 BtuH: 10,200/7500

Voltage: 240/208 Hz: 60

Phase: 1

Amps AC: 12.5/11.0 Temp. Rise (F): 27 CFM: 350 Height (In.): 16 Width (In.): 14 Depth (In.): 8-1/2

Max. Mounting Height (Ft.): 8 Horizontal Air Throw (Ft.): 12 Vertical Floor Coverage (Ft.): 18 Vertical Mounting H (Ft.): 9 Housing Material: 20 Gauge Steel

Housing Finish: Neutral Gray Powder Coated

### **Optional Accessories**


Radial Diffuser, For 7.5/10/15 kW



Item #: 2YU34 Brand: DAYTON

Usually Ships: Ready to Ship Price (ea): \$166.75

\_\_\_\_\_





Item #: 2YU93 Brand: DAYTON

Usually Ships: Ready to Ship Price (ea): \$208.75

Unit Mounted Tstat, 24-277 V, SPST, 25 Amp



Item #: 2YU33 Brand: DAYTON

Usually Ships: Ready to Ship

Mounting Position: Vertical or Horizontal

Built-In Features: Totally Enclosed Fan Motor, 4 Top and 4 Back Threaded Reinforced Holes for Field Mounting with 5/16" Threaded Rod ( Not Included), Automatic Reset Linear Thermal

Protector

Requires: 5/16"-18 Threaded Rod for Ceiling

Installation

Agency Compliance: UL/CUL Includes: Adjustable Air Outlet Louvers

Warranty (Years): 1

### **Notes & Restrictions**

Note: Wall-mounted or unit-mounted thermostat required; sold separately, this page.

### MSDS

This item does not require a Material Safety Data Sheet (MSDS).

### **Required Accessories**

There are currently no required accessories for this item.

Price (ea): \$111.15

Unit Mounted Summer Fan Switch, 240-480 V



Item #: 2YU82 Brand: DAYTON Usually Ships: Ready to Ship Price (ea): \$113.55

Ceiling Mount Bracket, Vert Throw,



Item #: 2YU83 **Brand: DAYTON** 

Usually Ships: Ready to Ship Price (ea): \$169.75

Disconnect Switch, 120-600 V, 63



Item #: 2YU94 Brand: DAYTON

Usually Ships: Ready to Ship Price (ea): \$326.25

Wall or Ceiling Mount Bracket



Item #: 2YV16 Brand: DAYTON

Usually Ships: Ready to Ship

Price (ea): \$98.35

### Line Voltage Control



Item #: 4E636 Brand: PECO

Usually Ships: Ready to Ship Price (ea): \$60.40

### **Alternate Products**

### UNIT HEATER, 3 kW, 208 V



Item #: 2YU61 **Brand: DAYTON** Usually Ships: Ready to Ship

Price (ea): \$418.80

### Repair Parts



Repair Parts Information is available for this

printed September 27, 2012





### Exhaust Fan, 12 In, 115 V, 820 CFM

Exhaust Fan, Guard Mounted, Propeller Dia. (In.) 12, CFM @ 0.000-In. SP 820, CFM @ 0.125-In. SP 535, Voltage 115, 60 Hz, 1 Phase, Operating Amps 1.5, Motor HP 1/25, Max. Ambient Temp. (F) 104, Motor RPM 1550, Motor Type Shaded Pole, Motor Enclosure Totally Enclosed Air-Over, Max. Depth (In.) 5-15/16, Mounting Position Horizontal or Vertical, Mounting Holes O.C. (In.) 10-3/16, Guard Material Steel, Wire Guard Finish Gray Polyester, Outside Dia. (In.) 13-1/2, Propeller Material Stamped Aluminum

Grainger Item # 1HKL4 Price (ea.) \$125.60 Brand DAYTON 1HKL4 Mfr. Model # Ship Qty. Sell Qty. (Will-Call) 1 Ship Weight (lbs.) 8.72 Availability Ready to Ship Catalog Page No. 4257

Price shown may not reflect your price. Log in or register.

### **Additional Info**

### **Guard- and Ring-Mount Exhaust Fans**

Designed for low-pressure exhausting and cooling applications. Automatic shutter is recommended; see Index under "Shutters, Fan".

Guard-mount fans are UL and C-UL Listed.

- Mount: vertical or horizontal
- Motors: totally enclosed, 115V, 60 Hz
- Max. inlet/ambient temp.: 104°F

### **Tech Specs**

Item: Exhaust Fan
Type: Guard Mounted
Propeller Dia. (In.): 12
CFM @ 0.000-In. SP: 820
CFM @ 0.125-In. SP: 535
Sones @ 0.000-In. SP @ 5 Ft.: 6.2

Voltage: 115 Hz: 60 Phase: 1

Operating Amps: 1.5 Motor HP: 1/25

Max. Ambient Temp. (F): 104
Bearing Type: Sleeve
Motor RPM: 1550
Motor Type: Shaded Pole

Motor Enclosure: Totally Enclosed Air-Over

Motor Insulation: Class A Max. Depth (In.): 5-15/16

Mounting Position: Horizontal or Vertical Mounting Holes O.C. (In.): 10-3/16 Guard Material: Steel

Wire Guard Finish: Gray Polyester

Outside Dia. (In.): 13-1/2

Propeller Material: Stamped Aluminum

Number of Blades: 3 Thermal Protection: Auto

Includes: Wiring, Junction Box, and 8" Leads Agency Compliance: UL-CUL E53236

**Notes & Restrictions** 

### **Optional Accessories**

### Thermostat, Linevoltage



Item #: 2E734
Brand: WHITE-RODGERS
Usually Ships: Ready to Ship

Price (ea): \$66.08

### **Ventilation Control**



Item #: 2E869 Brand: DAYTON

Usually Ships: Ready to Ship

Price (ea): \$52.45

### Alternate Products

### Exhaust Fan, 10 In, 115 V, 595 CFM



Item #: 1HKL3 Brand: DAYTON

Usually Ships: Ready to Ship

Price (ea): \$119.85

### Repair Parts

Repair Parts Information is available for this tem.

There are currently no notes or restrictions for this item.

### MSDS

This item does not require a Material Safety Data Sheet (MSDS).

### Required Accessories

There are currently no required accessories for this item.

# T4031A,B,P; T6031A,B Refrigeration Temperature Controllers

### PRODUCT DATA



### **GENERAL**

The T4031A,B,P and T6031A,B are temperature controllers used in a variety of cooling applications where remote mounting of the sensing element in the controlled medium is required.

### **FEATURES**

- Wide control temperature range is suitable for controlling ducts, tanks, freezers, coolers, display cases. and defrost termination.
- Universal mounting bracket is available for easy replacement of other controllers.
- . Models are available with various control ranges.
- · Control setpoint is dial-knob adjustable.
- Models are available with fixed or adjustable temperature differentials.
- Capillary lengths are 5, 8, or 20 ft (1.5, 2.4, 6.1m) depending on model.
- · Reliable snap-acting spst or spdt switch.
- Ambient temperature compensated.
- Insert supplied with TRADELINE® models replaces setpoint knob to discourage tampering.

### **Contents**

General	1
Features	1
Specifications	2
Ordering Information	2
Installation	3
Operation and Checkout	5



### **SPECIFICATIONS**

### **IMPORTANT**

The specifications given in this publication do not include normal manufacturing tolerances. Therefore, this unit may not exactly match the specifications listed. Also, this product is tested and calibrated under closely controlled conditions, and some minor differences in performance can be expected if those conditions are changed.

### TRADELINE® Models

TRADELINE® models are selected and packaged to provide ease of stocking, ease of handling, and maximum replacement value. TRADELINE® model specifications are the same as those of standard models except as noted below.

### TRADELINE® Model Available:

T6031A Refrigeration Temperature Controller-spdt switch, adjustable temperature differential, tamper-resistant insert.

### **Capillary Length:**

8 ft (2.4m)

### **Additional Features:**

TRADELINE® pack with cross reference label and special instructions

### Standard Models

T4031A Refrigeration Temperature Controller-spst switch makes on temperature rise; fixed differential

T4031B Refrigeration Temperature Controller—same as T4031A but less case

T4031P Refrigeration Temperature Controller—same as T4031A but uses screw, not knob, to adjust setpoint

T6031A Refrigeration Temperature Controller-spdt switch, fixed or adjustable temperature differential

T6031B Refrigeration Temperature Controller—same as T6031A but less case

### **Switch Action:**

T4031A,B,P spst switch makes R to W on temperature rise T6031A,B spdt switch makes R to W on temperature rise, R to B on temperature fall

### **Capillary Lengths and Temperature Ranges:**

	Copper Capillary Tube Length		Setting Range <sup>a</sup>		Differential			
Model	ft	m	°F	°C	°F	°C		
T4031A,B	5	1.5	-30 to 50	-34 to 10	Fixed at 3.5	Fixed at 1.6		
	20	6.1						
T4031P	8	2.4	-30 to +90	-34 to +32	3.5 to 16	1.6 to 9		
T6031A,B	5	1.5	-15 to +90	-9 to +32	Fixed at 3.5 or Adjust. from 3.5 to 12	Fixed at 1.6 or Adjust. from 1.6 to 7		
	20	6.1						
	5	1.5	-30 to +50	-34 to +10				
	20	6.1						
	8	2.4	-30 to +90	-34 to +32				

<sup>&</sup>lt;sup>a</sup> Dial scale markings in degrees Fahrenheit

### ORDERING INFORMATION

When purchasing replacement and modernization products from your TRADELINE® wholesaler or your distributor, refer to the TRADELINE® catalog or price sheets for complete ordering number, or specify:

1. Order number.

4. Length of copper capillary tube.

2. Setting range.

- 5. Accessories, if desired.
- 3. Fixed or adjustable differential (T6031).

If you have additional questions, need further information, or would like to comment on our products or services, please write or phone:

- 1. Your local Honeywell Home and Building Control Sales office (check white pages of your phone directory).
- Home and Building Control Customer Relations Honeywell, 1885 Douglas Drive North Minneapolis, Minnesota 55422-4386

In Canada—Honeywell Limited/Honeywell Limitée, 35 Dynamic Drive, Scarborough, Ontario M1V 4Z9. International Sales and Service Offices in all principal cities of the world.

60-2177—3

### **Electrical Ratings:**

	120	Vac	240 Vac		
	Normally Closed	Normally Open <sup>a</sup>	Normally Closed	Normally Open <sup>a</sup>	
Full Load Amp	8	16	5.1	8	
Locked Rotor Amp	48	80	30.6	40	

<sup>&</sup>lt;sup>a</sup> Makes on temperature rise.

### **Pilot Duty:**

125 VA

### **Dimensions:**

See Fig. 1




Fig. 1. Dimensions of T4031, T6031 in in. (mm).

### **Underwriters Laboratories Inc.:**

Listed

### **Maximum Ambient Operating Temperature:**

125°F (52°C)

### **Accessories:**

112622AA Immersion Well—short-necked, 1/2 in. NPT, copper

7617ABY Compression Fitting—50 psi water, 15 psi air 107324A Bulb Holder—for duct installation 105900 T-strap—for strapping bulb to pipe

7617ABZ Bag Assembly—for mounting controller to fan coil units

801534 Calibration Wrench

7640HY Standoff Bracket Bag Assembly—to mount controller to an insulated duct

130883 Universal Mounting Bracket

194899 Tamper-resisting Insert Button

Celsius Scaleplates:

194486 D: -15°C to +35°C replaces (0°F to 100°F) scaleplate

194486H: 15°C to 75°C replaces (55°F to 175°F) 194486F: 75°C to 125°C replaces (160°F to 260°F)

### INSTALLATION

### When Installing this Product...

- Read these instructions carefully. Failure to follow them could damage the product or cause a hazardous condition.
- Check the ratings given in the instructions and on the product to make sure the product is suitable for your application.
- 3. Installer must be a trained, experienced service technician.
- 4. After installation is complete, check out product operation as provided in these instructions.



- Disconnect power supply before installation to prevent electrical shock and equipment damage.
- Do not damage or change shape of capsule. Deformed capsule will cause calibration offset.

### Mounting

Install controller in any convenient location. Make sure that the sensing bulb reaches the system to be controlled. The ambient temperature must not exceed 125°F (52°C) in the area where the controller is installed.

Install the sensing element where it can sense the average temperature. Avoid sharp bends or kinks in the capillary tubing that can affect the accuracy of the controller. Carefully coil the excess capillary tubing and leave it directly beneath the controller.

The 130883 Mounting Plate furnished with TRADELINE® models allows the control to be mounted in existing mounting holes.

### **Duct Installation**

3

Position the sensing bulb in the duct to sense the average air temperature. Avoid mounting the bulb close to hot pipes, cooling coils, etc.

The 107324A Bulb Holder is available for suspending the bulb in a duct. See Fig. 2.




Fig. 2. 107324A bulb holder.

### To install duct:

- Make a hole in duct wall to admit sensing bulb into holder.
- 2. Using holder as template, mark and drill mounting holes.
- 3. Break off bulb holder to required length. (Be sure holder is long enough to hold sensing bulb away from duct wall and in freely circulating air.)
- Place capillary tubing in bulb holder channel, with bulb at inner end of holder. Pinch together top edges of channel segments.
- Insert assembled bulb and holder into duct, and fasten to duct wall with screws supplied.

### **Tank Installation**

The sensing bulb can be inserted directly into a tank using a compression fitting; or the bulb can be inserted into an immersion well (order separately), which is screwed into a tank or boiler.

Select a location where liquid of average temperature can circulate freely around the sensing bulb.

### Using Compression Fitting (Fig. 3)

- Drain system. Screw boiler plug into properly sized and threaded boiler or pipe tapping.
- 2. Place packing nut on capillary tubing.
- 3. Slide sensing bulb completely through boiler plug.
- 4. Place composition disc and the four slotted brass washers on capillary tubing.
- 5. Slide assembly into boiler plug and tighten packing nut.
- Refill system and check for leaks. Neatly coil excess capillary tubing.

### Using Immersion Well (Fig. 4)

- 1. Drain system. Screw the well into threaded fitting.
- 2. Refill system and check for leaks.
- 3. Insert sensing bulb into well until it bottoms.
- Fit bulb retaining clamp over immersion well flange and capillary tubing, and tighten screw.




Fig. 3. Compression fitting installation.




Fig. 4. Immersion well installation.

### **Cold Room Installation**

Locate the bulb in freely circulating air in the controlled area or on the suction side of a refrigerant line, and secure the bulb in position.

### Wiring (Fig. 5)

All wiring must comply with local electrical codes and ordinances.

Two knockouts are provided, one at the top and one at the bottom of the case for 1/2 in. conduit. Follow the wiring instructions furnished with the heating or cooling system. For replacement, make sure the new control is wired into the system to operate the same as the old control.




Fig. 5. Wiring terminals on T4031 and T6031 temperature controllers.

60-2177—3

### OPERATION AND CHECKOUT

When the temperature at the sensing bulb rises above the controller setpoint, a circuit is made between the R-W terminals. During a temperature fall, the R-W circuit breaks at the setpoint temperature *minus* the switch differential. Controllers with a B terminal break the B-R terminal circuit on a temperature rise to the setpoint. B-R makes again when R-W breaks on a temperature drop. See Fig. 6.

For example, if a controller with a 3°F (1.7°C) differential is set at 39°F (3.9°C), R-W makes when the bulb temperature rises to 39°F. Then during a temperature fall, R-W breaks when the temperature drops to 35°F (1.7°C) (39°F minus the 3°F differential [3.9°C minus the 1.7°C differential]).

On models with a B terminal, B-R makes when R-W breaks. Then the temperature has to climb past the control differential to the set point of 39°F (3.9°C) before the B-R circuit breaks and the R-W circuit makes.




Fig. 6. Operation of switch on temperature rise and fall.

### **SETTING**

Set the controller to the system manufacturer's recommended settings, if available.

Temperature Setpoint Knob—Turn the knob on the front of the case until the pointer indicates the temperature to be maintained in the controlled medium.

Screw—Insert a flatheaded screwdriver into the slot on the shaft, which is located in the center of the scaleplate. Turn the screwdriver clockwise  $\bigcap$  to increase the temperature control point. Turn the screwdriver counterclockwise  $\bigcap$  to decrease the temperature control point.

Adjustable Differential—With the cover off, turn the differential adjustment wheel (marked 3-6-9-12°F) until the desired differential is aligned with the notch in the frame. See Fig. 7.

Fixed differential models are 3.5°F at midscale.

### Calibration

All controllers are carefully tested and calibrated at the factory under controlled conditions. If the controller is not operating at a temperature corresponding to the scale and differential setting, verify that the bulb senses the average temperature of the medium. If the temperature of the controlled medium is changing rapidly, the differential will appear wider than its setting.




Fig. 7. Internal view showing differential adjustment wheel (applicable models).

For calibration, take an accurate temperature reading of the controlled medium. Place an accurate thermometer near the bulb of the controller, or refer to a thermometer installed as part of the system. If the bulb of the controller is installed in an inaccessible area, or if the controlled medium is unstable, remove the bulb and place in a controlled bath for accurate calibration.

These controllers are calibrated so the dial setting is the point at which the R-W switch contacts make (B-R contacts break) on a temperature rise. Measure the temperature at the bulb. Rotate the dial counterclockwise from the top of the scale, simulating a temperature rise, until the R-W switch contacts make. Note the dial reading. If it differs from the setpoint, calibrate the dial as follows:

- 1. Determine the number of degrees difference between the set point and the point at which the contacts make.
- 2. Remove the dial knob and slip the fingers of the calibration wrench into the slots of the dial. Rotate the dial until the fingers of the wrench drop into the slots of the calibration nut under the dial. Note the dial indication at this point. Turn the dial and the calibration nut up or down scale the number of degrees that the set point differs from the point at which the contacts make (determined in step 1). For example, move the dial from 45 to 65 degrees for a 20 degree change in calibration.
- Check the calibration adjustment by moving the dial up and down the scale while watching the contacts make and break. If dial is still out of calibration, repeat calibration procedure.
- To install tamper-resisting insert on TRADELINE® model, remove screw from adjustment knob, remove knob, and install insert.

60-2177—3

5

60-2177—3

6

60-2177—3

7

# Honeywell

Helping You Control Your World







### Shutter, Wall, 12 In

Exhaust Shutter, Gravity Operated, Single Panel, Fits Fan Dia 12 In, Overall Square 15 In, Opening Required 12 1/2 x 12 1/2 In, Frame Depth 2 1/2 In, Open Depth 5 3/4 In, Flange Width 1 1/2 In, Free Area 0.786 Square-Ft, Max Velocity 2500 FPM, Vertical Mounting Position, Blade Material White Painted Aluminum, Extruded Aluminum Frame and G-90 Glavanized Tie Rod, For Use With Vertical Mounted Exhaust Fans

Grainger Item #	4C556
Price (ea.)	\$37.50
Brand	DAYTON
Mfr. Model #	4C556
Ship Qty.	1
Sell Qty. (Will-Call)	1
Ship Weight (lbs.)	4.0
Usually Ships	Today
Catalog Page No.	3915

Price shown may not reflect your price. Log in or register.

### Additional Info

### Single- and Double-Panel Exhaust Shutters

Efficient shutters for direct- or belt-driven exhaust fans are designed to prevent air backflow when the fan is off.

Counterbalanced louvers with felted edges (except fiberglass models) open easily and seal quietly. Units with 54" and 60" galvanized and aluminum shutters have 4 additional tie rods on the discharge side for smooth, quiet operation.

- Exhaust only
- Mount: vertical
- Max. velocity: 2500 FPM
- 1 1/2" flange

### Aluminum Frame

For areas where corrosion may be a problem.

Aluminum louvers have white enamel finish, galvanized steel reinforcement strip, and stainless steel rivets. 16-ga. extruded aluminum frame. Frame depth: 2 1/2" for 10 to 24" models, 3" for models 30" and up.

### Tech Specs

Item: Exhaust Shutter

Type: Gravity Operated, Single Panel

Fits Fan Dia. (In.): 12 Overall Square (In.): 15

Opening Required (In.): 12 1/2 x 12 1/2 Frame Depth (In.): 2 1/2

Open Depth (In.): 5 3/4 Flange Width (In.): 1 1/2

Mounting Hole Size (In.): 9/32 x 1/2 Free Area (Square-Ft.): 0.786 Max. Velocity (FPM): 2500 Mounting Position: Vertical Blade Material: White Painted Aluminum

Construction Material: Extruded Aluminum Frame

and G-90 Galvanized Tie Rod For Use With: Vertical Mounted Exhaust Fans

### Notes & Restrictions

There are currently no notes or restrictions for this item.

MSDS

This item does not require a Material Safety Data Sheet (MSDS).

### Required Accessories

There are currently no required accessories for

### **Optional Accessories**



Item #: 2C831 Brand: DAYTON Usually Ships: Today Price (ea): \$89.80

Shutter Motor

Pull Chain Kit, Single Pannel Shutters



Item #: 2FTW3 Brand: DAYTON Usually Ships: Today Price (ea): \$25.30

### Alternate Products

### Fan Shutter, 12 1/2 In



Item #: 1C742 Brand: DAYTON Usually Ships: Today Price (ea): \$34.05

### Fan Shutter, 12 In, Beige Fiberglass



Item #: 5C211 Brand: DAYTON Usually Ships: Today Price (ea): \$62.65

### Repair Parts

A Repair Part may be available for this item. Visit our Repair Parts Center or contact your local branch for more information.




### Series 626 & 628 Pressure Transmitters

### Specifications - Installation and Operating Instructions



### -CH Conduit Housing



The Series 626 and 628 Pressure Transmitters converts a single positive pressure into a standard 4-20 mA output signal. The Series 626 and 628 can be used to accurately measure compatible gases and liquids; Series 626 full scale accuracy is 0.25%; Series 628 full scale accuracy is 1.0% (see specifications). Designed for industrial environments with a NEMA 4X (IP66) housing, this transmitter resists most effects of shock and vibration.




CAUTION: Do not exceed specified supply voltage ratings. Permanent damage not covered by warranty will result. This device is not designed for 120 or 240 volt AC operation. Use only on 13 to 30 VDC.

Pressure Ranges		
Pressure	Maximum	Over
Range	Pressure	Pressure
0-15 psia	30 psia	45 psia
15-0 psia	30 psia	45 psia
0-30 psia	60 psia	90 psia
0-50 psia	100 psia	150 psia
0-100 psia	200 psia	300 psia
0-200 psia	400 psia	600 psia
0-300 psia	600 psia	900 psia
0-5 psig	10 psig	50 psig
0-15 psig	30 psig	150 psig
0-30 psig	60 psig	300 psig
0-50 psig	100 psig	300 psig
0-100 psig	200 psig	500 psig
0-150 psig	300 psig	750 psig
0-200 psig	400 psig	1000 psig
0-300 psig	600 psig	1500 psig
0-500 psig	1000 psig	2500 psig
0-1000 psig	2000 psig	5000 psig
0-1500 psig	3000 psig	5000 psig
0-2000 psig	4000 psig	5000 psig
0-3000 psig	6000 psig	7500 psig
0-5000 psig	7500 psig	10000 psig
0-8000 psig	10000 psig	12000 psig



### -GH General Purpose Housing



### **SPECIFICATIONS**

Service: Compatible gases and liquids. Wetted Materials: Type 316 SS.

Accuracy:

626: 0.25% FS; : 0.20% RSS: 628: 1.0% FS; · 0.5% RSS

626 absolute ranges: 0.5% FS; : 0.35% RSS.

(Includes linearity, hysteresis, and repeatability).

Temperature Limit: 0 to 200°F (-18 to

Compensation Temperature Range: 0 to 175° (-18 to 79°C).

Thermal Effect: 626: ±0.02% FS/°F. 628: ±0.04% FS/°F (includes zero and

Pressure Limits: See table. Power Requirements: 10-30 VDC (for 4-20 mA, 0-5, 1-5, 1-6 VDC outpus); 13-30 VDC (for 0-10, 2-10 VDC outputs); 5 VDC ±0.5 VDC (for 0.5-4.5

VDC ratio-metric output).

Output Signal: 4-20 mA, 0-5 VDC,1-5 VDC, 0-10 VDC, or 0.5-4.5 VDC.

Response Time: 50 msec.

Loop Resistance: 0-1000 Ohms max. R max = 50 (Vps-10) Ohms (4-20 mA output), 5K Ohms (0-5, 1-5, 1-6, 0-10, 2-10, 0.5-4.5 VDC output).

Current Consumption: 38 mA maximum (for 4-20 mA output); 10 mA maximum (for 0-5, 1-5, 1-6, 0-10, 2-10, 0.5-4.5 VDC output); 140 mA maxumum (for all 626/628/629-CH with optional LED).

Electrical Connections: Conduit Housing (-CH): terminal block, 1/2" female NPT conduit; General Purpose Housing (-GH): cable DIN EN 175801-803-C

Process Connection: 1/4" male or

female NPT and BSPT.

Enclosure Rating: NEMA 4X (IP66). Mounting Orientation: Mount in any

www.dwyer-inst.com

e-mail: info@dwyer-inst.com

position.

Weight: 10 oz (283 g). Agency Approvals: CE.

### INSTALLATION

- 1. Location: Select a location where the temperature of the transmitter will be between 0 and 175°F (-18 to 79°C). Distance from the receiver is limited only by total loop resistance. The tubing or piping supplying pressure to the unit can be practically any length required but long lengths will increase response time slightly.
- 2. Position: The transmitter is not position sensitive. However all standard models are originally calibrated with the unit in a position with the pressure connection downward. Although they can be used at other angles, for best accuracy it is recommended that units be installed in the position calibrated at the factory.
- 3. Pressure Connection: Use a small amount of plumber's tape or other suitable sealants to prevent leaks. Be sure the pressure passage inside the port is not blocked.

### 4. Electrical Connections

Phone: 219/879-8000

Fax: 219/872-9057

Wire Length -The maximum length of wire connecting the transmitter and receiver is a function of wire size and receiver resistance. Wiring should not contribute more than 10% of the receiver resistance to total loop resistance. For extremely long runs (over 1000 feet), choose receivers with higher resistance to minimize the size and cost of connecting leads. Where wiring length is under 100 feet, wire as small as 22 AWG can be used.

### **CURRENT (4-20 mA) OUTPUT OPERATION**

An external power supply delivering 10-30 VDC with minimum current capability of 40 mA DC (per transmitter) is required to power the control loop. See Fig. A for connection of the power supply, transmitter and receiver. The range of appropriate receiver load resistance (RL) for the DC power supply voltage available is expressed by the formula:

$$R_{\perp} \text{ Max} = \frac{\text{Vps} - 10}{20 \text{ mA DC}}$$

Shielded cable is recommended for control loop wiring.




Fig. A: Current output connection

Conduit Housing with 4-20 mA Output (-CH) Electrical connections to the pressure transmitters are made to the terminal block located inside the housing. Remove the screws and lift off the cover. Wire as shown in Fig. A, B or C. Use Fig. A for current output connection. Use Fig. B for current output with optional LED display. Use Fig. C for current output with optional LED display using two power supplies.

If ordering optional pre-wired cable, black wire is negative (-) and red wire is positive (+).




Fig. B: Current output with optional LED display connection





Fig. C: Current output with optional LED display using two power supplies

**Heirschman DIN Connector with 4-20 mA** When using cable version of -GH General Purpose Housing, black wire is negative (-) and red wire is positive (+). When using optional Heirschman DIN Plug, remove top-center screw and lift off the terminal block assembly. Wire to terminals shown below in Fig. D. For optional 4-pin M-12 connector, wire to pins as shown in Fig. E.



### VOLTAGE (0-5, 1-5, 0-10, 1-6 or 2-10 VDC) OUTPUT OPERATION

(Other outputs contact the factory) See Fig. F for connection of the power supply, transmitter and receiver.




Fig. F: Voltage output connection

**Conduit Housing (-CH)** Electrical connections to the pressure transmitters are made to the terminal block located inside the housing. Remove the screws and lift off the cover. Wire as shown in Fig. F or Fig. G. Use Fig. F for voltage output connection. Use Fig. G for voltage output with optional LED display connection. If ordering optional pre-wired cable, black wire is negative (-), red wire is positive (+) and white wire is +Vout.




Fig. G: Voltage output with optional LED display connection

Heirschman DIN Connector with Voltage Output When using cable version of -GH General Purpose Housing, black wire is negative (-), red wire is positive (+) and white wire is output. When using optional Heirschman DIN Plug, remove top-center screw and lift off the terminal block assembly. Wire to terminals shown below in Fig. H. For optional 4-pin M-12 connector, wire to pins as shown in Fig. I. If utilizing optional A-164 cable for M-12 connection, brown wire corresponds to pin #1, white #2, blue #3, and black #4.



### RATIOMETRIC (0.5-4.5 VDC) OUTPUT OPERATION

(Other outputs contact the factory) See Fig. J for connection of the power supply, transmitter and receiver.




Fig. J: Voltage output connection

**General Purpose Housing with Ratiometric Output** When using cable version of -GH General Purpose Housing, black wire is negative (-), red wire is positive (+) and white wire is output. When using optional Heirschman DIN Plug, remove topcenter screw and lift off the terminal block assembly. Wire to terminals shown below in Fig. K. For optional 4-pin M-12 connector, wire to pins as shown in Fig. L. If utilizing optional A-164 cable for M-12 connection, brown wire corresponds to pin #1, white #2, blue #3, and black #4.



### MAINTENANCE

After final installation of the pressure transmitter and its companion receiver, no routine maintenance is required. A periodic check of system calibration is suggested. The Series 626 and 628 transmitters are not field repairable and should be returned if repair is needed (field repair should not be attempted and may void warranty). Be sure to include a brief description of the problem plus any relevant application notes. Contact customer service to receive a return goods authorization number before shipping.

Phone: 219/879-8000 Fax: 219/872-9057 www.dwyer-inst.com e-mail: info@dwyer-inst.com



Series 626 &

628

# **Industrial Pressure Transmitter**

Complete Offering of Ranges, Connections and Outputs

 $\epsilon$ 



General Purpose Housing (-GH)



General Purpose Housing (-GH) with DIN C



626 with LED Display (CH housing only)



Conduit Housing (-CH)

\*Please see our website for dimensional drawings.

The Series 626 Pressure Transmitters possess a highly precise 0.25% piezo-resistive sensor contained in a compact, rugged, NEMA 4X (IP66) stainless steel general purpose housing or east aluminum conduit housing.

The Series 628 Pressure Transmitters are ideal for OEMs with 1% full scale accuracy sensors. The transmitter is also available in the general purpose stainless steel housing and the cast aluminum conduit housing.

The corrosion resistant 316L stainless steel wetted parts allow the Series 626 and 628 transmitters to measure the pressure in a multitude of processes from hydraulic oils to chemicals. The Series 626 and 628 are available in ranges of vacuum, compound to 5000 psi with a variety of optional outputs, process connections and electrical terminations to allow you to select the right transmitter for your application.

### **APPLICATIONS**

- Compressors
- Pumping systems
- Irrigation equipment
- Hydraulic
- · Industrial process monitoring

### **FEATURES**

- · Metal conduit housing option
- Robust 316 SS oil filled sensor
- Compact design

### **SPECIFICATIONS**

**Service:** Compatible gases and liquids. **Wetted Materials:** Type 316L SS.

### Accuracy:

626: 0.25% FS; : 0.20% RSS;

628: 1.0% FS; : 0.5% RSS:

626 Absolute Ranges: 0.5% FS; : 0.35% RSS.

(Includes linearity, hysteresis, and repeatability.) **Temperature Limit:** 0 to 200°F (-18 to 93°C).

Compensated Temperature Range: 0 to 175°F (-18 to 79°C). Thermal Effect: ±0.02% FS/°F (includes zero and span).

Pressure Limits: See table.

Power Requirements: 13-30 VDC (for 4-20 mA, 0-5 VDC, 1-5 VDC, 0-10 VDC);

5 VDC ±10% (for 0.5-4.5 VDC).

 $\textbf{Output Signal:} \ 4\text{-}20 \ \text{mA}, \ 0\text{-}5 \ \text{VDC}, 1\text{-}5 \ \text{VDC}, \ 0\text{-}10 \ \text{VDC}, \ \text{or} \ 0.5\text{-}4.5 \ \text{VDC}.$ 

Response Time: 50 ms.

**Loop Resistance:** 0 - 1300  $\Omega$  max for current. For voltage outputs, min load

resistance: 2000  $\Omega$ .

Stability: 1.0% FS/year (Typ.). Current Consumption: 38 mA (max).

Electrical Connections: Conduit Housing (-CH): terminal block, 1/2" female NPT

conduit; General Purpose Housing (-GH): cable DIN EN 175801-803-C.

Process Connection: 1/4" male or female NPT and BSPT.

Enclosure Rating: NEMA 4X (IP66).

Mounting Orientation: Mount in any position.

Weight: 10 oz (283 g). Agency Approvals: CE.

#### **Pressure Limits**

Range	Pressure	Maximum	Over	Range	Pressure	Maximum	Over
Number	Range	Pressure (psig)	Pressure (psig)	Number	Range (psig)	Pressure (psig)	Pressure (psig)
00	0-15 psia	30	45	11	0-150	300	750
30	15-0 psia	30	45	12	0-200	400	1000
06	0-5 psig	10	50	13	0-300	600	1500
07	0-15 psig	30	150	14	0-500	1000	2500
08	0-30 psig	60	300	15	0-1000	2000	5000
09	0-50 psig	100	300	16	0-1500	3000	5000
10	0-100 psig	200	500	18	0-3000	6000	7500
				19	0-5000	7500	10000
				26	0-8000	10000	12000

Ordering Char	t							
Accuracy								
	626							0.25% Full-Scale Accuracy
	628							1.0% Full-Scale Accuracy
Range		-00						0-15 psia
		-01						0-30 psia
		-02						0-50 psia
		-03						0-100 psia
		-04						0-200 psia
		-05						0-300 psia
		-06						0-5 psi
		-07						0-15 psi
		-08						0-30 psi
		-09						0-50 psi
		-10						0-100 psi
		-11						0-150 psi
		-11 -12						0-130 psi 0-200 psi
		-12						0-200 psi 0-300 psi
		-13 -14						·
								0-500 psi
		-22						0-600 psi
		-15						0-1000 psi
		-16						0-1500 psi
		-18						0-3000 psi
		-19						0-5000 psi
		-26						0-8000 psi
		-67						0-0.5 bar
		-71						0-2.5 bar
		-75						0-10 bar
		-81						0-40 bar
Housing			-CH					Conduit Housing
			-GH					General Purpose Housing
Process				-P1				1/4" male NPT
Connection				-P2				1/4" female NPT
				-P3				1/4" male BSPT
				-P5				1/4" female SAE with Refrigerant Valve Depressor ①
				-P9				1/2" male NPT ①
Electrical					-E1			Cable Gland with 3' of Prewired Cable
Connection					-E3			Cable Gland with 9' of Prewired Cable
					-E4			DIN EN 175801-803-L ①
					-E5			1/2" female NPT Conduit ②
					-E6			M-12 4 Pin Connector
Signal Output						-S1		4-20 mA
0						-S2		1-5 VDC
						-S4		0-5 VDC
						-S5		0-10 VDC
						-S7		0.5-4.5 VDC ①
Options						3,	-AT	Aluminum Tag
Ориона							-NIST	NIST Traceable Certificate
							-LED	Bright Red LED display ②③
							-220	Dilgit Neu LLD display 60

- Available with -GH Housing only
   Available with -CH Housing only
   LED option is not NEMA 4X (IP66)
- Power Requirement: 5 VDC ±10%



## 201L LIQUID FILLED

Our '200' series gauge line is a high quality line of liquid filled gauges. The glycerine filling helps dampen the effects of pulsation and vibration, while also perpetually lubricating the movement (and keeping contaminates such as dirt away from all moving parts) which will extend the life of the gauge.

This gauge has been specifically designed with original equipment manufacturers in mind and are typically used on hydraulic & pneumatic systems as well as any commercial or industrial application not corrosive to brass and bronze wetted parts where glycerine filling is suitable for use.

## **SPECIFICATIONS:**

• Available Dial Sizes: 1 ½", 2", 2 ½", 4", 6"

Available Connection Sizes:

1/8"MNPT on 1 ½" and 2" 1/4"MNPT on 2", 2 ½" and 4" 1/2"MNPT on 4" and 6"

Stainless Steel Case And Bezel

Brass Internals & Connection

Phosphour Bronze Bourdon Tube

Liquid Filled (Dry Available)

Accuracy: 1 ½" or 2"Dial Size = 3-2-3 %

2 ½"Dial Size = 1.5 % 4" or 6"Dial Size = 1 %

Dual Scale: PSI & Bar (x100=kPa)

Single Scale available from stock

Ambient temperature: FILLED: 30'F to 160'F

DRY: -30'F to 180'F

DANIOE	0005	B4 - 1 1	NA* I	h
RANGE	CODE	Major In	Minor In	ļ.
30/0"VAC	Α	5	0.5	5
30/0/15	CB	5	0.5	cati
30/0/30	CC	10	1	효
30/0/60	CD	10	1	l g
30/0/100	CE	20	2	B
30/0/150	CF	20	2	arti
30/0/300	CH	50	10	l p
0/15	В	2	0.2	ا ۾
0/30	С	5	0.5	wit
0/60	D	10	1	g
0/100	E	20	2	Se (
0/160	F	20	2	lea Sea
0/200	G	40	4	S,
0/300	Н	50	5	size
0/400	I	50	5	dial
0/500	J	100	10	ā
0/600	K	100	10	e E
0/800	L	100	10	apl
0/1000	M	200	20	ıvai
0/1500	N	200	20	ğ
0/2000	0	400	50	es r
0/3000	Р	500	50	ang
0/4000	Q	500	50	Je r
0/5000	R	1000	100	Some ranges not available in all dial sizes, please call with your particular application
0/6000	S	2000	200	∥ຶ
0/10,000	U	2000	200	
0/15,000	V	2000	200	



	<b>⊢</b> B →
A	D + C + E *

		Α	В	С	D	Е
1 ½"	In	1.88	1.06	.89	2.77	1/8"
Dial	MM	48	27	23	58	NPT
2"	In	2.24	1.27	.71	2.80	1/8" or
Dial	MM	57	32	23	71	1/4" NPT
2 1/2"	In	2.80	1.28	1.07	3.55	1/4"
Dial	MM	71	33	27	90	NPT
4"	In	4.32	1.63	1.25	5.57	1/4" or
Dial	MM	110	42	32	141	½" NPT
6"	ln	6.54	1.70	1.68	8.22	1/4" or
Dial	MM	166	43	43	210	½" NPT



## 202L LIQUID FILLED

Our '200' series gauge line is a high quality line of liquid filled gauges. The glycerine filling and built in snubber helps dampen the effects of pulsation and vibration, while also perpetually lubricating the movement (and keeping contaminates such as dirt away from all moving parts) which will extend the life of the gauge.

This gauge has been specifically designed with the original equipment manufacturers in mind and are typically used on hydraulic & pneumatic systems as well as any commercial or industrial application not corrosive to brass and bronze wetted parts where glycerine filling is suitable for use.

## **SPECIFICATIONS:**

• Available Dial Sizes: 1 ½", 2", 2 ½", 3 ½", 4"

• Available Connection Sizes: (includes built-in snubber)

1/8"MNPT on 1 1/2" and 2"

1/4"MNPT on 2", 2 1/2", 3 1/2" and 4"

Stainless Steel Case And Bezel

Brass Internals & Connection

• Phosphor Bronze Bourdon Tube

• Plastic Lens Standard (Glass Available)

Liquid Filled (Dry Available)

• Accuracy: 1 ½" and 2" Dial = 3-2-3 %

2 1/2" Dial Size = 1.5 %

3 1/2" and 4" Dial Size = 1 %

Dual Scale: PSI & Bar (x100=kPa)


Single Scale available from stock

• Ambient temperature: FILLED: 30'F to 160'F


DRY: -30'F to 180'F

RANGE	CODE	Major In	Minor In
30/0"VAC	Α	5	0.5
30/0/15	CB	5	0.5
30/0/30	CC	10	1
30/0/60	CD	10	1
30/0/100	CE	20	2
30/0/150	CF	20	2
30/0/300	CH	50	10
0/15	В	2	0.2
0/30	С	5	0.5
0/60	D	10	1
0/100	E	20	2
0/160	F	20	2
0/200	G	40	5
0/300	Н	50	5
0/400		50	5
0/600	K	100	10
0/1000	М	200	20
0/1500	N	200	20
0/2000	0	400	50
0/3000	Р	500	50
0/5000	R	1000	100
0/10,000	U	1000	100
0/15,000	V	2000	200





	ï	Α	В	C	D	Е
1 ½"	In	1.88	1.06	.89	1.95	1/8"
Dial	MM	48	27	23	50	Npt
2"	In	2.23	1.09	.71	1.99	1/8" or
Dial	MM	57	28	23	51	1⁄4"npt
2 1/2"	In	2.80	1.28	1.18	2.46	1/4"
Dial	MM	71	33	30	63	NPT
3 ½"	In	3.83	1.14	1.08	2.20	1/4"
Dial	MM	97	29	27	56	NPT
4"	In	4.32	1.63	1.14	2.77	1/4"
Dial	MM	110	42	29	71	NPT



**Compact, low-cost Wallpack with uniform** light output for outdoor security lighting. HPS, **Metal Halide or CFL with photocell or sensor.** 

Photocell for automatic dusk to dawn operation

Vandal resistant polycarbonate housing on WPT Series

Die formed aluminum reflector and prismatic polycarbonate refractor for wide light distribution

Heavy, die cast aluminum back plate with box mounting template

Heavy duty cast aluminum housing on WPTG Series

Shades work great with Tallpacks! (see pg. 54)

Heavy prismatic glass refractor

Packaging has product features, ballast and lamp specifications plus lighting layout photometrics and installation instructions

1/2" bottom conduit knockout

**Starting Amps / Operating Amps** 208V

.5 / .5 .4 / .4

.7 / .6

.3 / .5

.7 / .6

.8 / .7

.3 / .5

.8 / .7

240V 277V

4 / 4

.6 / .5

.17

.3 / .3

.3 / .4

.6 / .5

120V

1.4 / 0.9 1.8 / 1.2 2.1 / 1.6 .8 / .9

3.1 / 2.1 1.3 / 1.2

.6 / .2

.38

2.0 / 1.6 .8 / .7 .6 / .7

2.5 / 2.1 .6 / .9

1.2 / 1.2









## **Product Information**

High	Pressure Sodium	
Lamp	supplied with fixture	

Compact Fluorescent Lamp supplied with fixture

Metal Halide	
amp supplied with fixture	
🗱 = Pulse Start	

**Accessories** 

		Lamp	Lamp	
1	Watts	Туре	Base	Ballast
	35	ED17	Med	R-NPF 120V
	50	ED17	Med	R-NPF 120V
	70	ED17	Med	R-NPF 120V
	70	ED17	Med	HX-HPF QT
	100	ED17	Med	R-NPF 120V
	100	ED17	Med	HX-HPF QT
	28	Quad	GX32d-3	NPF 120V
	42	Triple	GX24q-4	Electronic QT
S	<b>/</b> 50	ED17	Med	HX-NPF 120V
(2)	<b>f</b> 50	ED17	Med	HX-HPF 120V
(5)	<b>/</b> 50	ED17	Med	HX-HPF DT
(2)	<b>/</b> 70	ED17	Med	HX-NPF 120V
(2)	<b>/</b> 70	ED17	Med	HX-HPF QT
(2)	<b>/</b> 100	ED17	Med	HX-HPF QT

Wire Guard Shade - curved Shade - rectangular





Input Watts	Lamp ANSI	Initial Lumens	Lamp Hours
46	S76	2,250	24,000
62	S68	4,000	24,000
86	S62	6,300	24,000
91	S62	6,300	24,000
115	S54	9,500	24,000
130	S54	9,500	24,000
26		1,200	10,000
47		3,200	12,000
69	M110	3,400	10,000
69	M110	3,400	10,000
72	M110	3,400	10,000
94	M98	5,600	15,000
90	M98	5,600	15,000
129	M90	9,000	15,000

## Specifications @ us

### **UL Listing:**

Suitable for wet locations

## **Housing & Refractor:**

Vandal resistant polycarbonate molded refractor. Die cast Aluminum back plate.

Heavy die cast aluminum housing with prismatic glass refractor.

#### Reflector:

Die formed aluminum for wide light distribution.

### **Ballast Housing:**

Stamped steel painted white

#### **Back Plate:**

Heavy die cast aluminum. 1/2" bottom conduit knockout. Knockouts for mounting to 3" or 4" junction boxes.

HPS: Porcelain 4kv Pulse Rated CFL: 28w = GX32d-3, 42w = GX24q-4

#### **Sensor Switching Capacity:**

250 watts fluorescent on WPTFMS model only. 120 volt only.

### **Sensor Time Adjustment:**

5 seconds to 15 minutes

**Sensor Detection Zone:** Full 180° by 30'


## Info Online 24/7

Installation Manuals, Wiring Diagrams and Photometrics

www.rabweb.com > click "PRODUCTS"

## **Photometrics**

70w HPS @ 10' Mounting Height



Mounti Height	ng Multiplier	HPS Watts	Multiplier	CFL Watts	Multiplie
8'	1.6	100	1.5	22	.2
10'	1.0	70	1.0	42	.5
12'	.7	50	.6		
16'	.4	35	.4		
20'	.25	MH Watts	Multiplier		
		100	1.4		



## **Tallpack** Die Cast w/ Glass

Heavy duty die cast aluminum housing with prismatic glass refractor. HPS and Metal Halide models available. with 1/2" bottom and back conduit knockout. Factory installed photocell optional. Lamp included.

Finish: Architectural Bronze ○ White



## **HPS Tallpack**

HPS "Tall" Wallpack. Vandal resistant polycarbonate housing. Heavy diecast aluminum back plate with 1/2" bottom and back conduit knockout. Factory installed photocell optional. Lamp included.

Finish: Architectural Bronze ○ White



## **Fluorescent Tallpack**

28 & 42 watt compact fluorescent Tallpack. Vandal resistant polycarbonate housing. Heavy die-cast aluminum back plate with 1/2" bottom and back conduit knockout. Factory installed photocell optional. Operating temperature 28w (-20°F), 42w (0°F). Lamp included.

Finish: Architectural Bronze White



## **Fluorescent Smart Tallpack**

28 & 42 watt compact fluorescent Tallpack with built-in mini sensor for motion activated operation. Vandal resistant polycarbonate housing. Sensor has 180° detection and controls up to 250 watts. 120 volt only. Lamp included.

Finish: 

Architectural Bronze O White



## Catalog Numbers

For white fixture finish add suffix "W"

Photocell	No Photocell
WPTGSN70/PC WPTGSH70QT/PC WPTGSN100/PC WPTGSN100QT/PC	WPTGSN100
▲ Specify Photocell v	voltage
WPTGHN50/PC WPTGHH50/PC	WPTGHN50 WPTGHH50

WPTGHH50QT/PC▲ WPTGHH50QT WPTGHN70/PC WPTGHN70 WPTGHH70QT/PC▲ WPTGHH70QT WPTGHH100QT/PC▲ WPTGHH100QT

**GDWPTG GDWPTG** SHC1 SHC1 SHR<sub>1</sub> SHR<sub>1</sub>

For white fixture finish add suffix "W"

Photocell	No Photocell
WPTS35 WPTS50 WPTS70	WPTS35NPC WPTS50NPC WPTS70NPC

SHC1 SHC<sub>1</sub> SHR<sub>1</sub> SHR<sub>1</sub> For white fixture finish add suffix "W"

Photocell	No Photocell

WPTF28 WPTF28NPC WPTF42 WPTF42NPC

SHC1 SHC<sub>1</sub> SHR1 SHR<sub>1</sub>


For white fixture finish add suffix "W"


With Sensor


WPTF28MS (120 volt only) WPTF42MS (120 volt only)

SHC1 SHR<sub>1</sub>


## **Dimensions**







## **Detection Pattern**



Side View 30' Double Look Down Lens

TEL 888 RAB 1000 FAX 888 RAB 1232 www.rabweb.com



## **TALLPACK**

## Installation Instructions





Thank you for buying RAB lighting fixtures. Our aim is to design the best quality products so you can get the job done right. We'd like to hear your comments. Call us at 888-RAB-1000, attention Marketing Department.

### **IMPORTANT**

### READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.

RAB Tallpack fixtures must be wired in accordance with the National Electrical Code and applicable local codes. Proper grounding is required for safety.

Tallpack fixtures are for outdoor use and should not be used in areas with limited ventilation or high ambient temperatures. Installation should be done by a qualified electrician.

USE SUPPLY WIRE RATED FOR 90°. WARNING: RISK OF FIRE. MOST DWELLINGS BUILT BEFORE 1985 HAVE SUPPLY WIRE RATED FOR 60°. CONSULT AN ELECTRICIAN BEFORE INSTALLING. Warning: Make certain power is OFF before installing or maintaining fixture.

### LOCATION

Fixtures should not be recessed and is for wall mount only. Fixture must be positioned with lamp in vertical position with lampholder base up.

### MOUNTING

- 1. Loosen 2 screws from both sides of the front refractor.
- 2. Remove front refractor.
- 3. Remove refractor by loosening screws just enough to allow reflector to slide upward until keyhole in reflector releases screws.


#### **Standard Box Mounting:**


- 1. Remove center ½" Plug to route wires.
- 2. For 3½" or 4" round box or 4" square box, knockout 2 or 4 slotted openings in rear housing for screw attachment to box (screws not provided).
- Use gasket supplied. It is also advised to use weatherproof silicone sealant to prevent entry of moisture into fixture.

### **Odd-sized Box Mounting:**

- 1. Remove center 1/2" Plug to route wires.
- 2. Knockout 2 mounting holes in housing.
- 3. Mount with 2 lag screws (not provided) which will penetrate at least ¾" of wood or similar solid surface.
- 4. Use weatherproof silicone sealant when mounting fixture to outlet box and mounting surface to prevent entry of moisture into fixture.







**Opening** 



## TALLPACK INSTALLATION INSTRUCTIONS

MOUNTING

(continued)

**Bottom Conduit Mounting:** 


- 1. With front housing and reflector off, knockout the bottom conduit hole in the rear housing.
- 2. Pull service wires through the conduit opening and make connection as indicated under Wiring section.
- 3. Replace the reflector and refractor cover.
- 4. Attach to wall box per "Odd-sized Box Mounting", instructions #2 & 3 on previous page.



Use supply wire rated for 90°C.

Caution: Check that voltage is compatible with fixture ballast.

- 1. Connect the black fixture lead to the black supply lead.
- 2. Connect the white fixture lead to the white supply lead.
- Connect supply ground wire to fixture ground screw.



## RE-LAMPING

Caution: Prior to installing, check that the lamp is of the proper type and wattage. Observe lamp manufacturers recommendations on lamp operation, ballast type and burning positions. Disconnect power. Make sure fixture and lamp are cool enough to touch.

- Remove front refractor following instructions under Mounting section.
- 2. Remove old lamp.

- 3. Place lamp into lamp socket securely until it is firmly seated.
- 4. Replace front refractor.

### REPLACEMENT LAMPS

High Pressure Sodium		ANSI	Fluorescent	Fluorescent	
<b>Wattage</b>	Catalog #	Code	<u>Wattage</u>	Catalog #	
35	LHPS35	S76	28	LCFL28	
50	LHPS50	S68	42	LCFL42	
70	LHPS70	S62			

## **CLEANING**

Caution: Be sure fixture is cool enough to touch. Be sure power is off.

Clean reflector and refractor with a cloth moistened with non abrasive, non flammable glass cleaning solution.

### TROUBLE SHOOTING CHECKLIST

#### **Check that:**

- 1. Proper lamp is installed. Lamp is not faulty.
- 2. Line voltage at the fixture is proper.

- 3. Fixture is wired properly.
- 4. Fixture is grounded properly.

### **EASY INSTALLATION & PRODUCT HELP**

Fax Back 888-RAB-1236

Tech Help Line 8AM - 5PM ET Mon. - Fri. 888-RAB-1000

Wehsite www.rabweb.com e-mail sales@rabweb.com THESE INSTRUCTIONS DO NOT COVER ALL DETAILS OR VARIATIONS IN EQUIPMENT, NOR DO THEY PROVIDE FOR EVERY POSSIBLE CONTINGENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION OR MAINTENANCE.

Over 28 warehouses nationwide!

©2005 RAB Lighting, Inc.





JOB NAME:	
DATE:	

## **WPTS70**

#### **DESCRIPTION**

HPS "Tall" Wallpack. Vandal resistant polycarbonate housing. Heavy die-cast aluminum back plate with 1/2" bottom and back conduit knockout. Factory installed photocontrol optional. Lamp supplied.

### **SPECIFICATIONS**

#### **Back Plate:**

Heavy die cast aluminum. 1/2" bottom conduit knockout. Knockouts for mounting to 3" or 4" junction boxes

#### **Ballast Housing:**

Stamped steel painted white

#### Reflector:

Die formed aluminum for wide light

### distribution

**UL Listing:**Suitable for wet locations

### Housing:

Vandal resistant polycarbonate housing

#### Patents:

RAB sensor and fixture designs are protected under U.S. and International Intellectual Property laws.

#### Refractor:

Prismatic polycarbonate refractor for wide light distribution

#### Socket:

Porcelain 4kv Pulse Rated


#### Color: Bronze

Weight:

#### 6.17


### **DIMENSIONS**

TYPE:



#### **PHOTOMETRIC**

70w HPS @ 10' Mounting Height



	Mulup	res or mo	unung nerg	114	
Mounti Height	ng Multiplier	HPS Watts	Multiplier	CFL Watts	Multiplier
8'	1.6	100	1.5	22	.2
10'	1.0	70	1.0	42	.5
12'	.7	50	.6		
16'	.4	35	.4		
20'	.25	MH Watts	Multiplier		
		100	1.4		

#### ORDERING INFORMATION

**High Pressure Sodium** Total Lamp Lamp Starting Amps/ Operating Amps Input LAMP Initial Lamp Watts **Ballast** 120V 208V 240V Lamp supplied with fixture Type Base Lumens Hours 70 ED17 Medium R-NPF 120V 2.1/1.6 S62 6300 24000

Factory Installed Options Tamperproof screws (/TP)
Add suffix to Catalog Number Swivel Photocontrol (/PCS)

Single fusing for 120 and 277 volt (/F)

Double fusing for 208 and 240 volt (/FF) Button Photocontrol (/PC)

Note: Specifications may change without notice

## Appendix C

## PROCESS ROOM COMPONENTS

<u>Component</u>	PID	Description	<u>Manufacturer</u>	<u>Part Number</u>
Liquid Ring Pump 101	LRP-101	Liquid Ring Pump 101 40 HP, 600 ACFM @ 28.6" HG, 1750RPM 230/460 VAC, 3 Phase, 60 HZ	Travaini DynaSeal	TRO600V-1A-XP
Liquid Ring Pump 102	LRP-102	Liquid Ring Pump 102 40 HP, 600 ACFM @ 28.6" HG, 1750RPM 230/460 VAC, 3 Phase, 60 HZ	Travaini DynaSeal	TRO600V-1A-XP
Transfer Pump 200	TP-200	Transfer Pump 200 Progressive Cavity 1-1/2" Suction, 1-1/4" Discharge	Moyno	35601
Transfer Pump 200 Motor	TP-200	Transfer Pump 200 Motor 1//.75 HP, 1750//1450 RPM, 3 Phase, 143T Frame, 60//50 HZ, 230/460//190/380 VAC	Baldor	M7014T
Transfer Pump 202	TP-202	Transfer Pump 202 Progressive Cavity 1-1/2" Suction, 1-1/4" Discharge	Moyno	35601
Transfer Pump 202 Motor	TP-202	Transfer Pump 202 Motor 1//.75 HP, 1750//1450 RPM, 3 Phase, 143T Frame, 60//50 HZ, 230/460//190/380 VAC	Baldor	M7014T
Transfer Pump 300	TP-300	Air Operated Diaphragm Pump Max 49 GPM, Max 100 PSI, Max 30 CFM	Dayton	6PY44
Transfer Pump 301	TP-301	Transfer Pump 301 - Centrifugal 3 HP, 3500 RPM, 3 Phase, 60 HZ, 208-230/460 VAC, 8.3-7.6/3.8 A, 1-1/2" Suction, 1-1/4" Discharge, 56C Frame	Goulds	2ST1H7B
Lovejoy Coupler Body 1		Lovejoy Shaft Coupler Body for Transfer Pump 200, 202 & Motors	Lovejoy	68514436059 (Grainger 1L801)
Lovejoy Coupler Body 2		Lovejoy Shaft Coupler Body for Transfer Pump 200, 202 & Motors	Lovejoy	68514436060 (Grainger 1L802)

Component	PID	<u>Description</u>	<u>Manufacturer</u>	Part Number
Lovejoy Shaft Coupler Insert		Lovejoy Shaft Coupler Insert for Transfer Pump 200, 202 & Motors	Lovejoy	5JE (Grainger 1L797)
Oil Water Separator	OWS	200 GPM Oil Water Separator 80 Ft <sup>3</sup> Coalescing Media	Hydro Quip	AG-4CS-IP-1H
Knock Out Tank		220 Gallon Knock Out Tank Vapor Liquid Separator	ProAct	
Knock Out Tank Filter		6" L-Style Vacuum Filter	Solberg	CSL-375P-600F
Air Silencer		Dilution Air Silencer – Manifold Header	Solberg	FS-231P-200
Vacuum Relief Valve		Knock Out Tank Vacuum Breaker Set at 29"HG	Kunkle	215V
Bag Filter		Particulate Filters P12 bag size, 2" female NPT, 150PSI	RoseDale	NLCO8
Liquid Carbon Vessel		1000 LB Stainless Steel Liquid Carbon Vessel	ProAct	
Liquid Carbon Media		Granular Activated Liquid Carbon (Regen)	Envirotrol	EI-30R
Liquid Clay Vessel		1000 LB Stainless Steel Liquid Clay Vessel	ProAct	
Clay Media		Organoclay media – 8x30 Mesh	Hydrosil	HS-200
Vapor Carbon Vessel		1000 LB Stainless Steel Vapor Carbon Vessel	ProAct	

<u>Component</u>	<u>PID</u>	<u>Description</u>	<u>Manufacturer</u>	<u>Part Number</u>
Vapor Carbon Media		Granular Activated Vapor Carbon (Virgin)	Envirotrol	EI-410
Clean Water Tank		750 Gallon Clean Water Holding Tank	Norwesco	40606
Forced Air Heater		7.5kW Rear Process Room Heater	Indeeco	233-FA-0086U-T
Forced Air Heater		7.5kW Front Process Room Heater	Indeeco	233-FA-0086U-T
P-Fan		Process Room Fan - 16" Diameter 1/4HP, 1PH, 120V, XP, 1725RPM	Cook	16A17D
Shutter		12"x 12" Shutter for Process Room Man Doors	Dayton	4C556
Shutter		16" x 16" Shutter for Process Room Vent Fan	Dayton	4C557
Shutter		18" x 18" Shutter for Process Room Rear Doors	Dayton	4C558
Vapor Flow Meter	FM1 – FM2	Pitot Tube In-Line Flow Sensor for LRP-101, LRP-102	Dwyer	DS-300
Vapor Flow Transducer		Flow Transmitter and Display for FM1, FM2	Dwyer	ISDP
Liquid Flow Meter	FM3	Liquid Flow Meter - 1" B111 Meter Product Flow Totalizer	Blancett	B111-110
Liquid Flow Meter	FM4	Liquid Flow Meter – 1-1/2" B111 Meter Water Flow Totalizer	Blancett	B111-121

<u>Component</u>	PID	<u>Description</u>	<u>Manufacturer</u>	Part Number
Liquid Flow Monitor		Liquid Flow Monitor for FM3, FM4 B2800 Simplified	Blancett	B2800
Vacuum Transducer	VT1 – VT14	Vacuum Transducer - DPE Manifold (-14.7 – 30 PSI)	American Sensor Technologies, Inc.	AST4400
Vacuum Transducer	VT15	Vacuum Transducer - Knock Out Tank (-14.7 – 30 PSI)	American Sensor Technologies, Inc.	AST4400
Vacuum Transducer	VT16 – VT17	Vacuum Transducer - LRP-101, LRP-102 (-14.7 – 30 PSI)	American Sensor Technologies, Inc.	AST4400
Pressure Transducer	PT1 – PT3	Pressure Transducer - Vapor Pressure (0 – 5 PSI)	American Sensor Technologies, Inc.	AST44LP
Pressure Transducer	PT4 – PT11	Pressure Transducer - Liquid Pressure (0 – 50 PSI)	American Sensor Technologies, Inc.	AST4400
Differential Pressure Transducer	DPT1	Differential Pressure Transducer – Knock Out Tank $(0-50 \text{ IWC})$	Dwyer	ISDP
Differential Pressure Transducer	DPT2	Differential Pressure Transducer – Bag Filters (0 – 50 PSID)	InterTechnology GP:50	315Z
Vacuum Gauge	VII – VI15	Vacuum Gauge (-30 – 0 HG)	Precision Instrument Co	201L 202L
Pressure Gauge	PI1 – PI7	Pressure Gauge (0 - 160 IWC)	Precision Instrument Co	LP1
Pressure Gauge	PI8 – PI9, PI11 – PI20	Pressure Gauge (0 - 60 PSI)	Precision Instrument Co	201L 202L
Pressure Gauge	PI10	Pressure Gauge (0 - 100 PSI)	Precision Instrument Co	201L 202L

Component	PID	<u>Description</u>	<u>Manufacturer</u>	Part Number
Pneumatic Actuator		Pneumatic Actuator for AV1-AV14	Valworx	5301
Butterfly Valve	AV1 – AV14	4" Automated Butterfly Valve – DPE Manifold	Valworx	5647
Gate Valve	PV1 – PV14	4" Gate Valve	Nibco	TI-8
Butterfly Valve	PV29 – PV32	2" Butterfly Valve - Bag Filter Influent / Effluent Isolation Valves	Delval	DN50
Butterfly Valve	PV16 – PV17	4" Butterfly Valve – LRP-101, LRP-102 Isolation Valves	Delval	DN100
Ball Valve	PV19 – PV20	1" Ball Valve – TP-200, TP-202 Effluent Valves	Apollo	94A-105
Ball Valve	PV22 – PV24	1" Ball Valve – Miscellaneous Product Valves	Apollo	94A-105
Ball Valve	PV28	1-1/4" Ball Valve – TP-301 Discharge Valve	Apollo	94A-106
Ball Valve	PV15	2" Ball Valve – Air Dilution DPE Manifold	Apollo	94A-108
Ball Valve	PV18	2" Ball Valve – Knock Out Tank Water Effluent	Apollo	94A-108
Ball Valve	PV21	2" Ball Valve – TP-200 and TP-202 Combined Discharge Valve	Apollo	94A-108
Ball Valve	PV27	2" Ball Valve – Oil Water Separator Site Discharge Valve	Apollo	94A-108

Component	PID	<u>Description</u>	<u>Manufacturer</u>	Part Number
Ball Valve	PV33 – PV41	2" Ball Valve – Carbon Vessel, Clay Vessel Inlet and Outlet Valves	Apollo	94A-108
Ball Valve	PV25 – PV26	2" Ball Valve – Oil Water Separator Site Tube Isolation Valve	Asahi	1605020
Ball Valve (Sample Ports)	SP1 - SP26	1/4" Ball Valve - Sample Port Valves	Apollo	94A-101
Ball Valve (Air Bleed)	ABV1 - ABV2	1/4" Ball Valve - Bag Filter Ambient Breather Valves	Apollo	94A-101
Ball Valve (Bypass Loop)	BLV	1" Ball Valve - Transfer Pump Bypass Loop Valves	Apollo	94A-105
Ball Valve (Drain)	D	1" Ball Valve - Drain Valves	Apollo	94A-105
Check Valve		1/2" Check Valve - Anti-Siphon	Nibco	T-413
Check Valve		1" Check Valve – Transfer Pump Discharge Valves	Nibco	T-413
Vacuum Relief Valve		1/2" Anti-Siphon Valve	Watts	N36-M1
Floor Sump Float Switch	LSH17 – LSH18	Float Switch NC, Open on Rise	Madison	M5000
Y-Strainer		2" Y-Sediment Strainer Under Knock Out Tank	Asahi	1257-020
Hose		Petroleum Hose used in system	Goodyear	Flexwing

Component	<u>PID</u>	<u>Description</u>	<u>Manufacturer</u>	Part Number
Hose		Petroleum Hose used in system	Gates	Longhorn
Hose		Thermoplastic Rubber Hose used in system	West Michigan Rubber & Supply	RFH





Water Sealed & Oil Sealed (DynaSeal™)
Systems



Web Site: www.travaini.com

200 NEWSOME DRIVE YORKTOWN, VA 23692 Telephone: 757.988.3930

Toll Free: 800.535.4243

Fax: 757.988.3975



OPERATING
MANUAL FOR
INSTALLATION,
START-UP AND
MAINTENANCE
FOR LIQUID
RING VACUUM
PUMPS,
COMPRESSORS
AND SYSTEMS

This manual applies to TRAVAINI PUMPS USA liquid ring pumps single stage series TRM, TRS, TRV, double stage series TRH, compressors series SA and systems series water sealed and oil sealed (DynaSeal™) Systems, which utilize above pump series. (Please see section 18 or 19 for details pertaining to systems).

NOTE: Unless otherwise specified, the term pump used throughout this manual means also pump/motor assembly or system type water sealed or oil sealed (DynaSeal<sup>™</sup>).

#### **MANUFACTURER:**

#### TRAVAINI PUMPS USA

200 Newsome Drive Yorktown, VA 23692

Telephone: (757) 988-3930 Fax: (757) 988-3975 Website: www.travaini.com

#### WARRANTY:

All products manufactured by TRAVAINI PUMPS USA are guaranteed to meet the conditions listed on the general terms & conditions of sales and/or conditions listed on the order confirmations. Failure to strictly adhere to the instructions and recommendations listed in this manual, will void the manufacturer's warranty. Detailed warranty policy can be found in Section 21.

#### PROPRIETY DOCUMENT:

This document and the information enclosed herein are proprietary to Travaini Pumps USA and must, along with any copies, be returned upon demand. Reproduction or use of any information disclosed herein, or the manufacture of any assembly or part depicted herein is permissible only to the extent expressly authorized in writing by Travaini Pumps USA on and for which this document is provided.

In preparing this manual, every possible effort has been made to help the customer and operator with the proper installation and operation of the pump and/or system. Should you find errors, misunderstandings or discrepancies please do not hesitate to bring them to our attention.



LIQUID RING VACUUM PUMPS

**LIQUID RING COMPRESSORS** 

**ROTARY VANE VACUUM PUMPS** 

**ROTARY VANE VACUUM SYSTEMS** 

**MEDICAL SYSTEMS (NFPA99)** 

PACKAGE VACUUM SYSTEMS
WITH PARTIAL OR TOTAL
SERVICE RECIRCULATION

CUSTOM ENGINEERED VACUUM SOLUTIONS



"Proven Designs"

SECTIO	N		PAGE	SECTION	PAG
1	Gener	al instructions	1	9.9	Typical installation schematics for vacuum pumps 18
2	Safety	instructions	1	9.1	LO Typical installation schematics for compressors 19
3	In cas	e of emergency	2	9.1	L1 Connections location
	3.1	Basic first aid	2	9.1	L2 Pump engineering data
4	Pump	outlines	3	10 Ch	eck list prior to start-up
	4.1	Principle of operation	3	11 Sta	arting, operating and stopping procedures
	4.2	Service liquid properties	3	11	.1 Start-up of "WATER SEALED" system
	4.3	Pump models and tables for material of construction	3	11	.2 Operation of "WATER SEALED" system
5	Uncrat	ting, lifting and moving instructions	4	11	.3 Shut down of "WATER SEALED" system
6	Storag	ge instructions	7	11	.4 Start-up of "OIL SEALED (DynaSeal™)" systems
7	Mount	ting and alignment instructions	7	11	.5 Operation of "OIL SEALED (DynaSeal <sup>TM</sup> )" systems
	7.1	Assembly of base mounted pump unit	7	11	.6 Shut down of "OILSEALED (DynaSeal <sup>TM</sup> )" systems
	7.2	Alignment procedures for monoblock and for	8	12 Op	erating maintenance
		pump/motor assembly on baseplate		12	.1 "OIL SEALED (DynaSeal™)" systems
	7.3	Alignment instructions		13 Be	arings and mechanical seals maintenance
8		cal connections		13	.1 Bearings
9	Install	ation instructions	12	13	.2 Mechanical seals
	9.1	Piping connections	13	14 Tro	buble shooting: problems, causes and solutions
	9.2	Accessories	13	15 Re	pairing and removing pump from the installation34
	9.3	Installation schematics for vacuum pumps	14	16 Sp	are parts35
	9.3.1	Service liquid: Once-through system (no recovery)	14	17 Eng	gineering data36
	9.3.2	Service liquid: Partial recovery system	14	17	.1 Influence of service liquid temperature, specific gravity 36
	9.3.3				and viscosity on pump performance
	9.4	Installation schematics for compressors	15	17	.2 Service liquid temperature change across the pump
	9.5	Installation of "WATER SEALED" systems	15	17	.3 Operation with partial recovery of service liquid
	9.6	Installation of "OIL SEALED (DynaSeal™)" systems	15	17	.4 Units conversion table
	9.7	Service liquid (H <sub>2</sub> O at 60° F) flow (in ACFM) for	16	18 Eng	gineering data for "WATER SEALED" systems
	0.0	vacuum pumps	4 7	19 Eng	gineering data for "OIL SEALED (DynaSeal $^{ extsf{TM}}$ )" systems
	9.8	Service liquid flow (H <sub>2</sub> O at 60° F) and pressure for	1/	20 Pro	oduct Data Information Form
		55p. 556676 567766 577		21 Wa	arranty Policies - Vacuum Pumps, Compressors and Systems 45

## 1 – GENERAL INSTRUCTIONS

This manual is intended to provide reference to:

- application and operating safety
- installation and maintenance for pump or system
- starting, operating and stopping procedures for pump or system

NOTE: All references made to pumps are also applicable to systems that employ these pumps, unless otherwise specified.

Upon receipt of this manual, the operator should complete the Product Data sheet with the requested data. The manual should then be read **CAREFULLY** and kept in a safe file for future reference. It should always be available to the qualified operating and maintenance personnel responsible for the safe operation of the pump or system. (Qualified personnel should be experienced and knowledgeable of Safety Standards, should be recognized by the safety department manager as being capable to effectively act on safety issues, should the need arise and knowledge of first aid should also be required).



The pump is to be used only for the applications specified on the confirming order for which TRAVAINI PUMPS USA has selected the design, materials of construction and tested the pump to meet the order specifications. Therefore, the pump or system **CANNOT** be used for applications other than those specified on the order confirmation.

In the event the pump is to be used for different applications, please consult TRAVAINI PUMPS USA or a representative of the manufacturer. TRAVAINI PUMPS USA declines to assume any responsibility if the pump is used for different applications without prior written consent. The user is responsible for the verification of the ambient conditions where the pump will be stored or installed. Extreme low or high temperatures may severely damage the pump or system unless proper precautions are taken. TRAVAINI PUMPS USA does not guarantee repairs or alterations done by user or other unauthorized personnel. Special designs and constructions may vary from the information given in this manual. Please contact TRAVAINI PUMPS USA should you have any difficulty or doubt.

<u>NOTE:</u> Drawings appearing in this manual are only schematics. These drawings are not for construction.

## 2 - SAFETY INSTRUCTIONS



**CAUTION:** 

CAREFULLY READ FOLLOWING INSTRUCTIONS. STRICTLY ADHERE TO THE INSTRUCTIONS LISTED BELOW TO PREVENT PERSONAL INJURIES AND/OR EQUIPMENT DAMAGE.

- **ALWAYS** apply the pump for the conditions outlined on the confirming order.
- Electrical connections on the motor or accessories must **ALWAYS** be carried out by authorized personnel and in accordance to the local codes.
- Any work on the pump should be carried out by at least 2 people.

When approaching the pump **ALWAYS** be properly dressed (avoid use of clothing with wide sleeves, neckties, necklaces, etc.) and/or wear safety equipment (hard hat, safety glasses, safety shoes, etc.) adequate for the work to be done.

- **ALWAYS** stop the pump prior to touching it, regardless of the reason.
- ALWAYS disconnect the power to the motor prior to working or removing the pump from the installation.
- **NEVER** work on the pump when it is hot.
- After completion of the work ALWAYS re-install the safety guards previously removed.
- ALWAYS be careful when handling pumps that convey acids or hazardous fluids.
- **ALWAYS** has a fire extinguisher in the vicinity of the pump installation.
- **DO NOT** operate the pump in the wrong direction of rotation.
- **NEVER** put hands or fingers in the pump or system openings or cavities.
- **NEVER** step on pump and/or piping connected to the pump.
- Pump or piping (connected to the pump) must NEVER be under pressure or vacuum when maintenance or repair is carried out.

<u>NOTE:</u> There are materials in the pump that may be hazardous to people suffering from allergies. Maintenance and operating personnel should consult Table 1 for such materials.

TABLE 1

MATERIAL	USE	POSSIBLE DANGER
Oil and Grease	General lubrication, ball	Skin and eye irritation
	or roller bearings	
Plastic and elastomer	O-Ring, V-Ring, Splash ring,	Release of fumes and
components	Oil seals	vapours when overheated
Teflon & Kevlar fibers	Packing rings	Release of dangerous
		powders, release of
		fumes when overheated
Varnishes	Exterior pump surface	Release of powder and
		fumes in case of rework,
		flammable
Protective liquid	Pump inside surface	Skin and eye rash
Liquid compound	Gasket between flat surfaces	Skin, eye and breathing
		organs irritation

## 3 - IN CASE OF EMERGENCY

Should the pump break down leak gas and/or service liquid, immediately disconnect the electrical power following the instructions given in section 11. Alert the maintenance personnel, at least two people should intervene using precautions, as it is required for the specific installation: pump may be handling dangerous and/or hazardous fluids.

After correction of all the problems that created the emergency situation, it is necessary to carry out all the recommended starting procedures (see section 10).

#### 3.1 - BASIC FIRST AID

In the event dangerous substances have been inhaled and/or have come in contact with the human body, immediately contact the medical staff and follow the instructions given by the company's internal medical safety procedures.

## 4 - PUMP OUTLINES

The instructions given in this manual are for liquid ring vacuum pumps and compressors and for systems type WATER SEALED or OIL SEALED (DynaSeal $^{\text{TM}}$ ) which utilize said pumps.


NOTE: Capacities, vacuum and pressures are nominal and are the maximum attainable values under standard operating conditions. Please contact TRAVAINI PUMPS USA for data on liquid ring compressors series TR...

TRM	Single stage liquid ring vacuum pumps Capacity to 210 ACFM, max vacuum 33 mbar (25 Torr)
TRS	Single stage liquid ring vacuum pumps Capacity to 2100 ACFM, max vacuum 150 mbar (100 Torr)
TRV	Single stage vacuum pumps Capacity to 300 ACFM, max vacuum 33 mbar (25 Torr)
TRH	Two stage liquid ring vacuum pumps Capacity to 2100 ACFM, max vacuum 33 mbar (25 Torr)
SA	Double acting liquid ring compressors Capacity to 110 ACFM, pressures to 10 bar–(145 psig)

#### 4.1 - PRINCIPLE OF OPERATION

(See figure at side)

The aspirated gas enters the pump chamber A-B via the pump suction flange. The gas is trapped between two (2) impeller vanes. The impeller rotates eccentrically in relation to the centerline of the liquid ring that, by centrifugal force, assumes the shape of the impeller casing. The progressive change of volume between the two (2) vanes, the impeller hub and the liquid ring first creates a vacuum and then a compression of the gas in the B-C area till the gas is discharged, together with a portion of the liquid, through the discharge port C-D. The lost liquid must then be replenished.



#### **4.2 - SERVICE LIQUID PROPERTIES**

For good operation, the liquid ring pumps must be supplied with a service liquid, which is clean, non-abrasive and free of any solids. The service liquid temperature should not exceed 80 °C and the gas handled should be maximum 100 °C; the liquid density should be between 0.8 and 1.2 g/cm3 and the viscosity should be less than 40 °C (the pump performance will change if the service liquid has properties different than those of water at 15°C (60°F). All engineering data is based on the use of 15°C (60°F) as service liquid, see section 17 for additional information. Contact TRAVAINI PUMPS USA before using liquids with properties outside the ranges listed above.

#### 4.3 - PUMP MODELS AND TABLES FOR MATERIAL OF CONSTRUCTION

On the pump nameplate are printed the pump serial number, the year of manufacture and the pump model. Refer to the following example for understanding the coding of the pump model. Every letter or number in the pump model designation has a specific meaning relating to the pump design.

Example of pump model number:

_		
	T R H C 80 - 7	50 / C - M / GH
T	<ul> <li>Manufacturer POMPETRAVAINI</li> </ul>	<b>750</b> – Nominal capacity in m <sup>3</sup> /h
R	<ul> <li>Liquid ring pump</li> </ul>	<b>C</b> – C = Shaft sealing by mechanical
Н	<ul> <li>M and V = Single stage pump</li> </ul>	seal
	with high vacuum	B = Shaft sealing by stuffing box
	S = Single stage pump with	M – Monoblock design with motor
	medium vacuum	flange (upon request)
	H = Two stage pump with high	GH - Material of construction
	vacuum	GH - F - RZ - RA - A3
C	<ul> <li>Revision of hydraulic design</li> </ul>	(see following table)
80	<ul><li>Ø Flange size (mm)</li></ul>	]

STANDARD materials of construction

VDMA	Description	GH	F	RZ	RA	А3
106	Suction casing					
107	Discharge casing		Cast iron 1561			
137	Intermediate plate					
110	Center body	Carbon Steel				
210	Shaft	Stainless steel AISI 420 Stair			Stainles	ss steel
					AISI	316
147	Manifold	Carbon steel				
357	Bearings & M.S. Hous.	Cast iron 1561				
230	Impeller	Bronze	Duotilo			

For additional details regarding standard or special materials contact TRAVAINI PUMPS USA.

# 5 - UNCRATING, LIFTING AND MOVING INSTRUCTIONS

Upon receipt, verify that the material received is in exact compliance with that listed on the packing slip.

When uncrating, follow the instructions listed below:

- check for visible damages on the crate that could have occurred during transport
- carefully remove the packaging material
- check the pump/or accessories such as tanks, piping, valves, etc. to ensure that it is free of visible markings such as dents and damage which may have occurred during transportation
- in the event of damage, report this immediately to the transport company and to TRAVAINI PUMPS USA Customer Service department.

Discard through controlled disposals all packaging materials that may constitute personal injury (sharp objects, nails, etc.).

The pump or assembly must **ALWAYS** be moved and transported in the horizontal position. Prior to moving the unit find the following:


- total weight
- center of gravity
- maximum outside dimensions
- lifting points location.




For safe lifting to prevent material damages and/or personal injuries is recommended to use ropes, or belts properly positioned on the pump and/or lifting eyebolts and make correct movements.

NOTE: Lifting eyebolts fitted on single components of the assembly (pump or motor) should not be used to lift the total assembly.

Avoid lifts whereby the ropes or straps, form a triangle with the top angle over 90° (see fig. 3). The fig. 4 shows several additional examples of lifting to be avoided. Prior to moving the unit from an installation, always drain any pumped fluid from the pump, piping and accessories, rinse and plug all openings to prevent spillage. For instructions to remove the unit from installation see section 15.





## **6 - STORAGE INSTRUCTIONS**

After receipt and inspection, if not immediately installed, the unit must be repackaged and stored. For a proper storage proceed as follows:

- store the pump in a location that is closed, clean, dry and free of vibrations
- do not store in areas with less than 5 °C (41 °F) temperature (for lower temperature it is necessary to completely drain the pump of any liquids that are subject to freezing)



#### FREEZING DANGER!

Where the ambient temperature is less than 5 °C (41°F) it is recommended to drain the pump, piping, separator, heat exchanger, etc. or add an anti-freeze solution to prevent damage to the equipment.

- fill the pump halfway with an anti-rust liquid but compatible with gaskets and elastomers materials, rotate the pump shaft by hand so that all internal parts get wet and then drain the pump of the excessive anti-rust liquid
- plug all openings that connect the pump internals to the atmosphere
- protect all machined surfaces with an anti-rust material (grease, oils, etc.)
- cover the unit with plastic sheet or similar protective material
- rotate pump shaft at least every three months to avoid possible rust build-up which may result in seizing of the pump.
- pump accessories should be subjected to similar procedure.

## 7 - MOUNTING AND ALIGNMENT INSTRUCTIONS

#### 7.1 - ASSEMBLY OF BASE MOUNTED PUMP UNIT



In some cases such as bare pump orders, pumps are shipped with anti-rust and anti-freeze agents. Ensure pump is thoroughly flushed and these agents are removed prior to installation.

If the pump has been purchased with a free shaft end, a proper baseplate is required to mount the pump/motor assembly. The baseplate must be properly designed for maximum rigidity to prevent vibrations and distortions. It is recommended the use of a fabricated baseplate manufactured with rigid "U" shaped channel (fig. 16 illustrates an example).

When the pump has been purchased without the electric motor, it is then required to select the proper motor before proceeding to the installation of the unit. When selecting a motor the following must be considered:

- maximum power absorbed by the pump over the total operating range
- pump operating speed (RPM)
- available power (Hertz, voltage, etc.)
- motor enclosure type (ODP, TEFC, EX.PR., etc.)
- motor mount (B3, B5, horizontal, vertical, C-flange, D-flange, etc.).

When selecting Flexible couplings the following must be considered:

- nominal motor horsepower
- motor operating speed
- coupling guard must meet safety standards as dictated by OSHA, etc.

Flexible couplings must be properly aligned. Bad alignments will result in coupling failures and damage to pump and motor bearings.

Assembly instructions for MONOBLOCK design are listed on paragraph 7.3 steps 1. 2. 4. 5. 6.

Assembly instructions for PUMP-MOTOR ON BASEPLATE are listed on paragraph 7.3 steps 7. 1. 8. 5. 9. 10. 11.

For pump driven with V-Belt, please consult TRAVAINI PUMPS USA for further information.

#### 7.2 - ALIGNMENT PROCEDURES FOR MONOBLOCK AND FOR PUMP/MOTOR ASSEMBLY ON BASEPLATE.

TRAVAINI PUMPS USA prior to shipment properly aligns the pump/motor assembly. It is however required to verify the alignment prior to the start-up. Misalignment can occur during handling, transportation, grouting of assembly, etc.

For alignment procedures of MONOBLOCK design see paragraph 7.3 steps 3, 4, 5. 6.

For alignment procedure of BASEPLATE design see paragraph 7.3 steps 7. 5. 9.

NOTE: Coupling sizes and permissible coupling tolerances listed in this manual are applicable to the particular coupling brand installed by TRAVAINI PUMPS USA as a standard. For sizes and tolerances of other type of couplings, follow the instructions given by their respective manufacturer.


#### 7.3 - ALIGNMENT INSTRUCTIONS

NOTE: Alignment should be done at ambient temperature, with power to the motor disconnected and following the safety procedures to avoid accidental starting (see section 2).


Should the pump operate at high temperatures that could upset the coupling alignment, it is necessary to check the alignment to secure proper working operation at such operating temperatures. It is recommended the use of proper hand protections such as gloves, when carrying out the operations listed below (schematics for various assemblies are shown).

NOTE: The following points must be followed with the sequence stated above and depending upon the type of operation: alignment assembly or alignment verification.

1 - Thoroughly clean motor/pump shaft ends and shaft keys, place the shaft keys in the proper key way slots and fit the coupling halves in line with the shaft ends. The use of rubber hammers and even pre-heating of the metal half couplings may be required (see fig. 5). Lightly tighten the set screws. Verify that both pump and motor shafts rotate freely.



- **2** Insert the perforated metal sheet coupling guard inside the lantern so that the coupling is accessible from one of the lateral openings. Couple the electric motor to the pump lantern engaging the two coupling halves, hands may reach the coupling halves through the lateral opening (see fig. 7) tighten the assembly with bolts supplied with the unit and install the supporting foot, when applicable (see fig. 6).
- **3** Applying slight hand pressure to the coupling guard, rotate it so that one opening of the lantern is accessible (see fig. 8).






Fig. 7 - PREPARING TO ASSEMBLE THE MONOBLOCK DESIGN




Fig. 8 - CHECKING THE ALIGNMENT ON MONOBLOCK DESIGN

- **4** Rotate by hand the coupling through the lateral opening of the lantern to make sure the pump is free.
- **5** With a feeler gauge, check the distance between the two coupling halves. The gap value "S" should be as listed on table 2 or as given by the coupling manufacturer. In the event, an adjustment is necessary, loosen the set screws on the coupling half and with a screw driver move the coupling half to attain the gap "S" (see fig. 12). Then tighten the set screw and rotate the rotor by hand to make sure, once more, that there is no obstruction.
- **6** Rotate back the coupling guard by hand through the two openings of the lantern so that both openings are completely covered. This will complete the alignment verification of the MONOBLOCK design.
- **7** Remove the coupling guard and its extension (if there is one) attached to the pump, by removing the two locking screws (see fig. 9 and 10).




Fig 9 - CHECKING ALIGNMENT ON BASE MOUNTED PUMP DESIGN




Fig. 10 - ASSEMBLING THE UNIT ON THE BASEPLATE

**8** - Place the electric motor on the baseplate and bring the two coupling halves together with approx. 2mm gap between them keeping the motor axially aligned with the pump shaft. In the event the two shaft heights do not align, proper shimming under the pump or motor feet will be required. Mark the motor and/or pump anchoring bolt holes. Remove motor and/or pump, drill and tap the holes, clean and mount pump and/or motor in place and lightly tighten the bolts (see fig. 11).





Fig. 11

**9** - With a straight edge ruler check the parallelism of the two coupling halves at several points, 90° from each other (see fig. 13).

NOTE: Easier and more accurate readings can be attained with instruments such as Dial Indicators (if readily available).

If the maximum value of "X" is higher than that listed in the table 2 (for the given coupling size) it will be required to correct the align-

ment by using shims under the pump or motor feet. When the measured values fall within the tolerances (tolerances only given for "S"), the pump and motor mounting bolts can be tightened.




10 - Angular misalignment can be measured with a Caliper. Measure the outside coupling dimension at several points (see fig. 14). Find the minimum and maximum width of the coupling, the difference between these two readings "Y" (Y1-Y2) should not exceed the value listed in table 2 for the given coupling size. Should this value be greater it will be necessary to correct the alignment by shimming the pump and/or motor. Following this operation it is recommended to check once more the value "X" to make sure that both values are within the allowed tolerance (see point 9). Make

sure that both set screws on the coupling halves are properly secured.

<b>T</b> -		-	•
ıа	b	ıe	_

COUPLING "Ø A" mm	GAP "S" mm	PARALLEL "X" mm	ANGULAR "Y" mm		
60	2 to 2.50	0.10	0.20		
80	2 to 2.50	0.10	0.20		
100	2 to 2.50	0.15	0.25		
130	2 to 2.50	0.15	0.25		
150	3 to 3.75	0.15	0.30		
180	3 to 3.75	0.15	0.30		
200	3 to 3.75	0.15	0.30		

**11** - Install the coupling guard and its extension (if applicable) on the pump, secure the two locking bolts. The gap between motor frame and the guard should not be greater than 2 to 3mm (see fig. 15).



8 - ELECTRICAL CONNECTIONS



Electrical connections must be made exclusively by qualified personnel in accordance with the instructions from the manufacturer of the motor or other electrical components and must adhere to the local National Electrical Code.



FOLLOW ALL SAFETY PRECAUTIONS AS LISTED IN SECTION 2. BEFORE DOING ANY WORK TO THE INSTALLATION, DISCONNECT ALL POWER SUPPLIES.

It is recommended that electric motors be protected against overloading by means of circuit breakers and/or fuses. Circuit breakers and fuses must be sized in accordance with the full load amperage appearing on the motor nameplate. It is advisable to have an electrical switch near the pump for emergency situations. Prior to connecting the electrical wiring, turn the pump shaft by hand to make sure that it rotates freely. Connect the electrical wiring in accordance with local electrical codes and be sure to ground the motor. Motor connection should be as indicated on the motor tag (frequency and voltage) and as discussed in the motor instruction manual. It is recommended that motors over 75Hp be wired for soft

start, to avoid electrical overloads to the motor and mechanical overloads to the pump. Be sure to replace all safety guards before switching on the electrical power. If possible check the direction of rotation before the motor is coupled to the pump but protect the motor shaft to prevent any accidents. When this is not possible briefly jog the pump to check its direction of rotation (see arrow on pump for correct rotation). If the direction must be changed two of the three electrical wire leads must be alternated with each other (at the terminal box or at the motor starter). Be aware that rotation in the wrong direction and/or pump running dry may cause severe pump damage. Electrical instrumentation such as solenoid valves, level switches, temperature switches, etc. which are supplied with the pump or systems must be connected and handled in accordance with the instructions supplied by their respective manufacturers. Contact TRAVAINI PUMPS USA for specific details.

## 9 - INSTALLATION INSTRUCTIONS

Information to determine the piping sizes and floor space requirements can be obtained from dimensional drawings and other engineering data. The information required is:

- size and location of suction and discharge flanges
- size and location of service liquid connection and connections for cooling, heating, flushing, draining, etc.
- location and size for mounting bolts for monoblock pump and/or baseplate and/or frame.

In the event additional accessories are required to complete the installation such as separators, piping, valves, etc. refer to sections 9.2 to 9.8. Proper lifting devices should be available for installation and repair operations. Pump assembly should be installed in an accessible location with adequate clear and clean space all around for maintenance, so that an efficient and proper installation can be made. It is important to have proper room around the unit for ventilation of motor and air-cooled radiator, if applicable. Avoid installing the unit in hidden locations, dusty and lacking of ventilation. Select a mounting pad that will minimize vibrations or torsion of the pump baseplate or frame. It is generally preferred to have a concrete base or sturdy steel beams. It is important to provide adequate anchor bolting for the pump frame or baseplate to be firmly attached to the foundations (see fig. 16).




Fig. 16

Concrete pads and other concrete works must be aged, dry and clean before the pump assembly can be positioned in place. Complete all the work relating to the foundations and grouting of the pump assembly, before proceeding with the mechanical and electrical portion of the installation.

#### 9.1 - PIPING CONNECTIONS

Identify first locations and dimensions of all connections required to interconnect the pump with the installation, then proceed with the actual piping: connect the pump suction and discharge flanges, the service liquid line and all other service connections (see fig. 17 to 26).



## BE SURE TO PIPE THE CORRECT CONNECTION FROM THE INSTALLATION TO THE RESPECTIVE PUMP CONNECTION!

To prevent foreign matters from entering the pump during installation, do not remove protection cap from flanges or cover from openings until the piping is ready for hook-up. Verify that all foreign objects such as welding bits, bolts, nuts, rags and dirt are removed from piping, separators, etc. before these are connected to the pump. Flanges should be connected parallel with each other, without stress and with bolt holes lined up. The flange gaskets should not interfere with the inside diameter of piping and/or flange. All piping must be independently supported, easily located and must not transmit forces or torque to the pump due to the weight or to thermal expansions. Piping size must never be less than the respective connection on the pump. Suction and discharge flanges are vertical and identified with arrows. To minimize friction losses and back-pressures, the discharge piping should be one size larger than the pump connection size. To avoid back-pressure and possibility of flooding the pump when it stops, it is recommended to limit the rise of the discharge piping to approximately 2 feet above the pump discharge flange. Upon completion, piping and connections should be tested for leakage under vacuum.

#### 9.2 - ACCESSORIES

Listed below are common accessories that may be supplied with the pump or added at a later date. See fig. 17 to 26 for locations and connection sizes on the pumps.

#### Non return valve, (check valve)

Prevent back-flow of gas and liquid in the suction piping and/or discharge piping when the pump stops. Is installed on the pump suction flange in the case of vacuum service or on the pump discharge flange in the case of compressor service.

#### Vacuum relief valve

It is used to protect the pump from cavitation or to regulate the suction minimum pressure (or max vacuum).

When the pump capacity exceeds the system load at a given vacuum, the relief valve opens letting in atmospheric air or gas (if connected to the discharge separator) keeping constant the pre-set vacuum.

#### **Automatic draining valve**

It is used to drain the pump to the shaft centerline when the pump stops so to prevent that the pump has excessive liquid for the next start-up. Starting the pump full or with too much liquid could severely damage the pump and may cause excessive Amp draw from the motor.

#### Vacuum gauge

It usually installed under the pump suction flange and will provide an indication of the pump operating vacuum (pressure).

#### Discharge reservoir separator

It separates the service liquid from the gases at the pump discharge. It can be mounted on the pump discharge flange or on the pump baseplate. It is required when the system is with partial or total recovery of the service liquid.

#### **Heat exchanger**

It cools the service liquid for those systems with total liquid recovery: it can be plate and frame, shell and tube or radiator type, depending upon the application.

#### Filter

Required to stop solids from entering the pump suction. Sizing of the filter is very important as it could create excessive pressure drops, which would affect the pump performance.

#### 9.3 - INSTALLATION SCHEMATICS FOR LIQUID RING VACUUM PUMPS

The working principle of the vacuum pump requires a continuous flow of fresh and clean liquid that enters the pump at the service liquid connection identified by the letter  ${\bf Z}$  (see section 9.11). The liquid is discharged together with the handled gas through the pump discharge flange. The quantity of said liquid will vary with pump size and degree of working vacuum (see performance curves and/or table 3). The service liquid absorbs the compression heat generated by the pump compression, which results in a temperature rise of the service liquid (for additional information, see chapter 17). There are three basic installation schematics listed below that may be considered, depending upon the quantity of service liquid that is desired and possible to be recycled.

#### 9.3.1 - Service liquid: Once-through system (no recovery)

All the service liquid is supplied from an external source. The liquid is separated from the incoming gas in the discharge separator and is completely drained. This is a popular installation and is used where there is an abundant supply of fresh liquid and/or there is no contamination of the same. The service liquid should be supplied at the pump connection with a pressure of 5.8psig maximum to avoid flooding the pump with too much liquid. If this is not possible it is recommended to install a reservoir fitted with a float valve, this tank is supplied with the liquid that is then pulled by the pump as required by the operating conditions. The liquid level in the reservoir should be approximately at the pump shaft centerline. Schematic fig. 17 illustrates the once-through system.

#### 9.3.2 - Service liquid: Partial recovery system

This type of installation is used where it is desired to minimize the use of fresh service liquid (for calculations see section 17). The service liquid enters and leaves the pump same as the once through system, however part of the liquid is recycled from the discharge separator and the balance is continuously supplied from an external source. The excessive liquid is drained through the separator overflow connection. The temperature of the mixed liquid supplied to the pump will be higher than the temperature of the make-up liquid. Its final temperature will depend upon the amount of the recycled liquid. It is important to remember that with higher service liquid temperature the pump performance will decrease (see section 17) with the possibility of operating the pump in the cavitation area. When the separator/reservoir is installed along side of the pump, its liquid level should not be above the pump shaft centerline. When flanged separators are mounted on the pump discharge flange, the liquid level is automatically maintained by the location of the connections. Schematic fig. 18 illustrates the system with partial recovery of the service liquid.

#### 9.3.3 - Service liquid: Total recovery system

This system has total recycle of the service liquid without fresh liquid make-up from an outside source. A heat exchanger is required to lower and control the temperature of the recycled service liquid: for sizing and calculations of heat loads

see section 17. A circulating pump will be required for those applications where the vacuum pump operates for extended periods of times in the pressure ranges above 20"Hg vacuum or when there are high pressure drops in the closed loop including the heat exchanger (over approximately 30psi.). The liquid level in the separator/reservoir should not be above the pump shaft centerline. Losses of liquid from the closed loop must be compensated with an equal amount from an outside source. Schematic fig. 19 illustrates the system with total recovery of the service liquid.

#### 9.4 - INSTALLATION SCHEMATICS FOR LIQUID RING COMPRESSORS

The liquid ring vacuum pump can also operate as a compressor up to a maximum differential pressure, depending upon the models, of about 30 psig. The compressor series SA are specifically engineered to perform with differential pressures of up to 150 psig, depending on models. The principle of operation is same as given in previous paragraph (9.3 for vacuum pumps) and there are three possible types of installation: once-through service liquid, partial recovery service liquid and total recovery service liquid. The service liquid entering the compressor connection should have a pressure of minimum 5psig, above the compressor operating inlet pressure. A booster pump will be required if the service liquid is available at lower pressures. Separator/reservoir is considered a pressure vessel and as such it must be engineered and built to the applicable codes (ASME, etc.). Accessories such as a pressure relief valve, check valve (non-return valve), automatic float type drain valve (water trap), etc. are required in a compressor system. Fig. 20, 21 and 22 illustrate the three possible types of installations.

#### 9.5 - INSTALLATION OF "WATER SEALED" SYSTEMS

WATER SEALED systems are factory assembled and piped including discharge separator/reservoir, heat exchanger (air/liquid or air/air), circulating pump, and all required accessories mounted on a common compact baseplate/frame. See section 18 for additional details. Installation of WATER SEALED system is similar to that of a vacuum pump or a compressor with partial recovery or total recovery of service liquid depending upon the application (see section 9.3 or 9.4). It is important to properly engineer the connecting piping to the system suction and discharge, cooling lines, flushing lines, and draining lines. The used heat exchanger is designed with service liquid being cooled approximately 4 to 6°C (39 to 43 °F) over the available cooling media temperature. The cooling liquid flow is approximately the same as the service liquid flow needed by the pump at the operating conditions (see section 9.7 or 9.8). Schematics for once-through, partial and total service liquid recovery are shown in fig. 18 - 19 - 21 - 22.

#### 9.6 - INSTALLATION OF "OIL SEALED (DynaSeal™)" SYSTEMS

OIL SEALED (DynaSeal<sup>TM</sup>) are factory packaged systems including liquid ring vacuum pump using oil for service liquid. For additional details see section 19. Installation is simple and does not require additional details other than those already discussed in the previous chapter. Suction and discharge piping should be connected to the respective pump flanges. When locating the discharge piping it should be noted that although the system is fitted with oil demister, there may still be traces of oil fumes carried by the vented gas. Make sure therefore, that the selected area for vacuum pump discharge is suitable for such purpose. All other connections, (heat exchanger, draining, etc.) must be properly done. See fig. 37 for location of connections.



## ATTENTION: HOT SURFACES, DO NOT TOUCH TO AVOID POSSIBLE BURNS!

During operation, the temperature of pump, frame, separator and piping can reach values over 60 °C. Therefore, take all precautions necessary to comply with the safety regulations.

#### 9.7 - SERVICE LIQUID (H<sub>2</sub>O at 60 °F) FLOW (in GPM) FOR VACUUM PUMPS

The listed values are referred to the system with "Once-through" service liquid, handling dry air at 20 °C (68 °F) (for more specific data see the pumps performance curve). To reduce the amount of service liquid flow read the information given in section 17. If the pump is handling saturated or condensable gases at relatively high temperatures, there will be condensation inside the pump. In those cases the service liquid flow listed below can be increased up to 25% to reduce the discharge temperature and minimize the danger of pump cavitation at high vacuum.

Table 3

**PUMP** 

MODEL

PUMP	SUCTION	(in Torr)		
MODEL	25-150	>150-450	>450	
TRH 32-4	0.9	0.9	0.7	
TRH 32-20	1.5	1.3	1.2	
TRH 32-45	1.5	1.5	1.2	
TRH 32-60				
TRH 40-110	4.0	3.0	2.6	
TRH 40-140				
TRH 40-190	4.4	3.7	3.0	
TRH 50-280	10.5	7.5	4.0	
TRH 50-340	13.0	9.8	5.3	
TRH 50-420	15.8	12.0	7.0	
TRH 80-600	11.0	8.7	5.7	
TRH 80-750	13.0	10.6	7.0	
TRH 100-870				
TRH 100-1260	32.5	25.0	16.7	
TRH 100-1600				
TRH 150-2000	53	42	26	
TRH 150-2600	58	49	29	
TRH 150-3100	16.20	14.10	8.70	

TRS 32-20 TRS 32-50	1.5	1.0
TRS 40-55	2.4	4.0
TRS 40-80	3.4	1.9
TRS 40-100	4.2	2.5
TRS 40-150	5.1	3.2
TRS 50-220	10.6	5.7
TRS 100-550	12.8	7.7
TRS 100-700	14.5	9.2
TRS 100-980	40	24
TRS 125-1250	38	18
TRS 125-1550	44	20
TRS 200-1950	80	50
TRS 200-2500	88	51
TRS 200-3100	114	77

**SUCTION PRESSURE (in mbar)** 

150 - 450 > 450

PUMP			
MODEL	25-150	>150-450	>450
TRM 32-25	1.8	0.9	0.6
TRM 32-50	2.0	1.0	0.7
TRM 32-75	3.0	1.8	1.5
TRM/V 40-110	5.3	3.5	2.2
TRM/V 40-150	5.5	3.0	2.4
TRM/V 40-200	5.7	4.0	2.6
TRM/V 50-300	7.0	5.3	3.5
TRV 65-300	7.0	5.3	3.5
TRV 65-450	10.5	7.4	4.0


For the above pumps running as compressors without the specific performance curves, please contact TRAVAINI PUMPS USA.


## 9.8 - SERVICE LIQUID FLOW (H20 at 60°F) AND PRESSURE FOR COMPRESSORS SERIES "SA"


Values are applicable when the compressor suction is barometric pressure (1013 mbar) and the gas is air at 20°C (68 °F). The indicated flow and pressure requirements are valid for the compressor total performance curve.

SA0E3U = 4 GPM at minimum pressure of 20 to 40psi. SA0G2D = 4 GPM at minimum pressure of 20 to 40psi. SA0G2G = 6 GPM at minimum pressure of 20 to 40psi.

#### 9.9 - TYPICAL INSTALLATION SCHEMATICS FOR VACUUM PUMPS










- 1 Separator/ reservoir
- 2 Non-return valve
- 3 Shut-off valve (check valve)
- 4 Liquid ring vacuum pump
- 5 Solenoid valve
- 6 Electric motor
- 7 Level gauge glass
- 8 Float valve
- 9 Heat exchanger
- 10 Make-up solenoid valve
- 11 Drain valve
- 13 Flow control valve
- 13A By-pass valve
- 14 Pressure gauge
- 15 Level switch
- 16 Filter (y-strainer)
- 18 Automatic drain valve (check valve)

#### 9.10 - TYPICAL INSTALLATION SCHEMATICS FOR COMPRESSORS







- 19 Valve for spare vacuum connection
- 20 Vacuum gauge
- 21 Anti-cavitation valve
- 22 Circulating pump
- 23 Pressure relief valve
- 24 Overflow valve
- 25 Draining solenoid valve
- 26 Solenoid valve for heat exchanger cooling liquid
- 27 Temperature gauge
- 28 Fill connection
- 32 By-pass piping
- 38 Orifice flow
- 48 Automatic drain valve or water trap
- Air or Gas
- Liquid-Gas mixture
- Liquid

#### 9.11 - CONNECTIONS LOCATION




Fig. 23 - Pump series TRH (for details, see table 4)




Fig. 24 - Pump series TRM - TRV (for details see table 5)




Fig. 25 - Pump series TRS (for details, see table 6)




Fig. 26 - Pump series SA (for details, see table 7)

Table 4 - Pump series TRH

		4	ı	D		Z	Qty.
PUMP MODEL	Location	Connection Size	Location	Connection Size	Location	Connection Size	Manifolds
TRHE 32-4	-	-	-	-	7	1/4" GAS	
TRHE 32-20 & 45					8	3/8" GAS	-
TRHC 32-20 & 45	1				4		
TRHE & TRHC 32-60					4	1/2" GAS	1
TRHE 40-110		1/4" GAS				3/4" GAS	
TRHC 40-110	2	17 1 0/10	4			1/2" GAS	
TRHE 40-140 & 190			3	1/2" GAS		3/4" GAS	
TRHC 40-140 & 190			4	1/2 GAS	9	1/2" GAS	
TRHB 50	7		3			1" GAS	1
TRHC 80	6	3/8" GAS	4			1 1/4" GAS	_
TRHE 100		1/2" GAS	4	1" GAS		1 1/2" GAS	
TRHA 150	7	3/4" GAS	4 - 5			2 1/2" GAS	

Table 5 - Pump series TRM - TRV

PUMP MODEL		Qty.			
POWIP WIODEL	Α	D	S	Z	Manifolds
TRMA 32-25 & TRMB 32-50			1/8" GAS	1/4" GAS	
TRMB 32-75		-	1/6 GAS	3/8" GAS	
TRMB & TRVB 40	1/8" GAS	1/2" GAS		1/2" GAS	-
TRMB & TRVB 50		3/4" GAS	1/4" GAS	3/4" GAS	
TRVA 65		1/2" GAS		1/2" GAS	2

**Table 6 - Pump series TRS** 

PUMP MODEL		D		Qty.	
	Location	<b>Connection Size</b>	Location	<b>Connection Size</b>	Manifolds
TRSE 32			8	2 /0" CAC	
TRSC 32	] .	-	4	3/8" GAS	_
TRSE 40-55 to 150	1			3/4" GAS	
TRSC 40-55 to 100	1 ,		9	4 (0" 040	
TRSC 40-150	1 4	4 (0" 040		1/2" GAS	1
TRSE 50-220	3	1/2" GAS		3/4" GAS	
TRSC 50-220				1/2" GAS	
TRSB & TRSC 100	4		9 - 10	1 1/4" GAS	2
TRSE 125	-	1" GAS		1 1/2" GAS	
TRSA 200	4 - 5			2 1/2" GAS	

Table 7 - Pump series SA

COMPRESSOR MODEL	Connection Size			
	S	<b>Z</b>		
SA0E3U		3/8" GAS		
SA0G2D	1/4" GAS	1/2" GAS		
SA0G2G		1/2 GAS		

GAS = Straight pipe thread

A = Connection anti-cavitation

D = Auxiliary connection for automatic draining valve,

connection valve for spare vacuum pick-up, vacuum relief valve

S = Connection for drain plugs or valves

V = Connection for vacuum gauge 1/4" GAS (series 32 excluded)

Z = Connection for service liquid

All drawings are general and schematics (for additional details see the specific pump catalogue).

Table 8

PUMP MODEL	Noise Level	Weight Bare Pump	Weight assembly Monoblock	Weight assembly with	Oper:	eed	Insta Motor	Size
MODEL			(B5 design)	baseplate	RP	M	k\	N
	dB(A)	lbs.	lbs.	lbs.	50 Hz	60 Hz	50 Hz	60 Hz
TRHE 32-4	67	30	42	70	1450	1750	0.55	0.75
TRHC 32-20	66	55	68	90	2900	3500	1.1	1.5
TRHE 32-20	66	40	50	75	2900	3500	1.1	1.5
TRHC 32-45	66	62	75	97	2900	3500	1.5	2.0
TRHE 32-45	66	46	56	81	2900	3500	1.5	2.0
TRHC 32-60	66	66	79	103	2900	3500	2.2	3
TRHE 32-60	66	57	68	95	2900	3500	2.2	3
TRHC 40-110	65	147	174	202	1450	1750	4	5
TRHE 40-110	65	108	134	160	1450	1750	4	5
TRHC 40-140	65	174	194	262	1450	1750	4	5
TRHE 40-140	65	147	167	220	1450	1750	4	5
TRHC 40-190	65	191	231	301	1450	1750	5.5	7.5
TRHE 40-190	65	165	205	260	1450	1750	5.5	7.5
TRHB 50-280	70	286	321	429	1450	1750	9	15
TRHB 50-340	70	308	374	466	1450	1750	11	15
TRHB 50-420	71	319	392	484	1450	1750	15	20
TRHC 80-600	76	484	539	792	1450	1750	22	30
TRHC 80-750	76	528	616	829	1450	1750	30	40
TRHE 100-870	79	906	_	1263	960	1150	30	40
TRHE 100-1260	79	1067	_	1434	960	1150	37	50
TRHE 100-1600	79	1140	_	1518	960	1150	45	60
TRHA 150-2000	83	2926	_	3971	730	880	75	100
TRHA 150-2600	84	3256	_	4609	730	880	90	125
TRHA 150-3100	84	3586		4939	730	880	110	150
TRSC 32-20	69	42	55	85	2900	3500	1.1	1.5
TRSE 32-20	69	32	45	68	2900	3500	1.1	1.5
TRSC 32-50	69	44	58	89	2900	3500	1.5	2.0
TRSE 32-50	69	38	47	73	2900	3500	1.5	2.0
TRSC 40-55	66	119	147	73	1450	1750	2.2	3
TRSE 40-55	66	75	103	130	1450	1750	2.2	3
TRSC 40-80	66	125	154	180	1450	1750	3	5.0
TRSE 40-80	66	81	110	136	1450	1750	3	5.0
TRSC 40-100	67	132	158	187	1450	1750	3	5.0
TRSE 40-100	67	86	114	141	1450	1750	3	5.0
TRSC 40-150	67	156	194	211	1450	1750	4	5.0
TRSE 40-150	67	97	125	152	1450	1750	4	5.0
TRSC 50-220	67	191	229	268	1450	1750	5.5	7.5
TRSE 50-220	67	162	202	240	1450	1750	5.5	7.5
TRSC 100-550	76	440	495	719	1450	1750	15	20
TRSC 100-700	76	506	561	836	1450	1750	18.5	30
TRSB 100-980	78	550	638	847	1450	1750	30	40
TRSE 125-1250	174	959	_	596	960	1150	37	50
TRSE 125-1550	174	1016	_	634	960	1150	45	60
TRSA 200-1950	183	2475	_	1600	730	880	75	100
TRSA 200-2500	184	2695	_	1700	730	880	75	100
TRSA 200-3100	184	2915	_	1800	730	880	110	160

Table 8 (continued)

PUMP MODEL	Noise Level	Weight assembly Monoblock 50 Hz motor	Weight assembly Monoblock 60 Hz motor	Oper Spo RF		Insta Moto k\	r Size
	dB(A)	lbs.	lbs.	50 Hz	60 Hz	50 Hz	60 Hz
TRMA 32-25	69	37	40	2900	3500	0.75	1.1
TRMB 32-50	69	53	57	2900	3500	1.5	2.2
TRMB 32-75	70	81	91	2900	3500	3	4
TRMB 40-110	68	145	156	1450	1750	3	4
TRMB 40-150	69	167	233	1450	1750	4	5.5
TRMB 40-200	72	227	244	1450	1750	5.5	7.5
TRMB 50-300	72	277		1450	_	7.5	

PUMP MODEL	Noise Level	Weight Bare Pump	Weight assembly Monoblock (B5 design)	Weight assembly with baseplate	Operating Speed RPM		Installed Motor Size kW	
	dB(A)	lbs.	lbs.	lbs.	50 Hz	60 Hz	50 Hz	60 Hz
TRVB 40-110	68	_	136	_	1450	1750	3	4
TRVB 40-150	69	_	141	_	1450	1750	4	5.5
TRVB 40-200	72	_	172	_	1450	1750	5.5	7.5
TRVB 50-300	72	_	194	_	1450	1750	7.5	10
TRVA 65-300	70	293	341	354	1450	1750	7.5	10
TRVA 65-450	70	321	387	442	1450	1750	11	15

PUMP MODEL	Noise Level	document		eed	Installed Motor Size kW		
	dB(A)	lbs.	lbs.	50 Hz	60 Hz	50 Hz	60 Hz
SA0E3U	67	123	242	2900	3500	11	15
SAULSU	01	123	242	2300	3300	15	20
SA0G2D	69	183	297	2900	3500	11	18,5
SAUGZD	09	103	291	2900	3300	15	25
00000	60	101	139	2000	2500	15	20
SA0G2G	69	191	157	2900	3500	22	30

#### **NOTES:**

- Noise level (measured at 3 feet distance, without motor, with pump installed in the system) for pump series TRH, TRM, TRV when operating at 60 Torr and pump series TRS when operating at 175 Torr. Noise level test to ISO 3746 standards and with pumps at 50 Hz operating speeds.
- Weights are for pumps fitted with Mechanical Seals and in Cast Iron materials (tolerance  $\pm$  10%).
- The assemblies, Monoblock and with Baseplate, are suitable for 50 Hz motors, except where otherwise noted. Indicated total weights for the assemblies are without motors.
- The installed motor size will cover the whole performance curve when operating as vacuum pump.

## **10 - CHECK LIST PRIOR TO START-UP**



All questions listed below must have **POSITIVE** answers prior to proceeding to the pump start-up. Please note that the following is a partial list. Special installations may require further precautions therefore; additional safety steps must be taken as the case dictates.

- This manual has been completely read, including the following chapters, and is understood in its entirety?
- The piping system has been flushed of any foreign particles, welding impurities, etc.?
- Have all piping and pump obstruction been removed?
- All connections and piping are leak proof and there are no external forces or moments applied to the piping or pump flanges?
- Pump and motor are properly lubricated, per instructions?
- Pump/motor alignment has been checked?
- Mechanical seal flushing line has been connected, where required?
- All valves in the installation are in the correct position?
- All safety guards are in place?
- Pump direction of rotation has been checked by jogging the motor?
- The pump Stop switch is clear and visible?
- Pump as well as installation are ready for start-up?

# 11 - STARTING, OPERATING AND STOPPING PROCEDURES

Upon receipt and/or completion of installation, before turning on the power to the electric motor, rotate the pump shaft by hand to make sure that the pump rotor is free. In the event the shaft does not turn, try to free the rotor by applying a torque to the pump coupling with a pipe wrench. To free the rotor of a monoblock style pump (without coupling) introduce a bolt (or similar tool) at the motor shaft end that has a threaded connection and apply the torque by hand. In the event the pump does not become free with the above procedures, fill up the pump with a suitable solvent or lubricating liquid, let it rest for several hours to allow softening of the rust build-up inside the pump, drain the pump and apply torque to the pump shaft as described above to finally free the rotor.

<u>NOTE:</u> The selected solvent or lubricating fluid must be compatible with the pump, seals and gasketing materials.



#### CHECK PUMP-MOTOR COUPLING ALIGNMENT!

This must be done prior to the first start-up and before every startup if pump or motor has been removed from the installation for maintenance or other reasons. See section 7.2.

Prior to starting the pump verify that all auxiliary components are available, ready for use and, where required, they are in the open position (i.e.: double mechanical seals are pressurized with buffer liquid, cooling liquid to heat exchanger is open, etc.) and the pump bearings are lubricated. If the gas and/or service liquid temperatures are in the dangerous levels, it is recommended to insulate the pump, piping and separator to avoid direct contact with their surface, avoid freezing, thermal shock or loosing heat energy.

<u>NOTE:</u> See section 11.4 to 11.6 for OIL SEALED (DynaSeal $^{\text{TM}}$ ) systems start-up, operation and shut-down.

#### 11.1 - START-UP of WATER SEALED Systems

(In the following, reference is made to certain ITEM numbers, which appear on fig. 17 to 22 of section 9 and 18).

Open valve at gas discharge if installed and partially open the valve at the suction side. When operating the pump as a compressor, there must be a check valve ITEM 2, fitted at the discharge side. When pump ITEM 4, is fitted in a partial recovery or total recovery or WATER SEALED systems, as built by TRAVAINI PUMPS USA, it is required to have drain valve ITEM 11, at separator ITEM 1, in the closed position, flow regulating valve ITEM 13, in the open positions. Before start-up fill the pump to the shaft centerline, separator and piping of system with service liquid through pump inlet flange or fill connection ITEM 28. Check all components for leakage. Start all accessories (temperature switches, level switches, pressure switches, etc.) open cooling and flushing lines. Start the pump and open the service liquid valve, ITEM 3 if applicable, soon after, start the circulating pump, ITEM 22 (if applicable) and adjust the service liquid flow (see table 3). Gradually open the valve at gas suction side till the required vacuum level is reached. Check the system for abnormal conditions (see section 12 and 14). If the system is fitted with a circulating pump and/or the service liquid has an excessive pressure the by-pass valve ITEM 13A, (if available) or valve, ITEM 13 can be adjusted to reduce the service liquid flow to the vacuum pump and/or optimize the thermodynamic efficiency of the heat exchanger ITEM 9.

<u>NOTE:</u> WATER SEALED systems engineered with multiple pumps are fitted with isolating valves at suction, discharge, and service liquid lines of each pump. When one or more pumps are not operating it is required to isolate the idle pump(s) by closing these valves. When the pumps are put back into service the said valves (at suction and discharge) must be opened.

#### 11.2 - OPERATION

After starting the vacuum pump check the following:

- the vacuum level is as desired or adjust the flow-regulating valve to the required vacuum
- flow and temperature of service liquid and/or cooling liquid are as expected (within 25% tolerance)
- motor does not draw more amperage than shown on its nameplate
- the pump-motor assembly does not have abnormal vibrations and noises such as cavitation
- the operating temperature at full load does not exceed approximately 85°C
- there are no leaks from mechanical seals, joints and flushing or cooling liquid lines
- liquid level in separator is between the minimum and the maximum.



#### **NEVER OPERATE THE PUMP DRY!**

If the gas discharge is not open to the immediate atmosphere but it is piped to other locations, the pump discharge should be checked for back-pressures that could cause higher power consumption and loss of pump capacity.

#### 11.3 - SHUT DOWN of "WATER SEALED" SYSTEMS

First close the service liquid flow and cooling liquid flow (if applicable) then shut down the circulating pump, ITEM 22, (if applicable). Where possible, gradually decrease the vacuum level to 300-675 Torr in about 10 seconds max or, if compressor, decrease the discharge pressure. The discharged service liquid from pump, ITEM 4, helps produce a slow deceleration rather than sudden stop. Turn off the power to motor ITEM 6 and close any accessories and flushing lines. Make sure the non-return valves, ITEM 2 or similar, at suction and discharge lines are leak tight. Should the system be idle for an extended period of time it is recommended to disconnect the electricity to the motor or control panel and drain all liquids from pump, separator and piping. Refer to chapter 6 for storage procedures.

#### 11.4 - START-UP OF "OIL SEALED (DynaSeal™)" SYSTEMS

(In the following, reference is made to certain ITEM numbers which are listed in the figures and legend of section 12.1 and 19). Open the valve at the gas discharge, if applicable, and partially close the valve at the suction side. Close draining valve ITEM 11, and valves for condensate recovery ITEMS 13F and 13L, which are on the frame separator, ITEM 1B; open the valve ITEM 13D which is between the circulating pump, ITEM 22, and the frame separator, ITEM 1B, then partially open flow regulating valve, ITEM 13 between the discharge of circulating pump, ITEM 22 and the heat exchanger, ITEM 9, and the by-pass valve, ITEM 13A. If the system is fitted with a separator cyclone, ITEM 1D, and the adjacent collecting tank, ITEM 1E, it is required to close valves, ITEM 11A and 12 and open valve ITEM 13E. Fill frame separator with service oil through the filling plugs ITEM 28. Proper oil level can be seen on sight glass ITEM 7. Refer to table 12 and 13 for the required oil quantity. Start and/or open applicable accessories (temperature switches, level switches, etc.) and circuitry for cooling and flushing. Start vacuum pump, ITEM 4, and soon after, start the circulating pump, ITEM 22. Adjust the circulating pump capacity with valve ITEM 13. Gradually open the system suction valve till the desired vacuum is achieved. Check the systems for abnormal noises or vibrations (see section 12 and 14). Adjust by-pass valve ITEM 13A, to regulate the oil flow to the vacuum pump or to improve the thermodynamic efficiency of the heat exchanger.

NOTE: OIL SEALED (DynaSeal™) systems engineered with multiple pumps are fitted with isolating valves at suction, discharge, and service liquid lines of each pump. When one or more pumps are not operating, it is required to isolate the idle pump(s) by closing these valves. When the pumps are put back into service the said valves (at suction and discharge) must be opened.

#### 11.5 - OPERATION OF "OIL SEALED (DynaSeal™)" SYSTEMS

After starting the vacuum pump check the following:

- the vacuum level is as desired or adjust the flow-regulating valve to the required vacuum
- the oil temperature is between 140 and 175°F. If required, adjust the thermostat on the radiator or in case of water/oil heat exchanger adjust the cooling water flow
- motor does not draw more amperage than shown on its nameplate
- the pump-motor assembly does not have abnormal vibrations or noises such as cavitation
- the surface temperature at full load, does not exceed approximately 85°F
- that there are no leaks from mechanical seals, joints, flushing or cooling liquid lines
- liquid level in separator and pump is between the minimum and the maximum

• the pressure gauge of the oil demister separator does not read more than 4 psi. When this value is exceeded, it will be required to change the filter element.

If the gas discharge is not open to the immediate atmosphere but it is piped to other locations, the pump discharge should be checked for back-pressures that could cause higher power consumption and loss of pump capacity.

#### 11.6 - SHUT DOWN OF "OIL SEALED (DynaSeal™)" SYSTEMS

Close, if applicable, the cooling water to the water/oil heat exchanger ITEM 9, then turn off the power to the circulating pump ITEM 22. Where possible, gradually decrease the vacuum level to 300-625 Torr in about 10 seconds max. The discharged service liquid from pump ITEM 4 helps producing a slow deceleration rather than sudden stop.

Turn off motor ITEM 6, radiator ITEM 9 and any accessories and flushing circuitry. Make sure the non-return valves ITEM 2, or similar, at suction and discharge lines are leak tight. Should the system be idle for an extended period of time it is recommended to disconnect the electricity to the motor panel, drain all liquids from pump, separator and piping. Refer to chapter 6 for storage procedures.

## **12 - OPERATING MAINTENANCE**

Periodically check the working conditions of the system by means of the instrumentation on the installation (pressure gauges, vacuum gauges, temperature gauges, ampmeters, etc.) and that the pump is consistently handling the application for which it was selected. The operation of the pump should be without abnormal vibrations or noises, if any of these problems is noticed, the pump should be stopped immediately, search for the cause and make the necessary corrections. It is good practice to check the pump/motor alignment, the running conditions of the bearings and of the mechanical seals (see section 13) at least once a year, even if no abnormalities have been noticed. If there is a deterioration of the pump performance, which is not attributable to changes in system demands, the pump must be stopped and proceed with necessary repairs or replacement. If the mechanical seals are fitted with external flushing and/or quenching lines their pressures, temperatures and flows must be checked constantly.



### **NEVER ALLOW THE PUMP TO OPERATE IN THE CAVITATION AREA!**

Cavitation has the characteristic metallic sound, like if gravel was rotating inside the pump, and it causes also high pump vibrations. This happens when the pump is running at absolute pressures close to the vapor pressure of the service liquid at the running conditions. This is a damaging condition for the impellers, port plates and casings. The cavitation causes erosion taking away metal particles and attacking the surface of the pump components. This is particularly damaging if the pump is handling corrosive gases, see chapter 14 for suggestions to correct the problem.

Pump series TRH, TRM and TRV are fitted with an anti-cavitation valve that should be left open (if required) see fig. 23 and 24 for the location. This valve should be connected toward the upper part of the discharge separator so that, depending upon the operating vacuum, the pump can either take air or discharge excessive liquid. For OIL SEALED (DynaSeal™) systems the anti-cavitation valve ITEM 13H is piped from pump ITEM 4 to the frame separator ITEM 1B.

During operation it must be avoided to have sudden and frequent variations from high to low vacuum. (e.g. suddenly opening the suction valve when the pump is operating at pressures lower than 150 Torr). This would flood the pump creating high power absorption that would put heavy stress on the motor and coupling.

Particular attention should be put on the quantity of the service liquid flow. The flow will depend upon the type of installation (see section 9), the pump size, and/or the desired temperature rise. The flow of service water at 15 °C, for standard pumps and normal operating conditions at various vacuum levels, is listed on the specific pump curves and/or on table 3 of section 9.7. Usually the temperature rise of service water, when handling dry air at 68 °F, is approximately 10 °F. When condensable (e.g.: vapours) are present in the gas stream the heat load to be removed by the service water will be higher, therefore the service water temperature rise will be higher. The service liquid flow and its temperature will affect the pump performance. Generally the low service liquid flow will decrease the pump capacity, while a high service liquid flow will increase the absorbed power by flooding the pump (see section 17 for information and calculations). Hard service water will generate lime build-up inside the pump. The severity of the deposit will vary with the water temperature. Lime or mineral deposits on the surface of the internal pump components will cause an increase of absorbed power, wear of the components and eventually will seize the pump. It is recommended to monitor the water hardness and, if too high, treat the water, If there are no alternatives. there should be periodical flushing of the pump with a solution that will remove the specific deposits, or the pump must be periodically disassembled, cleaned of all incrustations and re-assembled. Systems with total service liquid recovery require periodical change of the service liquid contained in the closed loop. The heat exchanger must be kept well cleaned of all mineral deposits for an effective thermodynamic heat exchange. During operation, a closed loop system will lose some of the service liquid, due to evaporation and/or saturation of the discharged gases. It will be required to periodically make-up fresh liquid into the system. This operation is not required for those systems that are fitted with a float type automatic make-up valve ITEM 8. This valve requires water at a pressure of approximately 2 bar. Systems that handle condensable will experience a rise in the level of the service liquid in the separator. The excessive liquid will be overflowed through the overflow valve or connection. If the specific gravity of the condensable is higher than that of the service liquid, the condensable must be discharged through the separator drain valve ITEM 11, preferably with system not running.

#### 12.1 - "OIL SEALED (DynaSeal™)" SYSTEMS

(For ITEM numbers refer to fig. 27 and it's legend).

It is very important to keep the service oil temperature under control when the oil temperature exceeds 90  $^{\circ}$ C there is the danger of seizing the pump and the gasketing may start leaking.

Every 100 - 200 working hours it is suggested to check the oil level in the oil reservoir, make-up oil if necessary and change the oil every 10,000 working hours (depending upon the use and the application).

Those installations where the handled gases are contaminated with dust or suspended solids that can alter the oil characteristics will require more frequent oil check and changes.

Condensable vapors, if present during evacuation, can be flushed right through the discharge of the separator (if they have low boiling point) or, when the system is idle, can be drained by opening valves, ITEM 16. During operation, the oil demister filter will be impregnated with oil particles; the pressure gauge, ITEM 2,

installed at the housing, ITEM 2, will provide an indication of the filter being plugged; pressure reading over 4 psi. maybe an indication that the filter needs replacement. At higher discharge pressures the discharged air quality will decrease and the vacuum pump absorbed power will increase.

To replace the oil demister filter, simply disconnect the oil scavenger line, remove the cover, ITEM 25, remove the used filter element, apply a gasketing material over the gasket faces of the new filter and place the latter in the housing, put in place the cover and the scavenger line.

SYSTEM INLET

TYPICAL BILL OF MATERIALS						
TEM	DESCRIPTION					
1	VACUUM GAUGE (STD)					
2	PRESSURE GAUGE (STD)					
3	TEMPERATURE GAUGE (STD)					
4	COMPOUND GAUGE (STD)					
5	LEVEL GAUGE (STD)					
6	BULLSEYE GAUGE (STD)					
7	BACK PRESSURE SWITCH (OPT)					
8	LEVEL SWITCH, HIGH AND LOW (OPT)					
9	TEMPERATURE SWITCH (STD)					
10	HEAT EXCHANGER AIR OR WATER COOLED (STD)					
11	FILTER SILENCER (STD)					
12	INLET FILTER (OPT)					
13	SPIN-ON OIL FILTER (OPT)					
14	Y-STRAINER (STD)					
15	SEPARATOR ELEMENT (STD)					
16	BALL VALVE (STD)					
17	BALL VALVE STRAINER ISOLATOR (STD)					
18	MANUAL UNLOADING VALVE (STD)					
19	AUTOMATIC UNLOADING VALVE (OPT)					
20	GLOBE VALVE (STD)					
21	CHECK VALVE (STD)					
22	VACUUM RELIEF VALVE (OPT)					
23	SOLENOID VALVE (NOT USED WITH ITEM 22)(OPT)					
24	TEMPERATURE CONTROL VALVE (OPT)					
25	SEPARATOR TANK (STD)					
26	CIRCULATION PUMP (OPT)					
27	TRAVAINI LIQUID RING VACUUM PUMP (STD)					
28	CONTROL PANEL NEMA 12 (STD)					




Fig 27 (General Schematic Drawing)

# 13 - BEARINGS AND MECHANICAL SEALS MAINTENANCE

WARNING: The maintenance must be carried out with the pump turned off and the electrical power, or other driving mechanism, must be disconnected. The power should only be turned back on by the same person doing the maintenance. It is, however, recommended to have at least a team of two workers doing the maintenance and the supervisors should be fully aware of the work in progress.



CAREFULLY FOLLOW THE SAFETY PROCEDURES LISTED IN CHAPTER 2.

#### 13.1 - BEARINGS

At assembly time the pump bearings are lubricated with quality grease (sealed bearings are greased for life). Some of the recommended greases are:


BP - ENERGREASE LS - EP 2 EXXON - BEACON EP 2 MOBIL - MOBILUX EP 2

SHELL - SHELL ALVANIA EP GREASER

Bearings for pumps working in standard conditions should be lubricated every 2000/2500 working hours with a quality grease (see "Disassembly & Assembly" for the replacement of bearings). Bearing temperature should not exceed the 85 °C during normal working conditions and normal environments. Bearings can overheat for reasons such as too much grease, misalignment of flexible coupling, wrong bearings, excessive vibrations, bearing wear. See tab. 9 for bearing numbers and type used for each pump.

#### 13.2 - MECHANICAL SEALS

Mechanical seals can be with many types of materials, design and installations (see fig. 28). TRAVAINI PUMPS USA has evaluated their selection at the time of pump design: it is a function of the fluid and working conditions. The seals are supplied with the proper flow of liquid for their lubrication, through internal pump passages. Upon request, the pump can be provided with seal lubrication coming from an outside source; the set-up must be such that the seals are guaranteed the liquid quantity and pressure as recommended by TRAVAINI PUMPS USA or by the seal manufacturer. For mechanical seal shaft size see table 9.



Mechanical seals normally fitted in the vacuum pumps are to DIN 24960 standards. See "Disassembly & Assembly Instructions" for major seal dimensions. Normally mechanical seals do not require maintenance until there is a visible liquid loss (leakage). See "Disassembly & Assembly Instructions" for seal replacement.



Mechanical seals **MUST NOT** run dry! When seals are operated with out lubricant and/or flushing liquid their faces and the elastomers may suffer damages beyond repair. It is suggested to check the conditions of the seal faces every approximately 4000 working hours.

Table 9

		BEARII	NG	<b>MECHANI</b>	CAL SEAL
PUMP MODEL	Quantity	Туре	Grease Quantity each bearing - gr.	Quantity	Diameter mm
TRHE 32-4	1	6302.2RSR		1	16
TRHC and TRSC 32					22
TRHE 32-20/45/60-TRSE 32	2	6304.2RSR		2	
TRHE 40-110 - TRSE 40		6305.2RSR			
TRMA 32-25	1	6304.2RSR			28
TRIVIA 32-23	1	6204.2RSR			
TRMB 32-50	1	6305.2RSR			24
	1	6205.2RSR			24
TRMB 32-75	1	6306.2RSR			28
11(WID 32-13	1	6206.2RSR		1	20
TRMB 40-110	1	3208.2RSR	_		
	1	6206.2RSR			
TRMB 40-150	1	3208.2RSR			35
	1	6306.2RSR			
TRVB 40-110/150	2	6208.2RSR			
TRMB 40-200 and 50-300	1	3210.2RSR			
	1	6308.2RSR			45
TRVB 40-200 and 50-300	1	6210.2RSR			
	1	6208.2RSR			
TRHC and TRSC 40		6006 0000			٥٦
TRHE 40-140/190	2	6306.2RSR			35
TRSC and TRSE 50	1	0200	20	1	42
TRHB 50 - TRVA 50 and 65	1	6308 6310	20 35	2	43 55
TRHB/C 80 - TRSB/C 100	1	6314	30		55
TRHE 100 - TRSE 125	1 1	NU 314	50		75
	2	7320B.MB.UA			
TRHA 150 - TRSA 200		22320ES.TVPB.C3	180		110
	1 +	122020L3.1VF 0.03		I .	l

NOTE: The supplied data are for pumps in STANDARD construction. For special construction please contact TRAVAINI PUMPS USA.

# 14 - TROUBLE SHOOTING: PROBLEMS, CAUSES AND SOLUTIONS

Consult the following table when problems are experienced, if solutions are not found in this chart or should there be any doubts; do not hesitate to contact TRAVAINI PUMPS USA or your local distributor.

Table 10 - LIST OF PROBLEMS

PROBLEM	LIST OF POSSIBLE CAUSES
Pump does not create or the	1 - 2 - 3 - 4 - 9 - 11 - 18 - 19 – 22 - 23 - 24 - 25
vacuum is too low	
Excessive noise	1 - 4 - 5 - 6 - 7 - 10 - 24
High power consumption	1 - 5 - 6 - 8 - 9 - 15 - 24 – 25
Vibration	5 - 6 - 7 - 8 - 10 - 12 - 13 – 24
Mechanical seal leaking	11 – 14
Pump looses liquid	11 – 19 - 23
Bearing failure	5 - 6 – 7
Pump does not start	1 - 6 - 20 - 21
Shaft partially or totally locked	6 - 10 - 15 - 16 - 21
Cavitation	3 - 4 - 8 - 9 - 17 - 24

	CAUSES	SOLUTIONS
1	Defective motor or	Check the voltage, the frequency, motor type,
	wired wrong	power consumption, rotation, wiring
		connections, phase consistency
	Leakage in suction piping	Repair piping; check valves for leakage
3	Service liquid high	Lower the service liquid temperature;
	temperature	check the level of the service liquid; adjust the
		cooling liquid flow; adjust the radiator
		thermostat to lower temperature setting
	Low service liquid flow	Increase the service liquid flow
5	Coupling misalignment	Re-align the coupling and the pump/motor
		assembly (see cap. 7)
6	Faulty bearing	Replace the bearing(see "Disassembly &
		Assembly Instructions")
7	Cavitation	Open the anti-cavitation valve or set the relief
		valve to a lower vacuum (see table 4 to 6)
8	High service liquid flow	Reduce the service liquid flow; adjust the by-
		pass valve
9	High back pressure	Check the discharge line for obstructions or high
		friction losses; reduce the back-pressure to
4.0		maximum 0.1 bar
10	Wrong pump/motor	Verify that the base surface is level and that all
	assembly	pump feet are resting on the surface,
4.4	NA 1 . 1 . 1 . 1 . 1	add spacers if required (see section 11)
11	Mechanical seal failure	Change the mechanical seal (see "Disassembly
4.6	14/	& Assembly Instructions")
	Wrong pump mounting	Remount the pump (see section 7)
13	Piping weight resting	Support the piping with hangers or other means
	on pump	(see section 11)

OALICEC	COLUTIONS
*****	SOLUTIONS
Inadequate seal lubrication	Check flushing liquid temperature, flow and
	pressure
Mineral deposits from hard	Clean the pump
water	
Foreign particles in pump	Disassemble the pump to remove the foreign
_	objects (see "Disassembly & Assembly
	Instructions")
Low suction pressure	Open the vacuum regulating valve and/or the
-	anti-cavitation valve (vacuum relief valve)
Wrong pump rotation	Reverse the rotation (see section 8)
Bad gaskets	Replace the defective gaskets (see the
_	"Disassembly & Assembly Instructions")
Wrong motor connections	Check the electrical connections (connectors,
	fuses, breakers) and the power supply line
	(see section 8)
Pump seized	Disassemble and repair the pump (see
-	"Disassembly & Assembly Instructions")
Pump undersized	Select a pump with higher capacity
Pump worn-out	Disassemble and repair the pump (see
	"Disassembly & Assembly Instructions")
Excessive liquid flow	Reduce the liquid flow through the pump suction;
through suction line	install a centrifugal separator (cyclone)
_	before the pump
Instrumentation out of	Check the working characteristics, replace
calibration	if required
	water Foreign particles in pump  Low suction pressure  Wrong pump rotation  Bad gaskets  Wrong motor connections  Pump seized  Pump undersized  Pump worn-out  Excessive liquid flow through suction line  Instrumentation out of

# 15 - REPAIRING AND REMOVING PUMP FROM THE INSTALLATION

Should there be the need for pump repair a knowledge of the specific "Disassembly and Assembly Instructions" is required.



## FOLLOW THE SAFETY PRECAUTION MEASURES OUTLINED IN CHAPTER 2.

#### Before working on the pump it is important to:

- procure and wear the proper safety equipment (hard hat, safety glasses, gloves, safety shoes, etc.)
- disconnect the electrical power supply and, if required, disconnect the electrical cable from the motor
- close the isolating valves at pump inlet, outlet and service liquid
- let the pump cool down to ambient temperature if it has been handling hot fluids
- adopt safety measures if the pump has been handling hazardous liquids
- drain the pump internals of the pumped liquid through the draining connections, if necessary rinse with neutral liquid.

#### To remove the pump and the motor from the installation proceed as follows:

- remove bolts from pump suction and discharge flanges
- remove the coupling guard
- remove the spacer of the coupling, if there is one

- if required, remove the motor anchor bolts on the baseplate, for base mounted assembly, or the bolts on the adapter flange in the case of monoblock design
- remove the pump anchor bolts on the baseplate
- remove the pump from the installation. Avoid damaging other system components.

After pump repairs, re-install following the steps from "Assembly and Alignment" procedures and after (see the applicable chapters).

## **16 - SPARE PARTS**

When ordering the pump it is good practice to also order the necessary spare parts, especially when there are no stand-by pumps in the installation. This will minimize unnecessary down times in the event of pump failure or routine maintenance.

It is therefore, recommended to stock the following spare parts for each pump

- (1)Impeller set
- (1)Complete shaft assembly
- (1)Bearing set
- Mechanical seal set (or packing set) (1)
- (1)Gasket sets
- (1)Radial seal ring set
- (1)Bearing spacer set
- (1)Coupling rubber insert set

For better parts management, the VDMA 24296 standards suggest to stock the number of parts as a function of the number of pumps being used in the plant. On the pump nameplate are printed pump model, year of manufacture and pump serial number. When ordering spare parts always provide this information. Pump type, parts item number (VDMA) and description as per the pump sectional drawing and parts list is useful information that helps to supply correct spare parts for your pump. We recommend the use of original spares: in case this is not respected, TRAVAINI PUMPS USA declines any responsibility for eventual damages and not correct running caused by not original spare parts.


## 17 - ENGINEERING DATA

#### 17.1 - INFLUENCE OF SERVICE LIQUID TEMPERATURE. SPECIFIC GRAVITY AND VISCOSITY ON PUMP PERFORMANCE


The performance of liquid ring vacuum pumps is based on the use of water at 15 °C as service liquid. With water at different temperatures the pump capacity and the maximum attainable vacuum level will vary as a function of the type of pump, as illustrated by the curve sets of fig. 29 and 30.

EXAMPLE: Pressure = 45 Torr - Water temperature = 24°C - Pump series TRH -Capacity (15°C water) = 310 ACFM From curves of fig. 30 we find the correcting factor of 0.80, therefore the actual capacity for the pump at the given conditions will be: 310 x 0.80 = 248 ACFM. The maximum suction pressure before incurring cavitation will be approximately 35 Torr.

Regarding the performance variation due to changes of specific gravity and viscosity, it can be assumed a proportional variation in power consumption however; the changes in capacity at different pressures must be analyzed case by case. Please refer the conditions to TRAVAINI PUMPS USA when these corrections are



Single stage pump (series TRM, TRS, TRV)




MAXIMUM OPERATING PRESSURE

CAPACITY FACTOR

Fig. 30 Two stage pump (series TRH)





#### 17.2 - SERVICE LIQUID TEMPERATURE CHANGE ACROSS THE PUMP

The service liquid of a liquid ring pump absorbs total heat QT as follows:

$$Q_T (BTU) = Q_C + Q_K + Q_R$$

Where:

 $Q_c$  = 0.9 x BHP x 2545 = Isothermal compression heat

 $Q_K$  =  $m_V x r$  = Condensation heat

 $Q_R = m_g \times c_p \times \Delta T_a = Cooling heat (Generally negligible,$ 

ignored in calculation of  $Q_T$ )

 $m_v$  = mass condensed incoming vapor in PPH

 $m_{\sigma}$  = mass incoming gas in PPH

P = absorbed power at operating point in kW

c<sub>p</sub> = gas specific heat in BTU/1B/°F r = heat of vaporization in BTU's

 $\Delta T_a$  = differential temperature in R, between incoming gas TG and service

liquid discharge temperature ( $T^2 + \Delta T$ )

K = Kelvin temperature

Once the  $Q_{\text{T}}$  is known it is possible to calculate the differential temperature  $\Delta T$  of the pump service liquid:

$$\Delta T = \frac{Q_T}{Q_A \cdot \rho \cdot c_P}$$

Where:

Q<sub>T</sub> = total heat load before calculated in BTU/hour

 $Q_A$  = pump service liquid flow in GPM

 $\rho$  = service liquid density in kg/m<sup>3</sup> (water = 1.0)

c<sub>P</sub> = service liquid specific heat

<u>NOTE:</u> It can be assumed that the discharge gas and service liquid have same temperature.

#### 17.3 - OPERATION WITH PARTIAL RECOVERY OF SERVICE LIQUID

Where the working conditions will allow it, the service liquid temperature can be increased utilizing a smaller quantity of fresh liquid from an outside source. A similar flow as the make-up is discharged to the drain while the balance of liquid required by the pump is recirculated. In these cases the service liquid working temperature rises and the pump capacity will require correction per curves of fig. 29 and 30. The system installation will be similar to the schematic of fig. 31. Depending upon the affordable loss of capacity the service liquid temperature T2 may be set and the make-up flow of fresh liquid QF can then be calculated:

$$Q_F(m^3/h) = \frac{Q_A \cdot \Delta T}{T_2 - T_1 + \Delta T}$$

Where:

Q<sub>F</sub> = Fresh make-up flow from outside source in m³/h Q<sub>A</sub> = Total service liquid flow required for the operating


conditions in m<sup>3</sup>/h

 $\Delta T$  = Service liquid temperature rise (see section 17.2)

 $T_2$  = Service liquid temperature to pump  $T_1$  = Temperature of make-up liquid


The fig. 31 indicates a generic schematic of a liquid ring vacuum pump in a partial recovery system. By closing the recirculation line the system would become a "once through" installation where all the service liquid is drained, therefore:

$$Q_A = Q_F$$
 and  $T_2 = T_1$ 



#### O **7**2° vapour Vaporization heat Saturated water temperature at air flow **Absolute Pressure** Vacuum Saturated Dry •F °C cmHg "Hg m3/kg m3/kg "Hg Αtα % mH20 KPa mbar Torr 2,5 95 90 10 20 30 11 5 10 15 0,816 100 0 1 2 3 4 5 6 7,5 700 600 90 0,9 - 200 80 800 0,8 0,7 70 700 - 190 85 ---1,5 2 2,5 3 4 5 5 6 6 6 6 6 6 6 6 6 7 7 180 50 400 300 75 -55 20 21 22 70 -30 150 200 65 -23 24 25 25 26 27,5 28 28,5 29,1 29,2 29,2 25 0,25 150 20 200 55 -- 130 15 65 66 100 66 67 68 -- 120 90 80 90 91 92 0,1 0,09 0,08 0,07 0,06 0,05 10 100 70 71 72 72 15 45 -9,5 9,6 9,7 9,8 9,9 80 20 93 94 95 96 97,5 70 35 ~ 30 30 ---73,5 30 0,04 0,9 50 60 70 0,025 - 70 2,5 0,5 10,1 20 -29,4 29,5 29,6 29,65 29,65 29,7 29,75 98 🗀 0,02 15 98,5 1,5 90 0,015 10 = 75 ---100 10,2 - 50 75,1 75,2 99 80 ---0,3 75,3 75,4 75,5 75,6 99,1 90 0,9 - 40 150 99,2 0,8 99,3 **—** 35 10,26 0,7 0,2 200 250 0,8 150 ----10.28

#### 18 - ENGINEERING DATA FOR "WATER SEALED" SYSTEMS



	TYPICAL BILL OF MATERIALS							
ITEM	DESCRIPTION							
1	VACUUM GAUGE (STD)							
2	TEMPERATURE GAUGE (STD)							
3	COMPOUND GAUGE (STD)							
4	LEVEL GAUGE (STD)							
5	LEVEL SWITCH (STD)							
6	FLOW SWITCH (OPT)							
7	HEAT EXCHANGER WATER COOLED (STD)							
8	FILTER SILENCER (STD)							
9	INLET FILTER (OPT)							
10	Y~STRAINER (STD)							
11	BALL VALVE (STD)							
12	MANUAL UNLOADING VALVE (STD)							
13	AUTOMATIC UNLOADING VALVE (OPT)							
14	GLOBE VALVE (STD)							
15	CHECK HINGE VALVE (STD)							
16	CHECK SWING VALVE (STD)							
17	VACUUM RELIEF VALVE (OPT)							
18	SOLENOID VALVE (STD)							
19	SEPARATOR TANK (STD)							
20	CIRCULATION PUMP (STD 50HP AND UP)							
21	TRAVAINI LIQUID RING VACUUM PUMP (STD)							
22	CONTROL PANEL NEMA 12 (OPT)							




FIG. 32a PARTIAL RECOVERY System

#### **WORKING PRINCIPLE**

The WATER SEALED packages main components are: a liquid ring vacuum pump ITEM 21 from series **TRH, TRS, TRM, TRV**, an air/liquid separator reservoir ITEM 19, a heat exchanger ITEM 7, all mounted on a common base. When operating the vacuum pump discharges from the discharge port the gas handled with a portion of the liquid from the pump internal liquid ring. This liquid must be continuously returned to the pump.

The gas/liquid mixture is separated in a cylindrical tank (separator), the gas is vented through the top mounted discharge flange of the separator and the liquid is collected at the bottom of the separator ready to be returned to the vacuum gump.

During the suction and compression cycle of the vacuum pump, all the energy is transformed into heat energy and almost all of it is absorbed by the service liquid. Therefore the liquid must be cooled prior to be returned to the pump, either with a heat exchanger (total recovery system) or with the addition of cool make-up liquid (partial recovery system).

The FULL RECOVERY system (see fig. 32 and legend) does not require an appreciable flow of make-up from an external source but only the necessary amount to compensate for the liquid lost due to evaporation, with the discharged gases.

The heat exchanger sizing should be based on using a minimum amount of cooling liquid (usually water) to keep the service liquid at the ideal temperature for the best efficiency of the vacuum pump. Remember the higher the temperature of the service liquid the higher the losses in pump capacity and maximum vacuum see section 17.

This system is particular suitable where the service liquid and the condensed gases cannot be discharged to the environment, either for pollution reasons or because the fluids are too valuable.

The PARTIAL RECOVERY system (see fig. 32a and legend) requires a constant flow of cold make-up liquid from an external source. This liquid must be of the same nature as the service liquid being used by the pump. The mixture of the make-up and the service liquid being discharged by the pump, will have a constant temperature when enters the vacuum pump service liquid connection.

The same amount of service liquid taken from the outside source must be overflowed through the separator overflow connection situated at the pump shaft centerline. This system is utilized in many applications for conditions where there is intermittent use, or low vacuum levels, or there is no danger of pollution and the liquid can easily be drained.

Furthermore, this may prove to be the only alternative to the total recovery system for those installations where the cooling liquid is not available or it is too warm. Numerous accessories are available to meet the customers' requests and suitable for the installation, process and maintenance. For materials of construction and some engineering data see table 11 and 12.

Table 11 - STANDARD MATERIALS FOR "WATER SEALED" SYSTEMS

CO	MPONENT	MATERIAL DESIGN				
Vacuum pump		GH - F - RA - RZ	A3			
Separator reser	voir	Carbon steel	AISI 316 SS			
Baseplate		Carbon Steer				
Heat	Plates	Carbon Steel				
Exchanger	Gaskets	Nitrile ru	bber / Viton			
Piping		Carbon steel	AISI 316 SS			
Valves - Thermo	meter	Brass				
Level gauge		Polycarbonate "Pirex" Glass				

For vacuum pump materials (GH - F - RA - RZ - A3) see section 4.

Table 12 - GENERAL AND NOT BINDING ENGINEERING DETAILS FOR "WATER SEALED" and "OIL SEALED (DynaSeal™)" SYSTEMS

PACKAGE SERIES		Motor Size	Dry weight lbs.			
		Wiotor Size	WATER SEALED	OIL SEALED (DynaSeal™)		
WATER SEALED OIL SEALED	2	5HP 2 poles / 60 Hz	300	450		
WATER SEALED OIL SEALED	3	5HP 4 poles / 60 Hz	400	800		
WATER SEALED OIL SEALED	4	10HP 4 poles / 60 Hz	1000	1000		
WATER SEALED OIL SEALED	5	20HP 4 poles / 60 Hz	1200	1500		
WATER SEALED OIL SEALED	6	40HP 4 poles / 60 Hz	1800	2000		
WATER SEALED OIL SEALED	7	60HP 6 poles / 60 Hz	2500	3500		

EXAMPLE OF "WATER SEALED" SYSTEM General Schematic and Accessories or Options




Fig. 34 - Typical accessories and options upon request




Fig. 35 - Option with Shell & Tube heat exchanger

#### **LEGEND**

- Separator reservoir
- Separator reservoir with removable lid
- Oil demister Check valve
- Vacuum pump
- Electric motor
- Level gauge
- Float valve
- Heat exchanger
- Solenoid valve liquid make-up
- Drain valve
- Isolating valve
- 13 Service liquid flow regulating valve
- 13A By-pass valve
- Pressure gauge
- Level switch 15
- Air ejector
- 20 Vacuum gauge
- 22 Circulating pump
- Pressure relief valve
- Overflow valve
- Solenoid valve for overflow
- Solenoid valve for cooling liquid
- 27 Thermometer
- 28 Fill connection
- 30 Frame
- By-pass piping
- Connection cooling lines
- Temperature switch
- Vacuum relief valve
- Automatic drain valve (for systems used as Compressor only)

# 19 - ENGINEERING DATA FOR "OIL SEALED (DynaSeal™)" SYSTEMS

#### **WORKING PRINCIPLE**

OIL SEALED (DynaSeal™) packages main components are: a liquid ring vacuum pump, ITEM 4, from series **TRH, TRS, TRM, TRV,** an air/liquid separator reservoir, ITEM 1A, a heat exchanger ITEM 9 and an oil demister filter, ITEM 1B.

Turbine type mineral oil, or equal, is used for service liquid. The characteristics of the chosen oil are such that at pressures below 75 Torr, the pump capacity is greater than what would be when using water, and higher vacuum levels are attainable. When operating, the vacuum pump discharges the gas handled with a portion of the liquid in tank, ITEM 15, that acts as separator of gas from the oil and let settle any condensable or particles coming through the pump suction flange. The circulator pump, ITEM 26, pumps the oil back to the vacuum pump after it has been through the heat exchanger, ITEM 10, and cooled at about 140-180 ∞F. The gas is vented after being cleaned of all oil with the special oil demister element; a pressure gauge, ITEM 2, on the filter housing, ITEM 5, gives indication of the degree of dirt contained by the filter element. Contrary to rotary vane vacuum pumps, there are no moving parts that come in contact with each other, therefore there is no need for lubrication of the pump internals; these are very robust and reliable pump packages which offer extended operating life even when handling condensable gases. See table 14 for materials of construction and table 12 in chapter 18 for some engineering data.

Table 14 - STANDARD MATERIALS FOR "OIL SEALED (DynaSeal™)" SYSTEMS

COMPO	NENT	MATERIAL DESIGN				
Vacuum pump		GH - F - RA - RZ				
Baseplate		Carbon steel				
Hoot ovehender	Cooler core	Aluminium				
Heat exchanger air-oil	Shroud	Carbon steel				
all-Oll	Fan - Guard	Carbon steel-Plastic coated				
Piping		Carbon steel -Carburite rubber				
Valves - Thermometer		Brass				
Level gauge		Polycarbonate				

See section 4 for vacuum pump materials of construction (GH-F-RA-RZ).




Fig. 38 - Option with Shell & Tube heat exchanger

#### **LEGEND**

13H - Anti-cavitation valve

13L - Condensate drain valve

13M - Flow regulating valve

14 - Pressure gauge

20 - Vacuum gauge

22 - Circulating pump

27 - Thermometer

28 - Fill connection

43 - Inspection openings

#### 20 - PRODUCT DATA INFORMATION FORM

PUMP model			Serial N	umber	Syste	m N	umber				Year o	f mfg.
GAS handled			Capacit	У	Sucti	on P	ressure	Disch	arge	Press.	Temp.	
				cfm			Torr	<u></u>		psi		.°C/°F
Lethal	Toxic	oxio	us	Corr	osive		Malode	orous		]		
Service LIQUID			Capacit	У	Temp	erat	ure					
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,				GPM			°C					
TOTAL WEIGHT	MAXIMUM DIMEN	SIO	NS	X =	=		in				ed at 1	
lbs	X		Z		= =			Pre	ssure ver			
			,									
	STALLATION							SER'	VICE	_		
Inside	Outside		1		Щ	Con	tinuous		L	Inter	mittent	
Explosive area		•••••		L								
MOTOR type / Frame	No Poles	N	o Revolut	ions	Al	osorb	ed powe	er	Inst	alled po	wer	_
				DD.	NA			Δmn		k۱۸	//	HP
Frequency	Supply		nclosure				ion class			orbed p		
Hz	Volt	IP	·							kW	1	НР
COMMENTS												



#### OIL MATERIAL SAFETY DATA SHEET FOR DynaSeal™ OIL # 971-0022-A000

PRODUCT INFORMATION:

CHEMICAL NAME: HYDROTREATED, PARAFFINIC MINERAL OIL

CHEMICAL FAMILY: SEMI-SYNTHETIC HYDROCARBON

FORMULA: PROPRIETARY CAS#: PROPRIETARY

#### **COMPONENTS AND HAZARD STATEMENT:**

**NOTE**: This product is **NON-HAZARDOUS**. The product contains no known carcinogens. No special warning labels are required under OSHA 29 CFR 1910.1200.

#### **SAFE HANDLING AND STORAGE:**

**NOTE:** Do not take internally. Avoid contact with skin, eyes, and clothing. Upon contact with skin, wash with soap and water. Flush eyes with water for 15 minutes and consult physician. Wash contaminated clothing before reuse.

**NOTE:** Keep container tightly sealed when not in use.

PHYSICAL DATA:

APPEARANCE: CLEAR LIQUID, LIGHT AMBER TINT

**BOILING POINT**: >300°F

VAPOR PRESSURE: <0.01mmHg @ 20°C SPECIFIC GRAVITY (WATER = 1): 0.87-0.89 VOLATILES, PERCENT BY VOLUME: 0%

**ODOR:** SLIGHT

**SOLUBILITY IN WATER: INSOLUBLE** 

EVAPORATION RATE (BUTYL ACETATE = 1): NIL



# OIL MATERIAL SAFETY DATA SHEET FOR DynaSeal™ OIL # 971-0022-A000

#### FIRE AND EXPLOSION HAZARDS:

FLASH POINT (BY CLEVELAND OPEN CUP): 375-500°F

FLAMMABLE LIMITS: NOT ESTABLISHED AUTOIGNITION TEMPRATURE: NO DATA

**HMIS RATINGS:** 

HEALTH: 0

FLAMMABILITY: 1 REACTIVITY: 0

**NFPA RATINGS:** NOT ESTABLISHED

**EXTINGUISHING MEDIA:** DRY CHEMICAL; CO<sub>2</sub> FOAM; WATER SPRAY

**UNUSUAL FIRE AND EXPLOSION HAZARDS: NONE** 

**NOTE:** Burning fluid may evolve irritating/noxious fumes. Firefighters should use NIOSH/MNSA-approved self-contained breathing apparatus. Use water to cool fire exposed containers. Use water carefully near exposed liquid to avoid frothing and splashing of hot liquid.

#### **REACTIVITY DATA:**

**STABILITY: STABLE** 

HAZARDOUS POLYMERIZATION: WILL NOT OCCUR INCOMPATABLE MATERIALS: STRONG OXIDIZERS

**CONDITIONS TO AVOID: EXCESSIVE HEAT** 

HAZARDOUS DECOMPOSITION PRODUCTS: ANALOGOUS COMPOUNDS EVOLVE CARBON MONOXIDE,

CARBON DIOXIDE, AND OTHER UNIDENTIFIED FRAGMENTS WHEN BURNED. SEE SECTION 5.

#### **HEALTH HAZARDS DATA:**

THRESHOLD LIMIT VALUE: 5MG/M³ACGIH FOR OIL MISTS SITUATIONS TO AVOID: AVOID BREATHING OIL MISTS

FIRST AID PROCEDURES:

INGESTION: CONSULT A PHYSICIAN AT ONCE. **DO NOT INDUCE VOMITING.** MAY CAUSE NAUSEA AND DIARRHEA.

INHALATION: PRODUCT IS NOT TOXIC BY INHALATION. IF OIL MIST IS

INHALED, REMOVE TO FRESH AIR AND CONSULT PHYSICIAN.

**NOTE:** To the best of our knowledge the toxicity of this product had not been fully investigated. Analogous compounds are considered to be essentially non-toxic.



# OIL MATERIAL SAFETY DATA SHEET FOR DynaSeal™ OIL # 971-0022-A000

#### PERSONAL PROTECTION INFORMATION:

**RESPIRATORY PROTECTION:** USE IN WELL VENTILATED AREA

**VENTALATION: LOCAL EXHAUST** 

PROTECTIVE GLOVES: NOT REQUIRED, BUT RECOMMENDED, ESPECIALLY FOR PROLONGED EXPOSURE.

**EYE/FACE PROTECTION**: GOGGLES

#### **SPILL OR LEAK PROCEDURES:**

**NOTE:** In case of spill, wear suitable protective equipment, especially goggles. Stop source of spill. Dike spill area. Use absorbent materials to soak up fluid (i.e. sand, sawdust, and commercially available materials). Wash spill area with large amounts of water. Properly dispose of all materials.

#### **WASTE DISPOSAL METHODS:**

**NOTE:** Incinerate this product and all associated wastes in a licensed facility in accordance with Federal, state, and local regulations.

**NOTE:** The information in this material safety data sheet should be provided to all who use, handle, store, transport, or otherwise exposed to this product. TRAVAINI PUMPS believes the information in this document to be reliable and up to date of publication, but makes no guarantee that it is.

DOC: MATERIAL SAFETY DATA SHEET FOR TRAVAINI, P/N 971-0022-A000

FILE: 9710022.DOC REV: 7/8/97

#### Transfer Pump 1 & Transfer Pump 1 Motor Shaft Coupler Body Lovejoy 68514436059 (Grainger 1L801)



# S-Flex Shaft Coupling, Body Style 5J, Bore Dia 3/4 In, Rated Torque 240 In-Lb, Max RPM 7600, Keyway Length 3/16 In, Keyway Width 3/32 In

Item	S-Flex Shaft Coupling
Body Style	5J
Bore Dia. (In.)	3/4
Length through Bore (In.)	1.060
Rated Torque (InLb.)	240
Max. RPM	7600
Keyway Length (In.)	3/16
Keyway Width (In.)	3/32
Outside Dia. (In.)	3 1/4
Length (In.)	2 7/8
Width (In.)	1.060
Height (In.)	3.250
Hub Dia. (In.)	1.880
Material of Construction	Cast-iron
Setscrew Location	One over the Key and One at 90 Degrees
Max. Angular Misalignment	1 Degree with EPDM Rubber Inserts and 1/4 Degree with H Inserts
Ideal For	Applications In Motors, Pumps, Compressors, Blowers, Mixers and Conveyors

#### Transfer Pump 1 & Transfer Pump 1 Motor Shaft Coupler Body Lovejoy 68514436060 (Grainger 1L802)



# S-Flex Shaft Coupling, Body Style 5J, Bore Dia 7/8 In, Rated Torque 240 In-Lb, Max RPM 7600, Keyway Length 3/16 In, Keyway Width 3/32 In


Item	S-Flex Shaft Coupling
Body Style	5J
Bore Dia. (In.)	7/8
Length through Bore (In.)	1.060
Rated Torque (InLb.)	240
Max. RPM	7600
Keyway Length (In.)	3/16
Keyway Width (In.)	3/32
Outside Dia. (In.)	3 1/4
Length (In.)	2 7/8
Width (In.)	1.060
Height (In.)	3.250
Hub Dia. (In.)	1.880
Material of Construction	Cast-iron
Setscrew Location	One over the Key and One at 90 Degrees
Max. Angular Misalignment	1 Degree with EPDM Rubber Inserts and 1/4 Degree with H Inserts
Ideal For	Applications In Motors, Pumps, Compressors, Blowers, Mixers and Conveyors

#### Transfer Pump 1 & Transfer Pump 1 Motor Shaft Coupler Insert Lovejoy 5JE (Grainger 1L797)



Shaft Coupling Insert, JE Insert Type, 5J Body Style, Rated Torque 240 In-Lb, Max RPM 7600, One-piece Solid EPDM Rubber Insert Material

Item	Shaft Coupling Insert
Insert Type	JE
Body Style	5J
Rated Torque (InLb.)	240
Max. RPM	7600
HP Rating @ 50 RPM	0.19
HP Rating @ 100 RPM	0.38
HP Rating @ 300 RPM	1.14
HP Rating @ 690 RPM	2.63
HP Rating @ 870 RPM	3.31
HP Rating @ 1150 RPM	4.38
HP Rating @ 1200 RPM	4.57
HP Rating @ 1750 RPM	6.66
HP Rating @ 1800 RPM	6.85
HP Rating @ 3450 RPM	13.33
HP Rating @ 3600 RPM	13.71
Operating Temp.	-30 - 275
Outside Dia. (In.)	2.94
Length (In.)	1.56
Width (In.)	2.94
Height (In.)	2.94
Insert Material	One-piece Solid EPDM Rubber
Application	General Industrial Purposes





### **Inlet Vacuum Filters**

"CSL" Series 4" - 6" 125/150# Pattern Flange

#### **APPLICATIONS & EQUIPMENT**

- Vacuum Pumps & Systems P.D., Side Channel, Rotary Vane, Screw, Piston
- Vacuum Packaging Equipment
- Vacuum Furnaces
- · Blowers Side Channel & P.D.
- · Intake Suction Filters

- Pneumatic Conveying Systems
- Remote Install for Piston, Screw & Centrifugal Compressors
- Factory Automation Equip
- Ash Handling
- Food Industry
- Paper Processing
- Glass, Ceramic Processing
- Waste Water Treatment
  Woodworking
- Cement
- Bag House Systems
- Envelope Manufacturing
- Medical Industry
- · Chemical Processing

#### **FEATURES & SPECIFICATIONS**

- Vacuum level: Typically 1x10<sup>-3</sup> mmHg (1.3x10<sup>-3</sup> mbar)
- Polyester: 99%+ removal efficiency standard to 5 micron
- Paper: 99%+ removal efficiency standard to 2 micron
- · Heavy duty T bolts for easy maintenance
- Hydrostatically tested to 0.5 bar pressure for vacuum tightness
- Low pressure drop
- · Positive engagement O-ring seal system

- Large dirt holding capacity and Easy field cleaning, especially when mounted horizontally or inverted
- Inlet/outlet 1/4" gauge taps standard
- Rugged all steel construction w/baked enamel finish
- Temp (continuous): min -15°F (-26°C) max 220°F (104°C)
- Filter change out differential: 10" 15" H<sub>2</sub>O over initial delta P
- · Pressure drop graphs available upon request


#### **OPTIONS** (Inquiries Encouraged)

- Various media
- Larger sizes available
- Straight-Through Configurations
- Available in Stainless Steel
- Epoxy coated housings
- · Support brackets

- Special connections
- Activated carbon prefilters to reduce order

#### **CONFIGURATION**

#### **DRAWING**



Dimension tolerance + 1/4"

# B.C. — D.D.

B.H.

Flange Orientation

Note: All side inlet to outlet flanges are orientated "split center"

#### I = Industrial Duty S = Severe Duty E = Extreme Duty

1	, with	with	Flg						Rated Flo	ow SCFM	
V	Polyester	Paper	Inlet &		DIMEN	ISIONS -	inches	Nominal	Element	Approx.	
	Element	Element	Outlet	Α	В	С	D	Е	Rating	Rating	Wt. lbs
I	CSL-235P-400F	CSL-234P-400F	4"	27 1/8	9	14	18 1/2	15	520	570	62
S	CSL-335P-400F	CSL-334P-400F	4"	27 1/8	9	14	18 1/2	20	520	800	64
I	CSL-245P-500F	CSL-244P-500F	5"	28 1/8	11	18 1/2	19 1/2	15	800	880	88
S	CSL-345P-500F	CSL-344P-500F	5"	28 1/2	11	18 1/2	19 1/2	20	800	1100	90
I	CSL-275P-600F	CSL-274P-600F	6"	29 1/8	12	18 1/2	20 1/2	15	1100	1100	110
S	CSL-375P-600F	CSL-374P-600F	6"	29 1/8	12	18 1/2	20 1/2	20	1100	1500	113

pg. 4

125/150#	DIME	NSIONS - i	No. of	Flange	
Pattern Flg	O.D.	B.C.	B.H.	Holes	Thickness
4"	9	7 1/2	0.75	8	0.38
5"	10	8 1/2	0.88	8	0.38
6"	11	9 1/2	0.88	8	0.38

Note: Model offerings and design parameters may change without notice.

1151 Ardmore Ave. • Itasca, IL 60143 USA Sales/Service: 630.773.1363 • Fax: 630.773.0727 E-mail: sales@solbergmfq.com • Web Site: www.solbergmfq.com



# SMALL COMPACT FILTER SILENCERS

### w/ Standard Filter Design

"FS" Series 1/2" - 3" MPT

#### **APPLICATIONS & EQUIPMENT**

- Industrial & Severe Duty
- Piston Compressors
- Screw Compressors
- Blowers Side Channel & P.D.
- Hydraulic Breathers fine filtration
- Engines
- Construction\Contractor Industry
- Workshop
- Medical\Dental Industry
- Pneumatic Conveying

- Waste Water Aeration
- Nailers and Staplers
- Vacuum Vent Breathers

#### **FEATURES & SPECIFICATIONS**

- Polyester: 99%+ removal efficiency standard to 5 micron
- Paper: 99%+ removal efficiency standard to 2 micron
- Fully drawn weatherhood no welds to rust or vibrate apart
- Tubular silencing design tube is positioned to maximize attenuation and air flow while minimizing pressure drop
- Durable carbon steel construction with baked enamel finish and powder coated weatherhood
- Interchangeable media: Polyester, Paper, HEPA
- Several element sizes available per given connection (safety factor)
- Temp (continuous): min -15°F (-26°C) max 220°F (104°C)
- Filter change out differential: 10"-15" H<sub>2</sub>O over initial delta P
- · Pressure drop graphs available upon request


#### **OPTIONS** (Inquiries Encouraged)

- 1/8" tap holes
- Pressure Drop Indicator
- Available in Stainless Steel
- · Epoxy coated housings
- · Various media available
- · Special connections, BSPT


#### CONFIGURATION

#### **DRAWING**





Dimension tolerance + 1/4"



Noise attenuation may vary due to the wide range of applications and machines

#### I = Industrial Duty S = Severe Duty

	Rated Flow SCFM										
						Rated Flow SCFM					
	with	with		DIME	NSIONS - i	nches	Screw,			No. of	
4	Polyester	Paper	MPT					Blower,	Element	Silencing	Approx.
	Element	Element	Outlet	Α	В	С	Piston	Fan	Rating	Tubes	Wt. lbs
Ι	FS-15-050	FS-14-050	1/2"	4	1 1/2	6	10	10	35	1	2
Ι	FS-15-075	FS-14-075	3/4"	4	1 1/2	6	20	25	35	2	2
Ι	FS-15-100	FS-14-100	1"	4	1 1/2	6	25	35	35	3	2
S	FS-19P-100	FS-18P-100	1"	6 5/8	1 5/8	6	35	55	100	3	3
Ι	FS-19P-125	FS-18P-125	1 1/4"	6 5/8	1 5/8	6	55	70	100	5	3
Ι	FS-19P-150	FS-18P-150	1 1/2"	6 5/8	1 5/8	6	70	85	100	5	4
Ι	FS-31P-200	FS-30P-200	2"	7 1/4	2 1/4	10	85	135	195	5	8
S	FS-231P-200	FS-230P-200	2"	12 1/4	2 1/4	10	135	135	300	5	14
Ι	FS-31P-250	FS-30P-250	2 1/2"	7 1/2	2 1/2	10	100	195	195	5	8
S	FS-231P-250	FS-230P-250	2 1/2"	12 1/2	2 1/2	10	195	195	300	9	15
Ι	FS-231P-300	FS-230P-300	3"	13	3	10	200	300	300	9	15

Note: Model offerings and design parameters may change without notice.

1151 Ardmore Ave. • Itasca, IL 60143 USA Tel: 630/773-1363 • Fax: 630/773-0727

E-mail: sales@solbergmfg.com • Web Site: www.solbergmfg.com



Model 215V is Non-code Vacuum and Model 337 is ASME Section VIII, Air/Gas Vacuum, 'UV' National Board Certified, Safety Valves. PED Certified for Non-Hazardous Gas.

#### **Features**

- Large nozzle design provides high capacity.
- Flat bronze valve seats are lapped for optimum performance.
- Warn ring offers easy adjustability for precise opening with minimum preopen or simmer and exact blowdown control.
- Pivot between disc and spring corrects misalignment and compensates for spring side thrust.

#### **Model Descriptions**

- Model 337 has 'lift-pin' lift device for easy manual testing.
- Every valve is 100% tested/inspected for pressure setting, blowdown and leakage.
- All adjustments are factory sealed to prevent tampering or disassembly.

#### Option

• SS trim. (nozzle and disc) (Variation 03)

#### **Applications**

- Protection of low to medium pressure high volume blowers, compressors and pneumatic conveying systems.
- · Bulk hauling trailers/equipment.
- · Light gauge tanks.
- Protection of high volume vacuum pumps and conveying systems.



## Vacuum Limits Model 215V:

2-inch HG to 29-inch HG [67.7 to 982 mbarg] -20° to 406°F [-29° to 208°C]


### **Pressure and Temperature Limits** Model 337:


1 to 60 psig [0.07 to 4.1 barg] -20° to 406°F [-29° to 208°C]



Kunkle is either a trademark or registered trademark of Tyco International Services AG or its affiliates in the United States and/or other countries. All other brand names, product names, or trademarks belong to their respective holders

#### **Parts and Materials**





Model 215V


Model 337

Models 215V and 337										
No.	Part Name	215V	337							
1	Nozzle <sup>1</sup>	Bronze, SB62	Bronze, SB62							
2	Set Screw	Steel A108-1018 Brass Plated	Steel A108-1018 Brass Plated							
3	Regulator Ring	Bronze B584 Alloy 84400	Bronze B584-C84400							
4	Disc <sup>1</sup>	Bronze B584 Alloy 84400	Bronze B584-C84400							
5	Spring Step	Steel A-109 Coated <sup>3</sup>	Steel A109 Coated <sup>3</sup>							
6	Spring	SS, A313 TY 302	SS A313-302							
7	Body	Cast Iron A-126, CL A or B	Iron A-126, CL A or B							
8	Compression Screw	Bronze, B-584 Alloy 84400	Bronze, B584-C84400							
9	Stem <sup>2</sup>	N/A	Brass B16							
10	Lift Pin <sup>2</sup>	N/A	Steel, Zinc Plated							
11	Regulator Ring Set Screw	N/A	Brass B16							
12	NPT Drainplug	Steel A108-1018	N/A							

- Disc and nozzle available in SSA-479 TY 316.
- 2. Stem and lift pin available on Model 337 only.
- 3. Corrosion preventative coating.

Specification	ns				
Size Inlet		- Dimensions	s, in [mm] —		Weight
and Outlet	Α	В	C 215V	C 337	lb [kg]
2" [50.8 mm]	31/4 [82.5]	3 [76.2]	61/2 [165.1]	7 [177.8]	8 [3.6]
21/2" [63.5 mm]	33/4 [95.2]	31/2 [88.9]	75/8 [194.6]	8 [203.2]	12 [5.4]
3" [76.2 mm]	41/4 [107.9]	4 [101.6]	81/2 [215.9]	9 [228.6]	20 [9.07]

Dimensions are for reference only.



Model 337

#### **Capacities**

# Model 337, Non-code<sup>1</sup> and ASME Section VIII Air (SCFM)

	Va	alve Inlet and Outlet S	Size
Set	2"	21/2"	3"
Pressure (psig)	1.84	<ul> <li>Orifice Area, in<sup>2</sup></li> <li>2.79</li> </ul>	4.04
1	240	364	527
5	531	805	1166
10	741	1124	1628
15	948	1436	2081
20	1092	1656	2399
25	1237	1875	2718
30	1382	2095	3036
35	1542	2337	3386
40	1701	2578	3736
45	1860	2820	4086
50	2020	3061	4436
55	2179	3303	4786
60	2338	3544	5136

#### Note

1. No code stamp or 'NB' on nameplate below 15 psig set.

#### Model 337, Non-code<sup>1</sup> and ASME Section VIII Air [Metric, Nm³/h]

Set	Valore		0:
Pressure [barg]	50 mm	Inlet and Outlet 63 mm	80 mm
0.5	1049	1589	2303
1.0	1457	2208	3200
1.5	1888	2861	4147
2.0	2235	3387	4910
2.5	2613	3959	5739
3.0	2995	4538	6579
3.5	3377	5117	7418
4.0	3760	5696	8258

#### Note

1. No code stamp or 'NB' on nameplate below 1.1 barg set.

Relief Set (in, HG)	2"	Valve Inlet and Outlet Size			
(, 1.0.)	1.84	Orifice Area, in <sup>2</sup> — 2.79	4.04		
2	229	347	503		
5	338	512	742		
10	415	630	912		
15	426	646	936		
20	426	646	936		
29	426	646	936		


1. Based on 10% accumulation.

		Vacuum Air [Met	_	
Relief Set [mbarg]	5.08 cm	e Inlet and Outlet 5 6.35 cm — Orifice Area —	7.62 cm	
	[11.86 cm <sup>2</sup> ]	[17.97 cm <sup>2</sup> ]	[26.05 cm <sup>2</sup> ]	
50	328	498	722	
100	450	682	988	
150	533	807	1170	
200	593	899	1303	
250	638	966	1400	
300	669	1014	1470	
350	690	1046	1516	
400	701	1062	1540	
450	704	1067	1546	
500	704	1067	1546	
550	704	1067	1546	
600	704	1067	1546	
650	704	1067	1546	
700	704	1067	1546	
750	704	1067	1546	

Note

1. Based on 10% accumulation.

#### Model Number/Order Guide



Model 337, 1 psig [0.7 barg] (0001) through 60 psig [4.1 barg] (0060) Model 215V, 2-inch HG [68 mbarg] (0002) through 29-inch HG [982 mbarg] (0029) vacuum

Facility Phone: 828-669-3700 www.kunklevalve.com





#### **Liquid Storage Tanks**

Vertical Storage Tanks

Norwesco is proud to be the world's largest manufacturer of molded poly tanks. For over 25 years, our customers have relied on Norwesco tanks for premium quality and reliability in performance.

Norwesco tanks are manufactured to strict quality guidelines to ensure years of high-performance use. Rugged, impact-resistant, one-piece seamless polyethylene construction make our tanks suitable for the storage and/or transport of most liquid chemicals. Norwesco tanks are manufactured using resins that meet FDA specifications to ensure safe storage of potable water. Norwesco tanks will be delivered to you with a fitting installed when applicable, but may also be ordered without a fitting.

Our goal is to make it easy and pleasant to do business with Norwesco. We consider our relationship with our customers to be our most valuable asset.

vertical storage ranks
Horizontal Leg Tanks
Elliptical Leg Tanks
Drainable Leg Tanks
Steel Supports & Accessories for Leg Tanks
Pickup Truck Tanks6
Flat Bottom Utility Tanks & Bands 6
PCO Tanks6
Mini Bulk Tanks 7
Elliptical Tanks & Skids
Applicator Tanks 8
Inductor Tanks
Total Drain Tanks
Spot Sprayer Tanks
Inductor Stands
Applicator Saddle Assemblies
Black or Dark Green Water Tanks
Specialty Water Tanks
Containment Basins/Tanks11
Cone Bottom Tanks & Stands
High Density Polyethylene Lids
Hinged Lid & Hinged Lid Repair Parts13
Polyethylene Tank Repair Kits
Polypropylene Bulkhead Fittings14
Polypropylene Bolted Fittings15
Stainless Steel Bolted Fittings

#### **Vertical Storage Tanks**

Vertical storage tanks are most frequently used for bulk storage and mobile nursing applications.

Norwesco vertical tanks feature tie-down slots, built-in graduated gallon indicators, an offset fill-opening and a self-vented, slosh-proof lid.



Gallon Capacity	Diameter	Overall Height	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White	Heavy Weight Part No. Blue			
25 ¤	18"	29"	5"	3/4"	41867	_			
50 ¤	18"	53"	5"	3/4"	41865	_			
65 ¤	23"	43"	8"	11/4"	45192	_			
75 ¤	23"	49"	8"	11/4"	41863	_			
100 ¤	28"	43"	8"	11/4"	41861				
105 ¤	23"	63"	8"	2"	40803				
150	30"	56"	8"	11/4"	41859	_			
165	31"	56"	16"	2"	40281	_			
200	30"	72"	8"	2"	41856	_			
210	32"	67"	16"	2"	47401				
250	30"	89"	8"	2"	41854	_			
300	36"	79"	16"	2"	40213	_			
305	46"	50"	16"	2"	40302	_			
500	48"	73"	16"	2"	40148	40150			
550	67"	44"	16"	2"	40023	_			
750	48"	103"	16"	2"	40606	_			
850	48"	118"	16"	2"	42214	_			
1000	64"	80"	16"	2"	40152	40154			
1100	87"	53"	16"	2"	40070	40081			
1100 G	87"	53"	16"	2"	42591	42593			
1500	64"	116"	16"	2"	40144	40146			
1550	87"	67"	16"	2"	40235	40236			
1550 G	87"	67"	16"	2"	42595	42597			
1700	87"	74"	16"	2"	40010	40012			
2000	64"	152"	16"	2"	47109	47564			
2100	87"	89"	16"	2"	40178	40241			
2100	102"	69"	16"	2"	41399	_			
2500	95"	91"	16"	2"	40051	40052			
2500	102"	79"	22"	2"	42382	42384			
3000	91"	119"	16"	2"	45081				
3000	95"	109"	16"	2"	40754	40755			
3000	102"	93"	16"	2"	45246	42380			
3000	102"	93"	22"	2"	43136	43138			
4000	102"	125"	16"	3"/2"	40312	<del></del>			
4200	102"	131"	16"	3"/2"	41403	_			
5000	102"	152"	16"	3"/2"	40164	40166			
5500	138"	92"	16"	3"/2"	45086				
6000	102"	182"	16"	3"/2"	40226	40233			
6100	119"	140"	16"	3"/2"	40659	40661			
6500	119"	150"	16"	3"/2"	40224	40232			
6500	120"	147"	16"	3"/2"	42315	42317			
7800	119"	176"	16"	3"/2"	40663	40665			
8400	119"	188"	16"	3"/2"	42060	42062			
9000	141"	146"	16"	3"/2"	40543	40231			
10000	141"	160"	16"	3"/2"	40545	40353			
10000	141"	160"	22"	3"/2"	43128	43130			
12000	141"	193"	16"	3"*	40539	40541			
15000	141"	244"	16"	3" *	41334	41336			
13000	141	Z <del>44</del>	10	3 "	41334	41330			

May ship UPS G=Gusset Top \*316 Stainless Steel Bolted Fitting



#### **Horizontal Leg Tanks**

With the broadest leg tank line available, Norwesco manufactures a size that will fit your needs. Used primarily for transport and nursing applications, Norwesco's leg tanks feature molded-in legs that act as "baffles" to reduce sloshing. Please refer to page 5 for support bands.

Gallon Capacity	Diameter	Overall Height	Length	Fill Opening	Outlet/Drain Specification	No. of Bands	Premium Weight Part No. White	Heavy Weight Part No. Blue
35 ¤	20"	23"	29"	5"	3/4"	2 optional	45223	
55 ¤	23"	26"	34"	5"	3/4"	2 optional	41873	
65 ¤	23"	26"	43"	5"	3/4"	2 optional	45191	_
125	32"	35"	41"	8"	2"	2 optional	40298	_
225	38"	41"	49"	8"	2"	2 optional	40299	_
225 Stand	38" W	41"	45"	_	_	_	42854	_
325	38"	43"	68"	16"	2"	2 optional	40217	_
330	38"	40"	74"	5"	2"	2 optional	42923	_
425	49"	54"	60"	16"	2"	2 optional	42016	_
525	49"	54"	71"	16"	2"	2 optional	40181	40193
725 *	49"	54"	101"	16"	2"	3 required	40180	40194
925 *	62"	65"	80"	16"	2"	2 required	45209	_
925 * with sump	62"	69"	80"	16"	2"	2 required	45210	_
1025 *	49"	54"	139"	16"	2"	4 required	40089	40131
1325 *	66"	70"	99"	16"	2"	3 required	41875	41877
1625 *	63"	68"	139"	16"	2"	4 required	40026	40133
1800 * 2CPT	62"	68"	146"	16"	2"	4 required	42990	_
1800 * with sump, 2CPT	62"	72"	146"	16"	2"	4 required	42992	_
5025 *	92"	96"	190"	16" **	3"/2"	5 required	41879	41881

may ship UPS \*Require full length support and bands \*\*16" hinged lid



#### **Elliptical Leg Tanks**

This elliptical tank style is designed to provide the greatest capacity with the lowest center of gravity, making it the best design available for transporting larger volumes. Norwesco elliptical tanks feature molded-in legs that act as "baffles" to reduce sloshing and provide increased stability during transport. Norwesco elliptical leg tanks require full length bottom support as well as support bands. Please refer to page 5 for support bands. The 1600 flat bottom requires full length bottom support but does not require bands.

	1					_	
Gallon Capacity	Width	Overall Height	Length	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White	Heavy Weight Part No. Blue
335	48"	33"	71"	16"	2"	42339	_
535	57"	39"	80"	16"	2"	42353	_
1035	79"	54"	89"	16"	2"	40191	_
1235	66"	53"	128"	16"	2"	40239	_
1335	66"	55"	126"	16"	2"	42927	42929
1600 flat bottom	80"	53"	126"	16"	2"	43143	43167
1635	71"	58"	142"	16"	2"	40387	40388
2035	84"	56"	142"	16"	2"	40618	40623
2635	90"	72"	140"	16"	3"/2"	40547	40283
3135	88"	80"	150"	16"	3"/2"	40686	40688
4035	92"	75"	192"	16" **	3"/2"	41267	41269

<sup>\*\*16&</sup>quot; hinged lid

#### **Drainable Leg Tanks**

When complete drainage is necessary, these are the tanks of choice. They are designed primarily for use on fertilizer and chemical nurse trailers. All Norwesco drainable tanks require full length bottom support as well as support bands. Please refer below for support bands.



1010 Gallon Drainable Leg Tank

Gallon Capacity	Width	Overall Height	Length	Fill Opening	Outlet/Drain Specification	No. of Bands	Premium Weight Part No. White	Heavy Weight Part No. Blue
710 (horizontal)	47"	57"	104"	16"	2"	3 required	40655	40657
1010 (horizontal)	47"	58"	140"	16"	2"	4 required	40393	40395
1310 (horizontal)	66"	75"	99"	16"	_	3 required	41871	41872
1315 (elliptical)	66"	60"	126"	16"	_	3 required	42925	42926
1610 (elliptical)	69"	63"	140"	16"	_	4 required	40806	40808
2610 (elliptical)	90"	79"	140"	16"*	_	4 required	41382	41383
3210 (elliptical)	92"	75"	178"	16"*	_	4 required	40822	40824

<sup>\*16&</sup>quot; hinged lid

#### **Steel Supports and Accessories for Leg Tanks**

Norwesco bands are custom fabricated to support the Norwesco tanks and are galvanized or powder coated for added corrosion protection. Whether using the tank in a stationary position or for transport, bands are necessary to ensure that the tank retains its shape and integrity.


#### **Elliptical Leg Tank Bands**

Tank Size (Gallon)	A	В	C	No. of Bands	Part No.
335	29"	461/2"	52½"	2 required	63546
535	35"	55½"	61½"	2 required	63547
1035	471/4"	77"	83"	3 required	60325
1235	47¾"	64¾"	70¾"	4 required	60477
1335	53"	65"	71"	3 required	63642
1635	51"	68"	74"	4 required	60586
2035	511/4"	81½"	86¾"	4 required	62079
2635	651/4"	871/2"	94"	4 required	60353
3135 *	751/4"	851/2"	92"	4 required	62097
3135 **	741/4"	851/2"	92"	4 required	63620
4035	701/4"	891/2"	96"	4 required	62832

<sup>\*</sup> For tanks manufactured in CA, MN, OK, TX, UT

#### **Horizontal Leg Tank Bands**

Tank Size (Gallon)	A	В	С	No. of Bands	Part No.
35 ¤	18½"	181/2"	21%"	2 optional	60520
55 ¤	22"	22"	261/2"	2 optional	61745
65 ¤	22"	22"	261/2"	2 optional	61745
125 ¤	30¾"	30½"	35"	2 optional	61744
225 ¤	36½"	36"	42"	2 optional	60478
325 ¤	361/2"	36"	42"	2 optional	60478
330 ¤	361/2"	36"	42"	2 optional	60478
425	47¾"	461/4"	521/4"	2 optional	60057
525	47¾"	461/4"	521/4"	2 optional	60057
725	47¾"	461/4"	521/4"	3 required	60057
925	61"	60"	66"	2 required	62852
1025	47¾"	461/4"	521/4"	4 required	60057
1325	64"	64"	70"	3 required	63282
1625	61"	60¾"	671⁄4"	4 required	60079
1800 ∞	61"	60"	66"	4 required	62852
5025	89¾"	89½"	93%"	5 required	63284



#### **Drainable Leg Tank Bands**

Tank Size (Gallon)	Α	В	C	No. of Bands	Part No.
710 ¤	461/4"	45"	51"	3 required	60584 short
1010 ¤*	461/4"	45"	51"	2 required	60584 short
1010 ¤*	48"	45"	51"	2 required	60585 long
1310	64"	64"	70"	3 required	63282
1315	50"	64"	70"	3 required	63642
1610	49"	66"	72"	4 required	62434
2610 *	58"	871/2"	91%"	2 required	63044 short
2610 *	62"	871/2"	91%"	2 required	63045 long
3210 *	56"	891/2"	92¾"	2 required	62347 short
3210 *	60"	89½"	92¾"	2 required	62348 long

m May ship UPS \* 2 short and 2 long bands are required for 1 tank

#### Ladders (Galvanized)

Description	Tank Size (Gallon)	Part No.
Ladder (optional)	2635 & 3135	60354
Ladder (optional)	2610 & 3210	63047
Ladder (optional)	4035	63033
Adaptor kit for ladder †	3135	62301

<sup>†</sup> This kit is required when using the ladder on the 3135 gallon tank

<sup>\*\*</sup> For tanks manufactured in GA, OH



#### **Pickup Truck Tanks**

Designed to fit full-size, American made pickups,

the 325 and 425 sizes have low profiles for better rear vision. They feature fill openings offset to the side of the tank for safety and easy access. A tough circular design adds strength. The 210 gallon tank fits both "mini" pickups and full-size models. Depending on which way the tank is turned, the bottom width can be either 39" or 48".

	allon pacity	Top Width or Diameter	Bottom Width or Diameter	Overall Height	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White
2	210	60"/51"	48"/39"	29"	8"	2"	40300
3	325	62"	49"	33"	8"	2"	40160
	125	65"	49"	39"	8"	2"	40102



#### **Flat Bottom Utility Tanks**

Like the PCO tank, the Flat Bottom Utility tank can be used for many applications. It is the perfect choice when looking for a tank to put in the bed of a pickup truck. The tank may be used with or without bands.

Gallon Capacity	Width	Overall Height	Length	Fill Opening	Outlet/ Drain Specification	Premium Weight Part No. White
50 ¤	19"	23"	38"	8"	1"	42341
100 ¤	27"	29"	43"	8"	1"	42343
110 low profile	35"	18"	48"	5"	1"	42349
150	36"	29"	48"	8"	1"	42345
200	36"	38"	48"	8"	1"	42347


m May ship UPS



A multi-purpose tank, the PCO is well suited for nursery, agricultural and lawn care applications. These tanks feature self-supporting legs and do not require any saddles or steel supports. Flat spots are molded into both ends to provide mounting areas for agitation equipment.

	Gallon Capacity	Width	Overall Height	Length	Fill Opening	Premium Weight Part No. White
	SMOOTH WALL					
	30 ¤	19"	23"	25"	5"	41254
	50 ¤	19"	22"	38"	8"	40664
	100 ¤	30"	28"	38"	8"	40668
	150	36"	28"	48"	8"	40669
	200	36"	37"	48"	8"	41413
	300	36"	37"	69"	16"	41381
RIBBED						
	50 ¤	19"	23"	38"	8"	42834
	100	30"	30"	38"	8"	42835
	150	37"	29"	48"	16"	42836
	200	37"	37"	48"	16"	42837

<sup>¤</sup> May ship UPS



#### **Flat Bottom Utility Tank Bands**

Tank Size (Gallon)	Α	В	С	No. of Bands	Part No.
50 ¤	19"	181/2"	23"	2 optional	63551
100 ¤	24"	25"	291/2"	2 optional	63552
150 ¤	24"	341/2"	39"	2 optional	63553
200 ¤	33"	34½"	39"	2 optional	63554

<sup>¤</sup> May ship UPS




#### **Mini Bulk Tanks**

Norwesco mini bulk tanks are most frequently used for chemical dispensing. The tanks can be mounted on forklift accessible pads for ease of movement. A 2" polypropylene fitting is installed directly across from the fill-opening.

Gallon Capacity	Diameter	Overall Height	Fill Opening	Outlet/ Drain Specification	Premium Weight Part No. White	
120	38"	31"	5"	2"	40318	
220	42"	44"	5"	2"	40320	



Gallon Capacity	Width	Overall Height Including Sump	Length	Sump Depth	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White	
200	40"	30"	66"	3/4"	8"	1¼" & 1¼"	41252	GI I I
300	48"	36"	70"	3"	16"	11/4" & 11/4"	40327	Skid not
500	57"	44"	82"	5"	16"	11/4" & 11/4"	40328	included
750	69"	48"	88"	3"	16"	2"	40329	with tank.
1000	78"	55"	90"	3"	16"	2"	40330	See below
1600 *	78"	54"	138"	21/2"	16"	2"	47111	for skids.
2550 **	88"	82"	142"	9"	16"	3"	47677	ioi skius.



### **Elliptical Tank Skids** (See dimensional drawings at left.) (Skids come with bands and bolts.)

Tank Size (Gallon)	Tank Part No.	A	В	С	D	E	F	Part No.
200	41252	4"	24"	52"	57"	2" x 68"	8"	63015
300	40327	4"	34"	461/4"	541/4"	2" x 76"	8"	63016
500	40328	4"	34"	60"	68"	2" x 96"	8"	63018
750	40329	4"	38"	691/2"	78"	2" x 112"	8"	60371
1000	40330	4"	46"	60"	72"	2" x 130"	8"	60372
2550*	47677	_	_	_	_	_	_	67456

<sup>\*</sup> Band only, no skid. The 2550 requires 4 support bands, part #67456.

<sup>200</sup> and 300 are galvanized; 500 and larger are black painted steel.

Replacement bands and hardware are available. Please contact Norwesco Customer Service for details.

#### **Applicator, Inductor, Total Drain and Spot Sprayer Tanks**

Whether you're looking for a new or replacement tank, you'll find it in the Norwesco line. All Norwesco applicator tanks feature a lid which threads directly into the fill-opening of the tank to prevent the sloshing or leaking of tank contents during transport or application. The inductor tanks are suitable for mixing chemicals when filling a tank. The spot sprayers feature threaded inserts on the bottom of the tank for mounting purposes, on one side for wand/gun placement and on the top for a 12 volt pump. Please refer to page 9 for steel supports.



#### **Applicator Tanks**

Gallon Capacity	Diameter	Overall Height	Length	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White
20 ¤	15"	18"	31"	5"	3/4"	61737
30 ¤	23"	26"	21"	5"	3/4"	41799
55 ¤	23"	27"	34"	5"	3/4"	45193
85 ¤	23"	26"	52"	5"	3/4"	45105
100 ¤	24"	28"	57"	8"	3/4"	60204
110 ¤	30"	34"	41"	8"	11/4" & 11/4"	45053
150	30"	33"	58"	8"	11/4" & 11/4"	40648
150	32"	35"	46"	8"	11/4" & 11/4"	45117
200	32"	35"	62"	8"	11/4" & 11/4"	45059
200	38"	42"	47"	8"	11/4" & 11/4"	45061
300	38"	41"	68"	8"	11/4" & 11/4"	40135
400	42"	45"	74"	8"	11/4" & 11/4"	40137
500	48"	51"	75"	8"	11/4" & 11/4"	40274
150 Slim Line	28"	41"	50"	8"	11/4" & 11/4"	40777
200 Slim Line	24"	48"	61"	8"	11/4" & 11/4"	41305
200 Slim Line	31"	46"	48"	8"	11/4" & 11/4"	40780

m May ship UPS

#### **Inductor Tanks**

Gallon Capacity	Diameter	Overall Height	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White
15 ¤	19"	23"	8"	2"	60214
15 ¤	24"	21"	16"	2"	42064
30 ¤	24"	28"	16"	2"	42065
35 ¤	23"	29"	8"	2"	45098
60 ¤	31"	32"	16"	2"	62205
60	24"	42"	16"	2"	42066
80	32"	37"	16"	2"	47190

<sup>¤</sup> May ship UPS

#### **Total Drain Tanks**

Gallon Capacity	Width	Overall Height	Length	Fill Opening	Outlet/Drain Specification	
5 square ¤	11"	18"	11"	8"	11⁄4"	42321
10 square ¤	13"	21"	13"	8"	11/4"	42351
12 ¤	14"	15"	18"	5"	3/4"	60521

<sup>¤</sup> May ship UPS

#### **Spot Sprayer Tanks**


Gallon Capacity	Width	Overall Height	Length		Outlet/Drain Specification	
14 ¤	14"	15"	31"	5"	_	45115
25 ¤	18"	18"	36"	5"	_	62080

<sup>¤</sup> May ship UPS

PLEASE NOTE: Tank availability may vary according to manufacturing location. Please contact Norwesco Customer Service or your Norwesco distributor for specific details.

Tank dimensions and capacities may vary slightly and are subject to change without notice.

8




### Inductor Stands and Applicator Saddle Assemblies

Designed to provide necessary support for the applicator/inductor tank during use. Norwesco saddles include polyester straps, buckles and bolts to secure tanks, and inductor stands are supplied with all necessary hardware.

#### Inductor Tank Stands (See dimensional drawing at left.)

Tank Size (Gallon)	Tank Part No.	A	В	Part No.
15 × 19"D ¤	60214	151/2"	38"	60313
15 × 24"D ¤	42064	131/2"	36"	63397
30 × 24"D ¤	42065	131/2"	43"	63397
35 × 23"D ¤	45098	15"	44"	65517
60 × 31"D ¤	62205	141/2"	47"	62204
60 × 24"D ¤	42066	131⁄4"	56"	63397

<sup>¤</sup> May ship UPS



Replacement bands and hardware are available. Please contact Norwesco Customer Service for details.

#### Applicator Tank Saddle Assemblies (See dimensional drawings above.)

Tank Size (Gallon)	Tank Part No.	A	В	С	D	E	F	G	Part No.
30 ¤	41799	3"	19"	131/2"	13½"	2" x 54"	8"	73/4"	60321
55 ¤	45193	6"	181/8"	24"	24"	2" x 48"	_	12"	60303
85 ¤	45105	6"	181/8"	24"	24"	2" x 48"	_	12"	60303
110 ¤	45053	12"	23¾"	28¾"	34¾"	2" x 72"	_	10¾"	60315
150-30" ¤	40648	12"	23¾"	28¾"	34¾"	2" x 72"	_	10¾"	60315
150-32" ¤	45117	12"	23¾"	28¾"	34¾"	2" x 72"	_	10¾"	60315
200-32"	45059	6"	247/8"	36"	60"	2" x 96"	8"	13¼"	63019
200-38"	45061	6"	24¾"	34"	42"	2" x 96"	_	131⁄4"	63020
300-38"	40135	6"	24¾"	34"	60"	3" x 96"	8"	12"	63021
400-42"	40137	6"	301/8"	421/2"	60"	3" x 96"	8"	12"	63022
500-48"	40274	6"	301/8"	421/2"	60"	3" x 132"	8"	12"	63023

<sup>¤</sup> May ship UPS



#### **Black or Dark Green Water Tanks**

Our water tanks are manufactured using resins that meet FDA specifications to ensure safe storage of potable water. The black or green color limits light penetration, which reduces the growth of waterborne algae. These tanks are rated at 8 pounds per gallon, which means that they are for WATER STORAGE ONLY! They should not be used for chemicals, fertilizers or any other product. Where applicable, the tanks will carry the NSF approval. Please contact your distributor for more specific information regarding NSF approval.

Gallon Capacity	Diameter	Overall Height	Fill Opening	Bottom Fitting	Top Fitting
305	46"	50"	16"	2"	11/2"
500	48"	73	16"	2"	11/2"
550	67"	44"	16"	2"	11/2"
1000	64"	80"	16"	2"	11/2"
1100	87"	53"	16"	2"	11/2"
1350	71"	88"	16"	2"	11/2"
1500	95"	58"	16"	2"	1½"
1550	87"	67"	16"	2"	11/2"
2500	95"	91"	16"	2"	1½"
2500	102"	79"	16"	2"	11/2"
2500	102"	79"	22"	2"	11/2"
3000	95"	109"	16"	2"	11/2"
3000	102"	93"	16"	2"	1½"
3000	102"	93"	22"	2"	1½"
5000	102"	152"	16"	2"	1½"
5000 Peanut Can	119"	112"	22"	2"	1½"
5000 Tuna Can	141"	86"	22"	2"	1½"
10,000 *	141"	160"	16"	2"	_
10,000 *	141"	160"	22"	2"	_

Please refer to www.norwesco.com for part numbers and tank availability locations.

#### **Specialty Water Tanks**



#### **Horizontal Box Tank**

The low profile design of this tank makes it ideal for use on trailers or in the back of a truck. The slosh reduction ribs provide excellent structural support. It can also be used as a stationary water storage tank.

Gallon Capacity	Width	Overall Height	Length	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White
2400	90"	53"	150"	16"	2"	40912

**Low Profile Tank** 

The low profile tanks may be used for storage or transport. They are an excellent choice when height limitations are a factor and are the perfect height for putting under your cottage or cabin.

Gallon Capacity	Width	Overall Height	Length	Fill Opening	Outlet/Drain Specification	Premium Weight Part No.
1250	81"	38"	130"	16"	2"	40756
1275	84"	36"	126"	16"	2"	43011
1500	81"	44"	130"	16"	2"	41392
1600	84"	42"	126"	16"	2"	43013

<sup>\*</sup>Includes one bottom fitting only.

#### **Free Standing Water Tank**

These tanks have been specifically designed with residential and commercial applications in mind. The dimensions of the 250, 300 or 400 gallon allow it to fit through a conventional doorway. The design of the freestanding/self-supporting tanks eliminate the need for a steel support frame.

#### **Free Standing Water Tank**

Gallon Capacity	Width	Overall Height	Length	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White
250	29"	40"	62"	16"	11/4"	42337
300	29"	48"	62"	16"	11/4"	41869
400	30"	68"	63"	16"	11⁄4"	41247



#### **Containment Basins/Tanks**

Be kind to the environment and limit your liability by using a Norwesco polyethylene containment tank. Federal, state and local agencies are enforcing stringent rules and regulations regarding spills, leaks and overflows from primary containment tanks. These spills can be hazardous and costly and with that in mind, we have designed our containment basins and tanks to meet your containment needs. Our containment basins and tanks are impact and corrosion resistant and are molded as a one-piece, seamless unit. The 140, 250, 360, 500, 600 and 1300 gallon sizes are "basin style"; the 1350 is an open top tank and the 2050 and 2800 "Tank In A Tank" is molded with a dome that can be cut off to enable it to be used as a containment tank. Required containment capacity may vary depending on application and location.




250 Gallon Containment Basin

1300 Gallon Containment Basin

Gallon	Width/Diameter	l Overall	Length	l Fill	Outlet/Drain	l Premium	l Color
Capacity	width/Diameter	Height	Length	Opening	Specification	Weight Part No.	Color
125 w/stand*	48" Diameter	60"		8"	1" SS Fitting	43161	White Tank /
							Black Stand
140	45"	17"	45"	_	_	42771	Black
250	68"	11"	92"	_	_	42114	Black
360	69"	16"	93"		_	42940	Black
500	80"	19"	92"		_	42051	Black
600	84"	20"	98"	_	_	43069	Black
1300	97"	22"	175"	_	_	42195	Black
1350	87" Diameter	53"			_	42052	White
2050 **	102" Diameter	82"		16"	_	43072	White
2800 **	102" Diameter	104"		16"		42222	White

<sup>\*</sup> Polyethylene stand

<sup>\*\*</sup> Tank In A Tank




#### **Cone Bottom Tanks**

Norwesco offers a full range of cone bottom tanks designed for a variety of applications. The conical bottoms enable quick and complete drainage. As with all Norwesco tanks, the cone bottom tanks are molded of rugged, high density polyethylene and are both impact and chemical resistant. Please refer below for polyethylene or steel stands.

Gallon Capacity	Diameter	Overall Height	Slope	Fill Opening	Outlet/Drain Specification	Premium Weight Part No. White	Heavy Weight Part No. Blue
175 w/stand*	43"	49"/9"†	30°	16"	2"	60113	_
300 w/stand*	49"	61"/9"†	30°	16"	2"	62343	_
310 w/stand*	43"	72"/9"†	30°	8"	2"	62441	_
500 w/stand*	49"	87"/9"†	30°	16"	2"	40289	_
750	72"	56"	20°	16"	2"	40811	_
750 w/stand*	73"	67"/11"†	20°	16"	2"	40809	_
1050	72"	75"	20°	16"	2"	40356	_
1050 w/stand*	73"	86"/11"†	20°	16"	2"	40359	_
1600	88"	84"	30°	16"	2"	40817	40819
1600 w/stand*	89"	96"/11"†	30°	16"	2"	40813	40815
2500	95"	105"	30°	16"	2"	40066	40129
2500 w/stand*	96"	116"/10"†	30°	16"	2"	40672	40674
2500 15° slope**	91"	108"	15°	16"	2"	43065	43067
3000	95"	123"	30°	16"	2"	40170	40172
3000 w/stand*	96"	134"/10"†	30°	16"	2"	40797	40799
3000 15° slope**	91"	120"	15°	16"	3"/2"	45141	_
4500	102"	145"	10°	16"	3"/2"	43058	43060
5500	119"	148"	30°	16"	3"/2"	40549	40316
6000	102"	195"	15°	16"	3"/2"	40931	40933
6000 10° slope	102"	189"	10°	16"	3"/2"	43054	43056
7500	141"	149"	30°	16"	3"/2"	40551	40409


Polyethylene stand \*\* Stand not available for this tank † Distance from bottom of cone to ground



#### Polyethylene Cone Bottom Stands

Maintenance free, lightweight Norwesco polyethylene stands offer unequaled corrosion resistance.

Tank Size (Gallon)	Α	В	С	D
175	_	31½"	8"	43"
300	_	32"	8"	49"
310	_	31½"	8"	43"
500	_	32"	8"	49"
750	_	34"	10"	73"
1050	_	34"	10"	73"
1600	_	46"	10"	89"
2500/3000 (30°)	_	47"	10"	96"




#### Heavy Duty Steel Cone Bottom Stands

Norwesco heavy duty cone bottom stands are manufactured from structural steel and offer a full dish for uniform support. An optional top band is available for the 2500/3000 steel stand when additional support is needed.

Tank Size (Gallon)	Α	В	С	D	F	Part No.
2500/3000 (30°)	_	36"	11"	96"	11"	60059
4500/6000 (10°)	_	20%"	12"	102"	12"	63675
5500	_	45"	11"	119"	121/2"	60358
6000	_	25"	13"	102"	121/8"	62473
7500	_	49"	11"	140"	10¾"	61860
2500/3000 (30°)	Optional Top Band Assembly	_	_	_	_	60359

#### **High Density Polyethylene Lids**

Description	Item Code	Part No.
22" Lid and ring with air vent		63679
16" Lid and ring with blue snap-in vent	А	63485
16" Lid, ventless with ring		60367
16" Lid, ventless	В	60365
16" Ring only		60012
Ethafoam gasket for 16" non-hinged lid		62941
Blue snap-in vent for 16" lid (63485)		63539
8" Lid with blue snap-in vent	C	63480
Blue snap-in vent for 8" lid (63480)		63482
5" Lid with ball check air vent (for tanks manufactured after 2/1/00)	D	63484
5" Lid with 2" FPT (does not include vent cap)		63264
5" Lid, hinged for 110 Low Profile		63673
EPDM gasket for 5" lid, 63264 or 63484		60366
2" MPT vent cap with poly screen		63266
18" lanyard for 8" lid and 16" non-hinged lid (tethers lid to tank)		62531
Stainless steel screw for 8" and 16" rings		60081
Strainer basket for 16" fill-opening (7" depth)		67374



#### **Hinged Lid**

This lid is manufactured from a co-polymer material for strength, durability and excellent chemical resistance. Our unique locking tab allows you to easily slip a padlock through it and secure your lid from theft or spills. The lid is interchangeable with a standard 16" lid and ring assembly if you choose to replace your existing lid.

- Easy open/close opens a full 180 degrees
- Comes complete with a baffle vent assembly, allowing for adequate venting when bottom filling your tank.
- Unique locking tab
- All parts of lid may be ordered as repair parts

Description	Part No.
Complete lid assembly	62532

#### **Hinged Lid Repair Parts**

Description	Part No.
16" hinged lid with vent assembly, without ring	62826
16" hinged ventless lid, with ring	63390
Vent assembly	62827
Ring assembly	62828
Hinge assembly	62829
EPDM O-ring for lid	62830
Neoprene O-ring for ring	62831




#### **Polyethylene Tank Repair Kits**

The tank repair kit (welding gun and rod) includes a specially formulated welding wire containing co-polymers and adhesives. Wire may be used to effectively repair linear polyethylene. Easy to use and requires only 110 volt power. The poly patch kit is ideal for repairing pinholes, hairline cracks and holes up to ½" in diameter. For best results, surface to be repaired should be above 32° F. The kit consists of epoxy, a small brush to apply the epoxy, a small piece of sandpaper to "roughen" the area to be patched, a piece of mastic to temporarily fill the hole/crack and a piece of fiberglass.

Description	Part No.
Poly welding gun & rod	60221
Poly welding rod 30'	61879
Poly patch kit	67412

Poly Welding Gun



**Polypropylene Bulkhead Fittings / EPDM Or Viton Gaskets**Norwesco's polypropylene fittings come standard with an EPDM gasket. Viton gaskets are available as an option when EPDM may not be suitable for your application. The 2" stainless steel bulkhead fitting comes standard without a gasket.

Description	Hole Size Required in Tank for Installation	Part No.	Item Code
½" Heavy duty double threaded polypropylene fitting	17/16"	62834	А
¾" Double threaded polypropylene fitting	17/16"	60401	Α
EPDM gasket for $\frac{1}{2}$ " and $\frac{3}{4}$ " (62834 and 60401)		60402	
Type B Viton gasket for $\frac{1}{2}$ " and $\frac{3}{4}$ " (62834 and 60401)		60360	
3/4" Heavy duty double threaded polypropylene fitting	15/8"	62798	А
EPDM gasket ¾" (62798)		62799	
Type B Viton gasket for ¾" (62798)		62800	
1" Double threaded polypropylene fitting	21/4"	60427	Α
1¼" Double threaded polypropylene fitting	21/4"	60403	А
1¼" Anti-vortex polypropylene fitting	21/4"	63065	D
EPDM gasket for 1" and 1¼" (60427, 60403 and 63065)		60404	
Type B Viton gasket for 1" and 11/4" (60427, 60403 and 63065)		60361	
Anti-vortex adapter for 11/4" (60403)		62398	
1½" Double threaded polypropylene fitting	3"	60124	А
Siphon tube, 1½" x 12" long		63279	
2" Double threaded polypropylene fitting	3"	60405	Α
2" Double threaded 316 stainless steel fitting, less gasket	3"	61767	
EPDM gasket for 11/2" and 2" (60124, 60405, 63481 and 61767)		60406	
Type B Viton gasket for 11/2" and 2" (60124, 60405, 63481 and 61767)		60523	
2" Standard duty double threaded polypropylene fitting	3"	63481	Е
(Maximum tank wall thickness = $\frac{3}{8}$ ")			
2" Heavy duty double threaded polypropylene fitting	31/4"	63683	В
EPDM gasket for 2" (63683)		60336	
Type B Viton gasket for 2" (63683)		60008	
Siphon tube, 2" short		60335	
Siphon tube, 2" x 12" long		63262	
2" MPT vent cap with poly screen		63266	
2" MPT vent cap, anti-vortex, without screen		63316	
Anti-vortex adapter for 2" bulkhead fitting		62399	
2" Polypropylene dust plug		60021	
2" Self-aligning double-threaded polypropylene fitting	4½"	63668	
(Designed to install in dome of vertical tank above the liquid level)			
EPDM gasket for 2" self-aligning (63668)		60331	
Type B Viton gasket for 2" self aligning (63668)		60351	
3" Double threaded polypropylene fitting	4½"	62299	C
EPDM gasket for 3" (62299)		60331	
Type B Viton gasket for 3" (62299)		60351	
2" Polypropylene reducer for 3"		60330	
Siphon tube, 3" short		60327	
Siphon tube, 3" x 12" long		63263	
4" Double threaded polypropylene fitting (hex nut as shown in photo C)	5¾"	62171	
EPDM gasket for 4" (62171)		62785	
Type B Viton gasket for 4" (62171)		62786	
Siphon tube for 4"		62714	

#### **Bolted Fittings**

Polypropylene Double Threaded Bolted Fittings / EPDM or Viton Gaskets (Require two gaskets.)

Bolted polypropylene fittings are equipped with 316 stainless steel bolts and come standard with EPDM gaskets. Viton gaskets are available as an option for the fittings.

Description	Part No.	Item Code
3/4" Polypropylene bolted fitting with ss bolts and EPDM gaskets	60502	Α
1" Polypropylene bolted fitting with ss bolts and EPDM gaskets	60505	Α
EPDM gasket for ¾" and 1"	60498	
Type B Viton gasket for ¾" and 1"	60355	
11/2" Polypropylene bolted fitting with ss bolts and EPDM gaskets	60513	Α
2" Polypropylene bolted fitting with ss bolts and EPDM gaskets	60516	Α
EPDM gasket for 1½" and 2"	60497	
Type B Viton gasket for 1½" and 2"	60356	
3" Polypropylene bolted fitting with ss bolts and EPDM gaskets	62471	
EPDM gasket for 3"	62048	
Type B Viton gasket for 3"	60602	



Bolts are threaded into the back plate of the fitting so there are no welds or bolt holes that can be potential points of leakage. These fittings come standard without a gasket and require a single gasket that is installed on the inside of the tank. Available gaskets are cross-linked polyethylene, EPDM or Viton.

Description	Part No.	Item Code
½" 316 Stainless steel double threaded bolted fitting less gasket	63216	В
3/4" 316 Stainless steel double threaded bolted fitting less gasket	63035	В
1" 316 Stainless steel double threaded bolted fitting less gasket	62948	В
EPDM gasket for ½", ¾" & 1" (1 required)	63205	
Type B Viton gasket for ½", ¾" & 1" (1 required)	63224	
Cross-linked polyethylene gasket for ½", ¾" & 1" (1 required)	62950	
1¼" 316 Stainless steel double threaded bolted fitting less gasket	63036	В
Cross-linked polyethylene gasket for 11/4" (1 required)	63041	
1½" 316 Stainless steel double threaded bolted fitting less gasket	63037	В
EPDM gasket for 11/4" and 11/2" (1 required)	63426	
Cross-linked polyethylene gasket for 11/2" (1 required)	63042	
2" 316 Stainless steel double threaded bolted fitting less gasket	63038	В
EPDM gasket for 2" (1 required)	63206	
Type B Viton gasket for 11/4", 11/2" and 2" (1 required)	63225	
Cross-linked polyethylene gasket for 2" (1 required)	62848	
3" 316 Stainless steel double threaded bolted fitting less gasket	63039	C
EPDM gasket for 3" (1 required)	63223	
Type B Viton gasket for 3" (1 required)	63226	
Cross-linked polyethylene gasket for 3" (1 required)	63043	
4" 316 Stainless steel 8-bolt double threaded bolted fitting with gasket	63688	
EPDM gasket for 4" (1 required)	63690	
Viton gasket for 4" (1 required)	63691	
Cross-linked polyethylene gasket for 4" (1 required)	63689	

#### **Stainless Steel Single Threaded Bolted Fittings**

Description	Part No.
2" 316 Stainless steel single threaded bolted fitting less gasket	62847
EPDM gasket for 11/4", 11/2" and 2" (1 required)	63206
Type B Viton gasket for 1¼", 1½" and 2" (1 required)	63225
Cross-linked polyethylene gasket for 2" (1 required)	62848
3" 316 Stainless steel single threaded bolted fitting, anti-vortex, less gasket	63233
EPDM gasket for 3" (1 required)	63223
Type B Viton gasket for 3" (1 required)	63226
Cross-linked polyethylene gasket for 3" (1 required)	63043
Type B Viton gasket for 3" (1 required)	0022





#### **Manufacturing and Distribution**

- B. St. Bonifacius, Minnesota
- C. Lancaster, Ohio
- D. Griffin, Georgia
- E. Shawnee, Oklahoma
- F. Tooele, Utah

- G. Owego, New York
- H. Washougal, Washington
- I. Sheldon, Iowa
- J. Washington Court House, Ohio
- L. Hanford, California

- M. Edmonton, Alberta-Canada
- O. Saskatoon, Saskatchewan-Canada
- Q. Edmonton, Alberta-Canada
- T. Fairfield, Texas
- X. Albertville, Alabama

Tank dimensions and capacities may vary slightly and are subject to change without notice.

#### Warranty

Norwesco offers a three year warranty from date of manufacture on all premium weight tanks and a five year warranty on all heavy weight tanks. Should a defect appear within the warranty period Norwesco will supply a new, equivalent tank in replacement thereof. Norwesco's liability is limited to the value of the tank itself and specifically excludes the cost of installation and/or removal or consequential damages. Please contact your chemical supplier or Norwesco Customer Service for chemical resistance information.



Norwesco, INC.

4365 Steiner Street P.O. Box 439 St. Bonifacius, MN 55375-0439 Tel (800) 328-3420 Fax (800) 874-2371

ux (000) 07 + 257 1

www.norwesco.com

### ULTRA-SAFET EXPUNIT HEATER







### Applications

- Aircraft Hangars/Service Areas
- Chemical Storage/Handling Areas
- Coal Preparation Plants
- Compressor Stations
- Grain Elevators
- Oil Refineries and Rigs

- Paint Storage Areas
- Petrochemical Plants
- Sewage Pump Stations/ Treatment Plants
- · Spray Booths
- Class I, Divisions 1 and 2, Groups C and D Class II, Divisions 1 and 2, Groups E, F and G Class I, Zones 1 and 2, Group IIB Temperature Code T3C, 320°F (160°C)

INDEECO's ULTRA-SAFE™ EXP explosion-proof unit heater is designed with both safety and versatility in mind. Unique ULTRA-SAFE™ EXP features include:

- Industry's Lowest Ignition Temperature Code Rating: T3C, 320°F (160°C)
- Dual Overtemperature Protection: With both automatic and manual reset overtemperature cutouts for additional safety.
- Nontoxic Propylene Glycol Heat Transfer Fluid
- Low 70 PSIG Relief Valve Setting: This assures that in an emergency, the initial escaping vapor temperature remains below the 320°F (160°C) ignition temperature.
- Corrosive Resistant Options: INDEECO offers three constructions suitable for most applications. Standard construction for use in dry non-corrosive areas includes: welded steel heat exchanger; powder-coated cabinet; epoxy-coated motor. A 316 stainless steel construction suitable for Waste Water Treatment Plants includes: 316 stainless steel heat exchanger, headers and tubes with aluminum fins; stainless steel cabinet; corrosive resistance hardware; epoxy-coated motor. Third construction is suitable for use in Chemical Plants where chlorides are present and includes: Heresite® coated heat exchanger, cabinet, fan blade; corrosive resistance hardware; epoxy-coated motor.

#### **Standard Construction Features**

Heat Exchanger – Efficient liquid-to-air design utilizes an all welded steel headers and finned tube construction with spiral wound aluminum fins. Industrial grade INDEECO heating elements are immersed in a nontoxic, inhibited, propylene glycol heat transfer fluid that provides freeze protection down to -49°F (-45°C). The heat exchanger is hydrostatically tested at 350 psig. A pressure relief valve provides excess pressure protection and is set at 70 psig.

Fan Motor Assembly – Consists of an explosion-proof motor fitted with an aluminum fan blade. The motor has double-shielded, permanently lubricated ball bearings and automatic reset line breaking thermal overload protection. Motors furnished on standard units operate at line voltage and are prewired to the control enclosure so separate field wiring to the motor is not required.

The standard motor is rated for Class I, Groups C and D, Class II, Groups F and G. The minimum operating temperature is -14°F (-25°C) and the minimum storage temperature is -49°F (-45°C). Optional motor ratings are described on page 9.

Cabinet/Louvers – Industrial grade, corrosion resistant construction fabricated from powder coated 14-gauge galvanized steel. The adjustable louvers have minimum opening safety stops.

**Controls** – Factory mounted on the unit heater. Standard built-in controls include automatic and manual reset overtemperature cutouts, controlling magnetic contactor, 24-volt control circuit transformer and incoming power terminal blocks housed in a NEMA 7, 9 cast aluminum enclosure.



# UNIT HEATER ULTRA-SAFET EXP

### **Factory Built-in Options**

Code	Option	Description	Availability Code (2)
C1	316 Stainless Steel Corrosion Resistant Construction (Waste Water Treatment Plants)	316 Stainless steel heat exchanger with aluminum fins, 316 stainless steel cabinet; aluminum fan blade; cast aluminum NEMA 4X, 7, 9 control enclosure; corrosionresistant hardware; corrosion-resistant protective coated motor which has passed the ASTM B117 salt-spray test.	С
C2	Dirty Duty Corrosion- Resistant Construction (Chemical Plants)	Epoxy-coated motor; Heresite® coated heat exchanger cabinet and fan blade; cast aluminum NEMA 4X, 7, 9 control enclosure; corrosion resistant hardware; corrosion-resistant protective coated motor which has passed the ASTM B117 salt-spray test.	С
D	Disconnect Switch	Factory installed on the unit heater beside the control enclosure. This is an inexpensive and positive way to meet NEC/CEC requirements for a disconnecting means within sight of the heater.	S
E	Group E (Metal Dust ) Construction	Class II, Group E (Metal Dust) Construction Temperature Code T3C, 320°F (160°C)	С
Н	50 Hertz Motor	Optional motors for international requirements. Contact factory for KW availability.	С
К	"Warning" Pilot Light	Indicates when the thermal cutouts have tripped and the unit heater needs servicing.	AS
L	"Heater On" Pilot Light	Indicates when the electric heating elements are energized.	AS
М	Manual Reset Thermal Cutout with Backup Contactor	A pilot duty manual reset thermal cutout with a backup contactor is provided for independent secondary overtemperature protection. This option cannot be provided if option Code S or V are also specified.	AS
S	Auto/Fan Selector Switch	A two-position switch wired to the control circuit for auto (automatic heat) and fan only control. This selector switch cannot be provided if option Code M or V are also specified.	AS
Т	Adjustable Thermostat	Factory installed and prewired to the control enclosure. Thermostat is adjustable from 50° to 90°F (10° to 32°C) range.	S
V	120 Volt Control Circuit	Can be provided when required for special external thermostat circuit. This option cannot be provided if option Code S or M are also specified. Nor can both K and L be specified.	AS


<sup>(2)</sup> S = Stock, AS = Assembly Stock, C = Custom Stock heaters ordered with assembly stock or custom options subject to longer delivery.


### ULTRA-SAFET EXPUNIT HEATER


#### **Accessory Items**

#### **ULTRA-SAFE™ EXP Heater Mounting Kits**

These are available for ceiling, wall and pole mounting configurations as described below. Specify type required and catalog number at time of order entry.







**Ceiling Mounting Kit** 

Size

1

2

MW In. (mm)
9 (228.6)
7 (177.8)

3	19.063 (484.2)	5 (127)	
Unit Heater Mounting Kits (One kit required per heater)			

**Mounting Kits for use with Standard Heater Powder Coated Construction** 

MH In. (mm)

11.063 (281) 15.063 (382.6)

Catalog Number	Description	Availability
1022451	Ceiling Mounting Kit, for Frame Sizes 1, 2, 3	
1022452	Wall Mounting Kit, for Frame Size 1, 2, 3	1 Week
1022455	Pole Mounting Kit, for Frame Size 1, 2, 3	

# Unit Heater Mounting Kits (One kit required per heater) Mounting Kits for use with Heaters which include optional Corrosion Resistant Codes C1 and C2

Catalog Number	Description	Availability
1022451-S	Corrosion Resistant Ceiling Mounting Kit, for Frame Sizes 1, 2, 3	
1022454-S	Corrosion Resistant Wall Mounting Kit, for Frame Size 1, 2, 3	1 Week
1022455-S	Corrosion Resistant Pole Mounting Kit, for Frame Size 1, 2, 3	

For corrosion resistant option, add - S to the end of item number.


Remote Room Thermostat – Use catalog number 1007002. See page 95.




# UNIT HEATER ULTRA-SAFET EXP

## **Dimensions, Airflows and Weights**

	KW Range	Siz	Size 1		Size 2		Size 3	
	NW Kalige	3-5 KW	7.5-10 KW	15 KW	20 KW	25 KW	30 KW	
Overall	'X' In. (mm)	18.25	(463.55)	18.25 (	(463.55)	20.00	(508)	
Heater	'Y' In. (mm)	19.375	(492.125)	23.375 (	(593.725)	27.375 (	695.325)	
Dimensions	'Z' In. (mm)	16.06	3 (408)	20.188 (	88 (512.775) 24.188 (614		614.375)	
Airflow	CFM (M3/Hr)	650 850 1800		300	3110	3850		
Characteristics	Throw Ft. (m)	15 (4.5)	25 (7.6)	45 (13.7)		65 (19.8)	75 (22.8)	
	RPM			17	'25			
Motor/Fan	HP	1/4		1/4		1/2		
motor, run	Fan Diameter In. (mm)	12 (	304.8)	16 (406.4)		20 (508)		
	Net Lbs (Kg)	110 (49.89)		150 (68.03)		190 (86.18)		
Weight	Shipping Lbs (Kg)	130	(58.96)	169 (76.65)		216 (	97.97)	





# ULTRA-SAFET EXPUNIT HEATER

Class I, Divisions 1 and 2, Groups C and D Class II, Divisions 1 and 2, Groups F and G Class I, Zones 1 and 2, Group IIB



# IIITDA\_SAFE™ EYD Unit Heater Licting



ULIK	A-SAF	E'™ E <i>)</i>	(P Unit	Heate	r Listing Temper	rature Code T3C, 320°	F (160°C)
KW	Volts	Phase	Total Amps (1)	Frame Size	Approximate Air Temperature Rise °F (°C)	Catalog Number	Availability
	208	1	17	1	15 (8)	233-FA-0036C	
	240	1	15	1	15 (8)	233-FA-0036J	
3	208	3	10	1	15 (8)	233-FA-0036D	
	240	3	9	1	15 (8)	233-FA-0036K	
	480	3	5	1	15 (8)	233-FA-0036U	
	600	3	4	1	15 (8)	233-FA-0036Z	
	208	1	26	1	25 (13)	233-FA-0056C	
	240	1	23	1	25 (13)	233-FA-0056J	
5	208	3	16	1	25 (13)	233-FA-0056D	
	240	3	14	1	25 (13)	233-FA-0056K	
	480	3	7	1	25 (13)	233-FA-0056U	
	600	3	6	1	25 (13)	233-FA-0056Z	
	208	1	38	1	28 (16)	233-FA-0086C	
	240	1	34	1	28 (16)	233-FA-0086J	
7.5	208	3	23	1 28 (16)		233-FA-0086D	-
	240	3	20	1	28 (16)	233-FA-0086K	1
	480	3	10	1	28 (16)	233-FA-0086U	Week
	600	3	9	1	28 (16)	233-FA-0086Z	VVCCK
	240	1	44	1	38 (21)	233-FA-0106J	
	208	3	30	1	38 (21)	233-FA-0106D	
10	240	3	26	1	38 (21)	233-FA-0106K	
	480	3	13	1	38 (21)	233-FA-0106U	
	600	3	11	1	38 (21)	233-FA-0106Z	
	208	3	44	2	27 (15)	233-FB-0156D	
	240	3	38	2	27 (15)	233-FB-0156K	
15	480	3	19	2	27 (15)	233-FB-0156U	
	600	3	16	2	27 (15)	233-FB-0156Z	
20	480	3	25	2	35 (19)	233-FB-0206U	
20	600	3	21	2	35 (19)	233-FB-0206Z	
25	480	3	31	3	26 (14)	233-FC-0256U	
20	600	3	25	3	26 (14)	233-FC-0256Z	
30	480	3	37	3	25 (13)	233-FC-0306U	
50	600	3	30	3	25 (13)	233-FC-0306Z	

<sup>(1)</sup> Total Amps = Heating element amps and motor amps.



# UNIT HEATER ULTRA-SAFET EXP

## **Explosion-Proof Unit Heater**

## Three Constructions to Choose From; Standard, Stainless Steel or Heresite®

#### Standard - Non-corrosive applications


- Aircraft Hangars/Servicing Areas
- Coal Mines/Preparation Plants
- Gasoline Fueling/Storage Areas
- Paint Spraying/Storage Areas
- Utility Plants

## **Optional 316 Stainless Steel or Heresite® Coating**

- Chemical Plants
- Chemical Storage/Handling Areas
- Food Processing Plants
- Oil Refineries
- Petrochemical Plants
- Sewage Treatment/Wastewater Treatment Plants

#### Heavy 14-Gauge Cabinet

- Powder coated standard
- 316 stainless steel or Heresite®



## **Designed for Easy Servicing**

- · Removable core
- Split fan guard
- · Easy access to motor and fan
- Replaceable automatic and manual thermal cutouts

field servicing.

explosion-proof motor with heavy-gauge aluminum fan blade designed for easy

Threaded control enclosure

#### **Heater Core**

#### All welded construction with:

- · Painted steel heaters with steel tubes and spiral wound aluminum fins - standard
- 316 stainless or heresite® construction options

Core can be easily removed through bottom of cabinet

Heresite® is a registered trademark of Heresite® Protective Coatings, Inc.




## **INDEECO**

## Owner's Manual

## **ULTRA-SAFE EXP Series**

**Electric Forced Air Heater for Hazardous Locations** 





## This manual covers installation, maintenance and repair parts.

FM and CSA Approved for the following classified areas:

Class I, Divisions 1 & 2, Groups C & D

Class II, Divisions 1 & 2, Groups F & G

Operating Temperature Code T3C - 320°F (160°C)

Class I, Zones 1 & 2, Group IIB, T3 (FMUS & CSAUS only)

or

Class I, Divisions 1 & 2, Groups C & D

Class II, Divisions 1 & 2, Groups E, F & G

Operating Temperature Code T3C - 320°F (160°C)

Class I, Zones 1 & 2, Group IIB T3 (FMUS & CSAUS only)

See Data Plate for Specific Area Classification

For details on the particular hazardous environments having the potential for explosion, refer to Articles 500 through 516 of the National Electric Code, and/or Section 18 of the Canadian Electric Code, Part I.





#### WARNINGS

Installation and maintenance personnel should familiarize themselves with this manual and all the **WARNINGS** before installing or working on this heater to avoid potential hazardous conditions, severe property damage, personal injury or death.

- To reduce the risk of ignition of hazardous atmospheres: Do not install where the operating temperature code limit exceeds the ignition temperature of the hazardous atmosphere.
- 2. Potentially lethal voltages are present. Be sure to lock the branch circuit disconnect switch in the OFF position and tag the circuit "Out for Maintenance" before working on this equipment.
- Keep electrical enclosure covers tightly closed while in operation.
- 4. Hazard of Electric Shock. Heater must be grounded in accordance with the N.E.C. and/or C.E.C.
- 5. This heater should be installed by qualified personnel familiar with the National Electric Code and/or the Canadian Electrical Code requirements for hazardous locations. It is the responsibility of the installer to verify the safety and suitability of the installation.
- 6. Disassembly of the unit, for installation, is not required or authorized.
- 7. When connecting the room thermostat, be sure that the thermal cutouts remain connected in series with the controlling contactor. The unit must not operate without the thermal cutouts properly connected in the circuit.
- 8. Do not attempt to install a "Fan Only" switch on a standard unit heater and do not try to field modify a standard unit heater for this option. The heater must have been ordered for this option to have the necessary internal controls.
- Replacement of electrical components should only be done by qualified personnel familiar with the requirements of maintaining electrical equipment in hazardous locations.
- 10. Replacement electrical components must be obtained from the factory in order to maintain the hazardous location rating.

- 11. The heat exchanger is a factory vacuum-sealed unit. Do not attempt to loosen or tighten any of the fill or drain plugs or attempt to operate the pressure relief valve. A loss of vacuum could cause nuisance tripping of the cutouts or high pressures which will cause the relief valve to actuate with an accompanying loss of liquid. Should leakage occur, remove unit from service and investigate cause.
- 12. The heat exchanger is filled with a mixture of water and inhibited propylene glycol. Contact with the fluid at operating temperatures may produce a burn hazard. The Material Safety Data sheets indicate that there is not a health hazard from coming in contact with the inhibited propylene glycol. Suggested first aid consists of flushing eyes with plenty of water and to wash off skin in flowing water or a shower.
- 13. Install and operate in an upright position only. Failure to comply will cause the overtemperature thermal cutouts to trip.
- 14. Installation minimum mounting clearances on nameplate must be maintained.
- 15. Use copper wire for supply connections according to size and rating on nameplate.
- 16. Do not attempt to override louver stops or operate unit with louvers fully closed.
- 17. "Warning Light", if supplied, will turn on if the high temperature thermal cutout opens. This could result if the heat exchanger is dirty, inlet air is obstructed, vacuum loss in heat exchanger, fan not turning or incorrect supply voltage. Disconnect power to unit before servicing.
- 18. Crackling noises within the heat exchanger at startup are normal.

WARRANTY WILL BE VOID IF INSTRUCTIONS ARE NOT FOLLOWED.

#### **GENERAL**

The air heaters are designed for comfort heating and should not be used in ambient temperatures exceeding  $104^{\circ}F$  ( $40^{\circ}C$ ). The units may be wall, pole or ceiling mounted. They utilize a hermetically sealed, liquid-to-air heat exchanger containing immersion type electric heating elements. A mixture of nontoxic propylene glycol and water is place in the heater core to act as a heat transfer fluid. The propylene glycol provides freeze damage protection to -49°F (-45°C). The unit is designed to give years of safe, trouble-free operation when properly installed and maintained.

#### **INSTALLATION**


#### A. Site Selection:

The Heaters should not be mounted close to drapery or similar materials which could lay on the cabinet, or block the inlet or outlet of the heater. The heaters are intended for elevated mounting locations so that they blow warm air down to the floor area. A mounting height should be selected so that the heater is out of the way of possible moving equipment or personnel, yet low enough to deliver warm air to the selected area. See mechanical installation instructions for recommended installation heights.

#### **B.** Mechanical Installation:

Once an acceptable location has been determined, follow these instructions to complete the mechanical installation.

1. The Heaters are designed for use only while permanently mounted in an upright, level position. See figure below maximum tilt angles:



2. To ensure proper heating of floor surfaces, observe the following recommended maximum mounting heights (to bottom of heater):


#### Maximum Mounting Height from Floor:

Maxillul	n Mounting Height In	JIII I 1001.
233-FA	233-FB	233-FC
9 ft.	10 ft.	13 ft.
(2.7m)	(3.0m)	(4.0m)

3. The supporting structure that the heater is attached to must have adequate strength to safely support the heater and be sufficient to keep the heater in its proper upright operating position. The maximum unit weights are:

MODEL	lbs	(kgs)
233-FA	150	68
233-FB	200	91
233-FC	250	114

4. See figure below for minimum installation clearances:



- 5. The heater may be suspended from overhead beams or mounted to a side wall or a 4" pipe using one of the approved mounting kits. Use of non-approved mounting kits voids all warranties, expressed or implied.
- 6. Wall mounting should be to structural steel. If the wall construction is plasterboard with wooden 2 X 4 framing or similar, it must be reinforced with angle iron or wooden cross braces.
- 7. Lock washers should be used on all mounting nuts and bolts to ensure they don't vibrate or work loose due to fan vibration or other vibration transmitted to the heater.

#### C. Electrical Installation:

Follow these instructions to complete the electrical installation:

- 1. External branch circuit protection is required. See nameplate ratings and follow Code recommendations.
- 2. Use only an approved explosion-proof means of wiring, such as mineral insulated cable or copper conductors in rigid conduit with conduit seals as required to make connection to the heater.
- 3. Follow the NEC and/or CEC and any local electrical and building codes related to the installation and intended use of the heater in an explosion-hazard area.
- 4. When doing any work on a heater, including the initial electrical connection, disconnect the electrical current at the main branch circuit switch, and lock the switch in the off (open) position and tag the circuit "Out for Maintenance" to prevent potential lethal shock hazards.
- 5. Confirm that the electrical power supply matches the nameplate voltage, phase, amperage and frequency rating of the heater to be connected.
- 6. Ensure conductors are of appropriate gauge size. The minimum gauge is stamped on the nameplate. Size all input conductors according to accepted standards consistent with the temperature rating of the wire being used. Use minimum 75°C rated wire.

- 7. Proper installation of the heater requires that an adequate grounding conductor be connected to the ground terminal. This terminal is painted green or marked with the letter "G" and is located on the inside of the control enclosure next to the power input opening.
- 8. Check and confirm all connections are securely fastened.
- Before application of electrical power, check all connections to ensure compliance with the wiring diagram and any code requirements. Remove any foreign objects from the control boxes. Reinstall covers tightly.
- 10. On all 3-phase heaters, it is necessary to verify that the fan is rotating in the proper direction. If air delivery is not from the front of the heater, exchange any 2 input wires at the main contactor terminal located in the control enclosure.
- 11. The explosion-proof control box is designed with threaded joints and metal-to-metal contact at the lid or cover joint to prevent an explosion. Do not attempt to install gasket material of any type at these joints. A light coating of anti-seize compound is applied to the threads to prevent seizing.
- 12. See section titled "operation" before energizing the heater.

#### **D.** Field Installed Controls:

#### 1. Power Disconnect Switch:

The NEC requires that a power disconnect switch be mounted within sight of the heater. The CEC or local codes may require a disconnect switch within sight of the heater. Refer to the electrical diagram and follow these steps:

- a.) The remote power disconnect switch must be an explosion-proof disconnect switch rated for the area classification.
- b.) The switch must be indicating and have a locked off position.
- c.) The switch must be rated for the nameplate voltage and current per the NEC, CEC and any local codes.
- d.) Follow steps 6 through 12 of the electrical installation instructions to complete the installation.

#### 2. Room Thermostat:

Refer to the electrical wiring diagram and follow these steps:

- a.) Connect the remote thermostat across the leads marked "C" and "C1". The external thermostat will then be in series with the heater thermal high-limit switches and correct operation of the heater will result.
- b.) The wiring to the remote thermostat must be copper wire, 16 gauge minimum (for Class II) or 14 gauge minimum (Class I) and run in explosion-proof conduit with appropriate conduit seals installed per the NEC, CEC and any local codes.
- c.) Any room thermostat used with this heater must be of an explosion-proof type rated for the area classification, open on temperature rise, rated 250VAC, 75VA inductive capacity.

#### 3. 'Fan Only' Switch:

Refer to the electrical wiring diagram and follow these steps:

- a.) Do not attempt to install a "Fan Only" switch on a standard unit heater and do not try to field modify a standard unit heater for this option. The heater must have been ordered for this option to have the necessary internal controls.
- b.) Connect the remote 'fan only' selector switch across the leads marked "C" and "F".
- c.) The wiring to the fan selector switch must be copper wire, 16 gauge minimum (for Class II) or 14 gauge minimum (for Class I) and run in explosion-proof conduit with appropriate conduit seals installed per the NEC, CEC and any local codes.
- d.) Any selector switch used with this heater must be an explosion-proof switch rated for the area classification, maintained 2 position selector switch rated for 250 VAC, 75 VA inductive.

#### **OPERATION**

The unit heater may be operated normally at ambient temperatures of 104°F (40°C) or less and at altitudes of 3,300 feet (1000m) or less in atmospheres containing less than 21% oxygen by volume, and as classified on the nameplate. All of these conditions must be met before attempting to operate the heater. The heater should never be operated in an oxygenenriched atmosphere or at ambient temperatures above 104°F, (40°C). The heater may be operated at higher altitudes if the ambient temperatures are below 104°F, (40°C).

#### A. Initial Operation:

Check to make sure the mechanical and electrical installation is complete and that it is safe to operate the heater.

- 1.) Heater without built on or remotely mounted fan switch:
  - a.) Set the temperature control thermostat to a setting above the current room temperature.
  - b.) Energize the heater electrical supply circuit.
  - c.) The heater and fan should come on and in 5 to 15 minutes reach a stable operating temperature. If the room temperature is high and the installation is above 3,300 feet, the unit heater may cycle on the thermal high limits of the motor or the heater.
  - d.) Check out and report any unusual or questionable operating characteristics, such as noise, vibration, loss of fluid, etc. Note that crackling noises coming from the heat exchanger during warm up are normal.
  - e.) Set the temperature control thermostat to the desired room temperature setting.
  - f.) De-energize the heater electrical supply circuit until heater operation is required.
- 2.) Heater with fan switch:
  - a.) Place the fan switch in the fan position.
  - b.) Set the temperature control thermostat to a setting below the current room temperature.
  - c.) Energize the heater electrical supply circuit.
  - d.) The heater fan should come on but the heater should remain off.
  - e.) Place the fan switch in the auto position.
  - f.) The fan should go off.
  - g.) Set the temperature control thermostat to a setting above the current room temperature.

- h.) The fan and heater should operate. If the room temperature is high and the installation is above 3,300 feet (1000m), the unit heater may cycle on the thermal high limit cutouts of the motor or the heater.
- i.) Check out and report any unusual or questionable operating characteristics, such as noise, vibration, loss of fluid, etc.
   Note that crackling noises coming from the heat exchanger during warm up are normal.
- j.) Set the fan switch and temperature control thermostat to the desired operating positions.

#### **B.** Normal Operation:

Prior to the start of the heating season, perform the electrical and mechanical steps outlined in the section titled "maintenance".

- a.) Perform the Operation steps for the applicable temperature control option.
- b.) Place all switches in their normal operating position and place the unit heater in service.

#### **MAINTENANCE**

Maintenance and repair must be performed by qualified personnel only.

#### A. Electrical:

- Inspect all terminal connections, contactor and conductor insulation for damage, looseness, fraying, etc., as applicable. Tighten any loose terminals and replace or repair wire with damaged or deteriorated insulation. If contactor contacts are badly pitted, welded together, or burned, replace the contactor. Check all explosion-proof conduit for visible damage and tightness.
- 2. If reduced heat output is suspected, perform the mechanical checks. If low heat output is still suspected after completing the mechanical checks, verify the condition of the heating elements by using an amperage meter to check the current draw of each input line. All input lines should draw approximately equal current which should agree with nameplate rating. If they do not, one or more of the heating elements could be burned out and the heater/core assembly should be replaced.
- The electric motor is permanently lubricated and thermally protected. Check for smooth and quiet running at all inspections. Replace motor if excessive bearing play is detected. Contact the factory for instructions.

#### **B.** Mechanical:

- 1. Never attempt to fill, drain or check the liquid level of the heat exchanger or check the action of the pressure relief valve. Contact the factory for instructions.
- The explosion-proof control box is designed with threaded joints and metal-to-metal contact at the lid or cover joints to prevent an explosion. Do not attempt to install gasket material of any type at these joints. A light coating of anti-seize compound is applied to the threads to prevent seizing.

- 3. Annually check the tightness of all visible bolts and nuts, in particular the support structure bolts and nuts. Similarly check the motor mounting bolts and nuts.
- 4. Periodically, check the motor, fan and heater core fins for cleanliness. A dirty heat exchanger can cause the unit to over heat and cycle on the thermal cutouts. If the dirt is loose dust, clean with a vacuum or by air jet. If the dirt can't be vacuumed or blown off, use a warm water spray directed to the inlet side of the heat exchanger then to the outlet side. A soft bristled brush may be required to loosen stubborn deposits. Be careful not to bend the aluminum fins on the heat exchanger or the fan blade propeller. Allow unit to dry before re-energizing.
- 5. Check louvers for position tightness and equal angle settings. Check motor and fan for smooth running operation. Any unusual noise or vibration must be investigated and rectified.
- 6. Should there be any evidence of fluid leakage from the heater core, the heater should be repaired immediately. The heater will not operate properly with a low fluid level. Contact the factory for replacement core.

#### REPAIR AND REPLACEMENT

Maintenance and repair must be performed by qualified personnel only.

#### A. Replacing the Heat Exchanger Core:

The heat exchanger core is not field repairable. Contact factory for replacement.

- 1. Disconnect the heater electrical power supply, unwire and lower the heater from it's mounting location. Set heater face down on a table or on the floor.
- 2. Remove the cabinet bottom, cabinet top, wiring and heater enclosure covers.
- 3. Disconnect all heater wires from the contactor in the wiring enclosure. Disconnect the control wiring from thermal cutout.
- 4. Thread conduit into wiring enclosure to disconnect the heater terminal box.
- 5. With an assistant supporting the weight of the heat exchanger, remove the 3 heat exchanger mounting bolts. Carefully remove the heat exchanger out of the bottom of the cabinet.
- 6. Locate rating tag on the heat exchanger and verify that electrical ratings of the core to be installed match the electrical ratings on the heater nameplate.
- 7. To reinstall, slide the core through the bottom of the cabinet while an assistant lines up and installs the 3 heat exchanger mounting bolts.
- 8. Guide the heater lead wires back into the wiring enclosure.
- 9. Reconnect the heater lead wires to the contactor and the conduit.
- 10. Reattach the cabinet bottom and enclosure covers before mounting heater and energizing.

#### **B.** Replacing the Temperature High-Limit Cutouts:

 Disconnect the heater electrical power supply and remove the heater enclosure cover.

- 2. Remove the wire barrier to expose the high limit cutout.
- 3. Disconnect the wires from the high limit cutout and mark their location.
- 4. Remove the two nuts used to attach the temperature high limit cutout.
- 5. Lift and remove the sheetmetal mounting plate.
- 6. Carefully lift and remove the temperature high limit cutout.
- 7. Use only factory supply parts for safe operation.
- 8. Lightly coat the new manual and automatic cutout bulbs with the supplied thermal transfer compound. This is critical for proper cutout operation.
- 9. Carefully slide the automatic cutout bulb into the <u>left</u> thermowell and the manual cutout bulb into the <u>right</u> thermowell.
- 10. Reinstall the sheetmetal plate. Note that the sheetmetal plate also acts as a stop to keep the cutout bulbs from backing out of the wells.
- 11. Carefully install the temperature high limit control to avoid putting kinks into the capillary.
- 12. Reattach the wires to the cutout and reinstall the wire barrier.
- 13. Ensure heater enclosure cover is in place before energizing heater.

#### **C.** Resetting the Manual Cutout:

All unit heaters contain a built-in manual reset thermal cutout with or without backup contactor.

- 1. Disconnect the heater electrical power supply and remove the heater enclosure cover.
- 2. Determine the reason for the manual reset thermal cutout actuating and rectify the situation. See section titled "maintenance".
- Reset the manual reset thermal cutout by pressing on the red stem in the center of the control
- 4. Replace the heater enclosure cover securely.
- 5. Energize the heater electrical supply circuit.
- 6. The heater and fan should come on and in 5 to 15 minutes reach a stable operating temperature.
- 7. Check out and report any unusual or questionable operating characteristics, such as noise, vibration, loss of fluid, etc.
- 8. If heater operation appears normal, place the unit into normal operation.

#### D. Replacing the Fan Motor and Blade:

The fan motor is permanently lubricated and does not require any maintenance. If the fan motor is defective, a replacement must be obtained from the factory.

- 1. To replace the fan motor:
  - a. Disconnect the heater electrical power supply.
  - b. Disconnect the motor supply wires from the contactor in the wiring enclosure.

- c. Disassemble the conduit union located at the motor wiring hub.
- d. Remove top fan guard and motor mounting bolts.
- e. Lift motor out of heater assembly.
- f. Remove fan blade and conduit union from defective motor and install on new motor.
- g. Install new motor to heater using existing motor mounting hardware.
- h. Reinstall top fan guard and ensure that the fan blade rotates freely.
- i. Feed motor wires through conduit and into wiring enclosure.
- j. Reattach conduit union. Reconnect motor wires to contactor.
- k. Check fan rotation by momentarily energizing heater. Airflow should exit from front of heater cabinet. If rotation is incorrect, disconnect electrical power supply and reverse two of the motor lead wires at the contactor.
- l. Reattach wiring enclosure cover before placing heater back in service.


#### 2. To replace the motor fan blade:

- a. Remove the top fan guard.
- b. Remove the four motor mounting bolts and disconnect the conduit union at the motor.
- c. Loosen the bolt that connects the fan blade to the motor shaft.
- d. Slide the motor back and tilt in order to remove the old blade & install a new one.
- e. Tighten the fan blade attachment bolt to the motor shaft.
- f. Reattach the motor conduit union and the four motor mounting bolts.
- g. Reinstall the top fan guard and ensure that the fan blade rotates freely.

## **REPLACEMENT PARTS**

- All replacements must be factory supplied to ensure safe heater operation. Mark wires and refer to wiring diagram to ensure proper electrical connections.


Reference heater catalog number and item number in figures below when contacting factory for replacement parts. Contact factory for items not shown.





ITEM	DESCRIPTION
1	Heat Exchanger Core Assy.
2	Cabinet – Top
3	Fan Venturi
4	Fan Blade
5	Fan Guard
6	Fan Motor
7	Motor Support – Top
8	Motor Junction Box
9	Thermostat Support Bracket
10	Thermostat
11	Conduit Tee
12	Disconnect Switch - Small
13	Large Disconnect Support Bkt.
14	Fan Switch


ITEM	DESCRIPTION
15	Conduit Seal
16	Pilot Light – Bottom
17	Pilot Light – Top
18	Cabinet – Left Side
19	High Limit Cutout
20	Cabinet – Bottom
21	Cabinet - Louver
22	Cabinet – Right Side
23	High Limit Barrier
24	High Limit Mounting Bridge
25	Heater Enclosure Cover
26	Motor Support – Side
27	<sup>3</sup> / <sub>4</sub> " Conduit Pull Elbow
28	Reducer Bushing

Select the Figure that corresponds to your heater.









## FIGURE 1:

ITEM	DESCRIPTION
41	Wiring Enclosure and Cover
42	Option Mounting Bridge
43	Option Contactor
44	Main Contactor
45	Ground Lug
46	Transformer
47	Auxiliary Contact
48	Main Mounting Bridge

## FIGURE 2:

ITEM	DESCRIPTION
50	Wiring Enclosure and Cover
51	Main Contactor
52	Ground Lug
53	Transformer
54	Auxiliary Contact
55	Main Mounting Bridge

#### FIGURE 3:

ITEM	DESCRIPTION
60	Wiring Enclosure and Cover
61	Auxiliary Contact
62	Ground Lug
63	Transformer
64	Main Contactor
65	Transformer Fuse & Fuse Block
66	Main Mounting Bridge

#### FIGURE 4:

ITEM	DESCRIPTION		
70	Switch Enclosure and Cover		
71	Disconnect Switch		
72	Disconnect Switch Track		

# UNIT HEATER ULTRA-SAFET EXP

## **Explosion-Proof Unit Heater**

## Three Constructions to Choose From; Standard, Stainless Steel or Heresite®

#### Standard - Non-corrosive applications


- Aircraft Hangars/Servicing Areas
- Coal Mines/Preparation Plants
- Gasoline Fueling/Storage Areas
- Paint Spraying/Storage Areas
- Utility Plants

## **Optional 316 Stainless Steel or Heresite® Coating**

- Chemical Plants
- Chemical Storage/Handling Areas
- Food Processing Plants
- Oil Refineries
- Petrochemical Plants
- Sewage Treatment/Wastewater Treatment Plants

#### Heavy 14-Gauge Cabinet

- Powder coated standard
- 316 stainless steel or Heresite®



## **Designed for Easy Servicing**

- · Removable core
- Split fan guard
- · Easy access to motor and fan
- Replaceable automatic and manual thermal cutouts

field servicing.

explosion-proof motor with heavy-gauge aluminum fan blade designed for easy

Threaded control enclosure

#### **Heater Core**

#### All welded construction with:

- · Painted steel heaters with steel tubes and spiral wound aluminum fins - standard
- 316 stainless or heresite® construction options

Core can be easily removed through bottom of cabinet

Heresite® is a registered trademark of Heresite® Protective Coatings, Inc.



# ADVANTAGES / APPLICATIONS















## **Experience**

This catalog represents 75 years of experience in industrial electric heating - our specialty since INDEECO was founded in 1929. INDEECO has been manufacturing products for use in hazardous locations for over 50 years.

## **Complete Product Line**

INDEECO offers the industry's most comprehensive line of space heating equipment. Explosion-proof unit heaters are available with ratings up to 30 KW and 600 volts. TRIAD® unit heaters provide heat in non-hazardous environments where moisture and corrosion are present. Standard unit heaters include a heavy duty industrial model, several commercial models, vertical, cabinet and portable designs. A wide range of floor, wall and ceiling heaters, including baseboard heaters and radiant ceiling panels, are available to meet any application requirement. INDEECO also offers the widest selection of built-in controls in the industry.

## **Quick Delivery**

Popular stock unit heater and convector designs are available for 72 hour shipment. A wide selection of assembly stock designs with options are available in one or two weeks. Most comfort heating products will ship in two weeks.

#### **Colors**

Many of INDEECO's comfort heating products are available in a choice of colors. Standard and special colors are shown in the back of this catalog. Custom colors, including bronze or clear anodizing and matches to customer supplied paint samples, are also available on select heaters.

## Safety

INDEECO explosion-proof unit heaters are Factory Mutual (FM) Approved and include redundant overtemperature protection which exceeds agency requirements. The ULTRA-SAFE™ EXP unit has the industry's lowest Ignition Temperature Code rating, 320°F (160°C), and is also CSA Approved.

INDEECO corrosion resistant heaters are available with UL and cUL Approvals. Explosion-proof and corrosion resistant heater designs are available for marine and shipboard use that are ABS Approved and meet U.S. Coast Guard requirements.

INDEECO commercial and industrial unit heaters are UL and cUL Approved for non-hazardous, non-corrosive environments. Comfort heating products are CSA<sub>IIS</sub> or CSA Approved.

## **Hazardous and Corrosive Area Applications**

- Aircraft Hangars/Service Areas
- Battery Storage Areas
- Chemical Plants
- Chemical Storage/Handling Areas
- Coal Mines/Preparation Plants
- Control Rooms
- Dry Cleaning Plants
- Dusty Areas Subject to Washdown
- Food Processing Plants (Washdown Areas)

- Foundries
- Gasoline Fueling/Storage Areas
- Grain Elevators
- Hydrogen Atmospheres
- Marine/Shipboard and Landbase Facilities
- Natural Gas (Methane) Atmospheres
- Oil Refineries
- Offshore Drilling Rigs
- Paint Spraying/Storage Areas

- Parking Garages
- · Petrochemical Plants
- Pipeline Pumping Stations
- Pulp and Paper Mills
- Sewage/Wastewater **Treatment Plants**
- Solvent Recovery/ Storage Areas
- Utility Plants

## **Industrial and Commercial Applications**

- Basements
- Classrooms
- Conference Rooms
- Entryways/Hallways
- Factories
- Lobbies

- Mechanical Rooms
- Offices
- Power Generating Stations
- Pump Houses
- Restrooms
- Service Stations/Garages

- Shipping and Receiving Areas
- Stairwells
- Storage Areas
- Vestibules
- Warehouses
- Workshops



# **USE OF ELECTRIC HEATERS**

## **In Hazardous Locations**

#### Introduction

Hazardous locations are those areas where a potential for explosion and fire exists due to the presence of flammable gases, vapors, pulverized dusts or ignitable fibers in the atmosphere. Hazardous locations are created from the normal processing of volatile chemicals, gases, coal, grains, etc., or from the accidental failure of storage systems for these materials.

Open flames are not permitted in these locations. The use of electric heating equipment is permitted with two major restrictions: 1) The surface temperature of the equipment cannot exceed the ignition temperature of the hazardous atmosphere and 2) all arc and spark producing devices must be isolated from the atmosphere in an appropriate enclosure.

Both people and equipment in hazardous locations can be heated safely and economically with electric heat. Electric heating is typically much less expensive to install and maintain than comparable remote oil or gas fired heating systems.

#### **National Electrical Code Classification**

Articles 500 through 516 of the National Electrical Code deal with the definition of hazardous areas and the use or design of electrical equipment used in these locations. Electric heating equipment for hazardous areas is specified based on the NEC class, division, group and ignition temperature or the alternate class and zone classification.

#### Class

Hazardous locations are divided into the three general classes of vapors/gases, dusts and fibers.

Class I – Locations where the potential for explosion and fire exists due to the presence of flammable gases or vapors in the air. Typical Class I locations include oil or natural gas drilling rigs, petroleum refining or pumping facilities, petrochemical plants, wastewater/sewage treatment plants, solvent extraction plants, paint spraying booths, locations where open tanks or vats of combustible liquids are present and storage areas for flammable materials.

Class II – Locations where the potential for explosion exists because of finely pulverized flammable dusts suspended in the atmosphere. Typical locations would include coal fired power plants, coal preparation/coal handling facilities, coal mines, grain elevators, flour and feed mills, packaging and handling of pulverized sugar and processing and storage of magnesium and aluminum powder.

Class III – This third classification is primarily a fire hazard where fibers or flyings suspended in the air create a hazard. This would include small pieces of thread-like fiber, sawdust, lint, etc. Typical applications would include textile mills, woodworking plants, cotton gins, cotton seed mills and flax producing plants.

#### Division

Class I, Class II and Class III areas are further defined in terms of when the hazard occurs. Division 1 and Division 2 occurrences are summarized below.

**Division 1** – If the hazard is expected to be present under normal conditions, such as a production or processing facility, the occurrence is designated Division 1. The hazardous atmosphere may be present continuously, intermittently, periodically, or during normal repair or maintenance operations. Division 1 occurrences also include locations where a breakdown in the operation of processing equipment results in the release of hazardous vapors.

**Division 2** – If the hazardous material is normally expected to be contained within a closed area, system or container, and would enter the ambient atmosphere only under an abnormal failure, then it is referred to as a Division 2 occurrence.

# Use of Electric Heaters

## In Hazardous Locations

#### Group

The nature and explosive characteristics of the hazardous material are defined by the NEC group to which it is assigned.

Class I – Hazardous gas locations include chemicals and other materials that have been divided into four groups based on their ignition temperature and explosive characteristics. (Groups A, B, C and D)

**Class II** – Hazardous dust locations are divided into three groups based on their ignition temperature and electrical conductivity of the suspended particles.

**Group E** – Atmospheres containing metal dusts, such as aluminum and magnesium.

**Group F** – Atmospheres containing coal, charcoal or coke dusts.

**Group G** – Atmospheres with grain, flour, starch, combustible plastics or chemical dusts.

Class III - Locations have no group definitions.

#### **Ignition Temperature**

All electrical equipment is designed not to exceed the ignition temperature of the hazardous atmosphere. The maximum surface temperature for electric heaters is defined by the NEC.

	m Surface re of Heater	NEC Ignition Temperature
°F	°C	Ćode
842	450	T1
572	300	T2
536	280	T2A
500	260	T2B
446	230	T2C
419	215	T2D
392	200	T3
356	180	T3A
329	165	T3B
320	160	T3C

#### **Class and Zone Classifications**

**Class I, Zone 0** – Locations in which ignitable concentrations of flammable gases or vapors are present continuously or for long periods.

Class I, Zone 1 – Locations in which ignitable concentrations of flammable gases or vapors are likely to exist, may exist frequently or exist as a result of equipment breakdown or faulty operation. Applies to locations adjacent to a Class I, Zone 0 location.

Class I, Zone 2 – Locations in which ignitable concentrations of flammable gases or vapors are not likely to occur under normal operation, exist only for a short period or exist only as a result of accidental failure, such as rupture or breakdown of the container or system, abnormal operation of equipment, failure or abnormal operation of the ventilation equipment. Applies to locations adjacent to a Class I, Zone 1 location.

#### **Material Groups**

**Group IIC** – Atmospheres containing acetylene or hydrogen. Equivalent to a combination of Class I, Group A and Class I, Group B as described in NEC Article 500.

**Group IIB** – Atmospheres containing acetaldehyde. Equivalent to Class I, Group C as described in NEC Article 500.

**Group IIA** – Atmospheres containing acetone, ammonia, ethyl alcohol, gasoline, methane or propane. Equivalent to Class I, Group D as described in NEC Article 500.

# USE OF ELECTRIC HEATERS

## **In Hazardous Locations**

#### Special Requirements for Electric Heating Equipment used in Hazardous Areas

Electric heating equipment can be economically designed and safely used in hazardous areas if the following special requirements are observed.

- The surface temperature of the electric heating equipment cannot exceed the ignition temperature of the hazardous atmosphere. To insure that the proper heater has been selected, it is essential that the correct NEC Ignition Temperature Code be specified.
  - If the temperature code selected is too high, the electric heating system may operate above the ignition point of the application, creating a potentially hazardous condition.
- 2. All arc and spark-producing control devices must be isolated from the hazardous atmosphere. If it is not economically feasible to locate the control devices in the non-hazardous area, they must be housed in an enclosure that will withstand the pressure of a potential explosion from within the enclosure.
- 3. All electrical supply connections must be made according to the latest NEC and local code requirements for hazardous locations. This includes the requirement that conduit entering the enclosures must be provided with seals at the enclosure.

CLASS I — HAZARDOUS GAS ATMOSPHERES					CLAS	SS I — HAZARDOUS GAS ATMOSPHERES (cont.)				
_	Ignition Temp. NEC					Ignition		NEC		
	Material	°F	°C	Code		Material	°F	°C	Code	
<u>A</u>	Acetylene	581	305	T2	D	Methyl Isobutyl Ketone	840	448	T2	
В	Acrolein (Inhibited)	428	220	T2D		2-Methyl-1-Propanol	780	415	T2	
	Butadiene	788	420	T2		(Isobutyl Alcohol)		200	T2.4	
	Ethylene Oxide	804	429	T2	l ——	Petroleum Naptha	550	288	T2A	
	Hydrogen	932	500	T1	l ——	Pyridine	900	482	T1	
	Propylene Oxide	840	449	T2	l —	Octanes	403	206	T3	
	Propyl Nitrate	347	175	T3B	l ——	Pentanes	500	260	T2B	
C	Acetaldehyde	347	175	T3B	l ——	1-Pentanol (Amyl Alcohol)	650	343	T2	
	Allyl Alcohol	713	378	T2	l ——	Propane	842	450	T1	
	Carbon Monoxide	1128	609	T1	l ——	1-Propanol (Propyl Alcohol)	775	412	T2	
	Cyclopropane	928	498	T1	l ——	2-Propanol (Isopropyl Alcohol)	750	399	T2	
	Ethylene	842	450	T1	l ——	Propylene	851	455	T1	
	Hydrogen Cyanide	1000	538	T1	l ——	Styrene	914	490	T1	
	Hydrogen Sulfide	500	260	T2B		Toluene	896	480	T1	
	2-Nitropropane	802	428	T2	l ——	Vinyl Acetate	756	402	T2	
	Tetrahydrofuran	610	321	T2		Vinyl Chloride	882	472	T1 T1	
D	Acetic Acid (Glacia)	867	463	T1		Xylenes	867- 984	463- 528	11	
	Acetone	869	465	T1						
	Ammonia, Anhydrous	1204	651	T1	CLAS	S II — HAZARDOUS DUST AT				
	Benzene	928	498	T1	Croup	Group Material °F		Temp. °C	NEC Code	
	Butane	550	287	T2A	<u> </u>		-			
	1-Butanol (Butyl Alcohol)	650	343	T2	<u> </u>	Aluminum, A422 Flake Calcium Silicide	608 1004	320 540	T2 T1	
	2-Butanol	761	405	T2	l —	Manganese	464	240	T2C	
	(Secondary Butyl Alcohol)					Magnesium, Grade B, Milled	806	430	T2	
	Ethane	882	472	T1	F	Charcoal	356	180	T3A	
	Ethanol (Ethyl Alcohol)	685	363	T2	<u>'</u>	Coal, Kentucky Bituminous	356	180	T3A	
	Ethyl Acetate	800	427	T2		Coal, Pittsburgh Experimental	338	170	T3B	
	Ethylene Dichloride	775	413	T2		Pitch, Petroleum	1166	630	T1	
	Gasoline (56-60 Octane)	536	280	T2A	<del>G</del>	Alkyl Ketone Dimer	320	160	T3C	
	Gasoline (100 Octane)	853	456	T1		Sizing Compound	320	200	.,,	
	Heptanes	399	204	T3		Corn	482	250	T2C	
	Hexanes	437	235	T2D		Corn Starch, Modified	392	200	T3	
l	Isoprene	428	220	T2D		Polyurethane Foam,	734	390	T2	
	торгене				I	Fire Retardant				
	Isopropyl Ether	830	443	T2	l ——					
	•	900-	482-	<u>T2</u> T1		Shellac	752	400	T2	
	Isopropyl Ether Methane (Natural Gas)	900- 1170	482- 632	T1		Shellac Soy Flour	374	190	T3A	
	Isopropyl Ether Methane (Natural Gas)  Methanol (Methyl Alcohol)	900- 1170 867	482- 632 464	T1 T1		Shellac Soy Flour Sugar, Powdered	374 698	190 370	T3A T2	
	Isopropyl Ether Methane (Natural Gas)  Methanol (Methyl Alcohol) 3-Methyl-1-Butanol	900- 1170	482- 632	T1		Shellac Soy Flour Sugar, Powdered Sulfur	374 698 428	190 370 220	T3A T2 T2D	
	Isopropyl Ether Methane (Natural Gas)  Methanol (Methyl Alcohol)	900- 1170 867	482- 632 464	T1 T1		Shellac Soy Flour Sugar, Powdered	374 698	190 370	T3A T2	

The materials given are found in NFPA 497M, 1991 and NFPA 325, 1994.

**AWD - Direct Drive** 

Fan	Catalog	Mtr.	Max.	RPM	FA			CFM vs. S	tatic Pressure		
Size	Number	HP	BHP	RPIN	Sones	0.000	0.125	0.250	0.375	0.500	0.750
12	12A17D	1/6	0.10	1725	13.4	1195	829	627	558		
	16A11D	1/6	0.08	1140	8.1	1585	1022	663			
16	16A11DA	1/6	0.15	1140	11.7	1987	1292	996			
10	16A17D	1/4	0.26	1725	15.5	2398	2037	1644	1303	1079	
	16A17DB	1/2	0.61	1725	24	3007	2578	2108	1738	1592	1134
	20A11D	1/6	0.20	1140	12.2	3179	2673	1991	1379		
	20A11DA	1/4	0.37	1140	14.2	3891	3290	2306	1775	1146	
20	20A17D	1/4	0.29	1725	16.4	3010	2686	2374	2072	1755	1181
	20A17DA	1/3	0.39	1725	27	3602	3348	3121	2632	2321	
	20A17DB	1/2	0.66	1725	23	4811	4496	4160	3738	3299	
	24A11D	1/4	0.29	1140	13.8	3663	3092	2625	2028	1666	
	24A11DA	1/3	0.40	1140	15.4	4522	3962	3338	2732	2158	
24	24A11DB	1/2	0.62	1140	18.2	5969	5472	4703	3832	2958	
	24A11DC	3/4	0.74	1140	19.7	6570	6022	5168	4153	3237	
	24A11DD	1	1.10	1140	21	7185	6513	5431	4095	3519	2649
	30A8D	3/4	0.80	860	18.6	8945	8045	6816	4671	3738	
	30A8DA	1	0.93	860	20	9830	8884	7168	5030		
30	30A11D	3/4	0.83	1140	23	7822	7110	6308	5585	4709	
30	30A11DA	1	1.13	1140	25	9359	8625	7870	7074	6131	
	30A11DB	1-1/2	1.66	1140	29	11099	10413	9692	8903	7687	
	30A11DC	2	2.18	1140	32	13030	12353	11563	10283	8950	5912
	36A8D	1	1.02	860	22	11765	10629	9341	7719		
	36A8DA	1-1/2	1.59	860	25	14396	13226	11733	10363		
36	36A11D	3/4	0.84	1140	27	9641	8391	7389	6424		
30	36A11DA	1-1/2	1.56	1140	31	13151	12206	11254	10332	9295	
	36A11DB	2	2.23	1140	35	15595	14745	13873	12911	11851	
	36A11DC	3	3.43	1140	42	19084	18230	17291	16170	15085	
	42A8D	1-1/2	1.71	860	27	16900	15549	14166	12703	11019	
42	42A8DA	2	2.45	860	29	20547	19036	17452	16003	14400	
42	42A8DB	3	3.17	860	33	22430	21228	19867	18288	16700	
	42A8DC	5	4.70	860	38	27000	25540	24010	22376	20470	
	48A8D	2	2.25	860	30	21050	18978	17300	15643	13692	
48	48A8DA	3	3.38	860	35	24800	23225	21571	19852	18055	
	48A8DB	5	5.72	860	42	33680	31846	30054	28301	26445	21342

Performance shown is for Installation Type A: free inlet, free outlet. Performance ratings do not include the effects of appurtenances in the airstream. The sound ratings shown are loudness values in fan sones at 5 ft. (1.5 m) in a hemispherical free field calculated per AMCA Standard 301. Values shown are for Installation Type A: free inlet fan sone levels.



# **Propeller Wall**

Propeller Wall Fans

## INSTALLATION, OPERATION, AND MAINTENANCE MANUAL

This publication contains the installation, operation and maintenance procedures for standard units of the *Propeller Wall and X.Stream- Propeller Wall Fans*.

•APD •APB ·SPB •AWBS/AWBE •EWBSM •SPD •SWDS •EWB •XLW/XMW/XLWS/XMWS •EWD •XLP/XMP/XLPS/XMPS •EPB •XLWHS/XMWHS •EPD •XLWH/XMWH •SWD

•XLPH/XMPH •XLPHS/XMPHS

Carefully read this publication prior to any installation or maintenance procedure.

Loren Cook catalog, *Propeller Wall* and *X.Stream*, provides additional information describing the equipment, fan performance, available accessories and specification data.

For additional safety information, refer to AMCA publication 410-96, Safety Practices for Users and Installers of Industrial and Commercial Fans.

All of the publications listed above can be obtained from Loren Cook Company by phoning 417.869.6474, extension 166; by FAX at 417.832.9431; or by e-mail at info@lorencook.com.

For information and instructions on special equipment, contact Loren Cook Company at 417.869.6474.

## **Receiving and Inspection**

Carefully inspect the fan and accessories for any damage and shortage immediately upon receipt of the fan.

- Turn the propeller by hand to ensure it turns freely and does not bind
- Record on the Delivery Receipt any visible sign of damage.

#### Handling

Lift propeller wall fans by attachment to the power assembly or by the shipping carton. Never lift by the shaft, motor or housing.

#### Storage

If the fan is stored for any length of time prior to installation, coat the shaft with grease or a rust preventative compound. Store it in its original shipping crate and protect it from dust, debris and the weather.

Rotate the wheel several revolutions every three to five days to keep a coating of grease on all internal bearing parts.

#### **WARNING**

This unit has rotating parts. Safety precautions should be exercised at all times during installation, operation, and maintenance.

ALWAYS disconnect power prior to working on fan.

#### Installation

Fans mounted to a wall require a different wall opening

size than fans mounted in wall collars or wall housings. For specific dimensions, refer to the submittal drawing for the specific fan type.

#### **Motor Installation**

To prevent damage to the fan during shipping, motors 5 HP and larger, and extremely heavy motors (cast iron or severe duty) are shipped loose and must be field mounted by bolting the motor on the motor mounting plate in the existing slots.

The motor should be mounted in order that the motor plate is between the fan shaft and the motor shaft.

- a. Remove the motor plate mounting bolts and motor plate.
- b. Remove the motor mounting bolts from the motor plate.
- c. Mount the motor to the motor plate aligning the appropriate holes.
- d. Place the motor plate on the power assembly and reinstall the mounting bolts.

#### **Personal Safety**

Disconnect switches are recommended. Place the disconnect switch near the fan in order that the power can be swiftly cut off in case of an emergency, and in order that maintenance personnel are provided complete control of the power source.







Figure 1

#### **Belt and Pulley Installation**

Belt tension is determined by the sound of the belts when the fan is first started. The belts will produce a loud squeal, which dissipates after the fan is operating at full capacity. If belt tension is too tight or too loose, lost efficiency and damage can occur.

Do not change the pulley pitch diameter to change tension. The change will result in a different fan speed.

- a. Loosen the motor plate adjustment nuts on motor base and move motor plate in order that the belts can easily slip into the grooves on the pulleys. Never pry, roll, or force the belts over the rim of the pulley.
- b. Adjust the motor plate until proper tension is reached. For proper tension, a deflection of approximately 1/4" per foot of center distance should be obtained by firmly pressing the belt. Refer to Figure 1.
- c. Lock the motor plate adjustment nuts in place.
- d. Ensure pulleys are properly aligned. Refer to Figure 2.



#### **Pulley Alignment**

Pulley alignment is adjusted by loosening the motor pulley setscrew and by moving the motor pulley on the motor shaft or by moving the entire motor along the motor mounting bracket.

Figure 2 illustrates correct and incorrect pulley alignment. A recommended method of inspecting the pulley alignment is shown in Figure 3. With the shorter leg of a carpenter's square or other straight edge lying along the case of the motor, adjust the position of the motor pulley (or the motor) until the longer leg of the square is parallel to the belt.

#### Fan Installation

Insert the fan into the wall opening and secure with lag screws, anchor bolts, or other suitable fasteners.

Always mount belt drive wall fans in order that the motor base is below the fan shaft.

#### Wiring Installation

All wiring should be in accordance with local ordinances and the National Electrical Code, NFPA 70. Ensure the power supply (voltage, frequency, and current carrying capacity of wires) is in accordance with the motor nameplate. Refer to the *Wiring Diagrams*, next page.

## Lock off all power sources before unit is wired to power source.

Leave enough slack in the wiring to allow for motor movement when adjusting belt tension. Some fractional motors have to be removed in order to make the connection with the terminal box at the end of the motor.

#### **Personal Safety**

Disconnect switches are recommended. Place the disconnect switch near the fan in order that the power can be swiftly cut off in case of an emergency, and in order that maintenance personnel are provided complete control of the power source.

Follow the wiring diagram in the disconnect switch and the wiring diagram provided with the motor. Correctly label the circuit on the main power box and always identify a closed switch to promote safety (i.e., red tape over a closed switch).

#### **Wall Fans**

- a. Extend wires to the fan.
- Prevent excess wire from entering the shaft and propeller area by restraining the excess wire to a point outside the base

#### **Wall Fans with Wire Guard**

- a. Remove end panel from the wire guard to gain access to the motor.
- b. Extend wires through a side panel of the wire guard to gain access to the motor.
- c. Prevent excess wire from entering the shaft and propeller area by restraining the excess wire to a point outside the base.

#### Wall Fans with Wall Housing

- a. Remove end guard from the wall housing.
- b. Drill a hole through either side panel at a convenient location and pull the wires through. Do not pull wires through wire guard at the back panel.
- c. Restrain the incoming wire at the side panel to prevent excess wire from entering the shaft and propeller area.

#### Shutter Installation


If your fan is supplied with a shutter, follow the direction below. If your fan is not supplied with a shutter, proceed to *Final Installation Steps*.

To ensure long-life, make a weather-proof seal by using a good quality silicon caulking under the shutter flange.

- a. Place the shutter into the wall opening.
- b. Mount the shutter to the supporting surface using Num-


#### **Wiring Diagrams**

#### Single Speed, Single Phase Motor




When ground is required, attach to ground A or B with no. 6 thread forming screw. To reverse, interchange T-1 and T-4.

#### 2 Speed, 2 Winding, Single Phase Motor




When ground required, attach to ground A or B with No. 6 thread forming screw. To reverse, interchange T-1 and T-4 leads.

#### Single Speed, Single Phase, Dual Voltage



When ground required, attach to ground A or B with No. 6 thread forming screw. To reverse, interchange T-5 and J-10 leads.

#### **Typical Damper Motor Schematic**



- b. Mount the shutter to the supporting surface using Number 12 sheet metal screws on six inch centers around the perimeter.
- c. Manually operate the shutter to ensure the blades move freely.

## **Typical Installation**

Refer to page 5.

#### Final Installation Steps

- a. Inspect fasteners and setscrews, particularly fan mounting and bearing fasteners, and tighten according to the recommended torque shown in the table on page 4, Recommended Torque for Setscrews/Bolts.
- b. Inspect for correct voltage with voltmeter.
- c. Ensure all accessories are installed.
- d. Test the fan to be sure the rotation is the same as indicated by the arrow marked **Rotation**.

#### Wiring Diagrams

#### 3 Phase, 9 Lead Motor

## 3 Phase, 9 Lead Motor Y-Connection


Low Voltage 208/230 Volts	High Voltage 460 Volts	Low Voltage 208/230 Volts	High Voltage 460 Volts
o_o_o 4 5 6	4 5 6 0 8 9 7 8 9	97 98 99 96 94 95 91 92 93	7 8 9 8 8 8 4 5 6
1 0 2 0 3 0 7 1 8 1 9 1 L <sub>1</sub> L <sub>2</sub> L <sub>3</sub>	1 02 0 30 L <sub>1</sub> L <sub>2</sub> L <sub>3</sub>	$L_1$ $L_2$ $L_3$	1 02 0 30 L <sub>1</sub> L <sub>2</sub> L <sub>3</sub>

To reverse, interchange any 2 line leads.

3 Phase, 9 Lead Motor


Delta-Connection

#### 2 Speed, 1 Winding, 3 Phase Motor



To reverse, interchange any 2 line leads. Motors require magnetic control.

#### 2 Speed, 2 Winding, 3 Phase



To reverse: High Speed-interchange leads  $T_{11}$  and  $T_{12}$ . Low Speed-interchange leads  $T_1$  and  $T_2$ . Both Speeds-interchange any 2 line leads.

For 3 phase, damper motor voltage should be the same between  $\rm L_1$  and  $\rm L_2$ . For single phase application, disregard  $\rm L_3$ . \*Damper motors may be available in 115, 230 and 460 volt models. The damper motor nameplate voltage should be verified prior to connection. \*\*A transformer may be provided in some installations to correct the damper motor voltage to the specified voltage.

Do not allow the fan to run in the wrong direction. This will overheat the motor and cause serious damage. For 3-phase motors, if the fan is running in the wrong direction, check the control switch. It is possible to interchange two leads at this location so that the fan is operating in the correct direction.

#### Operation

#### **Pre-Start Checks**

- a. Lock out all the primary and secondary power sources.
- b. Inspect fasteners and setscrews, particularly those used for mounting the unit, and tighten if necessary.
- c. Inspect belt tension and pulley alignment. (Remember, if belt tension is correct, a loud squeal occurs as the fan increases to full power.)
- d. Inspect motor wiring.
- e. Ensure the belt touches only the pulleys.
- Rotate the prop to ensure it does not rub against the venturi.

- g. Ensure fan and ductwork are clean and free of debris.
- h. Test the fan to ensure the rotation of the propeller is the same as indicated by the rotation label.
- i. Close and secure all access doors.
- j. Restore power to unit.

#### Start Up

Turn the fan on. In variable speed units, set the fan to its lowest speed. Inspect for the following:

- Direction of rotation.
- · Excessive vibration.
- Unusual noise.
- · Bearing noise.
- Improper belt alignment or tension (listen for a continuous squealing noise).
- Improper motor amperage or voltage.

If a problem is discovered, immediately shut off the fan. Lock out all electrical power and check for the cause of the trouble. Refer to *Troubleshooting*, page 7.

#### Recommended Torque for Setscrews/Bolts (IN/LB.)

	S	etscrews				
Size	Key Hex		nded Torque n-lbs.	Hold Down Bolts		
Size	Across Flats	Min.	Max.	Size	Wrench Torque (inch-lbs)	
No.10	3/32"	28	33	3/8"-16	240	
1/4"	1/8"	66	80	1/2"-13	600	
5/16"	5/32"	126	156	5/8"-11	1200	
3/8"	3/16"	228	275	3/4"-10	2100	
7/16"	7/32"	348	384	7/8"-9	2040	
1/2"	1/4"	504	600	1"-8	3000	
5/8"	5/16"	1104	1200	1-1/8"-7	4200	
3/4"	3/8"	1440	1800	1-1/4"-7	6000	

#### Inspection

Inspection of the fan should be conducted at the first **30 minute**, **8 hour** and **24 hour** intervals of satisfactory operation. During the inspections, stop the fan and inspect as per directions below.

#### 30 Minute Interval

Inspect bolts, setscrews, and motor mounting bolts. Adjust and tighten as necessary.

#### 8 Hour Interval

Inspect belt alignment and tension. Adjust and tighten as necessary.

#### 24 Hour Interval

Inspect belt tension. Adjust and tighten as necessary.

#### Maintenance

Establish a schedule for inspecting all parts of the fan. The frequency of inspection depends on the operating conditions and location of the fan.

Inspect fans exhausting corrosive or contaminated air within the first month of operation. Fans exhausting contaminated air (airborne abrasives) should be inspected every three months. Clean the propeller and air inlets if material build-up is excessive. Excessive build-up can cause imbalance and failure of the propeller.

Regular inspections are recommended for fans exhausting non-contaminated air.

It is recommended the following inspections be conducted twice per year.

Inspect bolts and setscrews for tightness. Tighten as necessary.

- Inspect belt wear and alignment. Replace worn belts with new belts and adjust alignment as needed. See *Belt and Pulley Installation*, on page 2.
- Bearings should be inspected as recommended in the *Conditions Chart*. below.
- Inspect for cleanliness. Clean exterior surfaces only.
   Removing dust and grease on motor housing assures proper motor cooling.

#### Lubricants

Loren Cook Company uses petroleum lubricant in a lithium base conforming to NLGI grade 2 consistency. Other grades of grease should not be used unless the bearings and lines have been flushed clean. If another grade of grease is used, it should be lithium-based.

A NLGI grade 2 grease is a light viscosity, low-torque, rust-inhibiting lubricant that is water resistant. Its temperature range is from -30°F to +200°F and capable of intermittent highs of +250°F.

#### **Motor Bearings**

Motor bearings are pre-lubricated and sealed. Under normal conditions they will not require further maintenance for a period of ten years. However, it is advisable to have your maintenance department remove and disassemble the motor, and lubricate the bearings after three years of operation in excessive heat and or in a contaminated airstream consisting of airborne abrasives.

Conditions Chart								
RPM	Temperature	Fan Status	<b>Greasing Interval</b>					
Up to 100	Up to 120°F	Clean	6 to 12 months					
Up to 500	Up to 150°F	Clean	2 to 6 months					
Up to 1000	Up to 210°F	Clean	2 weeks to 2 months					
Up to 1500	Over 210°F	Clean	Weekly					
Any Speed	Up to 150°F	Dirty	1 week to 1 month					
Any Speed	Over 150°F	Dirty	Daily to 2 weeks					
	Any Temperature		Daily to 2 weeks					
Any Speed	Any Temperature	Extreme Conditions	Daily to 2 weeks					

#### Fan Bearings

Greasable fan bearings are lubricated through a grease connector and should be lubricated by the schedule, *Conditions Chart*, on page 4.

For best results, lubricate the bearing while the fan is rotating. Slowly pump grease into the bearing until a slight bead forms around the bearing seals. Excessive grease can burst seals thus reduce bearing life.

In the event the bearing cannot be seen, use no more than three injections with a hand-operated grease gun.

#### **Motor Services**

Should the motor prove defective within a one-year period, contact your local Loren Cook representative or your nearest authorized electric motor service representative.

#### **Changing Shaft Speed**

All belt driven Propeller Wall fans with motors up to and including 5HP are equipped with variable pitch pulleys. To change the fan speed, perform the following:

a. Loosen setscrew on driver (motor) pulley and remove key, if equipped.

## **Typical Installations**

# C WO D 1-1/2 A 1-1/2 Fan support and flashing by others.

#### Exhaust wall fan with OSHA wire guard and shutter

Illustrated is the typical installation of an exhaust wall fan with an OSHA wire guard and shutter in a steel structure with corrugated siding. The installer will provide a sleeve of suitable material to support the fan at a correct distance from the shutter (minimum distance is the "A" dimension).

AWB, AWD	XLW, XLWH	EWB	Α	В	С	D	Е	W	NO	
SWD	XMW, XMWH	EWD	^				_	Std. Fan	Wire Gd.	
8		-	11	13	12-3/4	10	1	12-1/2	13-1/4	
10-12	-	-	12	13	16-3/4	14	1	16-7/16	17-1/4	
14-16	-	-	12	13	20-3/4	18	1	20-7/16	21-1/4	
18-20	-	-	13	12	24-3/4	22	1	24-7/16	25-1/4	
-	20	-	13	21	24-3/4	22	1	24-7/16	25-1/4	
24		-	15	21	30-3/4	27	1-1/2	30-7/16	31-1/4	
-	24	-	15	13	30-3/4	27	1-1/2	30-7/16	31-1/4	
30	30	24	16	21	36-3/4	33	1-1/2	36-7/16	37-1/4	
36	36	30	16	21	42-3/4	39	1-1/2	42-7/16	43-1/4	
42	42	36	17	26	48-7/8	45	1-1/2	48-7/16	49-1/4	
48	48	42	17	26	54-7/8	51	1-1/2	54-7/16	55-5/16	
-	54	48	17	28	60-7/8	57	1-1/2	60-7/16	61-5/16	
-	60	54	17	28	66-7/8	63	1-1/2	66-7/16	67-1/2	
-	1	60	17	28	72-7/8	69	1-1/2	72-7/16	73-1/2	
-	-	72	17	31	84-7/8	81	1-1/2	84-7/16	85-1/2	

#### **Exhaust Pac-Fan with shutter guard**

Illustrated is the typical installation of an exhaust PAC-Fan in a masonry wall with a shutter guard. The installer provides suitable fasteners (Hex bolts or Lag screws) to support the fan. It is recommended that 5/16" minimum bolts on 6" to 10" centers be used on the perimeter of the housing. Mounting flange should be caulked to exterior of the wall. Fans with motors in excess of 80 lbs. should be additionally supported by hanging rods or supports placed underneath the fan.


APB, APD, SPD	XLP, XLPH, XMP, XMPH	EPB, EPD	Α	B- Direct	B-Belt	WO
8	-	-	10-5/8	13-5/8	-	13-1/4
10-12	-	-	14-5/8	17-5/8	-	17-1/4
14-16	-	-	18-5/8	20	-	21-1/4
18-20	20	-	22-5/8	22	34-1/4	25-1/4
24	24	-	27-7/8	23	34-1/4	31-1/4
30	30	24	33-7/8	24-3/8	37-7/8	37-1/4
36	36	30	39-7/8	28-3/8	39-3/8	43-1/4
42	42	36	45-7/8	33-5/8	40-5/8	49-1/4
48	48	42	51-7/8	39-5/8	50-5/8	55-5/16
-	54	48	57-7/8	40-1/8	47-3/4	61-5/16
-	60	54	63-7/8	44-3/4	47-3/4	67-1/2
-	-	60	69-7/8	-	47-3/4	73-1/2
-	-	72	81-7/8	-	50-3/4	85-1/2

# WO A A

# Supply wall fan with wall collar, OSHA wire guard, motorized supply shutter and weather hood

Illustrated is the typical installation of a supply wall fan in a masonry wall with a wall collar, OSHA wire guard, motorized supply shutter and weather hood. The installer provides suitable fasteners to support the fan. Fasteners should be placed on 6" to 10 centers on the perimeter of the wall collar. Wall collar should be caulked to the exterior of the wall. The weather hood should be securely fastened and sealed to the wall. Fans with motors in excess of 80 lbs. should be additionally supported by hanging rods or supports placed underneath the fan.

AWB, AWD, SWD	XLW, XLWH XMW, XMWH	EWB, EWD	Α	В	С	D	E	WO
8	-	-	18	16	12	13	1	13-1/4
10-12	-	-	22	18-3/4	14-3/8	13	1	17-1/4
14-16	-	-	26	21-3/4	15-3/8	13	1	21-1/4
18-20	-	-	30	24-1/2	17-5/8	13	1	25-1/4
-	20	-	30	24-1/2	17-5/8	21	1	25-1/4
24	-	-	30	24-1/2	17-5/8	13	1-1/2	31-1/4
-	24	-	34	27-1/4	18-3/4	21	1-1/2	31-1/4
30	30	24	40	31-1/2	18-3/4	21	1-1/2	37-1/4
36	36	30	46	35-3/4	19-1/2	21	1-1/2	43-1/4
42	42	36	52	40	19-1/2	26	1-1/2	49-1/4
48	48	42	58	44-1/4	19-3/4	26	1-1/2	55-5/16
-	54	48	64	48-1/2	19-3/4	28	1-1/2	61-5/16
-	60	54	70	52-3/4	19-3/4	28	1-1/2	67-1/2
-	-	60	76	57	19-3/4	28	1-1/2	73-1/2
-	-	72	88	67-1/2	19-3/4	31	1-1/2	85-1/2



#### **Changing Shaft Speed** continued

- b. Turn the pulley rim to open or close the groove facing. If the pulley has multiple grooves, all must be adjusted to the same width.
- c. After adjustment, inspect for proper belt tension.

#### **Speed Reduction**

Open the pulley in order that the belt rides deeper in the groove (smaller pitch diameter).

#### **Speed Increase**

Close the pulley in order that the belt rides higher in the groove (larger pitch diameter). Ensure that the RPM limits of the fan and the horsepower limits of the motor are maintained.

# Pulley and Belt Replacement Maximum RPM

-									
SWD Size	Maximum RPM	EWB Size	Maximum RPM	AWB Size	Maximum RPM				
8	1690	24	1675	24	1510				
10	1550	30	1370	30	1145				
12	1615	36	1310	36	990				
14	1130	42	1175	42	905				
16	1115	48	1215	48	900				
18	1095	54	960	-	-				
20	1075	60	890	-	-				
24	1050	72	700	-	-				

#### **Maximum RPM**

APB Size	Maximum RPM	XLP/XLPS Size	Maximum RPM	XLPH/XLPHS Size	Maximum RPM
24	1005	20	1280	-	-
30	800	24	1012	24	1110
36	645	30	666	30	930
42	660	36	566	36	714
48	605	42	424	42	610
-	-	48	356	48	512
-	-	54	316	54	472
-	-	60	260	60	446

#### **Maximum RPM**

XMP/XMPS Size	Maximum RPM	XMPH/ XMPHS Size	Maximum RPM	XLW/ XLWS Size	Maximum RPM			
20	1280	-	-	20	1276			
24	1276	24	1410	24	1018			
30	830	30	1172	30	674			
36	680	36	838	36	570			
42	498	42	716	42	422			
48	414	48	596	48	356			
54	346	54	516	54	320			
60	318	60	474	60	256			

#### Maximum RPM

XLWH/ XLWHS Size	Maximum RPM	XMW/ XMWHS Size	Maximum RPM	XMWH/ XMWHS Size	Maximum RPM
-	-	20	1462	-	-
24	1126	24	1272	24	1400
30	932	30	860	30	1184
36	720	36	672	36	864
42	610	42	498	42	718
48	516	48	416	48	600
54	478	54	350	54	522
60	438	60	320	60	476

- a. Clean the motor and fan shafts.
- b. Loosen the motor plate mounting bolts to relieve the belt tension. Remove the belt.
- c. Loosen the pulley setscrews and remove the pulleys from the shaft.

If excessive force is required to remove the pulleys, a three-jaw puller can be used. This tool, however, can easily warp a pulley. If the puller is used, inspect the trueness of the pulley after it is removed from the shaft. The pulley will need replacement if it is more than 0.020

- inch out of true.
- d. Clean the bores of the pulleys and place a light coat of oil on the bores.
- e. Remove grease, rust and burrs from the shaft.
- f. Place fan pulley on the fan shaft and the motor pulley on the motor shaft. Damage to the pulleys can occur when excessive force is used in placing the pulleys on their respective shafts.
- g. After the pulleys have been correctly placed back onto their shafts, tighten the pulley setscrews.
- h. Install the belts on the pulleys. Align and adjust the belts to the proper tension as described in *Belt and Pulley Installation*, page 2.

#### **Bearing Replacement**

The fan bearings are pillow block ball bearings.

- a. Mark the position of the shaft in reference to both the bearing races and the propeller and pulley. Make a note of the clearance between the propeller and the frame.
- b. Remove the pulley.
- c. Remove the propeller from the shaft. A two-jaw puller may be needed to remove the propeller from the shaft
- d. Remove the bearing hold-down bolts. Remove the shaft and the bearings as one unit.
- e. Remove the anti-corrosion coating from the shaft with a suitable degreaser.
- f. Remove the bearing from the shaft using a bearing puller. If a bearing puller is not available, remove the bearing by using a wood block and hammer. An emery cloth or file may be needed to remove imperfections in the shaft left by the setscrews.
- g. Clean the shaft and bearing bore thoroughly.
- h. Place the bearings into position ensuring they are not on a worn section of the shaft. Tapping the inner ring face with a soft driver may be required. Do not hammer on the housing.
- i. The outer ring of the bearing is spherical and swivels in the housing to compensate for misalignment.
   Slightly tighten the hold down bolts.
- j. Align the setscrews on the bearings and tighten one setscrew on each bearing.
- k. Rotate the shaft to allow the bearing outer rings to find the center of free movement.
- I. Install the propeller on the shaft and adjust the bearing position to center the propeller in the opening.
- m. Tighten the hold-down bolts to the proper torque. Refer to the *Torque Chart*, page 4.
- n. Turn the shaft by hand. Resistance should be the same as it was before the hold-down bolts were fully tightened.
- o. Tighten the bearing setscrews to the specified torque.
- p. Install the pulley and adjust the belt tension.

After 24 hours of continuous operation, tighten the setscrews to the appropriate torque. This assures the full locking of the inner race to the shaft. Ensure the socket key or driver is in good condition with no rounded corners. The key should be fully engaged in the setscrew and held squarely to prevent the rounding out of the setscrew socket when applying maximum torque.

## **Troubleshooting**

#### **Problem and Potential Cause**

#### Low Capacity or Pressure

- •Incorrect direction of rotation. Make sure the fan rotates in same direction as the arrows on the motor or belt drive assembly.
- •Poor fan inlet conditions. There should be a straight clear duct at the inlet.
- •Improper propeller alignment.

#### **Excessive Vibration and Noise**

- •Damaged or unbalanced propeller.
- •Belts too loose; worn or oily belts.
- ·Speed too high.
- •Incorrect direction of rotation. Make sure the fan rotates in same direction as the arrows on the motor or belt drive assembly.
- •Bearings need lubrication or replacement.
- •Fan surge.


#### Overheated Motor

- ·Motor improperly wired.
- •Incorrect direction of rotation. Make sure the fan rotates in same direction as the arrows on the motor or belt drive assembly.
- •Cooling air diverted or blocked.

#### **Overheated Bearings**


- •Improper bearing lubrication
- ·Excessive belt tension.

#### **APD Parts List**




Parts	Description	Parts	Description		
No.	APD Sizes 16-36	No.	APD Sizes 16-36		
1	Power Assembly	6	Anchor Angles (2)		
2	Propeller	7	Fan Box Panel (4)		
3	Shutter Assembly	8	End Wire Guard		
4	Mounting Collar Angles (4)	9	Motor Plate		
5	Wall Base	10	Motor		


## **APB Parts List**



Parts No.	Description	Parts	Description
	APB Sizes 24-48	No.	APB Sizes 24-48
1	Bearings (2)	9	Motor Plate
2	Power Assembly	10	Motor
3	Propeller	11	Fan Box Panel (4)
4	Shutter Assembly	12	End Wire Guard
5	Mounting Collar Angles (4)	13	Driver Sheave
6	Wall Base	14	Belt Set
7	Anchor Angles (2)	15	Driven Sheave
8	Shaft		


## **AWDS and AWDE Parts List**







Parts	Description	
No.	AWDS	AWDE
1	Supply Venturi	_
2	Motor	Motor
3	Motor Plate	Motor Plate
4	Optional Wire Guard	Birdscreen
5	Wall Base	Wall Base
6	Cast Aluminum Propeller	Cast Aluminum Propeller
7	Power Assembly	Power Assembly

## **AWBS and AWBE Parts List**





## **EPD Parts List**






**EPB Parts List** 






Supply








Part	Description	
No.	AWBS	AWBE
1	Driven Sheave	Driven Sheave
2	Bearings (2)	Bearings (2)
3	Power Assembly	Power Assembly
4	Supply Venturi	_
5	Propeller	Propeller
6	Shaft	Shaft
7	Motor Plate	Motor Plate
8	Motor	Motor
9	Belt Set	Belt Set
10	Optional Wire Guard	Birdscreen
11	Driver Sheave	Driver Sheave
12	Wall Base	Wall Base

Part	Description
No.	EPD
1	Power Assembly
2	Supplemental Venturi
3	Shutter Assembly
4	Mounting Collar Angles (4)
5	Anchor Angles (2)
6	Wall Base
7	Fan Box Panel (4)
8	End Wire Guard
9	Motor Plate
10	Motor
11	Wall Base
	Propeller (Not Shown)

Part	Description
No.	EPB
1	Bearings (2)
2	Power Assembly
3	Wall Base
4	Propeller
5	Shutter Assembly
6	Mounting Collar Angles (4)
7	Supplemental Venturi
8	Anchor Angles (2)
9	Shaft
10	Motor Plate
11	Motor
12	Fan Box Panel (4)
13	End Wire Guard
14	Driver Sheave
15	Belt Set
16	Driven Sheave


Part	Description
No.	EWD
1	Propeller
2	Motor
3	Power Assembly
4	Supplemental Venturi
5	Motor Plate
6	Optional Wire Guard
7	Wall Base

## **EWB Parts List**




Part	Description
No.	EWB
1	Bearings (2)
2	Wall Base
3	Supply Venturi
4	Steel Propeller
5	Shaft
6	Motor Plate
7	Power Assembly
8	Motor
9	Optional Wire Guard
10	Driver Sheave
11	Belt Set
12	Driven Sheave

## 36-60 Wall Propeller Weather Hood Parts List




Part	Description
No.	36-60 Wall Prop
1	Top Panel, Piece 1
2	Top Panel, Piece 2
3	Right Side Panel
4	Left Side Panel
5	Bottom Panel
6	Bird Screen Support
7	1/2" Mesh Galvanized Bird Screen
8	1/4" X 1/2" Speed Screw
9	5/16 SAE Steel Washer

## 8-30 Wall Propeller Weather Hood Parts List





Part	Description
No.	8-30 Wall Prop
1	Top Panel
2	Right Side Panel
3	Left Side Panel
4	Bottom Panel
5	1/2" Mesh Galvanized Bird Screen
6	1/4" X 1/2" Speed Screw
7	5/16 SAE Steel Washer


## 72 EWB Weather Hood Parts List



## **SPD Parts List**







2

SWDS Parts List	
	5 4 6


Part	Description
No.	72 EWB
1	Top Panel, Piece 1
2	Top Panel, Piece 2
3	Right Side Panel Tip
4	Right Side Panel
5	Left Side Panel Tip
6	Left Side Panel
7	Bottom Panel
8	Bird Screen Support
9	1/2" Mesh Galvanized Bird Screen
10	1/4" X 1/2" Speed Screw
11	5/16 SAE Steel Washer

Part No.	Description
	SPD
1	Fan Box Panel (4)
2	Stamped Aluminum Propeller
3	Anchor Angle (4)
4	Mounting Collar Angle (2)
5	Automatic Louver
6	Wall Base
7	Mounting Grille
8	Motor
9	Mesh Guard

Part	Description
No.	SWD
1	Wire Guard
2	Wall Base
3	Stamped Aluminum Propeller
4	Motor


Part	Description
No.	SWDS
1	Stamped Aluminum Propeller
2	Wall Base
3	Wire Guard
4	Motor
5	End Wire Guard
6	Wall Collar

## XLW, XMW, XLWS, XMWS 20 - 36 Parts List




Part No.	Description	Part No.	Description
1	Wall Venturi Base	8	Motor
2	Prop Assembly	9	Optional Wire Guard
3	Power Assembly Foot (3)	10	Drive Sheave
4	Bearings (2)	11	Belt Set
5	Inlet Venturi (Supply only)	12	Driven Sheave
6	Fan Shaft	13	Power Assembly Rail
7	Motor/Bearing Plate		

## XLW, XMW, XLWS, XMWS 42 - 60 Parts List




Part No.	Description	Part No.	Description
1	Wall Venturi Base	8	Motor/Bearing Plate
2	Prop Assembly	9	Optional Wire Guard
3	Power Assembly Foot (2)	10	Motor
4	Power Assembly Rail (2)	11	Motor Plate Brace
5	Fan Shaft	12	Drive Sheave
6	Bearings (2)	13	Belt Set
7	Inlet Venturi (Supply Only)	14	Driven Sheave

## XLP, XMP, XLPS, XMPS 20 -36 Parts List




Part No.	Description	Part No.	Description
1	Wall Venturi Base	9	Motor/Bearing Plate
2	Prop Assembly	10	Housing Wrapper Panel (4)
3	Bearings (2)	11	End Safety Guard
4	Fan Shaft	12	Motor
5	Exhaust Shutter (Exhaust Only) Supply Shutter (Supply Only)	13	Drive Sheave
5		14	Belt Set
6	Mounting Collar Angle (4)	15	Driven Sheave
7	Inlet Venturi (Supply Only)	16	Power Assembly Rail
8	Wall Mounting Angle (2)	17	Power Assembly Foot (3)

## XLP, XMP, XLPS, XMPS 42 - 60 Parts List




Part No.	Description	Part No.	Description
1	Wall Venturi Base	10	Wall Mounting Angle (2)
2	Prop Assembly	11	Motor/Bearing Plate
3	Power Assembly Foot (2)	12	Housing Wrapper Panel (4)
4	Power Assembly Rail (2)	13	End Safety Guard
5	Bearings (2)	14	Motor
6	Fan Shaft	15	Motor Plate Brace
7	Inlet Venturi (Supply Only)	16	Drive Sheave
	Exhaust Shutter (Exhaust Only)	17	Belt Set
	Supply Shutter (Supply Only)	18	Driven Sheave
9	Mounting Collar Angle (4)		

## XLWHS, XMWHS, XLWH, XMWH 24 - 60 Parts List



Part No.	Description	Part No.	Description
1	Wall Venturi Base	7	Motor
2	Power Assembly	8	Optional Wire Guard
3	Prop Assembly	9	Motor Plate
4	Bearings (2)	10	Drive Sheave
5	Fan Shaft	11	Belt Set
6	Inlet Venturi (Supply Only)	12	Driven Sheave

## XLPH, XMPH, XLPHS, XMPHS 24 - 60 Parts List



Part No.	Description	Part No.	Description
1	Wall Venturi Base	9	Wall Mounting Angle (2)
2	Power Assembly	10	Motor
3	Prop Assembly	11	Housing Wrapper Panel
4	Bearings	12	End Safety Guard
5	Fan Shaft	13	Motor Plate
6	Exhaust Shutter (Exhaust Only) Supply Shutter (Supply Only)	14	Drive Sheave
		15	Belt Set
7	Mounting Collar Angle (4)	16	Driven Sheave
8	Inlet Venturi (Supply Only)		

#### Limited Warranty

Loren Cook Company warrants that your Loren Cook fan was manufactured free of defects in materials and workmanship, to the extent stated herein. For a period of one (1) year after date of shipment, we will replace any parts found to be defective without charge, except for shipping costs which will be paid by you. This warranty is granted only to the original purchaser placing the fan in service. This warranty is void if the fan or any part thereof has been altered or modified from its original design or has been abused, misused, damaged or is in worn condition or if the fan has been used other than for the uses described in the company manual. This warranty does not cover defects resulting from normal wear and tear. To make a warranty claim, notify Loren Cook Company, General Offices, 2015 East Dale Street, Springfield, Missouri 65803-4637, explaining in writing, in detail, your complaint and referring to the specific model and serial numbers of your fan. Upon receipt by Loren Cook Company of your written complaint, you will be notified, within thirty (30) days of our receipt of your complaint, in writing, as to the manner in which your claim will be handled. If you are entitled to warranty relief, a warranty adjustment will be completed within sixty (60) business days of the receipt of your written complaint by Loren Cook Company. This warranty gives only the original purchaser placing the fan in service specifically the right. You may have other legal rights which vary from state to state.

## LOREN COOK COMPANY

Corporate Offices: 2015 E. Dale Street Springfield, MO 65803 417.869.6474 lorencook.com





#### Shutter, Wall, 12 In

Exhaust Shutter, Gravity Operated, Single Panel, Fits Fan Dia 12 In, Overall Square 15 In, Opening Required 12 1/2 x 12 1/2 In, Frame Depth 2 1/2 In, Open Depth 5 3/4 In, Flange Width 1 1/2 In, Free Area 0.786 Square-Ft, Max Velocity 2500 FPM, Vertical Mounting Position, Blade Material White Painted Aluminum, Extruded Aluminum Frame and G-90 Glavanized Tie Rod, For Use With Vertical Mounted Exhaust Fans

Grainger Item #	4C556
Price (ea.)	\$37.50
Brand	DAYTON
Mfr. Model #	4C556
Ship Qty.	1
Sell Qty. (Will-Call)	1
Ship Weight (lbs.)	4.0
Usually Ships	Today
Catalog Page No.	3915

Price shown may not reflect your price. Log in or register.

#### Additional Info

#### Single- and Double-Panel Exhaust Shutters

Efficient shutters for direct- or belt-driven exhaust fans are designed to prevent air backflow when the fan is off.

Counterbalanced louvers with felted edges (except fiberglass models) open easily and seal quietly. Units with 54" and 60" galvanized and aluminum shutters have 4 additional tie rods on the discharge side for smooth, quiet operation.

- Exhaust only
- Mount: vertical
- Max. velocity: 2500 FPM
- 1 1/2" flange

#### Aluminum Frame

For areas where corrosion may be a problem.

Aluminum louvers have white enamel finish, galvanized steel reinforcement strip, and stainless steel rivets. 16-ga. extruded aluminum frame. Frame depth: 2 1/2" for 10 to 24" models, 3" for models 30" and up.

#### Tech Specs

Item: Exhaust Shutter

Type: Gravity Operated, Single Panel

Fits Fan Dia. (In.): 12 Overall Square (In.): 15

Opening Required (In.): 12 1/2 x 12 1/2 Frame Depth (In.): 2 1/2

Open Depth (In.): 5 3/4 Flange Width (In.): 1 1/2

Mounting Hole Size (In.): 9/32 x 1/2 Free Area (Square-Ft.): 0.786 Max. Velocity (FPM): 2500 Mounting Position: Vertical Blade Material: White Painted Aluminum

Construction Material: Extruded Aluminum Frame

and G-90 Galvanized Tie Rod

For Use With: Vertical Mounted Exhaust Fans

#### Notes & Restrictions

There are currently no notes or restrictions for this item.

#### MSDS

This item does not require a Material Safety Data Sheet (MSDS).

#### Required Accessories

There are currently no required accessories for

#### **Optional Accessories**



Item #: 2C831 Brand: DAYTON Usually Ships: Today Price (ea): \$89.80

Shutter Motor



Item #: 2FTW3 Brand: DAYTON

Usually Ships: Today Price (ea): \$25.30

#### Alternate Products

#### Fan Shutter, 12 1/2 In



Item #: 1C742 Brand: DAYTON Usually Ships: Today Price (ea): \$34.05

#### Fan Shutter, 12 In, Beige Fiberglass



Item #: 5C211 Brand: DAYTON Usually Ships: Today Price (ea): \$62.65

#### Repair Parts

A Repair Part may be available for this item. Visit our Repair Parts Center or contact your local branch for more information.





#### Shutter, Wall, 16 In

Exhaust Shutter, Gravity Operated, Single Panel, Fits Fan Dia 16 In, Overall Square 19 In, Opening Required 16 In /2 x 16 I/2 In, Frame Depth 2 1/2 In, Open Depth 2 1/2 In, Open Depth 5 3/4 In, Flange Width 1 1/2 In, Free Area 1.436 Square-Ft, Max Velocity 2500 FPM, Vertical Mounting Position, Blade Material White Painted Aluminum, Extruded Aluminum Frame and 6-90 Glavanized Tie Rod, For Use With Vertical Mounted Exhaust Fans

Grainger Item #	4C557
Price (ea.)	\$46.75
Brand	DAYTON
Mfr. Model #	4C557
Ship Qty.	1
Sell Qty. (Will-Call)	1
Ship Weight (lbs.)	4.4
Usually Ships	Today
Catalog Page No.	3915

Price shown may not reflect your price. Log in or register

#### Additional Info

#### Single- and Double-Panel Exhaust Shutters

Efficient shutters for direct- or belt-driven exhaust fans are designed to prevent air backflow when the fan is off

Counterbalanced louvers with felted edges (except fiberglass models) open easily and seal quietly. Units with 54" and 60" galvanized and aluminum shutters have 4 additional tie rods on the discharge side for smooth, quiet operation.

- Exhaust only
- Mount: vertical
- Max. velocity: 2500 FPM
- 1 1/2" flange

#### **Aluminum Frame**

For areas where corrosion may be a problem.

Aluminum louvers have white enamel finish, galvanized steel reinforcement strip, and stainless steel rivets. 16-ga. extruded aluminum frame. Frame depth: 2 1/2" for 10 to 24" models, 3" for models 30" and un

#### Tech Specs

Item: Exhaust Shutter

Type: Gravity Operated, Single Panel

Fits Fan Dia. (In.): 16

Overall Square (In.): 19
Opening Required (In.): 16 1/2 x 16 1/2

Frame Depth (In.): 2 1/2 Open Depth (In.): 5 3/4

Flange Width (In.): 1 1/2 Mounting Hole Size (In.): 9/32 x 1/2

Free Area (Square-Ft.): 1.436
Max. Velocity (FPM): 2500
Mounting Position: Vertical

Blade Material: White Painted Aluminum

Construction Material: Extruded Aluminum Frame and G-90 Galvanized Tie Rod

and G-90 Galvanized Tie Rod

For Use With: Vertical Mounted Exhaust Fans

#### Notes & Restrictions

There are currently no notes or restrictions for this item.

#### MSDS

This item does not require a Material Safety Data Sheet (MSDS).

#### Required Accessories

There are currently no required accessories for this item.

#### Optional Accessories

# 1

Item #: 2C831 Brand: DAYTON Usually Ships: Today

Shutter Motor

Price (ea): \$89.80

Shutters

Pull Chain Kit, Single Pannel



Item #: 2FTW3
Brand: DAYTON
Usually Ships: Today
Price (ea): \$25.30

#### Alternate Products





Item #: 1C743 Brand: DAYTON Usually Ships: Today Price (ea): \$42.45

Fan Shutter, 16 In, Beige Fiberglass



Item #: 5C212 Brand: DAYTON Usually Ships: Today Price (ea): \$82.10

Exh Shutter, Fits Fan Dia 16 In,



Item #: 4FZH4

Brand: DAYTON

Usually Ships: 1-3 Days

Price (ea): \$65.45

#### Repair Parts

A Repair Part may be available for this item. Visit our Repair Parts Center or contact your local branch for more information.





#### Shutter, Wall, 18 In

Exhaust Shutter, Gravity Operated, Single Panel, Fits Fan Dia 18 In, Overall Square 21 In, Opening Required 18 1/2 x 18 1/2 In, Frame Depth 2 1/2 In, Open Depth 5 3/4 In, Flange Width 1 1/2 In, Free Area 2.043 Square-Ft, Max Velocity 2500 FPM, Vertical Mounting Position, Blade Material White Painted Aluminum, Extruded Aluminum Frame and G-90 Glavanized Tie Rod, For Use With Vertical Mounted Exhaust Fans

Grainger Item #	4C558
Price (ea.)	\$52.75
Brand	DAYTON
Mfr. Model #	4C558
Ship Qty.	1
Sell Qty. (Will-Call)	1
Ship Weight (lbs.)	5.35
Usually Ships	Today
Catalog Page No.	3915

Price shown may not reflect your price. Log in or register.

#### Additional Info

- Single- and Double-Panel Exhaust Shutters
- Efficient shutters for direct- or belt-driven exhaust fans are designed to prevent air backflow when the fan is off.
- Counterbalanced louvers with felted edges (except fiberglass models) open easily and seal quietly. Units with 54" and 60" galvanized and aluminum shutters have 4 additional tie rods on the discharge side for smooth, quiet operation.
- Exhaust only
- Mount: vertical
- Max. velocity: 2500 FPM
- 1 1/2" flange
- Aluminum Frame
- For areas where corrosion may be a problem.
- Aluminum louvers have white enamel finish, galvanized steel reinforcement strip, and stainless steel rivets. 16-ga. extruded aluminum frame. Frame depth: 2 1/2" for 10 to 24" models, 3" for models 30" and up.

#### Tech Specs

Type: Gravity Operated, Single Panel

Fits Fan Dia. (In.): 18

Overall Square (In.): 21

**Opening Required (In.):** 18-1/2 x 18-1/2

Frame Depth (In.): 2-1/2

Open Depth (In.): 5-3/4

Flange Width (In.): 1-1/2

Mounting Hole Size (In.): 9/32 x 1/2

Free Area (Square-Ft.): 2.043

Max. Velocity (FPM): 2500

Mounting Position: Vertical

Blade Material: White Painted Aluminum

Construction Material: Extruded Aluminum Frame and G-90 Galvanized Tie Rod

For Use With: Vertical Mounted Exhaust Fans

Notes & Restrictions
There are currently no notes or restrictions for this item.

MSDS

This item does not require a Material Safety Data Sheet (MSDS).

Required Accessories
There are currently no required accessories for this item.
Optional Accessories



**Shutter Motor** 

Item #: 2C831 **Brand: DAYTON** Usually Ships: Today Price (ea): \$89.80



Pull Chain Kit, Single Pannel Shutters

Item #: 2FTW3 **Brand:** DAYTON Usually Ships: Today Price (ea): \$25.30

#### Alternate Products



Fan Shutter, 18 In, Beige Fiberglass

Item #: 5C213 Brand: DAYTON Usually Ships: Today Price (ea): \$91.80



Exh Shutter, Fits Fan Dia 18 In, Aluminum

Item #: 4FZH5 Brand: DAYTON Usually Ships: 1-3 Days Price (ea): \$74.95

Repair Parts
A Repair Part may be available for this item. Visit our Repair Parts Center or contact your local branch for more information.

# AST4400 Class 1 Div 1 IS Groups C, D with Approved Barrier





The AST4400 is a media isolated stainless steel pressure sensor with a wide variety of options. With its rugged construction and best price-toperformance ratio in the industry, the AST4400 is the solution for pressure measurement in Intrinsically Safe areas.

#### **Benefits**

- UL/cUL 913 (CSA 157) Class 1 Div 1 Groups C, D when installed with an approved barrier
- High Strength Stainless Steel Construction
- No Oil, Welds or Internal O-rings
- Wide Operating Temperature Range
- Ranges up to 10,000 PSI
- Low Static and Thermal Errors
- Unparalleled Price and Performance
- Compatible with Wide Range of Liquids and Gases
- EMI/RFI Protection

## **Applications**

- Industrial OEM Equipment
- Water Management
- Pneumatics
- HVAC/R Equipment
- Control Panels
- Hydraulic Systems
- **Data Loggers**

Performance @	25°C (77°F)	
Accuracy*	< ±0.25% BFSL	
	(< ±0.5% BFSL for 7,500 & 10,000 PSI)	
Stability (1 year)	±0.25% FS, typical	
Over Range Protection	2X Rated Pressure	
Burst Pressure	5X or 20,000 PSI (whichever is less)	
Pressure Cycles	> 100 Million	
* Accuracy includes non-linearity, hysteresis & non-repeatability		




Environmental Data				
Temperature				
Operating	-40 to 85°C (-40 to 185°F)			
Storage	-40 to 100°C (-40 to 212°F)			
Thermal Limits				
Compensated Range	0 to 55°C (30 to 130°F)			
TC Zero	<±1.5% of FS			
TC Span	<±1.5% of FS			
Other				
Shock	100G, 11 msec, 1/2 sine			
Vibration	10G peak, 20 to 2000 Hz.			
EMI/RFI Protection:	Yes			
Rating:	IP-66			

<b>Electrical Data</b>				
Output	4-20mA	1-5VDC, 1-6VDC	0-50mV (10mV/V)	0.5-4.5V Ratiometric
Excitation	10-28VDC	10-28VDC	5VDC, typical	5VDC, regulated
Output Impedance	>10k Ohms	<100 Ohms, Nominal	1100 Ohms, Nominal	<100 Ohms, Nominal
Current Consumption:	20mA, typical	5mA, typical	<5mA	5mA, typical
Bandwidth	(-3dB): DC to 250 Hz	(-3dB): DC to 1kHz	(-3dB): DC to 5kHz, min	(-3dB): DC to 1kHz
Output Noise:	-	<2mV RMS	-	<2mV RMS
Zero Offset:	<±1% of FS	<±1% of FS	< ±2% of FS	<±1% of FS
Span Tolerance:	<±2% of FS	<±1.5% of FS	< ±2% of FS	<±1.5% of FS
Output Load:	0-800 Ohms@10-28VDC	10k Ohms, Min.	>1M Ohms	10K Ohms, Min.
Reverse Polarity Protection	Yes	Yes	-	Yes



## **Ordering Information**



Electrical\*\*

A= 2 ft. (0.6 m) I= DIN 43650A (mate included)+ B= 4 ft. (1.2 m) L= Conduit fitting, Cable 2 ft.\* M= Conduit fitting, Cable 4 ft.\* C= 6 ft. (1.8 m) D= 10 ft. (3.0 m) N= Conduit fitting, Cable 6 ft.\* E= Mini DIN 43650 P= Conduit fitting, Cable 10 ft.\*

F= Packard Metripack 150 3-Pin Conn. Y= M12 Eurofast

Wetted Material


0=17-4PH 1=316 L 2= Inconel 718 (consult factory on availability)

Options

000= No special options

\*Not available under 50PSI, or in 316L \*\*Wiring information available at: http://www.astsensors.com/mediacenter.php \*Also approved to UL/cUL 1604 Class 1 Div 1, Group A, B, C, D without requiring a barrier

#### **Dimensional Data**



#### Warranty


Workmanship - AST, Inc. pressure transmitters have a limited one-year warranty to the original purchaser. AST, Inc. will replace or repair, free of charge, any defective transmitter. This warranty does not apply to any units that have been modified; misused, neglected or installed where the application exceeds published ratings. AST4400 is not recommended for use with hydrogen. For Hydrogen storage and applications, contact AST for AST4300, AST4401, & AST4600 model information. AST's sensors are made with pride in New Jersey, USA. If in the area please feel free to stop by for a visit!

Installation/Applications - The purchaser is responsible for media compatibility, functional adequacy, and correct installation of the transmitter.

#### **Pressure Ranges**

		_		
PSIG Measurement Range	Pressure Range Code	BARG Measurement Range	Pressure Range Code	
-14.7 to 30**	V0030	-1 to 2**	V0002	
0-25	00025	0-2	00002	
0-50	00050	0-5	00005	
0-100	00100	0-10	00010	
0-200	00200	0-20	00020	
0-250	00250	0-50	00050	
0-300	00300	0-100	00100	
0-500	00500	0-250	00250	
0-1,000	01000	0-350	00350	
0-1,500	01500	0-500	00500	
0-2,500	02500	0-700	00700	
0-3,000	03000	Typical ranges. All ranges between 0-25 PSI and 0-10,000 PSI available.  **Compound ranges up to -14.7 to 500 PSI available. Please consult factory.		
0-5,000	05000			
0-7,500	07500			
0-10,000	10000			

#### **Barrier Installation**



The transducers listed below are designed for installation in a Class I, Division I, Groups C and D, Division I hazardous location when connected to Associated Apparatus as described in note 1.

Entity Parameters Vmax = 28Vdc Imax = 175mA C1 = 0.44uf L1 = 0

 $\mbox{Im}\, \alpha x$  is the total current available from the Associated Apparatus under any condition.

Notes

1. Associated Apparatus shall provide intrinsically safe connections which meet the following parameters.

Voc or Vt ≤ Vmax

Lo ≥ C1 + Cleads

Ls co t t ≤ Imax

Lo ≥ L1 + Lleads

2. Control Room aparatus shall not generate in excess of 250V (Umax).

3. Installation should be in accordance with Article 504 in the National Electrical Code, ANSI/NFPA 70.

# AST44LP Class 1 Div 1 IS Groups C, D with Approved Barrier





#### **OVERVIEW**

The AST44LP is a media isolated stainless steel pressure sensor with a wide variety of options. With its rugged construction and the best price-to-performance ratio in the industry, the AST44LP is the solution for low pressure measurement in Intrinsically Safe areas.

### **BENEFITS**

- UL/cUL 913 (CSA 157) Class 1 Div 1 Groups C,D when installed with an approved barrier
- High Strength Stainless Steel Construction
- No Welds or Internal O-rings
- Wide Operating Temperature Range
- Ranges from 0-2.5 to 0-15 PSI
- Low Static and Thermal Errors
- Unparalleled Price and Performance
- Compatible with Wide Range of Liquids and Gases
- EMI/RFI Protection

### **APPLICATIONS**

- Industrial OEM Equipment
- Water Management
- Pneumatics
- Vapor Recovery
- External Tank Levels
- HVAC/R Equipment
- Control Panels
- Hydraulic Systems
- Data Loggers

Performance @	25°C (77°F)			
Accuracy*	< ±0.25% BFSL (< ±0.5% BFSL for 0-1 PSI)			
Stability (1 year)	±0.25% FS, typical			
Over Range Protection	2X Rated Pressure			
Burst Pressure	5X or 75 PSI (whichever is less)			
Pressure Cycles	> 100 Million			
* Accuracy includes non-linearity, hysteresis & non-repeatability				

——• 15 PSI	
•7.5 PS(((1))	Po
• 5 PSI • 2.5 PSI	
	c UL US C E


Environmental	Data
Temperature	
Operating	-40 to 85°C (-40 to 185°F)
Storage	-40 to 100°C (-40 to 212°F)
Thermal Limits	
Compensated Range	0 to 55°C (30 to 130°F)
TC Zero	<±1.5% of FS
TC Span	<±1.5% of FS
Other	
Shock	100G, 11 msec, 1/2 sine
Vibration	10G peak, 20 to 2000 Hz.
EMI/RFI Protection:	Yes
Rating:	IP-66

<b>Electrical Data</b>			
Output	4-20mA	1-5VDC, 1-6VDC	0-50mV (10mV/V)
Excitation	10-28VDC	10-28VDC	5VDC, typical
Output Impedance	>10k Ohms	<100 Ohms, Nominal	1100 Ohms, Nominal
Current Consumption:	20mA, typical	5mA, typical	<5mA
Bandwidth	(-3dB): DC to 250 Hz	(-3dB): DC to 1kHz	(-3dB): DC to 5kHz, min
Output Noise:	-	<2mV RMS	-
Zero Offset:	<±1% of FS	<±1% of FS	< ±2% of FS
Span Tolerance:	<±2% of FS	<±1.5% of FS	< ±2% of FS
Output Load:	0-800 Ohms@10-28VDC	10k Ohms, Min.	>1M Ohms
Reverse Polarity Protection	Yes	Yes	-



### **Ordering Information**

000



H= Inches H<sub>2</sub>O P= PSI

Outputs

6= 1-6V 3= 1-5V 4= 4-20mA (2 wire loop powered) A= 10mV/V

Electrical\*

I= DIN 43650A A= 2 ft. (0.6 m) L= Conduit, Cable 2 ft. B= 4 ft. (1.2 m) M= Conduit, Cable 4 ft. C= 6 ft. (1.8 m) D= 10 ft. (3.0 m) N= Conduit, Cable 6 ft. E= Mini DIN 43650C P= Conduit, Cable 10 ft. F= Packard Metripack 150 R= 6 Pin Bendix


**Wetted Material** 1=316 L

#### **Options**

000 -No special options

\*Wiring information available at: http://www.astsensors.com/mediacenter.php

### **Dimensional Data**



### Warranty

Workmanship - AST, Inc. pressure transmitters have a limited one-year warranty to the original purchaser. AST, Inc. will replace or repair, free of charge, any defective transmitter. This warranty does not apply to any units that have been modified; misused, neglected or installed where the application exceeds published ratings. AST4400 is not recommended for use with hydrogen. For Hydrogen storage and applications, contact AST for AST4300, AST4401, & AST4600 model information. AST's sensors are made with pride in New Jersey, USA. If in the area please feel free to stop by for a visit!


Installation/Applications - The purchaser is responsible for media compatibility, functional adequacy, and correct installation of the transmitter.

### **Pressure Ranges**

Gage <b>PSIG</b>	Pressure Range Code
0-1	00001
0-2.5	00069*
0-5	00005
0-7.5	00208*
0-10	00010
0-15	00015

\*2.5 and 7.5 PSI Sensor must be ordered in inches of H<sub>2</sub>O.

### **Barrier Installation**



The transducers listed below are designed for installation in a Class I, Division I, Groups C and D, Division I hazardous location when connected to Associated Apparatus as described in note  $\bf i.$ 

Entity Parameters Vmax = 28Vdc Imax = 175mA C1 = 0.44uf L1 = 0

 $\mbox{Im}\, \alpha x$  is the total current available from the Associated Apparatus under any condition.

Notes:

1. Associated Apparatus shall provide intrinsically safe connections which meet the following parameters.

Vac or Vt ≤ Vmax

Isc or It ≤ Imax

Co ≥ C1 + Cleads

Lo ≥ L1 + Lleads

- 2. Control Room aparatus shall not generate in excess of 250V (Umax).
- 3. Installation should be in accordance with Article 504 in the National Electrical Code, ANSI/NFPA 70.




**Series ISDP** 

# **Intrinsically Safe Differential Pressure Transmitter**

# For Hazardous Zone Pressure and Flow Applications





The ISDP Differential Pressure Transmitter provides a 4-20 mA process output, a robust NEMA 4X enclosure, plus a large LCD display that can be programmed to read in pressure, velocity or flow. The ISDP offers simplified programming via a Menu key that enables the user to select: security level; English or Metric engineering units; pressure, velocity or flow operation, K-factor for use with various Pitot tubes and flow sensors, circular or rectangular duct size for volumetric flow operation plus many more. The Series ISDP Differential Pressure Transmitter is powered on its two wire loop with 10-35 VDC via its integral M-12 four pin male connector. The ISDP provides a 0.5% full scale accuracy on ranges from 0.25 " w.c. to 100 " w.c. as well as bi-directional models up to 10 " w.c. These features make the Series ISDP Differential Pressure Transmitter the ideal instrument for monitoring pressures or air flows in hazardous zones having a Class I Div. I Groups A, B, C, D; Class II Div. I Groups E, F, G; Class III Div. I ratings.

Model	Range
ISDP-002	0 - 0.25 in w.c.
ISDP-004	0 - 1 in w.c.
ISDP-006	0 - 5 in w.c.
ISDP-007	0 - 10 in w.c.
ISDP-008	0 - 25 in w.c.
ISDP-009	0 - 50 in w.c.
ISDP-010	0 - 100 in w.c.
ISDP-012	-0.25 / +0.25 in w.c.
ISDP-014	-1.0 / +1.0 in w.c.
ISDP-015	-2.5 / +2.5 in w.c.
ISDP-016	-5.0 / +5.0 in w.c.
ISDP-017	-10 / +10 in w.c.

#### **ACCESSORIES**

A-231, 16' (5 m) Shielded Cable with 4 Pin Female M-12 Connection A-486, 4.9' (1 m) Shielded Cable with 4 Pin Female M-12 Connection A-487, 9.8' (3 m) Shielded Cable with 4 Pin Female M-12 Connection A-488, 33' (10 m) Shielded Cable with 4 Pin Female M-12 Connection A-295, Female 4 Pin M-12 to Cable Gland Connector

MTL5041, Intrinsically Safe Galvanic Isolator MTL7706, Intrinsically Safe Zener Barrier A-438, Surface Mounting Brackets

### **SPECIFICATIONS**

Service: Air and non-corrosive gases.

Wetted Materials: Ranges 5" and greater: glass, PVC, silicon, alumina ceramic, epoxy, RTV, gold, aluminum, stainless steel and nickel; Ranges 1" and lower: stainless steel, silicone, gold and ceramic.

Housing Materials: Aluminum, glass.

Accuracy: ±0.5% at 77°F (25°C) including hysteresis and repeatability (after 1 hour warm-up)

Stability: < ±1% per year.

**Pressure Limits:** Ranges ≤ 2.5 in. w.c. = 2 psi; 5": 5 psi; 10": 5 psi; 25": 5 psi; 50":

5 psi; 100": 9 psi.

Temperature Limits: 32 to 140°F (0 to 60°C).

Compensated Temperature Limits: 32 to 140°F (0 to 60°C). Thermal Effects: 0.020%/°F (0.036/°C) from 77°F (25°C).

Power Requirements: 10-35 VDC. Output Signal: 4-20 mA DC.

Zero & Span Adjustments: Accessible via menus.

Response Time: 250 ms (damping set to 1).

Display: 4 digit LCD 0.6" height.

Electrical Connections: M-12 4 PIN Connector. Process Connections: 1/8" female NPT.

Enclosure Rating: Designed to meet NEMA 4X (IP66). Mounting Orientation: Mount unit in horizontal plane.

Weight: 2 lb 10 oz (1.19 kg).

Agency Approvals: FM Intrinsically Safe CLI Div I GR: A, B, C, D; CLII Div I GR: E, F, G; CLIII Div I. CE: CENELEC EN 61326/55024: 2003; IEC 61000-4-2/3/4/6: 2001/2006/2004/2005; CENELEC EN 55011: 2006; 2004/108/EC EMC Directive.



### Series ISDP Intrinsically Safe Differential Pressure Transmitter

**Specifications - Installation and Operating Instructions** 




P.O. BOX 373 • MICHIGAN CITY, IN 46361, U.S.A.

Phone: 219/879-8000 Fax: 219/872-9057


e-mail: info@dwyer-inst.com

www.dwyer-inst.com

#### **DIMENSIONS**



### OPTIONAL A-438 BRACKET MOUNTING DIAGRAM



#### **SPECIFICATIONS**

**Service:** Air and non-corrosive gases.

**Wetted Materials:** Ranges 5" and greater: glass, PVC, silicon, alumina ceramic, epoxy, RTV, gold, aluminum, stainless steel and nickel; Ranges 1" and lower: stainless steel, silicone, gold and ceramic.

Housing Materials: Aluminum, glass.

Accuracy: ±0.5% at 77°F (25°C) including hysteresis and repeatability (after 1 hour

warm-up).

Stability: < ±1% per year.

**Pressure Limits:** Ranges ≤ 2.5 in. w.c. = 2 psi; 5″: 5 psi; 10″: 5 psi; 25″: 5 psi; 50″: 5 psi; 100″: 9 psi.

Temperature Limits: 32 to 140°F (0 to 60°C).

Compensated Temperature Limits: 32 to 140°F (0 to 60°C). Thermal Effects: 0.020%/°F (0.036/°C) from 77°F (25°C).

Power Requirements: 10-35 VDC.

Output Signal: 4-20 mA DC.

**Zero & Span Adjustments:** Accessible via menus. **Response Time:** 250 ms (dampening set to 1).

Display: 4 digit LCD 0.6" height.

Electrical Connections: M12 4 PIN Connector.

Process Connections: 1/8 female NPT.

**Enclosure Rating:** Designed to meet NEMA 4x (IP66). **Mounting Orientation:** Mount unit in horizontal plane. **Size:** 4.73" x 4.73" x 3.43" (120 mm x 120 mm x 87.1 mm).

Weight: 2 lb 10 oz (1.19 kg).

**Agency Approvals:** FM, C-FM Intrinsically Safe CL1 Div 1 GR: A, B, C, D; CL2 Div 1 GR: E, F, G; CL3 Div 1 CE. CENELEC EN 61326/55024: 2003; IEC 61000-4-2/3/4/6: 2001/2006/2004/2005; CENELEC EN 55011: 2006; 2004/108/EC EMC Directive.

### **Intrinsic Safety Information**

### **Entity Parameters**

Ui = 28VDC

Ii = 93mA

Ci = 22 nF

Li = 400 uH

Pi = 651mW

#### Intrinsically Safe for the following hazardous areas:

CLASS I DIV. 1 GROUPS A, B, C, D


CLASS II DIV. 1 GROUPS E, F, G

CLASS III DIV. 1 T4

#### Notes:

- 1. Remove power from the instrument before carrying out any servicing.
- 2. Return the instrument to the manufacturer for any repair. Any unauthorized repairs may impair the intrinsic safety of the instrument.
- 3. Use only FM approved Associated Apparatus.
- 4. Install in accordance with ANSI/ISA RP12.06.01, the National Electric Code ANSI/NFPA 70, in the US, and the Canadian electrical code in Canada.
- 5. The earth terminal on the housing must be wired to a local earth ground in the hazardous area.

#### M-12 Connector



A-231 M-12 Cable Colors PIN 1 is Brown (positive) PIN 3 is Blue (negative)

Use Model A-231 shielded cable with 4 pin Female M-12 connection.

#### 2-WIRE CONNECTION




Fig. C

**2-Wire Operation-** An external power supply delivering 10 - 35 VDC with minimum current capability of 40 mA DC (per transmitter) must be used to power the control loop. See Fig. C for connection of the power supply, transmitter, and receiver. The range of the appropriate receiver load resistance (RL) for the DC power supply voltage available is expressed by the formula and graph in Fig. D.

### POWER SUPPLY VOLTAGE - VDC (2-WIRE CONNECTION)





Fig. D

#### INSTALLATION

Mount the instrument in a location that will not be subject to excessive temperature, shock or vibration.

#### **Pressure Connections**


Use 1/8" male NPT fittings. When tightening fittings, grasp the brass fitting on the ISDP with a 1/2" wrench to prevent the fitting on the ISDP from turning.





#### **KEY FUNCTIONS**

	HOME POSITION FUNCTION	MAIN MENU FUNCTION	SUB MENU FUNCTION
MENU MENU	Allows access to the menus	Return to home position	Return to previous menu
UP ARROW		Sequences through menus	Increments a value
DOWN ARROW		Sequences through menus	Decrements a value
E	Displays full scale range of unit	Enter into SUB MENU	Changes a value or setting. Press ENTER and display will blink. Adjust with UP or DOWN arrows. Press ENTER to store. Display will stop blinking.  Peak/Valley SUB MENU resets display to present value.

#### **MENU MAP**







Model Chart				
Model	Range			
ISDP-002	0-0.25"			
ISDP-004	0-1" WC			
ISDP-005	0-2.5" WC			
ISDP-006	0-5" WC			
ISDP-007	0-10" WC			
IDSP-008	0-25" WC			
ISDP-009	0-50" WC			
ISDP-010	0-100" WC			
ISDP-011	-0.1/+0.1" WC			
ISDP-012	-0.25/+0.25" WC			
ISDP-013	-0.5/+0.5" WC			
ISDP-014	-1.0/+1.0" WC			
ISDP-015	-2.5/+2.5" WC			
ISDP-016	-5.0/+5.0" WC			
ISDP-017	-10/+10" WC			

### Main Menu Selections (Upper Right Display Reads MENU)

- SECr Security Lock out access to menus and settings.
- OPEr Operation Selection of Pressure, Velocity or Flow and corresponding engineering units.
- াচ Display Monitor and adjust display related settings: Peak, Valley, display resolution, % output and dampening.
- $\vdash$  Advanced functions Modify advanced function parameters, transmitter output scaling, and calibration.

#### **MAIN MENUS and SUB MENUS**

#### SEC- (Security) MAIN MENU

SECr is the only SUB MENU in the security MENU. When the security SUB MENU is selected, the present security level is displayed in the upper right hand display. To change the security level, adjust the number displayed to the number shown in the following table for the desired security level.

Security Level Displayed	Access	Password Value to Enter
1	All menus access	10
2	All settings locked	70

The password values shown in the table cannot be altered, so retain a copy of these pages for future reference.

#### **OPEr\_(Operation) MAIN MENU**

The OPEr MENU selects the measurement type of the instrument. The SUB MENUS are:

Pressure KFAC - K Factor XDIM - X Dimension

 UEL - Velocity
 R−ER - Area
 Y□II - Y Dimension

Fl Π - Flow ΠΙΘ - Diameter



### Pressure) SUB MENU

For pressure measurement, the following units are available:

INUC - Inches of water column /INHG - Millimeters of mercury

Table 1 Pressure Range vs. Available Units

INWC	FTWC	MMWC	CMWC	PSI	INHG	MMHG	MBAR	PA	KPA	HPA	OZIN
.1000		2.540	.2540			.1868	.2491	24.91		.2491	
.2500		6.350	.6350			.4671	.6227	62.27		.6227	.1445
.5000		12.70	1.270			.9342	1.245	124.5	.1245	1.245	.2890
1.000	0000	25.40	2.540		4000	1.868	2.491	249.1	.2491	2.491	.5780
2.500	.2083	63.50	6.350	4000	.1839	4.671	6.227	622.7	.6227	6.227	1.445
5.000	.4167	127.0	12.70	.1806	.3678	9.342	12.45	1245	1.245	12.45	2.890
10.00	.8333	254.0	25.40	.3613	.7356	18.68	24.91	2491	2.491	24.91	5.780
25.00	2.083	635.0	63.50	.9032	1.839	46.71	62.27	6227	6.227	62.27	14.45
50.00	4.167	1270	127.0	1.806	3.678	93.42	124.5		12.45	124.5	28.90
100.0	8.333	2540	254.0	3.613	7.356	186.8	249.1		24.91	249.1	57.80

**NOTE:** □VFL(over flow) or U¬FL(under flow) will appear when the ranges have been exceeded above or below full scale by 2%.

### <u>LIEL</u> (Velocity) SUB MENU

For velocity measurement, the following units are available:

SFPM - Standard feet per minute

M/5 - Meters per second

Table 2 Available Velocity Ranges

INPUT RANGE INWC	SFPM RANGE	M/S RANGE
0 - 0.1	0 - 1266	0 - 6.431
0 - 0.25	0 - 2002	0 - 10.17
0 - 0.5	0 - 2832	0 - 14.39
0 - 1	0 - 4004	0 - 20.35
0 - 2.5	0 - 6332	0 - 32.17
0 - 5	0 - 8954	0 - 45.48
0 - 10	0 - 12.66 x IK	0 - 64.33
0 - 25	0 - 20.02 x IK	0 - 101.7

**NOTE:** Air velocity and flow readings are based upon standard dry air conditions with an ambient temperature of 70°F and a barometric pressure of 29.92 INHG.

### FLD (Flow) SUB MENU

For flow measurements the following units are available:

SCFM - Standard cubic feet per minute

/7<sup>3</sup>H - Cubic meters per hour

### FLO\_r (Flow Range) SUB MENU

∠□ - 99.99 x 1K flow range

H - 999.9 x 1K flow range

Tables 3 -6 show the flow ranges available, and the maximum duct size that can be set for each input range.

Table 3

FLO- = LO Maximum Duct Size (English)

RANGE IN WC	SCFM RANGE	MAX. DUCT SIZE, SQ. FT.
0.1	99.99 x 1K	78.9
0.25	99.99 x 1K	49.9
0.5	99.99 x 1K	35.3
1	99.99 x 1K	24.9
2.5	99.99 x 1K	15.7
5	99.99 x 1K	11.1
10	99.99 x 1K	7.8
25	99.99 x 1K	4.9

Table 5
FLO- = LO Maximum Duct Size (Metric)

RANGE IN WC	M <sup>3</sup> /Hr RANGE	MAX. DUCT SIZE M^2
0.1	99.99 x 1K	4.32
0.25	99.99 x 1K	2.73
0.5	99.99 x 1K	1.93
1	99.99 x 1K	1.37
2.5	99.99 x 1K	0.86
5	99.99 x 1K	0.61
10	99.99 x 1K	0.43
25	99.99 x 1K	0.27

KFAC SUB MENU

Table 4

FLOr = H Maximum Duct Size (English)

RANGE IN WC	SCFM RANGE	MAX. DUCT SIZE, SQ. FT.
0.1	999.9 x 1K	789.8
0.25	999.9 x 1K	499.5
0.5	999.9 x 1K	353.1
1	999.9 x 1K	249.7
2.5	999.9 x 1K	157.9
5	999.9 x 1K	111.7
10	999.9 x 1K	78.9
25	999.9 x 1K	49.9

Table 6

FLOr = H Maximum Duct Size (Metric)


RANGE IN WC	M^3/Hr Range	MAX. DUCT SIZE, M <sup>2</sup>
0.1	999.9 x 1K	43.19
0.25	999.9 x 1K	27.31
0.5	999.9 x 1K	19.3
1	999.9 x 1K	13.64
2.5	999.9 x 1K	8.63
5	999.9 x 1K	6.10
10	999.9 x 1K	4.31
25	999.9 x 1K	2.73

KFRC K Factor - becomes accessible if the instrument is set for Velocity or Flow. When the Digihelic® II Controller is used with a Pitot tube, the manufacturer may specify a K Factor. The adjustment range is 0.01 to 2.00. The factory setting is 1.

#### R-ER, DIR, XDIT and YDIT SUB MENUS

These SUB MENUS become accessible if the instrument is set for flow. When measuring flow, the area of the duct must be specified. Tables 3 and 4 show the input range vs maximum flow and duct size. For a rectangular duct the maximum size is specified in square feet or meters. For a circular duct the maximum size is specified as the diameter. X, Y and circular dimensions are entered in feet with 0.01 foot resolution for FLDr = H, or entered in millimeters with 1 millimeter resolution.

 $\propto BPP$  - Area, select  $\propto BPP$  for a circular duct or  $\propto BPP$  for a rectangular duct. If a circular duct is selected, the  $\propto BPP$  SUB MENUS will be activated. If a rectangular duct is selected, the  $\propto BPP$  and  $\propto BPP$  SUB MENUS will be activated.



#### d.5 (Display) MAIN MENU

PERK - Peak valuerESD - ResolutionVRLy - Valley valuePd.5 - Process displayZERD - ZeroDRMP - Dampening level

#### PERK (Peak) SUB MENU

The Peak feature stores the highest pressure reading the instrument has measured since the last reset or power up. At power up PEAK is reset to the present pressure reading. To manually reset the PEAK value, press the ENTER key while in the PEAK SUB MENU.

### レ머니 (Valley) SUB MENU

The valley feature stores the lowest pressure reading the instrument has measured since the last reset or power up. At power up  $\mathcal{VAL}_{\mathcal{A}}$  is reset to the present pressure reading. To manually reset the  $\mathcal{VAL}_{\mathcal{A}}$  value, press the ENTER key while in the  $\mathcal{VAL}_{\mathcal{A}}$  SUB MENU.

#### r=ESD (Resolution) SUB MENU

The Series ISDP Controller is capable of displaying four digits of resolution.

However, at very low pressures the instability of the pressure may cause fluctuations in the least significant digit causing the least significant digit to be of little value.

Three digit resolution ( $\exists \square \square \square$ ) can only be active when there is at least one digit to the right of a decimal.

∃□IG - Set display for 3 digit resolution

4□15 - Set display for 4 digit resolution

#### Pd.5 (Process Display) SUB MENU

5TD - Display reads pressure, velocity, or flow values

PET - Display reads % of full scale value

When the display is reading percent, PET is displayed in the upper right of the display. The percent display is only available in pressure operation.

### <u>□⊣⊓P (Dampening) SUB MENU</u>

Adjust from 1-16

Dampening stabilizes the display from instabilities due to things such as vibration and excessive pressure fluctuations. The dampening setting adjusts the amount of readings that are averaged for each display update. Adjust the dampening value until the display reads a stable value for the application.

#### 의 (Advanced) MAIN MENU

POL - Process output low

PDH - Process output high

ZERO - Zero calibration

SPAN - Span calibration

#### POL and POH (Process Output Low and High) SUB MENUS

This feature is used in pressure operation only.

Process output low and high are used to scale the 4-20 mA output. Set PDL to the desired display reading for 4mA output, and set PDL to the desired display reading for 20 mA output. PDL must be higher than PDL. PDL may be adjusted 2% BELOW minimum scale up to PDL may be adjusted from PDL to 2% ABOVE maximum scale.

#### ZERO and SPAN (Calibration of Zero and Span) SUB MENUS

The lower display reads *LAL* in this mode.

#### ZERO Calibration

**NOTE:** For accurate calibration, DO NOT apply any pressure when performing this function.


With the display reading ZERD, press the ENTER key. The upper display will blink. Press ENTER again to complete the zeroing of the instrument or press the PEPL key to cancel.

### 5PAN Calibration

With the display set to SPAN, apply full scale pressure to the unit. Press the ENTER key. The upper display will blink. Press ENTER again to complete the calibration or press the NENU key to cancel.

#### Maintenance


Upon final installation of the Series ISDP intrinsically Safe Differential Pressure Transmitter, no routine maintenance is required. The Series ISDP is not field serviceable and should not be returned if repair is needed (field repair should not be attempted and may void warranty). Be sure to include a brief description of the problem plus any relevant application notes. Contact customer service to receive a return goods authorization number before shipping.



©Copyright 2009 Dwyer Instruments, Inc.

Printed in U.S.A. 5/09

FR# 19-443480-00 Rev.2





### DIFFERENTIAL PRESSURE TRANSMITTER

Models 115, 215, 315, 115X/P, 215X/P, 315X/P/Z



#### **FEATURES:**

- Rugged, all welded, totally encapsulated electronics
- Leakproof. No O-ring construction
- Small size
- All SST wetted parts
- Base pressure to 10,000 psi (with option HM)
- Explosion Proof & Intrinsically Safe Approvals

#### PRESSURE RANGES:

- From 30 to 5000 psid
- From 2 to 300 bar
- (Bi-directional available)

### **Approvals**





# **WIRING:**

F/6 BROWN SHIFI D

#### 115 A/1 RED +EXC. B/2 GREEN C/3 WHITE D/4 BLACK E/5 BLUE

+SIGNAL -SIGNAL -EXC. NC OPTION GH NC OPTION GH OPFN

215 +FXC +SIGNAL NC

-EXC./SIGNAL NC OPTION GH NC OPTION GH OPFN

NC -EXC./SIGNAL NC OPTION GH NC OPTION GH **OPFN** 

+EXC./SIGNAL

315

NC

#### Zero Balance:

(Model 115) 0.0 mV/V ±2% FSOat 70°F at 10 Vdc (Model 215) 0.0 Vdc ±2% FSO at 70°F at 24 Vdc (Model 315) 4.0 mA ±2% FSO at 70°F at 24 Vdc

### **Temperature Compensation:**

• Effect on Zero / Span ≤ ±2.0% FSO/100°F for each

#### Electricals:

(Consult factory for ATEX approval)

Excitation Voltage:

(Model 115) 3.5-15 Vdc

(Models 215/215X) 9-40 Vdc / 10.5-32 Vdc

(Models 315/315Z) 9-36 Vdc (Model 315X) 13-36 Vdc

Output Current:

(Model 215) 2.0 mA maximum for less than 0.1% FSO attenuation.

Output at 70°F:

(Model 115) 3 mV/V ±2% FSO

(Models 215/215X) 5 Vdc ±2% FSO

(Models 315/315X/315Z) 4-20 mA ±2% FSO

· Load Impedance:

(Model 115) 50,000 ohms min. for less than 0.1% FSO attenuation (Model 215) 750 ohms maximum at 24 Vdc & 1350 ohms at 36 Vdc

· Input Impedance:

(Model 115) 5000 ohms nominal

Input Current:

(Model 215) 10 mA nominal

### **Temperature Limits:**

- Compensated: +70° to +180° F
- Operating: -20° to +190° F
- Storage: -65° to +250° F

### **Mechanicals:**

- Proof Pressure: 10 X full scale pressure range or 3000 psi, whichever is less.
- Burst Pressure: 15 X full scale pressure range or 4000 psi, whichever is less.
- · Weight: 16 oz. nominal.
- Static Line Pressure: 2000 psi maximum (10,000 psi option)
- Static Line Shift (Zero Shift): ≤ ±1% FSO/1000 PSI
- · Wetted Materials: 316 SST
- Enclosure Material: 17-4 and 316 SST
- · Mounting: Pressure Port

#### **Connections:**

- Pressure: 1/4" NPT (F)
- · Electrical Cable:

(Model 115, 215) 36" long, 4 conductor (Model 315) 36" long, 2 conductor


A5SL-15.00 Rev D




### DIFFERENTIAL PRESSURE TRANSMITTER

### Models 115, 215, 315, 115X/P, 215X/P, 315X/P/Z

Some options will affect dimensions. Consult factory if important.





Specifications reflect standard product, improved performance / mechanical options available.

Modifications may alter specs, consult factory for more information.



#### MODEL:

115 3 mV/V 215 0-5 Vdc 4-20 mA 315

215X 0-5 Vdc Explosion Proof 315X 4-20 mA Explosion Proof 4-20 mA Intrinsically Safe 315Z

#### ACCURACY:

A - 1.0% FSO / B - 0.5% FSO / C - 0.2% FSO

PRESSURE RANGE (PSI): \*\*Available with option HM only 30 RF **RS** 2500 PV 50 RH 500 RT 3000\*\* PX 75 5000\*\* 600 RV RJPΖ 100 RK 750 RW 6000\*\* **RX** 7500\*\* RR 150 **RM** 1000

200 1500 RD RO SZ Other RE 250 **RR** 2000

### **OPTIONS**

AA None (standard connector)

### ALTERNATE CONNECTOR OR CABLE

Bendix PTIH-10-6P (Mate:PTO6E-10-6S [SR], not supplied) CA СВ Bendix CF3102E-14S-6P(Mate: CF 3106E-14A-6S (not supplied))

CE

CF 1/2" NPT(M) thread w/24" potted leads. (Std. on exp. proof models)

CH NEMA-4X cable, 8' vented polyurethane jacket cable

DIN 43650 (includes mate) CJ

CL 1/2" NPT (M) conduit, 2' vented polyurethane jacket cable CO Junction Box (thermocouple type) and Terminal Block Teflon jacketed cable, Tefzel used on submersible units, (Options CH, CL, DE)

### ALTERNATE PRESSURE PORT

FΑ MS33649-4 (1/4 AND-10050, [F])

FC 3/8" NPT (F)

FΖ Non-Standard Pressure Port

### **GENERAL**

CW Submersible non-vented cable (max. 500 psi external)

DE IP-67 (NEMA-6) vented polyurethane cable, neoprene grommet

GA Standardized Output to ±0.5% FSO

GB Alternate Full Scale, Outputs that are non-standard

Improved Temp. Compensation to ±0.5% FSO/100°F for Zero & Span GE GF

Expanded process temperature range, -65 to 250°F (±2% FSO/100°F)

GG Alternate Calibration Resistor Signal GH Internal Calibration Resistor, set to 100% ±0.5% FSO

GJ Zero & Span Controls (Approximately ±20% FSO) 215 & 315 only

Cleaned for Oxygen Service GL

GS 0-10 Vdc FSO, Model 215. (Requires 16-40 Vdc excitation)

HK NEMA-4X rating

HL RFI Protection (for unit in proximity to radio transmitter).

HM 10,000 psi Base Pressure Flange Girdle.

Proof pressure 10 x full scale range or 10,000 psi, whichever is less. Burst pressure 15 x full scale range or 10,500 psi, whichever is less.

HR ±15 Vdc Excitation, Model 215

MD Zero and Span Controls for Explosion-Proof Units.

Bi-Directional Differential Pressure allows for both positive & Negative signal MS

(Model 315 has a 12 mA zero)



# 201L LIQUID FILLED

Our '200' series gauge line is a high quality line of liquid filled gauges. The glycerine filling helps dampen the effects of pulsation and vibration, while also perpetually lubricating the movement (and keeping contaminates such as dirt away from all moving parts) which will extend the life of the gauge.

This gauge has been specifically designed with original equipment manufacturers in mind and are typically used on hydraulic & pneumatic systems as well as any commercial or industrial application not corrosive to brass and bronze wetted parts where glycerine filling is suitable for use.

# **SPECIFICATIONS:**

• Available Dial Sizes: 1 ½", 2", 2 ½", 4", 6"

Available Connection Sizes:

1/8"MNPT on 1 ½" and 2" 1/4"MNPT on 2", 2 ½" and 4" 1/2"MNPT on 4" and 6"

Stainless Steel Case And Bezel

Brass Internals & Connection

Phosphour Bronze Bourdon Tube

Liquid Filled (Dry Available)

Accuracy: 1 ½" or 2"Dial Size = 3-2-3 %

2 ½"Dial Size = 1.5 % 4" or 6"Dial Size = 1 %

Dual Scale: PSI & Bar (x100=kPa)

Single Scale available from stock

Ambient temperature: FILLED: 30'F to 160'F

DRY: -30'F to 180'F

DANIOE	0005	B4 - 1 1	NA* I	h
RANGE	CODE	Major In	Minor In	ļ.
30/0"VAC	Α	5	0.5	- F
30/0/15	CB	5	0.5	cati
30/0/30	CC	10	1	효
30/0/60	CD	10	1	l g
30/0/100	CE	20	2	B
30/0/150	CF	20	2	arti
30/0/300	CH	50	10	l p
0/15	В	2	0.2	ا ۾
0/30	С	5	0.5	wit
0/60	D	10	1	g
0/100	E	20	2	Se (
0/160	F	20	2	lea Sea
0/200	G	40	4	S,
0/300	Н	50	5	size
0/400	I	50	5	dial
0/500	J	100	10	ā
0/600	K	100	10	e E
0/800	L	100	10	apl
0/1000	M	200	20	ıvai
0/1500	N	200	20	ğ
0/2000	0	400	50	es r
0/3000	Р	500	50	ang
0/4000	Q	500	50	Je r
0/5000	R	1000	100	Some ranges not available in all dial sizes, please call with your particular application
0/6000	S	2000	200	∥ຶ
0/10,000	U	2000	200	
0/15,000	V	2000	200	



	<b>⊢</b> B →
A	D + C + E *

		Α	В	С	D	Е
1 ½"	In	1.88	1.06	.89	2.77	1/8"
Dial	MM	48	27	23	58	NPT
2"	In	2.24	1.27	.71	2.80	1/8" or
Dial	MM	57	32	23	71	1/4" NPT
2 1/2"	In	2.80	1.28	1.07	3.55	1/4"
Dial	MM	71	33	27	90	NPT
4"	In	4.32	1.63	1.25	5.57	1/4" or
Dial	MM	110	42	32	141	½" NPT
6"	ln	6.54	1.70	1.68	8.22	1/4" or
Dial	MM	166	43	43	210	½" NPT



# 202L LIQUID FILLED

Our '200' series gauge line is a high quality line of liquid filled gauges. The glycerine filling and built in snubber helps dampen the effects of pulsation and vibration, while also perpetually lubricating the movement (and keeping contaminates such as dirt away from all moving parts) which will extend the life of the gauge.

This gauge has been specifically designed with the original equipment manufacturers in mind and are typically used on hydraulic & pneumatic systems as well as any commercial or industrial application not corrosive to brass and bronze wetted parts where glycerine filling is suitable for use.

# **SPECIFICATIONS:**

• Available Dial Sizes: 1 ½", 2", 2 ½", 3 ½", 4"

• Available Connection Sizes: (includes built-in snubber)

1/8"MNPT on 1 1/2" and 2"

1/4"MNPT on 2", 2 1/2", 3 1/2" and 4"

Stainless Steel Case And Bezel

Brass Internals & Connection

• Phosphor Bronze Bourdon Tube

• Plastic Lens Standard (Glass Available)

Liquid Filled (Dry Available)

• Accuracy: 1 ½" and 2" Dial = 3-2-3 %

2 1/2" Dial Size = 1.5 %

3 1/2" and 4" Dial Size = 1 %

Dual Scale: PSI & Bar (x100=kPa)


Single Scale available from stock

• Ambient temperature: FILLED: 30'F to 160'F

DRY: -30'F to 180'F

RANGE	CODE	Major In	Minor In
30/0"VAC	Α	5	0.5
30/0/15	CB	5	0.5
30/0/30	CC	10	1
30/0/60	CD	10	1
30/0/100	CE	20	2
30/0/150	CF	20	2
30/0/300	CH	50	10
0/15	В	2	0.2
0/30	С	5	0.5
0/60	D	10	1
0/100	E	20	2
0/160	F	20	2
0/200	G	40	5 5
0/300	Н	50	
0/400		50	5
0/600	K	100	10
0/1000	М	200	20
0/1500	N	200	20
0/2000	0	400	50
0/3000	Р	500	50
0/5000	R	1000	100
0/10,000	U	1000	100
0/15,000	V	2000	200





		Α	В	С	D	Е
1 ½"	In	1.88	1.06	.89	1.95	1/8"
Dial	MM	48	27	23	50	Npt
2"	In	2.23	1.09	.71	1.99	1/8" or
Dial	MM	57	28	23	51	1⁄4"npt
2 1/2"	In	2.80	1.28	1.18	2.46	1/4"
Dial	MM	71	33	30	63	NPT
3 ½"	In	3.83	1.14	1.08	2.20	1/4"
Dial	MM	97	29	27	56	NPT
4"	In	4.32	1.63	1.14	2.77	1/4"
Dial	MM	110	42	29	71	NPT




# LP SERIES LOW PRESSURE

### **SPECIFICATIONS**

- Chrome plated case
- Black steel case (u-clamp panel mnt)
- Brass internals and connection
- Dry non-fillable
- +/- 1.5 % accuracy

### **FEATURES**

- 2 1/2"dial size with twist lock plastic lens
- zero adjustment screw on back of case
- 1/4"mnpt bottom or back connection
- Capsule type diaphragm to measure low pressures



### **AVAILABLE RANGES:**

200-0"wc Vacuum (2"Minor inc) 160-0"wc Vacuum (2"Minor inc.) 100-0"wc Vacuum (1"Minor inc.) 60-0"wc vacuum (1"Minor Inc.) 30-0"wc vacuum ( .5"wc minor) 0-10"wc (.5"wc minor inc.) 0-15"wc ( .2"wc minor inc.) 0-30"wc ( .5"wc minor inc.)
20 oz./35"wc ( .5"wc minor inc.)
35 oz./60"wc ( 1"wc minor inc.)
0-60"wc ( 1"wc minor inc.)
0-100"wc (2"wc minor inc.)
0-160"wc (5"wc minor inc.)
0-200"wc (5"wc minor inc.)

0-3 psi ( .05 psi minor inc.) 0-5 psi ( .1 psi minor inc.) 0-10 psi ( .2 psi minor inc.)

NOTE: OTHER RANGES AVAILABLE UPON REQUEST, PLEASE CALL WITH ANY INQUIRIES



### **Pneumatic Actuators**

Quarter Turn Rack & Pinion Double Acting and Spring Return 5300 5301

#### **Features**

- Prelubricated and tested to minimum 1,000,000 operations
- Direct valve mounting per ISO 5211
- Visual valve position indicator
- Extruded aluminum body with 50 micron hard anodizing
- Aluminum polyester powder coated end covers for maximum corrosion resistance
- Epoxy coated pre-compressed spring cartridges used with all spring return models
- Namur mounting for direct mounted solenoid valves
- Standard VDI/VDE 3845 mounting for top mounted accessories
- Independent end of travel stops +/- 5 degrees each direction



Pneumatic actuators typically used to operate quarter turn ball valves, butterfly valves and plug valves, but they can be applied virtually anywhere a 90 degree rotation is required such as dampers. Quick and easy to install with standard ISO 5211/DIN 3337 mounting dimensions and a double square female output shaft (star drive). The operating temperature range of the actuator is 0 to 175° F.



Body	ASTM 6063 extruded aluminium, 50 micron anodizing
End Covers	ASTM B179 die-cast aluminium, 60-80 micron polyester coating
Drive Shaft	Carbon steel, 20 micron nickel plated
Valve Position Indicator	Glass filled Polyamide
Seals	NBR (Buna-N)
Springs (spring return act.)	Pre-compressed cartridges, 60-80 micron polyester coating
Pistons	ASTM B179 die-casted aluminium alloy
Fasteners	Stainless Steel



### Operation

Double acting actuators require air pressure to open and air pressure to close (pilot air typically supplied by a 4-way valve). Spring return actuators require air pressure to open and use springs to close (pilot air typically supplied by a 3-way valve). Dry or lubricated filtered compressed air supply pilot pressure between 40 and 120 PSI.

### Description

Compact heavy duty quarter turn (90 degree) air actuators designed for long life and tested for a minimum 1,000,000 operations. Actuator meets international ISO 5211 standards for easy valve mounting and replacement. Many options are available and easily mounted to the actuator with the standard VDI/VDE-3845 mounting pattern.

### **Options**

- Direct mount solenoid valves
- Position indicator switches
- Pneumatic valve positioners



# Double Acting "DA" Torque Ratings (inch Ibs.) - English Units

			AIR SUPPLY IN PSI							
STOCK NO.	SIZE	36	43	58	72	80	87	100		
530032	32	1	-	44	56	61	67	78		
530050	50	67	81	109	135	150	164	190		
530063	63	122	146	195	243	267	292	341		
530075	75	259	311	414	518	570	622	725		
530085	85	394	473	631	788	867	947	1105		
530090	100	613	826	982	1228	1351	1474	1720		
530095	115	1013	1215	1261	2026	2229	2432	2835		

# Double Acting "DA" Torque Ratings (Nm) - Metric Units

		AIR SUPPLY IN BAR						
STOCK NO.	SIZE	3	4	5	6	7	8	
530032	32	1	5.0	6.3	7.6	8.8	10	
530050	50	9.2	12.3	15.4	18.5	21.5	24.6	
530063	63	16.5	22	27.5	33	38.5	44	
530075	75	35.1	46.8	58.5	70.2	81.9	93.6	
530085	85	53.4	71.2	89	106.9	124.7	142.4	
530090	100	83.2	110.9	138.6	166.4	194.1	221.8	
530095	115	137.2	183	228.7	274.5	320.2	366	

	DA Actuator Weights							
SIZE	32	50	63	75	85	100	115	
Lbs.	1.2	2.5	3.6	6.4	9.3	12.8	20.3	
Kg.	0.6	1.2	1.6	2.9	4.2	5.8	9.2	



# Spring Return "SR" Torque Ratings (inch lbs.) - English Units

					AIR SUPP	LY IN PSI				SPRINGS	
STOCK			2	8	0	8	7	10	00	TORQUE	
NO.		O°	90°	0°	90°	0°	90°	O°	90°	90°	0°
530150	50	85	51	98	56	112	78	139	105	85	51
530163	63	136	92	185	116	234	140	282	189	141	107
530175	75	333	186	385	238	436	290	540	391	333	186
530185	85	510	279	589	358	668	436	825	594	510	279
530190	100	785	443	908	565	1031	688	1277	933	785	443
530195	115	1244	782	1447	985	1650	1188	2055	1593	1244	782
530196	125	1725	941	1992	1208	2258	1474	2791	2007	1725	941
530197	145	2357	1375	2739	1757	3125	2143	3902	2920	2500	1518
(	D° = closed	d pistons,	extended	springs		9	O° = ope	n pistons,	compres	sed spring	s


# Spring Return "SR" Torque Ratings (Nm) - Metric Units

			AIR SUPPLY IN BAR							SPRINGS	
STOCK			5	(	6	7	7	8	3	TOR	QUE
NO.		O°	90°	0°	90°	0°	90°	0°	90°	90°	0°
530150	50	9.6	5.8	12.7	8.9	15.7	11.9	18.8	15	9.6	5.8
530163	63	15.4	10.4	20.9	15.9	26.4	21.4	31.9	26.9	17.1	12.1
530175	75	37.6	21.1	49.3	32.8	61.0	44.5	72.7	56.2	37.6	21.1
530185	85	57.6	31.5	75.4	49.3	93.2	67.1	111	84.9	57.6	31.5
530190	100	88.7	50	116	77.7	144	105	171	133	88.7	50
530195	115	140	88	186	134	231	179	277	225	140	88
530196	125	194	106	254	166	315	226	375	286	194	106
530197	145	264	154	350	240	437	327	524	414	280	170
(	D° = closed	d pistons,	extended	springs		9	O° = ope	n pistons,	compres	sed spring	S

		SR Actuator Weights						
SIZE	50	63	75	85	100	115	125	145
Lbs.	2.8	4.2	7.3	10.4	14.7	22.3	30.5	41.1
Kg.	1.3	1.9	3.3	4.8	6.7	10.1	13.8	18.7




### **Dimensions Sizes 50-145: (inches)**






### Dimensions Sizes 50-145: (mm)





### **Dimensions Size 32: inches (mm)**

Size	32
A	4.61 (117)
В	1.77 (45)
C	1.89 (48)
F	1.97 (50)
G	0.98 (25)
J	0.39 (10)
L	1.00 (25.5)
М	0.89 (22.5)
N	0.31 (8)
0	0.47 (12)
Р	0.79 (20)
R	0.35 (9)
Т	1.26 (32)
U	0.63 (16)
V	0.47 (12)
Х	0.94 (24)
Υ	0.79 (20)
Z	1.38 (35)
Ports A & B	1/8 NPT
F ISO 5211	F03
S	1.42 (36)
w	M5 X 8
Н	0.98 (25)





# **Soft Seated Butterfly Valves**

Ductile Iron Lug Body ANSI/ASME 150 2" to 6" Sizes 5645 5647

### **Features**

- ISO5211 mounting for manual, air or electric actuators
- Unique wave line seat reduces torque and extends seal life
- Ductile iron body with 3-layer epoxy coating
- 316SS disc with 2-piece stem design enhances flow capacity
- Seat vulcanized to valve body
- · V-ring stem/shaft seals, same material as seat
- PTFE graphite reinforced stem bearings
- Pressure rated 230 PSI (16 Bar)
- Easily mounts between ANSI/ASME Class 125/150 flanges



Lug body butterfly valves with EPDM seals are typically used for on-off control of water and other media compatible with the materials of construction. Buna-N seals are typically used for air, oil, vacuum and other media compatible with the materials of construction.

### **Temperature Range**

EPDM Seals: 0 to 266° F (-18 to 130°C) Buna-N Seals: 0 to 185° F (-18 to 85°C)

#### Construction

Valve Body	3-layer Epoxy/Epoxy/PUR coated ductile iron GGG40
Disc	316 stainless steel CF8M
Disc Seat/Liner	EPDM or Buna-N
Stem Seals	V-ring (same material as seat)
Stem	420SS
Bearings	PTFE Graphite reinforced/Nylon
Fasteners	Stainless Steel



### Operation

Direct mount lug butterfly valves can be easily fitted with optional manual operator, air actuator or electric actuator using standard ISO5211 top mounting. Turning the square stem one quarter turn rotates the stainless steel disc and opens or closes the valve. Unique wave line soft seat reduces the torque required to close the valve and extends the seal life.

### Description

Lug butterfly valves with epoxy- coated ductile iron body are designed to control various media in commercial and industrial applications. Valve mounts between two standard ANSI/ASME Class 125/ 150 flanges. Seat to flange seal, eliminates the need for flange gaskets. Disc is precision machined 316SS for maximum corrosion resistance. Two piece stem and disc design enhances the flow capacity and reduces turbulence.

### **Options**

- Hand lever with 10 position locking
- Gear Operators (6" sizes)
- Air Actuators
- Electric Actuators



### **Specifications** (English units)

Stock Number	Pipe Size (inch)	Orifice Diam. (inch)	Cv Flow Factor	Pressure Max.(PSI)	Fluid Media*	Body	Disc
Lug Body EF	PDM Seals: B	ARE STEM					
564516	2	2.00	124	230	Water	Ductile Iron	316SS
564520	2-1/2	2.50	247	230	Water	Ductile Iron	316SS
564524	3	3.00	470	230	Water	Ductile Iron	316SS
564532	4	4.00	929	230	Water	Ductile Iron	316SS
564548	6	6.00	2243	230	Water	Ductile Iron	316SS
Lug Body Bl	JNA-N Seals:	BARE STEM					
564716	2	2.00	124	230	Air, Oil, Vacuum	Ductile Iron	316SS
564720	2-1/2	2.50	247	230	Air, Oil, Vacuum	Ductile Iron	316SS
564724	3	3.00	470	230	Air, Oil, Vacuum	Ductile Iron	316SS
564732	4	4.00	929	230	Air, Oil, Vacuum	Ductile Iron	316SS
564748	6	6.00	2243	230	Air, Oil, Vacuum	Ductile Iron	316SS

Cv = The GPM of water at 60° F that will pass through the valve with 1 PSI pressure drop

### **Specifications** (Metric units)

Stock Number	Pipe Size (DN)	Orifice Diam. (mm)	Kv Flow Factor	Pressure Max.(Bar)	Fluid Media*	Body	Disc
Wafer Body	EPDM Seals:	BARE STEM					
564516	50	50	107	16	Water	Ductile Iron	316SS
564520	65	65	212	16	Water	Ductile Iron	316SS
564524	80	80	404	16	Water	Ductile Iron	316SS
564532	100	100	799	16	Water	Ductile Iron	316SS
564548	150	150	1929	16	Water	Ductile Iron	316SS
Wafer Body	BUNA-N Sea	Is: BARE STEM					
564716	50	50	107	16	Air, Oil, Vacuum	Ductile Iron	316SS
564720	65	65	212	16	Air, Oil, Vacuum	Ductile Iron	316SS
564724	80	80	404	16	Air, Oil, Vacuum	Ductile Iron	316SS
564732	100	100	799	16	Air, Oil, Vacuum	Ductile Iron	316SS
564748	150	150	1929	16	Air, Oil, Vacuum	Ductile Iron	316SS


Kv = The number of  $m^3$  per hour of  $20^{\circ}$  C water at 1 bar pressure drop

<sup>\*</sup> Consult compatibility chart for other fluid media. Suitable for vacuum up to 29 inHg

<sup>\*</sup> Consult compatibility chart for other fluid media. Suitable for vacuum up to 29 inHg



### Dimensions 2" to 6" Sizes



#### Weight Pipe Size В C D Ε F G K 0 IS0 A J M 2.56 0.43 1.97 0.28 0.53 1.97 3.74 0.39 4.96 7.95 4) 5/8-11 4.74 6.6 lb inch 1.81 F05 7 13.5 95 10 126 202 120.5 3.0 kg 2-1/2 inch 2.56 0.43 1.97 0.28 0.53 2.56 4.13 0.39 5.28 8.50 1.93 4) 5/8-11 5.50 8.4 lb 139.7 mm 65 11 7 13.5 65 105 10 134 216 49 3.8 kg 3 2.56 0.43 0.28 0.53 3.15 4.72 0.39 6.18 4) 5/8-11 6.00 11.2 lb inch 1.97 9.96 1.93 F05 mm 13.5 120 10 157 253 152.4 5.1 kg 4 inch 2.56 0.43 1.97 0.28 0.53 3.94 5.79 0.51 6.57 11.06 2.19 8) 5/8-11 7.50 15.9 lb 7 65 11 50 13.5 100 147 13 167 281 56 190.5 7.2 kg mm 3.54 0.67 2.76 0.35 0.73 5.91 8.07 0.51 7.99 13.58 2.31 8) 3/4-10 9.50 29.8 lb 18.5 203 345 241.3 13.5 kg mm




### Valve Seating Torques (inch lbs)

	Maximum Differential Pressure (PSI)						
SIZE	50	100	145	200	230		
2	62	62	71	71	71		
2-1/2	97	97	106	115	115		
3	124	133	151	159	168		
4	186	195	212	239	248		
6	400	434	487	558	593		

### Valve Seating Torques (NM)

		Maximum Differential Pressure (Bar)					
SIZE	3.5	7	10	14	16		
DN50	7	7	8	8	8		
DN65	11	11	12	13	13		
DN80	14	15	17	18	19		
DN100	21	22	24	27	28		
DN150	45	49	55	63	67		





### Flow Capacity (Cv)

		Disc Open Angle							
SIZE	20°	30°	40°	50°	60°	70°	80°	90°	
2	1	5.5	16	33	54	82	113	124	
2-1/2	2.7	13	31	57	89	141	199	247	
3	7	32	62	106	163	248	350	470	
4	16	66	125	203	225	470	691	929	
6	59	150	260	422	665	1136	1785	2243	

Cv = The number of US gallons per minute of 60° F water at 1 psi pressure drop

### Flow Capacity (Kv)

		Disc Open Angle						
SIZE	20°	30°	40°	50°	60°	70°	80°	90°
DN50	0.9	4.7	13	29	47	71	97	107
DN65	2.3	11	26	49	77	121	170	212
DN80	6	28	54	91	140	213	301	404
DN100	14	57	108	175	262	404	594	799
DN150	51	129	224	363	572	977	1535	1929

Kv = The number of  $m^3$  per hour of  $20^{\circ}$  C water at 1 bar pressure drop



### **Hand Lever**

ACCESSORY **5650** 

Wafer or Lug Style Butterfly Valves 2" to 6" Sizes

### **Features**

- Powder epoxy coated steel hand lever
- 10 position locking handle
- Convenient installation and usage
- 304SS bolts and nuts

### **Appication**


Hand lever operator for wafer and lug style butterfly valves. The valve disc can be locked in any one of 10 positions with spring loaded lever. Hand lever kit includes lever, gear locking plate and stainless hardware for mounting.



### **Specifications**

Stock No.	Description
565001	Hand lever for valve sizes 2", 2-1/2", 3" and 4" (DN50, DN65, DN80, DN100)
565003	Hand lever for valve size 6" (DN150)

### **Dimensions**



Pipe Size		A	В	C	D	ISO	Weight	
2, 2-1/2, 3, 4	inch	1.14	7.28	1.10	0.43		0.90 lbs	
(DN50, 65, 80, 100)	mm	29	185	28	11	F05	0.41 kg	
6	inch	1.18	10.24	1.10	0.67		1.15 lbs	
(DN150)	mm	30	260	30	17	F07	0.52 kg	



# **Hand Wheel Gear Operator**

Wafer or Lug Style Butterfly Valves 2" to 6" Sizes

Accessory **5650** 


### **Features**

- Aluminum alloy housing
- Hand wheel control
- Steel input shaft and worm gear drive
- Easy ISO5211 mounting
- Waterproof enclosure
- Adjustable travel stops are standard and factory set
- 304SS bolts and nuts



### **Specifications**

Stock No.	Description
565006	Hand wheel gear operator for valve sizes 2", 2-1/2", 3" and 4" (DN50, DN65, DN80, DN100)
565008	Hand wheel gear operator for valve size 6" (DN150)



Pipe Size		A	В	C	D	E	F	G	Н	J	K	М	N	IS0	Weight
2, 2-1/2, 3, 4	inch	5.55	4.25	4.72	0.47	1.69	4.41	3.15	1.02	2.05	0.43	1.97	-	F05	2.9 lbs
(DN50, 65, 80, 100)	mm	141	108	120	12	43	112	80	26	52	11	50	M6x10 depth		1.32 kg
6	inch	6.77	4.69	7.87	0.47	2.01	5.12	3.94	1.02	2.05	0.67	2.76	-	F07	4.9 lbs
(DN150)	mm	172	119	200	12	51	130	100	26	52	17	70	M8x12 depth		2.22 kg

#### AHEAD OF THE FLOW®

### **Brass Gate Valve**

Brass Body • Non-Rising Stem • Full Port

#### 200 PSI/14 Bar Non-Shock Cold Working Pressure Truesdail LAB listed to NSF/ANSI 61-8

#### **MATERIAL LIST**

	1417	LIII/ LE EIO I
	PART	SPECIFICATION
1.	Nut	Steel plated ASTM A 108 Alloy G10100
2.	Name Plate	Aluminum ASTM B 209 Alloy 1100
3.	Handwheel	Cast Iron ASTM A 48 Class No. 35
4.	Stem	Brass ASTM B 16 Alloy C36000
5.	Packing Nut	Brass ASTM B 16 Alloy C36000 or
		B 584 Alloy C85700
*6.	Gland	Brass ASTM B 16 Alloy C36000
7.	Packing	Graphite/Rubber Non-Asbestos
8.	Bonnet	Brass ASTM B 584 Alloy C85700
9.	Lock Nut	Brass ASTM B 16 Alloy C 36000
10.	Wedge	Brass ASTM B 584 Alloy C85700
11.	Body	Brass ASTM B 584 Alloy C85700


<sup>\*</sup> Packing gland only for valves 1½" and larger.







**SI-8** Solder



#### **DIMENSIONS—WEIGHTS**

												Dime	ension	s											
		Т	I-8	S	I-8	TI	-8	S	l-8	Т	I-8	SI	-8	Т	I-8	SI-	-8		SI-	-8			WEIG	THE	
S	ize		4		A		В	E	3		C		C		D		)	Е		F		TI	-8		SI-8
In.	mm.	ln.	mm.	ln.	mm.	ln.	mm.	ln.	mm.	ln.	mm.	ln.	mm.	In.	mm.	ln.	mm.	ln.	mm.	Īn.	mm.	Lbs.	Kg.	Lbs.	Kg.
1/4	8	1.61	41	_	_	2.76	70	_	_	2.13	54	_	_	0.39	10	_	_	_	_	_	_	0.55	0.25	_	_
3/8	10	1.61	41	1.57	40	2.76	70	2.76	70	2.13	54	2.13	54	0.39	10	0.39	10	.50	13	0.38	10	0.55	0.25	0.55	0.25
1/2	15	1.69	43	1.77	45	2.83	72	2.83	72	2.13	54	2.13	54	0.50	12	0.50	13	.63	16	0.50	13	0.59	0.27	0.59	0.27
3/4	20	1.85	47	2.32	59	3.31	84	3.31	84	2.13	54	2.13	54	0.75	19	0.75	19	.88	22	0.75	19	0.77	0.35	0.77	.035
1	25	2.13	54	2.76	70	3.86	98	3.86	98	2.40	61	2.40	61	0.94	24	0.94	24	1.13	29	0.91	23	1.06	0.48	1.06	0.48
11/4	32	2.40	61	2.87	73	4.57	116	4.57	116	3.03	77	3.03	77	1.25	32	1.25	32	1.38	35	0.97	25	1.54	0.70	1.54	0.70
11/2	40	2.44	62	3.19	81	4.92	125	4.92	125	3.03	77	3.03	77	1.48	38	1.48	38	1.63	41	1.09	28	2.11	0.96	2.11	0.96
2	50	2.83	72	3.90	99	6.02	153	6.02	153	3.27	83	3.27	83	1.94	49	1.94	49	2.13	54	1.34	34	3.17	1.44	3.17	1.44
*21/2	65	3.50	89	4.61	117	7.32	186	7.32	186	4.13	105	4.13	105	2.48	63	2.48	63	2.63	67	1.47	37	3.79	2.63	5.79	2.63
*3	80	3.98	101	5.20	132	8.70	221	8.70	221	4.41	112	4.41	112	2.95	75	2.95	75	3.13	80	1.66	42	8.10	3.68	8.10	3.68
*4	100	4.57	116	_	_	10.16	258	_	_	6.67	172	_	_	3.62	92	_	_	_	_	_	_	20.94	9.52	_	

<sup>\*</sup>Conventional Port only

 $<sup>\</sup>dagger$  Available with Drain in sizes  $1\!\!/2$  and  $3\!\!/4$  for TI-8. Specify TI-8D on order.

# DelVal®SERIES 56/57



High Flow Resilient Seated Butterfly Valves
Wafer & Lug , Sizes 2"-24" / DN50-DN600
2"-12" Class 150 / 285 PSI
14"-24" PN16 / 230 PSI




Leading the Industry with Innovation by Design

DelTech Controls is pleased to offer top-of-the-line products in pipeline flow control. The DelVal Series 56 (wafer body) and Series 57 (lug body) Butterfly Valves have been developed with extensive application, design and manufacturing expertise. These products are produced by employing modern manufacturing practices under a robust quality assurance system. These practices ensure consistent product quality and dependable performance. The DelVal Series 56/57 Butterfly Valves have been designed to include state-of-the-art features that are described in this bulletin.


#### **Features**

- **1.** High Strength Stem Stem connection available in standard DelVal sizes.
- 2. Top plate drilled to fit ISO 5211 dimensions. All handles, gear operators, pneumatic and electric DelTorq actuators are designed to mount directly to DelVal Valves.
- **3.** Four flange locating ribs for sizes up to 12" and four flange locating holes from size 14" to 24" for easy alignment of valve during installation. They meet ANSI #125/150 or other world drilling standards.
- **4.** Unique stem retention system to provide blow-out proof stem and easy assembly and disassembly of valve.
- **5.** Unique "integral rubber rich seat" in various elastomeric materials provides ultimate sealing in a wide variety of applications. Integral rubber rich seat offers all the advantages of a cartridge seat and the integrity of one-piece body/seat design. This construction allows easy installation between tightly spaced flanges without using flange spreader. Offers 100% bi-directional sealing against vacuum and dead end service to full rated pressure without the use of a downstream flange.
- **6**. Heavy duty one-piece body. Standard coating is two coats of hard, zinc-rich epoxy for excellent corrosion resistance.



- **7.** Heavy duty acetal bushing absorbs the forces acting on the stem/disc assembly due to line pressure.
- **8.** The secondary sealing is achieved through double integrally molded 'O' rings which are compressed around the stem.
- **9.** Positive disc stem engagement by a precision machined square drive, eliminating potential leak path and failure of stem joint.
- **10.** Precision machined radius on the upper and lower disc hubs is pressed against upper and lower seat sealing faces for achieving primary sealing between disc and seat.

- **11.** High flow disc design provides a streamlined flow passage, enhanced flow characteristics and reduced resistance to flow especially for control applications.
- **12.** Nylon PA 12 coated disc option ensures excellent corrosion resistance to several chemical media. The hard, non-porous sintered polymer has very low hygroscopicity and is suitable for use in drinking water and food grade applications.
- **13.** Flange gasket ('0' ring) is integral to the body lining which eliminates the need of separate gasket.



FOR 14" & ABOVE

DIMENSIONS (Inch)

DIMENSIONS (mm)

_																				
( \	Valve S	Size	CA.		αn	_	Call	TOP F	LANGE	DRILLING	ØG	н	١.	Key	K	LUG	BOLTIN	G DATA	Weight	s In Lbs
Inch	ies	DN	ØA	*B	ØD	E	Sq'F'	BC	NO. OF HOLES	HOLE DIA.	ยน	п	J	Size	N.	BC	NO. OF HOLES	THREADS UNC/UN-2B	Wafer (Series 56)	Lug (Series 57)
2		<mark>50</mark>	3.54	1.69	2.83	4.13	1.96	1.96	4	0.27	0.55	0.39	0.78	-	1.29	4.75	4	5/8-11	4.96	6.61
2 1/	/2	65	4.13	1.81	3.46	4.48	1.96	1.96	4	0.27	0.55	0.39	0.78	-	2.02	5.50	4	5/8-11	5.73	7.82
3		80	4.80	1.81	4.13	4.72	1.96	1.96	4	0.27	0.55	0.39	0.78	-	2.67	6.00	4	5/8-11	6.83	8.92
4		100	6.02	2.06	5.31	5.31	1.96	1.96	4	0.27	0.63	0.43	0.78	-	3.52	7.50	8	5/8-11	9.92	15.43
5		125	7.24	2.19	6.45	5.90	2.75	2.76	4	0.39	0.75	0.51	1.25	-	4.54	8.50	8	3/4-10	15.87	23.58
6		150	8.26	2.19	7.40	6.49	2.75	2.76	4	0.39	0.75	0.51	1.25	-	5.45	9.50	8	3/4-10	17.19	26.23
8		200	10.39	2.38	9.52	8.07	3.93	2.76/4.01	4	0.39/0.47	0.87	0.63	1.25	-	7.38	11.75	8	3/4-10	31.41	41.33
10	)	250	12.44	2.69	11.49	9.25	3.93	4.01	4	0.47	1.18	0.87	2.0	-	9.30	14.25	12	7/8-9	47.61	65.25
12	2	300	14.56	3.06	13.62	10.82	3.93	4.01	4	0.47	1.18	0.87	2.0	-	11.11	17.00	12	7/8-9	66.13	97.00
14	ļ	350	16.22	3.06	15.11	12.20	4.72	4.92	4	0.55	1.38	-	2.00	0.39x0.39	12.70	18.75	12	1-8	88.18	123.01
16	j	400	18.42	4.00	17.24	13.38	4.72	4.92	4	0.55	1.38	-	2.00	0.39x0.39	14.65	21.25	16	1-8	132.71	186.51
18	3	450	20.66	4.48	19.40	14.56	Ø6.89	5.51	4	0.70	1.57	-	2.36	0.31x0.47	16.52	22.75	16	1 1/8-8	196.21	240.30
20		500	22.75	5.00	21.57	15.74	Ø6.89	5.51	4	0.70	1.57	-	2.36	0.31x0.47	18.43	25.00	20	1 1/8-8	239.20	309.08
24	ļ	600	26.96	6.06	25.59	18.30	Ø8.27	6.50	4	0.83	1.97	-	2.76	0.39x0.47	22.55	29.50	20	1 1/4-8	385.80	477.07

Valv	e Size	~*		an.	_	C-IFI	TOP F	LANGE	DRILLING	ØG			Key	К	LUG	BOLTIN	G DATA	Weight	s In Kg
Inches	DN	ØA	*B	ØD	E	Sq'F'	BC	NO. OF HOLES	HOLE DIA.	ØG	Н	J	Size	,	BC	NO. OF HOLES	THREADS UNC/UN-2B	Wafer (Series 56)	Lug (Series 57)
2	50	90	43	72	105	50	50	4	7	14	10	20	-	32.7	120.7	4	5/8-11	2.25	3.00
2.5	65	105	46	88	114	50	50	4	7	14	10	20	-	51.4	139.7	4	5/8-11	2.60	3.55
3	80	122	46	105	120	50	50	4	7	14	10	20	-	67.8	152.4	4	5/8-11	3.10	4.05
4	100	153	52	135	135	50	50	4	7	16	11	20	-	89.5	190.5	8	5/8-11	4.50	7.00
5	125	184	56	164	150	70	70	4	10	19	13	32	1	115.3	215.9	8	3/4-10	7.20	10.70
6	150	210	56	188	165	70	70	4	10	19	13	32	1	138.4	241.3	8	3/4-10	7.80	11.90
8	200	264	60	242	205	100	70/102	4	10/12	22	16	32	-	187.6	298.5	8	3/4-10	14.25	18.75
10	250	316	68	292	235	100	102	4	12	30	22	51	-	236.4	362.0	12	7/8-9	21.60	29.60
12	300	370	78	346	275	100	102	4	12	30	22	51	-	282.4	431.8	12	7/8-9	30.00	44.00
14	350	412	78	384	310	120	125	4	14	35	-	51	10x10	322.4	476.2	12	1-8	40.00	55.80
16	400	468	102	438	340	120	125	4	14	35	-	51	10x10	372.3	539.7	16	1-8	60.20	84.60
18	450	525	114	493	370	Ø175	140	4	18	40	-	60	8x12	419.8	577.8	16	1 1/8-8	89.00	109.00
20	500	578	127	548	400	Ø175	140	4	18	40	-	60	8x12	468.1	635.0	20	1 1/8-8	108.50	140.20
24	600	685	154	650	465	Ø210	165	4	21	50	-	70	10x12	572.7	749.3	20	1 1/4-8	175.00	216.40

<sup>\*</sup> Face to Face dimension "B", generally conforming to API 609 Category A//BS EN 558-1 Series 20/ISO 5752 Series 20/MSS SP 67/ASME B 16.10 All bolt holes 1 1/8" and larger have a 8-UN thread series as per API 609

Valve Size		2"	2.5"	3"	4"	5"	6"	8"	10"	12"	14"	16"	18"	20"	24"
Full Rated Pressure Valve	50	62	106	115	241	360	484	878	1409	2366	3064	3684	5795	6741	9601
	100	72	124	142	256	393	545	977	1586	2677	3527	4428	7273	8441	12482
ΔP. PSI	150	80	142	177	271	426	582	1083	1756	2987	3980	5178	8756	10126	15576
21, 1 01	230	150	212	283	478	575	1062	1859	2823	4142	6106	8187	10550	13329	26809
	285	177	248	354	540	637	1150	2168	3098	4673	-	-	-	-	-
Reduced Disc Dia. △P, PSI	50	-	-	-	133	187	267	623	771	1259	2159	2627	3649	4285	6500
5 11 5	3.5	7	12	13	27	41	55	99	159	267	346	416	655	762	1085
Full Rated	7	8	14	16	29	44	62	110	179	302	398	500	822	954	1410
Pressure Valve	10	9	16	20	31	48	66	122	198	337	450	585	989	1144	1760
△P, Bar	16	17	24	32	54	65	120	210	319	468	690	925	1192	1506	3029
	Class 150	20	28	40	61	72	130	245	350	528	-	-	-	-	-
Reduced Disc Dia ∧P Bar	3.5	_	-	-	15	21	30	70	87	142	244	297	412	484	734

#### Disc

- ◆ DI ASTM A 536 Grade 65-45-12 + Epoxy coated
- 316 Stainless Steel ASTM A351 Grade CF8M
- Nylon 12 Coated Ductile Iron ASTM A536 Grade 65-45-12 (Optional)

#### General Design and Manufacturing Standard: API 609 / BS EN -593

Testing Standard: API 598 / BS EN 12266-1

#### Seat Temperature Range:

**Operators** 

Soat Tuno	Temperatu	ire Range
Seat Type	Min.	Max.
EPDM	-13°F (-25°C)	302° F (150°C)
BUNA-N	-13° F (-25°C)	212° F (100°C)

Valves up to size 8" can be supplied

with lever handles for manual

operation. Optional accessories for

hand-lever operation can be provided

for various flow control requirements.

Pad locking can also be provided for

preventing unauthorized operation.

#### Stem

- 410 Stainless Steel ASTM A479 Type 410
- ASTM A564 17-4-PH

#### Seat

- EPDM Food Grade
- Buna-N Food Grade

#### **Pressure Rating:**

For bi-directional bubble tight shut off and full vacuum service with disc in the closed position.



Valves up to size 24" can be direct mounted with gear operators for pipelines at high elevations.



STEM BUSHING (ACETAL)

**BODY** 

STEM

All valves can be direct mounted with pneumatic actuators or electric actuators and accessories for complete automation options such as fail open/close & positioner controlled. Valves can be mounted with manual overrides.

Inch	DN	PSIG	BARG
2"- 24"	50-600	50	3.5
2"- 24"	50-600	150	10
2"- 24"	50-600	230	16
2"- 12"	50-300	285	Class150

Dead-End Service: Without a downstream flange installed, the deadend pressure ratings are equal to the values stated above.

manual operation. Gear operators can also be attached with chainwheel operators for opening or closing valves located on

All statements, technical information and recommendations in the bulletin are for general use only. DelTech is not responsible for suitability or compatibility of these products in relation to system requirements. Consult DelTech distributors or factory for the specific requirements and material selection for your intended application. DelTech reserves the right to change or modify product design or product without prior notice. DelVal® - Registered trademark of DelTech Controls.

Distributor



#### **DelTech Controls LLC**

6068 Highway 73 Geismar, LA 70734 USA

Phone: (225) 744-4326

(225) 744-4328

Email: sales@deltechcontrols.com

Website: www.deltechcontrols.com

#### DelVal Flow Controls Pvt. Ltd.

(A division of DelTech Controls LLC, USA) Office & Works: Gat. No 625/1/2, Kuruli, Tal. Khed, Pune-Nasik Highway,

Pune 410501, INDIA

Phone: +91-2135-662700 +91-2135-662727

Email: salesindia@deltechcontrols.com



# Installation, Operation, and Maintenance Guide For Apollo Series Valves:

2 Piece Threaded and Solder End Ball Valves





### INSTALLATION, OPERATION AND MAINTENANCE OF THREADED AND SOLDER END APOLLO BALL VALVES

Valves must be installed in piping systems that comply to the applicable A.N.S.I. B31 Standard. Special considerations must be taken with respect to pipe line expansions and contractions and the media expansions and contractions within the piping system.

#### THREADED END INSTALLATION

- 1. Pipe connections to be threaded into these valves should be accurately threaded, clean and free of dirt and metal shavings.
- 2. Teflon tape is recommended for use as the pipe joint sealant.
- 3. Use two wrenches when making the pipe joint. Apply one wrench on the hex pads nearest the joint being tightened to prevent breaking the retainer-to-body seal.
- 4. UNION END VALVES: Remove the union nut from valve and place onto pipe. Thread the tailpiece onto the pipe using a smooth jaw wrench. Thread the union nut onto the valve body and *lightly* torque.

#### SOLDER END INSTALLATION

- 1. Piping connections to be soldered into these valves should be cut square and then cleaned with an appropriate cleaner or flux.
- 2. These valves are designed to be soft soldered. Apply heat with the flame directed away from the center of the valve body. Excessive heat can harm the Teflon seats. Solder valves only in the fully open position.
- 3. UNION END VALVES: Remove the union nut from valve and place onto pipe. Solder the tailpiece onto pipe, thread union nut onto valve body and *lightly* torque.

#### **OPERATION**

The valve is marked showing proper rotation direction for "ON" and "OFF" positions. Rotation is clockwise for "OFF" and counterclockwise for "ON".

#### **MAINTENANCE**

Normal stem packing wear can be compensated for by tightening the packing gland screw clockwise. If all of the adjustment to the packing gland screw has been made, remove the lever and packing gland nut and add one or two replacement bearings on top of the old packing. Reassemble the lever and packing gland nut.

CAUTION: Do not disassemble Valve while under pressure nor with entrapped hazardous fluids therein.

General repair of the valve can be made by:


- 1. Close valve.
- 2. Remove retainer from body center section by turning counterclockwise
- 3. 1/4" thru 1" valves only; pry out the top seat being careful not to damage the ball. 1-1/4" thru 3" valves; the top seat will come out with the retainer.
- 4. Push ball out of body with finger.
- 5. Remove packing gland nut by turning counterclockwise and push stem down into body to remove.
- 6. Remove all seats and seals. To facilitate removal of the stem packing, cut with knife.
- 7. Replace all seats and seals as furnished in the Service Kit. Inspect the ball and stem for excessive wear or damage and replace if necessary.
- 8. Reverse the above procedure to reassemble using a sealant on the retainer threads equivalent to Loctite Hydraulic Sealant. NOTE: VALVES IN OXYGEN SERVICE CAN ONLY BE SEALED WITH AN OXYGEN COMPATIBLE THREAD SEALANT.

Union End Valves cannot be easily field repaired, therefore it is recommended that the main valve section be replaced.

NOTE: ALWAYS TEST VALVE AND SYSTEM BEFORE PUTTING THE SYSTEM INTO SERVICE.

<u>Bronze Valves</u>: **WARNING**: This product is made from Bronze Alloys which contain lead; a chemical known to the State of California to cause cancer and birth defects and other reproductive harm.

## **General 2-PC. BALL VALVE Identification**



- 1. Lever and grip
- 2. Stem packing
- 3. Stem bearing
- 4. Ball
- 5. Seat (2)

- 6. Retainer
- 8. Stem
- 9. Lever nut
- 10. Body seal
- 11. Body



# 94A SERIES Full-Port Brass Ball Valve

Job Name:	Contractor:
Job Location:	P.O. Number:
Engineer:	Representative:
Tag:	Wholesale Distributor:

#### **DESCRIPTION**

The 94A full port ball valves are designed for reliable yet economic applications using corrosion resistant brass with all pertinent agency approvals.

#### **FEATURES**

- Full-Port
- Blow-out Proof Stem Design
- Adjustable Stem Packing Nut
- Silicone Free

#### **MATERIALS**

Body Forged Brass (Cu >57%)
Retainer Forged Brass (Cu >57%)
Ball Brass, Cr plated
Stem Brass, Cr plated

Seat Ring PTFE Stem Seal NBR

Packing Nut Steel w/corrosion resistant plating


Packing Gland Brass Friction Washer PTFE

Handle Steel w/corrosion resistant plating

Handle Cover PVC

Handle Nut Steel w/corrosion resistant plating

#### PERFORMANCE RATING



#### **APPROVALS**

CSA: 1/4"-4" NPT per ANSI Z21.15/CGA 9.1 (1/2 psi)

1/4"-4" NPT per ASME B16.44 (5 psi)
1/2"-2" NPT per ASME B16.33 (125 psi)
2 1/2'-4" NPT per ASME B16.38 (125 psi)

UL: Guides YQNZ, YRBX, YRPV, and YSDT (NPT only)


**FM:** 1/4"-2" per FM1140 (<175 psi)

**NSF:** 1/4"-4" meets ANSI/NSF 61 Section 8 (61<5)



#### **DIMENSIONS**

Part No.	Size	Α	В	С	D	E	Wt.
			NPT				(lbs.)
94A-101	1/4"	0.395	1.746	1.278	3.543	-	0.33
94A-102	3/8"	0.407	1.756	1.278	3.543	-	0.30
94A-103	1/2"	0.583	2.047	1.921	3.543	-	0.44
94A-104	3/4"	0.748	2.362	2.087	3.780	-	0.66
94A-105	1"	0.945	2.756	2.559	4.528	-	1.10
94A-106	1 1/4"	1.260	3.307	2.953	4.528	-	1.57
94A-107	1 1/2"	1.575	3.661	3.346	5.512	-	2.40
94A-108	2"	1.969	4.181	3.681	5.512	-	3.37
94A-109	2 1/2"	2.520	5.378	4.764	8.661	-	7.60
94A-100	3"	2.953	6.039	5.079	8.661	-	9.36
94A-10A	4"	3.898	7.386	5.866	9.606	-	16.85
			SWEAT				
94A-203	1/2"	0.583	2.047	1.839	3.543	0.630	0.38
94A-204	3/4"	0.748	2.748	1.996	3.780	0.878	0.64
94A-205	1"	0.945	3.228	2.441	4.528	1.130	0.99
94A-206	1 1/4"	1.260	3.819	2.854	4.528	1.378	1.40
94A-207	1 1/2"	1.575	4.425	3.169	5.512	1.630	2.17
94A-208	2"	1.969	5.315	3.449	5.512	2.130	2.97
94A-209	2 1/2"	2.520	6.283	4.764	8.661	2.630	6.36
94A-200	3"	2.953	7.150	5.079	8.661	3.130	8.32



### Technical Data and Standards

#### Physical Properties of Thermoplastics Used In Asahi Valves\*

		-					
Properties	Unit	PVC	HI-PVC	CPVC	PP	PVDF	Test Method
Specific Gravity	-	1.43	1.40	1.54	0.92	1.76	ASTM D792
Tensile Strength	psi	7690 - 8700	7110 - 7540	8410 - 9280	4210 - 4930	7980 - 8700	ASTM D638
Elongation	%	60 - 120	60 - 180	30 - 80	200 - 400	30 - 60	ASTM D638
Tensile Modulus	10³ psi	421 - 479	392 - 421	479 - 508	116 - 174	174 - 203	ASTM D638
Flexural Strength	psi	11310 - 15660	11310 - 12760	14210 - 15660	7830 - 9280	13490 - 14940	ASTM D790
Flexural Modulus	10³ psi	377 - 406	290 - 334	421 - 450	203 - 232	218 - 261	ASTM D790
Compressive Strength	psi	12760 - 14210	8410 - 11310	14210 - 15660	8410 - 10010	12760 - 14210	ASTM D695
Compressive Modulus	10³ psi	232 - 261	189 - 218	247 - 290	131 - 160	145 - 203	ASTM D695
Poisson's Ratio	-	0.37	NA	0.35	0.44	0.28	ASTM D638/D790
Hardness (Rockwell R)	degrees	114 - 116	112 - 116	117	95	110	ASTM D785
Impact Strength (Izod) with V-Notch	kJ/m²	3 - 5	10 - 15	4 - 6	4 - 7	8 - 10	ASTM D256
Heat resistance	°F	32 ~ 140	23 ~ 140	32 ~ 194	- 4 ~ 194	- 40 ~ 248	-
Deflection Temperature (at 66 psi)	°F	163 - 167	162 - 165	250	230 - 244	302	ASTM D648
Thermal Expansion	10⁻⁵mm/ mm/℃	6 - 8	7 - 8	6 - 8	11 - 12	11 - 12	ASTM D696
Thermal Conductivity	Kcal/mh⁰F	0.15	0.11	0.14	0.09	0.11	ASTM C177
Dielectric Strength	kV/inch	0.90	NA	0.90	1.02	1.18	ASTM D149
Volume Resistivity	ohm-inch	2.17 x 10 <sup>15</sup>	NA	2.28 x 10 <sup>16</sup>	1.93 x 10 <sup>16</sup>	1.97 x 10 <sup>15</sup>	ASTM D257
Dielectric Constant							
10 Hz	-	2.8 - 3.0	NA	NA	NA	NA	
60 Hz	-	3.15	NA	2.93	2.42	9.8	ASTM D150
10 <sup>3</sup> Hz	-	3.14	NA	2.92	2.41	9.5	
10 <sup>6</sup> Hz	-	2.85	NA	2.69	2.41	7.5	
Dissipation Factor							
60 Hz	10-2	1.18	NA	1.09	NA	0.05	ACTN4 D450
10 <sup>3</sup> Hz	10-2	1.91	NA	1.10	0.044	0.048	ASTM D150
10 <sup>6</sup> Hz	10-2	1.72	NA	0.92	0.063	0.160	
Water absorption 24 hr. 1/8 inch thickness	%	0.07	NA	0.15	0.01	0.03	ASTM D570

#### **Standards**

#### ANSI B1.20.1 (Was B2.1)

#### (American National Standards Institute)

This specification details the dimensions and tolerance for tapered pipe threads. This standard is referenced in the ASTM standard for threaded fittings mentioned above.

#### **ASTM STANDARD D-1784 A**

#### (American Society for Testing and Materials)

This standard covers PVC and CPVC compounds used in the manufacture of plastic pipe, valves, and fittings. It provides a means for selecting and identifying compounds on the basis of a number of physical and chemical criteria. Conformance to a particular material classification in this standard requires meeting a number of minimum physical and chemical properties.

### **ANSI B16.5**

This specification sets forth standards for bolt holes, bolt circles, and overall dimensions for steel 150 lbs flanges.

#### **ASTM STANDARD D-3222**


This standard covers the polymerization method and physical properties of PVDF (polyvinylidene fluoride) fluoroplastic materials for molding and extrusion. Organizations other than ASTM issue standards that are commonly encountered in industrial thermoplastic piping design. The most important of these are described here.

#### ASTM STANDARD D-4101 (FORMERLY D-2146)

This standard covers the polymeric content and physical characteristics of PP (polypropylene) plastic materials for injection molding and extrusion.

\* This data for reference only.

### Flow Characteristics



This table shows the relationship between valve opening and Cv values. Each curve is the representative average of all sizes for a particular type of valve. Cv value is the percentage of the full open Cv. The Cv value can be found in the appropriate section of this catalog.

Using the Cv value to calculate the differential pressure or flow rate through a valve:

Whenever a fluid passes through a valve, there will be a drop in pressure. The upstream pressure less the downstream pressure is know as the differential pressure, or:

$$P_1 - P_2 = P$$

where,

P<sub>1</sub> = upstream pressure P<sub>2</sub> = downstream pressure P = dif ferential pressure Cv is the flow rate through a valve which will produce a differential pressure of 1 psi.

$$P = (Q/Cv)^{2} s.g.$$
  
 $Q = Cv (P/s.g.)$ 

$$Cv = Q (s.g./P)$$

where,

P = dif ferential pressure (psi)

s.g.= specific gravity

Q = flow rate (gpm)

For further technical information consult factory.

### **Part Numbers**

All part numbers for Asahi/America products are seven digits long. In general, the first four digits specify the product and the last three digits specify the size. In this catalog, part numbers will be referenced with the first four digits followed by "\* \* \*", signifying that the size code should follow. The Part Numbers Table, below, defines the three digit code for various valve sizes.

Nominal Size	Asahi/America	Nominal Size	Asahi/America
(inches)	Part Number	(inches)	Part Number
3/8	****003	5	****050
1/2	****005	6	****060
3/4	****007	8	****080
1	****010	10	****100
1 1/4	****012	12	****120
1 1/2	****015	14	****140
2	****020	16	****160
2 1/2	****025	18	****180
3	****030	20	****200
4	****040	24	****240

#### Type 21 Ball Valves

Body	Elastomer	Connection	1/2" - 2"	2 1/2" - 6"
PVC	EPDM	Soc	1601***	1602***
PVC	EPDM	Thd	1601***	1603***
PVC	EPDM	Flg	1604***	1604***
PVC	FKM	Soc	1605***	1606***
PVC	FKM	Thd	1605***	1607***
PVC	FKM	Flg	1608***	1608***
CPVC	EPDM	Soc	1609***	1610***
CPVC	EPDM	Thd	1609***	1611***
CPVC	EPDM	Flg	1612***	1612***
CPVC	FKM	Soc	1613***	1614***
CPVC	FKM	Thd	1613***	1615***
CPVC	FKM	Flg	1616***	1616***
PP	EPDM	DIN Soc	1638***	1638***
PP	EPDM	IPS Soc	1618***	1618***
PP	EPDM	Thd	1619***	1619***
PP	EPDM	Butt	1620***	1620***
PP	EPDM	Flg	1621***	1621***
PP	FKM	DIN Soc	1652***	1652***
PP	FKM	IPS Soc	1622***	1622***
PP	FKM	Thd	1623***	1623***
PP	FKM	Butt	1624***	1624***
PP	FKM	Flg	1625***	1625***
PVDF	FKM	DIN Soc	1666***	1666***
PVDF	FKM	IPS Soc	1626***	1626***
PVDF	FKM	Thd	1627***	1627***
PVDF	FKM	Butt	1628***	1628***
PVDF	FKM	Flg	1629***	1629***

#### Type 23 Multiport Ball Valves

Body	Elastomer	Connection	1/2" - 4"
PVC	EPDM	Soc	2510***
PVC	EPDM	Thd	2511***
PVC	EPDM	Flg	2512***
PVC	FKM	Soc	2513***
PVC	FKM	Thd	2514***
PVC	FKM	Flg	2515***
CPVC	EPDM	Soc	2516***
CPVC	EPDM	Thd	2517***
CPVC	EPDM	Flg	2518***
CPVC	FKM	Soc	2519***
CPVC	FKM	Thd	2520***
CPVC	FKM	Flg	2521***
PP	EPDM	DIN Soc	2522***
PP	EPDM	IPS Soc	2523***
PP	EPDM	Thd	2524***
PP	EPDM	Butt	2525***
PP	EPDM	Flg	2526***
PP	FKM	DIN Soc	2527***
PP	FKM	IPS Soc	2528***
PP	FKM	Thd	2529***
PP	FKM	Butt	2530***
PP	FKM	Flg	2531***
PVDF	FKM	DIN Soc	2532***
PVDF	FKM	IPS Soc	2533***
PVDF	FKM	Thd	2534***
PVDF	FKM	Butt	2535***
PVDF	FKM	Flg	2536***

#### **Quarter-Bloc Ball Valves**

Body	Elastomer	Connection	1/2"-2"
PVC	EPDM	SOC	1640***

#### **Gate Valves**

Body	Gate	Elastomer	Connection	1 1/2"-14"
PVC	PP	EPDM	Flg	1251***
PVC	SBR	EPDM	Flg	1252***

#### **Constant Flow Valves**

Body	Elastomer	Connection	1" - 4"
PVC	EPDM	Flg	1307***

#### **Trademarks**

Air-Pro, Duo-Pro, Electromni, FloSonex, Fluid-Lok, Labcock, Multiport, Omni, Poly-Flo, Poly-Pure, Purad, Proline, Pro-Tek, Pro-Vent, Proweld, and UltraPro are registered trademarks of Asahi/America, Inc.

Hypalon is a registered trademark of E. I. du Pont de Nemours and Company.

AFLAS is a registered trademark of Asahi Glass Co., Ltd.

Halar is a registered trademark of Ausimont.

Contents

### **Ball Valve Type 21**

#### User's Manual



### (1) General operating instructions \_\_\_\_\_\_1 (2) General instructions for transportation, unpacking and storage $\hspace{0.1cm} \hspace{0.1cm} (3) \quad \text{Name of parts} \qquad \qquad \qquad 2$ (4) Comparison between working temperature and pressure 3(5) Installation procedure 4 Operating procedure 9 (7) Method of Adjusting face pressure between ball and seat 9 (8) Disassembling method for parts replacement 10 (9) Mounting actuator, metal Ensert and base(panel) 11 (10) Inspection items 13 (11) Troubleshooting 13 (12) Handling of residual and waste materials 13



### (1) General operating instructions


0	Operate the valve within the pressure Vs temperature range.  (The valve can be damaged by operating beyond the allowable range.)
0	Select a valve material that is compatible with the media, refer to "CHEMICAL RESISTANCE ON ASAHI AV VALVE".
	(Some chemicals may damage incompatible valve materials.)
0	Do not use the valve to fluid containing slurry. (The valve will not operate properly.)
0	Do not use the valve on condition that fluid has crystallized. (The valve will not operate properly.)
0	Do not step on the valve or apply excessive weight on valve. (It can be damaged.)
0	Do not exert excessive force in closing the valve.
0	Make sure to consult a waste treatment dealer to dispose of the valves.
	(Poisonous gas is generated when the valve is burned improperly.)
0	Allow sufficient space for maintenance and inspection.
0	Keep the valve away from excessive heat or fire. (It can be deformed, or destroyed.)
0	The valve is not designed to bear any kind of external load. Never stand on or place anything heavy on the valve at anytime.
0	Certain liquid such as H2O2, NaClO, etc may be prone to vaporization which may cause irregular pressure increases, which may destroy the valve.
(2) (	General instructions for transportation, unpacking and storage
(2) (	beneral instructions for transportation, unpacking and storage
0	Keep the valve packed in the carton or box as delivered until installation.
0	Keep the valve away from any coal tar, creosote (antiseptic for wood), termite insecticide, vermicides, and
	paint. (This could cause swelling damage the valve.)
0	Do not impact or drop the valve. (It can be damaged.)


Ball Valve Type 21


O Avoid scratching the valve with any sharp object.

#### (3) Name of parts

#### Nominal size 15-50mm (1/2"-2")









No.	DESCRIPTION	No.	DESCRIPTION
1	Body	7	Seat
2	Ball	8	O-ring (A)
3	Carrier	9	O-ring (B)
(4b)	End connector (Flanged end type)	10	Cushion
(4c)	End connector (Socket end type)	(1)	O-ring (C)
(4d)	End connector (Threaded end type)	(12)	O-ring (D)
(4e)	End connector(Spigot type)	(13)	Stop ring
(5)	Union nut	(14)	Handle
(6)	Stem	(15)	Screw

#### (4) Comparison between working temperature and pressure


#### Nominal size: 15mm-50mm (1/2"-2")



#### Nominal size: 65mm (2 1/2")



#### Nominal size: 80mm, 100mm (3", 4")



Caution

Do not operate the valve beyond the range of working temperature and pressure. (The valve can be damaged.)

#### (5) Installation procedure

#### Flanged type (Material: PVC,C-PVC,PP,PVDF)

Necessary items

Torque wrench

Spanner wrench

AV gasket

Bolt, Nut, Washer (For many flanges specification)

(When a non-AV gasket is used, a different tightening torque specification should be followed.)

#### Procedure

- 1) When the union nut ⑤ flange assembly set was removed or loosen from body ①, O-ring (A) ⑧ should be installed into carrier and body groove. (In either horizontal or vertical installation, if necessary apply a small amount of lubricant to O-ring to hold in place.) Align union nut and end connector with the body. Insure end connector mates with body and O-ring. Make certain union nut threads onto body smoothly. Tighten union nuts on each side valve until hand tight. Then using a strap wrench tighten union nuts uniformly on each side approx 90° -180° turns, 1/4 to 1/2 turns.
- 2) Set the AV gasket between the flanges.
- 3) Insert washers and bolts from the pipe side, insert washers and nuts from the valve side, then temporarily tighten them by hand.




#### Caution

The parallelism and axial misalignment of the flange surface should be under the values shown in the following table to prevent damage the valve.

(A failure to observe them can cause destruction due to stress application to the pipe)

#### Unit: mm (inch)


Nom. Size	Axial Misalignment	Parallelism (a-b)
15-32mm (1/2"-1 1/4")	1.0mm (0.04")	0.5mm (0.02")
40-80mm (1 1/2"-3")	1.0mm (0.04'')	0.8mm (0.03")
100mm (4'')	1.0mm (0.04")	1.0mm (0.04")



4) Tighten the bolts and nuts gradually with a torque wrench to the specified torque level in a diagonal manner. (Refer to fig.1.)

#### Recommended torque value

	•			- 0 - 1
Nom, Size	15-20mm	25-40mm	50, 65 mm	80, 100 mm
Noili. Size	(1/2"-3/4")	(1"-1 1/2")	(2", 2 1/2")	(3", 4")
	17.5	20.0	22.5	30.0
Torque value	{179}	{204}	{230}	{306}
	[155]	[177]	[230]	[266]





#### Caution

Avoid excessive tightening. (The valve can be damaged.)

#### Threaded type (Material: PVC,C-PVC,PP,PVDF)

#### Necessary items

- Sealing tape (A non-sealing tape can cause leakage.)
- Strap wrench (Do not use Pipe wrench.)
- Spanner wrench



Caution

Make sure that the threaded connections are plastic x plastic.

(Metallic thread can cause damage.)

#### **Procedure**

- 1) Wind a sealing tape around the external thread of joint, leaving the end (about 3mm) free.
- 2) Loosen the union nut 5 with a strap wrench..
- 3) Remove the union nut 5 and the end connector 4d.
- 4) Lead the union nut (5) through the pipe.
- 5) Tighten the external thread of the joint and the end connector 4d hardly with hand.
- 6) Using a spanner wrench, screw in the end connector 4d by turning 180° -360° carefully without damaging it.



Caution

Avoid excessive tightening. (The valve can be damaged.)

- 7) Make sure that the O-ring (A) (8) is mounted.
- 8) Set the end connector 4d and union nut 5 directly on the body without allowing the O-ring (A) 8 to come off.
- 9) Tighten union nuts 5 on each valve until hand tight.
- 10) Using a strap wrench tighten union nuts uniformly on each on each side approx  $90^{\circ}$  -180° turns, 1/4 to 1/2 turns.



Caution

Avoid excessive tightening. (The valve can be damaged.)

#### Socket type (Material: PVC, C-PVC)

Necessary items

- Adhesive for hard vinyl chloride pipes
- Strap wrench (Do not use the pipe wrench)



Caution

Do not install a socket type valve where the atmospheric temperature is  $5^{\circ}$ C or lower. (The valve can be damaged.)

#### **Procedure**

- 1) Loosen the union nut 5 with a strap wrench.
- 2) Remove the union nut 3 and end connector 4.
- 3) Lead the union nut through the pipe.
- 4) Clean the hub part of the end connector 4c by wiping the waste cloth.
- 5) Apply adhesive evenly to the hub part of the end connector @ and the pipe spigot.



Caution

Do not apply more adhesives than necessary.

(The valve can be damaged due to solvent cracking.)

Adhesive quantity (guideline)

Nom. Size	15mm	20mm	25mm	32mm	40mm	50mm	65mm	80mm	100mm
	(1/2")	(3/4")	(1")	(1 1/4")	(1 1/2")	(2")	(2 1/2")	(3")	(4")
Quantity(g)	1.0	1.3	2.0	2.4	3.5	4.8	6.9	9.0	13.0

- 6) After applying adhesive, insert the pipe quickly to the end connector 4c and leave it alone for at least 60 seconds.
- 7) Wipe away overflowing adhesive.
- 8) Make sure that O-ring(A) (8) is mounted
- 9) Set the end connector & and union nut 5 directly on the body without allowing the O-ring (A) 8 to come off.
- 10) Tighten union nut 5 hardly with hand.
- 11) Using a strap wrench tighten union nuts uniformly on each side approx 90° -180° turns, 1/4 to 1/2 turns.



Caution

Avoid excessive tightening. (The valve can be damaged.)

Socket type (Material: PP, PVDF)

Necessary items

- Strap wrench (Do not use the pipe wrench.)
- Sleeve welder or automatic welding machine
- User's manual for sleeve welder or automatic welding machine

#### **Procedure**

- 1) Loosen the union nut with a strap wrench.
- 2) Remove the union nut (5) and the end connector.
- 3) Lead the union nut (5) through the pipe.
- 4) For the next step, refer to the user's manual for the sleeve welder or the automatic welding machine.
- 5) After welding, make sure that the O-ring (A) (8) is mounted.
- 6) Set the end connector ⓐ and the union nut ⑤ directly without allowing the O-ring (A) ⑧ to come off.
- 7) Tighten union nut (5) hardly with hand.
- 8) Using a strap wrench tighten union nuts uniformly on each side approx  $90^{\circ}$  -180° turns, 1/4 to 1/2 turns.



Caution

Avoid excessive tightening. (The valve can be damaged.)

#### **Spigottype** (Material: PVDF)

Necessary items

- Strap wrench (Do not use the pipe wrench.)
- Automatic welding machine
- User's manual for automatic welding machine

#### **Procedure**

- 1) Loosen the union nut with a strap wrench.
- 2) Remove the union nut 5 and the end connector.
- 3) Lead the union nut (5) through the pipe.
- 4) For the next step, refer to the user's manual for the sleeve welder or the automatic welding machine.
- 5) After welding, make sure that the O-ring (A) (8) is mounted.
- 6) Set the end connector (a) and the union nut (5) directly without allowing the O-ring (A) (8) to come off.
- 7) Tighten union nut (5) hardly with hand.
- 8) Using a strap wrench tighten union nuts uniformly on each side approx 90° -180° turns, 1/4 to 1/2 turns.



Caution

Avoid excessive tightening. (The valve can be damaged.)



Caution

{15mm-50mm(1/2"-2")}

It is recommended to install the valve with the threaded carrier to the upstream side of the system.


This allows for an increase safety factor and eliminating a threaded connection when used as a blocking valve.

This also allows the down stream union nut and end connector to be removed safely under pressure.

It increases the safety where there is no chance of thread leakage or accidentally removing the carrier.

The designation of the up stream side (non threaded carrier is marked as shown) on the body.

#### Nominal size 15mm - 50mm (1/2" - 2")



#### (6) Operating Procedure



Caution


Avoid excessive tightening. (The valve can be damaged.)

O Turn the handle gently to open or close.

(Turn the handle clockwise to close and counter clockwise to open.)

Fully closed · · · · The position of the handle should be perpendicular to the pipe.

Fully opened · · · · The position of the handle should be parallel to the pipe.





### (7) Method of Adjusting Face Pressure between Ball and Seat

Necessary items

- Strap wrench
- Protective gloves
- Safety goggles
- Screwdriver (+) (only with nominal size 65~100mm)

#### **Procedure**

- 1) Completely discharge fluid from pipes.
- 2) Turn the handle to full close.
- 3) Loosen the right union nut and the left one (5) with a strap wrench.
- 4) Remove the body part from piping system.



Caution

Wear protective gloves and safety goggles as some fluid remains in the valve. (You may be injured.)

5) Pull the handle off the body part.



Caution

As for nominal size 65-100mm (2 1/2"-4"), loosen the screw (5) properly with a screwdriver before pulling it off..

6) Engage the upper convex part of the handle with the concave part of the union (3).



Caution


As for nominal size 15-50mm


Only the union 3 on the right side when viewed from the trademark (AV mark) can be adjusted.

As for nominal size 65-100mm

adjust the unions on both sides.

- 7) Make an adjustment by turning the union clockwise (to tighten it) or counter clockwise (to loosen it).
- 8) Make sure that the handle can be operated smoothly.
- 9) Assemble the valve by following the above procedure in the reverse order, starting at 6)





9

### (8) Disassembling Method for Replacing Parts

Necessary items

Strap wrench

Safety goggles

Protective gloves



Caution

Wear protective gloves and safety goggles as some fluid remains in the valve.

(You may be injured.)

#### <Disassembly>

#### Procedure

- Completely discharge fluid from pipes.
- Turn the handle to full close.
- 3) Loosen the right union nut and the left one (5) with a strap wrench.
- 4) Remove the body part from piping system.
- 5) Pull the handle off the body part.



As for nominal size 65-100mm (2 1/2"-4"), loosen the screw (15) properly with a screwdriver before pulling it off..

6) Engage the upper convex part of the handle with the concave part of the union.




As for nominal size 15-50mm

Only the union 3 on the right side when viewed

from the trademark (AV mark) can be adjusted.

As for nominal size 65-100mm, adjust the unions on both sides.

- 7) In the engaged state, turn the handle (4) counter clockwise to loosen it and remove the union ③.
- 8) Remove the seat 7 carefully by hand without damaging it.
- 9) Push out the ball 2 by hand.
- 10) Push out the stem 6 from the top flange side to the body side.



Ball

#### <Assembly>


#### Procedure


Carry out the assembly work in the reverse procedure from item 10)



/ Caution

With regard to item 8), before installing seat ① on the valve, check the seat for its face and back.





Seat

#### (9) Mounting actuator, Ensat and base (panel)

#### O Attach actuator to the top flange

#### Procedure


1) Remove the handle (14).




Caution

As for nominal 65mm-100mm, tighten the screw (5) properly before removing it.

- 2) Fix the stand ②4 to actuator ③3 with bolt (A).
- 3) Fix the stem 6 to the joint 25 with screw (B) 28.
- 4) Engage the joint ② with actuator ③.
- 5) Fix the stand ②4 to the top flange with bolt-nut (B) ②7.





#### O Attach Inserted metal to the bottom stand.


#### **Procedure**


Refer to the user's manual for the Inserted metal (Commercially available.)

Bottom stand dimension
------------------------

Unit;	mm
-------	----


Nom.	Size	<b>S</b> 1	S2	S3
15mm	(1/2")	19	7.3	11
20mm	(3/4")	19	7.3	11
25mm	(1")	19	7.3	11
32mm	(1 1/4")	30	9	15
40mm	(1 1/2")	30	9	15
50mm	(2")	30	9	15
65mm	(2 1/2")	48	9	6
80mm	(3")	55	11	7
100mm	(4")	65	11	8







#### OFixation of bottom stand with panel


#### Nominal size: 15mm-50mm (1/2"-2")





#### Nominal size: 65mm-100mm (2 1/2"-4")





#### (10) Inspection items

#### OInspect the following items.

(1)	Existence of scratches, cracks, deformation, and discoloring.
(2)	Existence of leakage from the valve to the outside.
(3)	Existence of leakage when the valve is opened fully at right or left.

### (11) Troubleshooting

Problem	Cause	Treatment
	The carrier is loosened.	Adjust the face pressure between the ball and the seat. (Refer to page 9)
Fluid leaks from the valve even when the valve is closed	The seat is scratched or worn.	Replace the seat with a new one.
fully.	Foreign matter is in the valve.	Clean up.
	The ball is scratched or worn.	Replace the scratched ball with a new one.
	The union nut is loosened.	Tighten up the union nut.
Fluid leaks from the valve.	The carrier is loosened.	Adjust the face pressure between the ball and the seat. (Refer to page 9)
	The O-ring is scratched or worn.	Replace the O-ring with a new one.
The handle can not be turned	Foreign matter is in the valve.	Clean up.
smoothly.	Deformation. (By heat etc.)	Replace the parts.
The handle fails to engage	The stem is broken.	Replace the stem with a new one.
The handle fails to engage.	The engagement between the stem and the ball is broken.	Replace the stem and ball with new ones.

### (12) Handling of residual and waste materials



Caution

In discarding remaining or waste materials, be sure to ask waste service company. (Poisonous gas is generated.)

#### (13) Inquiries

#### ASAHI ORGANIC CHEMICALS INDUSTRY CO., LTD.

Nobeoka Head Office : 2-5955, Nakanose-Cho, Nobeoka –City, Miyazaki-Pref., Japan.

Tel: (81) 982-35-0880 Fax: (81) 982-35-9350

**Tokyo Head Office** : (Furukawachiyoda Bldg.) 15-9, Uchikanda 2- Chome, Chiyoda-Ku, Tokyo, Japan.

Tel: (81) 3-3254-8177 Fax: (81) 3-3254-3474

Singapore Branch Office : 16 Raffles Quay, #40-03 Hong Leong Building, Singapore 048581.

Tel: (65) 220-4022 Fax: (65) 324-6151

**Europe Representative Office**: Kaiser-Friedrich-Promenade 61 D-61348 Bad Homburg v. d. H. Germany.

Tel: (49) 6172-9175-0 Fax: (49) 6172-9175-25

Shanghai Branch Office : Room 1301-P Shanghai Kerry Center, 1515 Nanjing Xi Road, Shanghai China

Tel: (21) 5298-6900 Fax: (21) 5298-6556

**ASAHI /AMERICA Inc.** :35 Green Street P.O.Box 653, Malden, Massachusetts 02148 U.S.A.

Tel: (1) 781-321-5409 Fax: (1) 781-321-4421

<u>Distributor</u>	

Information in this manual is subject to change without notice.



#### AHEAD OF THE FLOW"

### **Class 125 Bronze Check Valves**

Horizontal Swing ● Regrinding Type ● Y-Pattern ● Renewable Seat and Disc

125 PSI/8.6 Bar Saturated Steam to 353° F/178° C 200 PSI/13.8 Bar Non-Shock Cold Working Pressure

#### CONFORMS TO MSS SP-80

#### **MATERIAL LIST**

	IVIA	I LNIAL LIST
	PART	SPECIFICATION
1.	Bonnet	Bronze ASTM B 62
2.	Body	Bronze ASTM B 62
3.	Hinge Pin	Bronze ASTM B 140 Alloy C31400 or
		B 134 Alloy C23000
4.	Disc Hanger	Bronze ASTM B 62 or
		304 Stainless Steel 1/4" thru 3/4" sizes
5.	Hanger Nut	Bronze ASTM B 16
6.	Disc Holder	Bronze ASTM B 62
7.	Seat Disc	Water, Oil or Gas (Buna-N) (W)
		Steam (PTFE) (Y)
		Bronze ASTM B 62 (B)
		Viton (V)
8.	Seat Disc Nut	Bronze ASTM B 16 or B 62
9.	Hinge Pin Plug	Bronze ASTM B 140 Alloy C32000 (not shown)
*10.	Seat Disc Washer	ASTM B 98 Alloy C65500
		or ASTM B 103 (not shown)

<sup>\*</sup>Sizes 3/4", 1", 11/4", and 11/2" only.

#### **DIMENSIONS—WEIGHTS—QUANTITIES**

			Dime	nsions				
Siz	e		Α		3		M	aster
In.	mm.	ln.	mm.	ln.	mm.	Lbs.	Kg.	Ctn. Qty.
1/4	8	2.13	54	1.63	41	0.50	0.23	50
3/8	10	2.13	54	1.63	41	0.47	0.22	50
1/2	15	2.44	62	1.69	43	0.55	0.25	50
3/4	20	2.94	75	1.88	48	0.90	0.41	50
1	25	3.56	90	2.31	59	1.46	0.66	30
1 1/4	32	4.19	106	2.69	68	2.17	0.99	20
1 1/2	40	4.50	114	2.94	75	2.95	1.34	10
2	50	5.25	133	3.94	100	4.79	2.17	10
21/2*	65	8.00	203	5.06	129	11.48	5.21	5
3*	80	9.25	235	6.25	159	17.53	7.96	4


Ordering: T-413 normally furnished with Bronze Disc (T-413-B).


Available with PTFE Steam Disc (T-413-Y) or CWP Disc (T-413-W) or 300 $^{\circ}$  F 67 PSI steam Viton Disc (T-413-V).





T-413
Threaded





NIBCO check valves may be installed in both horizontal and vertical lines with upward flow or in any intermediate position. They will operate satisfactorily in a declining plane (no more than 15°).

Warning – Do Not Use For Reciprocating Air Compressor Service.

<sup>\*-</sup> Class 150 (433) furnished for these sizes.

#### Calibrated Pressure and Vacuum Relief Valve Part Number: Watts N36 (Grainger 6A772)



#### Vacuum Relief Valve, 1/2 In, Brass

Vacuum Relief Valve, Inlet/Outlet 1/2 In, MNPT Connection, Material of Construction Brass, Pressure Range 15 To 200 PSI, Standards ANSI Z21.22, CSA Certified

Prevents vacuum conditions that could siphon water from the system and burn out a heater or collapse a tank. Automatically vents closed system to atmosphere when a vacuum is created. Opens at less than 1/2" vacuum. Also suitable for steam service.

Item Vacuum Relief Valve
Inlet/Outlet (In.) 1/2
Connection MNPT
Material of Construction Brass
Pressure Range 15 To 200 PSI

# Liquid Level Switches and Sensors



Madison Company's comprehensive line of level sensors includes single- and multi-point level switches, continuous level and conductivity sensors and more. The wide selection of materials offers reliable and durable level sensors for all liquid environments, as well as a full range of other application conditions. Madison engineers can incorporate temperature sensors into level sensor designs, offering combination sensing and cost savings for many applications.

- Hermetically sealed reed switches
- Various models operate at temperatures ranging up to 300°C
- Units available to withstand pressures up to 500 PSI
- Electronic <u>controllers</u>, <u>relays</u> and converters can be provided

#### **Madison Company**

(203) 488-4477 • (800) 466-5383 • Fax (203) 481-5036 E-mail: info@madisonco.com • www.madisonco.com



### M Series Stainless Steel Liquid Level Switches

#### **Full-size Switches**

MODEL NO.	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	FITTING	** APPROVALS
M5600	MS5600	1	316SS	316SS	200°	200	0.55	60	22 ga. Teflon 24"	1/4" NPT	A,B,C,D,E
M5600-SPDT	MS5600-SPDT	1	316SS	316SS	200°	200	0.55	25*	22 ga. Teflon 24"	1/4" NPT	A,B,C,D
M5601	MS5601	1	316SS	316SS	200°	200	0.55	100	22 ga. Teflon 24"	1/4" NPT	A,B,C,D
M5917	MS5917	1	316SS	316SS	250°	200	0.55	60	18 ga. UL/CSA appr.	1/4" NPT	A,B,C,D
M4600	MS4600	2	Buna-N	316SS	105°	150	0.45	60	22 ga. Teflon 24"	1/4" NPT	A,B,C
M4600-SPDT	MS4600-SPDT	2	Buna-N	316SS	105°	150	0.45	25*	22 ga. Teflon 24"	1/4" NPT	A,B,C
M4601	MS4601	2	Buna-N	316SS	105°	150	0.45	100	22 ga. Teflon 24"	1/4" NPT	A,B,C
M8600	MS8600	2	PP	316SS	105°	100	0.75	60	22 ga. Teflon 24"	1/4" NPT	A,B,C,D
M8600-SPDT	MS8600-SPDT	2	PP	316SS	105°	100	0.75	25*	22 ga. Teflon 24"	1/4" NPT	A,B,C,D
M8601	MS8601	2	PP	316SS	105°	100	0.75	100	22 ga. Teflon 24"	1/4" NPT	A,B,C,D
M5600-PR	MS5600-PR	3	316SS	316SS	200°	500	0.70	100	22 ga. Teflon 24"	1/4" NPT	C,D
MSB5600	_	4	316SS	316SS	110°	85	0.55	60	Teflon Cable 6 ft.	_	_
M3842	_	4	316SS	316SS	100°	30	0.64	25*	18 AWG Neoprene Cable 10 ft.	_	-

<sup>\*</sup> SPDT switch operation PP= Polypropylene

#### **Miniature Switches**

MODEL	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	FITTING	** APPROVALS
M5000	MS5000	5	316SS	316SS	200°	300	0.70	30	22 ga. Teflon 24"	1/8" NPT	A,B,C,D
M4400	MS4400	6	Buna-N	316SS	105°	150	0.45	30	22 ga. Teflon 24"	1/8" NPT	A,B,C
M8020	MS8020	6	PP	316SS	105°	100	0.80	30	22 ga. Teflon 24"	1/8" NPT	A,B,C,D

PP= Polypropylene

#### **Side-Mounted Switches**


MODEL	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	** APPROVALS
M5900*	-	11	316SS	316SS	200°	300	0.60	30	22 ga. Teflon 24"	A,B,C,D,E
M5910*	_	13	316SS	316SS	200°	300	0.60	30	22 ga. Teflon 24"	A,B,C,D,E
M5920*	_	12	316SS	316SS	200°	300	0.60	30	22 ga. Teflon 24"	A,B,C,D,E
M5970	_	14	316SS	316SS	200°	100	0.70	30	22 ga. Teflon 24"	A,B,C,D
M5010	MS5010	15	316SS	316SS	200°	300	0.70	30	22 ga. Teflon 24"	A,B,C,D

<sup>\*</sup> Available with extended stem length, see drawing No. 19. Consult factory for appropriate model number.


MODEL	SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	OUTER THREAD
M3827-1	-	16	316SS	316SS	200°	50	0.60	30	22 ga. Teflon 24"	1/2-13 Bulkhead
M3827-2	_	17	316SS	316SS	200°	50	0.60	30	22 ga. Teflon 24"	1/2 NPT
M3827-3	_	18	316SS	316SS	200°	50	0.60	30	22 ga. Teflon 24"	1/8 NPT
M3827-1NO	-	_	316SS	316SS	200°	50	0.60	30	22 ga. Teflon 24"	1/2-13 Bulkhead
M3827-2NO	-	_	316SS	316SS	200°	50	0.60	30	22 ga. Teflon 24"	1/2 NPT
M3827-3NO	_	_	316SS	316SS	200°	50	0.60	30	22 ga. Teflon 24"	1/8 NPT

### M Series Stainless Steel Liquid Level Switches

#### **Vertical Switches**







Madison Company • (203) 488-4477 • Fax (203) 481-5036 • E-mail: info@madisonco.com • www.madisonco.com

### M Series Plastic Liquid Level Switches

#### **Full-size Switches**

MODEL NO.	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	FITTING	** APPROVALS
M8800	MS8800	28	PP	PP	105°	100	0.75	60	22 ga. MTW 24"	1/4" NPT	A,B,C,D
M8800-SPDT	MS8800-SPDT	28	PP	PP	105°	100	0.75	25**	22 ga. Teflon 24"	1/4" NPT	A,B,C,D
M8801	MS8801	28	PP	PP	105°	100	0.75	100	22 ga. MTW 24"	1/4" NPT	A,B,C,D
M8800-PR	MS8800-PR	28	PP	PP	105°	100	0.75	360	22 ga. MTW 24"	1/4" NPT	C,D
M7800*	MS7800*	28	Buna-N	PBT	105°	150	0.45	60	22 ga. Teflon 24"	1/4" NPT	A,B,C
M7800-SPDT*	MS7800-SPDT*	28	Buna-N	PBT	105°	150	0.45	25**	22 ga. Teflon 24"	1/4" NPT	A,B,C
M7801*	MS7801*	28	Buna-N	PBT	105°	150	0.45	100	22 ga. Teflon 24"	1/4" NPT	A,B,C
M8060-PR	MS8060-PR	28	PP	CPVC	105°	100	0.75	360	22 ga. MTW 24"	1/4" NPT	С
M9800	MS9800	28	Kynar	Kynar	105°	15	0.75	60	22 ga. Teflon 24"	1/4" NPT	B,C,D
MSB7800*	-	29	Buna-N	PBT	105°	150	0.45	60	Nylon Cable 6 ft.	_	-
MSB8800	-	29	PP	PP	105°	100	0.75	60	PP Cable 6 ft.	_	_

#### **Miniature Switches**

MODEL	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	FITTING	** APPROVALS
M8000	MS8000	30	PP	PP	105°	100	0.80	30	22 ga. MTW 24"	1/8" NPT	A,B,C,D
M4008	MS4008	30	Buna-N	PP	105°	150	0.45	30	22 ga. MTW 24"	1/8" NPT	A,B,C
M7000*	MS7000*	30	Buna-N	PBT	105°	150	0.45	30	22 ga. Teflon 24"	1/8" NPT	A,B,C
M9000	MS9000	30	Kynar	Kynar	105°	15	0.85	30	22 ga. Teflon 24"	1/8" NPT	A,B,C,D

<sup>\*</sup> Not for use in hot water at temperatures above 65°C PP=Polypropylene

### **Side-Mounted Switches**

MODEL NO.	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	** APPROVALS	
M8700	M8705	32	PP	PP	105°	100	0.60	30	22 ga. MTW 24"	A,B,C,D	
M8725	MS8725	33	PP	PP	105°	100	0.60	30	22 ga. MTW 24"	A,B,C,D	
M8740	-	34	PP	PP	105°	100	0.60	30	22 ga. Teflon 24"	A,B,C,D	
M8750	M8755	35	PP	PP	105°	100	0.60	30	22 ga. MTW 24"	A,B,C,D	
M8790	-	36	PP	PP	105°	100	0.60	30	22 ga. MTW 24"	A,B,C,D	
M7700*	M7705*	32	PBT	PBT	150°	100	0.70	30	22 ga. Teflon 24"	A,B,C	
M7725*	MS7725*	33	PBT	PBT	150°	100	0.70	30	22 ga. Teflon 24"	A,B,C	
M7740*	-	34	PBT	PBT	150°	100	0.70	30	22 ga. Teflon 24"	A,B,C	
M7750*	M7755*	35	PBT	PBT	150°	100	0.70	30	22 ga. Teflon 24"	A,B,C	
M7790*	-	36	PBT	PBT	150°	100	0.70	30	22 ga. Teflon 24"	A,B,C	
M9700	M9705	32	Kynar	Kynar	105°	100	0.93	30	22 ga. Teflon 24"	A,B,C,D	

<sup>\*</sup> Not for use in hot water at temperatures above 65°C PP=Polypropylene




### M Series Plastic Liquid Level Switches

#### **Subminiature Switches**


MODEL	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	FITTING	** APPROVALS
M3326	_	31	PP	PP	105°	50	0.85	15	22 ga. Teflon 24"	3/8-16	A,B,C
M3326-NO	_	31	PP	PP	105°	50	0.85	15	22 ga. Teflon 24"	3/8-16	A,B,C


PP= Polypropylene






Cutaway Showing Slosh Shield Operation








Cutaway Showing Slosh Shield Operation


**DWG No. 31** 

















Cutaway Showing Slosh Shield Operation

## M Series Brass Liquid Level Switches

## **Full-size Switches**

MODEL NO.	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	FITTING	** APPROVALS
M4300	MS4300	21	Buna-N	Brass	105°	150	0.45	60	22 ga. MTW 24"	1/4" NPT	A,B,C
M4300-SPDT	MS4300-SPDT	21	Buna-N	Brass	105°	150	0.45	25*	22 ga. Teflon 24"	1/4" NPT	A,B,C
M4301	MS4301	21	Buna-N	Brass	105°	150	0.45	100	22 ga. MTW 24"	1/4" NPT	A,B,C
M5400	MS5400	21	316SS	Brass	200°	200	0.55	60	22 ga. Teflon 24"	1/4" NPT	A,B,C
M5400-SPDT	MS5400-SPDT	21	316SS	Brass	200°	200	0.55	25*	22 ga. Teflon 24"	1/4" NPT	A,B,C
M5401	MS5401	21	316SS	Brass	200°	200	0.55	100	22 ga. Teflon 24"	1/4" NPT	A,B,C
M8400	MS8400	21	PP	Brass	105°	100	0.75	60	22 ga. MTW 24"	1/4" NPT	A,B,C
M8400-SPDT	MS8400-SPDT	21	PP	Brass	105°	100	0.75	25*	22 ga. Teflon 24"	1/4" NPT	A,B,C
M8401	MS8401	21	PP	Brass	105°	100	0.75	100	22 ga. MTW 24"	1/4" NPT	A,B,C

<sup>\*</sup> SPDT switch operation PP=Polypropylene

## **Miniature Switches**

MODEL	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	FITTING	** APPROVALS
M4500	MS4500	22	Buna-N	Brass	200°	300	0.70	30	22 ga. Teflon 24"	1/8" NPT	A,B,C
M5040	MS5040	22	316SS	Brass	105°	150	0.45	30	22 ga. Teflon 24"	1/8" NPT	A,B,C
M8040	MS8040	22	PP	Brass	105°	100	0.80	30	22 ga. Teflon 24"	1/8" NPT	A,B,C

PP=Polypropylene

## **Side-Mounted Switches**


MODEL	With SLOSH SHIELD	DWG NO.	FLOAT MATL	STEM MATL	MAX TEMP (CELSIUS)	MAX PSIG	FLOAT SG	NOMINAL VA	LEAD WIRES	** APPROVALS
M4010	MS4010	23	Buna-N	Brass	105°	100	0.45	30	22 ga. Teflon 24"	A,B,C

3.38"
(85.8)


1.50" (38.1) dia. max. (Polypro.)
1.25" (31.75) dia. max. (Buna-N)

2" dia. max. (50.8 mm)

Cutaway Showing Slosh Shield Operation



Cutaway Showing Slosh Shield Operation



Cutaway Showing Slosh Shield Operation



## Single-Level Liquid Level Switches



A selection of engineered single-level switches

Madison Company offers a complete line of Standard and Configured (slightly modified Standard designs) models. These products continue to meet the needs of applications in many markets, at competitive prices. In addition, Madison Company offers the capability to design specific liquid level switches for OEM applications that require unique considerations in materials, configurations and system interfacing.

Engineered designs incorporate over 45 years of experience in liquid level switch applications in a variety of environments and installation configurations. High reliability of the magnetic reed switch technology assures repeatability at an economical price. Our design experience and flexible manufacturing techniques also offer customers many valueadded design and assembly options to reduce their product cost.

## Features

- Single-point
- Magnetic reed switch technology
- High reliability
- Wide selection of available materials
- Three basic sizes: full, miniature and subminiature
- Direct interface to controllers available

## Product Selection Guide

The first consideration is the type of liquid, temperature and pressure to which the switch will be subjected. Madison manufactures liquid level switches in various styles, in a variety of materials, to cover a broad range of conditions. Following are some basic recommendations for selecting the proper liquid level switch material for your application.



► See Approvals pages

Material	Application
316 Stainless Steel	For high-temperature (to 200°C), high-pressure (to 300 PSIG) and corrosive conditions. Commonly used in food processing, medical, heating, and cooling equipment.
Polypropylene	For acidic conditions, such as found in electroplating and metal cleaning. Another choice for lower-temperature (to 105°C) food processing applications (Madison Company uses only polypropylene that is FDA-approved for food contact). Also a good choice for general-purpose applications in commercial or consumer appliances and equipment. Available in white and other colors.
Brass & Buna-N PBT & Buna-N	The selection for petroleum-based liquids, such as lubricating oils, gasoline and diesel fuels. Widely used in storage tanks of vehicles, generators, transmissions and hydraulic systems. Other uses are in lubrication, recovery, refining and fuel processing equipment. <i>Please note: PBT is not suitable for use in water above 65°C.</i>
Kynar	Chemical- and solvent-resistant properties make this material a problem solver for many applications. Its high-purity nature is ideal for food handling and sensitive laboratory or test equipment.

Once a suitable material has been selected, the type of switch and configuration are the next considerations. Madison Company stocks a full line of standard products that can meet the requirements of many applications. For specific designs, Madison can custom-build, to order, switches with an infinite number of variations and options. Please utilize our M & MT Series single-level specification sheet which, when completed, will allow our engineering department to better meet your needs.




Sensor solutions for today and the future™

## **Madison Company 800-466-5383**

27 Business Park Drive, Branford, CT 06405 • 203-488-4477 • Fax: 203-481-5036 www.madisonco.com • E-mail: info@madisonco.com



CERTIFIED ISO 9001



## **Sediment Strainers**

#### **Standard Features**

- True Union design facilitates installation or repair without expanding the pipeline
- Large filtration capacities and low pressure drops
- Transparent PVC strainer body permits easy evaluation of filter screen's condition
- Complete thermoplastic construction
- Pressure rating: 1/2" 2", 150 psi; 3" and 4",
   85 psi
- Sizes 1/2" 2" supplied with two sets of end connectors (socket and threaded)

## **Options**

- FKM seals for corrosive media
- Stainless Steel 316 screens available in 20, 40 and 60 mesh
- Inline cleaning (clean out valve)

## **Tips on Sediment Strainers**

- Clean screen regularly.
- Union nut of screening section can be removed for quick and easy maintenance (no need to remove body from pipeline).
- Sediment strainers protect pipeline's important and costly components, such as pumps and meters, by removing suspended particles and impurities.
- Filtering section must face downward when installed.
- You must identify flow direction, shown by molded "Arrow" on the body, before installation.

## **Sediment Strainers**

Specifications

Sizes: 1/2" - 4"

Models: Socket, Threaded, Flanged (ANSI)

Body: PVC

Screens: Standard: 20 mesh PVC

Optional: PVC - 30 and 40 mesh

Stainless Steel - 20, 40 and 60 mesh

Seals: EPDM, FKM

Sizes 1/2" - 4" PVC/EPDM/FKM

Models available with NSF-61

Certification

## Parts (Sizes 1/2" - 4")

	P.	ARTS	
NO.	DESCRIPTION	PCS.	MATERIAL
1	Body	1	PVC
2	Filter Screen	1	PVC, Stainless Steel 316
3	Screen Support	1	PVC
4	End Connector	2	PVC
5	Union Nut	3	PVC
6	Retaining Ring	1	PVC
7	Split Ring	1	PVC
8	O-Ring (A)	1	EPDM, FKM, Others
9	O-Ring (B)	2	EPDM, FKM, Others
10	Stop Ring	2	PVDF**


<sup>\* \*</sup> Used for flanged end

## Sample Specification

All True Union Sediment Strainers, Sizes 1/2"- 4", shall be of true union design and shall be constructed of transparent PVC. All O-rings shall be EPDM or FKM. Screens shall be 20, 30 and 40 mesh PVC or 20, 40 and 60 mesh 316 SS. Filter maintenance is achieved without removing strainer from the pipeline. PVC shall conform to ASTM D1784 Cell Classification 12454-A. Valves shall be rated to 150 psi sizes 1/2" thru 2" and 85 psi sizes 3" and 4" at 70 degrees F, as manufactured by Asahi/America, Inc.



## Sediment Strainers



## Dimensions (Sizes 1/2" - 4")

NOMI	NAL	FLANGED					SOCKET			THREADED								
SIZ	Έ	ΙA	NSI CL	ASS 1	50			ASTN	1 CLAS	SS 40								
INCHES	mm	D	С	n	h	L	t	d1	d2	l	L	d1	l	L	d	D1	H1	H2
1/2	15	3.50	2.38	4	0.62	8.11	0.47	0.848	0.836	0.688	6.93	1/2-14 NPT	0.59	6.50	0.59	1.89	3.74	3.19
3/4	20	3.88	2.75	4	0.62	10.00	0.55	1.058	1.046	0.719	8.31	3/4-14 NPT	0.67	7.91	0.79	2.36	4.49	3.74
1	25	4.25	3.12	4	0.62	11.02	0.55	1.325	1.310	0.875	9.37	1-111/2 NPT	0.79	8.82	0.98	2.76	5.12	4.33
1 1/4	30	-	-	-	-	-	-	1.670	1.655	0.938	12.13	11/4-111/2 NPT	0.87	11.34	1.57	3.78	6.85	5.79
1 1/2	40	5.00	3.88	4	0.62	13.23	0.63	1.912	1.894	1.094	12.13	11/2-111/2 NPT	0.98	11.34	1.57	3.78	6.85	5.79
2	50	6.00	4.75	4	0.75	14.20	0.63	2.387	2.369	1.156	12.55	2-111/2 NPT	1.10	13.27	2.01	4.17	7.48	6.57
3	80	7.50	6.00	4	0.75	18.78	0.71	3.516	3.492	1.875	17.84	3 – 8 NPT	1.38	17.17	3.07	5.98	10.67	9.21
4	100	9.00	7.50	8	0.75	23.94	0.71	4.518	4.491	2.000	23.06	4 – 8 NPT	1.77	23.47	3.94	8.27	14.21	12.44

## Weight (POUNDS)

	9	, ,				
	IINAL ZE	SOCKET	FLANGED			
INCHES	mm	THREADED				
1/2	15	0.66	1.10			
3/4	20	1.32	2.20			
1	25	1.76	3.31			
1 1/2	40	4.41	5.51			
2	50	5.51	8.82			
3	80	15.43	18.74			
4	100	40.78	45.19			

## Cv Values

	IINAL ZE	Cv
INCHES	mm	<b>.</b>
1/2	15	5.2
3/4	20	7.5
1	25	14
1 1/2	40	34
2	50	50
3	80	110
4	100	165

#### Filter Screen Sizes\*

MESH (HOLES PER LINEAR INCH)	20	30	40
MAXIMUM PARTICLE SIZE (INCH)	.033	.023	.011
MICRON PARTICLE SIZE (10-30 μ)	840	595	420

<sup>\*</sup> For 60 mesh consult factory

#### Caution

- Never remove strainer from pipeline under
- Always wear protective gloves and goggles.

Serial No. H – V034E – 2
--------------------------

# Sediment strainer (Type Y)

#### User's Manual



#### Contents


1)	General operating instructions	1
2)	General instructions for transportation, unpacking and storage	1
3)	Name of parts	2
4)	Comparison between working temperature and pressure	3
5)	Installation procedure Flanged end type Threaded end type Socket end type	4 4 5 6
6)	Cleaning and replacing method for screen	7
7)	Inspection items	7
8)	Troubleshooting	7
9)	Handling of residual and waste materials	7
10)	Inquiries	0



## (1) General operating instruction

0	Operate the valve within the range of the published working temperature and pressure.  (The valve can be damaged by operation beyond the maximum allowable range of temperature vs pressure.)
0	To select a valve in appropriate materials, refer to "CHEMICAL RESISTANCE ON ASAHI AV VALVE". (Some chemicals give heavy damage to valve materials.)
0	The valve is not designed to bear any kind of external load. Never stand on or place anything heavy on the valve at anytime.
0	When the valve is disposed of, contact waste disposal specialist.
0	The valve should be installed at place where space for periodic inspection & maintenance is sufficient.
0	Do not store or install the valve near any heat source or hot surface. (The valve may cause deformation, destruction, and fire.)
0	Volatile liquids such as a hydrogen peroxide (H2O2) and sodium hypochlorite (NaC1O) may vaporize, thus causing an abnormal pressure increase in the valve.  (If the pressure rises abnormally, gas may break a valve into pieces.)
0	Plumb in the strainer considering the fluid direction (the arrow is shown on the body) so that the screen points downward.
0	Avoid excessive force on the strainer when plumbed in.
0	As for the flanged end type, tighten bolts in turn diagonally not to tighten unevenly. Avoid excessive tightening the union nut (5) of the screen. There is no influence on sealing.
(2) Ge	neral instructions for transportation, unpacking and storage
0	Keep the valve in its original packaging until needed for installation.
0	Avoid contact with any coal tar creosote, insecticides, vermicides or paint.  (The force of swelling may damage the valve.)
0	The valve is not designed to handle any kind of impact. Avoid throwing or dropping the valve.
0	Avoid scratching the valve with any sharp object.


## (3) Name of parts




No.	DESCRIPTION	No.	DESCRIPTION
1	Body	(5)	Union nut
2	Filter screen	6	Retaining ring
3	Screen support	7	Split ring
<b>4</b> b	End connector (Flanged end type)	8	O-ring(A)
(4c)	End connector (Socket end type)	9	O-ring(B)
(4d)	End connector (Threaded end type)	10	Stop ring

## (4) Comparison between operating temperature and pressure

#### Nominal size; 15mm-65mm (1/2"-2")



#### Nominal size; 80mm, 100mm (3", 4")



A Caution

Do not operate the valve beyond the range of working temperature and pressure. (The valve can be damaged.)

## (5) Installation procedure

Flanged type (Material; PVC, CPVC, PVDF)

Necessary items

- Torque wrench
- Spanner wrench
- Bolt, Nut, Washer (For many flanges specification)
- AV gasket (When a non-AV gasket is used, a different tightening torque specification should be followed.)

#### Procedure

- 1) Set the AV gasket between the flanges.
- 2) Insert washers and bolts from the pipe side, insert washers and nuts from the valve side, then temporarily tighten them by hand.




Caution

The parallelism and axial misalignment of the flange surface should be under the values shown in the following table to prevent damage the valve.

(A failure to observe them can cause destruction due to stress application to the pipe)

#### Unit: mm (inch)

Nom. Size	Axial	Parallelism		
	Misalignment	(a-b)		
15-25mm	1.0	0.5		
(1/2"-1")	(0.04)	(0.02)		
40-80mm	1.0	0.8		
(1 1/2"-3")	(0.04)	(0.03)		
100mm	1.0	1.0		
(4")	(0.04)	(0.04)		




3) Using a torque wrench, tighten the bolts and nuts gradually to the specified torque in a diagonal manner (Refer to fig.1.) Fig. 1



//\ Caution

Avoid excessive tightening. (The valve can be damaged.)



Recommended torque value

Unit: N-m{kgf-cm}[lb-inch]

Nom. Size	15mm	20mm	25mm	40mm	50mm	80mm	100mm
Noili. Size	(1/2")	(3/4")	(1")	(1 1/2")	(2")	(3")	(4")
	17.5	17.5	20.0	20.0	22.5	30.0	30.0
Torque value	{179}	{179}	{204}	{204}	{230}	{306}	{306}
	[155]	[155]	[200]	[200]	[200]	[266]	[266]

- \*Be sure to set the union nut (5) when it was removed or loosen from body (1).
  - 1) The o-ring(A) (8) should be set on surface of the end connector (4b).
  - 2) The end connector (4) must be put onto the carrier, then ensure that the o-ring(A) (8) is being between the end connector (4b) and the carrier.
  - 3) Tighten the union nut (5) hardly with hand.
  - 4) Screw the union nut 5 on the body 1 by quarter or half turn using a strap wrench without damaging it.



Caution

Avoid excessive tightening. (The valve can be damaged.)

#### ASAHI AV VALVES

#### Threaded type



- Sealing tape (A non-sealing tape can cause leakage.)
- Strap wrench (Do not use Pipe wrench.)
- Spanner wrench



Caution

Make sure that the threaded connections are plastic x plastic.

(Metallic thread might damage the body cap.)

#### **Procedure**

- 1) Wind a sealing tape around the external thread of joint, leaving the end (about 3mm) free.
- 2) Loosen the union nut 5 with a strap wrench..
- 3) Remove the union nut 5 and the end connector 4d.
- 4) Lead the union nut 5 through the pipe.
- 5) Tighten the external thread of the joint and the end connector 4d hardly with hand.
- 6) Using a spanner wrench, screw the end connector 4d by turning 180° ~360° carefully without damaging it.



Caution

Avoid excessive tightening. (The valve can be damaged.)

- 7) Make sure that the O-ring(A) (8) is mounted.
- 8) Set the end connector 4d and union nut 5 directly on the body without allowing the O-ring (A) 8 to come off.
- 9) Tighten the union nut (5) hardly with hand.
- 10) Using a strap wrench, screw it in by turning 90° -180° carefully without damaging it.



Caution

Avoid excessive tightening. (The valve can be damaged.)

#### ASAHI AV VALVES

#### **Sockettype**

Necessary items

- Adhesive for hard vinyl chloride pipes
- Spanner wrench (Do not use a piping wrench.)



Caution

Do not install a socket type valve where the atmospheric temperature is 5°C or lower. (The valve can be damaged.)

#### Procedure

- 1) Loosen the union nut (5) with a spanner wrench.
- 2) Remove the union nut (5) and end connector (40).
- 3) Lead the union nut (5) through the pipe.
- 4) Clean the hub part of the end connector 4c by wiping with waste cloth.
- 5) Apply adhesive evenly to the hub part of the end connector 4c and the pipe spigot.



Caution

Do not apply more adhesive than necessary.

(The valve can be damaged due to solvent cracking.)

Adhesive quantity (guideline)

Nom. Size	15mm (1/2")	20mm (3/4")	25mm (1")	40mm (1 1/2")	50mm (2")	80mm (3")	100mm (4")
Quantity(g)	1.0	1.3	2.0	3.5	4.8	9.0	13.0

- 6) After applying adhesive, insert the pipe quickly to the end connector 4c and leave it alone for at least 60 seconds.
- 7) Wipe away overflowing adhesive.
- 8) Make sure that O-ring(A) (8) is mounted
- 9) Set the end connector (4) and union nut (5) directly on the body without allowing the O-ring (A) (8) to come off.
- 10) Tighten the union nut 5 hardly with hand.
- 11) Using a strap wrench, screw it in by turning 90° -180° carefully without damaging it.



Caution

Avoid excessive tightening. (The valve can be damaged.)

## (6) Cleaning and Replacing Method for Screen

Necessary items		
<ul><li>Strap wrench</li></ul>	<ul><li>Protective gloves</li></ul>	Safety goggles

- 🔼 Caution

Wear protective gloves and safety goggles as some fluid remains in the valve.

(You may be injured.)

- 1) Loosen the union nut ⑤, and remove the screen part (the numbers or the part are ②, ③, ⑤, ⑥, and ⑦) from the body ①.
- 2) Remove the retaining ring 6, and pull the filter screen 2 out then wash it to remove the dust or foreign matter.
- 3) If the filter screen ② or the O-ring (B) ⑨ is damaged, replace with a new one. (Replace the O-ring (B) ⑨ removing the split ring ⑦ from the screen support ③.)
- 4) Carry out the assembly work in the reverse procedure from 3).

## (7) Inspection items

- O Periodically clean the screen in accordance with the use.
- O Inspect the following items.

Ī	(1)	Check for any flaw, crack, or deformation on the outside.
	(2)	Check whether fluid leaks to the outside.
ľ	(3)	Check the tightness of union nuts (loose or not).

## (8) Troubleshooting

Problem	Problem Cause			
Elvid leake to the autoide	The union nut is loose.	Retighten.		
Fluid leaks to the outside.	The O-ring is scratched or worn.	Replace the O-ring.		

## (9) Handling of residual and waste materials



Caution

In discarding remaining or waste materials, be sure to ask waste service company.

(10) Inquiries

#### ASAHI ORGANIC CHEMICALS INDUSTRY CO., LTD.

Nobeoka Head Office : 2-5955, Nakanose-Cho, Nobeoka –City, Miyazaki-Pref., Japan.

Tel: (81) 982-35-0880 Fax: (81) 982-35-9350

**Tokyo Head Office** : (Furukawachiyoda Bldg.) 15-9, Uchikanda 2- Chome, Chiyoda-Ku, Tokyo, Japan.

Tel: (81) 3-3254-8177 Fax: (81) 3-3254-3474

Singapore Branch Office : 16 Raffles Quay, #40-03 Hong Leong Building, Singapore 048581.

Tel: (65) 220-4022 Fax: (65) 324-6151

Europe Representative Office : Kaiser-Friedrich-Promenade 61 D-61348 Bad Homburg v. d. H. Germany.

Tel: (49) 6172-9175-0 Fax: (49) 6172-9175-25

Shanghai Branch Office : Room 1301-P Shanghai Kerry Center, 1515 Nanjing Xi Road, Shanghai China

Tel: (21) 5298-6900 Fax: (21) 5298-6556

**ASAHI /AMERICA Inc.** :35 Green Street P.O.Box 653, Malden, Massachusetts 02148 U.S.A.

Tel: (1) 781-321-5409 Fax: (1) 781-321-4421

<u>Distributor</u>		

ASAHI AV VALVES	Installation, Operation and Mainten	ance Manual
	Sediment strainer (Type Y)	



#### Plicord® Flexwing® Petroleum

#### APPLICATION:

For use in tank truck and in-plant operations to transfer gasoline, oil, and other petroleum base products up to 50% aromatic content. It is designed for pressure, gravity flow, or full-suction service.



#### CONSTRUCTION:

TUBE: Nitrile synthetic rubber RMA Class A (High Oil Resistance)

COVER: Black (red spiral stripe) or Red Chemivic (white spiral stripe) synthetic rubber (oil resistant); smooth cover; wrapped finish

REINFORCEMENT: Spiral-plied synthetic fabric with wire helix

TEMPERATURE: -35°F to 200°F (-37°C to 93°C)

PACKAGING: 100' lengths, coiled and polywrapped

BRANDING: Continuous spiral brand example "Goodyear™ Flexwing Petroleum 150 psi WP."

COUPLINGS: Use Goodyear's Insta-Lock Cam & Groove Fittings with this product. See page 221 for available Insta-Lock products.

NON-STOCK/SIZES: Refer to page 300 for special production run minimum requirements.

ORDER CODES: 543-109 (black) / 543-110 (red)

NOM. ID		NO	NOM. OD		MAX. WP		BEND RADIUS		VACUUM HG		WEIGHT	
in.	mm.	in.	mm.	psi	Мра	in.	mm.	in.	mm.	lb./ft.	kg./m.	
3/4	19.1	1.22	31.0	150	1.03	2	51	29	737	0.47	0.70	
1	25.4	1.50	38.1	150	1.03	2	51	29	737	0.63	0.94	
1 1/4	31.8	1.76	44.7	150	1.03	3	76	29	737	0.79	1.18	
1 1/2	38.1	2.03	51.6	150	1.03	4	102	29	737	0.99	1.47	
1 3/4	44.5	2.28	57.9	150	1.03	4	102	29	737	1.07	1.59	
2	50.8	2.55	64.8	150	1.03	5	114	29	737	1.30	1.93	
2 1/2	63.5	3.07	78.0	150	1.03	6	146	29	737	1.66	2.47	
3	76.2	3.57	90.7	150	1.03	7	178	29	737	2.03	3.02	
3 1/2	88.9	4.13	104.9	150	1.03	8	203	29	737	2.39	3.56	
4	101.6	4.60	116.8	150	1.03	10	254	29	737	2.68	3.99	
6	152.7	6.78	171.9	150	1.03	30	762	29	737	5.61	8.36	

The GOODYEAR (and Winged Foot Design) trademark is used by Veyance Technologies, Inc. under license from The

Goodyear Tire & Rubber Company.

Goodyear Engineered Products are manufactured and sourced exclusively by Veyance Technologies, Inc. or its affiliates.



Temperature range: -40°F to +180°F(-40°C to +82°C). **NOTE**: Fuels are normally conveyed below 120°F (+49°C).

Tube: Type C (Nitrile) hose. Black.

Reinforcement: Synthetic, high tensile textile with steel wire helix.

Cover: Type A (Neoprene). Black with red spiral stripe. Smooth or corrugated.

Branding: Continuous transfer label.


Example: Gates Longhorn® Petroleum Transfer hose 150 PSI (1.03MPa) WP Made In U.S.A.

Packaging: Coiled and wrapped in polyethylene.

Nom. I.D. (In.)	(mm)	Nom. O.D. (In.)	(mm)	Max. W.P. (psl)	Suction (In. Hg)	Min. Bend Radius (In.)	Wt. Per Ft. (Lbs.)	Standard Pack	or Min. Order Qty.	Gates Product No.			
Smo	oth Co	ver											
1	25.4	1.50	38.1	150	30	3.0	0.59	100 ft.	Х	4688-1305			
1 1/4	31.8	1.75	44.5	150	30	4.0	0.71	100 ft.	X	4688-1306			
1 1/2	38.1	2.02	51.3	150	30	4.0	0.87	100 ft.	X	4688-1307			
2	50.8	2.52	64.0	150	30	6.0	1.12	100 ft.	X	4688-1308			
2 1/2	63.5	3.05	77.5	150	30	8.0	1.48	100 ft.	Х	4688-1309			
3	76.2	3.58	90.9	150	30	9.0	1.87	100 ft.	X	4688-1310			
4	101.6	4.60	116.8	150	30	12.0	2.72	100 ft.	X	4688-1311			
6	152.4	6.88	174.8	150	30	18.0	6.28	50 ft.	Х	4688-1312			
Corrugated Cover													
2	50.8	2.52	64.0	150	30	5.0	1.08	100 ft.	Х	4688-1351			
3	76.2	3.58	90.9	150	30	8.0	1.70	100 ft.	X	4688-1352			
4	101.6	4.64	117.9	150	30	11.0	2.50	100 ft.	X	4688-1353			

Miles

Stock (X)



# WEST MICHIGAN RUBBER & SUPPLY 1.800.533.9677 sales@westmichiganrubber.com

## **RFH DUCTING HOSE**

**Temperature Range:** -60°F to 275°F (intermittent to 300°F) **Construction:** Thermoplastic rubber reinforced with a wire helix

Standard Colors: Black

Standard Lengths: 25', 50' (available up to 100')

**Size Range:** 1-1/4" to 24"

**Description:** 

Most versatile general purpose hose available today

• No cements, glues or adhesives are used in the manufacturing process

Can handle applications with a wide temperature range

Superior chemical resistance

• RFH-FR (flame retardant) version available

Good abrasion resistance

UV/ozone resistant

Available in metric diameter, other colors and with cuffed ends


I.D. (in)	Working Pressure (PSI)	Vacuum (inHg)	CL Bend Radius (in)	Compression Ratio	O.D. Nominal (in)	Wall Thickness (in)	Wt (lbs/ ft)	Part #
1.25	28	>29	1.50	1 ft/6 in	1.49	.026	.11	RFH0125
1.50	24	>29	1.75	1 ft/6 in	1.75	.026	.22	RFH0150
1.75	22	>29	2.00	1 ft/9 in	2.00	.026	.23	RFH0175
2.00	17	>29	3.50	1 ft/6 in	2.27	.030	.24	RFH0200
2.50	13	28	4.00	1 ft/6 in	2.77	.030	.29	RFH0250
3.00	10	28	4.25	1 ft/5 in	3.27	.030	.32	RFH0300
3.50	10	20	5.25	1 ft/6 in	3.77	.030	.41	RFH0350
4.00	10	25	6.50	1 ft/6 in	4.29	.030	.50	RFH0400
5.00	9	15	8.00	1 ft/6 in	5.29	.030	.63	RFH0500
6.00	8	11.5	8.75	1 ft/6 in	6.29	.030	.85	RFH0600
7.00	7	10	10.50	1 ft/7 in	7.35	.030	.95	RFH0700
8.00	6	5.5	12.00	1 ft/7 in	8.35	.030	1.20	RFH0800
10.00	4	5	12.50	1 ft/4 in	10.38	.030	1.63	RFH1000
12.00	4	4	13.75	1 ft/4 in	12.38	.030	1.90	RFH1200
14.00	2	2	18.00	1 ft/4 in	14.48	.030	1.87	RFH1400
16.00	2	2	21.00	1 ft/4 in	16.48	.030	3.19	RFH1600
18.00	2	2	21.50	1 ft/4 in	18.48	.030	3.36	RFH1800
20.00	1	2	25.50	1 ft/4 in	20.50	.030	3.63	RFH2000
24.00	1	1	36.00	1 ft/4 in	24.50	.030	3.81	RFH2400


Pressure and vacuum data based on straight lengths of hose at ambient temperature 72°F.




## **PLATES**

- 1. DPVE System Layout
- 2. DPVE Well Details
- 3. DPVE System Details






## 1 TYPICAL ABOVEGROUND DPVE WELL CONSTRUCTION DETAIL





TYPICAL ABOVEGROUND DPVE WELL HEAD


SCALE: NOT TO SCALE



# 2 TYPICAL OBSERVATION MONITORING WELL CONSTRUCTION DETAIL SCALE: NOT TO SCALE







5 SINGLE LEAF DOOR HATCH DETAIL

SCALE: NOT TO SCALE

				TE OF NEW
				STALES J MC PE
				1 3 W 8 1
				CE WE STATE
				TEN STATE OF THE S
	11/6/13	REVISED TO SHOW AS-BUILT SYSTEM LOCATION	G.N.	069509
١.	DATE	REVISION DESCRIPTION	INT.	OF ESSION P

UNAUTHORIZED ALTERATION OR ADDITION TO THIS DOCUMENT IS A VIOLATION OF STATE LAW.

THESE DOCUMENTS (OR COPIES OF ANY THEREOF) PREPARED BY OR BEARING THE SEAL OF THE ENGINEER, SHALL NOT BE REUSED FOR ANY EXTENSIONS OF THE PROJECT OR ANY OTHER PROJECT WITHOUT THE WRITTEN CONSENT OF THE

j	PROJ. ENGINEER:	G.N.	DRAWN BY: J.	A.D.		
S	DESIGNED BY:	D.M.H.	CHECKED BY: C.	М.		
5	DRAWING SCALE:	AS SHOWN	PLOT SCALE: 1:	1		
	DRAWING DATE:	05NOV13	PRINT TYPE: B	&W		
	OFFICE:	NY	PAPER SIZE: AF	RCH D		
	PROJECT NO.:	0055.0045Y018				
	DRAWING FILE:	0055.0045Y298.03.DWG				

Remedial

REMEDIAL ENGINEERING, P.C.

209 Shafter Street
Islandia, New York 11749 (631) 232-2600

OPERATION, MAINTENANCE, AND MONITORING
MANUAL OU-3
PROJECT FOR:
AMTRAK SUNNYSIDE YARD


QUEENS, NEW YORK


DPVE WELL DETAILS AS-BUILT

2

DRAWING NO.


DRAWING 2 OF 3






## 6 FLUSH-MOUNTED DPVE WELL HEAD SCALE: NOT TO SCALE


PLAN VIEW




## 8 TYPICAL 4" DIAMETER PIPE TRENCH DETAIL




TYPICAL TRACK CROSSING DETAIL - 4 PIPES SCALE: NOT TO SCALE




DPVE WELL VALVE VAULT FOR ZONE A1 SCALE: NOT TO SCALE



9 TYPICAL 2" DIAMETER PIPE TRENCH DETAIL
SCALE: NOT TO SCALE



10 TYPICAL TRACK CROSSING DETAIL - 2 PIPES SCALE: NOT TO SCALE



DPVE WELL VALVE VAULT NOTES

- THE DPVE WELL VALVE VAULTS ARE PRE-CAST CONCRETE.
- 2. THE CONCRETE HAS A COMPRESSIVE STRENGTH OF
- 3. THE PRE-CAST CONCRETE VAULTS HAVE NO.4 REBAR SPACED EVERY 6" ON CENTER, EACH WAY.
- AN ALUMINUM SINGLE LEAF DOOR HATCH IS PROVIDED FOR EACH VAULT, RATED FOR H20 LOADING. THE DOOR FRAME IS CAST INTO DPVE WELL VALVE VAULT.
- 5. A DRAINAGE VALVE IS PROVIDED IN EACH VAULT.

DPVE WELL VALVE VAULT FOR ZONE A2

SCALE: NOT TO SCALE

			TE OF NEW
			STALES J MC TO
			1 3 M 2 2 1
			C W F Z
			18 V
11/6/13	REVISED TO SHOW AS-BUILT SYSTEM LOCATION	G.N.	069509
DATE	REVISION DESCRIPTION	INT.	OFESSION P

UNAUTHORIZED ALTERATION C ADDITION TO THIS DOCUMENT A VIOLATION OF STATE LAW. THESE DOCUMENTS (OR COPI OF ANY THEREOF) PREPARED
BY OR BEARING THE SEAL OF
THE ENGINEER, SHALL NOT BE
REUSED FOR ANY EXTENSIONS
OF THE PROJECT OR ANY
OTHER PROJECT WITHOUT THE WRITTEN CONSENT OF THE ENGINEER.

OR .	PROJ. ENGINEER:	G.N.	DRAWN BY: J.A.D.			
NT IS 1.	DESIGNED BY:	D.M.H.	CHECKED BY: C.M.			
PIES	DRAWING SCALE:	AS SHOWN	PLOT SCALE: 1:1			
ED OF	DRAWING DATE:	05NOV13	PRINT TYPE: B&W			
BE DNS	OFFICE:	NY	PAPER SIZE: ARCH D			
THE	PROJECT NO.:	0055.0045Y	018			
	DRAWING FILE:	0055.0045Y298.03.DWG				

Remedial
MEDIAL ENGINEERING, P

209 Shafter Street Islandia, New York 11749 (631) 232-2600

PROJECT NAME:
OPERATION, MAINTENANCE, AND MONITORING
MANUAL OU-3
PROJECT FOR:

QUEENS, NEW YORK

DPVE SYSTEM DETAILS **AS-BUILT** AMTRAK SUNNYSIDE YARD

DRAWING NO.

DRAWING 3 OF 3