



figure 2.1
SOIL BORING LOCATIONS
IN THE VICINITY OF BUILDING 14
VRI RIVERVIEW FACILITY
Schenectady, New York