



figure 2.2

SOIL BORING LOCATIONS  
IN THE VICINITY OF BUILDING 37  
VRI RIVERVIEW FACILITY  
*Schenectady, New York*