

Unpaved Forest Road Handbook



**New York State
Department of Environmental Conservation
Bureau of State Land Management**

Unpaved Forest Road Handbook

**New York State Department of Environmental Conservation
Bureau of State Land Management**

**Edited by
Kurt C. Swartz**

August 19, 2008

Revision History

November 9, 1973	Unpaved Forest Road Handbook, ECH 8409.11 Approved for distribution by Commissioners Directive Henry L. Diamond, November 9, 1973
August 22, 1974	Amendments Balance on Side Hill Cuts Calculation of yardage from Cross Section
July, 2004	Adjustments to document structure and organization Road Class definition changes Integration of new technologies & procedures

Table of Contents

Introduction	1
Objectives	2
Policy	2
Standards	3
General Requirements	3
Road Classification	3
Public Forest Access Roads	3
Haul Roads	4
Turnout Specifications	5
Sections	6
Surveys	8
Reconnaissance Survey	8
Scope	8
Field Instrumentation	8
Preparation for Field Reconnaissance	8
Selection of Possible Routes	8
Field Reconnaissance	8
Location Surveys	9
Preliminary Location Survey	9
Field method	9
Final Location Survey	9
Centerline Stakes	9
Leveling	9
Slope Stakes	9
Placement of Slope Stakes	9
Right-of-Way Clearing	11
Grading of Side Slopes	11
Construction Surveys	11
Offset Stakes	11
Grade Stakes	11
Horizontal Curves	12
Functions of a Circular Curve	12
Curve Formulae	13
Laying out a Curve by the Middle Ordinate Method	13
Laying out a Curve by the Tangent Method	13

Vertical Curves	16
Elements of a Parabolic Vertical Curve	16
Minimum Length of a Vertical Curve	16
Calculation of a Vertical Curve	17
Required Information For Calculation by the Bureau of Construction Management	20
Project Plans	24
Plan and Profile	24
Scale	24
Required Information to be Shown	24
Approval of the Plan and Profile	24
Permits	24
Drainage	24
Surface Drainage	24
Culverts	26
Cross Sections and Estimates	26
Calculation of Yardage from Cross Section	28
Balance on Side Hill Cuts	28
Erosion Control	28
Erosion Control Methods	28
Slope Angle	28
Vegetative Cover	28
Rip-Rap	29
Road Crown	29
Streams	29
Construction	30
Construction Standards	30
Job Planning and Supervision	30
Safety	30
Safety Standards	30
Use of Explosives	30
Right-of-Way Clearing	30
Protection of Stakes	30
Width of Clearing	30
Disposal of Cut Material	30
Stumps	31
Grading	31
Grade Stakes	31
Rock Excavation	31
Sub-Surface Drainage	31
Surface Drainage	31
Culverts	31
Culvert Installation	32

List of Tables

Table 1, Forest Road Design Standards	4
Table 2, Location of Slope Stakes	10
Table 3, Minimum Length of Vertical Curves for Forest Roads	17
Table 4, Example Vertical Curve Values	19
Table 5, Round Culvert Sizing	27

List of Figures

Figure 1, Access Road Turnout Specifications	5
Figure 2, Haul Road Turnout Specifications	5
Figure 3, Side Hill Section	6
Figure 4, Through Cut Section	6
Figure 5, Fill Section	7
Figure 6, Section of Flat Ground	7
Figure 7, Section on Flat ground Where Additional Elevation is Needed For Drainage	7
Figure 8, Typical Slope Section	10
Figure 9, Grade Stakes	11
Figure 10, Circular Curve Geometry	12
Figure 11, Horizontal Curve Formulae	13
Figure 12, Laying out a Curve by the Middle Ordinate Method	14
Figure 13, Laying out a Curve by the Tangent Method	15
Figure 14, Vertical Curve Geometry	21
Figure 15, Vertical Curve Data Sheet	23
Figure 16, Standard Cross Section for Public Forest Access Road	25
Figure 17, Typical Road Cross Section	26
Figure 18, Balancing Side Hill Cuts	28
Figure 19, Culvert Placement - Alignment	33
Figure 20, Culvert Placement - Cross Section	33

Introduction

This handbook is prepared as a guide to the planning, construction and maintenance of the forest road system on Reforestation, Multiple-Use and Unique Areas hereinafter referred to as State lands.

It has been established that a well-planned system of forest roads, properly constructed and maintained, is a primary need in the management and use of forest lands.

Such access will provide benefits to the public for maximum use of State lands for the variety of recreational pursuits, while facilitating the administration of these areas for protection from fire and forest pests, harvesting of forest products, and silvicultural operations.

Additional information to guide planning, design and construction activities is contained in the DEC publication titled New York State Forestry; Best Management Practices for Water Quality BMP Field Guide.

Objectives

Permanent useable access to all parts of State lands will be established for:

1. Forest management and silvicultural operations.
2. Harvesting forest products.
3. Outdoor recreational use by the public.
4. Forest protection.
5. Emergency Management

The objective of this handbook is to provide a set of guidelines, used by field personnel, to insure that all roads on State Lands under the jurisdiction of the Department of Environmental Conservation, exclusive of the Forest Preserves, are constructed in accordance with established standards.

Policy

The policy of the Department as regards forest roads shall be as follows:

1. The forest road system includes all transportation corridors within, partly within or adjacent to State Lands.
2. All roads will be planned, designed and constructed in a sound manner to avoid or minimize unnecessary degradation of natural resources, providing the service needed and at a justifiable cost, with minimal negative impacts to the environment.
3. All new construction, rehabilitation and maintenance shall be performed in accordance with the established standards and policies of the Department.

Standards

The State Forest Road System provides for both public and administrative access. Roads will be constructed to standards that will keep maintenance costs at a minimum and provide for travel in comparative safety.

General Requirements

All road locations will consider the following:

1. The area to be served.
2. Terminal points.
3. Effect on watershed and scenic values.
4. Maximum grades.
5. Availability of fill and surfacing material.
6. Intermediate control points.
7. Volume of earth and rock to be moved.
8. Drainage measures needed.
9. Curve radii.
10. Construction costs.

Road Classification

Roads are divided into the following classes, based upon intended use and standards of construction.

Public Forest Access Roads - These roads have been renamed as Public Forest Access Roads to maintain consistency with Unit Management Planning, Infrastructure and other guidance documents. Hereinafter they are abbreviated as PFAR.

Public Forest Access Roads are permanent, unpaved roads which may be designed for all-weather use depending upon their location, surfacing and drainage. These roads provide primary access for administration and public use within the Unit. The design standards for these roads are those of the Class A and Class B access roads as provided in the Unpaved Forest Road Handbook (8/74). As a general guideline, sufficient access is typically achieved when 1 mile of PFAR is developed for each 500 acres of state land, and no position within the Unit lies more than 1 half mile from a PFAR or public highway.

Haul Roads - These roads have been renamed as Haul Roads to maintain consistency with Unit Management Planning, Infrastructure and other guidance documents. Hereinafter they are abbreviated as HR.

Haul Roads are permanent, unpaved roads which are not designed for all weather travel, but may have hardened or improved surfaces with artificial drainage. They are constructed according to best management practices primarily for the removal of forest products, providing limited access within the unit by log trucks and other heavy equipment. These roads may or may not be open for public motor vehicle use, depending on management priorities and objectives. They may serve as recreational access corridors, but are not maintained according to specific standards or schedules. The design standards for these roads are below those of the Class B access roads as provided in the Unpaved Forest Road Handbook.


Table 1 Public Forest Access Road Design Standards	
Traffic Lanes ¹	1
Vehicles Per Hour	1-5
Design Speed - MPH	15 -25
Minimum Curve Radius (Ft.)	50
Maximum Grade - Pitch	15
Maximum Grade - Sustained	10
Width of Roadbed (Ft.)	14
Width of Travel Surface (Ft.)	12
Width of Bridges (Ft.)	14
Minimum Bridge Loading	H15 S12
Turnouts	Turnouts on all single lane forest roads shall be inter-visible and not over 1000 feet apart

Turnout Specifications

Turnouts on Access Roads shall be at least 100 feet long and 10 feet wide; the tapered end sections should be at least 50 feet long, as shown in Figure 1.


¹ Two lanes will be provided on all horizontal and vertical curves having stopping sight distances of less than 200 feet

Figure 1
Typical Maximum Turnout Specifications



Turnouts on Haul Roads shall be at least 75 feet long and 10 feet wide; with tapered ends at least 40 feet long, as shown in Figure 2.

Figure 2
Minimum Turnout Specifications



Sections

Typical grading sections are shown as follows:

Legend for Figures 3-7

----- Existing Ground

V - Variable

A - Commonly, the upper standard for PFAR

B - Minimal standard for PFAR





Figure 5
Fill Section




Figure 6
Section on Flat Ground





Figure 7
Section on Flat Ground Where additional Elevation is Needed For Drainage



Surveys

The importance of adequate surveys and careful planning for road construction cannot be over-emphasized. Proper attention to these elements is vital to insure that an access system is developed that will meet long-term needs for safe and efficient travel, and that may be constructed and maintained at a minimum cost.

Reconnaissance Survey:

Scope

This phase of the survey should consider the following:

1. Terminal points;
2. Intermediate control points;
3. Alternate routes;
4. Gradient,
5. Topographical features.

Field Instrumentation

Effective survey, design, layout and construction is dependent upon the use of field instruments to assess, record, plan and execute road construction. These instruments include hand or staff compass, abney level, hand or tripod level with rod, clinometer, transit or most recently Global Positioning Systems technologies. Whatever series of instruments are selected, care should be exercised to ensure suitable precision and relocatable accuracies can be obtained.

Preparation For Field Reconnaissance

Prior to making the field reconnaissance, all available information about the area should be obtained. This will include mapping and other data resources which depict topography, vegetative cover, land boundary and forest inventory. U.S.G.S. maps, aerial photos, property maps and inventory maps, or GIS spatial data resources are available to provide the necessary planning information.

Selection of Possible Routes

State property lines, terminal points and control points should be plotted and a suitable map produced which highlights pertinent information. A route is then tentatively plotted that will satisfy the requirements of grade, location, control points and economic construction. Alternate routes may also be plotted for later field evaluation.

Field Reconnaissance

With the aid of a field instruments, check the tentatively-selected route or routes to ascertain that the terminal points may be connected, through the control points, within the limits of allowable

grades. During the field reconnaissance all factors that have a bearing on the road location and construction, such as soils, drainage, stream crossings, problem areas and general topography should be carefully noted, and can be compared to other limiting factors discovered during the reconnaissance or preliminary assessment phase.

Location Surveys:

Preliminary Location Survey

After the best possible route has been selected, based on information learned during the reconnaissance, a preliminary location survey of this route will be made.

Field Method

Using field instruments, locate a trial center line using plastic flagging tape or other suitable material. Make necessary adjustments dictated by previously selected control points and grade requirements. Note radii of curves, and adjust tentative center line when necessary. Plot the tentative center line as a Plan and Profile, and adjusting the center line where necessary to give the best alignment and grade.

Final Location Survey:

Center Line Stakes

When a final center line location has been selected, set center line stakes at 50 or 100 foot intervals, and mark the stakes to show the total distance from the start of the road (e.g. - Sta. 10+50). Other stakes may be required at critical points on the center line, such as culvert locations, changes in grade, turnouts, etc. Use field instruments to obtain alignment and bearing of the final center line, and distances.

Leveling

Elevations for each station can be obtained with field instruments. Establish bench marks not less than 1,000 feet apart for reference during construction. Where possible, bench marks should be established outside the right-of-way to be cleared, to prevent destruction during the clearing operation.


Slope Stakes

The location of slope stakes, and right-of-way clearing lines can be determined by taking readings at each station on the final center line to obtain the percentage of slope at right angles to the center line. Slope stakes are required only on side hill construction having slopes in excess of 20%.

Placement of Slope Stakes

Table No. 2 is used to calculate the location of slope stakes. Upper slope stakes should be placed three feet above the distance shown in the Table. Lower slope stakes should be placed one foot below the toe of the slope.

Table 2 Location of Slope Stakes						
Side Slope %	Access Roads - 20 foot Road Width			Haul Roads - 14 foot Road Width		
	Cut & Fill Slope	S in feet	C	Cut & Fill Slope	S in feet	C
10	3.0 : 1	17.5	2.0	3.0 : 1	13.0	1.0
15	2.0 : 1	18.5	3.0	2.0 : 1	14.0	2.0
20	1.5 : 1	19.5	4.0	1.5 : 1	15.0	3.0
25	1.5 : 1	22.0	5.5	1.5 : 1	17.0	4.0
30	1.5 : 1	25.0	7.5	1.5 : 1	19.0	5.5
35	1.25 : 1	25.0	8.0	1.25 : 1	19.5	7.0
40	1.0 : 1	25.0	9.0	1.0 : 1	20.0	8.5
45	1.0 : 1	26.0	11.0	1.0 : 1	21.0	9.0
50	1.0 : 1	29.5	13.0	1.0 : 1	22.0	9.5
55	1.0 : 1	33.5	16.0	1.0 : 1	25.0	12.0
60	1.0 : 1	38.0	19.5	1.0 : 1	29.0	15.0
65	1.0 : 1	45.0	24.5	1.0 : 1	34.0	18.0
70	1.0 : 1	53.0	30.0	1.0 : 1	39.0	22.0
75	1.0 : 1	60.0	39.0	1.0 : 1	49.0	30.0
80	1.0 : 1	77.0	48.0	1.0 : 1	60.0	38.0
S = Slope Distance from Centerline				C = Cut Depth in Feet		



Right-of-Way Clearing

Add 3' to slope distance for Upper Slope; add 1' to Lower Slope

Grading of Side Slopes

Where the ground line has a gradient of up to 10%, side slopes will be graded to 3:1. A ground line slope of 10% to 30% will require grading of the side slope to 1 ½ :1. A ground line slope of over 40% will be graded 1:1. There will be a transition between 30% and 40% slopes from 1 ½ :1 to 1:1 for cut and fill slopes.


Construction Surveys

Offset Stakes

Offset stakes will be set from the center line stakes at regular intervals, not over 500 feet apart, so that the center line can be determined and re-established when center line stakes have been knocked out in construction. Offset stakes should be set 30 feet or more from, and at right angles to, the center line stakes, and marked as follows: Sta. 10+50 30' to center line. They should be set on each side of the center line where they will not be disturbed in the construction process. The Point of Intersection (P.I.) and the Point of Tangents on all curves should be referenced in the same manner.

Grade Stakes

Grade stakes, where required, should be set opposite stations at the side of the road where they will not be disturbed, and a reference mark established on them from which the final road sub-grade can be determined (e.g - Sta. 10+50 Sub-grade 2.0'). See Figure 9.



Horizontal Curves

The center line of a road consists of a series of straight lines connected by curves. Horizontal curves on all forest roads will be laid out as the arc of a circle having a pre-selected radius. For best alignment, the largest radius possible should be selected, consistent with topographic limitations and the economics of construction. In no case will a radius be used which is less than a minimum shown in Table 1.

Functions of a Circular Curve

The functional parts of a circular curve are shown in Figure 10.

I = Interior or Deflection Angle

T = Tangent Dist. P.C. to P.I. or
P.T. to P.I.

P.I. = Point of Curvature


P.T. = Point of Tangency

R = Curve Radius

E = External Dist.

M = Middle Ordinate

L.C. = Long Chord



Curve Formulae

The values of the functional parts of the curve may be calculated by using the following formulae:

Figure 11 Horizontal Curve Formulae	
$T = R \times \tan \frac{1}{2}I$	Example
$R = \frac{T}{\tan \frac{1}{2}I}$	$I = 30^\circ$
$\tan \frac{1}{2}I = \frac{T}{R}$	$R = 200' \text{ (assumed)}$
$E = \frac{R}{\cos \frac{1}{2}I} - R$	$T = 200 \times \tan 15^\circ = 53.6'$
	$E = \frac{200'}{\cos 15^\circ} - 200' = 7.05'$

Laying Out a Curve by the Middle Ordinate Method

Refer to Table, page 8, Engineering Field Tables, U.S.D.A., Forest Service, and to Figure 12, this handbook.


Laying Out a Curve by the Tangent Method

Refer to Table, page 5, Engineering Field Tables, U.S.D.A., Forest Service, and to Figure 13, this handbook.

Information for both methods can also be obtained at:

<http://www.fs.fed.us/rm/rrr/applications/curvrds.xls>

Figure 12
Laying out a Curve by the Middle Ordinate Method



Refer to Table II, Middle Ordinates, p 8, in Engineering Field Tables, USDA Forest Service


1. For the radius selected, find the desired chord length in the table
2. Find the Middle ordinate for the radius and chord
3. At point A (P.C.), measure $\frac{1}{2}$ the length of the chord on a tangent towards (P.I.) to point B.
4. Measure BC at right angles to AB equal to the distance for the middle ordinate, full chord. Set stake at the C point on the curve.
5. Measure CD equal to the middle ordinate distance. Make AD = AB. Set temporary sighting stake or pole at D.
6. Extend AD to E on a straight line. Make DE = AD. Set stake at the E point on the curve.
7. Measure EF = Middle ordinate distance. Set temporary sighting pole at F. Make CF = CE.
8. Sight from stake C through pole at F, and continue to G. Make FG = CF. Set stake at G as a point on the curve.
9. Continue in the same manner to intersect tangent line at K (P.T.).

Figure 13
Laying out a Curve by the Tangent Method

(Refer to pages 4, 5, 6 of U.S. Forest Service "Engineering Field Tables")

$$\text{Formula: - Tangent offset} = \text{Radius} \sqrt{\text{Radius} \frac{2}{\text{Tangent distance}} - 1}$$

$$\text{T. O.} = R \sqrt{\frac{2}{T. D.} - 1}$$



1. Locate P.C. and P. T. by measuring T. from P. I.
2. From P.C. and P.T., measure toward P.I. distances equal to 0.1 of the radius (in the example, $0.1R = 0.1 \times 550' = 55'$), and set stakes.
3. In the Engineering Field Tables on page 5, look up the tangent offsets for each 0.1 radius station,, for radius selected (550') (e.g. $0.1R = 2.75'$, $0.2R = 11.12'$, etc).
4. From each 0.1 radius station on the tangent, measure at right angles the appropriate distance as shown on the tables. Set stakes at points on the curve.

Vertical Curves

The parabolic vertical curve is used in connecting different rates of grade on a profile. The parabola is used because the elevations can be computed more easily for points on a parabola than for points on a circular arc.

Elements of a Parabolic Vertical Curve

The elements are:

g_1 = incoming grade in percent

g_2 = outgoing grade in percent

P.V.I. = Point of Vertical Curvature

P.V.T. = Point of Vertical Tangent

L = Length of Curve

Minimum Length of a Vertical Curve

To insure that sight distances are adequate to allow for safe travel, standards have been set that place minimums on the length of the vertical curve. These minimums, based on the change in grade, are shown in Table No. 3. They apply on all “summit” curves, where the road crests a hill. Under normal circumstances they will not apply on “sag” curves.

Minimum Lengths of Vertical Curves for Forest Roads

Definitions: g_1 = incoming or approach grade in per cent

g_2 = outgoing or departing grade in per cent

$g_2 - g_1$ = change in grade in per cent
(neglect sign)

L = minimum length of vertical curve in feet

Table 3 Minimum Lengths of Vertical Curves for Forest Roads			
g2 - g 1	L	g2 - g1	L
0 to 4.5	100	11.5 to 12.0	340
4.5 to 5.0	120	12.0 to 13.0	360
5.0 to 5.5	140	13.0 to 13.5	380
5.5 to 6.0	160	13.5 to 14.5	400
6.0 to 6.5	180	14.5 to 15.0	420
6.5 to 7.0	200	15.0 to 16.0	440
7.0 to 8.0	220	16.0 to 16.5	460
8.0 to 8.5	240	16.5 to 17.5	480
8.5 to 9.5	260	17.5 to 18.0	500
9.5 to 10.0	280	18.0 to 19.0	520
10.0 to 11.0	300	19.0 to 19.5	540
11.0 to 11.5	320	19.5 to 20.0	560

Calculation of a Vertical Curve

The following is a solution to produce a 400 ft. vertical curve to “round” the hillcrest at approximate station 47+80.

First the P.V.I. (point of vertical intersection) must be located as to both station and elevation. Choosing points on the profile presented we note:

<u>Sta.</u>	<u>Elev.</u>	<u>Grade</u>
45+00	37.00	+3.8%
50+00	42.50	-2.3%

The intersection of these two grades; which is the P.V.I.; must be equal to itself. Therefore:

1. $37.00 + .038 Z = \text{Elev. of P.V.I.}$
2. $42.50 + .023 (500 - Z) = \text{Elev. of P.V.I.}$

Where “Z” is the horizontal distance from 45+00 to the P.V.I. and “(500 - Z)” is the horizontal

distance from the P.V.I. to 50+00.

Proceeding to solve the simultaneous equation:

Subtracting EQ 1 from EQ 2

$$5.50 + .023 (500 - Z) - .382 = 0$$

$$5.50 + 11.50 - 0.61Z = 0$$

$$Z = 278.69$$

$$\text{Or Sta. Of P. V. I.} = 45+00 + 278.69 \text{ or } 47+78.69$$

Putting Z back into either equation gives:

$$\text{Elev. of P. V. I.} = 47.59$$

We now define the elements of a vertical curve:

g_1 = the incoming grade. In this case + 3.8 %

g_2 = the outgoing grade. In this case -2.3%

P. V. I. = Point of Vertical Intersection. In this case Station 47+78.69, Elevation 47.59

P. V. C. = Point of Vertical Curvature. This is to be calculated.

P. V. T. = Point of Vertical Tangent. This is to be calculated.

L = Length of curve. In this case the length has been chosen as 400 ft., or 4 stations.

In most vertical curves the P. V. C. and P. V. I. are equidistant from the P. V. I.. Therefore:

$$\text{Station P. V. C.} = 47+78.69 - (400 \text{ ft} / 2)$$

$$\text{or } 45+78.69$$

$$\text{Station P. V. T.} = 47+78.69 + (400 \text{ ft} / 2)$$

$$\text{or } 49 + 78.69$$

The corresponding elevations:

$$\text{Elevation P. V. C.} = 47.59 - 200 \times .038 = 39.99$$

$$\text{Elevation P. V. T.} = 47.59 - 200 \times .023 = 42.99$$

All vertical road curves are parabolas; the general equation is:

$$y = ax^2 + bx + c$$

Where:

y = the elevation of the curve at any given point.

x = the horizontal distance in stations from the P. V. C. I.E. @ sta. 48+78.69 $x = 3.00$

$$a = \frac{g_2 - g_1}{2L}$$

$$b = g_1$$

c = elevation of P. V. C.

With our vertical curve:

$$a = \frac{g_2 - g_1}{2L} = \frac{-2.8 - -3.8}{2 \times 4} = -0.726$$

$$b = g_1 = +3.8$$

c = elevation of P.V.C = 39.99

Therefore our equation is:

$$y = -0.762 x^2 + 3.80 x + 39.99$$

With this equation, elevations for any station along the curve can be calculated. The following table shows values for this curve.

Table 4 Example Vertical Curve Values						
Sta.	x^2	x	$-0.762 X^2$	$+3.80X$	$+39.99$	y
45+78.69	0	0	0	0	39.99	39.99
46+78.69	1	1	- 0.76	3.8	39.99	43.03
47+78.69	2	4	- 3.04	7.60	39.99	44.55
48+78.69	3	9	- 6.85	11.40	39.99	44.54
49+78.69	4	16	-12.20	15.20	39.99	42.99

Table 4 Example Vertical Curve Values						
If even station elevations are desired:						
Sta.	x ²	x	-762 X ²	+3.80X	+39.99	y
46+00	0.213	0.045	- 0.03	0.81	39.99	40.77
47+00	1.213	1.471	- 1.12	4.61	39.99	43.48
48+00	2.213	4.897	- 3.73	8.41	39.99	44.67
49+00	3.213	10.323	- 7.87	12.21	39.99	44.33

Required Information For Calculation by the Bureau of Construction Management

Included herewith is a sample sheet showing a set of vertical curves calculated by the Bureau of Construction Management for a typical road. Such a computation can be completed only after the necessary input information has been provided.

This includes:

1. Sta. P.V.C. This station value must be equal to the station of the P.V.I. minus half the chosen length. The station and elevation of the P.V.I. should be carefully computed. See “An Example of Vertical Curve Calculation” for a means of computing the P.V.I. The program provides elevations of the curve at half station increments. Therefore, if it is desired to have these elevations fall on full and half stations of the trail it is necessary that the P.V.C. fall on full or half station.

2. Elev. P.V.C. This elevation should be computed using elevation of the P.V.I., the incoming grade, and half the chosen length (the horizontal distance between the P.V.C. and the P.V.I.).

3. Chosen Length Enter the desired length of curve in stations. i.e. 380 ft. would be entered as 3.80. If the P.V.C. has been selected, the Chosen Length must be equal to twice the horizontal distance from the P.V.I. to the P.V.C. . In the case of “crest” or “hump” curves the chosen length greater than or equal to the minimum length. With “sag” or “valley” curves it is recommended but not absolutely necessary for the Chosen Length to be equal or greater than the minimum length.

4. Min. Length Enter the Minimum Length in stations from the table titled “Minimum Lengths of Vertical Curves for Forest Roads”.


5. g1 is the incoming grade. Enter it as a percentage but do not enter the percentage

sign. -3.8% should be entered -3.8. The sign of the grade is + if the grade is uphill as the station increase. The sign of the grade is - if the grade is downhill as the stations increase.

6. g_2 if the outgoing grade. The instructions for g_1 apply here also.

When the above information is supplied on the form elevations of the curve at half station, increments from including the P.V.C. to the last full or half station before the P.V.T. will be provided. If the P.V.T. falls on a full or half station, its elevation will be the last provided.

Two or more solutions may be desired for a given location. There is no problem in providing multiple solutions. Each alternate solution would, of course, require its own P.V.C. Station and Elevation and its own Chosen Length. It is suggested that alternate solutions for the same location be distinguished by a letter. i.e. 9A, 9B, 9C etc.



Vertical Curves - For Use With Calculator Program

Job LIVINGSTON
CANADIAN STORE FOREST
 2/3

Date 4/18/73

By B.S.H.

Vertical Curve No.	9	9A	10	11	12	13	14	15	16
Sta. P.V.C.	65+50	65+83	83+00	89+50	31+00	37+00	41+00	45+00	50+00
Elev. P.V.C.	1470.67	1467.70	1564.0	1602.2	1729.0	1715.4	1715.0	1730.6	1723.2
Chosen Length ¹	5.46	4.80	2.00	2.00	2.00	1.70	2.58	2.74	1.00
Min. Length ¹	4.80	4.80	1.00	1.00	1.00	1.00	1.00	2.60	1.00
g ₁ ²	-9.0	-9.0	8.0	6.7	-0.3	-2.6	+0.9	+5.0	-4.3
g ₂ ²	+8.0	+8.0	6.7	8.0	-2.6	+0.9	+5.0	-4.3	-7.7
Elev. @ #									
0	1470.67	1467.70	1564.00	1602.20	1729.00	1715.40	1715.80	1730.60	1723.20
.5	1466.56	1463.64	1567.92	1605.63	1728.71	1714.36	1716.45	1732.68	1720.63
1.0	1463.63	1460.47	1571.66	1609.23	1728.13	1713.83	1717.49	1733.90	1717.20
1.5	1460.67	1458.18	1575.29	1612.98	1727.26	1713.82	1718.94	1734.28	
2.0	1458.90	1456.78	1579.70	1616.90	1726.10		1720.78	1733.81	
2.5	1457.90	1456.27					1723.02	1732.49	
3.0	1457.68	1456.64							
3.5	1458.24	1457.89							
4.0	1459.58	1460.03							
4.5	1461.69	1463.06							
5.0	1464.57								

* Stationing from P.V.C. of Vertical Curve
 1 Provide all lengths in stations. i.e. 268 Ft. = 2.68 Stations.
 2 Provide grades in % i.e. for 6.5% provide 6.5.

Figure 15
Vertical Curve Data Sheet

Job _____ Date _____ By _____
Location _____

Vertical Curve No.									
Sta. P.V.C									
Elev. P.V.C									
Chosen Length ¹									
Min. Length ¹									
g_1 ²									
g_2 ²									
Elev. @ *									
0									
0.5									
1.0									
1.5									
2.0									
2.5									
3.0									
3.5									
4.0									
4.5									
5.0									

* Stationing from P.V.C. of Vertical Curve
¹ Provide all lengths in Stations, I.E. 268 Ft. = 2.68 Stations
² Provide grades in percent I.E. for 6.5% provide 6.5

Project Plans

Plan and Profile

A Plan and Profile is required for each forest road. This will be prepared from survey notes for the final center line survey, and will be drawn on Federal Aid Sheets, Plan and Profile Paper, size 22" x 36". The plan and profile of the section of road represented should appear on the same sheet.

Scale

Horizontal Scale - 1 inch = 100 feet

Vertical Scale - 1 inch = 10 feet

Required Information to be Shown

There should be sufficient data on the Plan and Profile sheets to permit construction in the field. Alignment, curve data, grades, location and size of drainage structures, turnouts and typical road sections should be shown. See Figure 13. For curve calculations it is best to assume an appropriate curve radius and calculate other data by use of the applicable formulae.

Approval of the Plan and Profile

The completed Plan and Profile should be forwarded to the Bureau of State Land Management, who in turn will arrange for an engineering review of the sheets by the Bureau of Design and Construction. The purpose of this review is to insure that standards have been adhered to, all necessary information has been provided, and that all calculations are correct. Upon approval of the Plan and Profile, copies will be made and forwarded to the appropriate field office. Major construction should not commence until the plan and profile has been approved.

Permits


A necessary component in the planning process is to identify the need for, and obtain, any applicable permits. Additional planning may be required to comply with a particular permit. For example, a Storm water Pollution prevention plan may need to be developed if a SPEDES permit is required

Drainage

Surface Drainage

The removal of surface water from forest roads, and adequate provision for drainage is a most important part of the planning and construction process. Proper attention given in the planning stage to drainage will minimize later erosion and maintenance problems. Removal of water may be accomplished by crowning of the road surface, cross drainage by culvert pipes placed at regular intervals, water bars on Haul roads, and run-off channels.

Figure 16
Standard Cross Section for Public Forest Access Roads




Culverts

Information on the drainage area served by a culvert, or bridge, should be obtained from topographic data. For most surface drainage, and 18 inch diameter culvert will suffice, but for larger drainage areas, Table 5 provides necessary design information. In Table 4, culverts up to 90 inches in diameter are shown. For larger area waterways, use bridge dimensions, or comparative area, as indicated.

Cross Sections and Estimates

Economy of road construction requires that every effort should be made to balance cut and fill sections. These can be estimated by preparing cross sections at successive stations, showing elevation of existing ground, side slopes, and proposed grade elevation, with typical road section plotted on the cross section. See Figure 15. One method is to use cross-section paper, 10x10 squares to inch at a scale of 1 inch = 10 feet, both horizontal and vertical scale.



**Table 5
Round Culvert Sizing**

Size of round culvert pipe needed for 2.5 inch per hour rainfall

Acres in Drainage Area	Impervious 100% runoff	Steep Slopes/ Heavy Soils		Moderate Slopes/ Heavy to Light soils + Dense Cover		Gentle slopes Agricultural soils Agricultural cover		Flatland/ Previous soils
		C = 0.80	C = 0.70	C = 0.60	C = 0.50	C = 0.40	C = 0.30	
Required Culvert Cross Sectional Size								
2	15	15	15	15	15	15	15	15
4	18	15	15	15	15	15	15	15
6	18	18	18	15	15	15	15	15
8	24	24	18	18	18	15	15	15
10	24	24	24	18	18	18	15	15
20	30	30	30	24	24	24	18	15
40	42	36	36	36	30	30	24	18
60	48	42	42	42	36	36	30	24
80	54	48	48	42	42	36	30	24
100	60	54	54	48	48	42	36	30
150	72	66	60	54	54	48	42	36
200	78	72	66	60	60	54	48	36
250	84	78	72	66	60	54	48	42
300	90	84	78	72	72	60	54	42
400	8 x 7	90	84	78	72	66	60	48
500	10 x 7	9 x 6	90	84	78	72	60	54
700	10 x 9	10 x 7	10 x 6	10 x 5	90	84	72	60
1000	10 x 12	10 x 9	10 x 8	10 x 7	10 x 6	90	78	66

Table adapted from Permanent Logging Roads handbook, U.S. Forest Service

Based upon Talbots formula $A = C \sqrt{M^3}$

A = Area of the drainage basin.

C = Constant factor based on slope, soil absorptive capacity and cover.

M = Area in square feet of waterway required.


No culverts smaller than 15" will be used

Calculation of Yardage from Cross Section

The area of each cross section in square feet can be determined by a planimeter. To obtain volumes in cubic yards, multiply the average cross section area (sq. ft.) of two successive stations by the distance (ft.) between the stations and divide the result by 27.

Balance on Side Hill Cuts

On side hill cuts, the cut from the uphill side should approximately balance the fill on the downhill side, as shown in Figure 15. This will avoid the cost of moving materials over a long distance.



Erosion Control

Construction operations generate conditions which require methods to prevent or reduce erosion of slopes. The areas involved include side slopes, road bed, shoulders, and back slopes. Erosion will increase the costs of maintenance to correct the condition, and cause deposits of silt in streams. Each project must conform to the State Forest Commercial Products Sales Program GEIS, and any other applicable provisions of SEQRA.

Erosion Control Methods

Slope Angle

Flatter slopes are less likely to erode, and they permit a quicker establishment of vegetative cover. Therefore, within the limitations of economic construction, the flattest feasible slopes will be used. The tops of cut slopes should be rounded to reduce erosion, and improve appearance.

Vegetative Cover

Vegetative cover, including perennial grasses, low shrubs and/or legumes may be planted on the slopes to bind soil. A mulch of straw or wood chips blown on the slopes will retain moisture and help vegetation to become established. In selecting species for planting, the recommendations of

the Regional Supervisor of Fish and Wildlife will be sought to insure proper consideration for wildlife values.

Rip-Rap

Where the slope is likely to come in contact with flowing water, loose rock rip-rap protection is needed to prevent erosion. This is particularly the case with culverts, and along bridge wing-walls.

Road Crown

Roads will be crowned 1/4 inch per foot of road width to drain surface water from the road center towards the shoulders.

Streams

Roads will not be constructed in stream channels. A filter strip with a minimum width of 150 feet will be maintained where a road parallels a stream. When required, stream crossings will be made at right angles, insofar as possible, to minimize siltation and to disturb the stream as little as possible.

Construction

Construction Standards

Roads will be constructed to the standards as outlined in this handbook. Standards establish the width, grade, alignment and service class of roads to be constructed.

Job Planning and Supervision

Roads should be surveyed and planned well in advance of the proposed date of construction. Planning is required at least one year in advance so that the necessary materials and equipment may be ordered, and to obtain the necessary funds. Planning includes a provision for supervision of the project by persons trained and informed in road construction standards and methods.

Safety

Full consideration must be given to the use of all appropriate safety measures and equipment. Road construction contains many hazardous situations for which provisions must be made. The use of heavy equipment and explosives, falling and flying objects, and lifting of objects are examples of situations which demand full safety measures to prevent accidents and serious injury.

Safety Standards

Applicable Department safety standards will be strictly adhered to during all phases of planning and construction.

Use of Explosives

Explosives will be used only under the direction of a competent person, licensed by the New York State Department of Labor to engage in such work. All applicable State and Federal laws relating to the use, possession, storage and transport of explosives will be observed. “The Blaster’s Handbook”, prepared by the E.I. DuPont Company, should be used as a guide in all blasting operations.

Right-Of-Way Clearing

Clearing the right-of-way for road construction will be accomplished after the final center line location has been determined and staked in the field. This includes center line stakes, offset stakes, and slope stakes where required.

Protection of Stakes

Workers engaged in the clearing operation should be instructed to use special care to insure that stakes are not damaged or destroyed as a result of their activities.

Width of Clearing

Width of the right-of-way to be cleared will be determined by the class of the road being constructed, and the topography.

Disposal of Cut Material

Insofar as possible, brush from tops should be chipped and scattered on the site. Useable materials will be cut and piled along the sides of the right-of-way for sale or other use. If it is not feasible to chip tops they should be pulled at least 30 feet from the edge of the road right-of-way, and lopped and scattered close to the ground. This will improve the aesthetics along the road and aid in the deterioration of the woody material.

Stumps

Stumps of large trees can be blasted to facilitate removal and to reduce the soil clinging to them. If necessary to remove trees on the lower side of side hill cuts, the low-cut stumps may be left and covered with at least one foot of fill. Stumps will be disposed of either in stump dumps along the right-of-way, righted and scattered unobtrusively outside the right-of-way, or trucked off. Efforts should be made to reduce the visibility of removed stumps from the road.

Grading

Rough grading can be best accomplished with a bulldozer. After the rough grading is completed, a grader will smooth out the road to proper grade, prepare the sub-grade, pull up earth shoulders to contain the surfacing material, and smooth out the side slopes. The ditch line can also be cleared with a grader to give a uniform slope.

Grade Stakes

Grade stakes, as required, should be set at the side of the road where they will not be disturbed. Stationing and the sub-grade elevation reference point will be marked on all grade stakes.

Rock Excavation

Rock excavation is costly and should be avoided wherever possible. If conditions require that rock excavation be done, the depth of excavation needed should be calculated, and arrangements made for the necessary drilling and blasting. Depth should be sufficient to permit at least one foot of fill material and 8 inches of surfacing material over the final rock surface. Side slopes of rock cut should be no more than 0.50 : 1.

Sub-surface Drainage

Sub-base and fill material should be of such a nature that it will permit sub-drainage of the road to the ditch line. This would include rock fill, coarse gravel, or coarse shale. Where seepage points occur, water should be conducted through a channel of rock weep-drains to the ditch line. In severe cases, perforated tile should be used.

Surface Drainage

Road crowns, ditches, culverts and bridges should be designed to take care of the surface drainage. A properly crowned road will conduct water to the ditch line and prevent rutting. Ditches carry water alongside the road until it reaches a culvert, a lead-off channel, or a stream. Ditches should have no less than a 1% slope to drain properly.

Culverts

Culverts will take care of most surface drainage until the drainage area exceeds 400 acres.

Waterway requirements in excess of 44 square feet will call for a bridge to handle the flow. Use Table No. 4 to calculate the size of drainage structure required. Culverts will be required at low points, stream crossings, and spaced not over 300 feet apart on side hill cuts to provide cross drainage.

Culvert Installation

Culverts should be installed according to the following guidelines:

1. Installation should equal or exceed slightly the slope of the stream or ditch which flows through the culvert.
2. Put in a cushion of sand or fine gravel to minimum depth of 6 inches in the bottom of the trench dug for the culvert. Put grade stakes at upper and lower end (minimum slope 2%). Make center of cushion approximately 2 inches higher than grade to allow for settling of the pipe when covered.
3. Culverts should be 40% of length uphill from center line; 60% downhill from center line.
4. Fine sand or gravel should be tamped in all around and over the culvert. Pipes should be covered with fill to a depth at least equal to their diameter.
5. Culvert pipes should be angled downhill from a right angle on side hill drainage.
6. Add two feet to establish length of culvert pipe needed.
7. If road crosses a stream at an angle, culvert pipes should be skewed to be in line with stream flow.
8. Avoid twin culverts. Use a larger size single culvert, or “squash” type culvert if elevation is a problem.
9. Make drop inlets or catch basins at culvert inlets to intercept water, and to protect inlet. Use dry masonry or concrete masonry as situation requires. Culvert outlets should be protected by culvert head walls or stone rip-rap. See Figures 17 and 18.

Figure 19
Culvert Placement - Alignment




Figure 20
Culvert Placement - Cross Section

