Table 2-1
Sample Inventory and Analyses Performed of Soil, Soil Vapor, Indoor Air, and Groundwater
Former Empire Electric Facility, Brooklyn, New York
Site Number 2-24-015

	Matrix	Laboratory Analysis Method					
Sub-Slab & Indoor Air Samples		**TO-15**					
SS-01	Air	x					
IA-01	Air	x					
Groundwater Monitoring Wells - December 2006		**VOCs 8260b**	**SVOCs 8270**	**PCBs 8082**			
EMMW-5	Groundwater	x	x	x			
EMMW-5 (Filtered)	Groundwater			x			
Soil Boring Samples (Depth in feet below basement grade or road grade)		**VOCs 8260b**	**SVOCs 8270**	**PCBs 8082**	**Pesticides 8081**	**Metals 6010**	**Hg 7471**
SB-01-0.0-0.6	Soil	x	x	x	x	x	x
SB-01-3.0-3.5	Soil	x	x	x	x	x	x
SB-02-0.0-0.6	Soil	x	x	x	x	x	x
SB-02-3.0-3.5	Soil	x	x	x	x	x	x
SB-03-0.6-1.0	Soil	x	x	x	x	x	x
SB-04-0.6-1.0	Soil	x	x	x	x	x	x
SB-05-0.6-1.0	Soil	x	x	x	x	x	x
SB-06-0.6-1.0	Soil	x	x	x	x	x	x
SB-07-0.6-1.0	Soil	x	x	x	x	x	x
SB-08-0.6-1.0	Soil	x	x	x	x	x	x

TO = Toxic Organics
VOCs = Volatile Organic Compounds
SVOCs = Semi-Volatile Organic Compounds
PCBs = Polychlorinated Biphenyls
Hg = Mercury