

FINAL
VAPOR INVESTIGATION WORK PLAN
SHERIDAN WASTE OIL COMPANY
SITE NO. 1-52-024

WORK ASSIGNMENT NO. D004434-25

Prepared for:

New York State Department of Environmental Conservation
Albany, New York

Prepared by:

MACTEC Engineering and Consulting, P.C.
Portland, Maine

Project Number: 3612072085

AUGUST 2007

This document was prepared for the sole use of New York State Department of Environmental Conservation, the only intended beneficiary of our work. No other party shall rely on the information contained herein without prior written consent of MACTEC Engineering and Consulting, P.C.

FINAL
VAPOR INVESTIGATION WORK PLAN
SHERIDAN WASTE OIL COMPANY
SITE NO. 1-52-024

WORK ASSIGNMENT NO D004434-25

Prepared for:

New York State Department of Environmental Conservation
Albany, New York

Prepared by:


MACTEC Engineering and Consulting, P.C.
Portland, Maine

Project Number: 3612072085

AUGUST 2007

This document was prepared for the sole use of New York State Department of Environmental Conservation, the only intended beneficiary of our work. No other party shall rely on the information contained herein without prior written consent of MACTEC Engineering and Consulting, P.C.

Submitted by:


John W. Peterson, P.M.
Project Manager

Approved by:



Eric C. Sandin, C.G.
Site Manager

TABLE OF CONTENTS

LIST OF FIGURES	ii
LIST OF TABLES.....	iii
GLOSSARY OF ACRONYMS AND ABBREVIATIONS.....	iv
1.0 INTRODUCTION	1-1
2.0 SITE LOCATION AND HISTORY	2-1
3.0 SCOPE OF WORK	3-1
3.1 GENERAL FIELD ACTIVITIES	3-1
3.2 TASK 2 – SAMPLING	3-3
3.2.1 Structure Sampling	3-3
3.2.2 Soil Vapor Sampling	3-6
4.0 REFERENCES	4-1

FIGURES

TABLES

APPENDICES

APPENDIX A:	NYSDOH GUIDANCE FOR EVALUATING SOIL VAPOR INTRUSION
APPENDIX B:	QUALITY ASSURANCE PROJECT PLAN
APPENDIX C:	HEALTH AND SAFETY PLAN

LIST OF TABLES

Table

- 3.1 Proposed Field Tasks and Methodology
- 3.2 Proposed Sample Identification and Analyses

GLOSSARY OF ACRONYMS AND ABBREVIATIONS

HASP	Health and Safety Plan
MACTEC	MACTEC Engineering and Consulting, P.C.
ml/min	milliliters per minute
NYSDEC	New York State Department of Environmental Conservation
NYSDOH	New York State Department of Health
PID	photoionization detector
PMWP	Project Management Work Plan
ppm	parts per million
QA	Quality Assurance
QAPP	Quality Assurance Program Plan
QAPjP	Quality Assurance Project Plan
QC	Quality Control
Site	Sheridan Waste Oil Company Site
SVIE	Soil Vapor Intrusion Evaluation
$\mu\text{g}/\text{m}^3$	micrograms per cubic meter
VI	Vapor Investigation
VOCs	Volatile Organic Compounds
WA	Work Assignment
WP	Work Plan

1.0 INTRODUCTION

MACTEC Engineering and Consulting, P.C. (MACTEC), under contract to the New York State Department of Environmental Conservation (NYSDEC), is submitting this Site Characterization Work Plan (WP) for the Sheridan Waste Oil Company Site (Site). This WP addresses the Vapor Investigation (VI) at the Sheridan Waste Oil Company Site (Site # 1-52-024) in Medford, Suffolk County (see Figure 1.1 for Site Location). This WP has been prepared in accordance with the NYSDEC requirements in Work Assignment (WA) No. D004434-25 dated March 28, 2007, and with the April 2006 Superfund Standby Contract No. D004434 between the NYSDEC and MACTEC. Vapor and air samples will be collected in accordance with New York State Department of Health (NYSDOH) “*Guidance for Evaluating Soil Vapor Intrusion in the State of New York*” (NYSDOH, 2006).

The VI Project Management Work Plan (PMWP), submitted under separate cover, provides cost budgets for WA Tasks 1 through 3, including budget estimates for subcontractors and other direct field investigation costs. The PMWP also provides project organization, staffing plan, and schedule for this WA.

Based on the results of a Soil Vapor Intrusion Evaluation (SVIE) that was conducted in 2006, NYSDEC has required additional characterization investigation to evaluate potential vapor impacts to surrounding structures.

This WP represents the culmination of Work under Task 1. During Task 1, MACTEC reviewed historical Site information and developed technical and costing information for the scope of work identified by NYSDEC for the VI WP. The WA is provided in Appendix A, the Quality Assurance Project Plan (QAPjP) is presented in Appendix B. A WA-specific Health and Safety Plan (HASP) is presented in Appendix C. The HASP covers site-specific activities at the Sheridan Waste Oil Company Site and three additional Sites where work is planned concurrently.

Resources used to prepare this plan include: (1) information provided in the WA, (2) appropriate guidelines in the NYSDEC Draft DER-10 Guidance (NYSDEC, 2002), (3) results of previous

investigations, (4) Program HASP (MACTEC, 2005) and (5) Quality Assurance Program Plan (QAPP) (ABB ES, 1994).

2.0 SITE LOCATION AND HISTORY

The Sheridan Waste Oil Company Site is located at 114 Peconic Avenue in the Town of Medford, Suffolk County and occupies approximately 2.7 acres. The site was a waste oil recycling operation from 1977 to 1983, during which time oil spills and discharges of solvent and heavy metal contaminated water were reportedly deposited to the on-site soil.

As a result of a complaint in April 1982, significant amounts of volatile organic compounds (VOCs) were found in the groundwater on and off the property. The Suffolk County Department of Health (SCDOH) closed down the recycling operation and forced the removal of above ground and below ground storage tanks (in 1984). The Site was included on the New York List of Inactive Hazardous Waste Sites in June 1986 as a Class 2 Site. Based on the results of a subsequent 1990 Remedial Investigation, it was determined that there was no remaining current or potential threat to public health and the environment.

In February 2005, the site was included on the List of Inactive Hazardous Waste Sites with Pre-2003 Remedial Decisions Where Disposal of Chlorinated Hydrocarbons Occurred.

NYSDEC completed a SVIE in 2006. The SVIE included five groundwater grab samples and co-located soil gas samples that were collected from two depths at each location. Elevated concentrations of VOCs were found within the soil vapor at levels up to 244 micrograms per cubic meter ($\mu\text{g}/\text{m}^3$) of toluene, 169 $\mu\text{g}/\text{m}^3$ methylene chloride, 24 $\mu\text{g}/\text{m}^3$ tetrachloroethene (PCE), and 42 $\mu\text{g}/\text{m}^3$ 1,1,1-trichloroethane.

The goals of this WA are to evaluate the adjacent structures to determine if site contaminants have impacted adjacent structures.

3.0 SCOPE OF WORK

NYSDEC has determined that sampling of adjacent structures is necessary to document that residual contaminants in soil vapor are not a human health hazard. This section describes the scope of work that MACTEC will perform under this WA. The VI will be conducted in accordance with the specifications presented in the QAPP (ABB-ES, 1994) and the site specific QAPjP, included as Appendix B of this WP. Quality Control (QC) and Quality Assurance (QA) procedures for sample handling and sample shipment are presented in Section 5.0 of the QAPP. QA/QC sample frequencies are presented in table 3.2. Health and Safety procedures for on site activities are presented in the Program HASP (MACTEC, 2005) and the site specific HASP is included as Appendix C to this WP. Off-site laboratory analyses will be performed by Con-Test, a NYSDOH-approved and Environmental Laboratory Accreditation Program-certified laboratory.

3.1 GENERAL FIELD ACTIVITIES

General field activities, including mobilization, health and safety, and decontamination, are described in the following subsections. Upon approval of the PMWP and WP, MACTEC will procure the subcontractors.

Mobilization. Upon receiving the NYSDEC authorization to begin fieldwork, MACTEC will mobilize to the Site and begin the field program. Mobilization will include obtaining utility clearances, if applicable, and acquisition of the following:

- transportation to and from the Site;
- health and safety clothing and monitoring equipment;
- decontamination supplies and equipment; and
- sampling equipment.

A field team orientation meeting will be held on-site with MACTEC personnel to familiarize field workers with site history, health and safety requirements, equipment calibration procedures, and other field procedures.

Health and Safety. The site-specific HASP is provided as Appendix C to this document. Based on available site information, MACTEC anticipates that the field activities will be conducted at Level D personal protection. Specific field investigation activities and required level of personal protection are set forth in the HASP. Criteria for upgrading or downgrading the specified level of personal protection are provided in the site specific HASP. Additional health and safety requirements are set forth in the Program HASP (MACTEC, 2005). Should site conditions pose a threat to those present on-site, and/or should site conditions warrant an upgrade from Level D, as defined by the Site specific HASP, work will stop and the situation will be reevaluated by the NYSDEC and MACTEC.

Decontamination. Sampling methods and equipment for this field program have been chosen to minimize decontamination requirements and minimize possibility of cross contamination. Disposable sampling equipment will be used as much as practical to minimize decontamination time and water disposal. Non disposable sampling equipment will be decontaminated before and after the collection of each sample per Subsection 4.3 of the QAPP and as outlined in the WA (see page 3, Appendix A).

Decontamination fluids will be released on-site to the ground surface in the area of decontamination, so as to allow the liquids to infiltrate into the soil and not run off-site. In the event that decontamination fluids or equipment exhibit visual or olfactory evidence of contamination, fluids will be containerized for offsite disposal.

Investigation Derived Wastes. Decontamination fluids will be discharged to the ground surface unless a visible sheen or odor is detected either on the equipment or the fluids, at which point the water will be staged in an appropriate container and disposed of appropriately. Wastes generated during collection of sub-slab samples will be removed from each structure and disposed of as municipal waste. These wastes are not anticipated to contain hazardous materials.

Personal Protective Equipment. Used disposable equipment and protective clothing will be double bagged in polyethylene trash bags and sealed with twist ties. MACTEC personnel will measure the headspace in the closed bags with a photoionization detector (PID) at least one hour after sealing the bags. If the headspace reading is greater than 5 parts per million (ppm), the tubing will be decontaminated by flushing with potable water and re-bagged. This process will be

repeated until PID readings are below 5 ppm. If the headspace is below 5 ppm, the disposable equipment and clothing will be disposed of as non-hazardous refuse.

Air Monitoring. Ground invasive activities such as interior sub-slab vapor points and exterior soil gas vapor points will require monitoring for VOCs. A PID will be used to assess ambient conditions and to monitor for any added volatiles during each invasive activity. The activities described in this WP are not expected to release VOCs or generate dust at levels that would pose a risk to the community. MACTEC will use common-sense measures to keep VOCs, dust, and odors to a minimum during the performance of all field work. For example, sub-slab soil vapor point sampling will include purging vapor into a syringe or other container instead of into the building interior space. A Community Air Monitoring Plan (CAMP) will be prepared if conditions are encountered that would require an upgrade to personal protective equipment or if the scope of invasive activities evolves to include larger diameter borings than geoprobe or more extensive sub-slab penetration to investigate residual contamination at a release location.

Location Survey. MACTEC will develop a site plan (figure) using the most recent available public aerial photography. The plan will identify pertinent features such as buildings, roadways, fences, etc. MACTEC will locate sampling points and monitoring wells on the plan using Ground Positioning System (GPS) such as a Trimble XR or XT Sub-meter unit.

3.2 TASK 2 – SAMPLING

3.2.1 Structure Sampling

MACTEC will collect air samples at four structures at the Sheridan Site to evaluate the soil vapor intrusion pathway (Figure 3.1). The typical sampling approach for each structure includes:

- Completion of the NYSDOH Indoor Air Quality Questionnaire and Inventory,
- One sub-slab soil vapor air sample (or basement/crawl space air sample if basement/crawl space floor is dirt),
- One basement air sample (if floor is sealed),
- One air sample from the first floor, and
- An outdoor ambient air sample (a total of two ambient air samples are planned to document outside conditions in the neighborhood of the Site).

Figure 3.1 includes the locations of proposed structure samples and Tables 3.1 and 3.2 summarize the sampling and analytical program

Indoor Air Questionnaire and Inventory Survey.

Indoor air surveys and product inventories will be conducted at each home sampled using the NYSDOH “Indoor Air Quality Questionnaire and Building Inventory” form, included in Appendix A. A MiniRae PID that measures parts per billion will be used to scan inventoried items that may be off-gassing VOCs. VOCs that are listed on the household container and are also included on the air sample analytical target compound list will be noted on the inventory form, along with any PID readings. If any products that are inventoried list primary contaminants of concern (i.e. chlorinated solvents) as ingredients and exhibit positive PID results above background, and if the homeowner/resident allows, such containers will be removed from the home to an alternative location (i.e. garage or shed) and MACTEC will wait approximately 24 hours before commencing sampling activities. If it is determined that no containers need to be moved or no alternative location is available, MACTEC personnel may sample the home upon completion of the survey.

The completed surveys will include sketches of the structure layout and location of air and sub-slab samples.

Sub-slab, Soil Vapor, Indoor Air, and Ambient Outdoor Air Samples.

Sub-slab soil vapor samples will be collected from below each building’s concrete slab. A one-inch diameter hole will be drilled with a hammer drill two inches into the building floor. The hole will be continued with a 3/8-inch drill bit, until the building slab is penetrated. The hole will be continued approximately 3-inches below the slab. The hole will then be swept to remove drill cuttings/dust from the area. A permanent sub-slab vapor point will be constructed utilizing a stainless steel sample port and ¼-inch diameter Teflon tubing such that the sampling port and screw on cap is flush with the upper floor surface. Prior to sampling, three volumes of air will be purged from the tubing with the PID or with a polyethylene syringe at a rate less than 200 milliliters per minute (ml/min). A 6-liter SUMMA®-type canister with a certified 24-hour flow valve will be connected to the tubing.

Indoor air samples will be collected in 6-liter SUMMA®-type canisters from the basement level or crawl space. Samples will be collected from approximately three to five feet above the floor level and set up with 24-hour flow valves.

A second indoor air sample will be collected from the first floor level (i.e. one sample will be collected from the first floor of occupied living space in the home/business). The second samples will also be collected from approximately three to five feet above the floor level, and set up with 24-hour flow valves.

Ambient air samples will be collected in 6-liter SUMMA®-type canisters from the vicinity of the homes/businesses being sampled for indoor air and sub-slab vapor VOC contamination. Samples will be collected from approximately three to five feet above ground surface. Ambient air samples will be set up with 24-hour flow valves. MACTEC anticipates that a total of two ambient air samples will be collected on successive sampling days.

For all air samples, the time of sample collection, canister vacuum (in inches Mercury), weather conditions, and barometric pressure will be recorded in the field log book. After approximately 24-hours, the flow valves will be shut off. The time, remaining vacuum in the canister and barometric pressure will be noted in the field log book. The samples will be analyzed by Con-Test for VOCs via USEPA method TO-15. Laboratory analysis will include Category B deliverables.

While conducting sub-slab soil vapor sampling, the following will be performed:

- Measure PID readings before and after sampling
- At the time the flow valve is opened, document the initial reading and a reading shortly thereafter to verify that the canister and flow valve are working properly.
- Confirm sample was collected at an appropriate rate by monitoring gage pressure accordingly
- A minimum of three implant volumes shall be purged from each sampling point prior to collecting soil gas samples (less than 200 ml/min)
- Sample at a rate less than 200ml/min for at least 20 minutes
- Field notes will include any observations during installation and purging of sub-slab points (e.g., quicker flow rate, final vacuum, etc.)
- The PID measurement, regulator ID, and SUMMA® ID will be included on the Chain of Custody Record

- Field duplicate pair will be collected by connecting a second canister before purging by installing a ¼ inch stainless steel “tee” fitting between the probe discharge tubing and the stainless steel valve.

3.2.2 Soil Vapor Sampling

At NYSDEC’s request, MACTEC will sample soil vapor from a single location along Hanover Place. Historical data indicates low levels of chlorinated compounds in groundwater at this location downgradient from the Site. MACTEC will install a single soil vapor point within the road right-of-way alongside 3 Hanover Place. The approximate location is shown on Figure 3.2.

The vapor point will be installed up to 8 feet below ground surface (bgs) using hand augering or driving methods. A small-diameter (1 to 1 ½ inch diameter) borehole will be created using a hand auger and/or slide hammer to advance a borehole to 8-feet or as deep as possible and a soil vapor implant will be installed in the shallow open borehole. The implant will have a 6-inch length with a double woven stainless steel wire screen. Glass beads will be used to create a sampling zone around the screen. The beads will extend one foot above the top of the implant screen. Bentonite slurry will be placed above the glass beads and extending up to the ground surface. Inert Teflon tubing with cap will extend from the implant to the ground surface to permit sampling.

Before collecting samples, vapor will be purged from the constructed implant such that greater than three times the volume of the annular space of the screen pack plus the volume of the implant and sample tubing is removed. The volume calculation will be documented in the field notes and the purge rate will be at a rate of less than 0.2 liters per minute using a personal air monitoring pump. During the soil gas purge, vapors will be screened with a PID. In addition, a helium leak test will be conducted to ensure the sample is representative of sub-surface conditions and not outdoor ambient air. This helium test will be conducted by encapsulating the sample point with a bucket sealed to the ground surface with hydrated bentonite. The encapsulated area will be filled with helium, but care will be taken not to pressurize the enclosure. The soil gas sample port will be tested for helium breakthrough with a portable monitoring device (e.g., Radiodetection MGD-2002 Multi Gas Meter) both before and after collection of the soil gas sample. If greater than 10 percent of the tracer gas is detected in the screening sample, the sample point seal will be enhanced and the procedure repeated. The soil gas samples will be collected with one-liter SUMMA®-type canisters with flow valves (set to approximately 20 minutes per sample). Flow into the canisters will be less

than 0.2 liters per minute, as requested by the NYSDOH. Samples will be analyzed by Con-Test for VOCs by USEPA Method TO-15 with minimum reporting limits of 1.0 ug/m³.

4.0 REFERENCES

ABB Environmental Services, 1994. Program Quality Assurance Program Plan. Prepared for the New York State Department of Environmental Conservation, Albany, New York. June 1994.

MACTEC Engineering and Consulting, Inc. P.C., 2005. *Program Health and Safety Plan*. Prepared for New York State Department of Environmental Conservation, Albany, New York. 2005.

New York State Department of Environmental Conservation (NYSDEC), 2007. Work Assignment #D003826-25, Sheridan Waste Oil Company, Site # 1-52-024- letter dated March 28, 2007.

New York State Department of Environmental Conservation (NYSDEC), 2002. Draft DER-10, Technical Guidance for Site Investigation and Remediation. December 2002.


New York State Department of Health (NYSDOH), 2006. “*Guidance for Evaluating Soil Vapor Intrusion in the State of New York*”, Final, October 2006.

FIGURES



**SITE
LOCATION**
114 Peconic Ave
Medford, NY

Legend

 Approximate Site Boundary



0 100 200
Feet

Prepared/Date: BRP 06/07/07
Checked/Date: ECS 06/07/07

NYSDEC
Sheridan Waste Oil Company
Medford, NY



Site Location

Project 3612072085 Figure 1.1





TABLES

TABLE 3.1: PROPOSED FIELD TASKS AND METHODOLOGY

Exploration Type	Exploration ID	Location	Termination Criteria	Sample Determination	Rationale	Analytical ¹
Sub-slab Soil Vapor	SV-01 to SV-04	One in basement of site building and one in three adjacent buildings.	2" below sub-slab.	Based on OBG study (2006)	To define extent of contamination from the site.	VOCs by TO-15
Soil Vapor (Exterior)	DP-01	Right-of-way (unpaved roadside) opposite 3 Hanover Place.	8 feet or to refusal using hand auger methods. Sample collected over approximately 20 minutes	Based on successful completion and leak-testing of insert	Requested by county health department to assess vaporlevels downgradient of Site where hisotirc groundwater contamination was documented	VOCs by TO-15
Indoor Air/Ambient Air Sampling	BA-01 to BA-04; FA-01 to FA-04 AA-01 to AA-02	One in basement of site building and one in three adjacent buildings. Two ambient air samples from outdoor locations on consecutive days	Indoor sample from approximately two feet above floor. Samples collected over approximately 24-hours using a rate-certified regulator	Based on OBG study (2006)	To define extent of contamination from the site.	VOCs by TO-15

Prepared/Date: MJW 4/26/07
 Checked/Revised: ECS 8/15/07

Table 3.2: Proposed Sample Identification and Analyses

					Vapor Samples
Site Type	Media	Site ID	Sample ID	DUP	VOCs (TO-15)
Sub-Slab Soil Vapor Sampling					
Soil Vapor	Vapor	SS-001	SOSS001	1	1
Soil Vapor	Vapor	SS-002	SOSS002		1
Soil Vapor	Vapor	SS-003	SOSS003		1
Soil Vapor	Vapor	SS-004	SOSS004		1
Basement Air Sampling					
Air	Vapor	BA-001	SOBA001		1
Air	Vapor	BA-002	SOBA002		1
Air	Vapor	BA-003	SOBA003		1
Air	Vapor	BA-004	SOBA004		1
First Floor Air Sampling					
Air	Vapor	FA-001	SOFA001		1
Air	Vapor	FA-002	SOFA002		1
Air	Vapor	FA-003	SOFA003		1
Air	Vapor	FA-004	SOFA004		1
Ambient Air Sampling					
Air	Vapor	AA-001	SOAA001		1
Air	Vapor	AA-002	SOAA002		1
Exterior Soil Vapor Sampling					
Soil Vapor	Vapor	DP-01	SODP001		1
TOTAL SAMPLES				1	15

Notes:

Sample ID = SO (Sheridan Waste Oil);

SS (sub-slab); BA (basement air); FA (First livable floor air); AA (ambient air)

DUP = Duplicate sample collected

TO-15 = Vapor samples analyzed for VOCs by USEPA Method TO-15.

Prepared/Date: MJW
 4/26/07
 Checked/Revised: ECS
 8/15/07

APPENDIX A

NYSDOH GUIDANCE FOR EVALUATING SOIL VAPOR INTRUSION (Sections 2.6 and 2.7 from Final, October 2006 Guidance document)

FINAL

**Guidance for Evaluating Soil Vapor Intrusion
in the State of New York**

October 2006

Prepared by:



NEW YORK STATE DEPARTMENT OF HEALTH

Center for Environmental Health

Bureau of Environmental Exposure Investigation

2.6 Sampling locations

The general approach for selecting sampling locations as part of a soil vapor intrusion investigation is similar to the approach for the investigation of other environmental media (e.g., soil and groundwater). Sampling locations should be selected with consideration of the conceptual site model [Section 1.6]. These locations should be selected to meet the stated objectives of the sampling program. Additionally, similar to the investigation of soil and groundwater, it is typical to start at a known or suspected source and work outward. The specific approach, however, will be dependent upon site-specific and building-specific conditions.

2.6.1 Soil vapor

If available, existing environmental data (e.g., groundwater and soil data) and site background information should be used to select locations for sampling soil vapor as part of a vapor intrusion investigation. Locations will vary depending upon surface features (e.g., presence or absence of buildings, areas of pavement, or vacant lot) and subsurface characteristics (e.g., soil stratigraphy, buried structures, utility corridors, or clay lenses), as well as the specific purpose of the sampling. Therefore, a figure illustrating proposed sampling locations (with respect to both areal position and depth), actual locations sampled in the field, and relevant on-site and off-site features should be included in all sampling work plans and reports.

Examples of how locations may vary given the specific purpose of the sampling follow. They include general guidelines that should be followed when selecting soil vapor sampling locations:

- a. to evaluate the **potential for current on-site or off-site exposures**, samples should be collected
 1. in the vicinity of a building's foundation [see special sampling consideration at the end of Section 2.6.1 if sampling around a building with no surrounding surface confining layer], as well as between the building's foundation and the source (if known and not located beneath the building),
 2. along the site's perimeter, and
 3. at a depth comparable to the depth of foundation footings (determined on a building-specific or site-specific basis) or at least 1 foot above the water table in areas where the groundwater table is less than 6 feet below grade;
- b. to evaluate the **potential for future exposures if development** on a known or suspected contaminated area on-site or off-site is possible, representative samples should be collected
 1. in areas with either known or suspected subsurface sources of volatile chemicals, in areas where elevated readings were obtained with field equipment during previous environmental investigations, and in areas of varying concentrations of contamination in the upper groundwater,
 2. in a grid pattern across the area (at an appropriate spacing interval for the size of the area) if information is limited for the area, and
 3. at multiple depths from the suspected subsurface source, or former source, to a depth comparable to the expected depth of foundation footings;

- c. to evaluate the **potential for off-site soil vapor contamination**, samples should be collected
 - 1. along the site's perimeter,
 - 2. in areas of potential subsurface sources of vapor contamination (e.g., a groundwater plume that has migrated off-site), and
 - 3. at a depth comparable to the depth of foundation footings (determined on a site-specific basis) or at least 1 foot above the water table in areas where the groundwater table is less than 6 feet below grade;
- d. to evaluate on-site and off-site **preferential migration pathways** in areas with low permeability soils, samples should be collected
 - 1. along preferential soil vapor flow paths, such as sewer lines, utility corridors, trenches, pipelines, and other subsurface structures that are likely to be bedded with higher permeability materials, and
 - 2. at depths corresponding to these subsurface features (will depend on site-specific conditions);
- e. to characterize on-site or off-site **contamination in the vadose zone**, samples should be collected
 - 1. in areas with either known or suspected sources of volatile chemicals, in areas where elevated readings were obtained with field equipment (e.g., PID) during previous soil and groundwater investigations, and in areas of varying concentrations of contamination in the upper groundwater regime, and
 - 2. at appropriate depths associated with these areas (will depend on site-specific conditions); and
- f. to investigate the **influence of contaminated groundwater or soil on soil vapor** and to characterize the **vertical profile** of contamination, samples should be collected from clusters of soil vapor probes at varying depths in the vadose zone [Figure 2.2, Section 2.7.1] and preferably in conjunction with the collection of groundwater or soil samples.

Soil vapor samples collected at depths shallower than 5 feet below grade may be prone to negative bias due to infiltration of outdoor air. Therefore, samples from these depths should be collected only if appropriate (based on site-specific conditions), and sampling procedures and results should be reviewed accordingly. The depth of sampling near buildings with slab-on-grade foundations is dependent upon site-specific conditions (e.g., building surrounded by grassy or surface confining layer).

When collecting soil vapor samples around a building with no surrounding surface confining layer (e.g., pavement or sidewalk), samples should be located in native or undisturbed soils away from fill material surrounding the building (approximately 10 feet away from the building) to avoid sampling in an area that may be influenced by the building's operations. For example, operation of HVAC systems, fireplaces, or mechanical equipment (e.g., clothes dryers or exhaust fans/vents) in a building may exacerbate the infiltration of outdoor air into the vadose zone adjacent to the building. As a result, soil vapor samples collected in uncovered areas adjacent to the building may not be representative.

Investigations of soil vapor contamination should proceed outward from known or suspected subsurface sources, as appropriate, on an areal basis until the nature and extent of

subsurface vapor contamination has been characterized and human exposures have been addressed.

2.6.2 Sub-slab vapor

Existing environmental data (e.g., soil vapor, groundwater and soil data), site background information, and building construction details (e.g., basement, slab-on-grade, or multiple types of foundations, HVAC systems, etc.) should be considered when selecting buildings and locations within buildings for sub-slab vapor sampling.

At a minimum, these general guidelines should be followed when selecting buildings to sample for sub-slab vapors:

- a. buildings, including residential dwellings, located above or directly adjacent to known or suspected areas of subsurface volatile chemical contamination should be sampled;
- b. buildings in which screening with field equipment (e.g., PID, ppbRAE, Jerome Mercury Vapor Analyzer, etc.) suggests a completed migration pathway, such as when readings are above background and from unidentified sources or when readings show increasing gradients, should be sampled; and
- c. buildings within known or suspected areas of subsurface volatile chemical contamination that are used or occupied by sensitive population groups (e.g., daycare facilities, schools, nursing homes, etc.) should be given special consideration for sampling.

Investigations of sub-slab vapor and/or indoor air contamination should proceed outward from known or suspected sources, as appropriate, on an areal basis until the nature and extent of subsurface vapor contamination has been characterized and potential and current human exposures have been addressed. In cases of widespread vapor contamination and depending upon the basis for making decisions (e.g., a "blanket mitigation" approach within a specified area of documented vapor contamination [Section 3.3.1]), a representative number of buildings from an identified study area, rather than each building, may be sampled. Prior to implementation, this type of sampling approach should be approved by State agency personnel.

Within a building, sub-slab vapor samples should be collected

- a. in at least one central location away from foundation footings, and
- b. from the soil or aggregate immediately below the basement slab or slab-on-grade.

The number of sub-slab vapor samples that should be collected in a building depends upon the number of slabs (e.g., multiple slabs-on-grade in a large warehouse) and foundation types (e.g., combined basement and slab-on-grade in a residence). At least one sub-slab vapor sample should be collected from each representative area.

2.6.3 Indoor air

Existing environmental data (e.g., soil vapor, groundwater and soil data), site background information, and building construction details (e.g., basement, slab-on-grade, or multiple types of foundations; number and operation of HVAC systems; elevator shafts; tunnels or other confined-space entry points; etc.) should be considered when selecting buildings and

locations within buildings for indoor air sampling. Indoor air samples are typically collected concurrently with sub-slab vapor and outdoor air samples [Section 2.2.4].

At a minimum, these general guidelines should be followed when selecting buildings to sample for indoor air:

- a. where sub-slab vapor samples were collected without indoor air samples, buildings in which elevated concentrations of contaminants were measured in sub-slab vapor samples should be sampled;
- b. buildings, including residential dwellings, located above or directly adjacent to known or suspected subsurface sources of volatile chemicals or known soil vapor contamination should be sampled;
- c. buildings in which screening with field equipment (e.g., PID, ppbRAE, Jerome Mercury Vapor Analyzer, etc.) suggests a completed migration pathway, such as when readings are above background and from unidentified sources or when readings show increasing gradients, should be sampled; and
- d. buildings within known or suspected areas of subsurface volatile chemical contamination that are used or occupied by sensitive population groups (e.g., daycare facilities, schools, nursing homes, etc.) should be given special consideration for sampling.

To characterize contaminant concentration trends and potential exposures, indoor air samples should be collected

- a. from the crawl space area,
- b. from the basement (where vapor infiltration is suspected, such as near sump pumps or indoor wells, or in a central location) at a height approximately three feet above the floor to represent a height at which occupants normally are seated and/or sleep,
- c. from the lowest level living space (in centrally-located, high activity use areas) at a height approximately three feet above the floor to represent a height at which occupants normally are seated and/or sleep, and
- d. if in a commercial setting (e.g., a strip mall), from multiple tenant spaces at a height approximately three feet above the floor to represent a height at which occupants normally are seated.

These locations are illustrated in Figure 2.1.

Investigations of indoor air contamination should proceed outward from known or suspected subsurface sources, as appropriate, on an areal basis until potential and current human exposures associated with soil vapor intrusion have been addressed. In cases of widespread vapor contamination and depending upon the basis for making decisions (e.g., a "blanket mitigation" approach within a specified area of documented vapor contamination), a representative number of buildings from an identified study area, rather than each building, may be sampled. Prior to implementation, this type of sampling approach should be approved by State agency personnel.




Figure 2.1
Schematic of indoor and outdoor air sampling locations

2.6.4 Outdoor air

Typically, an outdoor air sample is collected outside of each building where an indoor air sample is collected. However, if several buildings are being sampled within a localized area, representative outdoor air samples may be appropriate. For example, one outdoor air sample may be sufficient for three houses being sampled in a cul-de-sac. Outdoor air samples should be collected from a representative upwind location, away from wind obstructions (e.g., trees or bushes), and at a height above the ground to represent breathing zones (3 to 5 feet) [Figure 2.1]. A representative sample is one that is not biased toward obvious sources of volatile chemicals (e.g., automobiles, lawn mowers, oil storage tanks, gasoline stations, industrial facilities, etc.). For buildings with HVAC systems that draw outdoor air into the building, an outdoor air sample collected near the outdoor air intake may be appropriate.

2.7 Sampling protocols

The procedures recommended here may be modified depending on site-specific conditions, the sampling objectives, or emerging technologies and methodologies. Alternative sampling procedures should be described thoroughly and proposed in a work plan submitted for review by the State. The State will review and comment on the proposed procedure and consider the efficacy of the alternative sampling procedure based on the objectives of investigation. In all cases, work plans should thoroughly describe the proposed sampling procedure. Similarly, the procedures that were implemented in the field should be documented and included in the final report of the sampling results.

2.7.1 Soil vapor

Soil vapor probe installations [Figure 2.2] may be permanent, semi-permanent or temporary. In general, permanent or semi-permanent installations are preferred for data consistency reasons and to ensure outdoor air infiltration does not occur. Temporary probes should only be used if measures are taken to ensure that an adequate surface seal is created to prevent outdoor air infiltration and if tracer gas is used at every sampling location. [See Section 2.7.5 for additional information about the use of tracer gas when collecting soil vapor samples.] Soil vapor implants or probes should be constructed in the same manner at all sampling locations to minimize possible discrepancies. The following procedures should be included in any permanent construction protocol:

- a. implants should be installed using an appropriate method based on site conditions (e.g., direct push, manually driven, auger — if necessary to attain the desired depth or if sidewall smearing is a concern, etc.);
- b. porous, inert backfill material (e.g., glass beads, washed #1 crushed stone, etc.) should be used to create a sampling zone 1 to 2 feet in length;
- c. implants should be fitted with inert tubing (e.g., polyethylene, stainless steel, nylon, Teflon[®], etc.) of the appropriate size (typically 1/8 inch to 1/4 inch diameter) and of laboratory or food grade quality to the surface;
- d. soil vapor probes should be sealed above the sampling zone with a bentonite slurry for a minimum distance of 3 feet to prevent outdoor air infiltration and the remainder of the borehole backfilled with clean material;
- e. for multiple probe depths, the borehole should be grouted with bentonite between probes to create discrete sampling zones or separate nested probes should be installed [Figure 2.2]; and
- f. steps should be taken to minimize infiltration of water or outdoor air and to prevent accidental damage (e.g., setting a protective casing around the top of the probe tubing and grouting in place to the top of bentonite, sloping the ground surface to direct water away from the borehole like a groundwater monitoring well, etc.).




Figure 2.2

Schematics of a generic permanent soil vapor probe and permanent nested soil vapor probes

[Note: Many variations exist and may be proposed in a work plan. Proposed installations should meet the sampling objectives and requirements of the analytical methods.]

To obtain representative samples and to minimize possible discrepancies, soil vapor samples should be collected in the following manner at all locations:

- a. at least 24 hours after the installation of permanent probes and shortly after the installation of temporary probes, one to three implant volumes (i.e., the volume of the sample probe and tube) should be purged prior to collecting the samples;
- b. flow rates for both purging and collecting should not exceed 0.2 liters per minute to minimize outdoor air infiltration during sampling;
- c. samples should be collected, using conventional sampling methods, in an appropriate container — one which
 - i. meets the objectives of the sampling (e.g., investigation of areas where low or high concentrations of volatile chemicals are expected; to minimize losses of volatile chemicals that are susceptible to photodegradation),
 - ii. is consistent with the sampling and analytical methods (e.g., low flow rate; Summa® canisters if analyzing by using EPA Method TO-15), and
 - iii. is certified clean by the laboratory;

- d. sample size depends upon the volume of that will achieve minimum reporting limits [Section 2.9]; and
- e. a tracer gas (e.g., helium, butane, sulfur hexafluoride, etc.) should be used when collecting soil vapor samples to verify that adequate sampling techniques are being implemented (i.e., to verify infiltration of outdoor air is not occurring) [Section 2.7.5].

In some cases, weather conditions may present certain limitations on soil vapor sampling. For example, condensation in the sample tubing may be encountered during winter sampling due to low outdoor air temperatures. Devices, such as tube warmers, may be used to address these conditions. Anticipated limitations to the sampling should be discussed prior to the sampling event so appropriate measures can be taken to address these difficulties and produce representative and reliable data.

When soil vapor samples are collected, the following actions should be taken to document local conditions during sampling that may influence interpretation of the results:

- a. if sampling near a commercial or industrial building, uses of volatile chemicals during normal operations of the facility should be identified;
- b. outdoor plot sketches should be drawn that include the site, area streets, neighboring commercial or industrial facilities (with estimated distance to the site), outdoor air sampling locations (if applicable), and compass orientation (north);
- c. weather conditions (e.g., precipitation and outdoor temperature) should be noted for the past 24 to 48 hours; and
- d. any pertinent observations should be recorded, such as odors and readings from field instrumentation.

Additional information that could be gathered to assist in the interpretation of the results includes barometric pressure, wind speed and wind direction.

The field sampling team should maintain a sample log sheet summarizing the following:

- a. sample identification,
- b. date and time of sample collection,
- c. sampling depth,
- d. identity of samplers,
- e. sampling methods and devices,
- f. purge volumes,
- g. volume of soil vapor extracted,
- h. if canisters used, the vacuum before and after samples were collected,
- i. apparent moisture content (dry, moist, saturated, etc.) of the sampling zone, and
- j. chain of custody protocols and records used to track samples from sampling point to analysis.

2.7.2 Sub-slab vapor

During colder months, heating systems should be operating to maintain normal indoor air temperatures (i.e., 65 – 75 °F) for at least 24 hours prior to and during the scheduled sampling time. Prior to installation of the sub-slab vapor probe, the building floor should be inspected and any penetrations (cracks, floor drains, utility perforations, sumps, etc.) should be noted and recorded. Probes should be installed at locations where the potential for ambient air infiltration via floor penetrations is minimal.

Sub-slab vapor probe installations [Figure 2.3] may be permanent, semi-permanent or temporary. A vacuum should not be used to remove drilling debris from the sampling port. Sub-slab implants or probes should be constructed in the same manner at all sampling locations to minimize possible discrepancies. The following procedures should be included in any construction protocol:

- permanent recessed probes should be constructed with brass or stainless steel tubing and fittings;
- temporary probes should be constructed with inert tubing (e.g., polyethylene, stainless steel, nylon, Teflon®, etc.) of the appropriate size (typically 1/8 inch to 1/4 inch diameter), and of laboratory or food grade quality;
- tubing should not extend further than 2 inches into the sub-slab material;
- porous, inert backfill material (e.g., glass beads, washed #1 crushed stone, etc.) should be added to cover about 1 inch of the probe tip for permanent installations; and
- the implant should be sealed to the surface with non-VOC-containing and non-shrinking products for temporary installations (e.g., permagum grout, melted beeswax, putty, etc.) or cement for permanent installations.




Figure 2.3

Schematic of a generic sub-slab vapor probe

[Note: Many variations exist and may be proposed in a work plan. Proposed installations should meet the sampling objectives and requirements of the analytical methods.]

To obtain representative samples that meet the data quality objectives, sub-slab vapor samples should be collected in the following manner:

- a. after installation of the probes, one to three volumes (i.e., the volume of the sample probe and tube) must be purged prior to collecting the samples to ensure samples collected are representative;
- b. flow rates for both purging and collecting must not exceed 0.2 liters per minute to minimize ambient air infiltration during sampling; and
- c. samples should be collected, using conventional sampling methods, in an appropriate container — one which
 - i. meets the objectives of the sampling (e.g., investigation of areas where low or high concentrations of volatile chemicals are expected; to minimize losses of volatile chemicals that are susceptible to photodegradation),
 - ii. is consistent with the sampling and analytical methods (e.g., low flow rate; Summa[®] canisters if analyzing by using EPA Method TO-15), and
 - iii. is certified clean by the laboratory;
- d. sample size depends upon the volume of that will achieve minimum reporting limits [Section 2.9], the flow rate, and the sampling duration; and
- e. ideally, samples should be collected over the same period of time as concurrent indoor and outdoor air samples.

When sub-slab vapor samples are collected, the following actions should be taken to document conditions during sampling and ultimately to aid in the interpretation of the sampling results [Section 3]:

- a. historic and current storage and uses of volatile chemicals should be identified, especially if sampling within a commercial or industrial building (e.g., use of volatile chemicals in commercial or industrial processes and/or during building maintenance);
- b. the use of heating or air conditioning systems during sampling should be noted;
- c. floor plan sketches should be drawn that include the floor layout with sampling locations, chemical storage areas, garages, doorways, stairways, location of basement sumps or subsurface drains and utility perforations through building foundations, HVAC system air supply and return registers, compass orientation (north), footings that create separate foundation sections, and any other pertinent information should be completed;
- d. outdoor plot sketches should be drawn that include the building site, area streets, outdoor air sampling locations (if applicable), compass orientation (north), and paved areas;
- e. weather conditions (e.g., precipitation and indoor and outdoor temperature) and ventilation conditions (e.g., heating system active and windows closed) should be reported; and
- f. any pertinent observations, such as spills, floor stains, smoke tube results, odors and readings from field instrumentation (e.g., vapors via PID, ppbRAE, Jerome Mercury Vapor Analyzer, etc.), should be recorded.

Additional documentation that could be gathered to assist in the interpretation of the results includes information about air flow patterns and pressure relationships obtained by using smoke tubes or other devices (especially between floor levels and between suspected

contaminant sources and other areas), the barometric pressure and photographs to accompany floor plan sketches.

The field sampling team should maintain a sample log sheet summarizing the following:

- a. sample identification,
- b. date and time of sample collection,
- c. sampling depth,
- d. identity of samplers,
- e. sampling methods and devices,
- f. soil vapor purge volumes,
- g. volume of soil vapor extracted,
- h. if canisters used, vacuum of canisters before and after samples collected,
- i. apparent moisture content (dry, moist, saturated, etc.) of the sampling zone, and
- j. chain of custody protocols and records used to track samples from sampling point to analysis.

2.7.3 Indoor air

[Reference: NYSDOH's *Indoor Air Sampling & Analysis Guidance (February 1, 2005)*]

During colder months, heating systems should be operating to maintain normal indoor air temperatures (i.e., 65 – 75 °F) for at least 24 hours prior to and during the scheduled sampling time. If possible, prior to collecting indoor samples, a pre-sampling inspection [Section 2.11.1] should be performed to evaluate the physical layout and conditions of the building being investigated, to identify conditions that may affect or interfere with the proposed sampling, and to prepare the building for sampling. This process is described in Section 2.11.1.

In general, indoor air samples should be collected in the following manner:

- a. sampling duration should reflect the exposure scenario being evaluated without compromising the detection limit or sample collection flow rate (e.g., an 8 hour sample from a workplace with a single shift versus a 24 hour sample from a workplace with multiple shifts). To ensure that air is representative of the locations sampled and to avoid undue influence from sampling personnel, samples should be collected for at least 1 hour. If the goal of the sampling is to represent average concentrations over longer periods, then longer duration sampling periods may be appropriate. Typically, 24 hour samples are collected from residential settings;
- b. personnel should avoid lingering in the immediate area of the sampling device while samples are being collected;
- c. sample flow rates must conform to the specifications in the sample collection method and, if possible, should be consistent with the flow rates for concurrent outdoor air and sub-slab samples; and
- d. samples must be collected, using conventional sampling methods, in an appropriate container — one which

- i. meets the objectives of the sampling (e.g., investigation of areas where low or high concentrations of volatile chemicals are expected; to minimize losses of volatile chemicals that are susceptible to photodegradation),
- ii. is consistent with the sampling and analytical methods (e.g., low flow rate; Summa[®] canisters if analyzing by using EPA Method TO-15), and
- iii. is certified clean by the laboratory.

At sites with tetrachloroethene contamination, passive air monitors that are specifically analyzed for tetrachloroethene (i.e., "perc badges") are commonly used to collect indoor and outdoor air samples. If site characterization activities indicate that degradation products of tetrachloroethene also represent a vapor intrusion concern, perc badges may be used to indicate the likelihood of vapor intrusion (i.e., by using tetrachloroethene as a surrogate) followed, as appropriate, by more comprehensive sampling and laboratory analyses to quantify both tetrachloroethene and its degradation products. Perc badge samples ideally should be collected over a twenty-four hour period, but for no less than eight hours.

The following actions should be taken to document conditions during indoor air sampling and ultimately to aid in the interpretation of the sampling results [Section 3]:

- a. historic and current uses and storage of volatile chemicals should be identified, especially if sampling within a commercial or industrial building (e.g., use of volatile chemicals in commercial or industrial processes and/or during building maintenance);
- b. a product inventory survey documenting sources of volatile chemicals present in the building during the indoor air sampling that could potentially influence the sample results should be completed [Section 2.11.2];
- c. the use of heating or air conditioning systems during sampling should be noted;
- d. floor plan sketches should be drawn that include the floor layout with sampling locations, chemical storage areas, garages, doorways, stairways, location of basement sumps or subsurface drains and utility perforations through building foundations, HVAC system supply and return registers, compass orientation (north), footings that create separate foundation sections, and any other pertinent information should be completed;
- e. outdoor plot sketches should be drawn that include the building site, area streets, outdoor air sampling locations (if applicable), compass orientation (north), and paved areas;
- f. weather conditions (e.g., precipitation and indoor and outdoor temperature) and ventilation conditions (e.g., heating system active and windows closed) should be reported; and
- g. any pertinent observations, such as spills, floor stains, smoke tube results, odors and readings from field instrumentation (e.g., vapors via PID, ppbRAE, Jerome Mercury Vapor Analyzer, etc.), should be recorded.

Additional documentation that could be gathered to assist in the interpretation of the results includes information about air flow patterns and pressure relationships obtained by using smoke tubes or other devices (especially between floor levels and between suspected contaminant sources and other areas), the barometric pressure and photographs to accompany floor plan sketches.

The field sampling team should maintain a sample log sheet summarizing the following:

- a. sample identification,
- b. date and time of sample collection,
- c. sampling height,
- d. identity of samplers,
- e. sampling methods and devices,
- f. depending upon the method, volume of air sampled,
- g. if canisters are used, vacuum of canisters before and after samples collected, and
- h. chain of custody protocols and records used to track samples from sampling point to analysis.

2.7.4 Outdoor air

Outdoor air samples should be collected simultaneously with indoor air samples to evaluate the potential influence, if any, of outdoor air on indoor air quality. They may also be collected simultaneously with soil vapor samples to identify potential outdoor air interferences associated with infiltration of outdoor air into the sampling apparatus while the soil vapor was collected. To obtain representative samples that meet the data quality objectives, outdoor air samples should be collected in a manner consistent with that for indoor air samples (described in Section 2.7.3).

The following actions should be taken to document conditions during outdoor air sampling and ultimately to aid in the interpretation of the sampling results [Section 3]:

- a. outdoor plot sketches should be drawn that include the building site, area streets, outdoor air sampling locations, the location of potential interferences (e.g., gasoline stations, factories, lawn movers, etc.), compass orientation (north), and paved areas;
- b. weather conditions (e.g., precipitation and outdoor temperature) should be reported; and
- c. any pertinent observations, such as odors, readings from field instrumentation, and significant activities in the vicinity (e.g., operation of heavy equipment or dry cleaners) should be recorded.

2.7.5 Tracer gas

When collecting soil vapor samples as part of a vapor intrusion evaluation, a tracer gas serves as a quality assurance/quality control measure to verify the integrity of the soil vapor probe seal. Without the use of a tracer, there is no way to verify that a soil vapor sample has not been diluted by outdoor air.

Depending on the nature of the contaminants of concern, a number of different compounds can be used as a tracer. Typically, sulfur hexafluoride (SF_6) or helium are used as tracers because they are readily available, have low toxicity, and can be monitored with portable measurement devices. Butane and propane (or other gases) could also be used as a tracer in some situations. Compounds other than those mentioned here may be appropriate, provided they meet project-specific data quality objectives. Where applicable, steps should

be taken to ensure that the gas used by the laboratory to clean the air sampling container is different from the gas used as a tracer during sampling (e.g., helium).

The protocol for using a tracer gas is straightforward: simply enrich the atmosphere in the immediate vicinity of the area where the probe intersects the ground surface with the tracer gas, and measure a vapor sample from the probe for the presence of high concentrations (> 10%) of the tracer. A cardboard box, a plastic pail, or even a garbage bag can serve to keep the tracer gas in contact with the probe during the testing. If there are concerns about infiltration of ambient air through other parts of the sampling train (such as around the fittings, not just at the probe/ground interface), then consideration should be given to ensuring that the tracer gas is in contact with the entire sampling apparatus. In these cases, field personnel may prefer to use a liquid tracer — soaking paper towels with a liquid tracer and placing the towels around the probe/ground interface, around fittings, and/or in the corner of a shroud.

There are two basic approaches to testing for the tracer gas:

1. include the tracer gas in the list of target analytes reported by the laboratory; or
2. use a portable monitoring device to analyze a sample of soil vapor for the tracer prior to and after sampling for the compounds of concern. (Note that the tracer gas samples can be collected via syringe, Tedlar[®] bag etc. They need not be collected in Summa[®] canisters or minicans.)

The advantage of the second approach is that the real time tracer sampling results can be used to confirm the integrity of the probe seals prior to formal sample collection.

Figure 2.4 depicts common methods for using tracer gas. In examples a, b and c, the tracer gas is released in the enclosure prior to initially purging the sample point. Care should be taken to avoid excessive purging prior to sample collection. Care should also be taken to prevent pressure build-up in the enclosure during introduction of the tracer gas. Inspection of the installed sample probe, specifically noting the integrity of the surface seal and the porosity of the soil in which the probe is installed, will help to determine the tracer gas setup. Figure 2.4a may be most effective at preventing tracer gas infiltration, however, it may not be appropriate in some situations depending on site-specific conditions. Figures 2.4b and 2.4c may be sufficient for probes installed in tight soils with well-constructed surface seals. Figure 2d provides an example of using a liquid tracer. In all cases, the same tracer gas application should be used for all probes at any given site.




Figure 2.4

Schematics of generic tracer gas applications when collecting soil vapor samples

Because minor leakage around the probe seal should not materially affect the usability of the soil vapor sampling results, the mere presence of the tracer gas in the sample should not be a cause for alarm. Consequently, portable field monitoring devices with detection limits in the low ppm range are more than adequate for screening samples for the tracer. If high concentrations (> 10%) of tracer gas are observed in a sample, the probe seal should be enhanced to reduce the infiltration of outdoor air.

Where permanent or semi-permanent sampling probes are used, tracer gas samples should be collected at each of the sampling probes during the initial stages of a soil vapor sampling program. If the results of the initial samples indicate that the probe seals are adequate, reducing the number of locations at which tracer gas samples are employed may be considered. At a minimum, tracer gas samples should be collected with at least 10% of the soil vapor samples collected in subsequent sampling rounds. When using permanent soil vapor probes as part of a long-term monitoring program, annual testing of the probe integrity is recommended. Where temporary probes are used, tracer gas should be used at every sampling location, every time.

Appendix B

Indoor air quality questionnaire and building inventory

As discussed in Section 2.11, products in buildings should be inventoried every time indoor air is sampled to provide an accurate assessment of the potential contribution of volatile chemicals. In addition, the type of structure, floor layout and physical conditions of the building being studied should be noted to identify (and minimize) conditions that may interfere with the proposed testing.

Toward this end, a blank copy of the NYSDOH Center for Environmental Health's Indoor Air Quality Questionnaire and Building Inventory is provided in this appendix. Also provided is an example that demonstrates how the form should be completed properly.

This page is intentionally blank.

**NEW YORK STATE DEPARTMENT OF HEALTH
INDOOR AIR QUALITY QUESTIONNAIRE AND BUILDING INVENTORY
CENTER FOR ENVIRONMENTAL HEALTH**

This form must be completed for each residence involved in indoor air testing.

Preparer's Name _____ Date/Time Prepared _____

Preparer's Affiliation _____ Phone No. _____

Purpose of Investigation _____

1. OCCUPANT:

Interviewed: Y / N

Last Name: _____ First Name: _____

Address: _____

County: _____

Home Phone: _____ Office Phone: _____

Number of Occupants/persons at this location _____ Age of Occupants _____

2. OWNER OR LANDLORD: (Check if same as occupant ___)

Interviewed: Y / N

Last Name: _____ First Name: _____

Address: _____

County: _____

Home Phone: _____ Office Phone: _____

3. BUILDING CHARACTERISTICS

Type of Building: (Circle appropriate response)

- | | | |
|-------------|--------|----------------------|
| Residential | School | Commercial/Multi-use |
| Industrial | Church | Other: _____ |

If the property is residential, type? (Circle appropriate response)

- | | | |
|--------------|-----------------|-------------------|
| Ranch | 2-Family | 3-Family |
| Raised Ranch | Split Level | Colonial |
| Cape Cod | Contemporary | Mobile Home |
| Duplex | Apartment House | Townhouses/Condos |
| Modular | Log Home | Other: _____ |

If multiple units, how many? _____

If the property is commercial, type?

Business Type(s) _____

Does it include residences (i.e., multi-use)? Y / N If yes, how many? _____

Other characteristics:

Number of floors _____ Building age _____

Is the building insulated? Y / N How air tight? Tight / Average / Not Tight

4. AIRFLOW

Use air current tubes or tracer smoke to evaluate airflow patterns and qualitatively describe:

Airflow between floors

Airflow near source

Outdoor air infiltration

Infiltration into air ducts

5. BASEMENT AND CONSTRUCTION CHARACTERISTICS (Circle all that apply)

- a. Above grade construction: wood frame concrete stone brick
- b. Basement type: full crawlspace slab other _____
- c. Basement floor: concrete dirt stone other _____
- d. Basement floor: uncovered covered covered with _____
- e. Concrete floor: unsealed sealed sealed with _____
- f. Foundation walls: poured block stone other _____
- g. Foundation walls: unsealed sealed sealed with _____
- h. The basement is: wet damp dry moldy
- i. The basement is: finished unfinished partially finished
- j. Sump present? Y / N
- k. Water in sump? Y / N / not applicable

Basement/Lowest level depth below grade: _____(feet)

Identify potential soil vapor entry points and approximate size (e.g., cracks, utility ports, drains)

6. HEATING, VENTING and AIR CONDITIONING (Circle all that apply)

Type of heating system(s) used in this building: (circle all that apply – note primary)

- Hot air circulation
- Space Heaters
- Electric baseboard
- Heat pump
- Stream radiation
- Wood stove
- Hot water baseboard
- Radiant floor
- Outdoor wood boiler
- Other _____

The primary type of fuel used is:

- Natural Gas
- Electric
- Wood
- Fuel Oil
- Propane
- Coal
- Kerosene
- Solar

Domestic hot water tank fueled by: _____

Boiler/furnace located in: Basement Outdoors Main Floor Other _____

Air conditioning: Central Air Window units Open Windows None

Are there air distribution ducts present? Y / N

Describe the supply and cold air return ductwork, and its condition where visible, including whether there is a cold air return and the tightness of duct joints. Indicate the locations on the floor plan diagram.

7. OCCUPANCY

Is basement/lowest level occupied? Full-time Occasionally Seldom Almost Never

Level General Use of Each Floor (e.g., familyroom, bedroom, laundry, workshop, storage)

Basement	_____
1 st Floor	_____
2 nd Floor	_____
3 rd Floor	_____
4 th Floor	_____

8. FACTORS THAT MAY INFLUENCE INDOOR AIR QUALITY

- a. Is there an attached garage? Y / N
- b. Does the garage have a separate heating unit? Y / N / NA
- c. Are petroleum-powered machines or vehicles stored in the garage (e.g., lawnmower, atv, car) Y / N / NA
Please specify _____
- d. Has the building ever had a fire? Y / N When? _____
- e. Is a kerosene or unvented gas space heater present? Y / N Where? _____
- f. Is there a workshop or hobby/craft area? Y / N Where & Type? _____
- g. Is there smoking in the building? Y / N How frequently? _____
- h. Have cleaning products been used recently? Y / N When & Type? _____
- i. Have cosmetic products been used recently? Y / N When & Type? _____

- j. Has painting/staining been done in the last 6 months? Y / N Where & When? _____
- k. Is there new carpet, drapes or other textiles? Y / N Where & When? _____
- l. Have air fresheners been used recently? Y / N When & Type? _____
- m. Is there a kitchen exhaust fan? Y / N If yes, where vented? _____
- n. Is there a bathroom exhaust fan? Y / N If yes, where vented? _____
- o. Is there a clothes dryer? Y / N If yes, is it vented outside? Y / N
- p. Has there been a pesticide application? Y / N When & Type? _____

Are there odors in the building? Y / N
 If yes, please describe: _____

Do any of the building occupants use solvents at work? Y / N
 (e.g., chemical manufacturing or laboratory, auto mechanic or auto body shop, painting, fuel oil delivery, boiler mechanic, pesticide application, cosmetologist)

If yes, what types of solvents are used? _____

If yes, are their clothes washed at work? Y / N

Do any of the building occupants regularly use or work at a dry-cleaning service? (Circle appropriate response)

- Yes, use dry-cleaning regularly (weekly) No
- Yes, use dry-cleaning infrequently (monthly or less) Unknown
- Yes, work at a dry-cleaning service

Is there a radon mitigation system for the building/structure? Y / N Date of Installation: _____
Is the system active or passive? Active/Passive

9. WATER AND SEWAGE

Water Supply: Public Water Drilled Well Driven Well Dug Well Other: _____

Sewage Disposal: Public Sewer Septic Tank Leach Field Dry Well Other: _____

10. RELOCATION INFORMATION (for oil spill residential emergency)

a. Provide reasons why relocation is recommended: _____

b. Residents choose to: remain in home relocate to friends/family relocate to hotel/motel


c. Responsibility for costs associated with reimbursement explained? Y / N

d. Relocation package provided and explained to residents? Y / N


11. FLOOR PLANS

Draw a plan view sketch of the basement and first floor of the building. Indicate air sampling locations, possible indoor air pollution sources and PID meter readings. If the building does not have a basement, please note.

Basement:




First Floor:



12. OUTDOOR PLOT

Draw a sketch of the area surrounding the building being sampled. If applicable, provide information on spill locations, potential air contamination sources (industries, gas stations, repair shops, landfills, etc.), outdoor air sampling location(s) and PID meter readings.

Also indicate compass direction, wind direction and speed during sampling, the locations of the well and septic system, if applicable, and a qualifying statement to help locate the site on a topographic map.



13. PRODUCT INVENTORY FORM

Make & Model of field instrument used: _____

List specific products found in the residence that have the potential to affect indoor air quality.

Location	Product Description	Size (units)	Condition *	Chemical Ingredients	Field Instrument Reading (units)	Photo ** <u>Y/N</u>

* Describe the condition of the product containers as **Unopened (UO)**, **Used (U)**, or **Deteriorated (D)**

** Photographs of the **front and back** of product containers can replace the handwritten list of chemical ingredients. However, the photographs must be of good quality and ingredient labels must be legible.

Example

1

Correct

**NEW YORK STATE DEPARTMENT OF HEALTH
INDOOR AIR QUALITY QUESTIONNAIRE AND BUILDING INVENTORY
CENTER FOR ENVIRONMENTAL HEALTH**

This form must be completed for each residence involved in indoor air testing.

Preparer's Name Mary Jones Date/Time Prepared 10/22/04 10:00am

Preparer's Affiliation XYZ Consulting Phone No. 518-555-1212

Purpose of Investigation Thomasville Soil Vapor Intrusion Investigation (Site#32141)

1. OCCUPANT:

Interviewed: Y / N

Last Name: Smith First Name: Carol

Address: 25 Main Street Thomasville, New York 25230

County: Albany

Home Phone: 518-556-2222 Office Phone: 518-556-2400

Number of Occupants/persons at this location 2 Age of Occupants 36, 10

2. OWNER OR LANDLORD: (Check if same as occupant)

Interviewed: Y N

Last Name: White First Name: Frank

Address: 64 Mountain Road Bainbridge, New York 26390

County: Dutchess

Home Phone: 845-876-1301 Office Phone: 845-227-2430

3. BUILDING CHARACTERISTICS

Type of Building: (Circle appropriate response)

Residential
 Industrial

School
 Church

Commercial/Multi-Use
Other: _____

Example Correct 2

If the property is residential, type? (Circle appropriate response)

<u>Ranch</u>	2-Family	3-Family
Raised Ranch	Split Level	Colonial
Cape Cod	Contemporary	Mobile Home
Duplex	Apartment House	Townhouses/Condos
Modular	Log Home	Other: _____

If multiple units, how many? NA

If the property is commercial, type?

Business Type(s) NA

Does it include residences (i.e. multi-use)? Y / N If yes, how many? _____

Other characteristics:

Number of floors 1

Building age 20 years

Is the building insulated? (Y) N

How air tight? (Tight) Average / Not Tight

4. AIRFLOW

Use air current tubes or tracer smoke to evaluate airflow patterns and qualitatively describe:

Airflow between floors

Basement air flows up to 1st floor through plumbing waste line and domestic water line floor penetrations

Airflow near source

Yes, furnace/oil tank area open to rest of basement

Outdoor air infiltration

Outdoor air enters at loose bilco doorway openings, and at sill plate near furnace.

Infiltration into air ducts

Basement air flows into bottom of hot air unit and in loose cold air return joints.

Example Correct 3

5. BASEMENT AND CONSTRUCTION CHARACTERISTICS (Circle all that apply)

- a. Above grade construction: wood frame concrete stone brick
- b. Basement type: full crawlspace slab other _____
- c. Basement floor: concrete dirt stone other _____
- d. Basement floor: uncovered covered covered with _____
- e. Concrete floor: unsealed sealed sealed with _____
- f. Foundation walls: poured block stone other _____
- g. Foundation walls: unsealed sealed sealed with _____
- h. The basement is: wet damp dry moldy
- i. The basement is: finished unfinished partially finished
- j. Sump present? Y N
- k. Water in sump? Y / N not applicable

Basement/Lowest level depth below grade: 6 (feet)

Identify potential soil vapor entry points and approximate size (e.g., cracks, utility ports, drains)

Floor drain in laundry area

6. HEATING, VENTING and AIR CONDITIONING (Circle all that apply)

Type of heating system(s) used in this building: (circle all that apply – note primary)

- Hot air circulation Heat pump Hot water baseboard
- Space Heaters Stream radiation Radiant floor
- Electric baseboard Wood stove Outdoor wood boiler Other _____

The primary type of fuel used is:

- Natural Gas Fuel Oil Kerosene
- Electric Propane Solar
- Wood Coal

Domestic hot water tank fueled by: gas

- Boiler/furnace located in: Basement Outdoors Main Floor Other _____
- Air Conditioning: Central Air Window units Open Windows None

Example Correct 4

Are there air distribution ducts present? Y N

Describe the supply and cold air return ductwork, and its condition where visible, including whether there is a cold air return and the tightness of duct joints. Indicate the locations on the floor plan diagram.

Cold air return ductwork on ceiling in basement. Cold air return joints appear loose.

7. OCCUPANCY

Basement / Is lowest level occupied? Full time Occasionally Seldom Almost Never

Level General Use of Each Floor (e.g., familyroom, bedroom, laundry, workshop, storage)

Basement	Storage and laundry
1 st Floor	living area and bedrooms
2 nd Floor	
3 rd Floor	
4 th Floor	

8. FACTORS THAT MAY INFLUENCE INDOOR AIR QUALITY

- a. Is there an attached garage? Y N
- b. Does the garage have a separate heating unit? Y N / NA
- c. Are petroleum-powered machines or vehicles stored in the garage (e.g., lawnmower, atv, car etc.) Y / N / NA
Please specify lawnmower, car
- d. Has the building ever had a fire? Y N When? _____
- e. Is a kerosene or unvented gas space heater present? Y N Where? _____
- f. Is there a workshop or hobby/craft area? Y N Where & Type? _____
- g. Is there smoking in the building? Y N How frequently? _____
- h. Have cleaning products been used recently? Y / N When & Type? w/in week - windex, tilex
- i. Have cosmetic products been used recently? Y / N When & Type? yesterday - hairspray

Example Correct

5

j. Has painting/staining been done in the last 6 months? Y / N Where & When? _____

k. Is there new carpet, drapes or other textiles? Y / N Where & When? carpet in dining room

l. Have air fresheners been used recently? Y / N When & Type? _____

m. Is there a kitchen exhaust fan? Y / N If yes, where vented? outside

n. Is there a bathroom exhaust fan? Y / N If yes, where vented? _____

o. Is there a clothes dryer? Y / N If yes, is it vented outside? Y / N

p. Has there been a pesticide application? Y / N When & Type? _____

Are there odors in the building? Y / N

If yes, please describe: _____

Do any of the building occupants use solvents at work? Y / N

(e.g., chemical manufacturing or laboratory, automechanic or autobody shop, painting, fuel oil delivery, boiler mechanic, pesticide application, cosmetologist etc.)

If yes, what types of solvents are used? hair salon dyes, alcohols, peroxides, acetone

If yes, are their clothes washed at work? Y / N

Do any of the building occupants regularly use or work at a dry-cleaning service? (Circle appropriate response)

Yes, use dry-cleaning regularly (weekly)

Yes, use dry-cleaning infrequently (monthly or less)

Yes, work at a dry-cleaning service

No

Unknown

Is there a radon mitigation system for the building/structure? Y / N Date of Installation: June 2000

Is the system active or passive? Active / Passive

9. WATER AND SEWAGE

Water Supply: Public Water Drilled Well Driven Well Dug Well Other: _____

Sewage Disposal: Public Sewer Septic Tank Leach Field Dry Well Other: _____

10. RELOCATION INFORMATION (for oil spill residential emergency)

a. Provide reasons why relocation is recommended: not applicable

b. Residents choose to: remain in home relocate to friends/family relocate to hotel/motel

c. Responsibility for costs associated with reimbursement explained? Y / N


d. Relocation package provided and explained to residents? Y / N

Example Correct


11. FLOOR PLANS

Draw a plan view sketch of the basement and first floor of the building. Indicate air sampling locations, possible indoor air pollution sources and PID meter readings. If the building does not have a basement, please note.

Basement:



First Floor:




Example Correct 7

12. OUTDOOR PLOT

Draw a sketch of the area surrounding the building being sampled. If applicable, provide information on spill locations, potential air contamination sources (industries, gas stations, repair shops, landfills, etc.), outdoor air sampling location(s) and PID meter readings.

Also indicate compass direction, wind direction and speed during sampling, the locations of the well and septic system, if applicable, and a qualifying statement to help locate the site on a topographic map.



↑ N
Wind direction = NE

Example Correct

13. PRODUCT INVENTORY FORM

Make & Model of field instrument used: RAE photoionization detector

List specific products found in the residence that have the potential to affect indoor air quality.


Location	Product Description	Size (oz.)	Condition*	Chemical Ingredients	Field Instrument Reading	Photo** Y/N
Kitchen	WD-40	12oz	UO	See photo	10 ppb	Y
garage	mineral spirits	24oz	U	benzene, toluene	15 ppb	N
garage	American Semi-Gloss latex paint	64oz	U	titanium dioxide, ethylene glycol, aluminum hydroxide, 2,2,4-trimethyl 1,3-pentanediol isobutyrate, Vinyl acetate	2 ppb	N
garage	Krylon semi-gloss oil paint	64oz	D	butane, propane, titanium dioxide, xylene, ethylbenzene, acetone, MEK, butanol, MJK	10 ppb	N
garage	Rustoleum	12oz	U	talc, calcium carbonate, titanium dioxide, xylene, ethylbenzene, acetone, liquified petroleum gases, pentaerythritol	4 ppb	N
garage	Deep 6 Double Strength Insect Repellent	8oz	D	propane, isobutane, N,N-Diethyl-meta-toluamide Di-n-propyl isocinchomerate	0.5 ppb	N
base-ment	12 cans latex paint	128oz	U	talc, titanium dioxide, Kaolin clay, 2,2,4-trimethyl-1,3-pentanediol isobutyrate, vinyl acetate	0	N

* Describe the condition of the product containers as **Unopened (UO)**, **Used (U)**, or **Deteriorated (D)**

** Photographs of the **front and back** of product containers can replace the handwritten list of chemical ingredients. However, the photographs must be of good quality and ingredient labels must be legible.

Product Inventory Attachment — 25 Main Street, City

WD-40 FRONT



WD-40 INGREDIENTS

HARMFUL OR FATAL IF SWALLOWED:
Contains petroleum distillates. If swallowed, **DO NOT** induce vomiting. Call physician immediately. Use in a well-ventilated area.
DELIBERATE OR DIRECT INHALATION OF VAPOR OR SPRAY MIST MAY BE HARMFUL OR FATAL.

This page is intentionally blank.

APPENDIX B

QUALITY ASSURANCE PROJECT PLAN

**QUALITY ASSURANCE PROJECT PLAN
SHERIDAN WASTE OIL COMPANY SITE**

**NEW YORK STATE DEPARTMENT OF ENVIRONMENTAL
CONSERVATION**

This Quality Assurance Project Plan (QAPjP) identifies sections of the QAPP (ABB ES, 1994) that apply to the activities described in the site WP, describes variances to those procedures, and specifies the analytical methods used for laboratory analysis of environmental samples.

1.0 GENERAL PROCEDURES AND PRACTICES

The general procedures used to conduct the Site Characterization at the Active Industrial Uniform Site Industrial Uniform site will be taken from the following sections of the QAPP:

Section 2.0	Program Organization and Responsibilities
Section 8.3	Data Reporting
Section 9.0	Internal Quality Control
Section 11.0	Preventive Maintenance
Section 12.0	Data Assessment
Section 13.0	Corrective Action
Section 14.0	Reports to Management

2.0 FIELD PROCEDURES AND SAMPLING

The following field investigation techniques and procedures set forth in the QAPP will be used at the site:

QA/QC Procedures	Section 3.0
Sample Container Requirements and Sample Preservation	Subsection 4.2
Decontamination	Subsection 4.3
Sample Handling	Subsections 4.3 and 5.0
General Water Sampling Methodology	Subsection 4.6.1

Field Instrument Calibration

Section 6.0

The following variances to the above procedures are described below.

2.1 SAMPLING AND ANALYSIS PROGRAM

Data Quality Objectives (DQOs) for Site sampling activities are summarized in Table B-1. DQOs are described in accordance with USEPA guidelines (USEPA, 1987) and the NYSDEC Analytical Services Protocols (ASP) (NYSDEC, 2000).

Analytical data requirements were established using the methods described in the ASP. Analytical methods to be used for laboratory analysis are presented in Table B-2. Laboratory quantitation limits and associated QC limits for methods 8260, 8270, 6010/7470, and TO-15, as appropriate, are provided in Attachment 1. Analytical Level B deliverables as described in the ASP will be provided by the laboratory. Data Usability Summary Report (DUSR) will be issued based on DEC guidelines (NYSDEC, 1997).

2.2 SAMPLING IDENTIFICATION

Sample identification will deviate from Subsection 4.1 of the QAPP per sample identification procedures provided in the WA (see pages 3 and 5, Appendix A).

Soil vapor and air samples will be identified as follows:

SOSSM01-date (sub-slab vapor sample from structure M01)

SOBAM01-date (basement air sample from structure M01)

SOFAM01-date (first floor air sample from structure M01)

SOAA001 (Ambient outdoor air sample 001)

SOSVM01-depth (soil vapor sample from location M01)

REFERENCE

ABB Environmental Services, 1994. Program Quality Assurance Program Plan. Prepared for the New York State Department of Environmental Conservation, Albany, New York. June 1994.

New York State Department of Environmental Conservation (NYSDEC), 2000. “Analytical Services Protocols”; 6/00 Edition; June 2000.

U.S. Environmental Protection Agency (USEPA), 1987. “Data Quality Objectives for Remedial Response Activities”; Office of Emergency and Remedial Response and Office of Waste Programs Enforcement; Washington DC; EPA/540/G-87/003; March 1987.

**Table B-1:
 Analytical DQO Levels**

Parameter	Use	Data Quality Level
PH Temperature Specific Conductance Turbidity	Provides physical and chemical data on groundwater samples for use during sampling collection.	Level I
PID screening	Provides qualitative real-time information on air quality in the breathing zone for health and safety decisions, and to identify potentially contaminated groundwater, soil, and soil gas.	Level I
TCL VOCs	Provides analytical information to compare to standards and guidance values.	Level III

**Table B-2:
 Summary of Analytical Methods**

Media	Parameter	Method	Container	Preservative	Holding Time
Groundwater from monitoring well	TCL VOCS	EPA Method 8260	2 (40 ml vial) Teflon-lined septa	Cool, 4 degrees Celsius	7 days
Soil vapor/Indoor Air/Outdoor Air	TCL VOCS	USEPA Method TO-15	6 L Summa® Canister	None	14d

Notes:

TCL = target compound list

VOCs = volatile organic compounds

ATTACHMENT 1

TO-15 RLS and MDLS

05/16/06

CON-Test
 ANALYTICAL LABORATORY
 39 SPRUCE ST
 E. LONGMEADOW, MA 01028

TO-14 / TO-15 5/16/2006	Low* RL	Low* RL	Low* MDL	Low* MDL														
heptane	0.1	0.4	0.03	0.14														
mibk	0.1	0.4	0.05	0.22														
1,3-dichloropropene (cis)	0.1	0.5	0.04	0.19														
1,3-dichloropropene (trans)	0.1	0.5	0.06	0.27														
1,1,2-trichloroethane	0.1	0.5	0.07	0.35														
toluene	0.1	0.4	0.03	0.12														
2-hexanone	0.1	0.4	0.03	0.11														
dibromochloromethane	0.1	0.9	0.03	0.29														
1,2-dibromoethane	0.1	0.8	0.03	0.20														
tetrachloroethene	0.1	0.7	0.07	0.47														
chlorobenzene	0.1	0.5	0.03	0.14														
ethylbenzene	0.1	0.4	0.03	0.11														
m/p xylene	0.1	0.4	0.06	0.26														
bromoform	0.1	0.7	0.04	0.31														
styrene	0.1	0.4	0.03	0.11														
o-xylene	0.1	0.4	0.03	0.11														
1,1,2,2-tetrachloroethane	0.1	0.7	0.03	0.23														
4-ethyltoluene	0.1	0.5	0.03	0.13														
1,3,5-trimethylbenzene	0.1	0.5	0.03	0.13														
1,2,4-trimethylbenzene	0.1	0.5	0.03	0.13														
1,3-dichlorobenzene	0.1	0.6	0.03	0.20														
benzyl chloride	0.1	0.5	0.02	0.09														
1,4-dichlorobenzene	0.1	0.6	0.03	0.17														
1,2-dichlorobenzene	0.1	0.6	0.05	0.28														
1,2,4-trichlorobenzene	0.1	0.7	0.04	0.30														
hexachlorobutadiene	0.1	1.1	0.01	0.15														
Upon request:																		
Napthalene																		
Cumene																		
1,4 Dioxane																		
Acrylonitrile																		
Methyl Acetate																		
2,2,4 Trimethylpentane																		
Methylcyclohexane																		
1,1,2 Tetrachloroethane																		
Propylbenzene																		

TO-15 RLS and MDLs

05/16/06

Analyte	PPBv	UG/M3	PPBv	UG/M3															
TO-14 / TO-15	Low*	Low*	Low*	Low*															
5/16/2006	RL	RL	MDL	MDL															
propene	0.1	0.2	0.04	0.07															
dichlorodifluoromethane	0.1	0.5	0.07	0.36															
chloromethane	0.1	0.2	0.05	0.10															
freon 114	0.1	0.7	0.06	0.42															
vinyl chloride	0.1	0.3	0.04	0.11															
1,3-butadienen	0.1	0.2	0.09	0.19															
bromomethane	0.1	0.4	0.03	0.10															
chloroethane	0.2	0.5	0.11	0.28															
acetone	0.1	0.2	0.09	0.20															
trichlorofluoromethane	0.1	0.6	0.04	0.21															
ethanol	0.2	0.4	0.15	0.29															
1,1-dichloroethene	0.1	0.4	0.05	0.20															
methylene chloride	0.1	0.3	0.06	0.21															
freon 113	0.1	0.8	0.04	0.32															
carbon disulfide	0.1	0.3	0.03	0.08															
trans-1,2-dichloroethene	0.1	0.4	0.05	0.21															
1,1-dichloroethane	0.1	0.4	0.08	0.33															
mtbe	0.1	0.4	0.07	0.23															
ipa	0.1	0.2	0.04	0.09															
2-butanone	0.1	0.3	0.05	0.14															
cis-1,2-dichloroethene	0.1	0.4	0.03	0.12															
vinyl acetate	0.1	0.4	0.05	0.17															
hexane	0.1	0.4	0.06	0.23															
ethyl acetate	0.2	0.7	0.12	0.44															
chloroform	0.1	0.5	0.03	0.17															
tetrahydrofuran	0.2	0.6	0.13	0.39															
1,2-dichloroethane	0.1	0.4	0.04	0.17															
1,1,1-trichloroethane	0.1	0.5	0.03	0.14															
benzene	0.1	0.3	0.04	0.13															
carbon tetrachloride	0.1	0.6	0.04	0.23															
cyclohexane	0.1	0.3	0.04	0.15															
1,2-dichloropropane	0.1	0.5	0.04	0.19															
bromodichloromethane	0.1	0.7	0.03	0.21															
trichloroethene	0.1	0.5	0.04	0.19															
Analyte	PPBv	UG/M3	PPBv	UG/M3															

TO-15 RLs and MDLs

05/16/06

Tert-Butylbenzene																			
Sec-Butylbenzene																			
P-Cymene																			
Indane																			
Butylbenzene																			
1,2-Dibromo-3-Chloropropane																			
Hexylcyclohexane																			
2- Methyl-naphthalene																			
1- Methyl-naphthalene																			
* A .25ug/m3 is achievable by TO 15 low curve, and/ or by SIM																			
Low reporting limits are subject to sample matrix problems. Matrix interference's may cause limits to be elevated.																			
Trace reporting limits are subject to sample matrix problems. Matrix interference's may cause limits to be elevated.																			
Reporting Limit, lowest point in the calibration curve. Please note that the lowest point in the Low and Trace RL's																			

* Note: Per phone conversation with Con-Test 6/8/2007
 between Amanda Zeidler (MALTEC) and Tim Kelley
 note on field COC "0.25 ug/m³ RL required for TCE, PCE"

APPENDIX C

HEALTH AND SAFETY PLAN

MACTEC Engineering and Consulting, PC.
HEALTH AND SAFETY PLAN

The purpose of this HASP is to protect the health and safety of on-site personnel and the surrounding community during the SVIE activities at the Site. This HASP is based on the MACTEC Program HASP (MACTEC, 2005) and consists of a site-specific HASP Addendum to document aspects of the Site.

Prior to initiation of field activities, MACTEC will notify the local fire, police, and potential emergency responders, as deemed necessary, to advise them of the investigation activities that will take place and the schedule of these activities. The Site tenants will also be notified.

In the event of an emergency or corresponding evacuation procedure, evacuation procedures documented in the HASP Addendum will be followed and the emergency contacts notified.

Attachment:

Prepared by: Michael Washburn
 *Approved by: Kendra Bavor *Kendra Bavor*
 Sites: Manfred F. J. Schulte
 Street Address: 405 Jericho Turnpike, New Hyde Park, New York
 Active Industrial Uniform
 Street Address: 63 West Merrick Road, Lindenhurst, NY
 Eugene's Dry Cleaners
 Street Address: 54 East Main Street, Babylon, NY
 Sheridan Waste Oil Company
 Street Address: 114 Peconic Avenue, Medford, NY

Date: 4-25-2007
 Date: 6-18-2007
 Job Number: 3612072084
 Job Number: 3612072086
 Job Number: 3612072087
 Job Number: 3612072085

Proposed Date(s) of Investigation: Fall 2007

Site Description: Four inactive hazardous waste sites with similar contaminants of concern consisting principally of chlorinated solvents.
 (attach map)

Proposed Activity(s):	Manfred F. J. Schulte	Geoprobe drilling with groundwater and soil vapor samples and hand collected indoor air samples and sub-slab soil vapor samples (see Work Plan for details)
	Active Industrial Uniform	
	Eugene's Dry Cleaners	
	Sheridan Waste Oil Company	Soil vapor samples and hand collected indoor air samples and sub-slab soil vapor samples (see Work Plan for details)

*Approval also serves as certification of a Hazard Assessment as required by 29 CFR 1910.132

Known or Suspected Contaminants (include PELs/TLVs):

Contaminants of Concern	PEL/TLV
Groundwater/soil/air: PCE	25 ppm
TCE	10 ppm
TCA	350 ppm
1,1 DCA	100 ppm
1, 2 DCE	200 ppm
Groundwater: PCE	25 ppm
Vinyl Chloride	1 ppm
1, 2 DCE	200 ppm

JHAs: Check and attach all that apply:

Activity Specific JHAs:

<input checked="" type="checkbox"/>	Mobilization/Demobilization and Site Preparation
<input checked="" type="checkbox"/>	Field Work - General
<input checked="" type="checkbox"/>	Groundwater Sampling
<input type="checkbox"/>	Drilling Operation (MACTEC Driller)
<input checked="" type="checkbox"/>	Soil Sampling
<input checked="" type="checkbox"/>	Geoprobe (MACTEC Geoprobe Operator)
<input type="checkbox"/>	Excavations and Backfilling
<input checked="" type="checkbox"/>	Decontamination
<input type="checkbox"/>	Stream/Wetlands Work
<input type="checkbox"/>	Clearing Brush and Trees
<input type="checkbox"/>	Chain Saw
<input type="checkbox"/>	

Hazard Specific JHAs:

<input type="checkbox"/>	Insect Stings and Bites
<input type="checkbox"/>	Gasoline
<input checked="" type="checkbox"/>	Working with Preservatives (Acids)
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	
<input type="checkbox"/>	

Chemicals Brought to the Site:

List all chemicals brought to the site (e.g., preservatives, decontamination solutions, gasoline, etc.). Attach MSDS

Chemicals	MSDS Attached?
HELIUM GAS (RENTAL CYLINDER)	<input checked="" type="checkbox"/>
HCl (Preservative in glass vials)	<input checked="" type="checkbox"/>
AUTO CAL SOLUTION	<input checked="" type="checkbox"/>
ISOBUTYLENE - PID SPAN GAS	<input checked="" type="checkbox"/>

Chemicals will be kept in their original containers. If transferred to another container, aside from days use by one individual, the new container will be labeled with the name of the chemical and the hazard warnings.

HAZARD IDENTIFICATION SUMMARY

Complete the checklist for summarizing the hazards identified in the JHAs

Standard Hazards			
<input type="checkbox"/> Falling Objects	<input checked="" type="checkbox"/> Slips and trips	<input checked="" type="checkbox"/> Pinch points	<input type="checkbox"/> Rotating equipment
<input checked="" type="checkbox"/> Falls	<input checked="" type="checkbox"/> Power equipment/tools	<input type="checkbox"/> Elevated work surfaces	<input type="checkbox"/> _____
Eye Hazards			
<input checked="" type="checkbox"/> Particulates	<input type="checkbox"/> Liquid splashes	<input type="checkbox"/> Welding Arc	<input type="checkbox"/> Concrete drilling
Hearing Hazards			
<input type="checkbox"/> None	<input checked="" type="checkbox"/> Impact noise	<input type="checkbox"/> High frequency noise	<input checked="" type="checkbox"/> High ambient noise
Respiratory Hazards			
<input type="checkbox"/> None	<input type="checkbox"/> Dust / aerosols / particulates	<input checked="" type="checkbox"/> Organic Vapors	<input type="checkbox"/> Acid Gases
<input type="checkbox"/> Oxygen deficient	<input type="checkbox"/> Metals	<input type="checkbox"/> Asbestos	<input type="checkbox"/> _____
Chemical Hazards			
<input type="checkbox"/> None	<input type="checkbox"/> Organic solvents	<input type="checkbox"/> Reactive metals	<input type="checkbox"/> PCBs
<input checked="" type="checkbox"/> Acids / bases	<input type="checkbox"/> Oxidizers	<input type="checkbox"/> Volatiles/Semi-volatiles	<input type="checkbox"/> _____
Environmental Hazards			
<input checked="" type="checkbox"/> None	<input type="checkbox"/> Temperature extremes <input type="checkbox"/> Cold <input type="checkbox"/> Heat	<input type="checkbox"/> Wet location	<input type="checkbox"/> Bio hazards (snakes, insects, spiders, poisonous plants, etc.)
<input type="checkbox"/> Explosive vapors	<input type="checkbox"/> Confined space	<input type="checkbox"/> Engulfment Hazard	<input type="checkbox"/> _____
Electrical Hazards			
<input type="checkbox"/> None	<input type="checkbox"/> Energized equipment or circuits	<input checked="" type="checkbox"/> Overhead utilities <input checked="" type="checkbox"/> Underground utilities	<input type="checkbox"/> Wet location
Fire Hazards			
<input checked="" type="checkbox"/> None	<input type="checkbox"/> Cutting, welding, or grinding generated sparks or heat sources	<input type="checkbox"/> Flammable materials present	<input type="checkbox"/> Oxygen enriched location
Ergonomic Hazards			
<input checked="" type="checkbox"/> Lifting	<input checked="" type="checkbox"/> Bending	<input type="checkbox"/> Twisting	<input checked="" type="checkbox"/> Pulling/tugging
Computer Use in the: <input type="checkbox"/> Office <input type="checkbox"/> Field	<input type="checkbox"/> Repetitive motion	<input checked="" type="checkbox"/> Carrying	<input type="checkbox"/> _____
Radiological Hazards			
<input checked="" type="checkbox"/> None	<input type="checkbox"/> Alpha	<input type="checkbox"/> Beta	<input type="checkbox"/> Gamma/X-rays
<input type="checkbox"/> Neutron	<input type="checkbox"/> Radon	<input type="checkbox"/> Non-Ionizing	<input type="checkbox"/> _____
Other Hazards			
<input type="checkbox"/>			
<input type="checkbox"/>			

PPE and Monitoring Instruments

Initial Level of PPE *			
<input checked="" type="checkbox"/> Level D	<input type="checkbox"/> Modified Level D	<input type="checkbox"/> Level C	* Cannot use Short Form HASP for Level B or A work
Standard PPE			
<input checked="" type="checkbox"/> Hard Hat	<input checked="" type="checkbox"/> Safety boots	<input checked="" type="checkbox"/> Safety glasses	<input type="checkbox"/> Chemical Resistant Boots
<input checked="" type="checkbox"/> High visibility vest	<input type="checkbox"/> Other: _____		
Eye and Face Protection			
<input type="checkbox"/> Face shield	<input type="checkbox"/> Vented goggles	<input type="checkbox"/> Unvented goggles	<input type="checkbox"/> Indirect vented goggles
Hearing Protection			
<input checked="" type="checkbox"/> Ear plugs (drilling task)	<input type="checkbox"/> Ear Muffs	<input type="checkbox"/> Ear plugs and muffs	<input type="checkbox"/> Other _____
Respiratory Protection			
<input type="checkbox"/> None	<input type="checkbox"/> Dust mask	<input checked="" type="checkbox"/> Full Face APR <input type="checkbox"/> Half Face APR	Cartridge Type: <u>Ultra Twin</u> Change Cartridges: <u>3.5 hrs</u>
Protective Clothing			
<input type="checkbox"/> White uncoated Tyvek®	<input type="checkbox"/> Poly-coated Tyvek®	<input type="checkbox"/> Saranex®	<input checked="" type="checkbox"/> Work uniform
<input type="checkbox"/> Boot covers	<input type="checkbox"/> Reflective vest	<input type="checkbox"/> Chaps or Snake Legs	<input type="checkbox"/> Other _____
Hand Protection			
<input type="checkbox"/> None	<input type="checkbox"/> Cotton gloves	<input type="checkbox"/> Leather gloves	<input type="checkbox"/> Glove liners
<input checked="" type="checkbox"/> Outer Gloves List Type <u>vinyl</u>	<input checked="" type="checkbox"/> Inner Gloves List Type <u>nitrile</u>	<input type="checkbox"/> Cut-resistant gloves	<input type="checkbox"/> Other _____
Monitoring Instruments Required			
<input type="checkbox"/> LEL/O2 Meter	<input checked="" type="checkbox"/> PID <input type="checkbox"/> 10.0-10.6 eV Lamp <input checked="" type="checkbox"/> 11.7 eV Lamp	<input type="checkbox"/> FID	<input type="checkbox"/> Hydrogen Sulfide/Carbon Monoxide
<input checked="" type="checkbox"/> Dräger Pump (or equivalent) List Tubes <u>Vinyl chloride</u>	<input type="checkbox"/> Dust Meter <input type="checkbox"/> Respirable dust <input type="checkbox"/> Total dust	<input type="checkbox"/> Other _____	

Air Monitoring Action Levels:

PID/FID Reading ¹	Detector Tube ¹	Dust Meter ¹	LEL ² /O ₂	Action	Level of PPE
Anything above background (ppm)	<0.5 ppm			Continue to monitor with PID	Modified Level D
22 ppm	<0.5 ppm			Continue to monitor with PID and DT	Level C (stop and re-assess)

¹ Sustained readings measured in the breathing zone

² Readings at measured at the source (borehole, well, etc.)

PPE Selection Guidelines

When selecting the appropriate PPE for the job, consider the following:

- **Safety glasses** – general eye protection – source of hazard, typically coming from straight on, required at most sites
- **Tinted Safety Glasses** – same as above, but when working in direct sunlight. May need two both tinted and untinted if working in both sunlight and shade/overcast skies.
- **Safety goggles** – needed for splash hazard, more severe eye exposures coming from all directions. Non-vented or indirect venting for chemical splash, non-vented for hazardous gases or very fine dust, vented for larger particulates coming from all directions.
- **Face shield** – needed to protect face from cuts, burns, chemicals (corrosives or chemicals with skin notation), etc.
- **Safety boots** – needed if danger of items being dropped on foot that could injure foot
- **Hard hat** – danger from items falling on head – any overhead work, tools, equipment, etc that is above the head and could fall on head if item fails, or falls off work platform. Typically required at most sites as a general PPE
- **Thin, chemical protective inner gloves** (e.g., thin Nitrile, PVC – do not use latex – many people are allergic to latex) – needed to protect hands from incidental contact with low risk contamination at very low concentrations (ppb or low ppm concentrations in groundwater or soil) or used in combination with outergloves as a last defense against contamination. Need to specify type
- **Outer gloves** – thicker gloves (e.g., Nitrile, Butyl, Viton, etc.) – used when potential for high concentrations of contaminants (e.g., floating product, percent ranges of contaminant, opening drums, handling pure undiluted chemicals, etc.). Need to specify type.
- **Leather gloves, leather palm, cotton** – good in protecting hands against cuts – no protection from chemicals. May be used in combination with chemical protective gloves.
- **Boot Covers** – when there is contamination in surface soils or wading surface in general. When safety boots need protection from contact with contaminants.
- **White (uncoated) Tyveks** – protect clothing from getting dirty, good for protection against solid, non-volatile chemicals (e.g., asbestos, metals) – no chemical protection.
- **Polycoated Tyveks** – least protective of chemical protective clothing. Used when some risk of contamination getting on skin or clothing. Usually, lower ppm ranges of contaminants.
- **Saranex** – Greater protection against contamination than Polycoated Tyveks. Used to protect against PCBs or higher concentrations of contaminants in the soil or groundwater.
- **Other Chemical protective clothing** – if significant risk of dermal exposure, contact H&S to determine best kind.
- **Long sleeved shirts, long pants** – if working in areas with poison ivy/oak/sumac, poisonous insects, etc. and no chemicals exposure. May want to use uncoated Tyveks for work in areas where poisonous plants are known to be to protect clothing.
- **Cartridge Respirator (Level C PPE)** – Need to calculate change schedule (contact Division EH&S Manager for this) to determine length of use. To be able to use cartridge respirators, need to know contaminants, estimate levels to be encountered in the breathing zone, need to ensure that cartridge will be effective against COCs, and need to be able to monitor for COCs using PID, FID, Dräger tubes, etc.. If can't do any of these, then Level B PPE is probably going to be needed.
- **High Visibility Vest** – needed for any road work (within 15 feet of a road) or when working on a site with vehicular traffic or working around heavy equipment. Needed if work tasks would take employee concentration away from movement of vehicles and workers would have to rely on the other driver's ability to see the employee in order not to hit them. This includes heavy equipment as well as cars and trucks, on public roads or the jobsite. Not needed if wearing Polycoated Tyveks – as they are already high visibility.
- **Reflective Vest** – see above, but for use at night.
- **Hearing Protection** – needed if working at noise levels above 85 dBA on a time weighted average. If noise measurements are not available, use around noisy equipment, or in general, if you have to raise your voice to be heard when talking to someone standing two feet away.
- **Protective Chaps** – required when using a machete or chain saw or any other cut hazard to legs.

Work Zones:

The work zones will be defined relative to the location of the work activity. The Exclusion Zone is considered the area within a 10-foot diameter of the sampling location. The Contamination Reduction Zone is considered to be the area within a 20-foot diameter of the sampling location. The decontamination zone being located upwind of the work area. Work zones will be maintained through the use of:

- XX Warning Tape around drill rig and working zone when near road
- XX Visual Observations

Site Communication:

- XX Verbal
- Two-way radio
- XX Cellular telephone
- Hand signals
 - Hand gripping throat Out of air, can't breathe
 - Grip partner's wrist or both hands around waist Leave area immediately
 - Hands on top of head Need assistance
 - Thumbs up OK, I am all right, I understand
 - Thumbs down No, negative
- XX Horn
- Siren
- Other:

EMERGENCY CONTACTS

NAME	TELEPHONE NUMBERS		DATE OF PRE-EMERGENCY NOTIFICATION (if applicable)
Fire Department:	911		
Police Department:	911		
Site Health And Safety Officer: Phil Muller	Office: 781-245-6606	Home:	
Client Contact: Brian Jankauskas	Office: 518-402-9620	Pager:	
Project Manager: John Peterson	Office: 207-775-5401	Home:	
Division EH&S Manager: Cindy Sundquist	Office: 207-828-3309 (w) 207-650-7593(c)	Home: 207-892-4402	
OTHER: Ambulance	911		
Manfred F. J. Schulte Site Hospital: Long Island Jewish Medical Center	718-470-7000		
Active Industrial Uniform Site Hospital: Good Samaritan Hospital/Medical Center	516-376-3000		
Sheridan Waste Oil Company Site Hospital: Yaphank Center	516-924-4411		
Eugene's Dry Cleaners Site Hospital: Good Samaritan Hospital/Medical Center	516-376-3000		

Emergency Equipment:

The following emergency response equipment is required for this project and shall be readily available:

- XX Field First Aid Kit
- XX Fire Extinguisher (ABC type) **MAY BE DRILLERS**
- Eyewash (Note: 15 minutes of free-flowing fresh water)
- Other: _____

EMERGENCY PROCEDURES

- The HSO (or alternate) should be immediately notified via the on-site communication system. The HSO assumes control of the emergency response.
- The HSO notifies the Project Manager and client contact of the emergency. The HSO shall then contact the Division ES&H Manager who will then contact the Corporate EH&S Manager.
- If applicable, the HSO shall notify off-site emergency responders (e.g. fire department, hospital, police department, etc.) and shall inform the response team as to the nature and location of the emergency on-site.
- If applicable, the HSO evacuates the site. Site workers should move to the predetermined evacuation point (See Site Map).
- For small fires, flames should be extinguished using the fire extinguisher. Large fires should be handled by the local fire department.
- In an unknown situation or if responding to toxic gas emergencies, appropriate PPE, including SCBAs (if available), should be donned. If appropriate PPE is unavailable, site workers should evacuate and call in emergency personnel.
- If chemicals are accidentally spilled or splashed into eyes or on skin, use eyewash and wash affected area. Site worker should shower as soon as possible after incident.
- If a worker is injured, first aid shall be administered by certified first aid provider.
- If the emergency involves toxic gases, workers will back off and reassess. Prior to re-entering the work zone, the area must be determined to be safe. Entry will be using Level B PPE and utilize appropriate monitoring equipment to verify that the site is safe.
- An injured worker shall be decontaminated appropriately.
- After the response, the SHSO shall follow-up with the required company reporting procedures, including the completing the MACTEC Incident Analysis Report.

Site Specific Emergency Procedures are as follows:

USE ENGINEERING CONTROLS TO CONTROL VISUAL DUST IF PRESENT DURING
CONCRETE BORING (i.e. water surface to control dust)

FIELD TEAM REVIEW: I acknowledge that I understand the requirements of this HASP, and agree to abide by the procedures and limitations specified herein. I also acknowledge that I have been given an opportunity to have my questions regarding the HASP and its requirements answered prior to performing field activities. Health and safety training and medical surveillance requirements applicable to my field activities at this site are current and will not expire during on-site activities.

Name: _____	Date: _____
Name: _____	Date: _____
Name: _____	Date: _____
Name: _____	Date: _____
Name: _____	Date: _____

Routes to Emergency Medical Facilities

Manfred F. J. Schulte Site

PRIMARY HOSPITAL:

Facility Name: Long Island Jewish Medical Center
Address: 27005 76th Ave # C204, New Hyde Park, NY (2.2 miles)
Telephone Number: 718-470-7000

DIRECTIONS TO PRIMARY HOSPITAL (attach map):

- 1: Start out going EAST on JERICHO TURNPIKE / NY-25 toward HILLSIDE BLVD. 0.1 miles
- 2: Turn LEFT onto LAKEVILLE RD. 1.6 miles
- 3: Turn LEFT onto UNION TURNPIKE. 0.1 miles
- 4: Turn RIGHT onto 270TH ST. 0.2 miles
- 5: Turn RIGHT onto 76TH AVE. <0.1 miles
- 6: End at **27005 76th Ave**
New Hyde Park, NY 11040-1433, US

ALTERNATE HOSPITAL:

Facility Name: South Nassau Communities Hospital
Address: 2445 Oceanside Road, Oceanside, NY (14 miles)
Telephone Number: 516-763-2030


DIRECTIONS TO ALTERNATE HOSPITAL (attach map):

- 1: Start out going WEST on JERICHO TURNPIKE / NY-25 toward S 4TH ST. Continue to follow JERICHO TURNPIKE. 1.9 miles
- 2: Turn LEFT onto 241ST ST. <0.1 miles
- 3: Merge onto CROSS ISLAND PKWY S via the ramp on the LEFT. 2.4 miles
- 4: Take the SOUTHERN STATE PKWY EAST exit- EXIT 25A- on the LEFT toward EASTERN LONG IS. 0.4 miles
- 5: Merge onto SOUTHERN PKWY E / SOUTHERN STATE PKWY. 5.2 miles
- 6: Take the PENINSULA BLVD SOUTH exit- EXIT 19S- toward ROCKVILLE CTR. 0.1 miles
- 7: Turn RIGHT onto PENINSULA BLVD. 1.7 miles
- 8: Turn LEFT onto LAKEVIEW AVE. 0.6 miles
- 9: Turn RIGHT onto MORRIS AVE. 0.3 miles
- 10: Turn LEFT onto SUNRISE HWY / NY-27 E / POW / MIA MEMORIAL HWY. 0.5 miles
- 11: Turn RIGHT onto N OCEANSIDE RD. 0.3 miles
- 12: End at **2445 Oceanside Rd**
Oceanside, NY 11572-1548, US


Directions to Primary Hospital:




1: Start out going EAST on JERICHO TURNPIKE / NY-25 toward HILLSIDE BLVD. 0.1 miles



2: Turn LEFT onto LAKEVILLE RD. 1.6 miles




3: Turn LEFT onto UNION TURNPIKE. 0.1 miles





4: Turn RIGHT onto 270TH ST.

0.2 miles



5: Turn RIGHT onto 76TH AVE.

<0.1 miles



6: End at 27005 76th Ave
New Hyde Park, NY 11040-1433, US




Total Est. Time: 7 minutes Total Est. Distance: 2.16 miles


Directions to alternate Hospital:




1: Start out going WEST on JERICHO TURNPIKE / NY-25 toward S 4TH ST. Continue to follow JERICHO TURNPIKE. 1.9 miles



2: Turn LEFT onto 241ST ST. <0.1 miles



3: Merge onto CROSS ISLAND PKWY S via the ramp on the LEFT. 2.4 miles





4: Take the SOUTHERN STATE PKWY EAST exit- EXIT 25A- on the LEFT toward EASTERN LONG IS. 0.4 miles



5: Merge onto SOUTHERN PKWY E / SOUTHERN STATE PKWY. 5.2 miles




6: Take the PENINSULA BLVD SOUTH exit- EXIT 19S- toward ROCKVILLE CTR. 0.1 miles






7: Turn RIGHT onto PENINSULA BLVD.

1.7 miles




8: Turn LEFT onto LAKEVIEW AVE.

0.6 miles



9: Turn RIGHT onto MORRIS AVE.


0.3 miles





10: Turn LEFT onto SUNRISE HWY / NY-27 E / POW / MIA MEMORIAL HWY.

0.5 miles




11: Turn RIGHT onto N OCEANSIDE RD.

0.3 miles



12: End at 2445 Oceanside Rd
Oceanside, NY 11572-1548, US



Total Est. Time: 25 minutes Total Est. Distance: 14.01 miles

Routes to Emergency Medical Facilities

Active Industrial Uniform

PRIMARY HOSPITAL:

Facility Name: Good Samaritan Hospital/Medical Center
Address: 1000 Montauk Highway, West Islip, NY (4.1 miles)
Telephone Number: 516-376-3000

DIRECTIONS TO PRIMARY HOSPITAL (attach map):

- 1: Start out going EAST on W MONTAUK HWY / NY-27A E toward S 1ST ST. 4.1 miles
- 2: End at **1000 Montauk Hwy**
West Islip, NY 11795-4927, US

ALTERNATE HOSPITAL:

Facility Name: Brunswick General Hospital Center
Address: 366 Broadway, Amityville, NY (3.4 miles)
Telephone Number: 516-789-7711

DIRECTIONS TO ALTERNATE HOSPITAL (attach map):

- 1: Start out going SOUTHWEST on W MONTAUK HWY / NY-27A toward S 2ND ST. <0.1 miles
- 2: Turn RIGHT onto S 2ND ST. 0.7 miles
- 3: Turn LEFT onto W HOFFMAN AVE / CR-12. Continue to follow CR-12. 1.3 miles
- 4: Turn RIGHT onto GREAT NECK RD / CR-47. 0.3 miles
- 5: Turn LEFT onto DIXON AVE / CR-2. 0.9 miles
- 6: End at **366 Broadway**
Amityville, NY 11701-2711, US

Directions to Primary Hospital:

START

1: Start out going EAST on W MONTAUK HWY / NY-27A E toward S 1ST ST.

4.1 miles



END

2:

End at 1000 Montauk Hwy
West Islip, NY 11795-4927, US




Total Est. Time: 11 minutes **Total Est. Distance: 4.12 miles**


Directions to Alternate Hospital:




- 1: Start out going SOUTHWEST on W MONTAUK HWY / NY-27A toward S 2ND ST. <0.1 miles



- 2: Turn RIGHT onto S 2ND ST. 0.7 miles




- 3: Turn LEFT onto W HOFFMAN AVE / CR-12. Continue to follow CR-12. 1.3 miles





4: Turn RIGHT onto GREAT NECK RD / CR-47.

0.3 miles




5: Turn LEFT onto DIXON AVE / CR-2.

0.9 miles



6: End at 366 Broadway
Amityville, NY 11701-2711, US



Total Est. Time: 9 minutes Total Est. Distance: 3.40 miles

Routes to Emergency Medical Facilities

Sheridan Waste Oil Company

PRIMARY HOSPITAL:

Facility Name: Yaphand Center
Address: 31 Scouting Blvd, Medford, NY (1.3 miles)
Telephone Number: 516-924-4411

DIRECTIONS TO PRIMARY HOSPITAL (attach map):

- 1: Start out going EAST on PECONIC AVE toward KANE AVE. 0.8 miles
- 2: Turn RIGHT onto HORSE BLOCK RD / CR-16. 0.3 miles
- 3: Turn RIGHT onto SCOUTING BLVD / INDUSTRIAL BLVD. 0.1 miles
- 4: End at **31 Scouting Blvd**
Medford, NY 11763-2220, US

ALTERNATE HOSPITAL:

Facility Name: Brookhaven Memorial Hospital
Address: 101 Hospital Road, Patchogue, NY (4.8 miles)
Telephone Number: 516-654-7100

DIRECTIONS TO ALTERNATE HOSPITAL (attach map):


- 1: Start out going EAST on PECONIC AVE toward KANE AVE. 0.8 miles
- 2: Turn RIGHT onto HORSE BLOCK RD / CR-16. 0.7 miles
- 3: Turn RIGHT onto PATCHOGUE YAPHANK RD / CR-101 S / SILLS RD. Continue to follow CR-101 S / SILLS RD. 2.9 miles
- 4: Turn RIGHT onto BROOKHAVEN HOSPITAL RD. 0.2 miles
- 5: End at **101 Hospital Rd**
Patchogue, NY 11772-4870, US

Directions to Primary Hospital:



1: Start out going EAST on PECONIC AVE toward KANE AVE.

0.8 miles



2: Turn RIGHT onto HORSE BLOCK RD / CR-16.

0.3 miles



3: Turn RIGHT onto SCOUTING BLVD / INDUSTRIAL BLVD.

0.1 miles



END

4:

End at 31 Scouting Blvd
Medford, NY 11763-2220, US




Directions to Alternate Hospital:




1: Start out going EAST on PECONIC AVE toward KANE AVE.

0.8 miles




2: Turn RIGHT onto HORSE BLOCK RD / CR-16.

0.7 miles



3: Turn RIGHT onto PATCHOGUE YAPHANK RD / CR-101 S / SILLS RD. Continue to follow CR-101 S / SILLS RD. 2.9 miles






4: Turn RIGHT onto BROOKHAVEN HOSPITAL RD.

0.2 miles



5: End at 101 Hospital Rd
Patchogue, NY 11772-4870, US



Routes to Emergency Medical Facilities

Eugene's Dry Cleaners

PRIMARY HOSPITAL:

Facility Name: Good Samaritan Hospital/Medical Center

Address: 1000 Montauk Highway, West Islip, NY (1.5 miles)

Telephone Number: 516-376-3000

DIRECTIONS TO PRIMARY HOSPITAL (attach map):

- 1: Start out going EAST on E MAIN ST / NY-27A E / MONTAUK HWY toward TOTTEN PL. Continue to follow NY-27A E / MONTAUK HWY. 1.4 miles
- 2: End at **1000 Montauk Hwy**
West Islip, NY 11795-4927, US

ALTERNATE HOSPITAL:

Facility Name: Brunswick General Hospital Center

Address: 366 Broadway, Amityville, NY (6.8 miles)

Telephone Number: 516-789-7711


DIRECTIONS TO ALTERNATE HOSPITAL (attach map):

- 1: Start out going WEST on E MAIN ST / NY-27A / MONTAUK HWY toward DEER PARK AVE. 0.6 miles
- 2: Turn RIGHT onto LITTLE EAST NECK RD N / NY-109 W. Continue to follow NY-109 W. 2.3 miles
- 3: Take the ramp toward RT-27 W / NEW YORK. 0.1 miles
- 4: Turn SLIGHT RIGHT onto POW / MIA MEMORIAL HWY / SUNRISE HWY. 3.3 miles
- 5: Merge onto NY-110 S / BROADWAY toward AMITYVILLE. 0.3 miles
- 6: End at **366 Broadway**
Amityville, NY 11701-2711, US

Directions to Primary Hospital:

START

- 1: Start out going EAST on E MAIN ST / NY-27A E / MONTAUK HWY toward TOTTEN PL. 1.4 miles
Continue to follow NY-27A E / MONTAUK HWY.



END


- 2: End at 1000 Montauk Hwy
West Islip, NY 11795-4927, US




Directions to Alternate Hospital:



1: Start out going WEST on E MAIN ST / NY-27A / MONTAUK HWY toward DEER PARK AVE. 0.6 miles



2: Turn RIGHT onto LITTLE EAST NECK RD N / NY-109 W. Continue to follow NY-109 W. 2.3 miles



3: Take the ramp toward RT-27 W / NEW YORK. 0.1 miles





4: Turn SLIGHT RIGHT onto POW / MIA MEMORIAL HWY / SUNRISE HWY.

3.3 miles




5: Merge onto NY-110 S / BROADWAY toward AMITYVILLE.

0.3 miles



6: End at 366 Broadway
Amityville, NY 11701-2711, US



Material Safety Data Sheet

Hydrochloric Acid, Reagent ACS

ACC# 95547

Section 1 - Chemical Product and Company Identification

MSDS Name: Hydrochloric Acid, Reagent ACS

Catalog Numbers: AC423790025, AC423790250, AC423795000, NC9619320

Synonyms: Muriatic acid; Chlorohydric acid; Hydrogen chloride; Spirits of salt

Company Identification:

Fisher Scientific

1 Reagent Lane

Fair Lawn, NJ 07410

For information, call: 201-796-7100

Emergency Number: 201-796-7100

For CHEMTREC assistance, call: 800-424-9300

For International CHEMTREC assistance, call: 703-527-3887

Section 2 - Composition, Information on Ingredients

CAS#	Chemical Name	Percent	EINECS/ELINCS
7647-01-0	Hydrochloric acid	36.5	231-595-7
7732-18-5	Water	Balance	231-791-2

Hazard Symbols: C

Risk Phrases: 34 37

Section 3 - Hazards Identification

EMERGENCY OVERVIEW

Appearance: colorless to slight yellow clear liquid. **Danger!** Corrosive. Causes eye and skin burns. May cause severe respiratory tract irritation with possible burns. May cause severe digestive tract irritation with possible burns. May be harmful if swallowed.

Target Organs: Respiratory system, teeth, eyes, skin, circulatory system.

Potential Health Effects

Eye: May cause irreversible eye injury. Vapor or mist may cause irritation and severe burns. Contact with liquid is corrosive to the eyes and causes severe burns. May cause painful sensitization to light.

Skin: May be absorbed through the skin in harmful amounts. May cause skin sensitization, an allergic reaction, which becomes evident upon re-exposure to this material. Contact with liquid is corrosive and causes severe burns and ulceration.

Ingestion: May cause circulatory system failure. Causes severe digestive tract burns with abdominal pain, vomiting, and possible death. May cause corrosion and permanent tissue destruction of the esophagus and digestive tract. May be harmful if swallowed.

Inhalation: May cause severe irritation of the respiratory tract with sore throat, coughing, shortness of breath and delayed lung edema. Causes chemical burns to the respiratory tract. Exposure to the mist and vapor may erode exposed teeth. Causes corrosive action on the mucous membranes.

Chronic: Prolonged or repeated skin contact may cause dermatitis. Repeated exposure may cause erosion of teeth. May cause fetal effects. Laboratory experiments have resulted in mutagenic effects. Prolonged exposure may cause conjunctivitis, photosensitization, and possible blindness.

Section 4 - First Aid Measures

Eyes: Get medical aid immediately. Do NOT allow victim to rub or keep eyes closed. Extensive irrigation with water is required (at least 30 minutes). SPEEDY ACTION IS CRITICAL!

Skin: Get medical aid immediately. Immediately flush skin with plenty of water for at least 15 minutes while removing contaminated clothing and shoes. Wash clothing before reuse. Destroy contaminated shoes.

Ingestion: Do NOT induce vomiting. If victim is conscious and alert, give 2-4 cupfuls of milk or water. Never give anything by mouth to an unconscious person. Get medical aid immediately. Give milk of magnesia.

Inhalation: Get medical aid immediately. Remove from exposure and move to fresh air immediately. If breathing is difficult, give oxygen. Do NOT use mouth-to-mouth resuscitation. If breathing has ceased apply artificial respiration using oxygen and a suitable mechanical device such as a bag and a mask.

Notes to Physician: Do NOT use sodium bicarbonate in an attempt to neutralize the acid.

Antidote: Do NOT use oils or ointments in eye.

Section 5 - Fire Fighting Measures

General Information: As in any fire, wear a self-contained breathing apparatus in pressure-demand, MSHA/NIOSH (approved or equivalent), and full protective gear. Water runoff can cause environmental damage. Dike and collect water used to fight fire. During a fire, irritating and highly toxic gases may be generated by thermal

decomposition or combustion. Not flammable, but reacts with most metals to form flammable hydrogen gas. Use water spray to keep fire-exposed containers cool. Vapors may be heavier than air. They can spread along the ground and collect in low or confined areas. Reaction with water may generate much heat which will increase the concentration of fumes in the air. Containers may explode when heated.

Extinguishing Media: For large fires, use water spray, fog, or alcohol-resistant foam. Substance is nonflammable; use agent most appropriate to extinguish surrounding fire. Do NOT get water inside containers. Do NOT use straight streams of water. Most foams will react with the material and release corrosive/toxic gases. Cool containers with flooding quantities of water until well after fire is out. For small fires, use carbon dioxide (except for cyanides), dry chemical, dry sand, and alcohol-resistant foam.

Flash Point: Not applicable.

Autoignition Temperature: Not applicable.

Explosion Limits, Lower: Not available.

Upper: Not available.

NFPA Rating: (estimated) Health: 3; Flammability: 0; Instability: 0

Section 6 - Accidental Release Measures

General Information: Use proper personal protective equipment as indicated in Section 8.

Spills/Leaks: Large spills may be neutralized with dilute alkaline solutions of soda ash (sodium carbonate, Na_2CO_3), or lime (calcium oxide, CaO). Avoid runoff into storm sewers and ditches which lead to waterways. Clean up spills immediately, observing precautions in the Protective Equipment section. Remove all sources of ignition. Provide ventilation. Do not get water inside containers. A vapor suppressing foam may be used to reduce vapors. Cover with dry earth, dry sand, or other non-combustible material followed with plastic sheet to minimize spreading and contact with water.

Section 7 - Handling and Storage

Handling: Wash thoroughly after handling. Remove contaminated clothing and wash before reuse. Use only in a well-ventilated area. Contents may develop pressure upon prolonged storage. Do not breathe dust, vapor, mist, or gas. Do not get in eyes, on skin, or on clothing. Keep container tightly closed. Do not ingest or inhale. Discard contaminated shoes. Use caution when opening. Keep from contact with moist air and steam.

Storage: Do not store in direct sunlight. Store in a tightly closed container. Store in a cool, dry, well-ventilated area away from incompatible substances. Corrosives area. Do not store in metal containers. Store protected from moisture. Do not store near flammable or oxidizing substances (especially nitric acid or chlorates).

Section 8 - Exposure Controls, Personal Protection

Engineering Controls: Facilities storing or utilizing this material should be equipped with an eyewash facility and a safety shower. Use adequate general or local exhaust ventilation to keep airborne concentrations below the permissible exposure limits.

Exposure Limits

Chemical Name	ACGIH	NIOSH	OSHA - Final PELs
Hydrochloric acid	2 ppm Ceiling	50 ppm IDLH	5 ppm Ceiling; 7 mg/m ³ Ceiling
Water	none listed	none listed	none listed

OSHA Vacated PELs: Hydrochloric acid: No OSHA Vacated PELs are listed for this chemical. Water: No OSHA Vacated PELs are listed for this chemical.

Personal Protective Equipment

Eyes: Wear appropriate protective eyeglasses or chemical safety goggles as described by OSHA's eye and face protection regulations in 29 CFR 1910.133 or European Standard EN166.

Skin: Wear neoprene or polyvinyl chloride gloves to prevent exposure.

Clothing: Wear appropriate protective clothing to prevent skin exposure.

Respirators: A respiratory protection program that meets OSHA's 29 CFR 1910.134 and ANSI Z88.2 requirements or European Standard EN 149 must be followed whenever workplace conditions warrant a respirator's use.

Section 9 - Physical and Chemical Properties

Physical State: Clear liquid

Appearance: colorless to slight yellow

Odor: strong, pungent

pH: 0.01

Vapor Pressure: 5.7 mm Hg @ 0 deg C

Vapor Density: 1.26

Evaporation Rate: > 1.00 (N-butyl acetate)

Viscosity: Not available.

Boiling Point: 81.5-110 deg C @ 760 mmHg

Freezing/Melting Point: -74 deg C

Decomposition Temperature: Not available.

Solubility: Miscible.

Specific Gravity/Density: 1.0-1.2

Molecular Formula: HCl.H₂O

Molecular Weight: 36.46

Section 10 - Stability and Reactivity

Chemical Stability: Stable under normal temperatures and pressures.

Conditions to Avoid: Mechanical shock, incompatible materials, metals, excess heat, exposure to moist air or water, bases.

Incompatibilities with Other Materials: Acetates, acetic anhydride, alcohols + hydrogen cyanide, 2-aminoethanol, ammonium hydroxide, calcium carbide, calcium phosphide, cesium acetylene carbide, cesium carbide, chlorosulfonic acid, 1,1-difluoroethylene, ethylene diamine, ethyleneimine, fluorine, lithium silicides, magnesium boride, mercuric sulfate, oleum, perchloric acid, potassium permanganate, beta-propiolactone, propylene oxide, rubidium acetylene carbide, rubidium carbide, silver perchlorate + carbon tetrachloride, sodium, sodium hydroxide, sulfuric acid, uranium phosphide, vinyl acetate, zinc, metal oxides, aluminum, amines, carbonates, iron, steel, copper alloys, copper, alkali metals, bases, moisture.

Hazardous Decomposition Products: Hydrogen chloride, chlorine, carbon monoxide, carbon dioxide, hydrogen gas.

Hazardous Polymerization: Will not occur.

Section 11 - Toxicological Information

RTECS#:

CAS# 7647-01-0: MW4025000; MW4031000

CAS# 7732-18-5: ZC0110000

LD50/LC50:

CAS# 7647-01-0:

Inhalation, mouse: LC50 = 1108 ppm/1H;

Inhalation, mouse: LC50 = 8300 mg/m³/30M;

Inhalation, rat: LC50 = 3124 ppm/1H;

Inhalation, rat: LC50 = 45000 mg/m³/5M;

Inhalation, rat: LC50 = 8300 mg/m³/30M;

Oral, rabbit: LD50 = 900 mg/kg; <BR.

CAS# 7732-18-5:

Oral, rat: LD50 = >90 mL/kg; <BR.

Carcinogenicity:

CAS# 7647-01-0:

ACGIH: A4 - Not Classifiable as a Human Carcinogen

IARC: IARC Group 3 - not classifiable **CAS#** 7732-18-5: Not listed by ACGIH, IARC, NIOSH, NTP, or OSHA.

Epidemiology: Experimental reproductive effects have been reported.

Teratogenicity: Embryo or Fetus: Stunted fetus, Inhalation, rat TCL0=450 mg/m³/1H Specific Developmental Abnormalities: homeostatis, Inhalation, rat TCL0=450 mg/m³/1H (female 1 days pre-mating).

Reproductive Effects: No information available.

Neurotoxicity: No information available.

Mutagenicity: Cytogenetic analysis: Hamster, lung = 30 mmol/L.; Cytogenetic analysis: Hamster, ovary = 8 mmol/L.

Other Studies: No data available.

Section 12 - Ecological Information

Ecotoxicity: Fish: Bluegill/Sunfish: 3.6 mg/L; 48Hr; Lethal (unspecified)
Bluegill/Sunfish: LC50; 96 Hr; pH 3.0-3.5 No data available.

Environmental: Rapidly hydrolyzes when exposed to water. Will exhibit extensive evaporation from soil surfaces. Upon transport through the soil, hydrochloric acid will dissolve some of the soil materials (especially those with carbonate bases) and the acid will neutralize to some degree.

Physical: No information available.

Other: No information available.

Section 13 - Disposal Considerations

Chemical waste generators must determine whether a discarded chemical is classified as a hazardous waste. US EPA guidelines for the classification determination are listed in 40 CFR Parts 261.3. Additionally, waste generators must consult state and local hazardous waste regulations to ensure complete and accurate classification.

RCRA P-Series: None listed.

RCRA U-Series: None listed.

Section 14 - Transport Information

	US DOT	IATA	RID/ADR	IMO	Canada TDG
Shipping Name:	HYDROCHLORIC ACID				No information available.
Hazard Class:	8				
UN Number:	UN1789				
Packing Group:	II				

Section 15 - Regulatory Information

US FEDERAL

TSCA

CAS# 7647-01-0 is listed on the TSCA inventory.

CAS# 7732-18-5 is listed on the TSCA inventory.

Health & Safety Reporting List

None of the chemicals are on the Health & Safety Reporting List.

Chemical Test Rules

None of the chemicals in this product are under a Chemical Test Rule.

Section 12b

None of the chemicals are listed under TSCA Section 12b.

TSCA Significant New Use Rule

None of the chemicals in this material have a SNUR under TSCA.

SARA

CERCLA Hazardous Substances and corresponding RQs

CAS# 7647-01-0: 5000 lb final RQ; 2270 kg final RQ

SARA Section 302 Extremely Hazardous Substances

CAS# 7647-01-0: 500 lb TPQ

SARA Codes

CAS # 7647-01-0: acute.

Section 313

This material contains Hydrochloric acid (CAS# 7647-01-0, 36 5%), which is subject to the reporting requirements of Section 313 of SARA Title III and 40 CFR Part 373.

Clean Air Act:

CAS# 7647-01-0 is listed as a hazardous air pollutant (HAP). This material does not contain any Class 1 Ozone depleters. This material does not contain any Class 2 Ozone depleters.

Clean Water Act:

CAS# 7647-01-0 is listed as a Hazardous Substance under the CWA. None of the chemicals in this product are listed as Priority Pollutants under the CWA. None of the chemicals in this product are listed as Toxic Pollutants under the CWA.

OSHA:

None of the chemicals in this product are considered highly hazardous by OSHA.

STATE

CAS# 7647-01-0 can be found on the following state right to know lists: California, New Jersey, Pennsylvania, Minnesota, Massachusetts.

CAS# 7732-18-5 is not present on state lists from CA, PA, MN, MA, FL, or NJ.

California No Significant Risk Level: None of the chemicals in this product are listed.

European/International Regulations

European Labeling in Accordance with EC Directives

Hazard Symbols:

C

Risk Phrases:

R 34 Causes burns.

R 37 Irritating to respiratory system.

Safety Phrases:

- S 1/2 Keep locked up and out of reach of children.
S 26 In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
S 36/37/39 Wear suitable protective clothing, gloves and eye/face protection.
S 45 In case of accident or if you feel unwell, seek medical advice immediately (show the label where possible).
S 9 Keep container in a well-ventilated place.

WGK (Water Danger/Protection)

CAS# 7647-01-0: 1

CAS# 7732-18-5: No information available.

Canada - DSL/NDSL

CAS# 7647-01-0 is listed on Canada's DSL List.

CAS# 7732-18-5 is listed on Canada's DSL List.

Canada - WHMIS

This product has a WHMIS classification of D1A, E.

Canadian Ingredient Disclosure List

CAS# 7647-01-0 is listed on the Canadian Ingredient Disclosure List.

Exposure Limits

CAS# 7647-01-0: OEL-AUSTRALIA:TWA 5 ppm (7 mg/m³) OEL-AUSTRIA:TWA 5 ppm (7 mg/m³) OEL-BELGIUM:STEL 5 ppm (7.7 mg/m³) OEL-DENMARK:STEL 5 ppm (7 mg/m³) OEL-FINLAND:STEL 5 ppm (7 mg/m³); Skin OEL-FRANCE:STEL 5 ppm (7.5 mg/m³) OEL-GERMANY:TWA 5 ppm (7 mg/m³) OEL-HUNGARY:STEL 5 mg/m³ OEL-JAPAN:STEL 5 ppm (7.5 mg/m³) OEL-THE NETHERLANDS:TWA 5 ppm (7 mg/m³) OEL-THE PHILIPPINES:TWA 5 ppm (7 mg/m³) OEL-POLAND:TWA 5 mg/m³ OEL-RUSSIA:STEL 5 ppm (5 mg/m³) OEL-SWEDEN:STEL 5 ppm (8 mg/m³) OEL-SWITZERLAND:TWA 5 ppm (7.5 mg/m³);STEL 10 ppm (15 mg/m³) OEL -THAILAND:TWA 5 ppm (7 mg/m³) OEL-TURKEY:TWA 5 ppm (7 mg/m³) OEL-UNITED KINGDOM:TWA 5 ppm (7 mg/m³);STEL 5 ppm (7 mg/m³) OEL IN BULGARIA, COLOMBIA, JORDAN, KOREA check ACGIH TLV OEL IN NEW ZEALAND, SINGAPORE, VIETNAM check ACGI TLV

Section 16 - Additional Information

MSDS Creation Date: 7/06/1999

Revision #4 Date: 8/14/2003

The information above is believed to be accurate and represents the best information currently available to us. However, we make no warranty of merchantability or any other warranty, express or implied, with respect to such information, and we assume no liability resulting from its use. Users should make their own investigations to determine the suitability of the information for their particular purposes. In no event shall Fisher be liable for any claims, losses, or damages of any third party or for lost profits or any special, indirect, incidental, consequential or exemplary damages, howsoever arising, even if Fisher has been advised of the possibility of such damages.

PRAXAIR INC -- HELIUM -- 6830-01-008-3431

=====
MSDS Safety Information
=====

FSC: 6830
NIIN: 01-008-3431
MSDS Date: 12/01/1992
MSDS Num: BWXRX
Tech Review: 02/14/1995
Product ID: HELIUM
Responsible Party
Cage: 0LV01
Name: PRAXAIR INC
Address: 39 OLD RIDGEBURY RD
City: DANBURY CT 06810-5113 US
Info Phone Number: 800-772-9247
Emergency Phone Number: 800-772-9247

=====
Preparer Co. when other than Responsible Party Co.
=====

Cage: 0LV01
Assigned Ind: N
Name: PRAXAIR, INC.
Address: 39 OLD RIDGEBURY RD
City: DANBURY CT 06810-5113

=====
Contractor Summary
=====

Cage: 0LV01
Name: PRAXAIR, INC.
Address: 39 OLD RIDGEBURY RD
City: DANBURY CT 06810-5113 US
Phone: 800-772-9247; 800-PRAXAIR

=====
Item Description Information
=====

Item Name: HELIUM, TECHNICAL
Specification Number: NK
Type/Grade/Class: NK

=====
Ingredients
=====

Cas: 7440-59-7
RTECS #: MH6520000
Name: HELIUM
% by Wt: 100
ACGIH TLV: SIMPLE ASPHYXIAN
Ozone Depleting Chemical: N

=====
Health Hazards Data
=====

Route Of Entry Inds - Inhalation: YES
Skin: NO
Ingestion: NO
Carcinogenicity Inds - NTP: NO
IARC: NO
OSHA: NO

Effects of Exposure: INHALATION: ASPHYXIANT. CAN CAUSE RAPID SUFFOCATION/DEATH DUE TO OXYGEN DEFICIENCY.

Explanation Of Carcinogenicity: NONE

Signs And Symptions Of Overexposure: HEADACHE, DROWSINESS, DIZZINESS, EXCITATION, EXCESS SALIVATION, VOMITING, UNCONSCIOUSNESS.

First Aid: SKIN: WASH W/SOAP & WATER. INHALATION: REMOVE TO FRESH AIR. GIVE CPR/OXYGEN IF NEEDED. EYES: FLUSH W/WATER. OBTAIN MEDICAL

ATTENTION

IN ALL CASES. NOTE TO PHYSICIAN: NO SPECIFIC ANTIDOTE. PRODUCT IS I NERT. TREATMENT OF OVEREXPOSSURE SHOULD BE DIRECTED AT CONTROL OF SYMPTOMS & CLINICAL CONDITION.

=====
Handling and Disposal
=====

Spill Release Procedures: EVACUATE ALL PERSONNEL FROM AREA. WEAR SCBA WHERE NEEDED. SAFELY SHUT OFF LEAK. VENTILATE AREA & MOVE LEAKING ASSEMBLY TO WELL VENTILATED AREA. TEST AREA/CONFINED AREAS FOR SUFFICIENT OXYGEN CONTENT P RIOR TO PERMITTING REENTRY TO AREA.

Waste Disposal Methods: SLOWLY RELEASE INTO ATMOSPHERE. DISPOSE OF ANY PRODUCT/RESIDUE/DISPOSABLE CONTAINER/LINER IN AN ENVIRONMENTALLY ACCEPTABLE MANNER IAW/FEDERAL, STATE & LOCAL REGULATIONS.

Handling And Storage Precautions: STORE & USE W/ADEQUATE VENTILATION. CLOSE VALVE WHEN NOT IN USE & WHEN EMPTY.

Other Precautions: DON'T GROUND CYLINDER/ALLOW TO BECOME PART OF AN ELECTRICAL CIRCUIT. DON'T STRIKE ARC ON CYLINDER. USE PIPING & EQUIPMENT

ADEQUATELY DESIGNED TO WITHSTAND PRESSURES TO BE ENCOUNTERED. NEVER WORK ON A PRESSURIZED SYSTEM. (SEE SUPP)

=====
Fire and Explosion Hazard Information
=====

Extinguishing Media: USE MEDIA APPROPRIATE FOR SURROUNDING FIRE.

Fire Fighting Procedures: EVACUATE ALL PERSONNEL FROM DANGER AREA.

IMMEDIATELY DELUGE CONTAINERS W/WATER SPRAY FROM MAXIMUM DISTANCE UNTIL

COOL, THEN SAFELY REMOVE CONTAINERS FROM AREA.

Unusual Fire/Explosion Hazard: CONTAINER MAY RUPTURE DUE TO HEAT OF FIRE.

=====
Control Measures
=====

Respiratory Protection: WEAR AIR PURIFYING/AIR SUPPLIED RESPIRATOR WHERE

LOCAL &/GENERAL EXHAUST VENTILATION ISN'T ADEQUATE TO KEEP WORKER EXPOSURE BELOW APPLICABLE TLV'S DURING WELDING W/THIS PRODUCT. AIR SUPPLIED RESPIRATOR REQUIRED IF WORKING IN CONFINED AREAS.

Ventilation: LOCAL/GENERAL EXHAUST TO MAINTAIN CONCENTRATION OF HAZARDOUS

FUMES & GASES <APPLICABLE TLV'S IN WORKER'S BREATHING ZONE.

Protective Gloves: PREFERRED FOR CYLINDER HANDLING

Eye Protection: RECOMMENDED

Other Protective Equipment: METATARSAL SHOES FOR CYLINDER HANDLING

Supplemental Safety and Health: OTHER PRECAUTIONS CONT'D: IF THERE IS A LEAK, CLOSE CYLINDER VALVE, BLOW DOWN SYSTEM BY VENTING TO A SAFE PLACE,

THEN REPAIR LEAK. WHEN TWO/MORE GASES/LIQUEFIED GASES ARE MIXED,
THEIR
HAZARDOUS PROPER TIES MAY COMBINE TO CREATE ADDITIONAL UNEXPECTED
HAZARDS. OBTAIN/EVALUATE SAFETY INFORMATION FOR EACH PRIOR TO MIXING.

=====
Physical/Chemical Properties
=====

B.P. Text: -452F
M.P/F.P Text: -457.6F
Vapor Pres: GAS
Vapor Density: 0.138
Spec Gravity: GAS
Solubility in Water: NEGLIGIBLE
Appearance and Odor: COLORLESS GAS AT NORMAL TEMP & PRESSURE W/NO ODOR.
Percent Volatiles by Volume: 100
=====

Reactivity Data
=====

Stability Indicator: YES
Stability Condition To Avoid: FIRE, TEMPS >125F, ARC
Hazardous Decomposition Products: NONE
Hazardous Polymerization Indicator: NO
=====

Toxicological Information
=====

Ecological Information
=====

MSDS Transport Information
=====

Regulatory Information
=====

Other Information
=====

HAZCOM Label
=====

Product ID: HELIUM
Cage: 0LV01
Company Name: PRAXAIR, INC.
Street: 39 OLD RIDGEBURY RD
City: DANBURY CT
Zipcode: 06810-5113 US
Health Emergency Phone: 800-772-9247
Date Of Label Review: 12/16/1998
Label Date: 12/16/1998
Hazard And Precautions: INHALATION: ASPHYXIANT. CAN CAUSE RAPID
SUFFOCATION/DEATH DUE TO OXYGEN DEFICIENCY.

HEADACHE, DROWSINESS,
DIZZINESS, EXCI TATION, EXCESS SALIVATION, VOMITING, UNCONSCIOUSNESS.

=====
Disclaimer (provided with this information by the compiling agencies):
This information is formulated for use by elements of the Department
of

Defense. The United States of America in no manner whatsoever expressly or implied warrants, states, or intends said information to have any application, use or viability by or to any person or persons outside the Department of Defense nor any person or persons contracting with any instrumentality of the United States of America and disclaims all liability for such use. Any person utilizing this instruction who is not a military or civilian employee of the United States of America should seek competent professional advice to verify and assume responsibility for the suitability of this information to their particular situation regardless of similarity to a corresponding Department of Defense or other government situation.



Job Hazard Analysis - HASP Format

Job Title: Decontamination

Date of Analysis: 5/30/06

Minimum Recommended PPE*: High visibility vest, hard hat, steel-toed boots, safety glasses, hearing protection

*See HASP for all required PPE

Key Work Steps	Hazards/Potential Hazards	Safe Practices
1. Establish Decontamination Station	1A) Materials Handling	1A) Materials Handling <ul style="list-style-type: none"> ▪ Use proper lifting techniques ▪ Use mechanical aids, if available, to move heavy items.
2. Decontamination / Steam cleaning.	2A) Struck by steam/hot water/pressure washing	2A) Struck by steam/hot water <ul style="list-style-type: none"> ▪ Workers not directly engaged in steam cleaning operations must stay clear. ▪ Workers using steam cleaning equipment must be trained on operation and safety devices/procedures using the owners/operators manual. ▪ Use face shield and safety glasses or goggles, if steam cleaning. ▪ Stay out of the splash/steam radius. ▪ Pressure washer must have dead man switch. ▪ Do not direct steam at anyone. ▪ Do not hold objects with your feet or hands. ▪ Ensure that direction of spray minimizes spread of contaminants of concern. ▪ Use shielding as necessary.
	2B) Exposure to contaminants	2B) Exposure to contaminants <ul style="list-style-type: none"> ▪ Conduct air monitoring (see HASP). ▪ Wear proper PPE (see HASP). ▪ See MSDSs for hazards associated with the decon solutions used (if other than water alone us used).
	2C) Slips/Trips/Falls	2C) Slips/Trips/Falls <ul style="list-style-type: none"> ▪ Be cautious as ground/plastic can become slippery ▪ Use boots or boot covers with good traction
3. Vehicle Decontamination	3A) Vehicle traffic in and out of the CRZ	3A) Large Vehicle Traffic <ul style="list-style-type: none"> ▪ Always wear a hard hat, steel toe boots, and a high visibility vest (unless Tyveks are used and are high visibility). ▪ Vehicle drivers are not to exit the vehicle in the CRZ. ▪ Identify an individual to communicate with vehicle drivers and maintain order ▪ Trucks will be lined with plastic and kept out of direct contact with any contaminated materials during loading. Wear PPE when removing plastic lining from truck beds. ▪ If not in the vehicle, obtain eye contact with the driver, so he is aware of your presence and location in the CRZ. ▪ If you are driving the vehicle, be aware of personnel in the CRZ and maintain communication with the identified personnel.
	3B) Exposure to contaminants	3B) Exposure to contaminants <ul style="list-style-type: none"> ▪ Use safety glasses or goggles, Polycoated Tyvek (if level of contamination poses dermal hazard or to keep work clothes dry), high visibility vest (if high visibility Tyveks are not used) hard hats, steel toe boots, and gloves while cleaning contaminated materials. ▪ Do not doff PPE until decontamination of the vehicle is complete and a decontamination certificate has been issued by the HSO. ▪ Conduct air monitoring (see HASP). ▪ See MSDSs for hazards associated with the decon solutions (if other than water alone is used).



Job Hazard Analysis - HASP Format

Job Title: Decontamination

Date of Analysis: 5/30/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	3C) Slips/Trips/Falls	3C) Slips/Trips/Falls <ul style="list-style-type: none"> ▪ Be cautious as ground/plastic can become slippery ▪ Use boots or boot covers with good traction
4. Equipment and Sample Decontamination	4A) Chemical exposure when handling contaminated sample jars and equipment	4A) Chemical exposure <ul style="list-style-type: none"> ▪ Wear PPE as outlined in the HASP. ▪ Refer to MSDS for specific hazards associated with decon solutions ▪ Monitor breathing zone for contaminants ▪ Monitor breathing zone for decon solutions (e.g., methanol, hexane, etc.) if appropriate (see HASP)
	4B) Materials Handling related injuries	4B) Materials Handling related injuries <ul style="list-style-type: none"> ▪ Use proper lifting techniques when lifting heavy equipment ▪ Use two person lift for heavy coolers
5. Personal Decontamination	4C) Exposure to contaminants	4C) Exposure to contaminants <ul style="list-style-type: none"> ▪ Avoid bringing contaminated materials via shoes and clothing into the CRZ by examining such prior to exiting the EZ. ▪ Removal of PPE will be performed by the following tasks in the listed order: <ul style="list-style-type: none"> ▪ Gross boot wash and rinse and removal ▪ Outer glove removal ▪ Suit removal ▪ Respirator removal (if worn). ▪ Inner glove removal ▪ Contaminated PPE is to be placed in the appropriate, provided receptacles. ▪ Respirators will be removed and decontaminated at a specified location within the CRZ by a designated technician, then placed in storage bag. ▪ Employees will wash hands, face, and any other exposed areas with soap and water. ▪ Portable eyewash stations and showers will be available should employees come into direct contact with contaminated materials. ▪ See MSDSs for hazards associated with the decontamination solutions used. ▪ Decon solutions will be disposed of according to the work plan.



Job Hazard Analysis – HASP Format

Job Title: Field Work - General

Date of Analysis: 8/15/06

Minimum Recommended PPE*: hard hat, steel-toed boots, safety glasses


*See HASP for all required PPE

Key Work Steps	Hazards/Potential Hazards	Safe Practices
1. Mobilization/ Demobilization and Site Preparation	1A) See Mobilization/Demobilization and Site Preparation JHA	1A) See Mobilization/Demobilization and Site Preparation JHA
2. Communication	2A) Safety, crew unity	2A) Talk to each other. <ul style="list-style-type: none"> ▪ Log all workers and visitor on and off the site. ▪ Let other crewmembers know when you see a hazard. ▪ Avoid working near known hazards. ▪ Always know the whereabouts of fellow crewmembers. ▪ Carry a radio and spare batteries or cell phone ▪ Review Emergency Evacuation Procedures (see below).
3. Walking and working in the field	3A) Falling down, twisted ankles and knees, poor footing	3A) Always watch your footing. <ul style="list-style-type: none"> ▪ Horseplay is strictly prohibited ▪ Slow down and use extra caution around logs, rocks, and animal holes. ▪ Extremely steep slopes (>50%) can be hazardous under wet or dry conditions; consider an alternate route. ▪ Wear laced boots with a minimum 8" high upper and non-skid Vibram-type soles for ankle support and traction.
	3B) Falling objects	3B) Protect head against falling objects. <ul style="list-style-type: none"> ▪ Wear your hardhat for protection from falling limbs and pinecones, and from tools and equipment carried by other crewmembers. ▪ Stay out of the woods during extremely high winds.
	3C) Chemical/Toxicological Hazards	3C) Chemical/Toxicological Hazards <ul style="list-style-type: none"> ▪ See HASP for appropriate level of PPE ▪ Use monitoring equipment, as outlined in HASP, to monitor breathing zone ▪ Read MSDSs for all chemicals brought to the site ▪ Be familiar with hazards associated with site contaminants. ▪ Ensure that all containers are properly labelled ▪ Decon thoroughly prior to consumption of food, beverage or tobacco.
	3D) Damage to eyes	3D) Protect eyes: <ul style="list-style-type: none"> ▪ Watch where you walk, especially around trees and brush with limbs sticking out. ▪ Exercise caution when clearing limbs from tree trunks. Advise wearing eye protection. ▪ Ultraviolet light from the sun can be damaging to the eyes; look for sunglasses that specify significant protection from UV-A and UV-B radiation. If safety glasses require, use one's with tinted lenses
	3E) Bee and wasp stings	3E) See JHA for Insect Stings and Bites
	3F) Ticks and infected mosquitos	3F) See JHA for Insect Stings and Bites
	3G) Wild Animals	3G) Wild Animals <ul style="list-style-type: none"> ▪ Avoid physical contact with wild animals ▪ Do not threaten and/or corner animals ▪ Make noise to get the animal to retreat. ▪ Stay in or return to vehicle/equipment if in danger

Job Hazard Analysis – HASP Format

Job Title: Field Work - General

Date of Analysis: 8/15/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	3H) Contact with poisonous plants or the oil from those plants:	3H) Contact with poisonous plants or the oil from those plants: <ul style="list-style-type: none"> ▪ Look for signs of poisonous plants and avoid. ▪ Ensure all field workers can identify the plants. Mark identified poisonous plants with spray paint if working at a fixed location. ▪ Do not allow plant to touch any part of your body/clothing. ▪ Wear PPE as described in the HASP and wear Tyveks, gloves and boot covers if contact with plant is likely ▪ Always wash gloves before removing them. ▪ Discard PPE in accordance with the HASP. ▪ Use commercially available products such as Ivy Block or Ivy Wash as appropriate.
		 <p style="text-align: center;"> POISON IVY <i>(Rhus toxicodendron L)</i> </p> <p style="text-align: center;"> POISON OAK <i>(Rhus diversiloba)</i> </p> <p style="text-align: center;"> POISON SUMAC <i>(Rhus toxicodendron vernix)</i> </p>
	3I) Back Injuries	3I) Back Injuries <ul style="list-style-type: none"> ▪ Site personnel will be instructed on proper lifting techniques. ▪ Mechanical devices should be used to reduce manual handling of materials. ▪ Split heavy loads in to smaller loads ▪ Team lifting should be utilized if mechanical devices are not available. ▪ Make sure that path is clear prior to lift.
	3J) Shoveling	3J) Shoveling <ul style="list-style-type: none"> ▪ Select the proper shovel for the task. A long handled, flat bladed shovel is recommend for loose material ▪ Inspect the handle for splinters and/or cracks ▪ Ensure that the blade is securely attached to the handle ▪ Never be more than 15 inches from the material you are shoveling ▪ Stand with your feet about hip width for balance and keep the shovel close to your body. ▪ Bend from the knees (not the back) and tighten your stomach muscles as you lift. ▪ Avoid twisting movements. If you need to move the snow to one side reposition your feet to face the direction the snow will be going. ▪ Avoid lifting large shoveling too much at once. When lifting heavy material, pick up less to reduce the weight lifted. ▪ Pace yourself to avoid getting out of breath and becoming fatigued too soon. ▪ Be alert for signs of stress such as pain, numbness, burning and tingling. Stop immediately if you feel any of these symptoms.
	3K) Slips/Trips/Falls	3K) Slips/Trips/Falls <ul style="list-style-type: none"> ▪ Maintain work areas safe and orderly; unloading areas should be on even terrain; mark or repair possible tripping hazards. ▪ Site SHSO inspect the entire work area to identify and mark hazards. ▪ Maintain three points of contact when climbing ladders or onto/off of equipment



Job Hazard Analysis – HASP Format

Job Title: Field Work - General

Date of Analysis: 8/15/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	3L) Overhead Hazards	3L) Overhead Hazards <ul style="list-style-type: none"> ▪ Personnel will be required to wear hard hats that meet ANSI Standard Z89.1. ▪ All ground personnel will stay clear of suspended loads. ▪ All equipment will be provided with guards, canopies or grills to protect the operator from falling or flying objects. ▪ All overhead hazards will be identified prior to commencing work operations.
	3M) Dropped Objects	3M) Dropped Objects <ul style="list-style-type: none"> ▪ Steel toe boots meeting ANSI Standard Z41 will be worn.
	3N) Noise	3N) Noise <ul style="list-style-type: none"> ▪ Hearing protection will be worn with a noise reduction rating capable of maintaining personal exposure below 85 dBA (ear muffs or plugs); all equipment will be equipped with manufacturer's required mufflers. Hearing protection shall be worn by all personnel working in or near heavy equipment.
	3O) Eye Injuries	3O) Eye Injuries <ul style="list-style-type: none"> ▪ Safety glasses meeting ANSI Standard Z87 will be worn.
	3P) Heavy Equipment (overhead hazards, spills, struck by or against)	3P) Heavy Equipment <ul style="list-style-type: none"> ▪ All operators will be trained and qualified to operate equipment ▪ Equipment will have seat belts. ▪ Operators will wear seat belts when operating equipment. ▪ Do not operate equipment on grades that exceed manufacturer's recommendations. ▪ Equipment will have guards, canopies or grills to protect from flying objects. ▪ Ground personnel will stay clear of all suspended loads. ▪ Personnel are prohibited from riding on the buckets, or elsewhere on the equipment except for designated seats with proper seat belts or lifts specifically designed to carry workers. ▪ Ground personnel will wear high visibility vests ▪ Spill and absorbent materials will be readily available. ▪ Drip pans, polyethylene sheeting or other means will be used for secondary containment. ▪ Ground personnel will stay out of the swing radius of excavators. ▪ Eye contact with operators will be made before approaching equipment. ▪ Operator will acknowledge eye contact by removing his hands from the controls. ▪ Equipment will not be approached on blind sides. ▪ All equipment will be equipped with backup alarms and use spotters when significant physical movement of equipment occurs on-site, (i.e., other than in place excavation or truck loading). ▪ Inspect rigging prior to each use.



Job Hazard Analysis – HASP Format

Job Title: Field Work - General

Date of Analysis: 8/15/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	3Q) Struck by vehicle/equipment	3Q) Struck by vehicle/equipment <ul style="list-style-type: none"> ▪ Be aware of heavy equipment operations. ▪ Keep out of the swing radius of heavy equipment. ▪ Ground personnel in the vicinity of vehicles or heavy equipment operations will be within the view of the operator at all times. ▪ Ground personnel will be aware of the counterweight swing and maintain an adequate buffer zone. ▪ Ground personnel will not stand directly behind heavy equipment when it is in operation. ▪ Drivers will keep workers on foot in their vision at all times, if you lose sight of someone, Stop! ▪ Spotters will be used when backing up trucks and heavy equipment and when moving equipment. ▪ High visibility vests will be worn when workers are exposed to vehicular traffic at the site or on public roads.
	3R) Struck/cut by tools	3R) Struck/cut by tools <ul style="list-style-type: none"> ▪ Cut resistant work gloves will be worn when dealing with sharp objects. ▪ All hand and power tools will be maintained in safe condition. ▪ Do not drop or throw tools. Tools shall be placed on the ground or worksurface or handed to another employee in a safe manner. ▪ Guards will be kept in place while using hand and power tools.
	3S) Caught in/on/between	3S) Caught in/on/between <ul style="list-style-type: none"> ▪ Workers will not position themselves between equipment and a stationary object. ▪ Workers will not wear long hair down (place in pony-tail and tuck into shirt) or jewelry if working with tools/machinery.
	3T) Contact with Electricity/Lightning	3T) Contact with Electricity/Lighting <ul style="list-style-type: none"> ▪ All electrical tools and equipment will be equipped with GFCI. ▪ Electrical extension cords will be of the "Hard" or "Extra Hard" service type. ▪ All extension cords shall have a three-blade grounding plug. ▪ Personnel shall not use extension cords with damaged outer covers, exposed inner wires, or splices. ▪ Electrical cords shall not be laid across roads where vehicular traffic may damage the cord without appropriate guarding. ▪ All electrical work will be conducted by a licensed electrician. ▪ All equipment will be locked out and tagged out and rendered in a zero energy state prior to commencing any operation that may exposed workers to electrical, mechanical, hydraulic, etc. hazards. ▪ All utilities will be marked prior to excavation activities. ▪ All equipment will stay a minimum of 10 feet from overhead energized electrical lines (50 kV). This distance will increase by 4 inches for each 10 kV above 50 kV. Rule of Thumb: Stay 10 feet away from all overhead powerlines known to be 50 kV or less and 35 feet from all others.) ▪ The SHSO shall halt outdoor site operations whenever lightning is visible, outdoor work will not resume until 30 minutes after the last sighting of lightning.
	3U) Equipment failure	3U) Equipment failure <ul style="list-style-type: none"> ▪ All equipment will be inspected before use. If any safety problems are noted, the equipment should be tagged and removed from service until repaired or replaced.

Job Hazard Analysis – HASP Format

Job Title: Field Work - General

Date of Analysis: 8/15/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	3V) Hand & power tool usage.	3V) Hand & power tool usage <ul style="list-style-type: none"> ▪ Daily inspections will be performed. ▪ Ensure guards are in place and are in good condition. ▪ Remove broken or damaged tools from service. ▪ Use the tool for its intended purpose. ▪ Use in accordance with manufacturers instructions. ▪ No tampering with electrical equipment is allowed (e.g., splicing cords, cutting the grounding prong off plug, etc.) ▪ See JHA for Power Tool Use - Electrical and Power Tool Use - Gasoline
	3W) Fire Protection	3W) Fire Protection <ul style="list-style-type: none"> ▪ Ensure that adequate number and type of fire extinguishers are present at the site ▪ Inspect fire extinguishers on a monthly basis – document ▪ All employees who are expected to use fire extinguishers will have received training on an annual basis. ▪ Obey no-smoking policy ▪ Open fires are prohibited ▪ Maintain good housekeeping. Keep rubbish and combustibles to a minimum. ▪ Keep flammable liquids in small containers with lids closed or a safety can. ▪ When dispensing flammable liquids, do in well vented area and bond and ground containers.
	3X) Confined Space Entry	3X) Confined Space Entry <ul style="list-style-type: none"> ▪ See JHA for Confined Space Entry
4. Environmental health considerations	4A) Heat Stress	4A) Take precautions to prevent heat stress <ul style="list-style-type: none"> ▪ Remain constantly aware of the four basic factors that determine the degree of heat stress (air temperature, humidity, air movement, and heat radiation) relative to the surrounding work environmental heat load. ▪ Know the signs and symptoms of heat exhaustion, heat cramps, and heat stroke. Heat stroke is a true medical emergency requiring immediate emergency response action. <p>NOTE: The severity of the effects of a given environmental heat stress is decreased by reducing the work load, increasing the frequency and/or duration of rest periods, and by introducing measures which will protect employees from hot environments.</p> <ul style="list-style-type: none"> ▪ Maintain adequate water intake by drinking water periodically in small amounts throughout the day (flavoring water with citrus flavors or extracts enhances palatability). ▪ Allow approximately 2 weeks with progressive degrees of heat exposure and physical exertion for substantial acclimatization. ▪ Acclimatization is necessary regardless of an employee's physical condition (the better one's physical condition, the quicker the acclimatization). Tailor the work schedule to fit the climate, the physical condition of employees, and mission requirements. <ul style="list-style-type: none"> ▪ A reduction of work load markedly decreases total heat stress. ▪ Lessen work load and/or duration of physical exertion the first days of heat exposure to allow gradual acclimatization. ▪ Alternate work and rest periods. More severe conditions may require longer rest periods and electrolyte fluid replacement.

Job Hazard Analysis – HASP Format

Job Title: Field Work - General

Date of Analysis: 8/15/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices						
	4B) Wet Bulb Globe Temperature (WBGT) Index	4B) WBGT <ul style="list-style-type: none"> ▪ Curtail or suspend physical work when conditions are extremely severe (see attached Heat Stress Index). ▪ Compute a Wet Bulb Globe Temperature Index to determine the level of physical activity (take WBGT index measurements in a location that is similar or closely approximates the environment to which employees will be exposed). <p style="text-align: center;">WBGT THRESHOLD VALUES FOR INSTITUTING PREVENTIVE MEASURES</p> <table style="width: 100%; border: none;"> <tr> <td style="width: 30%;">80-90 degrees F</td> <td>Fatigue possible with prolonged exposure and physical activity.</td> </tr> <tr> <td>90-105 degrees F</td> <td>Heat exhaustion and heat stroke possible with prolonged exposure and physical activity.</td> </tr> <tr> <td>105-130 degrees F</td> <td>Heat exhaustion and heat stroke are likely with prolonged heat exposure and physical activity.</td> </tr> </table>	80-90 degrees F	Fatigue possible with prolonged exposure and physical activity.	90-105 degrees F	Heat exhaustion and heat stroke possible with prolonged exposure and physical activity.	105-130 degrees F	Heat exhaustion and heat stroke are likely with prolonged heat exposure and physical activity.
80-90 degrees F	Fatigue possible with prolonged exposure and physical activity.							
90-105 degrees F	Heat exhaustion and heat stroke possible with prolonged exposure and physical activity.							
105-130 degrees F	Heat exhaustion and heat stroke are likely with prolonged heat exposure and physical activity.							
	4C) Cold Extremes	4C) Take precautions to prevent cold stress injuries <ul style="list-style-type: none"> ▪ Cover all exposed skin and be aware of frostbite. While cold air will not freeze the tissues of the lungs, slow down and use a mask or scarf to minimize the effect of cold air on air passages. ▪ Dress in layers with wicking garments (those that carry moisture away from the body – e.g., cotton) and a weatherproof slicker. A wool outer garment is recommended. ▪ Take layers off as you heat up; put them on as you cool down. ▪ Wear head protection that provides adequate insulation and protects the ears. ▪ Maintain your energy level. Avoid exhaustion and over-exertion which causes sweating, dampens clothing, and accelerates loss of body heat and increases the potential for hypothermia. ▪ Acclimate to the cold climate to minimize discomfort. ▪ Maintain adequate water/fluid intake to avoid dehydration. 						
	4D) Wind	4D) Effects of the wind <ul style="list-style-type: none"> ▪ Wind chill greatly affects heat loss (see attached Wind Chill Index). ▪ Avoid marking in old, defective timber, especially hardwoods, during periods of high winds due to snag hazards. 						
	4E) Thunderstorms	4E) Thunderstorms <ul style="list-style-type: none"> ▪ Monitor weather channels to determine if electrical storms are forecasted. ▪ Plan ahead and identify safe locations to be in the event of a storm. (e.g., sturdy building, vehicle, etc.) ▪ Suspend all field work at the first sound of thunder. You should be in a safe place when the time between the lightning and thunder is less than 30 seconds. ▪ Only return to work 30 minutes after the last strike or sound of thunder 						

Relative Humidity (%) furnished by National Weather Service Gray, ME

Air Temperature °F	Relative Humidity (%)													
	40	45	50	55	60	65	70	75	80	85	90	95	100	
110	136													
108	130	137												
106	124	130	137											
104	119	124	131	137										
102	114	119	124	130	137									
100	109	114	118	124	129	136								
98	105	109	113	117	123	128	134							
96	101	104	108	112	116	121	126	132						
94	97	100	103	106	110	114	119	124	129	135				
92	94	96	99	101	105	108	112	116	121	126	131			
90	91	93	95	97	100	103	106	109	113	117	122	127	132	
88	88	89	91	93	95	98	100	103	106	110	113	117	121	
86	85	87	88	89	91	93	95	97	100	102	105	108	112	
84	83	84	85	86	88	89	90	92	94	96	98	100	103	
82	81	82	83	84	84	85	86	88	89	90	91	93	95	
80	80	80	81	81	82	82	83	84	84	85	86	86	87	

Heat Index
(Apparent
Temperature)

**With Prolonged Exposure
and/or Physical Activity**

Extreme Danger
Heat stroke or sunstroke highly likely
Danger
Sunstroke, muscle cramps, and/or heat exhaustion likely
Extreme Caution
Sunstroke, muscle cramps, and/or heat exhaustion possible
Caution
Fatigue possible



Wind Chill Chart



Temperature (°F)

Wind (mph)	Calm	40	35	30	25	20	15	10	5	0	-5	-10	-15	-20	-25	-30	-35	-40	-45
5		36	31	25	19	13	7	1	-5	-11	-16	-22	-28	-34	-40	-46	-52	-57	-63
10		34	27	21	15	9	3	-4	-10	-16	-22	-28	-35	-41	-47	-53	-59	-66	-72
15		32	25	19	13	6	0	-7	-13	-19	-26	-32	-39	-45	-51	-58	-64	-71	-77
20		30	24	17	11	4	-2	-9	-15	-22	-29	-35	-42	-48	-55	-61	-68	-74	-81
25		29	23	16	9	3	-4	-11	-17	-24	-31	-37	-44	-51	-58	-64	-71	-78	-84
30		28	22	15	8	1	-5	-12	-19	-26	-33	-39	-46	-53	-60	-67	-73	-80	-87
35		28	21	14	7	0	-7	-14	-21	-27	-34	-41	-48	-55	-62	-69	-76	-82	-89
40		27	20	13	6	-1	-8	-15	-22	-29	-36	-43	-50	-57	-64	-71	-78	-84	-91
45		26	19	12	5	-2	-9	-16	-23	-30	-37	-44	-51	-58	-65	-72	-79	-86	-93
50		26	19	12	4	-3	-10	-17	-24	-31	-38	-45	-52	-60	-67	-74	-81	-88	-95
55		25	18	11	4	-3	-11	-18	-25	-32	-39	-46	-54	-61	-68	-75	-82	-89	-97
60		25	17	10	3	-4	-11	-19	-26	-33	-40	-48	-55	-62	-69	-76	-84	-91	-98

Frostbite Times

30 minutes

10 minutes

5 minutes

$$\text{Wind Chill (°F)} = 35.74 + 0.6215T - 35.75(V^{0.16}) + 0.4275T(V^{0.16})$$

Where, T= Air Temperature (°F) V= Wind Speed (mph)

Effective 11/01/01



Job Hazard Analysis - HASP Format

Job Title: Groundwater Sampling

Date of Analysis: 9/21/06

Minimum Recommended PPE*: steel-toed boots, safety glasses, chemical resistant gloves

*See HASP for all required PPE

Key Work Steps	Hazards/Potential Hazards	Safe Practices
1. Mobilization	3A) See JHA Mobilization/Demobilization/Site Preparation	1A) See JHA Mobilization/Demobilization/Site Preparation
2. General Site Hazards	2A) See JHA Field Work - General	2A) See JHA Field Work - General
	2B) Chemical exposure	2B) Chemical Exposure <ul style="list-style-type: none"> ▪ Read HASP and determine air monitoring and PPE needs.
3. Calibrate monitoring equipment	4A) Exposure to calibration gases	4A) Exposure to calibration gases <ul style="list-style-type: none"> ▪ Review equipment manuals ▪ Calibrate in a clean, well ventilated area
4. Opening the well cap, taking water level readings	5A) Contact with poisonous plants or the oil from poisonous plants	5A) Contact with poisonous plants or the oil from those plants: <ul style="list-style-type: none"> ▪ Look for signs of poisonous plants and avoid. ▪ Ensure all field workers can identify the plants. Mark identified poisonous plants with spray paint if working at a fixed location. ▪ Wear PPE as described in the HASP. ▪ Do not touch any part of your body/clothing. ▪ Always wash gloves before removing them. ▪ Discard PPE in accordance with the HASP. ▪ Use commercially available products such as Ivy Block or Ivy Wash as appropriate.
	5B) Contact with biting insects (i.e., spiders, bees, etc.) which may have constructed a nest in the well cap/well.	5B) Contact with stinging/biting insects <ul style="list-style-type: none"> ▪ Discuss the types of insects expected at the Site and be able to identify them. ▪ Look for signs of insects in and around the well. ▪ Wear Level of PPE as described in the HASP. At a minimum, follow guidelines in the JHA "Insects Stings and Bites." ▪ If necessary, wear protective netting over your head/face. ▪ Avoid contact with the insects if possible. ▪ Inform your supervisor and the Site Health and Safety Supervisor if you have any allergies to insects and insect bites. Make sure you have identification of your allergies with you at all times and appropriate response kits if applicable. ▪ Get medical help immediately if you are bitten by a black widow or brown recluse, or if you have a severe reaction to any spider bite or bee sting.
	5C) Exposure to hazardous Inhalation and contact with hazardous substances (VOC contaminated groundwater/ soil); liquid splash; flammable atmospheres.	5C) Exposure to hazardous substances <ul style="list-style-type: none"> ▪ Wear PPE as identified in HASP. ▪ Review hazardous properties of site contaminants with workers before sampling operations begin ▪ Immediately monitor breathing zone after opening well to determine exposure and verify that level of PPE is adequate – see Action Levels in HASP ▪ Monitor headspace in well. After the initial headspace reading (if required by the Work Plan), allow the well to vent for several minutes before obtaining water level and before sampling. ▪ When decontaminating equipment wear additional eye/face protection over the safety glasses such as a face shield.
	5D) Back strain due to lifting bailers or pumps and from moving equipment to well locations	5D) Back strain <ul style="list-style-type: none"> ▪ Use mechanical aids when possible, if mechanical aids are not available, use two person lifts for heavy items. ▪ Use proper lifting techniques

Job Hazard Analysis - HASP Format

Job Title: Groundwater Sampling

Date of Analysis: 9/21/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	5E) Foot injuries from dropped equipment	5E) Foot Injuries <ul style="list-style-type: none"> ▪ Be aware when moving objects, ensure you have a good grip when lifting and carrying objects. ▪ Do not carry more than you can handle safely ▪ Wear Steel toed boots
5. Collecting water samples	6A) Fire/Explosion/Contamination hazard from refueling generators	6A) Fire/Explosion/Contamination hazard from refueling generators <ul style="list-style-type: none"> ▪ Turn the generator off and let it cool down before refueling ▪ Segregate fuel and other hydrocarbons from samples to minimize contamination potential ▪ Transport fuels in approved safety containers. The use of containers other than those specifically designed to carry fuel is prohibited ▪ See JHA for Gasoline use
	6B) Electrocutation	6B) Electrocutation <ul style="list-style-type: none"> ▪ A ground fault circuit interrupter (GFCI) device must protect all AC electrical circuits. ▪ Use only correctly grounded equipment. Never use three-pronged cords which have had the third prong broken off. ▪ Make sure that the electrical cords from generators and power tools are not allowed to be in contact with water ▪ Do not stand in wet areas while operating power equipment ▪ Always make sure all electrically-powered sampling equipment is in good repair. Report any problems so the equipment can be repaired or replaced. ▪ When unplugging a cord, pull on the plug rather than the cord. ▪ Never do repairs on electrical equipment unless you are both authorized and qualified to do so.
	6C) Exposure to contaminants	6C) Exposure to Contaminants <ul style="list-style-type: none"> ▪ Stand up wind when sampling ▪ Monitor breathing zone with appropriate monitoring equipment (see HASP) ▪ Wear chemical resistant PPE as identified in HASP ▪ See section 4C) under Safe Practices above
	6D) Infectious water born diseases	6D) Infectious water born diseases <ul style="list-style-type: none"> ▪ Wear chemical resistant gloves and other PPE – as identified in HASP ▪ Prevent water from contacting skin ▪ Wash exposed skin with soap and water ASAP after sampling event ▪ Ensure that all equipment is adequately decontaminated using a 10% bleach solution
	6E) Exposure to water preservatives	6E) Exposure to water preservatives <ul style="list-style-type: none"> ▪ Work in a well ventilated area, upwind of samples ▪ Wear chemical resistant PPE as identified in HASP ▪ When preserving samples always add acid to water, avoid the opposite. ▪ See JHA Acids - Sampling
	6F) Slips/trips/falls	6F) Slips/trips/falls <ul style="list-style-type: none"> ▪ Ground can become wet/muddy, created by spilled water ▪ Place all purged water in drums for removal ▪ Wear good slip resistant footwear
	6G) Repetitive Motion and other Ergonomic Issues	6G) Ergonomic Issues <ul style="list-style-type: none"> ▪ Use mechanical means where possible to raise and lower equipment into well. ▪ Alternate raising and lowering equipment between field sampling team members, and alternate bailing the well. ▪ Use safe lifting techniques.



Job Hazard Analysis - HASP Format

Job Title: Groundwater Sampling

Date of Analysis: 9/21/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
6. Sample Processing	7A) Contaminated water	7A) Contaminated water <ul style="list-style-type: none">▪ Wear appropriate PPE as identified in HASP▪ Decontaminate outside of bottles▪ Prevent water from contacting skin▪ Work in well ventilated area – upwind of samples▪ Waste will be returned to the operation office for storage and disposal
7. Shipping Samples	8A) Freeze burns, back strain, hazardous chemical exposure, sample leakage	8A) Freeze burns, back strain, hazardous chemical exposure, sample leakage <ul style="list-style-type: none">▪ Wear appropriate chemical resistant gloves as identified in HASP.▪ Wear leather or insulated gloves when handling dry ice.▪ Follow safe lifting techniques – get help lifting heavy coolers.▪ Samples that contain hazardous materials under the DOT definition, must be packaged, manifested and shipped by personnel that have the appropriate DOT HAZMAT training.



Job Hazard Analysis – HASP Format

Job Title: Mobilization/Demobilization and Site Preparation

Date of Analysis: 8/15/06

Minimum Recommended PPE*: High visibility vest, hard hat, steel-toed boots, safety glasses, hearing protection

*See HASP for all required PPE

Key Work Steps	Hazards/Potential Hazards	Safe Practices
1. Prepare for Site Visit	1A) N/A	1A) Prior to leaving for site <ul style="list-style-type: none"> ▪ Obtain and review HASP prior to site visit, if possible ▪ Determine PPE needs – bring required PPE to the site, if not otherwise being provided at the site (e.g., steel toed boots) ▪ Determine training and medical monitoring needs and ensure all required Health and Safety training and medical monitoring has been received and is current ▪ Ensure all workers are fit for duty (alert, well rested, and mentally and physically fit to perform work assignment) ▪ If respiratory protection is required/potentially required, ensure that training and fit-testing has occurred within the past year. ▪ Familiarize yourself with route to the site
	1B) Vehicle defects	1B) Inspect company owned/leased vehicle for defects such as: <ul style="list-style-type: none"> ▪ Flat tires ▪ Windshield wipers worn or torn ▪ Oil puddles under vehicle ▪ Headlights, brake lights, turn signals not working
	1C) Insufficient emergency equipment, unsecured loads	1C) Insufficient emergency equipment, unsecured loads <ul style="list-style-type: none"> ▪ Ensure vehicle has first aid kit and that all medications are current (if first aid kits are not provided at the site) ▪ Ensure vehicle is equipped with warning flashers and/or flares and that the warning flashers work ▪ Cell phones are recommended to call for help in the event of an emergency ▪ Vehicles carrying tools must have a safety cage in place. All tools must be properly secured ▪ Vehicles must be equipped with chocks if the vehicle is to be left running, unattended. ▪ Ensure sufficient gasoline is in the tank
2. Operating vehicles – general	2A) Collisions, unsafe driving conditions	2A) Drive Defensively! <ul style="list-style-type: none"> ▪ Seat belts must be used at all times when operating any vehicle on company business. ▪ Drive at safe speed for road conditions ▪ Maintain adequate following distance ▪ Pull over and stop if you have to look at a map ▪ Try to park so that you don't have to back up to leave. ▪ If backing in required, walk around vehicle to identify any hazards (especially low level hazards that may be difficult to see when in the vehicle) that might be present. Use a spotter if necessary
3. Driving to the jobsite	3A) Dusty, winding, narrow roads	3A) Dusty, winding, narrow roads <ul style="list-style-type: none"> ▪ Drive confidently and defensively at all times. ▪ Go slow around corners, occasionally clearing the windshield.
	3B) Rocky or one-lane roads	3B) Rocky or one-lane roads <ul style="list-style-type: none"> ▪ Stay clear of gullies and trenches, drive slowly over rocks. ▪ Yield right-of-way to oncoming vehicles---find a safe place to pull over.
	3C) Stormy weather, near confused tourists	3C) Stormy weather, near confused tourists <ul style="list-style-type: none"> ▪ Inquire about conditions before leaving the office. ▪ Be aware of oncoming storms. ▪ Drive to avoid accident situations created by the mistakes of others.



Job Hazard Analysis – HASP Format

Job Title: Mobilization/Demobilization and Site Preparation

Date of Analysis: 8/15/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	3D) When angry or irritated	3D) When angry or irritated <ul style="list-style-type: none"> ▪ Attitude adjustment; change the subject or work out the problem before driving the vehicle. Let someone else drive.
	3E) Turning around on narrow roads	3E) Turning around on narrow roads <ul style="list-style-type: none"> ▪ Safely turn out with as much room as possible. ▪ Know what is ahead and behind the vehicle. ▪ Use a backer if available.
	3F) Sick or medicated	3F) Sick or medicated <ul style="list-style-type: none"> ▪ Let others on the crew know you do not feel well. ▪ Let someone else drive.
	3G) On wet or slimy roads	3G) On wet or slimy roads <ul style="list-style-type: none"> ▪ Drive slow and safe, wear seatbelts.
	3H) Animals on road	3H) Animals on road <ul style="list-style-type: none"> ▪ Drive slowly, watch for other animals nearby. ▪ Be alert for animals darting out of wooded areas
4. Gain permission to enter site	4A) Hostile landowner, livestock, pets	4A) Hostile landowner, livestock, pets <ul style="list-style-type: none"> ▪ Talk to land owner, be courteous and diplomatic ▪ Ensure all animals have been secured away from work area
5. Mobilization/ Demobilization of Equipment and Supplies	5A) Struck by Heavy Equipment/Vehicles	5A) Struck by heavy equipment <ul style="list-style-type: none"> ▪ Be aware of heavy equipment operations. ▪ Keep out of the swing radius of heavy equipment. ▪ Ground personnel in the vicinity of heavy equipment operations will be within the view of the operator at all times ▪ Employees shall wear a high visibility vest or T-shirt (reflective vest required if working at night). ▪ Ground personnel will be aware of the counterweight swing and maintain an adequate buffer zone. ▪ Ground personnel will not stand directly behind heavy equipment when it is in operation.
	5B) Struck by Equipment/Supplies	5B) Struck by Equipment/Supplies <ul style="list-style-type: none"> ▪ Workers will maintain proper space around their work area, if someone enters it, stop work. ▪ When entering another worker's work space, give a verbal warning so they know you are there.
	5C) Overexertion Unloading/Loading Supplies	5C) Overexertion Unloading/Loading Supplies <ul style="list-style-type: none"> ▪ Train workers on proper body mechanics, do not bend or twist at the waist while exerting force or lifting. ▪ Tightly secure all loads to the truck bed to avoid load shifting while in transit.
	5D) Caught in/on/between	5D) Caught in/on/between <ul style="list-style-type: none"> ▪ Do not place yourself between two vehicles or between a vehicle and a fixed object.
	5E) Slip/Trip/Fall	5E) 1E). Slip/Trip/Fall <ul style="list-style-type: none"> ▪ Mark all holes and low spots in area with banner tape. Instruct personnel to avoid these areas. ▪ Drivers will maintain 3 point contact when mounting/dismounting vehicles/equipment. ▪ Drivers will check surface before stepping, not jumping down.



Job Hazard Analysis – HASP Format

Job Title: Mobilization/Demobilization and Site Preparation

Date of Analysis: 8/15/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	5F) Vehicle accident	5F) Vehicle accident <ul style="list-style-type: none"> ▪ Employees should follow MACTEC vehicle operation policy and be aware of all stationary and mobile vehicles.
6. Site Preparation	6A) Slip/Trip/Fall	6A) Slip/Trip/Fall <ul style="list-style-type: none"> ▪ Mark all holes and low spots in area with banner tape. Instruct personnel to avoid these areas
7. Installation of soil erosion and sediment controls	7A) Overexertion	7A) Overexertion <ul style="list-style-type: none"> ▪ Workers will be trained in the proper method of placing erosion controls. ▪ Do not bend and twist at the waist while lifting or exerting force.
	7B) Struck by Equipment/Supplies	7C) Struck by Equipment/Supplies <ul style="list-style-type: none"> ▪ Workers will maintain proper space around their work area, if someone enters it, stop work. ▪ When entering another worker's work space, give a verbal warning so they know you are there.
8. Driving back from the jobsite	8A) See hazards listed under item #3	8A) See safe work practices under item #3



Job Hazard Analysis - HASP Format

Job Title: Soil Sampling

Date of Analysis: 4/25/06

Minimum Recommended PPE*: High visibility vest, hard hat, steel-toed boots, safety glasses, hearing protection

*See HASP for all required PPE

Key Work Steps	Hazards/Potential Hazards	Safe Practices
1. Prepare for sampling event	1A) Chemical exposure	1A) Chemical Exposure <ul style="list-style-type: none"> ▪ Read HASP and determine air monitoring and PPE needs.
2. Carrying equipment to site location	2A) Back or muscle strain	2A) Back or muscle strain <ul style="list-style-type: none"> ▪ Use proper lifting techniques when lifting pumps or generators ▪ Use mechanical aids if available ▪ Use 2 person lift for heavy items
3. Calibrate monitoring equipment	1A) Exposure to calibration gases	3A) Exposure to calibration gases <ul style="list-style-type: none"> ▪ Review equipment manuals ▪ Calibrate in a clean, well ventilated area
4. Preparing sampling location	4A) Contact with poisonous plants or the oil from poisonous plants	4A) Contact with poisonous plants or the oil from those plants: <ul style="list-style-type: none"> ▪ Look for signs of poisonous plants and avoid. ▪ Wear PPE as described in the HASP. ▪ Do not touch anything part of your body/clothing. ▪ Always wash gloves before removing them. ▪ Discard PPE in accordance with the HASP.
	4B) Contact with biting insects (i.e., spiders, bees, etc.)	4B) Contact with stinging/biting insects <ul style="list-style-type: none"> ▪ Discuss the types of insects expected at the Site and be able to identify them. ▪ Look for signs of insects in and around the well. ▪ Wear Level of PPE as described in the HASP. At a minimum, follow guidelines in the JHA "Insects Stings and Bites." ▪ If necessary, wear protective netting over your head/face. ▪ Avoid contact with the insects if possible. ▪ Inform your supervisor and the Site Health and Safety Supervisor if you have any allergies to insects and insect bites. Make sure you have identification of your allergies with you at all times and appropriate response kits if applicable. ▪ Get medical help immediately if you are bitten by a black widow or brown recluse, or if you have a severe reaction to any spider bite or bee sting.
	4C) Exposure to hazardous Inhalation and contact with hazardous substances (VOC contaminated soil); flammable atmospheres.	4C) Exposure to hazardous substances <ul style="list-style-type: none"> ▪ Wear PPE as identified in HASP. ▪ Review hazardous properties of site contaminants with workers before sampling operations begin ▪ Monitor breathing zone air in accordance with HASP to determine levels of contaminants present. ▪ When decontaminating equipment wear additional eye/face protection over the safety glasses such as a face shield.
	4D) Back strain due to lifting or moving equipment to sampling locations	4D) Back strain <ul style="list-style-type: none"> ▪ Use mechanical aids when possible, if mechanical aids are not available, use two person lifts for heavy items. ▪ Use proper lifting techniques
	4E) Foot injuries from dropped equipment	4E) Foot Injuries <ul style="list-style-type: none"> ▪ Be aware when moving objects, ensure you have a good grip when lifting and carrying objects. ▪ Do not carry more than you can handle safely ▪ Wear steel toed boots

Job Hazard Analysis - HASP Format

Job Title: Soil Sampling

Date of Analysis: 4/25/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
5. Collecting soil samples	5A) Working around drill rigs	5A) See JHA - Drilling
	5B) Encountering underground or overhead utilities	5B) Have all utilities located.
	5C) Fire/Explosion/Contamination hazard from refueling generators	5C) Fire/Explosion/Contamination hazard from refueling generators <ul style="list-style-type: none"> ▪ Turn the generator off and let it cool down before refueling ▪ Segregate fuel and other hydrocarbons from samples to minimize contamination potential ▪ Transport fuels in approved safety containers. The use of containers other than those specifically designed to carry fuel is prohibited ▪ See JHA for Gasoline use
	5D) Electrocutation	5D) Electrocutation <ul style="list-style-type: none"> ▪ A ground fault circuit interrupter (GFCI) device must protect all AC electrical circuits. ▪ Use only correctly grounded equipment. Never use three-pronged cords which have had the third prong broken off. ▪ Make sure that the electrical cords from generators and power tools are not allowed to be in contact with water ▪ Do not stand in wet areas while operating power equipment ▪ Always make sure all electrically-powered sampling equipment is in good repair. Report any problems so the equipment can be repaired or replaced. ▪ When unplugging a cord, pull on the plug rather than the cord. ▪ Never do repairs on electrical equipment unless you are both authorized and qualified to do so.
	5E) Exposure to contaminants	5E) Exposure to Contaminants <ul style="list-style-type: none"> ▪ Stand up wind when sampling ▪ Monitor breathing zone with appropriate monitoring equipment (see HASP) ▪ Wear chemical resistant PPE as identified in HASP ▪ See section 4C) under Safe Practices above
	5F) Exposure to preservatives	5F) Exposure to preservatives <ul style="list-style-type: none"> ▪ Work in a well ventilated area, upwind of samples ▪ Wear chemical resistant PPE as identified in HASP ▪ Review MSDSs
	5G) Slips/trips/falls	5G) Slips/trips/falls <ul style="list-style-type: none"> ▪ Ground can become wet/muddy ▪ Wear good slip resistant footwear
	5H) Lifting Injury	5H) Lifting injury <ul style="list-style-type: none"> ▪ Use proper lifting techniques when carrying quantities of samples ▪ Use proper ergonomics when hand digging for samples
	5I) Eye injury	5I) Eye Injury <ul style="list-style-type: none"> ▪ Wear eye protection when using picks or similar devices to loosen soil



Job Hazard Analysis - HASP Format

Job Title: Soil Sampling

Date of Analysis: 4/25/06

Key Work Steps	Hazards/Potential Hazards	Safe Practices
	5J) Fire	5J) Fire <ul style="list-style-type: none"> ▪ When using gas powered auger, maintain fire watch whenever fueling or otherwise handling gasoline ▪ See JHA - Gasoline
6. Soil sampling using floor corer	6A) Back injury	6A) Back Injury <ul style="list-style-type: none"> ▪ Use proper lifting techniques when moving floor corer and generator ▪ Use mechanical aids if available ▪ Use two person lift for heavy items.
	6B) Electric Shock	6B) Electric Shock <ul style="list-style-type: none"> ▪ Use electric cords free from defects ▪ Keep cords out of water ▪ Ensure all electrical equipment is properly grounded ▪ Use GFCI
	6C) Hearing	6C) Hearing <ul style="list-style-type: none"> ▪ Wear hearing protection
	6D) Fire	6D) Fire <ul style="list-style-type: none"> ▪ When using generator, maintain fire watch whenever refueling or otherwise handling gasoline ▪ See JHA - Gasoline
	6E) Contamination	6E) Contamination <ul style="list-style-type: none"> ▪ Use appropriate PPE for the contaminants of concern (see HASP). ▪ Minimize sample contact ▪ Label sample in accordance with procedures ▪ Monitor breathing zone levels.



Job Hazard Analysis - HASP Format

Job Title: Working with Preservatives (Acids)

Date of Analysis: 5/30/06


Minimum Recommended PPE*: Safety glasses/goggles, nitrile gloves,

*See HASP for all required PPE

Key Work Steps	Hazards/Potential Hazards	Safe Practices
1. Opening the box of ampoules	1A) Cuts or punctures with a knife	1A) Cuts or punctures with a knife <ul style="list-style-type: none"> ▪ Use appropriate techniques when handling a knife. Always cut away from you.
	1B) Broken ampoules in the box. Cuts from the broken glass.	1B) Broken ampoules in the box. Cuts from the broken glass. <ul style="list-style-type: none"> ▪ Wear safety goggles and protective gloves. ▪ Dispose of the preservative and broken glass by approved methods.
	1C) Broken ampoules in the box. Breathing fumes.	1C) Broken ampoules in the box. Breathing fumes. <ul style="list-style-type: none"> ▪ Wear safety goggles and protective gloves. ▪ Always work in a well-ventilated area.
2. Breaking top of glass ampoule	2A) Cuts from the broken glass.	2A) Cuts from the broken glass <ul style="list-style-type: none"> ▪ Wear safety goggles and protective gloves. ▪ Use a paper towel to wrap ampoule in to snap the top or use an ampoule breaker. ▪ Always point the ampoule away from you when you snap off the top.
	2B) Skin contact chemical burns.	2B) Skin contact chemical burns. <ul style="list-style-type: none"> ▪ Wear safety goggles and protective gloves. ▪ Fumes may come into contact with the perspiration on your skin and rehydrate to form an acid. ▪ If your skin itches, flush affected area for 15 minutes with water.
	2C) Eye contact	2C) Eye contact <ul style="list-style-type: none"> ▪ Wear safety goggles. ▪ If acid splashes in the eyes, flush eyes for 15 minutes with water. Seek medical advice.
	2D) Breathing fumes	2D) Breathing fumes <ul style="list-style-type: none"> ▪ HNO₃ and HCL have high vapor pressure. Always work in a well-ventilated area.
	3A) Chemical reaction	3A) Chemical reaction <ul style="list-style-type: none"> ▪ Wear safety goggles and protective gloves. Acid may react with high alkaline sample and fizz (releases CO₂).
3. Adding acid to sample	3B) Eye contact	3B) Eye contact <ul style="list-style-type: none"> ▪ Wear safety goggles. ▪ If acid splashes in the eyes, flush eyes for 15 minutes with water. Seek medical advice.
	3C) Skin contact chemical burns.	3C) Skin contact chemical burns. <ul style="list-style-type: none"> ▪ Wear safety goggles and protective gloves.
	4A) Cuts from the broken glass.	4A) Cuts from the broken glass. <ul style="list-style-type: none"> ▪ Wear safety goggles and protective gloves. ▪ Place used ampoules in an empty, non-reactive container in the field and bring it back to the office. Dispose of the preservative and broken glass by approved methods.

ATTACHMENT A

CONTAMINANT FACT SHEET


 <p>CONTAMINANT FACT SHEET</p> <p>Chemical Name: <u>1,2-Dichloroethylene 156-59-2</u> CAS Number: <u>540-59-0, 156-60-5</u> Synonyms: <u>Acetylene dichloride,</u> <u>cis -Acetylene dichloride,</u> <u>trans-Acetylene dichloride.</u></p>					HEALTH HAZARD DATA								
					Color: <u>Colorless</u>	Physical State: Solid _____ Liquid <u>X</u> Gas _____	Odor: <u>Chloroform-like</u>	Odor Threshold: <u>0.08-17 ppm</u>	Vapor Density: <u>3.35 g/L</u>	Ionization Potential (IP): <u>9.65 eV</u>	IDLH: <u>1000 ppm</u>	Carcinogen: OSHA _____ IARC _____ NTP _____ ACGIH _____ NIOSH _____	Skin absorbable: yes ___ no <u>X</u> Skin corrosive: yes ___ no <u>X</u>
										OSHA PELs	200 ppm		
										ACGIH TLVs	200 ppm		
										NIOSH RELs	200 ppm		
AIR MONITORING					PERSONAL PROTECTIVE EQUIPMENT					FIRE/REACTIVITY DATA			
Type	Brand/Model No.	Calibrations Method/Media	Relative Response or Conversion Factor	Meter Specific Action Level	Recommended Protective Clothing Materials: Suits <u>Teflon, Viton, PE/EVAL,</u> <u>Barricade, CPF3, Tychem</u> <u>Responder</u> Gloves <u>Viton, Teflon, Polyvinyl Alcohol</u> <u>(do not use in water)</u> Boots <u>Teflon, Viton</u> _____ _____ Service Limit Concentration (ppm): <u>1000</u> MUC 1/2 Mask APR = TWA x 10 = <u>1000 ppm</u> MUC Full-Face APR = TWA x 10 = <u>1000 ppm</u>					Flash Point: <u>36-39 ° F</u>			
PID	Microtip 10.6eV	Isobutylene 100 ppm	1.45	290						LEL/UEL: <u>5.6% / 12.8%</u>			
										Fire Extinguishing Media:			
										Dry Chemical <u>X</u> Foam <u>X</u> Water Spray <u>X</u> CO ₂ <u>X</u>			
										Incompatibilities: <u>Strong oxidizers, strong alkalis, potassium hydroxide, copper</u>			
Checked by: <u>Emmet F. Curtis</u>					Date: <u>12/5/03</u>								

2003 by MACTEC Engineering & Consulting, Inc.

Note: The recommended protective clothing materials assumes that potential for direct contact (by splashing, dust inhalation, or other means) with the contaminant exists. Professional judgement and knowledge of on-site hazards should be used in selecting PPE appropriate to the concentration of the contaminant (trace vs percentage) to which the individual is likely to be exposed.

ATTACHMENT A

CONTAMINANT FACT SHEET


 <p>CONTAMINANT FACT SHEET</p> <p>Chemical Name: <u>1,1-Dichloroethane (11DCA)</u> CAS Number: <u>75-34-3</u> Synonyms: <u>Ethylidene chloride</u> <u>1,1-Ethylidene chloride</u> <u>Asymmetrical dichloroethane</u></p>					HEALTH HAZARD DATA									
					Color: <u>colorless</u>	Physical State: Solid _____ Liquid <u>X</u> Gas _____	Odor: <u>chloroform-like</u>	Odor Threshold: <u>120 ppm</u>	Vapor Density: <u>4.0 g/L</u>	Ionization Potential (IP): <u>11.06 eV</u>	IDLH: <u>3000 ppm</u>	Carcinogen: OSHA _____ IARC _____ NTP _____ ACGIH _____ NIOSH _____	Skin absorbable: yes ___ no <u>X</u> Skin corrosive: yes ___ no <u>X</u>	Signs/Symptoms of Acute Exposure: <u>Central nervous system depression, skin irritation, lung damage</u>
								OSHA PEL	100 ppm					
								ACGIH TLVs	100 ppm					
								NIOSH RELs	100 ppm					
AIR MONITORING					PERSONAL PROTECTIVE EQUIPMENT					FIRE/REACTIVITY DATA				
Type	Brand/Model No.	Calibrations Method/Media	Relative Response or Conversion Factor	Meter Specific Action Level	Recommended Protective Clothing Materials: Suits <u>Tychem</u> _____ _____ Gloves <u>Viton</u> <u>Polyvinyl Alcohol</u> (do not use in water) _____ Boots <u>Viton</u> _____ _____ Service Limit Concentration (ppm): <u>1000</u>					Flash Point: <u>2°F</u> LEL/UEL: <u>5.4%/11.4%</u> Fire Extinguishing Media: Dry Chemical <u>X</u> Foam <u>X</u> Water Spray _____ CO ₂ <u>X</u> Incompatibilities: <u>Strong oxidizers and strong caustics</u>				
PID	Micro tip 11.7 eV	Isobutylene 100 ppm	0.04	4										
Checked by: Emmet F. Curtis					Date: 12/5/03									

2003 by MACTEC Engineering & Consulting, Inc.

Note: The recommended protective clothing materials assumes that potential for direct contact (by splashing, dust inhalation, or other means) with the contaminants exists. Professional judgment and knowledge of on-site hazards should be used in selecting PPE appropriate to the concentration of the contaminant (trace vs percentage) to which the individual is likely to be exposed.

ATTACHMENT A

CONTAMINANT FACT SHEET


 <p style="text-align: center;">CONTAMINANT FACT SHEET</p> <p>Chemical Name: Vinyl Chloride CAS Number: 75-01-4 Synonyms: Chloroethene, chloroethylene, ethylene monochloride, VC, monochloroethene</p>					HEALTH HAZARD DATA									
					Color: <u>Colorless</u>	Carcinogen: OSHA <u>X</u> IARC <u>X</u> NTP <u>X</u> ACGIH <u>X</u> NIOSH <u>X</u>	Source	TWA (units)	STEL (units)	C (units)				
Physical State: Solid _____ Liquid <u>X</u> below 7 ^o F Gas <u>X</u>	Skin absorbable: yes ___ no <u>X</u> Skin corrosive: yes ___ no <u>X</u>	OSHA PELs	1.0 ppm		5.0 ppm									
Odor: <u>pleasant</u>	Signs/Symptoms of Acute Exposure: <u>Weakness, abdominal pain, frostbite paleness or blueness of extremities</u>	ACGIH TLVs	1.0 ppm											
Odor Threshold: <u>10-20 ppm</u>		NIOSH RELs	Lowest Feasible											
Vapor Density: <u>2.15 g/L</u>														
Ionization Potential (IP): <u>9.99 eV</u>														
IDLH: <u>Not Determined</u>														
AIR MONITORING					PERSONAL PROTECTIVE EQUIPMENT					FIRE/REACTIVITY DATA				
Type	Brand/Model No.	Calibrations Method/Media	Relative Response or Conversion Factor	Meter Specific Action Level	Recommended Protective Clothing Materials: Suits <u>Tychem, Teflon</u> _____ _____ Gloves <u>Teflon, Tychem</u> <u>Nitrile Rubber</u> _____ Boots <u>Nitrile Rubber, Teflon</u> _____ _____ Service Limit Concentration (ppm): <u>1000</u> MUC 1/2 Mask APR = TWA x 10 = <u>5 ppm</u> MUC Full-Face APR = TWA x 10 = <u>5 ppm</u>					Flash Point: <u>NA</u> LEL/UEL: <u>3.6% / 33%</u> Fire Extinguishing Media: Dry Chemical <u>X</u> Foam <u>X</u> Water Spray <u>X</u> CO ₂ <u>X</u> Incompatibilities: <u>Copper, oxidizers, aluminum, peroxides, iron, steel (polymerizes in air, sunlight, or heat unless stabilized by inhibitors). Attacks iron and steel in presence of moisture.</u>				
PID	Microtip 10.6eV	Isobutylene 100 ppm	0.67	0.67										
PID	HNu 10.2eV	Isobutylene 100 ppm	0.32	0.32										
PID	HNu 11.7 eV	Isobutylene 100 ppm	0.78	0.78										
Detector Tube	Drager 6728061	0.5 - 3 ppm		1.0 ppm										
Checked by: Emmet F. Curtis					Date: 12/5/03									

2003 by MACTEC Engineering & Consulting, Inc.

Note: The recommended protective clothing materials assumes that potential for direct contact (by splashing, dust inhalation, or other means) with the contaminant exists. Professional judgement and knowledge of on-site hazards should be used in selecting PPE appropriate to the concentration of the contaminant (trace vs percentage) to which the individual is likely to be exposed.

ATTACHMENT A

CONTAMINANT FACT SHEET


 <p>CONTAMINANT FACT SHEET</p> <p>Chemical Name: <u>Trichloroethene</u> CAS Number: <u>79-01-6</u> Synonyms: <u>Ethylene trichloride, TCE, Trichloroethylene, Trilene</u></p>					HEALTH HAZARD DATA									
					Color:	<u>Colorless</u>			Carcinogen:	OSHA _____ IARC _____ NTP _____ ACGIH _____ NIOSH _____ <u>X</u>			Source	TWA (units)
Physical State:	Solid _____ Liquid <u>X</u> Gas _____			Skin absorbable:	yes ___ no <u>X</u>			OSHA PELs	100 ppm		200 ppm			
Odor:	<u>Chloroform-like</u>			Skin corrosive:	yes ___ no <u>X</u>			ACGIH TLVs	50 ppm	100 ppm				
Odor Threshold:	<u>82 ppm</u>			Signs/Symptoms of Acute Exposure:	<u>Irritant to eyes and skin, headache</u> <u>nausea, vomiting, dermatitis, vertigo,</u> <u>visual disturbance, fatigue, giddiness,</u> <u>sleepiness</u>			NIOSH RELs	25 ppm					
Vapor Density:	<u>4.5 g/L</u>													
Ionization Potential (IP):	<u>9.45 eV</u>													
IDLH:	<u>1000 ppm</u>													
AIR MONITORING					PERSONAL PROTECTIVE EQUIPMENT					FIRE/REACTIVITY DATA				
Type	Brand/Model No.	Calibrations Method/Media	Relative Response or Conversion Factor	Meter Specific Action Level	Recommended Protective Clothing Materials: Suits <u>Viton, PE/EVAL, Tychem, Barricade, Trelchem, Teflon, Responder</u> Gloves <u>Viton, Teflon, Polyvinyl alcohol (do not use in water)</u> Boots <u>Teflon, Viton</u>					Flash Point: <u>Unknown</u> LEL/UEL: <u>8% / 10.5%</u> Fire Extinguishing Media: Alcohol resistant Dry Chemical <u>X</u> Foam <u>X</u> Water Spray <u>X</u> CO ₂ <u>X</u>				
PID	Microtip 10.6eV	Isobutylene 100 ppm	0.92	23	Service Limit Concentration (ppm): <u>1000</u> MUC 1/2 Mask APR = TWA x 10 = <u>250 ppm</u> MUC Full-Face APR = TWA x 10 = <u>250 ppm</u>					Incompatibilities: <u>Strong caustics and alkalis, chemically-active metals (such as barium, lithium, sodium, magnesium, titanium, and beryllium)</u>				
PID	HNu 10.2eV	Isobutylene 100 ppm	0.90	22.5										
Detector Tube	Drager 6828541	2 - 50 ppm		25										
Checked by: <u>Emmet F. Curtis</u>					Date: <u>12/5/03</u>									

2003 by MACTEC Engineering & Consulting, Inc.

Note: The recommended protective clothing materials assumes that potential for direct contact (by splashing, dust inhalation, or other means) with the contaminant exists. Professional judgement and knowledge of on-site hazards should be used in selecting PPE appropriate to the concentration of the contaminant (trace vs percentage) to which the individual is likely to be exposed.

ATTACHMENT A

CONTAMINANT FACT SHEET


 CONTAMINANT FACT SHEET Chemical Name: <u>Tetrachloroethene</u> CAS Number: <u>127-18-4</u> Synonyms: <u>tetrachloroethylene</u> <u>Perchloroethylene (Perc)</u>					HEALTH HAZARD DATA									
					Color: <u>colorless</u>	Physical State: Solid _____ Liquid <u>X</u> Gas _____	Odor: <u>chloroform-like</u>	Odor Threshold: <u>47 ppm</u>	Vapor Density: <u>6.8 g/L</u>	Ionization Potential (IP): <u>9.32 eV</u>				
					Carcinogen: OSHA _____ IARC _____ NTP <u>X</u> ACGIH <u>X</u> NIOSH <u>X</u>	Skin absorbable: yes ___ no <u>X</u> Skin corrosive: yes ___ no <u>X</u>	Source	TWA (units)	STEL (units)	C (units)				
					Signs/Symptoms of Acute Exposure: <u>Irritation of eyes, nose, and throat;</u> <u>nausea; flushing of the face and neck;</u> <u>vertigo; dizziness; incoherence;</u> <u>headache; sleepiness, and skin irritation</u>		OSHA PEL	100 ppm		200 ppm				
							ACGIH TLVs	25 ppm	100 ppm					
							NIOSH RELs	Lowest Feasible						
AIR MONITORING					PERSONAL PROTECTIVE EQUIPMENT					FIRE/REACTIVITY DATA				
Type	Brand/Model No.	Calibrations Method/Media	Relative Response or Conversion Factor	Meter Specific Action Level	<u>Recommended Protective Clothing Materials:</u> Suits <u>Teflon, Viton, CPF3,</u> <u>Barricade, Responder,</u> <u>Trelchem, Tychem</u> Gloves <u>Viton, Teflon, and Polyvinyl</u> <u>Alcohol (do not use in</u> <u>(water)</u> Boots <u>Nitrile Rubber</u> _____ _____					Flash Point: <u>NA</u> LEL/UEL: <u>NA / NA</u> <u>Fire Extinguishing Media:</u> Dry Chemical <u>X</u> Foam <u>X</u> Water Spray <u>X</u> CO ₂ <u>X</u>				
PID	Microtip 10.6 eV	Isobutylene 100 ppm	1.04 ppm	26 ppm	Service Limit Concentration (ppm): <u>1000</u>					<u>Incompatibilities:</u> <u>Strong oxidizers, chemically-active metals,</u> <u>caustic soda, sodium hydroxide, and potash</u>				
PID	HNu 10.2 eV	Isobutylene 100 ppm	0.86	21.5 ppm	MUC 1/2 Mask APR=TWA x 10= <u>125 ppm</u> MUC Full-Face APR=TWA x 10= <u>125 ppm</u>									
Detecor Tube	Drager 8101 501	2 - 40 ppm		25 ppm										
Checked by: Emmet F. Curtis					Date: 12/5/03									

2003 by MACTEC Engineering & Consulting, Inc.

Note: The recommended protective clothing materials assumes that potential for direct contact (by splashing, dust inhalation, or other means) with the contaminants exists. Professional judgment and knowledge of on-site hazards should be used in selecting PPE appropriate to the concentration of the contaminant (trace vs percentage) to which the individual is likely to be exposed.

ATTACHMENT A

CONTAMINANT FACT SHEET

 <p>CONTAMINANT FACT SHEET</p> <p>Chemical Name: <u>1,1,1-Trichloroethane</u> CAS Number: <u>71-55-6</u> Synonyms: <u>Methyl chloroform; chloroethene</u></p>					HEALTH HAZARD DATA									
					Color: <u>Colorless</u> Physical State: Solid _____ Liquid <u> X </u> Gas _____ Odor: <u>Chloroform-like</u> Odor Threshold: <u>100 ppm</u> Vapor Density: <u>5.5 g/L</u> Ionization Potential (IP): <u>11.00 eV</u> IDLH: <u>700 ppm</u>	Carcinogen: OSHA _____ IARC _____ NTP _____ ACGIH _____ NIOSH _____ Skin absorbable: yes ___ no <u>X</u> Skin corrosive: yes <u>X</u> no ___ Signs/Symptoms of Acute Exposure: <u>Skin irritation, headaches, dizziness,</u> <u>nausea, vomiting, diarrhea</u>	Source	TWA (units)	STEL (units)	C (units)				
		OSHA PEL	350 ppm											
		ACGIH TLVs	350 ppm	450 ppm										
		NIOSH RELs			350 ppm									
AIR MONITORING					PERSONAL PROTECTIVE EQUIPMENT					FIRE/REACTIVITY DATA				
Type	Brand/Model No.	Calibrations Method/Media	Relative Response or Conversion Factor	Meter Specific Action Level	Recommended Protective Clothing Materials: Suits <u>Tychem, Teflon, Viton</u> _____ _____ Gloves <u>Teflon, Viton, PE/EVAL</u> <u>Polyvinyl alcohol (Do</u> <u>not use in water)</u> _____ Boots <u>Teflon, Viton</u> _____ _____					Flash Point: <u>NA</u> LEL/UEL: <u>7.5% / 12.5%</u> Fire Extinguishing Media: Dry Chemical <u> X </u> Foam <u> X </u> Water Spray _____ CO ₂ <u> X </u>				
PID	HNU 11.7eV	Isobutylene 100 ppm	0.48	168	Service Limit Concentration (ppm): <u>NA</u> MUC 1/2 Mask APR=TWA x 10= <u>700 ppm</u> MUC Full-Face APR=TWA x 10= <u>700 ppm</u>					Incompatibilities: Strong caustics; strong oxidizers; chemically active metals such as: zinc, aluminum, magnesium powders, sodium, and potassium; water				
Checked by: Emmet F. Curtis					Date: 12/5/03									

2003 by MACTEC Engineering & Consulting, Inc.

Note: The recommended protective clothing materials assumes that potential for direct contact (by splashing, dust inhalation, or other means) with the contaminants exists. Professional judgment and knowledge of on-site hazards should be used in selecting PPE appropriate to the concentration of the contaminant (trace vs percentage) to which the individual is likely to be exposed.

This is Google's cache of http://www.hnu.com/msds/new_iso_msds.htm as retrieved on Nov 18, 2006 09:15:51 GMT.

Google's cache is the snapshot that we took of the page as we crawled the web.

The page may have changed since that time. Click here for the [current page](#) without highlighting.

This cached page may reference images which are no longer available. Click here for the [cached text](#) only.

To link to or bookmark this page, use the following url: [http://www.google.com/search?](http://www.google.com/search?q=cache:csn0BmDcnfcJ:www.hnu.com/msds/new_iso_msds.htm+Isobutylene+100+ppm+MSDS&hl=en&gl=us&ct=clnk&cd=1)

[q=cache:csn0BmDcnfcJ:www.hnu.com/msds/new_iso_msds.htm+Isobutylene+100+ppm+MSDS&hl=en&gl=us&ct=clnk&cd=1](http://www.google.com/search?q=cache:csn0BmDcnfcJ:www.hnu.com/msds/new_iso_msds.htm+Isobutylene+100+ppm+MSDS&hl=en&gl=us&ct=clnk&cd=1)

Google is neither affiliated with the authors of this page nor responsible for its content.

These search terms have been highlighted: **isobutylene 100 ppm msds**



Instrumentation for Environmental, Process & Industrial Hygiene Monitoring



Isobutylene in Air MSDS

[Home](#)

MATERIAL SAFETY DATA SHEET - CALIBRATION CHECK GAS/**ISOBUTYLENE** IN AIR

PRODUCT NAME: **100 PPM ISOBUTYLENE/AIR (100 PPM ISOBUTYLENE/AIR) MSDS**

Version:4 Date: January, 2004

1. Chemical Product and Company Identification **PID ANALYZERS, LLC** 25 Walpole Park Drive South Walpole, MA 02081 TELEPHONE NUMBER: (508) 660-5001 **24-HOUR EMERGENCY NUMBER: 1-617-699-4307** FAX NUMBER: (508) 660-5040 E-MAIL: sales@hnu.com

PRODUCT NAME: ISOBUTYLENE (100 PPM – 0.9%) IN AIR
CHEMICAL NAME: Isobutylene in air

COMMON NAMES/ SYNONYMS: Calibration Gas

CLASSIFICATION: 2.2 WHIMIS CLASSIFICATION: A, D2A, D2B

2. COMPOSITION/ INFORMATION ON INGREDIENTS

INGREDIENT %: **Isobutylene** 0.0001-0.9/Air 99-99.9999

VOLUME:17L

PEL-OSHA: N/A

TLV-ACGIH: N/A

LD50or LC50Route/Species:N/A

FORMULA: C4H8/Air 99.0

3. HAZARDS IDENTIFICATIONEMERGENCY OVERVIEW Release of this product may produce oxygen-deficient atmospheres (especially in confined spaces or other poorly ventilated environments); individuals in such atmospheres may be asphyxiated. **Isobutylene** may cause drowsiness and other central nervous system effects in high concentrations; however, due to the low concentration of this gas mixture, this is unlikely to occur.

ROUTE OF ENTRY:

Skin: No
Contact Skin: No
Absorption: No
Eye Contact: No
Inhalation: Yes
Ingestion: No

HEALTH EFFECTS:

Exposure Limits: Yes
Irritant: No
Sensitization: No
Reproductive Hazard: No
Mutagen: No
Carcinogenicity: No
NTP: No
IARC: No
OSHA: No

EYE EFFECTS: N/A.

SKIN EFFECTS: N/A.

MATERIAL SAFETY DATA SHEET - CALIBRATION CHECK GAS

PRODUCT NAME: **ISOBUTYLENE** (1 PPM - 0.9%) IN AIR

INGESTION EFFECTS: Ingestion unlikely. Gas at room temperature.

INHALATION EFFECTS: Due to the small size of this cylinder, no unusual health effects from over-exposure are anticipated under normal routine use.

NFPA HAZARD CODES HMIS HAZARD CODES RATING SYSTEM

Health: **1**
Flammability: **0**
Flammability: **0**
Reactivity: **0**

***0= No Hazard, 1= Slight Hazard, 2= Moderate Hazard, 3= Serious Hazard, 4= Severe Hazard**

4. FIRST AID MEASURES EYES: N/A

SKIN: N/A

INGESTION: Not required

INHALATION: PROMPT MEDICAL ATTENTION IS MANDATORY IN ALL CASES OF OVEREXPOSURE. RESCUE PERSONNEL SHOULD BE EQUIPPED WITH THE SELF-CONTAINED BREATHING APPARATUS. Victims should be assisted to an uncontaminated area and inhale fresh air. Quick removal from the contaminated area is most important. If breathing has stopped administer artificial resuscitation and supplemental oxygen. Further treatment should be symptomatic and supportive.

5. FIRE-FIGHTING MEASURES These containers hold gas under pressure, with no liquid phase. If involved in a major fire, they should be sprayed with water to avoid pressure increases, otherwise pressures will rise and ultimately they may distort or burst to release the contents. The gases will not add significantly to the fire, but containers or fragments may be

projected considerable distances - thereby hampering fire fighting efforts.

6. ACCIDENTAL RELEASE MEASURES In terms of weight, these containers hold very little contents, such that any accidental release by puncturing etc. will be of no practical concern.

7. HANDLING AND STORAGE Suck back of water into the container must be prevented. Do not allow backfeed into the container. Use only properly specified equipment which is suitable for this product, its supply pressure and temperature. Use only in well-ventilated areas. Do not heat cylinder by any means to increase rate of product from the cylinder. Do not allow the temperature where cylinders are stored to exceed 130oF (54oC).

8. EXPOSURE CONTROLS/PERSONAL PROTECTION Use adequate ventilation for extended use of gas.

MATERIAL SAFETY DATA SHEET - CALIBRATION CHECK GAS PRODUCT NAME:
ISOBUTYLENE (1 PPM - 0.9%) IN AIR

9. PHYSICAL AND CHEMICAL PROPERTIES PARAMETER: VALUE: Physical state : Gas
Evaporation point : N/A pH : N/A Odor and appearance : Colorless, odorless gas

10. STABILITY AND REACTIVITY Stable under normal conditions. Expected shelf life 24 months.

11. TOXICOLOGICAL INFORMATION No toxicological damage caused by this product.

12. ECOLOGICAL INFORMATION No ecological damage caused by this product.

13. DISPOSAL INFORMATION Do not discharge into any place where its accumulation could be dangerous. Used containers are acceptable for disposal in the normal waste stream as long as the cylinder is empty and valve removed or cylinder wall is punctured.

14. TRANSPORT INFORMATION

United States DOT/Canada TDG PROPER SHIPPING NAME:
Compressed Gas N.O.S. Compressed Gas N.O.S. (**Isobutylene** in Air)
HAZARD CLASS: 2.2
IDENTIFICATION NUMBER: UN1956
SHIPPING LABEL: NONFLAMMABLE GAS

15. REGULATORY INFORMATION **Isobutylene** is listed under the accident prevention provisions of section 112(r) of the Clean Air Act (CAA) with a threshold quantity (TQ) of 10,000 pounds.

16. OTHER INFORMATION This **MSDS** has been prepared in accordance with the Chemicals

(Hazard Information and Packaging for Supply (Amendment) Regulation 1996. The information is based on the best knowledge of PID Analyzers, LLC , and its advisors and is given in good faith, but we cannot guarantee its accuracy, reliability or completeness and therefore disclaim any liability for loss or damage arising out of use of this data. Since conditions of use are outside the control of the Company and its advisors we disclaim any liability for loss or damage when the product is used for other purposes than it is intended.

MSDS/S010/248/January, 2004

[Top](#)

AutoCal -----MATERIAL SAFETY DATA SHEET-----

AutoCal Solution
Compliance Technology Inc.
118 Starlite St.
So. San Francisco, CA 94080-6310
Prepared: February 20, 1996
Revised: February 14, 2000

----- NOTICE-----

This information is believed to be accurate and represents the best information currently available to us. However, we make no warranty of merchantability, or fitness for any particular use, or any other warranty, express or implied, with respect to this information, and we assume no liability resulting from the use of this information. Users should make their own investigations to determine the suitability of the information for their particular needs and purposes. Compliance Technology Inc. will assist in this regard.

-----SUBSTANCE IDENTIFICATION-----

SUBSTANCE: AutoCal Solution Calibrating Buffer Solution
Trade names/synonyms: This material is also known by various catalog numbers.
Cercla ratings (scale 0-3): health=0 fire=0 reactivity=0 persistence=0
Nfpa ratings (scale 0-4): health=0 fire=0 reactivity=0

-----COMPONENTS AND CONTAMINANTS---

Component: potassium hydrogen phthalate CAS# 877-24-7 Percent: <2.0
Component: water CAS# 7732-18-5 percent: >98
Other contaminants: none

----- EXPOSURE LIMITS-----

No occupational exposure limits established by osha, acgih or niosh.

-----PHYSICAL DATA-----

Description:
Clear, colorless liquid.
Approx. boiling point: 212°F (100°C). Approx. melting point: 32°F (0°C)
Vapor pressure: 14 torr @20°C Evap. Rate: (ether=1) < 1
pH: 4.0 Solubility in water: complete Vapor density: 0.7 (H2O)

-----FIRE AND EXPLOSION DATA-----

Fire and explosion hazard: No fire hazard when exposed to heat or flame.
Flash point: not applicable
Fire fighting media: dry chemical, carbon dioxide, water spray or regular foam. (1990 emergency response guidebook, dot p-5800.5) For larger fires, use water spray, fog or regular foam. (1990 emergency response guidebook, dot p-5800.5)
Fire fighting: Move container from fire area if it can be done without risk. Do not scatter spilled material with high-pressure water streams. Dike fire-control water for later disposal. (1990 emergency response guidebook, dot p-5800.5 Pg. 31) Use agents suitable for the type of surrounding fire. Avoid breathing hazardous vapors, stay upwind of the fire.

-----TOXICITY-----

potassium hydrogen phthalate:
Carcinogen status: none.
Local effects: irritant - inhalation, skin, eye.
Acute toxicity level: no data available.
Target effects: no data available.
medical conditions aggravated by exposure: no data available.

-----HEALTH EFFECTS AND FIRST AID-----

INHALATION
POTASSIUM HYDROGEN PHTHALATE: IRRITANT.
ACUTE EXPOSURE - MAY CAUSE IRRITATION.
CHRONIC EXPOSURE - REPEATED OR PROLONGED EXPOSURE MAY CAUSE IRRITATION.

FIRST AID - REMOVE FROM EXPOSURE AREA TO FRESH AIR IMMEDIATELY. IF BREATHING HAS STOPPED, PERFORM ARTIFICIAL RESPIRATION. KEEP PERSON WARM AND AT REST. TREAT SYMPTOMATICALLY AND SUPPORTIVELY. GET MEDICAL ATTENTION IMMEDIATELY.

SKIN CONTACT:

POTASSIUM HYDROGEN PHTHALATE: IRRITANT.

ACUTE EXPOSURE - MAY CAUSE IRRITATION.

CHRONIC EXPOSURE - REPEATED OR PROLONGED EXPOSURE MAY CAUSE DERMATITIS.

FIRST AID - REMOVE CONTAMINATED CLOTHING AND SHOES IMMEDIATELY, WASH AFFECTED AREA WITH SOAP OR MILD DETERGENT AND LARGE AMOUNTS OF WATER UNTIL NO EVIDENCE OF CHEMICAL REMAINS (APPROXIMATELY 15-20 MINUTES). GET MEDICAL ATTENTION IMMEDIATELY.

EYE CONTACT:

POTASSIUM HYDROGEN PHTHALATE: IRRITANT.

ACUTE EXPOSURE-DIRECT CONTACT MAY CAUSE IRRITATION, REDNESS AND PAIN.

CRONIC EXPOSURE-REPEATED OR PROLONGED EXPOSURE MAY CAUSE CONJUNCTIVITIS

FIRST AID - WASH EYES IMMEDIATELY WITH LARGE AMOUNTS OF WATER OR NORMAL SALINE, OCCASIONALLY LIFTING UPPER AND LOWER LIDS UNTIL NO EVIDENCE OF CHEMICAL REMAINS (APPROXIMATELY 15-20 MINUTES). GET MEDICAL ATTENTION IMMEDIATELY.

INGESTION

POTASSIUM HYDROGEN PHTHALATE: IRRITANT.

ACUTE EXPOSURE - MAY CAUSE NAUSEA, VOMITING AND DIARRHEA.

CRONIC EXPOSURE - NOT REPORTED TO OCCUR IN HUMANS

FIRST AID - IF VICTIM IS CONSCIOUS, IMMEDIATELY GIVE 2-4 GLASSES OF WATER, AND INDUCE VOMITING BY TOUCHING FINGER TO BACK OF THROAT, GET MEDICAL ATTENTION IMMEDIATELY.

-----REACTIVITY-----

Reactivity: stable under normal temperatures and pressures.

Incompatibilities: AFFECTED BY STRONG OXIDIZERS WHEN DRY.

Decomposition: NONE KNOWN WHILE IN SOLUTION.

Polymerization: NONE KNOWN WHILE IN SOLUTION.

-----STORAGE AND DISPOSAL-----

Observe all federal, state and local regulations when storing or disposing of this substance. for assistance, contact the district director of the environmental protection agency.

-----PROTECTIVE EQUIPMENT-----

When using, wear eye protection to prevent contact.