

Report

REMEDIAL DESIGN/REMEDIAL ACTION (RD/RA) WORK PLAN OU-3 SEDIMENTS

FRIEDRICHSOHN COOPERAGE SITE
153-155 SARATOGA AVENUE
TOWN OF WATERFORD, NEW YORK

Prepared for: General Electric Company and SI Group, Inc.

Conestoga-Rovers & Associates

651 Colby Drive
Waterloo, Ontario N2V 1C2

OCTOBER 2014 • 080987 • Report No. 5



**CONESTOGA-ROVERS
& ASSOCIATES**

651 Colby Drive, Waterloo, Ontario, N2V 1C2
Telephone: (519) 884-0510 Fax: (519) 884-0525
www.CRAworld.com

October 14, 2014

Reference No. 080987

Mr. Daniel J. Eaton,
New York State Department of Environmental Conservation
625 Broadway
Albany, NY 12233-7015

Dear Mr. Eaton:

Re: Remedial Design/Remedial Action (RD/RA) Work Plan, OU-3 Sediments,
Friedrichsohn Cooperage Site, 153-155 Saratoga Avenue, Waterford, New York

On behalf of SI Group Inc. and the General Electric Company (Companies), we have enclosed two hardcopies, one unbound hardcopy, and one CD containing an electronic copy of the revised OU-3 Sediments Remedial Design/Remedial Action (RD/RA) Work Plan. This document was revised to address NYSDEC comments that were received via email on September 25, 2014. The schedule (Figure 8.1) was also updated to reflect receiving NYSDEC approval by October 20, 2014.

Should you have any questions or require additional information, please do not hesitate to contact the undersigned.

Yours truly,

CONESTOGA-ROVERS & ASSOCIATES

Jamie Puskas, P. Eng.

AW/kf/6

Encl.

cc: Keith Cowan, CHA (1 electronic copy)
Krista Anders, New York State Department of Health (1 hard copy)
Dolores A. Tuohy, New York State Department of Environmental Conservation (1 hard copy)
Roger Florio, GE Corporate Environmental Programs (1 hard copy)
John Uruskyj, GE Corporate Environmental Programs (1 hard copy, 1 electronic copy)
Thomas Masterson, SI Group, Inc. (1 hard copy)
Dean S. Sommer, Young Sommer LLC (1 hard copy)
Michael G. Sterthous, Whileman, Osterman & Hanna LLP (1 hard copy)
Jeff Daniel, CRA (w/o encl.)

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	1
2.0 BACKGROUND INFORMATION	3
2.1 SITE LOCATION AND DESCRIPTION	3
2.2 OLD CHAMPLAIN CANAL.....	3
2.3 SITE HISTORY	3
2.4 OU-3 SEDIMENT DELINEATION DATA	6
2.4.1 SEDIMENT DELINEATION.....	8
3.0 REMEDIAL ACTION OBJECTIVES.....	9
4.0 REMEDIAL ACTION COMPONENTS	10
4.1 PRE-DESIGN ACTIVITIES	10
4.2 EXCAVATION OF SEDIMENT EXCEEDING 50 MG/KG PCBS IN OU-3.....	11
4.3 EXCAVATION OF SEDIMENT EXCEEDING 1 MG/KG PCBS IN OU-3.....	12
4.4 WATER TIGHTNESS OF THE CANAL	13
5.0 PREDESIGN DATA COLLECTION ACTIVITIES	15
5.1 SEDIMENT VOLUME DELINEATION	15
5.2 DEWATERING/STABILIZATION OF DREDGED SEDIMENT	16
5.3 WASTEWATER CHARACTERIZATION	17
5.4 UTILITY LOCATES AND OTHER PRE-DESIGN ACTIVITIES.....	18
6.0 REMEDIAL ACTION PROJECT PLANS	19
6.1 HEALTH AND SAFETY PLAN	19
6.2 QUALITY ASSURANCE PROJECT PLAN	20
6.3 FIELD SAMPLING PLAN.....	20
7.0 REMEDIAL DESIGN.....	22
7.1 PRELIMINARY DESIGN	22
7.1.1 PRELIMINARY DESIGN REPORT.....	22
7.1.2 PRELIMINARY PLANS AND SPECIFICATIONS.....	23
7.2 PRE-FINAL/FINAL DESIGN	23
7.2.1 DESIGN REPORT.....	24
7.2.2 PLANS AND TECHNICAL SPECIFICATIONS.....	24
7.2.3 WASTE MANAGEMENT PLAN.....	25
7.2.4 CONSTRUCTION HEALTH AND SAFETY PLAN	25
7.2.5 CONSTRUCTION SCHEDULE	26
8.0 SCHEDULE.....	27
9.0 PROGRESS REPORTS	28

LIST OF FIGURES
(Following Text)

FIGURE 1.1	SITE LOCATION
FIGURE 2.1	OU-3 SITE PLAN
FIGURE 2.2	LIMITS OF SEDIMENT BELOW 1 mg/kg PCBS
FIGURE 2.3	GAPS IN VERTICAL PCB DELINEATION - SEDIMENT
FIGURE 2.4	UNCERTAINTY IN TSCA MATERIAL DELINEATION - SEDIMENT
FIGURE 2.5	PROPOSED SEDIMENT SAMPLING LOCATIONS
FIGURE 2.6	PROPOSED SEDIMENT SAMPLING LOCATIONS - ADJACENT TO SITE
FIGURE 8.1	OU-3 SEDIMENT RD/RA WORK PLAN SCHEDULE

LIST OF TABLES
(Following Text)

TABLE 2.1	OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
TABLE 2.2	SEDIMENT DELINEATION SAMPLE SUMMARY

LIST OF APPENDICES

APPENDIX A	SUMMARY OF SEDIMENT ANALYTICAL DATA
APPENDIX B	HEALTH AND SAFETY PLAN
APPENDIX C	QUALITY ASSURANCE PROJECT PLAN
APPENDIX D	WASTE MANAGEMENT PLAN
APPENDIX E	FIELD SAMPLING PLAN

1.0 INTRODUCTION

This Remedial Design/Remedial Action Work Plan (RD/RA Work Plan) provides for the development and implementation of final plans and specifications for implementing the remedial alternative for Operable Unit 3 (OU-3) Sediments at the Friedrichsohn Cooperage inactive hazardous waste site (the Site) located at 153-155 Saratoga Avenue in the Town of Waterford, New York (see Figure 1.1 for the Site location). The RD/RA Work Plan for OU-1 and Upland Source Soils in OU-3 dated July 9, 2013 was previously submitted. OU-1 is comprised of the on-Site and off-Site contaminated soils associated with the former cooperage operation. OU-3 is comprised primarily of the sediments in the Old Champlain Canal between O'Connor Drive and Burton Avenue, and also includes on-Site source area soils.

This RD/RA Work Plan for OU-3 sediments has been prepared by Conestoga-Rovers & Associates (CRA) in accordance with an Order on Consent (Consent Order) between the New York State Department of Environmental Conservation (NYSDEC) and the Respondents, General Electric Company and SI Group, Inc. (the Companies), which came effective February 7, 2013 (Index No. A5-0784-1202). The Consent Order also requires the Respondents to prepare a RD/RA Work Plan for OU-1 and for the upland source soils in OU-3. This was submitted under separate cover and approved by NYSDEC on March 25, 2014.

This RD/RA Work Plan has been prepared in general accordance with the following guidance, directives, and other publications, where appropriate:

- Consent Order, Index No. A5-0784-1202, January 2013
- Record of Decision for OU-1, Site No. 546045, December 2012
- Record of Decision for OU-3, Site No. 546045, March 2011
- NYSDEC DER-10 Technical Guidance for Site Investigation and Remediation, May 2010
- Applicable provisions of the New York State Environmental Conservation Law (ECL) and associated regulations, including Title 6 of the New York Code of Rules and Regulations (6 NYCRR) Part 375
- United States Environmental Protection Agency (USEPA) guidance document entitled "Guidance for Conducting Remedial Investigations and Feasibility Studies Under the Comprehensive Environmental Response, Compensation and Liability Act" (CERCLA), Interim Final (USEPA, 1988)

- Applicable provisions of the National Oil and Hazardous Substances Pollution Contingency Plan (NCP) regulations contained in Title 40 of the Code of Federal Regulations (CFR) Part 300

This RD/RA Work Plan was prepared to fulfill the requirement in the Consent Order for a RD/RA Work Plan.

The RD/RA Work Plan is organized as follows:

Section 1.0 - Introduction

Section 2.0 - Background Information

Section 3.0 - Remedial Action Objectives

Section 4.0 - Remedial Action Components

Section 5.0 - Pre-Design Data Collection

Section 6.0 - Remedial Action Project Plans

Section 7.0 - Remedial Design

Section 8.0 - Schedule

Section 9.0 - Progress Reports

2.0 BACKGROUND INFORMATION

2.1 SITE LOCATION AND DESCRIPTION

The Site is located at 153-155 Saratoga Avenue, Waterford, Saratoga County, New York. A Site location map is presented as Figure 1.1. The Site is approximately 0.45 acres in size and has approximately 315 feet of frontage on Saratoga Avenue (Route 32). The Old Champlain Canal borders the Site on the side opposite the road. Residential properties are adjacent to the Site on Saratoga Avenue; residential and commercial properties are also located across from the Site on Saratoga Avenue. The Site is abandoned and is currently a vacant lot. OU-3 is comprised of the section of the Old Champlain Canal between O'Connor Drive and Burton Avenue. The approximate boundaries of the OU-3 are shown on Figure 2.1.

Access to the former industrial Site is limited by an 8-foot tall, lockable, chain-link fence that has been installed around the former Friedrichsohn Cooperage property. Warning signs have been installed on the fencing. Access to OU-3 is not limited.

The former industrial Site is currently zoned as residential (R-75) and is served by the public water supply system and the public stormwater and sanitary systems. The commercial properties across from the Site are located on property formerly known as the Friedrichsohn Cooperage Lot, which was used to store drums.

2.2 OLD CHAMPLAIN CANAL

The Champlain Canal was first considered in 1792 as a means of creating a waterway between Lake Champlain and the Hudson River. Construction of the Canal commenced in 1817 at the northern end and progressed southward with the southern section at Waterford being completed in 1822.

2.3 SITE HISTORY

A cooperage operated at this location from 1817 to 1991. During the early operations the cooperage made and refurbished wooden kegs and barrels. When the cooperage closed in 1991 the primary business had been cleaning and refurbishing metal drums. Industrial facilities, commercial businesses and municipal governments in the area used materials shipped in drums in their industrial processes, commercial operations or as part of maintenance activities. Drums would be sent to the cooperage to be cleaned,

repainted, and resold. The drum cleaning and refurbishing operations are alleged to be the source of the contamination that was identified at the Site.

During its most recent history, the cooperage operated out of five buildings at the Site. Three of the five buildings were constructed as slab-on-grade. Two of the buildings contained structures below grade. One of the buildings had a basement area, below grade, where the sumps were located. One of the buildings on the southwest end of the Site is labeled as a garage on historical drawings, and had an automobile service trench associated with it. The service trench is below grade and provided access to the undercarriage of vehicles.

Inspection and examination of the abandoned business in 1994 revealed many metal drums, and the buildings to be unstable and in poor condition. The USEPA conducted an emergency removal action between 1994 and 1996. The cooperage buildings were demolished, and clean fill was imported to replace contaminated soil that was removed. In the spring of 2008, NYSDEC collected samples of soil, groundwater, and surface water and sediment in the canal. The analytical results formed the basis for the listing of the Site in December 2008 as a Class 2 on the NYS Registry of Inactive Hazardous Waste Disposal Sites. The Site is currently divided into three OUs:

- OU-1 is comprised of the on-Site and off-Site soil at the former cooperage site, excluding the soil in the on-Site source area adjacent to the Canal that is part of OU-3
- OU-2 is comprised of on-Site and off-Site groundwater
- OU-3 is comprised of the sediments in the Old Champlain Canal between O'Connor Drive and Burton Avenue, as well as the adjacent on-Site source area and canal bank soil

The contaminants of concern (COCs) at the Site include polychlorinated biphenyls (PCBs), chlorinated volatile organic compounds (VOCs) (tetrachloroethane, trichloroethane, dichloroethene, vinyl chloride, and chlorobenzene), benzene, toluene, ethylbenzene, xylenes (BTEX), phenolic compounds (phenol and dimethylphenol), hexachlorobenzene, and metals (arsenic, barium, chrome, and lead).

NYSDEC issued a ROD for OU-1 in December 2012 and a ROD for OU-3 in March 2011. In the OU-1 ROD, NYSDEC selected the Site Cover remedy to achieve restricted residential soil cleanup objective (SCOs). In addition to the Site cover component, the remedy also included Institutional Controls. In the OU-3 ROD, the remedy pertinent to the on-Site source area included excavating the source soil down to bedrock and transporting it off-Site for disposal. The components of the remedy for OU-1 and OU-3

soils are discussed in the RD/RA Work Plan for OU-1 and Upland Source Soils in OU-3, previously submitted.

In the OU-3 ROD, the remedy pertinent to OU-3 sediment, as specified in the ROD is as follows:

- Address contamination of sediment of the Old Champlain Canal from O'Connor Drive in the south to Burton Avenue north of the site, with the horizontal and vertical extent to be refined by sampling during the design.
- PCBs have been identified by NYSDEC as the marker compound for the canal sediments. The remedial objective is removal of sediment within OU-3 for off-site disposal to achieve a cleanup goal of 1 ppm, consistent with verification sampling procedures established as part of the remedial design process.
- Excavation of an estimated 12,500 cubic yards of sediment from the canal within the boundary of OU-3 to a depth of approximately 2 feet. Where necessary, excavated sediments in the canal will be replaced with clean fill to establish the original design depth of 6 feet.
- Off-Site transport and disposal of excavated sediments (including sediments with PCBs above 50 ppm) will be to a permitted disposal facility.
- Restored canal bed will meet the NYS Canal Corporation requirements to retain the hydraulic integrity of the canal, (i.e., to retain water within the canal and transmit water within the canal).
- Design will contain elements to stabilize excavations, control water in the excavation, control odors, and dewater the excavated materials. In areas where the excavation does not end in bedrock, the design will also require confirmation samples to be collected at the completion of the excavation.

In January 2013, the two Companies and NYSDEC entered into a Consent Order to conduct and implement a RD/RA Work Plan. The objective of the RD/RA Work Plan is to provide for the development and implementation of final plans and specifications for implementing the remedial alternative set forth in the NYSDEC RODs, dated March 2011 and December 2012. The RD/RA Work Plan for OU-1 and Upland Source Soils in OU-3 dated July 9, 2013 was previously submitted.

2.4 OU-3 SEDIMENT DELINEATION DATA

The available sediment data for OU-3 was reviewed as part of preparation of this Work Plan. Sediment data was included in the following reports that were available during the preparation of this Work Plan:

- Summary Report for a Preliminary Site Assessment, Friedrichsohn Cooperage Site (5-46-045), EA Engineering, October 2008
- Focused Remedial Investigation/Feasibility Study, Malcolm Pirnie, April 2010
- Proposed Remedial Action Plan, Operable Unit Number 03, NYSDEC, February 2011
- Record of Decision, Operable Unit Number 03, NYSDEC, March 2011
- Post RI Pre-Design Sediment Sampling Data Tables and Sample Location Figures, Malcolm Pirnie, December 2011
- Fact Sheet, Operable Unit Number 01, NYSDEC, October 2012
- Record of Decision, Operable Unit Number 01, NYSDEC, December 2012
- Order on Consent and Administrative Settlement, Index A5-074-1202 Friedrichsohn Cooperage Site #564045

Of the eight documents listed above, four included tabulated data for sediment. The remaining documents include summary statistics for the data but not the parent data. The parent data for the sediment data summaries presented in OU-3 ROD and PRAPs were provided by the NYSDEC in electronic Equis file format.

A summary of the number of sediment samples collected within OU-3 and the associated events is as follows:

- **April 2008** - A total of 8 sediment samples from 4 locations (SD-01 to SD-04) collected using a slide hammer with a stainless steel sample collection bucket
- **August 2009** - A total of 36 sediment samples from 31 canal locations (FC-SD-01 to FC-SD-31) and 2 from west of Garret Field (FC-SD-32 and FC-SD-33). Canal locations collected by advancing Macrocore sleeves manually or with a Geoprobe direct-push drill rig. Borings in center channel collected from a floating barge. Borings inside the fence advanced from shore
- **April 2010** - A total of 5 sediment samples collected from 5 locations (FC-SED01 to FC-SED05)
- **January to March 2011** - A total of 288 sediment samples from 108 locations (SD-01 to SD-70, SD-73 to SD-75, SD-77 to SD-81, SD-84 to SD-85, SD-89 to SD-94, SD-103 to SD-124).

Data obtained from sediment samples collected as part of two sampling events (April 2008 and August 2009) was utilized to support development of the FS. These data as well as data generated from a sampling event in February 2011 were utilized to support development of the OU-3 ROD. The 2008 and 2009 sampling events focused on surficial sampling and did not include any discrete samples located entirely below the anticipated average sediment removal depth of 2-feet identified in the OU-3 ROD (page 22). Data collected in the February 2011 sampling event included deeper sample intervals.

Table 2.1 presents a summary of the available OU-3 sediment total PCB delineation data used in preparation of this Work Plan. Table A.1 in Appendix A presents a summary of the available data for all parameters for OU-3 sediment samples. The following observations may be made regarding the available delineation information. This discussion focuses on PCBs as they have been identified as the marker compound in the OU-3 ROD.

Table 4 of the OU-3 ROD states that 135 of 144 (approximately 94 percent) of samples exceed the Standards, Criteria, and Guidance (SCG) concentration of 1 mg/kg total PCBs (PCB SCG). The sampling results were also used by NYSDEC to identify an area of the canal adjacent to the Site in which sediment exceeded 50 mg/kg total PCBs based on collected data. This area is identified in the OU-3 ROD for removal of sediment to bedrock, unless verification sampling identifies portions of the sediment that have PCB concentrations less than or equal to 1 mg/kg and can remain in place.

For the remainder of the "Sediment Excavation Area" identified in the OU-3 ROD, the following observations may be made based on review of the data for samples collected from SD-1 through SD-121. This information is also identified on Figures 2.2 and 2.3:

- The horizontal extent of surficial sediment exceeding the total PCB SCG is reasonably well defined. Figure 2.2 identifies samples for which no exceedances of the PCB SCG was identified.
- In over 50 percent of the sample locations total PCBs at concentrations exceeding the PCB SCG were identified at a depth below 2 feet. These areas are identified on Figure 2.2.
- At 35 of 68 sample locations (51 percent), exceedances of the PCB SCG are not bounded vertically by samples with concentrations less than the PCB SCG. These areas are identified on Figure 2.3

- There are gaps in the vertical profiling between sampled intervals of between 0.5 foot and 1.5 feet, with the gap being 1.5 feet in most locations
- Detections of PCBs at concentrations above 50 mg/kg were identified adjacent to the Site and in 2 locations (SD-63 and SD-60) located approximately 100 feet and 200 feet from the area of > 50 mg/kg total PCB impacts identified on Figure 6 of the OU-3 ROD. It could not be determined from existing information if these locations represent a contiguous area of >50 mg/kg PCB material or are discrete areas.

2.4.1 SEDIMENT DELINEATION

Based on review of the available data, a number of uncertainties have been identified.

Delineation of TSCA Regulated Sediment: Significant effort has been made to delineate the extent of sediment with total PCB concentrations >50 mg/kg which will be subject to disposal in a TSCA approved disposal facility (TSCA material). A total of 22 sample locations were identified where total PCB concentrations exceeded 50 mg/kg. The limits of TSCA material against the northern bank of the canal have been well defined horizontally. The south limit of TSCA material has been defined in some locations by existing sampling locations (e.g., SD-69, SD-74, and SD-79). However, uncertainty in the limits of TSCA material in other locations was identified. These areas are presented on Figure 2.4.

Delineation of <50 mg/kg PCB Sediment: Limited delineation of the horizontal extent of sediment exceeding the total PCB SCG of 1 mg/kg may be beneficial to ensure areas not requiring removal are fully defined. Additional vertical delineation throughout most of the canal between O'Connor Street and Burton Avenue is proposed to support development of cut lines for sediment removal as part of the Remedial Design.

Proposed Activities: The scope of activities to obtain proposed additional sediment delineation data are shown on Figures 2.5 and 2.6 and summarized in Table 2.2. Pre-Design sediment delineation is further discussed in Section 5.0 of this Proposal.

3.0 REMEDIAL ACTION OBJECTIVES

As stated in Exhibit B of the ROD, the remediation goals for the OU-3 sediment at the Site are to:

- Prevent direct contact with contaminated sediments
- Prevent sediment contamination which may result in fish advisories
- Prevent releases of contaminants from sediment that would result in surface water levels in excess of ambient water quality criteria
- Prevent further migration of contamination in the sediment
- Prevent impacts to biota from ingestion/direct contact with soil causing toxicity or impacts from bioaccumulation through marine and aquatic food chain

4.0 REMEDIAL ACTION COMPONENTS

The primary components of the selected remedial action are as follows:

- Pre-design investigation
- Excavation of sediment in OU-3 exceeding 50 mg/kg PCBs
- Excavation of sediment in OU-3 exceeding 1 mg/kg PCBs
- Dewatering/stabilization and transportation and off-Site disposal of excavated sediment
- Restoration of the Canal

A description of each of the remedial action components is presented in the following subsections.

4.1 PRE-DESIGN ACTIVITIES

As described in Sections 2.2 and 2.3, the OU-3 sediment remediation activities involve removal of area of sediment above total PCB concentrations of 50 mg/kg. This may involve deeper excavation of sediments adjacent to the OU-3 upland soil source area. This upland area is discussed in detail in the RD/RA Work Plan for OU-1 and Upland Source Soils in OU-3 dated July 9, 2013. Information obtained as part of the OU-3 upland soil source are pre-design investigation will be utilized in conjunction with data collected consistent with this Work Plan to provide the necessary pre-design data to support detailed design activities for the OU-3 sediment exceeding 50 mg/kg PCBs. Information anticipated to be collected consistent with the RD/RA Work Plan for OU-1 and Upland Source Soils in OU-3 dated July 9, 2013 which will be used to support OU-3 sediment remedial design activities includes:

- Geotechnical data for the overburden and bedrock to allow for the design of a shoring plan for the OU-3 sediment excavation activities if required
- Estimated groundwater flow from the overburden and bedrock aquifer to develop estimates of the amount of water that will require management during excavation activities below the water table
- Obtain representative groundwater samples from the OU-3 upland soil source area to evaluate the quality of groundwater that will require management during dewatering activities

Pre-design activities completed as part of this Work Plan include:

- Collection of additional sediment samples to further define the vertical extent of PCB concentrations exceeding 50 mg/kg PCBs
- Collection of additional sediment samples to further define the horizontal and vertical extent of sediment which is below 50 mg/kg PCBs but exceeds the SGC concentration of 1 mg/kg PCBs
- Characterization of sediment for disposal
- Provide additional sediment physical data to evaluate dewatering characteristics
- Characterization of wastewater anticipated to be generated during sediment removal and dewatering in order to evaluate pre-treatment requirements for discharge to surface water
- Identification of utilities, access points, haul routes, and nearby receptors

A description of the proposed pre-design data collection activities is presented in Section 5.0. The NYSDEC will be notified at least seven business days prior to the initiation of pre-design field activities.

4.2 EXCAVATION OF SEDIMENT EXCEEDING 50 MG/KG PCBs IN OU-3

Sediment within OU-3 which exceeds 50 mg/kg PCBs will be excavated. Based on previous evaluations of site conditions, removal of sediment down to bedrock is anticipated for this area. The depth to bedrock in this area is approximately 7 feet, and will involve the excavation of approximately 1,000 cubic yards (based on estimates presented in the OU-3 ROD). This work is anticipated to be coordinated with removal of adjacent OU-3 upland soil source area materials. During the design process, considerations or limitations on material excavation or verification sampling associated with ensuring the integrity of the canal liner will be addressed based on consultation with the NYS Canal Corporation.

The extent of material around SD-68 which exceeds 50 mg/kg PCBs will be further defined during pre-design investigations as part of this Work Plan. This area is anticipated to be addressed as an isolated area which is not anticipated to require shoring as the depth of material exceeding 50 mg/kg PCBs is only 3.5 feet below the sediment surface and there are no adjacent structures or slopes requiring protection.

As the removal of this material will extend below the water table, dewatering will be necessary. Estimates of the rate and quality of groundwater that would flow into the

excavation will be estimated based on information to be obtained during pre-design studies as part of the RD/RA Work Plan for OU-1 and Upland Source Soils in OU-3 dated July 9, 2013. A temporary on-Site water treatment system will be designed for use during RA implementation. This treatment system will manage the water generated during the excavation in OU-3. The treated water will be discharged under a SPDES permit into the canal outside of active work areas.

Excavated sediment will be dewatered or mixed with stabilization reagents as necessary to meet treatment or disposal facility acceptance criteria and transported off Site to a permitted facility for treatment or disposal in accordance with State and Federal regulations. Stabilization would be completed only for the purpose of improving the physical characteristics of the material to facilitate transportation and disposal.

The design of the sediment removal activities will include an adaptive odor control program which includes both engineering and operational controls which will be implemented to control odor during RA implementation. A verification sampling program for any excavations which do not extend to bedrock will also be developed as part of the RD consistent with TSCA regulations 40 CFR 761.61(c). The verification sampling program will define the sampling grid for the excavation bottom and sides, sample collection methods, and data interpretation procedures.

Following confirmation of the removal of sediment exceeding 50 mg/kg PCBs, removal of any remaining sediment which exceeds the PCB SCG of 1 mg/kg will be removed as described below and verification sampling completed in accordance with the approved verification sampling program. Once all sediment removal is completed for an area, the area will be restored as discussed in Section 4.4.

4.3 EXCAVATION OF SEDIMENT EXCEEDING 1 MG/KG PCBs IN OU-3

Following confirmation that sediment exceeding 50 mg/kg PCBs has been removed, remaining sediment exceeding 1 mg/kg PCBs will be removed. Sediment removal will be completed for manageable sub-areas of the canal to limit odor and water management issues. The size of the sub areas may vary based on the depth of excavation and anticipated duration of excavation/restoration for the sub area. Excavation will be completed when the canal is drained to facilitate dewatering and access. Stormwater discharges into the area of the canal being remediated will be diverted past the work area by gravity diversion or pumping. Excavation of each area will include the following general steps:

- Establish temporary access to the work area.
- Establish temporary controls including isolation of the work area and diversion of any surface water flow in the canal around the work area. The appropriate method for isolating the work area will be determined based on the adjacent topography, depth of removal, and sediment stability.
- Excavate sediment to the lines and grades established in the design. Excavated sediment will be transported to a dewatering/stabilization area established prior to initiating sediment excavation. Manage excavation procedures and controls as necessary to control air quality and odor.
- Collect potentially impacted water within the excavation and transfer to the temporary on-site water treatment facility. Continue water management until SCGs are met and as necessary during restoration.
- If excavation does not extend to bedrock or the canal liner, collect and analyze verification samples in accordance with the approved verification sampling program. The potential to establish pre-defined excavation limits in place of verification sampling will be considered as part of the detailed design process based on an evaluation of the sufficiency of the delineation sampling data. Excavation to pre-defined limits for sediment containing <50 mg/kg PCBs will be employed if determined to be technically appropriate, subject to NYSDEC approval.
- Implement excavation until excavation area meets SCGs or bedrock is reached.
- Restore the canal liner if necessary and place additional backfill if required to meet design grades following procedures discussed in Section 4.4.
- Remove temporary access and controls no longer required.
- Maintain isolation of restored areas to protect against recontamination from adjacent areas which have not been remediated.

The design will include a phasing plan identifying the anticipated progression of the work. The plan will be designed to be adaptive to allow for modification during implementation to manage changes in conditions.

4.4 WATER TIGHTNESS OF THE CANAL

A plan will be developed for the canal, in consultation with the NYS Canal Corporation, with the primary objective being to maintain water-tightness of the canal consistent with the existing conditions. Backfill will not extend beyond the original canal design depth except as required to achieve water-tightness of the restored canal. Consultation with

the NYS Canal Corporation will include an assessment of any limitations on excavation or verification sampling based on the necessity to ensure canal liner integrity.

Backfill materials will be specified which meet the requirements of the NYS Canal Corporation and criteria established in 6 NYCRR Part 375 for ecological resources. Any areas outside of the canal limits which are disturbed as part of the RA will be repaired to match pre-existing conditions or restored to conditions agreed upon by the affected property owner.

The use of institutional controls and development of a Site Management Plan following remediation are not anticipated to be required. Should these elements be determined to be required during detailed design or implementation, they will be developed consistent with NYSDEC requirements and incorporated into the Site Management Plan developed as outlined in the RD/RA Work Plan for OU-1 and Upland Source Soils in OU-3 dated July 9, 2013.

5.0 PREDESIGN DATA COLLECTION ACTIVITIES

Pre-design activities will be conducted to collect additional data necessary to complete the RD. The Pre-design activities are described in the following sections.

5.1 SEDIMENT VOLUME DELINEATION

A RD could be completed with the available information, however, additional delineation in the areas identified in Section 2.3 of this Work Plan will increase certainty in volume estimates and increase efficiency in implementing the RA.

Additional sediment delineation is recommended to meet the following objectives:

1. Further delineate vertical extent of material exceeding 50 mg/kg PCBs in OU-3 sediment
2. Further delineate vertical and horizontal extent of material exceeding 1 mg/kg PCBs in OU-3 sediment
3. Confirm and refine the limits of areas of sediment which do not exceed the PCB SCGs and which may remain in place
4. Identify any significant layers of non-TSCA regulated sediment overlying TSCA regulated sediment which may be effectively segregated from TSCA material
5. Identify layers of sediment with PCBs at concentrations below the SCGs which overly sediment exceeding SCGs and which may be effectively segregated and remain in the canal
6. Identify the depth to the canal liner and possibly bedrock in the canal

Figures 2.5 and 2.6 identify proposed sediment sampling locations based on the review of available data. At these locations, sediment samples will be collected in 1-foot increments from the starting elevation to bedrock (or a maximum depth of 8 feet). The depth of investigation varies based on the location and purpose of the location. Table 2.2 summarizes the anticipated starting depth for sampling at each location. Samples will be analyzed sequentially from the top interval until a sample interval with PCB concentrations below the PCB SCG is identified. For sample locations co-located with an existing boring, intervals already characterized will not be re-analyzed.

Samples collected for PCB analysis will also be evaluated to obtain physical data (grain size, moisture content) and Total Organic Carbon (TOC) data. Grain size and TOC

samples will be selected in the field to be representative of differing sediment deposits based on visual classification. It is anticipated that approximately ten samples will be collected for each parameter. Moisture content will be determined for all samples analyzed for PCBs.

A total of 42 locations are proposed. Sampling procedures and analytical methods, including the collection of duplicate and Quality Assurance/Quality Control samples, will follow the requirements of the Field Sampling Plan (FSP) and Quality Assurance Project Plan (QAPP) which will be developed and submitted for approval prior to initiating field activities. Waste materials will be handled in accordance with the Waste Management Plan (WMP). All site activities will be completed in accordance with the site Health and Safety Plan (HASP). These documents are included in Appendices B through E. Sufficient sample volume will be collected from within the over 50 mg/kg PCB sediment and under 50 mg/kg PCB sediment to allow characterization for disposal of each waste stream. Analytical parameters and methods for waste characterization are included on Tables 4.1 and 4.4 of the QAPP (Appendix C).

Borings which extend through the canal liner will be backfilled with bentonite to restore the liner integrity.

Sampling will be scheduled to be completed from a boat when the canal is full. This will eliminate the need for water management during the sampling activities and facilitate access. A work permit from the NYS Canal Corporation will be obtained prior to initiating sampling.

5.2 DEWATERING/STABILIZATION OF DREDGED SEDIMENT

As the canal is dewatered annually, it will be most effective to remove impacted sediment from the canal while it is dewatered. The water content of the sediment is likely to be lower than typical for sediment removal projects completed through the water column. It may be more cost effective to add stabilization reagents to materials as a means of meeting disposal facility requirements than to further dewater materials. Limited bench scale treatability testing will be completed to evaluate the effectiveness of gravity dewatering, mechanical dewatering, and stabilization to support this evaluation as part of the design process.

Bulk samples of sediment will be collected while the canal is dewatered for the winter to support bench scale treatability testing of sediments. Approximately 20 gallons of

sediment will be collected and transported under chain-of-custody protocols to CRA's Treatability Testing Laboratory in Niagara Falls, NY.

Upon receipt, sediment will be physically characterized to determine moisture content, grain size distribution, and organic content. Collected sediment will be kept in sealed, refrigerated containers to maintain the as-received moisture content. Testing will include gravity dewatering, mechanical dewatering by filter press, and solidification utilizing locally sourced pozzolonic reagents. Dewatering tests will be completed in triplicate. Five dosages of each solidification reagent will be blended with the sediment. Following dewatering or blending with the solidification reagent, each sample will undergo Paint Filter Liquid testing (method SW 846 9095B). The objective of the testing is to identify the most cost effective method(s) of making the sediment suitable for disposal at appropriately permitted off-site landfills (i.e., amended sediment will meet the paint filter test requirements).

The results of this testing will be provided in a technical memorandum. This technical memorandum will summarize sample collection and handling, characterization, and testing procedures and results. This evaluation will provide the Design Team with the necessary information to develop an appropriate and cost-effective approach to material handling.

5.3 WASTEWATER CHARACTERIZATION

Concurrently with the completion of the sediment treatability testing, wastewater will be generated in the Treatability Study Laboratory using site water and sediment to evaluate the treatment requirements for water collected during the sediment remediation. Wastewater generated from mechanical dewatering of the sediments during the treatability study will be collected and characterized by the project laboratory for Site-related compounds and general chemistry parameters identified in Appendix C. This water will represent the worst-case water to be generated at the Site. As part of the design process, the characteristics of the influent to the temporary water treatment system will be estimated based on assessment of the volume and quality of water from each source (precipitation, surface water, groundwater, and dewatering filtrate).

Estimates of the anticipated quantity and quality of water requiring treatment will be estimated from the following sources:

- The dewatering filtrate generation rate and quality will be obtained from the treatability study

- Groundwater generation rates will be estimated from the water level and soil property information available from previous investigations and obtained during the OU-3 upland soils investigation. Groundwater quality information for groundwater discharging from the Site will be estimated from investigative data.
- Surface water generation rates from direct precipitation and runoff from adjacent areas will be estimated utilizing published precipitation data from the closest meteorological station to the Site and regulatory design storm events. Drainage areas from adjacent upland areas will be estimated from GIS-based topographic information.
- Stormwater entering the canal from point sources (storm sewers) will be bypassed around the work area to eliminate the need for treatment.

Based on the information developed from these activities, minimum treatment system capacities and treatment components will be established. Discharge criteria and monitoring information applicable to discharge from the system under a SPDES discharge will be developed during the design. Detailed design of the treatment system will be completed by the selected contractor to allow them to optimize the design based on treatment units available to them.

5.4 UTILITY LOCATES AND OTHER PRE-DESIGN ACTIVITIES

Local utilities will be contacted to identify the availability of utilities which may be needed to support remedy implementation and utilities which exist within areas to be investigated or remediated. Additional assessments of potential access points, nearby receptors (for dust, noise, and odor management planning), staging areas, and haul routes will also be completed by personnel while on Site for characterization activities.

6.0 REMEDIAL ACTION PROJECT PLANS

This section provides an overview of the following Project Plans that were presented as appendices to the OU-1 and Upland Source Soils in OU-3 RD/RA Work Plan previously submitted:

- Appendix B - Health and Safety Plan
- Appendix C - Quality Assurance Project Plan
- Appendix D - Waste Management Plan
- Appendix E - Field Sampling Plan

The aforementioned Project Plans were designed to provide the procedures and protocols that are necessary to support the remedial activities. All work will be conducted in accordance with the Project Plans.

6.1 HEALTH AND SAFETY PLAN

A Site-specific Health and Safety Plan (HASP) is required to ensure that all remedial activities are performed safely and in accordance with applicable regulatory requirements, and that all persons, the general public, and the environment are protected from exposure to Site-related contaminants. The health and safety requirements for the remedial activities were developed in accordance with 29 CFR 1910. The HASP includes:

- General requirements
- Personnel
- Levels of protection
- Safe work practices and safeguards
- Medical surveillance
- Personal and environmental air monitoring
- Personal protective equipment
- Personal hygiene
- Decontamination of personnel and equipment
- Site work zones
- Contaminant control

- Contingency and emergency planning
- Logs, reports, and recordkeeping
- Community Air Monitoring Plan

6.2 QUALITY ASSURANCE PROJECT PLAN

The field and laboratory quality assurance objectives, protocols, and procedures supporting the waste characterization and pre-design sampling activities are provided in the Quality Assurance Project Plan (QAPP). The QAPP includes:

- Project description
- Project organization
- Project responsibilities
- Sampling and custody procedures
- Calibration procedures
- Quality assurance (QA) objectives
- Analytical procedures
- Data analysis and reporting
- Internal quality control (QC) checks
- Performance and system audits
- Preventative maintenance
- Method-specific procedures for assessing data precision, accuracy, and completeness
- Laboratory corrective actions
- Quality assurance (QA) reports.

6.3 FIELD SAMPLING PLAN

A Site-specific Field Sampling Plan (FSP) is required to ensure that sampling and analyses are performed to established and accepted protocols. All sampling and analyses will be conducted as part of a quality assurance program to ensure that accurate and precise analytical results are obtained. All sampling and analysis activities will be completed in accordance with the FSP presented in Appendix E. The FSP includes:

- Number of samples to be collected
- Sampling protocols
- Sample collection locations
- Special sample collection equipment and techniques (if required)
- Analytical method to be used

7.0 REMEDIAL DESIGN

7.1 PRELIMINARY DESIGN

At the Preliminary Design stage, all pre-design data collection would be complete and technical requirements of the remediation are addressed and outlined in sufficient detail in order that they may be reviewed to determine if the Final Design will provide a constructible, effective remedy for the Site. NYSDEC comments on the Preliminary Design will be addressed as the design proceeds to the Pre-Final Design.

The Preliminary Design will consist of the following components:

- Draft Design Report including summary of Pre-Design Investigations and the Design narrative
- Draft Design drawings and list of project specifications including restoration details
- Major Design Calculations
- Draft Construction Quality Assurance Plan
- Draft Risk Management Plan
- Discussion of permits and approvals
- Discussion of temporary facilities and controls including water management and odor control measures
- Updated Project Schedule
- Preliminary Construction Cost Estimate

7.1.1 PRELIMINARY DESIGN REPORT

The Preliminary Design Report will present all of the pre-design data and a detailed description of all preliminary design assumptions and parameters, the basis and rationale for all technical aspects of the design including supporting calculations, and the interaction of the various design components. Calculations will be included for the dewatering requirements and volume of sediment to excavate. The Preliminary Design Report will, at a minimum, address the following:

OU-3

- Results for additional sediment sampling
- Dewatering of sediment excavated from below the water table

- Treatment of water/discharge
- Specification for fill quality and canal restoration requirements/grades
- Phasing of work area isolation and remediation
- Procedures to isolate work areas and for water management
- Adaptive odor control system procedures and equipment
- Site logistics including dewatering/stabilization area, water treatment area, lay down area, decon area, street access, equipment placement, material stockpiling, material handling, truck staging
- Design considerations or limitations to ensure liner integrity is maintained
- Sequence of operations
- Procedures for Verification sampling to confirm SCGs have been achieved (if excavation is not limited by bedrock or the canal liner)
- Transportation routes to disposal facilities

7.1.2 PRELIMINARY PLANS AND SPECIFICATIONS

The preliminary plans and specifications will include an outline of required drawings, specifications, and performance standards. Drawings will be prepared to present the conceptual aspects of the design. The drawings will be of sufficient detail to provide the reviewer with a clear understanding of the major components of the remediation and the interaction of the key components.

Appropriate project specifications will be selected during the Preliminary Design phase of the work. An outline of the required specifications will be prepared and submitted with the Preliminary Design.

7.2 PRE-FINAL/FINAL DESIGN

The Pre-Final Design will address comments generated from NYSDEC, and permitting authorities on the Preliminary Design review, and clearly show any modification of the design as a result of incorporation of the comments. The Pre-Final Design will function as the draft version of the Final Design. The package will represent a complete peer-reviewed design, subject to final review by the NYSDEC.

Following NYSDEC review and comment on the Pre-Final Design, the Final Design will be prepared along with a memorandum indicating how the Pre-Final Design comments

were incorporated into the Final Design. All Final Design documents will be certified by a Professional Engineer registered in the State of New York. The Pre-Final/Final Design will consist of the following components:

- Design Report
- Plans and Specifications
- Waste Management Plan
- Construction Quality Assurance Project Plan
- Construction Health and Safety Plan
- Construction Schedule

7.2.1 DESIGN REPORT

The Design Report will present a detailed description of all design assumptions and parameters, the basis and rationale for all technical aspects of the design including supporting calculations, and the interaction of the various design components. The selected design will be presented along with an analysis supporting the design approach.

7.2.2 PLANS AND TECHNICAL SPECIFICATIONS

A complete set of construction drawings and technical specifications will be submitted, which describe the selected design. This will include detailed design and specifications for all excavations, fill material, soil cover, excavation shoring, excavation dewatering and water treatment, and soil erosion and sediment control.

It is anticipated that the drawing package will include the following drawings:

- Overall Site Plan and General Notes
- Excavation areas and excavation depths
- Excavation shoring for OU-3 TSCA sediment removal
- Excavation phasing plan
- Work area isolation and water management plan and details
- Proposed canal liner restoration details and final grade contours
- Site security details

7.2.3 WASTE MANAGEMENT PLAN

The Waste Management Plan will describe procedures and protocols for the handling of materials generated during the remediation, which includes construction, and dewatering and excavation activities. The Waste Management Plan is presented in Appendix E and will be updated as necessary for the final design. Potential types of wastes that may be generated include, but may not be limited to the following:

- Aqueous waste
- Solid waste (e.g., drill cuttings, personal protective equipment)
- Impacted soil/sediment materials.

The overall objectives of the Waste Management Plan are to:

- Minimize the quantity of waste generated and requiring off-Site disposal
- Prevent commingling of different waste streams
- Ensure wastes are properly managed on Site to prevent releases to the environment or contamination of otherwise clean areas of the Site
- Manage all wastes in accordance with applicable regulations

The procedures and protocols outlined in the Waste Management Plan will include proper management, characterization testing/sampling, treatment, and transportation and/or disposal of wastes generated during the remediation. These procedures will be performed in conjunction with those presented in the Construction Health and Safety Plan.

The Waste Management Plan may be revised/expanded as appropriate as the remediation work progresses to include information, methodologies, and procedures associated with any changes in work scope and/or Site conditions.

7.2.4 CONSTRUCTION HEALTH AND SAFETY PLAN

A project-specific HASP will be prepared by the remedial contractor to describe the health and safety procedures and emergency response guidelines to be implemented during the construction phase of the project.

During construction activities, personnel will be working with heavy equipment and may come into contact with soils, groundwater, and waste materials, which potentially contain hazardous substances. The HASP will be developed to ensure the following:

- That Site personnel are appropriately trained and aware of potential hazards at the Site.
- That Site personnel are not adversely exposed to the compounds of concern.
- Compliance with applicable governmental and non-governmental (American Conference of Governmental Industrial Hygienists [ACGIH]) regulations and guidelines. In particular, the amended rules of the Occupational Safety and Health Administration (OSHA) for Subpart D of Part 1926 (Title 29 Code of Federal Regulations [CFR] Part 1926.65) will be implemented for Site work where there is a potential to come in contact with hazardous substances.
- Initiation of proper emergency response procedures to minimize the potential for any adverse impact to Site workers, the general public, or the environment.

All on-Site workers will have completed the 40-hour HAZWOPER training and annual refresher training pursuant to OSHA regulations.

7.2.5 CONSTRUCTION SCHEDULE

The Pre-Final/Final Design will include a final construction schedule.

8.0 SCHEDULE


A schedule for completing the RD is presented on Figure 8.1. The RD will include a schedule for implementing the RA.

9.0 PROGRESS REPORTS

Progress reports will be submitted to NYSDEC and NYSDOH by the tenth day of each month commencing with the month subsequent to the approval of the first Work Plan and ending with the termination date. The progress reports will include at a minimum:

- All actions taken pursuant to the Order during the reporting period and those anticipated for the upcoming reporting period
- All approved modifications to work plans and/or schedules
- All results of sampling and tests, and all other data received or generated by or on behalf of the Companies in connection with the Site during the reporting period, including quality assurance/quality control information
- Information regarding percentage of completion, unresolved delays encountered or anticipated that may affect the future schedule, and efforts made to mitigate such delays

FIGURES



USGS QUADRANGLE MAP
NORTH TROY, NEW YORK



0 1000 2000ft

figure 1.1

SITE LOCATION
FRIEDRICHSOHN COOPERAGE SITE
153-155 Saratoga Ave., Waterford, N. Y.



SOURCE: FOCUSED REMEDIAL INVESTIGATION FEASIBILITY STUDY,
MALCOLM PIRNIE, INC., FIGURE 2, APRIL 2010




figure 2.1
SITE PLAN
FRIEDRICHSOHN COOPERAGE SITE
153-155 Saratoga Ave., Waterford, N.Y.





figure 2.2
 SEDIMENT BELOW OR POTENTIALLY BELOW 1 mg/kg PCBs
 FRIEDRICHSOHN COOPERAGE SITE
 153-155 Saratoga Ave, Waterford, NY

SOURCE: TOPOGRAPHIC SURVEY, POPLI DESIGN GROUP, AUGUST 2009,
 TOPOGRAPHIC SURVEY OF CANAL, MJ ENGINEERING AND LAND
 SURVEYING, P.C., APRIL 2011
 BASE DRAWING INFORMATION FROM .PDF FILES OF MALCOLM
 PIRNIE FIGURES PROVIDED AS PART OF THE RFP PACKAGE.



Burton Avenue



O'Connor St.


- Legend**
- Sediment Sample Locations
 - ▭ Approximate Site Boundary
 - ▭ Areas with Confirmed Exceedances of PCB SCG (1 mg/kg PCBs) at Depths >2 Feet
 - ▭ Exceedance of SCG (1 mg/kg PCBs) not Vertically Bounded

figure 2.3

GAPS IN VERTICAL PCB DELINEATION - SEDIMENT
 FRIEDRICHSOHN COOPERAGE SITE
 153-155 Saratoga Ave, Waterford, NY



SOURCE: TOPOGRAPHIC SURVEY, POPLI DESIGN GROUP, AUGUST 2009,
 TOPOGRAPHIC SURVEY OF CANAL, MJ ENGINEERING AND LAND
 SURVEYING, P.C., APRIL 2011
 BASE DRAWING INFORMATION FROM .PDF FILES OF MALCOLM
 PIRNIE FIGURES PROVIDED AS PART OF THE RFP PACKAGE.






figure 2.5
 PROPOSED SEDIMENT SAMPLING LOCATIONS
 FRIEDRICHSOHN COOPERAGE SITE
 153-155 Saratoga Ave, Waterford, NY

SOURCE: TOPOGRAPHIC SURVEY, POPLI DESIGN GROUP, AUGUST 2009,
 TOPOGRAPHIC SURVEY OF CANAL, MJ ENGINEERING AND LAND
 SURVEYING, P.C., APRIL 2011
 BASE DRAWING INFORMATION FROM .PDF FILES OF MALCOLM
 PIRNIE FIGURES PROVIDED AS PART OF THE RFP PACKAGE.





figure 2.6

**PROPOSED SEDIMENT SAMPLING LOCATIONS - ADJACENT TO SITE
FRIEDRICHSOHN COOPERAGE SITE
153-155 Saratoga Ave, Waterford, NY**



SOURCE: TOPOGRAPHIC SURVEY, POPLI DESIGN GROUP, AUGUST 2009,
TOPOGRAPHIC SURVEY OF CANAL, MJ ENGINEERING AND LAND
SURVEYING, P.C., APRIL 2011
BASE DRAWING INFORMATION FROM .PDF FILES OF MALCOLM
PIRNE FIGURES PROVIDED AS PART OF THE RFP PACKAGE.



080987 RPT5 Fig. 8.1
 Task Milestone Summary Manual Progress

Notes:
 (1) Sediment sampling requires sufficient water depth in the canal to allow access by the sampling boat. Schedule may need to be extended if the timing for approval of the RD/RA Work Plan would result in sampling being scheduled when the canal is drained for the winter.

FIGURE 8.1: OU-3 SEDIMENT RD/RA WORK PLAN SCHEDULE
FRIEDRICHSOHN COOPERAGE SITE
153-155 SARATOGA AVE., WATERFORD, N.Y.

TABLES

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
SD-1	5-46-045-SD-01D	4/23/2008	0.75-1.5	60000
SD-1	5-46-045-SD-01S	4/23/2008	0-0.75	3400
FC-SD-01	FC-SD-01 (0-2)	8/17/2009	0-2 ft BGS	1157
FC-SED01	FC-TCLP-SED01	4/1/2010	- depth unknown	7450
SD-1	SD-1(0-0.5)	1/4/2011	0-0.5 ft BGS	2100
SD-1	SD-1(1.5-2)	1/4/2011	1.5-2 ft BGS	9600
SD-2	5-46-045-SD-02D	4/23/2008	0.75-1.5	320
SD-2	5-46-045-SD-02S	4/23/2008	0-0.75	120 R
FC-SD-02	FC-SD-02 (0-2)	8/17/2009	0-2 ft BGS	4690
FC-SED02	FC-TCLP-SED02	4/1/2010	- depth unknown	26000
SD-2	SD-2(0-0.5)	1/4/2011	0-0.5 ft BGS	1100
SD-2	SD-2(1.5-2)	1/4/2011	1.5-2 ft BGS	65
SD-2	SD-2(4-4.5)	1/4/2011	4-4.5 ft BGS	ND(25)
SD-3	5-46-045-SD-03D	4/23/2008	0.75-1.5	23000
SD-3	5-46-045-SD-03S	4/23/2008	0-0.75	180000
FC-SD-03	FC-SD-03 (0-2)	8/17/2009	0-2 ft BGS	17880
FC-SED03	FC-TCLP-SED03	4/1/2010	- depth unknown	2200000
SD-3	SD-3(0-0.5)	1/4/2011	0-0.5 ft BGS	24000
SD-3	SD-3(1.5-2)	1/4/2011	1.5-2 ft BGS	ND(28)
SD-4	5-46-045-SD-04D	4/23/2008	0.75-1.5	47
SD-4	5-46-045-SD-04S	4/23/2008	0-0.75	410 R
FC-SD-04	FC-SD-04 (0-2)	8/17/2009	0-2 ft BGS	8820
FC-SED04	FC-TCLP-SED04	4/1/2010	- depth unknown	33000
SD-4	SD-4(0-0.5)	1/4/2011	0-0.5 ft BGS	110
SD-4	SD-4(1.5-2)	1/4/2011	1.5-2 ft BGS	630
FC-SD-05	FC-SD-05 (0-2)	8/17/2009	0-2 ft BGS	4530
FC-SED05	FC-TCLP-SED05	4/1/2010	- depth unknown	5000
SD-5	SD-5(0-0.5)	1/4/2011	0-0.5 ft BGS	700
SD-5	SD-5(1.5-2)	1/4/2011	1.5-2 ft BGS	370
SD-5	SD-5(2.5-2.75)	1/4/2011	2.5-2.75 ft BGS	200 / 190
FC-SD-06	FC-SD-06 (0-2)	8/17/2009	0-2 ft BGS	13200
SD-6	SD-6(0-0.5)	1/4/2011	0-0.5 ft BGS	ND(28) / ND(28)
SD-6	SD-6(1.5-2)	1/4/2011	1.5-2 ft BGS	ND(29)
SD-6	SD-6(2.5-3)	1/4/2011	2.5-3 ft BGS	ND(27) / ND(27)
FC-SD-07	FC-SD-07 (0-2)	8/17/2009	0-2 ft BGS	16000
SD-7	SD-7(0-0.5)	1/4/2011	0-0.5 ft BGS	1500
SD-7	SD-7(1-1.5)	1/4/2011	1-1.5 ft BGS	440 / 4460 P
SD-7	SD-7(3-3.5)	1/4/2011	3-3.5 ft BGS	20
SD-7	SD-X	1/4/2011	0-0.5 ft BGS	6500
FC-SD-08	FC-SD-08 (0-2)	8/17/2009	0-2 ft BGS	4810
SD-8	SD-8(0-0.5)	1/4/2011	0-0.5 ft BGS	220000
SD-8	SD-8(1.5-2)	1/4/2011	1.5-2 ft BGS	7900
SD-8	SD-8(2.5-3)	1/4/2011	2.5-3 ft BGS	170000

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
FC-SD-09	FC-SD-09 (0-2)	8/17/2009	0-2 ft BGS	3800
SD-9	SD-9(0-0.5)	1/5/2011	0-0.5 ft BGS	6300
SD-9	SD-X2	1/5/2011	0-0.5 ft BGS	20000
FC-SD-10	FC-SD-10 (0-2)	8/17/2009	0-2 ft BGS	1172
SD-10	SD-10(0-0.5)	1/5/2011	0-0.5 ft BGS	1300000
SD-10	SD-10(1.5-2)	1/5/2011	1.5-2 ft BGS	39000
FC-SD-11	FC-SD-11 (0-1)	8/18/2009	0-1 ft BGS	4730
SD-11	SD-11(0-0.5)	1/5/2011	0-0.5 ft BGS	15000
SD-11	SD-11(1.5-2)	1/5/2011	1.5-2 ft BGS	44000
SD-11	SD-11(3.5-4)	1/5/2011	3.5-4 ft BGS	300000
FC-SD-12	FC-SD-12 (0-2)	8/18/2009	0-2 ft BGS	5790
SD-12	SD-12(0-0.5)	1/5/2011	0-0.5 ft BGS	350000
SD-12	SD-12(1.5-2)	1/5/2011	1.5-2 ft BGS	1100000
SD-12	SD-12(4-4.5)	1/5/2011	4-4.5 ft BGS	230000
SD-12	SD-12(6-6.5)	1/5/2011	6-6.5 ft BGS	13000
FC-SD-13	FC-SD-13 (0-2)	8/18/2009	0-2 ft BGS	4770
SD-13	SD-13(0-0.5)	1/5/2011	0-0.5 ft BGS	19000
SD-13	SD-13(1.5-2)	1/5/2011	1.5-2 ft BGS	1500000
SD-13	SD-13(4-4.5)	1/5/2011	4-4.5 ft BGS	650000
FC-SD-14	FC-SD-14 (0-3)	8/18/2009	0-3 ft BGS	36100
SD-14	SD-14(0-0.5)	1/5/2011	0-0.5 ft BGS	17000
SD-14	SD-14(1.5-2)	1/5/2011	1.5-2 ft BGS	5700000
SD-14	SD-14(2-2.5)	1/5/2011	2-2.5 ft BGS	1000000
FC-SD-15	FC-SD-15 (0-6)	8/18/2009	0-6 ft BGS	1777
SD-15	SD-15(0-0.5)	1/5/2011	0-0.5 ft BGS	11000
SD-15	SD-15(1.5-2)	1/5/2011	1.5-2 ft BGS	5100000
SD-15	SD-15(4.5-5)	1/5/2011	4.5-5 ft BGS	140000
FC-SD-16	FC-SD-16 (0-3)	8/18/2009	0-3 ft BGS	462
SD-16	SD-16(0-0.5)	1/6/2011	0-0.5 ft BGS	9800
SD-16	SD-16(1.5-2)	1/6/2011	1.5-2 ft BGS	230000
SD-16	SD-16(3-3.5)	1/6/2011	3-3.5 ft BGS	12000
SD-16	SD-X3	1/6/2011	1.5-2 ft BGS	260000
FC-SD-17	FC-SD-17 (0-2)	8/18/2009	0-2 ft BGS	41500
SD-17	SD-17(0-0.5)	1/6/2011	0-0.5 ft BGS	5400
SD-17	SD-17(1.5-2)	1/6/2011	1.5-2 ft BGS	250000
SD-17	SD-17(5-5.5)	1/6/2011	5-5.5 ft BGS	22000
FC-SD-18	FC-SD-18 (0-6)	8/18/2009	0-6 ft BGS	5850
SD-18	SD-18(0-0.5)	1/6/2011	0-0.5 ft BGS	2900
SD-18	SD-18(1.5-2)	1/6/2011	1.5-2 ft BGS	5800
SD-18	SD-18(5-5.5)	1/6/2011	5-5.5 ft BGS	2400
FC-SD-19	FC-SD-19 (0-1)	8/18/2009	0-1 ft BGS	63
SD-19	SD-19(0-0.5)	1/6/2011	0-0.5 ft BGS	7800
SD-19	SD-19(1.5-2)	1/6/2011	1.5-2 ft BGS	40000
SD-19	SD-19(6-6.5)	1/6/2011	6-6.5 ft BGS	830

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
FC-SD-20	FC-SD-20 (0-2)	8/18/2009	0-2 ft BGS	4000
FC-SD-20	FC-SD-X3	8/18/2009	0-2 ft BGS	86000
SD-20	SD-20(0-0.5)	1/6/2011	0-0.5 ft BGS	4200
SD-20	SD-20(1.5-2)	1/6/2011	1.5-2 ft BGS	8600
SD-20	SD-20(6.5-7)	1/6/2011	6.5-7 ft BGS	660
FC-SD-21	FC-SD-21 (0-2)	8/18/2009	0-2 ft BGS	15900
SD-21	SD-21(0-0.5)	1/7/2011	0-0.5 ft BGS	16000
SD-21	SD-21(1.5-2)	1/7/2011	1.5-2 ft BGS	81000
SD-21	SD-21(5.5-6)	1/7/2011	5.5-6 ft BGS	11000
SD-21	SD-X4	1/7/2011	1.5-2 ft BGS	25000
FC-SD-22	FC-SD-22 (0-2)	8/18/2009	0-2 ft BGS	60600
SD-22	SD-22(0-0.5)	1/7/2011	0-0.5 ft BGS	4300
SD-22	SD-22(1.5-2)	1/7/2011	1.5-2 ft BGS	13000
SD-22	SD-22(5-6)	1/7/2011	5-6 ft BGS	8700
FC-SD-23	FC-SD-23 (0-4)	8/18/2009	0-4 ft BGS	141
SD-23	SD-23(0-0.5)	1/7/2011	0-0.5 ft BGS	1700
FC-SD-24	FC-SD-24 (1-3)	8/19/2009	1-3 ft BGS	86
FC-SD-24	FC-SD-24 (4-7)	8/19/2009	4-7 ft BGS	12
FC-SD-24	FC-SD-X4	8/19/2009	1-3 ft BGS	12
SD-24	SD-24(0-0.5)	1/10/2011	0-0.5 ft BGS	690
SD-24	SD-24(1.5-2)	1/10/2011	1.5-2 ft BGS	9100
SD-24	SD-24(4-4.5)	1/10/2011	4-4.5 ft BGS	44000
FC-SD-25	FC-SD-25 (1-2)	8/19/2009	1-2 ft BGS	80
FC-SD-25	FC-SD-25 (5-6)	8/19/2009	5-6 ft BGS	9.5
FC-SD-25	FC-SD-25 (7-8)	8/19/2009	7-8 ft BGS	1337
SD-25	SD-25(0-0.5)	1/10/2011	0-0.5 ft BGS	1500
SD-25	SD-25(1.5-2)	1/10/2011	1.5-2 ft BGS	8300
SD-25	SD-25(4.5-5)	1/10/2011	4.5-5 ft BGS	52000
SD-25	SD-X4	1/10/2011	1.5-2 ft BGS	9600
FC-SD-26	FC-SD-26 (1-4)	8/19/2009	1-4 ft BGS	210000
SD-26	SD-26(0-0.5)	1/10/2011	0-0.5 ft BGS	10000
SD-26	SD-26(1.5-2)	1/10/2011	1.5-2 ft BGS	69000
SD-26	SD-26(4-4.5)	1/10/2011	4-4.5 ft BGS	410000
FC-SD-27	FC-SD-27 (0-1)	8/19/2009	0-1 ft BGS	460
SD-27	SD-27(0-0.5)	1/10/2011	0-0.5 ft BGS	670
SD-27	SD-27(1.5-2)	1/10/2011	1.5-2 ft BGS	37000
SD-27	SD-27(2-2.5)	1/10/2011	2-2.5 ft BGS	28000
FC-SD-28	FC-SD-28 (0-1.5)	8/19/2009	0-1.5 ft BGS	121000
SD-28	SD-28(0-0.5)	1/10/2011	0-0.5 ft BGS	11000
FC-SD-29	FC-SD-29 (0-2)	8/19/2009	0-2 ft BGS	165600
SD-29	SD-29(0-0.5)	1/10/2011	0-0.5 ft BGS	28000
SD-29	SD-29(1.5-2)	1/10/2011	1.5-2 ft BGS	830000
FC-SD-30	FC-SD-30 (0-3)	8/19/2009	0-3 ft BGS	98000
SD-30	SD-30(0-0.5)	1/10/2011	0-0.5 ft BGS	39000

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
SD-30	SD-30(1.5-2)	1/10/2011	1.5-2 ft BGS	27000
SD-30	SD-30(2-2.5)	1/10/2011	2-2.5 ft BGS	23000
FC-SD-31	FC-SD-31 (0-1.5)	8/19/2009	0-1.5 ft BGS	23290
SD-31	SD-31(0-0.5)	1/10/2011	0-0.5 ft BGS	34000
SD-31	SD-31(1.5-2)	1/10/2011	1.5-2 ft BGS	4000000
SD-31	SD-31(2.5-3)	1/10/2011	2.5-3 ft BGS	16000000
FC-SD-32	FC-SD-32	9/30/2009	0-0.5 ft BGS	35
SD-32	SD-32(0-0.5)	1/10/2011	0-0.5 ft BGS	40000
SD-32	SD-32(1.5-2)	1/10/2011	1.5-2 ft BGS	22000
SD-32	SD-32(2.5-3)	1/10/2011	2.5-3 ft BGS	1100
FC-SD-33	FC-SD-33	9/30/2009	0-0.5 ft BGS	38
SD-33	SD-33(0-0.5)	1/11/2011	0-0.5 ft BGS	1600
SD-33	SD-33(1.5-2)	1/11/2011	1.5-2 ft BGS	70000
SD-33	SD-33(2.5-3)	1/11/2011	2.5-3 ft BGS	28000
SD-33	SD-X5	1/11/2011	0-0.5 ft BGS	1900
SD-34	SD-34(0-0.5)	1/11/2011	0-0.5 ft BGS	430
SD-34	SD-34(1.5-2)	1/11/2011	1.5-2 ft BGS	18000
SD-34	SD-34(3-3.5)	1/11/2011	3-3.5 ft BGS	450
SD-35	SD-35(0-0.5)	1/11/2011	0-0.5 ft BGS	2500
SD-35	SD-35(1.5-2)	1/11/2011	1.5-2 ft BGS	14000
SD-35	SD-35(4.5-5)	1/11/2011	4.5-5 ft BGS	170
SD-36	SD-36(0-0.5)	1/11/2011	0-0.5 ft BGS	390
SD-36	SD-36(1.5-2)	1/11/2011	1.5-2 ft BGS	4400
SD-36	SD-36(3-3.5)	1/11/2011	3-3.5 ft BGS	710
SD-36	SD-X6	1/11/2011	0-0.5 ft BGS	450
SD-37	SD-37(0-0.5)	1/11/2011	0-0.5 ft BGS	1200
SD-37	SD-37(1.5-2)	1/11/2011	1.5-2 ft BGS	2400
SD-37	SD-37(4-4.5)	1/11/2011	4-4.5 ft BGS	110
SD-38	SD-38(0-0.5)	1/11/2011	0-0.5 ft BGS	390
SD-38	SD-38(1.5-2)	1/11/2011	1.5-2 ft BGS	5000
SD-38	SD-38(2.5-3)	1/11/2011	2.5-3 ft BGS	3400
SD-39	SD-39(0-0.5)	1/11/2011	0-0.5 ft BGS	4300
SD-39	SD-39(1.5-2)	1/11/2011	1.5-2 ft BGS	ND(390)
SD-40	SD-40(0.5-1)	1/11/2011	0.5-1 ft BGS	2600
SD-40	SD-40(0-0.5)	1/11/2011	0-0.5 ft BGS	1100
SD-41	SD-41(0-0.5)	2/22/2011	0-0.5 ft BGS	540
SD-41	SD-41(2-2.5)	2/22/2011	2-2.5 ft BGS	1400
SD-41	SD-41(4-4.5)	2/22/2011	4-4.5 ft BGS	660
SD-42	SD-42(0-0.5)	2/22/2011	0-0.5 ft BGS	340
SD-42	SD-42(2-2.5)	2/22/2011	2-2.5 ft BGS	1700
SD-42	SD-42(4-4.5)	2/22/2011	4-4.5 ft BGS	470
SD-43	022211-SD-X	2/22/2011	4-4.5 ft BGS	170
SD-43	SD-43(0-0.5)	2/22/2011	0-0.5 ft BGS	2540
SD-43	SD-43(2-2.5)	2/22/2011	2-2.5 ft BGS	1500

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
SD-43	SD-43(4-4.5)	2/22/2011	4-4.5 ft BGS	110
SD-44	SD-44(0-0.5)	2/23/2011	0-0.5 ft BGS	700
SD-44	SD-44(2-2.5)	2/23/2011	2-2.5 ft BGS	170
SD-45	SD-45(0-0.5)	2/22/2011	0-0.5 ft BGS	347
SD-45	SD-45(2-2.5)	2/22/2011	2-2.5 ft BGS	350
SD-45	SD-45(4-4.5)	2/22/2011	4-4.5 ft BGS	ND(28)
SD-46	SD-46(0-0.5)	2/22/2011	0-0.5 ft BGS	4200
SD-46	SD-46(2-2.5)	2/22/2011	2-2.5 ft BGS	ND(30)
SD-46	SD-46(4-4.5)	2/22/2011	4-4.5 ft BGS	ND(29)
SD-47	SD-47(0-0.5)	2/22/2011	0-0.5 ft BGS	1930
SD-47	SD-47(2-2.5)	2/22/2011	2-2.5 ft BGS	67
SD-47	SD-47(4-4.5)	2/22/2011	4-4.5 ft BGS	ND(29)
SD-48	SD-48(0-0.5)	2/23/2011	0-0.5 ft BGS	670
SD-48	SD-48(2-2.5)	2/23/2011	2-2.5 ft BGS	18000
SD-48	SD-48(4-4.5)	2/23/2011	4-4.5 ft BGS	2250
SD-49	022311-SD-X	2/23/2011	0-0.5 ft BGS	680
SD-49	SD-49(0-0.5)	2/23/2011	0-0.5 ft BGS	1930
SD-49	SD-49(2-2.5)	2/23/2011	2-2.5 ft BGS	ND(28)
SD-49	SD-49(4-4.5)	2/23/2011	4-4.5 ft BGS	ND(27)
SD-50	SD-50(0-0.5)	2/23/2011	0-0.5 ft BGS	1690
SD-50	SD-50(2-2.5)	2/23/2011	2-2.5 ft BGS	570
SD-50	SD-50(4-4.5)	2/23/2011	4-4.5 ft BGS	ND(26)
SD-51	SD-51(0-0.5)	2/23/2011	0-0.5 ft BGS	960
SD-51	SD-51(2-2.5)	2/23/2011	2-2.5 ft BGS	2700
SD-51	SD-51(4-4.5)	2/23/2011	4-4.5 ft BGS	960
SD-52	SD-52 (0-0.5)	3/22/2011	0-0.5 ft BGS	9090
SD-52	SD-52 (2-2.5)	3/22/2011	2-2.5 ft BGS	16950
SD-52	SD-52 (4-4.5)	3/22/2011	4-4.5 ft BGS	4270
SD-53	SD-53 (0-0.5)	3/22/2011	0-0.5 ft BGS	3170
SD-53	SD-53 (2-2.5)	3/22/2011	2-2.5 ft BGS	1721
SD-53	SD-53 (4-4.5)	3/22/2011	4-4.5 ft BGS	528
SD-54	SD-54 (0-0.5)	3/22/2011	0-0.5 ft BGS	3190
SD-54	SD-54 (2-2.5)	3/22/2011	2-2.5 ft BGS	7450
SD-54	SD-54 (4-4.5)	3/22/2011	4-4.5 ft BGS	5260
SD-55	SD-55 (2-2.5)	3/22/2011	2-2.5 ft BGS	3230
SD-55	SD-55 (4-4.5)	3/22/2011	4-4.5 ft BGS	365
SD-56	SD-56 (0-0.5)	3/22/2011	0-0.5 ft BGS	5040
SD-56	SD-56 (2-2.5)	3/22/2011	2-2.5 ft BGS	2600
SD-57	SD-57 (2-2.5)	3/22/2011	2-2.5 ft BGS	1442
SD-57	SD-57 (3-3.5)	3/22/2011	3-3.5 ft BGS	1468
SD-58	SD-58(0-0.5)	3/21/2011	0-0.5 ft BGS	349
SD-58	SD-58(1-1.5)	3/21/2011	1-1.5 ft BGS	71
SD-59	SD-59 (0-0.5)	3/22/2011	0-0.5 ft BGS	8300
SD-59	SD-59 (2-2.5)	3/22/2011	2-2.5 ft BGS	17270

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
SD-59	SD-59 (4-4.5)	3/22/2011	4-4.5 ft BGS	31500
SD-59	SD-X7	3/22/2011	2-2.5 ft BGS	10080
SD-60	SD-60 (2-2.5)	3/22/2011	2-2.5 ft BGS	82200
SD-60	SD-60 (3-3.5)	3/22/2011	3-3.5 ft BGS	11770
SD-61	SD-61 (0-0.5)	3/22/2011	0-0.5 ft BGS	7370
SD-61	SD-61 (3-3.5)	3/22/2011	3-3.5 ft BGS	4340
SD-62	SD-62(2-2.5)	3/18/2011	2-2.5 ft BGS	ND(19)
SD-63	SD-63 (2-2.5)	3/22/2011	2-2.5 ft BGS	49000
SD-63	SD-63 (4-4.5)	3/22/2011	4-4.5 ft BGS	10740
SD-64	SD-64 (0-0.5)	3/22/2011	0-0.5 ft BGS	3493
SD-64	SD-64 (2-2.5)	3/22/2011	2-2.5 ft BGS	5850
SD-64	SD-64 (4-4.5)	3/22/2011	4-4.5 ft BGS	13100
SD-65	SD-65 (2-2.5)	3/22/2011	2-2.5 ft BGS	14000
SD-65	SD-X8	3/22/2011	2-2.5 ft BGS	6530
SD-66	SD-66(0-0.5)	3/18/2011	0-0.5 ft BGS	238.2
SD-66	SD-66(2-2.5)	3/18/2011	2-2.5 ft BGS	29
SD-66	SD-66(4-4.5)	3/18/2011	4-4.5 ft BGS	51.6
SD-67	SD-67 (0-0.5)	3/22/2011	0-0.5 ft BGS	8810
SD-67	SD-67 (2-2.5)	3/22/2011	2-2.5 ft BGS	6850
SD-67	SD-67 (6-6.5)	3/22/2011	6-6.5 ft BGS	2770
SD-67	SD-X12	3/22/2011	0-0.5 ft BGS	4850
SD-68	SD-68 (0-0.5)	3/22/2011	0-0.5 ft BGS	34400
SD-68	SD-68 (2-2.5)	3/22/2011	2-2.5 ft BGS	70900
SD-68	SD-68 (3-3.5)	3/22/2011	3-3.5 ft BGS	55300
SD-69	SD-69 (2-2.5)	3/22/2011	2-2.5 ft BGS	21700
SD-69	SD-69 (4-4.5)	3/22/2011	4-4.5 ft BGS	19100
SD-70	SD-70(1.8-2.0)	3/16/2011	1.8-2 ft BGS	52.5
SD-73	SD-73(0-0.5)	3/21/2011	0-0.5 ft BGS	302000
SD-73	SD-73(2-2.5)	3/21/2011	2-2.5 ft BGS	76000
SD-73	SD-73(4-4.5)	3/21/2011	4-4.5 ft BGS	110000
SD-74	SD-74(2-2.5)	3/21/2011	2-2.5 ft BGS	19600
SD-74	SD-74(4-4.5)	3/21/2011	4-4.5 ft BGS	6100
SD-75	SD-75(2-2.5)	3/16/2011	2-2.5 ft BGS	ND(22)
SD-75	SD-75(4-4.5)	3/16/2011	4-4.5 ft BGS	ND(22)
SD-77	SD-77(0-0.5)	3/21/2011	0-0.5 ft BGS	186000
SD-77	SD-77(2-2.5)	3/21/2011	2-2.5 ft BGS	89000
SD-77	SD-77(5.5-6)	3/21/2011	5.5-6 ft BGS	125000
SD-78	SD-78(0-0.5)	3/21/2011	0-0.5 ft BGS	59500
SD-78	SD-78(2-2.5)	3/21/2011	2-2.5 ft BGS	690000
SD-78	SD-78(4.5-5)	3/21/2011	4.5-5 ft BGS	24300
SD-79	SD-79(2-2.5)	3/21/2011	2-2.5 ft BGS	1270
SD-79	SD-79(4-4.5)	3/21/2011	4-4.5 ft BGS	2320
SD-80	SD-80(2-2.5)	3/18/2011	2-2.5 ft BGS	48
SD-80	SD-80(6-6.5)	3/18/2011	6-6.5 ft BGS	130

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
SD-81	SD-81(0-0.5)	3/21/2011	0-0.5 ft BGS	15600
SD-81	SD-81(2-2.5)	3/21/2011	2-2.5 ft BGS	124000
SD-81	SD-81(4-4.5)	3/21/2011	4-4.5 ft BGS	N/A
SD-84	SD-84(2-2.5)	3/21/2011	2-2.5 ft BGS	1930
SD-84	SD-84(5-5.5)	3/21/2011	5-5.5 ft BGS	2978
SD-85	SD-85(2-2.5)	3/17/2011	2-2.5 ft BGS	29
SD-85	SD-85(6-6.5)	3/17/2011	6-6.5 ft BGS	20
SD-89	SD-89(2-2.5)	3/21/2011	2-2.5 ft BGS	6180
SD-89	SD-89(4-4.5)	3/21/2011	4-4.5 ft BGS	1490
SD-90	SD-90(2-2.5)	3/18/2011	2-2.5 ft BGS	187
SD-90	SD-90(3.5-4)	3/18/2011	3.5-4 ft BGS	134
SD-91	SD-91(0-0.5)	3/21/2011	0-0.5 ft BGS	3561
SD-91	SD-91(2-2.5)	3/21/2011	2-2.5 ft BGS	4110
SD-91	SD-91(3-3.5)	3/21/2011	3-3.5 ft BGS	535
SD-92	SD-92(0-0.5)	3/21/2011	0-0.5 ft BGS	3920
SD-92	SD-92(2-2.5)	3/21/2011	2-2.5 ft BGS	19700
SD-92	SD-92(3-3.5)	3/21/2011	3-3.5 ft BGS	32300
SD-92	SD-X17	3/21/2011	2-2.5 ft BGS	Duplicate 9100
SD-93	SD-93(0-0.5)	3/21/2011	0-0.5 ft BGS	705
SD-94	SD-94(0-0.5)	3/21/2011	0-0.5 ft BGS	4360
SD-94	SD-94(2-2.5)	3/21/2011	2-2.5 ft BGS	230
SD-103	SD-103(0-0.5)	3/15/2011	0-0.5 ft BGS	1060
SD-103	SD-103(2-2.5)	3/15/2011	2-2.5 ft BGS	26000
SD-103	SD-103(4.5-4.7)	3/15/2011	4.5-4.7 ft BGS	5900
SD-104	SD-104(0-0.5)	3/15/2011	0-0.5 ft BGS	3350
SD-104	SD-104(2-2.5)	3/15/2011	2-2.5 ft BGS	13000
SD-104	SD-104(4.5-5)	3/15/2011	4.5-5 ft BGS	5400
SD-105	SD-105(0-0.5)	3/17/2011	0-0.5 ft BGS	3880
SD-105	SD-105(2-2.5)	3/17/2011	2-2.5 ft BGS	318
SD-105	SD-105(3-3.5)	3/17/2011	3-3.5 ft BGS	147
SD-105	SD-X9	3/17/2011	0-0.5 ft BGS	Duplicate 2160
SD-106	SD-106(2-2.5)	3/17/2011	2-2.5 ft BGS	2850
SD-107	SD-107(0.0.5)	3/17/2011	0-0.5 ft BGS	16690
SD-107	SD-107(2-2.5)	3/17/2011	2-2.5 ft BGS	18800
SD-107	SD-X10	3/17/2011	2-2.5 ft BGS	Duplicate 22700
SD-108	SD-108(2-2.5)	3/17/2011	2-2.5 ft BGS	69
SD-109	SD-109(2-2.5)	3/17/2011	2-2.5 ft BGS	8100
SD-109	SD-109(4-4.5)	3/17/2011	4-4.5 ft BGS	3190
SD-110	SD-110(0-0.5)	3/17/2011	0-0.5 ft BGS	2280
SD-110	SD-110(2-2.5)	3/17/2011	2-2.5 ft BGS	1474
SD-111	SD-111(2-2.5)	3/17/2011	2-2.5 ft BGS	1210
SD-111	SD-111(4-4.5)	3/17/2011	4-4.5 ft BGS	1230
SD-112	SD-112(0-0.5)	3/17/2011	0-0.5 ft BGS	4390
SD-112	SD-112(2-2.5)	3/17/2011	2-2.5 ft BGS	13780

TABLE 2.1

**OU-3 SEDIMENT PCB ANALYTICAL DATA SUMMARY
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>SAMPLE LOCATION</i>	<i>SAMPLE ID</i>	<i>SAMPLE DATE</i>	<i>DEPTH INTERVAL (ft bgs)</i>	<i>TOTAL PCBs (ug/kg)</i>
SD-112	SD-112(4-4.5)	3/17/2011	4-4.5 ft BGS	4930
SD-113	SD-113(0-0.5)	3/17/2011	0-0.5 ft BGS	1990
SD-113	SD-113(2-2.5)	3/17/2011	2-2.5 ft BGS	4760
SD-113	SD-113(4-4.5)	3/17/2011	4-4.5 ft BGS	4000
SD-114	SD-114(2-2.5)	3/17/2011	2-2.5 ft BGS	1790
SD-114	SD-114(4-4.5)	3/17/2011	4-4.5 ft BGS	155
SD-115	SD-115(0-0.5)	3/17/2011	0-0.5 ft BGS	1000
SD-115	SD-115(2-2.5)	3/17/2011	2-2.5 ft BGS	1160
SD-115	SD-115(4-4.5)	3/17/2011	4-4.5 ft BGS	142
SD-115	SD-X11	3/17/2011	2-2.5 ft BGS	Duplicate 694
SD-116	SD-116(2-2.5)	3/17/2011	2-2.5 ft BGS	245.8
SD-116	SD-116(4-4.5)	3/17/2011	4-4.5 ft BGS	210.8
SD-117	SD-117(2-2.5)	3/18/2011	2-2.5 ft BGS	1237
SD-117	SD-117(4-4.5)	3/18/2011	4-4.5 ft BGS	338
SD-118	SD-118(0-0.5)	3/18/2011	0-0.5 ft BGS	344
SD-118	SD-118(2-2.5)	3/18/2011	2-2.5 ft BGS	423
SD-118	SD-118(4-4.5)	3/18/2011	4-4.5 ft BGS	187
SD-119	SD-119(2-2.5)	3/18/2011	2-2.5 ft BGS	645
SD-119	SD-119(4-4.5)	3/18/2011	4-4.5 ft BGS	408
SD-120	SD-120(0-0.5)	3/18/2011	0-0.5 ft BGS	772
SD-120	SD-120(2-2.5)	3/18/2011	2-2.5 ft BGS	2920
SD-120	SD-120(4-4.5)	3/18/2011	4-4.5 ft BGS	1141
SD-121	SD-121(0-0.5)	3/18/2011	0-0.5 ft BGS	1781
SD-121	SD-121(2-2.5)	3/18/2011	2-2.5 ft BGS	13200
SD-121	SD-121(4-4.5)	3/18/2011	4-4.5 ft BGS	131
SD-122	SD-122(2-2.5)	3/18/2011	2-2.5 ft BGS	1143
SD-122	SD-122(4-4.5)	3/18/2011	4-4.5 ft BGS	1150
SD-123	SD-123(0-0.5)	3/18/2011	0-0.5 ft BGS	105
SD-123	SD-123(2-2.5)	3/18/2011	2-2.5 ft BGS	129
SD-123	SD-123(4-4.5)	3/18/2011	4-4.5 ft BGS	157.5
SD-124	SD-124(2-2.5)	3/18/2011	2-2.5 ft BGS	61.6

Notes:

1100 Value exceeds the New York State Standards, Criteria and Guidance (SCG) of 1 ppm
ug/kg - microgram per kilogram

bgs - below ground surface

ND - Non-detect

R - Rejected

**SEDIMENT DELINEATION SAMPLE SUMMARY
FRIEDRICHSOHN COOPERAGE SITE, WATERFORD, NY**

Sample Location	Purpose of Sampling at Location			Start Depth of Sampling (Feet)	Assumed Number of Samples Analyzed
	TSCA Delineation	Aerial Delineation	Vertical Delineation		
SD-200			X	4.5	1
SD-201		X	X	0.0	1
SD-202		X	X	0.0	2
SD-203		X	X	0.0	1
SD-204			X	4.5	1
SD-205			X	4.5	1
SD-206			X	2.5	1
SD-207			X	3.5	1
SD-208			X	5.0	1
SD-209	X	X	X	TBD	3
SD-210	X	X	X	TBD	3
SD-211	X	X	X	2.5	1
SD-212	X	X	X	TBD	3
SD-213	X	X	X	TBD	3
SD-214	X	X	X	TBD	3
SD-215	X		X	5.0	1
SD-216	X		X	4.5	1
SD-217		X	X	4.5	1
SD-218	X			TBD	3
SD-219	X			TBD	3
SD-220	X			TBD	3
SD-221	X			TBD	3
SD-222	X			TBD	3
SD-223	X			TBD	3
SD-224	X			TBD	3
SD-225	X			TBD	3
SD-226	X		X	6.5	1
SD-227			X	3.5	1
SD-228	X		X	4.5	1
SD-229			X	2.5	1
SD-230	X		X	3.5	1
SD-231			X	2.5	1

**SEDIMENT DELINEATION SAMPLE SUMMARY
FRIEDRICHSOHN COOPERAGE SITE, WATERFORD, NY**

<i>Sample Location</i>	<i>Purpose of Sampling at Location</i>			<i>Start Depth of Sampling (Feet)</i>	<i>Assumed Number of Samples Analyzed</i>
	<i>TSCA Delineation</i>	<i>Aerial Delineation</i>	<i>Vertical Delineation</i>		
SD-232		X		0.0	3
SD-233		X		0.0	1
SD-234		X		0.0	1
SD-235		X		0.0	1
SD-236		X		0.0	1
SD-237		X		0.0	1
SD-238		X		0.0	1
SD-239		X		0.0	1
SD-240		X		0.0	1
SD-241			X	4.5	1
Total	19	19	25		71

Samples will be collected from the indicated start depth to bedrock in 1-foot intervals. Samples will be analyzed sequentially downward until a sample below the SCG concentration for PCBs is identified.

TBD - Start depth of sampling to be determined based on the review of all available data.

APPENDICES

APPENDIX A

SEDIMENT ANALYTICAL RESULTS SUMMARY

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Table with 25 columns for Sample Location (SD-1, SD-1, FC-SD-01, FC-SED01, SD-1, SD-1, SD-2, SD-2, FC-SD-02, FC-SED02, SD-2, SD-2, SD-2, SD-2, SD-3, SD-3, FC-SD-03, FC-SED03, SD-3, SD-3, SD-4, SD-4, FC-SD-04, FC-SED04, SD-4) and 3 columns for Parameters, Units, and Criteria. Rows are grouped into Volatile Organic Compounds, Volatile Organic Compounds - TCLP, and Semi-volatile Organic Compounds.

CRA 080987 (5)

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

Sample Location:	SD-1	SD-1	FC-SD-01	FC-SED01	SD-1	SD-1	SD-2	SD-2	FC-SD-02	FC-SED02	SD-2	SD-2	SD-2	SD-2	SD-3	SD-3	FC-SD-03	FC-SED03	SD-3	SD-3	SD-4	SD-4	FC-SD-04	FC-SED04	SD-4
Sample ID:	5-46-045-SD-01D	5-46-045-SD-01S	FC-SD-01 (0-2)	FC-TCLP-SED01	SD-1(0-0.5)	SD-1(1.5-2)	5-46-045-SD-02D	5-46-045-SD-02S	FC-SD-02 (0-2)	FC-TCLP-SED02	SD-2(0-0.5)	SD-2(1.5-2)	SD-2(4-4.5)	5-46-045-SD-03D	5-46-045-SD-03S	FC-SD-03 (0-2)	FC-TCLP-SED03	SD-3(0-0.5)	SD-3(1.5-2)	5-46-045-SD-04D	5-46-045-SD-04S	FC-SD-04 (0-2)	FC-TCLP-SED04	SD-4(0-0.5)	
Sample Date:	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	
Sample Depth:	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	
Parameters	Units	Criteria																							
2,6-Dinitrotoluene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
2-Chloronaphthalene	ug/kg	-	-	2300 U	-	660 U	150 J	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
2-Chlorophenol	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
2-Methylnaphthalene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	180 J	-	540 U	110 J	490 U	-	-	140 J	-	2300 U	540 U	-	-	2600 U	-	2100 U
2-Methylphenol	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	81 J	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
2-Nitroaniline	ug/kg	-	-	14000 U	-	660 U	510 U	-	-	16000 U	-	540 U	460 U	490 U	-	-	13000 U	-	2300 U	540 U	-	-	16000 U	-	2100 U
2-Nitrophenol	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
3&4-Methylphenol	ug/kg	-	-	-	-	660 U	190 J	-	-	-	-	540 U	180 J	490 U	-	-	-	-	2300 U	540 U	-	-	-	-	2100 U
3,3'-Dichlorobenzidine	ug/kg	-	-	5700 U	-	660 U	510 U	-	-	6200 U	-	540 U	460 U	490 U	-	-	5300 U	-	2300 U	540 U	-	-	6400 U	-	2100 U
3-Nitroaniline	ug/kg	-	-	14000 U	-	660 U	510 U	-	-	16000 U	-	540 U	460 U	490 U	-	-	13000 U	-	2300 U	540 U	-	-	16000 U	-	2100 U
4,6-Dinitro-2-methylphenol	ug/kg	-	-	14000 U	-	660 U	510 U	-	-	16000 U	-	540 U	460 U	490 U	-	-	13000 U	-	2300 U	540 U	-	-	16000 U	-	2100 U
4-Bromophenyl phenyl ether	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
4-Chloro-3-methylphenol	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	-	540 U	-	-	2600 U	-	2100 U
4-Chloroaniline	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
4-Chlorophenyl phenyl ether	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
4-Methylphenol	ug/kg	-	-	2300 U	-	-	-	-	-	2500 U	-	-	-	-	-	-	2100 U	-	-	-	-	-	2600 U	-	-
4-Nitroaniline	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
4-Nitrophenol	ug/kg	-	-	14000 U	-	660 U	510 U	-	-	16000 U	-	540 U	460 U	490 U	-	-	13000 U	-	2300 U	540 U	-	-	16000 U	-	2100 U
Acenaphthene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	160 J	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Acenaphthylene	ug/kg	-	-	2300 U	-	660 U	98 J	-	-	2500 U	-	540 U	73 J	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Acetophenone	ug/kg	-	-	-	-	660 U	510 U	-	-	-	-	540 U	460 U	490 U	-	-	-	-	2300 U	540 U	-	-	-	-	2100 U
Anthracene	ug/kg	-	-	170 J	-	660 U	110 J	-	-	170 J	-	540 U	160 J	490 U	-	-	2100 U	-	2300 U	150 J	-	-	580 J	-	2100 U
Atrazine	ug/kg	-	-	-	-	660 U	510 U	-	-	-	-	540 U	460 U	490 U	-	-	-	-	2300 U	540 U	-	-	-	-	2100 U
Benzaldehyde	ug/kg	-	-	-	-	660 U	510 U	-	-	-	-	540 U	460 U	490 U	-	-	-	-	2300 U	540 U	-	-	-	-	2100 U
Benzo(a)anthracene	ug/kg	-	-	720 J	-	120 J	280 J	-	-	680 J	-	170 J	500	-	-	330 J	-	530 J	470 J	-	-	2200 J	-	810 J	
Benzo(a)pyrene	ug/kg	-	-	690 J	-	130 J	230 J	-	-	660 J	-	180 J	510	-	-	390 J	-	700 J	420 J	-	-	2000 J	-	910 J	
Benzo(b)fluoranthene	ug/kg	-	-	1000 J	-	220 J	310 J	-	-	980 J	-	250 J	620	190 J	-	-	360 J	-	1100 J	640	-	-	2700	-	1500 J
Benzo(g,h,i)perylene	ug/kg	-	-	570 J	-	91 J	120 J	-	-	530 J	-	140 J	410 J	130 J	-	-	390 J	-	720 J	400 J	-	-	1800 J	-	740 J
Benzo(k)fluoranthene	ug/kg	-	-	370 J	-	660 U	110 J	-	-	350 J	-	92 J	270 J	-	-	210 J	-	410 J	180 J	-	-	950 J	-	470 J	
Benzyl alcohol	ug/kg	-	-	2300 U	-	-	-	-	-	2500 U	-	-	-	-	-	-	2100 U	-	-	-	-	-	2600 U	-	-
Biphenyl (1,1-Biphenyl)	ug/kg	-	-	-	-	660 U	510 U	-	-	-	-	540 U	460 U	490 U	-	-	-	-	2300 U	540 U	-	-	-	-	2100 U
bis(2-Chloroethoxy)methane	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
bis(2-Chloroethyl)ether	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	-	540 U	-	-	2600 U	-	2100 U
bis(2-Ethylhexyl)phthalate (DEHP)	ug/kg	-	-	720 J	-	660 U	630	-	-	2200 J	-	73 J	460 U	490 U	-	-	8000	-	1100 J	540 U	-	-	1700 J	-	570 J
Butyl benzylphthalate (BBP)	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	-	540 U	-	-	2600 U	-	2100 U
Caprolactam	ug/kg	-	-	-	-	660 U	510 U	-	-	-	-	540 U	460 U	490 U	-	-	-	-	-	540 U	-	-	-	-	2100 U
Carbazole	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	63 J	490 U	-	-	2100 U	-	2300 U	76 J	-	-	340 J	-	2100 U
Chrysene	ug/kg	-	-	910 J	-	150 J	270 J	-	-	990 J	-	190 J	500	150 J	-	-	460 J	-	680 J	490 J	-	-	2700	-	1100 J
Dibenz(a,h)anthracene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	63 J	490 U	-	-	2100 U	-	2300 U	100 J	-	-	430 J	-	2100 U
Dibenzofuran	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Diethyl phthalate	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Dimethyl phthalate	ug/kg	-	-	2300 U	-	1100 B	940 B	-	-	2500 U	-	930 B	880 B	840 B	-	-	2100 U	-	750 JB	1100 B	-	-	2600 U	-	890 JB
Di-n-butylphthalate (DBP)	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	69 J	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Di-n-octyl phthalate (DnOP)	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Fluoranthene	ug/kg	-	-	1800 J	-	280 J	520	-	-	1500 J	-	380 J	880	230 J	-	-	680 J	-	800 J	870	-	-	5500	-	2000 J
Fluorene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	190 J	-	540 U	70 J	490 U	-	-	2100 U	-	2300 U	540 U	-	-	170 J	-	2100 U
Hexachlorobenzene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2800	540 U	-	-	2600 U	-	540 J
Hexachlorobutadiene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Hexachlorocyclopentadiene	ug/kg	-	-	5700 U	-	660 U	510 U	-	-	6200 U	-	540 U	460 U	490 U	-	-	5300 U	-	2300 U	540 U	-	-	6400 U	-	2100 U
Hexachloroethane	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Indeno(1,2,3-cd)pyrene	ug/kg	-	-	470 J	-	91 J	120 J	-	-	510 J	-	110 J	320 J	-	-	2100 U	-	610 J	370 J	-	-	2000 J	-	670 J	
Isophorone	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Naphthalene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	68 J	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Nitrobenzene	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
N-Nitrosodi-n-propylamine	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
N-Nitrosodiphenylamine	ug/kg	-	-	2300 U	-	660 U	510 U	-	-	2500 U	-	540 U	460 U	490 U	-	-	2100 U	-	2300 U	540 U	-	-	2600 U	-	2100 U
Pentachlorophenol	ug/kg	-	-	14000 U																					

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

Sample Location:	SD-1	SD-1	FC-SD-01	FC-SED01	SD-1	SD-1	SD-2	SD-2	FC-SD-02	FC-SED02	SD-2	SD-2	SD-2	SD-2	SD-3	SD-3	FC-SD-03	FC-SED03	SD-3	SD-3	SD-4	SD-4	FC-SD-04	FC-SED04	SD-4	
Sample ID:	5-46-045-SD-01D	5-46-045-SD-01S	FC-SD-01 (0-2)	FC-TCLP-SED01	SD-1(0-0.5)	SD-1(1.5-2)	5-46-045-SD-02D	5-46-045-SD-02S	FC-SD-02 (0-2)	FC-TCLP-SED02	SD-2(0-0.5)	SD-2(1.5-2)	SD-2(4-4.5)	5-46-045-SD-03D	5-46-045-SD-03S	FC-SD-03 (0-2)	FC-TCLP-SED03	SD-3(0-0.5)	SD-3(1.5-2)	5-46-045-SD-04D	5-46-045-SD-04S	FC-SD-04 (0-2)	FC-TCLP-SED04	SD-4(0-0.5)		
Sample Date:	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011		
Sample Depth:	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS		
Parameters																										
Semi-volatile Organic Compounds - TCLP																										
1,4-Dichlorobenzene	ug/L	-	-	20 U	-	-	-	-	-	3.5 J	-	-	-	-	-	-	45	-	-	-	-	-	14 J	-		
2,4,5-Trichlorophenol	ug/L	-	-	100 U	-	-	-	-	-	100 U	-	-	-	-	-	-	100 U	-	-	-	-	-	100 U	-		
2,4,6-Trichlorophenol	ug/L	-	-	20 U	-	-	-	-	-	20 U	-	-	-	-	-	-	20 U	-	-	-	-	-	20 U	-		
2,4-Dinitrotoluene	ug/L	-	-	20 U	-	-	-	-	-	20 U	-	-	-	-	-	-	20 U	-	-	-	-	-	20 U	-		
2-Methylphenol	ug/L	-	-	20 U	-	-	-	-	-	20 U	-	-	-	-	-	-	110	-	-	-	-	-	20 U	-		
4-Methylphenol	ug/L	-	-	0.68 J	-	-	-	-	-	20 U	-	-	-	-	-	-	150	-	-	-	-	-	0.93 J	-		
Hexachlorobenzene	ug/L	-	-	20 U	-	-	-	-	-	20 U	-	-	-	-	-	-	2.4 J	-	-	-	-	-	20 U	-		
Hexachlorobutadiene	ug/L	-	-	20 U	-	-	-	-	-	20 U	-	-	-	-	-	-	20 U	-	-	-	-	-	20 U	-		
Hexachloroethane	ug/L	-	-	20 U	-	-	-	-	-	20 U	-	-	-	-	-	-	20 U	-	-	-	-	-	20 U	-		
Nitrobenzene	ug/L	-	-	20 U	-	-	-	-	-	20 U	-	-	-	-	-	-	20 U	-	-	-	-	-	20 U	-		
Pentachlorophenol	ug/L	-	-	100 U	-	-	-	-	-	100 U	-	-	-	-	-	-	100 U	-	-	-	-	-	100 U	-		
Pyridine	ug/L	-	-	40 U	-	-	-	-	-	40 U	-	-	-	-	-	-	40 U	-	-	-	-	-	40 U	-		
Metals																										
Aluminum	mg/kg	-	12200	-	-	-	-	-	12600	-	-	-	-	-	-	-	12900	-	-	-	-	-	15800	-		
Antimony	mg/kg	-	8.6 U	-	-	-	-	-	9.3 U	-	-	-	-	-	-	-	8.1 U	-	-	-	-	-	9.7 U	-		
Arsenic	mg/kg	-	15.2	-	-	-	-	-	11.4 J	-	-	-	-	-	-	-	6.7 J	-	-	-	-	-	7.5 J	-		
Barium	mg/kg	-	145	-	-	-	-	-	149	-	-	-	-	-	-	-	117	-	-	-	-	-	171	-		
Beryllium	mg/kg	-	0.95 J	-	-	-	-	-	0.97 J	-	-	-	-	-	-	-	0.87 J	-	-	-	-	-	1.0 J	-		
Cadmium	mg/kg	-	0.75 J	-	-	-	-	-	1.4 J	-	-	-	-	-	-	-	3.3	-	-	-	-	-	3.4	-		
Calcium	mg/kg	-	15400	-	-	-	-	-	8090	-	-	-	-	-	-	-	33800	-	-	-	-	-	7980	-		
Chromium	mg/kg	-	66.9	-	-	-	-	-	109	-	-	-	-	-	-	-	120	-	-	-	-	-	115	-		
Cobalt	mg/kg	-	12.5	-	-	-	-	-	13.0	-	-	-	-	-	-	-	12.1	-	-	-	-	-	13.7	-		
Copper	mg/kg	-	97.9	-	-	-	-	-	152	-	-	-	-	-	-	-	124	-	-	-	-	-	211	-		
Iron	mg/kg	-	28000	-	-	-	-	-	27300	-	-	-	-	-	-	-	25100	-	-	-	-	-	29200	-		
Lead	mg/kg	-	218	-	-	-	-	-	260	-	-	-	-	-	-	-	199	-	-	-	-	-	283	-		
Magnesium	mg/kg	-	8220	-	-	-	-	-	6820	-	-	-	-	-	-	-	19900	-	-	-	-	-	7090	-		
Manganese	mg/kg	-	511	-	-	-	-	-	517	-	-	-	-	-	-	-	353	-	-	-	-	-	624	-		
Mercury	mg/kg	-	0.17	-	-	-	-	-	0.64	-	-	-	-	-	-	-	0.52	-	-	-	-	-	0.38	-		
Nickel	mg/kg	-	31.5	-	-	-	-	-	34.8	-	-	-	-	-	-	-	35.3	-	-	-	-	-	36.8	-		
Potassium	mg/kg	-	1230	-	-	-	-	-	1240	-	-	-	-	-	-	-	1520	-	-	-	-	-	1860	-		
Selenium	mg/kg	-	19.6 U	-	-	-	-	-	21.1 U	-	-	-	-	-	-	-	18.3 U	-	-	-	-	-	21.9 U	-		
Silver	mg/kg	-	2.6 U	-	-	-	-	-	0.65 J	-	-	-	-	-	-	-	0.29 J	-	-	-	-	-	0.64 J	-		
Sodium	mg/kg	-	131 U	-	-	-	-	-	92.6 J	-	-	-	-	-	-	-	122 U	-	-	-	-	-	146 U	-		
Thallium	mg/kg	-	7.9 U	-	-	-	-	-	3.8 J	-	-	-	-	-	-	-	6.9 J	-	-	-	-	-	6.7 J	-		
Vanadium	mg/kg	-	26.3	-	-	-	-	-	25.1	-	-	-	-	-	-	-	27.7	-	-	-	-	-	33.9	-		
Zinc	mg/kg	-	295	-	-	-	-	-	366	-	-	-	-	-	-	-	284	-	-	-	-	-	401	-		
Metals - TCLP																										
Arsenic	ug/L	-	-	75 U	-	-	-	-	75 U	-	-	-	-	-	-	-	75 U	-	-	-	-	-	75 U	-		
Barium	ug/L	-	-	3200	-	-	-	-	1300	-	-	-	-	-	-	-	1400	-	-	-	-	-	1300	-		
Cadmium	ug/L	-	-	25 U	-	-	-	-	58	-	-	-	-	-	-	-	13 J	-	-	-	-	-	19 J	-		
Chromium	ug/L	-	-	2.5 J	-	-	-	-	2.5 J	-	-	-	-	-	-	-	4.9 J	-	-	-	-	-	4.7 J	-		
Lead	ug/L	-	-	26 J	-	-	-	-	260	-	-	-	-	-	-	-	250	-	-	-	-	-	340	-		
Mercury	ug/L	-	-	2 U	-	-	-	-	2 U	-	-	-	-	-	-	-	2 U	-	-	-	-	-	2 U	-		
Selenium	ug/L	-	-	190 U	-	-	-	-	190 U	-	-	-	-	-	-	-	190 U	-	-	-	-	-	190 U	-		
Silver	ug/L	-	-	25 U	-	-	-	-	25 U	-	-	-	-	-	-	-	25 U	-	-	-	-	-	25 U	-		
PCBs																										
Aroclor-1016 (PCB-1016)	ug/kg	U	U	73 U	610 U	170 U	520 U	U	UR	400 U	2600 U	140 U	24 U	25 U	U	U	1700 U	580000 U	-	28 U	UJ	UR	810 U	5700 U	22 U	
Aroclor-1221 (PCB-1221)	ug/kg	U	U	73 U	610 U	170 U	520 U	U	UR	400 U	2600 U	140 U	24 U	25 U	U	U	1700 U	580000 U	-	28 U	UJ	UR	810 U	5700 U	22 U	
Aroclor-1232 (PCB-1232)	ug/kg	U	U	73 U	610 U	170 U	520 U	U	UR	400 U	2600 U	140 U	24 U	25 U	U	U	1700 U	580000 U	24 U	28 U	UJ	UR	810 U	5700 U	22 U	
Aroclor-1242 (PCB-1242)	ug/kg	U	U	940	610 U	170 U	9600 P	U	UR	3700	26000	140 U	65 P	25 U	U	U	15000	2200000	-	28 U	UJ	UR	7700	33000	22 U	
Aroclor-1248 (PCB-1248)	ug/kg	60000	3400	73 U	5700	2100	520 U	320	120 R	400 U	2600 U	1100	24 U	25 U	23000	180000	1700 U	580000 U	24000 D	28 U	47 J	410 R	810 U	5700 U	110 P	
Aroclor-1254 (PCB-1254)	ug/kg	U	U	160 P	1500	170 U	520 U	U	UR	780 P	2600 U	140 U	24 U	25 U	U	U	1900 P	580000 U	24 U	28 U	UJ	UR	730 Jp	5700 U	22 U	
Aroclor-1260 (PCB-1260)	ug/kg	U	U	57 J	250 J	170 U	520 U	U	UR	210 J	2600 U	140 U	24 U	25 U	U	U	980 J	580000 U	-	28 U	UJ	UR	390 J	5700 U	22 U	
Total PCBs	ug/kg	1000	60000	3400	1157	7450	2100	9600	320	120 R	4690	26000	1100	65	0	23000	180000	17880	2200000	24000	0	47	410 R	8820	33000	110

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

Sample Location:	SD-1	SD-1	FC-SD-01	FC-SED01	SD-1	SD-1	SD-2	SD-2	FC-SD-02	FC-SED02	SD-2	SD-2	SD-2	SD-2	SD-3	SD-3	FC-SD-03	FC-SED03	SD-3	SD-3	SD-4	SD-4	FC-SD-04	FC-SED04	SD-4	
Sample ID:	5-46-045-SD-01D	5-46-045-SD-01S	FC-SD-01 (0-2)	FC-TCLP-SED01	SD-1(0-0.5)	SD-1(1.5-2)	5-46-045-SD-02D	5-46-045-SD-02S	FC-SD-02 (0-2)	FC-TCLP-SED02	SD-2(0-0.5)	SD-2(1.5-2)	SD-2(4-4.5)	5-46-045-SD-03D	5-46-045-SD-03S	FC-SD-03 (0-2)	FC-TCLP-SED03	SD-3(0-0.5)	SD-3(1.5-2)	5-46-045-SD-04D	5-46-045-SD-04S	FC-SD-04 (0-2)	FC-TCLP-SED04	SD-4(0-0.5)		
Sample Date:	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011		
Sample Depth:	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS		
Parameters	Units	Criteria																								
Pesticides																										
4,4'-DDD	ug/kg	-	-	14 U	-	-	-	-	4.5 Jp	-	-	-	-	-	-	-	8.4 Jp	-	-	-	-	-	3.0 Jp	-	-	
4,4'-DDE	ug/kg	-	-	7.6 J	-	-	-	-	21	-	-	-	-	-	-	-	37	-	-	-	-	-	22	-	-	
4,4'-DDT	ug/kg	-	-	14 U	-	-	-	-	48	-	-	-	-	-	-	-	11 Jp	-	-	-	-	-	34	-	-	
Aldrin	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	16 U	-	-	
alpha-BHC	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	16 U	-	-	
alpha-Chlordane	ug/kg	-	-	14 U	-	-	-	-	23	-	-	-	-	-	-	-	13 U	-	-	-	-	-	13 J	-	-	
beta-BHC	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	16 U	-	-	
Chlordane, technical	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	16 U	-	-	
delta-BHC	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	16 U	-	-	
Dieldrin	ug/kg	-	-	2.6 Jp	-	-	-	-	10 Jp	-	-	-	-	-	-	-	17 p	-	-	-	-	-	6.4 Jp	-	-	
Endosulfan I	ug/kg	-	-	14 U	-	-	-	-	3.0 Jp	-	-	-	-	-	-	-	6.7 Jp	-	-	-	-	-	4.4 Jp	-	-	
Endosulfan II	ug/kg	-	-	14 U	-	-	-	-	10 Jp	-	-	-	-	-	-	-	37 p	-	-	-	-	-	11 Jp	-	-	
Endosulfan sulfate	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	6.9 J	-	-	
Endrin	ug/kg	-	-	14 U	-	-	-	-	2.2 Jp	-	-	-	-	-	-	-	3.5 Jp	-	-	-	-	-	1.5 Jp	-	-	
Endrin aldehyde	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	7.0 Jp	-	-	-	-	-	16 U	-	-	
Endrin ketone	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	16 U	-	-	
gamma-BHC (lindane)	ug/kg	-	-	4.0 Jp	-	-	-	-	11 Jp	-	-	-	-	-	-	-	42 p	-	-	-	-	-	25 p	-	-	
Heptachlor	ug/kg	-	-	4.4 Jp	-	-	-	-	13 Jp	-	-	-	-	-	-	-	23 p	-	-	-	-	-	9.3 Jp	-	-	
Heptachlor epoxide	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	13 U	-	-	-	-	-	16 U	-	-	
Methoxychlor	ug/kg	-	-	14 U	-	-	-	-	16 U	-	-	-	-	-	-	-	12 Jp	-	-	-	-	-	16 U	-	-	
Toxaphene	ug/kg	-	-	140 U	-	-	-	-	160 U	-	-	-	-	-	-	-	130 U	-	-	-	-	-	160 U	-	-	
Pesticides - TCLP																										
Chlordane	ug/L	-	-	-	2.5 U	-	-	-	-	2.5 U	-	-	-	-	-	-	-	2.5 U	-	-	-	-	-	2.5 U	-	
Endrin	ug/L	-	-	-	0.5 U	-	-	-	-	0.5 U	-	-	-	-	-	-	-	0.5 U	-	-	-	-	-	0.5 U	-	
gamma-BHC (lindane)	ug/L	-	-	-	0.25 U	-	-	-	-	0.25 U	-	-	-	-	-	-	-	0.051 J	-	-	-	-	-	0.25 U	-	
Heptachlor	ug/L	-	-	-	0.25 U	-	-	-	-	0.25 U	-	-	-	-	-	-	-	0.14 J	-	-	-	-	-	0.25 U	-	
Heptachlor epoxide	ug/L	-	-	-	0.25 U	-	-	-	-	0.25 U	-	-	-	-	-	-	-	0.25 U	-	-	-	-	-	0.25 U	-	
Methoxychlor	ug/L	-	-	-	2.5 U	-	-	-	-	2.5 U	-	-	-	-	-	-	-	2.5 U	-	-	-	-	-	2.5 U	-	
Toxaphene	ug/L	-	-	-	12 U	-	-	-	-	12 U	-	-	-	-	-	-	-	12 U	-	-	-	-	-	12 U	-	
Geotech																										
#10 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#100 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#20 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#200 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#4 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#40 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#60 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#80 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Clay	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Coarse sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Fine sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Gravel	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Liquid limit (LL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Medium sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Plastic limit (PL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Plasticity index	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
 FRIEDRICHSOHN COOPERAGE SITE
 WATERFORD, NEW YORK

Sample Location:	SD-1	SD-1	FC-SD-01	FC-SED01	SD-1	SD-1	SD-2	SD-2	FC-SD-02	FC-SED02	SD-2	SD-2	SD-2	SD-2	SD-3	SD-3	FC-SD-03	FC-SED03	SD-3	SD-3	SD-4	SD-4	FC-SD-04	FC-SED04	SD-4
Sample ID:	5-46-045-SD-01D	5-46-045-SD-01S	FC-SD-01 (0-2)	FC-TCLP-SED01	SD-1(0-0.5)	SD-1(1.5-2)	5-46-045-SD-02D	5-46-045-SD-02S	FC-SD-02 (0-2)	FC-TCLP-SED02	SD-2(0-0.5)	SD-2(1.5-2)	SD-2(4-4.5)	5-46-045-SD-03D	5-46-045-SD-03S	FC-SD-03 (0-2)	FC-TCLP-SED03	SD-3(0-0.5)	SD-3(1.5-2)	5-46-045-SD-04D	5-46-045-SD-04S	FC-SD-04 (0-2)	FC-TCLP-SED04	SD-4(0-0.5)	
Sample Date:	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	1/4/2011	4/23/2008	4/23/2008	8/17/2009	4/1/2010	1/4/2011	
Sample Depth:	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	9-18 in BGS	0-9 in BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	
Parameters																									
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
General Chemistry																									
Ash	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cyanide (total)	ug/kg	-	-	1070 U	-	-	-	-	1170 U	-	-	-	-	-	-	-	981 U	-	-	-	-	-	1200 U	-	-
Ignitability	mm/sec	-	-	-	2.2 NEG	-	-	-	-	2.2 NEG	-	-	-	-	-	-	-	2.2 NEG	-	-	-	-	-	2.2 NEG	-
Organic matter	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	6.56 HF	-	-	-	-	6.63 HF	-	-	-	-	-	-	-	6.01 HF	-	-	-	-	-	-	6.48 HF
Reactive cyanide	mg/kg	-	-	-	0.50 U	-	-	-	-	0.50 U	-	-	-	-	-	-	-	0.50 U	-	-	-	-	-	-	0.50 U
Reactive sulfide	mg/kg	-	-	-	32.0	-	-	-	-	20.0 U	-	-	-	-	-	-	-	20.0 U	-	-	-	-	-	-	20.0 U

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Table with columns for Sample Location, Sample ID, Sample Date, Sample Depth, Parameters, Units, and various sample identifiers (SD-4, FC-SD-05, FC-SED05, SD-5, SD-5, SD-5, FC-SD-06, SD-6, SD-6, SD-6, FC-SD-07, SD-7, SD-7, SD-7, SD-7, FC-SD-08, SD-8, SD-8, SD-8, FC-SD-09, SD-9, SD-9, FC-SD-10, SD-10, SD-10). Rows include Volatile Organic Compounds (1,1,1-Trichloroethane, 1,1,2,2-Tetrachloroethane, etc.), Volatile Organic Compounds - TCLP, and Semi-volatile Organic Compounds (1,2,4-Trichlorobenzene, 1,2-Dichlorobenzene, etc.).

CRA 08/987 (5)

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

Sample Location:	SD-4	FC-SD-05	FC-SED05	SD-5	SD-5	SD-5	FC-SD-06	SD-6	SD-6	SD-6	FC-SD-07	SD-7	SD-7	SD-7	SD-7	FC-SD-08	SD-8	SD-8	SD-8	FC-SD-09	SD-9	SD-9	FC-SD-10	SD-10	SD-10	
Sample ID:	SD-4(L.5-2)	FC-SD-05 (0-2)	FC-TCLP-SED05	SD-5(0-0.5)	SD-5(1.5-2)	SD-5(2.5-2.75)	FC-SD-06 (0-2)	SD-6(0-0.5)	SD-6(L.5-2)	SD-6(2.5-3)	FC-SD-07 (0-2)	SD-7(0-0.5)	SD-7(1-1.5)	SD-7(3-3.5)	SD-X	FC-SD-08 (0-2)	SD-8(0-0.5)	SD-8(L.5-2)	SD-8(2.5-3)	FC-SD-09 (0-2)	SD-9(0-0.5)	SD-X2	FC-SD-10 (0-2)	SD-10(0-0.5)	SD-10(L.5-2)	
Sample Date:	1/4/2011	8/17/2009	4/1/2010	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/5/2011	1/5/2011	8/17/2009	1/5/2011	1/5/2011	
Sample Depth:	1.5-2 ft BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	2.5-2.75 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1-1.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-2 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	
	Duplicate															Duplicate										
Parameters	Units																									
Semi-volatile Organic Compounds - TCLP																										
1,4-Dichlorobenzene	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2,4,5-Trichlorophenol	ug/L	-	-	100 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2,4,6-Trichlorophenol	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2,4-Dinitrotoluene	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2-Methylphenol	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
4-Methylphenol	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hexachlorobenzene	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hexachlorobutadiene	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hexachloroethane	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Nitrobenzene	ug/L	-	-	20 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Pentachlorophenol	ug/L	-	-	100 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Pyridine	ug/L	-	-	40 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Metals																										
Aluminum	mg/kg	-	8230	-	-	-	8880	-	-	-	15300	-	-	-	-	15200	-	-	-	14500	-	-	8490	-	-	
Antimony	mg/kg	-	6.5 U	-	-	-	9.7 U	-	-	-	9.4 U	-	-	-	-	8.0 U	-	-	-	7.5 U	-	-	6.7 U	-	-	
Arsenic	mg/kg	-	8.0 J	-	-	-	7.9 J	-	-	-	7.3 J	-	-	-	-	9.8 J	-	-	-	6.8 J	-	-	3.8 J	-	-	
Barium	mg/kg	-	181	-	-	-	119	-	-	-	182	-	-	-	-	143	-	-	-	139	-	-	66.5	-	-	
Beryllium	mg/kg	-	0.56 J	-	-	-	0.75 J	-	-	-	1.1 J	-	-	-	-	1.1 J	-	-	-	1.1 J	-	-	0.56 J	-	-	
Cadmium	mg/kg	-	2.6	-	-	-	4.2	-	-	-	4.5	-	-	-	-	4.6	-	-	-	2.6	-	-	1.4 J	-	-	
Calcium	mg/kg	-	20300	-	-	-	7150	-	-	-	8060	-	-	-	-	4160	-	-	-	3800	-	-	11000	-	-	
Chromium	mg/kg	-	51.5	-	-	-	57.7	-	-	-	126	-	-	-	-	149	-	-	-	123	-	-	34.3	-	-	
Cobalt	mg/kg	-	8.1	-	-	-	12.2	-	-	-	14.1	-	-	-	-	14.1	-	-	-	13.4	-	-	7.6	-	-	
Copper	mg/kg	-	108	-	-	-	208	-	-	-	197	-	-	-	-	180	-	-	-	350	-	-	141	-	-	
Iron	mg/kg	-	19800	-	-	-	21700	-	-	-	29200	-	-	-	-	28300	-	-	-	28200	-	-	17700	-	-	
Lead	mg/kg	-	525	-	-	-	250	-	-	-	272	-	-	-	-	185	-	-	-	200	-	-	93.7	-	-	
Magnesium	mg/kg	-	5450	-	-	-	4200	-	-	-	6970	-	-	-	-	5350	-	-	-	5130	-	-	7260	-	-	
Manganese	mg/kg	-	301	-	-	-	349	-	-	-	519	-	-	-	-	442	-	-	-	452	-	-	285	-	-	
Mercury	mg/kg	-	0.36	-	-	-	0.94	-	-	-	0.41	-	-	-	-	0.45	-	-	-	0.39	-	-	0.088	-	-	
Nickel	mg/kg	-	22.1	-	-	-	24.7	-	-	-	68.6	-	-	-	-	37.6	-	-	-	36.5	-	-	19.3	-	-	
Potassium	mg/kg	-	955	-	-	-	1210	-	-	-	1890	-	-	-	-	1870	-	-	-	1750	-	-	931	-	-	
Selenium	mg/kg	-	14.7 U	-	-	-	22.0 U	-	-	-	21.3 U	-	-	-	-	18.3 U	-	-	-	17.0 U	-	-	15.2 U	-	-	
Silver	mg/kg	-	2.0 U	-	-	-	0.33 J	-	-	-	0.89 J	-	-	-	-	0.51 J	-	-	-	0.56 J	-	-	2.0 U	-	-	
Sodium	mg/kg	-	148	-	-	-	108 J	-	-	-	99.6 J	-	-	-	-	122 U	-	-	-	82.4 J	-	-	69.3 J	-	-	
Thallium	mg/kg	-	2.9 J	-	-	-	8.8 U	-	-	-	8.5 U	-	-	-	-	3.8 J	-	-	-	4.3 J	-	-	3.2 J	-	-	
Vanadium	mg/kg	-	18.0	-	-	-	21.2	-	-	-	33.1	-	-	-	-	30.5	-	-	-	28.6	-	-	20.1	-	-	
Zinc	mg/kg	-	274	-	-	-	298	-	-	-	384	-	-	-	-	318	-	-	-	348	-	-	187	-	-	
Metals - TCLP																										
Arsenic	ug/L	-	-	75 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Barium	ug/L	-	-	450	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Cadmium	ug/L	-	-	7.7 J	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Chromium	ug/L	-	-	3.5 J	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Lead	ug/L	-	-	30 J	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Mercury	ug/L	-	-	2 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Selenium	ug/L	-	-	190 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Silver	ug/L	-	-	25 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
PCBs																										
Aroclor-1016 (PCB-1016)	ug/kg	23 U	270 U	510 U	20 U	34 U	35 U / 35 U	2100 U	28 U / 28 U	29 U	27 U / 27 U	1900 U	20 U	29 U / 29 U	31 U	1000 U	650 U	28 U	2700 U	14000 U	310 U	21 U	1100 U	56 U	2000 U	22 U
Aroclor-1221 (PCB-1221)	ug/kg	23 U	270 U	510 U	20 U	34 U	35 U / 35 U	2100 U	28 U / 28 U	29 U	27 U / 27 U	1900 U	20 U	29 U / 29 U	31 U	1000 U	650 U	28 U	2700 U	14000 U	310 U	21 U	1100 U	56 U	2000 U	22 U
Aroclor-1232 (PCB-1232)	ug/kg	23 U	270 U	510 U	20 U	34 U	35 U / 35 U	2100 U	28 U / 28 U	29 U	27 U / 27 U	1900 U	20 U	29 U / 29 U	31 U	1000 U	650 U	28 U	2700 U	14000 U	310 U	21 U	1100 U	56 U	2000 U	22 U
Aroclor-1242 (PCB-1242)	ug/kg	23 U	3500	5000	20 U	370	200 / 190	10000 p	28 U / 28 U	29 U	27 U / 27 U	16000	20 U	440 / 460 P	31 U	1000 U	4500 p	220000 D	7900 P	170000	2900	6300 DP	20000	880	1300000 D	39000 D
Aroclor-1248 (PCB-1248)	ug/kg	630	270 U	510 U	700 D	34 U	35 U / 35 U	2100 U	28 U / 28 U	29 U	27 U / 27 U	1900 U	1500 D	29 U / 29 U	20 J	6500	650 U	28 U	2700 U	14000 U	310 U	21 U	1100 U	56 U	2000 U	22 U
Aroclor-1254 (PCB-1254)	ug/kg	23 U	700 p	510 U	20 U	34 U	35 U / 35 U	1700 Jp	28 U / 28 U	29 U	27 U / 27 U	1900 U	20 U	29 U / 29 U	31 U	1000 U	650 U	28 U	2700 U	14000 U	670 p	21 U	1100 U	230 p	2000 U	22 U
Aroclor-1260 (PCB-1260)	ug/kg	23 U	330	510 U	20 U	34 U	35 U / 35 U	1500 J	28 U / 28 U	29 U	27 U / 27 U	1900 U	20 U	29 U / 29 U	31 U	1000 U	310 Jp	28 U	2700 U	14000 U	230 J	21 U	1100 U	62	2000 U	22 U
Total PCBs	ug/kg	630	4530	5000	700	370	200 / 1190	13200	0	0	0	16000	1500	440 / 460 P	20	6500	4810	220000	7900	170000	3800	6300	20000	1172	1300000	39000

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-4	FC-SD-05	FC-SED05	SD-5	SD-5	SD-5	FC-SD-06	SD-6	SD-6	SD-6	FC-SD-07	SD-7	SD-7	SD-7	SD-7	FC-SD-08	SD-8	SD-8	SD-8	FC-SD-09	SD-9	SD-9	FC-SD-10	SD-10	SD-10	
Sample ID:	SD-4(L.5-2)	FC-SD-05 (0-2)	FC-TCLP-SED05	SD-5(0-0.5)	SD-5(L.5-2)	SD-5(2.5-2.75)	FC-SD-06 (0-2)	SD-6(0-0.5)	SD-6(L.5-2)	SD-6(2.5-3)	FC-SD-07 (0-2)	SD-7(0-0.5)	SD-7(1-1.5)	SD-7(3-3.5)	SD-X	FC-SD-08 (0-2)	SD-8(0-0.5)	SD-8(L.5-2)	SD-8(2.5-3)	FC-SD-09 (0-2)	SD-9(0-0.5)	SD-X2	FC-SD-10 (0-2)	SD-10(0-0.5)	SD-10(L.5-2)	
Sample Date:	1/4/2011	8/17/2009	4/1/2010	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/5/2011	1/5/2011	8/17/2009	1/5/2011	1/5/2011	
Sample Depth:	1.5-2 ft BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	2.5-2.75 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1-1.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-2 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	
	Duplicate															Duplicate										
Parameters	Units																									
Pesticides																										
4,4'-DDD	ug/kg	-	2.8 Jp	-	-	-	25	-	-	-	31	-	-	-	-	13 Jp	-	-	-	4.1 Jp	-	-	6.3 J	-	-	
4,4'-DDE	ug/kg	-	13	-	-	-	9.1 Jp	-	-	-	40	-	-	-	-	39	-	-	-	25	-	-	3.7 Jp	-	-	
4,4'-DDT	ug/kg	-	11 p	-	-	-	32	-	-	-	2.7 Jp	-	-	-	-	51	-	-	-	4.0 Jp	-	-	11 U	-	-	
Aldrin	ug/kg	-	10 U	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
alpha-BHC	ug/kg	-	10 U	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
alpha-Chlordane	ug/kg	-	18 p	-	-	-	12 J	-	-	-	15 Jp	-	-	-	-	13 U	-	-	-	9.8 Jp	-	-	4.1 J	-	-	
beta-BHC	ug/kg	-	10 U	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
Chlordane, technical	ug/kg	-	9.8 Jp	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
delta-BHC	ug/kg	-	10 U	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
Dieldrin	ug/kg	-	3.1 Jp	-	-	-	7.0 Jp	-	-	-	13 Jp	-	-	-	-	10 Jp	-	-	-	6.3 Jp	-	-	1.9 Jp	-	-	
Endosulfan I	ug/kg	-	10 U	-	-	-	7.9 J	-	-	-	3.6 Jp	-	-	-	-	6.2 Jp	-	-	-	1.8 Jp	-	-	11 U	-	-	
Endosulfan II	ug/kg	-	6.6 Jp	-	-	-	4.5 Jp	-	-	-	13 Jp	-	-	-	-	21 p	-	-	-	28	-	-	8.6 J	-	-	
Endosulfan sulfate	ug/kg	-	12 p	-	-	-	4.9 Jp	-	-	-	9.5 J	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
Endrin	ug/kg	-	3.7 J	-	-	-	16 U	-	-	-	2.4 Jp	-	-	-	-	4.0 Jp	-	-	-	12 U	-	-	11 U	-	-	
Endrin aldehyde	ug/kg	-	10 U	-	-	-	5.3 J	-	-	-	4.2 Jp	-	-	-	-	13 U	-	-	-	2.9 Jp	-	-	11 U	-	-	
Endrin ketone	ug/kg	-	10 U	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
gamma-BHC (lindane)	ug/kg	-	11 p	-	-	-	130 p	-	-	-	110 p	-	-	-	-	24 p	-	-	-	6.9 Jp	-	-	2.4 Jp	-	-	
Heptachlor	ug/kg	-	8.4 Jp	-	-	-	9.6 Jp	-	-	-	12 Jp	-	-	-	-	22 p	-	-	-	6.9 Jp	-	-	3.8 Jp	-	-	
Heptachlor epoxide	ug/kg	-	10 U	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
Methoxychlor	ug/kg	-	10 U	-	-	-	16 U	-	-	-	15 U	-	-	-	-	13 U	-	-	-	12 U	-	-	11 U	-	-	
Toxaphene	ug/kg	-	100 U	-	-	-	160 U	-	-	-	150 U	-	-	-	-	130 U	-	-	-	120 U	-	-	110 U	-	-	
Pesticides - TCLP																										
Chlordane	ug/L	-	-	2.5 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endrin	ug/L	-	-	0.5 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
gamma-BHC (lindane)	ug/L	-	-	0.25 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Heptachlor	ug/L	-	-	0.25 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Heptachlor epoxide	ug/L	-	-	0.25 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Methoxychlor	ug/L	-	-	2.5 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Toxaphene	ug/L	-	-	12 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Geotech																										
#10 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#100 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#20 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#200 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#4 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#40 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#60 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#80 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Clay	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Coarse sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Fine sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Gravel	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Liquid limit (LL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Medium sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Plastic limit (PL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Plasticity index	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	SD-4	FC-SD-05	FC-SED05	SD-5	SD-5	SD-5	FC-SD-06	SD-6	SD-6	SD-6	FC-SD-07	SD-7	SD-7	SD-7	SD-7	FC-SD-08	SD-8	SD-8	SD-8	FC-SD-09	SD-9	SD-9	FC-SD-10	SD-10	SD-10		
<i>Sample ID:</i>	SD-4(L.5-2)	FC-SD-05 (0-2)	FC-TCLP-SED05	SD-5(0-0.5)	SD-5(1.5-2)	SD-5(2.5-2.75)	FC-SD-06 (0-2)	SD-6(0-0.5)	SD-6(L.5-2)	SD-6(2.5-3)	FC-SD-07 (0-2)	SD-7(0-0.5)	SD-7(1-1.5)	SD-7(3-3.5)	SD-X	FC-SD-08 (0-2)	SD-8(0-0.5)	SD-8(L.5-2)	SD-8(2.5-3)	FC-SD-09 (0-2)	SD-9(0-0.5)	SD-X2	FC-SD-10 (0-2)	SD-10(0-0.5)	SD-10(L.5-2)		
<i>Sample Date:</i>	1/4/2011	8/17/2009	4/1/2010	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/4/2011	1/4/2011	1/4/2011	8/17/2009	1/5/2011	1/5/2011	8/17/2009	1/5/2011	1/5/2011		
<i>Sample Depth:</i>	1.5-2 ft BGS	0-2 ft BGS	- depth unknown	0-0.5 ft BGS	1.5-2 ft BGS	2.5-2.75 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1-1.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-2 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS		
															Duplicate							Duplicate					
<i>Parameters</i>	<i>Units</i>																										
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Silt	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
General Chemistry																											
Ash	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Carbon	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Cyanide (total)	ug/kg	-	787 U	-	-	-	1230 U	-	-	-	1160 U	-	-	-	-	974 U	-	-	-	929 U	-	-	824 U	-	-		
Ignitability	mm/sec	-	-	2.2 NEG	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Organic matter	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Percent moisture	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
pH	s.u.	-	-	6.66 HF	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Reactive cyanide	mg/kg	-	-	0.50 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Reactive sulfide	mg/kg	-	-	20.0 U	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	FC-SD-11	SD-11	SD-11	SD-11	FC-SD-12	SD-12	SD-12	SD-12	SD-12	FC-SD-13	SD-13	SD-13	SD-13	FC-SD-14	SD-14	SD-14	SD-14	FC-SD-15	SD-15	SD-15	SD-15	FC-SD-16	SD-16	
Sample ID:	FC-SD-11 (0-1)	SD-11(0-0.5)	SD-11(1.5-2)	SD-11(3.5-4)	FC-SD-12 (0-2)	SD-12(0-0.5)	SD-12(1.5-2)	SD-12(4-4.5)	SD-12(6-6.5)	FC-SD-13 (0-2)	SD-13(0-0.5)	SD-13(1.5-2)	SD-13(4-4.5)	FC-SD-14 (0-3)	SD-14(0-0.5)	SD-14(1.5-2)	SD-14(2-2.5)	FC-SD-15 (0-6)	SD-15(0-0.5)	SD-15(1.5-2)	SD-15(4.5-5)	FC-SD-16 (0-3)	SD-16(0-0.5)	
Sample Date:	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/6/2011	
Sample Depth:	0-1 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	3.5-4 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	6-6.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	0-3 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2-2.5 ft BGS	0-6 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4.5-5 ft BGS	0-3 ft BGS	0-0.5 ft BGS	
Parameters																								
Pesticides																								
4,4'-DDD	ug/kg	1.9 Jp	-	-	-	3.9 Jp	-	-	-	-	2.1 Jp	-	-	-	450	-	-	-	3.5 Jp	-	-	-	2.1 Jp	-
4,4'-DDE	ug/kg	10 Jp	-	-	-	20 p	-	-	-	-	12 U	-	-	-	180	-	-	-	3.2 Jp	-	-	-	10 U	-
4,4'-DDT	ug/kg	24	-	-	-	40	-	-	-	-	2.4 Jp	-	-	-	330	-	-	-	12 J	-	-	-	2.4 J	-
Aldrin	ug/kg	18 U	-	-	-	17 U	-	-	-	-	12 U	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
alpha-BHC	ug/kg	18 U	-	-	-	17 U	-	-	-	-	12 U	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
alpha-Chlordane	ug/kg	9.4 J	-	-	-	17 U	-	-	-	-	8.7 J	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
beta-BHC	ug/kg	18 U	-	-	-	17 U	-	-	-	-	12 U	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
Chlordane, technical	ug/kg	18 U	-	-	-	17 U	-	-	-	-	12 U	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
delta-BHC	ug/kg	18 U	-	-	-	17 U	-	-	-	-	12 U	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
Dieldrin	ug/kg	2.9 Jp	-	-	-	11 Jp	-	-	-	-	5.1 Jp	-	-	-	82 p	-	-	-	2.4 Jp	-	-	-	10 U	-
Endosulfan I	ug/kg	18 U	-	-	-	4.7 Jp	-	-	-	-	2.5 Jp	-	-	-	29 Jp	-	-	-	16 U	-	-	-	1.4 J	-
Endosulfan II	ug/kg	10 Jp	-	-	-	9.6 Jp	-	-	-	-	11 Jp	-	-	-	85	-	-	-	4.7 Jp	-	-	-	4.3 J	-
Endosulfan sulfate	ug/kg	6.3 Jp	-	-	-	17 U	-	-	-	-	12 U	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
Endrin	ug/kg	18 U	-	-	-	2.0 Jp	-	-	-	-	12 U	-	-	-	19 Jp	-	-	-	16 U	-	-	-	10 U	-
Endrin aldehyde	ug/kg	18 U	-	-	-	10 J	-	-	-	-	12 U	-	-	-	14 Jp	-	-	-	16 U	-	-	-	10 U	-
Endrin ketone	ug/kg	18 U	-	-	-	17 U	-	-	-	-	12 U	-	-	-	16 J	-	-	-	16 U	-	-	-	10 U	-
gamma-BHC (lindane)	ug/kg	14 Jp	-	-	-	8.6 Jp	-	-	-	-	17 p	-	-	-	21 Jp	-	-	-	5.3 Jp	-	-	-	1.6 Jp	-
Heptachlor	ug/kg	29	-	-	-	18 p	-	-	-	-	9.5 Jp	-	-	-	130 p	-	-	-	8.9 J	-	-	-	3.0 J	-
Heptachlor epoxide	ug/kg	22 p	-	-	-	17 U	-	-	-	-	12 U	-	-	-	30 U	-	-	-	16 U	-	-	-	10 U	-
Methoxychlor	ug/kg	18 U	-	-	-	17 U	-	-	-	-	12 U	-	-	-	38 p	-	-	-	16 U	-	-	-	10 U	-
Toxaphene	ug/kg	180 U	-	-	-	170 U	-	-	-	-	120 U	-	-	-	300 U	-	-	-	160 U	-	-	-	100 U	-
Pesticides - TCLP																								
Chlordane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Geotech																								
#10 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#100 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#20 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#200 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#4 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#40 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#60 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#80 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Clay	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Coarse sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Fine sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Gravel	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Liquid limit (LL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Medium sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plastic limit (PL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plasticity index	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	FC-SD-11	SD-11	SD-11	SD-11	FC-SD-12	SD-12	SD-12	SD-12	SD-12	FC-SD-13	SD-13	SD-13	SD-13	FC-SD-14	SD-14	SD-14	SD-14	FC-SD-15	SD-15	SD-15	SD-15	FC-SD-16	SD-16	
<i>Sample ID:</i>	FC-SD-11 (0-1)	SD-11(0-0.5)	SD-11(1.5-2)	SD-11(3.5-4)	FC-SD-12 (0-2)	SD-12(0-0.5)	SD-12(1.5-2)	SD-12(4-4.5)	SD-12(6-6.5)	FC-SD-13 (0-2)	SD-13(0-0.5)	SD-13(1.5-2)	SD-13(4-4.5)	FC-SD-14 (0-3)	SD-14(0-0.5)	SD-14(1.5-2)	SD-14(2-2.5)	FC-SD-15 (0-6)	SD-15(0-0.5)	SD-15(1.5-2)	SD-15(4.5-5)	FC-SD-16 (0-3)	SD-16(0-0.5)	
<i>Sample Date:</i>	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/5/2011	1/5/2011	1/5/2011	8/18/2009	1/6/2011	
<i>Sample Depth:</i>	0-1 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	3.5-4 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	6-6.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	0-3 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2-2.5 ft BGS	0-6 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4.5-5 ft BGS	0-3 ft BGS	0-0.5 ft BGS	
Parameters																								
	Units																							
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
General Chemistry																								
Ash	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cyanide (total)	ug/kg	1360 U	-	-	-	1260 U	-	-	-	899 U	-	-	-	1140 U	-	-	-	1180 U	-	-	-	-	752 U	-
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Organic matter	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	SD-16	SD-16	SD-16	FC-SD-17	SD-17	SD-17	SD-17	FC-SD-18	SD-18	SD-18	SD-18	FC-SD-19	SD-19	SD-19	SD-19	FC-SD-20	FC-SD-20	SD-20	SD-20	SD-20	SD-20	FC-SD-21	SD-21	SD-21	SD-21
<i>Sample ID:</i>	SD-16(1.5-2)	SD-16(3-3.5)	SD-X3	FC-SD-17 (0-2)	SD-17(0-0.5)	SD-17(1.5-2)	SD-17(5-5.5)	FC-SD-18 (0-6)	SD-18(0-0.5)	SD-18(1.5-2)	SD-18(5-5.5)	FC-SD-19 (0-1)	SD-19(0-0.5)	SD-19(1.5-2)	SD-19(6-6.5)	FC-SD-20 (0-2)	FC-SD-X3	SD-20(0-0.5)	SD-20(1.5-2)	SD-20(6.5-7)	FC-SD-21 (0-2)	SD-21(0-0.5)	SD-21(1.5-2)	SD-21(5.5-6)	
<i>Sample Date:</i>	1/6/2011	1/6/2011	1/6/2011	8/18/2009	1/6/2011	1/6/2011	1/6/2011	8/18/2009	1/6/2011	1/6/2011	1/6/2011	8/18/2009	1/6/2011	1/6/2011	1/6/2011	8/18/2009	8/18/2009	1/6/2011	1/6/2011	1/6/2011	8/18/2009	1/7/2011	1/7/2011	1/7/2011	
<i>Sample Depth:</i>	1.5-2 ft BGS	3-3.5 ft BGS	1.5-2 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	5-5.5 ft BGS	0-6 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	5-5.5 ft BGS	0-1 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	6-6.5 ft BGS	0-2 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	6.5-7 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	5.5-6 ft BGS	
<i>Parameters</i>	<i>Duplicate</i>			<i>Duplicate</i>																					
<i>Units</i>																									
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
General Chemistry																									
Ash	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cyanide (total)	ug/kg	-	-	-	731 U	-	-	301 J	-	-	-	697 U	-	-	-	641 U	684 U	-	-	-	656 U	-	-	-	-
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Organic matter	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
 SUMMARY OF SEDIMENT ANALYTICAL DATA
 FRIEDRICHSOHN COOPERAGE SITE
 WATERFORD, NEW YORK

Sample Location:	SD-21	FC-SD-22	SD-22	SD-22	SD-22	FC-SD-23	SD-23	FC-SD-24	FC-SD-24	FC-SD-24	SD-24	SD-24	SD-24	FC-SD-25	FC-SD-25	FC-SD-25	SD-25	SD-25	SD-25	SD-25	FC-SD-26	SD-26	SD-26	SD-26	FC-SD-27	SD-27
Sample ID:	SD-X4	FC-SD-22 (0-2)	SD-22(0-0.5)	SD-22(1.5-2)	SD-22(5-6)	FC-SD-23 (0-4)	SD-23(0-0.5)	FC-SD-24 (1-3)	FC-SD-24 (4-7)	FC-SD-X4	SD-24(0-0.5)	SD-24(1.5-2)	SD-24(4-4.5)	FC-SD-25 (1-2)	FC-SD-25 (5-6)	FC-SD-25 (7-8)	SD-25(0-0.5)	SD-25(1.5-2)	SD-25(4.5-5)	SD-X4	FC-SD-26 (1-4)	SD-26(0-0.5)	SD-26(1.5-2)	SD-26(4-4.5)	FC-SD-27 (0-1)	SD-27(0-0.5)
Sample Date:	1/7/2011	8/18/2009	1/7/2011	1/7/2011	1/7/2011	8/18/2009	1/7/2011	8/19/2009	8/19/2009	8/19/2009	1/10/2011	1/10/2011	1/10/2011	8/19/2009	8/19/2009	8/19/2009	1/10/2011	1/10/2011	1/10/2011	1/10/2011	8/19/2009	1/10/2011	1/10/2011	1/10/2011	8/19/2009	1/10/2011
Sample Depth:	1.5-2 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	5-6 ft BGS	0-4 ft BGS	0-0.5 ft BGS	1-3 ft BGS	4-7 ft BGS	1-3 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	1-2 ft BGS	5-6 ft BGS	7-8 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4.5-5 ft BGS	1.5-2 ft BGS	1-4 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	0-1 ft BGS	0-0.5 ft BGS
	Duplicate										Duplicate															
Parameters	Units																									
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
General Chemistry																										
Ash	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cyanide (total)	ug/kg	-	1190 U	-	-	-	595 U	-	210 J	624 U	730 U	-	-	773 U	634 U	605 U	-	-	-	-	992 U	-	-	-	714 U	-
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Organic matter	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-27	SD-27	FC-SD-28	SD-28	FC-SD-29	SD-29	SD-29	FC-SD-30	SD-30	SD-30	SD-30	FC-SD-31	SD-31	SD-31	SD-31	FC-SD-32	SD-32	SD-32	SD-32	FC-SD-33	SD-33
Sample ID:	SD-27(1.5-2)	SD-27(2-2.5)	FC-SD-28 (0-1.5)	SD-28(0-0.5)	FC-SD-29 (0-2)	SD-29(0-0.5)	SD-29(1.5-2)	FC-SD-30 (0-3)	SD-30(0-0.5)	SD-30(1.5-2)	SD-30(2-2.5)	FC-SD-31 (0-1.5)	SD-31(0-0.5)	SD-31(1.5-2)	SD-31(2.5-3)	FC-SD-32	SD-32(0-0.5)	SD-32(1.5-2)	SD-32(2.5-3)	FC-SD-33	SD-33(0-0.5)
Sample Date:	1/10/2011	1/10/2011	8/19/2009	1/10/2011	8/19/2009	1/10/2011	1/10/2011	8/19/2009	1/10/2011	1/10/2011	1/10/2011	8/19/2009	1/10/2011	1/10/2011	1/10/2011	9/30/2009	1/10/2011	1/10/2011	1/10/2011	9/30/2009	1/11/2011
Sample Depth:	1.5-2 ft BGS	2-2.5 ft BGS	0-1.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	0-3 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2-2.5 ft BGS	0-1.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS
Parameters																					
Pesticides																					
4,4'-DDD	ug/kg	-	-	7.7 J	-	8.6 U	-	-	10 U	-	-	58 p	-	-	-	17 U	-	-	-	6.7 U	-
4,4'-DDE	ug/kg	-	-	7.7 Jp	-	7.3 Jp	-	-	6.0 Jp	-	-	33 p	-	-	-	17 U	-	-	-	2.1 Jp	-
4,4'-DDT	ug/kg	-	-	37 p	-	30	-	-	8.5 J	-	-	120	-	-	-	17 U	-	-	-	6.9	-
Aldrin	ug/kg	-	-	13 U	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	8.9 U	-	-	-	3.5 U	-
alpha-BHC	ug/kg	-	-	2.1 Jp	-	7.4 J	-	-	10 U	-	-	8.4 J	-	-	-	8.9 U	-	-	-	3.5 U	-
alpha-Chlordane	ug/kg	-	-	44 p	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	8.9 U	-	-	-	3.5 U	-
beta-BHC	ug/kg	-	-	13 U	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	8.9 U	-	-	-	0.82 Jp	-
Chlordane, technical	ug/kg	-	-	13 U	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	8.9 U	-	-	-	3.5 U	-
delta-BHC	ug/kg	-	-	13 U	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	8.9 U	-	-	-	3.5 U	-
Dieldrin	ug/kg	-	-	7.8 Jp	-	3.3 Jp	-	-	1.7 Jp	-	-	28	-	-	-	17 U	-	-	-	6.7 U	-
Endosulfan I	ug/kg	-	-	6.7 Jp	-	8.6 U	-	-	10 U	-	-	10 p	-	-	-	8.9 U	-	-	-	3.5 U	-
Endosulfan II	ug/kg	-	-	27 p	-	14	-	-	10 U	-	-	9.9 U	-	-	-	17 U	-	-	-	6.7 U	-
Endosulfan sulfate	ug/kg	-	-	7.3 Jp	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	17 U	-	-	-	6.7 U	-
Endrin	ug/kg	-	-	1.9 Jp	-	0.84 Jp	-	-	10 U	-	-	6.0 Jp	-	-	-	17 U	-	-	-	6.7 U	-
Endrin aldehyde	ug/kg	-	-	13 p	-	2.0 Jp	-	-	10 U	-	-	18	-	-	-	17 U	-	-	-	6.7 U	-
Endrin ketone	ug/kg	-	-	3.1 Jp	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	17 U	-	-	-	6.1 Jp	-
gamma-BHC (lindane)	ug/kg	-	-	37 p	-	23 p	-	-	8.3 Jp	-	-	14 p	-	-	-	8.9 U	-	-	-	3.5 U	-
Heptachlor	ug/kg	-	-	34	-	40	-	-	29	-	-	25 p	-	-	-	8.9 U	-	-	-	3.5 U	-
Heptachlor epoxide	ug/kg	-	-	13 U	-	8.6 U	-	-	10 U	-	-	9.9 U	-	-	-	8.9 U	-	-	-	3.5 U	-
Methoxychlor	ug/kg	-	-	12 Jp	-	8.6 U	-	-	10 U	-	-	35 p	-	-	-	89 U	-	-	-	35 U	-
Toxaphene	ug/kg	-	-	130 U	-	86 U	-	-	100 U	-	-	99 U	-	-	-	430 U	-	-	-	220	-
Pesticides - TCLP																					
Chlordane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Geotech																					
#10 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#100 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#20 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#200 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#4 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#40 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#60 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#80 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Clay	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Coarse sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Fine sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Gravel	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Liquid limit (LL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Medium sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plastic limit (PL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plasticity index	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	SD-27	SD-27	FC-SD-28	SD-28	FC-SD-29	SD-29	SD-29	FC-SD-30	SD-30	SD-30	SD-30	FC-SD-31	SD-31	SD-31	SD-31	FC-SD-32	SD-32	SD-32	SD-32	FC-SD-33	SD-33
<i>Sample ID:</i>	SD-27(1.5-2)	SD-27(2-2.5)	FC-SD-28 (0-1.5)	SD-28(0-0.5)	FC-SD-29 (0-2)	SD-29(0-0.5)	SD-29(1.5-2)	FC-SD-30 (0-3)	SD-30(0-0.5)	SD-30(1.5-2)	SD-30(2-2.5)	FC-SD-31 (0-1.5)	SD-31(0-0.5)	SD-31(1.5-2)	SD-31(2.5-3)	FC-SD-32	SD-32(0-0.5)	SD-32(1.5-2)	SD-32(2.5-3)	FC-SD-33	SD-33(0-0.5)
<i>Sample Date:</i>	1/10/2011	1/10/2011	8/19/2009	1/10/2011	8/19/2009	1/10/2011	1/10/2011	8/19/2009	1/10/2011	1/10/2011	1/10/2011	8/19/2009	1/10/2011	1/10/2011	1/10/2011	9/30/2009	1/10/2011	1/10/2011	1/10/2011	9/30/2009	1/11/2011
<i>Sample Depth:</i>	1.5-2 ft BGS	2-2.5 ft BGS	0-1.5 ft BGS	0-0.5 ft BGS	0-2 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	0-3 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2-2.5 ft BGS	0-1.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS
Parameters																					
	Units																				
Sieve, 75000 microns, percent passing	%																				
Sieve, 9500 microns, percent passing	%																				
Silt	%																				
General Chemistry																					
Ash	%																				
Carbon	mg/kg																				
Cyanide (total)	ug/kg																				
Ignitability	mm/sec																				
Organic matter	%																				
Percent moisture	%																				
pH	s.u.																				
Reactive cyanide	mg/kg																				
Reactive sulfide	mg/kg																				

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	SD-33	SD-33	SD-33	SD-34	SD-34	SD-34	SD-35	SD-35	SD-35	SD-36	SD-36	SD-36	SD-36	SD-37	SD-37	SD-37	SD-38	SD-38	SD-38	SD-39	SD-39	SD-40	SD-40	SD-41	SD-41	SD-41	SD-42	SD-42		
<i>Sample ID:</i>	SD-33(1.5-2)	SD-33(2.5-3)	SD-X5	SD-34(0-0.5)	SD-34(1.5-2)	SD-34(3-3.5)	SD-35(0-0.5)	SD-35(1.5-2)	SD-35(4.5-5)	SD-36(0-0.5)	SD-36(1.5-2)	SD-36(3-3.5)	SD-X6	SD-37(0-0.5)	SD-37(1.5-2)	SD-37(4-4.5)	SD-38(0-0.5)	SD-38(1.5-2)	SD-38(2.5-3)	SD-39(0-0.5)	SD-39(1.5-2)	SD-40(0.5-1)	SD-40(0-0.5)	SD-41(0-0.5)	SD-41(2-2.5)	SD-41(4-4.5)	SD-42(0-0.5)	SD-42(2-2.5)		
<i>Sample Date:</i>	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	1/11/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011		
<i>Sample Depth:</i>	1.5-2 ft BGS	2.5-3 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4.5-5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	2.5-3 ft BGS	0-0.5 ft BGS	1.5-2 ft BGS	0.5-1 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS		
	<i>Duplicate</i>															<i>Duplicate</i>														
<i>Parameters</i>	<i>Units</i>																													
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>General Chemistry</i>																														
Ash	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cyanide (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Organic matter	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
 SUMMARY OF SEDIMENT ANALYTICAL DATA
 FRIEDRICHSOHN COOPERAGE SITE
 WATERFORD, NEW YORK

Sample Location:	SD-42	SD-43	SD-43	SD-43	SD-43	SD-44	SD-44	SD-45	SD-45	SD-45	SD-46	SD-46	SD-46	SD-47	SD-47	SD-47	SD-48	SD-48	SD-48	SD-49	SD-49	SD-49	SD-49	SD-50	SD-50	SD-50	SD-51	SD-51	SD-51	
Sample ID:	SD-42(4-4.5)	022211-SD-X	SD-43(0-0.5)	SD-43(2-2.5)	SD-43(4-4.5)	SD-44(0-0.5)	SD-44(2-2.5)	SD-45(0-0.5)	SD-45(2-2.5)	SD-45(4-4.5)	SD-46(0-0.5)	SD-46(2-2.5)	SD-46(4-4.5)	SD-47(0-0.5)	SD-47(2-2.5)	SD-47(4-4.5)	SD-48(0-0.5)	SD-48(2-2.5)	SD-48(4-4.5)	022311-SD-X	SD-49(0-0.5)	SD-49(2-2.5)	SD-49(4-4.5)	SD-50(0-0.5)	SD-50(2-2.5)	SD-50(4-4.5)	SD-51(0-0.5)	SD-51(2-2.5)	SD-51(4-4.5)	
Sample Date:	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/23/2011	2/23/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/22/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	2/23/2011	
Sample Depth:	4-4.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	
	Duplicate										Duplicate																			
Parameters	Units																													
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-	-	-	53.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
General Chemistry																														
Ash	%	-	-	-	-	-	-	-	-	-	90.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Carbon	mg/kg	-	-	47600	-	-	-	-	-	-	42400	-	-	-	-	-	-	-	-	-	-	44200	-	-	-	-	-	-	-	
Cyanide (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Organic matter	%	-	-	-	-	-	-	-	-	-	9.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Percent moisture	%	-	-	-	-	-	-	-	-	-	98.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-52	SD-52	SD-52	SD-53	SD-53	SD-53	SD-54	SD-54	SD-54	SD-55	SD-55	SD-56	SD-56	SD-57	SD-57	SD-58	SD-58	SD-59	SD-59	SD-59	SD-59	SD-60	SD-60	SD-61	SD-61	SD-62	SD-63	SD-63	
Sample ID:	SD-52 (0-0.5)	SD-52 (2-2.5)	SD-52 (4-4.5)	SD-53 (0-0.5)	SD-53 (2-2.5)	SD-53 (4-4.5)	SD-54 (0-0.5)	SD-54 (2-2.5)	SD-54 (4-4.5)	SD-55 (2-2.5)	SD-55 (4-4.5)	SD-56 (0-0.5)	SD-56 (2-2.5)	SD-57 (2-2.5)	SD-57 (3-3.5)	SD-58 (0-0.5)	SD-58 (1-1.5)	SD-59 (0-0.5)	SD-59 (2-2.5)	SD-59 (4-4.5)	SD-X7	SD-60 (2-2.5)	SD-60 (3-3.5)	SD-61 (0-0.5)	SD-61 (3-3.5)	SD-62(2-2.5)	SD-63 (2-2.5)	SD-63 (4-4.5)	
Sample Date:	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/21/2011	3/21/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/22/2011	3/22/2011	
Sample Depth:	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	1-1.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	
Parameters	Units																												
<i>Semi-volatile Organic Compounds - TCLP</i>																													
1,4-Dichlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2,4,5-Trichlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2,4,6-Trichlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2,4-Dinitrotoluene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2-Methylphenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4-Methylphenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hexachlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hexachlorobutadiene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hexachloroethane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Nitrobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Pentachlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Pyridine	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>Metals</i>																													
Aluminum	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Antimony	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Arsenic	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Barium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Beryllium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cadmium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Calcium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chromium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cobalt	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Copper	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Iron	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Lead	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Magnesium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Manganese	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Mercury	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Nickel	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Potassium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Selenium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silver	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sodium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Thallium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Vanadium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Zinc	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>Metals - TCLP</i>																													
Arsenic	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Barium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cadmium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chromium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Lead	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Mercury	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Selenium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silver	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>PCBs</i>																													
Aroclor-1016 (PCB-1016)	ug/kg	770 U	1500 U	340 U	330 U	160 U	31 U	360 U	690 U	290 U	190 U	27 U	320 U	180 U	89 U	92 U	25 U	22 U	730 U	1000 U	2300 U	810 U	4300 U	720 U	750 U	390 U	19 U	8100 U	2000 U
Aroclor-1221 (PCB-1221)	ug/kg	770 U	1500 U	340 U	330 U	160 U	31 U	360 U	690 U	290 U	190 U	27 U	320 U	180 U	89 U	92 U	25 U	22 U	730 U	1000 U	2300 U	810 U	4300 U	720 U	750 U	390 U	19 U	8100 U	2000 U
Aroclor-1232 (PCB-1232)	ug/kg	770 U	1500 U	340 U	330 U	160 U	31 U	360 U	690 U	290 U	190 U	27 U	320 U	180 U	89 U	92 U	25 U	22 U	730 U	1000 U	2300 U	810 U	4300 U	720 U	750 U	390 U	19 U	8100 U	2000 U
Aroclor-1242 (PCB-1242)	ug/kg	7400	14000	3300 p	2500	1200	180	1900 p	4600	3100	2100	27 U	3600	2100	1000	1100	260	53	6900	13000	22000	6700	67000	9600	4200 p	3100	19 U	38000	8000
Aroclor-1248 (PCB-1248)	ug/kg	770 U	1500 U	340 U	330 U	160 U	31 U	360 U	690 U	290 U	190 U	270	320 U	180 U	89 U	92 U	25 U	22 U	730 U	1000 U	2300 U	810 U	4300 U	720 U	750 U	390 U	19 U	8100 U	2000 U
Aroclor-1254 (PCB-1254)	ug/kg	1400 p	2500 p	820 p	560	450 p	320	1100	2600	1900	950 p	85 p	1300	430 p	390	330	78 p	18 Jp	1400 p	3700	8400	2900	14000	2000 p	2700	1000 p	19 U	11000	2200 p
Aroclor-1260 (PCB-1260)	ug/kg	290 J	450 J	150 J	110 J	71 J	28 J	190 J	250 J	260 J	180 J	10 J	140 Jp	70 J	52 J	38 J	11 J	22 U	730 U	570 J	1100 J	480 J	1200 J	170 Jp	470 J	240 J	19 U	8100 U	540 J
Total PCBs	ug/kg	9090	16950	4270	3170	1721	528	3190	7450	5260	3230	365	5040	2600	1442	1468	349	71	8300	17270	31500	10080	82200	11770	7370	4340	0	49000	10740

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-52	SD-52	SD-52	SD-53	SD-53	SD-53	SD-54	SD-54	SD-54	SD-55	SD-55	SD-56	SD-56	SD-57	SD-57	SD-58	SD-58	SD-59	SD-59	SD-59	SD-59	SD-59	SD-60	SD-60	SD-61	SD-61	SD-62	SD-63	SD-63
Sample ID:	SD-52 (0-0.5)	SD-52 (2-2.5)	SD-52 (4-4.5)	SD-53 (0-0.5)	SD-53 (2-2.5)	SD-53 (4-4.5)	SD-54 (0-0.5)	SD-54 (2-2.5)	SD-54 (4-4.5)	SD-55 (2-2.5)	SD-55 (4-4.5)	SD-56 (0-0.5)	SD-56 (2-2.5)	SD-57 (2-2.5)	SD-57 (3-3.5)	SD-58(0-0.5)	SD-58(1-1.5)	SD-59 (0-0.5)	SD-59 (2-2.5)	SD-59 (4-4.5)	SD-X7	SD-60 (2-2.5)	SD-60 (3-3.5)	SD-61 (0-0.5)	SD-61 (3-3.5)	SD-62(2-2.5)	SD-63 (2-2.5)	SD-63 (4-4.5)	
Sample Date:	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/21/2011	3/21/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/22/2011	3/22/2011	
Sample Depth:	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	1-1.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS
<i>Duplicate</i>																													
Parameters	Units																												
Pesticides																													
4,4'-DDD	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
4,4'-DDE	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
4,4'-DDT	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Aldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
alpha-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
alpha-Chlordane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
beta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Chlordane, technical	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
delta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Dieldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endosulfan I	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endosulfan II	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endosulfan sulfate	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endrin aldehyde	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endrin ketone	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
gamma-BHC (lindane)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Heptachlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Heptachlor epoxide	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Methoxychlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Toxaphene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Pesticides - TCLP																													
Chlordane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Endrin	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
gamma-BHC (lindane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Heptachlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Heptachlor epoxide	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Methoxychlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Toxaphene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Geotech																													
#10 sieve (passed)	% passed	-	-	-	100.0	94.0	-	-	-	-	-	-	73.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#100 sieve (passed)	% passed	-	-	-	98.0	77.4	-	-	-	-	-	-	41.2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#20 sieve (passed)	% passed	-	-	-	99.9	90.2	-	-	-	-	-	-	61.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#200 sieve (passed)	% passed	-	-	-	89.5	65.0	-	-	-	-	-	-	29.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#4 sieve (passed)	% passed	-	-	-	100.0	97.7	-	-	-	-	-	-	86.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#40 sieve (passed)	% passed	-	-	-	99.7	86.5	-	-	-	-	-	-	54.8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#60 sieve (passed)	% passed	-	-	-	99.2	83.7	-	-	-	-	-	-	49.8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
#80 sieve (passed)	% passed	-	-	-	98.5	79.5	-	-	-	-	-	-	43.8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Clay	%	-	-	-	37.1	24.4	-	-	-	-	-	-	11.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Coarse sand	%	-	-	-	0.0	3.7	-	-	-	-	-	-	13.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Fine sand	%	-	-	-	10.2	21.5	-	-	-	-	-	-	25.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Gravel	%	-	-	-	0.0	2.3	-	-	-	-	-	-	13.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 1 for particle size distribution	% passed	-	-	-	70.3	45.3	-	-	-	-	-	-	21.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 2 for particle size distribution	% passed	-	-	-	61.5	39.7	-	-	-	-	-	-	18.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 3 for particle size distribution	% passed	-	-	-	52.7	34.2	-	-	-	-	-	-	15.3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 4 for particle size distribution	% passed	-	-	-	45.9	28.7	-	-	-	-	-	-	13.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 5 for particle size distribution	% passed	-	-	-	37.1	24.4	-	-	-	-	-	-	11.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 6 for particle size distribution	% passed	-	-	-	25.0	17.9	-	-	-	-	-	-	8.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hydrometer 7 for particle size distribution	% passed	-	-	-	16.2	12.4	-	-	-	-	-	-	5.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Liquid limit (LL)	none	-	-	-	78	58	-	-	-	-	-	-	28	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Medium sand	%	-	-	-	0.3	7.5	-	-	-	-	-	-	18.3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Plastic limit (PL)	none	-	-	-	37	33	-	-	-	-	-	-	25	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Plasticity index	none	-	-	-	40	25	-	-	-	-	-	-	3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sand	%	-	-	-	10.5	32.7	-	-	-	-	-	-	57.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 19000 microns, percent passing	% passed	-	-	-	100.0	100.0	-	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 25000 microns, percent passing	% passed	-	-	-	100.0	100.0	-	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 37500 microns, percent passing	% passed	-	-	-	100.0	100.0	-	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Sieve, 50000 microns, percent passing	% passed	-	-	-	100.0	100.0	-	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	SD-52	SD-52	SD-52	SD-53	SD-53	SD-53	SD-54	SD-54	SD-54	SD-55	SD-55	SD-56	SD-56	SD-57	SD-57	SD-58	SD-58	SD-59	SD-59	SD-59	SD-59	SD-59	SD-60	SD-60	SD-61	SD-61	SD-62	SD-63	SD-63
<i>Sample ID:</i>	SD-52 (0-0.5)	SD-52 (2-2.5)	SD-52 (4-4.5)	SD-53 (0-0.5)	SD-53 (2-2.5)	SD-53 (4-4.5)	SD-54 (0-0.5)	SD-54 (2-2.5)	SD-54 (4-4.5)	SD-55 (2-2.5)	SD-55 (4-4.5)	SD-56 (0-0.5)	SD-56 (2-2.5)	SD-57 (2-2.5)	SD-57 (3-3.5)	SD-58(0-0.5)	SD-58(1-1.5)	SD-59 (0-0.5)	SD-59 (2-2.5)	SD-59 (4-4.5)	SD-X7	SD-60 (2-2.5)	SD-60 (3-3.5)	SD-61 (0-0.5)	SD-61 (3-3.5)	SD-62(2-2.5)	SD-63 (2-2.5)	SD-63 (4-4.5)	
<i>Sample Date:</i>	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/21/2011	3/21/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/22/2011	3/22/2011	
<i>Sample Depth:</i>	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	1-1.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	
<i>Parameters</i>	<i>Units</i>																												
Sieve, 75000 microns, percent passing	% passed	-	-	-	100.0	100.0	-	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	100.0	99.2	-	-	-	-	-	-	95.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	52.4	40.6	-	-	-	-	-	-	17.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>General Chemistry</i>	<i>Units</i>																												
Ash	%	-	-	-	91.8	91.0	-	-	-	-	-	-	96.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	-	67200	-	-	-	55300	-	-	-	-	-	-	23700	-	-	-	-	-	-	-	-	65200	-	-	-	-
Cyanide (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Organic matter	%	-	-	-	8.2	9.0	-	-	-	-	-	-	3.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	87.5	69.8	-	-	-	-	-	-	34.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-64	SD-64	SD-64	SD-65	SD-65	SD-66	SD-66	SD-66	SD-67	SD-67	SD-67	SD-67	SD-68	SD-68	SD-68	SD-69	SD-69	SD-70	SD-73	SD-73		
Sample ID:	SD-64 (0-0.5)	SD-64 (2-2.5)	SD-64 (4-4.5)	SD-65 (2-2.5)	SD-X8	SD-66(0-0.5)	SD-66(2-2.5)	SD-66(4-4.5)	SD-67 (0-0.5)	SD-67 (2-2.5)	SD-67 (6-6.5)	SD-X12	SD-68 (0-0.5)	SD-68 (2-2.5)	SD-68 (3-3.5)	SD-69 (2-2.5)	SD-69 (4-4.5)	SD-70(1.8-2.0)	SD-73(0-0.5)	SD-73(2-2.5)		
Sample Date:	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/18/2011	3/18/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/16/2011	3/21/2011	3/21/2011		
Sample Depth:	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	6-6.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	1.8-2 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS		
											Duplicate		Duplicate									
Parameters	Units																					
Volatiles Organic Compounds																						
1,1,1-Trichloroethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
1,1,2,2-Tetrachloroethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
1,1,2-Trichloroethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
1,1-Dichloroethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
1,1-Dichloroethene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U*	-	710 U	-	-	-	-	-	-		
1,2-Dichloroethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
1,2-Dichloropropane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
2-Butanone (Methyl ethyl ketone) (MEK)	ug/kg	-	-	-	-	-	-	-	17 U	-	-	19 U	-	710 U	-	-	-	-	-	-		
2-Hexanone	ug/kg	-	-	-	-	-	-	-	17 U	-	-	19 U	-	710 U	-	-	-	-	-	-		
4-Methyl-2-pentanone (Methyl isobutyl ketone) (MIBK)	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Acetone	ug/kg	-	-	-	-	-	-	-	34 U	-	-	38 U	-	4900	-	-	-	-	-	-		
Benzene	ug/kg	-	-	-	-	-	-	-	2.9 J	-	-	1.7 J	-	330 J	-	-	-	-	-	-		
Bromodichloromethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Bromoform	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Bromomethane (Methyl bromide)	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Carbon disulfide	ug/kg	-	-	-	-	-	-	-	8.4 U*	-	-	9.5 U*	-	1100	-	-	-	-	-	-		
Carbon tetrachloride	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U*	-	710 U	-	-	-	-	-	-		
Chlorobenzene	ug/kg	-	-	-	-	-	-	-	30	-	-	17	-	20000	-	-	-	-	-	-		
Chloroethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Chloroform (Trichloromethane)	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Chloromethane (Methyl chloride)	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
cis-1,2-Dichloroethene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
cis-1,3-Dichloropropene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Dibromochloromethane	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Ethylbenzene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	280 J	-	-	-	-	-	-		
Methylene chloride	ug/kg	-	-	-	-	-	-	-	34 U	-	-	38 U	-	180 JB	-	-	-	-	-	-		
Styrene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Tetrachloroethene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Toluene	ug/kg	-	-	-	-	-	-	-	2.3 JB	-	-	1.5 JB	-	460 J	-	-	-	-	-	-		
trans-1,2-Dichloroethene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
trans-1,3-Dichloropropene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Trichloroethene	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Vinyl chloride	ug/kg	-	-	-	-	-	-	-	8.4 U	-	-	9.5 U	-	710 U	-	-	-	-	-	-		
Xylenes (total)	ug/kg	-	-	-	-	-	-	-	3.0 J	-	-	9.5 U	-	1400	-	-	-	-	-	-		
Volatiles Organic Compounds - TCLP																						
1,1-Dichloroethene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
1,2-Dichloroethane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
2-Butanone (Methyl ethyl ketone) (MEK)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Benzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Carbon tetrachloride	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Chlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Chloroform (Trichloromethane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Tetrachloroethene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Trichloroethene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Vinyl chloride	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
Semi-volatile Organic Compounds																						
1,2,4-Trichlorobenzene	ug/kg	-	-	4800 U	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U		
1,2-Dichlorobenzene	ug/kg	-	-	4800 U	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	41000 J		
1,3-Dichlorobenzene	ug/kg	-	-	4800 U	-	-	-	-	310 J	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U		
1,4-Dichlorobenzene	ug/kg	-	-	4300 J	-	-	-	-	880 J	-	110 J	790 J	-	3300 J	-	350 U	-	-	-	100000 U		
2,2'-Oxybis(1-chloropropane) (bis(2-Chloroisopropyl) ether)	ug/kg	-	-	4800 U	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U		
2,4,5-Trichlorophenol	ug/kg	-	-	30000 U	-	-	-	-	5700 U	-	2600 U	65000 U	-	48000 U	-	2200 U	-	-	-	630000 U		
2,4,6-Trichlorophenol	ug/kg	-	-	4800 U	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U		
2,4-Dichlorophenol	ug/kg	-	-	4800 U	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U		
2,4-Dimethylphenol	ug/kg	-	-	2600 J	-	-	-	-	910 U	-	410 U	10000 U	-	2000 J	-	350 U	-	-	-	100000 U		
2,4-Dinitrophenol	ug/kg	-	-	30000 U	-	-	-	-	5700 U	-	2600 U	65000 U	-	48000 U	-	2200 U	-	-	-	630000 U*		
2,4-Dinitrotoluene	ug/kg	-	-	4800 U	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U		

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSON COOPERAGE SITE
WATERFORD, NEW YORK**

Sample Location:	SD-64	SD-64	SD-64	SD-65	SD-65	SD-66	SD-66	SD-66	SD-67	SD-67	SD-67	SD-67	SD-68	SD-68	SD-68	SD-69	SD-69	SD-70	SD-73	SD-73	
	SD-64 (0-0.5)	SD-64 (2-2.5)	SD-64 (4-4.5)	SD-65 (2-2.5)	SD-X8	SD-66(0-0.5)	SD-66(2-2.5)	SD-66(4-4.5)	SD-67 (0-0.5)	SD-67 (2-2.5)	SD-67 (6-6.5)	SD-X12	SD-68 (0-0.5)	SD-68 (2-2.5)	SD-68 (3-3.5)	SD-69 (2-2.5)	SD-69 (4-4.5)	SD-70(1.8-2.0)	SD-73(0-0.5)	SD-73(2-2.5)	
Sample ID:																					
Sample Date:	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/18/2011	3/18/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/16/2011	3/21/2011	3/21/2011	
Sample Depth:	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	6-6.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	1.8-2 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	
Parameters	Duplicate										Duplicate										
Units	Duplicate										Duplicate										
2,6-Dinitrotoluene	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
2-Chloronaphthalene	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	7100 J
2-Chlorophenol	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
2-Methylnaphthalene	ug/kg	-	-	1300 J	-	-	-	-	-	910 U	-	110 J	10000 U	-	8200	-	210 J	-	-	-	66000 J
2-Methylphenol	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
2-Nitroaniline	ug/kg	-	-	12000 U	-	-	-	-	-	2300 U	-	1000 U	26000 U	-	19000 U	-	870 U	-	-	-	250000 U
2-Nitrophenol	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
3&4-Methylphenol	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
3,3'-Dichlorobenzidine	ug/kg	-	-	5900 U	-	-	-	-	-	1100 U	-	500 U	13000 U	-	9400 U	-	430 U	-	-	-	120000 U
3-Nitroaniline	ug/kg	-	-	12000 U	-	-	-	-	-	2300 U	-	1000 U	26000 U	-	19000 U	-	870 U	-	-	-	250000 U
4,6-Dinitro-2-methylphenol	ug/kg	-	-	30000 U	-	-	-	-	-	5700 U	-	2600 U	65000 U	-	48000 U	-	2200 U	-	-	-	630000 U*
4-Bromophenyl phenyl ether	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
4-Chloro-3-methylphenol	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
4-Chloroaniline	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
4-Chlorophenyl phenyl ether	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
4-Methylphenol	ug/kg	-	-	2800 J	-	-	-	-	-	190 J	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
4-Nitroaniline	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
4-Nitrophenol	ug/kg	-	-	30000 U	-	-	-	-	-	5700 U	-	2600 U	65000 U	-	48000 U	-	2200 U	-	-	-	630000 U
Acenaphthene	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	4500 J	-	350 U	-	-	-	100000 U
Acenaphthylene	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	710 J	-	7700 U	-	350 U	-	-	-	100000 U
Acetophenone	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Anthracene	ug/kg	-	-	2200 J	-	-	-	-	-	890 J	-	410 U	1700 J	-	7700 U	-	350 U	-	-	-	100000 U
Atrazine	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Benzaldehyde	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Benzo(a)anthracene	ug/kg	-	-	1800 J	-	-	-	-	-	3700	-	150 J	5500 J	-	1800 J	-	350 U	-	-	-	100000 U
Benzo(a)pyrene	ug/kg	-	-	1800 J	-	-	-	-	-	3800	-	200 J	5500 J	-	2200 J	-	350 U	-	-	-	100000 U
Benzo(b)fluoranthene	ug/kg	-	-	2300 J	-	-	-	-	-	4900	-	230 J	8200 J	-	2800 J	-	350 U	-	-	-	100000 U
Benzo(g,h,i)perylene	ug/kg	-	-	1300 J	-	-	-	-	-	2100	-	140 J	9700 J	-	2100 J	-	350 U	-	-	-	100000 U
Benzo(k)fluoranthene	ug/kg	-	-	800 J	-	-	-	-	-	2100	-	88 J	3500 J	-	760 J	-	350 U	-	-	-	100000 U
Benzyl alcohol	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Biphenyl (1,1-Biphenyl)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
bis(2-Chloroethoxy)methane	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
bis(2-Chloroethyl)ether	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
bis(2-Ethylhexyl)phthalate (DEHP)	ug/kg	-	-	13000 B	-	-	-	-	-	2000 B	-	260 JB	16000 B	-	54000 B	-	510 B	-	-	-	56000 JB
Butyl benzylphthalate (BBP)	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Caprolactam	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbazole	ug/kg	-	-	4800 U	-	-	-	-	-	250 J	-	410 U	620 J	-	7700 U	-	350 U	-	-	-	100000 U
Chrysene	ug/kg	-	-	2200 J	-	-	-	-	-	4100	-	160 J	6200 J	-	2100 J	-	350 U	-	-	-	100000 U
Dibenz(a,h)anthracene	ug/kg	-	-	4800 U	-	-	-	-	-	550 J	-	410 U	3400 J	-	7700 U	-	350 U	-	-	-	100000 U
Dibenzofuran	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Diethyl phthalate	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Dimethyl phthalate	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Di-n-butylphthalate (DBP)	ug/kg	-	-	4800 U	-	-	-	-	-	190 J	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Di-n-octyl phthalate (DnOP)	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Fluoranthene	ug/kg	-	-	3800 J	-	-	-	-	-	6800	-	180 J	14000	-	2900 J	-	350 U	-	-	-	100000 U
Fluorene	ug/kg	-	-	4800 U	-	-	-	-	-	240 J	-	410 U	760 J	-	7700 U	-	350 U	-	-	-	100000 U
Hexachlorobenzene	ug/kg	-	-	4800 U	-	-	-	-	-	4800 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	800000
Hexachlorobutadiene	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Hexachlorocyclopentadiene	ug/kg	-	-	12000 U	-	-	-	-	-	2300 U	-	1000 U	26000 U	-	19000 U	-	870 U	-	-	-	250000 U*
Hexachloroethane	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Indeno(1,2,3-cd)pyrene	ug/kg	-	-	1200 J	-	-	-	-	-	2300	-	150 J	5800 J	-	2000 J	-	350 U	-	-	-	100000 U
Isophorone	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Naphthalene	ug/kg	-	-	990 J	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000
Nitrobenzene	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
N-Nitrosodi-n-propylamine	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
N-Nitrosodiphenylamine	ug/kg	-	-	4800 U	-	-	-	-	-	910 U	-	410 U	10000 U	-	7700 U	-	350 U	-	-	-	100000 U
Pentachlorophenol	ug/kg	-	-	12000 U	-	-	-	-	-	2300 U	-	1000 U	26000 U	-	19000 U	-	870 U	-	-	-	250000 U
Phenanthrene	ug/kg	-	-	3700 J	-	-	-	-	-	3400	-	160 J	10000	-	4000 J	-	78 J	-	-	-	100000 U
Phenol	ug/kg	-	-	750 J	-	-	-	-	-	2500	-	410 U	710 J	-	1500 J	-	350 U	-	-	-	19000 J
Pyrene	ug/kg	-	-	2300 J	-	-	-	-	-	5400	-	140 J	14000	-	2000 J	-	350 U	-	-	-	100000 U

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-64	SD-64	SD-64	SD-65	SD-65	SD-66	SD-66	SD-66	SD-67	SD-67	SD-67	SD-67	SD-68	SD-68	SD-68	SD-69	SD-69	SD-70	SD-73	SD-73	
Sample ID:	SD-64 (0-0.5)	SD-64 (2-2.5)	SD-64 (4-4.5)	SD-65 (2-2.5)	SD-X8	SD-66(0-0.5)	SD-66(2-2.5)	SD-66(4-4.5)	SD-67 (0-0.5)	SD-67 (2-2.5)	SD-67 (6-6.5)	SD-X12	SD-68 (0-0.5)	SD-68 (2-2.5)	SD-68 (3-3.5)	SD-69 (2-2.5)	SD-69 (4-4.5)	SD-70(1.8-2.0)	SD-73(0-0.5)	SD-73(2-2.5)	
Sample Date:	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/18/2011	3/18/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/16/2011	3/21/2011	3/21/2011	
Sample Depth:	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	6-6.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	1.8-2 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	
		Duplicate										Duplicate									
Parameters	Units																				
Semi-volatile Organic Compounds - TCLP																					
1,4-Dichlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2,4,5-Trichlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2,4,6-Trichlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2,4-Dinitrotoluene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2-Methylphenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
4-Methylphenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hexachlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hexachlorobutadiene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Hexachloroethane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Nitrobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Pentachlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Pyridine	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Metals																					
Aluminum	mg/kg	-	-	-	-	-	-	-	7360	-	-	8410	-	6800	-	-	-	-	-	-	
Antimony	mg/kg	-	-	-	-	-	-	-	6.9 U	-	-	7.6 U	-	5.9 U	-	-	-	-	-	-	
Arsenic	mg/kg	-	-	-	-	-	-	-	42.4	-	-	25.6	-	15.8	-	-	-	-	-	-	
Barium	mg/kg	-	-	-	-	-	-	-	646	-	-	731	-	280	-	-	-	-	-	-	
Beryllium	mg/kg	-	-	-	-	-	-	-	0.51 J	-	-	0.58 J	-	0.46 J	-	-	-	-	-	-	
Cadmium	mg/kg	-	-	-	-	-	-	-	1.8 J	-	-	1.8 J	-	2.7	-	-	-	-	-	-	
Calcium	mg/kg	-	-	-	-	-	-	-	13400	-	-	16300	-	36200	-	-	-	-	-	-	
Chromium	mg/kg	-	-	-	-	-	-	-	174	-	-	330	-	84.6	-	-	-	-	-	-	
Cobalt	mg/kg	-	-	-	-	-	-	-	8.6	-	-	8.8	-	7.3	-	-	-	-	-	-	
Copper	mg/kg	-	-	-	-	-	-	-	163	-	-	107	-	63.0	-	-	-	-	-	-	
Iron	mg/kg	-	-	-	-	-	-	-	64000	-	-	50300	-	18000	-	-	-	-	-	-	
Lead	mg/kg	-	-	-	-	-	-	-	924	-	-	1530	-	611	-	-	-	-	-	-	
Magnesium	mg/kg	-	-	-	-	-	-	-	5380	-	-	7440	-	5800	-	-	-	-	-	-	
Manganese	mg/kg	-	-	-	-	-	-	-	395	-	-	394	-	272	-	-	-	-	-	-	
Mercury	mg/kg	-	-	-	-	-	-	-	0.41	-	-	0.46	-	1.0	-	-	-	-	-	-	
Nickel	mg/kg	-	-	-	-	-	-	-	25.9	-	-	29.1	-	18.9	-	-	-	-	-	-	
Potassium	mg/kg	-	-	-	-	-	-	-	738	-	-	1020	-	820	-	-	-	-	-	-	
Selenium	mg/kg	-	-	-	-	-	-	-	15.7 U	-	-	17.3 U	-	13.3 U	-	-	-	-	-	-	
Silver	mg/kg	-	-	-	-	-	-	-	2.1 U	-	-	2.3 U	-	1.8 U	-	-	-	-	-	-	
Sodium	mg/kg	-	-	-	-	-	-	-	755	-	-	961	-	299	-	-	-	-	-	-	
Thallium	mg/kg	-	-	-	-	-	-	-	6.3 U	-	-	6.9 U	-	5.3 U	-	-	-	-	-	-	
Vanadium	mg/kg	-	-	-	-	-	-	-	18.7	-	-	19.5	-	13.1	-	-	-	-	-	-	
Zinc	mg/kg	-	-	-	-	-	-	-	677	-	-	606	-	289	-	-	-	-	-	-	
Metals - TCLP																					
Arsenic	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Barium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Cadmium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Chromium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Lead	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Mercury	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Selenium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Silver	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
PCBs																					
Aroclor-1016 (PCB-1016)	ug/kg	250 U	390 U	1500 U	1100 U	840 U	21 U	20 U	22 U	570 U	530 U	260 U	320 U	2300 U	4800 U	5400 U	2200 U	2100 U	21 U	47000 U	6300 U
Aroclor-1221 (PCB-1221)	ug/kg	250 U	390 U	1500 U	1100 U	840 U	21 U	20 U	22 U	570 U	530 U	260 U	320 U	2300 U	4800 U	5400 U	2200 U	2100 U	21 U	47000 U	6300 U
Aroclor-1232 (PCB-1232)	ug/kg	250 U	390 U	1500 U	1100 U	840 U	21 U	20 U	22 U	570 U	530 U	260 U	320 U	2300 U	4800 U	5400 U	2200 U	2100 U	21 U	47000 U	6300 U
Aroclor-1242 (PCB-1242)	ug/kg	2600	4400	10000	12000	5700	190 p	29	45 p	6700	4900	2400	3200	32000	63000	49000	19000 p	16000 p	43	260000	50000
Aroclor-1248 (PCB-1248)	ug/kg	250 U	390 U	1500 U	1100 U	840 U	21 U	20 U	22 U	570 U	530 U	260 U	320 U	2300 U	4800 U	5400 U	2200 U	2100 U	21 U	47000 U	6300 U
Aroclor-1254 (PCB-1254)	ug/kg	820	1300	3100	2000	830 J	40	20 U	6.6 J	1900	1700	370	1400	2400 p	7900	6300	2700	3100	9.5 J	42000 J	24000
Aroclor-1260 (PCB-1260)	ug/kg	73 Jp	150 J	1500 U	1100 U	840 U	8.2 J	20 U	22 U	210 J	250 J	260 U	250 J	2300 U	4800 U	5400 U	2200 U	2100 U	21 U	47000 U	2000 J
Total PCBs	ug/kg	3493	5850	13100	14000	6530	238.2	29	51.6	8810	6850	2770	4850	34400	70900	55300	21700	19100	52.5	302000	76000

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

Sample Location:	SD-64	SD-64	SD-64	SD-65	SD-65	SD-66	SD-66	SD-66	SD-67	SD-67	SD-67	SD-67	SD-68	SD-68	SD-68	SD-69	SD-69	SD-70	SD-73	SD-73
Sample ID:	SD-64 (0-0.5)	SD-64 (2-2.5)	SD-64 (4-4.5)	SD-65 (2-2.5)	SD-X8	SD-66(0-0.5)	SD-66(2-2.5)	SD-66(4-4.5)	SD-67 (0-0.5)	SD-67 (2-2.5)	SD-67 (6-6.5)	SD-X12	SD-68 (0-0.5)	SD-68 (2-2.5)	SD-68 (3-3.5)	SD-69 (2-2.5)	SD-69 (4-4.5)	SD-70(1.8-2.0)	SD-73(0-0.5)	SD-73(2-2.5)
Sample Date:	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/18/2011	3/18/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/16/2011	3/21/2011	3/21/2011
Sample Depth:	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	6-6.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	1.8-2 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS
	Duplicate										Duplicate									
Parameters	Units																			
Pesticides																				
4,4'-DDD	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4,4'-DDE	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4,4'-DDT	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Aldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
alpha-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
alpha-Chlordane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
beta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chlordane, technical	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
delta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Dieldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan I	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan II	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan sulfate	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin aldehyde	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin ketone	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Pesticides - TCLP																				
Chlordane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Geotech																				
#10 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	98.2	-
#100 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	19.0	-
#20 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	95.4	-
#200 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.6	-
#4 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	99.5	-
#40 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	63.3	-
#60 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	37.2	-
#80 sieve (passed)	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	24.3	-
Clay	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	4.0	-
Coarse sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1.3	-
Fine sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	54.8	-
Gravel	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0.5	-
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	6.3	-
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	5.8	-
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	5.2	-
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	4.6	-
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	4.0	-
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	4.0	-
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	2.8	-
Liquid limit (LL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0	-
Medium sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	34.9	-
Plastic limit (PL)	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0	-
Plasticity index	none	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0 U	-
Sand	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	91.0	-
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	100.0	-
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	100.0	-
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	100.0	-
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	100.0	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>		SD-64	SD-64	SD-64	SD-65	SD-65	SD-66	SD-66	SD-66	SD-67	SD-67	SD-67	SD-67	SD-68	SD-68	SD-68	SD-69	SD-69	SD-70	SD-73	SD-73		
<i>Sample ID:</i>		SD-64 (0-0.5)	SD-64 (2-2.5)	SD-64 (4-4.5)	SD-65 (2-2.5)	SD-X8	SD-66(0-0.5)	SD-66(2-2.5)	SD-66(4-4.5)	SD-67 (0-0.5)	SD-67 (2-2.5)	SD-67 (6-6.5)	SD-X12	SD-68 (0-0.5)	SD-68 (2-2.5)	SD-68 (3-3.5)	SD-69 (2-2.5)	SD-69 (4-4.5)	SD-70(1.8-2.0)	SD-73(0-0.5)	SD-73(2-2.5)		
<i>Sample Date:</i>		3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/18/2011	3/18/2011	3/18/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/22/2011	3/16/2011	3/21/2011	3/21/2011		
<i>Sample Depth:</i>		0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	6-6.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	1.8-2 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS		
		<i>Duplicate</i>										<i>Duplicate</i>											
<i>Parameters</i>	<i>Units</i>																						
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	100.0	-	
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	100.0	-	
Silt	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	4.5	-	
<i>General Chemistry</i>																							
Ash	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	96.3	-	
Carbon	mg/kg	-	-	-	-	-	-	-	2860	-	-	-	-	-	-	-	8640	-	-	-	-	-	
Cyanide (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Organic matter	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	3.7	-	
Percent moisture	%	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	29.5	-	
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	SD-73	SD-74	SD-74	SD-75	SD-75	SD-77	SD-77	SD-77	SD-78	SD-78	SD-78	SD-79	SD-79	SD-80	SD-80	SD-81	SD-81	SD-81	SD-84	SD-84	SD-85	SD-85	SD-89	SD-89	SD-90	SD-90	SD-91	SD-91	
<i>Sample ID:</i>	SD-73(4-4.5)	SD-74(2-2.5)	SD-74(4-4.5)	SD-75(2-2.5)	SD-75(4-4.5)	SD-77(0-0.5)	SD-77(2-2.5)	SD-77(5.5-6)	SD-78(0-0.5)	SD-78(2-2.5)	SD-78(4.5-5)	SD-79(2-2.5)	SD-79(4-4.5)	SD-80(2-2.5)	SD-80(6-6.5)	SD-81(0-0.5)	SD-81(2-2.5)	SD-81(4-4.5)	SD-84(2-2.5)	SD-84(5-5.5)	SD-85(2-2.5)	SD-85(6-6.5)	SD-89(2-2.5)	SD-89(4-4.5)	SD-90(2-2.5)	SD-90(3.5-4)	SD-91(0-0.5)	SD-91(2-2.5)	
<i>Sample Date:</i>	3/21/2011	3/21/2011	3/21/2011	3/16/2011	3/16/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/18/2011	3/18/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/17/2011	3/17/2011	3/21/2011	3/21/2011	3/18/2011	3/18/2011	3/21/2011	3/21/2011	
<i>Sample Depth:</i>	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	5.5-6 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4.5-5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	6-6.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	5-5.5 ft BGS	2-2.5 ft BGS	6-6.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	3.5-4 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	
Parameters	Units	Criteria																											
Sieve, 75000 microns, percent passing	% passed	100.0	-	-	-	-	-	-	-	-	-	-	100.0	100.0	-	-	100.0	-	-	-	-	-	-	100.0	100.0	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	100.0	-	-	-	-	-	-	-	-	-	-	100.0	100.0	-	-	90.5	-	-	-	-	-	-	100.0	95.0	-	-	-	-
Silt	%	31.3	-	-	-	-	-	-	-	-	-	-	47.8	40.5	-	-	26.6	-	-	-	-	-	-	41.0	41.4	-	-	-	-
General Chemistry																													
Ash	%	87.3	-	-	-	-	-	-	-	-	-	-	95.7	97.3	-	-	91.0	-	-	-	-	-	-	94.0	97.0	-	-	-	-
Carbon	mg/kg	-	-	-	15000	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Cyanide (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Organic matter	%	12.7	-	-	-	-	-	-	-	-	-	-	4.3	2.7	-	-	9.0	-	-	-	-	-	-	6.0	3.0	-	-	-	-
Percent moisture	%	58.6	-	-	-	-	-	-	-	-	-	-	48.5	35.9	-	-	52.7	-	-	-	-	-	-	65.0	37.9	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSONN COOPERAGE SITE
WATERFORD, NEW YORK

Table with columns for Sample Location, Sample ID, Sample Date, Sample Depth, Parameters (Semi-volatile Organic Compounds - TCLP, Metals, Metals - TCLP, PCBs), and Units. Data points are provided for 28 different sample locations across various depths and parameters.

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>Sample Location:</i>	<i>SD-91</i>	<i>SD-92</i>	<i>SD-92</i>	<i>SD-92</i>	<i>SD-92</i>	<i>SD-93</i>	<i>SD-94</i>	<i>SD-94</i>	<i>SD-103</i>	<i>SD-103</i>	<i>SD-103</i>	<i>SD-104</i>	<i>SD-104</i>	<i>SD-104</i>	<i>SD-105</i>	<i>SD-105</i>	<i>SD-105</i>	<i>SD-105</i>	<i>SD-106</i>	<i>SD-107</i>	<i>SD-107</i>	<i>SD-107</i>	<i>SD-108</i>	<i>SD-109</i>	<i>SD-109</i>	<i>SD-110</i>	<i>SD-110</i>
<i>Sample ID:</i>	<i>SD-91(3-3.5)</i>	<i>SD-92(0-0.5)</i>	<i>SD-92(2-2.5)</i>	<i>SD-92(3-3.5)</i>	<i>SD-X17</i>	<i>SD-93(0-0.5)</i>	<i>SD-94(0-0.5)</i>	<i>SD-94(2-2.5)</i>	<i>SD-103(0-0.5)</i>	<i>SD-103(2-2.5)</i>	<i>SD-103(4.5-4.7)</i>	<i>SD-104(0-0.5)</i>	<i>SD-104(2-2.5)</i>	<i>SD-104(4.5-5)</i>	<i>SD-105(0-0.5)</i>	<i>SD-105(2-2.5)</i>	<i>SD-105(3-3.5)</i>	<i>SD-X9</i>	<i>SD-106(2-2.5)</i>	<i>SD-107(0.0.5)</i>	<i>SD-107(2-2.5)</i>	<i>SD-X10</i>	<i>SD-108(2-2.5)</i>	<i>SD-109(2-2.5)</i>	<i>SD-109(4-4.5)</i>	<i>SD-110(0-0.5)</i>	<i>SD-110(2-2.5)</i>
<i>Sample Date:</i>	<i>3/21/2011</i>	<i>3/21/2011</i>	<i>3/21/2011</i>	<i>3/21/2011</i>	<i>3/21/2011</i>	<i>3/21/2011</i>	<i>3/21/2011</i>	<i>3/21/2011</i>	<i>3/15/2011</i>	<i>3/15/2011</i>	<i>3/15/2011</i>	<i>3/15/2011</i>	<i>3/15/2011</i>	<i>3/15/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>	<i>3/17/2011</i>
<i>Sample Depth:</i>	<i>3-3.5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>3-3.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>4.5-4.7 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>4.5-5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>3-3.5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>2-2.5 ft BGS</i>	<i>4-4.5 ft BGS</i>	<i>0-0.5 ft BGS</i>	<i>2-2.5 ft BGS</i>
<i>Parameters</i>	<i>Units</i>																										
<i>Pesticides</i>																											
4,4'-DDD	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4,4'-DDE	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4,4'-DDT	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Aldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
alpha-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
alpha-Chlordane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
beta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chlordane, technical	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
delta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Dieldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan I	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan II	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan sulfate	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin aldehyde	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin ketone	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>Pesticides - TCLP</i>																											
Chlordane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>Geotech</i>																											
#10 sieve (passed)	% passed	-	-	-	-	-	74.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#100 sieve (passed)	% passed	-	-	-	-	-	39.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#20 sieve (passed)	% passed	-	-	-	-	-	63.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#200 sieve (passed)	% passed	-	-	-	-	-	36.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#4 sieve (passed)	% passed	-	-	-	-	-	86.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#40 sieve (passed)	% passed	-	-	-	-	-	52.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#60 sieve (passed)	% passed	-	-	-	-	-	44.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#80 sieve (passed)	% passed	-	-	-	-	-	40.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Clay	%	-	-	-	-	-	17.7	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Coarse sand	%	-	-	-	-	-	12.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Fine sand	%	-	-	-	-	-	16.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Gravel	%	-	-	-	-	-	13.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	26.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	24.3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	21.7	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	19.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	17.7	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	11.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	7.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Liquid limit (LL)	none	-	-	-	-	-	39	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Medium sand	%	-	-	-	-	-	22.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plastic limit (PL)	none	-	-	-	-	-	24	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plasticity index	none	-	-	-	-	-	15	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sand	%	-	-	-	-	-	50.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
 SUMMARY OF SEDIMENT ANALYTICAL DATA
 FRIEDRICHSOHN COOPERAGE SITE
 WATERFORD, NEW YORK

Sample Location:	SD-91	SD-92	SD-92	SD-92	SD-92	SD-93	SD-94	SD-94	SD-103	SD-103	SD-103	SD-104	SD-104	SD-104	SD-105	SD-105	SD-105	SD-105	SD-106	SD-107	SD-107	SD-107	SD-108	SD-109	SD-109	SD-110	SD-110	
Sample ID:	SD-91(3-3.5)	SD-92(0-0.5)	SD-92(2-2.5)	SD-92(3-3.5)	SD-X17	SD-93(0-0.5)	SD-94(0-0.5)	SD-94(2-2.5)	SD-103(0-0.5)	SD-103(2-2.5)	SD-103(4.5-4.7)	SD-104(0-0.5)	SD-104(2-2.5)	SD-104(4.5-5)	SD-105(0-0.5)	SD-105(2-2.5)	SD-105(3-3.5)	SD-X9	SD-106(2-2.5)	SD-107(0.0.5)	SD-107(2-2.5)	SD-X10	SD-108(2-2.5)	SD-109(2-2.5)	SD-109(4-4.5)	SD-110(0-0.5)	SD-110(2-2.5)	
Sample Date:	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/21/2011	3/15/2011	3/15/2011	3/15/2011	3/15/2011	3/15/2011	3/15/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	
Sample Depth:	3-3.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4.5-4.7 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4.5-5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	3-3.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	
	Duplicate										Duplicate										Duplicate							
Parameters	Units																											
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	98.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	18.3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
General Chemistry																												
Ash	%	-	-	-	-	-	96.8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	-	-	-	-	25700	-	-	-	59100	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cyanide (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Organic matter	%	-	-	-	-	-	3.2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	28.9	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1

SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSON COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-111	SD-111	SD-112	SD-112	SD-112	SD-113	SD-113	SD-113	SD-114	SD-114	SD-115	SD-115	SD-115	SD-115	SD-116	SD-116	SD-117	SD-117	SD-118	SD-118	SD-118	SD-119	SD-119	SD-120	SD-120	SD-120	SD-121	
Sample ID:	SD-111(2-2.5)	SD-111(4-4.5)	SD-112(0-0.5)	SD-112(2-2.5)	SD-112(4-4.5)	SD-113(0-0.5)	SD-113(2-2.5)	SD-113(4-4.5)	SD-114(2-2.5)	SD-114(4-4.5)	SD-115(0-0.5)	SD-115(2-2.5)	SD-115(4-4.5)	SD-X11	SD-116(2-2.5)	SD-116(4-4.5)	SD-117(2-2.5)	SD-117(4-4.5)	SD-118(0-0.5)	SD-118(2-2.5)	SD-118(4-4.5)	SD-119(2-2.5)	SD-119(4-4.5)	SD-120(0-0.5)	SD-120(2-2.5)	SD-120(4-4.5)	SD-121(0-0.5)	
Sample Date:	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	
Sample Depth:	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	
	<i>Duplicate</i>																											
Parameters	Units																											
Volatile Organic Compounds																												
1,1,1-Trichloroethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
1,1,2,2-Tetrachloroethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
1,1,2-Trichloroethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
1,1-Dichloroethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
1,1-Dichloroethene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
1,2-Dichloroethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
1,2-Dichloropropane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
2-Butanone (Methyl ethyl ketone) (MEK)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	15 U
2-Hexanone	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	15 U
4-Methyl-2-pentanone (Methyl isobutyl ketone) (MIBK)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Acetone	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	51
Benzene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Bromodichloromethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Bromoform	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Bromomethane (Methyl bromide)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Carbon disulfide	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Carbon tetrachloride	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Chlorobenzene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Chloroethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Chloroform (Trichloromethane)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Chloromethane (Methyl chloride)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
cis-1,2-Dichloroethene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
cis-1,3-Dichloropropene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Dibromochloromethane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Ethylbenzene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Methylene chloride	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	4.8 JB
Styrene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Tetrachloroethene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Toluene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0.48 JB
trans-1,2-Dichloroethene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
trans-1,3-Dichloropropene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Trichloroethene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Vinyl chloride	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	7.7 U
Xylenes (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1.1 J
Volatile Organic Compounds - TCLP																												
1,1-Dichloroethene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
1,2-Dichloroethane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2-Butanone (Methyl ethyl ketone) (MEK)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Benzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon tetrachloride	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chloroform (Trichloromethane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Tetrachloroethene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Trichloroethene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Vinyl chloride	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Semi-volatile Organic Compounds																												
1,2,4-Trichlorobenzene	ug/kg	-	-	71 J	-	560 U	54 J	-	630 U	-	-	-	-	-	360 U	-	-	-	-	-	-	34 J	-	51 J	380 U	-	-	-
1,2-Dichlorobenzene	ug/kg	-	-	50 J	-	75 J	640 U	-	630 U	-	-	-	-	-	360 U	-	-	-	-	-	-	420 U	-	27 J	380 U	-	-	-
1,3-Dichlorobenzene	ug/kg	-	-	340 J	-	340 J	46 J	-	270 J	-	-	-	-	-	57 J	-	-	-	-	-	-	270 J	-	300 J	380 U	-	-	-
1,4-Dichlorobenzene	ug/kg	-	-	630	-	1100	110 J	-	940	-	-	-	-	-	130 J	-	-	-	-	-	-	580	-	650	33 J	-	-	-
2,2'-Oxybis(1-chloropropane) (bis(2-Chloroisopropyl) ether)	ug/kg	-	-	590 U	-	560 U	640 U	-	630 U	-	-	-	-	-	360 U	-	-	-	-	-	-	420 U	-	420 U	380 U	-	-	-
2,4,5-Trichlorophenol	ug/kg	-	-	3700 U	-	3500 U	4000 U	-	4000 U	-	-	-	-	-	2300 U	-	-	-	-	-	-	2600 U	-	2600 U	2400 U	-	-	-
2,4,6-Trichlorophenol	ug/kg	-	-	590 U	-	560 U	640 U	-	630 U	-	-	-	-	-	360 U	-	-	-	-	-	-	420 U	-	420 U	380 U	-	-	-
2,4-Dichlorophenol	ug/kg	-	-	590 U	-	560 U	640 U	-	630 U	-	-	-	-	-	360 U	-	-	-	-	-	-	420 U	-	24 J	380 U	-	-	-
2,4-Dimethylphenol	ug/kg	-	-	310 J	-	240 J	56 J	-	61 J	-	-	-	-	-	34 J	-	-	-	-	-	-	67 J	-	89 J	380 U	-	-	-
2,4-Dinitrophenol	ug/kg	-	-	3700 U	-	3500 U	4000 U	-	4000 U	-	-	-	-	-	2300 U	-	-	-	-	-	-	2600 U*	-	2600 U*	2400 U*	-	-	-
2,4-Dinitrotoluene	ug/kg	-	-	590 U	-	560 U	640 U	-	630 U	-	-	-	-	-	360 U	-	-	-	-	-	-	420 U	-	420 U	380 U	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSON COOPERAGE SITE
WATERFORD, NEW YORK

Sample Location:	SD-111	SD-111	SD-112	SD-112	SD-112	SD-113	SD-113	SD-113	SD-114	SD-114	SD-115	SD-115	SD-115	SD-115	SD-116	SD-116	SD-117	SD-117	SD-118	SD-118	SD-118	SD-119	SD-119	SD-120	SD-120	SD-120	SD-121	
Sample ID:	SD-111(2-2.5)	SD-111(4-4.5)	SD-112(0-0.5)	SD-112(2-2.5)	SD-112(4-4.5)	SD-113(0-0.5)	SD-113(2-2.5)	SD-113(4-4.5)	SD-114(2-2.5)	SD-114(4-4.5)	SD-115(0-0.5)	SD-115(2-2.5)	SD-115(4-4.5)	SD-X11	SD-116(2-2.5)	SD-116(4-4.5)	SD-117(2-2.5)	SD-117(4-4.5)	SD-118(0-0.5)	SD-118(2-2.5)	SD-118(4-4.5)	SD-119(2-2.5)	SD-119(4-4.5)	SD-120(0-0.5)	SD-120(2-2.5)	SD-120(4-4.5)	SD-121(0-0.5)	
Sample Date:	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	
Sample Depth:	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	
															Duplicate													
Parameters	Units																											
Semi-volatile Organic Compounds - TCLP																												
1,4-Dichlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2,4,5-Trichlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2,4,6-Trichlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2,4-Dinitrotoluene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
2-Methylphenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4-Methylphenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hexachlorobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hexachlorobutadiene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hexachloroethane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Nitrobenzene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Pentachlorophenol	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Pyridine	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Metals																												
Aluminum	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	12900
Antimony	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	6.2 U
Arsenic	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8.2
Barium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	118
Beryllium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0.75 J
Cadmium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0.57 J
Calcium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	16000
Chromium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	36.8
Cobalt	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	12.8
Copper	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	56.4
Iron	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	27500
Lead	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	225
Magnesium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	8420
Manganese	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	490
Mercury	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0.26
Nickel	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	27.3
Potassium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1460
Selenium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	14.1 U
Silver	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	0.19 J
Sodium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	317
Thallium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	5.6 U
Vanadium	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	23.1
Zinc	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	207
Metals - TCLP																												
Arsenic	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Barium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Cadmium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chromium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Lead	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Mercury	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Selenium	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silver	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
PCBs																												
Aroclor-1016 (PCB-1016)	ug/kg	180 U	160 U	740 U	790 U	350 U	400 U	360 U	400 U	200 U	24 U	240 U	63 U	23 U	31 U	23 U	22 U	130 U	25 U	43 U	26 U	21 U	26 U	24 U	74 U	170 U	70 U	170 U
Aroclor-1221 (PCB-1221)	ug/kg	180 U	160 U	740 U	790 U	350 U	400 U	360 U	400 U	200 U	24 U	240 U	63 U	23 U	31 U	23 U	22 U	130 U	25 U	43 U	26 U	21 U	26 U	24 U	74 U	170 U	70 U	170 U
Aroclor-1232 (PCB-1232)	ug/kg	180 U	160 U	740 U	790 U	350 U	400 U	360 U	400 U	200 U	24 U	240 U	63 U	23 U	31 U	23 U	22 U	130 U	25 U	43 U	26 U	21 U	26 U	24 U	74 U	170 U	70 U	170 U
Aroclor-1242 (PCB-1242)	ug/kg	580	630	3800	11000	4300	1500 p	4100	3500	1500	59 p	770 p	410 p	88	290	170	150	1100	180	200 p	200	100	360	230	510 p	2300	910	1400
Aroclor-1248 (PCB-1248)	ug/kg	180 U	160 U	740 U	790 U	350 U	400 U	360 U	400 U	200 U	24 U	240 U	63 U	23 U	31 U	23 U	22 U	130 U	25 U	43 U	26 U	21 U	26 U	24 U	74 U	170 U	70 U	170 U
Aroclor-1254 (PCB-1254)	ug/kg	560	490 p	590 J	2400	480 p	490	520 p	350 Jp	240	77	230 J	630	43	330	67	51	100 J	130	99 p	170	64	240 p	140 p	220	470	190	310
Aroclor-1260 (PCB-1260)	ug/kg	70 J	110 J	740 U	380 J	150 J	400 U	140 J	150 J	50 J	19 J	240 U	120	11 J	74	8.8 Jp	9.8 Jp	37 J	28	45	53	23	45	38	42 J	150 J	41 Jp	71 J
Total PCBs	ug/kg	1210	1230	4390	13780	4930	1990	4760	4000	1790	155	1000	1160	142	694	245.8	210.8	1237	338	344	423	187	645	408	772	2920	1141	1781

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

Sample Location:	SD-111	SD-111	SD-112	SD-112	SD-112	SD-113	SD-113	SD-113	SD-114	SD-114	SD-115	SD-115	SD-115	SD-115	SD-116	SD-116	SD-117	SD-117	SD-118	SD-118	SD-118	SD-119	SD-119	SD-120	SD-120	SD-120	SD-121
Sample ID:	SD-111(2-2.5)	SD-111(4-4.5)	SD-112(0-0.5)	SD-112(2-2.5)	SD-112(4-4.5)	SD-113(0-0.5)	SD-113(2-2.5)	SD-113(4-4.5)	SD-114(2-2.5)	SD-114(4-4.5)	SD-115(0-0.5)	SD-115(2-2.5)	SD-115(4-4.5)	SD-X11	SD-116(2-2.5)	SD-116(4-4.5)	SD-117(2-2.5)	SD-117(4-4.5)	SD-118(0-0.5)	SD-118(2-2.5)	SD-118(4-4.5)	SD-119(2-2.5)	SD-119(4-4.5)	SD-120(0-0.5)	SD-120(2-2.5)	SD-120(4-4.5)	SD-121(0-0.5)
Sample Date:	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011
Sample Depth:	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS
															<i>Duplicate</i>												
Parameters	Units																										
Pesticides																											
4,4'-DDD	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4,4'-DDE	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
4,4'-DDT	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Aldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
alpha-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
alpha-Chlordane	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
beta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Chlordane, technical	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
delta-BHC	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Dieldrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan I	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan II	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endosulfan sulfate	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin aldehyde	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin ketone	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Pesticides - TCLP																											
Chlordane	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Endrin	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Heptachlor epoxide	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Methoxychlor	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Toxaphene	ug/L	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Geotech																											
#10 sieve (passed)	% passed	-	-	-	-	-	-	-	94.3	93.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#100 sieve (passed)	% passed	-	-	-	-	-	-	-	91.7	80.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#20 sieve (passed)	% passed	-	-	-	-	-	-	-	94.2	89.7	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#200 sieve (passed)	% passed	-	-	-	-	-	-	-	85.3	74.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#4 sieve (passed)	% passed	-	-	-	-	-	-	-	98.1	97.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#40 sieve (passed)	% passed	-	-	-	-	-	-	-	93.7	86.2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#60 sieve (passed)	% passed	-	-	-	-	-	-	-	93.1	83.8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
#80 sieve (passed)	% passed	-	-	-	-	-	-	-	92.2	81.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Clay	%	-	-	-	-	-	-	-	29.6	29.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Coarse sand	%	-	-	-	-	-	-	-	3.8	4.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Fine sand	%	-	-	-	-	-	-	-	8.4	11.7	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Gravel	%	-	-	-	-	-	-	-	1.9	2.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	-	-	60.7	59.8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	-	-	54.5	51.2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	-	-	42.0	40.2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	-	-	32.7	34.6	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	-	-	29.6	29.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	-	-	20.2	18.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	-	-	10.9	12.5	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Liquid limit (LL)	none	-	-	-	-	-	-	-	85	28	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Medium sand	%	-	-	-	-	-	-	-	0.6	6.8	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plastic limit (PL)	none	-	-	-	-	-	-	-	56	21	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Plasticity index	none	-	-	-	-	-	-	-	28	7	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sand	%	-	-	-	-	-	-	-	12.8	23.1	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	-	-	100.0	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	-	-	100.0	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	-	-	100.0	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	-	-	100.0	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK

<i>Sample Location:</i>	SD-111	SD-111	SD-112	SD-112	SD-112	SD-113	SD-113	SD-113	SD-114	SD-114	SD-115	SD-115	SD-115	SD-115	SD-116	SD-116	SD-117	SD-117	SD-118	SD-118	SD-118	SD-119	SD-119	SD-120	SD-120	SD-120	SD-121	
<i>Sample ID:</i>	SD-111(2-2.5)	SD-111(4-4.5)	SD-112(0-0.5)	SD-112(2-2.5)	SD-112(4-4.5)	SD-113(0-0.5)	SD-113(2-2.5)	SD-113(4-4.5)	SD-114(2-2.5)	SD-114(4-4.5)	SD-115(0-0.5)	SD-115(2-2.5)	SD-115(4-4.5)	SD-X11	SD-116(2-2.5)	SD-116(4-4.5)	SD-117(2-2.5)	SD-117(4-4.5)	SD-118(0-0.5)	SD-118(2-2.5)	SD-118(4-4.5)	SD-119(2-2.5)	SD-119(4-4.5)	SD-120(0-0.5)	SD-120(2-2.5)	SD-120(4-4.5)	SD-121(0-0.5)	
<i>Sample Date:</i>	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/17/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	
<i>Sample Depth:</i>	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	
	<i>Duplicate</i>																											
<i>Parameters</i>	<i>Units</i>																											
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-	-	100.0	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-	-	100.0	100.0	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-	-	55.7	45.4	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
<i>General Chemistry</i>																												
Ash	%	-	-	-	-	-	-	-	-	85.2	96.3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Carbon	mg/kg	-	-	63000	-	-	-	-	-	70900	-	-	-	-	-	-	26300	-	-	-	-	-	-	-	-	-	-	-
Cyanide (total)	ug/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Ignitability	mm/sec	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Organic matter	%	-	-	-	-	-	-	-	-	14.8	3.7	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	-	-	-	160.9	35.3	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>Sample Location:</i>	SD-121	SD-121	SD-122	SD-122	SD-123	SD-123	SD-123	SD-124
<i>Sample ID:</i>	SD-121(2-2.5)	SD-121(4-4.5)	SD-122(2-2.5)	SD-122(4-4.5)	SD-123(0-0.5)	SD-123(2-2.5)	SD-123(4-4.5)	SD-124(2-2.5)
<i>Sample Date:</i>	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011
<i>Sample Depth:</i>	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS
<i>Parameters</i>	<i>Units</i>							
<i>Volatile Organic Compounds</i>								
1,1,1-Trichloroethane	ug/kg	-	-	-	-	-	-	-
1,1,2,2-Tetrachloroethane	ug/kg	-	-	-	-	-	-	-
1,1,2-Trichloroethane	ug/kg	-	-	-	-	-	-	-
1,1-Dichloroethane	ug/kg	-	-	-	-	-	-	-
1,1-Dichloroethene	ug/kg	-	-	-	-	-	-	-
1,2-Dichloroethane	ug/kg	-	-	-	-	-	-	-
1,2-Dichloropropane	ug/kg	-	-	-	-	-	-	-
2-Butanone (Methyl ethyl ketone) (MEK)	ug/kg	-	-	-	-	-	-	-
2-Hexanone	ug/kg	-	-	-	-	-	-	-
4-Methyl-2-pentanone (Methyl isobutyl ketone) (MIBK)	ug/kg	-	-	-	-	-	-	-
Acetone	ug/kg	-	-	-	-	-	-	-
Benzene	ug/kg	-	-	-	-	-	-	-
Bromodichloromethane	ug/kg	-	-	-	-	-	-	-
Bromoform	ug/kg	-	-	-	-	-	-	-
Bromomethane (Methyl bromide)	ug/kg	-	-	-	-	-	-	-
Carbon disulfide	ug/kg	-	-	-	-	-	-	-
Carbon tetrachloride	ug/kg	-	-	-	-	-	-	-
Chlorobenzene	ug/kg	-	-	-	-	-	-	-
Chloroethane	ug/kg	-	-	-	-	-	-	-
Chloroform (Trichloromethane)	ug/kg	-	-	-	-	-	-	-
Chloromethane (Methyl chloride)	ug/kg	-	-	-	-	-	-	-
cis-1,2-Dichloroethene	ug/kg	-	-	-	-	-	-	-
cis-1,3-Dichloropropene	ug/kg	-	-	-	-	-	-	-
Dibromochloromethane	ug/kg	-	-	-	-	-	-	-
Ethylbenzene	ug/kg	-	-	-	-	-	-	-
Methylene chloride	ug/kg	-	-	-	-	-	-	-
Styrene	ug/kg	-	-	-	-	-	-	-
Tetrachloroethene	ug/kg	-	-	-	-	-	-	-
Toluene	ug/kg	-	-	-	-	-	-	-
trans-1,2-Dichloroethene	ug/kg	-	-	-	-	-	-	-
trans-1,3-Dichloropropene	ug/kg	-	-	-	-	-	-	-
Trichloroethene	ug/kg	-	-	-	-	-	-	-
Vinyl chloride	ug/kg	-	-	-	-	-	-	-
Xylenes (total)	ug/kg	-	-	-	-	-	-	-
<i>Volatile Organic Compounds - TCLP</i>								
1,1-Dichloroethene	ug/L	-	-	-	-	-	-	-
1,2-Dichloroethane	ug/L	-	-	-	-	-	-	-
2-Butanone (Methyl ethyl ketone) (MEK)	ug/L	-	-	-	-	-	-	-
Benzene	ug/L	-	-	-	-	-	-	-
Carbon tetrachloride	ug/L	-	-	-	-	-	-	-
Chlorobenzene	ug/L	-	-	-	-	-	-	-
Chloroform (Trichloromethane)	ug/L	-	-	-	-	-	-	-
Tetrachloroethene	ug/L	-	-	-	-	-	-	-
Trichloroethene	ug/L	-	-	-	-	-	-	-
Vinyl chloride	ug/L	-	-	-	-	-	-	-
<i>Semi-volatile Organic Compounds</i>								
1,2,4-Trichlorobenzene	ug/kg	-	-	360 U	-	330 U	-	330 U
1,2-Dichlorobenzene	ug/kg	-	-	360 U	-	330 U	-	330 U
1,3-Dichlorobenzene	ug/kg	-	-	360 U	-	330 U	-	330 U
1,4-Dichlorobenzene	ug/kg	-	-	34 J	-	330 U	-	330 U
2,2'-Oxybis(1-chloropropane) (bis(2-Chloroisopropyl) ether)	ug/kg	-	-	360 U	-	330 U	-	330 U
2,4,5-Trichlorophenol	ug/kg	-	-	2300 U	-	2100 U	-	2100 U
2,4,6-Trichlorophenol	ug/kg	-	-	360 U	-	330 U	-	330 U
2,4-Dichlorophenol	ug/kg	-	-	360 U	-	330 U	-	330 U
2,4-Dimethylphenol	ug/kg	-	-	360 U	-	330 U	-	330 U
2,4-Dinitrophenol	ug/kg	-	-	2300 U*	-	2100 U*	-	2100 U*
2,4-Dinitrotoluene	ug/kg	-	-	360 U	-	330 U	-	330 U

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>Sample Location:</i>	SD-121	SD-121	SD-122	SD-122	SD-123	SD-123	SD-123	SD-124	
<i>Sample ID:</i>	SD-121(2-2.5)	SD-121(4-4.5)	SD-122(2-2.5)	SD-122(4-4.5)	SD-123(0-0.5)	SD-123(2-2.5)	SD-123(4-4.5)	SD-124(2-2.5)	
<i>Sample Date:</i>	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	
<i>Sample Depth:</i>	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	
<i>Parameters</i>	<i>Units</i>								
2,6-Dinitrotoluene	ug/kg	-	-	360 U	-	330 U	-	-	330 U
2-Chloronaphthalene	ug/kg	-	-	360 U	-	330 U	-	-	330 U
2-Chlorophenol	ug/kg	-	-	360 U	-	330 U	-	-	330 U
2-Methylnaphthalene	ug/kg	-	-	61 J	-	31 J	-	-	25 J
2-Methylphenol	ug/kg	-	-	360 U	-	330 U	-	-	330 U
2-Nitroaniline	ug/kg	-	-	900 U	-	810 U	-	-	830 U
2-Nitrophenol	ug/kg	-	-	360 U	-	330 U	-	-	330 U
3&4-Methylphenol	ug/kg	-	-	-	-	-	-	-	-
3,3'-Dichlorobenzidine	ug/kg	-	-	440 U	-	400 U	-	-	410 U
3-Nitroaniline	ug/kg	-	-	900 U	-	810 U	-	-	830 U
4,6-Dinitro-2-methylphenol	ug/kg	-	-	2300 U*	-	2100 U*	-	-	2100 U*
4-Bromophenyl phenyl ether	ug/kg	-	-	360 U	-	330 U	-	-	330 U
4-Chloro-3-methylphenol	ug/kg	-	-	360 U	-	330 U	-	-	330 U
4-Chloroaniline	ug/kg	-	-	360 U	-	330 U	-	-	330 U
4-Chlorophenyl phenyl ether	ug/kg	-	-	360 U	-	330 U	-	-	330 U
4-Methylphenol	ug/kg	-	-	35 J	-	24 J	-	-	330 U
4-Nitroaniline	ug/kg	-	-	360 U	-	330 U	-	-	330 U
4-Nitrophenol	ug/kg	-	-	2300 U	-	2100 U	-	-	2100 U
Acenaphthene	ug/kg	-	-	170 J	-	130 J	-	-	140 J
Acenaphthylene	ug/kg	-	-	21 J	-	330 U	-	-	330 U
Acetophenone	ug/kg	-	-	-	-	-	-	-	-
Anthracene	ug/kg	-	-	450	-	300 J	-	-	260 J
Atrazine	ug/kg	-	-	-	-	-	-	-	-
Benzaldehyde	ug/kg	-	-	-	-	-	-	-	-
Benzo(a)anthracene	ug/kg	-	-	1500	-	1200	-	-	1100
Benzo(a)pyrene	ug/kg	-	-	1300	-	1100	-	-	990
Benzo(b)fluoranthene	ug/kg	-	-	1300	-	1300	-	-	1200
Benzo(g,h,i)perylene	ug/kg	-	-	1000	-	910	-	-	870
Benzo(k)fluoranthene	ug/kg	-	-	540	-	480	-	-	450
Benzyl alcohol	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Biphenyl (1,1-Biphenyl)	ug/kg	-	-	-	-	-	-	-	-
bis(2-Chloroethoxy)methane	ug/kg	-	-	360 U	-	330 U	-	-	330 U
bis(2-Chloroethyl)ether	ug/kg	-	-	360 U	-	330 U	-	-	330 U
bis(2-Ethylhexyl)phthalate (DEHP)	ug/kg	-	-	1000 B	-	1200 B	-	-	440 B
Butyl benzylphthalate (BBP)	ug/kg	-	-	51 J	-	30 J	-	-	330 U
Caprolactam	ug/kg	-	-	-	-	-	-	-	-
Carbazole	ug/kg	-	-	190 J	-	200 J	-	-	210 J
Chrysene	ug/kg	-	-	1700	-	1500	-	-	1400
Dibenz(a,h)anthracene	ug/kg	-	-	510	-	450	-	-	420
Dibenzofuran	ug/kg	-	-	110 J	-	110 J	-	-	90 J
Diethyl phthalate	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Dimethyl phthalate	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Di-n-butylphthalate (DBP)	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Di-n-octyl phthalate (DnOP)	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Fluoranthene	ug/kg	-	-	2400	-	2000	-	-	1700
Fluorene	ug/kg	-	-	230 J	-	150 J	-	-	160 J
Hexachlorobenzene	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Hexachlorobutadiene	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Hexachlorocyclopentadiene	ug/kg	-	-	900 U*	-	810 U*	-	-	830 U*
Hexachloroethane	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Indeno(1,2,3-cd)pyrene	ug/kg	-	-	1100	-	990	-	-	940
Isophorone	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Naphthalene	ug/kg	-	-	63 J	-	31 J	-	-	24 J
Nitrobenzene	ug/kg	-	-	360 U	-	330 U	-	-	330 U
N-Nitrosodi-n-propylamine	ug/kg	-	-	360 U	-	330 U	-	-	330 U
N-Nitrosodiphenylamine	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Pentachlorophenol	ug/kg	-	-	900 U	-	810 U	-	-	830 U
Phenanthrene	ug/kg	-	-	2200	-	1700	-	-	1800
Phenol	ug/kg	-	-	360 U	-	330 U	-	-	330 U
Pyrene	ug/kg	-	-	7000	-	5000	-	-	4100

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>Sample Location:</i>	SD-121	SD-121	SD-122	SD-122	SD-123	SD-123	SD-123	SD-124	
<i>Sample ID:</i>	SD-121(2-2.5)	SD-121(4-4.5)	SD-122(2-2.5)	SD-122(4-4.5)	SD-123(0-0.5)	SD-123(2-2.5)	SD-123(4-4.5)	SD-124(2-2.5)	
<i>Sample Date:</i>	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	
<i>Sample Depth:</i>	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	
Parameters									
Semi-volatile Organic Compounds - TCLP									
1,4-Dichlorobenzene	ug/L	-	-	-	-	-	-	-	
2,4,5-Trichlorophenol	ug/L	-	-	-	-	-	-	-	
2,4,6-Trichlorophenol	ug/L	-	-	-	-	-	-	-	
2,4-Dinitrotoluene	ug/L	-	-	-	-	-	-	-	
2-Methylphenol	ug/L	-	-	-	-	-	-	-	
4-Methylphenol	ug/L	-	-	-	-	-	-	-	
Hexachlorobenzene	ug/L	-	-	-	-	-	-	-	
Hexachlorobutadiene	ug/L	-	-	-	-	-	-	-	
Hexachloroethane	ug/L	-	-	-	-	-	-	-	
Nitrobenzene	ug/L	-	-	-	-	-	-	-	
Pentachlorophenol	ug/L	-	-	-	-	-	-	-	
Pyridine	ug/L	-	-	-	-	-	-	-	
Metals									
Aluminum	mg/kg	-	-	-	-	-	-	-	
Antimony	mg/kg	-	-	-	-	-	-	-	
Arsenic	mg/kg	-	-	-	-	-	-	-	
Barium	mg/kg	-	-	-	-	-	-	-	
Beryllium	mg/kg	-	-	-	-	-	-	-	
Cadmium	mg/kg	-	-	-	-	-	-	-	
Calcium	mg/kg	-	-	-	-	-	-	-	
Chromium	mg/kg	-	-	-	-	-	-	-	
Cobalt	mg/kg	-	-	-	-	-	-	-	
Copper	mg/kg	-	-	-	-	-	-	-	
Iron	mg/kg	-	-	-	-	-	-	-	
Lead	mg/kg	-	-	-	-	-	-	-	
Magnesium	mg/kg	-	-	-	-	-	-	-	
Manganese	mg/kg	-	-	-	-	-	-	-	
Mercury	mg/kg	-	-	-	-	-	-	-	
Nickel	mg/kg	-	-	-	-	-	-	-	
Potassium	mg/kg	-	-	-	-	-	-	-	
Selenium	mg/kg	-	-	-	-	-	-	-	
Silver	mg/kg	-	-	-	-	-	-	-	
Sodium	mg/kg	-	-	-	-	-	-	-	
Thallium	mg/kg	-	-	-	-	-	-	-	
Vanadium	mg/kg	-	-	-	-	-	-	-	
Zinc	mg/kg	-	-	-	-	-	-	-	
Metals - TCLP									
Arsenic	ug/L	-	-	-	-	-	-	-	
Barium	ug/L	-	-	-	-	-	-	-	
Cadmium	ug/L	-	-	-	-	-	-	-	
Chromium	ug/L	-	-	-	-	-	-	-	
Lead	ug/L	-	-	-	-	-	-	-	
Mercury	ug/L	-	-	-	-	-	-	-	
Selenium	ug/L	-	-	-	-	-	-	-	
Silver	ug/L	-	-	-	-	-	-	-	
PCBs									
Aroclor-1016 (PCB-1016)	ug/kg	910 U	26 U	110 U	110 U	21 U	22 U	21 U	21 U
Aroclor-1221 (PCB-1221)	ug/kg	910 U	26 U	110 U	110 U	21 U	22 U	21 U	21 U
Aroclor-1232 (PCB-1232)	ug/kg	910 U	26 U	110 U	110 U	21 U	22 U	21 U	21 U
Aroclor-1242 (PCB-1242)	ug/kg	12000	100	500 p	740	71	92	120	34
Aroclor-1248 (PCB-1248)	ug/kg	910 U	26 U	110 U	110 U	21 U	22 U	21 U	21 U
Aroclor-1254 (PCB-1254)	ug/kg	1200	31	560	350	23	24	30	19 J
Aroclor-1260 (PCB-1260)	ug/kg	910 U	26 U	83 J	60 J	11 J	13 J	7.5 Jp	8.6 J
Total PCBs	ug/kg	13200	131	1143	1150	105	129	157.5	61.6

TABLE A.1

**SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>Sample Location:</i>	SD-121	SD-121	SD-122	SD-122	SD-123	SD-123	SD-123	SD-124
<i>Sample ID:</i>	SD-121(2-2.5)	SD-121(4-4.5)	SD-122(2-2.5)	SD-122(4-4.5)	SD-123(0-0.5)	SD-123(2-2.5)	SD-123(4-4.5)	SD-124(2-2.5)
<i>Sample Date:</i>	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011
<i>Sample Depth:</i>	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS
Parameters	Units							
Pesticides								
4,4'-DDD	ug/kg	-	-	-	-	-	-	-
4,4'-DDE	ug/kg	-	-	-	-	-	-	-
4,4'-DDT	ug/kg	-	-	-	-	-	-	-
Aldrin	ug/kg	-	-	-	-	-	-	-
alpha-BHC	ug/kg	-	-	-	-	-	-	-
alpha-Chlordane	ug/kg	-	-	-	-	-	-	-
beta-BHC	ug/kg	-	-	-	-	-	-	-
Chlordane, technical	ug/kg	-	-	-	-	-	-	-
delta-BHC	ug/kg	-	-	-	-	-	-	-
Dieldrin	ug/kg	-	-	-	-	-	-	-
Endosulfan I	ug/kg	-	-	-	-	-	-	-
Endosulfan II	ug/kg	-	-	-	-	-	-	-
Endosulfan sulfate	ug/kg	-	-	-	-	-	-	-
Endrin	ug/kg	-	-	-	-	-	-	-
Endrin aldehyde	ug/kg	-	-	-	-	-	-	-
Endrin ketone	ug/kg	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/kg	-	-	-	-	-	-	-
Heptachlor	ug/kg	-	-	-	-	-	-	-
Heptachlor epoxide	ug/kg	-	-	-	-	-	-	-
Methoxychlor	ug/kg	-	-	-	-	-	-	-
Toxaphene	ug/kg	-	-	-	-	-	-	-
Pesticides - TCLP								
Chlordane	ug/L	-	-	-	-	-	-	-
Endrin	ug/L	-	-	-	-	-	-	-
gamma-BHC (lindane)	ug/L	-	-	-	-	-	-	-
Heptachlor	ug/L	-	-	-	-	-	-	-
Heptachlor epoxide	ug/L	-	-	-	-	-	-	-
Methoxychlor	ug/L	-	-	-	-	-	-	-
Toxaphene	ug/L	-	-	-	-	-	-	-
Geotech								
#10 sieve (passed)	% passed	-	-	-	-	-	-	-
#100 sieve (passed)	% passed	-	-	-	-	-	-	-
#20 sieve (passed)	% passed	-	-	-	-	-	-	-
#200 sieve (passed)	% passed	-	-	-	-	-	-	-
#4 sieve (passed)	% passed	-	-	-	-	-	-	-
#40 sieve (passed)	% passed	-	-	-	-	-	-	-
#60 sieve (passed)	% passed	-	-	-	-	-	-	-
#80 sieve (passed)	% passed	-	-	-	-	-	-	-
Clay	%	-	-	-	-	-	-	-
Coarse sand	%	-	-	-	-	-	-	-
Fine sand	%	-	-	-	-	-	-	-
Gravel	%	-	-	-	-	-	-	-
Hydrometer 1 for particle size distribution	% passed	-	-	-	-	-	-	-
Hydrometer 2 for particle size distribution	% passed	-	-	-	-	-	-	-
Hydrometer 3 for particle size distribution	% passed	-	-	-	-	-	-	-
Hydrometer 4 for particle size distribution	% passed	-	-	-	-	-	-	-
Hydrometer 5 for particle size distribution	% passed	-	-	-	-	-	-	-
Hydrometer 6 for particle size distribution	% passed	-	-	-	-	-	-	-
Hydrometer 7 for particle size distribution	% passed	-	-	-	-	-	-	-
Liquid limit (LL)	none	-	-	-	-	-	-	-
Medium sand	%	-	-	-	-	-	-	-
Plastic limit (PL)	none	-	-	-	-	-	-	-
Plasticity index	none	-	-	-	-	-	-	-
Sand	%	-	-	-	-	-	-	-
Sieve, 19000 microns, percent passing	% passed	-	-	-	-	-	-	-
Sieve, 25000 microns, percent passing	% passed	-	-	-	-	-	-	-
Sieve, 37500 microns, percent passing	% passed	-	-	-	-	-	-	-
Sieve, 50000 microns, percent passing	% passed	-	-	-	-	-	-	-

TABLE A.1
SUMMARY OF SEDIMENT ANALYTICAL DATA
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK


<i>Sample Location:</i>	SD-121	SD-121	SD-122	SD-122	SD-123	SD-123	SD-123	SD-124
<i>Sample ID:</i>	SD-121(2-2.5)	SD-121(4-4.5)	SD-122(2-2.5)	SD-122(4-4.5)	SD-123(0-0.5)	SD-123(2-2.5)	SD-123(4-4.5)	SD-124(2-2.5)
<i>Sample Date:</i>	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011	3/18/2011
<i>Sample Depth:</i>	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	0-0.5 ft BGS	2-2.5 ft BGS	4-4.5 ft BGS	2-2.5 ft BGS
<i>Parameters</i>		<i>Units</i>						
Sieve, 75000 microns, percent passing	% passed	-	-	-	-	-	-	-
Sieve, 9500 microns, percent passing	% passed	-	-	-	-	-	-	-
Silt	%	-	-	-	-	-	-	-
<i>General Chemistry</i>								
Ash	%	-	-	-	-	-	-	-
Carbon	mg/kg	-	35100	36600	-	-	-	-
Cyanide (total)	ug/kg	-	-	-	-	-	-	-
Ignitability	mm/sec	-	-	-	-	-	-	-
Organic matter	%	-	-	-	-	-	-	-
Percent moisture	%	-	-	-	-	-	-	-
pH	s.u.	-	-	-	-	-	-	-
Reactive cyanide	mg/kg	-	-	-	-	-	-	-
Reactive sulfide	mg/kg	-	-	-	-	-	-	-

APPENDIX B

HEALTH AND SAFETY PLAN



www.CRAworld.com



SITE-SPECIFIC HEALTH AND SAFETY PLAN

FRIEDRICHSOHN COOPERAGE SITE

Prepared for: General Electric Company and SI Group,
INC.

Conestoga-Rovers & Associates
2055 Niagara Falls Boulevard, Suite #3
Niagara Falls, New York 14304

July 2013 • #080897
Report Number:2

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	1
1.1 PROJECT ORGANIZATION	3
2.0 SITE CHARACTERIZATION AND POTENTIALLY HAZARDOUS COMPOUNDS	9
3.0 BASIS FOR DESIGN	10
4.0 PERSONNEL TRAINING.....	11
4.1 GENERAL	11
4.2 BASIC 40-HOUR COURSE	11
4.3 SUPERVISOR COURSE.....	12
4.4 SITE-SPECIFIC TRAINING	12
4.5 DAILY SAFETY MEETINGS	13
4.6 FIRST AID AND CPR.....	13
5.0 PERSONAL PROTECTIVE EQUIPMENT	14
5.1 LEVELS OF PROTECTION.....	14
5.1.1 LEVEL D PROTECTION	14
5.1.2 MODIFIED LEVEL D PROTECTION.....	15
5.1.3 LEVEL C PROTECTION	15
5.1.4 LEVEL B PROTECTION.....	16
5.1.5 SELECTION OF PPE.....	17
5.2 RESPIRATORY PROTECTION	17
5.2.1 SITE RESPIRATORY PROTECTION PROGRAM.....	18
5.3 USING PPE.....	19
5.3.1 DONNING PROCEDURES	20
5.3.2 DOFFING PROCEDURES.....	20
5.4 SELECTION MATRIX	21
5.5 DURATION OF WORK TASKS	21
5.6 LIMITATIONS OF PROTECTIVE CLOTHING.....	21
6.0 SITE CONTROL	24
6.1 AUTHORIZATION TO ENTER.....	24
6.2 SITE ORIENTATION AND HAZARD BRIEFING.....	24
6.3 CERTIFICATION DOCUMENTS	24
6.4 ENTRY LOG.....	25
6.5 ENTRY REQUIREMENTS.....	25
6.6 EMERGENCY ENTRY AND EXIT	25
6.7 CONTAMINATION CONTROL ZONES.....	25
6.7.1 EXCLUSION ZONE (EZ)	26
6.7.2 CONTAMINATION REDUCTION ZONE (CRZ).....	26
6.7.3 SUPPORT ZONE (SZ).....	26

TABLE OF CONTENTS

	<u>Page</u>
7.0	ACTIVITY HAZARD/RISK ANALYSIS AND
	GENERAL SAFETY PRACTICES.....27
7.1	GENERAL PRACTICES27
7.1.1	BUDDY SYSTEM.....28
7.1.2	SANITATION.....29
7.1.3	BREAK AREA.....29
7.1.4	POTABLE WATER.....29
7.1.5	WASHING FACILITIES.....30
7.1.6	LAVATORY30
7.1.7	TRASH COLLECTION.....30
7.2	CHEMICAL EXPOSURE.....30
7.3	HEAT STRESS.....33
7.4	SUN EXPOSURE36
7.5	COLD STRESS.....37
7.6	EARTHWORK - EXCAVATION AND TRENCHING40
7.7	HEAVY EQUIPMENT AND DRILLING SAFETY.....43
7.7.1	DRILLING SAFETY PROCEDURES44
7.8	FALL HAZARDS.....48
7.9	NOISE.....49
7.10	ELECTRICAL HAZARDS.....50
7.11	MATERIAL HANDLING.....51
7.11.1	MANUAL LIFTING.....54
7.12	HAND AND POWER TOOLS.....54
7.13	ADVERSE WEATHER CONDITIONS.....55
7.14	BIOLOGICAL HAZARDS.....55
7.14.1	VEGETATION OVERGROWTH.....56
7.14.2	TICK-BORNE DISEASES56
7.14.3	POISONOUS PLANTS57
7.14.4	INSECTS58
7.14.5	POISONOUS SPIDERS.....60
7.14.6	THREATENING DOGS.....60
7.14.7	RODENTS.....61
8.0	AIR MONITORING PROGRAM.....63
8.1	SITE AIR MONITORING.....64
8.1.1	REAL-TIME VOC MONITORING.....65
8.1.2	PARTICULATE MONITORING65
8.1.3	PERSONAL AIR SAMPLING PROGRAM.....66
9.0	DECONTAMINATION PROCEDURES67
9.1	EQUIPMENT DECONTAMINATION PROCEDURES.....67
9.2	PERSONNEL DECONTAMINATION PROCEDURES.....67

TABLE OF CONTENTS

	<u>Page</u>
10.0 MEDICAL SURVEILLANCE	69
11.0 EMERGENCY RESPONSE AND CONTINGENCY PROCEDURES	70
11.1 ACCIDENT, INJURY AND ILLNESS REPORTING	70
11.2 EMERGENCY CONTACTS	71
11.3 ADDITIONAL EMERGENCY NUMBERS	72
11.4 EMERGENCY AND FIRST AID EQUIPMENT	72
11.5 PROJECT PERSONNEL RESPONSIBILITIES DURING EMERGENCIES.....	73
11.6 MEDICAL EMERGENCIES	74
11.7 FIRE OR EXPLOSION	74
11.8 SPILL CONTROL AND COUNTERMEASURES	74
12.0 RECORDKEEPING.....	76

LIST OF FIGURES
(Following Text)

FIGURE 11.1 HOSPITAL ROUTE MAP

LIST OF TABLES
(Following Text)

TABLE 2.1 SITE CONTAMINANTS OF CONCERN AND THEIR PROPERTIES

TABLE 8.1 ON-SITE AIR MONITORING PROGRAM ACTION LEVELS

LIST OF APPENDICES
(Following Text)

APPENDIX A JOB SAFETY ANALYSIS (JSA) FORMS

APPENDIX B PROJECT SAFETY FORMS

APPENDIX C COMMUNITY AIR MONITORING PLAN

1.0 INTRODUCTION

This Health and Safety Plan (HASP) describes the health and safety procedures and emergency response guidelines that will be implemented during the field activities supporting the Remedial Design (RD) for the Friedrichsohn Cooperage Site (Site) located in Waterford, New York. The layout of the Site is presented on Figure 2.1 of the Remedial Design/Remedial Action (RD/RA) Workplan. An Emergency Response Plan and Community Air Monitoring Plan are included as part of this HASP. This HASP shall be implemented and adhered to during all field activities that are presented in the Remedial Design (RD) Report.

The scope of work to be completed by the selected contractors during the RD field activities includes the following:

- i) Mobilization and demobilization of labor, materials, and equipment to and from the Site, which include Site preparation/setup and Site restoration activities.
- ii) Site reconnaissance activities
- iii) Surveying activities.
- iv) Collection of sediment samples.
- v) Equipment and personnel decontamination activities.

During a portion of these activities, personnel may come in contact with waste materials, debris, sediment, which may contain hazardous substances. This HASP has been developed to minimize direct contact by project personnel with materials potentially having chemical presence by ensuring:

- i) That project personnel are not adversely exposed to the contaminants of concern.
- ii) That public health and the environment are not adversely impacted by materials with elevated chemical presence that may potentially migrate outside of the work zone during project activities at the Site.
- iii) Compliance with applicable governmental and non-governmental (American Conference of Governmental Industrial Hygienists [ACGIH]) regulations and guidelines. In particular, the amended rules of the Occupational Safety and Health Administration (OSHA) for Part 1926, of Title 29 Code of Federal Regulations (CFR). Part 1926.65 will be implemented for all Site work where project personnel may come into contact with the health and safety hazards that are present at the Site.

- iv) Initiation of proper emergency response procedures to minimize the potential for any adverse impact to project personnel, the general public, or the environment.

A vital element of the selected contractor's Health and Safety Program will be the implementation of a Site-specific HASP for all field activities.

This project HASP requires the following measures:

- i) The communication of the contents of this HASP to project personnel.
- ii) The elimination of unsafe conditions. Efforts shall be initiated to identify conditions that can contribute to an accident and to remove exposure to these conditions.
- iii) The review of all activities prior to undertaking the task/job, after an incident, and/or as a result of any unusual circumstances. Stop activities to think about the task, analyze the task hazards, determine methods to reduce risk, and review the results with affected personnel.
- iv) The review of existing or the development of new Job Safety Analysis (JSA) forms for each project activity. Supervisors and affected personnel are responsible for the development and ongoing revisions of JSAs. The JSAs for all known work activities are presented in Appendix A.
- v) The reduction of unsafe acts. Project personnel shall make a conscious effort to work safely. A high degree of safety awareness must be maintained so those safety factors involved in a task become an integral part of the task. Supervisory personnel shall ensure that project personnel committing unsafe acts are held accountable via counseling, mentoring, and, if necessary, reprimand.
- vi) The frequent inspection of project activities. Regular safety inspections of the work site, materials, and equipment by qualified persons ensure early detection of unsafe conditions. Safety and health deficiencies shall be corrected as soon as possible, and project activities shall be temporarily suspended until the appropriate corrective actions are taken. Documentation of the daily inspections and corrective actions taken should be kept with the project files.

For the purpose of this HASP, activities performed at the Site involving contact with materials, which potentially have an elevated chemical presence will be considered contaminated operations requiring the use of Personal Protective Equipment (PPE). A detailed description of the required PPE is presented in Section 5.1 and is also identified on each JSA form.

The applicability of this HASP extends to all project personnel who will be on Site, including State and Federal Agency personnel, contractor personnel, subcontractor personnel, and visitors to the Site.

All project activities at the Site will be conducted in accordance with the provisions of an approved Site-specific HASP. A copy of the Site-specific HASP and employer-specific Standard Operating Procedures (SOPs) will be maintained on Site whenever activities are in progress. This HASP shall be used in conjunction with the selected contractor's Safety and Health Program.

1.1 PROJECT ORGANIZATION

All personnel conducting activities on the Site must conduct their activities in compliance with all applicable Safety and Health standards as specified by OSHA including, but not limited to, the OSHA 29 CFR 1910, 29 CFR 1926. Project personnel must also be familiar with the procedures and requirements in their approved Site-specific HASP and the applicable procedures found within their company's SOPs and Safety and Health Policy Manual. In the event of any conflicting safety procedures/requirements, personnel shall implement those safety practices, which afford the highest level of safety and protection.

Project Management and Safety Organization

Project Manager Contractor - (to be determined)

The Contractor's Project Manager (CPM) shall be responsible for the overall implementation of the HASP, and for ensuring that all health and safety responsibilities are carried out in conjunction with this project. This shall include, but is not limited to, review and approval of the HASP; qualifying/directing subcontractors relative to safety and health performance; coordinating all safety and health submittals; providing the appropriate technical information to write submittals; and consultation with the Frontier Chemical Site Potentially Responsible Parties Group (Frontier Group) regarding appropriate changes to the HASP.

Site Safety & Health Officer Contractor - (to be determined)

The Contractor's Safety & Health Officer (CSHO) is the person who, under the supervision of the CPM and the contractor's Corporate Safety and Health Manager, shall be responsible for the communication of the Site requirements to project personnel and any subcontractor personnel. Additional qualified safety officers will be assigned to

work during shifts when the CSHO is not on Site. These safety officers will be under the watchful eye of the CSHO and will contact the CSHO after hours if necessary. The CSHO will have prior experience in working at hazardous waste sites and will be responsible for carrying out the health and safety responsibilities by making sure that:

- i) He/she is on Site at all times during active excavation activities and when other active remediation work is ongoing.
- ii) All necessary clean-up and maintenance of safety equipment is conducted by project personnel.
- iii) Emergency services are contacted when necessary.
- iv) A Site-specific Hazard Communication (HAZCOM) Program is maintained on Site.
- v) Project safety forms attached to the HASP are correctly completed and filed.
- vi) A pre-entry briefing is conducted, which will serve to familiarize project personnel with the procedures, requirements, and provisions of this HASP.
- vii) All necessary records are maintained in the project files (e.g., air monitoring results, calibration log sheets, incident reports, daily toolbox meeting sheets, daily safety logbook entries, training certificates and/or certifications, etc.). The selected contractor may use either their employer-specific safety forms or the forms that are provided in Appendix B.
- viii) Daily safety meetings are held and documented.
- ix) Safe work practices for project personnel are enforced.
- x) Safety of any visitors who enter the Site is ensured.
- xi) Communication is maintained with the CPM.
- xii) Orders the immediate shutdown of Site activities in the case of a medical emergency, unsafe condition, or unsafe practice.
- xiii) Designates work areas and defines minimum PPE requirements.
- xiv) Provides the safety equipment, PPE, and other items necessary for project personnel.
- xv) Conducts the required air monitoring program.
- xvi) Enforces the use of required safety equipment, PPE, and other items necessary for project personnel safety.
- xvii) Oversees any potential confined space entry work including preplanning rescue activities with the local community responders.
- xviii) Ensures that there is a competent person in place who will be supervising trenching and excavation work.

- xix) Conducts job site inspections with the Construction Superintendent (CS) or Site Supervisor (SS) as a part of quality assurance for safety and health.
- xx) Reports safety and health concerns to the selected contractor's management as necessary.

Emergency Coordinator

The CSHO or his/her designate will act as the Emergency Coordinator (EC). The EC shall be able to implement the emergency procedures and is responsible for implementing the following activities in the event of an emergency:

- i) The EC shall immediately respond to all imminent or actual emergency situations. The EC shall notify all project personnel and emergency response agencies, identify the problem, assess the health or environmental hazards, and take all reasonable measures to stabilize the situation.
- ii) The EC shall take all reasonable measures necessary to ensure that fire, explosion, emission or discharge does not occur, re-occur, or spread. These measures may include stopping operations, collecting and containing released materials, and/or removing or isolating containers.
- iii) The EC shall develop Emergency Evacuation Routes on a daily basis and communicate them to all project personnel.
- iv) The EC shall also be responsible for follow-up activities after any incident such as the cleanup of the affected area, maintenance and decontamination of emergency equipment, and completion and submission of an incident report.

Construction Superintendent/Site Supervisor - Contractor (to be determined)

Health and safety is a line management responsibility, and as such, the CS and/or SS will implement the overall onsite direction and enforcement of the health and safety for this project. The CS and/or SS must meet the requirements of the "competent person" as per the OSHA regulations. The CS and/or SS will report to the CPM for this project.

The CS and/or SS is the person who, under the supervision of the CPM, shall be responsible for the communication of the Site requirements to project personnel and subcontractors, and is responsible for carrying out the health and safety responsibilities by making sure that:

- i) All underground utilities have been properly located prior to initiating work activities.
- ii) Each work area is secured with fencing at the end of each day.

- iii) All necessary cleanup and maintenance of safety equipment is conducted by project personnel.
- iv) JSA forms are developed, reviewed, and revised accordingly.
- v) Project personnel stop, think about, act accordingly and review the work activities that they are about to start before initiating activities.
- vi) Project safety forms attached to the HASP are completed properly and then filed.
- vii) A pre-entry briefing is conducted for all project personnel, which will serve to familiarize everyone with the procedures, requirements, and provisions of this HASP.
- viii) Orders the immediate shutdown of project activities in the case of a medical emergency, unsafe condition, or unsafe practice.
- ix) Provides the safety equipment, PPE, and other items necessary for project personnel.
- x) Enforces the use of required safety equipment, PPE, and other items necessary for personnel or community safety.
- xi) Conducts job site inspections as a part of quality assurance for safety and health.
- xii) Reports safety and health concerns to the CPM as necessary.
- xiii) Is responsible for the overall implementation of the HASP, and ensuring that all health and safety responsibilities are carried out during the project work activities. This shall include, but is not limited to, review and approval of any subcontractor HASPs, communication of site requirements to Subcontractor personnel, and consultation with the CPM regarding appropriate changes to the HASP.
- xiv) THE CS and/or SS also have the responsibility for enforcing safe work practices for all project personnel.
- xv) The CS and/or SS watch all personnel for any ill effects, especially those symptoms caused by heat stress and/or chemical exposure.
- xvi) The CS and/or SS oversee the safety of any visitors who enter the Site.

Corporate Safety & Health Manager Contractor – (to be determined)

The Corporate Safety & Health Manager (CSHM) is an individual who is trained as a health and safety professional, works full-time for the selected contractor in a health and safety role, and who serves in a consulting role to the CPM, CSHO, and CS and/or SS regarding potential health and safety issues.

Equipment Operators

All equipment operators are responsible for the safe operation of heavy equipment. Operators are responsible for inspecting their equipment on a daily basis to ensure safe performance. Brakes, hydraulic lines, backup alarms, and fire extinguishers must be inspected routinely throughout the project. Documentation of daily inspections will be required via an equipment inspection checklist. Heavy equipment inspections will be submitted to the CS or SS for review and subsequently placed in the project files. Unsafe conditions/acts are to be immediately reported to the CS or SS. Equipment will be taken out of service if an unsafe condition occurs.

Project Personnel Safety Responsibilities

Project personnel are responsible for their own safety as well as the safety of those around them and shall use any equipment provided in a safe and responsible manner, as directed by their supervisor. Project personnel will follow the policies set forth in this HASP and those in their employer-specific SOPs and Safety and Health Program.

Project personnel are directed to take the following actions when appropriate:

- i) Review all activity hazards and preventative measures before initiating work
- ii) Assist in the development/revision of JSA forms that are appropriate to their current work activities
- iii) Suspend any operations that may cause an imminent health hazard to project personnel
- iv) Inspect tools and other equipment before each use or as the manufacturer and/or OSHA mandates
- v) Correct job site hazards when possible without endangering life or health
- vi) Report safety and health concerns to the CSHO, CS, and/or SS

Subcontractors

Selected subcontractor(s) will be responsible for providing a CS and/or SS ("competent person") and a SHO to direct their activities and to meet all applicable OSHA Regulations. This may be the same individual if so qualified. These individuals will be responsible for ensuring that all contract specifications are met, including those related to project health and safety. The names of these individuals will be presented in the subcontractor Site-specific HASP.

The selected contractor will review any subcontractor HASP prior to the subcontractor's mobilization to the Site. Subcontractors will be responsible for the health and safety of their personnel, which includes following all applicable OSHA Regulations and the subcontractors' Site-specific HASP. Subcontractors will be required to attend an initial Site briefing put on by the selected contractor and subsequent daily safety meetings.

Authorized Visitors

Authorized Visitors shall be provided with all known information with respect to the project operations and hazards, as applicable to the purpose of their visit.

2.0 SITE CHARACTERIZATION AND POTENTIALLY HAZARDOUS COMPOUNDS

Table 2.1 presents the available information pertaining to the Site Contaminants of Concern (COCs) and their properties including the identification of the maximum detected concentrations of the COCs in Site soils and groundwater. The exposure routes and regulatory Time Weighted Averages (TWA) exposure levels for the COCs are also listed in Table 2.1. These levels are set to protect the health of workers.

3.0 BASIS FOR DESIGN

Regulations set forth by OSHA in Title 29, CFR, Parts 1910 and 1926 (29 CFR 1910 and 1926) form the basis of this HASP. Emphasis is placed on Section 1926.65 (Hazardous Waste Operations and Emergency Response), 1910 Subpart I (Personal Protective Equipment), 1910 Subpart Z (Toxic and Hazardous Substances), 1926 Subpart O (Motor Vehicles, and Mechanized Equipment), and 1926 Subpart F (Excavations). Some of the specifications within this section are in addition to the OSHA regulations, and reflect the positions of U.S. EPA, and the National Institute for Occupational Safety and Health (NIOSH), regarding safe operating procedures at hazardous waste sites.

The health and safety of the public and Site personnel and the protection of the environment will take precedence over cost and scheduling considerations for all project work.

4.0 PERSONNEL TRAINING

4.1 GENERAL

Required project personnel as discussed in Section 1.1 shall complete hazardous waste operations and emergency response related training, as required by the OSHA Standard 29 CFR 1926.65. Project personnel shall also initially receive a minimum of 3 days of actual field experience under the direct supervision of a trained, experienced supervisor. Personnel who completed their training more than 12 months prior to the start of this project shall have also completed an 8-hour refresher course within the past 12 months. The CS and or SS shall complete the additional 8 hours of training that is required for supervisors along with any "competent persons" training that may be needed for the required work.

Additional safety training for specific tasks/activities may include safety training for fall protection, ladder safety, confined space entry work, excavation safety, and the control of hazardous energy etc. Further safety training may also be required based on the scheduled scope of work. This safety training is to be conducted and documented before any tasks that require additional training are initiated. It is the responsibility of the CSHO and CS and/or SS to ensure that personnel have the necessary training and skills prior to activity assignment. Task safety training requirements are included on each JSA form.

4.2 BASIC 40-HOUR COURSE

The following is a list of the topics typically covered in a 40-hour training course:

- i) General safety procedures
- ii) Physical hazards (fall protection, noise, heat stress, cold stress)
- iii) Names and job descriptions of key personnel responsible for Site health and safety
- iv) Safety, health, and other hazards typically present at hazardous waste sites
- v) Use, application, and limitations of PPE
- vi) Work practices by which employees can minimize risks from hazards
- vii) Safe use of engineering controls and equipment on Site
- viii) Medical surveillance requirements

- ix) Recognition of symptoms and signs, which might indicate overexposure to hazards
- x) Worker right-to-know (Hazard Communication OSHA 1926.59/1910.1200)
- xi) Routes of exposure to contaminants
- xii) Engineering controls and safe work practices that may be implemented
- xiii) Components of a project HASP
- xiv) Decontamination practices for personnel and equipment
- xv) Confined space entry procedures
- xvi) General emergency response procedures

4.3 SUPERVISOR COURSE

Management and supervisors (i.e., the CS and SS) are required to receive an additional 8 hours of training in topics that are pertinent to the management of hazardous waste operations, which typically includes:

- i) Instruction in detailed project safety and health procedures dealing with emergencies
- ii) PPE programs
- iii) Implementation of specialized emergency response procedures
- iv) Air monitoring techniques

4.4 SITE-SPECIFIC TRAINING

All project personnel attending the initial safety meeting will accomplish the project-specific training on the contents of this HASP before work begins. The review will include a discussion of the chemical, physical, and biological hazards that may be present at the Site, the protective equipment and safety procedures to be used and followed, and emergency procedures that will be implemented at the Site. The Training Acknowledgment Form that project personnel will sign off on is provided in Appendix B (Project Safety Forms).

4.5 DAILY SAFETY MEETINGS

Daily safety meetings (tailgate safety talks) will be held to cover the work that is anticipated to be accomplished each day, the associated hazards, the PPE, procedures required to minimize exposure to these hazards, and the required emergency response procedures. The CS, SS, and/or CSHO will preside over these meetings prior to beginning the day's fieldwork. No work will be performed in an Exclusion Zone (EZ) before the daily safety meeting has been held. Additional safety meetings shall also be held prior to initiating new tasks, and repeated if new hazards are encountered. The form for documenting the daily safety meetings is also found in Appendix B.

4.6 FIRST AID AND CPR

At least one individual with current certification in First Aid/CPR will be assigned to the work crew and will be on the Site during all field activities. Refresher training in First Aid and CPR is required to keep the certificate current. These individuals must also receive training regarding the precautions and protective equipment necessary to protect against exposure to blood-borne pathogens. Blood-borne pathogen training should be included as part of the First Aid/CPR training course delivered by the training provider.

5.0 PERSONAL PROTECTIVE EQUIPMENT

PPE will be required to safeguard project personnel from various hazards. Varying levels of protection may be used depending on the level of contaminants and the degree of any physical hazard. This section presents the various levels of personal protection and defines the conditions of use for each level. Subcontractor Site-specific HASPs, if required, will adequately address PPE concerns for each specific task activity based on their proposed scope of work.

5.1 LEVELS OF PROTECTION

Protection levels are determined based upon chemicals and physical hazards present in the work area. The specific protection levels to be employed at the Site for each work task are presented on each JSA form, which are presented in Appendix A.

5.1.1 LEVEL D PROTECTION

The minimum level of protection that will be required for all project personnel will be Level D. Level D will only be used in clean areas where there is no potential for exposure to the COCs. The following equipment is to be worn as Level D PPE:

- i) Work clothing as prescribed by the weather.
- ii) Steel toed work boots meeting American National Standard Institute (ANSI) Z41.
- iii) Safety glasses or goggles, meeting ANSI Z87.
- iv) Leather work gloves.
- v) High visibility safety vest (Class II) when working near moving equipment.
- vi) Hard hat, meeting ANSI Z89.
- vii) Hearing protection, if necessary.

5.1.2 MODIFIED LEVEL D PROTECTION

Modified Level D will be worn when airborne contaminants are not present at levels where respiratory protection is required, but where project activities present an increased potential for skin contact with hazardous substances. The following equipment is to be worn as Modified Level D:

- i) Tyvek® coveralls or polyethylene coated Tyvek® coveralls (if liquids/splash hazards are present).
- ii) Steel toed work boots meeting ANSI Z41.
- iii) Neoprene or polyvinyl chloride (PVC) over boots.
- iv) Safety glasses or goggles.
- v) Hard hat.
- vi) Face shield in addition to safety glasses or goggles when projectiles and/or splashing liquids pose a hazard.
- vii) Disposable nitrile inner gloves (NDEX 8005, as manufactured by Best, or equivalent).
- viii) Nitrile over gloves.
- ix) Hearing protection (if necessary) (if noise levels exceed 85 dBA, then hearing protection with a Noise Reduction Rating (NRR) of at least 20 dBA must be used).
- x) High visibility safety vest (Class II) when working near moving equipment.

5.1.3 LEVEL C PROTECTION

Level C protection will be required when the airborne concentration of suspected contaminants are present in the worker's breathing zone at sustained levels of greater than 1 part per million (ppm) as measured with a photoionization detector (PID) or 1.0 milligram per cubic meter (mg/m³) measured with a particulate monitor (MIE personal Data Ram or equivalent). Supplied air will be required when the PID readings are sustained at levels greater than 25 ppm. If PID readings subside, workers can downgrade as necessary. The selected contractor shall attempt to obtain additional information on the chemicals present in the work area when readings are sustained above 25 ppm.

The following equipment will be used for Level C protection:

- i) Full-face air purifying respirator (APR) with organic vapor/acid gas cartridges in combination with particulate filters (P-100) which are NIOSH approved (MSA GME P100 cartridges or equivalent).
- ii) Polyethylene coated Tyvek® or Saranex® hooded suit (if liquids/splash hazards are present) or Tyvek® coveralls, ankles, and cuffs taped to boots and gloves.
- iii) A chemical splash apron and/or a polycoated Tyvek® suit when handling NAPL.
- iv) Nitrile over glove.
- v) Inner nitrile disposable gloves (NDEX 8005, as manufactured by Best, or equivalent).
- vi) Safety toe work boots, ANSI approved.
- vii) Chemical resistant neoprene or rubber boots with steel toes, or latex/PVC booties over safety toe shoes.
- viii) Hard hat, ANSI approved.
- ix) Hearing protection (if necessary).
- x) High visibility safety vest (Class II).

5.1.4 LEVEL B PROTECTION

Level B protection will be worn when the airborne concentrations of suspended contaminants are present at sustained levels greater than 25 ppm due to the presence of organic vapors or if carbon monoxide levels exceed 35 ppm. Therefore, Level B protection will be required when sustained readings reach 25 ppm as 25 ppm is the level where supplied air respiratory protection becomes required.

The action level necessitating Level B protection may be revised subject to determination of the compounds triggering the Level B protection requirement. However, if the CSHO is unable to identify/quantify the contaminants, supplied air will continue to be required when the PID reading is greater than 25 ppm.

The following equipment will be used for Level B protection:

- i) Supplied air respirator (NIOSH approved). Respirators may be positive pressure-demand self-contained breathing apparatus (SCBA), or positive

pressure-demand airline respirator (with 5-minute escape bottle for immediately dangerous to life and health (IDLH) situations).

- ii) Polyethylene coated Tyvek®(equipment operators) or Saranex® hooded coverall (directly exposed personnel or personnel working with NAPL) with ankles and cuffs taped to boots and gloves. (Note: Kimberly Clark Kleenguard A80 Hazard-Gard II Saranex® coveralls or equivalent).
- iii) A chemical splash apron and/or a polycoated Tyvek® suit when handling NAPL.
- iv) Nitrile over gloves.
- v) Inner nitrile disposable gloves (NDEX 8005, as manufactured by Best, or equivalent).
- vi) Safety toe work boots, ANSI approved.
- vii) Chemical resistant neoprene or rubber boots with steel toes, or latex/PVC booties over safety toe shoes.
- viii) Hard hat, ANSI approved.
- ix) Hearing protection (if necessary).
- x) High visibility safety vest (Class II).

5.1.5 SELECTION OF PPE

Equipment for personal protection will be selected based on the potential for contact, Site conditions, ambient air quality, and the judgment of the CPM, CS, SS, CSHO, and the CSHM. The PPE used will be chosen to be effective against the compound(s) present on the Site.

5.2 RESPIRATORY PROTECTION

Respiratory protection is an integral part of personnel health and safety at sites with potential airborne contamination.

5.2.1 SITE RESPIRATORY PROTECTION PROGRAM

The Site respiratory protection program will consist of the following:

- i) All project personnel who may use respiratory protection will have an assigned respirator.
- ii) All project personnel who may use respiratory protection will have been fit tested and trained in the use of all respirators within the past 12 months.
- iii) All project personnel who may use respiratory protection must, within the past year, have been medically certified as being capable of wearing a respirator. Documentation of the medical certification must be provided to the CSHO prior to commencement of Site work.
- iv) Only cleaned, maintained, NIOSH approved respirators are to be used on this Site.
- v) If respirators are used, the respirator cartridge is to be properly disposed of at the end of each work shift, prior to expected breakthrough, or when breathing becomes labored (filter load-up occurs).
- vi) Contact lenses may be worn with a full-face respirator.
- vii) All project personnel who may use respiratory protection must be clean-shaven. Mustaches and sideburns are permitted, but they must not interfere with the sealing surface of the respirator.
- viii) Respirators will be inspected and a negative pressure test performed prior to each use.
- ix) After each use, the respirator will be wiped with a disinfectant cleansing wipe or washed during a formal respirator cleaning procedure. When used, the respirator will be thoroughly cleaned at the end of the work shift. The respirator will be stored in a clean plastic bag, away from direct sunlight in a clean, dry location, in a manner that will not distort the facepiece.

Respiratory protection may be required during some of the project activities. This is to ensure worker protection from potentially contaminated particulates and volatile organic carbons (VOCs). It is expected that Modified Level D personal protection will be worn during the majority of the project activities involving the handling of impacted materials. However, the CSHO will make the determination of the acceptable level of protection based upon the results of the air-monitoring program. Also, if during these field activities, the real-time air monitoring program indicates the need for an upgrade in protection to Level C or Level B, then these activities will be continued with the increased level of personal protection and additional source controls (e.g., forced

ventilation, foam, plastic sheeting, modified production rate, water spray, etc.) to control vapors and/or particulates.

A PID with a 10.6 or greater eV lamp will be used to determine if organic vapors are present. A background reading will be established prior to commencing work activities at each active work area.

Action levels to determine the level of respiratory protection necessary for organic vapors are based on the sustained (15-minute) concentration of COCs measured within the breathing zone. The action levels and appropriate respiratory protection are referenced in Table 8.1 of this document. The PID action levels have been set based on the presence of the known VOCs, which have been identified at the Site. However, if the ambient concentrations of organic vapors are due to identifiable substances, the level of respiratory protection may be altered by the CSHO.

The appropriate air purifying respirator cartridges to be used at the Site are a combination organic vapor/acid gas and P-100 cartridge. The cartridge must be of the same manufacturer as the respirator face piece.

A personal aerosol monitor (e.g., MIE® Personal DataRam or equivalent) will also be utilized to determine airborne dust/particulate concentrations. A background reading will be established prior to commencing work activities at the upwind perimeter of each active work area.

Action levels to determine the level of respiratory protection necessary for dust levels are based on the concentration of the COCs measured within the breathing zone. The action levels and appropriate respiratory protection for particulates are included in Table 8.1 of this document.

5.3 USING PPE

Depending upon the level of protection selected for this project, specific donning and doffing procedures may be required. The procedures presented in this section are mandatory if Level B or Level C PPE is used.

All personnel entering the EZ must put on the required PPE in accordance with the requirements of this plan. When leaving the EZ, PPE will be removed in accordance with the procedures listed, to minimize the spread of contamination.

5.3.1 DONNING PROCEDURES

These procedures are mandatory only if Level B or Level C PPE is used on the project:

- i) Remove bulky outerwear. Remove street clothes and store in clean location.
- ii) Put on work clothes or coveralls.
- iii) Put on the required chemical protective coveralls or rain gear.
- iv) Put on the required chemical protective boots or boot covers.
- v) Tape the legs of the coveralls to the boots with duct tape.
- vi) Put on the required chemical protective gloves.
- vii) Tape the wrists of the protective coveralls to the gloves.
- viii) Don the required respirator and perform appropriate fit check.
- ix) Put hood or head covering over head and respirator straps and tape hood to facepiece.
- x) Check and secure all seams.
- xi) Don remaining PPE, such as hard hat.

When these procedures are instituted, one person (bottle watch/decon attendant) must remain outside the work area to ensure that each person entering has the proper protective equipment.

5.3.2 DOFFING PROCEDURES

The following procedures are only mandatory if Level B or C PPE is required for this project. Whenever a person leaves a Level B or C work site, the following decontamination sequence will be followed:

- i) Upon entering the Contamination Reduction Zone (CRZ) rinse contaminated materials from the boots or remove contaminated boot covers.
- ii) Clean reusable protective equipment.
- iii) Remove protective garments, equipment, and respirator. All disposable clothing should be placed in a covered container, which is labeled.
- iv) Clean the respirator using the appropriate method as determined by the CSHO.
- v) Wash hands, face, and neck and shower as soon as possible at the end of the day.

- vi) Proceed to clean area and dress in clean clothing.
- vii) Clean and disinfect respirator for next use.

All disposable equipment, garments, and PPE must be placed in covered containers and labeled for disposal. See Section 9.0 for detailed information on decontamination procedures.

5.4 SELECTION MATRIX

The level of personal protection selected will be based upon real-time air monitoring of the work environment and an assessment by the CSHO and CS and/or SS of the potential for skin contact with contaminated materials. The PPE selection matrix is given in each JSA form that is provided in Appendix A. This matrix is based upon information available at the time this HASP was written.

5.5 DURATION OF WORK TASKS

The duration of activities involving the usage of PPE will be established by the CSHO based upon ambient temperature and weather conditions, the capacity of personnel to work in the designated level of PPE (heat stress, see Section 7.3) and the limitations of the protective equipment (i.e., ensemble permeation rates, life expectancy of air purifying respirator (APR) cartridges, etc.).

All rest breaks will be taken in the Support Zone (SZ) after full decontamination and PPE removal. Rest breaks will be observed based upon the heat stress monitoring guidelines presented in Section 7.3.

5.6 LIMITATIONS OF PROTECTIVE CLOTHING

PPE ensembles have been selected to provide protection against contaminants at anticipated concentrations. However, no protective garment, glove, or boot is chemical-proof, nor will it afford protection against all chemical types. Permeation of a given chemical through PPE is a complex process governed by contaminant concentrations, environmental conditions, physical condition of the protection garment, and the resistance of a garment to a specific contaminant. Chemical permeation may continue even after the source of contamination has been removed from the garment.

In order to obtain optimum usage from PPE, the following procedures are to be followed by all Site personnel using PPE:

- i) When using disposable coveralls, don a clean, new garment after each rest break or at the beginning of each shift
- ii) Inspect all clothing, gloves, and boots both prior to and during use for:
 - a) Imperfect seams
 - b) Non-uniform coatings
 - c) Tears
 - d) Poorly functioning closures
- iii) Inspect reusable garments, boots, and gloves both prior to and during use for:
 - a) Visible signs of chemical permeation
 - b) Swelling
 - c) Discoloration
 - d) Stiffness
 - e) Brittleness
 - f) Cracks
 - g) Any sign of puncture
 - h) Any sign of abrasion

Reusable gloves, boots, or coveralls exhibiting any of the characteristics listed above will be discarded. PPE used in areas known or suspected to exhibit elevated concentrations of contaminants will not be reused.

Project personnel also carry certain responsibilities for their own health and safety, and are required to observe the following safe work practices:

- i) Familiarize themselves with this HASP.
- ii) Use the "buddy system" when working in a contaminated operation.
- iii) Use the safety equipment in accordance with training received, labeling instructions, and common sense.
- iv) Maintain safety equipment in good condition and proper working order.
- v) Refrain from activities that would create additional hazards (e.g., smoking, eating, etc., in restricted areas, leaning against dirty, contaminated surfaces).

- vi) Smoking, eating, and drinking will be prohibited except in designated areas. These designated areas may change during the duration of the project to maintain adequate separation from the active work area(s). Designation of these areas will be the responsibility of the CSHO.
- vii) Soiled disposable outerwear shall be removed and placed into a covered container prior to washing hands and face, eating, using lavatory facilities, or leaving the Site.

6.0 SITE CONTROL

Site control is provided by the implementation of the following measures:

- i) The CPM, CSHO, CS, and/or SS are to be advised of the dates and purpose of all field activities
- ii) All visitors must sign in and sign out each time they pass the Site access gate

6.1 AUTHORIZATION TO ENTER

All personnel working in EZs must have completed hazardous waste operations initial training as defined under OSHA Regulation 29 CFR 1926.65. They shall also have completed their training or refresher training within the past 12 months, and have been certified by a physician as fit for hazardous waste operations in order to enter a Site area designated as an EZ or CRZ. Personnel without such training or medical certification may enter the designated SZ only. The CSHO will maintain a list of authorized persons; only personnel on the authorized list will be allowed within the EZ or CRZ.

6.2 SITE ORIENTATION AND HAZARD BRIEFING

No person will be allowed in the general work area during project activities without first being given a Site orientation and hazard briefing. This orientation will be presented by the CSHO, and will consist of attending an initial safety meeting. This training will cover the chemical, physical, and biological hazards, protective equipment, safe work procedures, and emergency procedures for the project. A Training Acknowledgment Form for documentation purposes is provided in Appendix B. In addition to this meeting, daily safety meetings will be held each day before work begins. All individuals on Site, including visitors, must document their attendance to this briefing as well as to each daily safety meeting on the form that is also provided in Appendix B.

6.3 CERTIFICATION DOCUMENTS

The CSHO will be responsible for verifying that all project personnel have the required training, medical, and respirator fit testing qualifications prior to starting work. Subcontractor personnel, if needed, will provide a copy of their training, respirator fit test, and medical documentation to the CSHO prior to the start of fieldwork. Additional

safety training certification documents (e.g., fall protection) may be necessary based on the scheduled task activity.

6.4 ENTRY LOG

A log-in/log-out sheet must be maintained at the Site by the CSHO. Personnel may sign in and out on a log sheet as they enter and leave the CRZ, or the CSHO may document entry and exit in the field notebook.

6.5 ENTRY REQUIREMENTS

In addition to the authorization, hazard briefing and certification requirements listed above, no person will be allowed to enter the Site unless he/she is wearing the minimum SZ PPE as described in Section 5.0. Personnel entering the EZ or CRZ must wear the required PPE for those locations as identified on each JSA form.

6.6 EMERGENCY ENTRY AND EXIT

Individuals who must enter the Site on an emergency basis will be briefed of the hazards by the CSHO. All hazardous activities will cease in the event of an emergency and any sources of emissions will be controlled, if possible.

Individuals exiting the Site because of an emergency will gather in a safe area, as determined by the CSHO for a head count. The CSHO is responsible for ensuring that all individuals who entered the work area have exited in the event of an emergency. See Section 11.0 of this HASP for additional information.

6.7 CONTAMINATION CONTROL ZONES

Contamination control zones are maintained to prevent the spread of contamination and to prevent unauthorized people from entering hazardous areas.

6.7.1 EXCLUSION ZONE (EZ)

The EZ consists of the specific work area, or may be the entire area of suspected contamination. All employees entering the EZ must use the required PPE, and must have the appropriate training and medical clearance for hazardous waste work. The EZ is the defined area where there is a possible respiratory and/or contact health hazard. Barrier tape, fencing, or other appropriate means will identify the location of each EZ.

6.7.2 CONTAMINATION REDUCTION ZONE (CRZ)

The CRZ or transition area will be established to perform decontamination of personnel and equipment and to provide a buffer zone around the EZ. All personnel entering or leaving the EZ will pass through this area to prevent any cross-contamination. Tools, equipment, and machinery will be decontaminated in the CRZ (or a separate CRZ decontamination area) that may be set up to better address equipment decontamination. The decontamination of all personnel will be performed on Site in the CRZ that is adjacent to each EZ. Personal protective outer garments and respiratory protection will be removed in the CRZ and prepared for cleaning or disposal. This zone is the only appropriate corridor between the EZ and the SZ.

A separate CRZ may be set up at the boundary of the active excavation area and the outer ring of the EZ. The purpose of this CRZ will allow project personnel to replenish fluids and to sit down and cool off in the shade. These measures will help to prevent heat-related illness. Potable water will be available at this CRZ as will an umbrella or small tent with a couple of chairs. Personnel will not go through a full decontamination in this area but rather will partially unzip their polycoated Tyvek® suit and lower it to their waist. Respirators will then be removed followed by the removal of the gloves. Exposed skin areas will be washed and then personnel will be allowed to drink water and sit in the shade. Any personnel who have gross contamination on them will be directed to the primary CRZ where they will go through the full decontamination process and disposal of the contaminated polycoated Tyvek® suit.

6.7.3 SUPPORT ZONE (SZ)

The SZ is a clean area outside of the CRZ located to prevent project personnel from exposure to hazardous substances. Eating and drinking will be permitted in the SZ only after proper decontamination. Smoking will not be allowed in any portion of the SZ.

7.0 ACTIVITY HAZARD/RISK ANALYSIS AND GENERAL SAFETY PRACTICES

This section identifies and evaluates the potential chemical, physical, and biological hazards, which may be encountered while conducting project activities. Specific JSA forms (see Appendix A) have been developed to address the hazards associated with scheduled/known project activities, which are outlined in Section 1.0 of this HASP.

Note: If a non-routine task or previously unidentified task becomes necessary, then a JSA that addresses the new task shall be developed and implemented before initiating the new activity.

In addition to the chemical hazards identified in Table 2.1 of this HASP, physical and biological hazards may exist at the Site including: potential heat/cold stress; hazards presented by the use of heavy equipment; underground/overhead utility hazards; hazards presented by excavations/trenches; biological hazards including, vegetation, stray dogs, mosquitoes, bees, wasps, snakes; uneven terrain and slippery surfaces; and the use of decontamination equipment. It will be the responsibility of the CSHO and all project personnel to identify the physical and/or biological hazards posed by the various project activities that they are partaking in and implement all necessary preventative measures.

7.1 GENERAL PRACTICES

Additional general safety practices to be implemented are as follows:

- i) At least one copy of this HASP must be at the Site, in a location readily available to all personnel.
- ii) All project personnel must use the buddy system (working in pairs or teams).
- iii) Food, beverages, or tobacco products must not be present or consumed in the EZ and CRZ. Cosmetics must not be applied within these zones.
- iv) Emergency equipment such as eyewash, fire extinguishers, etc., must be removed from storage areas and staged in readily accessible locations.
- v) Contaminated waste, debris, and clothing must be properly contained and legible and understandable precautionary labels must be affixed to the containers.

- vi) Removing contaminated soil or waste debris from protective clothing and/or equipment using compressed air, shaking, or any other means that disperses contaminants into the air is prohibited.
- vii) Containers must be moved only with the proper equipment, and must be secured to prevent dropping or loss of control during transport.
- viii) Visitors to the Site must be instructed to stay outside of the EZ and CRZ and remain within the SZ during the extent of their stay. Visitors must be cautioned to avoid skin contact with surfaces, which are contaminated or suspected to be contaminated.
- ix) All project personnel are to stay a minimum of 50 feet away (50-foot zone) from operating equipment. The only exception to this rule will be when eye contact is made with the equipment operator and the equipment operator acknowledges the presence of the individual, lowers the excavation bucket or blade on the equipment to the ground and then motions for the individual to approach or enter the 50-foot zone.

7.1.1 BUDDY SYSTEM

All project personnel shall use the buddy system. Visual contact must be maintained between project team members at all times, and personnel must observe each other for signs of chemical exposure and heat stress. Indications of adverse effects include, but are not limited to:

- i) Changes in complexion and skin coloration
- ii) Changes in coordination
- iii) Excessive salivation and papillary response
- iv) Changes in speech pattern

Team members must also be aware of potential exposure to possible safety hazards, unsafe acts, or noncompliance with safety procedures. Personnel shall inform their partners, fellow team members, CSHO, CS, and/or the SS of non-visible effects of exposure to toxic materials. The symptoms of such exposure may include:

- i) Headaches
- ii) Dizziness
- iii) Nausea
- iv) Blurred vision

- v) Cramps
- vi) Irritation of eyes, skin, or respiratory tract

If protective equipment or noise levels impair communications, pre-arranged hand signals must be used for communication. Personnel must stay within line of sight of another team member. Downrange field teams in conjunction with the "buddy" system will use the following hand signals. These signals are very important when working with heavy equipment. The entire field team shall know them before operations commence.

<i>Signal</i>	<i>Meaning</i>
Hand Gripping Throat	Out of Air; Can't Breathe
Grip Partner's Wrist	Leave Area Immediately
Hands on Top of Head	Need Assistance
Thumbs Up	Ok, I'm All Right, I Understand
Thumbs Down	No, Negative

7.1.2 SANITATION

Sanitation at the Site will be maintained according to OSHA and Department of Health requirements.

7.1.3 BREAK AREA

Breaks must be taken in the SZ, away from the active work area after project personnel go through decontamination procedures. There will be no eating, drinking, or chewing gum in any area other than the SZ.

7.1.4 POTABLE WATER

The following rules apply for all project field operations:

- i) An adequate supply of potable water will be provided in each CRZ. Potable water must be kept away from hazardous materials, contaminated clothing, and contaminated equipment.

- ii) Portable containers used to dispense drinking water must be capable of being tightly closed, and must be equipped with a tap dispenser. Water must not be drunk directly from the container, nor dipped from the container.
- iii) Containers used for drinking water must be clearly marked and not used for any other purpose.
- iv) Disposable cups must be supplied, and both a sanitary container for unused cups and a receptacle for disposing of used cups must be provided.

7.1.5 WASHING FACILITIES

Access to facilities for washing ones hands, face and neck before eating, drinking, or smoking will be provided.

7.1.6 LAVATORY

If permanent toilet facilities are not available, an adequate number of portable chemical toilets will be provided.

7.1.7 TRASH COLLECTION

Trash collected from the CRZ will be separated as potentially contaminated waste. Trash collected in the support and break areas will be disposed of as non-hazardous waste. Trash receptacles will be set up in the CRZ and in the SZ.

7.2 CHEMICAL EXPOSURE

Preventing exposure to toxic chemicals is a primary concern. Chemical substances can enter the unprotected body by inhalation, skin absorption, ingestion, or through a puncture wound (injection). A contaminant can cause damage at the point of contact or can act systematically, causing a toxic effect at a part of the body distant from the point of initial contact. The COCs and their properties are identified in Table 2.1

Chemical exposures are generally divided into two categories: acute and chronic. Symptoms resulting from acute exposures usually occur during or shortly after exposure to a sufficiently high concentration of a contaminant. The concentration required to produce such effects varies widely from chemical to chemical. The term

"chronic exposure" generally refers to exposures to "low" concentrations of a contaminant over a long period of time. The "low" concentrations required to produce symptoms of chronic exposure depend upon the chemical, the duration of each exposure, and the number of exposures. For a given contaminant, the symptoms of an acute exposure may be completely different from those resulting from chronic exposure.

For either chronic or acute exposure, the toxic effect may be temporary and reversible, or may be permanent (disability or death). Some chemicals may cause obvious symptoms such as burning, coughing, nausea, tearing eyes, or rashes. Other chemicals may cause health damage without any such warning signs (this is a particular concern for chronic exposures to low concentrations). Health effects such as cancer or respiratory disease may not become evident for several years or decades after exposure. In addition, some toxic chemicals may be colorless and/or odorless, may dull the sense of smell, or may not produce any immediate or obvious physiological sensations. Thus, a worker's senses or feelings cannot be relied upon in all cases to warn of potential toxic exposure.

The effects of exposure not only depend on the chemical, its concentration, route of entry, and duration of exposure, but may also be influenced by personal factors such as the individual's smoking habits, alcohol consumption, medication use, nutrition, age, and sex.

An important exposure route of concern at the Site is inhalation. The lungs are extremely vulnerable to chemical agents. Even substances that do not directly affect the lungs may pass through lung tissue into the bloodstream, where they are transported to other vulnerable areas of the body. Some toxic chemicals present in the atmosphere may not be detected by human senses (e.g., they may be colorless, odorless, and their toxic effects may not produce any immediate symptoms). Respiratory protection is therefore extremely important if there is a possibility that the work site atmosphere may contain such hazardous substances. Chemicals can also enter the respiratory tract through punctured eardrums. Where this is a hazard, individuals with punctured eardrums should be medically evaluated specifically to determine if such a condition would place them at an unacceptable risk and preclude their working at the task in question.

Direct contact of the skin and eyes by hazardous substances is another important route of exposure. Some chemicals directly injure the skin. Some pass through the skin into the bloodstream where they are transported to vulnerable organs. Abrasions, cuts, heat, and moisture enhance skin absorption. The eye is particularly vulnerable because airborne chemicals can dissolve in its moist surface and be carried to the rest of the body through the bloodstream (capillaries are very close to the surface of the eye). Wearing protective equipment, not using contact lenses in contaminated atmospheres (since they

may trap chemicals against the eye surface), keeping hands away from the face, and minimizing contact with liquid and solid chemicals can help protect against skin and eye contact.

Although ingestion should be the least significant route of exposure at the Site, it is important to be aware of how this type of exposure can occur. Deliberate ingestion of chemicals is unlikely; however, personal habits such as chewing gum or tobacco, drinking, eating, smoking cigarettes, and applying cosmetics at the Site may provide a route of entry for chemicals.

The last primary route of chemical exposure is injection, whereby chemicals are introduced into the body through puncture wounds (e.g., by stepping or tripping and falling onto contaminated sharp objects). Wearing safety shoes, avoiding physical hazards, and taking common sense precautions are important protective measures against injection.

Chemical Hazard Controls

Airborne exposure or contact with the contaminants of concern at the Site shall be controlled by:

- i) Skin contact with chemicals may be controlled by use of the proper PPE and good housekeeping procedures. The proper PPE (e.g., polycoated Tyvek®, gloves) as described in Section 5.0 of this HASP shall be worn for all activities where contact with potentially harmful media or materials is anticipated.
- ii) Monitoring air concentrations for VOCs and particulates shall be conducted in the breathing zone with a PID with a 10.6 eV lamp or greater and a particulate monitor, as described in Section 8.0.
- iii) Dust control measures, such as wetting the immediate area, shall be employed when visible dust is generated in active work areas.
- iv) Contact the CSHM for additional information regarding a particular product's or activity's exposure hazards.
- v) Using respiratory protection as appropriate, in areas known to have concentrations above the specified action level.

Hazard Communication

Personnel required to handle or to use hazardous materials as part of their job duties will be trained and educated in accordance with the Hazard Communication Standard. The training shall include instruction on the safe usage, and handling procedures of

hazardous materials, how to read and access Material Safety Data Sheets (MSDSs), and the proper labeling requirements.

The MSDSs for those chemicals in use at the Site will be available to project personnel. The CSHO will be responsible for maintaining a copy of all MSDSs on Site.

7.3 HEAT STRESS

Heat stress is caused by a number of interacting factors including environmental conditions, clothing, workload, etc., as well as the physical and conditioning characteristics of the individual. Since heat stress is one of the most common illnesses associated with heavy outdoor work conducted with direct solar load, and in particular, because wearing PPE can increase the risk of developing heat stress, workers must be capable of recognizing the signs and symptoms of heat-related illnesses. Personnel must be aware of the types and causes of heat-related illnesses and be able to recognize the signs and symptoms of these illnesses in both themselves and their co-workers.

Heat Rashes: Are one of the most common problems in hot work environments. Commonly known as prickly heat, a heat rash is manifested as red papules and usually appears in areas where the clothing is restrictive. As sweating increases, these papules give rise to a prickling sensation. Prickly heat occurs in skin that is persistently wetted by unevaporated sweat, and heat rash papules may become infected if they are not treated. In most cases, heat rashes will disappear when the affected individual returns to a cool environment.

Heat Cramps: Are usually caused by performing hard physical labor in a hot environment. These cramps have been attributed to an electrolyte imbalance caused by sweating. It is important to understand that cramps can be caused both by too much and too little salt.

Cramps appear to be caused by the lack of water replenishment. Because sweat is a hypotonic solution (plus or minus 0.3 percent NaCl), excess salt can build up in the body if the water lost through sweating is not replaced. Thirst cannot be relied on as a guide to the need for water; instead, water must be taken every 15 to 20 minutes in hot environments.

Under extreme conditions, such as working for 6 to 8 hours in heavy protective gear, a loss of sodium may occur. Drinking commercially available carbohydrate-electrolyte

replacement liquids is effective in minimizing physiological disturbances during recovery.

Heat Exhaustion: Occurs from increased stress on various body organs due to inadequate blood circulation, cardiovascular insufficiency, or dehydration. Signs and symptoms include pale, cool, moist skin, heavy sweating, dizziness, nausea, headache, vertigo, weakness, thirst, and giddiness. Fortunately, this condition responds readily to prompt treatment.

Heat exhaustion should not be dismissed lightly, however, for several reasons. One is that the fainting associated with heat exhaustion can be dangerous because the victim may be operating machinery or controlling an operation that should not be left unattended; moreover, the victim may be injured when he or she faints. Also, the signs and symptoms seen in heat exhaustion are similar to those of heat stroke, which is a medical emergency.

Workers suffering from heat exhaustion should be removed from the hot environment, be given fluid replacement, and be encouraged to get adequate rest.

Heat Stroke: Is the most serious form of heat stress. Heat stroke occurs when the body's system of temperature regulation fails and the body's temperature rises to critical levels. This condition is caused by a combination of highly variable factors, and its occurrence is difficult to predict.

Heat stroke is a medical emergency. The primary signs and symptoms of heat stroke are confusion, irrational behavior, loss of consciousness, convulsions, a lack of sweating (usually), hot, dry skin, and an abnormally high body temperature, e.g., a rectal temperature of 41°C (105.8°F). If body temperature is too high, it causes death. The elevated metabolic temperatures caused by a combination of workload and environmental heat load, both of which contribute to heat stroke, are also highly variable and difficult to predict.

If a worker shows signs of possible heat stroke, professional medical treatment should be obtained immediately. The worker should be placed in a shady area and the outer clothing should be removed. The worker's skin should be wetted and air movement around the worker should be increased to improve evaporative cooling until professional methods of cooling are initiated and the seriousness of the condition can be assessed. Fluids should be replaced as soon as possible. The medical outcome of an episode of heat stroke depends on the victim's physical fitness and the timing and effectiveness of first aid treatment.

Regardless of the worker's protestations, no employee suspected of being ill from heat stroke should be sent home or left unattended unless a physician has specifically approved such an order.

Proper training and preventive measures will help avert serious illness and loss of work productivity. Preventing heat stress is particularly important because once someone suffers from heat stroke or exhaustion, that person may be predisposed to additional heat injuries.

Heat Stress Safety Precautions: Heat stress monitoring and work rest cycle implementation should commence when the ambient adjusted temperature exceeds 72°F. A minimum work rest regimen and procedures for calculating ambient adjusted temperature are described below.

<i>Adjusted Temperature⁽¹⁾</i>	<i>Work-Rest Regimen Normal Work Ensemble⁽²⁾</i>	<i>Work-Rest Regimen Impermeable Ensemble</i>
90°C (32.°C) or above	After each 45 minutes of work	After each 15 minutes of work
87.5° to 90°F (30.8°C to 32.2°C)	After each 60 minutes of work	After each 30 minutes of work
82.5° to 87.5°F (28.1° to 30.8°C)	After each 90 minutes of work	After each 60 minutes of work
77.5° to 82.5°F (25.3° to 28.1°C)	After each 120 minutes of work	After each 90 minutes of work
72.5° to 77.5°F (30.8° to 32.2°C)	After each 150 minutes of work	After each 120 minutes of work

Notes:

(1) Calculate the adjusted air temperature (ta adj) by using this equation: ta adj °F=ta °F + (13 x percent sunshine). Measure air temperature (ta) with a standard thermometer, with the bulk shielded from radiant heat. Estimate percent sunshine by judging what percent of the time the sun is not covered by clouds that are thick enough to produce a shadow (100 percent sunshine = no cloud cover and a sharp, distinct shadow; 0 percent sunshine = no shadows).

(2) A normal work ensemble consists of cotton coveralls or other cotton clothing with long sleeves and pants.

In order to determine if the work rest cycles are adequate for the personnel and specific Site conditions, additional monitoring of individual heart rates will be conducted during the rest cycle. To check the heart rate, count the radial pulse for 30 seconds at the

beginning of the rest period. If the heart rate exceeds 110 beats per minute, shorten the next work period by one-third and maintain the same rest period.

Additionally, one or more of the following control measures can be used to help control heat stress and are mandatory if any Site worker has a heart rate (measure immediately prior to rest period) exceeding 115 beats per minute:

- i) Project personnel will be encouraged to drink plenty of water and electrolyte replacement fluids throughout the day.
- ii) On-Site drinking water will be kept cool (50 to 60°F).
- iii) A work regimen that will provide adequate rest periods for cooling down will be established, as required.
- iv) All personnel will be advised of the dangers and symptoms of heat stroke, heat exhaustion, and heat cramps.
- v) Cooling devices such as vortex tubes or cooling vests should be used when personnel must wear impermeable clothing in conditions of extreme heat.
- vi) Project personnel shall be instructed to monitor themselves and co-workers for signs of heat stress and to take additional breaks as necessary.
- vii) A shaded rest area must be provided. All breaks should take place in the shaded rest area.
- viii) Project personnel must not be assigned to other tasks during breaks.
- ix) Project personnel must remove impermeable garments during rest periods. This includes Tyvek® garments.
- x) All project personnel must be informed of the importance of adequate rest, acclimation (usually takes about 2 hours/day for 1 to 2 weeks to become acclimated), and proper diet in the prevention of heat stress disorders.

7.4 SUN EXPOSURE

Overexposure to sunlight is a common concern when field activities occur during warm weather conditions. Overexposure can occur on clear, sunny days as well as on overcast and cloudy days. Ultraviolet (UV) rays from the sun can cause skin damage or sunburn, but can also result in vision problems, allergic reactions, and other skin concerns. Two types of UV rays are emitted from the sun: UVA and UVB rays.

UVB rays cause sunburn, skin cancer, and premature aging of the skin. UVB rays stimulate tanning but are also linked to other problems such as impaired vision, skin

rashes, and some allergic and other reactions to certain drugs. Extra care should be taken if activities are to be conducted on or near water. Sunlight reflected off the surface of the water is intensified resulting in accelerated effects. The following steps should be taken to protect against overexposure to sunlight:

- i) Always use sunscreen: Apply a broad-spectrum sunscreen with Sun Protection Factor (SPF) of at least 15 or higher liberally on exposed skin. Reapply every 2 hours or more. Even waterproof sunscreen can come off when you towel off or sweat.
- ii) Cover up: Wearing tightly woven, loose-fitting, and full-length clothing is a good way to protect your skin from UV rays.
- iii) Wear a hat: A hat with a wide brim offers good sun protection to your eyes, ears, face, and the back of your neck – areas particularly prone to overexposure to the sun.
- iv) Wear sunglasses that block 99 to 100 percent of UV radiation: Sunglasses that provide 99 to 100 percent UVA and UVB protection will greatly reduce sun exposure that can lead to cataracts and other eye damage. Check the label when buying sunglasses.
- v) Seek shade: Shade is a good source of protection, but keep in mind that shade structures (e.g., trees, umbrellas, canopies) do not offer complete sun protection.
- vi) Limit time in the midday sun: The sun's rays are strongest between 10 a.m. and 4 p.m. Whenever possible, limit exposure to the sun during these hours.

7.5 COLD STRESS

Cold stress is similar to heat stress in that it is caused by a number of interacting factors including environmental conditions, clothing, workload, etc., as well as the physical and conditioning characteristics of the individual. Fatal exposures to cold have been reported in individuals failing to escape from low environmental air temperatures or from immersion in low temperature water. Hypothermia, a condition in which the body's deep core temperature falls significantly below 98.6°F (37°C), can be life threatening. A drop in core temperature to 95°F (35°C) or lower must be prevented.

Air temperature is not sufficient to determine the cold hazard of the work environment. The wind chill must be considered as it contributes to the effective temperature and insulating capabilities of clothing. The equivalent chill temperature should be used when estimating the combined cooling effect of wind and low air temperatures on

exposed skin or when determining clothing insulation requirements to maintain the body's core temperature.

The body's physiologic defense against cold includes constriction of the blood vessels, inhibition of the sweat glands to prevent loss of heat via evaporation, glucose production, and involuntary shivering to produce heat by rapid muscle contraction.

The frequency of accidents increases with cold temperature exposures as the body's nerve impulses slow down, individuals react sluggishly, and numb extremities make for increased clumsiness. Additional safety hazards include ice, snow blindness, reflections from snow, and possible skin burns from contact with cold metal.

Pain in the extremities may be the first early warning of danger to cold stress. During exposure to cold, maximum severe shivering develops when the body temperature has fallen to 95°F (35°C). This must be taken as a sign of danger to the individuals on Site, and cold exposures should be immediately terminated for any individual when severe shivering becomes evident. Useful physical or mental work is limited when severe shivering occurs.

Predisposing Factors for Cold Stress

There are certain predisposing factors that make an individual more susceptible to cold stress. It is the responsibility of the project team members to inform the CSHO/SS to monitor an individual, if necessary, or use other means of preventing/reducing the individual's likelihood of experiencing a cold related illness or disorder.

Predisposing factors that will increase an individual's susceptibility to cold stress are listed below:

- **Dehydration:** The use of diuretics and/or alcohol, or diarrhea can cause dehydration. Dehydration reduces blood circulation to the extremities.
- **Fatigue during Physical Activity:** Exhaustion reduces the body's ability to constrict blood vessels. This results in the blood circulation occurring closer to the surface of the skin and the rapid loss of body heat.
- **Age:** Some older and very young individuals may have an impaired ability to sense cold.
- **Poor Circulation:** Vasoconstriction of peripheral vessels reduces blood flow to the skin surface.

- **Heavy Work Load:** Heavy workloads generate metabolic heat and make an individual perspire even in extremely cold environments. If perspiration is absorbed by the individual's clothing and is in contact with the skin, cooling of the body will occur.
- **The Use of PPE:** PPE usage that traps sweat inside the PPE may increase an individual's susceptibility to cold stress.
- **Lack of Acclimatization:** Acclimatization, the gradual introduction of workers into a cold environment, allows the body to physiologically adjust to cold working conditions.
- **History of Cold Injury:** Previous injury from cold exposures may result in increased cold sensitivity.

Prevention of Cold Stress

There are a variety of measures that can be implemented to prevent or reduce the likelihood of individuals developing cold related ailments and disorders. These include acclimatization, fluid and electrolyte replenishment, eating a well balanced diet, wearing warm clothing, the provision of shelter from the cold, thermal insulation of metal surfaces, adjusting work schedules, and personnel education.

- **Acclimatization:** Acclimatization is the gradual introduction of workers into the cold environment to allow their bodies to physiologically adjust to cold working conditions. However, the physiological changes are usually minor and require repeated uncomfortably cold exposures to induce them.
- **Fluid and Electrolyte Replenishment:** Cold, dry air can cause individuals to lose significant amounts of water through the skin and lungs. Dehydration affects the flow of blood to the extremities and increases the risk of cold injury. Warm, sweet, caffeine-free, non-alcoholic drinks and soup are good sources to replenish body fluids.
- **Eating a Well Balanced Diet:** Restricted diets including low salt diets can deprive the body of elements needed to withstand cold stress. Eat high-energy foods throughout the day.
- **Warm Clothing:** It is beneficial to maintain air space between the body and outer layers of clothing in order to retain body heat. However, the insulating effect provided by such air spaces is lost when the skin or clothing is wet.
- **Work/Rest Regimes:** Schedule work during the warmest part of the day, if possible. Rotate personnel and adjust the work/rest schedule to enable individuals to recover from the effects of cold stress.

The parts of the body most important to keep warm are the feet, hands, head, and face. As much as 40 percent of body heat can be lost when the head is exposed.

7.6 WORKING OVER OR NEAR WATER

The procedures outlined in this section are to be implemented by all CRA and subcontractor personnel when there is the potential for slipping or falling into water that is greater than 3 feet in depth. Additionally, these procedures are to be adhered to when water is flowing and has the potential to carry personnel away.

- When working at ground level, a 5-foot "no entry zone" can be established between the work area and the water hazard. The no entry zone is to be clearly defined and/or demarcated. Personnel will not be permitted to enter into this area unless the other provisions of this section are in place.
- Standard guardrails are required on any walking/working surface over or near water.
- Where guardrails are not practical due to impairment of work being performed, other types of safeguarding, such as safety harnesses, lifelines, and lanyards may be used (see CRA's Fall Protection SOP).
- If providing fall protection is not feasible due to the scope of work or location, personnel will be required to wear U.S. Coast Guard-approved life jackets or buoyant work vests. Prior to each use and after each use, the buoyant work vests and life preservers must be inspected for defects that would affect strength and/or buoyancy. Any damaged or defective buoyant work vest or life preserver cannot be used.
- Call in or make prearranged contacts after each activity posing a drowning hazard is completed.
- If work on wet or slippery surfaces above water is necessary, non-slip tape or other methods are to be used to increase traction.
- Ring buoys with a minimum 90 feet of line must be readily available for emergency operations. The distance between buoys cannot exceed 200 feet.
- Due to the anticipated scope of work, a life saving skiff may be necessary. However, the SS in conjunction with the RSHM will evaluate current site conditions to determine if a skiff is required.

7.7 EARTHWORK - EXCAVATION AND TRENCHING

Project activities will involve excavation and stockpiling of contaminated soil. Prior to initiating excavation activities, the CS is responsible for making sure that the following conditions are in place:

- i) Ensure that all above and underground utilities have been properly located prior to initiating work activities
- ii) Ensure that approved protective shoring devices are available for use at the Site if this means of protection is going to be used
- iii) Ensure that the competent person has inspected the excavation and determined that it is safe to enter prior to allowing project personnel to enter any excavation
- iv) Ensure that all excavation work is completed in accordance with 29 CFR 1926 Subpart P
- v) Ensure that the proper fencing materials are available to secure each active work area

Before excavation begins, the existence and location of underground utilities (e.g., pipe, electrical equipment, and gas lines) will be determined. This will be done, if possible, by contacting the appropriate client representative to mark the location of the lines. If the client's knowledge of the area is incomplete, an appropriate device, such as a magnetometer, will be used to locate the line. A Property Access Utility Clearance Form is presented in Appendix B to document that nearby utilities have been marked on the ground and that the excavation site has been cleared. The form shall be in the possession of the SS prior to commencement of the excavation.

The selected contractor's competent person shall observe all excavation and trenching operations where project personnel will enter. The competent person shall be responsible for evaluating, classifying and inspecting excavation and trenching operations to prevent possible cave-in and entrapment, and to avoid other hazards presented by excavation activities.

It is the responsibility of the CS and CSHO to implement the following components of the selected contractor's Excavation and Trenching Safety Program as they relate to project activities:

- i) Ensure that all excavations are completed in accordance with the approved Excavation and Trenching Safety Program

- ii) Ensure that the proper protective materials and equipment are available and being used to complete the excavation and/or trenching procedures
- iii) Ensure that the necessary inspections of the excavation are completed as required

Personnel required to enter or work in the excavation at any time must be protected from the hazards of cave-ins. This requires the use of sloping and/or shoring systems that comply with State and Federal OSHA standards. Excavation and trenching operations require pre-planning to develop appropriate designs for such systems. The selected contractor will make the appropriate plans.

The estimated location of all underground installations shall be determined before excavation begins. If there are any nearby buildings, walls, sidewalks, trees, or roads that may be threatened or undermined by the excavation, where the stability of any of these items may be endangered by the excavation, they must be removed or supported by adequate shoring, bracing, or underpinning.

Excavations may not go below the base of footings, foundations, or retaining walls, unless they are adequately supported or a person who is registered as a PE has determined that they will not be affected by the soil removal. OSHA requires using civil engineers or those with licenses in a related discipline and experience in the design and use of sloping and shoring systems. PE qualifications shall be documented in writing and available at the Site.

Access and Egress

Personnel access and egress from trench and/or excavations are as follows:

- i) A stairway, ladder, ramp, or other means of egress must be provided in excavations greater than 4 feet deep and for every 25 feet of lateral travel
- ii) All ladders shall extend 3 feet above the top of the excavation

Atmosphere Monitoring and Testing

Air quality is measured by the following three parameters:

Oxygen concentration

Flammability

Presence of toxic substances

There is a potential for hazardous atmospheres to exist in each proposed excavation. As such, project personnel will not be allowed to be exposed to any hazardous atmosphere. Whenever potentially hazardous atmospheres are suspected in excavations, the competent person shall test the atmosphere. A gas monitor capable of measuring the oxygen level, lower explosive limit (LEL) and toxicity will be used to take readings prior to and while workers are in any excavation. A hazardous atmosphere is defined as one that could contain less than 19.5 percent of oxygen, concentrations of hazardous substances greater than their permissible exposure level (PEL) including carbon monoxide and a LEL reading greater than 10 percent. A forced air ventilator will first be used to pump fresh air into the excavation and to push out (purge) any potentially contaminated air.

In the event that an unusual odor or liquid is suspected in excavations, the competent person shall stop work and arrange for air quality assessment and mitigation, if necessary.

Daily Inspections

The competent person shall perform daily inspections of excavations, the adjacent areas, and all protective systems for situations that could potentially result in slope failure.

The competent person shall inspect, evaluate, and document the inspection of the excavation on an Excavation Inspection Checklist at the following intervals:

- i) Prior to the start of work, after each extended halt in work, and as needed throughout the shift as new sections of the excavation are opened
- ii) After every rainstorm and other natural or man-made event that may increase the load on the walls of the excavation, or otherwise affect their stability

The SC or SS shall use the safety inspection checklist for excavations that is presented in Appendix B. The competent person shall stop the work and instruct all project personnel to leave the excavation when any potential hazards are detected. The competent person has the authority to immediately suspend work if any unsafe condition is detected.

7.8 HEAVY EQUIPMENT AND DRILLING SAFETY

Heavy Equipment

The following practices shall be adhered to by personnel operating heavy equipment (such as backhoes) and personnel working in the vicinity of heavy equipment:

- Heavy equipment is to be inspected when equipment is initially mobilized, delivered to a job site, or after it is repaired and returned to service, to ensure that it meets all manufacturer and OSHA specifications (e.g., fire extinguishers, backup alarms, etc.).
- Heavy equipment is to be inspected on a daily basis. Documentation of this daily pre-operational inspection is to be filed with the project files.
- Heavy equipment is only to be operated by authorized, competent operators.
- Seat belts are to be provided on heavy equipment that is not designed for stand-up operation.
- Equipment/vehicles whose payload is loaded by crane, excavator, loader, etc. will have a cab shield and/or canopy to protect the operator.
- Personnel will not be raised/lowered in buckets.
- Personnel will not ride on fender steps or any place outside the cab.
- Before leaving the equipment controls, ensure that the equipment is in its safe resting position. For a backhoe, apply the parking brake, put the front loader bucket down on the ground level, and ensure that the rear excavator bucket is locked in the travel position. Bulldozers and scraper blades, loader buckets, dump bodies, and similar equipment will be fully lowered or blocked when not in use.
- Before raising any booms, buckets, etc., check for overhead obstructions.
- Employees involved in the operation shall not wear any loose-fitting clothing, as it has the potential to be caught in moving machinery.
- Personnel shall wear high visibility safety vests, steel toed shoes, safety glasses, hearing protection, and hard hats during heavy equipment operations.
- When moving heavy equipment or when working within 10 feet of a stationary object or in tight quarters, a spotter will be used.

Drilling Equipment

The following practices shall be adhered to by drilling personnel:

- Equipment should be inspected daily by the operator to ensure that there are no operational problems.
- The kill switch will be function-checked and verified to be operational during the documented daily equipment check.
- Personnel shall be instructed in the location and use of the emergency kill switch on the drill rig.
- Employees involved in the operation shall not wear any loose-fitting clothing, including untied shoe/boot laces, draw strings, etc., which have the potential to be caught in moving machinery.
- Before leaving the controls, shift the transmission controlling the rotary drive into neutral and place the feed lever in neutral. Before leaving the vicinity of the drill, shut down the drill engine.
- Before raising the mast, check for overhead obstructions.
- Before the mast of a drill rig is raised, the drill rig must first be leveled and stabilized with leveling jacks and/or cribbing. Re-level the drill rig if it settles after initial setup. Lower the mast only when the leveling jacks are down, and do not raise the leveling jack pads until the mast is lowered completely.
- During freezing weather, do not touch any metal parts of the drill rig with exposed flesh. Freezing of moist skin to metal can occur almost instantaneously.
- Personnel shall wear steel toed shoes, safety glasses, hearing protection, and hard hats during drilling operations.
- The area shall be roped off, marked, or posted to keep the area clear of pedestrian traffic or spectators.

7.8.1 DRILLING SAFETY PROCEDURES

Drill Crews: All drillers must possess required State or local licenses to perform such work. All members of the drill crew shall receive Site-specific training prior to beginning work.

The driller is responsible for the safe operation of the drill rig as well as the crew's adherence to the requirements of their HASP. The driller must ensure that all safety equipment is in proper condition and is properly used. The members of the crew must

follow all instructions of the driller, wear all PPE, and be aware of all hazards and control procedures. The drill crews must participate in the Daily Safety Meetings and be aware of all emergency procedures.

Rig Inspection: Each day, prior to the start of work, the driller and/or drill crew must inspect the drill rig and associated equipment. The following items must be inspected:

- i) Vehicle condition
- ii) Proper storage of equipment
- iii) Condition of all wire rope
- iv) Fire extinguisher
- v) First aid kit

Drill Rig Setup: The drill rig must be properly blocked and leveled prior to raising the derrick. The wheels, which remain on the ground, must be chocked. The leveling jacks shall not be raised until the derrick is lowered. The rig shall be moved only after the derrick has been lowered.

Site Drilling Rules: Before drilling, the existence and location of underground utilities (e.g., pipe, electrical equipment, and gas lines) will be determined. This will be done, if possible, by contacting the appropriate client representative to mark the location of the lines. If the client's knowledge of the area is incomplete, an appropriate device, such as a magnetometer, will be used to locate the line. A Property Access Utility Clearance Form shall be developed and used to document that nearby utilities have been marked on the ground and that the drill site has been cleared. The form shall be in the possession of the SS prior to commencement of the intrusive investigation.

Under no circumstances will personnel be permitted to ride the traveling block or elevators, nor will the cat line be used as a personnel carrier.

Overhead Electrical Clearances: If drilling is conducted in the vicinity of overhead power lines, the power to the lines must be shut off or the equipment must be positioned and blocked such that no part, including cables, can come within the minimum clearances as follows:

<i>Nominal System Voltage</i>	<i>Minimum Required Clearance</i>
0 to 50 kV	10 Feet
51 to 100 kV	12 Feet

<i>Nominal System Voltage</i>	<i>Minimum Required Clearance</i>
101 to 200 kV	15 Feet
201 to 300 kV	20 Feet
301 to 500 kV	25 Feet
501 to 750 kV	35 Feet
751 to 1,000 kV	45 Feet

When the drill rig is in transit with the boom lowered and no load, the equipment clearance must be at least 4 feet for voltages less than 50 kV, 10 feet for voltages of 50 kV to 345 kV, and 16 feet for voltages above 345 kV.

Rig Set Up: All well sites will be inspected by the driller prior to the location of the rig to verify a stable surface exists. This is especially important in areas where soft, unstable terrain is common.

All rigs will be properly blocked and leveled prior to raising the derrick. Blocking provides a more stable drilling structure by evenly distributing the weight of the rig. Proper blocking ensures that differential settling of the rig does not occur.

When the ground surface is soft or otherwise unstable, wooden blocks, at least 24 inches by 24 inches and 4 inches to 8 inches thick shall be placed between the jack swivels and the ground. The emergency brake shall be engaged, and the wheels that are on the ground shall be chocked.

Hoisting Operations: Drillers should never engage the rotary clutch without watching the rotary table and ensuring it is clear of personnel and equipment.

Unless the draw-works is equipped with an automatic feed control, the brake should not be left unattended without first being tied down.

Auger strings or casing should be picked up slowly.

During instances of unusual loading of the derrick or mast, such as when making an unusually hard pull, only the driller should be on the rig floor, no one else should be on the rig or derrick.

The driller should test the brakes on the draw-works of the drill rig each day. The brakes should be thoroughly inspected by a competent individual each week.

A hoisting line with a load imposed should not be permitted to be in direct contact with any derrick member or stationary equipment, unless it has been specifically designed for line contact.

Workers should never stand near the borehole when any wire device is being run.

Hoisting control stations should be kept clean and controls labeled as to their functions.

Cat Line Operations: Only experienced workers will be allowed to operate the cathead controls. The kill switch must be clearly labeled and operational prior to operation of the cat line. The cathead area must be kept free of obstructions and entanglements.

The operator should not use more wraps than necessary to pick up the load. More than one layer of wrapping is not permitted.

Personnel should not stand near, step over, or go under a cable or cat line, which is under tension.

Personnel rigging loads on cat lines shall:

- i) Keep out from under the load
- ii) Keep fingers and feet where they will not be crushed
- iii) Be sure to signal clearly when the load is being picked
- iv) Use standard visual signals only and not depend on shouting to co-workers
- v) Make sure the load is properly rigged, since a sudden jerk in the cat line will shift or drop the load

Wire Rope: When two wires are broken or rust or corrosion is found adjacent to a socket or end fitting, the wire rope shall be removed from service or resocketed. Special attention shall be given to the inspection of end fittings on boom support, pendants, and guy ropes.

Wire rope removed from service due to defects shall be cut up or plainly marked as being unfit for further use as rigging.

Wire rope clips attached with u-bolts shall have the u-bolts on the dead or short end of the rope; the clip nuts shall be retightened immediately after initial load carrying use and at frequent intervals thereafter.

When a wedge socket fastening is used, the dead or short end of the wire rope shall have a clip attached to it or looped back and secured to it by a clip; the clip shall not be attached directly to the live end.

Protruding ends of strands in splices on slings and bridles shall be covered or blunted. Except for eye splices in the ends of wires and for endless wire rope slings, wire rope used in hoisting, lowering, or pulling loads, shall consist of one continuous piece without knot or splice.

An eye splice made in any wire rope shall have not less than five full tucks.

Knots shall not secure wire rope. Wire rope clips shall not be used to splice rope.

Eyes in wire rope bridles, slings, or bull wires shall not be formed by wire clips or knots.

Auger/Drill Pipe Handling: Auger/drill pipe sections shall be transported by cart or carried by two persons. Individuals should not carry auger/drill pipe sections without assistance.

Workers should not be permitted on top of the load during loading, unloading, or transferring of rolling stock.

When equipment is being hoisted, personnel should not stand where the bottom end of the equipment could whip and strike them.

Augers/drill pipe stored in racks, catwalks, or on flatbed trucks should be secured to prevent rolling.

7.9 FALL HAZARDS

Site personnel may be exposed to fall hazards greater than 6 feet above another surface and where there are no barriers in place to protect them. These hazards may be found next to each excavation and on top of any of the structures (buildings) that are on Site. Project personnel exposed to fall hazards greater than 6 feet will follow the selected contractor's Fall Protection Program.

The CSHO, CS and/or SS will control all fall hazards as they relate to project activities. It is their responsibility to implement the following components of the project's fall protection requirements as they relate to project activities:

- i) Ensure appropriate fall protection systems are utilized for project activities.
- ii) Verify that all project personnel are fully protected from fall hazards.
- iii) Ensure that necessary materials for proper fall protection (PPE including a harness and lanyard etc.) are available for project activities.
- iv) Provide for proper inspection and replacement of fall protection devices.
- v) Provide and ensure that all personnel have received the required training in the use, inspection, and the need for fall protection devices (proper fit, proper use, and proper inspection procedures). Note: This includes additional training required for the usage of ladders, scaffolds, and manlifts/aerial lifts.
- vi) Develop a written emergency rescue plan for retrieval of any worker who falls and is suspended in air while wearing personal fall arrest equipment.

Slip/Trip/Hit/Fall Injuries

Slip/trip/hit/fall injuries are the most frequent of all injuries to workers. They occur for a wide variety of reasons, but can be minimized by the following prudent practices:

- i) Spot check the work area to identify hazards
- ii) Establish and utilize a pathway which is free of slip and trip hazards
- iii) Beware of trip hazards such as slippery and uneven surfaces or terrain
- iv) Carry only loads which you can see over
- v) Keep work areas clean and free of clutter, especially walkways
- vi) Communicate hazards to project personnel

7.10 **NOISE**

Exposure to noise over the OSHA action level can cause temporary impairment of hearing; prolonged and repeated exposure can cause permanent damage to hearing. The risk and severity of hearing loss increases with the intensity and duration of exposure to noise. In addition to damaging hearing, noise can impair voice communication, thereby increasing the risk of accidents on Site. The selected contractor's Hearing Conservation Program will be implemented for affected project personnel.

Control: All personnel must wear hearing protection with a Noise Reduction Rating (NRR) of at least 20 when noise levels exceed 85 dBA. When it is difficult to hear a co-worker at normal conversation distance, the noise level is approaching or exceeding 85 dBA, and hearing protection is necessary. All Site personnel who may be exposed to noise must also receive baseline and annual audiograms and training as to the causes and prevention of hearing loss.

Whenever possible, equipment that does not generate excessive noise levels will be selected for this project. If the use of noisy equipment is unavoidable, barriers or increased distance will be used to minimize worker exposure to noise, if feasible.

7.11 ELECTRICAL HAZARDS

Electricity may pose a particular hazard to project personnel due to the use of portable electrical equipment. When electrical work is needed, a qualified electrician must perform it.

General electrical safety requirements include:

- i) All electrical wiring and equipment must be a type listed by Underwriters Laboratory (UL), Factory Mutual Engineering Corporation (FM), or other recognized testing or listing agency.
- ii) All installations must comply with the National Electrical Safety Code (NESC), the National Electrical Code (NEC), or United States Coast Guard regulations.
- iii) A multi-conductor cord having an identified grounding conductor and a multi-contact polarized plug-in receptacle must ground portable and semi-portable tools and equipment.
- iv) Tools protected by an approved system of double insulation, or its equivalent, need not be grounded. Double insulated tools must be distinctly marked and listed by UL or FM.
- v) Live parts of wiring or equipment must be guarded to prevent persons or objects from touching them.
- vi) Electric wire or flexible cord passing through work areas must be covered or elevated to protect it from damage by foot traffic, vehicles, sharp corners, projections, or pinching.
- vii) All circuits must be protected from overload.

- viii) Temporary power lines, switch boxes, receptacle boxes, metal cabinets, and enclosures around equipment must be marked to indicate the maximum operating voltage.
- ix) Plugs and receptacles must be kept out of water unless of an approved submersible construction.
- x) All extension outlets must be equipped with ground fault circuit interrupters (GFCIs).
- xi) Attachment plugs or other connectors must be equipped with a cord grip and be constructed to endure rough treatment.
- xii) Extension cords or cables must be inspected prior to each use, and replaced if worn or damaged. Cords and cables must not be fastened with staples, hung from nails, or suspended by bare wire.
- xiii) Flexible cords must be used only in continuous lengths without splice, with the exception of molded or vulcanized splices made by a qualified electrician.
- xiv) The OSHA requirements for electrical safety will be adhered to as minimum requirements to be followed by all Site personnel, including subcontractors. Electrical inspections are to occur during initial Site setup and monthly thereafter. These inspections are to be documented via either the CS's and/or the SS's logbook, the CSHO's logbook, or on specific forms that the selected contractor may have as part of their Electrical Safety Program.

7.12 MATERIAL HANDLING

Material handling operations to be conducted at the Site will include manual lifting of materials to and from trucks, placement of soil in stockpiles, placement and compaction of soil in excavations, and the setup/maintenance of thermal treatment units, soil handling equipment, soil storage areas, and storage enclosures.

Hoisting and Rigging

Wire ropes, chains, ropes, and other rigging equipment will be inspected prior to each use and as necessary during use to assure their safety. Defective rigging equipment will be immediately removed from service.

Rigging will not be used unless the weight of the load falls within the rigging's safe work operating range. The authorized rigger prior to any "pick" or lifting operation must verify this.

Only personnel trained in safe rigging procedures will be authorized to engage in rigging procedures. Additionally, the rigger must understand and use recognized crane signals.

Job or shop hooks and links and other makeshift fasteners **will not** be used. When U-bolts are used for eye splices, the U-bolt will be applied so the "U" section is in contact with the dead end of the rope.

Wire ropes, chains, ropes, and other rigging equipment will be stored where they will remain clean, dry, and protected from the weather and corrosive fumes.

The proper length of rope or chain slings will be used to avoid wide-angle lifts and dangerous slack. Knotted ropes or lengths of ropes reduced by bolts, knots, or other keepers will not be used.

General Storage Practices

The basic safety requirement for storage areas is that the storage of materials and supplies shall not create a hazard. Additional general storage area practices include the following:

- i) Bags, containers, bundles, etc. stored in tiers shall be stacked, blocked, interlocked, and limited in height so that they are stable and secure against sliding or collapse.
- ii) All stacked materials, cargo, etc. shall be examined for sharp edges, protrusions, signs of damage, or other factors likely to cause injury to persons handling these objects. Defects should be corrected as they are detected.
- iii) Storage areas shall be kept free from accumulation of materials that constitute hazards from tripping, fire, explosion, or pest harborage.
- iv) Storage areas shall have provisions to minimize manual lifting and carrying. Aisles and passageways shall provide for the movement of mechanical lifting and conveyance devices.
- v) Stored materials shall not block or obstruct access to emergency exits, fire extinguishers, alarm boxes, first aid equipment, lights, electrical control panels, or other control boxes.
- vi) "NO SMOKING" signs shall be conspicuously posted, as needed, in areas where combustible or flammable materials are stored and handled.
- vii) Cylindrical materials such as pipes and poles shall be stored in racks, or stacked on the ground and blocked.

Special Precautions for Hazardous or Incompatible Materials Storage

Generally, materials are considered hazardous if they are ignitable, corrosive, reactive, or toxic. Manufacturers and suppliers of these materials must provide the recipient with MSDSs, which describe their hazardous characteristics, and give instructions for their safe handling and storage.

Many hazardous materials are incompatible, which means they form mixtures that may have hazardous characteristics not described on the individual MSDSs. The following special precautions shall be followed regarding the storage of hazardous materials:

- i) Based on the information available on the MSDSs, incompatible materials shall be kept in separate storage areas
- ii) Warning signs shall be conspicuously posted, as needed, in areas where hazardous materials are stored

Hand Protection

Hand protection is the most important form of PPE when handling materials manually. The CSHO will select the appropriate hand protection for the task/activity. Gloves are often relied upon to prevent against abrasions, cuts and burns during material handling activities and many types of gloves actually improve your grip factor. Therefore, it is most important that the most appropriate glove (leather, cotton, Kevlar, metal mesh, nitrile, etc.) is selected for the given situation. The following table presents protection factors for commonly used gloves.

<i>Type of Glove</i>	<i>Protection</i>
Rubber	Acids, bases, alcohol – moderate resistance to cuts
Canvas or cloth	Dirt, wood splinters, sharp edges – some resistance to cuts
Metal mesh or Kevlar	Highly resistant to cuts and scratches and caught between hazards (crushing, etc.)
Insulated	Electrical charges
Cuffed	Protects against liquids trickling into glove and protects the wrist/forearm area from cuts and abrasions
Leather	Moderate resistance to cuts and abrasions and caught between hazards

It is important to wash hands frequently when wearing gloves to prevent the build-up of sweat and dirt on the hands. Check gloves regularly for cracks, holes and rips/tears. Keep gloves clean and dry as much as possible.

7.12.1 MANUAL LIFTING

When lifting objects, use the following proper lifting techniques:

- i) Feet must be parted, with one foot alongside the object being lifted and one foot behind. When the feet are comfortably spread, a more stable lift can occur and the rear foot is in a better position for the upward thrust of the lift.
- ii) Do not lift more than 50 pounds without the assistance of another individual.
- iii) Use the squat position and keep the back straight - but remember that straight does not mean vertical. A straight back keeps the spine, back muscles, and organs of the body in correct alignment. It minimizes the compression of the guts that can cause a hernia.
- iv) Grip is one of the most important elements of correct lifting. The fingers and the hand are extended around the object you're going to lift - using the full palm. Fingers have very little power - use the strength of your entire hand.
- v) The load must be drawn close, and the arms and elbows must be tucked into the side of the body. Holding the arms away from the body increases the strain on the arms and elbows. Keeping the arms tucked in helps keep the body weight centered.
- vi) The body must be positioned so that the weight of the body is centered over the feet. This provides a more powerful line of thrust and also ensures better balance. Start the lift with a thrust of the rear foot. Do not twist your back while lifting or moving heavy objects.

7.13 HAND AND POWER TOOLS

Hand Tools Requirements:

- i) Hand tools must meet the manufacturer's safety standards
- ii) Hand tools must not be altered in any way
- iii) At a minimum, eye protection must be used when working with hand tools
- iv) Wrenches (including adjustable, pipe, end, and socket wrenches) must not be used when jaws are sprung to the point that slippage occurs

- v) Impact tools (such as drift pins, wedges, and chisels) must be kept free of mushroom heads
- vi) Wooden handles must be free of splinters or cracks and secured tightly to the tool

Power Tools Requirements:

- i) All power tools must be inspected regularly and used in accordance with the manufacturer's instructions and the tool's capabilities
- ii) Electric tools must not be used in areas subject to fire or explosion hazards, unless they are approved for that purpose
- iii) Portable electric tools must be connected to a Ground Fault Circuit Interrupter (GFCI) when working in wet areas
- iv) Proper eye protection must be used when working with power tools
- v) Personnel must be trained in the proper use of each specific tool
- vi) Any damaged or defective power tools must be immediately tagged and removed from service

7.14 ADVERSE WEATHER CONDITIONS

The CSHO, CS and/or SS shall decide on the continuation or discontinuation of work based on current and pending weather conditions. Electrical storms, tornado warnings, and strong winds (approximately 40 mph) are examples of conditions that would call for the discontinuation of work and evacuation of the Site. Strong winds can generate hazardous conditions during the handling of materials.

In addition, no work with elevated super structures (e.g., drilling, crane operations, etc.) will be permitted during any type of electrical storm or during wind events that have wind speeds exceeding 25 mph.

7.15 BIOLOGICAL HAZARDS

Biological hazards may include snakes, thorny bushes, ticks, mosquitoes, and other pests.

7.15.1 VEGETATION OVERGROWTH

Overgrown weeds, bushes, trees, grass and other vegetation are fire and safety hazards. There are a number of hidden hazards not immediately recognized due to the overgrowth of vegetation in areas where field activities may occur, including discarded junk, litter, and debris. Construction materials such as boards, nails, concrete, and other debris may be hidden beneath blades of tall grass, weeds, and bushes. Other hazards may include steep slopes, potholes, trenches, soft spots, dips, etc.; all dangerously concealed from the view of the individual walking or operating motorized equipment in the area. Additionally, there are biological hazards such as snakes, ticks, chiggers, and mosquitoes that breed in overgrowth conditions.

Actions to be taken are:

- i) Assess the work area and determine if the area requires vegetation clearance. Consider that overgrowth that extends above the lowest level of motorized equipment (i.e., bumper or fender) or 6 inches above your ankle has hidden hazards that you will not be able to readily identify.
- ii) Determine if the area is safe to walk or whether you need motorized equipment. Consider the limitations of the equipment.
- iii) Identify slip, trip, and fall hazards and remove from the general work area. Remember to give adequate clearance so that the items being removed do not pose future hazards.
- iv) Adequately protect yourself against the hazards by wearing boots that protect the ankles, long pants, and using insecticides.
- v) Consider the limitations of manual or mechanical equipment for the clearance of overgrowth, particularly the safety hazards when using sling blades, machetes, weed eaters, bush hogs, or other brush removing equipment.

Before taking any action, determine whether there are any ecological issues that would affect or prevent the removal of overgrowth in protected areas such as wetlands, wildlife habitats, or sanctuaries for endangered and/or protected species.

7.15.2 TICK-BORNE DISEASES

Lyme Disease, Erlichiosis, and Rocky Mountain Spotted Fever (RMSF) are diseases transmitted by ticks and occur throughout the United States during spring, summer, and fall.

Lyme Disease: The disease commonly occurs in summer and is transmitted by the bite of infected ticks. "Hot spots" in the United States include New York, New Jersey, Pennsylvania, Massachusetts, Connecticut, Rhode Island Minnesota, and Wisconsin. Few cases have been identified in other states.

Erlichiosis: The disease also commonly occurs in summer and is transmitted by the bite of infected ticks. "Hot spots" in the United States include New York, Massachusetts, Connecticut, Rhode Island Minnesota, and Wisconsin. Few cases have been identified in other states.

Primarily the Deer Tick transmits these diseases, which is smaller and redder than the common Wood Tick. The disease may be transmitted by immature ticks, which are small and hard to see. The tick may be as small as a period on this page.

Symptoms of Lyme disease include a rash or a peculiar red spot, like a bull's eye, which expands outward in a circular manner. The victim may have headache, weakness, fever, a stiff neck, swelling and pain in the joints, and eventually, arthritis. Symptoms of Erlichiosis include muscle and joint aches, flu-like symptoms, but there is typically no skin rash.

Control: Tick repellent containing diethyltoluamide (DEET) should be used in tick-infested areas, and pants legs should be tucked into boots. In addition, workers should search the entire body every 3 or 4 hours for attached ticks. Ticks should be removed promptly and carefully without crushing, since crushing can squeeze the disease-causing organism into the skin. A gentle and steady pulling action should be used to avoid leaving the head or mouth parts in the skin. Hands should be protected with surgical gloves when removing ticks.

7.15.3 POISONOUS PLANTS

Common Poison Ivy (Rhus radicans) grows as a small plant, a vine, and a shrub. Poison Ivy occurs in every state. The leaves always consist of three glossy leaflets. Poison Sumac (Rhus vernix) grows as a woody shrub or small tree 5 to 25 feet tall. It usually contains nine leaves, with eight paired leaves and one on top, and is common in swampy areas. The plants are potent sensitizers and can cause a mild to severe allergic reaction. This reaction is called contact dermatitis.

Dermatitis, in Rhus-sensitive persons, can result from contact with the milky sap found in the roots, stems, leaves, and fruit. The sap may retain its potency for months or years in a dry atmosphere, and can occur during any time of the year. The sap may also be carried by animals, equipment or apparel.

The best form of prevention is to avoid contact. This can occur by wearing long sleeves and gloves if necessary. Disposable clothing, such as Tyvek, is recommended in high-risk areas to avoid exposure from contaminated apparel. Barrier creams and cleaners are also recommended.

7.15.4 INSECTS

Construction work presents many opportunities to be exposed to a variety of insects. Many these insects may present health and safety hazards. Wasps, bees, spiders, and mosquitoes present the bulk of these hazards.

Bees and wasps present problems to people working outdoors due to being stung and having adverse reactions to the venom injected during the sting. Mosquitoes on the other hand cause hazards by transmitting disease(s) from other infected animals and humans.

It is important to recognize the venomous spiders (spiders dangerous to humans) that are present in your work environment. Inspect boots, clothing, and other areas before using/entering, as spiders tend to hide in dark places. Many spiders are nocturnal.

Preventing Exposure

Preventing exposure to insects can be accomplished by the following:

- i) Wearing proper clothing and PPE
- ii) Inspecting work areas for wasp or bee nests prior to conducting work activities
- iii) Awareness of regional insects and their behavioral habits
- iv) Shaking out clothing and shoes and inspecting areas for spiders
- v) Using repellants

Proper Clothing

While working outdoors it is important to wear proper clothing and PPE. Insects tend to be attracted to bright colors, floral, prints, black, white, green, tan and khaki colors. Also it is important to wear long pants and if possible a long-sleeved shirt. Personnel should tuck the pant bottoms into the tops of boots and use insect proof work gloves (leather, thick cloth, etc.).

Repellants

It is important to ensure that there is an adequate supply of insect repellent. Use insect repellent, which contains DEET. Apply it to any exposed skin in accordance with the manufacturer's directions.

Reaction to insect bites can range from mild reactions to severe allergic reactions. In addition, mosquitoes may carry life-threatening diseases such as West Nile virus.

Bee (and Wasp) Stings

Reaction to bee stings may range from painful swelling, redness, itching all the way to shock. Swelling, redness, and itching should stop hurting within a day or two. Treatment for these items can be done at home. The treatment will involve initially removing any stinger left in the skin by scraping away from the skin and towards the venom sac (thus preventing one from squeezing more venom into the wound). Afterwards apply ice and anti-histamine cream. If irritation, swelling and/or pain persist seek medical attention.

If the victim of a bee sting is aware that they are allergic to bees, or if they begin to exhibit signs such as difficulty swallowing, difficulty breathing, abdominal cramps, nausea, and then they may be going into anaphylactic shock and will require medical treatment.

If personnel know that they are allergic to insects then they will be required to carry their own insect sting kit as directed by their personal physician. The victim must be taken to hospital immediately.

Mosquito Bites

Mosquito bites can range from mild skin irritation to severe viral infections. One of the most common viruses that mosquitoes carry is the West Nile virus. West Nile virus can cause encephalitis (swelling of the brain) and meningitis (swelling of the spinal cord).

First symptoms are as follows: rapid onset of headaches, dizziness, difficulty swallowing, and deep muscle aches, nausea, stiff neck, high-fever, high fever, confusion, muscle weakness. Once any of these symptoms are exhibited seek medical attention.

7.15.5 POISONOUS SPIDERS

Spider Bites

Spider bites can range from mild skin irritation to severe infections and tissue damage depending on the type of spider. The United States has only two spiders that are considered dangerous to humans (the black widow and the brown recluse).

A brown recluse spider (or fiddleback) possesses a V-shaped marking on its back. Its bite will cause tissue damage/destruction for up to 6 weeks. Symptoms can start with little initial pain followed by severe pain, headaches, fever, skin rash, muscle spasms, renal failure and possible coma. A halo may form around the bite. Medical treatment is to be sought immediately.

A black widow spider is an outdoor, nocturnal and non-aggressive spider. She's shiny, black with an hourglass shape on her abdomen. Only about 1 percent of her bites are fatal. The bite is not painful and may not be noticed until later when stomach, muscular, or feet pains begin. Other symptoms include heavy sweating, swollen eyelids, erratic saliva production, and difficulty breathing. Seek medical treatment if bitten.

7.15.6 THREATENING DOGS

If you are approached by a frightened or menacing dog:

- i) Do not attempt to run and don't turn your back.
- ii) Stay quiet, and remember to breathe.
- iii) Be still, with arms at sides or folded over chest with hands in fists.
- iv) Slowly walk away sideways.

- v) Don't stare a dog in the eyes, as this will be interpreted as a threat.
- vi) Avoid eye contact.
- vii) If you have a jacket, you could wrap it around your arm and should he snap, take the bite harmlessly.
- viii) Try calling its bluff. Yell, "sit!" "stay!" or "go home!". You might convince the dog that you are the stronger in the situation.

7.15.7 RODENTS

Rodentia: (rats, mice, beavers, squirrels, guinea pigs, capybaras, coypu)

Rodents, or Rodentia, are the most abundant order of mammals. There are hundreds of species of rats; the most common being the black and brown rat.

The **Brown Rat** has small ears, blunt nose, and short hair. It is approximately 14 to 18 inches long (with tail). They frequently infest garbage/rubbish, slaughterhouses, domestic dwellings, warehouses, shops, super-markets, in fact, anywhere there is an easy meal and potential nesting sites.

The **Black Rat** can be identified by its' tail, which is always longer than the combined length of the head and body. It is also slimmer and more agile than the Norwegian or Brown rat. Its size varies according to its environment and food supply.

The **House Mouse** has the amazing ability to adapt and it now occurs more or less in human dwellings. In buildings, mice will live anywhere and they are very difficult to keep out. Mice are also totally omnivorous; in other words, they will eat anything.

Rats and mice often become a serious problem in cold winter months when they seek food and warmth inside buildings. They may suddenly appear in large numbers when excavation work disturbs their in-ground nesting locations or their food source is changed.

There are six major problems caused by rats and mice:

- i) They eat food and contaminate it with urine and excrement.
- ii) They gnaw into materials such as paper, books, wood, or upholstery, which they use as nest material. They also gnaw plastic, cinder blocks, soft metals such as lead and aluminum, and wiring, which may cause a fire hazard.

- iii) Rats occasionally bite people and may kill small animals.
- iv) They, or the parasites they carry (such as fleas, mites, and worms), spread many diseases such as salmonella, trichinosis, rat bite fever, Hantavirus, Weils disease, and the bubonic plague.
- v) Rats can damage ornamental plants by burrowing among the roots or feeding on new growth or twigs. They also eat some garden vegetables, such as corn and squash.
- vi) Rats and mice are socially unacceptable. These rodents have been a problem for centuries, chiefly because they have an incredible ability to survive and are so difficult to eliminate. In addition, they are extremely compatible with human behavior and needs.

The CHSO will determine what actions to take should rodents become an issue.

8.0 AIR MONITORING PROGRAM

This section of the HASP presents the requirements for conducting air monitoring at the Site. The air-monitoring program is designed to ensure protection for personnel working on Site as well as the surrounding community. The on-Site monitoring program will be conducted by the CSHO or designee (i.e., Environmental Monitoring Technician) and will consist of monitoring project personnel exposures to VOCs and dust/particulate matter. A Community Air Monitoring Plan will also be conducted at the Site and is presented in Appendix C. The air monitoring program will be completed with the use of real-time direct reading instruments.

Inhalation hazards are caused from the intake of vapors and contaminated dust. Air monitoring shall be performed when potential exposure to on-Site contaminants is anticipated and during all confined space entry work. The purpose of air monitoring is to identify and quantify airborne contaminants in order to determine the level of worker protection needed. Initial screening for identification is often qualitative, but the determination of its concentration (quantification) must wait subsequent testing. The principle approaches available for identifying and/or quantifying airborne contaminants:

- i) The use of real-time (on-Site) reading instruments (i.e., photoionization detector etc.)

Direct reading instruments may be used to rapidly detect certain gases and vapors, and dusts. They are the primary tools of initial Site characterization and remediation. The information provided by direct reading instruments can be used to institute appropriate measures (i.e., PPE, evacuation), and determine the most appropriate equipment for future monitoring. All direct reading instruments have inherent constraints in their ability to detect hazards. It is imperative that direct reading instruments are operated, and the data interpreted by qualified individuals who are thoroughly familiar with the particular devices, operating principles and limitations. At hazardous waste sites, where unknown and multiple contaminants are the rule rather than the exception, instrument readings should be interpreted conservatively. The following guidelines may facilitate accurate recording and interpretation:

- i) Calibrate instruments according to the manufacturer's instructions before and after each use.
- ii) Develop chemical response curves if the instrument manufacturer does not provide these. Response curves/response factors are necessary to adapt PID

action levels to actual PID readings when a specific contaminant of concern is detected via air sampling.

- iii) Remember that the instrument readings have limited value where contaminants are unknown. When reading unknown contaminants, report them as "needle deflection", or "positive instruments response", or "units", rather than a specific concentration (i.e., ppm). Conduct additional monitoring at any location where a positive response occurs.
- iv) A reading of zero should be reported as "no instrument response" rather than "clean" because quantities of the chemicals may be present that is not detectable by the instrument.
- v) The survey should be repeated with several detection systems to maximize the number of chemicals detected.

The data collected throughout the monitoring effort shall be used to determine the appropriate levels of protection.

8.1 SITE AIR MONITORING

The CSHO or designee (i.e., Environmental Monitoring Technician) will perform air monitoring to evaluate the exposure of project personnel to chemical and physical hazards, verify the effectiveness of engineering controls, evaluate the effectiveness of Site control measures, and to determine the proper level of PPE. During the progress of remedial activities, the CSHO will monitor the levels of VOCs, and particulate levels on an hourly basis or more frequently as necessary based on Site conditions. The following monitoring equipment will be used for this purpose:

- i) A PID equipped with an 10.6 or greater eV lamp
- ii) A particulate monitor

An EZ perimeter air monitoring program will be implemented. PID and particulate monitoring will be conducted on an hourly basis or more frequently as necessary at the perimeter of the EZ in order to evaluate the effectiveness of Site control measures and verifies the integrity of the Site's clean areas. If necessary, the CSHO in conjunction with the SS will adjust the EZ and CRZ boundaries.

In the event that an EZ perimeter air monitor reading identifies levels that are above background conditions, then air monitoring readings will also be taken at the Site perimeter. The CSHO will evaluate all air monitor readings and modify operating

conditions on the Site as necessary to ensure all potentially exposed receptors are within safe limits.

All instruments will be calibrated on a daily basis in accordance with the manufacturer's instructions. Records of all calibrations and real-time measurements will be kept in a bound field logbook or documented via air monitoring and calibration log sheets. All air monitoring data collected by CSHO will be filed and made available upon request.

8.1.1 REAL-TIME VOC MONITORING

The CSHO or designee will continuously monitor for the presence of VOCs during the handling of impacted soil, intrusive activities, and operation of the soil treatment system. PID readings will be taken in and around all EZs. Action levels for upgrading or downgrading of PPE have been established and Table 8.1 presents the action levels for the on-Site Air Monitoring Program.

An action level is a point at which increased protection or cessation of activities is required due to the concentration of contaminants in the work area. Most activities shall be initiated in Modified Level D. The appropriate actions will be taken at designated action levels.

In addition to the action levels, an upgrade to Level C, supplied air, or evacuation of the immediate area is required if:

- i) Any symptoms occur, as described in Section 7.2
- ii) Sustained readings (15 minutes or greater) occur in the worker's breathing zone that are above the applicable action levels
- iii) Requested by an individual performing the task
- iv) Any irritation to eye, nose, throat, or skin occurs

8.1.2 PARTICULATE MONITORING

Based upon the results of an industrial hygiene air monitoring modeling program, the mixture PEL total dust levels have been calculated using "worst case" scenario concentrations for the principal contaminants identified in the Site soil. The particulate action levels are located in Table 8.1. Dust control measures (water spray, etc.) should

be implemented at the Site to control visible dust emissions. All readings should be taken in the worker's breathing zone.

8.1.3 PERSONAL AIR SAMPLING PROGRAM

The selected contractor shall also implement a personnel air sampling program for those project personnel who have the highest risk of potential for exposure to chemicals present on Site. This monitoring will be done in compliance with 1926.65(h). Samples will be collected during startup of those project activities where personnel face potential exposure. The CSHO and PM will determine what chemicals will be sampled and the number and frequency of sampling events. Appropriate National Institute of Occupational Safety and Health (NIOSH) methodology will be followed and all samples will be sent to an American Industrial Hygiene Association (AIHA) accredited laboratory. Results for all personnel air sampling will be posted for all project personnel to review. The requirements of this paragraph will be met when soil removal activities are taking place.

9.0 DECONTAMINATION PROCEDURES

In general, everything that enters the EZ at this Site must either be decontaminated or properly discarded upon exit from the EZ. All personnel, including any State and local officials must enter and exit the EZ through the CRZ. Prior to demobilization, potentially contaminated equipment will be decontaminated on a wash pad (decontamination pad) which has a built in sump and the equipment will be inspected by the CSHO before it is moved into the clean zone. A decontamination facility complete with water supply and sump for collection of wash water will be constructed at the Site. Any material that is generated by decontamination procedures will be collected and stored in a designated area in the EZ until disposal arrangements are made.

The type of decontamination solution to be used is dependent on the type of chemical hazards. The decontamination solution for heavy equipment and for any reusable PPE is Alconox/Liqui-nox soap. The MSDSs for Liqui-nox and any other chemical containing products brought to the Site will be maintained on Site by the CSHO.

9.1 EQUIPMENT DECONTAMINATION PROCEDURES

All equipment that comes in contact with waste material must be decontaminated within the CRZ by high-pressure water cleaner upon exit from the EZ. Decontamination procedures will include knocking soil/mud from machines; water brush scrubbing using a solution of water and Liqui-nox; and a final water rinse. Personnel shall wear Level C or Modified Level D protection, as determined by the CSHO, when decontaminating equipment. All decontamination wash water and residues will be carefully collected and disposed of in accordance with the appropriate environmental regulations. Following decontamination and prior to exiting from the EZ, the CSHO shall be responsible for ensuring that the item has been sufficiently decontaminated. This inspection shall be included in the Site log.

9.2 PERSONNEL DECONTAMINATION PROCEDURES

Procedures for decontamination must be followed to prevent the spread of contamination and to eliminate the potential for chemical exposure. Personnel decontamination will be completed in accordance with the procedures that are presented below. Potentially contaminated PPE and trash will be stored in covered and

labeled containers until disposal arrangements are made. It will be kept separate from trash generated in clean areas of the Site.

All disposable equipment shall be doffed before meal breaks and at the conclusion of the workday and replaced with new equipment prior to commencing work. Spent PPE will be kept in covered containers.

Personnel - Decontamination will take place upon exiting the contaminated work area in the CRZ.

Modified Level D decontamination procedures are as follows:

- Step 1:** Remove all visible contamination and loose debris by washing with clean water
- Step 2:** Remove all outer clothing that came in contact with the contamination (i.e., boot covers and outer gloves) and either dispose of in disposable container or wash in detergent solution and rinse
- Step 3:** Remove protective clothing; dispose of in used PPE storage container
- Step 4:** Remove inner gloves, dispose of in used PPE storage container
- Step 5:** Wash and rinse hands

Level C decontamination procedures to be utilized as follows:

- Step 1:** Remove all visible contamination and loose debris by washing with clean water
- Step 2:** Remove all outer clothing that came in contact with the contamination (i.e., boot covers and outer gloves) and either dispose of in used PPE container or wash in detergent solution and rinse
- Step 3:** Remove protective clothing; dispose of in used PPE container
- Step 4:** Remove respirator, sanitize prior to reuse
- Step 5:** Remove inner gloves; dispose of in used PPE container
- Step 6:** Wash and rinse hands with soap and water

10.0 MEDICAL SURVEILLANCE

In accordance with the requirements detailed in 29 CFR 1926.65 and 29 CFR 1910.134, all project personnel who will come in contact with potentially contaminated materials will have received medical surveillance by a licensed physician or physician's group.

Medical records for all project personnel will be maintained by their respective employers. The medical records will detail the tests that were taken and will include a copy of the consulting physician's statement regarding the tests and the individual's suitability for work as per the employer's medical surveillance program which is to be in accordance with 29 CFR 1926.65.

The medical records will be available to the employee or his designated representative upon written request, as outlined in 29 CFR 1910.1020.

If it becomes necessary to use subcontractors, they will also provide certifications to the CSHO showing that their personnel involved in Site activities have all necessary medical examinations prior to commencing work. The certifications will show proof of medical surveillance and respiratory fit testing. Personnel not obtaining medical certification will not perform work within contaminated areas.

Interim medical surveillance will be completed if an individual exhibits poor health or high stress responses due to any project activity or when accidental exposure to elevated concentrations of contaminants occur.

11.0 EMERGENCY RESPONSE AND CONTINGENCY PROCEDURES

It is essential that project personnel be prepared in the event of an emergency. Emergencies can take many forms; illnesses or injuries, chemical exposure, fires, explosions, spills, leaks, releases of harmful contaminants, or sudden changes in the weather. The following sections outline the general procedures for emergencies.

Emergency information should be posted as appropriate. Radios will be provided for contact purposes. All emergencies will be reported to the appropriate emergency responders. They may give the selected contractor further direction as to the responsibilities during any emergency situation. In general, project personnel will shut down equipment and evacuate to a safe pre-determined meeting area (rally point) during Site emergencies.

The CSHO will contact and meet on Site with local emergency response agencies (e.g., fire department, police department, etc.) prior to initiating construction activities. The purpose of this meeting is to inform these local authorities of the nature of the work and potential risks, to ensure that these responders are equipped to respond to a Site emergency, and to identify and resolve any potential problems, concerns, or conflicts.

The CSHO will be informed of Site hazards and activities prior to project initiation so those emergency situations can be handled most efficiently. A general orientation meeting to discuss emergency response procedures is to be held prior to initiating project activities.

In case of an emergency, an evacuation alarm would sound, which means that all the personnel should evacuate the area and proceed to a rally point for further instruction.

The CSHO will notify all project personnel of the emergency through radio/cell phone communications. Radios and cell phones will be taken to the rally point to enable further receipt of instruction(s) from the CSHO.

11.1 ACCIDENT, INJURY AND ILLNESS REPORTING

Any work-related incident, accident, injury, illness, exposure, or property loss shall be immediately reported to the CSHO and the SS. The SS and/or CSHO will report the accident details to the CSHM and will submit a completed accident report form. A sample Incident Reporting Form is provided in Appendix B. The selected contractor

may use their own company-specific form if they so choose. The report must be filed for the following circumstances:

- i) Accident, injury, illness, or exposure to project personnel
- ii) Injury to any subcontractor personnel
- iii) Damage, loss, or theft of property
- iv) Any motor vehicle accident regardless of fault, which involves a company vehicle, rental vehicle, or personal vehicle while the individual is acting in the course of employment for the Site

The CSHO and CPM will investigate occupational accidents resulting in employee injury or illness. This investigation will focus on determining the cause of the accident and modifying future work activities to eliminate the hazard.

All project personnel have the obligation and right to report unsafe work conditions, previously unrecognized safety hazards, or safety violations of others. If anyone wish to make such a report, it may be made orally to the CSHO, a supervisor, or other member of management, or it may be submitted in writing, either signed or anonymously.

11.2 EMERGENCY CONTACTS

Fire Department	911
Police Department	911
Ambulance	911
Hospital: Samaritan Hospital.....	(518) 271-3300

See Figure 11.1 - Hospital Route Map Directions to the Hospital.

Communication between work areas and the command post, located within the CZ, will be via verbal communication, auto horn, or two-way radio. The CSHO will use a mobile telephone to communicate with outside emergency and medical facilities.

The following signals shall be established for use with auto or compressed air-type horns:

- i) Three Blasts: Evacuate exclusion area and meet at the northwest corner of the intersection of 47th Street and Royal Avenue
- ii) An "All Clear" will be conveyed by radio communication

11.3 ADDITIONAL EMERGENCY NUMBERS

National Response Center (NRC)	800-424-8802
Poison Information	800-764-7661
Utility Locating Commission (One Call Nationwide)	811
Agency for Toxic Substances and Disease Registry	404-488-4100 (24 Hours)
U.S. EPA Emergency Response.....	800-424-8802
State of New York Emergency Response Commission	513-457-9996
Project Manager-Jamie Puskas	519-830-3254
Contractor Project Manager	TO BE DETERMINED
Contractor Corporate Safety and Health Manager	TO BE DETERMINED
Contractor Site Superintendent	TO BE DETERMINED
Contractor Safety and Health Officer.....	TO BE DETERMINED

11.4 EMERGENCY AND FIRST AID EQUIPMENT

Emergency safety equipment will be available for use by project personnel and will be located and maintained on Site. The safety equipment will include, but is not limited to, the following:

- i) Portable emergency eye wash and drench shower (pressurized)
- ii) Two 20-pound ABC type dry chemical fire extinguishers
- iii) Field eye wash/flush bottles
- iv) Approved first-aid kit for a minimum of twenty personnel
- v) Fire blanket

- vi) Spill response kit containing absorbent materials (booms/socks, pads, and earth/clay), overpack drum, shop vacuum, and hand tools (shovel, rake/hoe, etc.)
- vii) Two Self Contained Breathing Apparatus (SCBA) units; and
- viii) Portable air horn

11.5 PROJECT PERSONNEL RESPONSIBILITIES DURING EMERGENCIES

Contractor Safety and Health Officer (CSHO)

As the administrator of the HASP, the CSHO has primary responsibility for responding to and correcting emergency situations. The CSHO will:

- i) Take appropriate measures to protect personnel including: posting of acceptable Site evacuation routes, withdrawal from the EZ, total evacuation and securing of the Site or upgrading or downgrading the level of protective clothing and respiratory protection.
- ii) Take appropriate measures to protect the public and the environment including isolating and securing the Site, preventing runoff to surface waters, and ending or controlling the emergency to the extent possible.
- iii) Ensure that appropriate Federal, State, and local agencies are informed, and emergency response plans are coordinated. In the event of fire or explosion, the local fire department should be summoned immediately. In the event of an air release of toxic materials, the local authorities should be informed in order to assess the need for evacuation. In the event of a spill, sanitary districts and drinking water systems may need to be alerted.
- iv) Ensure that appropriate decontamination treatment or testing for exposed or injured personnel is obtained.
- v) Determine the cause of the incident and make recommendations to prevent the reoccurrence.
- vi) Ensure that all required reports have been prepared.

11.6 MEDICAL EMERGENCIES

Any person who becomes ill or injured in the EZ must be decontaminated to the maximum extent possible. If the injury or illness is minor, full decontamination should be completed and first aid administered prior to transport. If the patient's condition is serious, at least partial decontamination should be completed as much as possible without causing further harm to the patient. First aid should be administered while awaiting an ambulance or paramedics. All injuries and illnesses must immediately be reported to the CSHO, SS, and CPM.

Any person transporting an injured/exposed person to a clinic or hospital for treatment should take with them directions to the hospital and a copy of the identified chemicals on Site to which they may have been exposed.

Any vehicle used to transport contaminated personnel, will be cleaned or decontaminated as necessary.

11.7 FIRE OR EXPLOSION

In the event of a fire or explosion, the local fire department should be summoned immediately. Upon their arrival, the CSHO or designated alternate will advise the fire commander of the location, nature, and identification of the hazardous materials on Site.

If it is safe to do so, Site personnel should:

- i) Report to the CPM
- ii) Use firefighting equipment available on Site
- iii) Remove or isolate flammable or other hazardous materials, which may contribute to the fire

11.8 SPILL CONTROL AND COUNTERMEASURES

If a spill has occurred, the first step is personal safety, then controlling the spread of contamination if possible. Contractor personnel will immediately contact the CPM and/or CSHO to inform them of the spill and activate emergency spill procedures.

General Spill Response Procedures

If a spill occurs, the following general procedures will be followed:

- i) Notify the CSHO, SS, and CPM
- ii) Evacuate immediate area of spill
- iii) Determine the needed level of PPE
- iv) Don required levels of PPE and prepare to make entry to apply spill containment and control procedures
- v) No entry will be made until atmosphere is less than 20 percent of the LEL
- vi) After obtaining the proper spill response tools (shovels, booms and pads, absorbent socks, etc.) and PPE, personnel will attempt to contain the spill so that it does not enter any conveyance (sewer, drainage ditch, etc.) that eventually discharges to surface water
- vii) Locate and abate source of spill
- viii) Absorb or otherwise clean up the spill and containerize the material, sorbent, and affected soils
- ix) Clean and decontaminate the affected area(s)
- x) Replace used/spent spill kit contents


All spill material and debris will be managed in a manner that complies with applicable federal, state, and local environmental rules regarding recycling or disposal of wastes.

The CSHO and SS have the authority to commit resources as needed to contain and control released material and to prevent its spread to off-Site areas.


12.0 RECORDKEEPING

The CSHO shall establish and maintain records of all necessary and prudent monitoring activities as described below:

- i) Name and job classification of the employees involved on specific tasks
- ii) Records of fit testing and medical surveillance results for project personnel
- iii) Records of all OSHA and other applicable safety training certifications for project personnel
- iv) Records of Site safety inspections
- v) Records of training acknowledgment forms and daily safety meetings
- vi) Emergency report sheets describing any incidents or accidents
- vii) Air monitoring equipment calibrations
- viii) Air monitoring data



USGS QUADRANGLE MAP
NORTH TROY, NEW YORK



HOSPITAL DRIVING DIRECTIONS

1. Head south on NY-32 S / RTE32 S / State 32 S / State Route 32 S / Saratoga Ave toward Hill St.
2. Turn left onto NY-787 S
3. Continue onto I-787 S / NY-787 S
4. Take exit 9E to merge onto NY-7 E toward Troy / Bennington
5. Continue onto I-787 / NY-7 E
6. Slight left onto Hoosick St. (signs for New York 7 E)
7. Turn right onto Burdett Ave.

figure 11.1

**HOSPITAL ROUTE
HEALTH & SAFETY PLAN
FRIEDRICHSOHN COOPERAGE SITE
153-155 Saratoga Ave., Waterford, N.Y.**

TABLE 2.1

PROPERTIES OF POTENTIAL SITE CONTAMINANTS

Chemical Name (Synonyms)	Concentration at Site	Exposure Limits	Routes Of Entry	Symptoms/Health Effects	Chemical Properties	Physical Characteristics
cis-1,2-Dichloroethene Acetylene dichloride 1,2-Dichloroethylene CAS-540-59-0	0-250 ppb	TLV: 200 ppm PEL: 200 ppm STEL: NE IDLH: 1000 ppm	Inhalation Ingestion Skin contact Eye contact	ACUTE: Irritation of the eyes and respiratory tract. CNS depression. Exposure could cause lowering of consciousness. CHRONIC: Defatting of the skin. May cause damage to liver.	(FP) 36-39°F (VP) 180-265 mm (IP) 9.65 eV (UEL) 12.8% (LEL) 5.6%	Colorless liquid (usually a mixture of the cis and trans isomers) with a slightly acrid, chloroform-like odor.
Arsenic CAS-7440-38-2	0-168 ppb	TLV: 0.01 mg/m ³ PEL: 0.010 mg/m ³ STEL: NE IDLH: 5 mg/m ³ (as As)	Inhalation Absorption Ingestion	ACUTE: Contact dermatitis, gastrointestinal disturbances, ulceration of the nasal septum, and respiratory irritation. CHRONIC: Hyperpigmentation of the skin and cancers of the skin, lungs, and lymphatic system.	(FP) NA (VP) 0 mm (approx.) (IP) NA (UEL) NA (LEL) NA	Silver-gray or tin-white, brittle, odorless, solid.
Barium and soluble compounds as BA (excluding barium sulfate) CAS-7440-39-3	6.08-1,860 ppb	TLV: 0.5 mg/m ³ PEL: 0.5 mg/m ³ STEL: NE IDLH: 50 mg/m ³	Inhalation Ingestion Skin/eye contact	ACUTE: Irritation to the eyes, skin, upper respiratory system; skin burns CHRONIC: Gastroenteritis; muscle spasms; slow pulse; extrasystoles; hypokalemia (low blood potassium)	(FP) NE (VP) 0 mm (IP) NE (UEL) NE (LEL) NE	Yellow-white, slightly lustrous solid.
Benzene Benzol CAS-71-43-2	0-190 ppb	TLV: 0.5 ppm [skin] PEL: 1 ppm STEL: 2.5 ppm IDLH: 500 ppm	Inhalation Absorption (skin) Ingestion	ACUTE: Irritation to eyes, skin, respiratory tract; dizziness; headache; nausea; staggered gait; fatigue, abdominal pain. CHRONIC: Defatting of the skin, may have effects on bone marrow and immune system, decrease in blood cells. Carcinogenic to humans.	(FP) 12°F (VP) 75 mm (IP) 9.24 eV (UEL) 7.8% (LEL) 1.2%	Colorless to light-yellow liquid with an aromatic odor. Solid below 42°F.

Notes:

FP	FP - Flash Point	PEL	PEL - OSHA Permissible Exposure Limit
IDLH	IDLH - Immediately Dangerous to Life and Health	STEL	STEL - Short Term Exposure Limit
IP	IP - Ionization Potential	TLV	TLV - ACGIH Threshold Limit Value
NE	NE - Not Established (Information Not Available)	VP	VP - Vapor Pressure
NA	NA - Not Applicable	C	C - Ceiling Exposure Limit
CNS	CNS - Central Nervous System	[skin]	[skin] - potential for dermal absorption
PNS	PNS - Peripheral Nervous System	mm	mm - millimeters Hg (mercury)
ppm	ppm - parts per million	eV	eV - electronvolts
mg/m ³	mg/m ³ - milligrams per cubic meter		

TABLE 2.1

PROPERTIES OF POTENTIAL SITE CONTAMINANTS

Chemical Name (Synonyms)	Concentration at Site	Exposure Limits	Routes Of Entry	Symptoms/Health Effects	Chemical Properties	Physical Characteristics
Cadmium (dust/ metal) CAS-7440-43-9	-	TLV: 0.01 mg/m3 PEL: 0.005 mg/m3 STEL: NE IDLH: 9 mg/m3	Inhalation Ingestion	ACUTE: Irritation to eyes and respiratory tract. Pulmonary edema, coughing, tightness in chest, headache, chills, muscle aches, nausea, mild anemia. CHRONIC: Damage to respiratory system and kidneys, resulting in proteinuria and kidney dysfunction. Potential occupational carcinogen	(FP) NA (VP) NA (IP) NA (UEL) NA (LEL) NA	Metal: silver-white, blue tinged, lustrous, odorless solid.
Chlorobenzene Benzene chloride Chlorobenzol Phenyl chloride CAS-108-90-7	0-30 ppb	TLV: 10 ppm PEL: 75 ppm STEL: NE IDLH: 1,000 ppm	Inhalation Ingestion Skin contact Eye contact	ACUTE: Irritation of the eyes, nose and skin; causes drowsiness and uncoordination. Chemical pneumonitis if swallowed. CNS depression CHRONIC: Defatting of the skin. May cause liver and kidney damage.	(FP) 82°F (VP) 9 mm (IP) 9.07 eV (UEL) 9.6% (LEL) 1.3%	Colorless liquid with an almond-like odor.
Chromium (metal) Chrome CAS-7440-47-3	0-197 ppb	TLV: 0.5 mg/m3 PEL: 1 mg/m3 STEL: NE IDLH: 250 mg/m3	Inhalation Ingestion Skin contact Eye contact	ACUTE: Irritation to eyes, skin and lungs. CHRONIC: Skin sensitization, fibrosis (histologic)	(FP) NA (VP) NA (IP) NA (UEL) NA (LEL) NA	Blue-white to steel gray, lustrous, brittle, hard, odorless solid.
DDT p,p-DDT Dichlorodiphenyltrichloroethane 1,1,1-Trichloro-2,2-bis(p-chlorophenyl)ethane CAS-50-29-3	-	TLV: 1 mg/m3 PEL: 1 mg/m3 [skin] STEL: NE IDLH: 500 mg/m3 (ca)	Inhalation Ingestion Skin contact Absorption Eye contact	ACUTE: Inhalation - Nausea, drowsiness, loss of appetite, visual disturbances, and insomnia. Skin - See ingestion. Ingestion - Headaches, nausea, insomnia, profuse sweating, frothing at the mouth, convulsions, and lack of consciousness. CHRONIC: Dizziness, nausea, muscle twitch, convulsions, enlarged liver, and skin irritation. Suspected carcinogen.	(FP) 162-171°F (VP) 0.00000002 mm (IP) NI (UEL) NI (LEL) NI	White to yellow crystalline powder with a slight musty aromatic odor, (pesticide).

Notes:

FP	FP - Flash Point	PEL	PEL - OSHA Permissible Exposure Limit
IDLH	IDLH - Immediately Dangerous to Life and Health	STEL	STEL - Short Term Exposure Limit
IP	IP - Ionization Potential	TLV	TLV - ACGIH Threshold Limit Value
NE	NE - Not Established (Information Not Available)	VP	VP - Vapor Pressure
NA	NA - Not Applicable	C	C - Ceiling Exposure Limit
CNS	CNS - Central Nervous System	[skin]	[skin] - potential for dermal absorption
PNS	PNS - Peripheral Nervous System	mm	mm - millimeters Hg (mercury)
ppm	ppm - parts per million	eV	eV - electronvolts
mg/m3	mg/m3 - milligrams per cubic meter		

TABLE 2.1

PROPERTIES OF POTENTIAL SITE CONTAMINANTS

Chemical Name (Synonyms)	Concentration at Site	Exposure Limits	Routes Of Entry	Symptoms/Health Effects	Chemical Properties	Physical Characteristics
Styrene Vinyl Benzene Ethenyl Benzene CAS-100-42-5	0-650 ppb	TLV: 20 ppm PEL: 100 ppm C 200 ppm STEL: 40 ppm IDLH: 700 ppm	Inhalation Skin Contact Eye Contact Ingestion	ACUTE: The substance irritates the eyes, the skin and the respiratory tract. Swallowing the liquid may cause aspiration into the lungs with the risk of chemical pneumonitis. Exposure could cause lowering of consciousness. CHRONIC: Repeated or prolonged contact skin with skin may cause dermatitis. Repeated or prolonged contact may cause skin sensitization. Repeated or prolonged inhalation exposure may cause asthma. The substance may have effects on the central nervous system,. This substance is possibly carcinogenic to humans.	(FP) 88°F (VP) 5 mm (IP) 8.40 eV (UEL) 6.8% (LEL) 0.9%	Colorless to yellow, oily liquid with a sweet floral odor.
Hexachlorobenzene HCB Perchlorobenzene Phenyl perchloryl CAS-118-74-1	0-9.3 ppb	TLV: 0.002 mg/m ³ [skin] PEL: NE STEL: NE IDLH: NE	Inhalation Ingestion Skin contact Absorption Eye contact	ACUTE: Inhalation - Coughing, shortness of breath. Skin - May cause slight irritation and burns may occur at higher doses. Eyes - May cause irritation of the eyes and blurred vision. Ingestion - Headache, dizziness, nausea, vomiting, numbness of hands and arms, apprehension, excitement, tremors, partial paralysis of arms and legs, loss of muscle control, loss of sensory perception, convulsions and coma may result from high doses. CHRONIC: May affect liver and CNS, resulting in impaired organ functions and skin lesions. Possible human carcinogen.	(FP) 468 °F (VP) NE (IP) NE (UEL) NE (LEL) NE	Colorless to white solid in various forms.
Lead (metal) CAS-7439-92-1	0-321 ppb	TLV: 0.05 mg/m ³ PEL: 0.05 mg/m ³ STEL: NE IDLH: 100 mg/m ³	Inhalation Ingestion Skin contact Eye contact	ACUTE: Lead is a cumulative poison, however, it may cause eye and skin irritation. CHRONIC: Effects blood, bone marrow, CNS, PNS and kidneys resulting in anemia, convulsions, peripheral nerve disease and kidney impairment. Toxicity to human reproduction or development.	(FP) NA (VP) NA (IP) NA (UEL) NA (LEL) NA	A heavy, ductile, soft, gray solid. Turns tarnished on exposure to air.
Mercury (metal) Quicksilver Liquid silver CAS-7439-97-6	0-1.03 ppb	TLV: 0.025 mg/m ³ PEL: 0.1 mg/m ³ STEL: 0.03 mg/m ³ IDLH: 10 mg/m ³	Inhalation Absorption (skin) Ingestion	ACUTE: Irritation to skin. Vapor inhalation may cause pneumonitis. May effect CNS and kidneys. CHRONIC: May effect CNS and kidneys, resulting in irritability, tremors, speech disorders, mental/memory disturbances. Inflammation/discoloration of gums. Danger of cumulative effects.	(FP) NA (VP) 0.0012 mm (IP) NE (UEL) NA (LEL) NA	Odorless, heavy and mobile silvery-white liquid metal

Notes:

FP	FP - Flash Point	PEL	PEL - OSHA Permissible Exposure Limit
IDLH	IDLH - Immediately Dangerous to Life and Health	STEL	STEL - Short Term Exposure Limit
IP	IP - Ionization Potential	TLV	TLV - ACGIH Threshold Limit Value
NE	NE - Not Established (Information Not Available)	VP	VP - Vapor Pressure
NA	NA - Not Applicable	C	C - Ceiling Exposure Limit
CNS	CNS - Central Nervous System	[skin]	[skin] - potential for dermal absorption
PNS	PNS - Peripheral Nervous System	mm	mm - millimeters Hg (mercury)
ppm	ppm - parts per million	eV	eV - electronvolts
mg/m ³	mg/m ³ - milligrams per cubic meter		

TABLE 2.1

PROPERTIES OF POTENTIAL SITE CONTAMINANTS

Chemical Name (Synonyms)	Concentration at Site	Exposure Limits	Routes Of Entry	Symptoms/Health Effects	Chemical Properties	Physical Characteristics
Polychlorinated Biphenyls PCB (54%) Chlorodiphenyl (54% chlorine) Aroclor 1254 CAS-11097-69-1	0 - 53000 ppb	TLV: 0.5 mg/m ³ [skin] PEL: 0.5 mg/m ³ [skin] STEL: NE IDLH: 5 mg/m ³	Inhalation Absorption (skin) Ingestion	ACUTE: Eye irritation. CHRONIC: Dermatitis, chloracne, liver damage, reproductive system damage. Potential occupational carcinogen.	(FP) NA (VP) 0.00006 mm (IP) NA (UEL) NA (LEL) NA	Colorless to pale yellow viscous liquid or solid (<50°F) with a mild hydrocarbon odor.
Tetrachloroethene PCE Perchloroethylene Tetrachloroethylene CAS-127-18-4	0-86 ppb	TLV: 25 ppm PEL: 100 ppm STEL: 100 ppm IDLH: 150 ppm	Inhalation Ingestion Absorption	ACUTE: Irritation to skin, eyes and respiratory tract. Ingestion may cause chemical pneumonitis. Affects CNS. Unconsciousness at high level exposures. CHRONIC: Dermatitis. May cause liver and kidney damage. Probable human carcinogen.	(FP) NA (VP) 14 mm (IP) 9.32 eV (UEL) NA (LEL) NA	Colorless liquid with a mild, chloroform-like odor.
Phenol Hydroxybenzene Carbolic acid CAS-108-95-2	0-80000 ppb	TLV: 5 ppm [skin] PEL: 5 ppm [skin] STEL: NE IDLH: 250 ppm	Inhalation Absorption Ingestion	ACUTE: CORROSIVE to eyes, skin and respiratory tract. May cause lung edema, affects CNS, heart, and kidneys, resulting in convulsions, coma, cardiac disorders and respiratory failure. CHRONIC: Dermatitis. May damage liver and kidneys.	(FP) 175°F (VP) 0.4 mm (IP) 8.50 eV (UEL) 8.6% (LEL) 1.8%	Colorless to yellow or light pink, crystalline solid with a sweet, acrid odor.
Toluene Methylbenzene Toluol CAS-108-88-3	0-25000 ppb	TLV: 20 ppm PEL: 200 ppm STEL: NE IDLH: 500 ppm	Inhalation Ingestion Absorption	ACUTE: Irritation to eyes and respiratory tract. Ingestion may cause chemical pneumonitis. Affects CNS. Unconsciousness and cardiac dysrhythmia at high level exposures. CHRONIC: Defatting of the skin. Affects CNS. Enhanced hearing damage.	(FP) 40°F (VP) 21 mm (IP) 8.82 eV (UEL) 7.1% (LEL) 1.1%	Colorless liquid with a sweet, pungent, benzene-like odor.

Notes:

FP	FP - Flash Point	PEL	PEL - OSHA Permissible Exposure Limit
IDLH	IDLH - Immediately Dangerous to Life and Health	STEL	STEL - Short Term Exposure Limit
IP	IP - Ionization Potential	TLV	TLV - ACGIH Threshold Limit Value
NE	NE - Not Established (Information Not Available)	VP	VP - Vapor Pressure
NA	NA - Not Applicable	C	C - Ceiling Exposure Limit
CNS	CNS - Central Nervous System	[skin]	[skin] - potential for dermal absorption
PNS	PNS - Peripheral Nervous System	mm	mm - millimeters Hg (mercury)
ppm	ppm - parts per million	eV	eV - electronvolts
mg/m ³	mg/m ³ - milligrams per cubic meter		

TABLE 2.1

PROPERTIES OF POTENTIAL SITE CONTAMINANTS

Chemical Name (Synonyms)	Concentration at Site	Exposure Limits	Routes Of Entry	Symptoms/Health Effects	Chemical Properties	Physical Characteristics
Vinyl Chloride Chloroethene VCM Chloroethylene CAS-75-01-4	0-31 ppb	TLV: 1 ppm PEL: 1 ppm STEL: NE IDLH: NE	Inhalation Skin contact Eye contact	ACUTE: Irritation to eyes. Affects CNS. May cause unconsciousness. CHRONIC: Affects liver, spleen, blood and peripheral blood vessels, tissue and bones in fingers. Human carcinogen.	(FP) NA (gas) (VP) 3.3 atm (IP) 9.99 eV (UEL) 33.0% (LEL) 3.6%	Colorless gas or liquid (<7°F) with a pleasant odor at high concentrations.
Xylene (o;m;p isomers) CAS-106-42-3	0-550 ppb	TLV: 100 ppm PEL: 100 ppm STEL: 150 ppm IDLH: 900 ppm	Inhalation Absorption Ingestion	ACUTE: Irritation to eyes and respiratory tract. Ingestion may cause chemical pneumonitis. Affects CNS. CHRONIC: Defatting of the skin, lung damage resulting in chronic bronchitis. Affects CNS and blood.	(FP) 90/82/81°F (IP) 7/9/9 mm (IP) 8.56eV (UEL) 6.7% (LEL) 0.9%	Colorless liquid with an aromatic odor. (p-isomer solid <56°F).

Notes:

- | | | | |
|-------|--|--------|--|
| FP | FP - Flash Point | PEL | PEL - OSHA Permissible Exposure Limit |
| IDLH | IDLH - Immediately Dangerous to Life and Health | STEL | STEL - Short Term Exposure Limit |
| IP | IP - Ionization Potential | TLV | TLV - ACGIH Threshold Limit Value |
| NE | NE - Not Established (Information Not Available) | VP | VP - Vapor Pressure |
| NA | NA - Not Applicable | C | C - Ceiling Exposure Limit |
| CNS | CNS - Central Nervous System | [skin] | [skin] - potential for dermal absorption |
| PNS | PNS - Peripheral Nervous System | mm | mm - millimeters Hg (mercury) |
| ppm | ppm - parts per million | eV | eV - electronvolts |
| mg/m3 | mg/m3 - milligrams per cubic meter | | |

**ON-SITE AIR MONITORING PROGRAM ACTION LEVELS
HEALTH AND SAFETY PLAN
FRIEDRICHSOHN COOPERAGE SITE
WATERFORD, NEW YORK**

<i>Monitoring Device</i>	<i>Action Level</i>	<i>Action</i>
Photoionization Detector (PID) - Check correction factors (CF) from the manufacturer to convert PID reading to actual gas concentration 10.6 or greater eV lamp	< 1.0 ppm or Background	Full-Face Respirator Available
	≥ 1 ppm and ≤ 25 ppm	Full-face air purifying respirator Level C PPE
	>25 ppm and < 500 ppm	Supplied air respirator Level B PPE. Implement additional engineering controls.
	≥ 500 ppm	Shut down activities. Notify CSHO. Implement additional engineering controls.
Dust / Particulate - (Impacted)	< 1.0 mg/m ³ or Background	Full-Face Respirator Available
	≥ 1.0 mg/m ³ and < 50 mg/m ³	Wear Full-Face Respirator - Level C PPE
	> 50 mg/m ³	Wear Supplied Air Respirator - Level B PPE, Implement Additional Engineering Controls

Notes:

CSHO Safety and Health Officer (Contractor)

PPE Personal Protection Equipment.

ppm Parts Per Million.

APPENDIX A

JOB SAFETY ANALYSIS (JSA) FORMS



JOB SAFETY ANALYSIS (JSA)

Boat Safety



Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements, and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. CRA personnel have the authority and responsibility to use **Stop Work Authority (SWA)**.

Date Issued/Revised:	May 2014	JSA Type:	Surveying Activities on Water
Work Type:	Environmental	Client:	General Electric Company and SI Group, INC.
Work Activity:	Surveying activities on water		
Work Site:	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment:			
Task-specific Training:	Towing and Trailering, Boating Safety		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (see job steps for task-specific requirements)					
<input type="checkbox"/> Reflective Vest	<input type="checkbox"/> Goggles	<input type="checkbox"/> Gloves*	Supplied Air	APR	
<input type="checkbox"/> Hard Hat	<input type="checkbox"/> Face Shield*	<input type="checkbox"/> Coveralls*		<input type="checkbox"/> SCBA	<input type="checkbox"/> Full Face APR
<input type="checkbox"/> Lifeline/Harness*	<input type="checkbox"/> Hearing Protection*	<input type="checkbox"/> PPE Clothing*	<input type="checkbox"/> Airline Respirator (attach description)	<input type="checkbox"/> Half Mask APR	<input type="checkbox"/> Particulate/Organic Vapor Combined
<input type="checkbox"/> Safety Glasses	<input type="checkbox"/> Safety-toed Boots				<input type="checkbox"/> Acid Gas
<input checked="" type="checkbox"/> Other*	Personal Floatation Device (PFD)		<input type="checkbox"/> Other*	<input type="checkbox"/> Other*	
ADDITIONAL PPE (*provide specific type(s) or descriptions of this item below)					
Sunglasses; sunscreen					

Project Development Team		Position/Title	Modified By	Reviewed By	Position/Title	Date
Name	Signature					



JOB SAFETY ANALYSIS (JSA)

Boat Safety



Safety Means Awareness
Responsibility Teamwork

Job Steps ⁽¹⁾	Task Activity	Potential Hazard(s) ⁽²⁾	Corrective Measure(s) ⁽³⁾	Person Responsible
1	Mob equipment to boat launch	<ul style="list-style-type: none"> Over loading boat capacity Inclement weather Lifting hazards Manual material handling Back injury Pinch points Moving or flying projectiles inside vehicle while transporting equipment Slip/trip/fall hazards Fuel spill 	<ul style="list-style-type: none"> Review boat capacity and complete weight survey including personnel and gear Monitor weather forecasts Make sure grip is adequate; wear leather/cotton gloves Size up the load; if the object is too large or odd shaped OR is in excess of 50 pounds (23 kg) then assistance (mechanical or a buddy lift) will be required Ensure all equipment is properly secured during transport Lift with the legs (bend at the knees and use the leg muscles) to protect the lower back and keep lower back in a neutral position Avoid one-handed carrying if possible; maintain awareness of footing Refuel in appropriate location, no sparks or static buildup Practice STAR 	Competent operator and Site Personnel
2	Launch boat	<ul style="list-style-type: none"> Lifting hazards Manual material handling Back injury Pinch points Moving or flying projectiles inside vehicle while transporting equipment Slip/trip/fall hazards Fuel spill Drowning 	<ul style="list-style-type: none"> Practice STAR Make sure grip is adequate; wear leather/cotton gloves Size up the load; if the object is too large or odd shaped OR is in excess of 50 pounds (23 kg) then assistance (mechanical or a buddy lift) will be required Lift with the legs (bend at the knees and use the leg muscles) to protect the lower back and keep lower back in a neutral position Avoid one-handed carrying if possible; maintain awareness of footing Review JSA for proper fuelling Wear appropriate PFD or life vest Bring boating safety kit 	Competent operator
3	Navigate boat to site	<ul style="list-style-type: none"> Causing unnecessary wake Running aground Disturbing others Drowning 	<ul style="list-style-type: none"> Obey posted signage Follow channel marked with buoys Follow proper boating etiquette Practice STAR Wear appropriate PFD or life vest Bring boating safety kit Remain seated 	Competent operator
4	Perform sampling activities	<ul style="list-style-type: none"> Tipping boat Wet equipment Boating traffic 	<ul style="list-style-type: none"> Remain seated when operating; If the boat tips over, remain with the boat Keep equipment dry by storing in waterproof storage containers during transport Be aware of surroundings, verify water depth in shallow waters Be aware of other boat traffic (barges for shipping, or pleasure craft) 	Site Personnel

- (1) Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.
- (2) A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress/ergonomics/lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught".
- (3) Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable, and quantified terms. Avoid subjective general statements such as "be careful" or "use as appropriate".

Job Safety Analysis (JSA) EXCAVATOR OPERATION

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	July 2013	JSA Type	Loading Soil and/or Waste Material
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Excavator Operation		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment	Excavator		
Task-specific Training	40 HR and 8 HR HAZWOPER, PPE, Mobile Equipment Operations, Excavation Safety Training; Heavy Equipment Safety		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input checked="" type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: Full Facepiece*	<input checked="" type="checkbox"/> GLOVES*
<input checked="" type="checkbox"/> HARD HAT	<input checked="" type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input checked="" type="checkbox"/> HEARING PROTECTION*	<input type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER*
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER* _____	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest - Class II Gloves - Leather			
APR -Full-Facepiece equipped with organic vapor and particulate cartridges			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA) EXCAVATOR OPERATION

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Perform the STAR Process (Stop Think Act Review) and discuss Stop Work Authority (SWA) -	<ul style="list-style-type: none"> Slips, trips, falls; Situational risks - use STAR; 	<ul style="list-style-type: none"> Verify personnel training is sufficient for scheduled task(s). Is Job Instruction (hands-on) Training necessary? 	Site Supervisor on all
2	Inspect equipment	<ul style="list-style-type: none"> Equipment malfunction or damage Hydraulic fluid, fuel, oil leaks/spills Loss of steering, loss of brakes, etc.; accidents, decreased visibility Fire Slip/trip/fall hazards Unexpected operation of equipment Swing radius signage missing 	<ul style="list-style-type: none"> Follow Equipment Inspection Form/Tag Out if malfunction found Grease moving parts Check all fluids Ensure that fluids are not too low or too full Walk around equipment and look for leaking fluids Ensure that tracks are acceptable (no unacceptable wear and no objects present) Ensure that windows and mirrors are clean. Adjust mirrors! Remove trash or other debris from cab Ensure that back up alarm and horn are operational Correct any problems immediately and inform supervisor If equipment appears as though it has been tampered with or vandalized, do not start it Ensure that fire extinguisher is in place and functioning Inspect the fire extinguisher monthly Use three point mount/dismount at all times Be cautious of where you step and be aware of your surroundings Ensure that ignition key is in your pocket, equipment is in neutral and parking brake is engaged Use interlock safety mechanism any time equipment is not conducting a productive and/or controlled activity 	Site Supervisor and Operator
3	Entering equipment	<ul style="list-style-type: none"> Reduced visibility Uncomfortable seating - back strain Debris on floor getting stuck under pedals Unexpected movement of excavator 	<ul style="list-style-type: none"> Adjust seat and mirrors so that you are able to see where traveling Adjust controls and seat to your comfort and safety Ensure that all materials inside cab are secured Be cautious of where you step and be aware of your surroundings Ensure steps are clear of water, mud, and other debris Ensure parking brake is engaged and gear is in neutral Use interlock safety mechanism any time equipment is not conducting a productive and/or controlled activity 	Site Supervisor and Operator
4	Configure controls and seating	<ul style="list-style-type: none"> Ergonomics/unnecessary physical stress/ back injury Incapable of reaching controls Visual blocks 	<ul style="list-style-type: none"> Upon sitting, adjust seat fully to accommodate reach and comfort zone Fasten seat belt Make certain all controls are set in neutral positions Adjust mirrors 	Site Supervisor and Operator
5	Starting and warming up	<ul style="list-style-type: none"> Unanticipated rolling or movement, engine fire, or mechanical/electrical faults 	<ul style="list-style-type: none"> Review operator's manual if new to this particular machine Start engine and check controls to ensure all are in working conditions Allow a minimum of 2 minutes to warm up 	Site Supervisor and Operator

Job Safety Analysis (JSA) EXCAVATOR OPERATION

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
6	Moving equipment work area	<ul style="list-style-type: none"> • Other equipment, personnel, or objects in work area • Uneven terrain 	<ul style="list-style-type: none"> • Perform STAR – be aware of surroundings • Know the daily task and other people and equipment in the area • Make eye contact with other operators and site personnel in the immediate vicinity • Inspect pathway prior to moving equipment to ensure clear pathway 	Site Supervisor and Operator
7	Performing tasks	<ul style="list-style-type: none"> • Other equipment (collision) • Slopes, ground conditions possible injuries to personnel and equipment, buried obstacles, underground and overhead utilities • Dust 	<ul style="list-style-type: none"> • Perform STAR • Know where utilities are located – know where your bucket is in relation to any underground utilities at all times • Be aware of the scope of work to be performed • Use a spotter • Know the paths of other equipment or persons entering and leaving your work area • Communicate with supervisors and other operators throughout the day with any questions • Stop work immediately and contact a supervisor if you are uncertain of your task, experience equipment failure, or personal injury or near loss • Wear dust mask if conditions warrant 	Site Supervisor and Operator
8	Stopping at end of day	<ul style="list-style-type: none"> • Slip/trip/fall hazards • Overnight parking of equipment 	<ul style="list-style-type: none"> • Be cautious of where you step and be aware of your surroundings • Park in designated area • Set brake/control locks • Idle for 2 minutes if engine is hot • Lower bucket to ground – zero energy state • Turn equipment off; remove keys • Use three-point dismount • Secure inside equipment (i.e., fire extinguisher) 	Site Supervisor and Operator

¹ Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.

² A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"

³ Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".

Job Safety Analysis (JSA)

HEAVY EQUIPMENT DECONTAMINATION ACTIVITIES

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	July 2013	JSA Type	Heavy Equipment Decontamination Activities
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Heavy Equipment Decontamination Activities		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment	Alconox/Liquinox, buckets water, brushes and a high-pressure washer		
Task-specific Training	40 HR and 8 HR HAZWOPER; PPE, HAZCOM and High-Pressure Washing Equipment		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: _____*	<input checked="" type="checkbox"/> GLOVES*
<input checked="" type="checkbox"/> HARD HAT	<input type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input type="checkbox"/> HEARING PROTECTION*	<input checked="" type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER*
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER*	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest – Class II PPE Clothing – Polycoated Tyvek® suits			
Gloves – Outer Nitrile (e.g., Solvex) and Inner Nitrile gloves (e.g., Ndex)			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA)

HEAVY EQUIPMENT DECONTAMINATION ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Perform the STAR Process and discuss Stop Work Authority (SWA) Perform Review of this JSA.	Failing to identify hazardous conditions resulting in losses or near losses.	<ul style="list-style-type: none"> Perform the STAR Process. Assess the risks. Determine the hazards of performing the task and survey the work area. Consider weather conditions and review heat stress and cold stress information as applicable Always consider the worst case scenario. Analyze the hazards determined. Decide a plan of action to eliminate or reduce the hazards and act on it. 	Decontamination Personnel
2	Remove by hand excess visible dirt and debris from equipment	Pinch points	<ul style="list-style-type: none"> Keep hands, feet, & clothing away from moving parts/devices. Use proper climbing/access platforms to reach the various parts of the equipment. 	Decontamination Personnel
3	Use high pressure/low volume hot water or steam equipment	Use of hand and power tools	<ul style="list-style-type: none"> Follow manufacturers' safety precautions, inspect tools regularly, replace defective tools, wear the appropriate eye and foot protection. Use proper climbing/access platforms to reach the various parts of the equipment. 	Decontamination Personnel
4	Segregate all waste materials	Chemical hazard	<ul style="list-style-type: none"> Wear the PPE that is identified on the first page of this JSA. Maintain waste materials in a controlled area. Remove accumulated waste material as reasonably accumulated. Do not lift more than 50 pounds. Ask for assistance with heavy items. 	Decontamination Personnel
5	Containerize all waste materials	Pinch points, heavy lifting	<ul style="list-style-type: none"> Keep hands, feet, & clothing away from moving parts/devices; follow safe lifting practices. Lift items within your capabilities. Do not lift more than 50 pounds. Ask for assistance with heavy items 	Decontamination Personnel

¹ Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.

² A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"

³ Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".

Job Safety Analysis (JSA)

MATERIAL HANDLING ACTIVITIES – RIGGING AND PLACEMENT OF MATERIALS

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	July 2013	JSA Type	Material Handling Activities
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Rigging and Placement of Materials		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment	Excavator, Backhoe, or Crane		
Task-specific Training	Rigging; lifting signals; heavy equipment safety; use of taglines; proper use of load charts; 40 HR and 8 HR HAZWOPER, HAZCOM, PPE, Mobile Equipment Operations		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input checked="" type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: _____*	<input checked="" type="checkbox"/> GLOVES*
<input checked="" type="checkbox"/> HARD HAT	<input type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input type="checkbox"/> HEARING PROTECTION*	<input type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER* _____
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER* _____	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest - Class II			
Gloves - Leather			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA)

MATERIAL HANDLING ACTIVITIES – RIGGING AND PLACEMENT OF MATERIALS

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Perform the STAR Process and discuss Stop Work Authority (SWA) Equipment Inspection	<ul style="list-style-type: none"> Hydraulic failure 	<ul style="list-style-type: none"> Inspect equipment lines and fluid reservoirs 	Operator
2	Rigging components – Inspection of load and rigging	<ul style="list-style-type: none"> Attachment point failure 	<ul style="list-style-type: none"> Inspect attachment hook/ring for fractures, dents or abuse. Certify load capability of attachment point. 	Operator, Qualified Rigger and all field personnel involved in the operation
3	Rigging components – Continue inspection of load, rigging, and material to be lifted	<ul style="list-style-type: none"> Rigging assembly failure 	<ul style="list-style-type: none"> Inspect rigging chains, wire rope, cables, hooks, slings, d-rings, splitters, spreaders and all other components for unusual shape, fractures, fraying, dents, abuse or abnormalities. Insure components used have annual certification, proper load rating and are implemented as recommended by training and the manufacturer. 	Operator, Labor and all field personnel involved in operation.
4	Rigging components	<ul style="list-style-type: none"> Improper component attachment, lifting point usage, incorrect balance or component orientation 	<ul style="list-style-type: none"> Use the manufacturer's recommended lifting attachment points, slots or cable points to secure load to be rigged. Use proper rigging components to assure load is evenly distributed, proper balance is achieved and place hoisting equipment and rigged components in proper orientation to assure placement logistics are correct. 	Operator, Labor and all field personnel involved in operation.
5	Tag lines – Proper placement of taglines to ensure control of load. No one is to work under a suspended load	<ul style="list-style-type: none"> Lift control failure 	<ul style="list-style-type: none"> Use of tag lines, as a lifting control measure is mandatory as appropriate for correct placement of rigged component. Personnel assisting rigging or lift should never physically be in contact with rigged or lifted components as a measure of component control. 	Operator, Labor and all field personnel involved in operation.
6	Pre-plan the lift and prepare the landing zone	<ul style="list-style-type: none"> Objects/personnel in swing radius path; Lifting outside of equipment's load safe load radius 	<ul style="list-style-type: none"> Pre-plan the lift to ensure swing radius does not impact other operations. Ensure that load and load path stays within load radius of lifting equipment. 	Rigger, And Operator
7	Component placement – Pick the load and place the item in the correct position.	<ul style="list-style-type: none"> Improper preparation of location receiving rigged or lifted component resulting in need for multiple lifts. 	<ul style="list-style-type: none"> Preparation of the area receiving the rigged or lifted component to avoid and necessary re-lift or multiple lifts. 	Operator, Labor and all field personnel involved in operation.
8	Maintain Control of Area	<ul style="list-style-type: none"> Unauthorized personnel or equipment in rigging or lifting exclusion zone 	<ul style="list-style-type: none"> Area marking and clearance of all personnel and equipment to prevent interference during rigging or lifting activities. Spotter action to terminate rigging or lifting if situational changes occur putting personnel or equipment at risk. 	Operator, Labor and all field personnel involved in operation.
9	Control of communication between task personnel	<ul style="list-style-type: none"> Multiple signals interfering with operator 	<ul style="list-style-type: none"> During lifting or rigging activities, a communication order must be established previous to any attempt to hoist load. Spotters communicate to one load controller; load controller communicates to operator. Operator must maintain visual contact with load controller at all times. All operations are controlled by ground controller. 	Operator, Labor and all field personnel involved in operation.
10	Trench entry in order to place materials and piping – see JSA for Excavation Activities	<ul style="list-style-type: none"> Excavation Hazards (review of that JSA) 	<ul style="list-style-type: none"> Follow JSA for Excavation. 	All Affected Personnel

Job Safety Analysis (JSA)

MATERIAL HANDLING ACTIVITIES – RIGGING AND PLACEMENT OF MATERIALS

- ¹ Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.
- ² A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"
- ³ Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".

Job Safety Analysis (JSA)

MOBILIZATION AND DEMOBILIZATION ACTIVITIES

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	July 2013	JSA Type	Mobilization and Demobilization Activities
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Mobilization of Equipment and Supplies to and from the job site		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment			
Task-specific Training	PPE, HAZCOM, Motor Vehicle Safety, Mobile Equipment Operations		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input checked="" type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: _____*	<input checked="" type="checkbox"/> GLOVES*
<input checked="" type="checkbox"/> HARD HAT	<input type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input type="checkbox"/> HEARING PROTECTION*	<input type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER* _____
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER*	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest - Class II			
Gloves - Leather			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA)

MOBILIZATION AND DEMOBILIZATION ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Discuss STAR (Stop Think Assess & Review) and Stop Work Authority (SWA)	<ul style="list-style-type: none"> Site personnel not aware of STAR & SWA 	<ul style="list-style-type: none"> Project team discusses importance of and documentation procedures for SWA during pre-job safety meeting. Use SWA to stop any work that is unsafe. 	Personnel Taking Part in this Activity
2	Check weather	<ul style="list-style-type: none"> Unexpected storm; Fog; Rain; Snow; Lightening/Thunder; Heat/Cold stress 	<ul style="list-style-type: none"> Check local weather forecast. Discuss weather issues and precautions to take while driving and on-site during the pre-job safety meeting. If weather conditions (e.g., fog, rain, snow, etc.) impair the ability/vision of the driver, exit at nearest safe location and assess the situation. While on-site, at first sign of lightening/thunder utilize SWA and assess weather conditions. In extreme temperatures, ensure all personnel have proper clothing, hydration, and heat/cold protection (e.g., canopy, fan, and glove warmers). 	Personnel Taking Part in this Activity
3	Load equipment into vehicle	<ul style="list-style-type: none"> Back strain; Cuts; Pinch points; Hand/Foot injury; Forgotten equipment; Damaged equipment 	<ul style="list-style-type: none"> Use proper lifting techniques and buddy system if needed. Wear leather/cotton gloves and avoid placing hands/fingers in pinch point locations. Wear steel toe boots. Verify requested equipment against warehouse form. Load equipment in an organized manner to prevent shifting during transport or use cargo netting. 	Personnel Taking Part in this Activity
4	Complete CRA Daily Operator Vehicle Checklist	<ul style="list-style-type: none"> Damaged vehicle lights, tires, windows, mirrors, horn; Inadequate vehicle documents and/or safety items 	<ul style="list-style-type: none"> Check for fluid leaks under vehicle. Test operation of headlights, front/rear turn signals, backup lights, brake lights, and emergency flashers. Visually check the pressure/wear of tires. Ensure the vehicle has a spare tire. Assure windshield and window glass is clean and free from obstructions. Test the windshield wipers and horn. Verify vehicle registration, insurance card, and inspection sticker is present and valid. Ensure the vehicle contains a first aid kit, fire extinguisher, and road hazard kit. 	Personnel Taking Part in this Activity
5	Check and adjust seat, steering wheel, headrest, and mirrors	<ul style="list-style-type: none"> Back/body strain; Blind spots; Impaired vision. 	<ul style="list-style-type: none"> Adjust seat, headrest, and steering wheel height so body is fully supported/comfortable and pedals are within easy reach. Ensure mirrors are properly adjusted. 	Personnel Taking Part in this Activity
6	Fasten seat belt(s) and ensure passenger(s) seat belts are fastened	<ul style="list-style-type: none"> Serious injury, ejection, or death from collision and/or traffic citation 	<ul style="list-style-type: none"> Verify driver and passenger(s) seat belts are in good condition and properly latched. 	Personnel Taking Part in this Activity
7	Ensure vehicle doors are locked	<ul style="list-style-type: none"> Serious injury, ejection, or death from collision; Unwanted intrusion; Lost equipment 	<ul style="list-style-type: none"> Manually lock all doors to vehicle. 	Personnel Taking Part in this Activity
8	Start engine and check gauges and warning lights	<ul style="list-style-type: none"> Vehicle breakdown 	<ul style="list-style-type: none"> Verify sufficient fuel and other hazard lamps (e.g., battery, oil, and temperature) are not lit. 	Personnel Taking Part in this Activity

Job Safety Analysis (JSA)

MOBILIZATION AND DEMOBILIZATION ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
9	Mobilize to site	<ul style="list-style-type: none"> • Arriving late; • Collision; • Injury or Death to occupants or other parties 	<ul style="list-style-type: none"> • Do not use cell phones or perform other distracting activities while vehicle is in motion. • Constantly scan intersections, move eyes, check mirrors, and assess traffic lights (fresh vs. stale). • Maintain safety cushion around vehicle (front, sides, and rear) and 4 second following distance. • Utilize all driving defensive techniques. 	Personnel Taking Part in this Activity
10	Arrive at site	<ul style="list-style-type: none"> • Pedestrian injury; • Collision 	<ul style="list-style-type: none"> • Maintain awareness of pedestrian/vehicular traffic when entering site and traveling to work zone. 	Personnel Taking Part in this Activity
11	Park vehicle	<ul style="list-style-type: none"> • Pedestrian injury; • Collision; • Property damage 	<ul style="list-style-type: none"> • Maintain awareness of pedestrian/vehicular traffic. • Park vehicle in pull-through parking space or facing the exit. • Use caution and mirrors/spotter when backing vehicle. 	Personnel Taking Part in this Activity
12	Demobilization	<ul style="list-style-type: none"> • Collision; • Injury or Death to occupants or other parties 	<ul style="list-style-type: none"> • Perform perimeter vehicle check. • Maintain awareness of pedestrian/vehicular traffic when exiting site. • Utilize defensive driving techniques. • Complete post-departure checklist and report vehicle problems to company vehicle maintenance manager or rental car agency. 	Personnel Taking Part in this Activity

- 1 Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.
- 2 A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"
- 3 Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".

Job Safety Analysis (JSA)

OVERSIGHT OF CONTRACTOR AND SUBCONTRACTOR ACTIVITIES

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	June 2013	JSA Type	Oversight of Contractor and Subcontractor Activities
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Oversight of Contractor and Subcontractor Activities		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment			
Task-specific Training	40 HR and 8 HR HAZWOPER; PPE, HAZCOM, Mobil Equipment Safety Awareness Training.		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: _____*	<input checked="" type="checkbox"/> GLOVES*
<input checked="" type="checkbox"/> HARD HAT	<input type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input type="checkbox"/> HEARING PROTECTION*	<input type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER*
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER*	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest – Class II			
Gloves – For general Handling activities			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA)

OVERSIGHT OF CONTRACTOR AND SUBCONTRACTOR ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Perform the STAR Process and discuss Stop Work Authority (SWA) Perform Review of this JSA.	<ul style="list-style-type: none"> Failing to identify hazardous conditions resulting in losses or near losses. 	<ul style="list-style-type: none"> Perform the STAR Process. Assess the risks. Determine the hazards of performing the task and survey the work area. Consider weather conditions and review heat stress and cold stress information as applicable Always consider the worst case scenario. Analyze the hazards determined. Decide a plan of action to eliminate or reduce the hazards and act on it. 	CRA Site Representative
2	General inspection of contractor and subcontractor work activities	<ul style="list-style-type: none"> Slip/Trip/Falls Injury from Heat/Cold Stress or Inclement Weather Working From Elevated Heights Greater Than 6 Feet Noise Potential direct and indirect contact with chemical contaminants and hazardous atmospheres. Biological Hazards Lifting Heavy Objects Exposure to Vehicular traffic and Heavy Equipment Failure to identify and remove all hazards including atmospheric hazards, water, electrical and biological. Electrical hazards and potential physical injury from exposure to hazardous energy (i.e., hydraulic, pneumatic etc.) Potential heat hazard (e.g., touching hot objects) that could cause a burn 	<ul style="list-style-type: none"> Walk work area to look for additional hazards. Keep area free of excess materials and debris. Remove all travel path hazards by keeping materials/objects organized and out of walkways. Note and communicate areas of slick or uneven ground. Take breaks as needed by monitoring the Daily Heat Index, as outlined in the HASP Consume adequate food/beverages. Personnel should consume at least 8 ounces of cool water or electrolyte replacement drinks every 20-30 minutes. Observe work-rest schedule to manage heat/cold stresses When warranted, stay alert for rain, lightning, and high wind hazards, perform work in such weather as outlined in the HASP. Do not stand directly next to open excavations > 6-ft. without fall protection Access ladders or ramps if they were installed in the immediate work area, must be available to enter into and out of any excavation Perform pre-entry air monitoring to verify acceptable conditions Wear all of the PPE as identified on the first page of this JSA. Hearing protection is required when working near operating equipment and machinery. Do not lift or move objects by yourself if they weigh more than 50 pounds. Check for contact hazards such as other boxes/objects in the vicinity as well as other people/equipment in the area. Check that there is ample room to squat, lift, turn, or maneuver without twisting the back or other muscles or joints. Check travel path for, and remove, slip hazards such as tools puddles, and debris. Wear Reflective Safety Vest in areas near operating equipment and vehicular traffic. Maintain eye contact with equipment operators and do not walk into their path unless the operator motions for you to move. Ensure that energy control procedures are in place when work is being done on equipment that has hazard energy present. 	CRA Site Representative

¹ Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.

² A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"

Job Safety Analysis (JSA)

OVERSIGHT OF CONTRACTOR AND SUBCONTRACTOR ACTIVITIES

³ Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".



JOB SAFETY ANALYSIS (JSA)

Sediment Sampling



Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements, and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. CRA personnel have the authority and responsibility to use **Stop Work Authority (SWA)**.

Date Issued/Revised:	May 2014	JSA Type:	Sampling
Work Type:	Environmental	Client:	General Electric Company and SI Group, INC.
Work Activity:	Sediment sampling (general procedures)		
Work Site:	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment:	Hand core piston type, hand core split barrel type, Vibracore, drill rig, other proprietary core sampler		
Task-specific Training:	CRA Field Method Training on Soil Sampling Procedures; Boating Safety		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (see job steps for task-specific requirements)					
<input type="checkbox"/> Reflective Vest	<input checked="" type="checkbox"/> Goggles	<input type="checkbox"/> Gloves*	Supplied Air	APR	
<input checked="" type="checkbox"/> Hard Hat	<input type="checkbox"/> Face Shield*	<input type="checkbox"/> Coveralls*		<input type="checkbox"/> SCBA	<input type="checkbox"/> Full Face APR
<input type="checkbox"/> Lifeline/Harness*	<input type="checkbox"/> Hearing Protection*	<input type="checkbox"/> PPE Clothing*	<input type="checkbox"/> Airline Respirator (attach description)	<input type="checkbox"/> Half Mask APR	<input type="checkbox"/> Particulate/Organic Vapor Combined
<input checked="" type="checkbox"/> Safety Glasses	<input checked="" type="checkbox"/> Safety-toed Boots				<input type="checkbox"/> Acid Gas
<input checked="" type="checkbox"/> Other*	Personal Flotation Device (PFD) and sunscreen		<input type="checkbox"/> Other*	<input type="checkbox"/> Other*	
ADDITIONAL PPE (*provide specific type(s) or descriptions of this item below)					
Gloves will depend on the task and chemical contamination present or suspected present					

Project Development Team Name	Signature	Position/Title	Modified By	Reviewed By	Position/Title	Date



JOB SAFETY ANALYSIS (JSA)

Sediment Sampling



*Safety Means Awareness
Responsibility Teamwork*

Job Steps ⁽¹⁾	Task Activity	Potential Hazard(s) ⁽²⁾	Corrective Measure(s) ⁽³⁾	Person Responsible
1	Inspection and setup of sampling equipment on boat or barge	<ul style="list-style-type: none"> Lost time from improperly functioning equipment Incorrect sampling procedures/ collection due to malfunctioning equipment 	<ul style="list-style-type: none"> Ensure all PPE is worn including PFD for each person Ensure all equipment is functioning properly; complete Quality Control documents Ensure boat/barge sufficiently stable for retrieval of samples 	Sampling Technician
2	Prepare to lower sampler into water	<ul style="list-style-type: none"> Lifting hazards Back injury Manual material handling Pinch points Cuts Punctures Sample misidentification 	<ul style="list-style-type: none"> Reduce travel distance when there is a need to carry/lift materials Make sure grip is adequate; wear leather/cotton gloves Size up the load; if the object is too large or odd shaped OR is in excess of 50 pounds (23 kg) then assistance (mechanical or a buddy lift) will be required Lift with the legs (bend at the knees and use the leg muscles) to protect the lower back and keep lower back in a neutral position Avoid one-handed carrying if possible; maintain awareness of footing Sampler will be heavier when raised; take breaks to rest arms/shoulders Avoid placing hands/fingers in pinch point locations Use proper tools when opening container packaging Do not use fixed open blade knives when opening boxes or containers Ensure the sample id label matches sample location with site plan/CRA Site Supervisor/subcontractor 	Sampling Technician
3	Retrieve sampler when sample collected	<ul style="list-style-type: none"> Cuts due to sharp edges of sample sleeve; Contaminant exposure Lifting hazards Back injury Manual material handling Cuts from sharp objects retrieved by sampler Contamination hazards 	<ul style="list-style-type: none"> Refer to step 2 and the HASP for additional lifting information Wear nitrile gloves Maintain awareness of sharp edges from objects that may be in sampler 	Sampling Technician
4	Sieving sample collection using mesh sieve (if applicable)	<ul style="list-style-type: none"> Contaminant exposure Cuts from container breakage Sample misidentification Chemical exposure to reagent if used 	<ul style="list-style-type: none"> Wear nitrile gloves and replace between soil samples Inspect glass bottles for breaks/cracks; do not attempt to use any suspect containers Close glass sample containers carefully to avoid breakage Check sample labels for accuracy prior to placing in cooler Wear O/V respirator/cartridge when handling reagent (potential formaldehyde exposure) 	Sampling Technician
5	Headspace screening of samples (if applicable)	<ul style="list-style-type: none"> Contaminant exposure Incorrect headspace readings 	<ul style="list-style-type: none"> Wear nitrile gloves Ensure proper calibration of equipment 	Sampling Technician
6	Sample selection	<ul style="list-style-type: none"> Bottle breakage Contaminant exposure Pinch points Lost time due to incorrect sample selection 	<ul style="list-style-type: none"> Wear nitrile gloves when handling sample containers Confirm selected samples are correct based on work plan selection criteria, PID readings, and soil boring logs Avoid placing hands/fingers in pinch point locations (e.g., between cooler and lid) 	Sampling Technician



JOB SAFETY ANALYSIS (JSA)

Sediment Sampling



Job Steps ⁽¹⁾	Task Activity	Potential Hazard(s) ⁽²⁾	Corrective Measure(s) ⁽³⁾	Person Responsible
7	Packing samples in cooler(s)	<ul style="list-style-type: none"> • Bottle breakage • Contaminant exposure • Cuts • Pinch points • Lifting hazards • Back injury • Manual material handling • Lost time due to incorrect sample packaging or hold time exceedances 	<ul style="list-style-type: none"> • Wear nitrile gloves when handling sample containers • Pack glass containers in bubble wrap • Check COC against sample labels and SSOW for accuracy before shipping • Avoid placing hands/fingers in pinch point locations (e.g., between cooler and lid) • Refer to step 2 and the HASP for additional lifting information • Ensure equipment and supplies are loaded correctly and do not shift during transport 	Sampling Technician
8	Investigation derived waste (IDW) management	<ul style="list-style-type: none"> • Contaminant exposure • Heavy lifting • Pinch points • Slips/trips/fall hazards • Mislabeled waste 	<ul style="list-style-type: none"> • Wear nitrile gloves when handling IDW • Use proper lifting techniques to transport/dispose of IDW into drums and use buddy system if needed • Avoid placing hands/fingers in pinch point locations • Maintain awareness of walking surfaces • Label IDW with generator, a contact number, identification of contents, and site location • Specify IDW as either hazardous or non-hazardous material 	Sampling Technician

- (1) Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.
- (2) A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress/ergonomics/lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught".
- (3) Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable, and quantified terms. Avoid subjective general statements such as "be careful" or "use as appropriate".

Job Safety Analysis (JSA) SOIL SCREENING ACTIVITIES

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	July 2013	JSA Type	Soil Screening Activities
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Soil Screening Activities		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment	Photoionization Detector		
Task-specific Training	40 HR and 8 HR HAZWOPER; PPE, Mobile Equipment Operations		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input checked="" type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: _____*	<input checked="" type="checkbox"/> GLOVES*
<input checked="" type="checkbox"/> HARD HAT	<input type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input checked="" type="checkbox"/> HEARING PROTECTION*	<input checked="" type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER*
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER* _____	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest – Class II PPE Clothing – Polycoated Tyvek® suits			
Gloves – Inner Nitrile gloves (e.g., Ndex)			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA) SOIL SCREENING ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Perform the STAR Process and discuss Stop Work Authority (SWA) Perform Review of this JSA.	<ul style="list-style-type: none"> Failing to identify hazardous conditions resulting in losses or near losses. 	<ul style="list-style-type: none"> Perform the STAR Process. Assess the risks. Determine the hazards of performing the task and survey the work area. Consider weather conditions and review heat stress and cold stress information as applicable Always consider the worst case scenario. Analyze the hazards determined. Decide a plan of action to eliminate or reduce the hazards and act on it. 	Soil Screening Technician
2	Mob soil screening equipment to work area	<ul style="list-style-type: none"> Potential back Injuries from moving equipment; Potential exposure to onsite vehicle traffic Slip/trip/fall; Biological hazards. 	<ul style="list-style-type: none"> Follow proper lifting procedure identified in the HASP; Wear the appropriate PPE that is identified in this JSA; Practice STAR; Use the Buddy System to watch over other project team members. 	Soil Screening Technician
3	Conduct soil screening activities	<ul style="list-style-type: none"> Struck by moving heavy equipment; Slip/trip/fall; Potential direct or indirect contact with soils that potentially may contain chemicals; Biological hazards; Weather hazards (thunder storms) Heat Stress and Cold Stress. 	<ul style="list-style-type: none"> Wear hi-visibility safety vest, steel-toed boots, safety glasses, hard hat and respirator as required; Do not use old or worn out PPE; Make sure that proper PPE is being worn and is in good condition; Notify nearby equipment operators of changes in you activities/movement through work area; Inspect and properly decontaminate tools and screening equipment; Watch for snakes, insects, animals, etc; avoid walking through contaminated areas; Check weather prior to entering work area; Should conditions be windy, wear spoggles (safety glass goggles) to prevent dirt and debris from getting into the eyes when air purifying respirators are not being worn; Wear sunscreen, as required; If thunder is heard o lightning seen, leave work area immediately and take shelter; do not re-enter work area until 30 minutes after last lightning strike is seen; Proceed to the decontamination area at break time and upon completion of the assigned work task; Follow the Decontamination Procedures. 	Soil Screening Technician

¹ Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.

² A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"

³ Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".

Job Safety Analysis (JSA) SURVEYING ACTIVITIES

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	July 2013	JSA Type	Surveying Activities
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Surveying Activities		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment	GPS, grade rod, stakes, hammer, wood lathe, ribbon		
Task-specific Training	Flagger safety; Traffic control devices; PPE, Mobile Equipment Operations		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input checked="" type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: _____*	<input checked="" type="checkbox"/> GLOVES* Leather
<input checked="" type="checkbox"/> HARD HAT	<input type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input type="checkbox"/> HEARING PROTECTION*	<input type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER*
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER* _____	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest – Class II			
Gloves - Leather gloves for mobilization and demobilization equipment			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA) SURVEYING ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Perform the STAR Process and discuss Stop Work Authority (SWA) Perform Review "General Site Activities" JSA.	<ul style="list-style-type: none"> Failing to identify hazardous conditions resulting in losses or near losses. 	<ul style="list-style-type: none"> Perform the STAR Process STAR. Assess the risks. Determine the hazards of performing the task and survey the work area. Consider weather conditions such as fog that could reduce visibility. Always consider the worst case scenario. Analyze the hazards determined. Decide a plan of action to eliminate or reduce the hazards and act on it. 	Survey Team
2	Mob equipment to surveying area	<ul style="list-style-type: none"> Potential back Injuries loading equipment; Pinch points; Moving or flying projectiles inside vehicle while transporting equipment; Slip/trip/fall; Biological hazards. 	<ul style="list-style-type: none"> Follow proper lifting procedure identified in the HASP; Wear leather gloves when moving equipment around; Review JSA and HASP; Practice STAR; Properly secure all equipment inside the vehicle. Contact the owner of any public roadway (State or City) to determine requirements for surveying on or along their roadway. Develop a Temporary Traffic Control Plan (TTCP) if surveying activities will be taking place on or along the shoulder of a public highway. Set up a Temporary Traffic Control Zone (TTCZ) if surveying activities will be taking place on or along the shoulder of a public highway. The TTCP will describe the set up of the TTCZ. 	Survey Team
3	Setup in work zone	<ul style="list-style-type: none"> Struck by oncoming traffic/heavy equipment; Slip/trip/fall; Biological hazards; Potential back injuries from moving equipment; Heat/Cold Stress; 	<ul style="list-style-type: none"> Communication with other personnel/heavy equipment operators to notify them of survey team presence; Position a company truck with flashers on for added protection and to aid in the protection of the survey crew as they set up the TTCZ; Follow hot/cold stress procedures presented in the HASP. Ensure fluid intake and clothing/PPE is appropriate for conditions. 	Survey Team

Job Safety Analysis (JSA) SURVEYING ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
4	Conduct survey activities	<ul style="list-style-type: none"> • Struck by oncoming traffic; • Slip/trip/fall; • Potential injuries from misuse of tools or use of tools in disrepair; • Splinters, eye injuries from broken stakes; • Utility strikes; • Biological hazards; • Weather. 	<ul style="list-style-type: none"> • Wear hi-visibility safety vest, steel-toed boots, safety glasses, and hard hat; • Do not use old or faded PPE; • Make sure that proper PPE is being worn; • Notify nearby equipment of changes in you activities/movement through work area; • Inspect tools; • Repair/replace tools as necessary; • Visually inspect stakes prior to driving into ground. Do not use stakes that are cracked, split, have large knots, etc; • Perform utility clearance to with clients representative to verify presence of underground utilities to avoid driving grade stakes through any underground obstructions; • Watch for snakes, insects, animals, etc; avoid walking though tall grass and shrubs as much as possible; • Check weather prior to entering work area; • Should conditions be windy, wear spoggles (safety glass goggles) to prevent dirt and debris from getting into the eyes; • Wear sunscreen, as required; • If thunder is heard o lightning seen, leave work area immediately and take shelter; do not re-enter work area until 30 minutes after last lightning strike is seen 	Survey Team
5	Exit work zone	<ul style="list-style-type: none"> • Struck by oncoming traffic; • Slip/trip/fall; • Biological hazards; • Weather. 	<ul style="list-style-type: none"> • Walk through clear paths, especially when carrying equipment; watch for and avoid rough terrain as much as possible; • Note traffic patterns, make sure path to vehicle is clear and notify nearby equipment you are moving through their path; • Watch for snakes, insects, animals, etc; avoid walking though tall grass and shrubs as much as possible; • Check weather prior to entering work area; • Should conditions be windy, wear spoggles (safety glass goggles) to prevent dirt and debris from getting into the eyes; • Wear sunscreen, as required; • If thunder is heard o lightning seen, leave work area immediately and take shelter; do not re-enter work area until 30 minutes after last lightning strike is seen. 	Survey Team

¹ Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.

² A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"

³ Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".

Job Safety Analysis (JSA)

PERSONNEL AND SURVEY/SCREENING EQUIPMENT DECONTAMINATION ACTIVITIES

Field staff must review job-specific work plan and coordinate with project manager to verify that all up-front logistics are completed prior to starting work including, but not limited to, permitting, access agreements and notification to required contacts (e.g., site managers, inspectors, clients, subcontractors, etc.). Additionally, a tailgate safety meeting must be performed and documented at the beginning of each workday. **Stop, Think, Act, Review (STAR)** must be used prior to any activity. All personnel must possess the appropriate training prior to initiating scheduled tasks. Also consider weather conditions. All project personnel have the authority and responsibility to use **Stop Work Authority**.

Date Issued/Revised	July 2013	JSA Type	Personnel and Survey/Screening Equipment Decontamination Activities
Work Type	Construction	Client	General Electric Company and SI Group, INC.
Work Activity	Personnel and Survey/Screening Equipment Decontamination Activities		
Work Site	Friedrichsohn Cooperage Site. Town of Waterford, New York		
Key Equipment	Alconox/Liquinox, buckets water, brushes and or sponges		
Task-specific Training	40 HR and 8 HR HAZWOPER; PPE and HAZCOM		

MINIMUM REQUIRED PERSONAL PROTECTIVE EQUIPMENT (SEE JOB STEPS FOR TASK-SPECIFIC REQUIREMENTS)			
<input type="checkbox"/> REFLECTIVE VEST*	<input type="checkbox"/> GOGGLES	<input type="checkbox"/> APR: _____*	<input checked="" type="checkbox"/> GLOVES*
<input checked="" type="checkbox"/> HARD HAT	<input type="checkbox"/> FACE SHIELD*	<input type="checkbox"/> SUPPLIED AIR RESPIRATOR*	<input type="checkbox"/> COVERALLS*
<input type="checkbox"/> LIFELINE / HARNESS*	<input type="checkbox"/> HEARING PROTECTION*	<input checked="" type="checkbox"/> PPE CLOTHING*	<input type="checkbox"/> OTHER*
<input checked="" type="checkbox"/> SAFETY GLASSES	<input checked="" type="checkbox"/> STEEL TOED BOOTS	<input type="checkbox"/> OTHER* _____	<input type="checkbox"/> OTHER* _____
ADDITIONAL PPE: * Provide specific type(s) or descriptions of this item below			
Reflective Vest – Class II PPE Clothing – Polycoated Tyvek® suits			
Gloves – Inner Nitrile gloves (e.g., Ndex)			

Reviewed By	Position/Title	Date	Reviewed By	Position/Title	Date

Job Safety Analysis (JSA)

PERSONNEL AND SURVEY/SCREENING EQUIPMENT DECONTAMINATION ACTIVITIES

JOB STEPS ⁽¹⁾	TASK ACTIVITY	POTENTIAL HAZARD(S) ⁽²⁾	CORRECTIVE MEASURE(S) ⁽³⁾	Person Responsible
1	Perform the STAR Process and discuss Stop Work Authority (SWA) Perform Review of this JSA.	<ul style="list-style-type: none"> Failing to identify hazardous conditions resulting in losses or near losses. 	<ul style="list-style-type: none"> Perform the STAR Process. Assess the risks. Determine the hazards of performing the task and survey the work area. Consider weather conditions and review heat stress and cold stress information as applicable Always consider the worst case scenario. Analyze the hazards determined. Decide a plan of action to eliminate or reduce the hazards and act on it. 	Decontamination Personnel
2	Decontamination of survey/screening equipment	<ul style="list-style-type: none"> Contaminant exposure Pinch points Slip/trip/hit/fall hazards Lifting hazards Back injury Manual material handling 	<ul style="list-style-type: none"> Set up decontamination station to capture any spills to avoid cross-contamination and manage wastes Wear nitrile gloves Scrub applicable equipment clean then rinse and verify it is clean and free of contamination. In the case of monitoring equipment or sensitive equipment, use appropriate wipes to clean the equipment. Avoid putting hands in or near pinch points Maintain good housekeeping and be aware of surroundings Size up the load; if the object is too large or odd shaped OR is in excess of 50 pounds (23 kg) then assistance (mechanical means, such as a dolly, cart, or a buddy lift) will be required Lift with the legs (bend at the knees and use the leg muscles) to protect the lower back and keep lower back in a neutral position Refer to the HASP for additional lifting techniques 	Decontamination Personnel
3	Decontamination of personnel	<ul style="list-style-type: none"> Contaminant exposure Slip/trip/hit/fall hazards 	<ul style="list-style-type: none"> Refer to the HASP for specific procedures but in general start with most contaminated article and remove until inner gloves are the last item left Dispose of used PPE in accordance with site requirements Wash hands and face before eating, drinking, or using tobacco products Take care when removing PPE (boots, gloves, etc.); sit down to remove/change boots as necessary 	Decontamination Personnel
4	Management of waste derived from decontamination activities	<ul style="list-style-type: none"> Contaminant exposure Lifting hazards Back injury Manual material handling 	<ul style="list-style-type: none"> Containerize decontamination waste (e.g., water, used PPE) as required Wear medium duty gloves that meet the ANSI Cut and Abrasion Resistance Level 2 EN 388 3xx Testing Standard with nitrile gloves Properly dispose of decontamination fluids (e.g., wash waters) Size up the load; if the object is too large or odd shaped OR is in excess of 50 pounds (23 kg) then assistance (mechanical means, such as a dolly, cart, or a buddy lift) will be required Lift with the legs (bend at the knees and use the leg muscles) to protect the lower back and keep lower back in a neutral position Refer to the HASP for additional lifting techniques 	Decontamination Personnel

¹ Each Job or Task consists of a set of steps. Be sure to list all the steps in the sequence that they are performed. Specify the equipment or other details to set the basis for the potential (associated) hazards.

² A hazard is a potential danger. What can go wrong? How can someone get hurt? Consider, but do not limit, the analysis to: **Contact** - victim is struck by or strikes an object; **Caught** - victim is caught on, caught in or caught between objects; **Fall** - victim falls to ground or lower level (includes slips and trips); **Exertion** - excessive strain or stress / ergonomics / lifting techniques; **Exposure** - inhalation/skin hazards. Specify the hazards and do not limit the description to a single word such as "Caught"

³ Aligning with the Job Steps, Task Activity Description, and Potential Hazard columns, describe what actions or procedures are necessary to eliminate or minimize the hazards. Be clear, concise and specific. Use objective, observable and quantified terms. Avoid subjective general statements such as, "be careful" or "use as appropriate".

APPENDIX B

PROJECT SAFETY FORMS

ACCIDENT REPORTING FORM

Report all accidents immediately to the Safety and Health Officer

Instructions: For Personal Injuries, Property Damage, and Near Miss Reports, Complete Sections 1 and 2.
For Vehicle Accidents, Complete Sections 1, 2, and 4. Form must be completed within 24 hours.

SECTION 1

A. Employee Identification					() Employee	() Temporary Employee	() Subcontractor
Employee No.	Last Name	First Name		Middle Name/Initial	M or F		
Area Code ()	Telephone Number	Address (Street, City, State, Province, Zip Code)					
Date of Hire / /	Position/Title	Supervisor		Employee's Company/Office Location			
B. General Information							
Where did the accident occur? () Office () Project Site		Type of Occurrence () Near Miss () Employee Injury () Vehicle Accident () Property Damage Only					
Date and Hour of Accident		Date and Hour Reported to Employer		Date and Hour Last Worked		Time Employee Began Work	
Month	Day	Year	a.m. p.m.	Month	Day	Year	a.m. p.m.
Normal Work Hours on Last Day Worked		Witnesses?		Witness Name and Telephone Number			
From: a.m. To: p.m.		() Yes () No					
C. Project Information (Project Related Accidents/Near Misses Only)							
Project #	Project Name	Project Manager	Site Telephone Number ()	Employee Cell Number ()			
Was the Client Advised of the Accident? () Yes () No		Project Address (Street, City, State, Province, Zip Code)					
Name:		Specific Location of Accident					

SECTION 2




A. Details of the Accident/Near Miss	
1. What job/task was being performed when the accident occurred?	
2. Describe the employee's specific activities at the time of the accident. Include details of equipment/materials being used, including the size and weights of objects being handled.	
3. For injuries, identify the part of body injured, and specify left or right side.	
4. Identify the object or substance that directly injured employee and how.	
5. Identify Property Damaged (include owner of property, nature and source of damage, model and serial number, if appropriate).	
B. Health Care/Medical Treatment	
Employee received health care? () Yes () No	Identify the type of health care provided and where it was performed. (Check all that apply). () First Aid () Medical treatment other than first aid (sutures, etc.) () Hospitalized () Clinic () Hospital emergency room () On location by self or co-worker () On site by EMT
Name of Health Care Provider, Physician's Name, Address (Street, City, Province/State, and Postal/Zip Code)	

Section 2 (Continued)

C. Accident Investigation		
H&S plan prepared and on site? () Yes () Not applicable	Did the safety plan identify and provide safety procedures for the specific tasks the employee was conducting when injured? () Yes () No If no, why not? (Explain).	
Did the employee have the proper safety training to conduct these tasks or use the equipment? () Yes () No If not, why not?		
Identify all of the potential contributing factors and how they led to the occurrence of the accident. (Lack of attention, wrong use of equipment, lack of training, etc.)		
What contributing factor above was the underlying root cause of the accident.		
Is any training or retraining recommended? If yes, describe.		
What actions have been or will be taken to correct this accident from reoccurring?		
Additional information: Attach photos, accident diagrams, as applicable.		
Report Date Month Day Year	Report Prepared by: (please print)	Report Prepared by: (signature)

VEHICLE ACCIDENT SECTION
(Complete this Section for all Vehicle Accidents)

SECTION 4

A. Vehicle					
License Plate No.	State	Police Department	City	State	
Vehicle Year/Make/Model	Odometer Reading at Time of Accident		Police Report Number	Weather Conditions	
Name of Person Operating Vehicle		<div style="text-align: center;"> <p>"X" IN AREA OF VEHICLE DAMAGE</p>  </div>			
Address					
City	State/Province				Zip Code
Telephone: Area Code ()					
Vehicle Type: () Personal () Rental () CRA-Own					
Description of Vehicle Damage:					
B. Other Vehicles Involved					
Name of Owner		Address	City/State/Zip	Area Code and Telephone Number ()	
Operator's Name (if different from above)		Address	City/State/Zip	Area Code and Telephone Number ()	
Year/Make/Model	Description of Property Damage:		<div style="text-align: center;"> <p>"x" IN AREA OF VEHICLE DAMAGE</p>  </div>		
Insurance Co. Name & Telephone					
License Plate No./State/Province					
C. Injured Persons					
Name	Address Street, City, State/Zip Code	Phone Number	Nature of Injury	Indicate if Injured was a Vehicle Driver/ Passenger, Employee, Other, or Pedestrian	
1.					
2.					
3.					
D. Witnesses					
Name		Address Street, City, State/Prov./Zip Code		Area Code and Telephone Number	
1.				()	
2.				()	
E. Description of Accident					
<p>PLEASE COMPLETE OR ATTACH SEPARATE DIAGRAM</p> 		<p>Was Ticket Issued: _____ Reason: _____</p> <p>Other Operator <input type="checkbox"/></p> <p>Company Operator <input type="checkbox"/></p>			
Report Date Month Day Year		Report Prepared by: (please print)		Report Prepared by: (signature)	

Note: If Additional Space is Required to Complete this Report, Use Separate Sheet of Paper and Attach.

DAILY SAFETY MEETING FORM

PROJECT: FRIEDRICHSOHN COOPERAGE SITE

LOCATION: Waterford, New York

DATE/TIME: _____

1. Safety Issues or Topics Discussed:	
2. Work Summary and Physical/Chemical Hazards of Concern:	
Planned Activities:	
Physical hazards:	
Biological hazards:	
Chemicals onsite:	
3. Protective Equipment/Procedures:	
4. Emergency Procedure:	
MUSTERING POINT: Northwest corner of Intersection at Royal Avenue and 47th Street	
In event of an emergency gather/proceed to mustering point(s). Review Contingency Plan	
Emergency Procedures for Area(s) of activity.	
5. Signatures of Attendees (Handwriting must be legible):	

NL**CONESTOGA-ROVERS & ASSOCIATES (CRA) NEAR LOSS REPORTING FORM**

CRA Inc and Ltd – A Significant Near Loss must be called into Incident Hot Line: 1-866-529-4886
 CRA Europe – Incidents must be called into the Head Office during working hours (0115 965 6700)
 and to the CRA Europe Incident Hotline afterhours (0773 076 2845)



- Instructions:
- 1) Employee completes the Near Loss Report and submits to Supervisor.
 - 2) Supervisor reviews and makes other comments.
 - 3) Employee discusses Near Loss with Project Manager.
 - 4) Submit to Regional Safety & Health Manager

Report Status (insert date)	Initial Report	Update Report	Final Report	Verification/Validation	Report Input into SMART Database
--------------------------------	----------------	---------------	--------------	-------------------------	----------------------------------

SECTION 1

A. Employee Identification						<input type="checkbox"/> CRA Employee	<input type="checkbox"/> Temporary Employee	<input type="checkbox"/> Subcontractor
Employee No.	Last Name		First Name		Employee's Company - if Subcontractor			
Date of Hire	Position/Title		Supervisor		Home Office Location - if CRA Employee			
B. General Information								
Where did the Near Loss occur? <input type="checkbox"/> Office <input type="checkbox"/> Project Site <input type="checkbox"/> Other _____ <input type="checkbox"/> Canada <input type="checkbox"/> United States <input type="checkbox"/> UK				Type of Near Loss (Check all that apply) <input type="checkbox"/> Employee Injury/Illness <input type="checkbox"/> Vehicle Accident <input type="checkbox"/> Property Damage <input type="checkbox"/> Environmental				
Address of Near Loss (City, State/Province/County, Postal/Zip Code)				Specific Location of Near Loss (e.g., where on site)				
Date and Hour of Near Loss			Date and Hour Reported to CRA			Time Employee Began Work		
Month	Day	Year	a.m. p.m.	Month	Day	Year	a.m. p.m.	
Witnesses? <input type="checkbox"/> Yes <input type="checkbox"/> No		Witness Name and Telephone Number						
C. Project Information (Project Related Near Loss Only): Project Related: () Yes () No								
Project #	Project Name		CRA Project Manager		Client		Client Contact	
Was the Client Advised of the Near Loss? <input type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> N/A		Name:			Date and Time Month Day Year Time			

SECTION 2

A. Details of the Near Loss
1. What job/task was being performed when the Near Loss occurred? (Example: collecting groundwater samples).
2. Provide a detailed description of the employee's specific activities at the time of the Near Loss. Include details of equipment/materials being used, including the size and weights of objects being handled, and weather conditions at time of the Near Loss. If necessary, attach additional pages to the report.

B. Near Loss Investigation	
Conduct a 5-Why Root Cause Analysis Investigation. In addition, if there was the potential for a significant injury or loss, report the Near Loss to the Incident Hot Line (this will determine if a Tap Root Cause Analysis is necessary).	
HASP prepared? <input type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> N/A Submit a PDF of HASP to Investigation Team. If yes, was the HASP on site? <input type="checkbox"/> Yes <input type="checkbox"/> No	Did the safety plan identify and provide safety procedures for the specific tasks being performed when the Near Loss occurred? <input type="checkbox"/> Yes <input type="checkbox"/> No If no, why not? (Explain) _____ Did the employee utilize the STAR process before initiating the task? <input type="checkbox"/> Yes <input type="checkbox"/> No If no, why not? (Explain) _____

SECTION 2 (continued)

5-Why Root Cause:			Additional information: Attach photos, witness statement(s), affected employee statement, as applicable, to the end of this document.
1. Why did "above" happen?			
2. Why did "1" happen?			
3. Why did "2" happen?			
4. Why did "3" happen?			
5. Why did "4" happen?			
6. Why did "5" happen?			See Section 3 Below: Corrective Actions/ Verification and Validation
6. Why did "5" happen?			
C. Accountability			
Initial Report Date Month Day Year		Initial Report Prepared by: (please print)	Initial Report Prepared by: (signature)
Investigation Team		Company	Position/Title
Final Report Date Month Day Year		Final Report Prepared by: (please print)	Final Report Prepared by: (signature)
D. Stewardship			
Will a Near Loss Summary be Prepared? <input type="checkbox"/> Yes <input type="checkbox"/> No If yes, by:			
Quality Review By:	Date:	Findings:	

SECTION 3

Corrective Action					Validation & Verification		
CF	Corrective Actions (Must match Causative Factor)	Responsible Party	Due Date	Date Completed	Verified By/ Validated By	Date	Details
					Verified By		
					Validated By		
					Verified By		
					Validated By		
					Verified By		
					Validated By		

CRA 10 CAUSATIVE FACTORS (CF)

PERSONAL FACTORS		COMPANY FACTORS		EXTERNAL FACTORS	
1	Insufficient training for task	5	Incomplete or no procedures	10	Exposure to conditions
2	Hurrying to complete the task	6	Procedures not known or enforced		
3	Easier if proper process not followed	7	Improper PPE		
4	Took shortcuts without prior incident	8	Improper tools		
		9	Improper workplace layout		

**SAFETY INSPECTION CHECKLIST FOR EXCAVATIONS
REFERENCED BY OSHA STANDARDS**

This checklist is to be completed by the competent person at the start of work and as needed throughout the shift (i.e., after rain events, etc.). (A *competent person has been trained in the current OSHA excavation standard, is knowledgeable about soil analysis and protective systems, and has the authority to shut down the job.*)

Site Location: _____	Project #: _____
Date: _____ Time: _____	Competent Person: _____
Were visual soil tests made? If Yes, what type? _____	YES NO <input type="checkbox"/> Type: _____
Were manual soil tests made? If yes, what type? _____	YES <input type="checkbox"/> NO <input type="checkbox"/> Type: _____
Soil Type: _____	Signature: _____
Soil Classification: _____	
Excavation Depth: _____	Excavation Width: _____
Protective System Used: _____	

In the following table, please place an Y for Yes, N for No, or N/A for Not Applicable in the right hand column for each item. If No, place the date of correction.

	Subject	Y, N, or NA	Date Corrected
GENERAL INSPECTION OF THE JOB SITE			
1.	Does the competent person have the authority to remove employees from the excavation immediately?	Y	
2.	ARE SURFACE OBSTRUCTIONS REMOVED OR SUPPORTED?	Y	
3.	Are employees protected from loose rock or soil that could pose a hazard by falling or rolling into the excavation?	Y	
4.	Are hard hats worn by all employees?	Y	
5.	Are excavated soil, materials, and equipment placed at least 2 feet from the edge of the excavation?	Y	
6.	Are walkways and bridges over excavations 4 feet or more in depth equipped with standard guardrails and toe-boards?	N/A	
7.	Are warning vests or other highly visible clothing provided and worn by all employees exposed to public vehicular traffic?	Y	
8.	Are employees required to stand away from vehicles being loaded or unloaded?	Y	
9.	Is a warning system established and used when mobile equipment operates near the edge of the excavation?	N/A	
10.	Are employees prohibited from going beneath suspended loads?	N/A	
11.	Are employees prohibited from working on the faces of sloped or benched excavations above other employees?	N/A	
UTILITIES			
12.	Were utility companies contacted and/or utilities located?	N/A	
13.	Are the exact locations of the utilities marked?	N/A	
14.	Are underground installations protected, supported, or removed when excavation is opened?	N/A	
MEANS OF ENTERING AND EXITING THE TRENCH			
15.	Is the distance along the trench to an exit no greater than 25 feet in excavations 4 feet or more in depth?	N/A	
16.	IS A SUPPORT SYSTEM, SUCH AS UNDERPINNING, BEING USED?	N/A	
17.	Are ladders used in excavations secured and extended 3 feet above edge of the trench?	N/A	
18.	Are structural ramps used by employees designed by a competent person?	N/A	
19.	Are structural ramps used for equipment designed by a registered professional engineer?	N/A	
20.	Are employees protected from cave-ins when entering or exiting the excavation?	N/A	

Subject		Y, N, or NA	Date Corrected
WET CONDITIONS			
21.	Is water removal equipment monitored by a competent person?	Y	
22.	Is surface water or run-off diverted or controlled to prevent accumulation in the excavation?	Y	
23.	Are inspections made after every rainstorm or other hazard-increasing occurrence?	Y	
HAZARDOUS ATMOSPHERE			
24.	Is the atmosphere within the excavation tested where there is a reasonable possibility of an oxygen deficiency, combustible, or other harmful contaminant exposing employees to a hazard?	N/A	
25.	Are adequate precautions taken to protect employees from exposure to an atmosphere containing less than 19.5% oxygen and/or other hazardous atmospheres?	N/A	
26.	Is ventilation provided to prevent employee exposure to an atmosphere containing flammable gas 10% above the lower explosive limit of a gas?	N/A	
27.	Is testing conducted often to ensure that the atmosphere remains safe?	N/A	
28.	Is emergency equipment, such as breathing apparatus, safety harness and lifeline, and/or basket stretcher readily available where hazardous atmospheres could or do exist?	N/A	
SUPPORT SYSTEMS			
29.	Are materials and/or equipment for support systems selected based on soil analysis, trench depth, and expected loads?	N/A	
30.	Are materials and equipment used for protective systems inspected and in good condition?	N/A	
31.	Are protective systems installed without exposing employees to the hazards of cave-ins (including end walls), collapses, or threat of being struck by materials or equipment?	N/A	
32.	Are excavations below the level of the base, or footing supported, approved by a registered professional engineer?	N/A	
33.	Does the removal of support systems progress from the bottom and members are released slowly? Note any indication of possible failure.	N/A	
34.	Is the excavation of material a level no greater than 2 feet below the bottom of the support system and only if the system is designed to support the loads calculated for the full depth?	N/A	
35.	Is there a shield system placed to prevent lateral movement?	N/A	

TRAINING ACKNOWLEDGEMENT FORM

I have read or received instruction in the Site Health and Safety Plan and I understand the contents of the Site Health and Safety Plan. I have been informed whom to contact if I have any questions and I know where to report any additional health and safety hazards. I understand that I have “stop work” authority. I agree to work to the safety plan guidelines and understand that failure to do so could result in removal from the Site. **I will Stop Think Act Review prior to initiating a task.**

<i>Date</i>	<i>Printed Name</i>	<i>Signature</i>	<i>Company</i>

PROPERTY ACCESS/UTILITY CLEARANCE DATA SHEET

(QSF-019)

PROJECT NAME: _____ PROJECT NUMBER: _____

CRA REPRESENTATIVE: _____

CLIENT: _____ CLIENT REPRESENTATIVE: _____ PHONE: _____

ON-SITE PROPERTY ACCESS APPROVAL _____ (OWNER OR AUTHORIZED AGENT SIGNATURE)

OFF-SITE PROPERTY ACCESS APPROVAL (if applicable) _____ (OWNER OR AUTHORIZED AGENT SIGNATURE)

UTILITY CLEARANCE APPROVAL _____ (OWNER OR AUTHORIZED AGENT SIGNATURE)

CONTRACTOR VERIFICATION APPROVAL _____ (OWNER OR AUTHORIZED AGENT SIGNATURE)

UTILITIES (INDICATE THAT LOCATION/UTILITY PRESENCE WAS CHECKED) *

Borehole/ Excavation Location	Date (m/d/y)	Telephone	Water	Storm Sewer	Sanitary Sewer	Process Sewer	Gas	Electrical	Cable	Overhead Utilities	Other	Comments/Warnings

Additional Comments: _____

* Note as appropriate, Contractor, Client or Owner, or Agent to sign, indicating no utilities are at the selected borehole/excavation locations.

APPENDIX C

COMMUNITY AIR MONITORING PLAN

**COMMUNITY AIR MONITORING PLAN
DEVELOPED IN ACCORDANCE WITH THE NEW YORK STATE DEPARTMENT
OF HEALTH'S GENERIC COMMUNITY AIR MONITORING PLAN**

Overview

This site-specific Community Air Monitoring Plan (CAMP) requires real-time monitoring for volatile organic compounds (VOCs) and particulates (i.e., dust) at the downwind perimeter of each designated work area when certain activities are in progress at contaminated sites. The CAMP is not intended for use in establishing action levels for worker respiratory protection. Rather, its intent is to provide a measure of protection for the downwind community (i.e., off-site receptors including residences and businesses and on-site workers not directly involved with the subject work activities) from potential airborne contaminant releases as a direct result of remedial work activities. The action levels specified herein require increased monitoring, corrective actions to abate emissions, and/or work shutdown. Additionally, the CAMP will help to confirm that work activities do not spread contamination off site through the air.

Designated air monitoring station locations will be established around the perimeter of the site for use as monitoring locations. The site-specific CAMP presented below will be implemented during the soil removal and site restoration activities at the site. Each day that these activities are in progress one upwind and two downwind air monitoring stations will be set up to collect data. The instruments that will be used to collect the air monitoring data will have data logging capabilities. The data will be downloaded periodically, stored electronically and will be available to agency personnel for their review.

Reliance on this CAMP should not preclude simple, common sense measures to keep VOCs, dust, and odors at a minimum around the work areas.

Community Air Monitoring Plan

Real-time air monitoring for VOCs and particulate levels at the perimeter of the designated work area will be necessary, as described below.

Continuous monitoring will be required during all ground intrusive activities in contaminated areas and soil stabilization activities that will be conducted at the Site. Ground intrusive activities include, but are not limited to, contaminated soil excavation and handling activities.

Periodic monitoring for VOCs will be required during non-intrusive activities such as the collection of soil samples. Periodic monitoring during sample collection might reasonably consist of taking a reading upon arrival at a sample location, monitoring while overturning soil and then taking a reading prior to leaving a sample location.

VOC Monitoring, Response Levels, and Actions

VOCs will be monitored at the downwind perimeter of the designated work area (designated monitoring stations) on a continuous basis. Upwind concentrations should be measured at the start of each workday and periodically thereafter to establish background conditions, particularly if wind direction changes. The specific type of air monitoring equipment that will be used at the Site for VOC monitoring will be a MiniRae 3000, or equivalent. The equipment will be calibrated in accordance with the manufacturer's guidelines. The equipment will be capable of calculating 15-minute running average concentrations, which will be compared to the levels specified below.

1. If the ambient air concentration of VOCs at the downwind perimeter of the work area exceeds 5 parts per million (ppm) above background for the 15-minute average, work activities must be temporarily halted and monitoring continued. If the total organic vapor level readily decreases (per instantaneous readings) below 5 ppm over background, work activities can resume with continued monitoring.
2. If total organic vapor levels at the downwind perimeter of the work area persist at levels in excess of 5 ppm over background but less than 25 ppm, work activities must be halted, the source of vapors identified, corrective actions taken to abate emissions, and monitoring continued. After these steps, work activities can resume provided that the total organic vapor level 200 feet downwind of the designated work area or half the distance to the nearest potential receptor or residential/commercial structure, whichever is less - but in no case less than 20 feet, is below 5 ppm over background for the 15-minute average.
3. If the organic vapor level is above 25 ppm at the perimeter of the designated work area, activities must be shutdown.
4. All 15-minute readings must be recorded and be available for State (New York State Department of Environmental Conservation [NYSDEC] and the New York State Department of Health [NYSDOH]) personnel to review. Instantaneous readings, if any, used for decision purposes will also be recorded.

Particulate/Fugitive Dust Monitoring, Response Levels, and Actions

Particulate concentrations will be monitored continuously at one upwind and two downwind designated monitoring stations. The particulate monitoring will be performed using real-time monitoring equipment capable of measuring particulate matter less than 10 micrometers in size (PM-10) and capable of integrating over a period of 15 minutes (or less) for comparison to the airborne particulate action level. The particulate monitor that will be used will be a TSI 8520 DustTrak, or equivalent. The equipment will be equipped with an audible and/or visible alarm to indicate exceedance of the action level. In addition, fugitive dust migration should be visually assessed during all work activities.

1. If the downwind PM-10 particulate level is 100 micrograms per cubic meter (mcg/m^3) greater than background (upwind perimeter) for the 15-minute period or if airborne dust is observed leaving the designated work area, then dust suppression techniques must be employed. Work may continue with dust suppression techniques provided that downwind PM-10 particulate levels do not exceed $150 \text{ mcg}/\text{m}^3$ above the upwind level and provided that no visible dust is migrating from the designated work area.
2. If, after implementation of dust suppression techniques, downwind PM-10 particulate levels are greater than $150 \text{ mcg}/\text{m}^3$ above the upwind level, work must be stopped and a re-evaluation of activities initiated. Work can resume provided that dust suppression measures and other controls are successful in reducing the downwind PM-10 particulate concentration to within $150 \text{ mcg}/\text{m}^3$ of the upwind level and in preventing visible dust migration.
3. All readings must be recorded and be available for State (NYSDEC and NYSDOH) personnel to review.

The following fugitive dust suppression and corrective procedures will be employed at the Site.

1. Reasonable fugitive dust suppression techniques will be employed during all remedial activities, which may generate fugitive dust.
2. The following techniques are generally effective for the controlling of the generation and migration of dust during construction activities and may be employed as necessary:
 - (a) Applying water on haul roads
 - (b) Wetting equipment and excavation faces
 - (c) Spraying water on buckets during excavation and dumping
 - (d) Hauling materials in properly tarped or watertight containers
 - (e) Restricting vehicle speeds to 10 mph

- (f) Covering excavated areas and material after excavation activity ceases
- (g) Reducing the excavation size and/or number of excavations

When techniques involving water application are used, care must be taken not to use excess water, which can result in unacceptably wet conditions. Using atomizing sprays will prevent overly wet conditions, conserve water, and provide an effective means of suppressing the fugitive dust.

APPENDIX C

QUALITY ASSURANCE PROJECT PLAN

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	C-1
2.0 PROJECT DESCRIPTION	C-2
2.1 GENERAL	C-2
2.2 SITE BACKGROUND	C-2
3.0 PROJECT MANAGEMENT	C-3
4.0 QUALITY ASSURANCE OBJECTIVES FOR MEASUREMENT DATA	C-6
4.1 LEVEL OF QA EFFORT	C-6
4.2 ACCURACY, PRECISION, AND SENSITIVITY OF ANALYSES	C-7
4.3 COMPLETENESS, REPRESENTATIVENESS, AND COMPARABILITY	C-7
5.0 SAMPLING PROCEDURES	C-9
6.0 SAMPLE CUSTODY AND DOCUMENT CONTROL	C-10
6.1 FIELD LOG BOOK	C-10
6.2 SAMPLE LABELS	C-11
6.3 FIELD INSTRUMENT CALIBRATION AND USE LOGS	C-12
6.4 CHAIN-OF-CUSTODY RECORDS	C-12
6.5 SAMPLE SHIPMENT	C-12
6.6 LABORATORY SAMPLE CUSTODY LOG BOOKS	C-13
6.7 EVIDENTIARY FILES	C-13
7.0 CALIBRATION PROCEDURES AND FREQUENCY	C-15
7.1 INSTRUMENT CALIBRATION AND TUNING	C-15
7.1.1 GAS CHROMATOGRAPHY/MASS SPECTROMETRY (GC/MS)	C-15
7.1.2 GAS CHROMATOGRAPHY (GC)	C-16
7.1.3 INSTRUMENTATION FOR INORGANIC ANALYSES	C-16
7.1.4 FIELD INSTRUMENTATION	C-17
8.0 ANALYTICAL PROCEDURES	C-18
8.1 ANALYTICAL METHODS	C-18
8.2 COMPOUND IDENTIFICATION	C-18
8.3 QUANTITATION	C-18
8.4 QUANTITATION LIMIT REQUIREMENTS	C-19
9.0 DATA REDUCTION, VALIDATION, ASSESSMENT, AND REPORTING	C-20
9.1 GENERAL	C-20
9.2 LABORATORY REPORTING	C-21

TABLE OF CONTENTS

	<u>Page</u>
10.0	INTERNAL QUALITY CONTROL CHECKS AND FREQUENCY..... C-22
10.1	QC FOR FIELD MEASUREMENTS..... C-22
10.2	QC FOR LABORATORY ANALYSES..... C-22
10.2.1	REAGENT BLANKS C-22
10.2.2	MS/MSD ANALYSES C-22
10.2.3	SURROGATE ANALYSES..... C-22
10.2.4	LCS SAMPLES C-23
10.3	QC FOR SAMPLING PROTOCOL C-23
10.3.1	FIELD DUPLICATE SAMPLES..... C-23
10.3.2	FIELD BLANK SAMPLES..... C-23
11.0	PERFORMANCE AND SYSTEM AUDITS AND FREQUENCY C-25
11.1	LABORATORY C-25
11.2	FIELD C-25
12.0	PREVENTIVE MAINTENANCE..... C-26
13.0	SPECIFIC ROUTINE PROCEDURES USED TO ASSESS DATA PRECISION, ACCURACY, AND COMPLETENESS..... C-27
13.1	QA MEASUREMENT QUALITY INDICATORS..... C-27
13.1.1	PRECISION C-27
13.1.2	ACCURACY..... C-28
13.1.3	COMPLETENESS..... C-28
13.1.4	EXCEEDANCES C-28
14.0	CORRECTIVE ACTION..... C-29
15.0	QUALITY ASSURANCE REPORT TO MANAGEMENT C-30
16.0	REFERENCES..... C-31

LIST OF TABLES
(Following Text)

TABLE 4.1	SAMPLING AND ANALYSIS SUMMARY
TABLE 4.2	ORGANIC COMPOUND LIST AND PRACTICAL QUANTITATION LIMIT (PQL)
TABLE 4.3	INORGANIC COMPOUND LIST AND PRACTICAL QUANTITATION LIMIT (PQL)
TABLE 4.4	WASTE CHARACTERIZATION COMPOUND LIST AND REGULATORY LIMITS
TABLE 5.1	SAMPLE CONTAINER, PRESERVATION, AND HOLDING TIME PERIODS
TABLE 9.1	LABORATORY REPORTING DELIVERABLES - FULL
TABLE 9.2	LABORATORY REPORTING DELIVERABLES - STANDARD

LIST OF ATTACHMENTS

ATTACHMENT A	QA/QC OFFICER QUALIFICATIONS
--------------	------------------------------

1.0 INTRODUCTION

This Quality Assurance Project Plan (QAPP) presents the policies, organization, objectives, functional activities, and Quality Assurance (QA) and Quality Control (QC) activities designed to achieve the specific data quality goals associated with the Remedial Design/Remedial Action (RD/RA) and Groundwater Monitoring Plan (GWMP) for the Friedrichsohn Cooperage inactive hazardous waste site (the Site) located at 153-155 Saratoga Avenue in the Town of Waterford, New York. The RD/RA includes both the OU-1 and OU-3 upland areas and the OU-3 sediment. RD/RA work plans for the OU-1 and OU-3 Source Areas will be submitted separately from the RD/RA OU-3 Sediment work plan. This QAPP is intended to cover all sample collection activities for both RD/RA Work Plans and the Groundwater Monitoring Plan. This QAPP has been prepared in accordance with the following documents:

- 1) United States Environmental Protection Agency (USEPA) "Preparation Aids for the Development of Category III Quality Assurance Project Plans", EPA/600/8-91-005, February 1991.
- 2) New York State Department of Environmental Conservation (NYSDEC) Division of Hazardous Substance Regulation "RCRA Quality Assurance Project Plan Guidance", March 29, 1991
- 3) NYSDEC's "DER-10 Technical Guidance for Site Investigation and Remediation", May 3, 2010.

The objectives of the QAPP are to provide sufficiently thorough and concise descriptions of the measures to be applied during the RD/RA and groundwater monitoring programs such that the data generated will be of a known and acceptable level of precision and accuracy. The QAPP has been prepared to identify procedures for sample preparation and handling, sample chain-of-custody, laboratory sample analyses, and laboratory data reporting to be implemented during the remedial field activities to ensure the accuracy and integrity of the data generated.

Protocols for the collection of samples are presented in the Work Plans.

2.0 PROJECT DESCRIPTION

2.1 GENERAL

The objective is to satisfy the requirements of the Consent Order A5-0784-1202 (Order) executed on January 28, 2013 between NYSDEC and Respondents (General Electric Company and SI Group, Inc.).

The activities for the RD/RA and groundwater monitoring programs include the following:

- Predesign data collection including soil, sediment and groundwater sampling and analyses
- Routine groundwater monitoring for OU-2
- Active remediation including excavation of impacted soils and sediment
- Off-site transport and disposal of impacted soils and sediment
- Verification sampling following excavation
- Backfilling with clean imported soil
- Site restoration

2.2 SITE BACKGROUND

The Site location, description, and history are detailed in the Remedial Design/Remedial Action (RD/RA) Work Plan and the Groundwater Monitoring Plan.

3.0 PROJECT MANAGEMENT

The project management structure for QA/QC activities associated with the RD/RA and the groundwater monitoring program is discussed below, along with a brief description of the duties of the key personnel.

Keith Cowan/John Uruskyj - Project Manager

- Provides overall project management
- Participates in negotiations with the agencies involved
- Provides guidance to CRA's Project Manager

CRA Project Manager - Jamie Puskas

- Ensures professional services provided are cost effective and of the highest quality
- Ensures necessary resources are available on an as-required basis
- Participates in key technical negotiations with the agencies involved
- Provides managerial and technical guidance to the Project Engineer

CRA Design Coordinator - Jeff Daniel

- Provides day-to-day project management
- Provides managerial guidance to the project technical group
- Provides technical representation at meetings as appropriate
- Acts as liaison between the technical group and the client
- Acts as liaison with the agencies involved
- Prepares and reviews reports
- Conducts preliminary chemical data interpretation

CRA Quality Assurance/Quality Control Officer - Analytical Activities - Susan Scrocchi

- Overviews and reviews laboratory activities
- Determines laboratory data corrective action
- Performs analytical data validation and assessment
- Reviews laboratory QA/QC
- Assists in preparation and review of final report
- Provides technical representation for analytical activities

Quality Assurance/Quality Control Officer - Field Activities

- Provides immediate supervision of on-Site activities
- Provides field management of sample collection and field QA/QC
- Assists in preparation and review of final report
- Provides technical representation for field activities
- Is responsible for maintenance of the field equipment

Quality Assurance/Quality Control Site Coordinator - Field Activities

- The individual designated to be Site Coordinator will be specified prior to commencement of field activities
- Provides support to QA/QC Officer
- Conducts sample collection consistent with FSP and QAPP
- Manages subcontractors as directed by the QA/QC Officer

Laboratory Project Manager, Analytical Subcontractor

- Ensures resources of laboratory are available on an as-required basis
- Coordinates laboratory analyses
- Supervises laboratory's in-house chain of custody
- Schedules analyses of samples
- Oversees review of data
- Oversees preparation of analytical reports
- Approves final analytical reports prior to submission to CRA's QA/QC Officer

Laboratory Quality Assurance/Quality Control Officer, Analytical Subcontractor

- Overviews laboratory QA/QC
- Overviews QA/QC documentation
- Conducts detailed data review
- Decides laboratory corrective actions, if required
- Provides technical representation for laboratory QA/QC procedures

Laboratory Sample Custodian - Analytical Subcontractor

- Receives and inspects the sample containers
- Records the condition of the sample containers
- Signs appropriate documents

- Verifies chains of custody and their correctness
- Notifies laboratory project manager and laboratory QA/QC officer of sample receipt and inspection
- Assigns a unique laboratory identification number correlated to the field sample identification number, and enters each into the sample receiving log
- Initiates transfer of the samples to the appropriate lab sections with assistance from the laboratory project manager
- Controls and monitors access to and storage of samples and extracts

Primary responsibility for data quality rests with the QA/QC Officers. Ultimate responsibility for project quality rests with CRA's Project Manager. Independent QA will be provided by the laboratory's Project Manager and QA/QC Officer prior to release of the data to CRA.

The analytical laboratory chosen to perform the analyses will be certified by the New York State Department of Health (NYSDOH) through the environmental laboratory approval program for the appropriate categories of analysis. The name of the analytical laboratory and the laboratory QA/QC manual will be submitted to NYSDEC for review and approval prior to sample collection.

4.0 QUALITY ASSURANCE OBJECTIVES FOR MEASUREMENT DATA

The overall QA objective is to develop and implement procedures for sample collection and analyses of groundwater, soil and sediment which will provide data with an acceptable level of accuracy and precision.

The purpose of this Section is to define the QA goals required to meet the Data Quality Objectives (DQOs) of the project. QA goals for accuracy, precision, and sensitivity of analyses; and completeness, representativeness, and comparability of measurement data are established in the following sections.

The sampling and analysis program is summarized in Table 4.1.

4.1 LEVEL OF QA EFFORT

To assess the quality of data resulting from the field sampling program, field duplicate samples, field blank samples, samples for laboratory matrix spike/matrix spike duplicate (MS/MSD) analyses, trip blanks, and rinsate blank samples will be collected (where appropriate) and submitted to the contract laboratory.

For all field samples collected, field duplicate samples will be submitted at a frequency of one per 20 samples or in the event that a sampling round consists of less than 20 samples, one field duplicate will be collected. MS/MSD samples will be analyzed at a minimum frequency of one per 20 field samples. Rinsate blanks will be submitted at a frequency of one per 20 samples in the event that non-dedicated sampling equipment is used. Trip blanks will be submitted with each cooler containing aqueous samples for volatile organic compound (VOC) analyses.

The sampling and analysis program summarized in Table 4.1 lists the specific parameters to be measured, the number of samples to be collected and the level of QA effort required for each matrix.

Groundwaters, soil and sediment will be analyzed for VOCs, semi-volatile organic compounds (SVOCs), polychlorinated biphenyls (PCBs) and metals. Sediment samples may also be analyzed for Total Organic Carbon (TOC). Some soil samples may also be analyzed for waste characterization.

Target quantitation limits for compounds to be tested are presented in Tables 4.2 and 4.3. TCLP regulatory limits and analytes to be tested are presented in Table 4.4.

MS and MSD samples will be analyzed as a check on the analytical method's accuracy and precision. Trip blank samples (for VOC determinations only) will be shipped by the laboratory to the Site and back to the laboratory without opening in the field. The trip blank will provide a measure of potential cross-contamination of samples resulting from shipment, handling and/or ambient conditions at the Site. Rinsate blank samples will be collected and analyzed as a check on the efficiency of the sampling device cleansing protocols.

4.2 ACCURACY, PRECISION, AND SENSITIVITY OF ANALYSES

The fundamental QA objective with respect to the accuracy, precision and sensitivity of analytical data is to meet the QC acceptance criteria of each analytical protocol. Laboratory analytical parameters and methods are listed in Table 4.1 and target quantitation limits are listed in Tables 4.2 and 4.3.

The method accuracy (percent recovery) for groundwater, soil and sediment samples will be determined by spiking selected samples (matrix spikes) with representative spiking compounds as specified in the analytical methods. Accuracy will be reported as the percent recovery of the spiking compounds and will be compared to the criteria specified in the appropriate methods as identified in Section 8.0.

The precision of the methods (reproducibility between duplicate analyses) will be determined based on the analysis of field duplicate samples and the duplicate analysis of MS samples. Precision will be reported as relative percent differences (RPDs) between duplicate analyses; acceptance criteria will be as specified in the appropriate analytical methods identified in Section 8.0.

4.3 COMPLETENESS, REPRESENTATIVENESS, AND COMPARABILITY

A completeness requirement of 90 percent will be targeted for the RD/RA and the GWMP work (see Section 13.1.3 for a definition of completeness).

The quantity of samples to be collected has been determined in an effort to effectively represent the population being studied.

Analytical methods selected for this study are consistent with those used for previous studies (if applicable) to assure comparability of the data. All standards used by the laboratory will be traceable to reliable sources and will be checked with an independent standard.

5.0 SAMPLING PROCEDURES

All monitoring and sampling activities will be performed in accordance with the FSP and the Groundwater Monitoring Plan.

Sampling equipment will be decontaminated as specified in the FSP. Required sample containers, sample preservation methods, maximum holding times, and filling instructions are summarized in Table 5.1. Sample containers will be purchased from a USEPA-certified manufacturer and will be precleaned (I-Chem Series 200 or equivalent).

6.0 SAMPLE CUSTODY AND DOCUMENT CONTROL

The following documentation procedures will be used during sampling and analysis to provide chain-of-custody control during transfer of samples from collection through storage and analysis. Record keeping documentation will include use of the following:

- Field log books (bound with numbered pages) to document sampling activities in the field
- Labels to identify individual samples
- Chain-of-custody record sheets to document sample IDs and analyses to be performed
- Laboratory sample custody log books
- Evidentiary files

6.1 FIELD LOG BOOK

Log books will be used in the field to record information. The field log book will be bound and the information will be entered in indelible ink. Each field log book page will be signed by the sampler. Field measurements and observations will assist in the interpretation of analytical results obtained and it is important that these measurements and observations be as complete as possible.

For each sample collected, the following will be recorded in indelible ink in the field log book if applicable:

- i) Site location identification
- ii) Depth interval of sample
- iii) Unique sample identification number
- iv) Date and time (in 24:00-hour time format) of sample collection
- v) Weather conditions
- vi) Designation as to the type of sample (groundwater, soil, sediment, etc.)
- vii) Designation as to the means of collection (split spoon, etc.)
- viii) Brief description of the sample
- ix) Name of sampler
- x) Analyses to be performed on sample

- xi) Departure from established QA/QC field procedures
- xii) Instrument problems
- xiii) Other relevant comments such as odor, staining, texture, size of area sampled, etc.

6.2 SAMPLE LABELS

Sample labels are necessary to identify and prevent misidentification of the samples. The labels will be affixed to the sample container (not the caps) prior to the time of sampling. The labels will be filled out in waterproof ink at the time of collection. The labels will include the following information:

- i) Sample number/identification code
- ii) Name of collector
- iii) Date and time of collection
- iv) client and geographic location
- v) Project number
- vi) Required analysis
- vii) Type of preservation

A unique sample numbering system will be used to identify each collected sample. This system will provide a tracking number to allow retrieval and cross-referencing of sample information. The sample numbering system to be used is described as follows:

Example: GW-80987-110513 - AA-XXX
where: GW - Designates sample type
(GW - Groundwater, SE - Sediment, S - Soil)
80987 - ID number unique to the project site
110513 - date of collection (mm,dd,yy)
AA - sampler initials
xxx - unique sample number

QC samples will also be numbered with a unique sample number.

Sample container labels will include sample number, place of collection, and date and time of collection.

6.3 FIELD INSTRUMENT CALIBRATION AND USE LOGS

Standardized instrument calibration logs for each field instrument will be maintained during sampling activities to demonstrate properly functioning equipment. Included in the log should be documentation of time of instrument use, operator, and any maintenance performed.

6.4 CHAIN-OF-CUSTODY RECORDS

Chain-of-custody forms will be completed for samples collected during the program. chain-of-custody forms will be completed to document the transfer of sample containers.

The chain-of-custody record, completed at the time of sampling, will contain, but not be limited to, the sample number, date, and time of sampling, and the name of the sampler. The chain-of-custody document will be signed, timed, and dated by the sampler when transferring the samples.

The chain-of-custody form will consist of four copies which will be distributed to the shipper, the receiving laboratory, and two copies to CRA. The shipper will keep one copy while the other three copies will be enclosed in a waterproof envelope within the cooler with the samples. The laboratory, upon receiving the samples, will complete the three remaining copies. The laboratory will maintain one copy for their records; one copy will be returned to CRA upon receipt of the samples by the laboratory; one copy will be submitted to CRA with the data deliverables package.

6.5 SAMPLE SHIPMENT

All samples will be refrigerated using wet ice at <6°C. Custody seals will be placed around each cooler and the coolers will then be sealed with packing tape for shipment to the analytical laboratory within 24 to 48 hours of collection by either commercial courier or Subcontractor personnel.

6.6 LABORATORY SAMPLE CUSTODY LOG BOOKS

Upon receipt of the sample coolers at the laboratory, each sample cooler and the custody seal will be inspected by the designated sample custodian. The condition of the cooler and the custody seal will be noted on the chain-of-custody record sheet by the sample custodian.

The sample custodian will record the temperature of one sample (or temperature blank) from each cooler and the temperature will be noted on the chain-of-custody. If the shipping cooler seal is intact, the sample containers will be accepted for analyses. The sample custodian will document the date and time of receipt of the container, and sign the form.

If damage or discrepancies are noticed (including sample temperature exceedances), they will be recorded in the remarks column of the record sheet, dated and signed. Any damage or discrepancies will be reported to the lab supervisor who will inform the lab manager and QA Officer before samples are processed.

6.7 EVIDENTIARY FILES

The laboratory will be responsible for maintaining analytical log books and laboratory data as well as a sample (on hand) inventory for submittal to CRA on an as-required basis. Raw laboratory data produced from the analysis of samples submitted for this program will be inventoried and maintained by the laboratory for a period of 5 years at which time CRA will advise the laboratory regarding the need for additional storage.

Evidentiary files for the entire project will be inventoried and maintained by CRA and will consist of the following:

- i) Project-related plans
- ii) Project log books
- iii) Field data records
- iv) Sample identification documents
- v) Chain-of-custody records
- vi) Report notes, calculations, etc.
- vii) Laboratory data, etc.
- viii) References, copies of pertinent literature

- ix) Miscellaneous - photos, maps, drawings, etc.
- x) Copies of final reports pertaining to the project

The evidentiary file materials will be the responsibility of CRA's Project Manager with respect to maintenance and document removal.

7.0 CALIBRATION PROCEDURES AND FREQUENCY

7.1 INSTRUMENT CALIBRATION AND TUNING

Calibration of instrumentation is required to ensure that the analytical system is operating correctly and functioning at the proper sensitivity to meet established reporting limits. Each instrument is calibrated with standard solutions appropriate to the type of instrument and the linear range established for the analytical method. The frequency of calibration and the concentration of calibration standards is determined by the manufacturers' guidelines, the analytical method, or the requirements of special contracts.

A bound notebook will be kept with each instrument requiring calibration in which will be recorded activities associated with QA monitoring and repairs programs. These records will be checked during periodic equipment review and internal and external QA/QC audits.

7.1.1 GAS CHROMATOGRAPHY/MASS SPECTROMETRY (GC/MS)

It is necessary to establish that a given GC/MS meets the standard mass spectral abundance criteria prior to initiating any ongoing sample analyses and data collection. This is accomplished through the analyses of tuning compounds as specified in the analytical methods.

Calibration of the GC/MS system will be performed daily at the beginning of the day or with each 12 hours of instrument operating time when more than 12 hours of instrument operating time is needed in 1 day.

All method-specified calibration criteria will be met prior to sample analyses. All calibrations will be performed using either average response factors or first-order linear regression (with a correlation coefficient requirement of 0.995). Higher order fits will not be allowed unless the laboratory can demonstrate that the instrument is working properly, and that the instrument response over the concentration range of interest is second-order.

Quantification of samples that are analyzed by GC/MS will be performed by internal standard calibration. For quantitation, the nearest internal standard **free of interferences** will be used.

7.1.2 GAS CHROMATOGRAPHY (GC)

Quantification for samples that are analyzed by GC with element selective detectors will be performed by external standard calibration. Standards containing the compounds of interest will be analyzed at a minimum of three concentrations to establish the linear range of the detector. Single point calibration will be performed at the beginning of each day and at every tenth injection. The response factors from the single point calibration will be checked against the average response factors from multi-level calibration. If deviations in response factors are greater than those allowed by the analytical method protocols, then system recalibration will be performed. Alternatively, fresh calibration standards will be prepared and analyzed to verify instrument calibration.

All method-specified calibration criteria will be met prior to sample analyses. All calibrations will be performed using either average response factors or first-order linear regression (with a correlation coefficient requirement of 0.995). Higher order fits will not be allowed unless the laboratory can demonstrate that the instrument is working properly, and that the instrument response over the concentration range of interest is second-order.

7.1.3 INSTRUMENTATION FOR INORGANIC ANALYSES

All method-specified calibration procedures will be performed and acceptance criteria will be met prior to sample analyses. Standard curves derived from data consisting of one reagent blank and a minimum of three concentrations [one reagent blank and one concentration for ion coupled plasma (ICP)] will be prepared for each inorganic analyte. Calibrations will be performed using either average response factors, or first-order linear regression (with a correlation coefficient requirement of 0.995).

The standard curve will be used with each subsequent analysis provided the standard curve is verified by using at least one reagent blank and one standard at a level normally encountered or expected in such samples. If the results of the verification are not within ± 10 percent of the original curve, a new standard will be prepared and analyzed. If the results of the second verification are not within ± 10 percent of the original standard curve, the analysis will be stopped, and the analyst will reject any data obtained after the last acceptable verification standard. A reference standard will be used to determine if the discrepancy is with the standard or with the instrument. Once the cause is identified, a new calibration curve will be performed before sample analyses can continue.

New standards will also be prepared on a quarterly basis at a minimum. All data used in drawing or describing the curve will be so indicated on the curve or its description. A record will be made of the verification.

7.1.4 FIELD INSTRUMENTATION

Field equipment used during the RD/RA or groundwater monitoring program will be calibrated both prior to and following the day's utilization in accordance with the manufacturer's instructions. The equipment will also be operated in accordance with the manufacturer's instructions. Records of calibrations of field equipment will be recorded in a bound field notebook.

8.0 ANALYTICAL PROCEDURES

8.1 ANALYTICAL METHODS

All groundwater, soil and sediment samples will be analyzed for the parameters listed in Tables 4.2,4.3 and 4.4 using the methods cited in Table 4.1. These methods have been selected to meet the DQOs for each sampling activity.

Data deliverables for this program will be as specified in Section 9.2.

8.2 COMPOUND IDENTIFICATION

Compounds which will be analyzed by GC/MS will be identified by comparison of the sample mass spectrum with the mass spectrum of a standard of the suspected compound (standard reference spectrum). Mass spectra for standard references should be obtained on the user's GC/MS within the same 12 hours as the sample analysis. These standard reference spectra may be obtained through analysis of the calibration standards. The following criteria will be satisfied to verify identification:

- i) Elution of the sample component at the same GC relative retention time (RRT) as the standard component
- ii) Correspondence of the sample component and the standard component mass spectrum

For GC determinations of specific analytes, the RRT of the unknown will be compared with that of an authentic standard. Since a true identification by GC is not possible, an analytical run for compound confirmation will be followed according to the specifications in the methods. Peaks will elute within daily retention time windows established for each indicator parameter to be declared a tentative or confirmed identification. Retention time windows are determined using standard protocols defined in each method.

8.3 QUANTITATION

The procedures for quantitation of analytes are discussed in the appropriate analytical methods. Sample results are calculated using either an external standard or an internal standard technique. External standard techniques directly compare the response from the sample to the response of the target analyte in the calibration standards. Internal

standard technique utilizes the addition of a compound that resembles the target compound but is not commonly found in nature. This compound is added to all standards, samples, and QC samples. Quantitation is based on the ratio of the target compound in the sample to the response of the internal standard in the sample compared to a similar ratio derived for each calibration standard.

8.4 QUANTITATION LIMIT REQUIREMENTS

Targeted quantitation limits will be consistent with those presented in Tables 4.2 and 4.3. When matrix interferences are noted during sample analysis, actions will be taken by the laboratory to achieve the specified quantitation limits. Samples will not be diluted by more than a factor of five to reduce matrix effects. The laboratory will re-extract and/or use any of the cleanup techniques presented in the analytical methods to eliminate matrix interferences.

Samples may be diluted to a greater extent if the concentrations of analytes of concern exceed the calibration range of the instrument. In such cases, the laboratory QA/QC Officer will assure that the laboratory demonstrates good analytical practices and that such practices are documented in order to achieve the specified quantitation limits.

Soil and sediment results will be reported based on dry weight. The dry weight conversion will raise the targeted quantitation limit.

9.0 DATA REDUCTION, VALIDATION, ASSESSMENT, AND REPORTING

9.1 GENERAL

The contract laboratory will perform analytical data reduction and validation in-house under the direction of the laboratory QA Officer. The laboratory's QA Officer will be responsible for assessing data quality and advising of any data which were rated "preliminary" or "unacceptable" or other qualifications based on the QC criteria outlined in the analytical methods, which would caution the data user of possible unreliability. Data reduction, validation, and reporting by the laboratory will be conducted as detailed in the following:

- Raw data produced and checked by the responsible analysts is turned over for independent review by another analyst
- The area supervisor reviews the data for attainment of quality control criteria presented in the referenced analytical methods
- Upon completion of reviews and acceptance of the raw data by the laboratory operations manager, a computerized report will be generated and sent to the laboratory QA Officer
- The laboratory QA Officer will complete a thorough inspection of reports
- The laboratory QA officer and area supervisor will decide whether any sample reanalysis is required
- Upon acceptance of the preliminary reports by the laboratory QA officer, final reports will be generated and signed by the laboratory Project Manager

Validation of the analytical data pertaining to the monitoring wells will be performed by CRA's QA/QC Officer for analytical activities. The data validation will be performed utilizing guidance contained in the following documents: "USEPA Contract Laboratory Program National Functional Guidelines for Organic Data Review", EPA 540/R-08-01, June 2008 and "USEPA Contract Laboratory Program National Functional Guidelines for Inorganic Data Review", EPA 540/R-10-011, January 2010. Data analyzed using methods not covered in these documents will be validated using the general principles used in these documents, and the analytical requirements specified in the methods.

Assessment of analytical and in-house data will include checks on data consistency by looking for comparability of duplicate analyses, comparability to previous data from the same sampling location (if available), adherence to accuracy and precision control criteria detailed in this QAPP and anomalously high or low parameter values. Verification of 100 percent of QC sample results (both qualitative and quantitative) will

be performed. Verification of the identification of 100 percent of sample results (both positive hits and non-detects) will be performed and 10 percent of investigative sample results will be recalculated.

A Data Usability Summary Report (DUSR) will be prepared and will present the results of the data validation, including a summary assessment of laboratory data packages, sample preservation and chain-of-custody procedures, and a summary assessment of precision, accuracy, representativeness, comparability, and completeness for each analytical method. The DUSR will be submitted to CRA's Project Manager.

Data from field measurements and sample collection activities that are used in project reports will be appropriately identified and appended to the report. Where data have been reduced or summarized, the method of reduction will be documented in the report. Field data will be audited for anomalously high or low values that may appear to be inconsistent with other data.

The qualifications of CRA's QA/QC Officer are presented in Attachment A.

9.2 LABORATORY REPORTING

Reporting and deliverables will be in accordance with NYSDEC Analytical Services Protocol (ASP) Category B. The minimum deliverables required by the laboratory are summarized in Table 9.1. Reporting and deliverables for waste characterization samples (Toxicity Characteristic Leaching Procedure [TCLP] and Resource Conservation and Recovery Act [RCRA] analyses) shall include, but not be limited to, all items listed in Table 9.2. The laboratory will also include an electronic data deliverable in EQuis 4-file format.

All sample data and corresponding QA/QC data as specified in the analytical methods will be maintained accessible to CRA either in hard copy or on magnetic tape or disk.

10.0 INTERNAL QUALITY CONTROL CHECKS AND FREQUENCY

10.1 QC FOR FIELD MEASUREMENTS

Quality control procedures for field measurements will be limited to a check of the reproducibility of the measurement in the field by obtaining multiple readings and by calibrating the instrument (where appropriate).

10.2 QC FOR LABORATORY ANALYSES

Specific procedures related to internal laboratory QC samples are described in the following subsections.

10.2.1 REAGENT BLANKS

A reagent blank will be analyzed by the laboratory at a frequency of one blank per analytical batch. The reagent blank, an aliquot of analyte-free water or solvent, will be carried through the entire analytical procedure.

10.2.2 MS/MSD ANALYSES

An MS/MSD sample will be analyzed for all methods at the frequency specified in Table 4.1. Acceptable criteria and analytes that will be used for matrix spikes are identified in the analytical methods. Percent spike recoveries will be used to evaluate analytical accuracy while percent relative standard deviation or the relative percent difference (RPD) between duplicate analyses will be used to assess analytical precision.

10.2.3 SURROGATE ANALYSES

Surrogates are organic compounds which are similar to the analytes of interest, but which are not normally found in environmental samples. Surrogates are added to samples to monitor the effect of the matrix on the accuracy of the analysis. Every blank, standard and environmental sample analyzed by GC or GC/MS, including MS/MSD samples, will be spiked with surrogate compounds prior to sample preparation.

The compounds that will be used as surrogates and the levels of recommended spiking are specified in the methods. Surrogate spike recoveries will fall within the control

limits specified in the analytical methods. If surrogate recoveries are excessively low (<10 percent), the laboratory will contact CRA's QA/QC Officer for further instructions.

Dilution of samples to bring the analyte concentration into the linear range of calibration may dilute the surrogates out of the quantitation limit. Reanalysis of these samples is not required. Assessment of analytical quality in these cases will be based on the MS/MSD sample analysis results.

10.2.4 LCS SAMPLES

LCS samples (also known as QC Check Samples) will be analyzed to determine the accuracy of the analytical methods. LCS samples generally are prepared from standards that are from a different source than the calibration standards or are standard reference materials. The percent recoveries will be calculated and compared to the acceptance criteria. In most cases, sample analyses cannot proceed if the LCS acceptance criteria is not achieved. Corrective actions for outlying LCS data will be consistent with those specified in the methods.

10.3 QC FOR SAMPLING PROTOCOL

To assess the quality of data resulting from the field sampling program, field duplicate and field blank samples will be collected (where appropriate) and submitted to the analytical laboratory as samples.

10.3.1 FIELD DUPLICATE SAMPLES

Field duplicate samples will be collected at the frequency of one per 20 samples. These samples will be submitted "blind" to the laboratory for analysis, the results will be compared, and RPD values will be assessed against control limits of 50 percent for water samples and 100 percent for soil samples.

10.3.2 FIELD BLANK SAMPLES

Trip blanks for VOCs will be prepared by the laboratory using analyte-free water and submitted with the sample collection containers. The trip blanks will be kept unopened in the field with sample bottles. One trip blank will be transported to the laboratory

with each cooler of aqueous VOC samples. The laboratory will analyze trip blanks as samples.

Rinsate blanks will be used to assess decontamination procedures of collection equipment used for multiple samples. The rinse blank will be prepared using analyte-free deionized water when non-dedicated equipment is used in the field. The rinse blanks will be analyzed by the laboratory as samples. Rinse blanks will be prepared at the frequency of one per 20 samples in the event that non-dedicated sampling equipment is used.

11.0 PERFORMANCE AND SYSTEM AUDITS AND FREQUENCY

11.1 LABORATORY

For the purpose of external evaluation, performance evaluation check samples are analyzed periodically by the laboratory. Internally, the evaluation of data from these samples is done on a continuing basis over the duration of a given project.

CRA's QA/QC Officer may carry out performance and/or systems audits to insure that data of known and defensible quality are consistently produced during this program.

Systems audits are qualitative evaluations of all components of field and laboratory quality control measurement systems. They determine if the measurement systems are being used appropriately. The audits may be carried out before systems are operational, during the program, or after completion of the program. Such audits typically involve a comparison of the activities given in the laboratory's QA/QC plan described herein, with activities actually scheduled or performed. A special type of systems audit is the data management audit. This audit addresses only data collection and management activities.

The performance audit is a quantitative evaluation of the measurement systems used for a monitoring program. It requires testing the measurement systems with samples of known composition or behavior to quantitatively evaluate precision and accuracy. A performance audit may be carried out by or under the auspices of the laboratory's QA/QC Officer without the knowledge of the analyst during each sampling event for this program.

It should be noted, however, that any additional external QA audits will only be performed if deemed necessary.

11.2 FIELD

Audits of field techniques will be conducted by CRA's Field QA/QC Officer. These audits will include review of the sample collection and instrument calibration logbooks and chain-of-custody documents. Field inspections will also be performed to review: sample collection and handling techniques; on-Site supplies of sampling equipment and standards availability of relevant project documents.

12.0 PREVENTIVE MAINTENANCE

Analytical instruments to be used in this project will be serviced by laboratory personnel at regularly scheduled intervals in accordance with the manufacturers' recommendations. Instruments may also be serviced at other times due to failure. Requisite servicing beyond the abilities of laboratory personnel will be performed by the equipment manufacturer or their designated representative.

Daily checks of each instrument will be performed by the analyst who has been assigned responsibility for that instrument. Manufacturers' recommended procedures will be followed in every case.

Maintenance procedures and schedules and instrument logbooks will be documented in bound notebooks and made available to CRA's project QA/QC Officer upon request.

**13.0 SPECIFIC ROUTINE PROCEDURES USED TO ASSESS
DATA PRECISION, ACCURACY, AND COMPLETENESS**

13.1 QA MEASUREMENT QUALITY INDICATORS

13.1.1 PRECISION

Precision will be assessed by comparing the analytical results between duplicate spike or duplicate sample analyses. Precision as RPD will be calculated as follows for values significantly greater than the associated detection limit:

Matrix Spike/Matrix Spike Duplicate

$$\text{Precision} = \frac{\{D_2 - D_1\}}{\{D_1 + D_2 / 2\}} \times 100$$

D₁ = matrix spike recovery
D₂ = matrix spike duplicate recovery

Sample Duplicates

$$\text{Precision} = \frac{\{D_2 - D_1\}}{\{D_1 + D_2 / 2\}} \times 100$$

D₁ = original sample result
D₂ = duplicate sample result

For results near the associated detection limits, precision will be assessed based on the following criteria:

Precision = original result - duplicate result < Contract Required Detection Limits (CRDL)

13.1.2 ACCURACY

Accuracy will be assessed by comparing a set of analytical results to the accepted or "true" values that would be expected. In general, MS/MSD and check sample recoveries will be used to assess accuracy. Accuracy as percent recovery will be calculated as follows:

$$\text{Accuracy} = \frac{A-B}{C} \times 100$$

- A = The analyte determined experimentally from the spike sample
B = The background level determined by a separate analysis of the unspiked sample
C = The amount of spike added

13.1.3 COMPLETENESS

Completeness is a measure of the amount of valid data obtained from a measurement system compared with the amount that was expected to be obtained under normal conditions.

To be considered complete, the data set will contain QC check analyses verifying precision and accuracy for the analytical protocol. In addition, data are reviewed in terms of stated goals in order to determine if the database is sufficient.

When possible, the percent completeness for each set of samples will be calculated as follows:

$$\text{Completeness} = \frac{\text{valid data obtained}}{\text{total data planned}} \times 100 \text{ percent}$$

13.1.4 EXCEEDANCES

Procedures discussed previously will be followed for documenting deviations. In the event that a result deviates significantly from method established control limits, this deviation will be noted and its effect on the quality of the remaining data assessed and documented.

14.0 CORRECTIVE ACTION

The need for corrective action may be identified by system or performance audits or by standard QC procedures. The essential steps in the corrective action system will be:

- Checking the predetermined limits for data acceptability beyond which corrective action is required
- Identifying and defining problems
- Assigning responsibility for investigating the problem
- Investigating and determining the cause of the problem
- Determination of a corrective action to eliminate the problem (this may include reanalysis or resampling and analyses)
- Assigning and accepting responsibility for implementing the corrective action
- Implementing the corrective action and evaluating the effectiveness
- Verifying that the corrective action has eliminated the problem
- Documenting the corrective action taken

For each measurement system, the laboratory QA Officer will be responsible for initiating the corrective action and the laboratory supervisor will be responsible for implementing the corrective action.

15.0 QUALITY ASSURANCE REPORT TO MANAGEMENT

The CRA QA/QC Officer will receive reports on the performance of the measurement system and the data quality following each sampling round and at the conclusion of the project.

Minimally, these reports will include:

- Assessment of measurement quality indicator (i.e., data accuracy, precision, and completeness);
- Results of system audits
- QA problems and recommended solutions.

CRA's QA/QC Officer will be responsible within the organizational structure for preparing these periodic reports. The final report for the project will also include a separate QA section which will summarize data quality information contained in the periodic QA/QC reports to management, and present an overall data assessment and validation in accordance with the data quality objectives outlined in this QAPP.

16.0 REFERENCES

"Preparation Aids for the Development of Quality Assurance Project Plans", United States Environmental Protection Agency, Office of Research and Development, EPA/600/8-91/005, February 1991.

"RCRA Quality Assurance Project Plan Guidance", NYSDEC, August 1989.

"USEPA Region II CERCLA Quality Assurance Manual", Revision 1, October 1989.

"Test Methods for Evaluating Solid Waste" USEPA Office of Solid Waste, SW846 Third Edition, November 1986 (with revisions).

"DER-10 Technical Guidance for Site Investigation and Remediation", New York State Department of Environmental Conservation, May 2010.

TABLE 4.1

**SAMPLING AND ANALYSIS SUMMARY
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSOHN COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK**

<i>Sample Matrix</i>	<i>Analytical Parameters</i>	<i>Analytical Method¹</i>	<i>Investigative Samples</i>	<i>Field Duplicates</i>	<i>Rinsate Blanks</i>	<i>Trip Blanks</i>	<i>MS/MSD</i>
Groundwater	TCL Volatiles plus TICs	SW-846 8260	TBD	1/20	1/20	1/ Cooler	1/20
	TCL Semi-Volatiles plus TICs	SW-846 8270	TBD	1/20	1/20	-	1/20
	PCBs	SW-846 8082	TBD	1/20	1/20	-	1/20
	TAL Metals	SW-846 6010/7470	TBD	1/20	1/20	-	1/20
Soil	TCL Volatiles plus TICs	SW-846 8260	TBD	1/20	1/20	-	1/20
	TCL Semi-Volatiles plus TICs	SW-846 8270	TBD	1/20	1/20	-	1/20
	PCBs	SW-846 8082	TBD	1/20	1/20	-	1/20
	TAL Metals	SW-846 6010/7471	TBD	1/20	1/20	-	1/20
	TCLP Volatiles	SW-846 1311/8260	TBD	1/20	1/20	-	1/20
	TCLP Semi-Volatiles	SW-846 1311/8270	TBD	1/20	1/20	-	1/20
	TCLP Metals	SW-846 1311/6010/7471	TBD	1/20	1/20	-	1/20
	Ignitability	SW-846 1010	TBD	1/20	1/20	-	1/20
	Cyanide, Reactive (as Total)	SW-846 9014	TBD	1/20	1/20	-	1/20
	Corrosivity by pH (S. U.)	SW-846 9045	TBD	1/20	1/20	-	1/20
	Sulfide, Reactive (as Total)	SW-846 9030	TBD	1/20	1/20	-	1/20
Sediment	TCL Volatiles plus TICs	SW-846 8260	TBD	1/20	1/20	-	1/20
	TCL Semi-Volatiles plus TICs	SW-846 8270	TBD	1/20	1/20	-	1/20
	PCBs	SW-846 8082	TBD	1/20	1/20	-	1/20
	TAL Metals	SW-846 6010/7471	TBD	1/20	1/20	-	1/20
	TOC	Lloyd Kahn	TBD	1/20	1/20	-	1/20

Notes:

- (1) Methods referenced from "Test Methods for Evaluating Solid Waste - Physical/Chemical Methods", SW-846, Third Edition, 1986 (Revised 9/94).
Analysis of Water and Wastes", EPA-600/4-79-020, March 1983; for chloride, sulfate, nitrate-nitrite
- MS Matrix Spike.
MSD Matrix Spike Duplicate.
PCBs Polychlorinated Biphenyls.
TAL Target Analyte List.
TCL Target Compound List.
TICs Tentatively Identified Compounds.
- Not applicable.
TCLP Toxicity Characterization Leaching Procedure.

TABLE 4.2

**ORGANIC COMPOUND LIST AND
PRACTICAL QUANTITATION LIMIT (PQL)
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSON COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK**

	CAS Number	Quantitation Limits	
		Water (µg/L)	Soil/Sediment (µg/Kg)
<i>TCL Volatiles</i>			
1,1,2,2-Tetrachloroethane	79-34-5	10	10
1,1,2-Trichloroethane	79-00-5	10	10
1,1-Dichloroethane	75-34-3	10	10
1,1-Dichloroethylene	75-35-4	10	10
1,2-Dibromo-3-chloropropane	96-12-8	10	10
1,2-Dibromoethane	106-93-4	10	10
1,2-Dichloroethane	107-06-2	10	10
1,2-Dichloropropane	78-87-5	10	10
Bromodichloromethane	75-27-4	10	10
Bromoform	75-25-2	10	10
Carbon tetrachloride	56-23-5	10	10
Chlorobenzene	108-90-7	10	10
Chloroethane	75-00-3	10	10
Chloroform	67-66-3	10	10
cis-1,3-Dichloropropene	10061-01-5	10	10
Dibromochloromethane	124-48-1	10	10
Dichlorodifluoromethane	75-71-8	10	10
m-Dichlorobenzene	541-73-1	10	10
Bromomethane	74-83-9	10	10
Chloromethane	74-87-3	10	10
Methylene chloride	75-09-2	10	10
o-Dichlorobenzene	95-50-1	10	10
p-Dichlorobenzene	106-46-7	10	10
Tetrachloroethylene	127-18-4	10	10
trans-1,2-Dichloroethylene	156-60-5	10	10
trans-1,3-Dichloropropene	10061-02-6	10	10
Trichloroethylene	79-01-6	10	10
Trichlorofluoromethane	75-69-4	10	10
Vinyl chloride	75-01-4	10	10
4-Methyl-2-pentanone	108-10-1	10	10
2-Butanone	78-93-3	10	10
Benzene	71-43-2	10	10
Ethylbenzene	100-41-4	10	10
Styrene	100-42-5	10	10
Toluene	108-88-3	10	10
Xylene(total)	1330-20-7	10	10
1,1,1-Trichloroethane	71-55-6	10	10
2-Hexanone	591-78-6	10	10
Acetone	67-64-1	10	10
Carbon disulfide	75-15-0	10	10
1,1,2-Trichloro-1,2,2-trifluoroethane	76-13-1	10	10
Methyl Acetate	79-20-9	10	10
Methyl tert-Butyl Ether	1634-04-4	10	10
cis-1,2-Dichloroethene	156-59-2	10	10
Cyclohexane	110-82-7	10	10
Methylcyclohexane	108-87-2	10	10
Isopropylbenzene	98-82-8	10	10
1,2,4-Trichlorobenzene	120-82-1	10	10
<i>TCL Semi-Volatiles</i>			
2,4,6-Trichlorophenol	88-06-2	10	330
2,4-Dichlorophenol	120-83-2	10	330
2,4-Dimethylphenol	105-67-9	10	330
2,4-Dinitrophenol	51-28-5	25	830
2-Chlorophenol	95-57-8	10	330
4,6-Dinitro-o-cresol	534-52-1	25	830
o-Nitrophenol	88-75-5	10	330

TABLE 4.2

**ORGANIC COMPOUND LIST AND
PRACTICAL QUANTITATION LIMIT (PQL)
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSON COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK**

	CAS Number	Quantitation Limits	
		Water (µg/L)	Soil/Sediment (µg/Kg)
p-Chloro-m-cresol	59-50-7	10	330
Pentachlorophenol	87-86-5	25	830
Phenol	108-95-2	10	330
p-Nitrophenol	100-02-7	25	830
Bis(2-ethylhexyl) phthalate	117-81-7	10	330
Butyl benzyl phthalate	85-68-7	10	330
Diethyl phthalate	84-66-2	10	330
Dimethyl phthalate	131-11-3	10	330
Di-n-butyl phthalate	84-74-2	10	330
Di-n-octyl phthalate	117-84-0	10	330
2,4-Dinitrotoluene	121-14-2	10	330
2,6-Dinitrotoluene	606-20-2	10	330
Isophorone	78-59-1	10	330
Nitrobenzene	98-95-3	10	330
Acenaphthene	83-32-9	10	330
Acenaphthylene	208-96-8	10	330
Anthracene	120-12-7	10	330
Benzo[a]anthracene	56-55-3	10	330
Benzo[a]pyrene	50-32-8	10	330
Benzo[b]fluoranthene	205-99-2	10	330
Benzo[ghi]perylene	191-24-2	10	330
Benzo[k]fluoranthene	207-08-9	10	330
Chrysene	218-01-9	10	330
Dibenz[a,h]anthracene	53-70-3	10	330
Fluoranthene	206-44-0	10	330
Fluorene	86-73-7	10	330
Indeno(1,2,3 cd)pyrene	193-39-5	10	330
Naphthalene	91-20-3	10	330
Phenanthrene	85-01-8	10	330
Pyrene	129-00-0	10	330
2-Chloronaphthalene	91-58-7	10	330
Hexachlorobenzene	118-74-1	10	330
Hexachlorobutadiene	87-68-3	10	330
Hexachlorocyclopentadiene	77-47-4	10	330
Hexachloroethane	67-72-1	10	330
2,4,5-Trichlorophenol	95-95-4	25	830
2-Methylnaphthalene	91-57-6	10	330
3,3'-Dichlorobenzidine	91-94-1	10	330
4-Chlorophenyl phenyl ether	7005-72-3	10	330
Bis(2-chloroethoxy)methane	111-91-1	10	330
Bis(2-chloroethyl)ether	111-44-4	10	330
Dibenzofuran	132-64-9	10	330
m-Nitroaniline	99-09-2	25	830
N-Nitrosodiphenylamine	86-30-6	10	330
N-Nitrosodipropylamine	621-64-7 1	10	330
o-Cresol	95-48-7	10	330
o-Nitroaniline	88-74-4	25	830
p-Chloroaniline	106-47-8	10	330
p-Cresol	106-44-5	10	330
p-Nitroaniline	100-01-6	25	830
Benzaldehyde	100-52-7	10	330
2,2'-oxybis(1-Chloropropane)	108-60-1	10	330
Acetophenone	98-86-2	10	330
Caprolactam	105-60-2	10	330
1,1'-Biphenyl	92-52-4	10	330
4-Bromophenyl-phenylether	101-55-3	10	330
Atrazine	1912-24-9	10	330
Carbazole	86-74-8	10	330

TABLE 4.2

ORGANIC COMPOUND LIST AND
PRACTICAL QUANTITATION LIMIT (PQL)
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSON COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK

	CAS Number	Quantitation Limits	
		Water ($\mu\text{g/L}$)	Soil/Sediment ($\mu\text{g/Kg}$)
<i>PCBs</i>			
Aroclor-1016	12674-11-2	1.0	33
Aroclor-1221	11104-28-2	1.0	67
Aroclor-1232	11141-16-5	1.0	33
Aroclor-1242	53469-21-9	1.0	33
Aroclor-1248	12672-29-6	1.0	33
Aroclor-1254	11097-69-1	1.0	33
Aroclor-1260	11096-82-5	1.0	33
Aroclor-1262	37324-23-5	1.0	33
Aroclor-1268	11100-14-4	1.0	33

Notes:

- PCBs - Polychlorinated Biphenyls.
TCL - Target Compound List.

TABLE 4.3

INORGANIC COMPOUND LIST AND
PRACTICAL QUANTITATION LIMIT (PQL)
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSOHN COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK

<i>Parameters</i>	<i>CAS Number</i>	<i>Quantitation Limits</i>	
		<i>Water (µg/L)</i>	<i>Soil/Sediment (µg/Kg)</i>
<i>TAL Metals</i>			
Aluminum	7429-90-5	200	20
Antimony	7440-36-0	60	6.0
Arsenic	7440-38-2	10	1.0
Barium	7440-39-3	200	20
Beryllium	7440-41-7	5.0	0.5
Cadmium	7440-43-9	5.0	0.5
Calcium	7440-70-2	5000	500
Chromium	7440-47-3	10	1.0
Cobalt	7440-48-4	50	5.0
Copper	7440-50-8	25	2.5
Iron	7439-89-6	100	10
Lead	7439-92-1	5.0*	0.5
Magnesium	7439-95-4	5000	500
Manganese	7439-96-5	15	1.5
Mercury	7439-97-6	0.2	0.1
Nickel	7440-02-0	40	4.0
Potassium	7440-09-7	5000	500
Selenium	7782-49-2	5.0	0.5
Silver	7440-22-4	10	1.0
Sodium	7440-23-5	5000	500
Thallium	7440-28-0	10	1.0
Vanadium	7440-62-2	50	5.0
Zinc	7440-66-6	20	2.0
<i>General Chemistry</i>			
TOC	7440-44-0	-	1.0

Note:

TOC Total Organic Carbon.

TAL Target Analyte List.

TABLE 4.4

**WASTE CHARACTERIZATION COMPOUND LIST AND
REGULATORY LIMITS
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSON COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK**

<i>Parameters</i>	<i>Regulatory Limits</i>
<i>TCLP Volatiles (mg/L)</i>	
Vinyl chloride	0.2
1,1-Dichloroethene	0.7
Chloroform	6.0
1,2-Dichloroethane	0.5
2-Butanone	200
Carbon Tetrachloride	0.5
Trichloroethene	0.5
Benzene	0.5
Tetrachloroethene	0.7
Chlorobenzene	100
<i>TCLP Semi-Volatiles (mg/L)</i>	
Pyridine	5.0
1,4-Dichlorobenzene	7.5
2-Methylphenol	200
3- and/or 4-Methylphenol	200
Hexachloroethane	3.0
Nitrobenzene	2.0
Hexachlorobutadiene	0.5
2,4,6-Trichlorophenol	2.0
2,4,5-Trichlorophenol	400
2,4-Dinitrotoluene	0.13
Hexachlorobenzene	0.13
Pentachlorophenol	100
<i>TCLP Metals (mg/L)</i>	
Silver	5.0
Arsenic	5.0
Barium	100
Cadmium	1.0
Chromium	5.0
Lead	5.0
Mercury	0.2
Selenium	1.0
<i>RCRA Characteristics</i>	
Ignitability (° F)	<140
Cyanide, Reactive (as Total) (mg/Kg)	250
Corrosivity by pH (S. U.)	2.0-12.5
Sulfide, Reactive (as Total) (mg/Kg)	500
<i>Total Polychlorinated Biphenyls (µg/Kg)</i>	
Aroclor-1016	33
Aroclor-1221	67
Aroclor-1232	33
Aroclor-1242	33
Aroclor-1248	33
Aroclor-1254	33
Aroclor-1260	33
Aroclor-1262	33
Aroclor-1268	33

Note:

TCLP Toxicity Characteristic Leaching Procedures.

RCRA Resource Conservation and Recovery Act.

TABLE 5.1

**SAMPLE CONTAINER, PRESERVATION, AND HOLDING TIME PERIODS
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSOHN COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK**

<i>Matrix</i>	<i>Analyses</i>	<i>Sample Containers</i> ⁽¹⁾	<i>Preservation</i>	<i>Maximum Holding Time</i>	<i>Notes</i>
Water					
	TCL VOCs	Three 40 mL Teflon lined septum vials	Cool <6°C, HCl to pH<2	14 Days to analyses	Fill completely, no air bubbles
	TCL SVOCs	Two 1 liter amber glass bottles per analysis	Cool <6°C	7 Days to extraction 40 days from extraction to analysis	Fill to neck of bottles
	PCBs	Two 1 liter amber glass bottles per analysis	Cool <6°C	7 Days to extraction 40 days from extraction to analysis	Fill to neck of bottles
	TAL Metals (Except Mercury)	One 1 liter plastic bottle	HNO ₃ to pH<2, Cool <6°C	6 Months from collection to analysis	Fill to neck of bottles
	Mercury	One 1 liter plastic bottle	HNO ₃ to pH<2, Cool <6°C	28 Days to analysis	Fill to neck of bottles
Soil/Sediment					
	TCL VOCs	Three terracores (or equivalent) ⁽²⁾ One 2oz jar ⁽³⁾	Cool <6°C	48 Hours for preservation 14 Days to analyses	Fill per directions
	TCL SVOCs	One 4 oz. glass jar	Cool <6°C	14 Days to extraction 40 days from extraction to analysis	Fill to neck of bottles
	PCBs	One 4 oz. glass jar	Cool <6°C	14 Days to extraction 40 days from extraction to analysis	Fill to neck of bottles
	TAL Metals (Except Mercury)	One 4 oz. glass jar	Cool <6°C	6 Months from collection to analysis	Fill to neck of bottles
	Mercury	One 4 oz. glass jar	Cool <6°C	28 Days to analysis	Fill to neck of bottles
	TOC	One 4 oz. glass jar	Cool <6°C	28 Days to analysis	Fill to neck of bottles
Soil Waste Characterization					
	TCLP VOCs	Three 40 mL Teflon lined septum vials	Cool <6°C	7 days from collection to leaching 7 days from leaching to analysis	Fill completely, no air bubbles
	TCLP SVOCs	1 L Amber	Cool <6°C	5 days from receipt to leaching 7 days from leaching to extraction 40 days from extraction to analysis	Fill to neck of bottles
	TCLP Metals (except Mercury)	1-500 ml HDPE	Cool <6°C	180 days from receipt to leaching 180 days from leaching to analysis	Fill to neck of bottles
	TCLP Mercury	1-500 ml HDPE	Cool <6°C	5 days from receipt to leaching 28 days from leaching to analysis	Fill to neck of bottles
	RCRA Characteristics	2-500ml HDPE	Cool <6°C	Analyze immediately	Fill to neck of bottles

Notes:

- (1) Multiple parameters on a single sample with identical preservation requirements may be combined into one single sample container.
(2) Sediment samples may be too wet for Terracores and should be collected as a bulk sample.
(3) For dry weight determination and sediment collection, if necessary.
PCBs Polychlorinated Biphenyls.
TAL Target analyte list.
TCL Target compound list.
SVOC Semi-Volatile Organic Compound.
VOC Volatile Organic Compound.
TCLP Toxicity Characteristic Leaching Procedure.
RCRA Resource Conservation and Recovery Act.

TABLE 9.1

**LABORATORY REPORTING DELIVERABLES - FULL
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSOHN COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK**

A detailed report narrative should accompany each submission, summarizing the contents and results.

- A. Chain of Custody Documentation and Detailed Narrative ⁽¹⁾

- B. Sample Information
 - i) date collected
 - ii) date extracted or digested
 - iii) date analyzed
 - iv) analytical method and reference

- C. Data (including all raw data and CLP-like summary forms)
 - i) samples
 - ii) laboratory duplicates ⁽²⁾
 - iii) method blanks
 - iv) spikes; spike duplicates ⁽²⁾⁽³⁾
 - v) surrogate recoveries ⁽²⁾
 - vi) internal standard recoveries
 - vii) calibration
 - viii) any other applicable QC data (e.g., serial dilutions)
 - ix) TICs (if applicable)

- D. Miscellaneous
 - i) method detection limits and/or instrument detection limits
 - ii) percent solids (where applicable)
 - iii) metals run logs
 - iv) standard preparation logs
 - v) sample preparation logs

All sample data and its corresponding QA/QC data shall be maintained accessible to CRA either in hard copy or on magnetic tape or disc (computer data files). All solid sample results must be reported on a dry-weight basis.

Notes:

- (1) Any quality control (QC) outliers must be addressed and corrective action taken must be specified.
 - (2) Laboratory must specify applicable control limits for all quality control sample results.
 - (3) A blank spike must be prepared and analyzed with each sample batch.
- TICs Tentatively Identified Compounds.

TABLE 9.2

**LABORATORY REPORTING DELIVERABLES - STANDARD
REMEDIAL DESIGN/REMEDIAL ACTION
FRIEDRICHSOHN COOPERAGE SITE
TOWN OF WATERFORD, NEW YORK**

A detailed report narrative should accompany each submission, summarizing the contents and results.

- A. Chain of Custody Documentation and Detailed Narrative ⁽¹⁾

- B. Sample Information
 - 1. date collected
 - 2. date extracted or digested
 - 3. date analyzed
 - 4. analytical method and reference

- C. Final Results
 - 1. samples
 - 2. laboratory duplicates ⁽²⁾
 - 3. method blanks
 - 4. spikes, spike duplicates ^{(2) (3)}
 - 5. surrogate recoveries ⁽²⁾
 - 6. internal standard recoveries
 - 7. tentatively identified compounds (TICs) (if applicable)

- D. Miscellaneous
 - 1. method detection limits and/or instrument detection limits
 - 2. percent solids (where applicable)
 - 3. metals run logs
 - 4. sample preparation logs

All sample data and its corresponding quality assurance/quality control (QA/QC) data shall be maintained accessible to CRA either in hard copy or on magnetic tape or disc (computer data files). All solid sample results must be reported on a dry-weight basis.

Notes:

- ⁽¹⁾ Any QC outliers must be addressed and corrective action taken must be specified.
- ⁽²⁾ Laboratory must specify applicable control limits for all QC sample results.
- ⁽³⁾ A blank spike must be prepared and analyzed with each sample batch.

ATTACHMENT A

QA/QC OFFICER QUALIFICATIONS

EDUCATION

B.S. Chemistry, Canisius College, 1983

Other Training

USEPA Region II Training Course for CLP Organic Data Validation,

Westchester Community College, Dr. John Samuelian, March 1997

40-Hour HAZWOPER OSHA Training (per 29 CFR 1910.120), 2000

8-Hour HAZWOPER Refresher OSHA Training (per 29 CFR 1910.120), Annually

EMPLOYMENT HISTORY

2000-Present Conestoga-Rovers & Associates, Niagara Falls, NY

1996-00 Project Chemist, CRA Services

1983-96 Senior Organic Chemist, Advanced Environmental Services, Inc., Niagara Falls, NY

PROFESSIONAL REGISTRATIONS/AFFILIATIONS

Member, American Chemical Society

PROFILE OF PROFESSIONAL ACTIVITIES

- Stack Testing:
 - set up field gas chromatograph for on-site analyses
 - help develop methods for detection of various compounds in the field
- Innovative Technologies
 - Set up Gas Chromatographs (GCs) for the CRA Treatability Laboratory
 - Developed and conducted GC analyses for treated and untreated samples to monitor the removal of organic compounds
 - Performed training and oversight of organic extractions involving various matrices
- Project Chemist:
 - Oversight and review of analytical testing in support of NPDES projects
 - Assessment and validation of ASP, CLP, and SW-846 analytical data
 - Liaison with analytical laboratories in support of various investigative and remedial projects
 - Preparation of analytical laboratory bidding documents
 - Preparation of analytical Quality Assurance Project Plans (QAPPs)
 - Preparation of site sampling and analysis plans
 - Performance of laboratory audits and assessments

- Prepared a Laboratory Quality Control Manual for an application for National Environmental Laboratory Accreditation Program (NELAP) approval
- Training of plant personnel to perform required analytical methods for NELAP approval
- Senior Organic Chemist:
 - Provided administrative support for all department chemists and technicians
 - Provided a quality control check of all analytical data prior to submission
 - Prepared and maintained all analytical Standard Operating Procedures
 - Provided technical support for clients and agency personnel
 - Evaluated and developed new methods as needed
 - Technically proficient in all areas of organic testing, including sample extraction techniques and operation of gas chromatographs (GC) and gas chromatograph/mass spectrometers (GC/MS)
 - Proficient at performing routine maintenance and repairs on GC and GC/MS systems
- Database:
 - Basic training in database using Microsoft Access
 - Able to generate flat files
 - Import data and maintain the Shell database
- ISO Internal Auditor:
 - Internal ISO 9001 Auditor performing quality system checks on filing, document control, and other internal quality system guidelines

APPENDIX D

WASTE MANAGEMENT PLAN

TABLE OF CONTENTS

	<u>Page</u>
1.0 WASTE MANAGEMENT PLAN	1
1.1 OBJECTIVES AND SCOPE OF WORK	1
1.2 SITE PREPARATION.....	2
1.3 SEDIMENT	3
1.4 WASTEWATER AND LIQUIDS	3
1.5 CONSTRUCTION MATERIALS/DEBRIS/PPE.....	3

1.0 WASTE MANAGEMENT PLAN

1.1 OBJECTIVES AND SCOPE OF WORK

The following sections describe procedures and protocols for handling waste materials generated during the RD/RA activities. Potential types of wastes that may be generated include, but may not be limited to the following:

- Excavated sediment
- Drill cuttings
- Construction materials/debris (e.g., concrete, pipe)
- Waste water including decontamination water
- Personal Protection Equipment (PPE)

The following activities will be conducted as part of the Site RD/RA work plan:

- Collection of sediment samples
- Collection of bulk sediment samples to support bench scale treatability testing of sediments
- Installation of temporary controls to divert surface water around work areas
- Installation of temporary sheeting to isolate work areas to control groundwater infiltration (e.g., sheet piles, cofferdams or slurry walls)
- Excavation of contaminated sediment
- Verification sampling (e.g., establishment of dredge prisms)
- Backfilling with clean fill
- Temporary stockpiling of excavated sediment
- Dewatering of excavated sediment
- Transportation and off-Site disposal of excavated sediment
- Collection and off-Site disposal of drill cuttings and general waste (e.g., PPE)
- Restoration of canal bed

1.2 SITE PREPARATION

Prior to commencement of pre-design and construction activities, several temporary support facilities will be established at the Site. These additional support facilities will include:

Equipment Decontamination Area

An equipment decontamination area will be constructed prior to initiating ground intrusive work. Equipment and vehicles will be routed through this facility for decontamination and inspection prior to exiting the Site. A low-volume, high-pressure washer will be located at the decontamination facility for equipment cleaning. Liquid waste water generated from decontamination activities shall be collected in drums and temporarily stored in the waste staging area prior to off-Site disposal.

Waste Staging Area

A waste staging area will be constructed with an impermeable base and perimeter spill containment berm. The waste staging area will be used for temporary storage of drummed or containerized waste prior to off-Site disposal. In addition, the waste staging area will also function as a loading zone for drums/containers. Rainwater that comes in contact with contaminated material will be collected and disposed off Site.

Exclusion Zone

An exclusion zone (EZ) will be established around all areas where potentially impacted materials are to be excavated, handled or temporarily stored, and all areas where contaminated equipment or personnel travel. Work areas included within the EZ will be: excavation areas, waste staging area, and the decontamination area.

Demarcation of the EZ perimeter will be made by means of temporary construction fencing and/or barrier rope and colored tape which will be fixed at regular intervals to T-bars driven into the ground. Access to the EZ will be provided from the decontamination facility only.

Contaminant Reduction Zone

The contaminant reduction zone (CRZ) will be located at the interface of the EZ and Clean Zone and will provide for the decontamination of vehicles/equipment that have contacted potentially contaminated materials prior to leaving the EZ, the

decontamination of personnel and removal of PPE prior to entering the Clean Zone and for the physical segregation of the Clean Zone and EZ.

Clean Zone

The clean zone (CZ) is the portion of the Site defined as being the area outside the zone of significant air and waste contamination. The function of the CZ includes:

- Site entry for personnel, material and equipment
- Parking for personal vehicle
- The equipment compound

Site activities and controls shall be designed to prevent migration of contamination into the CZ from the EZ.

1.3 SEDIMENT

Dredged sediment will be dewatered/stabilized prior to being transported to an approved off-Site disposal facility. Bench scale treatability testing of sediments will be performed on bulk sediment samples to evaluate the effectiveness of gravity dewatering, mechanical dewatering, and solidification. Solidification reagents may be added to select materials to meet disposal facility requirements as opposed to mechanical dewatering the sediments.

1.4 WASTEWATER AND LIQUIDS

All liquids contacting waste materials (wastewater) will be collected in drums and stored in the waste staging area prior to being disposed off Site at a licensed liquid waste disposal facility. Wastewaters are anticipated to include decontamination water. Wastewater waste characterization samples will be analyzed for metals, SVOCs, PCBs, VOCs and RCRA characteristics.

1.5 CONSTRUCTION MATERIALS/DEBRIS/PPE

Clean construction waste (e.g., cut pieces of piping, wrappings, bags, etc) will be placed in a separate roll off box and disposed off Site as a non-hazardous solid waste.

Construction waste that has contacted potentially contaminated soils and used PPE will be placed in roll off containers along with the unsuitable excavated soils/sediment and drill cuttings and disposed off Site with that waste stream. Alternatively, if appropriate, the construction waste may be decontaminated and disposed off Site with the clean construction waste stream.

APPENDIX E

FIELD SAMPLING PLAN

TABLE OF CONTENTS

	<u>Page</u>
1.0 INTRODUCTION	E-1
2.0 GENERAL SAMPLING PROTOCOLS	E-2
3.0 SEDIMENT SAMPLING.....	E-3
3.1 SEDIMENT SAMPLING	E-3
4.0 GENERAL SAMPLING PROTOCOLS	E-8
4.1 SAMPLE HANDLING AND DOCUMENTATION.....	E-8
5.0 SAMPLING EQUIPMENT CLEANING.....	E-10
6.0 CHAIN-OF-CUSTODY	E-11
7.0 WASTE HANDLING	E-12

1.0 INTRODUCTION

This Appendix presents the Field Sampling Plan (FSP) for implementation of pre-design field activities associated with the Remedial Design/Remedial Action (RD/RA) Work Plan for Operable Unit (OU)-3 at the Friedrichsohn Cooperage Site (Site) in the Town of Waterford, New York. This report outlines the field sampling protocols that will be implemented during the following pre-design and remediation activities:

- Collection of sediment samples for chemical analysis
- Collection of bulk sediment samples for bench scale treatability testing
- Equipment cleaning
- Waste handling

2.0 GENERAL SAMPLING PROTOCOLS

The following general sampling procedures will be conducted for all sampling activities presented in this FSP.

- 1) Prior to sampling at each location, all sampling instruments and equipment will be cleaned in accordance with the protocols presented in Section 6.0.
- 2) Disposable gloves will be worn by samplers and changed between sampling points. Additional glove changes will be undertaken as necessary.
- 3) All sampling generated wastes such as gloves, Tyvek, etc., will be collected and consolidated with the waste material for proper disposal.
- 4) Samples will be labeled noting the location and/or interval, analysis required, preservative added, date, time and sampler's initials. A hardcover bound field book will be maintained to record all samples and sampling events. Details regarding recordkeeping and labeling are presented in the Quality Assurance Project Plan (QAPP).
- 5) Sample containers will be packed loosely in laboratory-supplied coolers to allow for placement of cushioning materials (i.e., vermiculite) between bottles to prevent breakage.
- 6) Following packing of the sample cooler, the completed chain-of-custody (see Section 7.0) will be placed in a watertight plastic bag and attached to the inside of the cooler lid.
- 7) A signed custody seal will be placed across the cooler closure and the cooler will then be sealed with packing tape. The packing tape will not completely cover the seal.
- 8) Samples will be handled and shipped in accordance with the protocols described in the QAPP.
- 9) All samples will be delivered to the laboratory via an overnight courier.
- 10) At the laboratory, all samples will be stored at 4 degrees Celsius (C) ± 2 degrees C.

3.0 SEDIMENT SAMPLING

As presented in the RD/RA Work Plan, the sediment investigation will include collection and analysis of 71 sediment samples throughout the Study Area. Additional samples will be collected, extracted, and archived for analysis as necessary to define the extent of material exceeding the SCG concentrations for PCBs. Sediment samples will be collected from varying depths to provide further definition of the concentrations of Site-related constituents in bioavailable sediments and to collect bulk material for treatability testing.

Proposed sediment sampling locations are presented in the RD/RA Work Plan.

The field sampling procedures for the sediment investigation are consistent with the approved Project Quality Assurance Project Plan (QAPP).

3.1 SEDIMENT SAMPLING

Sediment samples will be collected from the start depth of each location identified in Table 2.2 of the RD/RA Work Plan, and collected in 1-foot increments from the start depth down to bedrock. Each core will be advanced to until refusal is encountered. Cores with less than 60 percent recovery will be resampled; however, smaller intervals may be accepted based on difficult field conditions. Cores will be subsectioned into one ft intervals from the sampling start depth to the end of the core. The top intervals (top 1 ft) will be submitted for chemical analysis; all deeper intervals will be extracted and the extract stored for analysis if necessary. Samples will be analyzed moving downward from the starting sample interval until a sample with a PCB concentration below the SCG concentration is identified.

Field Procedures. Sediment core samples will be collected using an electrically powered vibracorer which is lowered through the water column under winch control and penetrates the sediment by means of its weight and powered vibration.

The following steps outline the procedures for using a vibracorer in the field.

1. Maneuver the sampling vessel to the proposed sampling location using DGPS and deploy a marker buoy at the location; record the water depth using a lead line or calibrated fathometer.

2. Check to ensure that the metal core barrel is securely fastened to the powerhead of the vibracorer and insert a decontaminated core liner inside the metal core barrel.
3. Insert a core catcher into the end of the barrel so that the catcher fingers will extend into the core liner, and then screw the cutter head onto the bottom of the core barrel until the shoulder snugs against the end of the core barrel. Tighten the cutter head with a spanner or strap wrench.
4. Start the electrical generator, but **DO NOT** yet energize the corer.
5. Signal the winch operator to hoist the corer and swing it over the stern or side of the vessel at the marked sampling location. Reposition the vessel if necessary. Record the water depth using a lead line or calibrated fathometer.
6. Signal the winch operator to lower the corer through the water column. Determine the depth of the corer in the water column and track its subsequent penetration into the sediment by either marking the winch line in 1 ft increments or by attaching a flexible tape measure to the powerhead.
7. When the cutter head is within approximately 10 ft of the bottom, energize the corer by actuating the circuit breaker on the generator control panel.
8. Slow the descent speed of the corer in order to determine when the core nose enters the sediment. Maintain tension on the winch line throughout the coring process to keep the corer from toppling over. The worker monitoring the penetration of the corer into the sediment will signal the winch operator when to pay out more line.
9. If refusal is encountered or if the measured distance to the tip of the core nose indicates that project depth has been reached, stop paying out line and de-energize the corer. Do not power down the generator. Refusal is indicated by less than 6 inches of penetration in a given 30-second interval.
10. Signal the winch operator to bring the winch line taut. Maneuver the boom or the boat until the winch pulley is directly above the corer, as indicated by the winch line being as close to true vertical as possible.
11. Record the position of the actual coring location. The navigation antenna may be mounted on the winch boom near the pulley to place it directly over the corer.
12. Signal the winch operator to retrieve the corer. If the corer is stuck in the bottom, energize the power head while maintaining tension on the winch line. To reduce the risk of losing sediment from the core barrel, de-energize the corer as soon as it shows any sign of vertical movement. As soon as retrieval of the corer is underway, power down the generator. Swing the corer over the deck and lower it to a holding rack. Note and record the length of smearing on the

outside of the core barrel, which gives an indication of the amount of penetration.

13. Use a spanner or strap wrench to unscrew the cutter head and remove it. The catcher may stay inside the cutter head or remain attached to sediment inside the core liner. Retain any sediment in the cutter head and core catcher for examination and possible use.
14. Pull the core liner approximately 6 inches out of the core barrel, remove the catcher, if necessary, and immediately cap the bottom end of the core liner with a plastic cap. Secure the bottom cap with duct tape.
15. Extract the core liner entirely from the core barrel, and immediately cap the top of the core liner.
16. If the core is to be cut into sections, draw a mark on the outside of the core liner where the cut will be made to cut off the bottommost section. Apply duct tape and use a permanent marker to mark the sections on both sides of the location of the future cut. Mark arrows pointing toward the top end of the core, write the core ID, write date and time, and indicate the depth interval spanned by the sections in terms of feet below mudline.
17. Cut the core at the section boundary using a saws-all loaded with a decontaminated blade. Another person will be at the ready to immediately cap both the exposed ends and secure with duct tape.
18. Repeat the cutting procedure if more sections need to be cut.
19. Remove the cap from the top end of the top-most section and drain the water. Draining may be accomplished by drilling a hole through the core liner just above the top of the sediment or by gently tipping the section to empty the water out the top. Care must be taken to avoid loss of sediments during decanting, particularly "soupy" sediments with high water content.
20. After decanting, cut off the excess plastic tubing, cap the end at the sediment interface, and secure the cap with duct tape.
21. Evaluate the appearance and length of the core sample by examination through the clear plastic core liner. Note any stratigraphic intervals or other salient features on the core collection log sheet.
22. Store the core sections at 4°C ($\pm 2^\circ\text{C}$) in a refrigerator or iced cooler for subsampling and further processing (see below).
23. Complete any additional entries on the coring field form.

Core Acceptance Criteria. Acceptance criteria for sediment core samples are as follows:

- The core penetrated to target depth
- The core did not suffer significant sample-induced compaction or loss of material (i.e., recovery greater than 60 percent, as measured by recovery length divided by penetration length)
- Cored material did not extend out the top of the core tube or contact any part of the sampling apparatus at the top of the core tube
- There are no obstructions in the cored material that might have blocked the subsequent entry of sediment into the core tube, which may have resulted in an incomplete and biased core section

If sample acceptance criteria are not achieved, the sample will be rejected and a repeated deployment will be made as close as possible to the original location. If redeployment does not result in an acceptable sample according to these criteria, the Project Manager will be contacted to discuss relocating the proposed core sample.

Core Processing. The following steps outline the general procedures to be followed when cores are split, logged, and subsampled for laboratory analysis.

1. All equipment coming into contact with sediment will be decontaminated before use with each sample to avoid cross contamination.
2. Cut the core liner longitudinally on opposite sides using a small jig or reciprocating saw. Pull away the top half of the core liner to expose the sediment sample.
3. Log and describe the sediment on a core log form according to standard ASTM soil description procedures. Core logs should include:
 - a. Visual grain size classification
 - b. Color
 - c. Consistency (stiffness or denseness)
 - d. Odor
 - e. Presence of debris
 - f. Presence of biological activity (e.g., detritus, shells tubes, bioturbation, live or dead organisms)
 - g. Presence of oil sheen
 - h. Any other unusual or distinguishing characteristics

4. After the sediment description is complete, subsample the core on two ft intervals (based on in situ conditions). The ex situ core intervals will be corrected for compaction, and therefore may be somewhat less than two ft in actual length.
5. Homogenize each depth interval using a stainless steel mixing spoon or an electric drill with a stainless steel paddle.
6. Collect samples of the homogenized sediment as appropriate for chemical and/or radioisotope analysis. Label sample jars and place them in refrigerators or coolers with blue ice to maintain sediment at 4°C until dispatched under chain of custody to the appropriate laboratory. Samples designated for archiving will be frozen for possible future analysis.

Additional cores will be co-located with investigative cores. Sediment from the upper 4 feet will be homogenized in a bulk sample for treatability sample analysis as outlined in the RD/RA Work Plan. Core locations for collection of bulk samples will be selected in the field to provide coverage of the areas of potential sediment removal in the canal.

Analytical methods, detection limits, and QA/QC requirements are provided in the QAPP.

4.0 GENERAL SAMPLING PROTOCOLS

4.1 SAMPLE HANDLING AND DOCUMENTATION

Samples will be collected at the locations and frequencies specified in this Work Plan. The following protocols will be employed during all sampling:

1. All sampling instruments and equipment will be cleaned in accordance with the protocol presented herein prior to collecting samples for chemical analysis at each location.
2. A new pair of disposable nitrile gloves will be used at each sampling location for chemical analysis. Additional glove changes at each sample location will be made if the gloves are observed to be torn, if the gloves are suspected of being soiled from a source other than the sample media itself, or at the discretion of the Field Task Leader.
3. Quality assurance samples will be collected as outlined in the QAPP
4. All sampling generated wastes such as gloves, tyvek, etc. will be collected and containerized for proper disposal.
5. Samples will be labeled with the following information:
 - a) Project name
 - b) Unique sample ID/number (e.g., SE-70267-MM-DD-YYYY-XX-01)
 - c) Sample interval (if appropriate)
 - d) Analysis required
 - e) Preservative added (if appropriate)
 - f) Date and time
 - g) Sampler's initials
6. A hard cover bound field book and/or field forms will be maintained to record all samples and sampling events. The field book will record, at a minimum, the following information:
 - a) Project name and location
 - b) Project number
 - c) Date and time of entry (24-hour clock)
 - d) Time and duration of daily sampling activities
 - e) Weather conditions and water level
 - f) Variations, if any, from specified sampling protocols and reasons for deviations

- g) Name of person making entries and other field personal present
 - h) Onsite visitors, if any
 - i) Specific information on each type of sampling activity
 - j) The station name, date, gear, water depth, and location coordinates
 - k) Station identifiers and sample numbers for all samples collected each day
7. Containers for sample collection, handling, and preservation requirements will be determined by the analytical laboratory as required by the laboratory's standard operating procedures (SOPs) and the analytical method. All sample bottles will be provided pre-cleaned by the laboratory.
8. Sample shipments for chemical analysis will be iced in supplied coolers after collection and labeling to minimize sample temperatures at 4°C. Any remaining space will be filled with packing to cushion the containers within the shipment coolers. A completed chain-of-custody form will be sealed in plastic and affixed to the inside lid of each cooler. Each cooler will be sealed in two places with custody seal and the sampler's name. The cooler will be then sealed with packing tape.
9. Samples will be shipped to the analytical laboratory under chain-of-custody procedures using an overnight service.

5.0 SAMPLING EQUIPMENT CLEANING

Prior to mobilization of sampling equipment and commencing work, all sampling equipment will be thoroughly cleaned to remove oil, grease, mud, and other foreign material. Subsequently, before sampling each location, samplers and associated equipment will be cleaned to prevent cross-contamination from the previous sampling location. Cleaning will be accomplished by flushing and wiping the components to remove all visible particulates and other solid material followed by a thorough high pressure water wash.

Equipment not used for collection of samples for chemical analyses will be cleaned as follows:

- 1) Clean off any gross contamination with a stiff brush
- 2) Wash and scrub using laboratory grade non-phosphate detergent
- 3) Rinse with potable water

Reusable equipment (e.g., stainless steel spoons and bowls, etc.) used for the collection of samples to be submitted for chemical laboratory analyses will be cleaned prior to use and between each sampling events/location using the following rinse sequence.

- 1) Wash and scrub with potable water and low phosphate detergent.
- 2) Rinse with potable water.
- 3) Rinse with 10 percent ultrapure HNO₃, (dilute to 1 percent HNO₃ if carbon samplers utilized).
- 4) Rinse with potable water.
- 5) Rinse with methanol.
- 6) Thoroughly rinse with deionized demonstrated analyte-free water. The volume of water used must be at least five times the volume of solvent used in step 5).
- 7) Air dry for 15 minutes.
- 8) Following the final rinse, sampling equipment will be visually inspected to verify that it is free of particulates and other solid material which may contribute to possible sample cross-contamination. Fluids used for cleaning will not be recycled. Washwater, rinse water, and decontamination fluids will be collected and disposed of off site following waste characterization sampling.
- 9) Excess sediment will be returned to the river at the corresponding sample location.

6.0 CHAIN-OF-CUSTODY

Samples will remain in coolers under the control of the sampling personnel in the field until relinquished to the delivery firm or directly to the laboratory. Chain-of-custody documents will be completed for each sample cooler. The original and two copies of each chain-of-custody will be placed within the cooler. The fourth copy will be retained by the sampler. In addition, Field Sampling Data Sheets and a sample log of samples collected and shipped off Site will be maintained on Site.

7.0 WASTE HANDLING

Decontamination water will be containerized and stored in a designated secure location until it is properly characterized, and disposed of in accordance with appropriate regulations.

All coveralls, gloves, etc. will be collected in plastic bags for disposal off Site.