
SITE CHARACTERIZATION WORK PLAN

RIVER ROAD SPOILS SITE

CORNING, STEUBEN COUNTY, NEW YORK

Prepared For:



New York State Department of Environmental Conservation
Division of Environmental Remediation
625 Broadway 12th Floor
Albany, New York 12233 – 7012

Prepared By:



301 Plainfield Road, Suite 350
Syracuse, New York 13212

JULY 2022

TABLE OF CONTENTS

SECTION 1	PROJECT OBJECTIVES AND BACKGROUND	1
1.1	Project Objectives	1
1.2	Project Background	1
SECTION 2	HEALTH AND SAFETY	2
SECTION 3	QUALITY CONTROL	3
3.1	Field Activities	3
3.2	Emerging Contaminants.....	3
SECTION 4	SURVEYS, INVESTIGATIONS, ENVIRONMENTAL SAMPLING, AND IMPLEMENTATION.....	4
4.1	Field Preparation	4
4.1.1	Geophysical Investigation.....	4
4.1.2	Site Layout and Proposed Boring Locations.....	5
4.2	Soil Investigation	5
4.2.1	Test Trenches.....	5
4.2.1.1	Installation	5
4.2.1.2	Sampling	6
4.2.2	Soil Borings	7
4.2.2.1	Installation	7
4.2.2.2	Sampling	7
4.3	Sediment and Surface Water Investigation	8
4.3.1	Sediment Coring.....	8
4.3.2	Sediment Sampling.....	9
4.3.3	Surface Water Sampling.....	9
4.4	Groundwater Investigation.....	9
4.4.1	Monitoring Well Installation.....	10
4.4.2	Monitoring Well Development.....	10
4.4.3	Monitoring Well Sampling.....	11
4.5	Site Survey	11
4.6	Waste Handling	12
SECTION 5	REPORT PREPARATION.....	13

SECTION 6	SCHEDULE	14
SECTION 7	REFERENCES.....	15

LIST OF FIGURES

- Figure 1 River Road Spoils Site Location
- Figure 2 River Road Spoils Site Proposed Sample Locations

LIST OF TABLES

- Table 1 Analytical Data Summary for Site Characterization

LIST OF ATTACHMENTS

- Attachment 1 Community Air Monitoring Plan
- Attachment 2 Parsons Subsurface Soil Disturbance Protocol
- Attachment 3 NYSDEC Corning Area Glass Sampling Standard Operating Procedure

ACRONYMS

AHA	Activity Hazard Analysis	PFOA	perfluorooctanoic acid
bgs	below ground surface	PFOS	perfluorooctanesulfonic acid
bml	below mudline	PID	photoionization detector
CAMP	Community Air Monitoring Plan	PPE	personal protective equipment
EM	electromagnetic induction	PSHEP	Project Safety, Health, and Environmental Plan
FAP	Field Activities Plan	PVC	polyvinyl chloride
GPR	ground-penetrating radar	QA/QC	quality assurance/quality control
GPS	global positioning system	QAPP	Quality Assurance Project Plan
HSA	hollow-stem auger	RF	radio frequency
HDPE	high-density polyethylene	SSC	State Sanitary Code
IDW	investigation-derived waste	SCOs	Soil Cleanup Objectives
MCL	Minimum Contaminant Levels	SGVs	Sediment Guidance Values
MS/MSD	matrix spike/matrix spike duplicate	SSHEP	Subcontractor Safety, Health, and Environment Plan
NAD 83	North American Datum of 1983	SVOCs	semivolatile organic compounds
NAVD 88	North American Vertical Datum of 1988	TCL	Target Compound List
NTUs	nephelometric turbidity units	TCLP	Toxicity Characteristic Leaching Procedure
NYSDEC	New York State Department of Environmental Conservation	VOCs	volatile organic compounds
NYSDOH	New York State Department of Health		
PET	polyethylene terephthalate		
PFAS	per- and polyfluoroalkyl substances		

SECTION 1 PROJECT OBJECTIVES AND BACKGROUND

1.1 Project Objectives

New York State Department of Environmental Conservation (NYSDEC), along with the New York State Department of Health (NYSDOH), have been overseeing the investigation and implementation of remedial activities associated with past disposal of waste materials from pre-cursor companies of Corning Incorporated.

Parsons proposes to assist NYSDEC with the site characterization efforts at the River Road Spoils site to:

1. Investigate potential impacts from target fill material containing ash, glass, and/or brick (glass manufacturing-related waste).
2. Investigate potential presence and location of contaminants in surface and subsurface soils.
3. Determine whether groundwater is being impacted.

The primary contaminants of concern, based on previous disposal of ash, glass, and/or brick, have been identified as arsenic, cadmium, lead, and semivolatile organic compounds (SVOCs). Investigations of neighboring properties are not included in this scope.

Tasks are further defined in subsequent sections, and include:

- Geophysical investigation and utility location
- Excavation of test pits and collection of soil samples
- Installation of soil borings and collection of soil samples
- Collection of sediment and surface water samples
- Construction of new monitoring wells and collection of groundwater samples
- Submittal of a final report

1.2 Project Background

The River Road Spoils site is a 26.37-acre property located in the Village of South Corning, New York, and is bounded by agricultural and forested land to the north, forested areas to the south, the Chemung River to the east, and by River Road and residential properties to the west. The site is located on the east side of River Road, south of the intersection with Caton Road, and extends south to the eastward bend in the roadway. The NYSDEC site number is #851070 and a site location map is shown on **Figure 1**.

The area is underlain by alluvial silts and fine sands. Site soils are likely derived from post-glacial flood-plain deposits that are expected to exhibit relatively low permeability. Groundwater likely exists within overburden sands. An assessment of local topography and proximity of the site to the Chemung River indicates groundwater will be encountered within the top 35 feet below ground surface (bgs), and presumably flows toward the Chemung River to the northeast.

Overburden soils in the vicinity of the site are likely underlain by Upper Devonian shale or siltstone. Bedrock depth at the site is unconfirmed but based on published information the top of bedrock is likely deeper than 80 feet bgs.

SECTION 2 HEALTH AND SAFETY

A *Project Safety, Health, and Environmental Plan* (PSHEP; Parsons 2020a) has been prepared for the investigation activities. All personnel and subcontractors working on the project are required to follow this plan for the work covered in this work plan. Copies of the PSHEP will be maintained at the support zone.

Prior to the start of work, the subcontractors shall submit a Subcontractor Safety, Health, and Environmental Plan (SSHEP) along with specific Activity Hazard Analyses (AHAs) for tasks to be performed under this work plan. Work cannot commence until SSHEP and AHAs are reviewed, and comments have been addressed. Copies of the SSHEP and AHAs will be maintained at the support zone.

A generic Community Air Monitoring Plan (CAMP) prepared for this contract will be implemented for real-time monitoring for volatile organic compounds (VOCs) and particulates (i.e., dust) at the upwind and downwind perimeter of each designated work area during invasive activities on-site. These readings will be provided on a weekly basis with all exceedances reported to NYSDEC and NYSDOH the same day (or next business day if after hours) along with the following:

- the reason for the exceedance
- what was done to correct the exceedance
- if the correction was effective

The Generic CAMP is included in Attachment 1 of this workplan. The Plan will follow the NYSDOH Generic CAMP as further detailed in DER-10 Appendix 1A (NYSDEC 2010), and recommended response levels and action(s) will be implemented in the event of exceedance.

SECTION 3 QUALITY CONTROL

3.1 Field Activities

Field activities will be conducted in accordance with the following documents, prepared by Parsons for the NYSDEC program:

- PSHEP (2020a)
- generic Quality Assurance Project Plan (QAPP; 2020b)
- Field Activities Plan (FAP; 2020c)

Site-specific elements and specific AHAs for soil borings, surface soil sampling, and monitoring well installation will be added to the PSHEP, as needed.

All proposed sample locations will be discussed with representatives of NYSDEC prior to implementation of this scope. Investigation/sample location may be modified with concurrence from NYSDEC.

3.2 Emerging Contaminants

Sampling will also be conducted for emerging contaminants as part of this investigation in general accordance with the applicable NYSDEC guidance, such as *Guidelines for Sampling and Analysis of PFAS* (NYSDEC, 2021). One of these contaminants is per- and polyfluoroalkyl substances (PFAS) compounds. PFAS can be found in many standard environmental sampling materials, including fluoropolymer bailer/tubing, some decontamination solutions, and pump bladders/valves. Two of the principal target analytes – perfluorooctanoic acid (PFOA) and perfluorooctanesulfonic acid (PFOS) – have been broadly utilized in the production of various everyday items such as: waterproof/stain-resistant clothing, non-stick cookware, and many commonly used plastics.

Another of the target analytes is 1,4-dioxane. This compound has been used in many products including the manufacturing of pharmaceuticals, personal care products, polyethylene terephthalate (PET) plastic, paint strippers, dyes, greases, varnishes, and waxes.

The field activities and methods in the FAP include steps to prevent cross-contamination, and to avoid the introduction of external contaminant sources. These steps include, but are not limited to:

- use of sampling materials, tools, and personal protective equipment (PPE) that are known to be free of emerging contaminants
- use of compatible apparel
- hygiene considerations
- sample management considerations
- quality assurance/quality control (QA/QC) procedures
- use of source water and decontamination solutions that are demonstrated to be free of emerging contaminants

SECTION 4 SURVEYS, INVESTIGATIONS, ENVIRONMENTAL SAMPLING, AND IMPLEMENTATION

Parsons' approach to the site characterization is described in the following sections. Each portion of the investigation work will follow NYSDEC guidelines outlined in Division of Environmental Remediation (DER)-10 Technical Guidance document (NYSDEC 2010).

The overall program consists of:

1. Geophysical investigation (utility mapping)
2. Site survey of utilities and as-built coordinates for soil borings
3. Subsurface investigation through installing soil borings and test pits, and collecting soil samples
4. Construction of monitoring wells and collection of groundwater samples
5. Sediment Samples
6. Surface water samples

4.1 Field Preparation

4.1.1 Geophysical Investigation

A geophysical investigation will initially be performed at the site to locate subsurface utilities and/or subsurface anomalies at proposed sample locations and test pits, which are shown in conjunction with site features on **Figure 1**.

Prior to initiation of site activities, Dig Safely NY will be contacted to locate utility lines that enter and/or cross the property. The geophysical survey will be conducted to detect buried structures and subsurface utilities within the specified locations, and/or to trace a particular utility line or system. The geophysical surveyor will apply the appropriate surface geophysical method(s) to search for utilities and/or buried obstructions. Geophysical technologies may include but not be limited to ground-penetrating radar (GPR), radio frequency (RF), and electromagnetic induction (EM). These techniques will be used to locate subsurface utility lines or subsurface features within a 10-foot radius of each proposed intrusive activity. Specific features may include subsurface utilities, subsurface anomalies, large voids, former subsurface structures, abandoned utilities, and former utility trenches. Based on an interpretation of data, the geophysical surveyor will mark the targets on the ground surface, for subsequent survey performed by others after the boring work and well installations are completed. Paint and flagging shall be used for marking of lines, showing any underground site utilities or obstructions.

Prior to intrusive work, Parsons will follow their *Subsurface Soil Disturbance Protocol* (see **Attachment 2**). Dig Safely New York will be called again prior to drilling activities. A geophysical utility locator will investigate and clear all boring locations for underground obstructions and utilities prior to drilling activities.

4.1.2 Site Layout and Proposed Boring Locations

The site characterization efforts will include the following proposed field sampling activities:

Matrix	Approach	Number of locations	Purpose
SOIL	Test Pits	3	Soil characterization, sample collection, laboratory analyses
	Soil Borings	14	Soil characterization, sample collection, laboratory analyses
GROUNDWATER	Monitoring Wells	3	Water table depth, sample collection, laboratory analyses
	Sediment Cores	7	Installed to 2 feet below mudline (bml) or bgs for sediment characterization, sample collection, laboratory analyses
SURFACE WATER	Grab samples	3	Surface water sample collection, laboratory analyses

The site layout with proposed sampling locations is shown in **Figure 2**.

Initially, the proposed sampling locations will be roughly located with a handheld global positioning system (GPS) and will consider surface and overhead features that may affect execution of field investigation activities. Following completion of the field investigation activities, a licensed professional land surveyor registered to practice in the State of New York will collect as-built data from the sample locations (as described in **Section 4.5 Site Survey**).

4.2 Soil Investigation

Soil characterization activities at the site consist of installing fourteen soil borings and three test pits. The proposed locations for each test pit and soil boring are shown on **Figure 2**. These proposed locations will be marked out during the site survey and will be verified following installation (**Section 4.5 Site Survey**). In the event that ABG material is identified, additional samples/sample locations may be added in consultation with NYSDEC.

Prior to intrusive work Dig Safely NY will be notified and a geophysical investigation will be conducted to identify underground utilities or buried obstructions at each proposed test pit or boring location (as described in **Section 4.1.1 Geophysical Investigation**).

4.2.1 Test Trenches

Three test trenches are proposed for excavation. The locations of proposed test pits were selected to visually assess and characterize subsurface soils at the site. The proposed locations for each test trench are shown on **Figure 2**. The proposed test trench locations will be marked out during the site survey and will be verified following excavation (**Section 4.5 Site Survey**).

4.2.1.1 INSTALLATION

Test trenches will be excavated to the following dimensions:

- Up to 25 feet long
- 2 feet wide
- 8 feet deep

Test trench dimensions may be modified in the field following discussion with the project manager and in concurrence with NYSDEC.

Test trenches will be installed using excavation equipment capable of reaching the maximum proposed depth. Track mats should be considered prior to accessing the proposed trench locations to minimize potential disturbances to ground surfaces at the site. During excavation, the operator will excavate thin layers of soil, and will be mindful of the potential to encounter any previously unidentified buried materials, containers, utilities, or a combination thereof. If the trench walls begin caving in, the sidewall may be cut back to prevent caving.

Excavated soils will be collected and logged from each test trench. Following excavation, field personnel should sketch both walls of the test trench, log the lithology of the side walls, and collect the requisite samples, as discussed in **Section 4.2.1.2 Sampling**. Soils will be visually classified using the Burmister (1970) and USCS (ASTM International 2018) soil classification systems. Soil descriptions will be recorded in the field notes or test pit log. Any non-native material present in the excavated soils will be noted and described (type, color, texture, moisture content, etc.) and any layer of fill material containing ash, brick and/or glass will be noted in the field logs. Photographs of recovered soils and any fill material containing ash, brick, and/or glass will be taken to provide in the final report. Excavated soils will also be screened for the presence of VOCs with a photoionization detector (PID) and readings will be recorded on the boring log and/or field book. The field crew should photograph the entirety of the test trench and surrounding site conditions.

Once the test trenches have been excavated to their total depth, approximately 8 feet bgs, and all requisite samples have been collected, the trenches will be backfilled using excavated material. All test trenches should be backfilled the same day as the excavation, or as soon thereafter as practical. Backfill should be placed in the bottom of the trench in one-foot lifts and compacted using the equipment bucket.

Excavating equipment will be decontaminated between trenches at the decontamination area using a high-pressure steam wash.

Grossly contaminated soils and decontamination rinsates will be containerized in 55-gallon steel drums and transported to a central waste staging area for further characterization and disposal.

4.2.1.2 SAMPLING

Up to six soil samples will be collected from each test trench. At a minimum, two of these soil samples will be collected and submitted for laboratory analysis based on the following criteria:

- If target fill material is encountered one sample will be collected from the target fill material itself, and another from the material directly below the fill layer.
- If target fill material is not encountered, one soil sample will be collected from the interval exhibiting the highest PID reading, or other evidence of impacts (staining or odors), or from the interval directly above the water table (if encountered). If the water table is not encountered, a sample should be collected from the bottom of the test trench.

Soil samples will be analyzed for the compounds listed in **Table 1**. Each sample will be analyzed for metals, Toxicity Characteristic Leaching Procedure (TCLP) metals, SVOCs, and 1,4-dioxane. The remaining parameters will be analyzed on 20 percent of the samples collected at locations based on field observations. Except for soils that will be analyzed for VOCs, each soil sample collected for laboratory analysis will be field homogenized prior to placement in laboratory-supplied bottles.

Archive samples will be collected if target fill material/waste glass is encountered, as described in **Attachment 3**.

For QA/QC purposes, duplicate samples, equipment blanks and matrix spike/matrix spike duplicate (MS/MSD) samples will be collected and analyzed at a rate of one for every 20 field samples. Trip blanks will also be

included in sample coolers containing field samples for VOC analyses; these trip blanks will be analyzed for Target Compound List (TCL) VOCs.

Results from the analytical sampling will be compared to Part 375 *Soil Cleanup Objectives* (SCOs; NYSDEC 2006).

4.2.2 Soil Borings

Fourteen soil borings are proposed for installation. The locations of proposed soil borings were selected to investigate and characterize the extent of potential impacts at the site. The proposed locations for each soil boring are shown on **Figure 2**. The proposed soil boring locations will be marked out during the site survey and will be verified following boring installation (**Section 4.5 Site Survey**).

4.2.2.1 INSTALLATION

Eleven soil borings, RRS-SB-04 through RRS-SB-14, will be installed to 25 feet bgs using direct push technology, and sampled continuously using a MacroCore Sampler (or equivalent). Three soil borings, RRS-SB-01 through RRS-SB-03, will be installed to 35 feet bgs using hollow stem auger (HSA) and sampled continuously using split-spoons.

Soil cores will be collected and logged continuously until borings are terminated. Soils will be visually classified using the Burmister (1970) and USCS (ASTM International 2018) soil classification systems. Soil descriptions will be recorded in the field notes or soil boring log form. Any non-native material present in the soil core will be noted and described (type, color, texture, moisture content, etc.) and any layer of fill material containing ash, brick and/or glass will be noted in the field logs. Photographs of recovered soils and any fill material containing ash, brick, and/or glass will be taken to provide in the final report. Each soil core will also be screened for the presence of VOCs with a PID, and readings will be recorded on the boring log and/or field book.

Monitoring wells will be constructed in three soils borings, RRS-SB-01 through RRS-SB-03. The monitoring wells will be constructed in accordance with **Section 4.4.1 (Monitoring Well Installation)**. The proposed well locations, RRS-MW-01 through RRS-MW-03, are shown on **Figure 2**. The ground surface around the well and surrounding area will be restored to conditions prior to intrusive activities. Track mats may be used to access the boring locations and minimize ground disturbances. The location, ground surface elevation, and top of casing elevation will be measured and recorded during the as-built survey (**Section 4.5 Site Survey**).

Upon completion, each soil boring that does not have an installed monitoring well will be grouted from total depth to surface. After grouting is complete, the surface and surrounding area will be restored to conditions prior to intrusive activities. Track mats may be used to access the boring locations and minimize ground disturbances.

Sampling equipment will be decontaminated between pushes and soil boring locations by washing equipment using a phosphate-free cleaning solution (e.g., Alconox) along with a distilled water rinse. All “down hole” drilling equipment will be decontaminated inside the decontamination pad, using a high-pressure steam wash.

Drill cuttings and decontamination rinsates will be containerized in 55-gallon steel drums and transported to a central waste staging area for further characterization and disposal.

4.2.2.2 SAMPLING

As previously noted in **Section 3.2 Emerging Contaminants**, care will be taken to prevent cross contamination of samples, especially introduction of emerging contaminants, into the samples. MacroCore samplers will be equipped with PFAS-free acetate liners. All necessary equipment, material, and supplies will be provided by the drilling subcontractor and will be compatible for collection of emerging contaminant samples (e.g., PFAS-free).

Soil boring samples will be collected from the following intervals and submitted for laboratory analysis:

- 0 – 6 inches bgs (exclusive of sod/grass layer)
- 6 – 12 inches bgs
- 12 – 24 inches bgs
- Bottom of the boring

In addition to the intervals above, up to two additional soil samples will be collected and submitted for laboratory analysis based on the following criteria:

- If target fill material is encountered one sample will be collected from the target fill material itself, and another from the material directly below the fill layer.
- If target fill material is not encountered, one soil sample will be collected from the interval exhibiting the highest PID reading, or other evidence of impacts (staining or odors), or from the interval directly above the water table.

As shown on **Table 1**, all samples will be analyzed for total and TCLP metals (including mercury) and SVOCs. The remaining parameters will be analyzed on 20 percent of the samples collected at locations based on field observations. Except for soils that will be analyzed for VOCs, each soil sample collected for laboratory analysis will be field homogenized prior to placement in laboratory-supplied bottles.

Archive samples will be collected if target fill material/waste glass is encountered, as described in **Attachment 3**.

For QA/QC purposes, duplicate samples, equipment blanks and MS/MSD samples will be collected and analyzed at a rate of one for every 20 field samples. Trip blanks will also be included in sample coolers containing field samples for VOC analyses; these trip blanks will be analyzed for TCL VOCs.

Results from the analytical sampling will be compared to Part 375 *Soil Cleanup Objectives* (SCOs; NYSDEC 2006).

4.3 Sediment and Surface Water Investigation

Seven sediment sampling locations are proposed for the drainage ditch located at the Site as shown on **Figure 2**. Sediment coring and sampling are discussed in **Section 4.3.1 Sediment Coring** and **Section 4.3.2 Sediment Sampling**, respectively. These samples will be evaluated as sediments per NYSDEC's *Screening and Assessment of Contaminated Sediments* guidance document (NYSDEC 2014).

Additionally, three surface water samples will be collected from locations as described in **Section 4.3.3 Surface Water Sampling**.

4.3.1 Sediment Coring

Sediment cores will be collected and logged continuously until corings are terminated. Sediment will be visually classified using the Burmister (1970) and USCS (ASTM International 2018) soil classification systems. Descriptions will be recorded in the field notes or soil boring log form. Any non-native material present in the sediment core will be noted and described (type, color, texture, moisture content, etc.) and any layer of fill material greater than 1-inch-thick containing ash, brick and/or glass will be noted in the field logs. Photographs of recovered sediment and any fill material containing ash, brick, and/or glass will be taken to provide in the final report. Each sediment core will also be screened for the presence of VOCs with a PID as previously noted and readings will be recorded on the boring log and/or field book.

Sampling equipment will be decontaminated between pushes and sediment sample locations by washing equipment using a phosphate-free cleaning solution (e.g., Alconox) along with a distilled water rinse. All “down

hole” drilling equipment will be decontaminated inside the decontamination pad, using a high-pressure steam wash. Drill cuttings and decontamination rinsates will be containerized in 55-gallon steel drums and transported to a central waste staging area for further characterization and disposal.

Upon completion, each sediment coring location will be grouted from total depth to surface. After grouting is complete, the surface and surrounding area will be restored to previous conditions.

4.3.2 Sediment Sampling

As previously noted in **Section 3.2 Emerging Contaminants**, care will be taken to prevent cross contamination of samples, especially introduction of emerging contaminants into the samples. MacroCore samplers will be equipped with PFAS-free acetate liners. All necessary equipment, material, and supplies will be provided by the drilling subcontractor and will be compatible with the collection of emergent contaminant samples (e.g., PFAS-free).

Sediment samples will be collected using a slide-hammer, or equivalent, with MacroCore sampler. The sampler will be advanced to two feet bgs or below mudline (bml) and samples will be collected from the following intervals:

- 0 – 6 inches
- 6 – 12 inches
- 12 – 24 inches

As shown on **Table 1**, all samples will be analyzed for total and TCLP metals (including mercury) and SVOCs. The remaining parameters will be analyzed on 20 percent of the samples collected based on field observations. Except for sediments that will be analyzed for VOCs, each sediment sample collected for laboratory analysis will be field homogenized prior to placement in laboratory-provided bottles.

Archive samples will be collected if target fill material/waste glass is encountered, as described in **Attachment 3**.

For QA/QC purposes, duplicate samples, equipment blanks and MS/MSD samples will be collected and analyzed at a rate of one for every 20 field samples. Trip blanks will also be included in sample coolers containing field samples for VOC analyses; these trip blanks will be analyzed for TCL VOCs.

Results from the analytical sampling will be compared to Class A Sediment Guidance Values (SGVs; NYSDEC 2014).

4.3.3 Surface Water Sampling

Surface water samples will be collected from three locations in the drainage ditch, as shown on **Figure 2**. Surface water locations were selected to evaluate ambient water quality within the ditch.

Surface water samples will be collected from the shoreline, using a dipper bucket and extendable pole. Surface water samples will be analyzed as shown in **Table 1**. All samples will be filtered by the laboratory to report both dissolved and total analyte concentrations. Laboratory analytical results will be compared to Class GA NYSDEC Ambient Water Quality Standards presented in T.O.G.S 1.1.1 (NYSDEC, 1998). Emergent contaminant analytical results (PFAS and 1,4-dioxane) will be compared to NYSDOH Minimum Contaminant Levels (MCLs) as presented in the New York State Sanitary Code (SSC, NYSDOH 2018).

4.4 Groundwater Investigation

Groundwater investigation activities at the site consist of installing three monitoring wells RRS-SB-01 through RRS-SB-03. The proposed well locations, RRS-MW-01 through RRS-MW-03, are shown on **Figure 2**. The location,

ground surface elevation, and top of casing elevation will be measured and recorded during the as-built survey (**Section 4.5 Site Survey**).

4.4.1 Monitoring Well Installation

Monitoring wells will be installed to 35 feet bgs. Each monitoring well will be constructed with 2-inch-diameter schedule 40 polyvinyl chloride (PVC) riser threaded with 10 feet of 2-inch-diameter schedule 40 PVC 0.010-slot screen. The screened interval should extend from the bottom of the boring to 2 feet above the water table. Groundwater depth is estimated to be between 25 and 30 feet bgs.

The annular space surrounding the well will be backfilled with clean sand from 6 inches below the bottom of the screen to 2 feet above the top of screen. A bentonite seal will be installed above the sand pack and either allowed to hydrate (in saturated conditions) or hydrated using potable water (in unsaturated conditions). Each well will be grouted from the top of bentonite to grade using a Portland cement and bentonite slurry grout. Each well will be completed with a flush-mount or stick-up protective cover set within a 2-foot-diameter concrete apron, whichever is more conducive to site conditions.

As noted in **Section 3.2 Emerging Contaminants**, care will be taken to prevent the introduction of emerging contaminants into the completed monitoring wells. Downhole drilling equipment will be decontaminated between wells as previously noted and the area around the wells (including access routes) will be restored to previous conditions.

All necessary equipment, material, and supplies used to advance the sampler, purge groundwater, and collect groundwater samples will be compatible with emergent contaminant sampling (e.g., PFAS-free).

4.4.2 Monitoring Well Development

Each new monitoring well will be developed to remove drilling fluid used during boring advancement, as well as any fine-grained material that may have settled in and around the well screen during well construction. Well development will be performed a minimum of 24 hours after grout has been installed to provide sufficient time for the grout to cure.

Well development activities will consist of purging water until one of the following two criteria are met:

1. Water quality parameters have stabilized for three successive measurements and purge water turbidity drops below 50 nephelometric turbidity units (NTUs).
2. A maximum of 10 well volumes have been removed.

Well development may be performed using a stainless steel or PVC bailer, as well as a water pump paired with high-density polyethylene (HDPE) tubing and surge block. If the well goes dry during development, bailing or pumping will pause until 80 percent of the initial water level has recharged, at which point pumping or bailing will resume. The well will be considered developed once this process has been repeated, and the well has been pumped dry three times.

Development water will be temporarily contained using new 55-gallon steel drums, which will be staged on-site at a central investigation-derived waste (IDW) accumulation area (refer to **Section 4.6 Waste Handling**). The drilling subcontractor will provide drums of sufficient number and quality to containerize well development water, and will provide the equipment, personnel, and materials necessary to transport IDW from the investigation location to the central IDW accumulation area. Parsons will be responsible for collecting waste characterization samples and coordinating subsequent disposal.

4.4.3 Monitoring Well Sampling

One round of groundwater sampling will be conducted at each of newly installed monitoring wells using low-flow sampling techniques. Prior to sampling, the water level in each boring will be measured and recorded to the nearest 0.01-foot using a PFAS-free electronic water level meter. Well sampling will commence once water quality parameters are stable for three consecutive readings. The stabilization guidelines are as follows:

- Temperature $\pm 10\%$ of measurement
- pH ± 0.1 pH units
- Specific conductance $\pm 3\%$ of measurement
- Redox ± 10 mV
- Dissolved oxygen $\pm 10\%$ of measurement
- Turbidity $\pm 10\%$ of measurement, or under 10 NTUs

Dedicated and disposable groundwater sampling equipment (e.g., tubing) will be used for sample collection. Any non-dedicated or non-disposable equipment (e.g., water level meter) will be decontaminated between samples by washing equipment with phosphate-free solution followed by a PFAS-free distilled water rinse. Purge water and decontamination water will be transferred to drums for characterization and disposal.

Groundwater samples will be analyzed as shown in **Table 1**. Laboratory analytical results will be compared to NYSDEC Class GA Ambient Water Quality Standards presented in *Technical and Operational Guidance Series 1.1.1* (NYSDEC, 1998). Emergent contaminant analytical results (PFAS and 1,4-dioxane) will be compared to NYSDOH MCLs as presented in the *New York State Sanitary Code* (SSC) 10 NYCRR Part 5. For QA/QC purposes, duplicate samples, equipment blanks and MS/MSD samples will be collected and analyzed at a rate of one for every 20 field samples. Trip blanks will also be included in sample coolers containing field samples for VOC analyses; these trip blanks will be analyzed for TCL VOCs.

As previously noted in **Section 3.2 Emerging Contaminants**, care will be taken to prevent cross contamination of samples, especially introduction of emerging contaminants into the samples. Any non-dedicated well sampling equipment will be decontaminated between well locations.

4.5 Site Survey

Following the completion of investigation activities, a licensed professional land surveyor registered to practice in the State of New York will collect as-built data from the sample locations.

The following as-built data will be collected for soil borings:

- Northing
- Easting
- Ground surface elevation

The following as-built data will be collected for monitoring wells:

- Northing
- Easting
- Ground surface elevation
- Top of riser elevation
- Top of flush-mount or stick-up protective cover elevation

Horizontal survey data will be based on the North American Datum of 1983 (NAD 83) New York State Plane (Central Zone) coordinate system (in feet). Elevations will be based on the North American Vertical Datum of 1988 (NAVD 88).

4.6 Waste Handling

IDW, including excess soils from sample locations, decontamination rinsates, purge water, and other used materials (such as PPE, acetate Geoprobe liners, poly sheeting, etc.) will be placed in Department of Transportation-approved 55-gallon 17-H type drums. The IDW will be classified as hazardous or non-hazardous based on characterization results and will be disposed of in accordance with applicable NYSDEC regulations. Appropriate equipment capable of handling and/or moving IDW stored to the designated waste storage area will be used, and IDW drums will be stored in an area lined with polyurethane sheeting for secondary containment.

SECTION 5 REPORT PREPARATION

Data obtained during the field investigations identified in this scope of work will be validated, evaluated, and summarized. A Site Characterization Report will then be prepared following completion of the investigation and receipt of analytical data. This report will document investigation activities specified in this work plan.

Chemical analytical results for soil and groundwater will be compared to 6 NYCRR Part 375 (NYSDEC, 2006) guidelines for various potential future land uses and State of New York Class GA water quality standards, respectively. CAMP data collected during intrusive activities will be summarized in a qualitative statement in the Site Characterization Report.

The document will include Category B data validation, and an evaluation of data for reclassification/delisting, or continuation of next steps of the site characterization.

SECTION 6 SCHEDULE


Following approval of this Work Plan by NYSDEC, the schedule shown below will be implemented. The work scope described herein is assumed to be completed during the Summer of 2022.

Task Name	Start	Finish
Utility Demarcation and Sample Location Mark-Out	Week 1	Week 1
Geophysical Investigation	Week 1	Week 1
Drilling Mobilization	Week 3	Week 3
Test Trench Excavation	Week 3	Week 3
Drilling/Soil Sampling/Well Installation/Well Development/Sediment Sampling	Week 4	Week 7
Groundwater Sampling	Week 8	Week 8
As-built Coordinates and Elevations Survey	Week 9	Week 9
Data Management and Reporting Tasks	2 months after completion of field activities	

SECTION 7 REFERENCES

- ASTM International. 2018. ASTM D2487-11. *Standard Practice for Classification of Soils for Engineering Purposes (Unified Soil Classification System)*. DOI: 10.1520/D2487-11. West Conshohocken, PA.
- Burmister, D.M. 1970. "Suggested Methods of Test for Identification of Soils." in *Special Procedures for Testing Soil and Rock for Engineering Purposes: Fifth Edition*. Editor(s): ASTM Committee D-18. STP38522S. January 1. pp. 311-323. DOI: 10.1520/STP38522S.
- NYSDEC. 1998. *Division of Water Technical and Operational Guidance Series (1.1.1) Ambient Water Quality Standards and Guidance Values and Groundwater Effluent Limitations*. New York State Department of Environmental Conservation Division of Water. June.
https://www.dec.ny.gov/docs/water_pdf/togs111.pdf
- NYSDEC. 2006. Subpart 375-6 "Remedial Program Soil Cleanup Objectives" in *6 NYCRR Part 375 Environmental Remediation Programs*. New York State Department of Environmental Conservation. Effective December 14. https://www.dec.ny.gov/docs/remediation_hudson_pdf/part375.pdf
- NYSDEC. 2010. DER-10, *Technical Guidance for Site Investigation and Remediation*. New York State Department of Environmental Conservation Program Policy. Issued May 3, 2010, with latest update April 9, 2019. https://www.dec.ny.gov/docs/remediation_hudson_pdf/der10.pdf
- NYSDEC. 2014. *Screening and Assessment of Contaminated Sediments*. June 24.
https://www.dec.ny.gov/docs/fish_marine_pdf/screenasssedfin.pdf
- NYSDEC. 2021. *Sampling, Analysis, and Assessment of Per- and Polyfluoroalkyl Substances (PFAS) under NYSDEC's Part 375 Remedial Programs*. New York State Department of Environmental Conservation. June. https://www.dec.ny.gov/docs/remediation_hudson_pdf/pfassampanaly.pdf
- NYSDOH. 2018. 10 NYCRR Chapter I *State Sanitary Code Part 5 Drinking Water Supplies Maximum Contaminant Levels*. Text is current through May 16, 2018.
https://www.health.ny.gov/environmental/water/drinking/regulations/docs/subpart_5-1.pdf
- Parsons. 2020a. *Project Safety, Health, and Environmental Plan (PSHEP)*. Prepared by Parsons for the New York State Department of Environmental Conservation Environmental Cleanup Program. Revision date April 2020.
- Parsons. 2020b. *Generic Quality Assurance Project Plan (QAPP)*. Prepared by Parsons for the New York State Department of Environmental Conservation Environmental Cleanup Program. May 2020.
- Parsons. 2020c. *Field Activities Plan*. Prepared by Parsons for the New York State Department of Environmental Conservation Environmental Cleanup Program. April 2020.

FIGURES



41 River Road




SCALE: 1"=1500'

FIGURE 1



River Road Spoils Site
South Corning, NY

SITE LOCATION MAP



TABLES

TABLE 1
ANALYTICAL DATA SUMMARY FOR SITE CHARACTERIZATION
RIVER ROAD SPOILS SITE, CORNING NEW YORK

Task	Sample Type	Analysis	Method	Turn-Around-Time	Samples	QA/QC Samples						Total
						Duplicate	Equipment Blank	Trip Blank	Field Blank	MS	MSD	
Test Pit Sampling ^{1,3,5}	Soil	Metals	SW6010D/SW7471B	Standard	6	1	1	0	0	1	1	10
	Soil	TCLP Metals	SW6010C/SW7470A	Standard	6	1	1	0	0	1	1	10
	Soil	SVOCs +1,4-Dioxane	SW8270D	Standard	6	1	1	0	0	1	1	10
	Soil	Cyanide	SW9012B	Standard	2	1	1	0	0	1	1	6
	Soil	VOCs	SW8260C	Standard	2	1	1	0	0	1	1	6
	Soil	Pesticides	SW8081B	Standard	2	1	1	0	0	1	1	6
	Soil	PCBs + Total	SW8082A	Standard	2	1	1	0	0	1	1	6
	Soil	Herbicides	SW8151A	Standard	2	1	1	0	0	1	1	6
	Soil	TPH	EPA 1664 (SGT HEM)	Standard	2	1	1	0	0	1	1	6
	Soil	PFAS	Modified EPA 537.1	Standard	2	1	1	0	0	1	1	6
Soil Boring Sampling ^{1,3,5}	Soil	Metals	SW6010D/SW7471B	Standard	56	3	3	0	0	3	3	68
	Soil	TCLP Metals	SW6010C/SW7470A	Standard	56	3	3	0	0	3	3	68
	Soil	SVOCs+1,4-Dioxane	SW8270D	Standard	56	3	3	0	0	3	3	68
	Soil	Cyanide	SW9012B	Standard	12	1	1	0	0	1	1	16
	Soil	VOCs	SW8260C	Standard	12	1	1	0	0	1	1	16
	Soil	Pesticides	SW8081B	Standard	12	1	1	0	0	1	1	16
	Soil	PCBs + Total	SW8082A	Standard	12	1	1	0	0	1	1	16
	Soil	Herbicides	SW8151A	Standard	12	1	1	0	0	1	1	16
	Soil	TPH	EPA 1664 (SGT HEM)	Standard	12	1	1	0	0	1	1	16
	Soil	PFAS	Modified EPA 537.1	Standard	12	1	1	0	0	1	1	16
Sediment Soil Sampling ^{2,3,5}	Sediment	Metals	SW6010D/SW7471B	Standard	21	2	2	0	0	2	2	29
	Sediment	TCLP Metals	SW6010C/SW7470A	Standard	21	2	2	0	0	2	2	29
	Sediment	SVOCs + 1,4-Dioxane	SW8270D	Standard	21	2	2	0	0	2	2	29
	Sediment	Cyanide	SW9012B	Standard	5	1	1	0	0	1	1	9
	Sediment	VOCs	SW8260C	Standard	5	1	1	0	0	1	1	9
	Sediment	Pesticides	SW8081B	Standard	5	1	1	0	0	1	1	9
	Sediment	PCBs + Total	SW8082A	Standard	5	1	1	0	0	1	1	9
	Sediment	Herbicides	SW8151A	Standard	5	1	1	0	0	1	1	9
	Sediment	TPH	EPA 1664 (SGT HEM)	Standard	5	1	1	0	0	1	1	9
	Sediment	PFAS	Modified EPA 537.1	Standard	5	1	1	0	0	1	1	9
	Sediment	Total Organic Carbon	Lloyd Kahn	Standard	5	1	1	0	0	1	1	9
Surface Water Sampling ⁴	Surfacewater	VOCs	SW8260C	Standard	3	1	1	1	1	1	1	9
	Surfacewater	SVOCs + 1,4-Dioxane	SW8270D/SW8270D SIM	Standard	3	1	1	0	1	1	1	8
	Surfacewater	Pesticides	SW8081A	Standard	3	1	1	0	1	1	1	8
	Surfacewater	PCBs + Total	SW8082A	Standard	3	1	1	0	1	1	1	8
	Surfacewater	Herbicides	SW8151A	Standard	3	1	1	0	1	1	1	8
	Surfacewater	Metals	SW6010D/SW7470A	Standard	3	1	1	0	1	1	1	8
	Surfacewater	TPH	EPA 1664 (SGT HEM)	Standard	3	1	1	0	1	1	1	8
	Surfacewater	PFAS	Modified EPA 537.1	Standard	3	1	1	0	1	1	1	8

TABLE 1
ANALYTICAL DATA SUMMARY FOR SITE CHARACTERIZATION
RIVER ROAD SPOILS SITE, CORNING NEW YORK

Task	Sample Type	Analysis	Method	Turn-Around-Time	Samples	QA/QC Samples						Total
						Duplicate	Equipment Blank	Trip Blank	Field Blank	MS	MSD	
Groundwater Sampling ⁴	Groundwater	VOCs	SW8260C	Standard	3	1	1	1	1	1	1	9
	Groundwater	SVOCs + 1,4-Dioxane	SW8270D/SW8270D SIM	Standard	3	1	1	0	1	1	1	8
	Groundwater	Pesticides	SW8081A	Standard	3	1	1	0	1	1	1	8
	Groundwater	PCBs + Total	SW8082A	Standard	3	1	1	0	1	1	1	8
	Groundwater	Herbicides	SW8151A	Standard	3	1	1	0	1	1	1	8
	Groundwater	Metals	SW6010D/SW7470A	Standard	3	1	1	0	1	1	1	8
	Groundwater	TPH	EPA 1664 (SGT HEM)	Standard	3	1	1	0	1	1	1	8
	Groundwater	PFAS	Modified EPA 537.1	Standard	3	1	1	0	1	1	1	8
Waste Characterization Sampling	Soil	TCLP	SW1311	Standard	2	0	0	0	0	0	0	2
	Soil	TCLP Volatiles	SW8260C	Standard	2	0	0	0	0	0	0	2
	Soil	TCLP Semivolatiles	SW8270D	Standard	2	0	0	0	0	0	0	2
	Soil	TCLP Pesticides	SW8081B	Standard	2	0	0	0	0	0	0	2
	Soil	TCLP Herbicides	SW8151A	Standard	2	0	0	0	0	0	0	2
	Soil	TCLP Metals	SW6010C/SW7470A	Standard	2	0	0	0	0	0	0	2
	Soil	PCBs + Total	SW8082A	Standard	2	0	0	0	0	0	0	2
	Soil	Corrosivity	SW9045	Standard	2	0	0	0	0	0	0	2
	Soil	Ignitability	SW1030	Standard	2	0	0	0	0	0	0	2
	Soil	Reactivity (Cyanide and Sulfide)	SW7.3.3.2/SW7.3.4.2	Standard	2	0	0	1	0	0	0	3
	Water	VOCs	SW8260C	Standard	2	0	0	0	0	0	0	2
	Water	SVOCs	SW8270D	Standard	2	0	0	0	0	0	0	2
	Water	Pesticides	SW8081B	Standard	2	0	0	0	0	0	0	2
	Water	Herbicides	SW8151A	Standard	2	0	0	0	0	0	0	2
	Water	Total Cyanide	SW9012B	Standard	2	0	0	0	0	0	0	2
	Water	PCBs + Total	SW8082A	Standard	2	0	0	0	0	0	0	2
	Water	Metals	SW6010D/SW7470A	Standard	2	0	0	0	0	0	0	2
	Water	Corrosivity (pH)	SW9040	Standard	2	0	0	0	0	0	0	2
	Water	Flashpoint	SW1010	Standard	2	0	0	0	0	0	0	2
	Water	Reactivity (Cyanide and Sulfide)	SW7.3.3.2/SW7.3.4.2	Standard	2	0	0	0	0	0	0	2

- NOTES:**
1. NYCRR Subpart 375 Compounds
 2. NYSDEC Screening and Assessment of Contaminated Sediment
 3. An additional soil sample will be collected from native materials directly under any ash/brick/glass layer encountered
 4. NYSDEC Ambient Water Quality Standard TOGS 1.1.1
 5. Analysis of Cyanide, VOCs, Pesticides, PCBs + Total, Herbicides, TPH, PFAS, and Organic Carbon(sediment only) will be submitted for 20% of samples.



ATTACHMENTS

ATTACHMENT 1 COMMUNITY AIR MONITORING PLAN

COMMUNITY AIR MONITORING PLAN

River Road Spoils Site

Corning, Steuben County, New York

Prepared for:



New York State Department of Environmental Conservation
Division of Environmental Remediation
625 Broadway 12th Floor
Albany, New York 12233 – 7012

Prepared by:



301 Plainfield Road
Suite 350
Syracuse, New York 13212

July 2022



TABLE OF CONTENTS

1.0 INTRODUCTION	3
2.0 SCOPE OF WORK.....	4
2.1 Meteorological Monitoring.....	4
2.2 Air Quality Monitoring.....	4
2.3 Action Levels.....	4
2.3.1 Fugitive Dust.....	4
2.4 Air Quality Documentation	5

1.0 INTRODUCTION

This Community Air Monitoring Plan (CAMP) describes the air quality monitoring requirements to be performed during the implementation of the Short Term Response Action - including excavation of target fill material containing ash, brick, and glass - at the River Road Spoils site, located in South Corning, New York. Details related to excavation activities are included in the Short Term Response Action Work Plan.

The purpose of the CAMP is to conduct real-time air monitoring to confirm that the community is not adversely impacted during activities associated with the excavation activities.

The CAMP is not intended for use in establishing action levels for worker respiratory protection. Rather, the intent of this CAMP is to provide a measure of protection for the downwind community (i.e., potential offsite receptors and onsite workers not directly involved with the subject work activities). The CAMP establishes action levels for airborne particulates that may trigger control actions. The action levels specified herein require increased monitoring, corrective actions to abate emissions, and/or shutdown of work activities if action levels are exceeded.

This CAMP fulfills the requirements set forth by the New York State Department of Health (NYSDOH) Generic Community Air Monitoring Plan included as Appendix 1A of DER-10 (NYSDEC, 2010)¹, as well as the guidance on fugitive dust suppression and particulate air monitoring requirements specified in Appendix 1B of DER-10 (NYSDEC, 2010).

¹ NYSDEC, 2010. *DER-10 Technical Guidance for Site Investigation and Remediation*. New York State Department of Environmental Conservation. Division of Environmental Remediation. May 2010.

2.0 SCOPE OF WORK

Air monitoring during excavation activities will consist of meteorological monitoring and real-time air quality monitoring for airborne particulates. The specifics for these tasks are described below.

2.1 Meteorological Monitoring

Site wind direction will be monitored during intrusive activities. Site wind direction will be established at the start of each workday and used to direct the placement of the air quality monitoring stations. Site wind direction may be re-established at any time during the workday if a significant shift in wind direction is noted.

2.2 Air Quality Monitoring

Real-time air monitoring for airborne particulates will be performed at a minimum of one downwind location and one upwind location at the perimeter of each excavation area on a continuous basis during removal activities.

Air monitoring for airborne particulates at the upwind location will be used to establish background conditions. Air monitoring and response levels/actions for airborne particulates will be performed in accordance with the NYSDEC's TAGM #4031.

Airborne particulates will be monitored using a particulate air monitor equipped with a data logger to measure and record real-time airborne particulate concentrations in milligrams per cubic meter (mg/m³). The particulate monitoring will be performed using real-time monitoring equipment capable of measuring particulate matter less than 10 micrometers in size (PM-10, or equivalent) and capable of integrating over a period of 15 minutes (or less) for comparison to the airborne particulate action levels. The monitoring equipment will be calibrated at least daily in accordance with the manufacturer's calibration requirements. The equipment must be equipped with an audible alarm to indicate exceedances of the action levels. In addition, fugitive dust migration should be visually assessed during all work activities. The particulate monitoring results will be compared with the action levels presented below.

2.3 Action Levels

2.3.1 Fugitive Dust

Dust suppression techniques must be employed if:

- The particulate concentrations measured at the downwind monitoring station exceed 100 micrograms per cubic meter (µg/m³) above background for a 15-minute period, or
- Airborne dust is observed leaving the work area.

Work may continue with dust suppression techniques provided that downwind particulate concentrations do not exceed 150 µg/m³ greater than background and provided that no visible dust is observed migrating from the work area.

If downwind particulate levels exceed 150 µg/m³ above the background level following implementation of dust suppression techniques work must be stopped and a re-evaluation of activities initiated. Work can resume provided that dust suppression measures and other controls are effective in reducing the downwind particulate concentration to within 150 µg/m³ of the upwind level and in preventing visible dust migration.

General dust suppression techniques may include applying water on haul roads, wetting equipment and work areas, spraying water on buckets during excavation and dumping, and immediately covering or wetting excavated materials.

In addition to continuous monitoring, a commonsense approach will be employed to address fugitive dust (i.e., if dust is visually observed to be leaving the work area and is not detected by the monitors, dust suppression techniques will be applied).

2.4 Air Quality Documentation

CAMP data collected during intrusive activities conducted during the execution of the site characterization investigation will be summarized in a qualitative statement in the Site Characterization Report.

ATTACHMENT 2 PARSONS SUBSURFACE SOIL DISTURBANCE PROTOCOL

PARSONS ENVIRONMENT & INFRASTRUCTURE GROUP MANDATORY SUBSURFACE SOIL DISTURBANCE PROTOCOL

1. INTRODUCTION

Intrusive investigation or excavation of the subsurface in areas developed for commercial, industrial or residential use exposes Parsons to the risk of causing damage to underground utilities and structures on a daily basis.

The potential consequences of causing damage to an underground utility or structure include, but are not limited to the following:

- Injury or loss of life
- Financial responsibility for repair, lost time, and/or loss of service
- Loss of client
- Federal investigation of job site work practices
- Litigation (third party lawsuits)

The mandatory protocol and checklists provided herein are intended as tools to aid in the management of risk, and ensure that a responsible standard is consistently applied at project sites where intrusion of the subsurface will occur.

2. PURPOSE

The purpose of this mandatory protocol is the prevention of potential injury and/or loss of life; and damage to subsurface utilities and structures. Parsons' staff will identify and evaluate the hazards associated with underground utilities and other structures prior to conducting any intrusive subsurface operation including but not limited to drilling/boring, test pitting, excavation and other subsurface intrusive activities.

3. SCOPE

Parsons' staff will employ sound investigative and work practices, and will use appropriate measures to avoid damage to subsurface utilities and structures. Furthermore, Parsons requires that these procedures be implemented by all of Parsons' employees and subcontractors, as appropriate. Subcontractors will have a copy of the procedures set forth in Section 6 of this document as an appendix to their contracts.

4. POLICY

Parsons' policy requires that the project manager follow all local, state, and federal laws applying to intrusive subsurface work (i.e. obtain permits, inform agencies, obtain utility clearances, etc). The project manager shall review, as available, all current and historical site drawings and plans from the client, facility owner or tenant, utility providers, municipal government offices (i.e. city engineer or building department) and third parties as appropriate.

The Pre-Drilling/Subsurface Checklist for Intrusive Fieldwork (**Attachment A**) shall be completed prior to initiating fieldwork. Note: *The checklist includes a site visit as a requisite to meet with knowledgeable staff as appropriate (current or former site/owner personnel, utility representatives, municipal representatives, etc.), and review site conditions and features relative to the proposed locations for intrusive work. The checklist should be turned in to the Parsons Project Manager and a copy placed in the project file.*

The procedure described under Section 6 of this document is mandatory at all sites where any intrusive subsurface activities will take place, including but not limited to drilling, augering, boring, excavating, test pitting, trenching or direct push (Geoprobe) technology.

Variance from the Subsurface Soil Disturbance Protocol is allowed only with the written approval from the appropriate Parsons' Program Manager or Sector Leader and the completion of the Utility Clearance Variance Request Form (Attachment B). GBU, Division or Project Safety personnel should be consulted as needed. Failure to obtain a variance in writing is grounds for disciplinary action. Copies of all variances will be maintained in the project files.

The Project Manager is encouraged to find locations that are acceptable to the project team to perform intrusive subsurface work that are not within right-of-ways, streets, highways, or near municipal or third party-owned utility corridors. When it is necessary to conduct work within these areas, the Project Manager should obtain approval from either the Program Manager or Sector Leader and submit the existing work plan to the GBU or Division Safety Manager for review.

5. RESPONSIBILITY

It is the responsibility of the Project Manager to ensure that the Pre-Drilling/Subsurface Checklist for Intrusive Fieldwork and Utility Clearance Variance Request form are followed. If a variance is sought, it is the responsibility of the Project manager to gain written approval of the appropriate Parsons' Program Manager or Sector Leader.

6. PROCEDURE: SUBSURFACE SOIL DISTURBANCE PROTOCOL

The Parsons' Project Manager will be responsible for fulfilling the objectives of this protocol by ensuring that the procedures are carried out by Parsons' employees, subcontractors, and any other person acting on behalf of Parsons. The Parsons' Project Manager will ensure that all individuals working on drilling and other subsurface exploration projects are adequately trained and supervised. Parsons will practice sound investigation and work practices and employ

PE&I Subsurface Soil Disturbance Protocol

all necessary measures to avoid damage to subsurface systems and structures. The Parsons' Program Manager or Sector Leader will be contacted and advised in advance of beginning field work in the event that a variance to this protocol is requested by the Parsons' Project Manager or designee. The following tasks/subtasks will be completed at every site and documented on the checklist.

6.1 PRE-INVESTIGATION TASKS

The objective of these tasks is to gather all relevant information about the site to assist in identifying exploration locations and obtaining necessary permits. Please note that in some instances the following information will be obtained or gathered by a subcontractor, which meets this objective.

6.1.1 Obtain Site Plans

Obtain as-built drawings and/or existing site plans as available. NOTE: As-built drawings may not accurately depict the locations of improvements and subsurface features and should therefore not be solely relied upon to determine acceptable locations for intrusive subsurface activities.

6.1.2 Obtain Permits

The project staff will observe all local, state, and federal laws, obtain all necessary permits and utility clearances, and secure site access permission. NOTE: Some permits/clearances require this step to be completed after the exploration locations have been identified and marked in the field. If this is required, proceed with Items 6.2 and 6.3 prior to obtaining permits.

6.1.3 Utility Mark-outs

Parsons' project staff will request a utility mark-out through the local utility locating one-call system for the work site, and document a reasonable degree of effort to locate all main electrical, gas, telephone and all other subsurface utilities. The Parsons' Project Manager must be notified of the status of locating underground utilities before field work progresses. If locating utilities becomes problematic, the Parsons' Project Manager should update the client and discuss potential alternative methods for locating or reducing risk of damage to underground utilities/structures for consideration (i.e. subcontract a private locating service, re-evaluate risk/reward of specific locations or utilize intrusive non-destructive methods as described in Section 6.5.6). Site plans will be updated as appropriate to include utility mark-out information. On third party sites, close coordination with the site owner's representatives for mark-outs, review of as-builts, and other information reviews should be conducted prior to work. NOTE: Some utilities require the exploration locations to be identified and marked in the field prior to performing mark-outs. If this is required proceed with Items 6.2 and 6.3 prior to obtaining permits.

6.2 SITE VISIT

A site visit is required to compare the site plan to actual conditions, document all findings, and update the site plan. Parsons will obtain information needed to prepare a vicinity map of the area that may include significant neighboring addresses, land use, surface water bodies, and other natural as well as manmade features of note, as appropriate. The site visit should be scheduled concurrent with, or soon after the utility mark-out. The inspection should include the following activities at a minimum.

6.2.1 Utilities

Note the location of all utility mark-outs and aboveground utilities:

- Area lights
- Phones
- Drain lines
- Overhead lines
- Fire hydrants
- Fiber optic cable signage
- Catch basins
- Manholes
- Junction boxes
- Natural gas
- Other utilities
- Observe paving scars such as areas of new pavement or saw cuts

6.2.2 Plant/Property Systems

If possible, speak with someone having historical site knowledge to gain information about the site (locations of former tanks, lines, etc.). For UST systems:

- Inspect for the presence of a dispenser pan and, if possible, determine whether product piping is rigid or flexible.
- Visually inspect the location of the tank field, observation wells (if present), dispensers and vent stack(s).

PE&I Subsurface Soil Disturbance Protocol

- Note the orientation, arrangement, location, sizes, etc. of the tanks and manholes. Estimate the burial depth of the tank field.
- Observe paving scars (i.e. fresh asphalt/concrete patches, scored asphalt/concrete). Note that this may not indicate location of product piping.

6.2.3 Existing Remediation Systems

Visually inspect the location of aboveground components. Note the locations of well manholes, sparge points, etc.

6.2.4 Safety

For UST systems, note the location of the emergency shut off switch and become familiar with its use.

6.3 SELECTION OF DRILLING/TEST PIT LOCATIONS

6.3.1 Critical Zones

Establish pre-drilling critical zones appropriate to the project site. These are zones where no drilling (if possible and if client concurs) will be conducted. As an example, the following critical zones could be applied at a UST site:

- 10ft (3m) distance from the furthest edge of any operating tank
- 10ft (3m) distance surrounding operating dispenser islands
- At active service station sites, the entire area between the tank field and the dispenser islands.
- The zone between 0 and 5-feet of utility markings

6.3.2 Select Drilling Locations

The information collected to this point will be utilized in combination with regulatory requirements and investigation objectives to select drilling locations. It is recommended that alternate drilling locations be selected in case additional explorations are required or obstructions are encountered. The effort to investigate a specific proposed drilling location should be to clear a minimum five-foot radius circle around the location.

6.3.3 Review Selected Locations with the Client

At a minimum, offer to review the selected and alternate drilling locations with the client's project manager or designated representative. When completing Geoprobe™ (or similar) investigations in which some boring locations are not selected in advance, but partially

PE&I Subsurface Soil Disturbance Protocol

determined in the field based on field screening results, the client should approve the areas in which work will be performed. Do not proceed with the investigation until the plan has been discussed with the client, and approval to proceed has been granted. If relocation of a boring outside approved limits is necessary at any time and for any reason, contact the client prior to proceeding. CLIENT APPROVAL MUST BE DOCUMENTED. Verbal approval is acceptable if followed with written approval. Documentation may include a notation in the field book, email or written correspondence.

6.4. REQUIRED NOTIFICATIONS

Affected parties must be notified at least 48-hours (longer if possible) in advance of planned intrusive fieldwork. An exception would be in the event of an emergency response situation. Parsons' staff will avoid scheduling conflicts with facility activities at the site. The Parsons' Project Manager or designee will notify the following persons as applicable:

- The oversight regulatory agency (includes local fire, police and municipal contacts as appropriate).
- Property owner for private properties. This should include neighboring third party property owners if a potential exists for causing inconvenience as a result of the scheduled fieldwork.
- Client specific notifications as appropriate (i.e. facility maintenance, retail and/or real estate managers as appropriate)

6.5. ON-SITE SUBSURFACE ACTIVITIES

6.5.1 Safety

A Project Safety, Health and Environmental Plan (PSHEP) must be available on site at all times and all Parsons' staff, contractors and subcontractors must be familiar with it. Parsons' employees are to acknowledge their review of the PSHEP by signing the signature form contained within the PSHEP. The Parsons' field team leader is tasked with conducting a tailgate meeting at the start of each day to review project specific health and safety items with staff and subcontractors. Subcontractors, however, are responsible for their own health and safety. All work areas shall be secured with safety cones, safety tape, construction fence, barricades, or signs as appropriate.

A copy of this entire subsurface activity protocol and completed checklist must be appended to the health and safety plan.

6.5.2 Supervision

A Parsons' on-site representative will be responsible for overseeing subsurface activities. This representative will ensure that the work is performed with due caution and will be alert for warning signs that could indicate the presence of underground tanks, lines, or other subsurface structures.

6.5.3 Warning Signs

The following warning signs may indicate the presence of a subsurface structure such as tanks or lines:

- Pea Gravel/Sand/Non-indigenous Material.
- The absence of soil recovery in the hand auger. This could indicate pea gravel that has spilled out of the auger.
- Any unexpected departure from the native soil or groundwater conditions as established in other on-site digging.
- Obstructions encountered

If any of the above warning signs or a suspicious condition is encountered, intrusive subsurface activities in this area should immediately cease and the Parsons' Project Manager shall be contacted.

6.5.4 Drill Boring Sequence

If possible, the boring sequence should be planned such that the boring furthest from any suspected underground improvements is carried out first. This is done to determine the natural subsurface conditions and to allow the field geologist/scientist to recognize native versus fill conditions. Also, least impacted locations should be done first if possible to prevent possible cross contamination.

6.5.5 Surface Removal for Paved Areas

Sufficient paving or surface improvement should be removed to allow clear visibility of the subsurface conditions during hand augering/digging, and allow excavation with hand tools. Drilling in an area of high risk may warrant a larger pavement opening.

- Monitoring Well Installations: 2-ft x 2-ft (60cm x 60cm) minimum removal is suggested (assumes for example: 6.25-inch hollow stem auger (HSA) or smaller).
- Soil Borings: 8-inch (20cm) diameter minimum removal is suggested (assumes for example: 3.25-inch HAS or smaller).
- Direct Push Samplers: 4 to 6 inch (10 to 15 cm) diameter minimum removal is suggested (assumes for example: 2-inch diameter sample tube).

The technique used should not pose a threat to subsurface structures. Final completion for holes in pavement shall be neatly saw-cut or cored unless otherwise directed by the client.

6.5.6 Clearing the Subsurface for Utilities and Other Structures

Parsons' staff must ensure that no subsurface utilities, structures, or improvements exist where intrusive subsurface activities will occur. Locations will be cleared using results of historical data research and with geophysical methods (see below for details) at a zone 5 feet in radius around the proposed location. Staff (or personnel supervised by Parsons) will also utilize intrusive, non-destructive procedures such as hand digging to a depth of 5 feet and a diameter or width equivalent to the outside dimensions of the auger to investigate the boring location.

The method used to delineate the subsurface should be compatible with the inherent risk associated with the type of facility/property and the location of the drilling. Proactive investigative methods to clear specific drilling locations will include the following non-invasive and invasive non-destructive methods:

Non-Invasive Geophysical Remote Sensing: Multiple appropriate instruments (ground penetrating radar, electromagnetic detector, magnetometer, metal detector) can be used for this work. Survey an area around the location to a distance of 5 feet using geophysical methods to identify potential subsurface utilities or facilities. Move the borehole location, if necessary, within the cleared circle to avoid an object identified by the geophysical instrument. Examples of geophysical methods are provided below:

- Electromagnetic and radio frequency;
- Ferrous metal or magnetic locators;
- Ground probing radar (GPR).

Important note: A combination of two or more non-invasive instruments may be required to properly clear a subsurface area. For example, a ferrous metal detector may not detect metals pipes embedded in concrete duct banks, PVC pipes, FRP pipes, or other non-ferrous materials.

Intrusive Non-Destructive Procedures: Delineate the subsurface at the borehole location by probing or digging. Several acceptable methods are discussed below. In some cases, these intrusive procedures may not be practical due to the subsurface conditions or requirements of the explorations.

- **Vacuum/Air Knife Digging:** Vacuum digging has proven to be a very effective and safe means of digging and is recommended instead of probing and digging with hand tools.
- **Probing:** The probe should have a blunt or rounded tip and should be advanced by hand in a triangular pattern around the bore location without excessive force.
- **Hand Digging:** Should be performed with a small hand garden spade.

PE&I Subsurface Soil Disturbance Protocol

- Hand Augering: The auger is to be turned slowly and not forced through the soil. It is recommended that an auger without sharp points (some augers have rounded edges) be used.
- Post Hole Digging: Can be used for soil removal only in soil that has been probed and cannot be used to advance the hole beyond the depth or width of probing.

The area to be cleared for underground utilities or structures for augering shall exceed the diameter of the largest tool (hand auger, drill auger, sampling tube, etc.) to be advanced and sufficiently large to allow for visual inspection of any obstructions encountered. The first 1 - 2ft (0.3 - 0.6m) can be cleared by hand digging to remove the soil. Slowly and carefully probe (i.e. triangular pattern), vacuum, or hand auger throughout the area to be cleared to ensure that no obstructions exist anywhere near the potential path of the drill auger or push type sampler. The soil in the area to be cleared shall be fully removed during this step. If probing is utilized, then alternate probing with soil removal as necessary, until the first 5-ft (1.5m) has been delineated.

6.5.7 Refusal

Where natural subsurface conditions (e.g. cobbles/rocks, fill material, and/or bedrock) may prevent adequate probing and augering, a practical and sensible evaluation by the Parsons' Project Manager will be the basis for determining if continuation of probing and augering is feasible. In all cases Parsons must employ all means necessary to prevent damaging subsurface utilities, product lines, tanks, or other structures. **When conventional means of probing and augering cannot be utilized, the Parsons' field representative believes that additional probing/augering is not feasible, or if the probing/augering poses additional hazard to personnel because of the physical demands of performing the task, work in that specific area will cease.** The Parsons' Project Manager will contact the client's project manager or designee to discuss alternatives. If Parsons' staff suspects, based on past information or boring logs, that hand augering is infeasible, then alternatives such as vacuum clearing or non-invasive procedures should be evaluated in advance.

6.5.8 Event Notification

If any portion of a tank, pipe, utility or other subsurface structure is encountered, or if there is any doubt it has been encountered, the work is to cease in that area and the Parsons' Project Manager notified immediately. If there is reason to believe that the structure has been damaged, if applicable, the emergency shut-off switch should be activated (if applicable) and the appropriate municipality and client notified immediately. The Parsons' Project Manager and/or client will decide if additional uncovering by hand is required. If it is confirmed that a UST system has been encountered, a tightness test(s) should be considered. Under no circumstances is the area to be backfilled without notifying the Parsons' Project Manager, unless risk of personal injury or damage warrants a temporary backfilling.

In case of refusal or if an unknown subsurface object is encountered during intrusive subsurface activities, then the following specified resolution process must take place.

PE&I Subsurface Soil Disturbance Protocol

- Additional and deliberately careful excavation by hand will be conducted in an attempt to define the cause of refusal or identify the subsurface object.
 - a. If the cause CAN be readily and correctly defined as not destructive or hazardous, the field task manager should call the PM to discuss the situation.
 - b. If the cause CAN be readily and correctly defined as potentially destructive or hazardous, the field task manager should call the PM to discuss the situation. The specific location must be re-evaluated.
 - c. If the cause CANNOT be readily and correctly defined, the field task manager should call the PM to discuss the situation. The specific location must be re-evaluated.
- In case “a,” drilling may proceed ONLY after consultation with the PM.
- In cases “b” and “c,” drilling MUST STOP so that location re-evaluation can take place. The client, the utility owner (if applicable) and if required, the appropriate regulatory agency, must be advised of the situation and consulted to determine if (1) the location is necessary, which may require additional effort to clear a new location, or (2) the location is not necessary, and can be deleted from the program.

6.5.9 Scheduling

Since clearing locations for augering, drilling, excavation and similar intrusive field work can be time consuming, it may be appropriate to perform the surface removal subsurface delineation prior to the arrival of subcontractors and their equipment on site. If these activities are conducted prior to the actual day of intrusive field work, then the cleared locations must be adequately covered with plates and/or backfilled, or barricaded to protect pedestrians and other surface traffic. Care must be taken to prevent settlement of the material used to cover the holes.

ATTACHMENT A

PRE-DRILLING/SUBSURFACE CHECKLIST
FOR INTRUSIVE FIELD WORK

PREDRILLING/SUBSURFACE CHECKLIST FOR INTRUSIVE FIELDWORK

Site Name: _____ Job Number: _____
 Site Phone Number: _____
 Site Address: _____ County: _____
 Client Proj. Mgr.: _____ Phone: _____
 Site Manager Contacted Date: _____ By: _____
 Site Drawings (yes / no / NA) _____ (please attach) Historical Drawings (yes / no / NA) _____
 Third Party Construction/Redevelopment Plans (Yes/No/NA) _____

***ATTACH SITE FIGURE WITH PROPOSED BORING LOCATIONS

Subcontractor's (drillers, concrete, etc...) Company _____
 Subcontractor's Contact Person _____ Phone _____
 Meeting / Start Date _____ Time _____

1) Health and Safety Signoff Form Completed? (Yes/No) Date _____

2) Utility Protection Services (Minimum 48 Hrs. Advance Notice, State Specific Notification Period Supercedes)

Called: Date _____ Time _____ Initials _____

Reference # _____

Proposed Drilling Locations Premarked for Locating Service. Y / N

3) Private or In-House Utility Locating Service Performed? Y / N _____

Called: Date _____ Time _____ Initials _____

Name of Locating Service: _____

Telephone #/ contact: _____

Name of Supplier Locating Technician: _____

Type of sensing equipment used: _____

Proposed Drilling Locations Premarked Y / N

4) Other Potential Underground Structures

Name of City Engineer/Utility Representative: _____

Telephone #: _____

Date Notified _____ Maps: Y / N

Cleared: Y / N

5) COMPLETED SITE WALKOVER W/ SITE MANAGER/DESIGNEE OR OWNER/TENANT REP. Y / N

Name of Site Manager: _____

Name of Property Owner/Tenant Representative: _____

Cleared: Yes / No

Building Utility Service Line Connections Identified: Y / N

(Hand sketch on site map w/proposed boring locations and most likely utility trench locations)

6) Utility Inventory: Y / N

Utility	Name	Depth (ft) (If Available)	Phone	Notified - Date	Marked
<u>Above Ground Services</u>					
Electric	_____	NA	_____	Y / N _____	Y / N
Telephone	_____	NA	_____	Y / N _____	Y / N
Cable	_____	NA	_____	Y / N _____	Y / N
Overhead Supports	_____	NA	_____	Y / N _____	Y / N
Traffic light cables	_____	NA	_____	Y / N _____	Y / N

PREDRILLING/SUBSURFACE CHECKLIST FOR INTRUSIVE FIELDWORK

6) Utility Inventory Continued:

Below Ground Services:

Electric				Y / N		Y / N
Telephone				Y / N		Y / N
Cable				Y / N		Y / N
Gas				Y / N		Y / N
Water				Y / N		Y / N
UST System				Y / N		Y / N
Storm				Y / N		Y / N
Sanitary				Y / N		Y / N
Steam				Y / N		Y / N
Pipeline Companies				Y / N		Y / N

Other:

_____	_____	_____	_____	Y / N _____	Y / N _____
_____	_____	_____	_____	Y / N _____	Y / N _____
				Y / N _____	Y / N _____

- | | | |
|----|---|-------|
| 7) | Site-Specific Emergency Contingency Plan Incorporated in Health & Safety Plan | Y / N |
| 8) | Drilling Locations Approved by Client Project Manager Named Above? | Y / N |
| 9) | Signature of Parsons' Project Mgr. (required to begin fieldwork): | |

Name of Project Manager

Signature of Project Manager

Name of Parsons Field Personnel

Signature of Field Personnel

(This document to be included with the site H&S Plan and should be available upon request.)

ADDITIONAL COMMENTS / NOTES:

ATTACHMENT B
UTILITY CLEARANCE VARIANCE REQUEST FORM



UTILITY CLEARANCE VARIANCE REQUEST

To: Enter Parsons Manager (Program, Sector or Operations)

From:

Client Company Name:

Site/Project Name:

Date of Request:

Work Start Date:

The purpose of this document is to request a variance from one or more of the PE&I Mandatory Subsurface Soil Disturbance Protocol requirements. The purpose of the mandatory protocol is to prevent potential injury and/or loss of life; and damage to subsurface utilities and structures during any soil disturbance. Any waiver of these requirements should be carefully evaluated.

Variance from the Subsurface Soil Disturbance Protocol is allowed only with the written approval of the appropriate Parsons' Program/Sector/Operations Manager. GBU/Divisional/Program safety resources should be consulted as needed. Failure to obtain a variance in writing is grounds for disciplinary action.

Brief Project Description

Insert a brief background and description of the intrusive activities, which are the reason(s) for requesting a variance.

Utility Clearance Requirements

Step No.	Requirement	Step Completed ¹
Prep-1	Obtain as-built drawings and/or existing site plans if available and review for on-site utilities.	<input type="checkbox"/> Yes <input type="checkbox"/> No

¹Any "No" response must include the rationale for not completing the step at the end of the Variance Request form.

Step No.	Requirement	Step Completed ¹
Prep-2	Utility mark-out requested through the nationwide utility locating one-call system (www.call811.com) for the work site.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Prep-3	Review the Subsurface Soil Disturbance protocol with all PE&I technical staff that will potentially be involved in projects that include subsurface investigation.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Pre Mob-1	Notify affected parties at least 48-hours (longer if possible) in advance of planned intrusive fieldwork.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Pre Mob-2	Prepare a Project Safety, Health and Environmental Plan (PSHEP) that includes a copy of the Subsurface Soil Disturbance protocol.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Pre Mob-3	Select a competent Parsons' on-site representative to oversee all surface removal, hand augering/digging, drilling, and test pitting.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Site ² Visit-1	Perform a site visit and identify indications of underground utilities. Indications could include ³ : <ul style="list-style-type: none">➤ Area lights➤ Phones➤ Drain lines➤ Overhead lines➤ Fire hydrants➤ Fiber optic cable signage➤ Catch basins➤ Manholes➤ Junction boxes➤ Natural gas	<input type="checkbox"/> Yes <input type="checkbox"/> No

¹ Any "No" response must include the rationale for not completing the step at the end of the Variance Request form.

² Site visit activities must be included with mobilization activities if a Site visit is not performed prior to mobilization for the field work.

³ Note that list is not all inclusive.

Step No.	Requirement	Step Completed ¹
	➤ Observe paving scars such as areas of new pavement or saw cuts	
Site Visit-2	Prepare a vicinity map of the proposed work area to include significant features and utilities. The site visit should be scheduled concurrent with, or soon after the utility mark-out.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Site Visit-3	Interview someone having historical site knowledge to gain information about the site (locations of former tanks, lines, etc.).	<input type="checkbox"/> Yes <input type="checkbox"/> No
Site Visit-4	Establish pre-drilling critical zones appropriate to the project site	<input type="checkbox"/> Yes <input type="checkbox"/> No
Site Visit-4	Review Selected Locations with the Client	<input type="checkbox"/> Yes <input type="checkbox"/> No
Field Work-1	Review site utility maps against each proposed work activity. Check for legibility, accuracy, and scale while walking areas of concern. Evaluate the work area for any items in Site Visit-1 that may have been missed.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Field Work-2	Obtain all necessary permits and utility from the facility.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Field Work-3	Remove any surface paving or surface cover allow clear visibility of the subsurface conditions during hand augering/digging, and allow excavation with hand tools.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Field Work-4	Non-Invasive Clearing: Clear a minimum of a five foot radius for each proposed intrusive activity. Locations will be cleared using results of historical data research <u>and</u> with geophysical methods. Multiple appropriate instruments (ground penetrating radar, electromagnetic detector, magnetometer, metal detector) can be used for this work.	<input type="checkbox"/> Yes <input type="checkbox"/> No
Field Work-5	Invasive Clearing: Delineate the subsurface at the borehole location by probing or digging. Dimensions of the intrusive method must exceed the diameter of the largest tool (hand auger, drill auger, sampling tube, etc.) to be advanced and	<input type="checkbox"/> Yes <input type="checkbox"/> No

PARSONS

Utility Variance Request

Page 4

Step No.	Requirement	Step Completed ¹
	sufficiently large to allow for visual inspection of any obstructions encountered. Approved methods could include the following: <ul style="list-style-type: none">➤ Vacuum Extraction (Air Knifing, SoftDig®)➤ Probing➤ Hand Digging➤ Hand Augering➤ Post Hole Digging	

Rationale

Below, identify the step or steps the variance is being requested for and an explanation of why the waiver is necessary and/or justified.

Step No.	Rationale for Variance Request

Approvals

	Name	Date
Parsons Manager (Program, Sector, or Operations)		

ATTACHMENT 3 NYSDEC CORNING AREA GLASS SAMPLING STANDARD OPERATING PROCEDURE

NYSDEC CORNING AREA GLASS SAMPLING STANDARD OPERATING PROCEDURE

TABLE OF CONTENTS

- 1. OBJECTIVE..... 2
- 2. PROCEDURE 2
 - a. Equipment and Supplies 2
 - b. Notification..... 2
 - c. Sampling Method 2
 - d. Chain of Custody..... 4
- 3. ATTACHMENTS..... 4
 - a. Appendix A Glass Archiving Sampling Record Log 4
 - b. Appendix B sample Chain of Custody Form 4

1. Objective

The purpose of this task is to collect and identify specific waste items associated with historic manufacturing waste (largely associated with glass manufacturing) disposal throughout the area. Performing this work involves the need to preserve unique shapes, markings, etc. of archive samples. Archived samples may be analyzed at NYSDEC's discretion to define their physical and chemical characteristics.

2. Procedure

a. Equipment and Supplies

The following equipment will be used:

- Clear Zip-Loc bags
- Digital camera
- PPE in accordance with the HASP
- Sample logs
- Ruler
- Tape measure
- Ultraviolet flashlight
- Fibrous brush
- Basic glass cutting equipment - different equipment may be utilized based on site- and sample-specific circumstances, including:
 - Triangular file
 - Hammer & chisel
 - Other hand tools (as applicable)

b. Notification

Prior to any archive sample being collected, to the extent practical, Corning Incorporated will be alerted of field archive sample collection if required by an order on consent or at the discretion of NYSDEC if not. Split samples may be provided to Corning Incorporated upon request. If splitting of a sample would otherwise impact the ability to get test results for the sampled material or would otherwise alter the nature of the material to damage it beyond its intended use as an archive sample, then Parsons and/or NYSDEC shall take the sample without splitting with Corning Incorporated and properly maintain the sample. NYSDEC solely reserves the right to refuse to split a sample.

c. Sampling Method

The following observations will be noted in the glass archiving sampling record log (Appendix A):

- Site name;
- Project number;

- Sampling date;
- Samplers;
- Sample ID;
- Parcel ID;
- Sampling Method;
- Location;
- Surrounding soil (or subject material) type & appearance;
- Optionally, if the following physical properties are applicable to a specific archive sample, record dimensions, shape, and color of the archive sample. Record opacity, fracture, and UV/fluorescence as applicable after sample collection; and
- Other notable observations.

To the extent possible, archive samples will be logged prior to being disturbed (e.g., moved by an excavator). A digital camera will be used to take photos of the archive sample and location; a ruler will be staged in the photo frame as a dimensional reference. An ultraviolet flashlight will be used to determine fluorescence of the archive sample after sample collection. A sketch of the sample location relative to property landmarks (e.g., fenceline, vegetation, shed, etc.) must be drawn and recorded in a field book, or supplemented with a written location description or photograph.

When handling the archive sample, samplers will wear nitrile gloves. Prior to or after the archive sample being split or bagged, a fibrous brush will be used to remove debris attached to glass or brick material.

As provided in Section 2.b., NYSDEC and Corning Incorporated will be notified before collection of any archive sample. If requested by Corning Incorporated, and where reasonable, larger pieces of glass may be split sampled into two pieces. A glass cutting device will be used to split the sample into two halves (to the extent possible). Glass pieces may be cut by scoring the glass with a triangular file and then breaking along the score, by breaking with a hammer and chisel, or by another appropriate hand methods. If hand tools are inadequate to physically split the glass sample, additional methods may be considered (e.g., a wet saw). Alternative methods of splitting samples will need to consider health and safety risks and generation/disposal of wastes prior to implementing.

If splitting a glass piece may harm its integrity, damage a unique and distinguishable shape, isn't feasible due to its size or shape, or presents another issue, field personnel will collect two pieces of similar material found together. One piece of the sample will be offered to Corning Incorporated as a split sample. NYSDEC and Corning Incorporated can discuss these instances, if they arise, and may make a future arrangement to split the piece.

The cutting device and splitting method (e.g., cut, crushed, or alternative method) must be noted on the glass archiving sampling record log (Appendix A). Additionally, an estimate of the percentage of the glass that is salvageable for archiving must be noted on the log. Once the archive sample is split, a photo must be taken of the glass samples. If an archive sample is unevenly split, NYSDEC reserves the right to choose the piece(s) to collect.

Sample identification information must be affixed to the Zip-Loc bag containing the archive sample. The following information must be noted on the bag, chain of custody, and/or sampling record log:

- Sample ID
- Chain of Custody number
- Sampler(s)
- Date sample collected
- Collection location (Area, Parcel ID, etc.)
- Sampler company (i.e., Parsons)
- Client (i.e., NYSDEC)

In the event a Corning Incorporated representative is unable to be present during the archive sample collection, the sample will be collected and stored in a secure location (e.g., the Parsons trailer). Corning Incorporated will be notified of the completion of the sampling effort. At Corning Incorporated's request, the archive sampling information will be shared. The archive sample may be split when a Corning Incorporated representative is present.

d. Chain of Custody

Archive samples will be collected under a chain of custody (Appendix B).

- The total number of samples on a chain is limited to 20.
- If the chain has multiple pages, it must be noted (e.g., Page 1 of 2).
- At the end of the workday, a picture will be taken of the chain to capture an electronic copy of the signed chain. A .pdf copy of the signed chain will be saved to the project file.

The *Site ID* consists of the work location (e.g., Study Area, Van Etten Road, etc.) that the archive sample is collected from. Each location has its own *Site ID*. Site IDs for each work location will be as follows, and this SOP will be amended as needed to list additional Site IDs.

Work Location	Site ID
Study Area	SA
Stewart Park	Stewart
Van Etten	Van
Guthrie Medical Center	GMC
Guthrie Center North Parking Lot	GCNPL
City of Corning Fire Department	CCFD
Post Creek	Post
3510 West Road	WR
McKinney Park	MCP; McKinney
William Street Park	WSP
Vine Street Site	Vine; 6FLA

Chain Numbers are the *Site ID* + *Sampling Date* (e.g., SA-072420 are the archive samples collected in the Study Area on July 24, 2020).

Field Sample IDs must be unique. The *Field Sample ID* for locations within the Study Area consists of the *Site ID* + *Residence Number* + *Date* + *Sequential Number* + *Sample Type* (AG for archive glass, FB for furnace brick, CS for ceramic, and ASH for ash). For example, SA-Res012-072420-01-AG would be the first sample collected at Study Area Residence 12 on July 24, 2020 and would consist of archive glass. The *Field Sample ID* for locations outside of the study area will consist of *Site ID* + *Date* + *Sequential Number* + *Sample Type*. For example, Stewart-101220-04-FB would be the fourth sample collected at Stewart Park on October 12, 2020 and would consist of furnace brick.

3. Attachments

A. APPENDIX A GLASS ARCHIVING SAMPLING RECORD LOG

B. APPENDIX B SAMPLE CHAIN OF CUSTODY FORM

PARSONS GLASS ARCHIVING SAMPLING RECORD

SITE NAME:	<hr/>		
PROJECT NUMBER:	<hr/>		
SAMPLING DATE / TIME:	<hr/>		
WEATHER:	<hr/>		
SAMPLERS:	<hr/>	of	<hr/>
	<hr/>	of	<hr/>
	<hr/>	of	<hr/>
SAMPLE ID:	<hr/>		
PARCEL ID:	<hr/>		
SAMPLING METHOD:	<hr/>		

DESCRIPTION OF SAMPLING POINT

LOCATION:
SURROUNDING SOIL/SUBJECT MATERIAL TYPE & APPEARANCE:
ORIENTATION:
DEPTH TO TOP:
DEPTH TO BOTTOM:
ABG* PROPORTIONS:

ARCHIVE SAMPLE DESCRIPTION

DIMENSIONS (Photograph with ruler): _____

SHAPE: _____

COLOR: _____

OPACITY: _____

FRACTURE: _____

UV/FLUORESCENCE TESTING: _____

OTHER: _____

CHAIN OF CUSTODY

SAMPLE SPLIT?: Y | N

SPLITTING DEVICE: _____

SPLIT METHOD: _____

SPLIT RECOVERY %: _____

CHAIN OF CUSTODY NUMBER: _____

SHIPPED VIA: Dropped off at

COMMENTS / MISCELLANEOUS

*ABG denotes ash, brick, and/or glass

[illegible]