North Parking Lot Mercury Speciation Soil Investigation Work Plan

Olin Niagara Falls Plant Niagara Falls, New York



Prepared by:



AMEC Environment &Infrastructure, Inc. 1075 Big Shanty Road NW, Suite 100 Kennesaw, Georgia 30144

> January 9, 2015 Project 6107-15-0002

TABLE OF CONTENTS

<u>Page</u>

1.0	INTRODUCTION1-1		
2.0	OBJECTIVES		
3.0	SAMPI	LE COLLECTION AND ANALYSIS	3-1
	3.1	SAMPLE COLLECTION	3-1
	3.2	FIELD QUALITY CONTROL SAMPLES	
	3.3	SAMPLE LABELS	3-1
	3.4	DECONTAMINATION	
	3.5	HEALTH AND SAFETY REQUIREMENTS	3-2
	3.6	SAMPLE ANALYSIS	3-2
4.0		EVALUATION AND REPORTING	
5.0		DULE	
6.0	REFEF	RENCES	6-1
FIGUR	ES		
APPEN	NDICES		

LIST OF FIGURES

Figure

- 1.1 Site Layout and Historic Soil Results
- 3.1 Surface Soil Sampling Locations

LIST OF APPENDICES

Appendix

- A USEPA Method 1631, Revision E
- B Analytical Laboratory SOPs for Performing Method 1631, Revision E

North Parking Lot Mercury Speciation Soil Investigation Work Plan Olin Niagara Falls Plant, Niagara Falls, New York AMEC Project Number 6107150002

ABBREVIATIONS AND ACRONYMS

Acronym	Definition
DD	Day
DI	De-ionized
GPS	Global Positioning System
HASP	Health and Safety Plan
HAZWOPER	Hazardous Waste Operations and Emergency Response
Hg	mercury
mg/kg	milligram per kilogram
MM	Month
NYSDEC	New York State Department of Environmental Conservation
PPE	Personal Protective Equipment
QC	Quality Control
SCO	Soil Cleanup Objective
SOP	Standard Operating Procedure
SS	Stainless Steel
USEPA	United States Environmental Protection Agency
YYYY	Year

1.0 INTRODUCTION

The Olin Parking Lot Site (Parcels I and II) is located north of Buffalo Avenue, across from Olin's Niagara Falls, Chlor-Alkali Plant (Figure 1.1). Results from previous sampling and analysis showed sporadic mercury detections in the Parking Lot Site surface soils. The mercury is thought to be associated with brine muds generated in the chlor-alkali process that were used to repair potholes in the Parking Lot Site in the 1950s or 1960s.

In 2014, Olin conducted a soil investigation in which representative surface soils from the Parking Lot Site were collected and analyzed for total mercury (Hg) to characterize the surface soils of the Parking Lot Site (AMEC, 2014). The report provides analytical results for 50 soil samples collected in Parking Lot Parcels I and II of the Olin Site. At thirteen sample locations mercury was detected at concentrations above the NYSDEC Industrial Soil Cleanup Objective (SCO) of 5.7 mg/kg for elemental mercury. No results exceeded the Industrial SCO of 220 mg/kg for inorganic salts of mercury in the brine circuit is likely to be an inorganic salt; therefore a presumption in the 2014 report was that the primary form of mercury in the brine muds was an inorganic salt.

After reviewing the 2014 AMEC report, the NYSDEC submitted a December 4, 2014 letter to Olin which indicated that NYSDEC must assume that the mercury in the soil samples is in the elemental form unless shown otherwise by analytical data. Subsequently, Olin offered to prepare this work plan for submittal, review, and approval by NYSDEC which includes an analytical method that can reliably and quantitatively differentiate various mercury species.

Olin proposes to collect samples at three locations, distributed spatially across the parking lot, at locations where the highest mercury concentrations were detected. The shallow surface soil samples will then be analyzed for total and elemental mercury to obtain inorganic mercury by mathematical subtraction. Once mercury speciation data is available, then data can be compared to the industrial SCOs for elemental mercury and inorganic mercury (5.7 mg/kg and 220 mg/kg) respectively. These data would then be used to develop an average ratio of elemental to inorganic mercury that could be compared to the remaining original samples for

North Parking Lot Mercury Speciation Soil Investigation Work Plan Olin Niagara Falls Plant, Niagara Falls, New York AMEC Project Number 6107150002

evaluating SCOs. This work plan describes the objectives, sample collection and analysis, data evaluation, reporting, and schedule for this work. This work plan has been written to specify analysis of individually collected samples, rather than composited samples.

2.0 OBJECTIVES

The characterization objectives are to:

- Collect surface soil samples from the Parking Lot Site at three separate locations.
- Analyze the samples for total mercury and elemental mercury to characterize the Parking Lot Site surface soils.
- Select an appropriate remedy for the Parking Lot Site based on the speciated surface soil sampling results.

3.0 SAMPLE COLLECTION AND ANALYSIS

This section describes the sample collection procedures, decontamination process, analytical method, and health and safety requirements.

3.1 SAMPLE COLLECTION

Three surface soil borings will be advanced at the Parking Lot Site. Approximate locations are shown on Figure 3.1. These locations coincide with previously collected samples to allow correlation of results obtained by using different analytical methods. Sample locations will be at previously sampled locations PLS-SS-10, PLS-SS-19, and PLS-SS-42. The latitude and longitude of the initial borings were surveyed with a handheld global positioning system (GPS), and a GPS will again be used to reoccupy these locations to collect the proposed samples.

The hand borings will be advanced to depths consistent with the original samples and samples collected using pre-cleaned, dedicated, stainless steel (SS) hand augers or other hand-operated tools. The borings will be advanced to 2-inches below the existing vegetation or cover material (gravel, etc.) as specified for surface soil investigations in NYSDEC Technical Guidance Document DER-10 (NYSDEC, 2010). Soil will be collected from the boring and placed in a clean, laboratory-supplied, 4-ounce glass jar.

3.2 FIELD QUALITY CONTROL SAMPLES

A Field Quality Control (QC) sample will consist of one duplicate samples collected at the PLS-SS-19 location where the highest mercury concentration was previously detected.

3.3 SAMPLE LABELS

The samples to be submitted to the laboratory will be identified and labeled as follows:

- 1. PLS-SS-X-MMDDYYY (X = 1 50 corresponding to boring location)
- 2. DUP01-SS-MMDDYYYY (for the duplicate sample)

3.4 **DECONTAMINATION**

Sample collection tools, utensils, and bowls will be decontaminated prior to sampling, with individually dedicated sets of tools to be used at each of the locations. The tools brought to the site

will be decontaminated prior to mobilization and will be wrapped in aluminum foil during transportation to the site. Decontamination of the tools will be as follows:

- 1. Liquinox and water wash
- 2. DI water rinse
- 3. Nitric Acid rinse
- 4. DI water rinse

After the samples are collected, any excess solids will be placed back into the individual excavations. Field personnel will wear nitrile gloves when handling the samples or sample tools. New gloves will be used in each area. Nitrile gloves and other personal protective equipment (PPE) will be disposed of with Olin's general waste.

Due to the relatively high concentrations of mercury detected previously compared to analytical detection limits, additional procedures for sample handling are not required.

3.5 HEALTH AND SAFETY REQUIREMENTS

Safety requirements will be outlined in a separate Health and Safety Plan (HASP). The HASP will be provided to field personnel for review before the investigation, and personnel performing the onsite investigation work will be required to sign an acknowledgement that they are familiar with the HASP.

Personnel engaged in field activities with potential for exposure to contaminants are required to have completed 40 hours of initial Hazardous Waste Operations and Emergency Response (HAZWOPER) training and annual 8-hour refreshers. Site personnel will be required to wear the PPE specified in the HASP while engaged in field activities or while onsite during field activities. Level D PPE (hard hat, safety shoes, safety glasses) will be required at a minimum for personnel collecting the soil samples. Level D PPE is anticipated to offer sufficient protection to personnel working onsite.

3.6 SAMPLE PRESERVATION AND ANALYSIS

The samples will be properly preserved and shipped to Eurofins Laboratory for analysis. Upon collection, samples will be preserved by being placed immediately on dry ice to freeze the soil.

North Parking Lot Mercury Speciation Soil Investigation Work Plan Olin Niagara Falls Plant, Niagara Falls, New York AMEC Project Number 6107150002

Headspace in the glass jar should be provided for soil expansion so that the glass jars do not break. Each sample will consist of two jars to insure against breakage.

The samples will be analyzed for total mercury by United States Environmental Protection Agency (USEPA) Method 1631E, and for Elemental Hg by USEPA Modified Method 1631E (Appendix A). For these methods, the typical reporting limit for Total Hg is 1.0 ng/g, and for Elemental Hg it is 2.0 ng/g, which are well below the NYSDEC Industrial SCO of 5.7 mg/kg for elemental Hg. The SOPs for this method, which represent the laboratory's procedures for these methods, are included in Appendix B. Appendix B contains a summary of the SOP sections that are relevant to the elemental and inorganic mercury analyses.

The analytical procedures will provide results for total mercury and elemental mercury in soils. The total mercury digestion and analytical procedures are described in Eurofins / Frontier Geosciences SOPs EFGS-066 and EFGS-121 (Appendix B). The method preparation and analysis is designed to report all types of mercury present in the sample including elemental and total. The concentration of elemental mercury is obtained using the elemental mercury procedure F0 described in Sections 5.2 and 15.1 of SOP FGS-090-R04. This procedure is based on the known volatility of elemental mercury during the condition of the sample preparation. Elemental mercury is vaporized and captured on a trap in the sample preparation step. Volatile mercury is collected on a Flue Gas Sorbent Total Mercury (FSTM) trap designed for mercury air emissions testing. The trap is then analyzed for total mercury. Other forms of mercury will not volatilize. Information on the FSTM traps is found at the link below:

http://www.sigmaaldrich.com/technical-documents/articles/analytix/us-epa-324-vapor-phase.html

Appendix A of this work plan contains USEPA Method 1631, Revision E, and Appendix B contains the analytical laboratory Standard Operating Procedures (SOPs) for the method used by Eurofins labs.

4.0 DATA EVALUATION AND REPORTING

A Level I completeness check will be performed on the data generated from the samples collected with this work. This verification will include checks that:

- All results are present for the parameters requested on the chain-of-custody for each sample submitted
- Requested methods were utilized
- Reporting limits were adhered to with the exception of dilutions
- Requested reporting units were provided
- The data package includes a definition of any qualifiers
- Exceptions to the data are documented

After the data checks have been performed, the sample results will be compared to the NYSDEC Industrial SCOs for elemental and inorganic mercury. A report will then be prepared that will detail the sampling effort and results.

5.0 SCHEDULE

Olin proposes to complete the field work when the weather becomes favorable but no later than April 30, 2015. Analytical results are expected to be available within 30 days of the sampling event. A report of the field investigation results, evaluation of the sampling data, and remedy selection will be submitted to NYSDEC within 30 days of the final lab report data validation.

6.0 **REFERENCES**


AMEC. (2014). *North Parking Lot Soil Investigation, Niagara Falls, New York*. Prepared for Olin Corporation, August 15, 2014.


NYSDEC. (2010). *DER 10 / Technical Guidance for Site Investigation and Remediation.* Albany, NY: NYSDEC.

USEPA. (2002). *Method 1361, Revision E: Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry.* August 2002.

North Parking Lot Mercury Speciation Soil Investigation Work Plan Olin Niagara Falls Plant, Niagara Falls, New York AMEC Project Number 6107150002 January 9, 2015

FIGURES






North Parking Lot Mercury Speciation Soil Investigation Work Plan Olin Niagara Falls Plant, Niagara Falls, New York AMEC Project Number 6107150002 January 9, 2015

APPENDIX A

Method 1631E



Method 1631, Revision E: Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry



August 2002

Method 1631, Revision E: Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry

Acknowledgments

This Method was developed under the direction of William A. Telliard and Maria Gomez-Taylor of the Engineering and Analysis Division (EAD) within the U.S. Environmental Protection Agency's (EPA's) Office of Science and Technology (OST). EPA acknowledges contributions to this method by Frontier Geosciences, Inc., Albion Environmental, Battelle Marine Sciences Laboratory, STL-Canton, and Tekran Inc. Additional assistance in preparing the Method was provided by DynCorp Environmental and Interface, Inc.

Disclaimer

This Method has been reviewed and approved for publication by the Statistics and Analytical Support Branch within EPA's Engineering and Analysis Division. Mention of trade names or commercial products does not constitute endorsement or recommendation for use.

Questions concerning this Method or its application should be addressed to:

W.A. Telliard
Statistics and Analytical Support Branch (4303T)
U.S. Environmental Protection Agency
Ariel Rios Building
1200 Pennsylvania Avenue, N.W.
Washington, DC 20460
Phone: 202/566–1061
Fax: 202/566–1053

Table of Contents

Introduction iii			
1.0	Scope and Application 1		
2.0	Summary of Method 2		
3.0	Definitions 3		
4.0	Contamination and Interferences 3		
5.0	Safety 6		
6.0	Apparatus and Materials 8		
7.0	Reagents and Standards 11		
8.0	Sample Collection, Preservation, and Storage 13		
9.0	Quality Control		
10.0	Calibration and Standardization 22		
11.0	Procedure		
12.0	Data Analysis and Calculations 27		
13.0	Method Performance		
14.0	Pollution Prevention		
15.0	Waste Management		
16.0	References		
17.0	Glossary		
18.0	Tables and Figures 34		

Introduction

Method 1631 (the "Method") supports technology-based and water quality-based monitoring programs authorized under the Clean Water Act (CWA; the "Act").

CWA Sections 301 and 306 require EPA to publish effluent standards that restrict the direct discharge of pollutants to the nations waters, and CWA Sections 307(b) and (c) require EPA to promulgate nationally applicable pretreatement standards which restrict pollutant discharges into sewers flowing to publicly owned treatment works (POTWs). The effluent limitations guidelines are published at CFR parts 401-503.

CWA Section 303 requires each State to set a water quality standard for each body of water within its boundaries. A State water quality standard consists of a designated use or uses of a water body or a segment of a water body, the water quality criteria that are necessary to protect the designated use or uses, and an antidegradation policy. CWA Section 304(a) requires EPA to publish water quality criteria that reflect the latest scientific knowledge concerning the physical fate of pollutants, the effects of pollutants on ecological and human health, and the effect of pollutants on biological community diversity, productivity, and stability. These water quality standards serve two purposes: (1) they establish the water quality goals for a specific water body, and (2) they are the basis for establishing water quality-based treatment controls and strategies beyond the technology-based controls required by CWA Sections 301(b) and 306.

In 1987, amendments to the CWA required States to adopt numeric criteria for toxic pollutants (designated in Section 307(a) of the Act) based on EPA Section 304(a) criteria or other scientific data, when the discharge or presence of those toxic pollutants could reasonably be expected to interfere with designated uses. Method 1631 was specifically developed to provide reliable measurements of mercury at EPA WQC levels.

In developing methods for determination of trace metals, EPA found that one of the greatest difficulties was precluding sample contamination during collection, transport, and analysis. The degree of difficulty, however, is highly dependent on the metal and site-specific conditions. Method 1631 is designed to preclude contamination in nearly all situations. It also contains procedures necessary to produce reliable results at the lowest WQC levels published by EPA. In recognition of the variety of situations to which this Method may be applied, and in recognition of continuing technological advances, Method 1631 is performance based. Alternative procedures may be used so long as those procedures are demonstrated to yield reliable results.

Requests for additional copies of this draft Method should be directed to:

U.S. EPA Sample Control Center 6101 Stevenson Avenue Alexandria, VA 22304-3540 703/461–2100 Note: This Method is performance based. The laboratory is permitted to omit steps or modify procedures provided that all performance requirements in this Method are met. The laboratory must not omit or modify any procedure defined by the term "shall" or "must" and must perform all quality control tests.

Method 1631, Revision E

Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry

1.0 Scope and Application

- **1.1** Method 1631, Revision E (the "Method") is for determination of mercury (Hg) in filtered and unfiltered water by oxidation, purge and trap, desorption, and cold-vapor atomic fluorescence spectrometry (CVAFS). This Method is for use in EPA's data gathering and monitoring programs associated with the Clean Water Act, the Resource Conservation and Recovery Act, the Comprehensive Environmental Response, Compensation and Liability Act, and the Safe Drinking Water Act. The Method is based on a contractor-developed procedure (Reference 16.1) and on peer-reviewed, published procedures for the determination of mercury in aqueous samples, ranging from sea water to sewage effluent (References 16.2–16.5).
- **1.2** This Method is accompanied by Method 1669: *Sampling Ambient Water for Determination of Trace Metals at EPA Water Quality Criteria Levels* (Sampling Method). The Sampling Method guidance document is recommended to preclude contamination during the sampling process.
- **1.3** This Method is for determination of Hg in the range of 0.5–100 ng/L. Application may be extended to higher levels by selection of a smaller sample size or by calibration of the analytical system across a higher range. For measurement of blank samples, the Method may be extended to a lower level by calibration to a lower calibration point. Section 10.4 gives requirements for extension of the calibration range.
- **1.4** The ease of contaminating ambient water samples with mercury and interfering substances cannot be overemphasized. This Method includes suggestions for improvements in facilities and analytical techniques that should minimize contamination and maximize the ability of the laboratory to make reliable trace metals determinations. Certain sections of this Method contain suggestions and other sections contain requirements to minimize contamination.
- **1.5** The detection limit and minimum level of quantitation in this Method usually are dependent on the level of interferences rather than instrument limitations. The method detection limit (MDL; 40 CFR 136, Appendix B) for Hg has been determined to be 0.2 ng/L when no interferences are present. The minimum level of quantitation (ML) has been established as 0.5 ng/L. An MDL as low as 0.05 ng/L can be achieved for low Hg samples by using a larger sample volume, a lower BrCl level (0.2%), and extra caution in sample handling.
- **1.6** Clean and ultraclean—The terms "clean" and "ultraclean" have been applied to the techniques needed to reduce or eliminate contamination in trace metals determinations. These terms are not used in this Method because they lack an exact definition. However, the information provided in this Method is consistent with the summary guidance on clean and ultraclean techniques (References 16.6-16.7).
- **1.7** This Method follows the EPA Environmental Methods Management Council's "Guidelines and Format for Methods to Be Proposed at 40 CFR, part 136 or part 141."

- **1.8** This Method is "performance based." The laboratory is permitted to modify the Method to overcome interferences or lower the cost of measurements if all performance criteria are met. Section 9.1.2.1 gives the requirements for establishing method equivalency.
- **1.9** Any modification of this Method, beyond those expressly permitted, shall be considered a major modification subject to application and approval of alternate test procedures under 40 CFR 136.4 and 136.5.
- **1.10** This Method should be used only by analysts experienced in the use of CVAFS techniques and who are trained thoroughly in the sample handling and instrument techniques described in this Method. Each laboratory that uses this Method must demonstrate the ability to generate acceptable results using the procedures in Section 9.2.
- **1.11** This Method is accompanied by a data verification and validation guidance document, *Guidance on the Documentation and Evaluation of Trace Metals Data Collected for CWA Compliance Monitoring* (Reference 16.8), that can be used for verification and validation of the data obtained.
- **1.12** This Method uses either a bubbler or flow-injection system for determination of mercury in water. Separate calibration, analysis, and calculation procedures are provided for a bubbler system (Sections 10.2, 11.2.1, and 12.2) and for a flow-injection system (Sections 10.3, 11.2.2, and 12.3).

2.0 Summary of Method

- **2.1** A 100- to 2000-mL sample is collected directly into a cleaned, pretested, fluoropolymer or glass bottle using sample handling techniques designed for collection of mercury at trace levels (Reference 16.9).
- **2.2** For dissolved Hg, the sample is filtered through a 0.45-µm capsule filter prior to preservation.
- **2.3** The sample is preserved by adding either pretested 12N hydrochloric acid (HCl) or bromine monochloride (BrCl) solution. If a sample will also be used for the determination of methyl mercury, it should be preserved according to procedures in the method that will be used for determination of methylmercury.
- **2.4** Prior to analysis, all Hg in a 100-mL sample aliquot is oxidized to Hg(II) with BrCl.
- **2.5** After oxidation, the sample is sequentially reduced with $NH_2OH \cdot HCl$ to destroy the free halogens, then reduced with stannous chloride (SnCl₂) to convert Hg(II) to volatile Hg(0).
- **2.6** The Hg(0) is separated from solution either by purging with nitrogen, helium, or argon, or by vapor/liquid separation. The Hg(0) is collected onto a gold trap (Figures 1, 2, and 3).
- **2.7** The Hg is thermally desorbed from the gold trap into an inert gas stream that carries the released Hg(0) to a second gold (analytical) trap. The Hg is desorbed from the analytical trap into a gas stream that carries the Hg into the cell of a cold-vapor atomic fluorescence spectrometer (CVAFS) for detection (Figures 2 and 3).
- **2.8** Quality is assured through calibration and testing of the oxidation, purging, and detection systems.

3.0 Definitions

- **3.1** Total mercury—all BrCl-oxidizable mercury forms and species found in an unfiltered aqueous solution. This includes, but is not limited to, Hg(II), Hg(0), strongly organo-complexed Hg(II) compounds, adsorbed particulate Hg, and several tested covalently bound organo-mercurials (e.g., CH₃HgCl, (CH₃)₂Hg, and C₆H₅HgOOCCH₃). The recovery of Hg bound within microbial cells may require the additional step of UV photo-oxidation. In this Method, total mercury and total recoverable mercury are synonymous.
- **3.2** Dissolved mercury—all BrCl-oxidizable mercury forms and species found in the filtrate of an aqueous solution that has been filtered through a 0.45-µm filter.
- **3.3** Apparatus—Throughout this Method, the sample containers, sampling devices, instrumentation, and all other materials and devices used in sample collection, sample processing, and sample analysis that come in contact with the sample and therefore require careful cleaning will be referred to collectively as the Apparatus.
- **3.4** Definitions of other terms used in this Method are given in the glossary (Section 17.0).

4.0 Contamination and Interferences

- **4.1** Preventing samples from becoming contaminated during the sampling and analysis process constitutes one of the greatest difficulties encountered in trace metals determinations. Over the last two decades, marine chemists have come to recognize that much of the historical data on the concentrations of dissolved trace metals in seawater are erroneously high because the concentrations reflect contamination from sampling and analysis rather than ambient levels. Therefore, it is imperative that extreme care be taken to avoid contamination when collecting and analyzing samples for trace metals.
- **4.2** Samples may become contaminated by numerous routes. Potential sources of trace metals contamination during sampling include: metallic or metal-containing labware (e.g., talc gloves that contain high levels of zinc), containers, sampling equipment, reagents, and reagent water; improperly cleaned or stored equipment, labware, and reagents; and atmospheric inputs such as dirt and dust. Even human contact can be a source of trace metals contamination. For example, it has been demonstrated that dental work (e.g., mercury amalgam fillings) in the mouths of laboratory personnel can contaminate samples directly exposed to exhalation (Reference 16.9).
- **4.3** Contamination Control
 - 4.3.1 Philosophy—The philosophy behind contamination control is to ensure that any object or substance that contacts the sample is metal free and free from any material that may contain mercury.
 - 4.3.1.1 The integrity of the results produced cannot be compromised by contamination of samples. This Method and the Sampling Method give requirements and suggestions for control of sample contamination.

- 4.3.1.2 Substances in a sample cannot be allowed to contaminate the laboratory work area or instrumentation used for trace metals measurements. This Method gives requirements and suggestions for protecting the laboratory.
- 4.3.1.3 Although contamination control is essential, personnel health and safety remain the highest priority. The Sampling Method and Section 5 of this Method give suggestions and requirements for personnel safety.
- 4.3.2 Avoiding contamination—The best way to control contamination is to completely avoid exposure of the sample to contamination in the first place. Avoiding exposure means performing operations in an area known to be free from contamination. Two of the most important factors in avoiding/reducing sample contamination are (1) an awareness of potential sources of contamination and (2) strict attention to work being done. Therefore, it is imperative that the procedures described in this Method be carried out by well-trained, experienced personnel.
- 4.3.3 Use a clean environment—The ideal environment for processing samples is a class-100 clean room. If a clean room is not available, all sample preparation should be performed in a class-100 clean bench or a nonmetal glove box fed by mercury-and particle-free air or nitrogen. Digestion should be performed in a nonmetal fume hood equipped with HEPA filtration and ideally situated in a clean room.
- 4.3.4 Minimize exposure—The Apparatus that will contact samples, blanks, or standard solutions should be opened or exposed only in a clean room, clean bench, or glove box so that exposure to an uncontrolled atmosphere is minimized. When not being used, the Apparatus should be covered with clean plastic wrap, stored in the clean bench or in a plastic box or glove box, or bagged in clean zip-type bags. Minimizing the time between cleaning and use will also minimize contamination.
- 4.3.5 Clean work surfaces—Before a given batch of samples is processed, all work surfaces in the hood, clean bench, or glove box in which the samples will be processed should be cleaned by wiping with a lint-free cloth or wipe soaked with reagent water.
- 4.3.6 Wear gloves—Sampling personnel must wear clean, non-talc gloves during all operations involving handling of the Apparatus, samples, and blanks. Only clean gloves may touch the Apparatus. If another object or substance is touched, the glove(s) must be changed before again handling the Apparatus. If it is even suspected that gloves have become contaminated, work must be halted, the contaminated gloves removed, and a new pair of clean gloves put on. Wearing multiple layers of clean gloves will allow the old pair to be quickly stripped with minimal disruption to the work activity.
- 4.3.7 Use metal-free Apparatus—All Apparatus used for determination of mercury at ambient water quality criteria levels must be nonmetallic, free of material that may contain metals, or both.
 - 4.3.7.1 Construction materials—Only fluoropolymer or glass containers must be used for collection of samples that will be analyzed for mercury because mercury vapors can diffuse in or out of other materials, leading to results that are biased low or high. Polyethylene and/or polypropylene labware may be used for digestion and other purposes because the time of sample exposure to these materials is relatively short. All materials, regardless of construction, that will directly or

indirectly contact the sample, must be known to be clean and free of Hg at the levels specified in this Method before proceeding.

- 4.3.7.2 Serialization—It is recommended that serial numbers be indelibly marked or etched on each piece of reusable Apparatus so that contamination can be traced, and logbooks should be maintained to track the sample from the container through the labware to introduction into the instrument. It may be useful to dedicate separate sets of labware to different sample types; e.g., receiving waters vs. effluents. However, the Apparatus used for processing blanks and standards must be mixed with the Apparatus used to process samples so that contamination of all labware can be detected.
- 4.3.7.3 The laboratory or cleaning facility is responsible for cleaning the Apparatus used by the sampling team. If there are any indications that the Apparatus is not clean when received by the sampling team (e.g., ripped storage bags), an assessment of the likelihood of contamination must be made. Sampling must not proceed if it is possible that the Apparatus is contaminated. If the Apparatus is contaminated, it must be returned to the laboratory or cleaning facility for proper cleaning before any sampling activity resumes.
- 4.3.8 Avoid sources of contamination—Avoid contamination by being aware of potential sources and routes of contamination.
 - 4.3.8.1 Contamination by carryover—Contamination may occur when a sample containing a low concentration of mercury is processed immediately after a sample containing a relatively high concentration of mercury. The Hg concentration at which the analytical system (purge, traps, detector) will carry greater than 0.5 ng/L of Hg into a succeeding bubbler or system blank must be determined by analyzing calibration solutions containing successively larger concentrations of Hg. This test must be run prior to first use of the analytical system and whenever a change is made that would increase the amount of carryover. When a sample contains $\frac{1}{2}$ or greater of this determined Hg concentration, a bubbler blank (bubbler system) or system blank (flow injection system) must be analyzed to demonstrate no carryover at the blank criteria level. For the bubbler system, the blank must be run using the same bubbler and sample trap used to run the high concentration sample. Samples analyzed following a sample that has been determined to result in carryover must be reanalyzed. Samples that are known or suspected to contain the lowest concentration of mercury should be analyzed first followed by samples containing higher levels.
 - 4.3.8.2 Contamination by samples—Significant laboratory or instrument contamination may result when untreated effluents, in-process waters, landfill leachates, and other undiluted samples containing concentrations of mercury greater than 100 ng/L are processed and analyzed. Samples known or suspected to contain Hg concentrations greater than 100 ng/L should be diluted prior to bringing them into the clean room or laboratory dedicated for processing trace metals samples.
 - 4.3.8.3 Contamination by indirect contact—Apparatus that may not directly come in contact with the samples may still be a source of contamination. For example, clean tubing placed in a dirty plastic bag may pick up contamination from the bag and subsequently transfer the contamination to the sample. It is imperative that every piece of the Apparatus that is directly or indirectly used in the collection, processing, and analysis of water samples be thoroughly cleaned (Section 6.1.2).

- 4.3.8.4 Contamination by airborne particulate matter—Less obvious substances capable of contaminating samples include airborne particles. Samples may be contaminated by airborne dust, dirt, particles, or vapors from unfiltered air supplies; nearby corroded or rusted pipes, wires, or other fixtures; or metal-containing paint. Whenever possible, sample processing and analysis should occur as far as possible from sources of airborne contamination.
- 4.3.8.5 Contamination from reagents— Contamination can be introduced into samples from method reagents used during processing and analysis. Reagent blanks must be analyzed for contamination prior to use (see Section 9.4.3). If reagent blanks are contaminated, a new batch of reagents must be prepared (see Section 9.4.3.2).

4.4 Interferences

- 4.4.1 At the time of promulgation of this Method, gold and iodide were known interferences. At a mercury concentration of 2.5 ng/L and at increasing iodide concentrations from 30 to 100 mg/L, test data have shown that mercury recovery will be reduced from 100 to 0 percent. At iodide concentrations greater than 3 mg/L, the sample should be prereduced with SnCl₂ (to remove the brown color) and additional or more concentrated SnCl₂ should be added. To preclude loss of Hg, the additional SnCl₂ should be added in a closed vessel or analysis should proceed immediately. If samples containing iodide concentrations greater than 30 mg/L are analyzed, it may be necessary to clean the analytical system with 4N HCl after the analysis (Reference 16.10).
- 4.4.2 The potential exists for destruction of the gold traps if free halogens are purged onto them, or if they are overheated (>500 °C). When the instructions in this Method are followed, neither of these outcomes is likely.
- 4.4.3 Water vapor may collect in the gold traps and subsequently condense in the fluorescence cell upon desorption, giving a false peak due to scattering of the excitation radiation. Condensation can be avoided by predrying the gold trap. Traps that tend to absorb large quantities of water vapor should not be used.
- 4.4.4 The fluorescent intensity is strongly dependent upon the presence of molecular species in the carrier gas that can cause "quenching" of the excited atoms. The dual amalgamation technique eliminates quenching due to trace gases, but it remains the laboratory's responsibility to ensure high purity inert carrier gas and a leak-free analytical train.

5.0 Safety

- **5.1** The toxicity or carcinogenicity of each chemical used in this Method has not been precisely determined; however, each compound should be treated as a potential health hazard. Exposure to these compounds should be reduced to the lowest possible level.
 - 5.1.1 Chronic mercury exposure may cause kidney damage, muscle tremors, spasms, personality changes, depression, irritability and nervousness. Organo-mercurials may cause permanent brain damage. Because of the toxicological and physical properties of Hg, pure standards should be handled only by highly trained personnel thoroughly familiar with handling and cautionary procedures and the associated risks.

- 5.1.2 It is recommended that the laboratory purchase a dilute standard solution of the Hg in this Method. If primary solutions are prepared, they shall be prepared in a hood, and a NIOSH/MESA-approved toxic gas respirator shall be worn.
- **5.2** This Method does not address all safety issues associated with its use. The laboratory is responsible for maintaining a current file of OSHA regulations for safe handling of the chemicals specified in this Method. OSHA rules require that a reference file of material safety data sheets (MSDSs) must be made available to all personnel involved in these analyses (29 CFR 1917.28, Appendix E). It also is suggested that the laboratory perform personal hygiene monitoring of each analyst who uses this Method and that the results of this monitoring be made available to the analyst. Personal hygiene monitoring should be performed using OSHA or NIOSH approved personal hygiene monitoring methods. Additional information on laboratory safety can be found in References 16.11-16.14. The references and bibliography included in Reference 16.14 are particularly comprehensive in dealing with the general subject of laboratory safety.
- **5.3** Samples suspected to contain concentrations of Hg at μ g/L or higher levels are handled using essentially the same techniques employed in handling radioactive or infectious materials. Well-ventilated, controlled access laboratories are required. Assistance in evaluating the health hazards of particular laboratory conditions may be obtained from certain consulting laboratories and from State Departments of Health or Labor, many of which have an industrial health service. Each laboratory must develop a safety program for handling Hg.
 - 5.3.1 Facility—When samples known or suspected of containing high concentrations of mercury are handled, all operations (including removal of samples from sample containers, weighing, transferring, and mixing) should be performed in a glove box demonstrated to be leak-tight or in a fume hood demonstrated to have adequate airflow. Gross losses to the laboratory ventilation system must not be allowed. Handling of the dilute solutions normally used in analytical and animal work presents no inhalation hazards except in an accident.
 - 5.3.2 Protective equipment—Disposable plastic gloves, apron or lab coat, safety glasses or mask, and a glove box or fume hood adequate for radioactive work should be used. During analytical operations that may give rise to aerosols or dusts, personnel should wear respirators equipped with activated carbon filters.
 - 5.3.3 Training—Workers must be trained in the proper method of removing contaminated gloves and clothing without contacting the exterior surfaces.
 - 5.3.4 Personal hygiene—Hands and forearms should be washed thoroughly after each manipulation and before breaks (coffee, lunch, and shift).
 - 5.3.5 Confinement—Isolated work areas posted with signs, segregated glassware and tools, and plastic absorbent paper on bench tops will aid in confining contamination.
 - 5.3.6 Effluent vapors—The effluent from the CVAFS should pass through either a column of activated charcoal or a trap containing gold or sulfur to amalgamate or react mercury vapors.
 - 5.3.7 Waste handling—Good technique includes minimizing contaminated waste. Plastic bag liners should be used in waste cans. Janitors and other personnel must be trained in the safe handling of waste.
 - 5.3.8 Decontamination

- 5.3.8.1 Decontamination of personnel—Use any mild soap with plenty of scrubbing action.
- 5.3.8.2 Glassware, tools, and surfaces—Sulfur powder will react with Hg to produce mercuric sulfide, thereby eliminating the possible volatilization of Hg. Satisfactory cleaning may be accomplished by dusting a surface lightly with sulfur powder, then washing with any detergent and water.
- 5.3.9 Laundry—Clothing known to be contaminated should be collected in plastic bags. Persons that convey the bags and launder the clothing should be advised of the hazard and trained in proper handling. If the launderer knows of the potential problem, the clothing may be put into a washer without contact. The washer should be run through a cycle before being used again for other clothing.
- 5.3.10 Wipe tests—A useful method of determining cleanliness of work surfaces and tools is to wipe the surface with a piece of filter paper. Extraction and analysis by this Method can achieve a limit of detection of less than 1 ng per wipe. Less than 0.1 μ g per wipe indicates acceptable cleanliness; anything higher warrants further cleaning. More than 10 μ g on a wipe constitutes an acute hazard and requires prompt cleaning before further use of the equipment or work space, and indicates that unacceptable work practices have been employed.

6.0 Apparatus and Materials

Disclaimer: The mention of trade names or commercial products in this Method is for illustrative purposes only and does not constitute endorsement or recommendation for use by the Environmental Protection Agency. Equivalent performance may be achievable using apparatus, materials, or cleaning procedures other than those suggested here. The laboratory is responsible for demonstrating equivalent performance.

- 6.1 Sampling equipment
 - 6.1.1 Sample collection bottles-fluoropolymer or glass, 125- to 1000-mL, with fluoropolymer or fluoropolymer-lined cap.
 - 6.1.2 Cleaning
 - 6.1.2.1 New bottles are cleaned by heating to 65–75 °C in 4 N HCl or concentrated HNO₃ for at least 48 h. The bottles are cooled, rinsed three times with reagent water, and filled with reagent water containing 1% HCl. These bottles are capped and placed in a clean oven at 60-70°C overnight. After cooling, they are rinsed three more times with reagent water, filled with reagent water containing 0.4% (v/v) HCl, and placed in a mercury-free Class-100 clean bench until the outside surfaces are dry. The bottles are tightly capped (with a wrench), double-bagged in new polyethylene zip-type bags until needed, and stored in wooden or plastic boxes until use. The bottles may be shipped to the sampling site containing dilute HCl solution (e.g., 0.04%), containing reagent water, or empty.
 - 6.1.2.2 Used bottles known not to have contained mercury at high (>100 ng/L) levels are cleaned as above, except for only 6–12 h in hot 4 N HCl.

- 6.1.2.3 Bottle blanks must be analyzed as described in Section 9.4.7. To verify the effectiveness of the cleaning procedures, bottle blanks must be demonstrated to be free of mercury at the ML of this Method.
- 6.1.2.4 As an alternative to cleaning by the laboratory, bottles may be purchased from a commercial supplier and each lot certified to be clean. Bottles from the lot must be tested as bottle blanks (Section 9.4.7) and demonstrated to be free of mercury at the ML of this Method. If mercury is present above this level in any bottle, either the lot must be rejected or the bottles must be re-cleaned.
- 6.1.3 Filtration Apparatus
 - 6.1.3.1 Filter—0.45-μm, 15-mm diameter capsule filter (Gelman Supor 12175, or equivalent)
 - 6.1.3.2 Peristaltic pump—115-V a.c., 12-V d.c., internal battery, variable-speed, singlehead (Cole-Parmer, portable, "Masterflex L/S," Catalog No. 07570-10 drive with Quick Load pump head, Catalog No. 07021-24, or equivalent).
 - 6.1.3.3 Tubing—styrene/ethylene/butylene/silicone (SEBS) resin for use with peristaltic pump, approx 3/8-in ID by approximately 3 ft (Cole-Parmer size 18, Catalog No. 06424-18, or approximately 1/4-in OD, Cole-Parmer size 17, Catalog No. 06424-17, or equivalent). Tubing is cleaned by soaking in 5–10% HCl solution for 8–24 h, rinsing with reagent water in a clean bench in a clean room, and drying in the clean bench by purging with metal-free air or nitrogen. After drying, the tubing is double-bagged in clear polyethylene bags, serialized with a unique number, and stored until use.
- **6.2** Equipment for bottle and glassware cleaning
 - 6.2.1 Vat, 100–200 L, high-density polyethylene (HDPE), half filled with 4 N HCl in reagent water.
 - 6.2.2 Panel immersion heater, 500-W, all-fluoropolymer coated, 120 vac (Cole-Parmer H-03053-04, or equivalent)

WARNING: Read instructions carefully!! The heater will maintain steady state, without temperature feedback control, of 60–75°C in a vat of the size described. However, the equilibrium temperature will be higher (up to boiling) in a smaller vat. Also, the heater plate MUST be maintained in a vertical position, completely submerged and away from the vat walls to avoid melting the vat or burning out!

- 6.2.3 Laboratory sink—in Class-100 clean area, with high-flow reagent water (Section 7.1) for rinsing.
- 6.2.4 Clean bench—Class-100, for drying rinsed bottles.
- 6.2.5 Oven—stainless steel, in Class-100 clean area, capable of maintaining \pm 5°C in the 60–70°C temperature range.
- **6.3** Cold vapor atomic fluorescence spectrometer (CVAFS): The CVAFS system used may either be purchased from a supplier, or built in the laboratory from commercially available components.

- 6.3.1 Commercially available CVAFS—Tekran (Toronto, ON) Series 2600 CVAFS, Brooks-Rand (Seattle, WA) Model III CVAFS, Leeman Labs Hydra AF Gold*plus* CVAFS, or equivalent
- 6.3.2 Custom-built CVAFS (Reference 16.15). Figure 2 shows the schematic diagram. The system consists of the following:
 - 6.3.2.1 Low-pressure 4-W mercury vapor lamp
 - 6.3.2.2 Far UV quartz flow-through fluorescence cell—12 mm x 12 mm x 45 mm, with a 10-mm path length (NSG Cells, or equivalent).
 - 6.3.2.3 UV-visible photomultiplier (PMT)—sensitive to < 230 nm. This PMT is isolated from outside light with a 253.7-nm interference filter (Oriel Corp., Stamford, CT, or equivalent).
 - 6.3.2.4 Photometer and PMT power supply (Oriel Corp. or equivalent), to convert PMT output (nanoamp) to millivolts
 - 6.3.2.5 Black anodized aluminum optical block—holds fluorescence cell, PMT, and light source at perpendicular angles, and provides collimation of incident and fluorescent beams (Frontier Geosciences Inc., Seattle, WA, or equivalent).
 - 6.3.2.6 Flowmeter—with needle valve capable of reproducibly keeping the carrier gas flow rate at 30 mL/min
- **6.4** Hg purging system—Figure 2 shows the schematic diagram for the purging system. The system consists of the following:
 - 6.4.1 Flow meter/needle valve—capable of controlling and measuring gas flow rate to the purge vessel at 350 ± 50 mL/min.
 - 6.4.2 Fluoropolymer fittings—connections between components and columns are made using 6.4-mm OD fluoropolymer tubing and fluoropolymer friction-fit or threaded tubing connectors. Connections between components requiring mobility are made with 3.2-mm OD fluoropolymer tubing because of its greater flexibility.
 - 6.4.3 Acid fume pretrap—10-cm long x 0.9-cm ID fluoropolymer tube containing 2–3 g of reagent grade, nonindicating, 8–14 mesh soda lime chunks, packed between wads of silanized glass wool. This trap is cleaned of Hg by placing on the output of a clean cold vapor generator (bubbler) and purging for 1 h with N₂ at 350 mL/min.
 - 6.4.4 Cold vapor generator (bubbler)—200-mL borosilicate glass (15 cm high x 5.0 cm diameter) with standard taper 24/40 neck, fitted with a sparging stopper having a coarse glass frit that extends to within 0.2 cm of the bubbler bottom (Frontier Geosciences, Inc. or equivalent).
- 6.5 The dual-trap Hg(0) preconcentrating system
 - 6.5.1 Figures 2 and 3 show the dual-trap amalgamation system (Reference 16.5).

- 6.5.2 Gold-coated sand traps—10-cm long x 6.5-mm OD x 4-mm ID quartz tubing. The tube is filled with 3.4 cm of gold-coated 45/60 mesh quartz sand (Frontier Geosciences Inc., Seattle, WA, or equivalent). The ends are plugged with quartz wool.
 - 6.5.2.1 Traps are fitted with 6.5-mm ID fluoropolymer friction-fit sleeves for making connection to the system. When traps are not in use, fluoropolymer end plugs are inserted in trap ends to eliminate contamination.
 - 6.5.2.2 At least six traps are needed for efficient operation, one as the "analytical" trap, and the others to sequentially collect samples.
- 6.5.3 Heating of gold-coated sand traps—To desorb Hg collected on a trap, heat for 3.0 min to 450–500 °C (a barely visible red glow when the room is darkened) with a coil consisting of 75 cm of 24-gauge Nichrome wire at a potential of 10-14 vac. Potential is applied and finely adjusted with an autotransformer.
- 6.5.4 Timers—The heating interval is controlled by a timer-activated 120-V outlet (Gralab, or equivalent), into which the heating coil autotransformer is plugged. Two timers are required, one each for the "sample" trap and the "analytical" trap.
- 6.5.5 Air blowers—After heating, traps are cooled by blowing air from a small squirrel-cage blower positioned immediately above the trap. Two blowers are required, one each for the "sample" trap and the "analytical" trap.
- **6.6** Recorder—Any multi-range millivolt chart recorder or integrator with a range compatible with the CVAFS is acceptable. By using a two-pen recorder with pen sensitivity offset by a factor of 10, the dynamic range of the system is extended to 10^3 .
- 6.7 Pipettors—All-plastic pneumatic fixed-volume and variable pipettors in the range of $10 \ \mu L$ to 5.0 mL.
- 6.8 Analytical balance capable of weighing to the nearest 0.01 g

7.0 Reagents and Standards

<u>Note</u>: The quantities of reagents and the preparation procedures in this section are for illustrative purposes. Equivalent performance may be achievable using quantities of reagents and procedures other than those suggested here. The laboratory is responsible for demonstrating equivalent performance.

- 7.1 Reagent water—18-M Ω minimum, ultrapure deionized water starting from a prepurified (distilled, reverse osmosis, etc.) source. Water should be monitored for Hg, especially after ion exchange beds are changed.
- 7.2 Air—It is very important that the laboratory air be low in both particulate and gaseous mercury. Ideally, mercury work should be conducted in a new laboratory with mercury-free paint on the walls. A source of air that is very low in Hg should be brought directly into the Class-100 clean bench air intake. If this is not possible, air coming into the clean bench can be cleaned for mercury by placing a gold-coated cloth prefilter over the intake. Gold-coated cloth filter: Soak 2 m² of cotton gauze in 500 mL of 2% gold chloride solution at pH 7. In a hood, add 100 mL of 30% NH₂OH·HCl solution, and homogenize into the cloth with gloved hands. The material will turn black as colloidal gold is precipitated. Allow the mixture to set for several hours, then rinse

with copious amounts of deionized water. Squeeze-dry the rinsed cloth, and spread flat on newspapers to air-dry. When dry, fold and place over the intake prefilter of the laminar flow hood.

CAUTION: Great care should be taken to avoid contaminating the laboratory with gold dust. This could cause interferences with the analysis if gold becomes incorporated into the samples or equipment. The gilding procedure should be done in a remote laboratory if at all possible.

- **7.3** Hydrochloric acid—trace-metal purified reagent-grade HCl containing less than 5 pg/mL Hg. The HCl should be analyzed for Hg before use.
- **7.4** Hydroxylamine hydrochloride—Dissolve 300 g of NH₂OH·HCl in reagent water and bring to 1.0 L. This solution may be purified by the addition of 1.0 mL of SnCl₂ solution and purging overnight at 500 mL/min with Hg-free N₂. Flow injection systems may require the use of less SnCl₂ for purification of this solution.
- **7.5** Stannous chloride—Bring 200 g of SnCl₂·2H₂O and 100 mL concentrated HCl to 1.0 L with reagent water. Purge overnight with mercury-free N₂ at 500 mL/min to remove all traces of Hg. Store tightly capped.
- **7.6** Bromine monochloride (BrCl)—In a fume hood, dissolve 27 g of reagent grade KBr in 2.5 L of low-Hg HCl. Place a clean magnetic stir bar in the bottle and stir for approximately 1 h in the fume hood. Slowly add 38 g reagent grade KBrO₃ to the acid while stirring. When all of the KBrO₃ has been added, the solution color should change from yellow to red to orange. Loosely cap the bottle, and allow to stir another hour before tightening the lid.

WARNING: This process generates copious quantities of free halogens (Cl_2 , Br_2 , BrCl), which are released from the bottle. Add the KBrO₃ slowly in a fume hood!

- **7.7** Stock mercury standard—NIST-certified 10,000-ppm aqueous Hg solution (NIST-3133). This solution is stable at least until the NIST expiration date.
- 7.8 Secondary Hg standard—Add approx 0.5 L of reagent water and 5 mL of BrCl solution (Section 7.6) to a 1.00-L Class A volumetric flask. Add 0.100 mL of the stock mercury standard (Section 7.7) to the flask and dilute to 1.00 L with reagent water. This solution contains 1.00 μg/mL (1.00 ppm) Hg. Transfer the solution to a fluoropolymer bottle and cap tightly. This solution is considered stable until the NIST expiration date.
- **7.9** Working Hg Standard A—Dilute 1.00 mL of the secondary Hg standard (Section 7.8) to 100 mL in a Class A volumetric flask with reagent water containing 0.5% by volume BrCl solution (Section 7.6). This solution contains 10.0 ng/mL and should be replaced monthly, or longer if extended stability is demonstrated.
- **7.10** Working Hg Standard B—Dilute 0.10 mL of the secondary Hg standard (Section 7.8) to 1000 mL in a Class A volumetric flask with reagent water containing 0.5% by volume BrCl solution (Section 7.6). This solution contains 0.10 ng/mL and should be replaced monthly, or longer if extended stability is demonstrated.
- 7.11 Initial Precision and Recovery (IPR) and Ongoing Precision and Recovery (OPR) solutions—Using the working Hg standard A (Section 7.9), prepare IPR and OPR solutions at a

concentration of 5 ng/L Hg in reagent water. IPR/OPR solutions are prepared using the same amounts of reagents used for preparation of the calibration standards.

- **7.12** Nitrogen—Grade 4.5 (standard laboratory grade) nitrogen that has been further purified by the removal of Hg using a gold-coated sand trap.
- **7.13** Argon—Grade 5.0 (ultra high-purity, GC grade) argon that has been further purified by the removal of Hg using a gold-coated sand trap.

8.0 Sample Collection, Preservation, and Storage

- **8.1** Before samples are collected, consideration should be given to the type of data required (i.e., dissolved or total), so that appropriate preservation and pretreatment steps can be taken. An excess of BrCl should be confirmed either visually (presence of a yellow color) or with starch iodide indicating paper, using a separate sample aliquot, prior to sample processing or direct analysis to ensure the sample has been properly preserved.
- **8.2** Samples are collected into rigorously cleaned fluoropolymer bottles with fluoropolymer or fluoropolymer-lined caps. Glass bottles may be used if Hg is the only target analyte. It is critical that the bottles have tightly sealing caps to avoid diffusion of atmospheric Hg through the threads (Reference 16.4). Polyethylene sample bottles must not be used (Reference 16.15).
- **8.3** Collect samples using guidance provided in the Sampling Method (Reference 16.9). Procedures in the Sampling Method are based on rigorous protocols for collection of samples for mercury (References 16.4 and 16.15).

NOTE: Discrete samplers have been found to contaminate samples with Hg at the ng/L level. Therefore, great care should be exercised if this type of sampler is used. It may be necessary for the sampling team to use other means of sample collection if samples are found to be contaminated using the discrete sampler.

- **8.4** Sample filtration—For dissolved Hg, a sample is filtered through a 0.45-μm capsule filter (Section 6.1.3.1) in a mercury-free clean area prior to preservation. If the sample is filtered, it must be accompanied by a blank that has been filtered under the same conditions. The Sampling Method describes sample filtration procedures.
- **8.5** Preservation—Samples are preserved by adding either 5 mL/L of pretested 12N HCl or 5 mL/L BrCl solution to the sample bottle. If a sample will be used also for the determination of methyl mercury, it should be collected and preserved according to procedures in the method that will be used for determination of methyl mercury (e.g., HCl or H₂SO₄ solution). Preserved samples are stable for up to 90 days of the date of collection.
 - 8.5.1 Samples to be analyzed for total or dissolved Hg only may be shipped to the laboratory unpreserved and unrefrigerated if they are collected in fluoropolymer or glass bottles and capped tightly. Samples must be either preserved or analyzed within 48 hours of collection. If a sample is oxidized in the sample bottle, the time to preservation can be extended to 28 days.
 - 8.5.2 Samples that are acid-preserved may lose Hg to coagulated organic materials in the water or condensed on the walls (Reference 16.16). The best approach is to add BrCl directly to the sample bottle at least 24 hours before analysis. If other Hg species are to be analyzed, these aliquots must be removed prior to the addition of BrCl. If BrCl

cannot be added directly to the sample bottle, the bottle must be shaken vigorously prior to sub-sampling.

8.5.3 Handling of the samples in the laboratory should be undertaken in a mercury-free clean bench, after rinsing the outside of the bottles with reagent water and drying in the clean air hood.

NOTE: Because of the potential for contamination, it is recommended that filtration and preservation of samples be performed in the clean room in the laboratory. However, if circumstances prevent overnight shipment of samples, samples should be filtered and preserved in a designated clean area in the field in accordance with the procedures given in Method 1669 (Reference 16.9). If filtered in the field, samples ideally should be filtered into the sample bottle.

- **8.6** Storage—Sample bottles should be stored in clean (new) polyethylene bags until sample analysis.
- **8.7** Sample preservation, storage, and holding time requirements also are given at 40 CFR part 136.3(e) Table II.

9.0 Quality Control

- **9.1** Each laboratory that uses this Method is required to operate a formal quality assurance program (Reference 16.17). The minimum requirements of this program consist of an initial demonstration of laboratory capability, ongoing analysis of standards and blanks as a test of continued performance, and the analysis of matrix spikes (MS) and matrix spike duplicates (MSD) to assess precision and recovery. Laboratory performance is compared to established performance criteria to determine that the results of analyses meet the performance characteristics of the Method.
 - 9.1.1 The laboratory shall make an initial demonstration of the ability to generate acceptable accuracy and precision. This ability is established as described in Section 9.2.
 - 9.1.2 In recognition of advances that are occurring in analytical technology, the laboratory is permitted certain options to improve results or lower the cost of measurements. These options include automation of the dual-amalgamation system, single-trap amalgamation (Reference 16.18), direct electronic data acquisition, calibration using gas-phase elemental Hg standards, use of the bubbler or flow-injection systems, or changes in the detector (i.e., CVAAS) when less sensitivity is acceptable or desired. Changes in the determinative technique, such as the use of colorimetry, are not allowed. If an analytical technique other than the CVAFS technique specified in this Method is used, that technique must have a specificity for mercury equal to or better than the specificity of the technique in this Method.
 - 9.1.2.1 Each time this Method is modified, the laboratory is required to repeat the procedure in Section 9.2 to demonstrate that an MDL (40 CFR part 136, Appendix B) less than or equal to one-third the regulatory compliance limit or less than or equal to the MDL of this Method (Table 1), whichever is greater, can be achieved. If the change will affect calibration, the instrument must be recalibrated according to Section 10.

<u>Note</u>: If the compliance limit is greater than the concentration of Hg in the OPR/OPR (5 ng/L), the acceptance criteria for blanks and the concentrations of mercury spiked into quality control samples may be increased to support measurements at the compliance limit. For example, if the compliance limit is 12

ng/L (National Toxics Rule, 40 CFR 131.36), the MDL must be less than or equal to 4 ng/L; concentrations of the calibration standards may be 5, 10, 20, 50, and 100 ng/L; concentrations of the IPR/OPR samples may be 10 ng/L; spike concentrations and acceptance criteria for MS/MSD samples would remain as specified in Section 9.3; and an appropriate blank acceptance criterion would be 5 ng/L.

- 9.1.2.2 The laboratory is required to maintain records of modifications made to this Method. These records include the following, at a minimum:
 - 9.1.2.2.1 The names, titles, addresses, and telephone numbers of the analyst(s) who performed the analyses and modification, and the quality control officer who witnessed and will verify the analyses and modification
 - 9.1.2.2.2 A narrative stating the reason(s) for the modification(s)
 - 9.1.2.2.3 Results from all quality control (QC) tests demonstrating the performance of the modified method, including the following:
 - (a) Calibration (Section 10)
 - (b) Initial precision and recovery (Section 9.2.2)
 - (c) Analysis of blanks (Section 9.4)
 - (d) Matrix spike/matrix spike duplicate analysis (Section 9.3)
 - (e) Ongoing precision and recovery (Section 9.5)
 - (f) Quality control sample (Section 9.6)
 - (g) Method detection limit (Section 9.2.1)
 - 9.1.2.2.4 Data that will allow an independent reviewer to validate each determination by tracking the instrument output to the final result. These data are to include the following:
 - (a) Sample numbers and other identifiers
 - (b) Processing dates
 - (c) Analysis dates
 - (d) Analysis sequence/run chronology
 - (e) Sample weight or volume
 - (f) Copies of logbooks, chart recorder, or other raw data output
 - (g) Calculations linking raw data to the results reported
 - 9.1.3 Analyses of MS and MSD samples are required to demonstrate the accuracy and precision and to monitor matrix interferences. Section 9.3 describes the procedure and QC criteria for spiking.
 - 9.1.4 Analyses of blanks are required to demonstrate acceptable levels of contamination. Section 9.4 describes the procedures and criteria for analyzing blanks.
 - 9.1.5 The laboratory shall, on an ongoing basis, demonstrate through analysis of the ongoing precision and recovery (OPR) sample and the quality control sample (QCS) that the system is in control. Sections 9.5 and 9.6 describe these procedures, respectively.
 - 9.1.6 The laboratory shall maintain records to define the quality of the data that are generated. Sections 9.3.7 and 9.5.3 describe the development of accuracy statements.
 - 9.1.7 Quality of the analyses is controlled by an analytical batch. An analytical batch is a set of samples oxidized with the same batch of reagents, and analyzed during the same 12-hour shift. A batch may be from 1 to as many as 20 samples. Each batch must be accompanied by 3 system blanks (Section 9.4.2 for the flow-injection system), a

minimum of 3 bubbler blanks (Section 9.4.1 for the bubbler system), 1 OPR sample at the beginning and end of the batch (Section 9.5), a QCS (Section 9.6), and at least 3 method blanks (Section 9.4.4). In addition, there must be 1 MS and 1 MSD sample for every 10 samples (a frequency of 10%). A typical analytical sequence would be:

- (a) Three system blanks (Section 9.4.2) or a minimum of 3 bubbler blanks (Section 9.4.1)
- (b) A minimum of five, non-zero calibration standards (Section 10.2.2.1)
- (c) On-going precision and recovery (Section 9.5)
- (d) Quality control sample (Section 9.6)
- (e) Method blank (Section 9.4.4)
- (f) Seven samples
- (g) Method blank (Section 9.4.4)
- (h) Three samples
- (i) Matrix spike (Section 9.3)
- (j) Matrix spike duplicate (Section 9.3)
- (k) Four samples
- (l) Method blank (Section 9.4.4)
- (m) Six samples
- (n) Matrix spike (Section 9.3)
- (o) Matrix spike duplicate (Section 9.3)
- (p) Ongoing precision and recovery (Section 9.5)

The above sequence includes calibration. If system performance is verified at the end of the sequence using the OPR, analysis of samples and blanks may proceed without recalibration (i.e., the analytical sequence would be entered at Step (d) above), unless more than 12 hours has elapsed since verification of system performance. If more than 12 hours has elapsed, the sequence would be initiated at Step (c) above.

- **9.2** Initial demonstration of laboratory capability
 - 9.2.1 Method detection limit—To establish the ability to detect Hg, the laboratory shall achieve an MDL that is less than or equal to the MDL listed in Section 1.5 or one-third the regulatory compliance limit, whichever is greater. The MDL shall be determined according to the procedure at 40 CFR 136, Appendix B using the apparatus, reagents, and standards that will be used in the practice of this Method. This MDL shall be used for determined when a new operator begins work or whenever, in the judgment of the laboratory, a change in instrument hardware or operating conditions would dictate reevaluation of capability.
 - 9.2.2 Initial precision and recovery (IPR)—To establish the ability to generate acceptable precision and recovery, the laboratory shall perform the following operations:
 - 9.2.2.1 Analyze four replicates of the IPR solution (5 ng/L, Section 7.11) according to the procedure beginning in Section 11.
 - 9.2.2.2 Using the results of the set of four analyses, compute the average percent recovery (X), and the standard deviation of the percent recovery (s) for Hg.
 - 9.2.2.3 Compare s and X with the corresponding limits for initial precision and recovery in Table 2. If s and X meet the acceptance criteria, system performance is acceptable and analysis of samples may begin. If, however, s exceeds the

precision limit or X falls outside the acceptance range, system performance is unacceptable. Correct the problem and repeat the test (Section 9.2.2.1).

- **9.3** Matrix spike (MS) and matrix spike duplicate (MSD)—To assess the performance of the Method on a given sample matrix, the laboratory must spike, in duplicate, a minimum of 10% (1 sample in 10) from a given sampling site or, if for compliance monitoring, from a given discharge. Therefore, an analytical batch of 20 samples would require two pairs of MS/MSD samples (four spiked samples total).
 - 9.3.1 The concentration of the spike in the sample shall be determined as follows:
 - 9.3.1.1 If, as in compliance monitoring, the concentration of Hg in the sample is being checked against a regulatory compliance limit, the spiking level shall be at that limit or at 1–5 times the background concentration of the sample (as determined in Section 9.3.2), whichever is greater.
 - 9.3.1.2 If the concentration of Hg in a sample is not being checked against a limit, the spike shall be at 1–5 times the background concentration or at 1-5 times the ML in Table 1, whichever is greater.
 - 9.3.2 To determine the background concentration (B), analyze one sample aliquot from each set of 10 samples from each site or discharge according to the procedure in Section 11. If the expected background concentration is known from previous experience or other knowledge, the spiking level may be established *a priori*.
 - 9.3.2.1 If necessary, prepare a standard solution to produce an appropriate level in the sample (Section 9.3.1).
 - 9.3.2.2 Spike two additional sample aliquots with identical amounts of the spiking solution and analyze these aliquots as described in Section 11.1.2 to determine the concentration after spiking (A).
 - 9.3.3 Calculate the percent recovery (R) in each aliquot using the following equation:

% R = 100
$$\frac{(A-B)}{T}$$

where:

- A = Measured concentration of analyte after spiking
- B = Measured concentration of analyte before spiking
- T = True concentration of the spike
- 9.3.4 Compare percent recovery (R) with the QC acceptance criteria in Table 2.
 - 9.3.4.1 If results of the MS/MSD are similar and fail the acceptance criteria, and recovery for the OPR standard (Section 9.5) for the analytical batch is within the acceptance criteria in Table 2, an interference is present and the results may not be reported or otherwise used for permitting or regulatory compliance purposes. If the interference can be attributed to sampling, the site or discharge should be resampled. If the interference can be attributed to a method deficiency, the laboratory must modify the method, repeat the test required in Section 9.1.2, and repeat analysis of the sample and MS/MSD. However, during the development

of Method 1631, very few interferences have been noted in the determination of Hg using this Method. (See Section 4.4 for information on interferences.)

- 9.3.4.2 If the results of both the spike and the OPR test fall outside the acceptance criteria, the analytical system is judged to be not in control, and the results may not be reported or used for permitting or regulatory compliance purposes. The laboratory must identify and correct the problem and reanalyze all samples in the sample batch.
- 9.3.5 Relative percent difference (RPD)—Compute the RPD between the MS and MSD results according to the following equation using the concentrations found in the MS and MSD. Do not use the recoveries calculated in Section 9.3.3 for this calculation because the RPD is inflated when the background concentration is near the spike concentration.

 $RPD = 200 \times \frac{(|D1-D2|)}{(D1+D2)}$ Where: D1 = concentration of Hg in the MS sample D2 = concentration of Hg in the MSD sample

- 9.3.6 The RPD for the MS/MSD pair must not exceed the acceptance criterion in Table 2. If the criterion is not met, the system is judged to be out of control. The problem must be identified and corrected, and the MS/MSD and corresponding samples reanalyzed.
- 9.3.7 As part of the QC program for the laboratory, method precision and recovery for samples should be assessed and records maintained. After analyzing five samples in which the recovery passes the test in Section 9.3.4, compute the average percent recovery (R_a) and the standard deviation of the percent recovery (s_r). Express the accuracy assessment as a percent recovery interval from $R_a 2s_r$ to $R_a + 2s_r$. For example, if $R_a = 90\%$ and $s_r = 10\%$ for five analyses, the accuracy interval is expressed as 70–110%. Update the accuracy assessment regularly (e.g., after every five to ten new accuracy measurements).
- **9.4** Blanks—Blanks are critical to the reliable determination of Hg at low levels. The sections below give the minimum requirements for analysis of blanks. Analysis of additional blanks is recommended as necessary to pinpoint sources of contamination in, and external to, the laboratory.
 - 9.4.1 Bubbler blanks—Bubbler blanks are analyzed to demonstrate that bubbler systems are free from contamination at levels that could affect data quality. At least three bubbler blanks must be run during calibration and with each analytical batch.
 - 9.4.1.1 To analyze a bubbler blank, place a clean gold trap on the bubbler. Purge and analyze previously purged water using the procedure in Section 11, and determine the amount of Hg remaining in the system.
 - 9.4.1.2 If the bubbler blank is found to contain more than 50 pg Hg, the system is out of control. The problem must be investigated and remedied, and the samples run on that bubbler must be reanalyzed. If the blanks from other bubblers contain less than 50 pg Hg, the data associated with those bubblers remain valid, provided that all other criteria in Section 9 also are met.

- 9.4.1.3 The mean result for all bubbler blanks (from bubblers passing the specification in Section 9.4.1.2) must be < 25 pg (0.25 ng/L) Hg with a standard deviation (n-1) of <10 pg (0.10 ng/L). If the mean is < 25 pg, the average peak area or height is subtracted from all raw data before results are calculated (Section 12.2).
- 9.4.1.4 If Hg in the bubbler blank exceeds the acceptance criteria in Section 9.4.1.3, the system is out of control. The problem must be resolved and the system recalibrated. Usually, the bubbler blank is too high for one of the following reasons:
 - (a) Bubblers need rigorous cleaning;
 - (b) Soda-lime is contaminated; or
 - (c) Carrier gas is contaminated.
- 9.4.2 System blanks— System blanks are analyzed to demonstrate that flow injection systems are free from contamination at levels that could affect data quality. Three system blanks must be run during calibration and with each analytical batch.
 - 9.4.2.1 To analyze a system blank, analyze reagent water containing the same amount of reagents used to prepare the calibration standards.
 - 9.4.2.2 If a system blank is found to contain ≥ 0.50 ng/L Hg, the system is out of control. The problem must be investigated and remedied, and the system recalibrated. If the blanks contain < 0.50 ng/L Hg, the data associated with the blanks remain valid, provided that all other criteria in Section 9 also are met.
 - 9.4.2.3 The mean result for the three system blanks must be <0.5 ng/L Hg with a standard deviation (n-1) <0.1 ng/L. If the mean exceeds these criteria, the system is out of control, and the problem must be resolved and the system recalibrated. If the mean is <0.5 ng/L, the average peak height or area is subtracted from all raw data before results are calculated (Section 12.3).
- 9.4.3 Reagent blanks—Reagent blanks are used to demonstrate that the reagents used to prepare samples for Hg analyses are free from contamination. The Hg concentration in reagent blanks is determined by analyzing the reagent solutions using either the bubbler or flow-injection system. For the bubbler system, reagent may be added directly to previously purged water in the bubbler.
 - 9.4.3.1 Reagent blanks are required when the batch of reagents (bromine monochloride plus hydroxylamine hydrochloride) are prepared. The amount of Hg in a reagent blank containing 0.5% (v/v) BrCl solution (Section 7.6) and 0.2% (v/v) hydroxylamine hydrochloride solution (Section 7.4) must be < 20 pg (0.2 ng/L).
 - 9.4.3.2 The presence of more than 20 pg (0.2 ng/L) of Hg indicates a problem with the reagent solution. The purging of certain reagent solutions, such as SnCl₂ or NH₂OH, with mercury-free nitrogen or argon can reduce Hg to acceptable levels. Because BrCl cannot be purified, a new batch must be prepared and tested if the BrCl is contaminated.
- 9.4.4 Method blanks— Method blanks are used to demonstrate that the analytical system is free from contamination that could otherwise compromise sample results. Method blanks are prepared and analyzed using sample containers, labware, reagents, and analytical procedures identical to those used to prepare and analyze the samples.

- 9.4.4.1 A minimum of three method blanks per analytical batch are required for both the bubbler and flow-injection systems.
- 9.4.4.2 If the result for any method blank containing the nominal amount of reagent used to prepare a sample (Section 11.1.1) is found to contain ≥ 0.50 ng/L (50 pg) Hg, the system is out of control. Mercury in the analytical system must be reduced until a method blank is free from contamination at the 0.50 ng/L level. Samples associated with a contaminated method blank must be reanalyzed.
- 9.4.4.3 Because method blanks are analyzed using procedures identical to those used to analyze samples, any sample requiring an increased amount of reagent must be accompanied by at least one method blank that includes an identical amount of reagent.
- 9.4.5 Field blanks–Field blanks are used to demonstrate that samples have not been contaminated by the sample collection and transport activities.
 - 9.4.5.1 Analyze the field blank(s) shipped with each set of samples (samples collected from the same site at the same time, to a maximum of 10 samples). Analyze the blank immediately before analyzing the samples in the batch.
 - 9.4.5.2 If Hg or any potentially interfering substance is found in the field blank at a concentration equal to or greater than the ML (Table 1), or greater than one-fifth the level in the associated sample, whichever is greater, results for associated samples may be the result of contamination and may not be reported or otherwise used for regulatory compliance purposes.
 - 9.4.5.3 Alternatively, if sufficient multiple field blanks (a minimum of three) are collected, and the average concentration (of the multiple field blanks) plus two standard deviations is equal to or greater than the regulatory compliance limit or equal to or greater than one-half of the level in the associated sample, results for associated samples may be the result of contamination and may not be reported or otherwise used for regulatory compliance purposes.
 - 9.4.5.4 If contamination of the field blanks and associated samples is known or suspected, the laboratory should communicate this to the sampling team so that the source of contamination can be identified and corrective measures taken before the next sampling event.
- 9.4.6 Equipment blanks—Before any sampling equipment is used at a given site, the laboratory or cleaning facility is required to generate equipment blanks on all sampling equipment that will be used to demonstrate that the sampling equipment is free from contamination.
 - 9.4.6.1 Equipment blanks are generated in the laboratory or at the equipment cleaning facility by processing reagent water through the sampling devices using the same procedures that are used in the field (see Sampling Method). Therefore, the "clean hands/dirty hands" technique used during field sampling should be followed when preparing equipment blanks at the laboratory or cleaning facility for low level mercury measurements. If grab samples are to be collected using any ancillary equipment, e.g., an extension pole or a dipper, an equipment blank

is generated by submersing this equipment into the reagent water and analyzing the resulting reagent water collected.

- 9.4.6.2 The equipment blank must be analyzed using the procedures in this Method. If mercury or any potentially interfering substance is detected in the blank at or above the level specified for the field blank (Section 9.4.5), the source of contamination or interference must be identified, and the problem corrected. The equipment must be demonstrated to be free from mercury and interferences before the equipment may be used in the field.
- 9.4.7 Bottle blanks— Bottles must be subjected to conditions of use to verify the effectiveness of the cleaning procedures. A representative set of sample bottles (Section 6.1.2) should be filled with reagent water acidified to pH <2 and allowed to stand for a minimum of 24 h. At least 5% of the bottles from a given lot should be tested, and the time that the bottles are allowed to stand should be as close as possible to the actual time that the sample will be in contact with the bottle. After standing, the water must be analyzed for any signs of contamination. If a bottle shows contamination at or above the level specified for the field blank (Section 9.4.5), the problem must be identified, the cleaning procedures corrected or cleaning solutions changed, and all affected bottles re-cleaned.
- **9.5** Ongoing precision and recovery (OPR)—To demonstrate that the analytical system is within the performance criteria of this Method and that acceptable precision and recovery is being maintained within each analytical batch, the laboratory shall perform the following operations:
 - 9.5.1 Analyze the OPR solution (5 ng/L, Section 7.11) prior to the analysis of each analytical batch according to the procedure beginning in Section 11. An OPR also must be analyzed at the end of an analytical sequence or at the end of each 12-hour shift.
 - 9.5.2 Compare the recovery with the limits for ongoing precision and recovery in Table 2. If the recovery is in the range specified, the analytical system is in control and analysis of samples and blanks may proceed. If, however, the concentration is not in the specified range, the analytical process is not in control. Correct the problem and repeat the ongoing precision and recovery test. All reported results must be associated with an OPR that meets the Table 2 performance criteria at the beginning and end of each batch.
 - 9.5.3 The laboratory should add results that pass the specification in Section 9.5.2 to IPR and previous OPR data and update QC charts to form a graphic representation of continued laboratory performance. The laboratory also should develop a statement of laboratory data quality by calculating the average percent recovery (R_a) and the standard deviation of the percent recovery (s_r). Express the accuracy as a recovery interval from $R_a 2s_r$ to $R_a + 2s_r$. For example, if $R_a = 95\%$ and $s_r = 5\%$, the accuracy is 85–105%.
- **9.6** Quality control sample (QCS) The laboratory must obtain a QCS from a source different from the Hg used to produce the standards used routinely in this Method (Sections 7.7–7.10). The QCS should be analyzed as an independent check of system performance.
- **9.7** Depending on specific program requirements, the laboratory may be required to analyze field duplicates and field spikes collected to assess the precision and accuracy of the sampling, sample transportation, and storage techniques. The relative percent difference (RPD) between field duplicates should be less than 20%. If the RPD of the field duplicates exceeds 20%, the laboratory should communicate this to the sampling team so that the source of error can be identified and corrective measures taken before the next sampling event.

10.0 Calibration and Standardization

- **10.1** Calibration and standardization— Separate calibration procedures are provided for a bubbler system (Section 10.2) and flow-injection system (Section 10.3). Both systems are calibrated using standards traceable to NIST Standard Reference Materials. If system performance is verified at the end of an analytical batch using the OPR, analysis of samples and blanks may proceed without recalibration, unless more than 12 hours has elapsed since verification of system performance.
- **10.2** Bubbler system calibration
 - 10.2.1 Establish the operating conditions necessary to purge Hg from the bubbler and to desorb Hg from the traps in a sharp peak. Further details for operation of the purge-and-trap, desorption, and analysis systems are given in Sections 11.2.1 and 11.2.2.
 - 10.2.2 The calibration must contain a minimum of five non-zero points and the results of analysis of three bubbler blanks. The lowest calibration point must be at the Minimum Level (ML).

NOTE: The purge efficiency of the bubbler system is 100% and is independent of volume at the volumes used in this Method. Calibration of this system is typically performed using units of mass. For purposes of working in concentration, the volume is assumed to be 100 mL.

10.2.2.1 Standards are analyzed by the addition of aliquots of Hg working standard A (Section 7.9) and Hg working standard B (Section 7.10) directly into the bubblers. Add 0.50 mL of working standard B and 0.5 mL SnCl₂ to the bubbler. Swirl to produce a standard containing 50 pg of Hg (0.5 ng/L). Purge under the optimum operating conditions (Section 10.2.1). Sequentially follow with the addition of aliquots of 0.05, 0.25, 0.50 and 1.0 mL of working standard A to produce standards of 500, 2500, 5000, and 10,000 pg Hg (5.0, 25.0, 50.0 and 100.0 ng/L).

NOTE: If calibration to the higher levels results in carryover (Section 4.3.8.1), calibrate the system across a narrower range (Section 10.4)

- 10.2.2.2 Analyze the standards beginning with the lowest concentration and proceeding to the highest. Tabulate the height or area for each peak.
- 10.2.2.3 Prepare and analyze a minimum of 3 bubbler blanks. If multiple bubblers are used, there must be 1 bubbler blank per bubbler (to a maximum of 4 bubblers). Calculate the mean peak area or height for the bubbler blanks.
- 10.2.2.4 For each calibration point, subtract the mean peak height or area of the bubbler blanks from the peak height or area for each standard. Calculate the calibration factor (CF_x) for Hg in each of the five standards using the mean bubbler-blank-subtracted peak height or area and the following equation:

$$CF_x = \frac{(A_x) - (\overline{A}_{BB})}{(C_y)}$$

Where:

 A_x = peak height or area for Hg in standard \overline{A}_{BB} = mean peak height or area for Hg in bubbler blank C_x = mass in standard analyzed (ng)

- 10.2.2.5 Calculate the mean calibration factor (CF_m) , the standard deviation of the calibration factor (SD; n-1), and the relative standard deviation (RSD) of the calibration factor, where RSD = 100 x SD/CF_m.
- 10.2.2.6 If RSD \leq 15%, calculate the recovery for the lowest standard using CF_m. If the RSD \leq 15% and the recovery of the lowest standard is in the range of 75-125%, the calibration is acceptable and CF_m may be used to calculate the concentration of Hg in samples. If RSD > 15% or if the recovery of the lowest standard is not in the range of 75-125%, recalibrate the analytical system and repeat the test.
- 10.2.2.7 Calculate the concentration of Hg in the bubbler blanks (Section 10.2.2.1) using CF_m . The bubbler blanks must meet the criteria in Section 9.4.1; otherwise, mercury in the system must be reduced and the calibration repeated until the bubbler blanks meet the criteria.
- **10.3** Flow-injection system calibration
 - 10.3.1 Establish the operating conditions necessary to purge Hg from the gas-liquid separator and dryer tube and desorb Hg from the traps in a sharp peak. Further details for operating the analytical system are given in Section 11.2.1.
 - 10.3.2 The calibration must contain a minimum of 5 non-zero points and the results of analysis of 3 system blanks. The lowest calibration point must be at the minimum level (ML).
 - 10.3.2.1 Place 25-30 mL of reagent water and 250 μL of concentrated BrCl solution (Section 7.6) in each of 5 calibrated 50-mL autosampler vials. Prepare the 0.5 ng/L calibration standard by adding 250 μL of working standard B (Section 7.10) to the vial. Dilute to the mark with reagent water. Sequentially follow with the addition of aliquots of 25, 125, 250 and 500 μL of working standard A (Section 7.9) to produce standards of 5.0, 25.0, 50.0 and 100.0 ng/L, respectively. Cap the vials and invert once to mix.
 - 10.3.2.2 Immediately prior to analysis, remove the caps and add 125 μL of NH₂OH solution (Section 7.4). Re-cap, invert once to mix, and allow to stand until the yellow color disappears. Remove all caps and place vials into the analysis rack.
 - 10.3.2.3 Analyze the standards beginning with the lowest concentration and proceeding to the highest. Tabulate the height or area for the Hg peak.
 - 10.3.2.4 Prepare and analyze a minimum of 3 system blanks and tabulate the peak heights or areas. Calculate the mean peak area or height for the system blanks.
 - 10.3.2.5 For each calibration point, subtract the mean peak height or area of the system blanks (Section 9.4.2) from the peak height or area for each standard. Calculate

the calibration factor (CF_x) for Hg in each of the five standards using the mean reagent-blank-subtracted peak height or area and the following equation:

$$CF_{x} = \frac{(A_{x}) - (\overline{A}_{SB})}{(C_{y})}$$

Where:

 A_x = peak height or area for Hg in standard \overline{A}_{SB} = mean peak height or area for Hg in calibration blanks C_x = concentration of standard analyzed (ng/L)

- 10.3.2.6 Calculate the mean calibration factor (CF_m) , the standard deviation of the calibration factor (SD; n-1), and the relative standard deviation (RSD) of the calibration factor, where RSD = 100 x SD/CF_m.
- 10.3.2.7 If RSD \leq 15%, calculate the recovery for the lowest standard (0.5 ng/L) using CF_m. If the RSD \leq 15% and the recovery of the lowest standard is in the range of 75-125%, the calibration is acceptable and CF_m may be used to calculate the concentration of Hg in samples, blanks, and OPRs. If RSD > 15% or if the recovery of the lowest standard is not in the range of 75-125%, recalibrate the analytical system and repeat the test.
- 10.3.2.8 Calculate the concentration of Hg in the system blanks (Section 9.4.2) using CF_m . The system blanks must meet the criteria in Section 9.4.2; otherwise, mercury in the system must be reduced and the calibration repeated until the system blanks meet the criteria.
- **10.4** Calibration to a range other than 0.5 to 100 ng/L—This Method may be calibrated to a range other than 0.5 to 100 ng/L, provided that the following requirements are met:
 - (a) There must be a minimum of five non-zero calibration points.
 - (b) The difference between successive calibration points must be no greater than a factor of 10 and no less than a factor of 2 and should be approximately evenly spaced on a logarithmic scale over the calibration range.
 - (c) The relative standard deviation (RSD) of the calibration factors for all calibration points must be less than 15%.
 - (d) The calibration factor for any calibration point at a concentration greater than 100 ng/L must be within $\pm 15\%$ of the average calibration factor for the points at or below 100 ng/L.
 - (e) The calibration factor for any point <0.5 ng/L must be within 25% of the average calibration factor for all points.
 - (f) If calibration is to a higher range and this Method is used for regulatory compliance, the ML must be less than one-third the regulatory compliance limit

11.0 Procedure

NOTE: The following procedures for analysis of samples are provided as guidelines. Laboratories may find it necessary to optimize the procedures, such as drying time or potential applied to the Nichrome wires, for the laboratory's specific instrument set-up.

11.1 Sample Preparation

- 11.1.1 Pour a 100-mL aliquot from a thoroughly shaken, acidified sample, into a 125-mL fluoropolymer bottle. If BrCl was not added as a preservative (Section 8.5), add the amount of BrCl solution (Section 7.6) given below, cap the bottle, and digest at room temperature for a 12 h minimum.
 - 11.1.1.1 For clear water and filtered samples, add 0.5 mL of BrCl; for brown water and turbid samples, add 1.0 mL of BrCl. If the yellow color disappears because of consumption by organic matter or sulfides, more BrCl should be added until a permanent (12-h) yellow color is obtained.
 - 11.1.1.2 Some highly organic matrices, such as sewage effluent, will require high levels of BrCl (e.g., 5 mL/100 mL of sample) and longer oxidation times, or elevated temperatures (e.g., place sealed bottles in oven at 50 °C for 6 h). The oxidation must be continued until it is complete. Complete oxidation can be determined by either observation of a permanent yellow color remaining in the sample or the use of starch iodide indicating paper to test for residual free oxidizer. The sample also may be diluted to reduce the amount of BrCl required, provided that the resulting level of mercury is sufficient for reliable determination.
- 11.1.2 Matrix spikes and matrix spike duplicates—For every 10 or fewer samples, pour 2 additional 100-mL aliquots from a selected sample (see Section 9.3), spike at the level specified in Section 9.3, and process in the same manner as the samples. There must be a minimum of 2 MS/MSD pairs for each analytical batch of 20 samples.
- **11.2** Hg reduction and purging—Separate procedures are provided for the bubbler system (Section 11.2.1) and flow-injection (Section 11.2.2).
 - 11.2.1 Hg reduction and purging for the bubbler system
 - 11.2.1.1 Add 0.2-0.25 mL of NH_2OH solution to the BrCl-oxidized sample in the 125-mL sample bottle. Cap the bottle and swirl the sample. The yellow color will disappear, indicating the destruction of the BrCl. Allow the sample to react for 5 min with periodic swirling to be sure that no traces of halogens remain.

NOTE: Purging of free halogens onto the gold trap will result in damage to the trap and low or irreproducible results.

- 11.2.1.2 Connect a fresh trap to the bubbler, pour the reduced sample into the bubbler, add 0.5 mL of $SnCl_2$ solution, and purge the sample onto a gold trap with N_2 at 350 ± 50 mL/min for 20 min.
- 11.2.1.3 When analyzing Hg samples, the recovery is quantitative, and organic interferents are destroyed. Thus, standards, bubbler blanks, and small amounts of high-level samples may be run directly in previously purged water. After very high samples (Section 4.3.8.1), a small degree of carryover (<0.01%) may occur. Bubblers that contain such samples must be demonstrated to be clean prior to proceeding with low level samples. Samples run immediately following a sample that has been determined to result in carryover must be reanalyzed using a bubbler that is demonstrated to be clean as per Section 4.3.8.1.
- 11.2.2 Hg reduction and purging for the flow-injection system

11.2.2.1 Add 0.2-0.25 mL of NH₂OH solution (Section 7.4) to the BrCl-oxidized sample in the 125-mL sample bottle or in the autosampler tube (the amount of NH₂OH required will be approximately 30 percent of the BrCl volume). Cap the bottle and swirl the sample. The yellow color will disappear, indicating the destruction of the BrCl. Allow the sample to react for 5 minutes with periodic swirling to be sure that no traces of halogens remain.

NOTE: Purging of free halogens onto the gold trap will result in damage to the trap and low or irreproducible results.

- 11.2.2.2 Pour the sample solution into an autosampler vial and place the vial in the rack.
- 11.2.2.3 Carryover may occur after analysis of a sample containing a high level of mercury. Samples run immediately following a sample that has been determined to result in carryover (Section 4.3.8.1) must be reanalyzed using a system demonstrated to be clean as per Section 4.3.8.1.
- **11.3** Desorption of Hg from the gold trap
 - 11.3.1 Remove the sample trap from the bubbler, place the Nichrome wire coil around the trap and connect the trap into the analyzer train between the incoming Hg-free argon and the second gold-coated (analytical) sand trap (Figure 2).
 - 11.3.2 Pass argon through the sample and analytical traps at a flow rate of approximately 30 mL/min for approximately 2 min to drive off condensed water vapor.
 - 11.3.3 Apply power to the coil around the sample trap for 3 minutes to thermally desorb the Hg (as Hg(0)) from the sample trap onto the analytical trap.
 - 11.3.4 After the 3-min desorption time, turn off the power to the Nichrome coil, and cool the sample trap using the cooling fan.
 - 11.3.5 Turn on the chart recorder or other data acquisition device to start data collection, and apply power to the Nichrome wire coil around the analytical trap. Heat the analytical trap for 3 min (1 min beyond the point at which the peak returns to baseline).
 - 11.3.6 Stop data collection, turn off the power to the Nichrome coil, and cool the analytical trap to room temperature using the cooling fan.
 - 11.3.7 Place the next sample trap in line and proceed with analysis of the next sample.

NOTE: Do not heat a sample trap while the analytical trap is still warm; otherwise, the analyte may be lost by passing through the analytical trap.

- **11.4** Peaks generated using this technique should be very sharp and almost symmetrical. Mercury elutes at approximately 1 minute and has a width at half-height of about 5 seconds.
 - 11.4.1 Broad or asymmetrical peaks indicate a problem with the desorption train, such as improper gas flow rate, water vapor on the trap(s), or an analytical trap damaged by chemical fumes or overheating.

- 11.4.2 Damage to an analytical trap is also indicated by a sharp peak, followed by a small, broad peak.
- 11.4.3 If the analytical trap has been damaged, the trap and the fluoropolymer tubing downstream from it should be discarded because of the possibility of gold migration onto downstream surfaces.
- 11.4.4 Gold-coated sand traps should be tracked by unique identifiers so that any trap producing poor results can be quickly recognized and discarded.

12.0 Data Analysis and Calculations

- **12.1** Separate procedures are provided for calculation of sample results using the bubbler system (Section 12.2) and the flow-injection system (Section 12.3), and for method blanks (Section 12.4).
- **12.2** Calculations for the bubbler system
 - 12.2.1 Calculate the mean peak height or area for Hg in the bubbler blanks measured during system calibration or with the analytical batch (A_{BB} ; n = 3 minimum).
 - 12.2.2 Calculate the concentration of Hg in ng/L (parts-per-trillion; ppt) in each sample according to the following equation:

$$[Hg] (ng/L) = \frac{A_s - \overline{A}_{BB}}{CF_m \times V}$$

where:

 A_s = peak height (or area) for Hg in sample \overline{A}_{BB} = peak height (or area) for Hg in bubbler blank CF_m = mean calibration factor (Section 10.2.2.5) V = Volume of sample (L)

- **12.3** Calculations for the flow-injection system
 - 12.3.1 Calculate the mean peak height or area for Hg in the system blanks measured during system calibration or with each analytical batch (A_{SB} ; n = 3)
 - 12.3.2 Calculate the concentration of Hg in ng/L in each sample according to the following equation:

$$[Hg] (ng/L) = \frac{(A_s - \overline{A}_{SB})}{CF_m} \times \frac{V_{std}}{V_{sample}}$$

where:

A_s = peak height (or area) for Hg in sample Ā_{SB} = mean peak height (or area) for Hg in system blanks CF_m = mean calibration factor (Section 10.3.2.6) V_{std} = volume (mL) used for standards – volume (mL) reagent used in standards V_{sample} = volume (mL) of sample – volume (mL) reagent used in sample

12.4 Calculations for concentration of Hg in method blanks, field blanks, and reagent blanks.

- 12.4.1 Calculate the concentration of Hg in the method blanks (C_{MB}), field blanks (C_{FB}), or reagent blanks (C_{RB}) in ng/L, using the equation in Section 12.2.2 (if bubbler system is used) or Section 12.3.2 (if flow injection system is used) and substituting the peak height or area resulting from the method blank, field blank, or reagent blank for A_s .
- 12.4.2 Determine the mean concentration of Hg in the method blanks associated with the analytical batch (a minimum of three). If a sample requires additional reagent(s) (e.g., BrCl), a corresponding method blank containing an identical amount of reagent must be analyzed (Section 9.4.4.3). The concentration of Hg in the corresponding method blank may be subtracted from the concentration of Hg in the sample per Section 12.5.2.

12.5 Reporting

- 12.5.1 Report results for Hg at or above the ML, in ng/L, to three significant figures. Report results for Hg in samples below the ML as <0.5 ng/L, or as required by the regulatory authority or in the permit. Report results for Hg in reagent blanks and field blanks at or above the ML, in ng/L, to three significant figures. Report results for Hg in reagent blanks, method blanks, or field blanks below the ML but at or above the MDL to two significant figures. Report results for Hg not detected in reagent blanks, method blanks, or field blanks as <0.2 ng/L, or as required by the regulatory authority or in the permit.
- 12.5.2 Report results for Hg in samples, method blanks and field blanks separately. In addition to reporting results for the samples and blank(s) separately, the concentration of Hg in the method blanks or field blanks associated with the sample may be subtracted from the results for that sample, or must be subtracted if requested or required by a regulatory authority or in a permit.
- 12.5.3 Results from tests performed with an analytical system that is not in control must not be reported or otherwise used for permitting or regulatory compliance purposes, but do not relieve a discharger or permittee of reporting timely results.

13.0 Method Performance

- **13.1** This Method was tested in 12 laboratories using reagent water, freshwater, marine water and effluent (Reference 16.19). The quality control acceptance criteria listed in Table 2 were verified by data gathered in the interlaboratory study, and the method detection limit (MDL) given in Section 1.5 was verified in all 12 laboratories. In addition, the techniques in this Method have been compared with other techniques for low-level mercury determination in water in a variety of studies, including ICES-5 (Reference 16.20) and the International Mercury Speciation Intercomparison Exercise (Reference 16.21).
- **13.2** Precision and recovery data for reagent water, freshwater, marine water, and secondary effluent are given in Table 3.

14.0 Pollution Prevention

- **14.1** Pollution prevention encompasses any technique that reduces or eliminates the quantity or toxicity of waste at the point of generation. Many opportunities for pollution prevention exist in laboratory operation. EPA has established a preferred hierarchy of environmental management techniques that places pollution prevention as the management option of first choice. Whenever feasible, laboratory personnel should use pollution prevention techniques to address waste generation. When it is not feasible to reduce wastes at the source, the Agency recommends recycling as the next best option. The acids used in this Method should be reused as practicable by purifying by electrochemical techniques. The only other chemicals used in this Method are the neat materials used in preparing standards. These standards are used in extremely small amounts and pose little threat to the environment when managed properly. Standards should be prepared in volumes consistent with laboratory use to minimize the disposal of excess volumes of expired standards.
- **14.2** For information about pollution prevention that may be applied to laboratories and research institutions, consult *Less is Better: Laboratory Chemical Management for Waste Reduction*, available from the American Chemical Society's Department of Governmental Relations and Science Policy, 1155 16th Street NW, Washington DC 20036, 202/872–4477.

15.0 Waste Management

- **15.1** The laboratory is responsible for complying with all Federal, State, and local regulations governing waste management, particularly hazardous waste identification rules and land disposal restrictions, and for protecting the air, water, and land by minimizing and controlling all releases from fume hoods and bench operations. Compliance with all sewage discharge permits and regulations is also required. An overview of requirements can be found in *Environmental Management Guide for Small Laboratories* (EPA 233-B-98-001).
- **15.2** Acids, samples at pH <2, and BrCl solutions must be neutralized before being disposed of, or must be handled as hazardous waste.
- **15.3** For further information on waste management, consult *The Waste Management Manual for Laboratory Personnel* and *Less is Better: Laboratory Chemical Management for Waste Reduction*, both available from the American Chemical Society's Department of Government Relations and Science Policy, 1155 16th Street NW, Washington, DC 20036.

16.0 References

- **16.1** Bloom, Nicolas, Draft "Total Mercury in Aqueous Media," Frontier Geosciences, Inc., September 7, 1994.
- **16.2** Fitzgerald, W.F.; Gill, G.A. "Sub-Nanogram Determination of Mercury by Two-Stage Gold Amalgamation and Gas Phase Detection Applied to Atmospheric Analysis," *Anal. Chem.* 1979, *15*, 1714.
- **16.3** Bloom, N.S; Crecelius, E.A. "Determination of Mercury in Sea water at Subnanogram per Liter Levels," *Mar. Chem.* 1983, *14*, 49.
- **16.4** Gill, G.A.; Fitzgerald, W.F. "Mercury Sampling of Open Ocean Waters at the Picogram Level," *Deep Sea Res* 1985, *32*, 287.

- **16.5** Bloom, N.S.; Fitzgerald, W.F. "Determination of Volatile Mercury Species at the Picogram Level by Low-Temperature Gas Chromatography with Cold-Vapor Atomic Fluorescence Detection," *Anal. Chim. Acta.* 1988, *208*, 151.
- **16.6** Guidance on Establishing Trace Metal Clean Rooms in Existing Facilities, U.S. EPA, Office of Water, Office of Science and Technology, Engineering and Analysis Division (4303), 401 M Street SW, Washington, DC 20460, January 1996, EPA 821-B-96-001.
- **16.7** Trace Metal Cleanroom, prepared by Research Triangle Institute for U.S. Environmental Protection Agency, 26 W. Martin Luther King Dr., Cincinnati, OH 45268, RTI/6302/04-02 F.
- **16.8** Guidance on the Documentation and Evaluation of Trace Metals Data Collected for Clean Water Act Compliance Monitoring, U.S. Environmental Protection Agency, Office of Water, Office of Science and Technology, Engineering and Analysis Division (4303), 401 M Street SW, Washington, DC 20460, July 1996, EPA 821-B-96-004.
- 16.9 Method 1669, "Method for Sampling Ambient Water for Determination of Metals at EPA Ambient Criteria Levels," U.S. Environmental Protection Agency, Office of Water, Office of Science and Technology, Engineering and Analysis Division (4303), 401 M Street SW, Washington, DC 20460, April 1995 with January 1996 revisions.
- **16.10** Correspondence from Nicolas Bloom, Frontier Geosciences, Inc. to Dale Rushneck, Interface, Inc., December 31, 1998.
- **16.11** "Working with Carcinogens," Department of Health, Education, and Welfare, Public Health Service. Centers for Disease Control. NIOSH Publication 77-206, Aug. 1977, NTIS PB-277256.
- 16.12 "OSHA Safety and Health Standards, General Industry," OSHA 2206, 29 CFR 1910.
- **16.13** "Safety in Academic Chemistry Laboratories," ACS Committee on Chemical Safety, 1979.
- **16.14** "Standard Methods for the Examination of Water and Wastewater," 18th ed. and later revisions, American Public Health Association, 1015 15th Street NW, Washington, DC 20005. 1-35: Section 1090 (Safety), 1992.
- 16.15 Bloom, N.S. "Trace Metals & Ultra-Clean Sample Handling," Environ. Lab. 1995, 7, 20.
- **16.16** Bloom, N.S. "Influence of Analytical Conditions on the Observed 'Reactive Mercury,' Concentrations in Natural Fresh Waters," In *Mercury as a Global Pollutant*; Huckabee, J. and Watras, C.J., Eds.; Lewis Publishers, Ann Arbor, MI: 1994.
- **16.17** "Handbook of Analytical Quality Control in Water and Wastewater Laboratories," U.S. Environmental Protection Agency. Environmental Monitoring Systems Laboratory, Cincinnati, OH 45268, EPA-600/4-79-019, March 1979.
- **16.18** Liang, L.; Bloom, N.S. "Determination of Total Mercury by Single-Stage Gold Amalgamation with Cold Vapor Atom Spectrometric Detection," *J. Anal. Atomic Spectrom.* 1993, *8*, 591.
- **16.19** "Results of the EPA Method 1631 Validation Study," February, 1998. Available from the EPA Sample Control Center, 6101 Stevenson Avenue, Alexandria, VA, 22304; 703/461-2100.

- **16.20** Cossa, D.; Couran, P. "An International Intercomparison Exercise for Total Mercury in Sea Water," *App. Organomet. Chem.* 1990, *4*, 49.
- **16.21** Bloom, N.S.; Horvat, M.; Watras, C.J. "Results of the International Mercury Speciation Intercomparison Exercise," *Wat. Air. Soil Pollut.*, 1995, 80, 1257.

17.0 Glossary

The definitions and purposes below are specific to this Method, but have been conformed to common usage as much as possible.

- **17.1 Ambient Water**—Waters in the natural environment (e.g., rivers, lakes, streams, and other receiving waters), as opposed to effluent discharges.
- **17.2** Analytical Batch—A batch of up to 20 samples that are oxidized with the same batch of reagents and analyzed during the same 12-hour shift. Each analytical batch must also include at least three bubbler blanks, an OPR, and a QCS. In addition, MS/MSD samples must be prepared at a frequency of 10% per analytical batch (one MS/MSD for every 10 samples).
- **17.3** Bottle Blank—The bottle blank is used to demonstrate that the bottle is free from contamination prior to use. Reagent water known to be free of mercury at the MDL of this Method is added to a bottle, acidified to pH <2 with BrCl or HCl, and allowed to stand for a minimum of 24 hours. The time that the bottle is allowed to stand should be as close as possible to the actual time that the sample will be in contact with the bottle. After standing, the water is analyzed.
- **17.4 Bubbler Blank**—For this Method, the bubbler blank is specific to the bubbler system and is used to determine that the analytical system is free from contamination. After analysis of a standard, blank, or sample, the solution in the bubbler is purged and analyzed. A minimum of three bubbler blanks is required for system calibration.
- **17.5** Equipment Blank—Reagent water that has been processed through the sampling device at a laboratory or other equipment cleaning facility prior to shipment of the sampling equipment to the sampling site. The equipment blank is used to demonstrate that the sampling equipment is free from contamination prior to use. Where appropriate, the "clean hands/dirty hands" technique used during field sampling should be followed when preparing equipment blanks at the laboratory or cleaning facility.
- **17.6** Field Blank—Reagent water that has been transported to the sampling site and exposed to the same equipment and operations as a sample at the sampling site. The field blank is used to demonstrate that the sample has not been contaminated by the sampling and sample transport systems.
- **17.7 Intercomparison Study**—An exercise in which samples are prepared and split by a reference laboratory, then analyzed by one or more testing laboratories and the reference laboratory. The intercomparison, with a reputable laboratory as the reference laboratory, serves as the best test of the precision and accuracy of the analyses at natural environmental levels.

- **17.8** Matrix Spike (MS) and Matrix Spike Duplicate (MSD)—Aliquots of an environmental sample to which known quantities of the analyte(s) of interest is added in the laboratory. The MS and MSD are analyzed exactly like a sample. Their purpose is to quantify the bias and precision caused by the sample matrix. The background concentrations of the analytes in the sample matrix must be determined in a separate aliquot and the measured values in the MS and MSD corrected for these background concentrations.
- **17.9** May—This action, activity, or procedural step is allowed but not required.
- **17.10** May not—This action, activity, or procedural step is prohibited.
- **17.11 Method blank** Method blanks are used to determine the concentration of mercury in the analytical system during sample preparation and analysis, and consist of a volume of reagent water that is carried through the entire sample preparation and analysis. Method blanks are prepared by placing reagent water in a sample bottle and analyzing the water using reagents and procedures identical to those used to prepare and analyze the corresponding samples. A minimum of three method blanks is required with each analytical batch.
- **17.12 Minimum Level (ML)**—The lowest level at which the entire analytical system must give a recognizable signal and acceptable calibration point for the analyte. It is equivalent to the concentration of the lowest calibration standard, assuming that all method-specified sample weights, volumes, and cleanup procedures have been employed. The ML is calculated by multiplying the MDL by 3.18 and rounding the result to the number nearest to (1, 2, or 5) x 10ⁿ, where n is an integer (See Section 1.5).
- **17.13** Must—This action, activity, or procedural step is required.
- **17.14** Quality Control Sample (QCS)—A sample containing Hg at known concentrations. The QCS is obtained from a source external to the laboratory, or is prepared from a source of standards different from the source of calibration standards. It is used as an independent check of instrument calibration.
- **17.15 Reagent blank**—Reagent blanks are used to determine the concentration of mercury in the reagents (BrCl, NH₂OH·HCl, and SnCl₂) that are used to prepare and analyze the samples. In this Method, reagent blanks are required when each new batch of reagents is prepared.
- **17.16 Reagent Water**—Water demonstrated to be free of mercury at the MDL of this Method. It is prepared from 18 M Ω ultrapure deionized water starting from a prepurified source. Reagent water is used to wash bottles, as trip and field blanks, and in the preparation of standards and reagents.
- **17.17 Regulatory Compliance Limit**—A limit on the concentration or amount of a pollutant or contaminant specified in a nationwide standard, in a permit, or otherwise established by a regulatory authority.
- 17.18 Shall—This action, activity, or procedure is required.
- 17.19 Should—This action, activity, or procedure is suggested, but not required.

- **17.20** Stock Solution— A solution containing an analyte that is prepared from a reference material traceable to NIST, or a source that will attest to the purity and authenticity of the reference material.
- **17.21** System Blank— For this Method, the system blank is specific for the flow-injection system and is used to determine contamination in the analytical system and in the reagents used to prepare the calibration standards. A minimum of three system blanks is required during system calibration.
- **17.22** Ultraclean Handling— A series of established procedures designed to ensure that samples are not contaminated during sample collection, storage, or analysis.

18.0 Tables and Figures

Table 1

Lowest Ambient Water Quality Criterion for Mercury and the Method Detection Limit and Minimum Level of Quantitation for EPA Method 1631

	Lowest Ambient Water and		Detection Limit (MDL) inimum Level (ML)	
Metal	Quality Criterion ⁽¹⁾	MDL ⁽²⁾	ML ⁽³⁾	
Mercury (Hg)	1.3 ng/L	0.2 ng/L	0.5 ng/L	

1. Lowest water quality criterion for the Great Lakes System (Table 4, 40 CFR 132.6). The lowest Nationwide criterion is 12 ng/L (40 CFR 131.36).

Method detection limit (40 CFR 136, Appendix B)

3. Minimum level of quantitation (see Glossary)

Table 2

Quality Control Acceptance Criteria for Performance Tests in EPA Method 1631

Acceptance Criteria	Section	Limit (%)
Initial Precision and Recovery (IPR)	9.2.2	
Precision (RSD)	9.2.2.3	21
Recovery (X)	9.2.2.3	79-121
Ongoing Precision and Recovery (OPR)	9.5.2	77-123
Matrix Spike/Matrix Spike Duplicate (MS/MSD)	9.3	
Recovery	9.3.4	71-125
Relative Percent Difference (RPD)	9.3.5	24

Table 3

Precision and Recovery for Reagent Water, Fresh Water, Marine Water, and Effluent Water Using Method 1631

Matrix	*Mean Recovery (%)	*Precision (% RSD)
Reagent Water	98.0	5.6
Fresh Water (Filtered)	90.4	8.3
Marine Water (Filtered)	92.3	4.7
Marine Water (Unfiltered)	88.9	5.0
Secondary Effluent (Filtered)	90.7	3.0
Secondary Effluent (Unfiltered)	92.8	4.5

*Mean percent recoveries and RSDs are based on expected Hg concentrations.




Figure 1. Schematic Diagram of Bubbler Setup




Figure 2. Schematic Diagram of the Bubbler, Purge and Trap, Cold Vapor Atomic Fluorescence Spectrometer (CVAFS) System




Figure 3. Schematic Diagram of the Flow-Injection, Cold Vapor Atomic Fluorescence Spectrometer (CVAFS) System

North Parking Lot Mercury Speciation Soil Investigation Work Plan Olin Niagara Falls Plant, Niagara Falls, New York AMEC Project Number 6107150002

January 9, 2015

APPENDIX B

Laboratory SOPs

		Document Title:	
🔅 eurofins		Preparation of Solids Samples for Total	Eurofins Document Reference:
	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Aqua-Regia Digestion	

Eurofins Document Reference	EFGS-066-R06	Revision	6		
Effective Date	3/27/2013	Status	Final		
Historical/Local Document Number	FGS-SOP-066.06				
Local Document Level	Level 3				
Local Document Type	SOP				
Local Document Category	NA				

Prepared by	Ryan Nelson		
Reviewed and Approved by	Dave Wunderlich and Patrick Garcia-Strickland		

Revision: 6	Revision: 6 Effective Date: 3/27/2012	
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

🔅 eurofins	
	10

Table of Contents

1	Revision Log:	
2	Reference:	
3	Cross Reference:	
4	Purpose:4	
5	Scope:4	
6	Basic Principles:	
7	Reference Modifications:	
8	Definitions:	
9	Interferences:	
10	Safety Precautions, Pollution Prevention and Waste Handling:	
11	Personnel Training and Qualifications:	
12	Sample Collection, Preservation, and Handling:	
13	Apparatus and Equipment:	
14	Reagents and Standards:	
15	Procedure:	
16	Calculations:	
17	Statistical Information/Method Performance:	
18	Quality Assurance/Quality Control:	
19	Corrective Action	
20	List of Attachments	
Арр	endix A: Example - Standard Operating Procedure Training Record	

evision: 6 Effective Date: 3/27/2012		Page 2 of 12
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

🔅 eurofins	Frontier Global Sciences	Document Title: Preparation of Solids Samples for Total Mercury Analysis by Modified Cold Aqua-Regia Digestion	Eurofins Document Reference: EFGS-SOP-066-R06
Approvals:			
Prepared by:			Date:
Approved by:			Date:
Approved by:			Date:

1 Revision Log:

Revision: 06	Effective Date: This version	
Section	Justification	Changes
Cover	Required change	Changed company name from Frontier Global Sciences to Eurofins Frontier Global Sciences.
All	Formatting requirement per LOM SOP-LAB-201	Reformatted document to new corporate specifications.
5.1	Enhancement	Updated Scope
8.9	Required	Updated spiking levels for the matrix spike
9	Required	Updated interferences
14.6 – 14.8	Required	Updated bromine monochloride reagents
18.2 – 18.6	Required	Updated QC limits
18.4	Required	Incorporated QA MOC 2011-007

2 Reference:

- 2.1 Chemical Hygiene Plan, Eurofins Frontier Global Sciences, current version.
- 2.2 EPA Method 1631, Revision E: Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry, 2002.
- 2.3 National Environmental Laboratory Accreditation Conference, NELAC Standard September 8, 2009.
- 2.4 Department of Defense Quality Systems Manual for Environmental Laboratories, prepared by DoD Environmental Quality Workgroup, Final Version 4.2, October 2010.

3 Cross Reference:

Document	Document Title
SOP FGS-003	Pipette Verification, Calibration and Maintenance
SOP FGS-008	Ultra Clean Aqueous Sample Collection
SOP FGS-038	Data Review and Validation
SOP FGS-094, App F	Standard Operating Procedure Training Record
SOP FGS-099	Waste Disposal Procedure for Client Sample Waste
SOP FGS-111	HF/HNO ₃ /HCI Bomb Digestion of Sediments, Soils, Rocks, and Other Solids for Mercury, followed by Repeated HNO ₃ Evaporation for other Metals
SOP FGS-121	Determination of Total Mercury in Various Matrices by Flow Injection Atomic Fluorescence Spectrometry (EPA Method 1631E)
SOP FGS-155	Calibration of Volumetric Dispensers

4 Purpose:

4.1 The purpose of this Standard Operating Procedure (SOP) is to describe the method for digesting geological samples (sediments and soils) and carbon (coal) samples prior to analysis for total mercury.

5 Scope:

5.1 This is a strong acid digestion procedure for the preparation of sediments, soils, and other types of solid materials prior to analysis for total mercury. If other metals besides Hg are to be analyzed as well, the preferred digestion is the HF/HNO₃ bomb digestion method (SOP FGS-111, "HF/HNO₃ /HCl Bomb Digestion of Sediments, Soils, Rocks, and Other Solids for Mercury, followed by Repeated HNO₃ Evaporation for other Metals"). Modified aqua regia is particularly capable of solubilizing cinnabar (HgS),

Revision: 6	Effective Date: 3/27/2012	Page 4 of 12	
by Washington State Law. Proprietary in	COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protected by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.		

		Document Title:	
🔅 eurofins		Preparation of Solids Samples for Total	Eurofins Document Reference:
	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Aqua-Regia Digestion	

making this technique more effective than the HNO_3/H_2SO_4 digestion that has been previously employed.

6 Basic Principles:

- 6.1 Modified aqua regia is not simply a mixture of the two acids. Rather, the oxidizing action of concentrated HNO₃ on HCI results in the formation of nitrosyl chloride (NOCI) and free Cl₂, which are particularly strong oxidizers for noble metals and metal-sulfide minerals. Modified aqua regia only exists as a concentrated acid species—dilution of modified aqua regia with water destroys its unique oxidizing capability, rendering it a simple mixture of HNO₃ and HCI. Furthermore, modified aqua regia loses its strength rapidly after preparation because of the loss of Cl₂ to the atmosphere. Modified aqua regia must therefore always be prepared fresh at the time of use.
- 6.2 This method involves leaching the sample overnight with modified aqua regia (.
- 6.3 This procedure must be performed in a fume hood due to the copious quantities of noxious fumes, including, but not limited to, Cl₂, which are generated during this process.
- 6.4 All homogenizations and other handling of low-level samples (< 100 ng/g) are to be performed by clean-room gloved personnel, in an area known to be low in atmospheric Hg.
- 6.5 Prior to digestion, samples must be homogenized as thoroughly as possible.
- 6.6 If dry weight correction is required, it determined on a separate sample aliquot.

7 Reference Modifications:

7.1 No significant modifications were made to this method.

8 Definitions:

- 8.1 Batch no more than 20 client samples grouped for preparation. 3 Preparation Blanks, 1 CRM or 1 LCS/LCSD (or BS/BSD) set and 1 MD are prepared per every 20 samples; 1 MS/MSD set is prepared for every 10 samples.
- 8.2 Celsius (C), conversion of Celsius to Fahrenheit: (C * 1.8) + 32.
- 8.3 Fahrenheit (F), conversion of Fahrenheit to Celsius: (F 32) * 5/9
- 8.4 Method Detection Limit (MDL) the limit derived from an exercise as described in 40 CFR, Part 136, Appendix B. The exercise produces a defined value that is the minimum concentration that can be measured and reported with 99% confidence that the analyte concentration is greater than zero from a given matrix.
- 8.5 Certified Reference Material (CRM) a standard of known composition that is certified by a recognized authority and representing a sample matrix. It is used to verify the accuracy of a method.
- 8.6 Laboratory Control Sample (LCS) and Laboratory Control Sample Duplicate (LCSD), is a sample containing known concentrations of the analytes of interest that is taken through the entire preparation and analysis process in the same manner as the samples to monitor complete method performance. A Certified Reference Material (CRM) is preferred as the LCS, but a blank spiked sample also meets the requirement.

Revision: 6	Effective Date: 3/27/2012	Page 5 of 12
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protect by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated benefit any party without prior written consent from Eurofins Frontier Global Sciences.		

		Document Title:	
🔅 eurofins		Preparation of Solids Samples for Total	Eurofins Document Reference:
- curonno	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Aqua-Regia Digestion	

- 8.7 Method or Preparation Blank (BLK) Method blanks consist of the same reagents used to digest the samples, in the same volume or proportion, and are carried through the complete sample preparation and analytical procedure.
- 8.8 Matrix Duplicate (MD) a representative sample is selected and digested in the same manner. This QC sample will indicate sample homogeneity on the analytes of interest.
- 8.9 Matrix Spike (MS) and Matrix Spike Duplicate (MSD) a representative sample is selected and spiked with a secondary source at *two* to five times the ambient concentration or at *two* to five times the MRL, whichever is greater These QC samples will indicate sample matrix effects on the analytes of interest.
- 8.10 May: This action, activity, or procedural step is optional.
- 8.11 May Not: This action, activity, or procedural step is prohibited.
- 8.12 Shall: This action, activity, or procedure is required.
- 8.13 Should: This action, activity, or procedure is suggested, but not required.

9 Interferences:

9.1 Modified aqua regia is a leaching method and as such does not dissolve silicate minerals.

10 Safety Precautions, Pollution Prevention and Waste Handling:

- 10.1 Personnel will don appropriate laboratory attire according to the Chemical Hygiene Plan. This includes, but is not limited to, laboratory coat, safety goggles, and latex gloves under clean gloves.
- 10.2 The toxicity or carcinogenicity of reagents used in this method has not been fully established. Each chemical should be regarded as a potential health hazard and exposure to these compounds should be as low as reasonably achievable. Chemists should refer to the MSDS (Material Safety Data Sheets) for each chemical they are working with.
 - 10.2.1 Note: Use particular caution when preparing and using BrCl, as it releases extremely irritating, corrosive fumes similar in effect to free chlorine. Always handle this reagent in an approved fume hood.
 - 10.2.2 Note: Modified aqua regia is <u>very</u> hazardous! <u>Always</u> work in fume hood wearing safety goggles and gloves while using this chemical.

CAUTION: THIS MIXTURE GETS HOT AND EMITS CAUSTIC FUMES.

- 10.3 All personnel handling environmental samples known to contain or to have been in contact with human waste should be immunized against known disease-causative agents. Frontier will reimburse the expense of Hepatitis A and B immunizations for any laboratory staff member who desires this protection.
- 10.4 Hydrochloric acid: Very hazardous in case of skin contact (corrosive, irritant, permeator), of eye contact (irritant, corrosive), of ingestion. Slightly hazardous in case of inhalation (lung sensitizer). Non-corrosive for lungs. Liquid or spray mist may produce tissue damage particularly on mucous membranes of eyes, mouth and respiratory tract. Skin contact may produce burns. Inhalation of the spray mist may produce severe irritation of respiratory tract, characterized by coughing, choking, or

Revision: 6	Effective Date: 3/27/2012	Page 6 of 12
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

		Document Title:	
🔅 eurofins		Preparation of Solids Samples for Total	Eurofins Document Reference:
, curonno	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Aqua-Regia Digestion	

shortness of breath. Severe over-exposure can result in death. Inflammation of the eye is characterized by redness, watering, and itching. Skin inflammation is characterized by itching, scaling, reddening, or, occasionally, blistering. For more information see MSDS.

- 10.5 Nitric acid (HNO₃): Corrosive. Strong oxidizer. Contact with other material may cause a fire. Causes eye and skin burns. May cause severe respiratory tract irritation with possible burns. May cause severe digestive tract irritation with possible burns. May cause severe digestive tract irritation with possible burns. May cause severe digestive tract irritation with possible burns. For more information see MSDS.
- 10.6 See Eurofins Frontier Global Sciences Chemical Hygiene Plan (CHP) for general information regarding employee safety, waste management, and pollution prevention.
- 10.7 Pollution prevention information can be found in the current Eurofins Frontier Global Sciences Chemical Hygiene Plan (CHP), which details and tracks various waste streams and disposal procedures.
- 10.8 All laboratory waste is accumulated, managed, and disposed of in accordance with all federal, state, and local laws and regulations. Any waste generated by this procedure should be disposed of according to SOP FGS-099 "Waste Disposal Procedure for Client Sample Waste," which provides instruction on dealing with laboratory and client waste.

11 Personnel Training and Qualifications:

- 11.1 An analyst must perform an initial demonstration of capability (IDOC) that includes four replicates of a secondary source before being qualified to analyze samples without supervision. Continuing DOC will be maintained and monitored via performance on CRMs and other QC samples, as well as obtaining acceptable results on proficiency testing exercises.
- 11.2 The analyst/laboratory technician must have read this SOP and other relevant SOPs and have the training documented on the applicable form(s). The analysis may be questioned on SOP by supervisor(s) and/or trainers.
- 11.3 Training is documented by the employee and supervisor, and is kept on file in the QA Office. The employee must read, understand, and by signing the training document, agree to perform the procedures as stated in all Standard Operating Procedures (SOPs) related to this method.
- 11.4 Reading of the SOP must be documented on the correct form such as "Standard Operating Procedure Training Record," Appendix F in FGS-094, the last page of this SOP, Appendix 1 "Standard Operating Procedure Training Record" or a similar document."
- 11.5 All employees must also, on a yearly basis, read the Quality Manual (QM), and complete the yearly Ethics training.
- 11.6 All training documents including IDOCs, CDOCs, SOP reading, Initial QA orientation, and Ethics training are stored by the Quality Assurance Manager in the employees training file for ten years after the employee is no longer working for Frontier Global Sciences.

Revision: 6	Effective Date: 3/27/2012	Page 7 of 12
by Washington State Law. Proprietary in	S Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

		Document Title:	
🔅 eurofins	1	Preparation of Solids Samples for Total	Eurofins Document Reference:
	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Aqua-Regia Digestion	

11.7 Chemical Safety Training, Compressed Gas Training, Chemical Hygiene Plan documentation, and Shipping of Hazardous goods, are stored by the Health and Safety Officer for ten years after the employee is no longer working for Frontier Global Sciences.

12 Sample Collection, Preservation, and Handling:

- 12.1 Sediment, soil, and other geological samples must be collected in accordance with established ultraclean sampling techniques (see e.g. FGS-008 "Ultra Clean Aqueous Sample Collection"). Samples may be placed in commercially available clean glass containers with Teflon-lined caps (i.e., I-Chem glass jars), or 125-mL or 250-mL HDPE jars.
- 12.2 Soil and sediment samples must be frozen at < -11 °C. Maximum holding time is 180 days at < -11 °C.
- 12.3 If sample do not contain elemental mercury (liquid Hg^o) and are only to be digested for total metals, they may be oven dried at 105 °C prior to digestion.

13 Apparatus and Equipment:

- 13.1 Digestion Vials.
- 13.2 Pipettors: Hydrochloric and nitric acids are conveniently dispensed separately from all glass or glass and Teflon bottle-top repetitive pipettors (10-mL size Re-Pipette or equivalent). Pipettes are to be calibrated *according to SOPs FGS-003 and FGS-155*.
- 13.3 Clean hood.
- 13.4 Analytical Balance: A laboratory analytical balance capable of weighing to ± 1 mg, with documented calibration.
- 13.5 Sample Digestion Log (LOG-HG-013) logbook.
- 13.6 Plastic or glass tools for homogenization.
- 13.7 Disposable spatula.
- 13.8 Teflon boiling chips
- 13.9 Centrifuging operating at 2000 RPM.
- 13.10 0.45-μm disposable filters.

14 Reagents and Standards:

- 14.1 Reagent Water: 18 M Ω ultra-pure deionized water starting from a pre-purified (distilled, R.O., etc.) source. As a final mercury and organic removal step, the activated carbon cartridge on the 18-M Ω system is placed between the final ion exchange bed and the 0.2 µm filter.
- 14.2 <u>Nitric Acid (HNO₃):</u> Several brands (Baker, Fisher, Omnitrace) have been found to have lots with acceptably low levels of trace metals. This reagent should be from a lot number that has been previously tested to be low for the analytes of interest. This reagent shall be entered into LIMS and the expiration date is set to the same as the manufacturer's expiration date.

Revision: 6	Effective Date: 3/27/2012	Page 8 of 12
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

		Document Title:	
🔅 eurofins		Preparation of Solids Samples for Total	Eurofins Document Reference:
. curorino	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Aqua-Regia Digestion	

- 14.3 <u>Hydrochloric Acid (HCI)</u>: Trace metal purified reagent-grade HCI is pre-analyzed to < 50 ng/L Hg and lot sequestered and before purchase. This solution shall be entered into LIMS and is considered stable until the expiration date on the bottle, 6 months from receipt.
- 14.4 <u>Potassium Bromide (KBr), neat:</u> This reagent is pre-certified by the vendor to be low in mercury. Reagent shall be entered into LIMS with a five year expiration date.
- 14.5 <u>Potassium Bromate (KBrO₃), neat:</u> This reagent is pre-certified by the vendor to be low in mercury. Reagent shall be entered into LIMS with a five year expiration date.
- 14.6 Bromine Monochloride (BrCl):
 - 14.6.1 The BrCL solution must be tested by analyzing a prepared solution.
 - 14.6.2 Reagent shall be entered into LIMS with a six months expiration date.

15 Procedure:

- 15.1 Obtain samples from the designated refrigerator or freezer. All samples must be completely thawed before homogenizing and weighing out. All tools used for homogenization and weighing must be cleaned thoroughly between samples with one HCl acid bath and one reagent bath or disposable.
- 15.2 Weigh an aliquot for common, low-level or large-grain samples. Place the aliquot directly into a 40-mL digestion vial. Add concentrated HCl and swirl the sample to wet all particles. Next, add concentrated HNO₃, swirl, and **LOOSELY** cap the vials.
- 15.3 Allow the loosely capped samples to digest in the fume hood. **Tightening the caps or** heating the samples can cause the vials to explode.
- 15.4 After digestion is complete, dilute soil or sediment digestions to 40 mL with BrCl. Shake vigorously and allow settling until the supernatant is clear prior to analysis.
- 15.5 For coal and other carbon materials, dilute the samples with BrCl solution. This ensures that of Hg will not re-adsorb to the carbon particles, producing low recoveries. Be sure that all finely grained particles are completely settled prior to analysis. This settling can be hastened by centrifuging for 20 minutes at *2000* RPM or by pre-filtering the sample through 0.45-μm disposable filters.

Caution: when adding BrCl to modified aqua regia, be aware of possible rapid bubble formation and foaming out of the vial. This is particularly a problem with carbon media, warm digests, and samples that have only been digested for a few hours

15.6 Analysis for total mercury is according to Eurofins Frontier SOP FGS-121.

16 Calculations:

16.1 This preparation procedure does not involve calculations.

17 Statistical Information/Method Performance:

17.1 Method Detection Limit (MDL) and Practical Quantitation Limit (PQL) studies are based on 40 CFR 136, Appendix B. The MDL and PQL must be performed for each analyte/matrix/preparation combination.

Revision: 6	Effective Date: 3/27/2012	Page 9 of 12
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

		Document Title:	
🔅 eurofins		Preparation of Solids Samples for Total	
	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Aqua-Regia Digestion	

- 17.2 The Practical Quantitation Limit (PQL) is the reporting limit for this method and is included as the lowest calibration point (2003 NELAC regulation 5.5.5.2.2.1.h.3). The PQL is determined by running ten replicate samples with a concentration the will produce a recovery of 70-130% for most analytes, but the recovery requirements are analyte dependent. The PQL is referred to as the Method Reporting Limit (MRL) in LIMS.
- 17.3 The current values for THg in sediments prepared by a Cold Modified Aqua Regia Digestion are 0.11 ng/g for the MDL and 1.00 ng/g for the PQL.
- 17.4 Current MDLs and PQLs are stored at: \General and Admin\Quality Assurance\MDLs & PQLs.

18 Quality Assurance/Quality Control:

- 18.1 Maximum Sample Batch Size: 20 samples.
- 18.2 Preparation Blanks: Minimum of three per batch. Each preparation blank must be less than *one-half* the PQL for the method.
- 18.3 The preparation blanks (PBs) are prepared with a similar mass of Teflon boiling chips as the samples, with the same reagents, and put through the same preparation process as the samples.
- 18.4 Certified Reference Material (CRM, representing the sample matrix when commercially available); a Laboratory Control Spike (LCS) and Laboratory Control Spike Duplicate (LCSD) are used when a suitable CRM is not available: One per batch in duplicate. The control limits are 77-123% recovery.
- 18.5 Matrix Duplicate (MD) Sample: One per batch. The control limit for the RPD is $\leq 24\%$.
- 18.6 Matrix Spike/Matrix Spike Duplicate (MS/MSD) Samples: One set per *10* samples. The control limits are *71-125*% recoveries and an RPD of ≤ *24%*.
- 18.7 Follow the flow charts in SOP FGS-038 "Data Review and Validation" to determine if any QC falling outside the established control limits can be qualified.
- 18.8 All of the quality control limits for the analysis method are included on the "Data Review Checklist."
 - 18.8.1 The data review checklists are located at: \\cuprum\General and Admin\Quality Assurance\Data Review\Current Data Review Checklists.

19 Corrective Action

- 19.1 A failing QC point does not necessary fail the entire dataset. If upon analysis a QC sample is out of control, some investigation must be performed to assess if the difficulties are related to matrix effects. The cause and method of determining the set's failure must be documented on the checklist and in the MMO notes, and the Group Supervisor shall be informed. See SOP FGS-038 "Data Review and Validation" for flow charts regarding analytical issues.
- 19.2 If there is any question as to the completeness of the digestion procedure, the samples must be allowed to react for an additional amount of time. If there is no change in the sample, the digestion is considered complete and can be diluted.

Revision: 6	Effective Date: 3/27/2012	Page 10 of 12
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Seurofins Frontier Globa	al Sciences Preparation of Solia Mercury Analysis Aqua-Reg	ent Title: ds Samples for Total s by Modified Cold ia Digestion	Eurofins Document Reference: EFGS-SOP-066-R06
20 List of Attachme	ents e - Standard Operating Pro	ocedure Training R	Record
Appendix A. Example	e - Standard Operating Pro		

COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protected by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.

		Document Title:	
🔅 eurofins	Î.	Preparation of Solids Samples for Total	Eurofins Document Reference:
- curornio	Frontier Global Sciences	Mercury Analysis by Modified Cold	EFGS-SOP-066-R06
		Áqua-Regia Digestion	

Appendix A: Example - Standard Operating Procedure Training Record

By signing this document, I the employee, certifies to have read, understood and agreed to follow the test method and quality procedure as described in this procedure.

Reading of SOP FGS-066.06:

Preparation of Solid Samples for Total Mercury Analysis by Modified Cold Aqua-Regia Digestion.

SOP name and Revision number	
Employee name (print)	
Employee name (sign)	Date:
Supervisor name (sign)	Date:
Initial COD Training (loove block if not one	

Initial SOP Training (leave blank if not applicable)

In	nitial reading of method and training	Initials	Date	Supervisor
1.	. Read method			
2.	. Observe the method			
3.	. Detailed review of method and associated literature			
4.	. Supervised practice of method with trainer			
5.	. Unsupervised practice of the method with trainer			
6	. Review of work with trainer and/or peer-review			
7.	. IDOC to determine precision and accuracy			
8.	. Determination of blanks			

Revision: 6	Effective Date: 3/27/2012	Page 12 of 12
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Curofins Frontler Global Sciences Determination of Total Mercury in Various Matrices by FI-AFS
--

Eurofins Document Reference	EFGS-SOP-121-R02	Revision	2
Effective Date	6/17/2013	Status	Final
Historical/Local Document Number	FGS-SOP-121.02		
Local Document Level	Level 3		
Local Document Type	SOP		
Local Document Category	NA		

Prepared by	Ryan Nelson
Reviewed and Approved by	Dave Wunderlich and Patrick Garcia-Strickland

Revision: 2	Effective Date: 6/17/2013	Page 1 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

٦

Table of Contents

1	Revision Log:	4
2	Reference:	4
3	Cross Reference:	5
4	Purpose:	5
5	Scope:	5
6	Basic Principles:	5
7	Reference Modifications:	6
8	Definitions:	6
9	Interferences:	8
10	Safety Precautions, Pollution Prevention and Waste Handlin	g:9
11	Personnel Training and Qualifications:	9
12	Sample Collection, Preservation, and Handling:	10
13	Apparatus and Equipment:	10
14	Reagents and Standards:	11
15	Calibration:	13
16	Procedure:	13
17	Calculations:	19
18	Statistical Information/Method Performance:	20
19	Quality Assurance/Quality Control:	20
20	Corrective Action	
21	List of Attachments	
Tab	le 1: QC Requirements for Total Mercury	23
Tab	le 2: Troubleshooting Flow Chart	Error! Bookmark not defined.
Арр	endix A: Example - Standard Operating Procedure Training	Record24

Revision: 2	Effective Date: 6/17/2013	Page 2 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain nformation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Т

Curofins Frontier Global Sciences	Document Title: Determination of Total Mercury in Various Matrices by FI-AFS	Eurofins Document Reference: EFGS-SOP-121-R02
-----------------------------------	--	--

Approvals:

Prepared by:	Date:	
Approved by:	Date:	
Approved by:	Date:	

COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protected by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.	Revision: 2	Effective Date: 6/17/2013	Page 3 of 24
	by Washington State Law. Proprietary in	formation must be maintained with the strictest of confidence a	

1 Revision Log:

Revision: 06	Effective Date: This version	
Section	Justification	Changes
Cover	Required change	Changed company name from Frontier Global Sciences to Eurofins Frontier Global Sciences.
All	Formatting requirement per LOM SOP-LAB-201	Reformatted document to new corporate specifications.
6.1	Required	Adjusted volumes/amounts
6.2, 13.9	Required	Changed primary and alternate gases
8.16, 8.17	Required	Added LOD and LOQ defs
13.1, 13.2	Required	Included software requirements
16.8, Table 2	Required	Added maintenance and troubleshooting procedures

2 Reference:

- 2.1 EPA Method 1631, Revision E: Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry, 2002.
- 2.2 Method 1669, "Method for Sampling Ambient Water for Determination of Metals at EPA Ambient Criteria Levels," U.S. Environmental Protection Agency, Office of Water, Office of Science and Technology, Engineering and Analysis Division (4303), 401 M Street SW, Washington, DC 20460, April 1995 with January 1996 revisions.
- 2.3 Bloom, N.S.; Ultra-Clean Sample Handling, Environmental Lab 1995, March/April, 20.
- 2.4 Bloom, N.S.; Horvat M., and Watras C.J. Results of the International Mercury Speciation Intercomparison Exercise. Wat. Air Soil Pollut. 1995, 80, 1257.
- 2.5 Bloom, N.S.; Crecelius, E.A. Determination of Mercury in Seawater at Sub-nanogram per Liter Levels.Mar.Chem.1983, 14, 49.
- 2.6 Bloom, N.S.; Crecelius, E.A. Distribution of Silver, Lead, Mercury, Copper, and Cadmium in Central Puget Sound Sediments Mar. Chem 1987, 21, 377-390.
- 2.7 Bloom, N.S.; Fitzgerald, W.F. Determination of Volatile Mercury Species at the Picogram Level by Low-Temperature Gas Chromatography with Cold-Vapor Atomic Fluorescence Detection. Anal. Chem. Acta. 1988, 208, 151.
- 2.8 Cossa, D.; Couran, P. An International Intercomparison Exercise for Total Mercury in Seawater. App.Organomet. Chem.1990, 4, 49.
- 2.9 Fitzgerald, W.F.; Gill, G.A. Sub-Nanogram Determination of Mercury by Two-Stage Gold Amalgamation and Gas Phase Detection Applied to Atmospheric Analysis. Anal. Chem. 1979, 15, 1714.
- 2.10 Gill, G.A.; Fitzgerald, W.F. Mercury Sampling of Open Ocean Waters at the Picogram Level Deep Sea Res. 1985, 32, 287.
- 2.11 Chemical Hygiene Plan, Eurofins Frontier Global Sciences, current version.
- 2.12 National Environmental Laboratory Accreditation Conference, NELAC Standard September 8, 2009.
- 2.13 Department of Defense Quality Systems Manual for Environmental Laboratories, prepared by DoD Environmental Quality Workgroup, Final Version 4.2, October 2010.

Revision: 2	Effective Date: 6/17/2013	Page 4 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

💸 curofins Frontier Global Scien	Document Title: Determination of Total Mercury in Various Matrices by FI-AFS	Eurofins Document Reference: EFGS-SOP-121-R02
---------------------------------------	--	--

3 Cross Reference:

Document	Document Title
SOP FGS-002	Balance Verification, Calibration and Maintenance
SOP FGS-003	Pipette Verification, Calibration and Maintenance
SOP FGS-007	Cleaning of Sampling Equipment and Bottles
SOP FGS-008	Ultra Clean Aqueous Sample Collection
SOP FGS-011	Digestion of Tissues for Total Mercury Analysis Using Nitric and Sulfuric Acids (70:30)
SOP FGS-038	Data Review and Validation
SOP FGS-058	Total Metals Digestion for Animal or Plant Tissues
SOP FGS-066	Preparation of Solid Samples for Total Mercury Analysis by Modified Cold
	Aqua-Regia Digestion
SOP FGS-094, App F	Standard Operating Procedure Training Record
SOP FGS-099	Waste Disposal Procedure for Client Sample Waste
SOP FGS-111	HF/HNO3/HCI Bomb Digestion of Sediments, Soils, Rocks, and Bayer Process Solids and Slurries for Mercury, followed by Repeated HNO_3 Evaporation
SOP FGS-155	Calibration of Volumetric Dispensers

4 Purpose:

- 4.1 This standard operating procedure (SOP) describes a method for the determination of total mercury (Hg) in a wide range of matrices including, but not limited to, aqueous, biological, and geological media. Total mercury is measured by Flow Injection Atomic Fluorescence Spectrometry and is calculated on a concentration (ppt) basis by comparing the instrument response of samples to the instrument response of standards.
- 4.2 This SOP is designed to ensure that reproducible traceable procedures are followed in the standardization of the total mercury analyzers and in the analysis of samples for total mercury, as well as to establish the limits wherein data will be considered acceptable.

5 Scope:

- 5.1 This method is designed for the determination of mercury in the typical range of 0.5-40ng/L (ppt). Application may be extended to higher levels by sample dilution, as long as the instrument value (intensity) remains within the calibration curve.
- 5.2 This SOP describes a method of the determination of arsenic species in aqueous and solid matrices (biological tissue, plant tissue, nutraceutical, etc.).

6 Basic Principles:

- 6.1 Total mercury analyses are split into two categories: waters and solids. For analysis of aqueous samples, a dilution of oxidized sample is added to a vial with BrCl. For solids, a dilution is made of the digested sample by pipetting into a vial with BrCl. In the case of waters and solids, the final volume is neutralized with hydroxylamine-hydrochloride (NH₂OH-HCl). The sample is drawn into the system by an auto sampler. Sample is then mixed with stannous chloride (SnCl₂) before entering the phase separator.
- 6.2 As sample travels down the phase separator it is exposed to a flow of *argon (or nitrogen)*. Mercury then travels through a soda-lime acid vapor trap and amalgamates onto it. At the same time this trap is heated, and mercury is released into the argon

Revision: 2	Effective Date: 6/17/2013	Page 5 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

stream and amalgamates onto a second trap. This trap is then heated, releasing mercury into the AFS detector.

7 Reference Modifications:

7.1 There were no significant modifications made to this method.

8 Definitions:

- 8.1 Analytical Duplicate (AD): A representative sample (that yielded a result within the calibration curve) is analyzed a second time during the analytical run. The second analysis should be at the same aliquot as the original.
- 8.2 Analytical Run The continuous analysis of one or more batches during the same 12 hour-shift. Each analytical day requires a minimum five-point calibration curve, ICV, at least 3 IBLs, and CCV/CCB every ten runs. An analytical day must conclude with a CCV/CCB.
- 8.3 Analytical Spike and Analytical Spike Duplicate (AS/ASD): A representative sample is selected and spiked, with a dilution of the primary source, during the analytical run, at a target concentration of 1-5X the ambient concentration of the sample. These QC samples are used to indicate sample matrix effects on the analyte of interest. Non-detectable samples are spiked at 1 5 x of the MRL/PQL.
- 8.4 Batch: 20 client samples or less grouped for preparation. See Quality Assurance Section for batch requirements.
- 8.5 Calibration Standards (CAL) a series of standards that will be used to calibrate the instrument, made from a primary source stock standard. A calibration blank plus at least five different concentrations are required, beginning with one at PQL concentration.
- 8.6 Certified Reference Material (CRM) a standard of known composition that is certified by a recognized authority and representing a sample matrix. It is used to verify the accuracy of a method.
- 8.7 Continuing Calibration Verification (CCV): A dilution of the OPR standard resulting in an instrumental concentration of 5.0ng/L. This standard is analyzed every 10 analyses after the ICV/IBLs, and determines whether the instrument is maintaining calibration.
- 8.8 Continuing Demonstration of Capability (CDOC)
- 8.9 Control Limit (CL) the limit of the range of acceptability for the quality control samples
- 8.10 Equipment Blank (EB): Reagent water processed through the sampling devices and placed in a sample container prior to using the equipment to collect samples and used to demonstrate that the sampling equipment is free from contamination.
- 8.11 Field Blanks (FB): A sample of reagent water placed in a sample container in the field and used to demonstrate that samples have not been contaminated by sample collection or transport activities. EPA-1631E recommends the analysis of at least one field blank per 10 samples collected at the same site at the same time. Analyze the blank immediately before analyzing the samples in the batch.

Revision: 2	Effective Date: 6/17/2013	Page 6 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

- 8.12 Initial Calibration Verification (ICV) A dilution of the OPR standard resulting in an instrumental concentration of 5.0 ng/L. This standard is run immediately following the calibration curve and verifies instrument calibration. It is always followed by the IBLs.
- 8.13 Instrument Blank Level and Continuing Calibration Blank (IBL and CCB) for evaluation of instrument drift, sensitivity and contamination. IBLs must be analyzed directly after the ICV, and the CCBs every 10 samples immediately after CCVs. IBLs and CCBs must individually be less than one-half of the Practical Quantitation Limit.
- 8.14 Initial Demonstration of Capability (IDOC).
- 8.15 Laboratory Control Sample (LCS and LCSD) or Quality Control Sample (QCS): A sample (and duplicate) containing a known concentration of mercury that is used to monitor complete method performance. The preferred LCS is a matrix matched Certified Reference Material (CRM), but a blank spike meets the requirement also. In LIMS, the LCS is always referred to as a Blank Spike (BS), whether it is matrix matched or not.
- 8.16 Limit of Detection (LOD) equal to MDL and verified on a quarterly/annual basis, depending on the preparation, by spiking within three times the established LOD and showing a positive result on the instrument.
- 8.17 Limit of Quantitation (LOQ) equal to PQL and verified on a quarterly/annual basis, depending on the preparation, by spiking within 2 times the LOQ and showing a recovery between 70 130%.
- 8.18 LIMS: Laboratory Information Management System. Computer software used for managing samples, standards, and other laboratory functions.
- 8.19 May: This action, activity, or procedural step is optional.
- 8.20 May Not: This action, activity, or procedural step is prohibited .
- 8.21 Matrix Spike (MS) and Matrix Spike Duplicate (MSD): A representative sample is selected and spiked with a dilution of the primary source at a known concentration. The MS and MSD are run through the entire analytical process just as the samples are. These QC samples will indicate sample matrix effects on the analyte of interest.
- 8.22 Method Blank (MBLK) or Preparation Blank (PB): For waters, reagent water that is prepared and analyzed in a manner identical to that of samples. For digested solids, preparations blanks consist of the same reagents used to digest the samples, in the same volume or proportion and are carried through the complete sample preparation and analytical procedure. Boiling chips are used as a blank matrix for solids. Preparation blanks are referred to as BLK in LIMS.
- 8.23 Method Detection Limit (MDL): A limit derived from 40 CFR, Part 136, Appendix B. This method produces a defined value that is the minimum concentration that can be measured and reported with a 99% confidence that the analyte concentration is greater than zero from a given matrix.
- 8.24 Method Duplicates/Method Triplicates (MD/MT): A second or third separate sample dilution, taken from the same source sample, prepared and analyzed in the laboratory separately. An MSD may be used as a duplicate.

Revision: 2	Effective Date: 6/17/2013	Page 7 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

- 8.25 Reagent water: 18 MΩ minimum, reagent water starting from a pre-purified (distilled, Reverse Osmosis, etc.) source.
- 8.26 Must: This action, activity, or procedural step is required.
- 8.27 Ongoing Precision and Recovery (OPR): A dilution of a secondary source.
- 8.28 PM: Project Manager.
- 8.29 Practical Quantitation Limit (PQL), Method Reporting Limit (MRL): The minimum concentration that can be reported quantitatively. The PQL is often described as 1-10 times higher than MDL. Eurofins Frontier defines the PQL as the lowest concentration that can achieve 70-130% recovery for 10 replicate sample preparations. In LIMS, the PQL is referred to as the MRL.
- 8.30 Primary Source: The stock standard used to make the calibration standard. Procedural Method: A method where standards and samples are run through the analytical procedure exactly the same. By NELAC definition, this SOP is a procedural method.
- 8.31 Secondary Source: The stock standard used to make the OPR standard.Shall: This action, activity, or procedure is required.
- 8.32 Should: This action, activity, or procedure is suggested, but not required.
- 8.33 Stock Standard Solution (SSS) a standard of analyte that is purchased from a certified source for the preparation of working standards.
- 8.34 Total mercury: As defined by this method, all bromine monochloride-oxidizable mercury forms and species found in aqueous solutions. This includes, but is not limited to, Hg(II), Hg(0), strongly organo-complexed Hg(II) compounds, adsorbed particulate Hg(P), and several tested covalently bound organomercurials (i.e. CH₃HgCl, (CH₃)₂Hg, and C₆H₅HgOOCCH₃). The recovery of mercury bound within microbial cells may require additional preparation steps (i.e. UV oxidation, or oven digestion).
- 8.35 Travel or Trip Blank (TB): A sample of reagent water placed in a sample container in the laboratory and used to demonstrate that samples have not been contaminated by transport activities.
- 8.36 Wash Station Blank (WSB) a "blank" that is drawn from the wash station.

9 Interferences:

- 9.1 It is recommended that aliquots of no more than 5.0mL be analyzed.
- 9.2 Improperly adjusted pump tubing can cause the phase separator to fill with sample
- 9.3 Water vapor has the potential to create recovery interferences.
- 9.4 The presence of high concentrations of silver and/or gold can cause interferences.
- 9.5 Analysis of samples containing high concentrations of strong acids can lead to low bias/recoveries.

Revision: 2	Effective Date: 6/17/2013	Page 8 of 24
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

10 Safety Precautions, Pollution Prevention and Waste Handling:

- 10.1 Personnel will don appropriate laboratory attire according to the Chemical Hygiene Plan. This includes, but is not limited to, laboratory coat, safety goggles and nitrile gloves under clean gloves.
- 10.2 The toxicity or carcinogenicity of reagents used in this method has not been fully established. Each chemical should be regarded as a potential health hazard and exposure to these compounds should be as low as reasonably achievable. Chemists should refer to the MSDS (Material Safety Data Sheets) for each chemical they are working with.
 - 10.2.1 Note: Use particular caution when preparing and using BrCl, as it releases extremely irritating, corrosive fumes similar in effect to free chlorine. Always handle this reagent in an approved fume hood
- 10.3 All personnel handling environmental samples known to contain or to have been in contact with human waste should be immunized against known disease-causative agents. Eurofins Frontier will reimburse the expense of Hepatitis A and B immunizations for any laboratory staff member who desires this protection.
- 10.4 Hydrochloric acid: Very hazardous in case of skin contact (corrosive, irritant, permeator), of eye contact (irritant, corrosive), of ingestion. Slightly hazardous in case of inhalation (lung sensitizer). Non-corrosive for lungs. Liquid or spray mist may produce tissue damage particularly on mucous membranes of eyes, mouth and respiratory tract. Skin contact may produce burns. Inhalation of the spray mist may produce severe irritation of respiratory tract, characterized by coughing, choking, or shortness of breath. Severe over-exposure can result in death. Inflammation of the eye is characterized by redness, watering, and itching. Skin inflammation is characterized by itching, scaling, reddening, or, occasionally, blistering. For more information see MSDS.
- 10.5 See Eurofins Frontier Global Sciences Chemical Hygiene Plan (CHP) for general information regarding employee safety, waste management, and pollution prevention.
- 10.6 Pollution prevention information can be found in the current Eurofins Frontier Global Sciences Chemical Hygiene Plan (CHP), which details and tracks various waste streams and disposal procedures.
- 10.7 All laboratory waste is accumulated, managed, and disposed of in accordance with all federal, state, and local laws and regulations. Any waste generated by this procedure should be disposed of according to SOP FGS-099 "Waste Disposal Procedure for Client Sample Waste," which provides instruction on dealing with laboratory and client waste.

11 Personnel Training and Qualifications:

11.1 An analyst must perform an initial demonstration of capability (IDOC) that includes four replicates of a secondary source before being qualified to analyze samples without supervision. Continuing DOC will be maintained and monitored via performance on CRMs and other QC samples, as well as obtaining acceptable results on proficiency testing exercises.

Revision: 2	Effective Date: 6/17/2013	Page 9 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Scurofins Frontier Global Sciences	Document Title: Determination of Total Mercury in Various Matrices by FI-AFS	Eurofins Document Reference: EFGS-SOP-121-R02
------------------------------------	--	--

- 11.2 The analyst/laboratory technician must have read this SOP and other relevant SOPs and have the training documented on the applicable form(s). The analysis may be questioned on SOP by supervisor(s) and/or trainers.
- 11.3 Training is documented by the employee and supervisor, and is kept on file in the QA Office. The employee must read, understand, and by signing the training document, agree to perform the procedures as stated in all Standard Operating Procedures (SOPs) related to this method.
- 11.4 Reading of the SOP must be documented on the correct form such as "Standard Operating Procedure Training Record," Appendix F in FGS-094, the last page of this SOP, Appendix A "Standard Operating Procedure Training Record" or a similar document."
- 11.5 All employees must also, on a yearly basis, read the Quality Manual (QM), and complete the yearly Ethics training.
- 11.6 All training documents including IDOCs, CDOCs, SOP reading, Initial QA orientation, and Ethics training are stored by the Quality Assurance Manager in the employees training file for ten years after the employee is no longer working for Eurofins Frontier Global Sciences.
- 11.7 Chemical Safety Training, Compressed Gas Training, Chemical Hygiene Plan documentation, and Shipping of Hazardous goods, are stored by the Health and Safety Officer for ten years after the employee is no longer working for Eurofins Frontier Global Sciences.

12 Sample Collection, Preservation, and Handling:

- 12.1 Aqueous samples are collected in rigorously cleaned fluoropolymer (e.g. Teflon) bottles and caps (as described in FGS-007 "Cleaning of Sampling Equipment and Bottles for Mercury Analysis"). Certified clean glass bottles with fluoropolymer lids may be used if mercury is the only analyte of interest.
 - 12.1.1 Aqueous samples are preserved upon receipt with BrCl. Refer to FGS-012 "Oxidation of Aqueous Samples for Total Mercury Analysis" for oxidation of aqueous samples.
- 12.2 Solid samples may be collected in glass, high density polyethylene, or fluoropolymer jars.
 - 12.2.1 Solid samples are preserved by freezing upon receipt.
- 12.3 All samples should be collected utilizing clean techniques, so as not to crosscontaminate samples with mercury. See FGS-008 "Ultra Clean Aqueous Sample Collection" and EPA Method 1669 for aqueous sample techniques.

13 Apparatus and Equipment:

- 13.1 LIMS
- 13.2 Instrument software
- 13.3 System Control Module

Revision: 2		Effective Date: 6/17/2013	Page 10 of 24
by Washington State Law.	Proprietary ir	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

- 13.4 Pump Unit
- 13.5 Auto-Sampler
- 13.6 Vials with screw caps
- 13.7 Tubing
- 13.8 Teflon Fittings and FEP tubing of various sizes and lengths.
- 13.9 Soda-Lime trap
- 13.10 *Phase* separator
- 13.11 Gold Coated Quartz Sand Trap
- 13.12 Pure Gold Bead Trap
- 13.13 Pipettes: Calibrated variable pipettes with a range of 5 μ L 10 mL. Used to make solutions and sample dilutions. Pipettes are to be calibrated weekly according to SOP FGS-003 and FGS-155.
- 13.14 Analytical Balance capable of accurately weighing to the nearest 0.1mg, and able to tare at least one gram. The analytical balances are verified for accuracy on a daily basis according to FGS-002 "Balance Verification, Calibration and Maintenance."

14 Reagents and Standards:

All reagents, except those made daily, must be entered into LIMS

- 14.1 Reagent Water: 18-MΩ ultra pure deionized water starting from a pre-purified (distilled, R.O., etc.) source is used.
- 14.2 <u>Hydrochloric Acid (HCI)</u>: Reagent-grade HCI.
- 14.3 Bromine Monochloride (BrCI):
 - 14.3.1 KBr is added to HCl.
 - 14.3.2 KBrO₃ is added to the acid.
 - 14.3.2.1 The expiration time for this reagent is set by default to six months in LIMS. There is no suggested holding time in EPA method 1631E, therefore the holding time can be extended, as long as the primary reagent has not expired. The mercury concentration of the BrCl is monitored through the preparation of water preparation blanks.
- 14.4 <u>Hydroxylamine hydrochloride</u>: dissolve NH₂OH-HCl in reagent water.
- 14.5 <u>Stannous Chloride(SnCl₂)</u>: *dissolve 500g SnCl₂ with HCl.*
 - 14.5.1 The expiration time for this reagent by default is set to six months in LIMS. There is no suggested holding time in EPA method 1631E; therefore the holding time can be extended, as long as the primary reagent has not expired.
- 14.6 <u>HCI Shutdown Rinse Solution</u>: HCI in reagent water.
- 14.7 <u>BrCl Rinse Solution</u>: BrCl in reagent water.

Revision: 2	Effective Date: 6/17/2013	Page 11 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

- 14.8 Preparation of Total Mercury Standard Solutions:
 - 14.8.1 Mercury standard solutions are prepared in volumetric glassware and gravimetrically calibrated pipettes. Resulting solutions must be stored in bottles and preserved with BrCl. All working standards must be tested prior to use.
 - 14.8.2 Total Mercury Stock Standard Solution (Stock): Certified mercury standard purchased a primary source and a secondary source).
 - 14.8.3 Total Mercury Spiking Standard Solutions (Spiking Standard): Spiking standards are made from either the primary or secondary sources.
 - 14.8.4 Spiking Standard: Made from the Primary Stock Standard
 - 14.8.5 Calibration Standard: Must be made from a dilution of the Primary Stock Standard.
 - 14.8.6 Initial Calibration Verification (ICV): Use the OPR Standard.
 - 14.8.7 Continuing Calibration Verification (CCV): For CCV analysis, use the OPR Standard.
 - 14.8.8 Certified Reference Material (CRM) for Total Mercury in Water
 - 14.8.9 OPR Standard: Must be made from a dilution of a Secondary Spiking Standard.
- 14.9 Documentation of Standards:
 - 14.9.1 Standards and Reagents are documented in LIMS upon receipt or creation. A LIMS generated label is affixed to each standard and reagent that has the name of the solution, the person who prepared or received it, the date it was prepared or received, and the expiration date.
 - 14.9.2 Each bottle of standard must be labeled with the following: the date of receipt or creation, the initials (or name) of who entered the standard into LIMS, the concentration and analyte, the expiration date and the LIMS ID. This information must also appear on the certificate of analysis of stock standards.
 - 14.9.3 Stock standards and CRMs are logged into LIMS upon receipt by Shipping and Receiving (S&R) or the Quality Assurance department (QA). These do not require testing, provided there is a Certificate of Analysis on file in QA. When receiving a solid CRM, QA shall generate a work order in LIMS for total solids analysis.
 - 14.9.4 For all standards, LIMS documentation must include the following: a description of the standard, department, expiration date of the standard (not to exceed the expiration of the parent standard), the name of the person who made (or received) the standard or reagent, the date it was prepared (or received), final volume, a reference date (date entered into LIMS), concentration units (µg/mL), the vendor and vendor lot. The solvent lot is used to document the Lot Number or LIMS ID of the BrCl that was used. In the comments section, the analyst must enter the sequence and applicable results for documentation of standard testing. Other notes may be entered in here as well. The correct parent standard must be noted, as well as the amount used. Analytes are entered individually from the list. LIMS will calculate the true value of the standard

Revision: 2	Effective Date: 6/17/2013	Page 12 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

based on the amount of the parent used and the final volume. Click the appropriate radio button under Standard type. A Spike Mix is a standard that is used in a bench sheet, and a Calibration standard is a standard used only in sequences. The standard must not be used until it has passed control limits and is approved by the mercury supervisor, mercury laboratory manager, or QA for use.

- 14.9.4.1 If the new standard is a calibration standard, a separate standard ID must be created for each calibration point based on the final concentration in the sequence. These are given the same expiration as the standard they are made from, and will need to be generated every three months as each new working calibration standard is made and tested.
- 14.9.5 Neat reagents are logged into LIMS with a unique identifier upon receipt by Shipping and Receiving Department.
- 14.9.6 Working reagents are prepared by the analyst, logged into LIMS and assigned a unique identifier. Reagents entered into LIMS must have the information listed in section 14.2.2, in addition the parent neat reagents are added by their unique identifier and the amount of each reagent is entered. It is not necessary to enter analytes from the list for reagents. The Solvent Lot is not applicable to working reagents. The radio button must be clicked to Reagent. If the reagent requires testing, it must test clean prior to using. All reagents used during analysis and prep must be added to bench sheet.
- 14.9.7 Each bottle of reagent must be labeled with the following: the date of receipt or creation, the initials (or name) of who entered the reagent into LIMS, a description of the reagent including composition when applicable, the expiration date and the LIMS ID. This information must also appear on the certificate of analysis or the certificate of purity for the reagent.
- 14.10 Argon
- 14.11 Nitrogen

15 Calibration:

- 15.1 The calibration sequence consists of a minimum 5-point calibration curve. Immediately following the standard curve, an ICV/OPR and IBLs are analyzed. All standards (and samples) are added to a vial with BrCl.
- 15.2 Once the instrument is calibrated and the ICV/OPR and three IBLs are analyzed and passing, the instrument is operational. The sample concentrations must fall within the range of the calibration standards or be diluted and reanalyzed.
- 15.3 Additional calibration standards (linearity standards) may be added to the curve to prove instrument linearity at higher levels. This is acceptable only when there is no more client sample available, otherwise a dilution must be performed to bring the sample within calibration range.
- 15.4 The calibration of this system and calculation of sample results are performed using units of concentration (ppt or ng/L).

16 Procedure:

Revision: 2	Effective Date: 6/17/2013	Page 13 of 24
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

- 16.1 Pre-analysis and Organization:
 - 16.1.1 Prior to analyzing samples it is imperative to reference LIMS for all project specific information, such as QC requirements, suggested dilutions, project manager information, and specifics regarding spike levels.
 - 16.1.2 The analyst should then locate samples and check the work order in LIMS for notes about specific project requirements.
 - 16.1.3 The analyst should compare the sample IDs to the work order and see that the samples are accounted for, and notify the project manager of any discrepancies in analysis required, sample identification, etc.
 - 16.1.4 All mercury analyses receive a unique dataset identifier and LIMS assigned sequence number. The dataset ID is comprised of the instrument type and number, the date and the calibration number for that day. The format is as follows: THg26001-130216-1, where "THg "refers to a total mercury analysis; "26001" refers to Tekran 2600 instrument number 1; 130216 refers to the date (February 16, 2013 in the YYMMDD format); and "1" refers to the first calibration of the day.

The sequence number is assigned by LIMS when the data gets imported into LIMS. The alpha-numeric code is based on the following format: 3B02001, where the 3 refers to the year (2013), the "B" is the month (A= January, B=February...L=December), "02" is the day of the month (February 2nd) and the final 3 digits is the nth sequence created on that particular year/month/day combination.

- 16.1.5 In general the analyst should organize their samples in the order listed on the bench sheet. The first samples analyzed should be the preparation blanks, then the LCS if analyzing solid samples, followed by actual samples. If possible, run total and dissolved samples side by side to facilitate verification that total concentration is greater than dissolved concentration. See QA section.
- 16.2 Instrument Start Up:
 - 16.2.1 If necessary, prepare the soda-lime trap.
 - 16.2.2 Start the software and check to make sure the computer is communicating with the instrument and the autosampler. Load a new work sheet and begin to enter the sample IDs into the run. Take care to insure that the appropriate autosampler position and dilution are entered correctly into the worksheet.
 - 16.2.3 Empty the waste carboy in accordance with FGS-099 "Waste Dumping Procedure for Client Sample Waste.
 - 16.2.4 Fill rinse basin with a fresh solution of BrCl and refill the SnCl₂ container.
 - 16.2.5 Clamp all tubing/cassettes onto pump head and adjust tension.
 - 16.2.6 Turn the pump on.
 - 16.2.7 Thoroughly wet the phase separator rod.

Revision: 2	Effective Date: 6/17/2013	Page 14 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

- 16.2.8 After wetting, turn on the phase separator gas.
- 16.2.9 Start the run.
- 16.3 Analyzing Aqueous Samples:
 - 16.3.1 All aqueous samples should be preserved with BrCl according to FGS-012 "Oxidation of Aqueous Samples for Total Mercury Analysis" at least 24 hours prior to analysis.
 - 16.3.2 While the standard curve is being analyzed, the analyst should prepare three preparation blanks (PBW).
 - 16.3.3 For all waters, prepare the appropriate dilution (refer to LIMS, historical data, etc.).
 - 16.3.4 Load sample vials into the auto sampler. Verify that the correct vial is in the proper position relative to the analysis worksheet entry.
 - 16.3.5 For each sample, the sample ID, BrCl percentage, and a dilution is entered into the software.
 - 16.3.6 The analyst should continue preparing and adding samples to the run in the same fashion to maximize efficiency. Positions on the autosampler can be used more than one time throughout the analysis run by removing a previously analyzed sample vial and replacing it with a new sample.
 - 16.3.7 Quality Control Procedures for Aqueous Samples:
 - 16.3.7.1 One Matrix Spike/Matrix Spike Duplicate (MS/MSD) must be performed every 10 samples. Be sure to note the samples used for the MS/MSD/MD, the spike concentration and the spike's LIMS ID/ on the bench sheet for cross referencing during peer review. *The recovery of the MS/MSD must be between 71-125%, and the Relative Percent Difference between them must be less than 24%. Some failures may be qualified using QA Qualification Flow Charts (Appendix A).*
 - 16.3.7.2 Matrix Duplicates One Matrix Duplicate (MD) should be analyzed for every batch of 20 samples. Upon request, a Matrix Triplicate (MT) may be performed. The MSD may serve as the MD if necessary. The Relative Percent Difference (RPD) and the Relative Standard Deviation (RSD) of duplicate samples must be less than 24%. Some failures may be qualified using QA Qualification Flow Charts.
 - 16.3.7.3 Laboratory Control Standard (LCS) or Quality Control Sample (QCS): For every batch of samples, at least one LCS is processed and analyzed. The recovery of the LCS must be within 80-120% for the aqueous NIST 1641d. An LCS Duplicate (LCSD) should accompany the LCS.
 - 16.3.7.3.1 A Certified Reference Material (CRM) is the preferred LCS, but a Blank Spike may serve as an LCS if an appropriate CRM does not exist. The spiking level is based on client request, historical data,

Revision: 2	Effective Date: 6/17/2013	Page 15 of 24
by Washington State Law. Proprietary in	S Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

,	Eurofins Document Reference: EFGS-SOP-121-R02
	mination of Total Mercury in rious Matrices by FI-AFS

or a default of mid-curve. A duplicate blank spike must also be prepared as an LCSD.

- 16.3.7.4 Ongoing Precision and Recovery (OPR): An OPR must be analyzed at the beginning and end of each analytical batch, or at the end of each 12-hour shift. The recovery of the OPR must be within 77-123% to be considered in control. Eurofins-FGS runs all ICV's and CCV's at OPR level, which satisfies the requirement of having an OPR at the beginning and end of runs.
- 16.3.7.5 All calibration standards must be traceable to the original standard source. The calibration curve must be established at the beginning of the analytical run. It must include at least five different concentrations, with the lowest concentration equal to the PQL. The average response factor of each calibration standard is used to calculate the sample values. The RSD of the response factors must be less than 15% of the mean or the calibration fails.
- 16.3.7.6 ICV and CCV control limit is 77-123%. The CCV is analyzed every 10 analyses, and at the end of an analytical run. CCBs are always analyzed after the CCVs.
- 16.3.7.7 Field Blanks: To be compliant with EPA 1631, clients must submit a field blank for each set of samples (samples collected from the same site at the same time, to a maximum of 10 samples).
 - 16.3.7.7.1 If no field blanks are submitted by the client, their data will be flagged with "FB-1631." "Required equipment/field/filter blank not submitted by the client. The sample has been analyzed according to 1631E, but does not meet 1631E criteria."
- 16.3.7.8 Method or Preparation Blanks (BLK): Method blanks are used to demonstrate that the analytical system is free from contamination that could otherwise compromise sample results. Method blanks are prepared and analyzed using sample containers, labware, reagents, and analytical procedures identical to those used to prepare and analyze the samples.
 - 16.3.7.8.1 For water samples, BrCl method blanks per analytical batch are required.
 - 16.3.7.8.2 If the result for any BrCl method blank is found to contain ≥ 0.25 ng/L Hg, the system is out of control.
- 16.3.7.9 Instrument Blanks (IBLs): Instrument blanks must be analyzed with each analytical run.
 - 16.3.7.9.1 If an instrument blank is found to contain more than 0.50ng/L, the system is out of control. The problem must be investigated and before any samples can be analyzed.

Revision: 2	Effective Date: 6/17/2013	Page 16 of 24
by Washington State Law. Proprietary in	S Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Curofins Frontier Global Sciences	Document Title: Determination of Total Mercury in Various Matrices by FI-AFS	Eurofins Document Reference: EFGS-SOP-121-R02
-----------------------------------	--	--

- 16.3.7.9.1.1 The mean result for all bubbler blanks must be <0.25ng/L with a standard deviation of 0.10 ng/L.
- 16.3.7.10 The analytical day must close with a CCV/OPR/CCB.
- 16.3.7.11 Because the method is done in real-time, it is EFGS' position that a single non-compliant QC sample result does not automatically invalidate a data set. All data points that can be explained and rerun with a passing result can be qualified. If the source of error cannot be corrected for a QC standard that day, none of the data can be validated. In the event that the system becomes out of control during the analysis day, all results bracketed between valid QC data points shall still be considered valid (CCV, OPR, CCB, etc).
- 16.3.7.12 The Control Limits are established from EPA 1631E.
- 16.4 Analysis of Digested Solids:
 - 16.4.1 With this method it is possible to determine the concentration of total mercury in solid samples following proper digestion. The following highlight the majority of total mercury prep techniques for solids and their matrix specific SOPs.
 - 16.4.1.1 For tissues, refer to FGS-011 "Digestion of Tissues for Total Mercury Analysis Using Nitric and Sulfuric Acids (70:30)" for the nitric acid/sulfuric acid digestion and FGS-058 "Total Metals Digestion for Animal or Plant Tissues" for the concentrated nitric acid digest.
 - 16.4.1.2 For soils/sediments, refer to FGS-066 "Preparation of Solid Samples for Total Mercury Analysis by Modified Cold Aqua-Regia Digestion" for the cold aqua regia digestion, FGS-011 for the nitric acid/sulfuric acid digestion, and FGS-111 "HF/HNO3/HCI Bomb Digestion of Sediments, Soils, Rocks, and Bayer Process Solids and Slurries for Mercury, followed by Repeated HNO3 Evaporation" for the hydrofluoric acid/nitric acid bomb digestion.
 - 16.4.1.3 For coal and ash, refer to FGS-066 Preparation of Solid Samples for Total Mercury Analysis by Modified Cold Aqua-Regia Digestion for the cold aqua regia digestion. For FSTM, refer to FGS-009 "Mercury Digest for Gas/Air Samples Collected on KCI/Quartz or KCI/Lime trap" for the digestion of traps.
 - 16.4.2 After the instrument calibration sequence, preparation blanks and the digested CRM(s) are analyzed. The analyst should use the *minimum dilution* allowed for each preparation blank and diluting with reagent water preserved with BrCl. Analysts are to calculate the appropriate dilution for the digested CRM, ensuring that the sample concentration stays within the calibration curve.
 - 16.4.3 Begin analyzing samples by the order of the digestion sheet, with the exception of the sample that has separate QC digested for MD/MS/MSD. It is appropriate to analyze this sample, and any associated QC, out of bench sheet order. The analyst should review any relevant project notes, historical data, or information

Revision: 2	Effective Date: 6/17/2013	Page 17 of 24
by Washington State Law. Proprietary in	S Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

🙆 ourofine I	Document Title:	Eurofins Document Reference:
Strontler Global Sciences	Determination of Total Mercury in Various Matrices by FI-AFS	EFGS-SOP-121-R02

given by client to the PM to help determine proper dilutions that will allow samples to recover within calibration curve.

- 16.4.4 The procedure for analysis is similar to that of the calibration:
 - 16.4.4.1 Selected digest samples are pipetted into a vial (one sample per vial) and diluted with reagent water preserved with BrCl.
 - 16.4.4.2 For each sample, the sample ID and dilution are entered into the software. The dilution should also be noted on the digestion bench sheet for cross referencing in peer review.
- 16.4.5 Quality Control Procedures for Digested Solid Samples:
 - 16.4.5.1 Please refer to the appropriate SOP for each matrix's corresponding quality control samples. All quality control samples prepared for the batch should be run with its analysis unless stated otherwise by the project manager. Please see Table 22.1 for acceptance criteria.
 - 16.4.5.2 Spiking standard LIMS ID and the amount used for the MS/MSD must be noted on the digestion bench sheet for cross referencing in peer review.
 - 16.4.5.3 The analytical day must close with a CCV(OPR) /CCB.
- 16.5 Analysis of Fluegas Sorbent for Total Mercury (FSTM)/KCI Traps and Particulate Filter:
 - 16.5.1 With a few exceptions FSTM traps and particulate filters are digested and analyzed as if they were solids.
 - 16.5.2 FSTM traps or particulate filters should be digested according to FGS-009 "Digestion for Gas/Air Samples Collected on Fluegas Sorbent for Total Mercury TM Traps."
 - 16.5.3 KCI traps should be digested according to EFGS-031 "Mercury Digest for Gas/Air Samples Collected on KCI/Quartz or KCI/Lime trap."
 - 16.5.4 Quality Control Requirements for FSTM Traps and Particulate Filters:
 - 16.5.4.1 Please refer to the appropriate SOP for each matrix's corresponding quality control samples. All quality control samples prepared for the batch should be run with its analysis unless stated otherwise by the project manager. Please see Table 22.1 for acceptance criteria.
 - 16.5.4.2 The amount of spiking standard used, it's LIMS ID and dilution used for the MS/MSD as well the sample(s) used for MS/MSD/MD, must be noted on the digestion bench sheet for cross referencing in peer review.
- 16.6 End of analysis close-down procedure:
 - 16.6.1 Turn off gas flow to the phase separator.
 - 16.6.2 Rinse carboy.
 - 16.6.3 Rinse system.

Revision: 2	Effective Date: 6/17/2013	Page 18 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

17 Calculations:

- 17.1 Average all instrument blanks (PH_x) using the peak area values from the TekMDS software. Subtract the average (IB) from the peak area for each standard and sample.
- 17.2 Calculate the calibration factor (CF_x) for mercury in each of the five standards using the mean instrument-blank-subtracted peak area and the following equation:

 $CF_x = PA_x - IB / C_x$

Where:

- 17.2.1 PAx=peak area for mercury in standard
- 17.2.2 IB=mean peak height for mercury in instrument blank
- 17.2.3 Cx=mass in standard analyzed (ng/L)
- 17.2.4 CFx=Response Factor of each concentration
 - 17.2.4.1 Average the five response factors to establish mean value: CF(Avg) (units/ng/L).
- 17.3 Sample results are then corrected for the average peak area values of at least three preparation blanks (PBs), unless otherwise requested. This result is shown as the Initial Result on the Excel spreadsheet and in LIMS.
- 17.4 Total Mercury in Water:

Hg / Initial Result (ng/L) = ((((Peak Area - IB) / CF_(Avg)) x D_s)– (PB_x x D_b)) / D_s

THg Final Result (ng/L) = (THg / Initial Result) x ($D_s x V_f$) / V_i

Where:

- 17.4.1 CF_(avg) = average response factor (in units/ng/L).
- 17.4.2 IB = average instrument blank peak area (in units)
- 17.4.3 V_f = final volume of sample analyzed in mL. The final volume should account for the added volume of BrCl needed for preservation. For instance, 100 mL of sample is preserved with 3% (v/v) BrCl. The final volume should be 103 mL.
- 17.4.4 V_i = initial volume of sample analyzed in mL prior to addition of BrCl.
- 17.4.5 D_s = final dilution factor of sample.
- 17.4.6 D_b = final dilution factor of corresponding blank results. All preparation blanks at the same preservation level must be analyzed at the same dilution.
- 17.4.7 PB_x= initial average (on instrument) of the preparation blanks in ng/L related to the preservation level of the samples (i.e., X=2 for a sample which is preserved at 2% BrCl), thus accounting for the extra contribution of mercury from the BrCl. Sample results are corrected for the average blank concentration of only the corresponding blanks preserved at the same BrCl preservation level. For

Revision: 2 Effective Date: 6/17/2013		Page 19 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain nformation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

example, if a sample is preserved at 2% and one PB was run at 2%, the sample is corrected using the results from that blank.

17.5 Total Mercury in Solids:

THg / Initial Result (ng/L) = ((((Peak Area - IB) / CF_(Avg)) x D_s)– (PB x D_b)) / D_s

THg Final Result (ng/g) = (THg / Initial Result) $x (D_s x V_f) / (m x 1000)$

Where:

- 17.5.1 CF_(avg) = average response factor (in units/ng/L).
- 17.5.2 IB = average instrument blank peak area (in units)
- 17.5.3 V_f = final volume of the digested sample in mL.
- 17.5.4 m = initial mass of the digested sample in g.
- 17.5.5 D_s = final dilution factor of sample.
- 17.5.6 D_b = final dilution factor of corresponding blank results. All preparation blanks must be analyzed at the same dilution.
- 17.5.7 PB = initial average (on instrument) of the preparation blanks found in the digest in ng/L. The initial mass of the digestion blanks must be the default mass specific to the preparation.

18 Statistical Information/Method Performance:

- 18.1 The Method Detection Limit (MDL) is determined according to 40 CFR Part 136 Section B. Ten replicates (9 degrees of freedom) spiked 3-10 times the expected MDL are run. The standard deviation (s) is taken from the resulting data and the MDL is calculated as follows: MDL=2.821*s. This value should not be interpreted as the method reporting limit.
- 18.2 The Practical Quantitation Limit (PQL) is the reporting limit for this method and is included as the lowest calibration point (2003 NELAC regulation 5.5.5.2.2.1.h.3). The PQL is determined by running ten samples with a concentration that will produce a recovery of 70-130 % for most analytes, but the recovery requirements are analyte dependent. The PQL is referred to as the Method Reporting Limit (MRL) in LIMS.
- 18.3 Current LODs, LOQs, MDLs and PQLs are stored at: Cuprum\General and Admin\Quality Assurance\MDLs & PQLs.

19 Quality Assurance/Quality Control:

- 19.1 A minimum of three preparation blanks and one LCS/LCSD (preferably NIST 1641d), must be analyzed per preparation batch. The upper control limit for each preparation blank is equal to the PQL.
- 19.2 Matrix Spikes: One Matrix Spike/Matrix Spike Duplicate (MS/MSD) must be performed for every 10 samples. The recovery of the MS/MSD must be between 71%-125% recovery, and the Relative Percent Difference (RPD) below 24%. If an MS/MSD is out of control, the analyst should investigate to identify the source of the failure. The MS

Revision: 2	Effective Date: 6/17/2013	Page 20 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

and MSD may be used as duplicates. Some failures may be qualified using QA Qualification Flow Charts (Appendix A).

- 19.3 Matrix Duplicates One Matrix Duplicate (MD) may be analyzed for every batch of 20 samples. Upon request, a Matrix Triplicate (MT) may be performed. The MSD may serve as the MD if necessary. The Relative Percent Difference (RPD) and the Relative Standard Deviation (RSD) of duplicate samples must be less than 24%. Some failures may be qualified using QA Qualification Flow Charts.
 - 19.3.1 For aqueous samples, analyze the parent, duplicate and triplicate at the same dilution.
- 19.4 Laboratory Control Standard (LCS) or Quality Control Sample (QCS): For every batch of samples, at least one LCS is processed and analyzed. The recovery of the LCS must be within 80-120% for the aqueous NIST 1641d. An LCS Duplicate (LCSD) should accompany the LCS.
 - 19.4.1 A Certified Reference Material (CRM) is the preferred LCS, but a Blank Spike may serve as an LCS if an appropriate CRM does not exist. The spiking level is based on client request, historical data, or a default of mid-curve. A duplicate blank spike must also be prepared as an LCSD.
- 19.5 Ongoing Precision and Recovery (OPR): An OPR must be analyzed at the beginning and end of each analytical batch, or at the end of each 12-hour shift. The recovery of the OPR must be within 77-123% to be considered in control.
- 19.6 All calibration standards must be traceable to the original standard source. The calibration curve must be established at the beginning of the analytical run. It must include at least five different concentrations, with the lowest concentration equal to the PQL. The average response factor of each calibration standard is used to calculate the sample values. The RSD of the response factors must be less than 15% of the mean or the calibration fails.
- 19.7 ICV and CCV control limit is 77-123%. The CCV is analyzed every 10 analyses, and at the end of an analytical run. CCBs are always analyzed after the CCVs.
- 19.8 Field Blanks: To be compliant with EPA 1631, clients must submit a field blank for each set of samples (samples collected from the same site at the same time, to a maximum of 10 samples).
 - 19.8.1 If no field blanks are submitted by the client, their data will be flagged with "FB-1631." "Required equipment/field/filter blank not submitted by the client. The sample has been analyzed according to 1631E, but does not meet 1631E criteria."
- 19.9 Method or Preparation Blanks (BLK): Method blanks are used to demonstrate that the analytical system is free from contamination that could otherwise compromise sample results. Method blanks are prepared and analyzed using sample containers, labware, reagents, and analytical procedures identical to those used to prepare and analyze the samples.
 - 19.9.1 BrCl method blanks per analytical batch are required.

	Revision: 2	Effective Date: 6/17/2013	Page 21 of 24
I	by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

- 19.9.2 If the result for any BrCl method blank is found to contain ≥0.50 ng/L Hg (0.25 ng/L for DOD), the system is out of control.
- 19.10 Instrument Blanks (IBL): Instrument blanks must be analyzed with each analytical batch.
 - 19.10.1 If the instrument blank is found to contain more than 0.50ng/L, the system is out of control.
 - 19.10.1.1 The mean result for all instrument blanks must be <0.25ng/L with a standard deviation of 0.10 ng/L.
- 19.11 The analytical day must close with a CCV/OPR/CCB.
- 19.12 Because the method is done in real-time, it is EFGS' position that a single noncompliant QC sample result does not automatically invalidate a data set. All data points that can be explained and rerun with a passing result can be qualified. If the source of error cannot be corrected for a QC standard that day, none of the data can be validated. In the event that the system becomes out of control during the analysis day, all results bracketed between valid QC data points shall still be considered valid (CCV, OPR, CCB, etc).
- 19.13 The Control Limits are established from EPA 1631E.

20 Corrective Action

- 20.1 The data is reviewed as in the QC section (or matrix specific QC section) for all parameters that pass specific requirements. If the data does not meet QC requirements it is qualified or submitted for reruns. Data may be qualified (based on scientific peer review) by the Group Supervisor, Project Manager, Lab Manager, or QA Officer.
- 20.2 Control Chart data is generated through LIMS to monitor the performance of the CCV, LCS, MS, and MSD. This is done by the QA department.
- 20.3 Due to the real-time nature of the CVAFS method, failures must be investigated as they happen. If the source of the problem can be identified, and corrected, the samples may be rerun. If source of problem cannot be isolated, see the Senior Analyst, Group Supervisor, or Laboratory Manager for instructions.
- 20.4 The Senior Analyst, Group Supervisor, Laboratory Manager, or QA Officer must be informed if QC fails. It is also advisable to always alert the Project Managers.

21 List of Attachments

- Table 1: QC Requirements for Total Mercury
- Table 2: Troubleshooting Flow Chart
- Appendix A: Example Standard Operating Procedure Training Record

F	Revision: 2	Effective Date: 6/17/2013	Page 22 of 24
b	y Washington State Law. Proprietary ir	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Curofins	Document Title: Determination of Total Mercury in Various Matrices by FLAES	Eurofins Document Reference: EFGS-SOP-121-R02
i i fårigtåt ärdeble är	Various Matrices by FI-AFS	

Table 1: QC Requirements for Total Mercury

QC Parameter	Acceptance Criteria
Initial Calibration Verification (ICV)	77-123% Recovery
Continuing Calibration Verification (CCV)	77-123% Recovery
Ongoing Precision and Recovery (OPR)	77-123% Recovery
Initial Calibration Blank (ICB)/ Continuing Calibration Blank (CCB)	Individually, IBL and CCB ≤0.50ng/L, but the mean of all the IBLs shall be <0.25ng/L with a standard deviation of 0.10ng/L.
Laboratory Control Standard (LCS) or Quality Control Standard (QCS)	80-120% Recovery RSD<24%
Calibration Curve RSD (Referred to as "Corr. RSD CF" in Excel spreadsheet).	RSD of Calibration Response Factor ≤15%
Lowest Calibration Point	75-125%
1% BrCl Method Blank (BLK)	Less than 0.50ng/L (0.25ng/L for DOD projects) (individually)
Matrix Duplicate (MD) and Analytical Duplicate (AD)	< 24% RPD
Matrix Spike and Matrix Spike Duplicate (MS/MSD) ; Analytical Spike (AS) and Analytical Spike Duplicate (ASD)	71-125% Recovery < 24% RPD

Revision: 2	Effective Date: 6/17/2013	Page 23 of 24
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Appendix A: Example - Standard Operating Procedure Training Record

By signing this document, I the employee, certifies to have read, understood and agreed to follow the test method and quality procedure as described in this procedure.

Reading of SOP FGS-SOP-121.02: Determination of Total Mercury in Various Matrices by FI-AFS.

SOP name and Revision number

Employee name (print)

Employee name (sign)

Supervisor name (sign)

Initial SOP Training (leave blank if not applicable)

Initial reading of method and training	Initials	Date	Supervisor
1. Read method			
2. Observe the method			
3. Detailed review of method and associated literature			
4. Supervised practice of method with trainer			
5. Unsupervised practice of the method with trainer			
6. Review of work with trainer and/or peer-review			
7. IDOC to determine precision and accuracy			
8. Determination of blanks			

Revision: 2	Effective Date: 6/17/2013	Page 24 of 24
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Date:

Date:

Document Not Controlled When Printed

🎲 eurofins	Frantier Global Solences	Document Title: Selective Sequential Extraction of Geological Samples for the Determination of Biogeochemically Relevant Inorganic Mercury Fractionation	Eurofins Document Reference: EFGS-SOP-090-R04
------------	--------------------------	--	--

Eurofins Document Reference	EFGS-SOP-090-R04	Revision	4
Effective Date	6/24/2013	Status	Final
Historical/Local Document Number	None	<u> </u>	
Local Document Level	Level 3		
Local Document Type	SOP		
Local Document Category	NA		

Prepared by	Ryan Nelson		
Reviewed and Approved by	Dave Wunderlich and Patrick Garcia-Strickland		

Revision: 4	Effective Date: 6/24/2013	Page 1 of 23
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	


hontholled

Document Not Controlled When Printed

Crontier Global Sulences	I Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
--------------------------	------------------------------------	--

Table of Contents

2 3	Reference:	
4	Purpose:	
5	Scope:	•••
6	Basic Principles:	•••
7	Reference Modifications:	
8	Definitions:	
9	Interferences:	
10	Safety Precautions and Waste Handling:	•••
11	Personnel Training and Qualifications:	•••
12	Sample Collection, Preservation, and Handling:	′
13	Apparatus and Equipment:	·· '
14	Reagents and Standards:	′
15	Procedure:	•••
16	Calculations:	′
17	Statistical Information/Method Ps for ance	1
18	Quality Assurance/Quality Control:	2
19	Corrective Action:	2
20	List of Attachments:	
	endix A: Historical tetho. Performance Data	
Λ	endix B: Standard Operating Procedure Training Record	. 1



Document Not Controlled When Printed

	Frontier Global Sciences	Samples for the Determination of Biogeochemically Relevant Inorganic Mercury Fractionation	Eurofins Document Reference: EFGS-SOP-090-R04
Approvals:		·	
Prepared by:	Signatures	on file	Date:
Approved by:			ate
Approved by:			Date:
		JIPO	

COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protected by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.

Carofins Frontier Global Sciences	Document Title: Selective Sequential Extraction of Geological Samples for the Determination of Biogeochemically Relevant Inorganic Mercury Fractionation	Eurofins Document Reference: EFGS-SOP-090-R04
-------------------------------------	--	--

1 Revision Log:

Revision: 01	Effective Date: This version		
Section	Justification	Changes Changed company name from Frontier Global Sciences to Eurofins Frontier Global Sciences	
Cover	Required		
All	Formatting per LOM SOP-LAB-201	Reformatted document to new corporate specific tions	
8	Required	Added definitions	
10.x	Required	Added safety precautions for relevant recents	
11.x	Required	Added minimum training requirement	
13.1	Required	Included software requirements	
14.x	Required	Added relevant reagents	
18.x	Update	Incorporated addendum regard og changes to batch QC	

2 Reference:

- 2.1 Bloom, N.S., Katon, J., and Turner, R.R. 1999 Can. See stive Extractions Provide useful Information about Mercury Speciation in Sedments and Soils," presentation at the American Chemical Society National Meeting, New Orkans, LA, August 22, 1999.
- 2.2 Bloom, N.S. 1999. *Method 1631: Mercury in Water by Oxidation, Purge and Trap, and Cold Vapor Atomic Fluorescence Spectrometry*, US EPA 821-R-95-027, Office of Water, Engineering and Analysis Division (4313) Mashington DC 20460.
- 2.3 Bloom, N.S. 1994. Sampling and Analysis for Mercury in Environmental Media of Importance to the Natural Cas Locustor, Gas Research Institute Topical Report #GRI-94/0033, Chicago, IL.
- 2.4 Davis, A., Bloom, N.S., and Has, S.Q. 1997. "The Environmental Geochemistry and Bioaccessability of Indiganic Mercury in Soils and Sediments--A Review." *Risk Anal* 17: 557-569.
- 2.5 Revis, N. W., Coborne, T.R., Holdsworth, G., and Hadden, C. (1990) "Mercury in Soil: A Method for Assessing Acceptable Limits," *Arch. Environ. Contam. Toxicol.*, **19**: 221-226.
- 2.6 Revise the Osborne, T.R., Holdsworth, G., and Hadden, C. (1989) "Distribution of Mercury Species in Soil from a Mercury-Contaminated Site," *Wat. Air. Soil Pollut.* **45**: 145-143.
 - Revis N. W., Osborne, T.R., Sedgely, D., and King, A. (1989) "Quantitative Method for Dutamining the Concentration of Mercury (II) Sulphide in Soils and Sediments," *Inalyst*, **114**: 823-826.
 - Willett K.L., Turner R.R., and Beauchamp J.J. 1992. "Effect of Chemical Form of Mercury on the Performance of Dosed Soils in Standard Leaching Protocols: EP and TCLP," *Haz. Waste Haz. Mat.* **9(3)**: 275-288.

Revision: 4 Effective Date: 6/24/2013		Page 4 of 23
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Conter Global Sciences	Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
------------------------	----------------------------------	--

3 Cross Reference:

Document	Document Title
SOP FGS-002	Balance Verification, Calibration and Maintenance
SOP FGS-003	Pipette Verification, Calibration and Maintenance
SOP FGS-008	Ultra Clean Aqueous Sample Collection
SOP FGS-012	Oxidation of Aqueous Samples for Total Mercury Analysis
SOP FGS-029	Ultra-Clean Sample Filtration
SOP FGS-045	Preparation of Sediments by Acidic KBr Extraction Into Methy and the Property Determination of Methyl Mercury
SOP FGS-094, App F	Standard Operating Procedure Training Record
SOP FGS-099	Waste Disposal Procedure for Client Sample Waste
SOP FGS-111	HF/HNO3/HCI Bomb Digestion of Sediments, Soil, Rock and Bayer Process
	Solids and Slurries for Mercury, followed by Repeated HIO ₃ Evaporation
SOP FGS-126	Health and Safety Evaluation and Auditing
SOP FGS-137	Mercury in Water by Oxidation, Purge and rap C AFS (EPA Method 1631E)
SOP FGS-155	Calibration of Volumetric Dispense

4 Purpose:

4.1 The purpose of this standard operating blocedure is to describe the selective extraction procedure used for geological sampler (some sediments, ores, mine tailings, etc.) using hydrofluoric, nitric, and hydrochloric ac is (H) HNO₃/HCI) for mercury analysis.

5 Scope:

- 5.1 This method is for the senertive excertion of geological samples (soils, sediments, ores, mine tailings, etc.), with the total of determining the biogeochemically relevant associations of inorganic tig within, and leachability of inorganic Hg from, the solid phase.
- 5.2 When applied exactly as written, this method defines the following extraction fractions (F-0 through F-s and F-S). The representativeness of each fraction varies from sample to sample dependence upon ancillary parameters such as TOC, soil pH, co-leached substance (i.e., Cl⁻, SO₄⁼, etc.) and actual solid phase speciation of the analyte. Additional ancillary chemistry measurements or kinetic studies may be required to fully integret the extraction pattern for each sample.

volations lemental Mercury (Hg°) This test is performed by placing sample in a teflon bomb vessel with a inlet and outlet and letting nitrogen purge the system collecting all estimates on a FSTM trap. The trap is then digested using EFGS-009. The mass of the ample is used as the initial mass in the LIMS database.

F-1 Water Soluble Mercury. Mercury extracted in this test is useful in assessing the potential leaching of soils by rain or groundwater, and is a reasonably good (±50%) predictor of the performance of the sample on an official TCLP or EP-toxicity leaching test. At high solid phase concentrations (100s-1000s of μ g/g), the water soluble salts such as HgCl₂, Hg(NO₃)₂, etc., will appear largely in this fraction, but as total Hg concentrations decrease, the percentage found in this fraction decreases dramatically,

Revision: 4	Effective Date: 6/24/2013	Page 5 of 23
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

🔅 eurofins Frontier Global Solencer		Eurofins Document Reference: EFGS-SOP-090-R04
--	--	--

due to adsorption of the free Hg on the soil particles. This fraction is extremely dependent upon the co-leached soil components such as CI-, I-, DOC, and pH Increases in any of these co-leached Hg complexing agents will generally greatly increase the solubility of water-soluble mercury compounds. High values for the parameter (greater than either 1 μ g/g or 5% of the total Hg) may warrant further investigations into the kinetics of leaching, such as column percolation studies.

F-2 pH 2 Soluble Mercury. Mercury extracted in this fraction is a surrelate what ٩Q might be extracted by the human stomach upon ingestion, or of leach abin k under the conditions of acid mine drainage. In cases where the sample contains bigh TOC. this fraction is usually the lowest in Hg, because of readsorption of Hg U) **T** coagulated humic matter at this pH. High concentrations of pH 2 leacha le H might warrant additional testing that more accurately models the human directive ct in terms of pH regime and contact time, or acid mine drainage conditions eser at the contaminated site.

F-3 1N KOH Extractable Mercury. Under the liti as of his extraction, most of the Hg associated with humic organic matter an ears to be solubilized, while none of the HgS is co-solubilized. 1N KOH soluble Hg dominates harine and freshwater sediments. as well as the soil humus layer. Not only does of the CH₃Hg in the sample also nos leach out in this fraction, but also this faction has been found to strongly correlate with in situ CH₃Hg concentrations, and the potential methylatability of the sample (Ref 10.1). The contribution of the CH₃Hg conter to the total Hg extracted is usually small, but if high concentrations of methyl Hg (grotection 1% of total) are measured in the samples (FGS-045), a correction might be appripriate. The most appropriate way to correct this Sct data is to also measure 🗬 d. on the 1N KOH extract, and subtract it from the , si measured total Hg value on he some extract.

F-4 12N HNO₃ Soluble hereury. This fraction serves largely to separate out all remaining non-HgS is that the final measured fraction may safely be taken to represent the HgS content of the sample. In cases where F-0 detected a saturation level of Hg⁰, and the fraction F-1 through F-3 are small by comparison to F-4, the latter fraction may be interpreted as encesenting essentially the total Hg⁰ content of the sample. At lower Hg concentrations in natural samples, much of the non-humic bound Hg(II) is found in this fraction, because it is strongly adsorbed to the particle surfaces, and so not leact able by the weak extractants F-1 and F-2.

Aug Regia Soluble Mercury (Residue). If the previous steps of the extraction scheme have been carried out accurately, this fraction consists of the cinnabar and neto cinnabar (HgS) content of the samples. Also included in this fraction, if present in the sample) would be HgSe, and amalgams of Hg with noble metals such as gold and platinum. Hg is leached from the surface of these amalgams, but the bulk concentrations require the dissolution of the noble metal particles, which is accomplished readily by aqua regia.

F-6 Mineral-Bound Mercury. For hard mineral samples, such as bauxite, the F5 (aqua regia) step is not vigorous enough to release all mercury from the crystal lattice. In

Revision: 4	Effective Date: 6/24/2013	Page 6 of 23
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

💸 eurofins Frantier Global Sciences		Eurofins Document Reference: EFGS-SOP-090-R04
--	--	--

samples of this type, a HF/HNO₃/HCI Bomb digest is necessary to recover all the mercury in the sample (see SOP FGS-111).

F-S Total Mercury by the Sum of Species. The sum of all of the fractions, F-0 through F-6 is the total Hg in the sample. It is *inadvisable* to try to measure total Hg (Fe on a separate aliquot of the sample, unless this is being done only for the pu assessing sample homogeneity. For real-world samples, heterogeneity is of that direct comparison of selective extraction on one aliquot and total Ho n a parate aliquot will produce misleading conclusions (such as that there is vissing" Hg а species, in cases where the total is much greater than the sum of specie Forvery fine, homogeneous samples such as CRMs, F-S should compare to dependently e measured total to within ± 20%.

- 5.3 This leaching is optimized for and only applicable to H analysis. Other leaching procedures are necessary to obtain reliable and biogeochemically neaningful results for other trace metals.
- 5.4 This method is a protocol for the extraction cary. All recovered aqueous fractions are then analyzed by an appropriate Hg quartification technique. Because of its low detection limits and high tolerance for complementives, EPA Method 1631 (ref 10.2), with preparation described in Frontier COP FGS 94 (Total Hg in aqueous media) and analysis in EFGS-137 (Total Hg analysis) are recommended, as indicated in the text below.

6 Basic Principles:

- 6.1 Prior to digestion, the sample should be sieved through a 2-mm plastic mesh screen to remove large chunks, and is a aloin homogenization. Inherently fine-grained samples do not need to be sieved prior to extraction.
- 6.2 Fresh samples should be exacted in a form as close to their natural state as possible. Under no circumstance, should samples be dried or pulverized prior to extraction, as this may lead a dragatic changes in leachability.
- 6.3 This methodizinvolues the sequential extraction of the *same sample aliquot* through a sequence of different extractants of increasing chemical strength. Recovery in a wide range of geological materials, as the sum of the selective extraction fractions was found to typically be 100 ± 15% (Table 2).
- 6.4 Its proclure contains many steps, and must be conducted on four consecutive days (no more, no less). Selective extractions of this type must be started on Monday or uesday, unless the analyst is planning to continue work on the weekend. Please read this SOP over several times, and plan the extraction timing, use of an analyzer for Hg⁰ on the second day, and quantity of filters, bottles, etc. carefully before beginning. Be sure to make a big enough volume of extraction reagents for all samples in a set (every 20 samples plus 8 QC samples requires 28 times 80 mL, or at least 2,300 mL of each extractant).

7 Reference Modifications:

7.1 No significant modifications were made to this method.

Revision: 4	Effective Date: 6/24/2013	Page 7 of 23
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	n proprietary information and are protected and must not be used or appropriated to

😵 eurofins Frontier Glabel Sole	Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
--	----------------------------------	--

8 Definitions:

- 8.1 Certified Reference Material (CRM) a standard of known composition that is certificately a recognized authority and representing a sample matrix. It is used to verify the accuracy of a method.
- 8.2 Laboratory Control Sample (LCS) and Laboratory Control Sample Duplicate (LCSP), is a sample containing known concentrations of the analytes of interest that is take, through the entire preparation and analysis process in the same manner as an samples to monitor complete method performance. A Certified Reference Material (CRM) is preferred as the LCS, but a blank spiked sample also meets the requirement.
- 8.3 Limit of Detection (LOD) equal to MDL and verified on an argual basis by spiking within three times the established LOD for Hg and within four times to established LOD for all other applicable metals showing a positive result on the instrument.
- 8.4 Limit of Quantitation (LOQ) equal to PQL and verified one an annual basis by spiking within 2 times the established LOQ for Hg and 3 days in all, ther applicable analytes.
- 8.5 LIMS Laboratory Information Management system.
- 8.6 Matrix Duplicate (MD) a representative sample is relected and digested in the same manner. This QC sample will indicate sample homogeneity on the analytes of interest.
- 8.7 Matrix Spike (MS) and Matrix Spike Duplicate (MSD) a representative sample is selected and spiked with a secondary source at *two* to five times the ambient concentration or at *two* to five times the MRL, whichever is greater. These QC samples will indicate sample matrix effects on the analytes of interest.
- 8.8 May: This action, activity of procedure is optional.
- 8.9 May Not: This action, activity of procedure is prohibited.
- 8.10 Method Detection, rime (MPL) the limit derived from an exercise as described in 40 CFR, Part 135, App andix B. The exercise produces a defined value that is the minimum concentration that can be measured and reported with 99% confidence that the analyte concentration of grouter than zero from a given matrix.
- 8.11 Preparation Blank (BLK) Method blanks consist of the same reagents used to digest the tampas, in the same volume or proportion, and are carried through the complete sample proparation and analytical procedure. Teflon boiling chips are added to the preparation blanks.
 - that This action, activity or procedure is required.
 - 3 Should: This action, activity or procedure is suggested, but is not required.

nterferences:

1 As an operationally defined analytical method, sequential selective extractions generate data which may range from somewhat to extremely ambiguous, depending upon the nature of the matrix, and the concentrations and species of the mercury compounds present. In general, this method provides an excellent resolution between "HgS" and

Revision: 4	Effective Date: 6/24/2013	Page 8 of 23
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protected by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.		

🏟 eurofins Fronti	ntier Global Sulencez	Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
---------------------	-----------------------	----------------------------------	--

"non-HgS," as well as a good assay for organically associated inorganic Hg, which has been found to be strongly linked to potential for methylation.

- 9.2 Samples may contain significant free elemental Hg, if indicated by one of the follow (a) the presence of visible balls of liquid Hg, (b) saturation of Hg⁰ in the water ex step of this method ([Hg⁰] >40 µg/L at room temperature), or (c) saturation of th headspace above the sample in a closed container (i.e., [Hg⁰] > 20 ng temperature). In these cases, the interpretation of all weak leachate fra confounded by the fact that significant Hg⁰ can be dissolved into each ique Lus fraction (approximately 40-60 µg/L of extractant, or 5.0 ppm by weight under the onditions used in these extractions). However, these values will be truly reflective of the potential leachability of total Hg from such samples, and may still be successfully interpreted that way. If the Hg found in the 12 N HNO3 extract of such samples is more greater than that found in the previous extractions, then the 12 N HNO3 fraction can be relatively comfortably assigned to be elemental Hg. Because of the the backward filtration, most of the Hg⁰ is lost from extracts F-1 through F-3 prior o oxidation for total Hg analysis. Thus, in samples containing liquid Hg⁰, the ta J+. will be underrepresented by al Hy twice the saturation concentration of Hg^o in the lost during filtration from F-2 and F-3), calculated to the equivalent solid phase a con entration (about $5\mu g/g$ under the conditions of this method). In most cases where here liquid Hg⁰ is present, this will be a trivial fraction of the total, and so can be ored.
- 9.3 Successful resolution of HgS in the last extraction step is critically dependent upon the absence of chloride in the sample during the 12 N HNO₃ step. If chloride residue were in the sediment at this time, it would be converted to free halogens, which quickly and easily dissolve HgS, and so void the electivity of the method. As ^described, the various dilute extraction steps prior to the 12 N HNO₃ step are sufficient even to rinse out the chloride from marine spannets.
 - 9.3.1 However, if an abreviated extraction involving only "non-HgS" (12N \square NO₃) and "HgS" (topia tegia) were being employed, it is critical that any chloride possibly present in the samples be rinsed out with at least two consecutive water rinses, prior to be addition of the 12N HNO₃. The water rinses and 12 N HNO₃ rinses can then be combined to minimiz_e analytical steps. If it is known that the sample does not contain chloride (i.e., <100ppm solids basis₁, then this step may be omitted.
- 9.4 Selective xtractions must be performed sequentially on the same sample aliquot, exactly in the sequence described, and for the time periods described to produce meaningful results.

Although empirical evidence shows that final aqua regia step effectively extracts all remaining mercury from virtually all sample types, there remains a possibility that Hg contained in large silicate mineral grains will not be fully extracted by this technique. If this becomes a question, the residue from fraction F-5 can be completely solubilized using hydrofluoric acid plus aqua regia in Teflon bombs (SOP FGS-111).

Revision: 4	Effective Date: 6/24/2013	Page 9 of 23
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are prote by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriate benefit any party without prior written consent from Eurofins Frontier Global Sciences.		

🔅 eurofins Frontier Global Sciences	Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
--	----------------------------------	--

10 Safety Precautions and Waste Handling:

- 10.1 Personnel will don appropriate laboratory attire according to the Chemical Hygiene Pla This includes, but is not limited to, laboratory coat, safety goggles, and nitrile glob under clean gloves.
- 10.2 The toxicity or carcinogenicity of reagents used in this method has not been fully established. Each chemical should be regarded as a potential health natare and exposure to these compounds should be as low as reasonably achievable. Chemists should refer to the MSDS (Material Safety Data Sheets) for each chemical they are working with.
- 10.3 Hydrofluoric Acid (HF): HF is used for many purposes including mineral digestion, surface cleaning, etching, and biological staining. HF's inique poperties make it significantly more hazardous than many of the other acids used on site.
 - 10.3.1 Always wear HF apron, face shield, tyvex sleeves and puble gloves when working with HF.
 - 10.3.2 Check PPE after you have finished woring for baken PPE.
 - 10.3.3 For spills, briefly spray with Boric acid and then neutralize. Make sure the acids have fully reacted before disposing of the neuralized waste.
 - 10.3.4 If HF is spilled on you, rinse for at east 15 minutes and then apply Calcium Gluconate
 - 10.3.5 Ventilation:



10.3.5.1 HF should be used with adequate ventilation to minimize inhalation of vapor. Concentration greater than 5% should always be handled inside a properly functioning chemical fume hood. The chemical fume hood needs to have a current inspection sticker (see FGS-126). Notify EH&S if there are any issues with the good.

10.3.6 Eye Protection:

10.3.6.1 Iways use chemical splash goggles together with a face shield when hardling concentrated HF. Due to HF's highly corrosive nature, safety glasses with side shields do not provide adequate eye protection.

Body Protection:

1 Wear laboratory coat with a chemical splash apron made out of natural rubber, neoprene, or viton. Never wear short pants or open-toed shoes when handling HF or other corrosive chemicals

10.3.8 Gloves:

10.3.8.1 Typically, medium or heavyweight viton, nitrile, or natural rubber gloves are worn when working with HF. Always consult the manufacturer's glove selection guide when selecting a glove for HF. If you have any questions

Revision: 4	Effective Date: 6/24/2013	Page 10 of 23
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain by Washington State Law. Proprietary information must be maintained with the strictest of confidence benefit any party without prior written consent from Eurofins Frontier Global Sciences.		

Curofins Frontier Global Sciences	Document Title: Selective Sequential Extraction of Geological Samples for the Determination of Biogeochemically Relevant Inorganic Mercury Fractionation	Eurofins Document Reference: EFGS-SOP-090-R04
-------------------------------------	--	--

about which glove to choose, contact EH&S. A second pair of nitrile exam gloves should be worn under the gloves for protection against leaks. Gloves that have not been contaminated with HF may be disposed of in the common trash. If gloves become contaminated with HF, remove them immediately thoroughly wash your hands, and check your hands for any sign of contamination. Contact the EH&S Officer if your skin has been expected b any direct HF.

- 10.4 Bromine Monochloride: Use particular caution when preparing and using BrCT, as it releases extremely irritating, corrosive fumes similar in effect to free blorine. Always handle this reagent in an approved fume hood.
- 10.5 Nitric acid (HNO₃): Corrosive. Strong oxidizer. Contact with other nate ial may cause a fire. Causes eye and skin burns. May cause severe respiratory tract irritation with possible burns. May cause severe digestive tract irritation with possible burns. For more information see MSDS. <u>Always</u> work in fume hood vearin, safety goggles, latex and clean gloves, apron and face shield while using this chamical.
- 10.6 Hydrochloric acid: Very hazardous in case of skin connect (corrosive, irritant, permeator), of eye contact (irritant, corrosive), of ingestion Slight hazardous in case of inhalation (lung sensitizer). Non-corrosive for lungs. Liquid or spray mist may produce tissue damage particularly on mucous membrases of eyes, mouth and respiratory tract. Skin contact may produce burns. Inhalation of the spray mist may produce severe irritation of respiratory tract, characterized by coupling, choking, or shortness of breath. Severe over-exposure can result in death. Information of the eye is characterized by redness, watering, and itching. Skin affanciation is characterized by itching, scaling, reddening, or, occasionally, blistering. For more information see MSDS. <u>Always</u> work in fume hood wearing safety googles, latex and clean gloves, apron and face shield while using this chemical.
- 10.7 See Eurofins Frontier Global Sciences Chemical Hygiene Plan (CHP) for general information recording employee safety, waste management, and pollution prevention.
- 10.8 Pollution proceedings information can be found in the current Eurofins Frontier Global Sciences them cal Hygiene Plan (CHP), which details and tracks various waste streams and disposit procedures.
- 10.9 All I boratory waste is accumulated, managed, and disposed of in accordance with all control state, and local laws and regulations. Any waste generated by this procedure should be disposed of according to SOP FGS-099 "Waste Disposal Procedure for Client ample Waste," which provides instruction on dealing with laboratory and client waste.

essonnel Training and Qualifications:

A lab technician/analyst must perform an initial demonstration of capability (IDOC) that includes four replicates of a secondary source before being qualified to prepare samples without supervision. Continuing DOC will be maintained and monitored via performance on CRMs and other QC samples, as well as obtaining acceptable results on proficiency testing exercises.

Revision: 4	Effective Date: 6/24/2013	Page 11 of 23
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

Reurofins

- 11.2 The analyst/laboratory technician must have read this SOP and other relevant SOPs and have the training documented on the applicable form(s). The analyst may be questioned on SOP by supervisor(s) and/or trainers.
- 11.3 Training is documented by the employee and supervisor, and is kept on file in the Office. The employee must read, understand, and by signing the training docume agree to perform the procedures as stated in all Standard Operating Procedures 100 related to this method.
- 11.4 Reading of the SOP must be documented on the correct form so h as "Standard Operating Procedure Training Record," Appendix F in FGS-094, the last page of this SOP, Appendix B "Standard Operating Procedure Training Record," or a similar document.
- 11.5 All employees must also, on a yearly basis, read the Quality Janua (QM), and complete the yearly Ethics training.
- 11.6 All training documents including IDOCs, CDOC SCP reading, Initial QA orientation, and Ethics training are stored by QA in the employee straining file for ten years after the employee is no longer working for Eurofins Frontier Global Sciences.
- 11.7 Chemical Safety Training, Compressed Gas Training, Chemical Hygiene Plan documentation, and Shipping of Hazardrus goods, are stored by the Health and Safety Officer for ten years after the employer is in longer working for Eurofins Frontier Global Sciences

12 Sample Collection, Preservation, and Handling:

- 12.1 Samples should be collected ato unde mouth glass or Teflon containers using good laboratory practice. Jars should be filled approximately 80% full of soil, mine tailings, etc. For sediments and other poentially anoxic samples, jars should be completely filled.
- 12.2 Samples should be stored cool (1-4 °C) and in the dark, for up to five days prior to processing in the aboratory. If samples must be held for more than five days, they should be frozen at less than -15 °C until processing. In this case, be sure that all samples, including rediments are packed into jars only 80% full, to avoid breakage of the jars during filezing! If the same samples are to be analyzed for methyl mercury or dimetry menury, these subsamples must be analyzed immediately (within one day), or a subaliquet (5-50 grams) be placed into a second (smaller) jar, and immediately frozen and salvais.
 - f sar ples are not naturally fine grained (<2 mm, i.e., sand, silt and clay), they should be querkly sieved through a 2-mm mesh screen, collected into a receiving tray, and then placed into a new wide mouth jar for storage until extraction. Quickly and thoroughly homogenize the sieved material by stirring or shaking prior to storage of the sample. The following cautions should be observed:
 - 12.3.1 If the samples are known or suspected to contain free elemental mercury, they should be sieved as rapidly as possible, outdoors (ideally in the field) or in an exhaust hood, and the sieve should not be re-used without thorough cleaning

Revision: 4	Effective Date: 6/24/2013	Page 12 of 23	
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protected by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.			

Scurofins Frontier Global Sciences	Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
--------------------------------------	----------------------------------	--

between samples. Low cost large mesh stainless steel kitchen sieves are ideal disposable items for this purpose.

- 12.3.2 It may be desirable to determine the total sample mass before sieving, as well is the mass of fines and/or coarse material recovered. The client should be concluded before sieving if this is unclear. In addition, in some cases, the coarse material may need to be saved for possible future analysis. Unless otherwise stated to be save or analyze the coarse material, however.
- 12.4 Under no circumstances should the raw sample or sieved material be vied, yet sieved, or stored in open air or a jar with a large headspace to sample rate (>0.3). Such conditions will radically change some of the speciation and observed leachability.
- 12.5 If sample results are to be reported on a dry weight basis a separate aliquot of the sieved sample should be taken for drying.

13 Apparatus and Equipment:

- 13.1 LIMS Element, version 5.85 or higher; Computer Windows XP, 7 or 8.
- 13.2 <u>Extraction Vessels:</u> off-the-shelf trace clean 10-mL birosilicate glass vials with Tefloncoated silicone rubber lined caps (I-Chem[™] 200 series or equivalent).
- 13.3 <u>Sample jars:</u> off-the-shelf trace metal clean 125-mL glass jars with Teflon-lined caps (I-Chem[™] 200-series or equivalent).
- 13.4 <u>Dilution bottles:</u> off-the-shelf trace meta-alean 125-mL narrow mouth glass bottles with Teflon-lined caps (I-Chem T 200 scale) or equivalent). NOTE: Four 125-mL bottles are needed for each sample and stand that is extracted.
- 13.5 <u>Pipettors:</u> concentrated HChand HNO₃ are conveniently dispensed separately from allglass or glass and Terion totto-top repetitive pipettors (0-10-mL size; Re-Pipette[™] or equivalent). Pipetters are to be calibrated weekly according to SOP FGS-003 and FGS-155
- 13.6 <u>Analytical Balance</u>: any lab analytical balance capable of weighing to the nearest milligram, and aring the full mass of the extraction vials (about 100 g when filled with 12 N HNO₃). The analytical balances are verified for accuracy on a daily basis according to FGS-200 "Balance Verification, Calibration and Maintenance."
- 13.7 2.0 km sieve: a sieve unit, 10-30 cm diameter by 5-15 cm deep made of plastic such as nylon supplyethylene, or of a non-rusting grade of stainless steel.

lece ving tray: borosilicate glass tray or dish larger in diameter than the sieve.

- **Sial shaking rack:** a divided tray with secure top capable of holding 10-100 extraction vials during shaking. A suitable rack for this purpose is the divided cardboard box in which the I-Chem vials are supplied.
- 13.10 <u>Low speed centrifuge:</u> any centrifuge with rotor head capable of holding 40-mL l-Chem[™] vials, and spinning at least 3,000 RPM. These tubes fit conveniently into a rotor designed for 35mL Oak Ridge type or 50mL conical bottom tubes.

Revision: 4	Effective Date: 6/24/2013	Page 13 of 23
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contair formation must be maintained with the strictest of confidence a ent from Eurofins Frontier Global Sciences.	

🏶 eurofins Frontier Global Selen		Eurofins Document Reference: EFGS-SOP-090-R04
---	--	--

- 13.10.1 HOWEVER: the tube cradle at the bottom of each rotor well must be modified to accommodate the flat-bottomed glass vials. This can be done by filling the conical or hemispherical indentation with silicone rubber caulk, and allowing to harden br at least 24 hours. Failure to take this step will result in shattering of the glass vial under the gravity of the centrifuge!
- 13.11 <u>Disposable Nitrocellulose Filtration Units:</u> disposable 0.2-μ or 0.4-μ pore the 10-μL polystyrene units containing a non-removable 47-mm diameter nitrocellulate membrane filter (Nalgene, or equivalent). Four filtration units are needed for each sample extracted. Because of the relatively large solids/extractant ratios, it is not critical whether 0.2-μ or 0.4-μ units are employed, but good laboratory practice dictates that has a given project, all of the filter units be of the same pore size, and from the same natch. These filters do not need to be acid cleaned before use.
- 13.12 <u>Vacuum pump</u>: standard laboratory vacuum pump or water aspirator capable of generating at least 0.5 atm vacuum, for the purpose of facuum filtration.

14 Reagents and Standards:

- 14.1 <u>Reagent Water:</u> 18 MΩ ultra-pure deionized water stating from a pre-purified (distilled, R.O., etc.) source. As a final mercury and organic emoval step, the activated carbon cartridge on the 18-MΩ system is placed retween the final ion exchange bed and the 0.2 µm filter.
- 14.2 <u>Oxygen-Free Reagent Water:</u> using a comprised tube, sparge a full 2.5-L glass bottle of reagent water overnight at 500 ml/min with argon or nitrogen. Quickly recap the bottle, and use within 24 your of paramg.
- 14.3 Potassium Bromide (KBr), neat: this reagent is pre-certified by the vendor to be low in mercury and is entered into the MS with a five year expiration date.
- 14.4 Potassium Bromate (KtrO₂) neat: this reagent is pre-certified by the vendor to be low in mercury and k entryed into the LIMS with a five year expiration date.
- 14.5 0.2N Bromine Motochoride:
 - 14.5.1 37.5 g of Br is added to a 2.5 L bottle of concentrated HCI (pre-analyzed and how ing/L Hg). The bottle is inverted in a fume hood to mix the acid and KBr. The polution sits overnight, allowing the KBr to dissolve.
 - g of KBrO3 (certified to be low in Hg) is slowly added to the acid. As the KBrO3 is added, the solution should go from yellow to red to orange.

CAUTION: This process generates copious quantities of free halogens (Cl₂, Br₂, BrCl) which are released from the bottle. Add the KBrO₃ SLOWLY in a well operating fume hood.

- 14.5.3 Loosely cap the bottle and allow to sit for 30 minutes (in a fume hood) before tightening. Once tightly capped, invert bottle to make sure all of the solids go into solution.
- 14.5.4 This reagent shall be entered into the LIMS with a six month expiration date.

Revision: 4	Effective Date: 6/24/2013	Page 14 of 23
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must no benefit any party without prior written consent from Eurofins Frontier Global Sciences.		proprietary information and are protected and must not be used or appropriated to

non eurofins	ntier Global Sciences	Document Title: Selective Sequential Extraction of Geological Samples for the Determination of Biogeochemically Relevant Inorganic Mercury Fractionation	Eurofins Document Reference: EFGS-SOP-090-R04
--------------	-----------------------	--	--

- 14.6 <u>Nitric Acid (HNO₃)</u>: concentrated reagent grade (16.0N) HNO₃, known to be low in Hg and/or other trace metals of interest. This solution should contain less than 0.01ng/mL of Hg to be suitable for selective extraction work. This reagent shall be entered into LWS and the expiration date is set to the same as the manufacturer's expiration date.
- 14.7 <u>Hydrochloric Acid (HCI):</u> concentrated reagent grade (12.2N) HCI, known to be I w in Fig and/or other trace metals of interest. This solution should contain less than 0.91n, mL of Hg to be suitable for selective extraction work. This reagent shall be entered into LIMS and the expiration date is set to the same as the manufacturer's expiration date.
- 14.8 <u>Hydrofluoric Acid (HF) (only if F6 is employed):</u> concentrated (48-50), weight basis) low trace-metals grade hydrofluoric acid (previously analyzed). This magen shall be entered into LIMS and the expiration date is set to the same as the manufacturer's expiration date.
- 14.9 <u>Glacial Acetic Acid</u>: concentrated low trace-metals grade (persously analyzed). This reagent shall be entered into LIMS and the expiration date is set to the same as the manufacturer's expiration date.
- 14.10 <u>12N Nitric Acid (HNO₃)</u>: dilute 1.5 ± 0.1 L on soncent ated (16.0N) HNO₃ to 2.0 L with reagent water in a 2.5-L acid bottle. This solution should contain less than 0.1ng/mL of Hg to be suitable for selective extraction work. Enter reagent into LIMS for traceability.
- 14.11 <u>1N KOH Solution</u>: dissolve 130 ± 10 grams of reagent grade KOH pellets (85% KOH assay) in 1 L of deionized water in a 2.5 L and bottle. Dilute to 2.0 L with reagent water, and allow cooling thoroughly be ore tightening cap. This solution should contain less than 0.1ng/mL of Hg to be suitable or elective extraction work. Enter reagent into LIMS for traceability.
- 14.12 <u>pH 2 Extraction Solution</u> Hun 2.0 mL of concentrated HCI and 12 mL of concentrated reagent grade glacial acetic acid to 2.0 L with reagent water in an empty reagent acid bottle. This solution should contain less than 0.01ng/mL of Hg to be suitable for selective extraction work. Entry reagent into LIMS for traceability.
- 14.13 Dry suspension of sinnabar in inert substrate (silica, boron nitride): prepare 100 grams of an approx matex 45 µg/g Hg suspension of powdered red HgS in silica powder. Shake vigorously 🗴 30 minutes in a half full jar containing two small marbles as mixing aids. the mixture repeatedly four times to further homogenize, and store in a wide The siew Accurately quantify the total Hg concentration of three replicates of this moi iar, material using aqua regia digestion and CVAFS (FGS-137). If the RSD of the three eplicates is less than or equal to 10%, then use the mean as the accepted value. If the is greater than 10%, then re-homogenize the sample 5 times, and repeat the iplicate analysis until homogeneity is verified. This sample serves as a verification check for the method selectivity for HgS.
- 4.14 <u>Dry suspension of HgCl₂ in inert substrate (silica, boron nitride)</u>: prepare 100 grams of an approximately 25μg/g Hg suspension of HgCl₂ in silica powder. Shake vigorously for 30 minutes in a half full jar containing two small marbles as mixing aids. Then sieve the mixture repeatedly four times to further homogenize, and store in a wide mouth jar. Accurately quantify the total Hg concentration of three replicates of this material using

	Revision: 4	Effective Date: 6/24/2013	Page 15 of 23
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sci by Washington State Law. Proprietary information must be benefit any party without prior written consent from Eurofins F		s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	n proprietary information and are protected and must not be used or appropriated to

Sciences	Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
----------	----------------------------------	--

aqua regia digestion and CVAFS (FGS-137). If the RSD of the three replicates is less than or equal to 10%, then use the mean as the accepted value. If the RSD is greater than 10%, then re-homogenize the sample 5 times, and repeat the triplicate analysis until homogeneity is verified. This sample serves as a behavior comparison check for water-soluble mercury species under the conditions of this extraction.

14.15 Dry suspension of HgO in inert substrate (silica, boron nitride) - prepare 100 approximately 1.4µg/g Hg suspension of HgO in silica powder. Shake vice rous for 30 minutes in a half full jar containing two small marbles as mixing aids Thus sieve the mixture repeatedly four times to further homogenize, and store in vide mouth jar. a Accurately quantify the total Hq concentration of three replicates of is Naterial using aqua regia digestion and CVAFS (FGS-137). If the RSD of the ree splicates is less than or equal to 10%, then use the mean as the accepted failue. RSD is greater than 10%, then re-homogenize the sample 5 times, and repeat the triplicate analysis until homogeneity is verified. This sample serves as a omparison check for a (FI) VIG. water-soluble mercury species under the conditions of raction. his ex

15 Procedure:

- 15.1 If F-0 is needed weigh out 2.5 g of the homogenized cample directly into a 60mL Teflon bomb vessel. Record the mass of each sample. The apparatus used for this fraction is the Teflon bomb vessel with an inlet appropriate cap, a FSTM trap with a KCL scrubber and nitrogen gas line.
 - 15.1.1 Close the vessels and setap the upparatus after each sample is weighed to minimize the loss of volatile marchry.
 - 15.1.2 Purge the system for thours at 400-500 mL/min.
 - 15.1.3 The FSTM trap is now the F0 fraction and is digested according to EFGS-009.
 - 15.1.4 The solid sample in the vessel is to be used for the weigh out in the following step.
- 15.2 Weigh approximates 0.4 g of the homogenized sample (within 1 mg) directly into a 40 mL extraction via. The sample masses and sample IDs must be recorded in a bound, paginated logb ok and on the vial labels at the time of weighing.
- 15.3 Fill each via completely to the base of the neck with mercury-free reagent water, cap the vial ightly and shake vigorously until all solids are clearly suspended in the water.
- 15.4 For explorements batch of samples (8-20), three method blanks, a pure HgS in silica sample, a pure HgCl₂ in silica sample, a sample duplicate, and one sample of HgO (or the designated CRM) must be co-extracted. Matrix spikes are not appropriate for selective extractions, so no MS/MSD is extracted.

When all samples in the batch have been weighed and filled with reagent water, place in the shaker box, and shake by slow (5-10 rpm) end-over-end rotation for a total elapsed extraction time of 16 \pm 2 hours. Alternatively, in the absence of a rotator, shake the samples very vigorously for 1-2 minutes every half-hour until evening, and then every hour the following morning for a total elapsed extraction time of 16 \pm 2 hours.

Revision: 4	Effective Date: 6/24/2013	Page 16 of 23
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

्रि eurofins _{Fn}	'rentier Global Sciences	Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04	
------------------------------	--------------------------	----------------------------------	--	--

- 15.6 Use a 5 or 10 mL pipette to transfer 90% of the solution into a labeled 125mL bottle. Take great care in not grabbing any of the solid sample. Pipette directly into a syringe and filter (0.2 to 0.4μm) the solution into a 125 mL bottle. Add 40 more mL of solution to sample and invert 10 times. Centrifuge again and transfer as much of the solution a possible (at least 90%) without grabbing any of the solid sample again into a syringe then 125mL bottle.
- 15.7 To each extract and blank, add 1.25 mL of concentrated BrCl solution, swill to wix, and bring up to volume of 125mL. Use an example bottle at 125mL for reference
- 15.8 Repeat steps 15.6-15.7, adding the rinse extract to the BrCl oxidized bitilarreagent water extract in the 125 mL bottles. For each sample, use the same filter as was used for the initial reagent water extract to filter the second reagent water (cose, ex ract. Dilute each bottle to the base of the neck with reagent water, shake thoroughly, and set aside at least one hour until analysis.
- 15.9 To each original sample pellet, fill the vial to the 40 rLL mak with the pH 2 extracting solution, and shake vigorously to resuspend the second to after vigorous shaking, the sediment pellet does not break up, use a third disposible glass rod (or Pasteur pipette) to dislodge the compacted sediment.
- 15.10 When all samples in the batch have bee ofilled with pH 2 extracting solution, place in the shaker box, and shake by slow (5-10 rpm) end-over-end rotation for a total elapsed extraction time of 16 ± 2 hours. Alternatively, in the absence of a rotator, shake the samples very vigorously for 1-2 matter overy half-hour until evening and then every hour the following morning for a total elapsed extraction time of 16 ± 2 hours.
- 15.11 After the extraction period, pentifuge the vials at 3000 RPM for 15 minutes.
- 15.12 Use a 5 or 10 mL pipers to cansfer 90% of the solution into a labeled 125mL bottle. Take great care in no grabbing any of the solid sample. Pipette directly into a syringe and filter (0.2 to 0 mum) the folution into a 125 mL bottle. Add 40 more mL of solution to sample and input 10 times. Centrifuge again and transfer as much of the solution as possible (at lease 90%) without grabbing any of the solid sample again into a syringe then 125m2 bottle.
- 15.13 To each extract and blank, add 1.25 mL of concentrated BrCl solution, swirl to mix, and bring up to volume of 125mL. Use an example bottle at 125mL for reference.
- 15.14 Ropert steps 15.12-15.13, adding the filtered rinse extract to the BrCl oxidized initial pH 2 extract in the 125 mL bottles. For each sample, use the same filter as was used for the nitial pH 2 extract to filter the second pH 2 (rinse) extract. Dilute each bottle to the base of the neck with reagent water, shake thoroughly, and set aside at least one hour until analysis.
- 5.15 To each original sample pellet, fill the vial to the 40 mL mark with the 1N KOH extracting solution, and shake vigorously to resuspend the sediment. If after vigorous shaking, the sediment pellet does not break-up, use a mechanical mixing device, such as the Thermolyne[™] Mixi-Max plus to dislodge the sample. As a last resort, use a thin, disposable glass rod (or Pasture pipette) to dislodge the compacted sediment.

Revision: 4	Effective Date: 6/24/2013	Page 17 of 23
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	

😵 eurofins Frontier Globel Solences
--

- 15.16 When all samples in the batch have been filled with 1N KOH extracting solution, place in the shaker box, and shake by slow (5-10 rpm) end-over-end rotation for a total elapsed extraction time of 16 ± 2 hours. Alternatively, in the absence of a rotator, shake the samples very vigorously for 1-2 minutes every half-hour until evening and then even hour the following morning for a total elapsed extraction time of 16 ± 2 hours.
- 15.17 After the extraction period, centrifuge the vials at 3000 RPM for 15 minutes.
- 15.18 Use a 5 or 10 mL pipette to transfer 90% of the solution into a labeled 25mL bottle. Take great care in not grabbing any of the solid sample. Pipette directly into a syringe and filter (0.2 to 0.4μm) the solution into a 125 mL bottle. Add 40 mbe moof solution to sample and invert 10 times. Centrifuge again and transfer as much of the solution as possible (at least 90%) without grabbing any of the solid sample again into a syringe then 125mL bottle.
- 15.19 To each extract and blank, add 1.25 mL of concentrate a DOL blation, swirl to mix, and bring up to volume of 125mL. Use an example bottle a 125mL for reference.
- 15.20 Repeat steps 15.18-15.19, adding the filter a rinse extract to the BrCI oxidized initial KOH extract in the 125 mL bottles. For each cample, use a separate filter as was used for the initial 1N KOH extract to filter the second 11 KOH (rinse) extract. Dilute each bottle to the base of the neck with reagest water, shake thoroughly, and set aside for at least 4 hours until analysis.
- 15.21 To each original sample pellet, fill the via to the 40-mL mark with the 12N HNO₃ extracting solution, and shake vgor dsly to resuspend the sediment. If, after vigorous shaking, the sediment pellet doe not break-up, use a mechanical mixing device, such as the Thermolyne[™] Mixi dax alus to dislodge the sample. As a last resort, use a thin, disposable glass rod (or Pasteur pipette) to dislodge the compacted sediment.
- 15.22 When all samples in the batch have been filled with 12N HNO_3 extracting solution, place in the shaker box and shake by slow (5-10 rpm) end-over-end rotation for a total elapsed extraction time of 16 ± 2 hours. Alternatively, in the absence of a rotator, shake the samples very vigorously for 1-2 minutes every half-hour until evening and then every hour the following horning for a total elapsed extraction time of 16 ± 2 hours.
- 15.23 After the expraction period, centrifuge the vials at 3000 RPM for 15 minutes.
- 15.24 After central ugation, carefully pour the supernatant liquid of each sample into a 125 mL insistant labeled with the same sample ID, soil weight, and the type of leach (F-4 in this case). Be very careful to minimize resuspension and loss of the sediment during excluting. If the sediment pellet is prone to resuspension (i.e., sandy materials), use a 5.0 mL pipettor to transfer the supernatant to 125-mL glass bottle. DO NOT TRY TO HILTER THE SAMPLES, AS THE 12N HNO₃ WILL INSTANTLY DISSOLVE THE CELLULOSE NITRATE MEMBRANE! To each extract and blank, add 2.5 mL of concentrated BrCl solution, swirl to mix, and set aside until the rinse aliguot is collected.
- 15.25 For each sediment sample pellet in the original 40 mL vials, refill with 12N HNO₃ extracting solution (rinse step), and shake vigorously for two minutes after all sediment is resuspended into the aqueous layer. If after vigorous shaking, the sediment pellet does

Revision: 4	Effective Date: 6/24/2013	Page 18 of 23	
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protecte by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.			

Reurofins Frontier Global Sciences
--

not break up, use a mechanical mixing device, such as the Thermolyne™ Mixi-Max plus to dislodge the sample. As a last resort, use a thin, disposable glass rod (or Pasteur pipette) to dislodge the compacted sediment.

- 15.26 Repeat steps 15.24-15.25, adding the decanted rinse extract to the BrCl oxidized 12N HNO₃ extract in the 125 mL bottles. Dilute each bottle to the base of the neck reagent water, shake thoroughly, and set aside at least one hour until analysis
- 15.27 To each original sample pellet, add 8.0 mL of concentrated HCI and 2.0 mL of concentrated HNO₃, swirling the samples between additions. Loosely replace caps to avoid pressure build up, and swirl periodically over a period of at least four hours.
 - 15.27.1 **CAUTION:** Perform this operation in a fume hood as the equal egia generated releases noxious fumes of Cl_2 and NO_2 .
- 15.28 After digestion of 4-16 hours, dilute each sample to 40.0 m in the original vial with a 10% BrCl solution, shake vigorously, and store at commemperature until analysis. **These are the F-5 samples** (unless F6 is required). If 76 is required, decant the sample into a 125 mL jar. Preserve the sample with 5 min 0.214 BrCl. Rinse the sample by suspending the remaining sediment pellet in 11 water Then centrifuge the sample, and add the supernatant to the sample in the 125 mL jar.
- 15.29 If F6 is required, the sample must be cansferred into a 45-mL Teflon Oak Ridge™ centrifuge vial, a 60 ml or 140 mL Teflen bonb. To ensure all of the sediment in the vial is transferred to the bomb, it may be necessary to rinse the vial up to 3 times with 5 mL of HNO₃.
- 15.30 To the bomb (or centrifuge well) is added 18.75 mL HNO₃ (this includes any nitric acid used to rinse the vial), 6.25 mL NF and 3 mL HCI. The lid is screwed on tightly, and the bomb is placed in the order at 30°C for 12hours. The bomb is then diluted up to 50 mL. A 10x dilution is taken with 56 BrCl and analyzed.
- 15.31 Determination of the by adspace analysis. As an alternative to measuring the free liquid element. mensury in the F1 extract, it is simpler to measure mercury in the headspace. on sample. Even a microscopic amount of elemental mercury in the divise Hg into the air and reach a temperature-dependant equilibrium sample v concentrat The detection of Hg in the headspace confirms the presence of elen ante. mercury in the sample. Refer to FGS-113 for the complete procedure. a small aliquot of sediment is placed in a jar with a pre-drilled lid overnight at tially 00m comperature. An aliquot of the air overlying the sample is removed from the jar ising a syringe. The headspace sample is then placed in a stream of N₂ connected to a trap. The trap is analyzed directly by CV-AFS.

Calculations:

6.1 This preparation procedure does not involve calculations.

7 Statistical Information/Method Performance:

17.1 The Method Detection Limit (MDL) is determined according to 40 CFR Part 136 Section B. Ten replicates (9 degrees of freedom) spiked 3-10 times the expected MDL are run.

Revision: 4	Effective Date: 6/24/2013	Page 19 of 23
by Washington State Law. Proprietary in	Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a ent from Eurofins Frontier Global Sciences.	

😵 eurofins Frantier Global Soler	I Samples for the Determination of	Eurofins Document Reference: EFGS-SOP-090-R04
---------------------------------------	------------------------------------	--

The standard deviation (s) is taken from the resulting data and the MDL is calculated as follows: MDL=2.821*s. This value should not be interpreted as the method reporting limit. Historical method performance data is summarized in Appendix C.

- 17.2 The Practical Quantitation Limit (PQL) is the reporting limit for this method and is included as one of the calibration points. The PQL is determined by running ten epicate samples with a concentration that will produce a recovery of 70-130% for ment analytes, but the recovery requirements are analyte dependent. The PQL is referred to as the Method Reporting Limit (MRL) in LIMS.
- 17.3 Current LODs and PQLs are stored at: General and Admin\Quality\\sstrance\MDLs & PQLs.

18 Quality Assurance/Quality Control:

- 18.1 The QA/QC for the digestions following EFGS-137 (EPA 163, with frequency and range of recoveries and RPDs for the instrument and batch QC.
- 18.2 Due to the nature of the solutions used in each fraction a fue LCS and MS cannot be prepped. A minimum dilution of one BLK is biked as the BS/BSD. An AS/ASD is also analyzed with the batch per 10 samples.
- 18.3 A minimum of three digestion blanks, one digestion duplicate, an HgS in clay lab standard, and an HgCl₂ in clay lab standard must be prepared for each discrete sample set (8-20 samples). For smaller sample sets under standard QA/QC, fewer QC samples may be digested, according to the project manager, or previous history with that client
- 18.4 **NOTE:** the fractionation of H161₂ in clay is very strongly dependent upon its concentration (at lower concentrations, more of the Hg(II) is found adsorbed to the clay at weaker extraction levels). Thus, for best QC, it is advisable to use the "low" Hg concentration of Hg(1₂ In clay (about 33 ppm) when doing low or moderately contaminated samples, and the "high" Hg concentration of HgCl₂ in clay (about 2600 ppm) when looking at heaving contaminated samples). This concentration dependence is not an issue for the HarS lab standard.

19 Corrective action:

- 19.1 As there is an exceptional amount of sample handling for this method, it is very important that all samples are handled according to clean sample handling protocols (EG. 008)
- 19.2 Due to the significant amount of filtration in this method, any person performing the trave procedure should be well versed in clean filtration. Refer to corrective actions from FGS-029.

Due to the above two concerns, very close attention is given to the blanks. As this procedure is arduous, re-preparation is very undesirable. If blanks are excessively high, the only recourse is to re-extract. The person preparing the digest needs to have good assurance that reagents and equipment are free of Hg contamination.

19.4 As the amount of QC performed in this preparation is very limited, it is critical that each extraction step is performed exactly as stated in this procedure. Any deviation could

Revision: 4	Effective Date: 6/24/2013	Page 20 of 23
by Washington State Law. Proprietary in	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a sent from Eurofins Frontier Global Sciences.	proprietary information and are protected and must not be used or appropriated to

are eurofins	Document Title: Selective Sequential Extraction of Geological Samples for the Determination of Biogeochemically Relevant Inorganic Mercury Fractionation	Eurofins Document Reference: EFGS-SOP-090-R04
--------------	--	--

result in the failing of QC samples. This would often result in an automatic re-

(;

20 List of Attachments:

Appendix A: Historical Method Performance Data

Appendix B: Standard Operating Procedure Training Record


Revision: 4	Effective Date: 6/24/2013	Page 21 of 23
by Washington State Law. Proprietary ir	s Frontier Global Sciences standard operating procedures contain formation must be maintained with the strictest of confidence a	proprietary information and are protected and must not be used or appropriated to
benefit any party without prior written con-	sent from Eurofins Frontier Global Sciences.	

Steurofins Frontier Global Solences	I Samples for the Determination of T	Eurofins Document Reference: EFGS-SOP-090-R04
---------------------------------------	--------------------------------------	--

Appendix A: Historical Method Performance Data

The results summarized in the Table below were compiled from an August, 1999 validation study using this method. The estimated MDLs are taken as three times the standard deviation of the method blanks. An MDL study run utilizing an actual low level sample (50% NIST-1046, estuarine sediment, plus water, [Hg] = 39ng/g) confirmed these results, except that it found an MDL of 5.0 ng/g for 1N KOH. However, the concentration in the IN KOH extract was ranger high, leading to the conclusion that near the blanks, the MDL associated with the vanibility of the blanks would be more apropos.

Method performance for the mercury selective extraction procedure (August, 1999): A total of four method blanks and three each of the HgS and HgCl₂ samples were run the CRMs are the result of a single run.



eurofins	Frontier Global Sciences	Document Title: Selective Sequential Extraction of Geological Samples for the Determination of Biogeochemically Relevant Inorganic Mercury Fractionation	Eurofins Document Reference: EFGS-SOP-090-R04
----------	--------------------------	--	--

Appendix B: Standard Operating Procedure Training Record By signing this document, I the employee, certifies to have read, understood and agreed to follo the test method and quality procedure as described in this procedure. Reading of SOP EFGS-090.04: Selective Sequential Extraction of Geological Samples for the Determination of Biogeocher Relevant Inorganic Mercury Fractionation SOP name and Revision number Employee name (print) Employee name (sign) Date: Supervisor name (sign) Date: Initial SOP Training (leave blank if Initial reading of method any Initials Date Supervisor 1. Read method 2. Observe the method 3. Detailed review of and associated literature thoo 4. Supervised pr thod with trainer ractic of the method with trainer 5. Unsupervised th trainer and/or peer-review 6. Review 7. IDOC deter ine precision and accuracy non of blanks 8. termin

Revision: 4	Effective Date: 6/24/2013	Page 23 of 23
COMPANY CONFIDENTIAL. All Eurofins Frontier Global Sciences standard operating procedures contain proprietary information and are protected by Washington State Law. Proprietary information must be maintained with the strictest of confidence and must not be used or appropriated to benefit any party without prior written consent from Eurofins Frontier Global Sciences.		