



Known for excellence.
Built on trust.



REMEDIAL INVESTIGATION WORK PLAN

55 ECKFORD ST LLC SITE

55 Eckford Street

Brooklyn, New York 11222

Block 2698, Lot 32

BCP Site No. C224168

June 2024

File No. 41.0163263.00

PREPARED FOR:

55 ECKFORD ST LLC

110-50 69th Avenue

Forest Hills, NY 11375

PREPARED BY:

GOLDBERG-ZOINO ASSOCIATES OF NEW YORK P.C.

D/B/A GZA GEOENVIRONMENTAL OF NEW YORK

324 South Service Road | Melville, NY 11747

32 Offices Nationwide

www.gza.com

Copyright© 2024 GZA GeoEnvironmental of New York



Known for excellence.
Built on trust.



June 25, 2024
File No. 41.0163263.00

New York State Department of Environmental Conservation
Division of Environmental Remediation
625 Broadway
Albany, NY 12233-7015

Re: Remedial Investigation Work Plan
55 Eckford St LLC Site
55 Eckford Street
Brooklyn, NY 11222
Block 2698, Lot 32
BCP Site No. C224168

Dear Sir/Madam:

On behalf of the 55 Eckford St LLC (Requestor/Owner), Goldberg-Zoino Associates of New York P.C. d/b/a GZA GeoEnvironmental of New York (GZA) is pleased to submit this Remedial Investigation Work Plan (RIWP) for the above-referenced property (Site).

If you have any questions, please contact Victoria D. Whelan at (631) 793-8821.

Very truly yours,


GZA GEOENVIRONMENTAL OF NEW YORK



Reinbill P. Maniquez, CHMM
Senior Project Manager



Stephen M. Kline, P.E.
Consultant Reviewer



Victoria D. Whelan, P.G.
QEP/ Vice President



TABLE OF CONTENTS

CERTIFICATION.....	III
1.0 INTRODUCTION	1
1.1 PROJECT OBJECTIVE.....	1
1.2 SCOPE OF WORK.....	1
2.0 SITE INFORMATION	1
2.1 SITE LOCATION, DESCRIPTION, AND USE	2
2.2 SITE AND AREA HISTORY	2
2.3 PROPOSED REDEVELOPMENT PLAN.....	3
3.0 ENVIRONMENTAL AND PHYSIOGRAPHIC SETTING.....	3
3.1 REGIONAL PHYSIOGRAPHY.....	3
3.2 GEOLOGIC, HYDROGEOLOGIC, AND HYDROLOGIC CONDITIONS.....	4
4.0 PREVIOUS SITE INVESTIGATIONS.....	4
4.1 PHASE I ENVIRONMENTAL SITE ASSESSMENT – OCTOBER 2011	5
4.2 DRAFT PHASE II ENVIRONMENTAL SUBSURFACE INVESTIGATION – DECEMBER 2011	5
4.3 PHASE II ENVIRONMENTAL SITE ASSESSMENT – APRIL 2012.....	5
4.4 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – JUNE 2013.....	6
4.5 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – JULY 2016	6
4.6 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – OCTOBER 2019	6
4.7 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – OCTOBER 2023	6
4.8 ADDITIONAL DOCUMENTATION	7
5.0 REMEDIAL INVESTIGATION	8
5.1 SOIL INVESTIGATION	9
5.2 GROUNDWATER INVESTIGATION.....	10
5.3 SOIL VAPOR AND OUTDOOR AIR SAMPLING.....	10
5.4 QUALITY ASSURANCE /QUALITY CONTROL	11
5.5 DATA MANAGEMENT AND VALIDATION	11
5.6 CHAIN OF CUSTODY AND SHIPPING.....	12
5.7 STORAGE AND DISPOSAL OF INVESTIGATION-DERIVED WASTE	13
6.0 QUALITATIVE HUMAN HEALTH EXPOSURE ASSESSMENT	13
7.0 HEALTH AND SAFETY	14
7.1 PROJECT KICKOFF AND UTILITY CLEARANCE	14
7.2 COMMUNITY AIR MONITORING PLAN (CAMP).....	14
8.0 REPORTING	16
9.0 PROJECT SCHEDULE AND PROJECT PERSONNEL.....	16



TABLES

TABLE 1	Sampling Summary and Rationale
---------	--------------------------------

FIGURES

FIGURE 1	Site Location Plan
FIGURE 2	Site Plan
FIGURE 3A	Phase II ESI (2020) - Soil Chemistry Exceedances – Chlorinated VOCs
FIGURE 3B	Phase II ESI (2020) - Soil Chemistry Exceedances – Metals
FIGURE 4	Phase II ESI (2020) – Groundwater Chemistry Exceedances – Metals
FIGURE 5	Phase II ESI (2020) – Soil Vapor Detections – Chlorinated VOCs
FIGURE 6	Proposed Remedial Investigation Sample Locations

APPENDICES

APPENDIX A	Proposed Redevelopment Plan
APPENDIX B	Quality Assurance Project Plan (QAPP)/Field Sampling Plan (FSP)
APPENDIX C	Field Forms and Logs
APPENDIX D	Health and Safety Plan (HASP)
APPENDIX E	Community Air Monitoring Program (CAMP)
APPENDIX F	Personnel Qualifications



CERTIFICATION

I, Victoria D. Whelan, P.G., certify that that I am a Qualified Environmental Professional (QEP) as defined in 6 NYCRR Part 375 and that this Remedial Investigation Work Plan (RIWP) for 55 Eckford Street, Brooklyn, New York, Block 2698, Lot 32, was prepared in accordance with applicable statutes and regulations and in substantial conformance with the DER-10 Technical Guidance for Site Investigation and Remediation (DER-10).

Victoria D. Whelan, P.G.

QEP Name

A handwritten signature in blue ink, appearing to read 'V. D. Whelan', is written over a horizontal line.

QEP Signature

June 25, 2024

Date



1.0 INTRODUCTION

This Remedial Investigation Work Plan (RIWP) for the property identified as 55 Eckford Street, Brooklyn, New York (Site) was prepared by Goldberg Zoino Associates of New York, P.C. d/b/a GZA GeoEnvironmental of New York (GZA) on behalf of 55 Eckford St LLC (Requestor /Owner). The Requestor intends to enter into the New York State Department of Environmental Conservation (NYSDEC), Division of Environmental Remediation (DER), Brownfield Cleanup Program (BCP) per Title 6 of the New York State Official Compilation of Codes, Rules, and Regulation (NYCRR) Part 375-3.4.

The Site is located in the Greenpoint neighborhood of Brooklyn, New York and is Block 2698, Lot 32 on the New York City (NYC) Department of Finance (DOF) Tax Map.

1.1 PROJECT OBJECTIVE

The previous investigations performed at the Site provided a preliminary understanding of the nature and extent of contamination, specifically volatile organic compounds (VOCs), semi-volatile organic compounds (SVOCs) and metal in subsurface soils, groundwater, and soil vapor. The objective of this RIWP is to collect sufficient quantity of data to supplement previous investigations, address the data gaps, and aid in the delineation of impacted areas that will need to be addressed during the remedial activities that will allow for the beneficial redevelopment of the property under the BCP.

1.2 SCOPE OF WORK

The RIWP describes the project objectives, details the Site information and location, relevant historical background, previous site investigations, and field methodologies that will be employed during the subsurface investigation. This RIWP was prepared by GZA for the Site in general accordance with the NYSDEC, DER *Technical Guidance for Site Investigation and Remediation (DER-10)*, dated May 2010. Appended to this RIWP are plans that detail the site-specific protocols to be followed during the investigation work, which include:

- Quality Assurance Project Plan (QAPP) and Field Sampling Plan (FSP)
- Health and Safety Plan (HASP)
- Community Air Monitoring Plan (CAMP)

2.0 SITE INFORMATION

The following section summarizes information provided by the Requestor such as survey plans, previous assessment and investigation reports related to the Site. These documents should be consulted for additional information and details not presented here. Previous documents include:

- *Phase I Environmental Site Assessment (ESA) Report, Hydro Tech Environmental Corp., October 27, 2011*
- *Phase II Environmental Sub Surface Investigation, EEA, INC., December 2011*
- *Phase II Environmental Site Assessment, Hydro Tech Environmental Corp., April 5, 2012*
- *Phase I Environmental Site Assessment Report, Hydro Tech Environmental Corp., June 3, 2012*
- *Phase I Environmental Site Assessment Report, Hydro Tech Environmental Corp., July 25, 2016*



- *Phase I Environmental Site Assessment Report, Touchstone Environmental Geology, P.C., October 10, 2023*

Previous plans and reports were transmitted to the NYSDEC as an attachment to the BCP Application Package provided under separate cover.

2.1 SITE LOCATION, DESCRIPTION, AND USE

The Site is identified 55 Eckford Street and is located in the Greenpoint-Williamsburg Special Mixed Use District (MX-8) of Brooklyn, New York in an area zoned for residential (R6A, R6B), light manufacturing (M1-2). The Site is identified as Block 2698, Lot 32 and 10,376 square feet (approximately 0.24 acres) in area. The Site is bound to the north by a 5-story building (65 Eckford Street, BCP Site No. C224218), to the east by Eckford Street, to the south by a 3-story residential building (68 Engert Avenue) and eight interconnected 5-story residential buildings (49 Engert Avenue), and to the west by 1-story warehouse building (488 Leonard Street) and a parking garage. A topographic map showing the location of the Site is provided as **Figure 1**.

The Site contains a 6-story steel structure for an unfinished building and the property is surrounded by a construction fence. **Figure 2** shows a Site Plan.

2.2 SITE AND AREA HISTORY

Records from 1887 show the Site as four abutting vacant undeveloped lots. By 1905, the Site is shown as being part of Meisel Danowitz & Co. woodworking operation and contained four 1- to 2-story buildings identified as “moulding shed”, “planning & moulding lumber racks”, “kiln house”, and an office. By 1916, the structures remain but were identified as “vacant and dilapidated”; by 1942 identified as “wool & rags sorting and baling”; and from 1951 until 1992 identified as “electric plating, storage, lacquer spraying”. NYC Department of Finance (DOF) records showed the Site was owned by the Berkman Family. Between 1993 and 2004, the structures remain but the use was unknown. By 2003, the Berkman Family sold the property to Blue Diamond Development, LLC. In August 2005, the NYC Department of Buildings (DOB) issued a demolition, and buildings were later demolished. By 2009, the property was sold to 55 Eckford Street Brooklyn LLC / Madison Realty Capital L.P. Between 2009 and 2015, construction permits were issued by NYCOB for the Site redevelopment into residential apartments. By 2016, a stop work order has been issued for the Site, and construction has been paused since then. According to the previous investigations performed at the Site (see Section 4.0), the Site was entered into the BCP under Site No. C224168 in 2017, with the Applicant, TCJ Construction, deemed a Volunteer, and withdrawn from the program. By the time of the BCP Application in June 2024, the Site contains a 6-story steel structure for an unfinished building and the property is surrounded by a construction fence.

The NYC Department of Finance (DOF) website lists the following ownership records and deed transfers:

Party 1	Party 2	Address	Date of Ownership or Operation
Eckford-Greenpoint LLC	55 Eckford St LLC	100 Jericho Quadrangle, Jericho, NY	04/24/2024 to 04/25/2024
55 Eckford Street Brooklyn LLC	Eckford-Greenpoint LLC	10 Glenville Street, Greenwich CT	12/28/2021 to 02/12/2013
Blue Diamond Development LLC	55 Eckford Street Brooklyn LLC	825 Third Avenue, New York, NY	06/22/2009 to 12/17/2009
Berkman, Theodore as co-trustees of Arlyne Berkman Revocable Living Trust	Blue Diamond Development LLC	199 Lee St., Suite 287 Brooklyn, NY	09/16/2003 to 03/16/2004
Berkman, Donald	Berkman, Gerald	55 Eckford St., Brooklyn, NY	01/30/2002 to 02/25/2002
Berkman, Arlyne	Berkman, Arlyne Revocable Living Trust	6655 NY 15 th St. Margate, FL	10/31/1995 to 12/21/1995
Berkman, Lillie	Berkman, Donald	71 Margaret Drive, Valley Stream, NY	03/04/1994 to 04/15/1994



Party 1	Party 2	Address	Date of Ownership or Operation
Berkman, Lillie	Berkman, Donald	71 Margaret Drive, Valley Stream, NY	01/05/1972 to 01/05/1972
Berkman, Lillie	Berkman, Donald	71 Margaret Drive, Valley Stream, NY	12/27/1971 to 12/27/1971

Records from as early as 1887 show the surrounding areas to the north, west and east of the Site as subdivided vacant interspersed with 2- to 3-story dwellings. The property to the south of the Site is shown with several 1-to 2-story story buildings labeled as “Plastering Hair Manufacturing Co.”. By early 1900s until the mid-2000s, the surrounding vicinity saw denser development with multiple 2 to 3-story -story dwellings and several manufacturing and commercial facilities (e.g., cooperage, lumber yards, moving pictures, cab company, garage, printing, furniture manufacturing, etc.). By late 2000s, the manufacturing properties were redeveloped into multi-story residential apartments. By July 16, 2015, the property that abuts the Site to the north (Former Carter Spray Finishing Corp. at 65 Eckford Street), was entered into the BCP under Site No. C224218 with documented contamination in soil related to historical operations and fuel storage in underground tanks.

2.3 PROPOSED REDEVELOPMENT PLAN

The project development will include horizontal extension existing metal structure of 14,400 square feet to 20,000 sq. ft. Project will include 14-16 residential condominium units, which will be built across 5 story building. Condominium development will include recreation space and 6- 8 on-grade parking in the rear. Original plans were approved under R6 zoning, which allowed for taller height requirement and additional square footage. Our plan is to reduce the structure to 5 floors to comply height requirements under R6B (new zoning) and make a wider footprint. The anticipated excavation depth for new extension will be between an estimated 8 to 9 feet. A copy of the proposed redevelopment plan is included in **Appendix A**.

In addition, the proposed redevelopment would entail construction excavation for the new building. The Requestor intends to remediate the Site during the redevelopment under the NYSDEC BCP. Assuming the Requestor’s application to join the BCP is accepted, the process will involve: (i) submission of this draft Remedial Investigation Work Plan to NYSDEC; (ii) a public comment period on the draft Remedial Investigation Work Plan; (iii) a BCP Agreement between the Requestor and NYSDEC; (iv) NYSDEC’s approval of a final Remedial Investigation Work Plan; (v) submission of a draft Citizen Participation Plan and draft Remedial Investigation Report and draft Remedial Work Plan to NYSDEC; (vi) a public comment period on the draft Remedial Investigation Report and draft Remedial Work Plan; (vii) NYSDEC’s issuance of a remedy selection decision in a Record of Decision; (viii) performance of the Remedial Work (which is expected to occur concurrently with the construction of the Proposed Project (a new school building); (ix) submission of a Remedial Action Report to NYSDEC; and (x) NYSDEC’s issuance of a Certificate of Completion.

3.0 **ENVIRONMENTAL AND PHYSIOGRAPHIC SETTING**

The following subsections provide information regarding the general physiographic, hydrologic, and soil conditions around the Site.

3.1 REGIONAL PHYSIOGRAPHY

As shown on **Figure 1**, the U.S. Geological Survey topographic map 2023 U.S Geologic Survey (USGS) Brooklyn, NY Quadrangle 7.5-Minute Series Map, the eastern portion of the Site is at an elevation between 15 and 20 feet above mean sea level (amsl) based on North American Vertical Datum of 1988 (NAVD88). The surface topography slopes downward towards the Bushwick Inlet / East River located approximately 0.87 kilometers northwest of the Site.



3.2 GEOLOGIC, HYDROGEOLOGIC, AND HYDROLOGIC CONDITIONS

Based on our review of the 1776-7 *Original High and Low Grounds, Salt Marsh and Shorelines in the City of Brooklyn Map*, the Site lies within the edge of the shoreline (blue) of where the original salt marsh land (green) is located (i.e., the current McCarren Park). Based on our experience in the area, fill used to raise grades is underlain by clayey silts and silty sands.



Source: Map prepared to accompany report to the Board of Health 1875, New York Public Library

Based on *Bedrock Engineering Geologic Maps of New York County and Parts of Kings and Queens Counties, New York, and Parts of Bergen and Hudson Counties, New Jersey*, dated 1990, the bedrock near the Site consists of interbedded units of gray thinly laminated muscovite-biotite-quartz schist, and white to pinkish with light green weathering gneiss. We anticipate bedrock to be encountered at approximately El. -150 feet NAVD88, which is over 100 feet below ground surface (bgs).

Based on previous investigations performed at the Site (see **Section 4.0**) , groundwater measurements range from approximately 7 to 13 feet bgs. However, the localized direction of groundwater flow near the Site might vary because of underground utilities, subsurface preferential pathways, variations in weather or heterogeneous geological and/or anthropogenic conditions.

4.0 **PREVIOUS SITE INVESTIGATIONS**

The following subsections document the previous site investigations were reviewed as part of this RIWP. GZA also performed a file review of the Site documents under the NYSDEC Document Repository for BCP Site No. C224168.



4.1 PHASE I ENVIRONMENTAL SITE ASSESSMENT – OCTOBER 2011

In October 2011, Hydro Tech Environmental, Corp. (HTE) of Hauppauge, NY performed a Phase I ESA for 55 Eckford Street Brooklyn LLC (former Owner) and found two Recognized Environmental Conditions (RECs) related to the Site. The first REC is the historical use of the Site as manufacturing facility and the undocumented removal of an aboveground fuel oil storage tank.

4.2 DRAFT PHASE II ENVIRONMENTAL SUBSURFACE INVESTIGATION – DECEMBER 2011

In December 2011, EEA Inc. of Garden City, NY, performed a Phase II Environmental Subsurface Investigation for Madison Realty Capital to address the RECs noted on the previous Phase I ESA, which included the advancement of six (6) soil borings and the installation of four (4) monitoring wells. Based upon visual, olfactory, and PID screening analysis the soils contained strong solvent odors, grey staining and elevated PID readings (at max of 1,85 parts per million [ppm]) at or in close proximity to the groundwater interface. Based upon their analysis of laboratory and field data, the Site soils are contaminated with VOCs and SVOCs and groundwater is contaminated with VOCs. The presence of these VOCs and SVOCs are due to releases from the lacquer spray facility once present on the Site. Furthermore, the following four (4) VOCs detected at levels above guidelines in groundwater are typically used as coating agents or thinners in lacquer applying applications: sec-Butylbenzene, 2-isopropyltoluene, Isopropylbenzene, and tert- Butylbenzene. Based upon analysis of laboratory and field data, the Site soils and groundwater are contaminated with Metals. These contaminants are due to releases from the electroplating facility once present on the Site. Furthermore, such metals as mercury and arsenic were listed as past hazardous wastes produced at the Site and were detected above regulatory guidelines in soil and unfiltered groundwater (arsenic also found above guidelines in filtered groundwater).

4.3 PHASE II ENVIRONMENTAL SITE ASSESSMENT – APRIL 2012

In April 2012, HTE performed a Phase II ESA for Madison Realty Capital of New York, NY which included the advancement of nine (9) soil probes and the installation seven (7) monitoring wells and seven (7) soil vapor implants to collect soil, groundwater, and soil vapor samples for laboratory analyses.

The laboratory analytical results reported samples containing SVOCs (at a maximum total concentration [max] of 32,232 milligrams per kilogram [mg/kg]) and metals (specifically arsenic, barium, cadmium, trivalent chromium, copper, lead, nickel, and mercury) detected at concentrations that exceeded regulatory standards.

The laboratory analytical results revealed VOCs (at a total max of 16.91 micrograms per liter [mg/L]) and metals (specifically arsenic, iron, manganese, silver and sodium) were detected in several groundwater samples at concentrations that exceeded regulatory standards.

The laboratory analytical results revealed VOCs associated with petroleum (specifically xylene and toluene) and chlorinated solvents (specifically, tetrachloroethylene/perchloroethylene [PCE] and trichloroethylene [TCE]) were detected in the soil vapor samples collected from the perimeter of the property. The maximum total VOC concentration in soil vapor is 4,344 micrograms per cubic meter [ug/m³]. At the request of the client, the findings of the Phase II investigation HTE discussed with the NYC Office of Environmental Remediation (NYCOER) the potential to develop the site under the NYC OER Voluntary Cleanup Program (VCP). The NYCOER indicated that due to the nature of the contamination identified during the Phase II, the development would require coordination with the NYSDEC. According HTE, they were not requested to pursue remedial approaches with the NYSDEC.



4.4 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – JUNE 2013

In June 2013, HTE performed a Phase I ESA for Olden Equities of Brooklyn, NY and identified five RECs in connection with the Site, namely:

- The historic use of the Site as a manufacturing facility;
- The presence of SVOC and metal-impacted soil at the Site;
- The presence of VOC and metal impacted groundwater at the Site;
- The presence of both petroleum and chlorinated solvent-impacted soil vapors at the Site; and
- The undocumented removal of an aboveground fuel oil storage tank.

4.5 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – JULY 2016

In July 2016, HTE performed a Phase I ESA for Madison Realty Capital of New York, NY and identified several RECs in connection with the Site, namely:

- The historic use of the Site as a manufacturing facility;
- The presence of SVOC and metal-impacted soil at the Site;
- The presence of VOC and metal impacted groundwater at the Site;
- The presence of both petroleum and chlorinated solvent-impacted soil vapors at the Site;
- The undocumented removal of an aboveground fuel oil storage tank;
- The presence of NYS BCP Site No. C224218 in the northern adjacent property;
- The presence of a petroleum and chlorinated potential vapor encroachment condition (PVEC)at the Site; and
- The presence of mold at the Site.

4.6 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – OCTOBER 2019

In October 2019, HTE performed a Phase I ESA for Avo Construction of New York, NY and identified several RECs in connection with the Site, namely:

- The historic use of the Site as a manufacturing facility;
- The presence of SVOC and metal-impacted soil at the Site;
- The presence of VOC and metal impacted groundwater at the Site;
- The presence of both petroleum and chlorinated solvent-impacted soil vapors at the Site;
- The undocumented removal of an aboveground fuel oil storage tank;
- The presence of NYS BCP Site No. C224218 in the northern adjacent property;
- The listing of the Site under BCP Site No. C224168.

The October 2019 Phase I ESA noted that the property was entered into the NYS BCP in 2017. The entrant, TCJ Construction Inc. (TCJ), was accepted into the program as a Volunteer.

4.7 PHASE I ENVIRONMENTAL SITE ASSESSMENT REPORT – OCTOBER 2023

In October 2023, Touchstone Environmental Geology, P.C. performed a Phase I ESA for the Requestor, Daniel Kaykov, and identified several RECs and HRECs in connection with the Site:

- The historic use of the Site as a manufacturing facility;
- The presence of SVOC and metal-impacted soil at the Site;
- The presence of VOC and metal impacted groundwater at the Site;
- The presence of both petroleum and chlorinated solvent-impacted soil vapors at the Site;



- The undocumented removal of an aboveground fuel oil storage tank;
- The presence of NYS BCP Site No. C224218 in the northern adjacent property;
- The listing of the Site under BCP Site No. C224168.

4.8 ADDITIONAL DOCUMENTATION

GZA also performed a file review of the documents at NYSDEC Document Repository under BCP Site No. C224168.

The documents reviewed included the aforementioned investigation reports and two additional documents namely:

- Remedial Investigation Work Plan - December 2018
HTE prepared a Remedial Investigation Work Plan for TCJ in accordance with the requirements of the BCP and proposed the advancement of ten (10) soil borings, installation of six (6) monitoring wells, and eight (8) soil vapor sampling points. No other information on the implementation of the RIWP is available in the NYSDEC Document Repository.
- Brownfield Cleanup Program Application – March 4, 2020
A BCP Application was filed with the NYSDEC on March 4, 2020, by 55 Eckford Acquisition LLC (former Requestor). The document referenced the Site's environmental history and known contaminants as follows:

Section III. Property's Environmental History			
All applications must include an Investigation Report (per ECL 27-1407(1)). The report must be sufficient to establish contamination of environmental media on the site above applicable Standards, Criteria and Guidance (SCGs) based on the reasonably anticipated use of the property. To the extent that existing information/studies/reports are available to the requestor, please attach the following (<i>please submit the information requested in this section in electronic format only</i>): 1. Reports: an example of an Investigation Report is a Phase II Environmental Site Assessment report prepared in accordance with the latest American Society for Testing and Materials standard (ASTM E1903). Please submit a separate electronic copy of each report in Portable Document Format (PDF).			
2. SAMPLING DATA: INDICATE KNOWN CONTAMINANTS AND THE MEDIA WHICH ARE KNOWN TO HAVE BEEN AFFECTED. LABORATORY REPORTS SHOULD BE REFERENCED AND COPIES INCLUDED.			
Contaminant Category	Soil	Groundwater	Soil Gas
Petroleum			
Chlorinated Solvents	X		X
Other VOCs			
SVOCs			
Metals	X	X	
Pesticides			
PCBs			
Other*			
3. FOR EACH IMPACTED MEDIUM INDICATED ABOVE, INCLUDE A SITE DRAWING INDICATING: <ul style="list-style-type: none">• SAMPLE LOCATION• DATE OF SAMPLING EVENT• KEY CONTAMINANTS AND CONCENTRATION DETECTED• FOR SOIL, HIGHLIGHT IF ABOVE REASONABLY ANTICIPATED USE• FOR GROUNDWATER, HIGHLIGHT EXCEEDANCES OF 6NYCRR PART 703.5• FOR SOIL GAS/ SOIL VAPOR/ INDOOR AIR, HIGHLIGHT IF ABOVE MITIGATE LEVELS ON THE NEW YORK STATE DEPARTMENT OF HEALTH MATRIX THESE DRAWINGS ARE TO BE REPRESENTATIVE OF ALL DATA BEING RELIED UPON TO MAKE THE CASE THAT THE SITE IS IN NEED OF REMEDIATION UNDER THE BCP. DRAWINGS SHOULD NOT BE BIGGER THAN 11" X 17". THESE DRAWINGS SHOULD BE PREPARED IN ACCORDANCE WITH ANY GUIDANCE PROVIDED. ARE THE REQUIRED MAPS INCLUDED WITH THE APPLICATION? <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No (*answering No will result in an incomplete application)			
4. INDICATE PAST LAND USES (CHECK ALL THAT APPLY):			
<input type="checkbox"/> Coal Gas Manufacturing	<input checked="" type="checkbox"/> Manufacturing	<input type="checkbox"/> Agricultural Co-op	<input type="checkbox"/> Dry Cleaner
<input type="checkbox"/> Salvage Yard	<input type="checkbox"/> Bulk Plant	<input type="checkbox"/> Pipeline	<input type="checkbox"/> Service Station
<input type="checkbox"/> Landfill	<input type="checkbox"/> Tannery	<input checked="" type="checkbox"/> Electroplating	<input type="checkbox"/> Unknown
Other: _____			



The BCP Application also noted the change of ownership for 55 Eckford 1875 DNB LLC to 55 Eckford Acquisition LLC.

The historical soil contamination is shown in **Figure 3A and 3B**. The historical groundwater contamination is shown in **Figure 4**. The historical soil vapor contamination is shown in **Figure 5**.

5.0 REMEDIAL INVESTIGATION

The proposed Remedial Investigation (RI) field program will focus on collecting additional soil, groundwater, and soil gas data to delineate and characterize the contamination, and historic fill materials underlying the property. The scope of the RI will include the collection of sufficient Site investigation data so that, together with the historical data, the entire Site will be sufficiently characterized to support the development of the Site-wide Remedial Action Work Plan (RAWP).

To accomplish this, the scope of work for the RI will include the following:

- The advancement of soil borings, collection of soil samples, installation of permanent groundwater monitoring wells, collection of groundwater samples from new monitoring wells, installation of soil vapor points, and sampling of new soil vapor points;
- The collection of soil, groundwater, and soil vapor sufficient to define the nature and extent of impacted media and current Site conditions and offsite groundwater and/or soil vapor migration potential;
- The collection of a synoptic round of groundwater level measurements and the collection of additional land survey data as needed for developing a groundwater elevation contour map; and
- The performance of a qualitative human health exposure assessment (QHHEA) to identify existing and potential exposure pathways and evaluate contaminant fate and transport.

The proposed scope of work includes:

Soil

- Advancement of ten (10) soil borings to a maximum depth of 15 feet bgs.
- Collection and laboratory analyses of two soil samples from each boring for a total of twenty (2) samples. One from the observed and document highest organic vapor based on field screening results and one from just above the groundwater interface (i.e., at approximately 7 to 13 feet bgs).

Groundwater

- Advancement of six (6) soil borings down to a maximum depth of 15 feet bgs that will be converted to permanent stick-up monitoring wells.
- Gauging and development of the permanent monitoring wells.
- Collection and laboratory analyses of six groundwater samples.

Soil Gas

- Advancement of eight (8) soil vapor points down to 5 feet bgs or just above the groundwater interface.
- Collection and laboratory analyses of eight soil vapor samples.

Outdoor Air

- Collection and laboratory analyses of two outdoor ambient air samples.



The remedial investigation will be conducted in accordance with the applicable requirements of the DER-10. The data will be produced in accordance with the New York State Department of Health (NYSDOH) Analytical Services Protocol (ASP) Category B deliverables and will be reviewed and validated by an independent data validator. The data validator will prepare a Data Usability Summary Report (DUSR) before data is incorporated into the RIR for the Site. All data will be submitted to NYSDEC in electronic format, in accordance with DER-10.

The sample summary and rationale are provided in **Table 1**. The proposed sample locations are shown on **Figure 6**. The following sections describe the methods, rationale, and proposed sampling schedule for the soil investigation activities summarized above. Sampling will be performed in accordance with the QAPP/FSP presented in **Appendix B**.

5.1 SOIL INVESTIGATION

As shown on **Figure 6**, GZA proposes to advance 10 soil borings (designated as GZ-10 to GZ-19) across the property. The borings will be performed under field observation of a GZA engineer or geologist. Soil samples will be obtained with a 5-foot steel MacroCore™ sampler using disposable acetate liners. The MacroCore™ sampler will be advanced through the subsurface to collect representative soil samples down to a maximum of 15 feet bgs. If refusal is encountered in a soil boring due to subsurface obstructions (e.g., boulders, construction, and fill debris) above the target depth, the drillers will attempt up to two off-set locations for each boring location. An example soil boring log is included in **Appendix C**.

We will collect soil samples continuously from grade to the target depth and observe/document the soil samples for staining and soil characteristics. We will screen the soil samples for total organic vapors with a hand-held, photoionization detector (PID) and record lithological descriptions of the soil and field screening results on the soil boring logs. GZA's visual inspection will also document for evidence of contamination including staining and/or odors.

The GZA field representative will retain selected samples for laboratory analyses from the soil samples that indicate the comparatively highest impacts based on visual, olfactory, and PID screening results, and/or based on our evaluation of relevant Site features and conditions. GZA will collect between two (2) soil samples set per boring totaling ten (10) soil sample sets. Discrete samples will be collected with an EnCore® sampler (or similar) in compliance with EPA Method 5035 from the 6-inch interval with the highest visual, olfactory and PID evidence of environmental impacts. The other sample will be collected across a two-foot interval just above the groundwater interface (i.e., between 7 to 13 feet bgs). The soil samples will be analyzed as follows:

- Target compound list (TCL) VOCs by EPA Method 8260 (discrete) with TICs;
- TCL SVOC by EPA Method 8270 with TICs, including 1,4 Dioxane;
- Target analyte list (TAL) Metals by EPA Method 6010C / 7471B, including hexavalent chromium and total cyanide;
- TCL Pesticides by EPA Method 8081/ Herbicides by EPA Method 8151;
- Polychlorinated Biphenyls (PCBs) by EPA Method 8082A; and
- Per- and Polyfluoroalkyl Substances (PFAS) by EPA Method 1633.

Each sample set will be labeled, sealed, and placed in a cooler for shipment under standard chain-of-custody protocol to a NYSDOH Environmental Laboratory Approval Program (ELAP)-laboratory.



5.2 GROUNDWATER INVESTIGATION

As shown on **Figure 6**, six soil borings will be converted into new permanent monitoring wells (designated GMW-08 through GMW-13). The permanent monitoring wells will be comprised of two-inch diameter PVC that will be installed to a maximum depth of approximately 15 feet bgs. Each well will consist of a 2-inch diameter PVC riser and at least 10 feet long of 0.02-inch slotted 2-inch diameter PVC screen with the screened interval designed to span across the water table to detect petroleum sheens or light non-aqueous phase liquids (LNAPL). A 2-foot bentonite plug will be placed above the filter pack. The remaining annular space will be filled with bentonite. The wells will be completed with a flush-mount manhole and locking cap. An example of a monitoring well construction log is provided in **Appendix C**.

Groundwater samples will be collected from the monitoring wells by peristaltic pump and with dedicated low-density polyethylene (LDPE) tubing. Prior to sample collection, a minimum of three well screen volumes will be purged from each well point with the pump intake placed at the approximate midpoint of the screened interval. At the ground surface, the water will pass through a sealed flow through cell containing probes which will measure the water temperature, pH, specific conductivity, turbidity, oxidation-reduction potential (ORP), and dissolved oxygen (DO). One groundwater sample will be collected after the water quality parameters have stabilized. Stabilization is defined by three successive readings that are within ± 0.1 for pH, $\pm 3\%$ for conductivity, ± 10 mv for ORP, and $\pm 10\%$ for turbidity and DO. GZA will field filter all groundwater samples (e.g., metals analyses) if the turbidity measurement is greater than 50 NTU following the purging of three to 10 well screen volumes. An example well purge log is provided in **Appendix C**.

The groundwater samples will be analyzed for the following parameters:

- TCL VOCs by EPA Method 8260 with TICs;
- TCL SVOC by EPA Method 8270 with TICs including 1-4 Dioxane;
- Total and dissolved TAL Metals by EPA Method 6010C / 7471B, including cyanide by EPA method 9010/9012, mercury by EPA Method 7471;
- Pesticides by EPA Method 8081/ PCBs by EPA Method 8082A / Herbicides by EPA method 8151; and
- PFAS by EPA Method 1633

One trip blank sample will accompany the groundwater sample (at a frequency of one per day of sampling with a sample submitted to the laboratory for TCL VOC analysis) and will be analyzed for TCL VOCs.

5.3 SOIL VAPOR AND OUTDOOR AIR SAMPLING

As shown on **Figure 6**, GZA proposes to install eight soil vapor probes (designated as GSV-8 to GSV-15) down to approximately 5 feet bgs, or just above the groundwater interface. GZA will collect each of the soil vapor samples using methods consistent with the NYSDOH Guidance for Evaluating Soil Vapor Intrusion, dated October 2006 (as amended). Soil vapor samples will be collected using a stainless-steel probe, consisting of a drive point and internal perforated sampling port with a retractable tip, connected to Teflon™ sampling tubing. GZA proposes to collect soil vapor samples in 6-liter Summa® canisters equipped with 2-hour flow regulators. The soil vapor samples will be submitted to a NYSDOH ELAP-accredited laboratory. The soil vapor samples will be submitted for Target Compound List (TCL) VOCs analysis via EPA Method TO-15. The analytical results will be compared to 8-hour exposure standards and NYSDOH-specified guidance values. Following soil vapor sample collection, the soil vapor sampling point materials will be removed from the ground. An example soil vapor sampling log is included in **Appendix C**.



GZA will also collect two outdoor ambient air samples to evaluate upwind and downwind vapor conditions. GZA will collect ambient samples in 6-liter Summa® canisters equipped with 2-hour flow regulators. The ambient air samples will be submitted to a NYSDOH ELAP-accredited laboratory for TCL VOC analysis via EPA Method TO-15.

5.4 QUALITY ASSURANCE /QUALITY CONTROL

As part of the field investigation, GZA will also collect Quality Assurance/Quality Control (QA/QC) samples in accordance with the QAPP, presented in **Appendix B**, to confirm the usability of the data. QA/QC samples include equipment rinsate/field blanks, trip blanks, sample duplicates and matrix spike/matrix spike duplicates (MS/MSDs).

When applicable, the sample result summary tables will list the laboratory method detection limit (MDL) at which a compound was non-detectable. The laboratory results will be reported to the sample-specific practical quantitation limit (PQL), equal to the sample-specific MDL, supported by the instrument calibrations. The reliability of laboratory data is supported by compliance with sample holding times and laboratory MDLs below cleanup criteria. Accuracy and precision of the laboratory analytical methods will be maintained by the use of calibration and calibration verification procedures, laboratory control samples, and surrogate, matrix, and analytical spikes.

5.5 DATA MANAGEMENT AND VALIDATION

GZA will coordinate with the laboratory to prepare the laboratory analytical reports in accordance with NYSDEC ASP Category B data deliverables, which include:

- Sample Delivery Group Narrative;
- Contract Lab Sample Information sheets;
- NYSDEC Data Package Summary Forms;
- Chain-of-custody forms; and,
- Test analyses results (including TICs for analysis of VOCs and SVOCs).

Plus, related QA/QC information and documentation consisting of:

- Calibration standards;
- Surrogate recoveries;
- Blank results;
- Spike recoveries
- Duplicate results;
- Confirmation (lab check/QC) samples;
- Internal standard area and retention time summary;
- Chromatograms;
- Raw data files; and
- Other specific information as described in the most current NYSDEC ASP

GZA will coordinate with the laboratory to prepare the results in Electronic Data Deliverables (EDDs) format compatible with EQUIS that can be uploaded into an EQUIS database for storage and development of tables or output to other data analysis tools and GIS as needed. GZA will have a data validate evaluate the data package for inclusion into a DUSR that will subsequently be prepared to document the usability of the data. Additional details regarding QA/QC and data management and validation are included in **Appendix B – QAPP/FSP**.



5.6 CHAIN OF CUSTODY AND SHIPPING

A chain-of-custody form will trace the path of sample containers from the Site to the laboratory. The project manager will notify the laboratory of upcoming field sampling events and the subsequent transfer of samples. This notification will include information concerning the number and type of samples, and the anticipated date of arrival. Insulated sample shipping containers (typically coolers) will be provided by the laboratory for shipping samples. All sample bottles within each shipping container will be individually labeled with an adhesive identification label provided by the laboratory. Project personnel receiving the sample containers from the laboratory will check each cooler for the condition and integrity of the bottles prior to field work.

The field sampler will indicate the sample designation/location number in the space provided on the chain-of-custody form for each sample. The chain of custody forms will be signed and placed in a sealed plastic Ziploc bag in the cooler. If sent via third party carrier, the shipping container will be closed for transport with nylon strapping, or a similar shipping tape, and a paper custody seals will be affixed to the lid. The seals must be broken to open the cooler and will indicate tampering if the seals are broken before receipt at the laboratory. A label may be affixed identifying the cooler as containing "Environmental Samples" and the cooler will be shipped via courier or by an overnight delivery service to the laboratory. When the laboratory receives the coolers, the custody seals will be checked, and lab personnel will sign the chain-of-custody form.

The following typical Chain-Of-Custody procedures will be implemented by GZA during the soil sampling:

- A. The samples are under custody of the GZA field personnel, if:
 - 1. they are in his/her possession,
 - 2. they are in view after being in possession,
 - 3. they are locked up or sealed securely to prevent tampering, or
 - 4. they are in a designated secure area.
- B. The original of the chain-of-custody form must accompany the samples at all times after collection, until receipt at the analytical laboratory. A copy of the chain-of-custody form will be kept by the sample collector until it is filed in the project file.
- C. When the possession of samples is transferred, the individuals relinquishing and receiving the samples will sign, date, and note the time on the Chain-Of-Custody form.
- D. When samples are shipped, the GZA personnel, or designated representative, will note the courier's name, and air bill number, if applicable, on the Chain-Of-Custody form. Prior to shipping, coolers will be secured with signed custody seals so the laboratory may confirm coolers were not opened during shipping.

The chain-of-custody form will contain information to distinguish each sample from any other sample. This information will include:

- A. The project name and address for which sampling is being conducted;
- B. The name(s) and signature(s) of sampler(s);
- C. The matrix being sampled (groundwater, soil, etc.);
- D. The sampling date and time;
- E. The specific sampling location in sufficient detail to allow re-sampling at the same location;
- F. The number of containers and the volume of sample collected, and
- G. The analytical method to be performed.



5.7 STORAGE AND DISPOSAL OF INVESTIGATION-DERIVED WASTE

Investigation derived waste (IDW) generated during the RI will be containerized and properly characterized and disposed of. Containers, which are USDOT approved storage containers (55-gallon drums) or a small bulk roll-off container, will be properly labeled and grouped by environmental matrix (soil, water, PPE/plastic, etc.). All drums or roll-offs will be staged in a central location on-Site prior to off-Site disposal.

If drums are used, they will be tracked as they are filled and given unique identification codes based on the following:

- A prefix indicating the drum's contents: i.e., S – Soil, W – Water, P – PPE/Plastic, and C&D – Construction Debris.
- Following the prefix and a hyphen will be the origin of the drum's contents. For example, drum SB-1, SB-2, SB-3 is a generated drum filled with soil from soil boring locations SB-1, SB-2 and SB-3; drum MW-1 is water generated from monitoring well MW-1.
- As drums are generated, their identification code, date of generation, contents, source (i.e., drill cuttings from location x, purge water from well y), and date sampled will be entered on a tracking table.

The drums (or roll-off container) will be centrally stored on-Site. Subsequently, the waste soils and/or water will be characterized with laboratory analyses for proper disposal.

6.0 **QUALITATIVE HUMAN HEALTH EXPOSURE ASSESSMENT**

A QHHEA will be performed following the collection of all RI data. The Exposure Assessment (EA) will be performed in accordance with Section 3.3(c)4 of DER-10 and the NYSDOH guidance for performing a qualitative EA (DER-10; Appendix 3B). The QHHEA will characterize the exposure setting, identify potentially complete exposure pathways, and qualitatively evaluate potential fate and transport of constituents from one medium to another (i.e., soil-to-air or soil-to-groundwater).

An exposure pathway is considered complete when the following five conditions are met:

1. Source identified (i.e., metals in paint on exterior building surfaces);
2. Release and transport mechanism from source to environmental media (i.e., into the subsurface or volatilization to the air of an overlying building);
3. Point of human exposure (i.e., an occupied building or surface soil);
4. A route of exposure (ingestion, dermal contact, or inhalation), and
5. A receptor population (i.e., on-site workers).

Once potentially complete exposure pathways are identified, the QHHEA will characterize Site conditions to determine whether the Site poses an existing or potential future hazard to the potentially exposed population. The evaluation will include a qualitative discussion of potential fate and transport mechanisms at the Site. The results of the QHHEA will be included as part of the RIR.

According to Section 3.10 of DER-10, and the Fish and Wildlife Resources Impact Analysis Decision Key in DER-10 Appendix 3C, a Fish and Wildlife exposure assessment will be performed (if needed) based on the results of the RI.



7.0 HEALTH AND SAFETY

The work outlined above will be completed under a GZA site-specific Health and Safety Plan (HASP), attached as **Appendix D** in accordance with OSHA Hazardous Waste Operations and Emergency Response (HAZWOPER) regulations. A photoionization detector (PID) will be used to monitor the breathing zone of workers performing investigative activities in areas where there is a potential for the presence of organic vapors (i.e., groundwater and soil vapor sampling). A dust meter will also be used to screen for dust in the breathing zone that has the potential presence of metal contamination. GZA anticipates the work will be completed in Modified Level D personal protective equipment (PPE); however, workers will be prepared to elevate to more protective PPE based on the conditions encountered during field activities.

7.1 PROJECT KICKOFF AND UTILITY CLEARANCE

A project kick-off meeting will be held prior to initiating field work to orient field team members and subcontractors with the Site background, scope of work, potential hazards, health and safety requirements, emergency contingencies and other field procedures.

Prior to performing any subsurface work, a utility clearance survey will be performed in accordance with New York State Dig-Safe protocol. Sample locations will be screened using surface geophysical techniques such as electromagnetic (EM), ground penetrating radar (GPR) and/or radiofrequency (RF) techniques.

7.2 COMMUNITY AIR MONITORING PLAN (CAMP)

Real-time air monitoring for VOCs and particulate levels at the perimeter of the exclusion zone or work area will be performed in accordance with the CAMP (see **Appendix E**).

Continuous air monitoring will be required during ground intrusive activities and other activities where equipment is disturbing the ground surface. Ground intrusive activities include, but are not limited to, soil/fill excavation and handling, test pitting or trenching, grading of existing Site soils and the installation of soil borings or monitoring wells.

Periodic monitoring for VOCs will be required during non-intrusive activities such as the collection of soil and sediment samples or the collection of groundwater samples from existing monitoring wells. Periodic monitoring during sample collection would generally consist of taking a reading upon arrival at a sample location, monitoring while opening a well cap or overturning soil, monitoring during well bailing/purging, and taking a reading prior to leaving a sample location.



VOC Monitoring, Response Levels, and Actions

VOCs will be monitored at the Site perimeter on a continuous basis during earthwork activities unless otherwise specified in the CAMP. Upwind concentrations will be measured at the start of each workday and periodically thereafter to establish background conditions, particularly if wind direction changes. The VOC monitoring work will be performed using equipment appropriate to measure the types of contaminants known or suspected to be present. The equipment will be calibrated at least daily for the contaminant(s) of concern or for an appropriate surrogate. The equipment will be capable of calculating 15-minute running average concentrations, which will be compared to the levels specified below.

1. If the ambient air concentration of total organic vapors at the downwind perimeter of the work area or exclusion zone exceeds 5 parts per million (ppm) above background for the 15-minute average, work activities will be temporarily halted and monitoring continued. If the total organic vapor level readily decreases (per instantaneous readings) below 5 ppm over background, work activities will resume with continued monitoring.
2. If total organic vapor levels at the downwind perimeter of the work area or exclusion zone persist at levels in excess of 5 ppm over background but less than 25 ppm, work activities will be halted, the source of vapors will be identified, corrective actions will be taken to abate emissions, and monitoring will be continued. After these steps, work activities will resume provided that the total organic vapor level 200 feet downwind of the exclusion zone or half the distance to the nearest potential receptor or residential/commercial structure, whichever is less - but in no case less than 20 feet - is below 5 ppm over background for the 15-minute average.
3. If the organic vapor level is above 25 ppm at the perimeter of the work area, activities will be shut down until the source of the problem is identified and corrective action is taken to reduce organic vapor levels.
4. Fifteen-minute readings will be recorded and be available for State (NYSDEC and NYSDOH) personnel to review. Instantaneous readings, if any, used for decision purposes will also be recorded.

Particulate Monitoring, Response Levels, and Actions

Particulate concentrations will be monitored at the Site perimeter and in work zones on a continuous basis during earthwork. The particulate monitoring will be performed using real-time monitoring equipment capable of measuring particulate matter less than 10 micrometers in size (PM-10) and capable of integrating over a period of 15 minutes (or less) for comparison to the airborne particulate action level. The equipment will be equipped with an audible alarm to indicate exceedance of the action level. In addition, fugitive dust migration will be visually assessed during all work activities. Visible dust from the work area will trigger the initiation of dust suppression procedures. Dust suppression equipment will be on Site, functional and available at the work zone prior to commencing work.

1. If the downwind PM-10 particulate level is 100 micrograms per cubic meter (mcg/m³) greater than background (upwind perimeter) for the 15-minute period or if airborne dust is observed leaving the work area, then dust suppression techniques will be employed. Work will continue with dust suppression techniques provided that downwind PM-10 particulate levels do not exceed 150 mcg/m³ above the upwind level and provided that no visible dust is migrating from the work area.
2. If, after implementation of dust suppression techniques, downwind PM-10 particulate levels are greater than 150 mcg/m³ above the upwind level, work will be stopped, and a re-evaluation of activities



initiated. Work will resume provided that dust suppression measures and other controls are successful in reducing the downwind PM-10 particulate concentration to within 150 mcg/m³ of the upwind level and in preventing visible dust migration.

3. Readings will be recorded and be available for State (NYSDEC and NYSDOH) and County Health personnel to review.

8.0 REPORTING

Upon completion of the field activities, a Remedial Investigation Report (RIR) will be prepared to document the findings of the investigations performed at the Site and the proposed remedy. The RIR will be consistent with the specifications presented in the DER-10 document and will include:

- An executive summary;
- A site description and history;
- Summary information regarding previous investigations and remedial work performed at the Site;
- Descriptions of field activities performed;
- A summary of pertinent field observations, field measurements, and laboratory analytical data summarized in tabular format - analytical results will be compared to appropriate NYSDEC guidance and standards;
- Plan view and cross-section figures presenting laboratory analytical data and field observations of surface and subsurface soil and groundwater impacts. A minimum of two profiles will be developed, one perpendicular to and one parallel with groundwater flow direction at the Site;
- A qualitative human health risk assessment which assesses the sources of impact, on and off-site human and ecological receptors, and exposure pathways;
- A data usability review and DUSRs for the laboratory data collected during the RI;
- An integration of field observations and measurements with laboratory analytical data to evaluate the nature and extent of impacts and to develop a site conceptual model of potential contaminant migration;
- A Remedial Alternatives Analysis;
- A set of conclusions for the investigation; and
- Recommendations

Data collected during the RI will be submitted in the Department's Environmental Information Management System (EIMS) format for Electronic Data Delivery (EDD).

9.0 PROJECT SCHEDULE AND PROJECT PERSONNEL

Our anticipated schedule to perform the investigation activities described in this work plan is summarized below:



Description	Anticipated RI Schedule
Submission of BCP Application and RIWP to NYSDEC	4 th week of June 2024
Approval and commencement of Field Investigation	September 2024
Complete RIR and submit to NYSDEC	December 2024

We note that the proposed schedule may be adjusted if unforeseen delays occur due to inclement weather, Department of Transportation (DOT) permit approval, drill rig availability or other conditions that are beyond GZA's control.

The following GZA project personnel are proposed to be involved as part of the remedial investigation activities. Qualifications of personnel are provided in **Appendix F**. Drilling and laboratory subcontractors have not yet been retained.

Personnel	Role	Contact Information
Stephen M. Kline, P.E.	Consultant Reviewer	347-242-7109
Victoria D. Whelan, P.G.	Qualified Environmental Professional / Vice President	631-793-8821
Reinbill P. Maniquez	Senior Project Manager	347-443-1059
Jackson Bogach	Assistant Project Manager	332-215-6349
Mark Frey	Field Geologist	347-213-8324



Tables

Table1 - Sample Summary and Rationale

Remedial Investigation Work Plan
55 Eckford Street
Brooklyn, New York

Sample Name	Location	Sample / Boring Termination Depth (feet below ground level and cellar level)	Approximate Number of Samples	Rationale for Sampling	Laboratory Analysis
Soil					Analyses
GZ-10	Approximately 20 feet east and 10 feet south of the northwest property corner, on the western portion of the Site	15	2	To characterize soil conditions and delineate extent and depths of contamination	GZ-10 (0-2') - Full Suite; GZ-10 (WT) - Full suite
GZ-11	Approximately 45 feet south and 3 feet east of the northwest property corner, on the western portion of the Site	15	2		GZ-11 (0-2') - Full Suite; GZ-11 (WT) - Full suite
GZ-12	Approximately 10 feet east and 3 feet north from the southwest property corner	15	2		GZ-12 (0-2') - Full Suite; GZ-12 (WT) - Full suite
GZ-13	Approximately 65 feet east and 5 feet north from the southwest property corner	15	2		GZ-13 (0-2') - Full Suite; GZ-13 (WT) - Full suite
GZ-14	Approximately 85 feet south and 3 feet east from the northeast property corner	15	2		GZ-14 (0-2') - Full Suite; GZ-14 (WT) - Full suite
GZ-15	Approximately 15 feet south and 6 feet west of the northeast property corner	8	2	To characterize soil conditions and delineate extent and depths of contamination below existing cellar and structure.	GZ-15 (0-2') - Full Suite; GZ-15 (WT) - Full suite
GZ-16	Approximately 40 feet east and 30 feet north of the southwest property corner	8	2		GZ-16 (0-2') - Full Suite; GZ-16 (WT) - Full suite
GZ-17	Center middle portion of existing building	8	2		GZ-17 (0-2') - Full Suite; GZ-17(WT) - Full suite
GZ-18	Approximately 20 feet west and 13 feet north of the southeast property corner	8	2		GZ-18 (0-2') - Full Suite; GZ-18(WT) - Full suite
GZ-19	Center of the northern portion of existing building	8	2		GZ-19 (0-2') - Full Suite; GZ-19 (WT) - Full suite

Soil Analysis Description

Full Suite : Part 375 TCL VOCs + TICs, including 1-4 Dioxane (EPA Method SW 846 8260, isotope dilution for 1-4 Dioxane), TCL SVOCs + TICs (EPA Method 8270), pesticides/herbicides/PCBs (EPA Methods SW 846 8081/8151/8082), TAL metals (EPA Methods SW 846 6010/6020/7470), cyanide (EPA Method SW 846 9010/9012), and mercury (EPA Method SW 846 7471); PFAS (EPA Method 1633)

Notes:

WT = water table. Sample will be taken at the groundwater interface and include the sample depth, [e.g. GZ-10 (6-8')]

TCL = Target Compound List

TAL = Target Analyte List

VOCs + TICs = volatile organic compounds plus tentatively identified compounds

SVOCs + TICs = semi-volatile organic compounds plus tentatively identified compounds

PCBs = polychlorinated biphenyls

PFAS = per and polyfluoroalkyl substances

Table1 - Sample Summary and Rationale

Remedial Investigation Work Plan
55 Eckford Street
Brooklyn, New York

Sample Name	Location	Sample / Boring Termination Depth (feet below ground or cellar surface)	Approximate Number of Samples	Rationale for Sampling	Laboratory Analysis
Soil Vapor					Analysis
GSV-08	Approximately 45 feet south and 10 feet east of northwest existing building corner	5	1	To characterize the soil vapor and delineate the extent of impacts	EPA Method TO-15 for VOCs
GSV-09	Approximately 70 feet south and 1 foot east from the northeast existing building corner	5	1		
GSV-10	Approximately 30 feet east and 2 feet south from the northwest existing property corner	5	1		
GSV-11	Approximately 65 feet south and 4 feet east from the northwest existing property corner	5	1		
GSV-12	Approximately 35 feet east and 1 foot north from the southwest existing property corner	5	1		
GSV-13	Approximately 65 feet east and 2 feet north from the southwest existing building corner	5	1		
GSV-14	Approximately 70 feet south and 20 feet east of northwest existing building corner	5	1		
GSV-15	Approximately 20 feet west and 4 feet south of the northeast existing building corner	5	1		
Ambient Air/Indoor Air					Analysis
OA-01	Center of existing building	-3	1	To characterize the concentration of VOCs in ambient air and analyze vapor intrusion of the existing cellar	EPA Method TO-15 for VOCs
OA-02	Center of existing concrete yard	-3	1		

Sample Name	Location	Sample / Boring Termination Depth (feet below ground surface)	Approximate Number of Samples	Rationale for Sampling	Laboratory Analysis
Groundwater - Permanent Wells					Analyses
GMW-08	Approximately 15 feet south and 6 feet west of the northeast property corner	15	1	To characterize the groundwater conditions at the Site	Full Suite
GMW-09	Approximately 40 feet north and 6 feet west of the southeast property corner	15	1		Full Suite
GMW-10	Approximately 20 feet east and 10 feet south of the northwest property corner, on the western portion of the Site	15	1		Full Suite
GMW-11	Approximately 45 feet south and 3 feet east of the northwest property corner, on the western portion of the Site	15	1		Full Suite
GMW-12	Approximately 10 feet east and 3 feet north from the southwest property corner	15	1		Full Suite
GMW-13	Approximately 65 feet east and 5 feet north from the southwest property corner	15	1		Full Suite

Notes:


Based on the Previous Phase II Reports, the water table is anticipated to be between 7 to 13 feet below ground surface.

Groundwater Analysis Description

Full Suite: TCL VOCs + TICs, including 1-4 Dioxane (EPA Method SW 846 8260, isotope dilution for 1-4 Dioxane), TCL SVOCs + TICs (EPA Method SW 846 8270), pesticides/herbicides/PCBs (EPA Methods SW 846 8081/8151/8082), total and dissolved TAL metals (EPA Methods SW 846 6010/6020/7470), cyanide (EPA Method SW 846 9010/9012), and mercury (EPA Method SW 846 7471); PFAS (EPA Method 1633)




Figures



SOURCE:

USGS TOPOGRAPHIC MAPS: BROOKLYN, NEW YORK (2023).
CONTOUR INTERVAL 10FT., NAVD-1988, ORIGINAL SCALE
1:24,000 (1IN.=2,000FT.).



UNLESS SPECIFICALLY STATED BY WRITTEN AGREEMENT, THIS DRAWING IS THE SOLE PROPERTY OF GZA GEOENVIRONMENTAL, INC. (GZA). THE INFORMATION SHOWN ON THE DRAWING IS SOLELY FOR USE BY GZA'S CLIENT OR THE CLIENT'S DESIGNATED REPRESENTATIVE FOR THE SPECIFIC PROJECT AND LOCATION IDENTIFIED ON THE DRAWING. THE DRAWING SHALL NOT BE TRANSFERRED, REUSED, COPIED, OR ALTERED IN ANY MANNER FOR USE AT ANY OTHER LOCATION OR FOR ANY OTHER PURPOSE WITHOUT THE PRIOR WRITTEN CONSENT OF GZA. ANY TRANSFER, REUSE, OR MODIFICATION TO THE DRAWING BY THE CLIENT OR OTHERS, WITHOUT THE PRIOR WRITTEN EXPRESS CONSENT OF GZA, WILL BE AT THE USER'S SOLE RISK AND WITHOUT ANY RISK OR LIABILITY TO GZA.

55 ECKFORD STREET
BROOKLYN, NEW YORK

PREPARED BY:

 **GZA**GeoEnvironmental of NY
Engineers and Scientists
www.gza.com

PREPARED FOR:

55 ECKFORD ST LLC

SITE LOCATION MAP

PROJ MGR:	VW	REVIEWED BY:	SK
DESIGNED BY:	VW	DRAWN BY:	NQ
DATE:	JUNE 2024	PROJECT NO.	41.0163263.00

CHECKED BY:	SK
SCALE:	1"=2000'
REVISION NO.	-

FIGURE
1

SHEET NO. 1 OF 10

©2024 - GZA GeoEnvironmental of NY.
GZA-J:\Active 163200 to 163299\163263.00 - 55 Eckford St BCP\Drawings\GZA CAD\55 Eckford.dwg [FIG 2 - Site Plan Aerial] May 31, 2024 - 12:36pm jackson.bogach





GENERAL NOTES

1. AERIAL IMAGERY DEVELOPED FROM © 2024 MICROSOFT CORPORATION 2024 MAXAR CNES (2024) DISTRIBUTION AIRBUS DS.

LEGEND

APPROXIMATE SITE BOUNDARY



NO.	ISSUE/DESCRIPTION	BY	DATE
UNLESS SPECIFICALLY STATED BY WRITTEN AGREEMENT, THIS DRAWING IS THE SOLE PROPERTY OF GZA GEOENVIRONMENTAL, INC. (GZA). THE INFORMATION SHOWN ON THE DRAWING IS SOLELY FOR USE BY GZA'S CLIENT OR THE CLIENT'S DESIGNATED REPRESENTATIVE FOR THE SPECIFIC PROJECT AND LOCATION IDENTIFIED ON THE DRAWING. THE DRAWING SHALL NOT BE TRANSFERRED, REUSED, COPIED, OR ALTERED IN ANY MANNER FOR USE AT ANY OTHER LOCATION OR FOR ANY OTHER PURPOSE WITHOUT THE PRIOR WRITTEN CONSENT OF GZA. ANY TRANSFER, REUSE, OR MODIFICATION TO THE DRAWING BY THE CLIENT OR OTHERS, WITHOUT THE PRIOR WRITTEN EXPRESS CONSENT OF GZA, WILL BE AT THE USER'S SOLE RISK AND WITHOUT ANY RISK OR LIABILITY TO GZA.			
55 ECKFORD STREET BROOKLYN, NEW YORK			
SITE PLAN			
PREPARED BY:  GZA GeoEnvironmental of NY Engineers and Scientists www.gza.com		PREPARED FOR: 55 ECKFORD ST LLC	
PROJ MGR: RM	REVIEWED BY: VW	CHECKED BY: VW	FIGURE 2 SHEET NO. 2 OF 11
DESIGNED BY: RM	DRAWN BY: NQ	SCALE: 1"=50"	
DATE: JUNE 2024	PROJECT NO. 41.0163263.00	REVISION NO. -	



ADJACENT VACANT LOT
(FORMER CARTER SPRAY
FINISHING, CORP)

SP-2			
Depth	0' - 2'	6' - 8'	
CVOCs	(mg/ Kg)	(mg/ Kg)	USCO
Methylene chloride	0.23	1.1	0.05
Trichloroethylene	ND	0.93	0.47

B-3	
Depth	9' - 11' (mg/ Kg)
CVOCs	ND

SP-3			
Depth	0' - 2'	6' - 8'	
CVOCs	(mg/ Kg)	(mg/ Kg)	USCO
Methylene chloride	0.037	1.0	0.05
Trichloroethylene	ND	0.21	0.47

SP-4			
Depth	0' - 2'	6' - 8'	
CVOCs	(mg/ Kg)	(mg/ Kg)	USCO
Methylene chloride	0.070	1.1	0.05
Trichloroethylene	0.23	1.2	0.47
Tetrachloroethylene	ND	0.13	1.8

B-2	
Depth	11' - 13' (mg/ Kg)
CVOCs	ND

SP-1			
Depth	0' - 2'	8' - 10'	
CVOCs	(mg/ Kg)	(mg/ Kg)	USCO
Methylene chloride	0.022	0.046	0.05
Trichloroethylene	ND	0.0056	0.47

B-1	
Depth	12' - 14' (mg/ Kg)
CVOCs	ND

SP-7			
Depth	0' - 2'	9' - 11'	
CVOCs	(mg/ Kg)	(mg/ Kg)	USCO
Methylene chloride	ND	0.021	0.05
Trichloroethylene	0.019	0.047	0.47
Tetrachloroethylene	ND	0.021	1.8

B-4		
Depth	11' - 12'	
CVOCs	(mg/ Kg)	USCO
sec-Butylbenzene	20	11

B-5		
Depth	11 - 12' (mg/ Kg)	12' - 13' (mg/ Kg)
CVOCs	ND	ND

B-6	
Depth	13' - 15' (mg/ Kg)
CVOCs	ND

SP-5			
Depth	0' - 2'	10' - 12'	
CVOCs	(mg/ Kg)	(mg/ Kg)	USCO
Methylene chloride	0.018	ND	0.05
Trichloroethylene	ND	0.010	0.47

ECKFORD STREET

SIDEWALK

ELEVATOR
IN BASEMENT

PARTIAL CELLAR

UNFINISHED MULTI STORY
METAL FRAME CONSTRUCTION


GENERAL NOTES


- BASE MAP DEVELOPED FROM DRAWING TITLED "FIGURE 1: MAP OF CHLORINATED COMPOUNDS OF CONCERN (CVOCs) IN SOIL", PREPARED BY "HYDRO TECH ENVIRONMENTAL ENGINEERING AND GEOLOGY DPC", ORIGINAL SCALE 1"=10', DATED 01/20/20.
- EXPLORATION LOCATIONS SHOWN ARE BASED ON TAPE MEASUREMENTS FROM TOPOGRAPHICAL FEATURES. THE LOCATIONS SHOULD BE CONSIDERED ACCURATE ONLY TO THE DEGREE IMPLIED BY THE METHOD USED.
- ELEVATIONS ARE REFERENCED TO THE NORTH AMERICAN VERTICAL DATUM OF 1988 (NAVD88)


SP-6			
Depth	0' - 2'	8' - 10'	
CVOCs	(mg/ Kg)	(mg/ Kg)	USCO
Methylene chloride	0.019	0.045	0.05
Trichloroethylene	ND	0.007	0.47

LEGEND:

- ⊕ SOIL PROBE LOCATIONS (SP) - INSTALLED BY HTE DURING FEBRUARY 2012
- SOIL PROBE LOCATION (SP) - INSTALLED BY HTE DURING MARCH 2012
- ① SOIL PROBE LOCATIONS (B) - INSTALLED BY EEA, INC DURING DECEMBER 2011
- SOIL PROBE LOCATIONS (B) - INSTALLED BY EEA, INC DURING DECEMBER 2011
- CVOCs CHLORINATED VOLATILE ORGANIC COMPOUNDS
- USCO UNRESTRICTED USE SOIL CLEANUP OBJECTIVE
- mg/ Kg MILLIGRAMS PER KILOGRAMS
- SHADED VALUES EXCEED USCO
- ND NONE DETECTED



NO.		ISSUE/DESCRIPTION	BY	DATE
UNLESS SPECIFICALLY STATED BY WRITTEN AGREEMENT, THIS DRAWING IS THE SOLE PROPERTY OF GZA. GEOENVIRONMENTAL, INC. (GZA). THE INFORMATION SHOWN ON THE DRAWING IS SOLELY FOR USE BY GZA'S CLIENT OR THE CLIENT'S DESIGNATED REPRESENTATIVE FOR THE SPECIFIC PROJECT AND LOCATION IDENTIFIED ON THE DRAWING. THE DRAWING SHALL NOT BE TRANSFERRED, REUSED, COPIED, OR ALTERED IN ANY MANNER FOR USE AT ANY OTHER LOCATION OR FOR ANY OTHER PURPOSE WITHOUT THE PRIOR WRITTEN CONSENT OF GZA. ANY TRANSFER, REUSE, OR MODIFICATION TO THE DRAWING BY THE CLIENT OR OTHERS, WITHOUT THE PRIOR WRITTEN EXPRESS CONSENT OF GZA, WILL BE AT THE USER'S SOLE RISK AND WITHOUT ANY RISK OR LIABILITY TO GZA.				
55 ECKFORD STREET BROOKLYN, NEW YORK				
PHASE II ESI (2020) SOIL CHEMISTRY EXCEEDANCES - CVOCs				
PREPARED BY:  GZA GeoEnvironmental of NY Engineers and Scientists www.gza.com		PREPARED FOR: 55 ECKFORD ST LLC		
PROJ MGR: RM	REVIEWED BY: VW	CHECKED BY: VW	FIGURE	
DESIGNED BY: RM	DRAWN BY: NQ	SCALE: 1"=20"	3A	
DATE: JUNE 2024	PROJECT NO. 41.0163263.00	REVISION NO. -	SHEET NO. 9 OF 11	




GENERAL NOTES

- BASE MAP DEVELOPED FROM DRAWING TITLED "FIGURE 2: METALS OF CONCERN IN SOIL", PREPARED BY "HYDRO TECH ENVIRONMENTAL CORP", ORIGINAL SCALE 1"=10', DATED 04/03/11.
- EXPLORATION LOCATIONS SHOWN ARE BASED ON TAPE MEASUREMENTS FROM TOPOGRAPHICAL FEATURES. THE LOCATIONS SHOULD BE CONSIDERED ACCURATE ONLY TO THE DEGREE IMPLIED BY THE METHOD USED.
- ELEVATIONS ARE REFERENCED TO THE NORTH AMERICAN VERTICAL DATUM OF 1988 (NAVD88)




UNLESS SPECIFICALLY STATED BY WRITTEN AGREEMENT, THIS DRAWING IS THE SOLE PROPERTY OF GZA GEOENVIRONMENTAL, INC. (GZA). THE INFORMATION SHOWN ON THE DRAWING IS SOLELY FOR USE BY GZA'S CLIENT OR THE CLIENT'S DESIGNATED REPRESENTATIVE FOR THE SPECIFIC PROJECT AND LOCATION IDENTIFIED ON THE DRAWING. THE DRAWING SHALL NOT BE TRANSFERRED, REUSED, COPIED, OR ALTERED IN ANY MANNER FOR USE AT ANY OTHER LOCATION OR FOR ANY OTHER PURPOSE WITHOUT THE PRIOR WRITTEN CONSENT OF GZA. ANY TRANSFER, REUSE, OR MODIFICATION TO THE DRAWING BY THE CLIENT OR OTHERS, WITHOUT THE PRIOR WRITTEN EXPRESS CONSENT OF GZA, WILL BE AT THE USER'S SOLE RISK AND WITHOUT ANY RISK OR LIABILITY TO GZA.			
55 ECKFORD STREET BROOKLYN, NEW YORK			
SOIL CHEMISTRY EXCEEDANCES - METALS			
PREPARED BY: GZA GeoEnvironmental of NY Engineers and Scientists www.gza.com		PREPARED FOR: 55 ECKFORD ST LLC	
PROJ MGR: RM	REVIEWED BY: VW	CHECKED BY: VW	FIGURE 3B SHEET NO. 9 OF 11
DESIGNED BY: RM	DRAWN BY: NQ	SCALE: 1"=20"	
DATE: JUNE 2024	PROJECT NO. 41.0163263.00	REVISION NO. -	



GENERAL NOTES

1. BASE MAP DEVELOPED FROM DRAWING TITLED "FIGURE 3: MAP OF METALS OF CONCERN IN GROUNDWATER", PREPARED BY "HYDRO TECH ENVIRONMENTAL CORP", ORIGINAL SCALE 1"=10', DATED 01/20/20.
2. EXPLORATION LOCATIONS SHOWN ARE BASED ON TAPE MEASUREMENTS FROM TOPOGRAPHICAL FEATURES. THE LOCATIONS SHOULD BE CONSIDERED ACCURATE ONLY TO THE DEGREE IMPLIED BY THE METHOD USED.
3. ELEVATIONS ARE REFERENCED TO THE NORTH AMERICAN VERTICAL DATUM OF 1988 (NAVD88)


NO.	ISSUE/DESCRIPTION	BY	DATE
UNLESS SPECIFICALLY STATED BY WRITTEN AGREEMENT, THIS DRAWING IS THE SOLE PROPERTY OF GZA GEOENVIRONMENTAL, INC. (GZA). THE INFORMATION SHOWN ON THE DRAWING IS SOLELY FOR USE BY GZA'S CLIENT OR THE CLIENT'S DESIGNATED REPRESENTATIVE FOR THE SPECIFIC PROJECT AND LOCATION IDENTIFIED ON THE DRAWING. THE DRAWING SHALL NOT BE TRANSFERRED, REUSED, COPIED, OR ALTERED IN ANY MANNER FOR USE AT ANY OTHER LOCATION OR FOR ANY OTHER PURPOSE WITHOUT THE PRIOR WRITTEN CONSENT OF GZA. ANY TRANSFER, REUSE, OR MODIFICATION TO THE DRAWING BY THE CLIENT OR OTHERS, WITHOUT THE PRIOR WRITTEN EXPRESS CONSENT OF GZA, WILL BE AT THE USER'S SOLE RISK AND WITHOUT ANY RISK OR LIABILITY TO GZA.			
55 ECKFORD STREET BROOKLYN, NEW YORK			
PHASE II ESI (2020) - GROUNDWATER CHEMISTRY EXCEEDANCES - METALS			
PREPARED BY: GZA GeoEnvironmental of NY Engineers and Scientists www.gza.com		PREPARED FOR: 55 ECKFORD ST LLC	
PROJ MGR: RM	REVIEWED BY: VW	CHECKED BY: VW	FIGURE 4 SHEET NO. 10 OF 11
DESIGNED BY: RM	DRAWN BY: NQ	SCALE: 1"=20"	
DATE: JUNE 2024	PROJECT NO. 41.0163263.00	REVISION NO. -	



GENERAL NOTES

1. BASE MAP DEVELOPED FROM DRAWING TITLED "FIGURE 4: MAP OF CVOCs IN SOIL VAPOR", PREPARED BY "HYDRO TECH ENVIRONMENTAL CORP", ORIGINAL SCALE 1"=10', DATED 01/20/20.
2. EXPLORATION LOCATIONS SHOWN ARE BASED ON TAPE MEASUREMENTS FROM TOPOGRAPHICAL FEATURES. THE LOCATIONS SHOULD BE CONSIDERED ACCURATE ONLY TO THE DEGREE IMPLIED BY THE METHOD USED.
3. ELEVATIONS ARE REFERENCED TO THE NORTH AMERICAN VERTICAL DATUM OF 1988 (NAVD88)

NO.	ISSUE/DESCRIPTION	BY	DATE
UNLESS SPECIFICALLY STATED BY WRITTEN AGREEMENT, THIS DRAWING IS THE SOLE PROPERTY OF GZA GEOENVIRONMENTAL, INC. (GZA). THE INFORMATION SHOWN ON THE DRAWING IS SOLELY FOR USE BY GZA'S CLIENT OR THE CLIENT'S DESIGNATED REPRESENTATIVE FOR THE SPECIFIC PROJECT AND LOCATION IDENTIFIED ON THE DRAWING. THE DRAWING SHALL NOT BE TRANSFERRED, REUSED, COPIED, OR ALTERED IN ANY MANNER FOR USE AT ANY OTHER LOCATION OR FOR ANY OTHER PURPOSE WITHOUT THE PRIOR WRITTEN CONSENT OF GZA. ANY TRANSFER, REUSE, OR MODIFICATION TO THE DRAWING BY THE CLIENT OR OTHERS, WITHOUT THE PRIOR WRITTEN EXPRESS CONSENT OF GZA, WILL BE AT THE USER'S SOLE RISK AND WITHOUT ANY RISK OR LIABILITY TO GZA.			
55 ECKFORD STREET BROOKLYN, NEW YORK			
PHASE II ESI (2020) - SOIL VAPOR DETECTIONS - CVOCs			
PREPARED BY: GZA GeoEnvironmental of NY Engineers and Scientists www.gza.com		PREPARED FOR: 55 ECKFORD ST LLC	
PROJ MGR: RM	REVIEWED BY: VW	CHECKED BY: VW	FIGURE 5 SHEET NO. 11 OF 11
DESIGNED BY: RM	DRAWN BY: NQ	SCALE: 1"=20"	
DATE: JUNE 2024	PROJECT NO. 41.0163263.00	REVISION NO. -	




55 ECKFORD STREET BROOKLYN, NEW YORK			
FIGURE 6 - PROPOSED REMEDIAL INVESTIGATION SAMPLE LOCATIONS			
PREPARED BY: GZA GeoEnvironmental of NY Engineers and Scientists www.gza.com		PREPARED FOR: BROOKLYN PUBLIC LIBRARY WILLIAMSBURG	
PROJ MGR: RM	DESIGNED BY: RM	REVIEWED BY: VW	CHECKED BY: VW
DATE: JUNE 2024	PROJECT NO. 41.0163263.00	SCALE: 1"= 20'	REVISION NO. -
FIGURE 6			SHEET NO. 1 OF 1



Appendix A – Proposed Redevelopment Plans

ENGERT AVENUE
(60' WIDE)



LEGEND
(FOR TITLE PURPOSES)
JOB # K-2698-32-13



Certify Only To:

- * Eckford-Greenpoint LLC
- * Confidential Lending LLC, ISAQA
- * Reliable Abstract Co., LLC
- * Old Republic National Title Insurance Company



UPDATE SURVEY
OCTOBER 13, 2013

SURVEY
JAN. 8, 2013

TITLE SURVEY

UNAUTHORIZED ALTERATIONS OR ADDITIONS TO THIS SURVEY IS A VIOLATION OF SECTION 7209 OF THE NEW YORK STATE EDUCATION LAW. COPIES OF THIS SURVEY MAP NOT BEARING THE LAND SURVEYOR'S INKED SEAL OR EMBOSSED SEAL SHALL NOT BE CONSIDERED TO BE A VALID TRUE COPY. GUARANTEES OR CERTIFICATIONS INDICATED HEREON SHALL RUN ONLY TO THE PERSON FOR WHOM THE SURVEY IS PREPARED, AND ON HIS BEHALF TO THE TITLE COMPANY, GOVERNMENTAL AGENCY AND LENDING INSTITUTION LISTED HEREON, AND TO THE ASSIGNEES OF THE LENDING INSTITUTION. GUARANTEES OR CERTIFICATIONS ARE NOT TRANSFERABLE TO ADDITIONAL INSTITUTIONS OR SUBSEQUENT OWNERS.

BLOCK _____ 2698
LOT _____ 32
SECTION _____ 8
COUNTY _____ KINGS
DWG BY _____ AAA
CHKD BY _____




AAA GROUP

LAND SURVEYORS SERVICES
100-A BROADWAY

BROOKLYN, N.Y. 11249

TEL (718) 387-9800, FAX 384-5050

SCALE 1"=16'
GRAPHIC SCALE



ECKFORD

(60' WIDE)
(30'± WIDE ASPHALT ROADWAY)
← TWO WAY TRAFFIC →

STREET



June 2024
55 Eckford Street, Brooklyn, NY
Remedial Investigation Work Plan
File No. 41.0163263.00

Appendix B – Quality Assurance Project Plan / Field Sampling Plan



Known for excellence.
Built on trust.

QUALITY ASSURANCE PROJECT PLAN (QAPP) / FIELD SAMPLING PLAN (FSP)

**55 ECKFORD ST LLC SITE
55 Eckford Street
Brooklyn, New York 11222
Block 2698, Lot 32**

Revised June 2024

PREPARED FOR:

55 Eckford St LLC

110-50 69th Avenue

Forest Hills, NY 11375

PREPARED BY:

Goldberg Zoino Associates of New York, P.C.

d/b/a GZA GeoEnvironmental of New York

104 West 29th Street, 10th Floor

New York, NY 10001

File No. 41.0163263.00



TABLE OF CONTENTS

1.0	INTRODUCTION	1
2.0	PROJECT ORGANIZATION AND RESPONSIBILITY	1
3.0	QA OBJECTIVES FOR DATA MANAGEMENT	2
4.0	SAMPLING PLAN	4
4.1.	UTILITY CLEARANCE	5
4.2.	TEST PIT SOIL SAMPLING	5
4.3.	DIRECT PUSH DRILLING SOIL SAMPLING	6
4.4.	SONIC DRILL RIG SOIL SAMPLING	6
4.5.	TEMPORARY WELL POINT INSTALLATION AND SAMPLING	8
4.6.	PERMANENT WELL INSTALLATION AND SAMPLING	8
4.6.1.	<i>Well Installation/Construction</i>	<i>8</i>
4.6.2.	<i>Well Development</i>	<i>9</i>
4.6.3.	<i>Well Purging</i>	<i>9</i>
4.6.4.	<i>Well Sampling</i>	<i>10</i>
4.7.	BOREHOLE ABANDONMENT	10
4.8.	MONITORING WELL ABANDONMENT	10
4.9.	SOIL REUSE AND WORKER HEALTH & SAFETY SAMPLING	11
4.10.	WASTE CHARACTERIZATION SAMPLING	11
4.10.1.	<i>Solid Waste</i>	<i>11</i>
4.10.2.	<i>Liquid Waste</i>	<i>11</i>
4.10.3.	<i>Grab versus Composite Sampling</i>	<i>12</i>
4.11.	SOIL GAS SAMPLING	12
4.12.	AMBIENT AIR SAMPLING	13
4.13.	QC SAMPLE COLLECTION	13
4.14.	SAMPLE PRESERVATION AND CONTAINERIZATION	14
4.15.	EQUIPMENT DECONTAMINATION	14
5.0	DOCUMENTATION AND CHAIN-OF-CUSTODY	15
5.1.	SAMPLE COLLECTION DOCUMENTATION	15
5.1.1.	<i>Field Notes</i>	<i>15</i>
5.1.2.	<i>Chain-of-Custody Records</i>	<i>16</i>
5.1.3.	<i>Sample Labeling</i>	<i>16</i>
5.2.	SAMPLE CUSTODY	18
5.2.1.	<i>Field Custody Procedures</i>	<i>19</i>
5.2.2.	<i>Laboratory Custody Procedures</i>	<i>20</i>
6.0	CALIBRATION PROCEDURES	20
6.1.	FIELD INSTRUMENTS	20



6.2.	LABORATORY INSTRUMENTS	21
7.0	SAMPLE PREPARATION AND ANALYTICAL PROCEDURES	21
8.0	DATA REDUCTION, VALIDATION, AND REPORTING	21
8.1.	DATA EVALUATION/VALIDATION	21
8.1.1.	Field Data Evaluation.....	21
8.1.2.	Data Usability	22
8.2.	IDENTIFICATION AND TREATMENT OF OUTLIERS	22
9.0	INTERNAL QUALITY CONTROL	23
10.0	CORRECTIVE ACTION.....	23
10.1.	IMMEDIATE CORRECTIVE ACTION.....	24

FIGURES

FIGURE 1 Site Location Plan

TABLE

TABLE 1A	Soil Criteria Table
TABLE 1B	Groundwater Criteria Table
TABLE 1C	Soil Vapor Criteria Table
TABLE 2	Analytical Parameters, Methods, Preservation, Holding Time and Container Requirements
TABLE 3	Typical Laboratory Data Quality Objectives: Soil, Sediment and Solid Waste Samples
TABLE 4	Typical Laboratory Data Quality Objectives: Aqueous Samples
TABLE 5	Typical Laboratory Data Quality Objectives: Soil Gas Samples
TABLE 6	QC Sample Preservation and Container Requirements

ATTACHMENTS

ATTACHMENT A Qualifications



1.0 INTRODUCTION

This Quality Assurance Project Plan (QAPP) and Field Sampling Plan (FSP) presents the organization, objectives, planned activities, and specific quality assurance/quality control (QA/QC) procedures associated with the Remedial Investigation Work Plan (RIWP) at the 55 Eckford St, Brooklyn, NY (Site). **Figure 1** presents a Site location map.

This QAPP/FSP describes specific protocols for field sampling, sample handling and storage, chain-of-custody, laboratory analysis, and data handling and management. Preparation of the Plan was based on EPA Quality Assurance Project Plan guidance documents, including:

EPA Requirements for Quality Assurance Project Plans (EPA QA/R-5, March 2001); and
Guidance for Quality Assurance Project Plans (EPA QA/G-5, December 2002).

The data generated from the analysis of samples will be used to determine the extent of contamination, identify impacted targets, and to compare the results of the remedial actions to site-specific cleanup goals. Potential parameters to be analyzed, including their respective quantitation limits (QLs), and data quality levels (DQLs), are provided in **Tables 1A through 1C**.

2.0 PROJECT ORGANIZATION AND RESPONSIBILITY

A qualified person will coordinate and manage the Site sampling and analysis program, data reduction, QA/QC, data validation, analysis, and reporting. A Stephen M. Kline, P.E. is a qualified environmental professional (QEP), as defined by the New York State Department of Environmental Conservation (NYSDEC) and will direct the sampling activities and coordinate laboratory and drilling activities. The intent of this QAPP/FSP is to be performed the RI in accordance with the technical guidance applicable to Technical Guidance for Site Investigation and Remediation (DER-10), and Sampling, Analysis and Assessment of Per- and Polyfluoroalkyl Substances (PFAS) under NYSDEC's Part 375 Remedial Programs dated April 2023.

A qualified person will ensure that the QA/QC plan is implemented and will oversee data validation. GZA's Senior Technical Specialist, Dr. Chunhua Liu will provide oversight and technical support for the sampling and analytical procedures followed acting as the project QA Officer. This individual has the broad authority to approve or disapprove project plans, specific analyses, and final reports. The QEP is independent from the data generation activities. In general, the QA officer will be responsible for reviewing and advising on all QA/QC aspects of this program.

Laboratories used will be New York State Department of Health Environmental (NYSDOH) Laboratory Approval Program (ELAP) certified laboratories. The laboratories will communicate directly with the sampler regarding the analytical results and reporting and will be responsible for providing all labels, sample containers, field blank water, trip blanks, shipping coolers, and laboratory documentation. Qualifications of the QA officer are provided in **Attachment A**.



3.0 QA OBJECTIVES FOR DATA MANAGEMENT

The analytical data will be provided by the laboratory using the NYSDEC Category B deliverable format. Analytical data collected for disposal characteristics that may be requested by off-site soil or wastewater disposal facilities will be provided in the format that the facility requests.

All analytical measurements will be made so that the results are representative of the media sampled and the conditions measured. Data will be reported in consistent dry weight units for solid samples [i.e., micrograms per kilogram ($\mu\text{g}/\text{kg}$) and/or milligram per kilogram (mg/kg), micrograms per liter ($\mu\text{g}/\text{L}$) or milligrams per liter (mg/L) for aqueous samples and in micrograms per cubic meter ($\mu\text{g}/\text{m}^3$) for soil vapor and air samples. **Table 2** presents the proposed samples, sampling and analytical parameters, analytical methods, sample preservation requirements and containers.

Quantitation Limits (QLs) are laboratory-specific and reflect those values achievable by the laboratory performing the analyses. Data Quality Levels (DQLs) are those reporting limits required to meet the objectives of the program (i.e., program action levels, cleanup standards, etc.). Data Quality Objectives (DQOs) define the quality of data and documentation required to support decisions made in the various phases of the data collection activities. The DQOs are dependent on the end uses of the data to be collected and are also expressed in terms of objectives for precision, accuracy, representativeness, completeness, and comparability.

The analytical methods to be used at this Site provide the highest level of data quality and can be used for purposes of risk assessment, evaluation of remedial alternatives and verification that cleanup standards have been met. However, in order to ensure that the analytical methodologies are capable of achieving the DQOs, measurement performance criteria have been set for the analytical measurements in terms of accuracy, precision, and completeness.

The overall QA objective is to develop and implement procedures for field sampling, chain-of-custody, laboratory analysis, and reporting which will provide results that are scientifically valid, and the levels of which are sufficient to meet DQOs. Specific procedures for sampling, chain of custody, laboratory instrument calibration, laboratory analysis, reporting of data, internal quality control, and corrective action are described in other sections of this QAPP/FSP.

Tables 3, 4, and 5 present the precision and accuracy requirements for each parameter to be analyzed. For quantitation limits for parameters associated with soil, sediment, and solid waste samples, the laboratory will be required to attempt to meet or surpass the parameter-specific limits listed in 6 NYCRR Part 375.

For quantitation limits for parameters associated with groundwater samples, the laboratory will be required to attempt to meet or surpass the parameter-specific limits for groundwater from the Division of Water Technical and Operational Guidance Series (TOGS 1.1.1) Ambient Water Quality Standards and Guidance Values. In certain instances, if the TOGS criteria are not achievable due to analytical limitations, the laboratory will report the lowest possible quantitation limit.

For quantitation limits for parameters associated with soil gas samples, the laboratory will be required to meet the parameter-specific limits from EPA's Draft Guidance for Evaluating the Vapor Intrusion to Indoor Air Pathway from Groundwater and Soils (Subsurface Vapor Intrusion Guidance), Table 3c-SG:



Question 5 Soil Gas Screening Levels for Scenario-Specific Vapor Attenuation Factors ($\alpha=2H10^{-3}$), November 2002. In certain instances, if these criteria are not achievable due to analytical limitations, the laboratory will report the lowest possible quantitation limits (see **Tables 1A through 1C** for affected analytes).

The QA objectives are defined as follows:

Accuracy is the closeness of agreement between an observed value and an accepted reference value. The difference between the observed value and the reference value includes components of both systematic error (bias) and random error.

Accuracy in the field is assessed through the adherence to all field instrument calibration procedures, sample handling, preservation, and holding time requirements, and through the collection of equipment blanks prior to the collection of samples for each type of equipment being used (e.g., split spoons, groundwater sampling pumps).

The laboratory will assess the overall accuracy of their instruments and analytical methods (independent of sample or matrix effects) through the measurement of “standards,” materials of accepted reference value. Accuracy will vary from analysis to analysis because of individual sample and matrix effects. In an individual analysis, accuracy will be measured in terms of blank results, the percent recovery (%R) of surrogate compounds in organic analyses, or %R of spiked compounds in matrix spikes (MSs), matrix spike duplicates (MSDs) and/or laboratory control samples (LCSs). This gives an indication of expected recovery for analytes tending to behave chemically like the spiked or surrogate compounds. **Tables 3, 4, and 5** summarize the laboratory accuracy requirements.

Precision is the agreement among a set of replicate measurements without consideration of the “true” or accurate value: i.e., variability between measurements of the same material for the same analyte. Precision is measured in a variety of ways including statistically, such as calculating variance or standard deviation.

Precision in the field is assessed through the collection and measurement of field duplicates (one extra sample in addition to the original field sample). Field duplicates will be collected at a frequency of one per twenty investigative samples per matrix per analytical parameter, with the exception of the Toxicity Characteristic Leaching Procedure (TCLP) parameters and parameters associated with wastewater samples. Precision will be measured through the calculation of relative percent differences (RPDs). The resulting information will be used to assess sampling and analytical variability. Field duplicate RPDs must be ≤ 50 for soil samples and ≤ 30 for aqueous samples. These criteria apply only if the sample and/or duplicate results are $>5x$ the quantitation limit; if both results are $\leq 5x$ the quantitation limit, the criterion will be doubled. Due to the uncertainty of available representative soil gas volume, field duplicates will not be collected for this matrix.

Precision in the laboratory is assessed through the calculation of RPD for duplicate samples. For organic soil, sediment and water analyses, laboratory precision will be assessed through the analysis of MS/MSD samples and field duplicates. For the inorganic analyses, laboratory precision will be assessed through the analysis of matrix duplicates and field duplicates. For soil gas analyses, laboratory precision will be assessed through the analysis of matrix duplicates. MS/MSD samples



or matrix duplicates will be performed at a frequency of one per twenty investigative samples per matrix per parameter. **Tables 3, 4, and 5** summarize the laboratory precision requirements.

Completeness is a measure of the amount of valid data obtained from a measurement system compared to the amount that was expected to be obtained under normal conditions. “Normal conditions” are defined as the conditions expected if the sampling plan was implemented as planned.

Field completeness is a measure of the amount of (1) valid measurements obtained from all the measurements taken in the project and (2) valid samples collected. The field completeness objective is greater than 90 percent.

Laboratory completeness is a measure of the amount of valid measurements obtained from all valid samples submitted to the laboratory. The laboratory completeness objective is greater than 95 percent.

Representativeness is a qualitative parameter that expresses the degree to which data accurately and precisely represent either a characteristic of a population, parameter variations at a sampling point, a process condition, or an environmental condition within a defined spatial and/or temporal boundary. To ensure representativeness, the sampling locations have been selected to provide coverage over a wide area and to highlight potential trends in the data. In addition, field duplicate samples will provide an additional measure of representativeness at a given location.

Representativeness is dependent upon the proper design of the sampling program and will be satisfied by ensuring that the Work Plans and QAPP are followed, and that proper sampling, sample handling, and sample preservation techniques are used.

Representativeness in the laboratory is ensured by using the proper analytical procedures, appropriate methods, and meeting sample holding times.

Comparability expresses the confidence with which one data set can be compared to another. Comparability is dependent upon the proper design of the sampling program and will be satisfied by ensuring that the Work Plans and QAPP are followed and that proper sampling techniques are used. Maximization of comparability with previous data sets is expected because the sampling design and field protocols are consistent with those previously used.

Comparability is dependent on the use of recognized EPA or equivalent analytical methods and the reporting of data in standardized units. Laboratory procedures are consistent with those used for previous sampling efforts.

4.0 SAMPLING PLAN

Environmental sampling may include soil, groundwater, soil vapor and sediment sampling. Additionally, wastes generated during remediation or development will be sampled and tested for characterization for disposal. Direct push drilling (GeoProbe[®]), sonic drilling, and/or test pit excavations will be the preferred methods for obtaining subsurface soil samples. However, other drilling methods including mud rotary and drive and wash may also be used if warranted by site conditions. Hand auger and/or hand-held sampling equipment will be the preferred method for collecting surficial and/or shallow soil



samples. Groundwater samples will be collected using bailers or peristaltic, bladder or submersible pumps. Soil vapor samples will be collected in SUMMA® canisters. Performing grab or composite sampling using appropriate hand-held sampling equipment will be the preferred method for waste characterization sampling.

4.1. Utility Clearance

New York State law requires that New York 811 be notified at least three working days prior to subsurface work is conducted to initiate the utility locating activities. Companies with subsurface utilities present will locate and mark out subsurface utility lines. However, New York 811 contractors will only locate utilities on public property and rights-of-way.

During the recent, subsurface investigations, GZA contracted for underground utilities within the Site, including electric lines, gas lines, storm and sanitary sewers, and communication lines will need to be located by survey and geophysical survey. If additional subsurface utility locating is considered necessary, a private locating company will be contracted to locate on-site utilities that have not been identified by New York 811 contractors or the Owner.

4.2. Test Pit Soil Sampling

Test pitting and/or excavating may be conducted during the RI, if necessary. Test pits will allow for visual characterization of subsurface soil conditions and the collection of grab soil samples. Prior to soil sample collection, headspace screening will be conducted to evaluate whether analysis of soil samples is warranted, and if so, which soils should be collected.

Prior to completing a test pit or excavation, underground utilities should be identified as discussed in **Section 4.1**. Should active, underground utilities be located in the vicinity of the intended excavation, hand or vacuum excavation methods should be employed, as appropriate, to confirm the location and depth prior to initiating the excavation.

The size and type of excavator used to complete the test pits will be selected based on the anticipated depth and overall size of the excavation required to meet the project objectives. At no time will field personnel enter a test pit/excavation unless it has been deemed safe to enter by an Excavation Competent person based on training and experience required by 29CFR 1926.652.

Grab soil/solid samples will be collected from the material or interval in question by retrieving a volume for analysis using a clean stainless steel, aluminum, or mild steel/ disposable scoop, trowel, spoon, or bucket auger and placing the soil in a cleaned stainless steel pan for homogenization before inserting into the sample container. Samples collected for analysis for volatile organic compounds and total organic halides will not be homogenized. Samples for volatile organics analysis and total organic halides will be placed directly into the sample container.

Composite samples will be collected in the same manner described above, except that the discrete sample volumes will be placed in a clean stainless steel pan and mixed to form the composite. Composite sampling will be performed for the following objectives:



- Waste characterization;
- Determination of the suitability of the soil for on-site re-use; and
- Evaluation of health and safety requirements for workers that will disturb the soil during subsequent construction work.

4.3. Direct Push Drilling Soil Sampling

This drilling method is typically used to collect shallow overburden soils and create boreholes for temporary monitoring well installations, or soil vapor sampling points. Sampling will be performed using four or five-foot-long acetate sleeves that will be advanced continuously to the desired depth below the surface. Soil samples from each sleeve will be screened using a photoionization detector (PID) to detect possible organic vapors. Organic vapor screening will be performed by slicing open the acetate sleeve, making a small slice in the soil column with a clean knife or sampling tool, inserting the PID probe and pushing the slice closed, and monitoring the soil for approximately 5 to 10 seconds. This procedure will be repeated at intervals along the soil column at the field geologist's discretion.

The samples will be examined for staining, discoloration, odors, and debris indicative of contamination (ash, coal fragments, wood chips, cinders, petroleum staining, etc.). Samples for laboratory analysis will be collected from the six-inch interval most likely to be contaminated, based on PID readings, discoloration, staining, and the field geologist's judgment (field conditions may require a section longer than six inches to make sufficient sample; however, this decision will be field-based).

The samples will be collected by cutting the soil in two places with a decontaminated steel, stainless steel, or aluminum trowel, spoon, or knife and homogenized in a decontaminated stainless steel pan before being placed in the sample bottles. Samples collected for analysis for VOCs and total organic halides will be placed directly into the sample containers without homogenization (as per EPA sampling method 5035A). Samplers will wear phthalate-free gloves such as nitrile (no latex will be used) and will avoid contact of the gloves with the sample. Clean metal/disposable instruments will be used to transfer samples. If there is insufficient soil volume in the spoon, then this will be made up by attempting a second direct push sleeve at the same depth, or by using the next immediate sample interval above or below this depth, if appropriate. If there is no recovery, then the sample depth will be skipped, and drilling will progress to the next depth interval.

Soil samples will be collected in laboratory provided containers and transported to a NYSDOH ELAP certified laboratory, under proper chain of custody procedures for analysis. Once the sample containers are filled, they will be immediately placed in the cooler with ice (in Ziploc plastic bags to prevent leaking) or synthetic ice packs to maintain the samples at below 4°C.

4.4. Sonic Drill Rig Soil Sampling

The sonic drilling system employs simultaneous high frequency vibration and low speed rotational motion along with down pressure to advance the cutting shoes of the drill string. This technique provides a continuous soil core and generates minimal cuttings. Due to the continuous sampling of the system,



accurate depictions of the stratigraphy and lithology of the overburden are obtained (minimal sloughing). Additionally, few cuttings are mobilized to the surface. Most of the formation material enters the core barrel, except small amounts, which are pushed into the borehole wall.

Drilling operations take place from the drill platform, which is about 4 feet above ground. Steel drill casing and core barrel are connected to the head from the work platform/support truck and are then hoisted to vertical in the derrick. Tool joints are connected and broken by a hydraulic vise/wrench that is in the base of the derrick. The sonic head is able to pivot 90 degrees to facilitate connection of the drilling rods.

The sonic drilling system uses an override core barrel system and can create a 4- or 6-inch diameter borehole. This is followed by the override casing drilled to the same depth as the core barrel cutting shoe. The core barrel is then removed, and cores are extruded into plastic sleeves. The outer casing prevents cross contamination and formation mixing and allows for a very controlled placement of wells.

GZA proposes to use a track-mounted sonic drill rig collecting soil continuously from either five-foot long or 10-foot long cores. Samples will be extruded from the core barrel into polyethylene sleeves. Once the plastic sleeve is cut open, soil will be screened using a PID to detect possible organic vapors. Organic vapor screening will be performed by making a small slice in the soil column with a clean knife or sampling tool, inserting the PID probe and pushing the slice closed, and monitoring the soil for approximately 5 to 10 seconds. This procedure will be repeated at intervals along the soil column at the field geologist's discretion.

The samples will be examined for staining, discoloration, odors, and debris indicative of contamination (ash, coal fragments, wood chips, cinders, petroleum staining, etc.) Samples for laboratory analysis will be collected from the six-inch interval most likely to be contaminated, based on PID readings, discoloration, staining, and the field geologist's judgment (field conditions may require a section longer than six inches to make sufficient sample; however, this decision will be field-based).

The samples will be collected by cutting the soil in two places with a decontaminated steel, stainless steel, or aluminum trowel, spoon, or knife and homogenized in a decontaminated stainless steel pan before being placed in the sample bottles. Samples collected for analysis for VOCs and total organic halides will be placed directly into the sample containers without homogenization (as per EPA sampling method 5035A). Samplers will wear phthalate-free gloves such as nitrile (no latex will be used) and will avoid contact of the gloves with the sample. Clean metal/disposable instruments will be used to transfer samples. If there is insufficient soil volume in the spoon, then this will be made up by attempting a second direct push sleeve at the same depth, or by using the next immediate sample interval above or below this depth, if appropriate. If there is no recovery, then the sample depth will be skipped, and drilling will progress to the next depth interval.

Soil samples will be collected in laboratory provided containers and transported to a NYSDOH ELAP certified laboratory, under proper chain of custody procedures for analysis. Once the sample containers



are filled, they will be immediately placed in the cooler with ice (in Ziploc plastic bags to prevent leaking) or synthetic ice packs to maintain the samples at below 4°C.

4.5. Temporary Well Point Installation and Sampling

If proposed for site characterization, temporary well points will be immediately installed in drilled soil direct-push soil borings by placing a one-inch diameter PVC screen and riser pipe directly into the borehole. No additional materials will be placed around the annular space. The screen will be set so as to straddle the water table. Temporary wells will not be purged prior to sample collection. Depth to water will be measured in each well point to provide data to approximate groundwater flow direction.

Groundwater samples will be collected from the temporary well point using a dedicated microbailer. The samples will be collected in sample bottles (pre-preserved, if appropriate), placed in iced coolers and removed from light immediately after collection. In addition, all sample bottles must be filled to the top so that no aeration of the samples occurs during transport. All bottles will be filled to avoid cascading and aeration of the samples, the goal being to minimize any precipitation of colloidal matter. Samples for dissolved metals will be collected in unpreserved containers and will be filtered and preserved at the laboratory within 24 hours of sampling. Samples will be transported to a NYSDOH ELAP certified laboratory under proper chain of custody procedures for analysis.

Screen and riser pipes will be removed from the borehole and the borehole will be backfilled.

4.6. Permanent Well Installation and Sampling

Groundwater sampling of permanent monitoring wells is described according to the following distinct phases of this work: well installation/construction, well development, well purging, and well sampling.

4.6.1. *Well Installation/Construction*

To collect representative groundwater samples, soil borings drilled with the sonic drilling method will be converted into permanent two-inch diameter monitoring wells. Groundwater monitoring wells will be constructed of threaded two-inch diameter PVC well casing and 20-slot well screen (to investigate the potential of floating product). The 10-foot screen will be set seven feet below the measured water table. Clean silica sand, Morie No. 1 or equivalent, will be placed in the annular space around the well to a minimum of one foot above the top of the well screen, two feet being optimal. Solid PVC riser, attached to the well screen, will extend to grade or above if the well is a stick-up. For a two-inch diameter well, the annular space for the filter pack should be 4 inches thick. A two-foot thick bentonite seal will then be placed above the sand pack and moistened with potable water for a minimum of 15 minutes before backfilling the remaining space with a cement-bentonite grout. If warranted by depth, filling will be completed using a tremie pipe placed below the surface of the grout. A stick-up or flush-mount protective casing with a locking well cap will then be installed, and a measuring point marked on each PVC well riser. Well construction diagrams will be prepared for each well.



4.6.2. Well Development

Following installation, the groundwater monitoring wells will be developed using a two-inch diameter submersible pump(s) (or equivalent) until the water is reasonably free of turbidity and field readings (pH, conductivity, temperature, and dissolved oxygen) sufficiently stabilize. Fifty nephelometric turbidity units (NTUs) or less will be the turbidity goal but not an absolute value. The wells will be developed aggressively to remove fines from the formation and sand pack. The wells will be allowed to equilibrate for seven days prior to sampling. The volume of water removed, the well development time, and field instrument readings will be recorded in the logbook.

4.6.3. Well Purging

The objective is to purge monitoring wells until turbidity stabilizes to a level as low as possible and this parameter will be given the greatest weight in determining when groundwater sampling may begin. With this objective in mind, a low-flow pump will be used to avoid entrainment of particulates within the well or from the formation. Groundwater from each well will be purged until parameters have stabilized. A turbidity level of fifty NTUs or less is the well purging goal, but not an absolute value before sampling. Other field parameters including temperature, conductivity, pH, and dissolved oxygen (DO) will also be monitored. As practical, all field measurements will be taken from the flow cell and will be recorded during and after purging, and before sampling. Field parameters should generally be within ± 10 percent for three consecutive readings, one minute apart, prior to sampling.

Upon opening each monitoring well and point, the concentration of VOCs in the headspace will be measured using a PID and water level measurements will be recorded using an electronic interface probe. The depth to product (if present), depth to water, and the total depth will be measured from the top of the marked PVC casings. Water level and free product measurements will first be made and the volume of water in the well determined. The volume of water in the well will be calculated so that the number of well volumes purged and an estimate of the time required to purge the well can be made. Before sampling, the wells will be purged utilizing a low-flow submersible stainless steel pump using dedicated Teflon® or Teflon®-lined polyethylene tubing connected to a flow cell. Very low purging rates are proposed, on the order of 100 ml/minute to 500 ml/minute, to minimize suspension of particulate matter in the well.

Purging will be done with the pump intake placed at the midpoint of the well screen or the midpoint of the water column (to be determined based on the depth and length of the screen interval) to ensure that all stagnant water in the well is removed, while not stirring up sediment that may have accumulated on the bottom of the well. Equipment will be lowered into the well very carefully to prevent suspension of bottom sediment and subsequent entrainment onto sampling equipment. Surging will be avoided. Tubing will be replaced between each well. Pumps must be carefully cleaned between wells according to the procedures specified in **Section 4.15**, below. It is anticipated that no more than three well volumes will be purged in order for turbidity to reach a minimum and the other parameters to stabilize. Ideally,



pumping rates will be at a rate so that no drawdown of the groundwater level occurs (i.e., pumping rate is less than recharge rate). During purging, the sampler will actively monitor and track the volume of water purged and the field parameter readings. Data will be recorded in the field logbook. For example, the sampler will record the running total volume purged from each well and note the readings for the corresponding field parameters.

4.6.4. Well Sampling

Once groundwater conditions have stabilized and groundwater levels have recovered, samples will be collected from the flow cell outlet (connected to the low-flow submersible pump). All non-disposable/non-dedicated (re-usable) sampling equipment will be cleaned according to the procedures specified in **Section 4.15**.

Sampling will be performed with the pump intake at the same location used for purging. Pumping rates for withdrawing the samples will be similar to those followed for well purging.

The samples will be collected in sample bottles (pre-preserved, if appropriate), placed in iced coolers and removed from light immediately after collection. In addition, all sample bottles must be filled to the top so that no aeration of the samples occurs during transport. All bottles will be filled to avoid cascading and aeration of the samples, the goal being to minimize any precipitation of colloidal matter. Samples will be transported to a NYSDOH ELAP certified laboratory under proper chain of custody procedures for analysis. Samples for dissolved metals will be collected in unpreserved containers and will be filtered and preserved at the laboratory within 24 hours of sampling.

4.7. Borehole Abandonment

Soils extracted during the advancement of the borings will be used to backfill the borings, provided that the borings are not to be used for installation of permanent monitoring wells. However, soils that exhibit “gross” contamination, as evidenced by staining or free-phase product, or any visual, olfactory, or PID readings greater than 100 ppm above background, will be managed in accordance with **Section 9**. In this event, bentonite chips or pellets to within 0.5 feet below ground surface. The ground surface will be restored to a similar condition as the surrounding grade (e.g., topsoil, asphalt, or concrete).

4.8. Monitoring Well Abandonment

There may be occasions when monitoring wells will require abandonment. For temporary monitoring wells, the approach will be to pull the PVC well materials from the borehole and backfill the remaining open portion of the borehole with cement/bentonite grout to approximately 0.5 feet below the ground surface. The ground surface will be restored to a similar condition as the surrounding grade (e.g., topsoil, asphalt, or concrete). For permanent overburden and bedrock monitoring wells, depending on the site-specific subsurface geologic conditions and nature of contamination, the abandonment approach will be in accordance with NYSDEC Policy CP-43 – Groundwater Monitoring Well Decommissioning Policy.



4.9. Soil Reuse and Worker Health & Safety Sampling

Soil reuse sampling may be performed to determine whether the soil can be reused elsewhere on the Site, or to determine whether contaminant levels in the soil would warrant OSHA 40-hour HAZWOPER training for workers disturbing the soil during post-remediation construction activities. This sampling would consist of compositing discrete soil samples from borings advanced by direct push (see **Section 4.3**), or during test pits following the procedures outlined in **Section 4.2**.

4.10. Waste Characterization Sampling

Waste classification sampling may be conducted to characterize soil, liquids and/or groundwater for the purpose of proper off-site waste disposal. Specific methods for sampling liquid and solid wastes are briefly discussed below.

4.10.1. Solid Waste

Solid sampling methods include utilizing dedicated stainless steel or Teflon® scoops/shovels, triers, and thieves. Scoops and shovels are the preferred method for sampling solids from piles or containers. Stainless steel triers are similar to a scoop and are used for the collection of a core sample of a solid material.

4.10.2. Liquid Waste

Liquid sampling methods include utilizing dedicated dippers, glass tube samplers, pump and tubing, kemmerer bottles, and Bacon Bomb samplers. Dippers are used to collect samples from the surface of the liquid and are appropriate for wastes that are homogeneous. Glass tube samplers consist of glass tubes of varying length and diameter used to collect a full-depth liquid sample from a drum or similar container. Pump and tubing (e.g., bladder pump or peristaltic pump) are used to collect liquid samples from a depth (up to approximately 20 feet below grade), and are typically relied upon for sampling subsurface structures, such as underground storage tanks. To minimize the loss of volatile organic components in the liquid, the lowest achievable flow rate is utilized for collecting the sample by this method. Kemmerer bottles and Bacon Bomb samplers are discrete-depth samplers. These samplers are lowered into the liquid and opened to collect a sample at a desired depth.



4.10.3. *Grab versus Composite Sampling*

Waste characterization of a liquid or a solid can involve grab or composite sampling depending upon the homogeneity and the volume of the waste. Grab sampling consists of collecting a discrete sample or samples of a material and submitting each sample for separate analysis. Grab sampling is appropriate for characterizing small quantities of waste as well as waste streams of varying content (e.g., drums of different contents). Composite sampling consists of taking discrete grab samples of a material and combining them into a smaller number of samples for analysis. Composite sampling generally is appropriate for large volumes of a homogenous waste material, such as a pile of soil or construction debris. The specific number of composite and grab samples largely will depend upon the size and nature of the waste pile (i.e., cubic yards) as well as the analysis required for characterization of the waste.

4.11. **Soil Gas Sampling**

A direct-push drill rig will be utilized to drive rods with a decontaminated stainless steel probe to the desired sample depth, which will be a minimum of 5 feet bgs or two feet above the water table if groundwater is present at 5 feet. The soil gas probe will then be purged at a flow rate not greater than 0.2 liters/minute to evacuate one to three volumes using a photoionization detector (PID) with an integrated vacuum pump (MiniRAE 3000 or appropriate alternate). Peak and stabilized PID readings will be recorded prior to sample collection. Following the stabilization period, each probe will be connected to an evacuated laboratory-supplied 6-liter SUMMA[®] canister. SUMMA[®] canisters are passivated stainless steel vessels that have been cleaned and certified contaminant-free by the contract laborer. After connecting the SUMMA[®] canister to the soil gas probe, a regulator valve on the canister will be opened and the vacuum will slowly draw the sample into the canister over a period of 20 minutes. The samples will not be drawn at greater than 0.2 liters per minute. Quantitation limits for all analytes range between 1.6 ppbV and 4.0 ppbV, depending on the compound. After collecting the soil gas sample, the valve will be closed and disconnected from the soil gas probe. The soil-gas samples will be transported to a NYSDOH ELAP certified laboratory for TO-15 analysis.

Prior to sample collection, helium will be used as a tracer gas to evaluate the potential for infiltration of outdoor air into the sample. Subsequent rounds of soil gas sampling would include the use of tracer gas only if the initial round of sampling indicates that outdoor air has the potential to influence soil gas sample results.

When soil vapor samples are collected, the following conditions that may influence the interpretation of results will be documented:

- Identification of any nearby commercial or industrial buildings that likely uses volatile organic compounds;
- A sketch of the Site, showing streets, neighboring commercial or industrial facilities (with estimated distances to the Site, and soil-gas sampling locations);



- Weather conditions (e.g., precipitation, outdoor temperature, barometric pressure, wind speed and direction); and
- Any pertinent observations, such as odors or readings from field instrumentation.

4.12. Ambient Air Sampling

Ambient air samples will be collected with an evacuated laboratory-supplied 6-liter SUMMA[®] canister. SUMMA[®] canisters are passivated stainless steel vessels that have been cleaned and certified contaminant-free by the contract laborer. The sample will be set at an elevation of approximately 4 to 5 feet above grade, to represent breathing zone air quality conditions. The samples will not be drawn at greater than 0.2 liters per minute. After collecting the ambient air sample, the valve will be closed, and the canister will be labeled with the necessary information. The soil-gas samples will be transported to a NYSDOH ELAP certified laboratory for TO-15 analysis.

When ambient air samples are collected, the following conditions that may influence the interpretation of results will be documented:

- Identification of any nearby commercial or industrial buildings that likely uses volatile organic compounds;
- A sketch of the Site, showing streets, neighboring commercial or industrial facilities (with estimated distances to the Site, and soil-gas sampling locations);
- Weather conditions (e.g., precipitation, outdoor temperature, barometric pressure, wind speed and direction); and
- Any pertinent observations, such as odors or readings from field instrumentation.

4.13. QC Sample Collection

QC samples will include equipment blanks, trip blanks, field duplicates and MS/MSDs.

Equipment blanks will consist of distilled water and will be used to check for potential contamination of the equipment that may cause sample contamination. Equipment blanks will be collected by routing the distilled water through the sampling equipment prior to sample collection. Equipment blanks will be submitted to the laboratory at a frequency of one per day per matrix per type of equipment being used per parameter. Equipment blanks will not be collected with samples for analysis for TCLP parameters, parameters associated with wastewater samples, samples collected for disposal purposes, soil gas samples, chip samples, wipe samples and samples collected for grain size analyses.

Trip blanks will consist of distilled water (supplied by the laboratory) and will be used to assess the potential for volatile organic compound contamination of groundwater samples due to contaminant



migration during sample shipment and storage. Trip blanks will be transported to the site unopened, stored with the investigative samples, and kept closed until analyzed by the laboratory. Trip blanks will be submitted to the laboratory at a frequency of one per cooler that contains groundwater samples for analysis for VOCs.

Field duplicates are an additional aliquot of the same sample submitted for the same parameters as the original sample. Field duplicates will be used to assess the sampling and analytical reproducibility. Field duplicates will be collected by alternately filling sample bottles from the source being sampled. Field duplicates will be submitted at a frequency of one per 20 samples for all matrices and all parameters with the exception of TCLP parameters, parameters associated with wastewater samples, samples collected for waste characterization purposes, chip samples, wipe samples and samples collected for grain size analyses. Soil gas field duplicates will be obtained by using a tubing a T-splitter.

MSs and MSDs are two additional aliquots of the same sample submitted for the same parameters as the original sample. However, the additional aliquots are spiked with the compounds of concern. Matrix spikes provide information about the effect of the sample matrix on the measurement methodology. MS/MSDs will be submitted at a frequency of one per 20 investigative samples per matrix for organic parameters for soil, sediment, and groundwater. MSs will be submitted at a frequency of one per 20 investigative samples per matrix for inorganic parameters.

4.14. Sample Preservation and Containerization

The analytical laboratory will supply the sample containers for the chemical samples. These containers will be cleaned by the manufacturer to meet or exceed all analyte specifications established in the latest U.S. EPA's *Specifications and Guidance for Contaminant-Free Sample Containers*. Certificates of analysis are provided with each bottle lot and maintained on file to document conformance to EPA specifications. The containers will be pre-preserved, where appropriate (see **Table 2**).

Table 6 presents a summary of QC sample preservation and container requirements.

4.15. Equipment Decontamination

Re-usable Teflon[®], stainless steel, and aluminum sampling equipment shall be cleaned between each use in the following manner:

- Wash/scrub with a biodegradable degreaser ("Simple Green") if there is oily residue on equipment surface
- Tap water rinse
- Wash and scrub with Alconox and water mixture
- Tap water rinse
- Distilled/deionized water rinse



- Air dry

Cleaned equipment shall be wrapped in aluminum foil if not used immediately after air-drying.

Groundwater sampling pumps will be cleaned by washing and scrubbing with an Alconox/water mixture, rinsing with tap water and irrigating with distilled/deionized water.

5.0 DOCUMENTATION AND CHAIN-OF-CUSTODY

5.1. Sample Collection Documentation

5.1.1. *Field Notes*

Field team members will keep a field logbook to document all field activities. Field logbooks will provide the means of recording the chronology of data collection activities performed during the remediation. As such, entries will be described in as much detail as possible so that a particular situation could be reconstructed without reliance on memory.

The logbook will be a bound notebook with water-resistant pages. Logbook entries will be dated, legible, and contain accurate and inclusive documentation of the activity. The title page of each logbook should contain the following:

- Person to whom the logbook is assigned
- The logbook number
- Project name and number
- Site name and location
- Project start date
- End date

Entries into the logbook will contain a variety of information. At the beginning of each entry, the date, start time, weather, and names of sampling team members present will be entered. Each page of the logbook will be signed and dated by the person making the entry. All entries will be made in permanent ink, signed, and dated and no erasures or obliterations will be made. If an incorrect entry is made, the information will be crossed out with a single strike mark that is signed and dated by the sampler. The correction shall be written adjacent to the error.

Field activities will be fully documented. Information included in the logbook should include, but may not be limited to, the following:

- Chronology of activities, including entry and exit times
- Names of all people involved in sampling activities
- Level of personal protection used



- Any changes made to planned protocol
- Names of visitors to the site during sampling and reason for their visit
- Sample location and identification
- Changes in weather conditions
- Dates (month/day/year) and times (military) of sample collection
- Measurement equipment identification (model/manufacture) and calibration information
- Sample collection methods and equipment
- Sample depths
- Whether grab or composite sample collected
- How sample composited, if applicable
- Sample description (color, odor, texture, etc.)
- Sample identification code
- Tests or analyses to be performed
- Sample preservation and storage conditions
- Equipment decontamination procedures
- QC sample collection
- Unusual observations
- Record of photographs
- Sketches or diagrams
- Signature of person recording the information

Field logbooks will be reviewed on a daily basis by the Field Team Leader. Logbooks will be supported by standardized forms.

5.1.2. Chain-of-Custody Records

On a regular basis (daily or on such a basis that all holding times will be met), samples will be transferred to the custody of the respective laboratories, via third-party commercial carriers or via laboratory courier service.

Chain-of-custody records are initiated by the samplers in the field. The field portion of the custody documentation should include: (1) the project name; (2) signatures of samplers; (3) the sample number, date and time of collection, and whether the sample is grab or composite; (4) signatures of individuals involved in sampling; and (5) if applicable, air bill or other shipping number. Sample receipt and log-in procedures at the laboratory are described in **Section 5.2.2** of this Plan.

5.1.3. Sample Labeling

Immediately upon collection, each sample will be labeled with a pre-printed adhesive label, which includes the date and time of collection, sampler's initials, tests to be performed, preservative (if applicable), and a unique identifier.



- A. The following identification scheme will be used:

Soil borings will be assigned sequential numbers. For soil samples collected from soil borings, sample numbers will be assigned as follows:

GZ-#(sampling interval)

Example:

Sample GZ-4(4-6') = soil sample collected from soil boring #4 at a depth of 5-6' below grade.

Groundwater wells will be assigned sequential numbers. Groundwater samples will be identified by the well that the sample was collected from.

Examples:

GMW-01 = groundwater sample collected from permanent well point #1

Sub-slab soil vapor/soil vapor/ambient air will be assigned numbers coordinating with the adjacent soil boring or a sequential number due to sample names being identical to a previous Site sampling event. Vapor samples will be identified by the soil gas point that the sample was collected from.

Examples:

GSV-01 = Soil vapor sample collected from the soil gas point

OA-01 = Outdoor ambient air sample

Duplicate samples will be labeled as blind duplicates by giving them sample numbers indistinguishable from a normal sample.

Blanks should be spelled out and identify the associated matrix, e.g., Equipment Blank, Soil

MS/MSDs will be noted in the Comments column of the COC.

- B. The analysis required will be indicated for each sample.

Example: SVOC

- C. Date taken will be the date the sample was collected, using the format: MM-DD-YY.

Example: 04-22-22

- D. Time will be the time the sample was collected, using military time.

Example: 14:30



- E. The sampler's name will be printed in the "Sampled By" section.
- F. Other information relevant to the sample.

Example: Equipment Blank

An example sample label is presented below:

Job No: XXXXXXXXX
Client: Name
Sample No: GZ-01(5-5.5')
Matrix: Soil
Date Taken: 5/22/24
Time Taken: 14:30
Sampler: B. Smith
Analysis: SVOC

Job No. _____
Client: _____
Sample Number _____
Date _____ Sample Time _____
Sample Matrix _____
Grab or Composite (explain) _____
Preservatives _____
Analyses _____
Sampler Signature _____

This sample label contains the authoritative information for the sample. Inconsistencies with other documents will be settled in favor of the vial or container label unless otherwise corrected in writing from the field personnel collecting samples or the QEP.

5.2. Sample Custody

Custody is one of several factors that are necessary for the admissibility of environmental data as evidence in a court of law. Custody procedures help to satisfy the two major requirements for admissibility: relevance and authenticity. Sample custody is addressed in three parts: field sample collection, laboratory analysis, and final evidence files.

A sample or evidence file is considered to be under a person's custody if

- the item is in the actual possession of a person



- the item is in the view of the person after being in actual possession of the person
- the item was in the actual physical possession of the person but is locked up to prevent tampering
- the item is in a designated and identified secure area

5.2.1. Field Custody Procedures

Samples will be collected following the sampling procedures documented in **Section 4.0** of this Plan. Documentation of sample collection is described in **Section 5.1** of this Plan. Sample chain-of-custody and packaging procedures are summarized below. These procedures are intended to ensure that the samples will arrive at the laboratory with the chain-of-custody intact.

- The field sampler is personally responsible for the care and custody of the samples until they are transferred or dispatched properly. Field procedures have been designed such that as few people as possible will handle the samples.
- All bottles will be identified by the use of sample labels with sample numbers, sampling locations, date/time of collection, and type of analysis.
- Sample labels will be completed for each sample using waterproof ink unless prohibited by weather conditions. For example, a logbook notation would explain that a pencil was used to fill out the sample label because the pen would not function in wet weather.
- Samples will be accompanied by a properly completed chain-of-custody form. The sample numbers and locations will be listed on the chain-of-custody form. When transferring the possession of samples, the individuals relinquishing and receiving will sign, date, and note the time on the record. This record documents the transfer of custody of samples from the sampler to another person, to a mobile laboratory, to the permanent laboratory, or to/from a secure storage location.
- All shipments will be accompanied by the chain-of-custody record identifying the contents. The original record will accompany the shipment, and copies will be retained by the sampler and placed in the project files.
- Samples will be properly packaged for shipment and dispatched to the appropriate laboratory for analysis, with a separate signed custody record enclosed in and secured to the inside top of each sample box or cooler. If third party commercial carriers are used for transfer to the laboratory, shipping containers will be secured with strapping tape and custody seals prior to shipment. The custody seals will be attached to the front right and back left of the cooler and covered with clear plastic tape after being signed by field personnel. The cooler will be strapped shut with strapping tape in at least two locations.
- If the samples are sent by third party commercial carrier, the air bill will be used. Air bills will be retained as part of the permanent documentation. Commercial carriers are not required to sign off



on the custody forms since the custody forms will be sealed inside the sample cooler and the custody seals will remain intact.

- Samples remain in the custody of the sampler until transfer of custody is completed. This consists of delivery of samples to the laboratory courier or sample custodian, and signature of the laboratory courier or sample custodian on chain-of-custody document as receiving the samples and signature of sampler as relinquishing samples.

5.2.2. Laboratory Custody Procedures

Samples will be received and logged in by a designated sample custodian or his/her designee. Upon sample receipt, the sample custodian will

- Examine the shipping containers to verify that the custody tape is intact,
- Examine all sample containers for damage,
- Determine if the temperature required for the requested testing program has been maintained during shipment and document the temperature on the chain-of-custody records,
- Compare samples received against those listed on the chain-of-custody,
- Verify that sample holding times have not been exceeded,
- Examine all shipping records for accuracy and completeness,
- Determine sample pH (if applicable) and record on chain-of-custody forms,
- Sign and date the chain-of-custody immediately (if shipment is accepted) and attach the air bill,
- Note any problems associated with the coolers and/or samples on the cooler receipt form and notify the Laboratory Project Manager, who will be responsible for contacting the QEP,
- Attach laboratory sample container labels with unique laboratory identification and test, and
- Place the samples in the proper laboratory storage.

Following receipt, samples will be logged in according to the following procedure:

- The samples will be entered into the laboratory tracking system. At a minimum, the following information will be entered: project name or identification, unique sample numbers (both client and internal laboratory), type of sample, required tests, date and time of laboratory receipt of samples, and field ID provided by field personnel.
- The Laboratory Project Manager will be notified of sample arrival.
- The completed chain-of-custody, air bills, and any additional documentation will be placed in the final evidence file.

6.0 CALIBRATION PROCEDURES

6.1. Field Instruments

Field instruments will be calibrated according to the manufacturer's specifications. Calibration procedures performed will be documented in the field logbook and will include the date/time of



calibration, name of person performing the calibration, reference standard used, temperature at which the readings were taken, and the readings.

6.2. Laboratory Instruments

Calibration procedures for a specific laboratory instrument will consist of initial calibrations, initial calibration verifications, and/or continuing calibration verification. Detailed descriptions of the calibration procedures for a specific laboratory instrument are included in the laboratory's standard operating procedures (SOPs), which describe the calibration procedures, their frequency, acceptance criteria, and the conditions that will require recalibration. These procedures are as required in the respective analytical methodologies (summarized in **Table 2** of this Plan). The initial calibration associated with all analyses must contain a low-level calibration standard which is less than or equal to the quantitation limit.

7.0 SAMPLE PREPARATION AND ANALYTICAL PROCEDURES

No field analyses are anticipated for this program. If site conditions were to warrant field analysis, the responsible contractor will prepare an addendum establishing the field analytical procedures. Analyses of all samples will be performed by NYSDOH ELAP certified laboratories. **Table 2** summarizes the analytical methods to be used during the remediation.

8.0 DATA REDUCTION, VALIDATION, AND REPORTING

Appropriate QC measures will be used to ensure the generation of reliable data from sampling and analysis activities. Proper collection and organization of accurate information followed by clear and concise reporting of the data is a primary goal in this project. Complete data packages suitable for data validation will be provided by the analytical laboratory.

For all analyses, the laboratory will report results that are below the laboratory's reporting limit; these results will be qualified as estimated (J) by the laboratory. The laboratory may be required to report tentatively identified compounds (TICs) for the VOC and SVOC analyses; this will be requested by the sampler on an as-needed basis. A Data Usability Summary Report (DUSR) will be prepared and will be included in the Remedial Investigation Report (RIR). Qualifications of the DUSR preparer can be found in **Attachment A**.

8.1. Data Evaluation/Validation

8.1.1. *Field Data Evaluation*

Measurements and sample collection information will be transcribed directly into the field logbook or onto standardized forms. If errors are made, results will be legibly crossed out, initialed and dated by



the person recording the data, and corrected in a space adjacent to the original (erroneous) entry. Daily reviews of the field records by the Field Team Leader will ensure that:

- Logbooks and standardized forms have been filled out completely and that the information recorded accurately reflects the activities that were performed.
- Records are legible and in accordance with good record keeping procedures, i.e., entries are signed and dated, data are not obliterated, changes are initialed, dated, and explained.
- Sample collection, handling, preservation, and storage procedures were conducted in accordance with the protocols described in the Plan, and that any deviations were documented and approved by the appropriate personnel.

8.1.2. Data Usability

A Data Usability Summary Report (DUSR) will be prepared in accordance with the DER Technical Guidance for Site Investigation and Remediation (DER-10).

The data usability evaluation will include reviewing the quality assurance/quality control (QA/QC) information including: (1) chain-of-custody; (2) the summary QA/QC information provided by the laboratory; and (3) the project narrative.

For each data package the following questions will be evaluated:

- Is the data package complete as defined under the requirements for the NYSDEC ASP Category B, USEPA CLP deliverables or other standards/guidance?
- Have all holding times and preservation requirements been met?
- Do the quality control (QC) data fall within the laboratory and project established limits and specifications?

8.2. Identification and Treatment of Outliers

Any data point which deviates markedly from others in its set of measurements will be investigated; however, the suspected outlier will be recorded and retained in the data set. One or both of the following tests will be used to identify outliers.

Dixon's test for extreme observations is an easily computed procedure for determining whether a single very large or very small value is consistent with the remaining data. The one-tailed t-test for difference may also be used in this case. It should be noted that these tests are designed for testing a single value. If more than one outlier is suspected in the same data set, other statistical sources may be consulted and the most appropriate test of hypothesis will be used and documented, if warranted.



Since an outlier may result from unique circumstances at the time of sample analysis or data collection, those persons involved in the analysis and data reduction will be consulted. This may provide an experimental reason for the outlier. Further statistical analysis may be performed with and without the outlier to determine its effect on the conclusions. In many cases, two data sets may be reported, one including, and one excluding the outlier.

In summary, every effort will be made to include the outlying values in the reported data. If the value is rejected, it will be identified as an outlier, reported with its data set and its omission noted.

9.0 INTERNAL QUALITY CONTROL

The subcontracting laboratories' Quality Assurance Project Plans will identify the supplemental internal analytical quality control procedures to be used. At a minimum, this will include:

- Matrix spike and/or matrix spike duplicate samples
- Matrix duplicate analyses
- Laboratory control samples
- Instrument calibrations
- Instrument tunes for SW-846 8260B and 8270C and EPA Method TO-15 analyses
- Method and/or instrument blanks
- Surrogate spikes for organic analyses
- Internal standard spikes for SW-846 8260B and 8270C and EPA Method TO-15 analyses
- Quantitation limit determination and confirmation by analysis of low-level calibration standard

As outline on **Table 5** and summarized in **Section 4.13**, field quality control samples will include:

- Equipment blanks
- Field duplicate samples
- Trip blanks
- MS/MSDs

10.0 CORRECTIVE ACTION

The entire sampling program will be under the direction of the QEP. The emphasis in this program is on preventing problems by identifying potential errors, discrepancies, and gaps in the data-collection-laboratory-analysis-interpretation process. Any problems identified will be promptly resolved. Likewise, follow-up corrective action is always an option in the event that preventative corrective actions are not totally effective.

The acceptance limits for the sampling and analyses to be conducted in this program will be those stated in the method or defined by other means in the Plan. Corrective actions are likely to be immediate in nature and most often will be implemented by the contracted laboratory analyst or the Program Manager. The corrective action will usually involve recalculation, reanalysis, or resampling.



10.1. Immediate Corrective Action

Corrective action in the field may be needed when the sample network is changed (i.e., more/less samples, sampling locations other than those specified in the Plan), or when sampling procedures and/or field analytical procedures require modification, etc. due to unexpected conditions. The field team may identify the need for corrective action. The Field Team Leader will approve the corrective action and notify the Program Manager. The Program Manager will approve the corrective measure. The Field Team Leader will ensure that the corrective measure is implemented by the field team.

Corrective actions will be implemented and documented in the field logbook. Documentation will include:

- A description of the circumstances that initiated the corrective action,
- The action taken in response,
- The final resolution, and
- Any necessary approvals

No staff member will initiate corrective action without prior communication of findings through the proper channels.

Corrective action in the laboratory may occur prior to, during, and after initial analyses. A number of conditions such as broken sample containers, omissions or discrepancies with chain-of-custody documentation, low/high pH readings, and potentially high concentration samples may be identified during sample log-in or just prior to analysis. Following consultation with laboratory analysts and Laboratory Section Leaders, it may be necessary for the Laboratory QA Manager to approve the implementation of corrective action. The laboratory SOPs specify some conditions during or after analysis that may automatically trigger corrective action or optional procedures. These conditions may include dilution of samples, additional sample extract cleanup, automatic reinjection/reanalysis when certain QC criteria are not met, loss of sample through breakage or spillage, etc.

The analyst may identify the need for corrective action. The Laboratory Section Leader, in consultation with the staff, will approve the required corrective action to be implemented by the laboratory staff. The Laboratory QA Manager will ensure implementation and documentation of the corrective action. If the nonconformance causes project objectives not to be achieved, the QEP will be notified. The QEP will notify the Program Manager, who in turn will contact all levels of project management for concurrence with the proposed corrective action.

These corrective actions are performed prior to release of the data from the laboratory. The corrective action will be documented in both the laboratory's corrective action files, and the narrative data report sent from the laboratory to the Program Manager. If the corrective action does not rectify the situation,



the laboratory will contact the Program Manager, who will determine the action to be taken and inform the appropriate personnel.


If potential problems are not solved as an immediate corrective action, the contractor will apply formalized long-term corrective action, if necessary.



June 2024
File No. 41.0163263.00
QAPP/FSP – 55 Eckford Street, Brooklyn, NY


FIGURES

© 2022 - GZA GeoEnvironmental of NY.
GZA-J:\Active 163200 to 163299\163263.00 - 55 Eckford St BCP\Drawings\GZA CAD\GZANY-2022 - FEET (REPORT FIGURES).dwg [FIG 1 8.5x11] May 17, 2024 - 3:05pm Nolan.Quinn



SOURCE:

USGS TOPOGRAPHIC MAPS: BROOKLYN, NEW YORK (2023).
CONTOUR INTERVAL 10FT., NAVD-1988, ORIGINAL SCALE
1:24,000 (1IN.=2,000FT.).



UNLESS SPECIFICALLY STATED BY WRITTEN AGREEMENT, THIS DRAWING IS THE SOLE PROPERTY OF GZA GEOENVIRONMENTAL, INC. (GZA). THE INFORMATION SHOWN ON THE DRAWING IS SOLELY FOR USE BY GZA'S CLIENT OR THE CLIENT'S DESIGNATED REPRESENTATIVE FOR THE SPECIFIC PROJECT AND LOCATION IDENTIFIED ON THE DRAWING. THE DRAWING SHALL NOT BE TRANSFERRED, REUSED, COPIED, OR ALTERED IN ANY MANNER FOR USE AT ANY OTHER LOCATION OR FOR ANY OTHER PURPOSE WITHOUT THE PRIOR WRITTEN CONSENT OF GZA. ANY TRANSFER, REUSE, OR MODIFICATION TO THE DRAWING BY THE CLIENT OR OTHERS, WITHOUT THE PRIOR WRITTEN EXPRESS CONSENT OF GZA, WILL BE AT THE USER'S SOLE RISK AND WITHOUT ANY RISK OR LIABILITY TO GZA.

55 ECKFORD STREET
BROOKLYN, NEW YORK

PREPARED BY:



GZAGeoEnvironmental of NY
Engineers and Scientists
www.gza.com

PREPARED FOR:

55 ECKFORD ST LLC

SUBJECT PROPERTY LOCATION MAP

PROJ MGR:	VW	REVIEWED BY:	SK
DESIGNED BY:	VW	DRAWN BY:	NQ
DATE:	JUNE 2024	PROJECT NO.	41.0163263.00

CHECKED BY:	SK
SCALE:	1"=2000'
REVISION NO.	-

FIGURE
1

SHEET NO. 1 OF 10



TABLES

Table 1 A
Soil Criteria Table

55 Eckford Street
Brooklyn, New York
BCP Site No. C224168
QAPP/FSP

Contaminant	Protection of Public Health					Protection of Ecological Resources ⁿ	Protection of Groundwater
	Unrestricted Use	Residential	Restricted-Residential	Commercial	Industrial		
All soil cleanup objectives (SCOs) are in parts per million (ppm); approximately equivalent to mg/kg.							
Metals							
Arsenic	13 ^m	16 ^f	17 ^f	18 ^f	19 ^f	13 ^f	16 ^f
Barium	350 ^m	350 ^f	400	400	10,000 ^d	433	820
Beryllium	7.2	14	72	590	2,700	10	47
Cadmium	2.5 ^m	2.5 ^f	4.3	9.3	60	4	7.5
Chromium, hexavalent ^h	1 ⁱ	22	110	400	800	1 ^e	19
Chromium, trivalent ^h	30 ^m	36	180	1,500	6,800	41	NS
Copper	50	270	270	270	10,000 ^d	50	1,720
Total Cyanide ^h	27	27	27	27	10,000 ^d	NS	40
Lead	63 ^m	400	400	1,000	3,900	63 ^f	450
Manganese	1600 ^m	2,000 ^f	2,000 ^f	10,000 ^d	10,000 ^d	1600 ^f	2,000 ^f
Total Mercury	0.18 ^m	0.81 ^j	0.81 ^j	2.8 ^j	5.7 ^j	0.18 ^f	0.73
Nickel	30	140	310	310	10,000 ^d	30	130
Selenium	3.9 ^m	36	180	1,500	6,800	3.9 ^f	4 ^f
Silver	2	36	180	1,500	6,800	2	8.3
Zinc	109 ^m	2200	10,000 ^d	10,000 ^d	10,000 ^d	109 ^f	2,480
PCBs/Pesticides							
2,4,5-TP Acid (Silvex)	3.8	58	100 ^a	500 ^b	1,000 ^c	NS	3.8
4,4'-DDE	0.0033 ⁱ	1.8	8.9	62	120	0.0033 ^e	17
4,4'-DDT	0.0033 ⁱ	1.7	7.9	47	94	0.0033 ^e	136
4,4'-DDD	0.0033 ⁱ	2.6	13	92	180	0.0033 ^e	14
Aldrin	0.005 ^m	0.019	0.097	0.68	1.4	0.14	0.19
alpha-BHC	0.02	0.097	0.48	3.4	6.8	0.04 ^g	0.02
beta-BHC	0.036	0.072	0.36	3	14	0.6	0.09
Chlordane (alpha)	0.094	0.91	4.2	24	47	1.3	2.9
delta-BHC	0.04	100 ^a	100 ^a	500 ^b	1,000 ^c	0.04 ^g	0.25
Dibenzofuran	7	14	59	350	1,000 ^c	NS	210
Dieldrin	0.005 ^m	0.039	0.2	1.4	2.8	0.006	0.1
Endosulfan I	2.4	4.8 ⁱ	24 ⁱ	200 ⁱ	920 ⁱ	NS	102
Endosulfan II	2.4	4.8 ⁱ	24 ⁱ	200 ⁱ	920 ⁱ	NS	102
Endosulfan sulfate	2.4	4.8 ⁱ	24 ⁱ	200 ⁱ	920 ⁱ	NS	1,000 ^c
Endrin	0.014	2.2	11	89	410	0.014	0.06
Heptachlor	0.042	0.42	2.1	15	29	0.14	0.38
Lindane	0.1	0.28	1.3	9.2	23	6	0.1
Polychlorinated biphenyls	0.1	1	1	1	25	1	3.2
Semivolatiles							
Acenaphthene	20	100 ^a	100 ^a	500 ^b	1,000 ^c	20	98
Acenaphthylene	100 ^k	100 ^a	100 ^a	501 ^b	1,000 ^c	NS	107
Anthracene	100 ^k	100 ^a	100 ^a	502 ^b	1,000 ^c	NS	1,000 ^c
Benz(a)anthracene	1 ^m	1 ^f	1 ^f	5.6	11	NS	1 ^f
Benzo(a)pyrene	1 ^m	1 ^f	1 ^f	1 ^f	1.1	2.6	22
Benzo(b)fluoranthene	1 ^m	1 ^f	1 ^f	5.6	11	NS	1.7
Benzo(g,h,i)perylene	100	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	1,000 ^c
Benzo(k)fluoranthene	0.8 ^m	1	3.9	56	110	NS	1.7
Chrysene	1 ^m	1 ^f	3.9	56	110	NS	1 ^f
Dibenz(a,h)anthracene	0.33 ⁱ	0.33 ^e	0.33 ^e	0.56	1.1	NS	1,000 ^c
Fluoranthene	100 ^k	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	1,000 ^c
Fluorene	30	100 ^a	100 ^a	500 ^b	1,000 ^c	30	386
Indeno(1,2,3-cd)pyrene	0.5 ^m	0.5 ^f	0.5 ^f	5.6	11	NS	8.2
m-Cresol	0.33 ⁱ	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	0.33 ^e
Napthalene	12	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	12
o-Cresol	0.33 ⁱ	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	0.33 ^e
p-Cresol	0.33 ⁱ	34	100 ^a	500 ^b	1,000 ^c	NS	0.33 ^e
Pentachlorophenol	0.8 ⁱ	2.4	6.7	6.7	55	0.8 ^e	0.8 ^e
Phenanthrene	100	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	1,000 ^c
Phenol	0.33 ⁱ	100 ^a	100 ^a	500 ^b	1,000 ^c	30	0.33 ^e
Pyrene	100	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	1,000 ^c

Table 1 A
Soil Criteria Table

55 Eckford Street
Brooklyn, New York
BCP Site No. C224168
QAPP/FSP

Contaminant	Protection of Public Health					Protection of Ecological Resources ^a	Protection of Groundwater
	Unrestricted Use	Residential	Restricted-Residential	Commercial	Industrial		
All soil cleanup objectives (SCOs) are in parts per million (ppm); approximately equivalent to mg/kg.							
Volatiles							
1,1,1-Trichloroethane	0.68	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	0.68
1,1-Dichloroethane	0.27	19	26	240	480	NS	0.27
1,1-Dichloroethene	0.33	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	0.33
1,2-Dichlorobenzene	1.1	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	1.1
1,2-Dichloroethane	0.02 ^m	2.3	3.1	30	60	10	0.02 ^f
cis-1,2-Dichloroethene	0.25	59	100 ^a	500 ^b	1,000 ^c	NS	0.25
trans-1,2-Dichloroethene	0.19	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	0.19
1,3-Dichlorobenzene	2.4	17	49	280	560	NS	2.4
1,4-Dichlorobenzene	1.8	9.8	13	130	250	20	1.8
1,4-Dioxane	0.1 ^l	9.8	13	130	250	0.1 ^e	0.1 ^e
Acetone	0.05	100 ^a	100 ^b	500 ^b	1,000 ^c	2.2	0.05
Benzene	0.06	2.9	4.8	44	89	70	0.06
Butylbenzene	12	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	12
Carbon tetrachloride	0.76	1.4	2.4	22	44	NS	0.76
Chlorobenzene	1.1	100 ^a	100 ^a	500 ^b	1,000 ^c	40	1.1
Chloroform	0.37	10	49	350	700	12	0.37
Ethylbenzene	1	30	41	390	780	NS	1
Hexachlorobenzene	0.33 ^l	0.33 ^e	1.2	6	12	NS	3.2
Methyl ethyl ketone	0.12	100 ^a	100 ^a	500 ^b	1,000 ^c	100 ^a	0.12
Methyl tert-butyl ether	0.93	62	100 ^a	500 ^b	1,000 ^c	NS	0.93
Methylene chloride	0.05	51	100 ^a	500 ^b	1,000 ^c	12	0.05
n-Propylbenzene	3.9	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	3.9
sec-Butylbenzene	11	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	11
tert-Butylbenzene	5.9	100 ^a	100 ^a	500 ^b	1,000 ^c	NS	5.9
Tetrachloroethene	1.3	5.5	19	150	300	2	1.3
Toluene	0.7	100 ^a	100 ^a	500 ^b	1,000 ^c	36	0.7
Trichloroethene	0.47	10	21	200	400	2	0.47
1,2,4-Trimethylbenzene	3.6	47	52	190	380	NS	3.6
1,3,5- Trimethylbenzene	8.4	47	52	190	380	NS	8.4
Vinyl chloride	0.02	0.21	0.9	13	27	NS	0.02
Xylene (mixed)	0.26	100 ^a	100 ^a	500 ^b	1,000 ^c	0.26	1.6
Per- and Polyfluoroalkyl Substances (PFAs) ^o							
PFOA	0.00066	0.0066	0.033	0.5	0.6	NS	0.0011
PFOS	0.00088	0.0088	0.044	0.44	0.44	NS	0.0037

Notes:

^a The SCOs for residential, restricted-residential and ecological resources use were capped at a maximum value of 100 ppm

^b The SCOs for commercial use were capped at a maximum value of 500 ppm

^c The SCOs for industrial use and the protection of groundwater were capped at a maximum value of 1000 ppm

^d The SCOs for metals were capped at a maximum value of 10,000 ppm.

^e For constituents where the calculated SCO was lower than the contract required quantitation limit (CRQL), the CRQL is used as the SCO value

^f For constituents where the calculated SCO was lower than the rural soil background concentration as determined by the Department and Department of Health rural soil survey, the rural soil background concentration is used as the Track 2 SCO value for this use of the site.

^g This SCO is derived from data on mixed isomers of BHC.

^h The SCO for this specific compound (or family of compounds) is considered to be met if the analysis for the total species of this contaminant is below the specific SCO.

ⁱ This SCO is for the sum of endosulfan I, endosulfan II, and endosulfan sulfate

^j This SCO is the lower of the values for mercury (elemental) or mercury (inorganic salts)

^k The SCOs for unrestricted use were capped at a maximum value of 100 ppm.

^l For constituents where the calculated SCO was lower than the contract required quantitation limit (CRQL), the CRQL is used as the Track 1 SCO value

^m For constituents where the calculated SCO was lower than the rural soil background concentration, as determined by the Department and Department of Health rural soil survey, the rural soil background concentration is used as the Track 1 SCO value for this use of the site.

ⁿ Protection of ecological resources SCOs were not developed for contaminants identified in Table 375-6.8(b) with "NS". Where such contaminants appear in Table 375-6.8(a), the applicant may be required by the Department to calculate a protection of ecological resources SCO according to the TSD.

^o SCOs for PFAs are taken from the NYSDEC Sampling, Analysis, and Assessment of Per- and Polyfluoroalkyl Substances (PFAS) under NYSDEC's Part 375 Remedial Programs, dated April 2023.

Table 1B
Groundwater Criteria Table
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Contaminant	Aqueous Water Quality Standards ¹ , ug/L
Metals	
Antimony	3
Arsenic	---
Arsenic	25
Barium	1,000
Beryllium	3
Cadmium	5
Chromium, hexavalent	---
Chromium, trivalent	50
Copper	200
Cyanide	---
Iron	300
Lead	25
Magnesium	35,000
Manganese	300
Mercury	0.7
Nickel	100
Selenium	10
Silver	50
Sodium	20,000
Thallium	0.5
Zinc	2000
PCBs/Pesticides	
alpha-BHC	0.01
2,4,5-TP Acid (Silvex)	---
4,4'-DDD	0.3
4,4'-DDE	0.2
4,4'-DDT	0.2
Aldrin	---
beta-BHC	0.04
Chlordane (alpha)	---
Dibenzofuran	---
Dieldrin	0.004
Endosulfan I	0.12
Endosulfan II	0.12
Endosulfan sulfate	0.12
Endrin	---
Endrin aldehyde	5
Endrin ketone	5
gamma-BHC (Lindane)	0.05

Table 1B
Groundwater Criteria Table
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Contaminant	Aqueous Water Quality Standards ¹ , ug/L
PCBs/Pesticides, Con't.	
gamma-Chlordane	0.12
Heptachlor	0.04
Heptachlor epoxide	0.03
Lindane	---
Methoxychlor	35
Polychlorinated biphenyls	---
Toxaphene	0.06
Semivolatiles	
1,1'-Biphenyl	5
2,2'-oxybis(1-Chloropropane)	5
2,4,5-Trichlorophenol	1
2,4-Dichlorophenol	1
2,4-Dimethylphenol	50
2,4-Dinitrophenol	10
2,4-Dinitrotoluene	5
2,6-Dinitrotoluene	5
2-Chloronaphthalene	10
2-Chlorophenol	1
2-Methylnaphthalene	502
2-Methylphenol	1
2-Nitroaniline	5
2-Nitrophenol	1
3,3'-Dichlorobenzidine	5
3-Nitroaniline	5
4-Chloro-3-methylphenol	1
4-Chloroaniline	5
4-Methylphenol	1
4-Nitroaniline	5
4-Nitrophenol	1
Acenaphthene	20
Acenaphthylene	202
Anthracene	50
Atrazine	7.5
Benz(a)anthracene	0.002
Benzo(a)pyrene	---
Benzo(b)fluoranthene	0.002
Benzo(g,h,i)perylene	52
Benzo(k)fluoranthene	0.002
bis(2-Chloroethoxy)methane	5

Table 1B
Groundwater Criteria Table
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Contaminant	Aqueous Water Quality Standards ¹ , ug/L
Semivolatiles, Con't.	
Bis(2-Chloroethyl)ether	1
bis(2-Ethylhexyl)phthalate	5
Butylbenzylphthalate	50
Chrysene	0.002
Dibenz(a,h)anthracene	502
Dibenzofuran	52
Diethylphthalate	50
Dimethylphthalate	50
Di-n-butylphthalate	50
Di-n-octylphthalate	50
Fluoranthene	50
Fluorene	50
Hexachlorobenzene	0.04
Hexachlorobutadiene	0.5
Hexachlorocyclopentadiene	5
Hexachloroethane	5
Indeno(1,2,3-cd)pyrene	0.002
Isophorone	50
m-Cresol	---
Naphthalene	10
Nitrobenzene	0.4
N-Nitrosodiphenylamine	50
o-Cresol	---
p-Cresol	---
Pentachlorophenol	1
Phenanthrene	50
Phenol	1
Pyrene	50
Volatiles	
1,1,1-Trichloroethane	5
1,1,2,2-Tetrachloroethane	5
1,1,2-Trichloro-1,2,2-trifluoroethane	5
1,1,2-Trichloroethane	1
1,1-Dichloroethane	5
1,1-Dichloroethene	5
1,1-Dichloroethylene	---
1,2,4-Trichlorobenzene	---

Table 1B
Groundwater Criteria Table
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Contaminant	Aqueous Water Quality Standards ¹ , ug/L
Volatiles, Con't.	
1,2,4-Trimethylbenzene	5
1,2-Dibromo-3-chloropropane	0.04
1,2-Dibromoethane	0.0006
1,2-Dichlorobenzene	3
1,2-Dichloroethane	0.6
1,2-Dichloropropane	1
1,3,5- Trimethylbenzene	---
1,3-Butadiene	---
1,3-Dichlorobenzene	3
1,3-Dichlorobenzene	---
1,4-Dichlorobenzene	3
1,4-Dichlorobenzene	---
1,4-Dioxane	1 ²
2-Butanone	50
2-Hexanone	50
4-Methyl-2-pentanone	502
Acetone	50
Benzene	1
Bromodichloromethane	50
Bromoform	50
Bromomethane	5
Butylbenzene	---
Carbon Disulfide	60
Carbon tetrachloride	5
Chlorobenzene	5
Chloroethane	5
Chloroform	7
Chloromethane	5
Cis- 1,3-Dichloropropene	0.4
cis-1,2-Dichloroethene	5
cis-1,2-Dichloroethylene	---
Cyclohexane	---
Dibromochloromethane	50
Dichlorodifluoromethane	5
Ethyl Acetate	---
Ethylbenzene	5
Freon 113	---
Hexachlorobenzene	---

Table 1B
Groundwater Criteria Table
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Contaminant	Aqueous Water Quality Standards ¹ , ug/L
Volatiles, Con't.	
Hexachlorobutadiene	---
Hexane	---
Isopropylbenzene	5
m,p-Xylene	---
m-Dichlorobenzene	---
Methyl Acetate	NS
Methyl ethyl ketone	---
Methyl Isobutyl Ketone	---
Methyl tert-butyl ether	10
Methylcyclohexane	---
Methylene chloride	5
n-Propylbenzene	---
o-Dichlorobenzene	---
o-Xylene	---
p-Dichlorobenzene	---
sec-Butylbenzene	---
Styrene	5
tert-Butylbenzene	---
Tertiary Butyl Alcohol	---
Tetrachloroethene	5
Toluene	5
trans-1,2-Dichloroethene	5
trans-1,3-Dichloropropene	0.4
Trichloroethene	5
Trichlorofluoromethane	5
Vinyl Acetate	---
Vinyl Chloride	2
Xylene (mixed)	5
Per- and Polyfluoroalkyl Substances (PFAS)	
PFOA	0.01 ²
PFOS	0.01 ²
Notes: ¹ - Division of Water Technical and Operational Guidance Values (TOGS) Ambient Water Quality Standards and Guidance Values (AWQS), ug/L ² - Guidance value for 1,4-Dioxane, PFOA, and PFOS is from the NYSDEC Guidance to Regulate PFOA, PFOS, and 1,4-Dioxane in State Waters, dated October 5, 2021 ug/L - micro gram per liter	

Table 1C
Soil Vapor Criteria Table
55 Eckford Street, Brooklyn, NY
BCP Site No, C224168
QAPP/FSP

Volatile Organics in Air	CAS No.	NYSDOH Soil Vapor Intrusion Guidance Criteria				Toxicity	Decision Matrices A, B, C, D, E, and F
		1	2	3	4		
1,1,1-Trichloroethane	71556	2.5	20.6	-	-	L	B
1,1,2,2-Tetrachloroethane	79345	0.4	-	-	-	M	TD
1,1,2-Trichloroethane	79005	0.4	<1.5	-	-	H	TD
1,1-Dichloroethane	75343	0.4	<0.7	-	-	L	TD
1,1-Dichloroethene	75354	0.4	<1.4	-	-	M	A
1,2,4-Trichlorobenzene	120821	0.5	<6.8	-	-	NA	TD
1,2,4-Trimethylbenzene	95636	9.8	9.5	-	-	NA	D
1,2-Dibromoethane	106934	0.4	<1.5	-	-	H	TD
1,2-Dichlorobenzene	95501	0.5	<1.2	-	-	M	TD
1,2-Dichloroethane	107062	0.4	<0.9	-	-	H	TD
1,2-Dichloropropane	78875	0.4	<1.6	-	-	M	TD
1,3,5-Trimethylbenzene	108678	3.9	3.7	-	-	M	D
1,3-Butadiene	106990	-	<3.0	-	-	H	TD
1,3-Dichlorobenzene	541731	0.5	<2.4	-	-	M	TD
1,4-Dichlorobenzene	106467	1.2	5.5	344	-	M	TD
1,4-Dioxane	123911	-	-	-	-	M	TD
2,2,4-Trimethylpentane	540841	5	-	-	-	M	D
2-Butanone	78933	16	12	-	-	M	TD
2-Hexanone	591786	-	-	-	-	NA	TD
3-Chloropropene	107051	-	-	-	-	M	TD
4-Ethyltoluene	622968	-	3.6	-	-	NA	TD
4-Methyl-2-pentanone	108101	1.9	6	-	-	M	TD
Acetone	67641	115	98.9	45.8	-	L	TD
Benzene	71432	13	9.4	10	-	H	D
Benzyl chloride	100447	-	<6.8	-	-	H	TD
Bromodichloromethane	75274	-	-	-	-	M	TD
Bromoform	75252	-	-	-	-	M	TD
Bromomethane	74839	0.5	<1.7	-	-	M	TD
Carbon disulfide	75150	-	4.2	-	-	M	TD
Carbon tetrachloride	56235	1.3	<1.3	1.1	-	H	A
Chlorobenzene	108907	0.4	<0.9	-	-	M	TD
Chloroethane	75003	0.4	<1.1	-	-	L	TD
Chloroform	67663	1.2	1.1	6.34	-	H	TD
Chloromethane	74873	4.2	3.7	-	-	M	TD
cis-1,2-Dichloroethene	156592	0.4	<1.9	-	-	M	A
cis-1,3-Dichloropropene	10061015	0.4	<2.3	-	-	NA	TD
Cyclohexane	110827	6.3	-	-	-	L	D

Table 1C
Soil Vapor Criteria Table
55 Eckford Street, Brooklyn, NY
BCP Site No, C224168
QAPP/FSP

Volatile Organics in Air	CAS No.	NYSDOH Soil Vapor Intrusion Guidance Criteria				Toxicity	Decision Matrices A, B, C, D, E, and F
		1	2	3	4		
Dibromochloromethane	124481	-	-	-	-	NA	TD
Dichlorodifluoromethane	75718	10	16.5	-	-	NA	TD
Ethanol	64175	1300	210	-	-	L	TD
Ethyl Acetate	141786	-	5.4	-	-	M	TD
Ethylbenzene	100414	6.4	5.7	7.62	-	M	D
Freon-113	76131	2.5	3.5	-	-	L	TD
Freon-114	76142	0.4	<6.8	-	-	NA	TD
Heptane	142825	18	-	-	-	M	E
Hexachlorobutadiene	87683	0.5	<6.8	-	-	M	TD
Isopropanol	67630	-	-	-	-	M	TD
Methyl tert butyl ether	1634044	14	11.5	36	-	M	TD
Methylene chloride	75092	16	10	7.5	60	NA	B
Napthalene	91203	-	20.9	-	-	M	D
n-Hexane	110543	14	10.2	-	-	M	E
o-Xylene	95476	7.1	7.9	7.24	-	M	D
p/m-Xylene	179601231	11	22.2	22.2	-	M	E
Styrene	100-42-5	1.4	1.9	5.13	-	M	TD
Tertiary butyl Alcohol	75-65-0	-	-	-	-	NA	TD
Tetrachloroethene (PCE)	127184	2.5	15.9	6.01	30	H	B
Tetrahydrofuran	109999	0.8	-	-	-	M	TD
Toluene	108883	57	43	39.8	-	L	F
trans-1,2-Dichloroethene	156605	-	-	-	-	NA	TD
trans-1,3-Dichloropropene	10061026	NC	<1.3	-	-	NA	TD
Trichloroethene	79016	0.5	4.2	1.36	2	H	A
Trichlorofluoromethane	75694	12	18.1	-	-	L	TD
Vinyl bromide	593602	-	-	-	-	H	TD
Vinyl chloride	75014	0.4	<1.9	-	-	H	C

Notes:

ND - Non-detect

TD -To be determined based on the NYSDOH VI Decision

Results are shown as micrograms per cubic meter (ug/m³)

NYSDOH Soil Vapor Intrusion Guidance Criteria

1 - Table C-1 2003 Upper Fence Study of Volatile Organic Chemicals in air of Fuel Oil Heated Homes for Indoor Air

2 - Table C-2 2001 USEPA BASE 90th Percentile for Indoor Air

3 -Table C-5 2005 Health Effects Institute 95th Percentile for Indoor Air

4 -NYSDOH Air Guidance Value

Toxicities from 6NYCRR Part 212 - DAR-1 Appendix C/SCG/ACG

(H) HIGH Toxicity Contaminant.

(M) MODERATE Toxicity Contaminant.

(L) LOW Toxicity Contaminant. Reasonable - Take reasonable/practical actions to identify source/reduce exposure

NYSDOH Decision Matrices :

Matrix A: Sub-Slab >6 , Indoor Air >1

Matrix B: Sub-Slab >100 , Indoor Air > 10

Matrix C: Sub-Slab >6 , Indoor Air > 0.2

Matrix D: Sub-Slab >60 , Indoor Air >10

Matrix E: Sub-Slab >200 , Indoor Air >20

Matrix F: Sub-Slab > 300 , Indoor Air >0.2

Table 2
Typical Analytical Parameters, Methods, Preservation, Holding Time and Container Requirements
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Sample Matrix	Analytical Parameter	Sample Type ¹	No. of Samples ²	EPA Analytical Method	Sample Preservation	Holding Time ³	Sample Container ⁴
Soil	VOCs	Discrete	74	SW-846 Method 8260C/5035	1 - Methanol, 2 - Water; Cool to 4° C;	14 days to analysis	(3) Vial
	(TCL)				no headspace		
Soil	VOCs with Tentatively Identified Compounds (TICs)	Discrete	8	SW-846 Method 8260C/5035	1 - Methanol, 2 - Water; Cool to 4° C;	14 days to analysis	(3) Vial
	(TCL)				no headspace		
Soil	PCBs	Composite	52	SW-846 Method 8082A	Cool to 4° C	365 days to analysis	(1) 250 mL amber glass jar
Soil	Pesticides	Composite	52	SW-846 Method 8081A	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
Soil	(TCL)						
Soil	SVOCs	Composite	74	SW-846 Method 8270D	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
Soil	(TCL)						
Soil	SVOCs with TICs	Composite	8	SW-846 Method 8270D	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
Soil	(TCL)						
Soil	1,4-Dioxane	Composite	8	SW-846 Method 8270D	Cool to 4° C	7 days to extraction	(2) 250 mL amber glass jars
Soil	(TCL)						
Soil	Metals	Composite	82	SW-846 Method 6010D Series	Cool to 4° C	180 days to analysis	(1) 60 mL glass jar
Soil	(TAL)						
Soil	Mercury	Composite	52	SW-846 Method 7471B	Cool to 4° C	28 days to analysis	(1) 60 mL glass jar
Soil	Cyanide	Composite	52	SW-846 Method 9010C/9012B	Cool to 4° C	14 days to analysis	(1) 250 mL amber glass jar
Soil	Herbicides	Composite	52	SW-846 Method 8151A	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
Soil	PFAs	Composite	8	EPA Method 1633	Cool to 4° C	14 Days	(1) 250 mL plastic container
Groundwater	VOCs	Grab	5	SW-846 Method 8260C	HCl; Cool to 4° C; no headspace	14 days to analysis	(3) Vial
	(TCL)						
Groundwater	VOCs with TICs, including 1,4-Dioxane	Grab	4	SW-846 Method 8260C	HCl; Cool to 4° C; no headspace	14 days to analysis	(3) Vial
	(TCL)						
Groundwater	1,4-Dioxane	Grab	4	SW-846 Method 8270D	Cool to 4° C	7 days to analysis	(2) 250 mL amber glass jar
Groundwater	SVOCs	Grab	5	SW-846 Method 8270D	Cool to 4° C	7 days to extraction	(2) 250 mL amber glass jar
	(TCL)						
Groundwater	SVOCs with TICs	Grab	4	SW-846 Method 8270D	Cool to 4° C	7 days to extraction	(2) 250 mL amber glass jar
	(TCL)						
Groundwater	Metals- total	Grab	9	SW-846 Method 6020B/7470A Series	HNO ₃ ; Cool to 4° C	28 days to analysis for Hg; 180 days to analysis for other	(1) 500 mL plastic container
	(TAL)						
Groundwater	Metals-dissolved	Grab	9	SW-846 Method 6020B/7470A Series	HNO ₃ ; Cool to 4° C	28 days to analysis for Hg; 180 days to analysis for other metals	(1) 500 mL plastic container
	(TAL)						
Groundwater	Pesticides (TCL)	Grab	9	SW-846 Method 8081B	Cool to 4° C	7 days to extraction	(2) 120 mL amber glass jar
Groundwater	Herbicides (TCL)	Grab	9	SW-846 Method 8151A	Cool to 4° C	7 days to extraction	(2) 1000 mL amber glass jar
Groundwater	PCBs	Grab	9	SW-846 Method 8082A	Cool to 4° C	365 days to analysis	(1) 250 mL amber glass jar
Groundwater	Cyanide	Grab	9	SW-846 Method 9012A	Cool to 4° C	14 days to analysis	(1) 250 mL amber glass jar
Groundwater	Mercury	Grab	9	SW-846 Method 7470 A	HNO ₃ ; Cool to 4° C	28 days to analysis	(1) 250 mL plastic container
Groundwater	PFAs	Grab	4	EPA Method 1633	Cool to 4° C	14 Days	(1) 250 mL plastic container
Soil Gas	VOCs	Grab	6	EPA Method TO-15	None	14 days to analysis	(1) Evacuated 6-Liter SUMMA® canister

Notes:

¹ For soil samples, a six-inch sampling interval is the preferred sample size; however, sample volume recovery, analytical method requirements, and field conditions can affect the actual sample interval size. For these reasons, the actual sampling interval may change in order to obtain adequate volume.

² Actual number of samples may vary depending on field conditions, sample material availability, and field observations. See RIWP for estimates.

³ Holding times listed are method holding time calculated from time of collection and not NYSDEC ASP holding times.

⁴ MS/MSDs require duplicate volume for all parameters for solid matrices; MS/MSDs require triplicate volume for organic parameters for aqueous matrices and duplicate volume for inorganic parameters for aqueous matrices

Table 3
Typical Laboratory Data Quality Objectives
Soil Samples
55 Eckford Street, Brooklyn, NY
BCP Site No. C24168
QAPP/FSP

Parameter	Method	Matrix	Accuracy Control Limits	Accuracy Frequency Requirements	Precision (RPD) Control Limits	Precision Frequency Requirements
VOCs (TCL)	SW-846 Methods 8260B/5035	Soil	<u>Surrogates</u> % Rec. 1,2-Dichloroethane-d4 70-130 4-Bromofluorobenzene 70-130 Dibromofluoromethane 70-130 Toluene-d8 70-130 2-Chloroethoxyethane 70-130 <u>Matrix Spikes</u> 30-151% recovery	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 30 per matrix type	<u>Field Duplicates</u> RPD <30 <u>MS/MSDs</u> (RPD) RPD <30	<u>Field Duplicates</u> : One per 20 per soils <u>MS/MSDs</u> : One per 30 per matrix type
VOCs with Tentatively Identified Compounds (TICs)	SW-846 Method 8260C	Soil	<u>Surrogates</u> % Rec. 1,2-Dichloroethane-d4 70-130 4-Bromofluorobenzene 70-130 Dibromofluoromethane 70-130 Toluene-d8 70-130 <u>Matrix Spikes</u> 36-162 % recovery	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 20	<u>Field Duplicates</u> RPD <30 <u>MS/MSDs</u> RPD RPD <30	<u>Field Duplicates</u> : One per 20 <u>MS/MSDs</u> : One per 20
PCBs	SW-846 Method 8082A	Soil	<u>Surrogates</u> % Rec. 2,4,5,6-Tetrachloro-m-xylene 30-150 Decachlorobiphenyl 30-150 <u>Matrix Spikes</u> 40-140% recovery	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 20 per matrix type	<u>Field Duplicates</u> RPD <50 <u>MS/MSDs</u> (RPD) RPD <50	<u>Field Duplicates</u> : One per 20 per soils <u>MS/MSDs</u> : One per 20 per matrix type
SVOCs	SW-846 Method 8270D	Soil	<u>Surrogates</u> % Rec. Phenol-d6 10-120 2-Fluorophenol 25-120 2,4,6-Tribromophenol 10-136 Nitrobenzene-d5 23-120 2-Fluorobiphenyl 30-120 4-Terphenyl-d14 18-120 <u>Matrix Spikes</u> 14-144% recovery	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 50 per matrix type	<u>Field Duplicates</u> RPD <50 <u>MS/MSDs</u> (RPD)	<u>Field Duplicates</u> : One per 20 per soils <u>MS/MSDs</u> : One per 20 per matrix type
SVOCs with TICs	SW-846 Method 8270D	Soil	<u>Surrogates</u> % Rec. Phenol-d5 10-120 2-Fluorophenol 21-120 2,4,6-Tribromophenol 10-120 Nitrobenzene-d5 23-120 2-Fluorobiphenyl 15-120 4-Terphenyl-d14 41-149 <u>Matrix Spikes</u> 14-144%	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 20	<u>Field Duplicates</u> RPD <50 <u>MS/MSDs</u> RPD RPD <50	<u>Field Duplicates</u> : One per 20 <u>MS/MSDs</u> : One per 20
1,4-Dioxane	SW-846 Method 8270D	Soil	<u>Surrogates</u> % Rec. 1,4-Dioxane-d8 15-110 <u>Matrix Spikes</u> 40-140% recovery	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 20 per matrix type	<u>Field Duplicates</u> RPD <30 <u>MS/MSDs</u> (RPD) RPD <30	<u>Field Duplicates</u> : One per 20 per soils <u>MS/MSDs</u> : One per 20 per matrix type
Pesticides (TCL)	SW-846 Method 8081A	Soil	<u>Surrogates</u> % Rec. Decachlorobiphenyl 30-150 Tetrachloro-m-xylene 30-150 <u>Matrix Spikes</u> 30-150% Recovery	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 20 per matrix type	<u>Field Duplicates</u> RPD <50 <u>MS/MSDs</u> (RPD) RPD <50	<u>Field Duplicates</u> : One per 20 per soils <u>MS/MSDs</u> : One per 20 per matrix type
Total Petroleum Hydrocarbons	SW-846 Method 8015B	Soil	<u>Surrogates</u> % Rec. o-Terphenyl 27-153 Tetracosane-d50 28-148 5 α -androstane 27-148 TPH-DRO 10-149	<u>Surrogates</u> : All samples, standards, QC samples One per 20 per matrix type	<u>Field Duplicates</u> RPD <50 TPH-DRO 44	<u>Field Duplicates</u> : One per 20 per soils One per 20 per matrix type
Herbicides	SW-846 Method 8151A	Soil	<u>Surrogates</u> % Rec. 2,4-DCAA 30-150 <u>Matrix Spikes</u> 30-150% Recovery	<u>Surrogates</u> : All samples, standards, QC samples <u>Matrix Spikes</u> : One per 20 per matrix type	<u>Field Duplicates</u> RPD <50 <u>MS/MSDs</u> (RPD) RPD <50	<u>Field Duplicates</u> : One per 20 per soils <u>MS/MSDs</u> : One per 20 per matrix type
Metals (TAL)	SW-846 Method 6010D	Soil	<u>Surrogates</u> % Rec. <u>Matrix Spikes</u> 75-125% recovery	<u>Surrogates</u> : <u>Matrix Spikes</u> : One per 20 per matrix type	<u>Field Duplicates</u> RPD <20 <u>MS/MSDs</u> (RPD) RPD <20	<u>Field Duplicates</u> : One per 20 per soils <u>MS/MSDs</u> : One per 20 per matrix type

Table 3
Typical Laboratory Data Quality Objectives
Soil Samples
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Parameter	Method	Matrix	Accuracy Control Limits	Accuracy Frequency Requirements	Precision (RPD) Control Limits	Precision Frequency Requirements
PFAs	LCMS/MS- Isotope Dilution	Soil	<u>Surrogates:</u> % Rec. Perfluoro[13C4]Butanoic Acid (MPFBA) 61-135 Perfluoro[13C4]Butanoic Acid (MPFBA) 58-132 Perfluoro[13C5]Pentanoic Acid (MSPFPEA) 62-163 Perfluoro[13C5]Pentanoic Acid (MSPFPEA) 58-150 Perfluoro[2,3,4-13C3]Butanesulfonic Acid (M3PFBS) 70-131 Perfluoro[2,3,4-13C3]Butanesulfonic Acid (M3PFBS) 74-139 Perfluoro[1,2,3,4,6-13C5]Hexanoic Acid (M5PFHxA) 57-129 Perfluoro[1,2,3,4,6-13C5]Hexanoic Acid (M5PFHxA) 66-128 Perfluoro[1,2,3,4-13C4]Heptanoic Acid (M4PFHpA) 60-129 Perfluoro[1,2,3,4-13C4]Heptanoic Acid (M4PFHpA) 71-129 Perfluoro[1,2,3-13C3]Hexanesulfonic Acid (M3PFHxS) 71-134 Perfluoro[1,2,3-13C3]Hexanesulfonic Acid (M3PFHxS) 78-139 Perfluoro[13C8]Octanoic Acid (M8PFOA) 62-129 Perfluoro[13C8]Octanoic Acid (M8PFOA) 75-130 1H,1H,2H,2H-Perfluoro[1,2-13C2]Octanesulfonic Acid (M2-6:2FTS) 14-147 1H,1H,2H,2H-Perfluoro[1,2-13C2]Octanesulfonic Acid (M2-6:2FTS) 20-154 Perfluoro[13C9]Nonanoic Acid (M9PFNA) 59-139 Perfluoro[13C9]Nonanoic Acid (M9PFNA) 72-140 Perfluoro[13C8]Octanesulfonic Acid (M8PFOS) 79-136 Perfluoro[13C8]Octanesulfonic Acid (M8PFOS) 69-131 Perfluoro[1,2,3,4,5,6-13C6]Decanoic Acid (M6PFDA) 75-130 Perfluoro[1,2,3,4,5,6-13C6]Decanoic Acid (M6PFDA) 62-124 1H,1H,2H,2H-Perfluoro[1,2-13C2]Decanesulfonic Acid (M2-8:2FTS) 19-175 1H,1H,2H,2H-Perfluoro[1,2-13C2]Decanesulfonic Acid (M2-8:2FTS) 10-162 N-Deuteriomethylperfluoro-1-octanesulfonamidoacetic Acid (d3-NMeFOSAA) 24-116 N-Deuteriomethylperfluoro-1-octanesulfonamidoacetic Acid (d3-NMeFOSAA) 31-134 Perfluoro[1,2,3,4,5,6,7-13C7]Undecanoic Acid (M7-PFUOA) 61-155 Perfluoro[1,2,3,4,5,6,7-13C7]Undecanoic Acid (M7-PFUOA) 55-137 Perfluoro[13C8]Octanesulfonamide (M8FOSA) 10-112 Perfluoro[13C8]Octanesulfonamide (M8FOSA) 10-117 N-Deuteroethylperfluoro-1-octanesulfonamidoacetic Acid (d5-NEtFOSAA) 34-137 N-Deuteroethylperfluoro-1-octanesulfonamidoacetic Acid (d5-NEtFOSAA) 27-126 Perfluoro[1,2-13C2]Dodecanoic Acid (MPFDOA) 48-131 Perfluoro[1,2-13C2]Dodecanoic Acid (MPFDOA) 54-150 Perfluoro[1,2-13C2]Tetradecanoic Acid (M2PFTEDA) 22-136 Perfluoro[1,2-13C2]Tetradecanoic Acid (M2PFTEDA) 24-159 <u>Matrix Spikes</u> 46-182% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20 per matrix type	<u>Field Duplicates</u> RPD <30 <u>MS/MSDs</u> (RPD) RPD <30	<u>Field Duplicates:</u> One per 20 per soils <u>MS/MSDs:</u> One per 20 per matrix type
Mercury	SW-846 Method 7471B	Soil	<u>Surrogates</u> % Rec. <u>Matrix Spikes</u> 80-125% recovery	<u>Surrogates:</u> <u>Matrix Spikes:</u> One per 20 per matrix type	<u>Field Duplicates</u> RPD <20 <u>MS/MSDs</u> (RPD) RPD <20	<u>Field Duplicates:</u> One per 20 per soils <u>MS/MSDs:</u> One per 20 per matrix type
Cyanide	SW-846 Method 9012A	Soil	<u>Surrogates</u> % Rec. <u>Matrix Spikes</u> 75-125% Recovery	<u>Surrogates:</u> <u>Matrix Spikes:</u> One per 35 per matrix type	<u>Field Duplicates</u> RPD <35 <u>MS/MSDs</u> (RPD) RPD <35	<u>Field Duplicates:</u> One per 20 per soils <u>MS/MSDs:</u> One per 20 per matrix type

Recovery criteria for laboratory control samples must be at least as stringent as MS/MSD criteria. Laboratory control limits are periodically updated. The latest control limits will be utilized at the time of sample analysis.

Table 4
Typical Laboratory Data Quality Objectives
Groundwater Samples
55 Eckford Street, Brooklyn, NY
BCp Site No. C224168
QAPP/FSP

Parameter	Method	Matrix	Accuracy Control Limits	Accuracy Frequency Requirements	Precision (RPD) Control Limits	Precision Frequency Requirements
VOCs (TCL)	SW-846 Method 8260C	Groundwater	<u>Surrogates</u> % Rec. 1,2-Dichloroethane-d4 70-130 4-Bromofluorobenzene 70-130 Dibromofluoromethane 70-130 Toluene-d8 70-130 <u>Matrix Spikes</u> 36-162 % recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates</u> RPD <20 <u>MS/MSDs</u> <u>RPD</u> RPD <20	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20
VOCs with Tentatively Identified Compounds (TICs)	SW-846 Method 8260C	Groundwater	<u>Surrogates</u> % Rec. 1,2-Dichloroethane-d4 70-130 4-Bromofluorobenzene 70-130 Dibromofluoromethane 70-130 Toluene-d8 70-130 <u>Matrix Spikes</u> 36-162 % recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates</u> RPD <20 <u>MS/MSDs</u> <u>RPD</u> RPD <20	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20
SVOCs (TCL)	SW-846 Method 8270D	Groundwater	<u>Surrogates</u> % Rec. Phenol-d5 10-120 2-Fluorophenol 21-120 2,4,6-Tribromophenol 10-120 Nitrobenzene-d5 23-120 2-Fluorobiphenyl 15-120 4-Terphenyl-d14 41-149 <u>Matrix Spikes</u> 14-144%	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates</u> RPD <50 <u>MS/MSDs</u> <u>RPD</u> RPD <50	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20
SVOCs with TICs	SW-846 Method 8270D	Groundwater	<u>Surrogates</u> % Rec. Phenol-d5 10-120 2-Fluorophenol 21-120 2,4,6-Tribromophenol 10-120 Nitrobenzene-d5 23-120 2-Fluorobiphenyl 15-120 4-Terphenyl-d14 41-149 <u>Matrix Spikes</u> 14-144%	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates:</u> RPD <50 <u>MS/MSDs</u> <u>RPD</u> RPD <50	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20
1,4-Dioxane	SW-846 Method 8270D	Groundwater	<u>Surrogates</u> % Rec. 1,4-Dioxane-d8 15-110 <u>Matrix Spikes</u> 40-140% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates</u> RPD <30 <u>Matrix Duplicates</u> RPD <30	<u>Field Duplicates:</u> One per 20 per soils <u>MS/MSDs:</u> One per 20
Metals (Total and Dissolved)	SW-846 Methods 6020B	Groundwater	<u>Matrix Spikes</u> 75-125% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates</u> RPD <20 <u>Matrix Duplicates</u> RPD <20	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20
Mercury (Total and Dissolved)	SW-846 Methods 7470A	Groundwater	<u>Matrix Spikes</u> 75-125% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates</u> RPD <35 (dissolved) RPD <20 (Total) <u>Matrix Duplicates</u> RPD <35 (dissolved) RPD <20 (Total)	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20
PCBs	SW-846 Method 8082A	Groundwater	<u>Surrogates</u> % Rec. 2,4,5,6-Tetrachloro-m-xylene 30-150 Decachlorobiphenyl 30-150 <u>Matrix Spikes</u> 40-140% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20 per matrix type	<u>Field Duplicates</u> RPD <50 <u>MS/MSDs</u> <u>(RPD)</u> RPD <50	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20 per matrix type
Herbicides	SW-846 Method 8151A	Groundwater	<u>Surrogates</u> % Rec. 2,4-DCAA 30-150 <u>Matrix Spikes</u> 30-150% Recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20 per matrix type	<u>Field Duplicates:</u> RPD <50 <u>MS/MSDs</u> <u>(RPD)</u> RPD <50	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20 per matrix type

Table 4
Typical Laboratory Data Quality Objectives
Groundwater Samples
55 Eckford Street, Brooklyn, NY
BCp Site No. C224168
QAPP/FSP

Parameter	Method	Matrix	Accuracy Control Limits	Accuracy Frequency Requirements	Precision (RPD) Control Limits	Precision Frequency Requirements
Pesticides (TCL)	SW-846 Method 8081B	Groundwater	<u>Surrogates</u> Decachlorobiphenyl 15-142 2,4,5,6-Tetrachloro-m-xylene 36-126 <u>Matrix Spikes</u> 30-150% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20	<u>Field Duplicates</u> RPD <30 <u>MS/MSDs</u> <u>RPD</u> RPD <30	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20
PFA's	EPA Method 1633	Grounwater	<u>Surrogates</u> Perfluoro[13C4]Butanoic Acid (MPFBA) Perfluoro[13C4]Butanoic Acid (MPFBA) Perfluoro[13C5]Pentanoic Acid (M5PFPEA) Perfluoro[13C5]Pentanoic Acid (M5PFPEA) Perfluoro[2,3,4-13C3]Butanesulfonic Acid (M3PFBS) Perfluoro[2,3,4-13C3]Butanesulfonic Acid (M3PFBS) Perfluoro[1,2,3,4,6-13C5]Hexanoic Acid (M5PFHxA) Perfluoro[1,2,3,4,6-13C5]Hexanoic Acid (M5PFHxA) Perfluoro[1,2,3,4-13C4]Heptanoic Acid (M4PFHpA) Perfluoro[1,2,3,4-13C4]Heptanoic Acid (M4PFHpA) Perfluoro[1,2,3-13C3]Hexanesulfonic Acid (M3PFHxS) Perfluoro[1,2,3-13C3]Hexanesulfonic Acid (M3PFHxS) Perfluoro[13C8]Octanoic Acid (M8PFOA) Perfluoro[13C8]Octanoic Acid (M8PFOA) 1H,1H,2H,2H-Perfluoro[1,2-13C2]Octanesulfonic Acid (M2-1H,1H,2H,2H-Perfluoro[1,2-13C2]Octanesulfonic Acid (M2-Perfluoro[13C9]Nonanoic Acid (M9PFNA) Perfluoro[13C9]Nonanoic Acid (M9PFNA) Perfluoro[13C8]Octanesulfonic Acid (M8PFOS) Perfluoro[13C8]Octanesulfonic Acid (M8PFOS) Perfluoro[1,2,3,4,5,6-13C6]Decanoic Acid (M6PFDA) Perfluoro[1,2,3,4,5,6-13C6]Decanoic Acid (M6PFDA) 1H,1H,2H,2H-Perfluoro[1,2-13C2]Decanesulfonic Acid (M2-1H,1H,2H,2H-Perfluoro[1,2-13C2]Decanesulfonic Acid (M2-N-Deuteriomethylperfluoro-1-octanesulfonamidoacetic Acid N-Deuteriomethylperfluoro-1-octanesulfonamidoacetic Acid Perfluoro[1,2,3,4,5,6,7-13C7]Undecanoic Acid (M7-PFUDA) Perfluoro[1,2,3,4,5,6,7-13C7]Undecanoic Acid (M7-PFUDA) Perfluoro[13C8]Octanesulfonamide (M8FOSA) Perfluoro[13C8]Octanesulfonamide (M8FOSA) N-Deuterioethylperfluoro-1-octanesulfonamidoacetic Acid (d5-N-Deuterioethylperfluoro-1-octanesulfonamidoacetic Acid (d5-Perfluoro[1,2-13C2]Dodecanoic Acid (MPFDOA) Perfluoro[1,2-13C2]Dodecanoic Acid (MPFDOA) Perfluoro[1,2-13C2]Tetradecanoic Acid (M2PFTEDA) Perfluoro[1,2-13C2]Tetradecanoic Acid (M2PFTEDA) <u>Matrix Spikes</u> 46-182% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 20 per matrix type	<u>Field Duplicates</u> RPD <30 <u>MS/MSDs</u> <u>(RPD)</u> RPD <30	<u>Field Duplicates:</u> One per 20 <u>MS/MSDs:</u> One per 20 per matrix
Cyanide	EPA Method 9012B	Groundwater	<u>Matrix Spikes</u> 75-125% recovery	<u>Surrogates:</u> All samples, standards, QC samples <u>Matrix Spikes:</u> One per 35	<u>Field Duplicates</u> RPD <35 <u>Matrix Duplicates</u> RPD <35	<u>Field Duplicates:</u> One per 20 <u>Matrix Duplicates:</u> One per 20
Recovery criteria for laboratory control samples must be at least as stringent as MS/MSD criteria.						
Laboratory control limits are periodically updated. The latest control limits will be utilized at the time of sample analysis.						

Table 5
Typical Laboratory Data Quality Objectives
Soil Vapor Samples
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Parameter	Method	Matrix	Accuracy Control Limits	Accuracy Frequency Requirements	Precision (RPD) Control Limits	Precision Frequency Requirements
VOCs	EPA Method TO-15	Soil Gas	<u>Surrogates</u> % Rec. 4-Bromofluorobenzene 78-124	<u>Surrogates:</u> All samples, standards, QC samples	<u>Matrix Duplicates</u> RPD £30	<u>Matrix Duplicates</u> One per 20

Table 6
QC Sample Preservation and Container Requirements
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Sample Matrix	Analytical Parameter	Sample Type	No. of Samples	EPA Analytical Method	Sample Preservation	Holding Time ¹	Sample Container
Soil	VOCs	Discrete	4	SW-846 Method 8260C/5035	1 - Methanol, 2 - Water; Cool to 4° C;	14 days to analysis	(3) Vial Preserved
	(TCL)				no headspace		
Soil	VOCs with Tentatively Identified	Discrete	1	SW-846 Method 8260C/5035	1 - Methanol, 2 - Water; Cool to 4° C;	14 days to analysis	(3) Vial Preserved
	(TCL)				no headspace		
Soil	PCBs	Composite	3	SW-846 Method 8082A	Cool to 4° C	365 days to analysis	(1) 250 mL amber glass jar
Soil	Pesticides	Composite	3	SW-846 Method 8081A	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
	(TCL)						
Soil	SVOCs	Composite	4	SW-846 Method 8270D	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
	(TCL)						
Soil	SVOCs with TICs	Composite	1	SW-846 Method 8270D	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
	(TCL)						
Soil	1,4-Dioxane	Composite	1	SW-846 Method 8270D	Cool to 4° C	7 days to extraction	(2) 250 mL amber glass jars
Soil	Metals	Composite	5	SW-846 Method 6010D Series	Cool to 4° C	180 days to analysis	(1) 60 mL glass jar
	(TAL)						
Soil	Mercury	Composite	3	SW-846 Method 7471B	Cool to 4° C	28 days to analysis	(1) 60 mL glass jar
Soil	Cyanide	Composite	3	SW-846 Method 9010C/9012B	Cool to 4° C	14 days to analysis	(1) 250 mL amber glass jar
Soil	Herbicides	Composite	3	SW-846 Method 8151A	Cool to 4° C	14 days to extraction	(1) 250 mL amber glass jar
Soil	Pesticides	Composite	3	SW-846 Method 8141A ⁶	Cool to 4° C	14 days to extraction	(1) 300 mL amber glass jar
Soil	PFAs	Composite	1	EPA Method 1633	Cool to 4° C	14 Days	(1) 250 mL plastic container

Table 6
QC Sample Preservation and Container Requirements
55 Eckford Street, Brooklyn, NY
BCP Site No. C224168
QAPP/FSP

Groundwater	VOCs (TCL)	Grab	1	SW-846 Method 8260C	HCl; Cool to 4 ⁰ C; no headspace	14 days to analysis	(3) Vial
Groundwater	VOCs with TICs, including 1,4- Dioxane	Grab	1	SW-846 Method 8260C	HCl; Cool to 4 ⁰ C; no headspace	14 days to analysis	(3) Vial
Groundwater	(TCL)						
Groundwater	1,4-Dioxane	Grab	1	SW-846 Method 8270D	Cool to 4 ⁰ C	7 days to analysis	(2) 250 mL amber glass jar
Groundwater	SVOCs	Grab	1	SW-846 Method 8270D	Cool to 4 ⁰ C	7 days to extraction	(2) 250 mL amber glass jar
Groundwater	(TCL)						
Groundwater	SVOCs with TICs	Grab	1	SW-846 Method 8270D	Cool to 4 ⁰ C	7 days to extraction	(2) 250 mL amber glass jar
Groundwater	(TCL)						
Groundwater	Metals- total	Grab	1	SW-846 Method 6020B/7470A Series	HNO ₃ ; Cool to 4 ⁰ C	28 days to analysis for Hg; 180 days to analysis for other metals	(1) 500 mL plastic container
Groundwater	(TAL)						
Groundwater	Metals-dissolved	Grab	1	SW-846 Method 6020B/7470A Series	HNO ₃ ; Cool to 4 ⁰ C	28 days to analysis for Hg; 180 days to analysis for other metals	(1) 500 mL plastic container
Groundwater	(TAL)						
Groundwater	Pesticides (TCL)	Grab	1	SW-846 Method 8081B	Cool to 4 ⁰ C	7 days to extraction	(2) 120 mL amber glass jar
Groundwater	Herbicides (TCL)	Grab	1	SW-846 Method 8151A	Cool to 4 ⁰ C	7 days to extraction	(2) 1000 mL amber glass jar
Groundwater	PCBs	Grab	1	SW-846 Method 8082A	Cool to 4 ⁰ C	365 days to analysis	(1) 250 mL amber glass jar
Groundwater	Cyanide	Grab	1	SW-846 Method 9012A	Cool to 4 ⁰ C	14 days to analysis	(1) 250 mL amber glass jar
Groundwater	Mercury	Grab	1	SW-846 Method 7470 A	HNO ₃ ; Cool to 4 ⁰ C	28 days to analysis	(1) 250 mL plastic container
Groundwater	PFA's	Grab	1	EPA Method 1633	Cool to 4 ⁰ C	14 Days	(1) 250 mL plastic container
Soil Gas	VOCs	Grab	1	EPA Method TO-15	None	14 days to analysis	(1) Evacuated 6- Liter SUMMA® canister
Notes: 1 Holding times listed are method holding time calculated from time of collection and not NYSDEC ASP holding times.							



June 2024
File No. 41.0163263.00
QAPP/FSP – 55 Eckford Street, Brooklyn, NY

ATTACHMENTS



Chunhua Liu

Senior Technical Specialist

Summary of Experience

Dr. Liu is a senior chemist with more than 10 years of experience in analytical chemistry, data validation and management, and quality control and quality assurance for remedial investigations and remedial actions. Her experience includes laboratory chemical analysis, EPA Region I and Region II data validation and data usability evaluation, data usability evaluation for Massachusetts Contingency Plan (MCP), sampling and analysis plan development in accordance with the NYSDEC Analytical Service Protocol and Massachusetts Compendium of Quality Assurance and Quality Control Requirements (QA/QC) and Performance Standards for Selected Analytical Methods, and quality control and quality assurance for Superfund and MCP projects.

Dr. Liu majored in environmental chemistry and during her doctoral study at Harvard School of Public Health, she researched analytical methods for sediment and evaluated metal fate and transport in sediment. Dr. Liu worked at Parsons for over seven years and at Gradient for one year before joining GZA. At Parsons, Dr. Liu led the quality control and assurance and data management efforts from developing Quality Assurance Project Plan (QAPP) to assuring implementation of QA/QC requirements and from field sampling preparation and arrangement to chemical data management. Dr. Liu was responsible for the QA/QC and data validation and data usability evaluation for a 10,000-acre BRAC and Superfund NPL site in New York and assisted in the successful transfer of over 8,000 acres of land. Dr. Liu performed data usability evaluation for various Massachusetts Contingency Plan sites at Gradient and GZA.

Relevant Project Experience

Senior Technical Specialist - Leads GZA human health risk assessment efforts for federal and state level superfund and MCP projects. Dr. Liu is also responsible for data usability evaluation for various projects.

Technical Director - Directed preparation and submittal of the Site-Wide Sampling and Analysis Plan (SAP) and the Site-Wide Quality Assurance Project Plan (QAPP) for a 10,000-acre Superfund site in New York in accordance with the Department of Defense (DOD), NYSDEC ASP, EPA Region II and EPA guidance. Directed project field sampling and data management. Supervised data validation in accordance with EPA Region II SOPs and NYSDEC ASP based on the NYSDEC ASP Category B deliverables. Identified laboratories qualified for project chemical analyses and interfaced with various analytical laboratories to address analytical deficiencies. Submitted data summary report to EPA Region II on a quarterly basis.

Lead Chemist and Risk Assessor - Led data usability evaluation and supported the successful closure of a 125-acre Hingham Annex Guaranteed Fixed Price Remediation Project. Dr. Liu also led the risk assessment effort and the effort of evaluating pesticide fate and transport at the site and successfully demonstrated that the pesticide conditions at the site were related to the past normal use of pesticides and therefore were not associated with the release at the Site.

Technical Director - Directed preparation and submittal of the SAP and the QAPP for various Formerly Used Defense (FUD) Sites. Supervised field sampling and data validation in accordance with guidance from various EPA regions. Reviewed data validation and data usability report.

Education

B.E., 1992, Environmental Engineering,

Tsinghua University, Beijing, China

M.E., 1995, Environmental Engineering,

Tsinghua University, Beijing, China

M.S., 1998, Environmental Health, Harvard
School of Public Health

D.S., 2000, Environmental Chemistry,
Harvard School of Public Health

Affiliations

- Member, LSP Association
- Member, Society for Risk Analysis
- Certified EIT in Massachusetts

Areas of Specialization

- Human Health Risk Assessment
- Ecological Risk Assessment
- Data Usability Evaluation
- Project Quality Control and Assurance
- Fate and Transport Modeling



Chunhua Liu

Senior Technical Specialist

Technical Director – Directed data validation for various Superfund sites in EPA Region I and Region II in accordance with the EPA regional and state SOPs and the EPA Functional Guidelines. Led data validation for numerous MCP sites for various analytical analyses including metal, VOC, SVOC, pesticide, PCB, EPH, VPH, and TPH analyses.

Project Chemist – Evaluated different analytical methods for hexavalent chromium analysis. Compared analytical methods developed by NJDEP and EPA and identified the appropriate method for a CERCLA site in New Jersey.

Project Chemist – Evaluated quantitatively potential impacts to metal data usability by interference caused by common metals in environmental samples for a CERCLA site in New York.

Project Chemist – Performed data validation for indoor air samples for various CERCLA and MCP Sites to assist evaluation of potential vapor intrusion pathway.

Project Chemist – Performed Level IV data validation for a Superfund site in New York for various analytical analyses including metal, VOC, SVOC, pesticide, and PCB analyses. Reviewed TIC identification and quantitation and assessed chromatograms and mass spectrums for VOCs and SVOCs.

Project Chemist – Provided technical support, prepared QAPPs, established proper data quality objectives (DQOs) for various projects, maintained project quality control, trained junior scientists, coordinated project field sampling and laboratory analyses, addressed non-conformance issues associated with the data produced by the laboratory, conducted statistical analysis, and prepared data validation reports on numerous RCRA/CERCLA and MCP projects.

Publications

Liu, C., J. Jay, T. Ford. Evaluation of Environmental Effects on Metal Transport from Capped Contaminated Sediment under Conditions of Submarine Groundwater Discharge. *Env. Sci. Tech.* 2001 35: 4549-4555.

Liu, C., J. Jay, R. Ika, S. James, and T. Ford. Capping efficiency for metal-contaminated marine sediment under conditions of groundwater inflow. *Env. Sci. Tech.* 2001 35: 2334-2340.

Blanchet, R., Liu, C., Bowers, T. Summary of Available Freshwater and Marine Sediment Quality Guidelines and Their Use in North America. Abstract accepted at SEATEC Conference, November, 2001

Blanchet, R., Liu, C., Bowers, T. Estimation of Average Exposure Point Concentrations for Pesticides Assuming Accumulation and

Degradation in the Environment. Abstract accepted at SEATEC Conference, November, 2001

Seeley, M.R., Schettler, S., Liu, C., Blanchet, R.J., Bowers, T.S. Assessing Cancer Risks Due to Use of Insecticides to Control the Mosquito-borne West Nile Virus: Use of the Margin of Exposure Approach. Abstract accepted at Society of Toxicology, 41st Annual Meeting, March 17-21, 2002.

Chunhua Liu, Jennifer Jay, Ravi Ika, Shine James, Timothy Ford. Capping Efficiency for Metal-Contaminated Marine Sediment under Conditions of Submarine Groundwater Discharge. Poster presentation at Conference on Dredged Material Management: Options and Environmental Considerations. December 3-6, 2000

Chunhua Liu, Jennifer Jay, Timothy Ford. Evaluation of Environmental Effects on Metal Transport from Capped Contaminated Sediment Under Conditions of Submarine Groundwater Discharge. Poster presentation at Conference on Dredged Material Management: Options and Environmental Considerations. December 3-6, 2000

Chunhua Liu, Jennifer Jay, Timothy Ford. Core analysis: Is it a good indicator of metal release and capping efficiency? Poster presentation at Conference on Dredged Material Management: Options and Environmental Considerations. December 3-6, 2000

Chunhua Liu. 2000. Capping Efficiency for Metal Contaminated Marine Sediment under Conditions of Submarine Groundwater Discharge. Doctoral Thesis. Harvard School of Public Health

Chunhua Liu, Ravi Ika, Tim Ford. 1998. Metal flux in near shore capping sites under conditions of submarine groundwater discharge. In: Fourth Marine & Estuarine Shallow Water Science & Management Conference. March 15-19, 1998

Wei Lin, Guowei Fu, Chunhua Liu. 1996. Study on allocating permissible pollutants discharge based on axioms system. *Chin. J. Environ. Sci.* 1996 17(3):35-37

Wei Lin, Chunhua Liu, Guowei Fu. 1995. Environmental conflict analysis and its application in environmental planning and management: siting of public facilities. *Chin. J. Environ. Sci.* 1995 16(6): 36-39

Chunhua Liu, Yongfeng Nie, Wei Lin. 1995. Application prospects of landfill gas utilization technique in China. *Pollution Control Technology* 1995 8(3): 143-145

Chunhua Liu. 1995. Evaluation of gas production from sanitary landfill. Master's thesis. Tsinghua University, Beijing, P.R.China

Wei Lin, Chunhua Liu. 1994. Rudimentary study on countermeasure to comprehensively control air pollution caused by motor vehicles in China. *Pollution Control Technology* 1994 7(4): 1-3

Xiurong Zhang, Chunhua Liu, Yanru Yang, Qingzhong Bai. 1993. Environmental impact report of wastewater treatment plant project



Chunhua Liu

Senior Technical Specialist

in Xuanhua City, China.

Chunhua Liu, Yongfeng Nie. 1993. Water balance evaluation in Hongmei hazardous waste landfill. In: Environmental Impact Assessment of Hongmei Hazardous Waste Landfill: 25-33

Chunhua Liu. 1992. Modeling landfill leachate production and migration. Bachelor Thesis. Tsinghua University, Beijing, P.R.China

Chunhua Liu. 1991. A discussion with the author of "clean water extraction from ocean water". Technology of Water Purification 1991(1): 39-41




Appendix C – Field Forms




Project:		Page 1 of 1		
Project No.:	Contractor:	Water Levels		
Surface Elevation:	Driller:	Date	Time	Depth*
Top of PVC Casing Elevation:	GZA Rep:			
Datum:	Date of Completion:			

Temporary Well Installation



* measurement is relative to the ground surface not the stickup.

 GZA GeoEnvironmental of New York Engineers and Scientists 104 West 29th St., 10th Fl. New York, NY 10001								Boring No. Sheet: File No.: Reviewed By:					
Logged By: Drilling Co. : Foreman						Geoprobe Location: Ground Surface Elevation (ft.): Final Geoprobe Depth (ft.): Date : Start Finish			Horizontal Datum: Vertical Datum:				
Type of Rig: Rig Model: Drilling Method:						Sampler Type: Sampler O.D. (in.): Sampler Length (in.) Rock Core Size			Groundwater Depth (ft.)				
									Date	Time	Water Depth	Stab. Time	
	Macro No.	Macro Depth (ft.)	Pen. (in.)	Rec. (in.)		Sample Description Modified Burmister Classification			Remark	Depth (ft.)	Stratum Description	Elevation (ft.)	
Field Screening performed with a photoionization detector (PID) with a 10.5 eV lamp span calibrated to 100 ppm via isobutylene gas. See Log key for exploration of sample description and identification procedures. Stratification lines represent approximate boundaries between soil types. Actual transition maybe gradual. Water level readings have been made at the times and under conditions stated. Fluctuations of groundwater may occur due to other factors than those present at the times the measurements were made.													Boring No.



SOIL VAPOR SAMPLE FIELD LOG

PROJECT NAME: _____ DATE : _____

LOCATION: _____ FILE NO.: _____

GZA Engineer: _____ Contractor/Lab: _____

Weather: _____ Analytical Method: _____ Depth to Water: _____

Operator: _____ Ground Elevation: _____

Barometric Pressure: _____ PID Calibration: _____ Water Elevation: _____

Sample ID	Canister No.	Regulator No.	Sample Depth (ft)	Vacuum Pressure (in.Hg)		Purge Time			Sample Date	Sample Time		PID Reading (ppm)	Container Type	Surface Cover	Driving Effort	Remark
				Start	End	Purge Start	Purge Stop	Elapsed Time		Start	End					

ABBREVIATIONS:

ft. - feet

in.Hg- Inches of mercury

l./min. - liters per minute

cu. Ft. - cubic feet

ppm - parts per million

NA - not applicable

CONTAINER TYPE	SURFACE COVER	PROBE DRIVING EFFORT	SOIL MOISTURE CONTENT
TB -Tedlar Bag	SO - Soil	E - Easy	D- Dry
SC- Suma Canister	GIL - Grass/Loam	M - Moderate	M- Moderate
ST- Sorbant Tube	Asph - Asphalt	D - Difficult	W - Wet
	Cncrt - Concrete	R - Rellisal	S - Saturated

REMARKS:

WELL PURGE DATA SHEET

WELL ID: MW-

CLIENT:
SITE:
WEATHER:

PROJECT NO:
DATE:
SAMPLER(S):

COLUMN OF WATER IN WELL:

T = Depth to Bottom (ft) - Static Water Level (ft)

$$\text{Water Column (T)} = \frac{\text{Pressure (psi)}}{2.31} - \frac{\text{Head (ft)}}{2.31}$$

TOTAL VOLUME PURGED:

Design = (gallons)

Actual = ¹ (gallons)

GALLONS OF WATER PER WELL VOLUME:

Well Volume = Water Column (T) (ft) x Multiplier

$$\text{Well Volume (V)} = \frac{\text{}}{\text{}} \times \frac{\text{}}{\text{}} \text{ (Gallons)}$$

well diameter	multiplier
1	0.041
1.5	0.092
2	0.163
4	0.653
6	1.469

PURGE RATE: Variable (mL / min)

PURGE METHOD: Peristaltic Pump, Low Flow Sampling

SCREENED INTERVAL: approximately to ft bgs

WATER QUALITY:[illegible]

UNITS:

gal. - gallons

ft. - feet

SU - standard units

ORP - Oxygen Reduction Potential

NOTES AND OBSERVATIONS:

mS/cm - millisiemens per centimeter

NTU -nephelometric turbidity units

mg/l -milligrams per liter

⁰C - degrees Celsius

bgs - below ground surface

NA - not applicable

1. Purged volume was estimated.



June 2024
55 Eckford Street, Brooklyn, NY
Remedial Investigation Work Plan
File No. 41.0163263.00

Appendix D – Health and Safety Plan

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

1. CLIENT/SITE/PROJECT INFORMATION

Client: 55 Eckford St LLC

Site Address: 55 Eckford Street, Brooklyn, NY

Site Description (be sure to list pertinent site features, chemicals used at the facility, and other potential hazard sources):
The property contains 6-story steel structure for an unfinished building and the property is surrounded by a construction fence.

Work Environment (active manufacturing, office, vacant site, undeveloped property, etc.):
Construction property

Job/Project #: 41.0163263.00

Field Start Date: TBD

Field Finish Date: TBD

Site is Covered by the Following Regulations:

OSHA HAZWOPER Standard ☒

Mine Safety and Health Administration ☐

OSHA Construction Regulations ☒

2. EMERGENCY INFORMATION

Hospital Name: NYC Health + Hospitals / Woodhull

Hospital Phone: 718-963-8000

Hospital Address: 706 Broadway, Brooklyn, NY

Directions and Street Map Attached: ☒ Yes

Local Fire #: 911

Local Ambulance #: 911

Local Police #: 911

WorkCare Incident Intervention Services:

For non-emergencies, if an employee becomes hurt or sick call 888-449-7787

Other Emergency Contact(s): Reinbill Maniquez

Phone #'s: 347-443-1059

Site-Specific Emergency Preparedness/Response Procedures/Concerns: See Site Access Safety Addendum (attached)



<p>LIFTING</p> <p>Get help lifting or carrying anything over 50 pounds</p>	<p>SITE RECON</p> <p>Walk your site before starting work to find and mark slips/trips/falls and insect nests</p>	<p>DRIVING</p> <p>Don't use your mobile phone while driving</p>	<p>ERGONOMICS</p> <p>Take a 5-minute break for every hour you work, whether it's in the office or the field</p>
<p>CUTS</p> <p>Wear cut-resistant gloves when using knives or other sharp objects</p>	<p>PPE</p> <p>At a minimum, always wear safety glasses and protective footwear in the field</p>	<p>HASP</p> <p>Develop a HASP and have it with you in the field</p>	<p>WORKCARE</p> <p>Without delay, call WorkCare immediately for any minor injury or illness at 888-449-7787</p>

- All EHS Events must be reported immediately to the Project Manager and to the GZA People-Based Safety mobile app.
- In the event of a chemical release greater than 5 gallons, site personnel will evacuate the affected area and relocate to an upwind location. The GZA Field Safety Officer and client site representative shall be contacted immediately.
- Site work shall not be conducted during severe weather, including high winds and lightning. In the event of severe weather, stop work, lower any equipment (drill rigs), and evacuate the affected area.

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

3. SCOPE OF WORK	
General project description, and phase(s) or work to which this H&S Plan applies.	Remedial Investigation, Field Sampling
Specific Tasks Performed by GZA:	Drilling Observation, soil sampling, groundwater sampling, soil vapor sampling, soil handling, and field logging
Concurrent Tasks to be Performed by GZA-hired Subcontractors (List Subcontractors by Name):	TBD Drillers - Drilling, soil sampling, groundwater sampling, soil vapor sampling, soil handling
Concurrent Tasks to be Performed by Others:	N/A

Any OSHA PERMIT-REQUIRED CONFINED SPACE entry? <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO IF YES, ADD CONFINED SPACE ENTRY PERMIT FOR THAT PORTION OF THE WORK	Any INDOOR fieldwork? <input type="checkbox"/> YES <input checked="" type="checkbox"/> NO IF YES, EXPLAIN:
---	---

4. SUB-SURFACE WORK, UNDERGROUND UTILITY LOCATION	
Will subsurface explorations be conducted as part of this work (drilling or excavation)?	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Will GZA personnel be required to use a hand-auger as part of this work?	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No
Site property ownership where underground explorations will be conducted on: 55 Eckford St LLC	Public Access Property <input type="checkbox"/> Yes <input checked="" type="checkbox"/> No Private Property <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No
Have Necessary Underground Utility Notifications for Subsurface Work Been Made?	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> Yet to be conducted
Specify Clearance Date & Time, Dig Safe Clearance I.D. #, And Other Relevant Information: GZA will review utility clearance with driller prior to field work.	
IMPORTANT! For subsurface work, prior to the initiation of ground penetrating activities, GZA personnel to assess whether the underground utility clearance (UUC) process has been completed in a manner that appears acceptable, based on participation/ confirmation by other responsible parties (utility companies, subcontractor, client, owner, etc.), for the following:	
Electric:	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA <input type="checkbox"/> Other _____
Fuel (gas, petroleum, steam):	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA <input type="checkbox"/> Other _____
Communication:	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA <input type="checkbox"/> Other _____
Water:	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA <input type="checkbox"/> Other _____
Sewer:	<input checked="" type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA <input type="checkbox"/> Other _____
Other: _____	<input type="checkbox"/> Yes <input type="checkbox"/> No <input type="checkbox"/> NA <input type="checkbox"/> Other _____
Comments: GZA to confirm mark outs prior to commencing work. Contractor to determine exact location of test boring.	

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

5. HAZARD ASSESSMENT (CHECK ALL THAT APPLY AND ADDRESS EACH HAZARD IN SECTION 6)

A. GENERAL FIELDWORK HAZARDS

<input type="checkbox"/> Confined Space Entry (Add Confined Space Entry Permit) <input checked="" type="checkbox"/> Abandoned or vacant building/Enclosed Spaces <input checked="" type="checkbox"/> Significant Slip/Trip/Fall Hazards <input type="checkbox"/> Unsanitary/Infectious Hazards <input type="checkbox"/> Poisonous Plants <input checked="" type="checkbox"/> Biting/Stinging Insects <input type="checkbox"/> Feral Animal Hazards <input type="checkbox"/> Water/Wetlands Hazards <input type="checkbox"/> Remote Locations/Navigation/Orientation hazards <input type="checkbox"/> Heavy Traffic or Work Alongside a Roadway <input checked="" type="checkbox"/> Weather-Related Hazards <input checked="" type="checkbox"/> Motor vehicle operation Hazards <input checked="" type="checkbox"/> Heavy Equipment Hazards <input checked="" type="checkbox"/> Structural Hazards (i.e. unsafe floors/stairways/roof) <input type="checkbox"/> Demolition/Renovation <input type="checkbox"/> Presence of Pedestrians or the General Public	<input checked="" type="checkbox"/> Overhead Hazards (i.e. falling objects, overhead power lines) <input checked="" type="checkbox"/> Portable Hand Tools or Power Tools <input checked="" type="checkbox"/> Significant Lifting or Ergonomic Hazards <input checked="" type="checkbox"/> Electrical Hazards (i.e. Equipment 120 Volts or Greater, Work Inside Electrical Panels, or Maintenance of Electrical Equipment) <input type="checkbox"/> Other Stored energy Hazards (i.e. Equipment with High Pressure or Stored Chemicals) <input type="checkbox"/> Fire and/or Explosion Hazard <input checked="" type="checkbox"/> Elevated Noise Levels <input checked="" type="checkbox"/> Excavations/Test Pits <input type="checkbox"/> Explosives or Unexploded Ordinance/MEC <input type="checkbox"/> Long Distance or Overnight Travel <input type="checkbox"/> Personal Security or High Crime Area Hazards <input type="checkbox"/> Working Alone <input type="checkbox"/> Ionizing Radiation or Non-Ionizing Radiation <input checked="" type="checkbox"/> Chemical/Exposure Hazards (See Part B for Details) <input checked="" type="checkbox"/> Other: COVID-19, Underground Utilities, Soil Handling
--	---

B. CHEMICAL/EXPOSURE HAZARDS (CONTAMINANTS ARE CONTAINED IN X SOIL, WATER, X GROUNDWATER)

<input type="checkbox"/> No chemical hazards anticipated <input type="checkbox"/> Hydrogen Sulfide (H ₂ S) <input type="checkbox"/> Cyanides, Hydrogen Cyanide (HCN) <input type="checkbox"/> Carbon Monoxide <input type="checkbox"/> Herbicides, Pesticide, Fungicide, Animal Poisons <input checked="" type="checkbox"/> Metals, Metal Compounds: <input type="checkbox"/> Corrosives, Acids, Caustics, Strong Irritants <input type="checkbox"/> Polychlorinated Biphenyls (PCBs) <input checked="" type="checkbox"/> Polycyclic Aromatic Hydrocarbons (PAHs) <input type="checkbox"/> Compressed Gases <input type="checkbox"/> Flammable/Combustible Liquids <input type="checkbox"/> Radiation Hazards (i.e. radioactive sealed/open source, x-rays, ultra violet, infrared, radio-frequency, etc.)	<input type="checkbox"/> Methane <input type="checkbox"/> Chemicals Subject to OSHA Hazard Communication (attach Safety Data Sheet for each chemical GZA brings to the site) <input type="checkbox"/> Containerized Waste, Chemicals in Piping & Process Equipment <input type="checkbox"/> Emissions from Gasoline-, Diesel-, Propane-fired Engine, Heater, Similar Equipment <input type="checkbox"/> General Work Site Airborne Dust Hazards <input checked="" type="checkbox"/> Volatile Organic Compounds (VOCs), BTEX <input checked="" type="checkbox"/> Chlorinated Organic Compounds <input checked="" type="checkbox"/> Fuel Oil, Gasoline, Petroleum Products, Waste Oil <input type="checkbox"/> Asbestos <input type="checkbox"/> Oxygen Deficiency, Asphyxiation Hazards <input checked="" type="checkbox"/> Other: Silica
--	--

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

6. SITE-SPECIFIC OVERVIEW OF H&S HAZARDS/MITIGATIONS (NOTE: Based on Hazard Assessment, Section 5)	
Describe the major hazards expected to be present at the jobsite, and describe the safety measures to be implemented for worker protection (refer to items checked in Section 5 above). Use brief abstract statements or more detailed narrative as may be appropriate.	
ON-SITE HAZARDS:	HAZARD MITIGATIONS:
Task Hazard Analyses	Task 21.1 – General Outdoor Field Work Task 4.1 – Drilling Observations Task 4.5 – Soil-Gas Sampling Task 20.11 – Field Sampling COVID-19
Owning Zero	Ensure all GZA personnel on-site have downloaded the People Based Safety app to their mobile phones and are familiar with using it to report safety events. Prior to work each day, review Owning Zero rules with all onsite personnel during morning safety meeting.
COVID-19	Check-in daily to the GZA COVID-19 app. Observe social distancing, i.e. stay 6 feet away from others where possible. If exhibiting any symptoms (cough, fever, prolonged shortness of breath), please stay home. Notify PM (Dharmil S. Patel 646-929-8908) for rescheduling site visits. Wash hands for 20 seconds after touching any shared equipment. The situation is rapidly developing, so keep up to date by checking guidelines from GZA's Pandemic Flu Response Team at: Notify PM for rescheduling site visits. See attached JHA and Follow Client specific work procedures related to Covid19 prevention if applicable
Abandoned or vacant building/Enclosed Spaces	Ask the client to validate that the building is structurally safe to enter. Constantly scan surroundings for integrity of floors and stairs and stay alert to debris on the ground or unsafe objects. Do not walk under ceilings or structures showing signs of distress and wear hard hats at all times within structures. Be alert for other people and / or animals in the building. Bring flashlights in case of poor lighting and a charged cell phone for communication. Inform your PM to let her/him know your anticipated hours of work on the site, and call them when you leave the site for the day. Leave the site if it is unsafe for any reason.
Biting and Stinging Insects	Ticks carry risk of Lyme and other Diseases. Tick season is basically any field day above 40 degrees F. Tuck pants into long socks and apply DEET (or permethrin pre-treatment) to clothing in season to control exposure to ticks. Check clothing for ticks frequently. Check whole body immediately upon returning from field and shower. Be aware of intermittent seasonal reports of mosquito borne diseases, such as West Nile disease and Eastern Equine Encephalitis (EEE), and their locations relative to your field site. Use DEET or other mosquito repellent. Be aware of potential cavity, suspended or ground nesting bee/wasp/hornet nests. Avoid undue disturbance or approach with appropriate safety clothing protection and netting. See attached Policy - GZA policy 03-3019 Lyme Disease.
Slip, Trips, and Falls	Inspect work area prior to starting work. Mark out or remove any potential hazards. Be aware and inspect area for uneven surface. Wear sturdy shoes with ankle support and good tread. Look for potential natural depressions/holes/or other obstructions in the area of work and travel. Personnel will be wearing appropriate boots with good tread to prevent slips and falls. Maintain one free hand to break falls. Provide adequate space for each employee to work safely with sound footing. Watch for equipment on ground and slippery surfaces. Keep work area clean, no running, be mindful of changing weather conditions that may change footing conditions. Store any hand tools used for sampling in their proper storage location when not in use. Do not perform work if adequate lighting is not available. Maintain an exit pathway away from the rig at all times.

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

Weather-Related Hazards	<p>Weather conditions will be assessed prior to on-site work and forecast examined for anticipated period of work. If weather permits fieldwork, then workers will dress appropriately. Should inclement weather be encountered, the project scope may be reduced or rescheduled. Breaks will be taken to reduce exposure to the elements. If conditions change and lightning or thunder is observed, work will be suspended immediately, and workers will seek shelter. Work may resume if thunder and/or lightning cease for 30 minutes. In the case of cold weather, proper warm gear should be worn to minimize cold exposure. Hand warmers (e.g. "Hot Hands") should be used when appropriate to keep extremities warm and multiple breaks within a warm area (vehicle with heat) should be taken. Review the signs of heat stress and dehydration before the start of fieldwork. Water, sunscreen, hardhat, tinted safety sunglasses, rain gear (if necessary) and periodic breaks should all be planned for. Be sure to consume plenty of liquids on hot summer days and stay out of direct sunlight for extended periods of time to the extent possible. Use protective ointments such as sunscreen and chap stick, and consult the OSHA Heat Safety App daily.</p>
Motor Vehicle Operation Hazard	<p>Check blind spots before backing up. Use a spotter when maneuvering vehicle in tight locations. Obey speed limits and wear seatbelts. No active hand-held or hands-free cell phone use while driving.</p>
Underground Utilities	<p>Confirm that underground utility clearance procedures have been completed in accordance with GZA Policy # 04-0301 Responsibility for Utility Clearance of Exploration Locations for clearing utility locations prior to breaking ground. Hand clear as necessary prior to commencement of drilling activities.</p>
Heavy Equipment Hazards	<p>All personnel working in proximity to heavy equipment will be familiarized with the locations and operations of emergency kill switches prior to equipment start-up. A first-aid kit and fire extinguisher (10 # Class B/C, minimum) will be available at all times. No loose clothing, jewelry, or unsecured long hair is permitted near the rig. Keep hands and feet away from all moving parts while drilling is in-progress. Persons shall not pass under or over a moving drill tools. Watch for moving vehicles and equipment. Stay out of equipment radius while drilling and excavation is in-progress. Maintain visibility and eye contact with operators when walking around trucks and excavators. Wear reflective vests to enhance visibility.</p> <p>Stay clear of drill rig or excavator (minimum of 6 feet) while operating and do not approach unless equipment has been stopped and eye contact/coordination is made with equipment operator for personnel to approach rig to make observations or collect samples. GZA personnel shall not climb onto or approach rig or excavator while operating or while drill rods are being attached or removed. GZA staff should verify that the onsite equipment has been routinely inspected. GZA staff should also maintain a safe working distance from the equipment while it is maneuvering around the site.</p> <p>GZA staff are not authorized to operate the drill rig or excavator, however, they should be familiar with the location and operation of the emergency shutoff in the event the main operator is unable to operate this control in the event of an emergency.</p> <p>Personnel are not allowed on a mast while drilling is in operation. While a drill rig or excavator is moved from one location to another, drill steel, tools, and other equipment shall be secured and the mast placed in a safe position. All borings and test pits will be adequately covered and/or barricaded if left unattended for any period of time to prevent injury.</p> <p>Working around heavy equipment, personnel shall be aware of pinch points, rotating equipment, and winch operated equipment. Maintain safe working distance and never walk underneath overhead projection of the equipment. Always maintain eye contact and communication with the operator. Follow GZA safe drilling and field work procedures.</p>
Struck by, caught by, run over by equipment	<p>Do not stand near or where equipment operators cannot see you. Always be in line of sight. Do not make sudden moves and always let the operator know of your intentions. Wear high-visibility safety vest, hard hat, eye protection, steel toe boots and use common sense and good housekeeping practices to avoid injury. Stay within sight of rig/excavator operator but at least 6-10 feet away from rig and excavator swing area. Maintain clear lines of communication (verbal and/or visual) with the operator. Stand clear of exhaust from operating equipment and stay out of the swing radius of heavy equipment. Be aware of overhead equipment and potential for falling objects (i.e. tree branches). Avoid any "pinch points" where one could become trapped between the equipment and other objects. Maintain awareness of general rig movement/operation and communication with drill crew. Do not conduct soil classification/sampling directly adjacent to the drill rig.</p> <p>Hearing protection shall be worn when working near operating equipment.</p>

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

	Equipment should be situated so that at full extension of bucket arm, the equipment is at least 10 feet away from overhead lines.																				
Overhead Hazards (i.e. Falling Objects, Overhead Power Lines)	Mechanical raising and falling weights and equipment are typical around drill rig. Stand clear of drill rig when possible. Observe proposed exploration locations for possible overhead utility lines/tree branches and avoid these if applicable. Check for overhead lines at each work location and between locations and keep equipment at least 25 feet from overhead utilities. Wear steel toed boots, hardhat and safety glasses/goggles. If stacked materials appear unstable inform the site representative. Be aware while equipment is advancing into soil / sediment. Do not stand directly in immediate vicinity of equipment in case equipment malfunction occurs. Maintain safe working distance and maintain eye contact and communication with operator. Never stand under elevated loads or equipment.																				
Significant Lifting or Ergonomic Hazards	Proper lifting techniques (lifting with the legs, carrying the load at a reasonable height to allow for proper posture during the carry, and avoiding twisting while carrying loads) should be followed at all times. Caution should be used when lifting equipment. Be aware of hand position during all stages of the lift, transport and placement of equipment. Review equipment to be moved prior to lifting to prevent moving parts from crushing fingers or otherwise pinching skin. Do not stack items prior to carrying, but rather transport one item at a time to prevent shifting during carrying. Follow GZA Safe Lifting SOP.																				
Elevated Noise Levels	<p>Always use ear protection when drill rig is in operation.</p> <p>In accordance with 29 CFR 1910.95(b)(1) When employees are subjected to sound exceeding those listed in Table G-16, feasible administrative or engineering controls shall be utilized. If such controls fail to reduce sound levels within the levels of Table G-16, personal protective equipment shall be provided and used to reduce sound levels within the levels of the table.</p> <p>TABLE G-16 - PERMISSIBLE NOISE EXPOSURES (1)</p> <table border="1"> <thead> <tr> <th>Duration per day (hours)</th><th>Sound level dBA slow response</th></tr> </thead> <tbody> <tr><td>8.....</td><td>90</td></tr> <tr><td>6.....</td><td>92</td></tr> <tr><td>4.....</td><td>95</td></tr> <tr><td>3.....</td><td>97</td></tr> <tr><td>2.....</td><td>100</td></tr> <tr><td>1 1/2</td><td>102</td></tr> <tr><td>1.....</td><td>105</td></tr> <tr><td>1/2</td><td>110</td></tr> <tr><td>1/4 or less.....</td><td>115</td></tr> </tbody> </table> <p>Hearing protection in the form of disposable ear plugs will be worn during field work with sound levels anticipated above those listed in Table G-16. Use sound meter app on phone to assess required PPE. Be aware that hearing protection can diminish warning sounds - do not stand with back to operating equipment and be alert for changing conditions.</p>	Duration per day (hours)	Sound level dBA slow response	8.....	90	6.....	92	4.....	95	3.....	97	2.....	100	1 1/2	102	1.....	105	1/2	110	1/4 or less.....	115
Duration per day (hours)	Sound level dBA slow response																				
8.....	90																				
6.....	92																				
4.....	95																				
3.....	97																				
2.....	100																				
1 1/2	102																				
1.....	105																				
1/2	110																				
1/4 or less.....	115																				
Soil Handling	Be aware that soil jars may have been broken during transport and properly cushion sample jars to prevent breakage. Do not eat, smoke or apply cosmetics (e.g. Chapstick, sunscreen) in the work area. Wear nitrile gloves during sampling to avoid common hazards associated with soil handling. Do not have skin contact with/ingest soils. Wash hands and face before eating or drinking.																				
Portable Hand Tools	Appropriate personal protective equipment (i.e.: safety glasses, face shield, safety goggles, gloves, etc.) shall be worn to protect from hazards that may be encountered while using portable power tools and hand tools																				
Silica Dust	Primary health effects of silica exposure include silicosis. Training will be provided to employees potentially exposed over the PEL for silica prior to them beginning work with silica, and will be updated on a regular basis. Depending on the levels of total and/or respirable dust in the employee's breathing zone, air monitoring will be performed for particulates. Ample ventilation will be provided to GZA workers.																				

7. AIR MONITORING ACTION LEVELS – Make sure air monitoring instruments are in working order, calibrated before use, and ‘bump-checked’ periodically throughout the day and/or over multiple days of use

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

Is air monitoring to be performed for this project? Yes <input checked="" type="checkbox"/> No <input type="checkbox"/>		
ACTION LEVELS FOR OXYGEN DEFICIENCY AND EXPLOSIVE ATMOSPHERIC HAZARDS (Action levels apply to occupied work space in general work area) <input type="checkbox"/> Applicable, See Below. <input checked="" type="checkbox"/> Not Applicable		
Parameter	Response Actions for Elevated Airborne Hazards	
Oxygen	At 19.5% or below – Exit area, provide adequate ventilation, or proceed to Level B, or discontinue activities Verify presence of adequate oxygen (approx. 12% or more) before taking readings with LEL meter. Note: If oxygen levels are below 12%, LEL meter readings are not valid.	
LEL	Less than 10% LEL – Continue working, continue to monitor LEL levels Greater than or Equal to 10% LEL – Discontinue work operations and immediately withdraw from area. Resume work activities ONLY after LEL readings have been reduced to less than 10% through passive dissipation, or through active vapor control measures.	
ACTION LEVELS FOR INHALATION OF TOXIC/HAZARDOUS SUBSTANCES (Action levels are for sustained breathing zone concentrations) <input checked="" type="checkbox"/> Applicable, See Below. <input type="checkbox"/> Not Applicable		
Air Quality Parameters (Check all that apply)	Remain in Level D or Modified D	Response Actions for Elevated Airborne Hazards
<input checked="" type="checkbox"/> VOCs	0 to 5 ppm	From 5 ppm to 10 ppm: Proceed to Level C, or Ventilate, or Discontinue Activities If greater than 5 ppm: Discontinue Activities and consult EHS Team
<input type="checkbox"/> Carbon Monoxide	0 to 35 ppm	At greater than 35 ppm, exit area, provide adequate ventilation, proceed to Level B, or discontinue activities.
<input type="checkbox"/> Hydrogen Sulfide	0 to 10 ppm	At greater than 10 ppm, exit area, provide adequate ventilation, proceed to Level B, or discontinue activities
<input checked="" type="checkbox"/> Dust	0 to 150 ug/m ³	If, after implementation of dust suppression techniques, downwind PM-10 particulate levels are greater than 150 ug/m ³ above the upwind level, work must be stopped and a re-evaluation of activities initiated. Work can resume provided that dust suppression measures and other controls are successful in reducing the downwind PM-10 particulate concentration to within 150 ug/m ³ of the upwind level and in preventing visible dust migration
<input type="checkbox"/>	0 to	
SPECIAL INSTRUCTIONS/COMMENTS REGARDING AIR MONITORING (IF APPLICABLE)		

8. HEALTH AND SAFETY EQUIPMENT AND CONTROLS

AIR MONITORING INSTRUMENTS

- ☒ PID Type: Lamp Energy: 10.6 eV
☐ FID Type:
☐ Carbon Monoxide Meter
☐ Hydrogen Sulfide Meter
☐ O₂/LEL Meter
☒ Particulate (Dust) Meter
☒ Calibration Gas Type - Isobutylene
☐ Others:

OTHER H&S EQUIPMENT & GEAR

PERSONAL PROTECTIVE EQUIPMENT

- ☐ Respirator – Type
☐ Respirator - Cartridge Type:
☒ Hardhat
☒ Outer Gloves Type: Nitrile
☒ Inner Gloves Type: nitrile
☒ Steel-toed boots/shoes
☐ Coveralls – Type
☐ Outer Boots – Type
☒ Eye Protection with side shields
☐ Face Shield

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

<input checked="" type="checkbox"/> Fire Extinguisher <input checked="" type="checkbox"/> Caution Tape <input checked="" type="checkbox"/> Traffic Cones or Stanchions <input type="checkbox"/> Warning Signs or Placards <input type="checkbox"/> Decon Buckets, Brushes, etc. <input type="checkbox"/> Portable Ground Fault Interrupter (GFI) <input type="checkbox"/> Lockout/Tagout Equipment <input type="checkbox"/> Ventilation Equipment <input checked="" type="checkbox"/> Others: First Aid Kit, Cell Phone, Water, Soap	<input checked="" type="checkbox"/> Traffic Vest <input type="checkbox"/> Personal Flotation Device (PFD) <input type="checkbox"/> Fire Retardant Clothing <input type="checkbox"/> EH (Electrical Hazard) Rated Boots, Gloves, etc. <input checked="" type="checkbox"/> Noise/Hearing Protection <input checked="" type="checkbox"/> Others: Face Covering (COVID—19) Discuss/Clarify, as Appropriate: face mask covering when social distancing cannot be readily practiced
--	--

9. H&S TRAINING/QUALIFICATIONS FOR FIELD PERSONNEL

- | | |
|--|---|
| <input checked="" type="checkbox"/> Project-Specific H&S Orientation (Required for All Projects/Staff)
<input checked="" type="checkbox"/> OSHA 40-Hour HAZWOPER/8 Hour Refreshers
<input type="checkbox"/> Hazard Communication (for project-specific chemical products)
<input checked="" type="checkbox"/> First Aid/CPR (required for HAZWOPER for at least one individual on site)
<input type="checkbox"/> Current Medical Clearance Letter (required for HAZWOPER)
<input checked="" type="checkbox"/> OSHA 10-hour Construction Safety Training
<input type="checkbox"/> Fall Protection Training
<input type="checkbox"/> Trenching & Excavation | <input type="checkbox"/> Lockout/Tagout Training
<input type="checkbox"/> Electrical Safety Training
<input type="checkbox"/> Bloodborne Pathogen Training
<input checked="" type="checkbox"/> Safe Drilling SOP
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/>
<input type="checkbox"/> |
|--|---|

Discuss/Clarify, as needed:

10. PERSONNEL AND EQUIPMENT DECONTAMINATION (SECTION ONLY REQUIRED FOR HAZWOPER SITES)

Describe personnel decontamination procedures for the project site, including "dry decon" (simple removal of PPE)	Dry Decon, wash hands and other exposed skin before taking breaks or leaving site. Change PPE before leaving site.
---	--

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

11. PROJECT PERSONNEL - ROLES AND RESPONSIBILITIES		
GZA ON-SITE PERSONNEL:		
Name(s)	Project Title/Assigned Role	Telephone Numbers
Reinbill Maniquez	Site Supervisor	Work: 212-594-8140 Cell: 347-443-1059
Jackson Bogach	Field Safety Officer	Work: 212-594-8140 Cell: 332-215-6349
Reinbill Maniquez	First Aid Personnel	Work: 212-594-8140 Cell: 332-215-6349
Jackson Bogach	GZA Project Team Members	Work: 212-594-8140 Cell: 332-215-6349
<p>Site Supervisors and Project Managers (SS/PM): Responsibility for compliance with GZA Health and Safety programs, policies, procedures and applicable laws and regulations is shared by all GZA management and supervisory personnel. This includes the need for effective oversight and supervision of project staff necessary to control the Health and Safety aspects of GZA on-site activities.</p> <p>Field Safety Officer (FSO): The FSO is responsible for implementation of the Site Specific Health and Safety Plan.</p> <p>First Aid Personnel: At least one individual designated by GZA who has current training and certification in basic first aid and cardiopulmonary resuscitation (CPR) must be present during on-site activities involving multiple GZA personnel at HAZWOPER sites.</p> <p>GZA Project Team: Follow instructions relayed by the HASP and GZA manager on-site.</p>		
OTHER PROJECT PERSONNEL:		
Name	Project Title/Assigned Role	Telephone Numbers
Victoria D. Whelan	Principal-in-Charge	Work: (212) 594-8140 Cell: (631) 793-8821
Reinbill Maniquez	Project Manager	Work: (212) 594-8140 Cell: (347) 443-1059
Reinbill Maniquez	Office Safety Coordinator	Work: (212) 594-8140 Cell: (347) 443-1059
Richard Ecord	GZA EHS Director	Work: 781-278-3809 Cell: 404-234-2834
<p>Principal-in-Charge: Responsible of overall project oversight, including responsibility for Health and Safety.</p> <p>Project Manager: Responsible for day-to-day project management, including Health and Safety.</p> <p>Health and Safety Coordinator: General Health and Safety guidance and assistance.</p> <p>GZA EHS Director: H & S technical and regulatory guidance, assistance regarding GZA H&S policies and procedures.</p>		

GZA SITE-SPECIFIC HEALTH, SAFETY & ACCIDENT PREVENTION STANDARD-PLAN

12. PLAN ACKNOWLEDGEMENT AND APPROVALS

GZA Project Site Worker Plan Acknowledgement

I have read, understood, and agree to abide by the information set forth in this Safety and Accident Prevention Plan. I will follow guidance in this plan and in the GZA Health and Safety Program Manual. I understand the training and medical monitoring requirements covered by the work outlined in this plan and have met those requirements.

GZA Employee Name	GZA Employee Signature	Date

Subcontractor Site Worker Plan Acknowledgement

GZA has prepared this plan solely for the purpose of protecting the health and safety of GZA employees. Subcontractors, visitors, and others at the site must refer to their organization's health and safety program or site-specific HASP for their protection. Subcontractor employees may use this plan for general informational purposes only. Subcontractor firms are obligated to comply with safety regulations applicable to their work, and understand this plan covers GZA activities only.

Subcontractor Employee Name	Subcontractor Employee Signatures	Date

GZA HASP Approval Signatures

The following individuals indicate their acknowledgement and/or approval of the contents of this Site Specific H&S Plan based on their understanding of project work activities, associated hazards and the appropriateness of health and safety measures to be implemented. A signed copy of this document must be present at the project site at all times work is being performed.

GZA Author/Reviewer Role	Signature	Date
Jackson Bogach HASP Preparer		05/21/2024
Todd Bown EHS Reviewer		5/21/2024
Stephen M. Kline Principal in Charge		5/24/2024



ATTACHMENTS

ATTACHMENT - A	HEALTH AND SAFETY BRIEFING/SITE ORIENTATION RECORD
ATTACHMENT - B	DIRECTIONS TO HOSPITAL
ATTACHMENT - C	JOB HAZARD ANALYSES
ATTACHMENT - D	ACCIDENT AND INJURY REPORT FORM
ATTACHMENT E	SAFETY ADDENDUM REQUIREMENTS



ATTACHMENT - A
HEALTH AND SAFETY BRIEFING



Health and Safety Briefing/Site Orientation Record/Hazard Communication

This is to verify that I, the undersigned, have been provided with a site (orientation) briefing, including hazard communication, regarding the safety and health considerations at the 1701 Purdy Street, Bronx, New York (Site). I agree to abide by my employer's Site-specific safety and health plan and other safety or health requirements applicable to the Site.

Name (Print)	Signature	Company	Date

Site (orientation) briefing conducted by: _____

Date: _____

Health and Safety Briefing/Site Orientation Record




**ATTACHMENT - B
ROUTE TO HOSPITAL**



55 Eckford St, Brooklyn, NY 11222 to NYC Health + Hospitals/Woodhull

Drive 1.9 miles, 19 min



Map data ©2024 Google 1000 ft

- via Leonard St

Best route, despite much heavier traffic than usual

19 min

1.9 miles
- via Leonard St and Humboldt St

Heavy traffic, as usual

19 min

2.0 miles
- via Graham Ave

Heavier traffic than usual

20 min

1.9 miles

[See details about NYC Health + Hospitals/Woodhull](#)

Explore nearby NYC Health + Hospitals/Woodhull

- Restaurants
- Hotels
- Gas stations
- Parking Lots
- More



ATTACHMENT - C
JOB HAZARD ANALYSES



GZA GEOENVIRONMENTAL, INC.

JOB HAZARD ANALYSIS WORKSHEET

Job: Drilling Observations, Monitoring Well Installation Observation and Soil Sampling

Analysis By: Andrew Whitsitt

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: October 2, 2011

Date: June 14, 2012

Date: June 26, 2012

Revised: June 14, 2012

Task 4.1

DRILLING OBSERVATIONS, MONITORING WELL INSTALLATION OBSERVATIONS, SOIL SAMPLING

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
Review Related THA's – 21.1 – General Outdoor Field Work		
Observation of Deploying of Traffic Protection Equipment by Drilling Contractor (e.g., cones, signs, etc.)	Personal injury due to vehicle traffic, Collisions, injuries	Wear high visibility vest at all times when out of vehicle.
		Park in designated parking locations or select off-road areas that are firm and free of hazards. Directly inspect parking location on foot if necessary.
		Use emergency flashers or other appropriate vehicle warning system as appropriate to local conditions when parking personal or GZA vehicle and/or equipment.
		If parking outside of a designated parking area, demarcate vehicle with traffic cones or equivalent.
		Use emergency flashers or other appropriate vehicle warning system when placing equipment.
		Observe if police detail or other required traffic control system (if necessary) is in place.
		Stay within the confines of the work area and do not venture outside of the demarcated work area into traffic.
		If you observe that contractor may back into structures, vehicles, fences, etc., notify contractor immediately with pre-determined signals. Do not cross the path of the heavy equipment.
Observation of Mobilizing Drill Rig To Job Site and positioning at borehole by Drilling Contractor	Struck by drill rig	Stand clear of moving Drill Rig.
		Before drilling begins, confirm that drill rig has been parked properly and securely by the drilling contractor.
		Wear high visibility vests. Make sure that the driver can see you and is aware of your location at all times.
		Inform the driller if it is observed that the rig is being moved with the mast raised and/or tools and other equipment on the rig are not secured and can fall over and potentially hurt personnel.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: Drilling Observations, Monitoring Well Installation Observation and Soil Sampling

Analysis By: Andrew Whitsitt

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: October 2, 2011

Date: June 14, 2012

Date: June 26, 2012

Revised: June 14, 2012

Task 4.1

DRILLING OBSERVATIONS, MONITORING WELL INSTALLATION OBSERVATIONS, SOIL SAMPLING

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
	Overhead utility	Look overhead to assess if any utilities are present and confirm with driller that they are aware of the overhead utility location and to take appropriate actions to prevent contact with the overhead utilities and to minimize any arc flash hazards. Review GZA's Electrical Safe Work Practices Program 03-3003.
Observation of drilling operations and monitoring well installations	Underground utilities	Confirm that underground utility clearance procedures have been completed in accordance with GZA Policy # 04-0301 <i>Responsibility for Utility Clearance of Exploration Locations</i> for clearing utility locations prior
	Moving machinery, rotating parts, cables, ropes, etc.	Do not wear loose fitting clothing.
		All GZA personnel working in proximity to a drill rig will be familiarized with the location and operation of emergency kill switches prior to equipment start-up. Maintain safe distance from rotating auger, drill casing, rods and cathead at all times. Observe operations from a safe distance. Persons shall not pass under or over a moving stem or auger Check that "kill" switches are present and working. Confirm with driller that daily inspection of rig has been performed prior to commencing work and no conditions were noted with the rig that would affect its proper operation.
		Do not touch or operate or assist with any rig operations and maintenance work.
		Make eye contact with operator before approaching equipment.
		Be alert and take proper precautions regarding slippery ground surfaces and similar hazards near rotating auger.
		Do not engage the driller or helper when drill is in operation. Work out prearranged signals to get their attention before approaching them.
		Confirm prior to drilling operations that driller and helper communicate and coordinate their actions and movements.
		GZA personnel are not allowed to be on the drill rig or operate a rig.



GZA GEOENVIRONMENTAL, INC.

JOB HAZARD ANALYSIS WORKSHEET

Job: Drilling Observations, Monitoring Well Installation Observation and Soil Sampling

Analysis By: Andrew Whitsitt

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: October 2, 2011

Date: June 14, 2012

Date: June 26, 2012

Revised: June 14, 2012

Task 4.1

DRILLING OBSERVATIONS, MONITORING WELL INSTALLATION OBSERVATIONS, SOIL SAMPLING

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Wear steel toed boots, hardhat and side-shielding safety glasses/goggles.
	Falling objects, debris	Stand clear of stacked drill rods. If stack appears unstable inform driller.
	Noise	Wear appropriate hearing protection.
	Roadway/traffic hazards	Be alert at all times; never step outside traffic cones.
		Wear high visibility vests at all times.
		Be familiar with escape routes at each location.
		Follow project Traffic Control Plan. Be alert at all times and never step outside the traffic cones.
		Use a Police detail when necessary.
	Slips, trips and falls	Maintain clean and sanitary work area free of tripping/slipping hazards.
		All borings, excavations, or partially completed groundwater monitoring wells will be adequately covered and/or barricaded if left unattended for any period of time to prevent injury.
		Store any hand tools used for sampling in their proper storage location when not in use.
		Provide adequate space for each employee to work safely with sound footing.
		Do not perform work if adequate lighting is not available.
	Cuts, bruises, shocks, lacerations, sprains and strains during tool use	Maintain an exit pathway away from the rig at all times.
		When working with a driller, do not assist the drilling crew with their work.
		Use properly maintained tools; do not use damaged tools.
		Wear the proper Personal Protective Equipment based on the task being performed.
		Store and carry tools correctly.
		Use the correct tool for the job.
		Do not use electrical tools with damaged cords or other electrical components.
		Observe proper electrical safety practices. Do not use electrical tools in wet areas.



GZA GEOENVIRONMENTAL, INC.

JOB HAZARD ANALYSIS WORKSHEET

Job: Drilling Observations, Monitoring Well Installation Observation and Soil Sampling

Analysis By: Andrew Whitsitt

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: October 2, 2011

Date: June 14, 2012

Date: June 26, 2012

Revised: June 14, 2012

Task 4.1

DRILLING OBSERVATIONS, MONITORING WELL INSTALLATION OBSERVATIONS, SOIL SAMPLING

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Coordinate activities with driller. Allow driller to open sampling equipment (i.e., split spoons, Geoprobe sleeves, etc.)
	Fire hazards	Be familiar with emergency procedures and where fire extinguishers are present on site.
		Inform GZA subcontractor if you observe improper storage of used rags and unsafe storage of flammable/combustible liquids brought on site.
		GZA and its subcontractors, suppliers and vendors shall not smoke in the work area in GZA project sites.
		Smoking can only be in designated smoking areas away from work areas and potential fire hazard locations.
		Confirm with driller that a fire extinguisher present with rig and will be available at all times and that inspection tag is not expired.
		If driller is welding or cutting on site confirm there are no flammables or combustible materials near the vicinity of welding machines or torches (such as debris, fuels, grass/weeds, etc.). Review Site requirements for obtaining "Hot Work Permit".
		Stand well clear of welding/cutting/burning areas.
		When drilling activities encounter the presence of gas or electric, the drill crew shall immediately curtail drilling activity, shut down the drill rig and contact the Project Manager.
	Exposure to Hazardous Substances/Chemicals	Become familiar with hazards associated with hazardous commercial products used in drilling (fuels, silica sand, grout, cement, bentonite, etc.). Review Safety Data Sheets (SDSs) for such products and participate in daily safety tailgate meetings.
		Do not handle drilling chemicals.
		Wear appropriate personal protective equipment.
		Review hazards of chemicals that may have been used or currently are being used on site.
		Refer to the site specific HASP for chemical hazards and the necessary precautions required for sampling.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: Drilling Observations, Monitoring Well Installation Observation and Soil Sampling

Analysis By: Andrew Whitsitt

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: October 2, 2011

Date: June 14, 2012

Date: June 26, 2012

Revised: June 14, 2012

Task 4.1

DRILLING OBSERVATIONS, MONITORING WELL INSTALLATION OBSERVATIONS, SOIL SAMPLING

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Be alert for hazardous site contaminants (as indicated by odor, visual characteristics, location, and site history). Assess whether procedures and contingencies are in place for characterizing hazards and protecting workers by use of appropriate air monitoring, personal protective clothing and respiratory protection, as needed. If contamination is identified at the Site only personnel trained and medically qualified to work on hazardous sites will be permitted to proceed with the work.
Sampling Soil	Exposure to chemicals	<p>Refer to the site specific HASP for chemical hazards and the necessary precautions required for sampling.</p> <p>Understand potential hazards associated with handling sample collection preservatives.</p> <p>Review and have SDS available for chemicals being brought on site, including that of sample preservatives.</p> <p>Wear appropriate PPE identified in the HASP</p> <p>Wash hands before eating and drinking. Eating and drinking are prohibited in areas of soil contamination/work area.</p>



GZA GEOENVIRONMENTAL, INC.

JOB HAZARD ANALYSIS WORKSHEET

Job: Soil-Gas Sampling

Analysis By: Joseph
DiAntonio

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: September 30, 2011
Revised: June 22, 2012

Date: June 22, 2012

Date: June 26, 2012

Task 4.5

Soil-Gas Sampling

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
Review Related THA's – 21.1 – General Outdoor Field Work		
Collection of Soil-Gas for Sampling	Exposure to Hazardous Substances	Become familiar with hazards through review of Task Hazard Analysis and participate in daily safety tailgate meetings. Communicate Task Hazard Analysis and Lessons Learned information to GZA field crew prior to initiating work and throughout the project as needed. Be alert for hazardous site contaminants (as indicated by odor, visual characteristics, location, and site history). Wear appropriate safety equipment as required by the Site Specific Health and Safety Plan (HASP) work area (hard hat, steel toe boots, work clothes, high visibility vest, eye and hearing protection, etc.). Implement work practices identified in the HASP. Be familiar with hazards associated with products used where samples will be collected and potential compounds of concern during the remedial investigation. Review and have Safety Data Sheets (SDSs) available on site for chemicals being used on site.
	Slips, Trips, and Falls	Become familiar with physical site specifics to reduce or eliminate slips, trips and falls due to uneven surfaces, onsite equipment, discarded materials, or working at height.
	Underground Utilities	Proper utility locations/clearance must be performed and the area checked for evidence of underground features prior to breaking ground. Review and comply with GZA Policy 04-0301 <i>Responsibility for Utility Clearance of Exploration Locations</i> .
	Electrical Conductor Hazards	Identify location of electrical conductors and maintain minimum approach distance of 25 feet.
	Poor visibility	Provide additional portable lighting if natural lighting is not adequate for performing the work safely.
	Manual Lifting, Equipment Handling	Use proper lifting techniques when lifting/moving objects or equipment to gain access into survey areas. Seek assistance with heavy loads. Use work gloves where appropriate to prevent hand injuries.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: Soil-Gas Sampling

**Analysis By: Joseph
DiAntonio**

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

**Date: September 30, 2011
Revised: June 22, 2012**

Date: June 22, 2012

Date: June 26, 2012

Task 4.5 Soil-Gas Sampling

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Wear steel-toed work shoes.
	Personnel Decontamination	All personnel, clothing, and equipment leaving the contaminated area of the site must be decontaminated to remove any harmful chemicals or properly disposed.
Sampling Near or In Roadways:	Personal Injury Due to Vehicular Traffic	Wear high visibility safety vest when out of vehicle and in areas with vehicular traffic.
		Park vehicle in designated parking locations, or select off-road area that is firm, and without hazards. Directly inspect parking location on foot if necessary.
		If parking outside of a designated parking area, demarcate vehicle with traffic cones or equivalent.
		Use emergency flashers or other appropriate vehicle warning system as appropriate to local conditions when parking vehicle.
		Use police detail (if necessary) to direct traffic while
Manual Installation of Sample Points	Cuts, Bruises, Shocks, Lacerations, Sprains and Strains	Observe proper electrical safety practices. Do not use electrical tools with damaged cords or other electrical components.
		Tools must be properly maintained; do not use damaged tools.
		Wear proper Personal Protective Equipment.
		Store and carry tools correctly.
		Use the correct tool for the job.
		Unplug tools or remove batteries when servicing or changing bit, blades, abrasive wheels or other components.
		Protect your "off hand" from gouges, hammer blows, cutting tools, etc. Position your "off hand" to prevent injury in case of slip of the tool.
Generator Use	Fire / Burn Hazards from Generator Used to Power Drill,	All flammable/combustible liquids must be stored in proper containers.
		A fire extinguisher (10 # class B/C, minimum) must be present on site.
		Generator must be placed on level, stable ground. Keep exhaust port/pipe away from potential flammable materials (i.e., dry brush, oily rags, etc).
		Use care when working around hot exhaust port/pipe.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: Soil-Gas Sampling

**Analysis By: Joseph
DiAntonio**

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

**Date: September 30, 2011
Revised: June 22, 2012**

Date: June 22, 2012

Date: June 26, 2012

Task 4.5 Soil-Gas Sampling

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		<p>If a fuel powered generator is being used take precautions to prevent carbon monoxide and other exhaust fume build up on the work area and other potential areas occupied by personnel.</p> <p>Vent outside of the work area away from other personnel/occupants. Where necessary have CO detector available to warn of hazardous concentrations.</p>



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: Field Sampling

Analysis By: Christie Wagner	Reviewed By: Jayanti Chatterjee, CIH	Approved By: Jayanti Chatterjee, CIH
Date: November 4, 2011 Revised: July 12, 2012	Date: July 12, 2012	Date: July 12, 2012

Task 20.11 Field Sampling

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
<u>Review Related THA's –</u> 21.1 General Outdoor Field Work		
Pre work task for site visit	Adverse Weather Conditions	Assess weather conditions prior to on-site work and examine forecast for anticipated period of work.
		Dress appropriately for weather conditions (e.g., precipitation, temperature ranges over anticipated duration of field work).
		Use protective ointments such as sunscreen and chap stick, as appropriate to the field conditions.
		Be aware of the anticipated weather conditions prior to mobilization to the site. Unacceptable field work conditions are not precise, but may include site specific conditions, general location, extreme weather conditions (e.g., icing, lightening, excessive cold or wind), travel conditions, and other factors. Professional judgment is required, and personal assessment of safety must always be individually assessed.
Conduct visual inspection of site	Dangerous Terrain	Be aware of the site terrain, watch for holes and rocks that can be tripping hazards
		Learn to identify and watch for plants such as thorn bushes and poison ivy that can either scratch you or give you a rash.
Collecting sample	Muscle strain from lifting heavy objects	Use proper lifting techniques. Use appropriate mechanical assistance and tools when possible. Wear work gloves and steel toed boots.
	Exposure to unknown sample	Be sure to treat effluent samples as unknowns and wear the proper PPE. If there are any unusual odors/fumes coming from a sample, especially those that cause reactions in the eyes or nose, leave the area and inform a supervisor immediately.



GZA GEOENVIRONMENTAL, INC.

JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

Analysis By: Anthony Zemba,
CHMM

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1

General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
Pre-work preparation	Overlooking of potential hazards	Become familiar with project area and job site by reviewing available on-line mapping (USGS Topographic, NWI Wetland, NRCS Soil, etc.; and aerial photographs before visiting site. Understand related hazards through review of this and other Task Hazard Analyses and participate in daily safety tailgate meetings (where applicable).
		Communicate Task Hazard Analysis and Lessons Learned information to operator(s) prior to initiating work and throughout the project as needed.
Driving to site	Vehicle accidents/collisions/injuries	Perform pre-operation check of vehicle, verifying service brakes, parking brake, steering, lights, tires, horn, wipers mirrors and glass are in good condition. verify that the rig is roadworthy.
		Wear seat belts always when driving even on site.
		Secure loose materials in cab or bed of vehicle.
		Keep windshields, windows and lights cleans.
Working within transportation corridors or active construction sites	Collisions injuries	Abide by safe driving procedures.
		If possible avoid backing by using a route that allows you to pull through.
		If backing up from a parked area do a quality 360 walker.
		Wear high visibility safety vest on site when out of personal or GZA vehicle.
		Park vehicle in designated parking locations, or select off-road area that is firm, and without hazards. Directly inspect parking location on foot if necessary.
		Use emergency flashers or other appropriate vehicle warning system as appropriate to local conditions when parking vehicle.
		Use emergency flashers or other appropriate vehicle warning system when parking outside of standard parking spaces, or to stop in right-of-
		Be alert at all times; never step outside traffic cones.



GZA GEOENVIRONMENTAL, INC.

JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

Analysis By: Anthony Zemba,
CHMM

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1

General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Stand clear of moving heavy equipment and away from any overhead utility lines until equipment is safely in position and parked properly and securely by the contractor.
		Do not wear headphones or earbuds, or listen to music or talk on the phone, which may distract from work hazards.
	Crossing Automobile traffic lanes	Wear high visibility safety vests at all times when out of vehicle and working within or adjacent to the roadway.
	Crossing Airport Movement Areas (e.g., Runways, taxiways, approaches)	Learn, know, and conform to project site Airport's, Airfield's, or Airbase's protocol for crossing movement areas (whether on foot or in vehicle).
		Work within airport movement areas or safety zones must be coordinated with the Air Traffic Control Tower.
		Vehicles to have blinking or flashing lights or beacons; pedestrians to wear high visibility safety vests.
		Using protocol, maintain communication with airport security and air traffic controllers.
	Crossing Railways	Work within active railroad ROWs requires railroad safety training. No work can be done within the railroad traffic envelope without the permission of a railroad flagman.
		No equipment or vehicles can cross without the permission of a railroad flagman.
		Expect any train on any track coming from either direction at any time.
Working in Natural or Remote Areas	Slips, trips, fall	Be aware of loose ground materials such as talus, unconsolidated rock, soil, sediment, ice and other media that could cause slips, trips or falls.
		Be careful when walking in heavily vegetated areas. Mind tangles of vines, thorny branches, and slippery logs and rock surfaces. Dense vegetation and especially entangled vines present trip hazards, or can mask voids, sharp objects, or other hazards beneath.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

Analysis By: Anthony Zemba,
CHMM

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1 General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Be vigilant for signs of cracking, shifting, fracturing, and evidence of past movement.
		Use wood mats or other stabilizing materials for equipment if soft ground conditions are present.
		Use walking stick, auger, or ski poles to steady yourself when traversing loose material or slopes.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

Analysis By: Anthony Zemba,
CHMM

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1 General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Wear proper footwear for conditions.
		Store tools in their proper storage location when not in use.
		Provide adequate lighting when necessary.
	Falls into excavations/ voids	Stand away from edges of excavations and voids. Do not attempt access without proper equipment / training. Remember that some excavations or voids may constitute a confined space and may present structural stability issues.
	Cave-ins and engulfment	DO NOT enter caves, sinkholes, excavations, and other voids or concavities that are not sloped or shored properly and have not been evaluated by a competent person to be safe.
		Stand away from edges of excavations, cliffs, dug wells, and other voids.
		Watch for cracks/fissures in the ground surface in the immediate vicinity of a pit or void, which indicate imminent sidewall failure/cave-in.
		Assess if confined space entry procedures need to be implemented.
		Before entering void (if required to do so and with proper training) be aware of any hazards at the surface (boulders, equipment) which may fall into the void.
	Working among hazardous biota	Plant toxins Incidental contact
Ticks		Ticks carry risk of Lyme's and other Diseases. Tick season is basically any field day above 40 degrees F.
		Tuck pants into long socks.
		The application of DEET (or permethrin pre-treatment) to clothing in season to control exposure to ticks is recommended.
		Check clothing for ticks frequently.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

**Analysis By: Anthony Zemba,
CHMM**

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1 General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Check whole body immediately upon returning from field and shower.
	Mosquitoes	Be aware of intermittent seasonal reports of mosquito borne diseases, such as West Nile disease and Eastern Equine Encephalitis (EEE), and their locations relative to your field site. Use of DEET or other mosquito repellent is recommended.
	Stinging bees and wasps	Be aware of potential cavity, suspended or ground nesting bee/wasp/hornet nests. Avoid undue disturbance or approach with appropriate safety clothing, protection and netting.
		Take appropriate precautions if allergic to bees. Carry at least two epi-pens in first aid kit as well as anti-histamines (oral and inhalers).
		Avoid areas of heavy bee activity if allergic. Avoid perfumed soaps, shampoos, deodorants, colognes, etc. that may attract bees.
	Poisonous Snakes	Be aware of terrain likelihood of harboring poisonous snakes in your work zone. Avoid reaching or stepping into hidden areas (such as into wood pile, rock pile, debris pile, stone wall, etc.) without pre-inspection.
		Coordinate with local hospitals to verify they have proper anti-venom in stock.
		Learn first aid procedures in case of poisonous snake bite.
		Devise an action plan and include in the site-specific HASP.
	Wild Animals	Do NOT handle wildlife unless properly trained to do so.
		Beware of any wild animal that shows no sign of wariness of humans.
		Do NOT attempt to feed wild animals or to help apparently injured wild animals.
		Be aware of domestic animals that may also pose a threat such as dogs off leash, bulls out to pasture, etc.



GZA GEOENVIRONMENTAL, INC.

JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

**Analysis By: Anthony Zemba,
CHMM**

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1

General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
Working in Adverse Weather Conditions	Heat / cold stress and other weather related hazards	<p>Assess weather conditions prior to on-site work and examine forecast for anticipated period of work.</p> <p>Dress appropriately for weather conditions (e.g., precipitation, temperature ranges over anticipated duration of field work). Include clothing and the presence / absence of shade when calculating a heat index.</p> <p>Schedule work day to avoid working during hottest or coldest parts of the day, to the extent practicable.</p> <p>Keep exposed skin covered in extremely cold weather.</p> <p>Recognize signs of frostbite; use warming packs and layer clothing to maintain warmth.</p> <p>Use a wicking layer of clothing against your body to keep moisture away from skin.</p> <p>Wool clothing will continue to keep you warm after it becomes wet; cotton will not.</p> <p>Use protective ointments such as sunscreen and chap stick, as appropriate to the field conditions.</p> <p>Stay hydrated in hot weather; drink fluids regularly throughout the day, even if not thirsty.</p> <p>Recognize signs of heat stress; take frequent breaks in shade when working in direct sunlight for prolonged periods.</p> <p>Be familiar with Heat index chart - add 20 degrees to chart if fully clothed and if working in direct sunlight.</p> <p>NOTE: Unacceptable field work conditions are not precise, but may include site specific conditions, general location, extreme weather conditions (e.g., icing, lightning, excessive cold or wind), travel conditions, and other factors. Professional judgment is required, and personal assessment of safety must always be individually assessed.</p>
	Working on Ice	Assess relative load bearing capacity of ice on lakes, ponds and other waterways. If unsure do not venture onto the ice.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

**Analysis By: Anthony Zemba,
CHMM**

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1 General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Wear proper footwear modified for traction on ice.
	Electrical storms	If lightning is observed during drilling activities, work shall be suspended immediately and employees shall find suitable shelter (building or vehicle at minimum). Work will commence no sooner than 30 minutes after the last indications of lightning have been observed
		Seek shelter inside a walled building or your vehicle.
		Open picnic pavilions and under trees are not adequate shelters.
		Assess vulnerability to lightning strikes as soon as thunder is heard on the horizon. Open areas and higher elevations are more susceptible to strikes.
		Tall objects such as metal towers and flag poles may attract lightning.
		Consult internet weather radar tracking devices to learn of impending storm patterns proximal to your work area.
	High Winds	Avoid working at high elevations, elevated platforms, and other exposed areas during high wind conditions.
		Assess work area for equipment that may be blown down, over, or carried aloft by high winds.
Working in areas without sanitary facilities	Hygiene related hazards	Provide hand washing kits (e.g., baby wipes, hand sanitizers, paper towels, bottled water, etc.) to be used prior to eating and drinking.
		Have garbage bags handy to collect trash.
Working in remote areas	Emergency Conditions	Be familiar with onsite emergency procedures and route to nearest hospital.
		Have a first aid kit available; know its contents and how to use them.
		Carry a cell phone during all field work for emergency purposes, and confirm the nearest location of cell phone signal on site prior to start of worksite.
	Disorientation	Plan your route and anticipated progress prior to field work.



GZA GEOENVIRONMENTAL, INC. JOB HAZARD ANALYSIS WORKSHEET

Job: General Outdoor Field Work

Analysis By: Anthony Zemba,
CHMM

Reviewed By: Guy Dalton

Approved By: Jayanti Chatterjee , CIH

Date: June 25, 2012

Date: June 25, 2012

Date: July 12, 2012

Task 21.1 General Outdoor Field Work

HAZARD CONTROLS

GZA Job Tasks	Potential Hazards	Controls
		Have multiple navigation aids (e.g., USGS Map, compass, GPS, etc.) and know how to use them before entering field. Remember to have charged batteries and battery back-ups for electronic devices.
		Share your progress plan with office staff prior to entering the field.
		Check in with office personnel periodically to update progress.
		Review and comply with GZA's Working Alone Policy 03-1009 in advance of working alone on a project site.
	Hunting	Be familiar with the various game hunting seasons. Follow rules and guidelines for remaining visible to hunters. Try to plan work around active hunting seasons or daily peak hunting hours as warranted.



ATTACHMENT - D
ACCIDENT AND INJURY REPORT FORM

SUPERVISOR'S ACCIDENT INVESTIGATION REPORT

Injured Employee _____ Job Title _____

Home Office _____ Division/Department _____

Date/Time of Accident _____

Location of Accident _____

Witnesses to the Accident _____

Injury Incurred? _____ Nature of Injury _____

Engaged in What Task When Injured? _____

Will Lost Time Occur? ____ How Long? _____ Date Lost Time Began _____

Were Other Persons Involved/Injured? _____

How Did the Accident Occur? _____

What Could Be Done to Prevent Recurrence of the Accident? _____

What Actions Have You Taken Thus Far to Prevent Recurrence? _____

Supervisor's Signature _____ Title _____ Date _____

Reviewer's Signature _____ Title _____ Date _____

Note: If the space provided on this form is insufficient, provide additional information on a separate page and attach. The completed accident investigation report must be submitted to the Health and Safety Manager within two days of the occurrence of the accident.



Appendix E – Community Air Monitoring Program (CAMP)



Known for excellence.
Built on trust.

GEOTECHNICAL
ENVIRONMENTAL
ECOLOGICAL
WATER
CONSTRUCTION
MANAGEMENT

GZA GeoEnvironmental of
New York
104 West 29th Street
10th Floor
New York, NY 10001
T: 212.594.8140
F: 212.279.8180
www.gza.com



Appendix E

New York State Department of Health

Generic Community Air Monitoring Plan

Overview

A Community Air Monitoring Plan (CAMP) requires real-time monitoring for volatile organic compounds (VOCs) and particulates (i.e., dust) at the downwind perimeter of each designated work area when certain activities are in progress at contaminated sites. The CAMP is not intended for use in establishing action levels for worker respiratory protection. Rather, its intent is to provide a measure of protection for the downwind community (i.e., off-site receptors including residences and businesses and on-site workers not directly involved with the subject work activities) from potential airborne contaminant releases as a direct result of investigative and remedial work activities. The action levels specified herein require increased monitoring, corrective actions to abate emissions, and/or work shutdown. Additionally, the CAMP helps to confirm that work activities did not spread contamination off-site through the air.

The generic CAMP presented below will be sufficient to cover many, if not most, sites. Specific requirements should be reviewed for each situation in consultation with NYSDOH to ensure proper applicability. In some cases, a separate site-specific CAMP or supplement may be required. Depending upon the nature of contamination, chemical-specific monitoring with appropriately-sensitive methods may be required. Depending upon the proximity of potentially exposed individuals, more stringent monitoring or response levels than those presented below may be required. Special requirements will be necessary for work within 20 feet of potentially exposed individuals or structures and for indoor work with co-located residences or facilities. These requirements should be determined in consultation with NYSDOH.

Reliance on the CAMP should not preclude simple, common-sense measures to keep VOCs, dust, and odors at a minimum around the work areas.

Community Air Monitoring Plan

Depending upon the nature of known or potential contaminants at each site, real-time air monitoring for VOCs and/or particulate levels at the perimeter of the exclusion zone or work area will be necessary. Most sites will involve VOC and particulate monitoring; sites known to be contaminated with heavy metals alone may only require



particulate monitoring. If radiological contamination is a concern, additional monitoring requirements may be necessary per consultation with appropriate DEC/NYSDOH staff.

Continuous monitoring will be required for all ground intrusive activities and during the demolition of contaminated or potentially contaminated structures. Ground intrusive activities include, but are not limited to, soil/waste excavation and handling, test pitting or trenching, and the installation of soil borings or monitoring wells.

Periodic monitoring for VOCs will be required during non-intrusive activities such as the collection of soil and sediment samples or the collection of groundwater samples from existing monitoring wells. A periodic monitoring during sample collection might reasonably consist of taking a reading upon arrival at a sample location, monitoring while opening a well cap or overturning soil, monitoring during well bailing/purging, and taking a reading prior to leaving a sample location. In some instances, depending upon the proximity of potentially exposed individuals, continuous monitoring may be required during sampling activities. Examples of such situations include groundwater sampling at wells on the curb of a busy urban street, in the midst of a public park, or adjacent to a school or residence.

VOC Monitoring, Response Levels, and Actions

Volatile organic compounds (VOCs) must be monitored at the downwind perimeter of the immediate work area (i.e., the exclusion zone) on a continuous basis or as otherwise specified. Upwind concentrations should be measured at the start of each workday and periodically thereafter to establish background conditions, particularly if wind direction changes. The monitoring work should be performed using equipment appropriate to measure the types of contaminants known or suspected to be present. The equipment should be calibrated at least daily for the contaminant(s) of concern or for an appropriate surrogate. The equipment should be capable of calculating 15-minute running average concentrations, which will be compared to the levels specified below.

1. If the ambient air concentration of total organic vapors at the downwind perimeter of the work area or exclusion zone exceeds 5 parts per million (ppm) above background for the 15-minute average, work activities must be temporarily halted and monitoring continued. If the total organic vapor level readily decreases (per instantaneous readings) below 5 ppm over background, work activities can resume with continued monitoring.
2. If total organic vapor levels at the downwind perimeter of the work area or exclusion zone persist at levels in excess of 5 ppm over background but less than 25 ppm, work activities must be halted, the source of vapors identified, corrective actions taken to abate emissions, and monitoring continued.



After these steps, work activities can resume provided that the total organic vapor level 200 feet downwind of the exclusion zone or half the distance to the nearest potential receptor or residential/commercial structure, whichever is less - but in no case less than 20 feet, is below 5 ppm over background for the 15-minute average.

3. If the organic vapor level is above 25 ppm at the perimeter of the work area, activities must be shutdown.
4. All 15-minute readings must be recorded and be available for State (DEC and NYSDOH) personnel to review. Instantaneous readings, if any, used for decision purposes should also be recorded.

Particulate Monitoring, Response Levels, and Actions

Particulate concentrations should be monitored continuously at the upwind and downwind perimeters of the exclusion zone at temporary particulate monitoring stations. The particulate monitoring should be performed using real-time monitoring equipment capable of measuring particulate matter less than 10 micrometers in size (PM-10) and capable of integrating over a period of 15 minutes (or less) for comparison to the airborne particulate action level. The equipment must be equipped with an audible alarm to indicate exceedance of the action level. In addition, fugitive dust migration should be visually assessed during all work activities.

1. If the downwind PM-10 particulate level is 100 micrograms per cubic meter (mcg/m³) greater than background (upwind perimeter) for the 15-minute period or if airborne dust is observed leaving the work area, then dust suppression techniques must be employed. Work may continue with dust suppression techniques provided that downwind PM-10 particulate levels do not exceed 150 mcg/m³ above the upwind level and provided that no visible dust is migrating from the work area.
2. If, after implementation of dust suppression techniques, downwind PM-10 particulate levels are greater than 150 mcg/m³ above the upwind level, work must be stopped and a re-evaluation of activities initiated. Work can resume provided that dust suppression measures and other controls are successful in reducing the downwind PM-10 particulate concentration to within 150 mcg/m³ of the upwind level and in preventing visible dust migration.
3. All readings must be recorded and be available for State (DEC and NYSDOH) and County Health personnel to review.



Appendix F – Personnel Qualifications



Victoria Whelan, PG, QEP

Associate Principal

Summary of Experience

Ms. Whelan is a Certified Professional Geologist and Qualified Environmental Professional with nearly 20 years of experience in environmental assessment. She has performed and managed field investigations and remedial activities at numerous sites on Long Island and throughout the Metro New York area. She has skillfully conducted all aspects of environmental investigations and remediation. Her primary focus is to accurately assess, investigate, remediate, and maintain environmental integrity for real estate transactions and the redevelopment of brownfield or similarly environmental impaired properties.

She manages all aspects of projects with the New York State Department of Environmental Conservation (NYSDEC) Brownfield (BCP) and Voluntary Cleanup Program (VCP), the New York City Office of Environmental Remediation (NYC OER), the New York City Department of Environmental Protection (NYCDEP) and the United States Environmental Protection Agency (USEPA).

Relevant Project Experience

NYCOER PROJECTS

Project Manager, Chester Street Brooklyn Supportive Housing Project, Brooklyn, New York. Managed all aspects of environmental project from due diligence investigation services, Phase I Environmental Site Assessment, and Phase II Environmental Site Investigation services to assisting client through NYCOER Voluntary Cleanup Program (VCP). Submitted and received approval for remedial investigation work plan, remedial investigation report, remedial action work plan, and construction health and safety plan, including a community air monitoring program. Managed removal of 12 buried aboveground storage tanks (ASTs). Managed waste characterization study to evaluate various soil types for disposal. Cost effectively utilized the NYC Clean Soil Bank as a disposal site and backfill source. Secured grant funding after receiving Notice of Satisfaction (NOS) for a Track 1 Cleanup.

Environmental Project Manager, Manhattan Avenue, Affordable Housing Project, Brooklyn, New York. Member of team that helped Ownership develop a new seven-story residential building on former factory site. Proposed development covered nearly 8,000 square feet of the property, including affordable housing with amenities such as a rear yard, recreation space, and children's play place. Site's contaminants included heavy metals and semi-volatile organic compounds. Hazardous and non-hazardous waste and non-hazardous was removed from the property as part of remediation efforts to address source material. Goal Soil Cleanup Objectives (SCOs) could not be achieved after remediation due to shallow groundwater. A track 4 Cleanup was achieved on this site by installing a composite cover inclusive of a vapor barrier. The project was completed on-time and on budget for the client to receive a NOS.

Project Manager, Bronx Community Development Project, Bronx, New York. Provided environmental services as client purchased, investigated, and remediated site for 81-unit community development, parking area and recreational area. The project is enrolled in NYC OER's VCP. Completed a Phase I ESA, VEA, Phase II ESI, RAWP and RAR.

Education

B.S., Geology, State University of New York at Oswego, 2001-2005; James Cook University 2004-2005

Licenses & Registrations

Registered Professional Geologist – 2017, New York, # 000318

Certified Professional Geologist, New York State

Qualified Environmental Professional, Institute of Professional Environmental Practice

Areas of Specialization

- Geology
- NYCOER VCP
- NYSBCP
- Environmental Assessments
- Environmental Site Investigation and Remediation
- UST Closures/Assessments
- Regulatory Compliance Planning and Permitting



Victoria Whelan, PG, QEP

Associate Principal

During remediation perimeter air monitoring was performed as per the CAMP. Designed oversaw removal of contaminated soil and installation of chemical vapor barrier during redevelopment.

NYSDEC BROWNFIELD PROJECTS

Principal-in-Charge, Former Auto Wreckers Site, Bronx, New York. Project is in the NYSDEC BCP with a planned Track 1 Cleanup. The site was successfully rezoned, and the proposed project will include 212 affordable housing apartments, 22,000 square feet (sf) of retail space, and parking. As remedial excavation was conducted it was quickly determined that the initial remedial plan would not satisfy the requirements for the project. As PIC, worked with the ownership, architect, accountant and construction team to steer the project towards new remedial goals without impacting project schedule. Remedial elements include a large-scale groundwater treatment system to address petroleum impacted groundwater and excavation of all source material ranging from depths of 2 to 15 feet below grade.

Environmental Project Manager, Confidential Residential Development, Bronx, New York. The 1.5-acre property was enrolled in the NYSDEC Brownfield Cleanup Program. Remedial components included excavation of soil exceeding the Site-specific Track 4 SCOs ranging from 2-22 feet, construction and maintenance of a composite cover system, removal of multiple underground storage tanks (USTs) and injection of Regenox and ORC Advanced (ISCO treatment) into the groundwater. Remediation also involved implementation of a CAMP. The site building was equipped with a vapor barrier and an active sub-slab depressurization system (SSDS). Throughout the process, assisted with design, maintaining a schedule and development of a Site Management Plan (SMP) and Final Engineering Report (FER).

Principal-in-Charge, Clay Street, NYCOER to NYSBCP Site, Brooklyn New York. Project consists of three parcels that share a property boundary and is in an area known to have heavy contamination. As the Principal-in-Charge, guided a team including ownership, developer and architect from the NYCOER VCP to the NYSDEC BCP based on contamination identified during the initial Remedial Investigation. Strategically conducted additional investigation to get multiple parts of the project eligible for the program and to maximize the tax credits available. Development will include a much-needed community facility in the way of a medical center, an indoor children's play center, and residential house.

USEPA PROJECTS

Project Manager, Remediation System, Confidential Client, Hicksville, New York. Managed this USEPA Superfund site for nearly 15 years through the operations and maintenance phase including a long-term groundwater treatment program, off-site soil vapor intrusion evaluations, and a large-scale groundwater sampling program. Contaminants of concern included PCBs and volatile organic compounds (VOCs). The site was complicated by multiple overlapping plumes of groundwater contamination. Collaborated with multiple property owners and their consultants to successfully drive the remediation.

NYS SPILLS PROJECTS

Project Manager, Spill Investigation and Remediation Services, Hempstead, New York. Performed a Phase I Environmental Site Assessment (ESA) that identified a gas station on the Site from 1940 through 1962, until redevelopment in the 1970s as a current commercial building. A subsequent Phase II Environmental Site Investigation (ESI) identified petroleum impacted soils, groundwater, and the presence of light non-aqueous phase liquids (LNAPL). A NYSDEC Spill Case was opened, and a Spill Investigation Work Plan was approved. Managed the spill investigation activities which included a work plan of Vacuum Enhanced Fluid Recovery (VEFR) events to evaluate feasibility of collecting residual petroleum contamination from beneath the Site building using VEFR. As part of long-term remedial plan, Monitored Natural Attenuation (MNA) and biodegradation to assess MNA is viable remedial strategy for the Site after the remediation of the LNAPL.

Certifications/Training

- 40-Hour OSHA HAZWOPER Training and 8-Hour Refreshers
- 10-Hour OSHA Construction Safety Course



Victoria Whelan, PG, QEP

Associate Principal

- First Aid/CPR Training
- LIRR Roadway Worker Training required by 49 CFR Part 214 Subpart C
- ARC Flash Training
- Confined Space Entry

Affiliations/Memberships

- Board Member - New York City Brownfield Partnership (NYCBP) 2022- present
- Committee Chair - Small Business Committee (NYCBP) 2022- present
- Member, New York State Council of Professional Geologists (NYSCPG)
- Member, American Council of Engineering Companies
- Member, Long Island Association of Professional Geologist

Honors & Awards

- Big Apple Brownfield Award - Hour Apartment House III
- Supportive Living Affordable Housing Award - Putnam Court
- Who's Who in Green Award - Atlantic Terrace



GZA GeoEnvironmental of New York